



Device Drivers, Features, and Commands on Red Hat Enterprise Linux 6.3



Device Drivers, Features, and Commands on Red Hat Enterprise Linux 6.3

Note

Before using this document, be sure to read the information in “Notices” on page 541.

This edition applies to Red Hat Enterprise Linux 6.3 and to all subsequent releases and modifications until otherwise indicated in new editions.

© **Copyright IBM Corporation 2000, 2012.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Summary of changes	v	Chapter 14. Writing z/VM monitor records	203
About this document	ix	Chapter 15. Reading z/VM monitor records	207
Part 1. General concepts	1	Chapter 16. z/VM recording device driver	213
Chapter 1. How devices are accessed by Linux	3	Chapter 17. z/VM unit record device driver	221
Chapter 2. Devices in sysfs	7	Chapter 18. z/VM DCSS device driver	223
Chapter 3. Kernel and module parameters	19	Chapter 19. Shared kernel support	233
Part 2. Storage	25	Chapter 20. Watchdog device driver	237
Chapter 4. DASD device driver	27	Chapter 21. z/VM CP interface device driver	241
Chapter 5. SCSI-over-Fibre Channel device driver	61	Chapter 22. Deliver z/VM CP special messages as uevents	243
Chapter 6. Channel-attached tape device driver	91	Chapter 23. AF_IUCV address family support	249
Chapter 7. XPRAM device driver	103	Chapter 24. Cooperative memory management.	253
Part 3. Networking	107	Part 5. System resources	255
Chapter 8. qeth device driver for OSA-Express (QDIO) and HiperSockets	109	Chapter 25. Managing CPUs	257
Chapter 9. OSA-Express SNMP subagent support	165	Chapter 26. Managing hotplug memory.	261
Chapter 10. LAN channel station device driver.	173	Chapter 27. Large page support	265
Chapter 11. CTCM device driver	179	Chapter 28. S/390 hypervisor file system	267
Part 4. z/VM virtual server integration	191	Chapter 29. ETR and STP based clock synchronization	273
Chapter 12. z/VM concepts	193	Chapter 30. Identifying the System z hardware	277
Chapter 13. Writing kernel APPLDATA records	197		

Part 6. Security	279	Chapter 40. Channel measurement facility	379
Chapter 31. Generic cryptographic device driver.	281	Chapter 41. Control program identification.	383
Chapter 32. Pseudo-random number device driver.	293	Chapter 42. Activating automatic problem reporting	387
Chapter 33. Data execution protection for user processes	295	Chapter 43. Avoiding common pitfalls	389
Part 7. Booting and shutdown. . .	297	Part 9. Reference	393
Chapter 34. Console device drivers	299	Chapter 44. Commands for Linux on System z	395
Chapter 35. Initial program loader for System z - zipl	321	Chapter 45. Selected kernel parameters	519
Chapter 36. Booting Linux	347	Chapter 46. Linux diagnose code use	537
Chapter 37. Suspending and resuming Linux	365	Accessibility.	539
Chapter 38. Shutdown actions	371	Notices	541
Part 8. Diagnostics and troubleshooting	375	Glossary	543
Chapter 39. Logging I/O subchannel status information	377	Bibliography.	547
		Index	551

Summary of changes

Updates for Red Hat Enterprise Linux 6.3

This edition contains changes related to release 6.3 of Red Hat Enterprise Linux.

New information

- DASD performance statistics are now available through a debugfs interface (see “Working with DASD statistics in debugfs” on page 48) and through a new command (see “dasdstat - Display DASD performance statistics” on page 426).
- Linux can now request hardware traces from the OSA adapters that are used by qeth devices. See “Capturing a hardware trace” on page 136.

Changed Information

- zipl now calculates a suitable default for the location of the initial RAM disk on a boot device, rather than using a fixed value of 0x800000, see “Preparing a boot device” on page 325.
- There is an additional shutdown trigger, restart. See Chapter 38, “Shutdown actions,” on page 371.
- The **qetharp** command now supports IPv6. See “qetharp - Query and purge OSA and HiperSockets ARP data” on page 490.
- The qethconf command now provides an option `list_msg` to list qeth messages and explanations, see “qethconf - Configure qeth devices” on page 492.

This revision also includes maintenance and editorial changes. Technical changes or additions to the text and illustrations are indicated by a vertical line to the left of the change.

Deleted Information

- None.

Updates for Red Hat Enterprise Linux 6.2

This edition contains changes related to release 6.2 of Red Hat Enterprise Linux.

New information

- You can now access full ECKD tracks. See “Accessing full ECKD tracks” on page 52.
- The AF_IUCV address family now supports addressing for real HiperSockets connections. See Chapter 23, “AF_IUCV address family support,” on page 249.
- New sysfs attributes show the machine name and network name of the System z mainframe where a Linux on System z instance runs. See Chapter 30, “Identifying the System z hardware,” on page 277.

Changed Information

- The defaults for rx-checksumming and for generic-receive-offload have changed from off to on. See “Configuring offload operations” on page 140.
- The **chreipl** command now supports device mapper multipath devices and NSSs as re-IPL devices. You can now also specify additional kernel parameters for re-IPL. See “chreipl - Modify the re-IPL configuration” on page 402.

- The `cpuplugd` daemon can now use additional data from `procfs` and an extended configuration file syntax to control the memory size and the number of available CPUs. See “`cpuplugd` - Control CPUs and memory” on page 415.

This revision also includes maintenance and editorial changes. Technical changes or additions to the text and illustrations are indicated by a vertical line to the left of the change.

Deleted Information

- “Starting and stopping collection of QDIO performance statistics” has become obsolete and has been removed.

Updates for Red Hat Enterprise Linux 6.1

This edition contains changes related to release 6.1 of Red Hat Enterprise Linux.

New information

- You can now set the timeout for DASD I/O requests. See “Setting the timeout for I/O requests” on page 47.
- You can now set a policy for handling DASD for which a reservation is lost to another system. See “Handling lost device reservations” on page 54.
- A new device driver sends and receives z/VM CP special messages (SMSG) as uevents in user space. See Chapter 22, “Deliver z/VM CP special messages as uevents,” on page 243.
- You can now obtain additional cache hierarchy information from `sysfs`. See “Examining the CPU topology” on page 258.
- A new program, `ttyrun`, can be used when enabling user logins on terminals. The new program prevents respawns through the `init` program if a terminal is not available. See “Preventing respawns for non-operational terminals” on page 310.
- You can now log I/O subchannel status information. See Chapter 39, “Logging I/O subchannel status information,” on page 377 and “Logging I/O subchannel status information” on page 86.
- With the new commands `lsmem` and `chmem` you can manage memory. See “`chmem` - Set memory online or offline” on page 400 and “`lsmem` - Show online status information about memory blocks” on page 465.
- With a new command, `cmsfs-fuse`, you can mount a CMS file system from a z/VM minidisk on the Linux file system and control which file types are subject to automatic translation when mounting a CMS file system. See “`cmsfs-fuse` - Mount a z/VM CMS file system” on page 410.
- A new command, `hyptop`, provides a real-time view of the System z hypervisor environment including CPU and memory consumption. See “`hyptop` - Display hypervisor performance data” on page 446.

Changed Information

- The DASD device driver can now handle multi-track extensions, see “Features” on page 27.
- The HBA API has been completed to include functions for CT passthrough and event handling, see “API provided by the `zfc` HBA API support” on page 87
- The OSA adapter now supports checksum calculations and thereby offloads the host processor. See “Turning outbound checksum calculations on and off” on page 141

- The qeth device driver for OSA-Express (QDIO) and HiperSockets can now handle tagged frames with VLAN ID 0. See “Scenario: Virtual LAN (VLAN) support” on page 152.
- “Potential problems after resuming a Linux instance” has been replaced with two new sections, “Handling of devices that are unavailable when resuming” on page 366 and “Handling of devices that become available at a different subchannel” on page 367.
- The CPU topology support is now enabled by default, see “Examining the CPU topology” on page 258.
- You can now use the **tunedasd** command to check the reservation status of ECKD DASD. See “tunedasd - Adjust DASD performance” on page 504.

This revision also includes maintenance and editorial changes. Technical changes or additions to the text and illustrations are indicated by a vertical line to the left of the change.

Deleted Information

- None.

About this document

This document describes the device drivers, features, and commands available to Red Hat Enterprise Linux 6.3 for the control of IBM® System z® devices and attachments. Unless stated otherwise, in this book the terms *device drivers* and *features* are understood to refer to device drivers and features for Red Hat Enterprise Linux 6.3 for System z.

Unless stated otherwise, all z/VM® related information in this document assumes a current z/VM version, see www.ibm.com/vm/techinfo.

In this document, System z is taken to include all IBM mainframe systems supported by Red Hat Enterprise Linux 6.3 for System z. In particular, this includes IBM zEnterprise™ 196 (z196) and IBM zEnterprise 114 (z114) mainframes.

For what is new, known issues, and frequently asked questions, see the Red Hat Enterprise Linux 6.3 release notes at

http://docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux/

Making changes persistent

This document describes how to change settings and options for mainframe computers in sysfs. In most cases, changes in sysfs are not persistent. If you need to make your changes persistent, see *Red Hat Enterprise Linux 6.3 Deployment Guide* for details about the configuration files to use.

This document describes how to load modules with **modprobe**. Loading a module this way is not persistent across re-boots. If you want to load your kernel modules automatically at boot time, see the section on persistent module loading in *Red Hat Enterprise Linux 6.3 Deployment Guide*.

You can find the latest versions of these documents that have been tailored to Red Hat Enterprise Linux 6.3 on

www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

- *Device Drivers, Features, and Commands on Red Hat Enterprise Linux 6.3*, SC34-2597
- *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607

For each of the following documents, the same web page points to the version that most closely reflects Red Hat Enterprise Linux 6.3:

- *How to Improve Performance with PAV*
- *How to use FC-attached SCSI devices with Linux on System z*
- *How to use Execute-in-Place Technology with Linux on z/VM*
- *How to Set up a Terminal Server Environment on z/VM*
- *libica Programmer's Reference*

How this document is organized

The first part of this document contains general and overview information for the System z device drivers for Red Hat Enterprise Linux 6.3 for System z.

Part two contains chapters specific to individual storage device drivers.

Part three contains chapters specific to individual network device drivers.

Part four contains chapters that describe device drivers and features in support of z/VM virtual server integration.

Part five contains chapters about device drivers and features that help to manage the resources of the real or virtual hardware.

Part six contains chapters about device drivers and features that support security aspects of Red Hat Enterprise Linux 6.3 for System z.

Part seven contains chapters about device drivers and features that are used in the context of booting and shutting down Linux.

Part eight contains chapters about device drivers and features that are used in the context of diagnostics and problem solving.

Part nine contains chapters with reference information about commands, kernel parameters, and Linux use of z/VM DIAG calls.

Who should read this document

Most of the information in this document is intended for system administrators who want to configure Red Hat Enterprise Linux 6.3 for System z.



Some sections are of interest primarily to specialists who want to program extensions to the System z device drivers and features for Red Hat Enterprise Linux 6.3. These sections are marked with the same icon on the left margin as this paragraph.

The following general assumptions are made about your background knowledge:

- You have an understanding of basic computer architecture, operating systems, and programs.
- You have an understanding of Linux and System z terminology.
- You are familiar with Linux device driver software.
- You are familiar with the System z devices attached to your system.

Authority:

Most of the tasks described in this document require a user with root authority. In particular, writing to procfs, and writing to most of the described sysfs attributes requires root authority.

Throughout this document, it is assumed that you have root authority.

Conventions used in this book

This section summarizes the styles, highlighting, and assumptions used throughout the book.

Terminology

In this document, the term *booting* is used for running boot loader code that loads the Linux operating system. *IPL* is used for issuing an IPL command, to load boot loader code, a stand-alone dump utility, or a DCSS. See also “IPL and booting” on page 347.

sysfs and procfs

In this document, the mount point for the virtual Linux file system sysfs is assumed to be /sys. Correspondingly, the mount point for procfs is assumed to be /proc.

debugfs

This document assumes that debugfs has been mounted at /sys/kernel/debug.

To mount debugfs, you can use this command:

```
# mount none -t debugfs /sys/kernel/debug
```

To mount debugfs persistently, add the following to /etc/fstab:

```
debugfs /sys/kernel/debug debugfs auto 0 0
```

Documentation directory

This document sometimes refers to files in the Documentation directory in the Linux source tree. On Red Hat Enterprise Linux 6.3 the full path to this directory is:

```
/usr/share/doc/kernel-doc-<version>/Documentation
```

If this directory is not present, install the kernel-doc.noarch RPM.

Number prefixes

In this publication, the meaning of number prefixes depends on the context.

When referring to processor storage, real and virtual storage, or channel volume, KB means 1024 bytes, MB means 1,048,576 bytes, and GB means 1,073,741,824 bytes.

When referring to hard disk drive capacity or communications volume, MB means 1,000,000 bytes, and GB means 1,000,000,000 bytes. Total user-accessible capacity can vary depending on the operating environment.

Hexadecimal numbers

Mainframe documents and Linux documents tend to use different styles for writing hexadecimal numbers. Thirty-one, for example, would typically read X'1F' in a mainframe book and 0x1f in a Linux book.

Because the Linux style is required in many commands and is also used in some code samples, the Linux style is used throughout this book.

Highlighting

This document uses the following highlighting styles:

- Paths and URLs are highlighted in monospace.
- Variables are highlighted in *<italics within angled brackets>*.
- Commands in text are highlighted in **bold**.
- Input and output as normally seen on a computer screen is shown

within a screen frame.
Prompts are shown as hash signs:
#

Understanding syntax diagrams

This section describes how to read the syntax diagrams in this manual.

To read a syntax diagram follow the path of the line. Read from left to right and top to bottom.

- The ►— symbol indicates the beginning of a syntax diagram.
- The —► symbol, at the end of a line, indicates that the syntax diagram continues on the next line.
- The ►— symbol, at the beginning of a line, indicates that a syntax diagram continues from the previous line.
- The —►◄ symbol indicates the end of a syntax diagram.

Syntax items (for example, a keyword or variable) may be:

- Directly on the line (required)
- Above the line (default).
- Below the line (optional)

If defaults are determined by your system status or settings, they are not shown in the diagram. Instead the rule is described together with the option, keyword, or variable in the list following the diagram.

Case sensitivity

Unless otherwise noted, entries are case sensitive.

Symbols

You **must** code these symbols exactly as they appear in the syntax diagram

*	Asterisk
:	Colon
,	Comma
=	Equal sign
-	Hyphen
//	Double slash
()	Parentheses
.	Period
+	Add

\$ Dollar sign

For example:

dasd=0.0.7000-0.0.7fff

Variables

An *italicized* lowercase word indicates a variable that you must substitute with specific information. For example:

►► — -p <interface> ————— ►►

Here you must code -p as shown and supply a value for <interface>. An italicized uppercase word indicates a variable that must appear in uppercase:

►► — vmhalt=<COMMAND> ————— ►►

Repetition

An arrow returning to the left means that the item can be repeated.

►► —> <repeat> ————— ►►

A character within the arrow means you must separate repeated items with that character.

►► —> , <repeat> ————— ►►

Defaults

Defaults are above the line. The system uses the default unless you override it. You can override the default by coding an option from the stack below the line. For example:

►► — A ————— ►►
| B
| C

In this example, A is the default. You can override A by choosing B or C.

Required Choices

When two or more items are in a stack and one of them is on the line, you **must** specify one item. For example:

►► — A ————— ►►
| B
| C

Here you must enter either A or B or C.

Optional Choice

When an item is below the line, the item is optional. Only one item **may** be chosen. For example:

A
B
C

Here you may enter either A or B or C, or you may omit the field.

Finding IBM books

You can locate the latest versions of the referenced IBM books through the IBM Publications Center at:

www.ibm.com/shop/publications/order

Part 1. General concepts

This part provides information at an overview level and describes concepts that apply across different device drivers and kernel features.

Newest version: You can find the newest version of this book at www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

Restrictions: For prerequisites and restrictions see the System z architecture specific information in the Red Hat Enterprise Linux 6.3 release notes at docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

Chapter 1. How devices are accessed by Linux. . . 3

Device name, device nodes, and major/minor numbers. 3
Network interfaces 4

Chapter 2. Devices in sysfs. 7

Device categories 7
Device directories. 9
Device views in sysfs 10
Channel path measurement 13
Channel path ID information 14
CCW hotplug events 16

Chapter 3. Kernel and module parameters . . . 19

Specifying kernel parameters 19
Specifying module parameters 24

Chapter 1. How devices are accessed by Linux

Applications on Linux access character and block devices through device nodes, and network devices through network interfaces.

Device name, device nodes, and major/minor numbers

The Linux kernel represents the character and block devices it knows as a pair of numbers `<major>:<minor>`.

Some major numbers are reserved for particular device drivers, others are dynamically assigned to a device driver when Linux boots. For example, major number 94 is always the major number for DASD devices while the device driver for channel-attached tape devices has no fixed major number. A major number can also be shared by multiple device drivers. See `/proc/devices` to find out how major numbers have been assigned on a running Linux instance.

The device driver uses the minor number `<minor>` to distinguish individual physical or logical devices. For example, the DASD device driver assigns four minor numbers to each DASD: one to the DASD as a whole and the other three for up to three partitions.

Device drivers assign device names to their devices, according to a device driver-specific naming scheme (see, for example, “DASD naming scheme” on page 33). Each device name is associated with a minor number (see Figure 1).




Figure 1. Minor numbers and device names

User space programs access character and block devices through *device nodes* also referred to as *device special files*. When a device node is created, it is associated with a major and minor number (see Figure 2).




Figure 2. Device nodes

Red Hat Enterprise Linux 6.3 uses udev to create device nodes for you. There is always a device node that matches the device name used by the kernel and additional nodes might be created by special udev rules. See the udev man page for more details.

Network interfaces

The Linux kernel representation of a network device is an interface.




Figure 3. Interfaces

When a network device is defined, it is associated with a real or virtual network adapter (see Figure 3). You can configure the adapter properties for a particular network device through the device representation in sysfs (see “Device directories” on page 9).

You activate or deactivate a connection by addressing the interface with **ip** or an equivalent command. All interfaces that are provided by the network device drivers described in this book are interfaces for the Internet Protocol (IP).

Interface names

The interface names are assigned by the Linux network stack.

Interface names are of the form `<base_name><n>` where `<base_name>` is a base name used for a particular interface type and `<n>` is an index number that identifies an individual interface of a given type.

Table 1 summarizes the base names used for the network device drivers for interfaces that are associated with real hardware:

Table 1. Interface base names for real devices

Base name	Interface type	Device driver module	Hardware
eth	Ethernet	qeth, lcs	OSA-Express, OSA-Express2, OSA-Express3
osn	ESCON/CDLC bridge	qeth	OSA-Express2, OSA-Express3
ctc	Channel-to-Channel	ctcm	ESCON® channel card, FICON® channel card
mpc	Channel-to-Channel	ctcm	ESCON channel card

Table 2 summarizes the base names used for the network device drivers for interfaces that are associated with virtual hardware:

Table 2. Interface base names for virtual devices

Base name	Interface type	Device driver module	Comment
hsi	HiperSockets™, Guest LAN	qeth	Real HiperSockets or HiperSockets guest LAN
eth	Guest LAN	qeth	QDIO guest LAN or virtual switch
ctc	virtual Channel-to-Channel	ctcm	virtual CTCA
mpc	virtual Channel-to-Channel	ctcm	virtual CTCA

When the first device for a particular interface name is set online, it is assigned the index number 0, the second is assigned 1, the third 2, and so on. For example, the first HiperSockets interface is named hsi0, the second hsi1, the third hsi2, and so on.

When a network device is set offline, it retains its interface name. When a device is removed, it surrenders its interface name and the name can be reassigned as network devices are defined in the future. When an interface is defined, the Linux kernel always assigns the interface name with the lowest free index number for the particular type. For example, if the network device with an associated interface name hsi1 is removed while the devices for hsi0 and hsi2 are retained, the next HiperSockets interface to be defined becomes hsi1.

Matching devices with the corresponding interfaces

If you define multiple interfaces on a Linux instance, you need to keep track of the interface names assigned to your network devices.

Red Hat Enterprise Linux 6.3 uses udev to track the network interface name and preserves the mapping of interface names to network devices across IPLs.

How you can keep track of the mapping yourself differs depending on the network device driver. For qeth, you can use the **lsqeth** command (see “lsqeth - List qeth-based network devices” on page 467) to obtain a mapping.

After setting a device online, read /var/log/messages or issue **dmesg** to find the associated interface name in the messages that are issued in response to the device being set online.

For each network device that is online, there is a symbolic link of the form /sys/class/net/<interface>/device where <interface> is the interface name. This link points to a sysfs directory that represents the corresponding network device. You can read this symbolic link with **readlink** to confirm that an interface name corresponds to a particular network device.

“Device views in sysfs” on page 10 tells you where you can find the device directories with their attributes in sysfs.

Main steps for setting up a network interface

The main steps apply to all Linux on System z network devices drivers.

The main steps are:

1. Define a network device.

The device driver creates directories that represent the device in sysfs.

Tip: Use the **znetconf** command to perform this step. See “znetconf - List and configure network devices” on page 516.

2. Configure the device through its attributes in sysfs (see “Device views in sysfs” on page 10).

For some devices, there are attributes that can or need to be set later when the device is online or when the connection is active.

3. Set the device online.

This makes the device known to the Linux network stack and associates the device with an interface name. For devices that are associated with a physical network adapter it also initializes the adapter for the network interface.

4. Configure and activate the interface.

This adds interface properties like IP addresses, MTU, and netmasks to a network interface and makes the network interface available to user space programs.

How to perform a particular step can be different for the different device drivers.

Chapter 2. Devices in sysfs

Most of the device drivers create structures in sysfs. These structures hold information about individual devices and are also used to configure and control the devices.

This section provides an overview of these structures and of two of the categories into which the Linux on System z device drivers and devices are grouped in sysfs.

Device categories

There are several Linux on System z specific device categories in the `/sys/devices` directory.

Figure 4 illustrates a part of sysfs.




Figure 4. *sysfs*

`/sys/bus` and `/sys/devices` are common Linux directories. The directories following `/sys/bus` sort the device drivers according to the categories of devices they control. There are several categories of devices. The `sysfs` branch for a particular category might be missing if there is no device for that category.

AP devices

are adjunct processors used for cryptographic operations.

CCW devices

are devices that can be addressed with channel-command words (CCWs). These devices use a single subchannel on the mainframe's channel subsystem.

CCW group devices

are devices that use multiple subchannels on the mainframe's channel subsystem.

IUCV devices

are devices for virtual connections between z/VM guest virtual machines within an IBM mainframe. IUCV devices do not use the channel subsystem.

Table 3 lists the device drivers that have representation in sysfs:

Table 3. Device drivers with representation in sysfs

Device driver	Category	sysfs directories
3215 console	CCW	/sys/bus/ccw/drivers/3215
3270 console	CCW	/sys/bus/ccw/drivers/3270
DASD	CCW	/sys/bus/ccw/drivers/dasd-eckd /sys/bus/ccw/drivers/dasd-fba
SCSI-over-Fibre Channel	CCW	/sys/bus/ccw/drivers/zfcp
Tape	CCW	/sys/bus/ccw/drivers/tape_34xx /sys/bus/ccw/drivers/tape_3590
Cryptographic	AP	/sys/bus/ap/drivers/cex2a /sys/bus/ap/drivers/cex2c
DCSS	n/a	/sys/devices/dcssblk
XPRAM	n/a	/sys/devices/system/xpram
z/VM recording device driver	IUCV	/sys/bus/iucv/drivers/vmlogrdr
OSA-Express, OSA-Express2, OSA-Express3, HiperSockets (qeth)	CCW group	/sys/bus/ccwgroup/drivers/qeth
LCS	CCW group	/sys/bus/ccwgroup/drivers/lcs
CTCM	CCW group	/sys/bus/ccwgroup/drivers/ctcm

Some device drivers do not relate to physical devices that are connected through the channel subsystem. Their representation in sysfs differs from the CCW and CCW group devices, for example, the Cryptographic device drivers have their own category, AP.

The following sections provide more details about devices and their representation in sysfs.

Device directories

Each device that is known to Linux is represented by a directory in sysfs.

For CCW and CCW group devices the name of the directory is a *bus ID* that identifies the device within the scope of a Linux instance. For a CCW device, the bus ID is the device's device number with a leading "0.n.", where n is the subchannel set ID. For example, 0.1.0ab1.

CCW group devices are associated with multiple device numbers. For CCW group devices, the bus ID is the primary device number with a leading "0.n.", where n is the subchannel set ID.

Device attributes

The device directories contain attributes. You control a device by writing values to its attributes.

Some attributes are common to all devices in a device category, other attributes are specific to a particular device driver. The following attributes are common to all CCW devices:

online

You use this attribute to set the device online or offline. To set a device online write the value "1" to its online attribute. To set a device offline write the value "0" to its online attribute.

cotype

specifies the control unit type and model, if applicable. This attribute is read-only.

cmb_enable

enables I/O data collection for the device. See "Enabling, resetting, and switching off data collection" on page 380 for details.

devtype

specifies the device type and model, if applicable. This attribute is read-only.

availability

indicates if the device can be used. Possible values are:

good This is the normal state, the device can be used.

boxed The device has been locked by another operating system instance and cannot be used until the lock is surrendered or forcibly broken (see "Accessing DASD by force" on page 42).

no device

Applies to disconnected devices only. The device is gone after a machine check and the device driver has requested to keep the (online) device anyway. Changes back to "good" when the device returns after another machine check and the device driver has accepted the device back.

no path

Applies to disconnected devices only. The device has no path left after a machine check or a logical vary off and the device driver has requested to keep the (online) device anyway. Changes back to "good" when the path returns after another machine check or logical vary on and the device driver has accepted the device back.

modalias

contains the module alias for the device. It is of the format:

```
ccw:t<cu_type>m<cu_model>
```

or

```
ccw:t<cu_type>m<cu_model>dt<dev_type>dm<dev_model>
```

“Device views in sysfs” tells you where you can find the device directories with their attributes in sysfs. Red Hat Enterprise Linux 6 uses configuration files to control devices. For example, network devices have interface scripts called `/etc/sysconfig/network-scripts/ifcfg-<interface-name>`. See the *Red Hat Enterprise Linux 6.3 Deployment Guide* for details about configuration files.

Working with newly available devices

Errors can occur if you try to work with a device before its sysfs representation is completely initialized.

When new devices become available to a running Linux instance, some time elapses until the corresponding device directories and their attributes are created in sysfs. Errors can occur if you attempt to work with a device for which the sysfs structures are not present or are not complete. These errors are most likely to occur and most difficult to handle when configuring devices with scripts.

Use the following steps before you work with a newly available device to avoid such errors:

1. Attach the device, for example, with a `z/VM CP ATTACH` command.
2. Assure that the sysfs structures for the new device have been completed.

```
# echo 1 > /proc/cio_settle
```

This command returns control after all pending updates to sysfs have been completed.

Tip: For CCW devices you can omit this step if you subsequently use **chccwdev** (see “chccwdev - Set a CCW device online” on page 396) to work with the devices. **chccwdev** triggers `cio_settle` for you and waits for `cio_settle` to complete.

You can now work with the new device, for example, you can set the device online or set attributes for the device.

Device views in sysfs

sysfs provides multiple views of device specific data.

The most important views are:

- Device driver view
- Device category view
- Device view
- Channel subsystem view

Many paths in sysfs contain device bus-IDs to identify devices. Device bus-IDs of subchannel-attached devices are of the form:

0.n.dddd

where n is the subchannel set-ID and dddd is the device ID. Multiple subchannel sets are available on System z9® or later machines.

Device driver view

This view groups devices by the device drivers that control them.

The device driver view is of the form:

`/sys/bus/<bus>/drivers/<driver>/<device_bus_id>`

where:

- `<bus>` is the device category, for example, ccw or ccwgroup.
- `<driver>` is a name that specifies an individual device driver or the device driver component that controls the device (see Table 3 on page 8).
- `<device_bus_id>` identifies an individual device (see “Device directories” on page 9).

Note: DCSSs and XPRAM are not represented in this view.

Examples:

- This example shows the path for an ECKD™ type DASD device:
`/sys/bus/ccw/drivers/dasd-eckd/0.0.b100`
- This example shows the path for a qeth device:
`/sys/bus/ccwgroup/drivers/qeth/0.0.a100`
- This example shows the path for a cryptographic device (a CEX2A card):
`/sys/bus/ap/drivers/cex2a/card3b`

Device category view

This view groups devices by major categories that can span multiple device drivers.

The device category view does not sort the devices according to their device drivers. All devices of the same category are contained in a single directory. The device category view is of the form:

`/sys/bus/<bus>/devices/<device_bus_id>`

where:

- `<bus>` is the device category, for example, ccw or ccwgroup.
- `<device_bus_id>` identifies an individual device (see “Device directories” on page 9).

Note: DCSSs and XPRAM are not represented in this view.

Examples:

- This example shows the path for a CCW device.
`/sys/bus/ccw/devices/0.0.b100`
- This example shows the path for a CCW group device.

```
/sys/bus/ccwgroup/devices/0.0.a100
```

- This example shows the path for a cryptographic device:

```
/sys/bus/ap/devices/card3b
```

Device view

This view sorts devices according to their device drivers, but independent from the device category. It also includes logical devices that are not categorized.

The device view is of the form:

```
/sys/devices/<driver>/<device>
```

where:

<driver>

is a name that specifies an individual device driver or the device driver component that controls the device.

<device>

identifies an individual device. The name of this directory can be a device bus-ID or the name of a DCSS or IUCV device.

Examples:

- This example shows the path for a qeth device.

```
/sys/devices/qeth/0.0.a100
```
- This example shows the path for a DCSS block device.

```
/sys/devices/dcssblk/mydcss
```

Channel subsystem view

The channel subsystem view shows the relationship between subchannels and devices.

The channel subsystem view is of the form:

```
/sys/devices/css0/<subchannel>
```

where:

<subchannel>

is a subchannel number with a leading "0.n.", where n is the subchannel set ID.

I/O subchannels show the devices in relation to their respective subchannel sets and subchannels. An I/O subchannel is of the form:

```
/sys/devices/css0/<subchannel>/<device_bus_id>
```

where:

<subchannel>

is a subchannel number with a leading "0.n.", where n is the subchannel set ID.

<device_bus_id>

is a device number with a leading "0.n.", where n is the subchannel set ID (see "Device directories" on page 9).

Examples:

- This example shows a CCW device with device number 0xb100 that is associated with a subchannel 0x0001.

```
/sys/devices/css0/0.0.0001/0.0.b100
```

- This example shows a CCW device with device number 0xb200 that is associated with a subchannel 0x0001 in subchannel set 1.

```
/sys/devices/css0/0.1.0001/0.1.b200
```

- The entries for a group device show as separate subchannels. If a CCW group device uses three subchannels 0x0002, 0x0003, and 0x0004 the subchannel information could be:

```
/sys/devices/css0/0.0.0002/0.0.a100
```

```
/sys/devices/css0/0.0.0003/0.0.a101
```

```
/sys/devices/css0/0.0.0004/0.0.a102
```

Each subchannel is associated with a device number. Only the primary device number is used for the bus ID of the device in the device driver view and the device view.

- This example lists the information available for a non-I/O subchannel with which no device is associated:

```
ls /sys/devices/css0/0.0.ff00/  
bus driver modalias subsystem type uevent
```

Subchannel attributes

There are sysfs attributes that represent subchannel properties, including common attributes and information specific to the subchannel type.

Subchannels have two common attributes:

type

The subchannel type, which is a numerical value, for example:

- 0 for an I/O subchannel
- 1 for a CHSC subchannel

modalias

The module alias for the device of the form `css:t<n>`, where `<n>` is the subchannel type (for example, 0 or 1).

These two attributes are the only ones that are always present. Some subchannels, like I/O subchannels, might contain devices and further attributes.

Apart from the bus ID of the attached device, I/O subchannel directories typically contain these attributes:

chpids

is a list of the channel-path identifiers (CHPIDs) through which the device is connected. See also “Channel path ID information” on page 14

pimpampom

provides the path installed, path available and path operational masks. See *z/Architecture® Principles of Operation*, SA22-7832 for details about the masks.

Channel path measurement

There is a sysfs attribute that controls the channel path measurement facility of the channel subsystem.

```
/sys/devices/css0/cm_enable
```

With the `cm_enable` attribute you can enable and disable the extended channel-path measurement facility. It can take the following values:

- 0 Deactivates the measurement facility and remove the measurement-related attributes for the channel paths. No action if measurements are not active.
- 1 Attempts to activate the measurement facility and create the measurement-related attributes for the channel paths. No action if measurements are already active.

If a machine does not support extended channel-path measurements the `cm_enable` attribute is not created.

Two `sysfs` attributes are added for each channel path object:

cmg Specifies the channel measurement group or unknown if no characteristics are available.

shared

Specifies whether the channel path is shared between LPARs or unknown if no characteristics are available.

If measurements are active, two more `sysfs` attributes are created for each channel path object:

measurement

A binary `sysfs` attribute that contains the extended channel-path measurement data for the channel path. It consists of eight 32-bit values and must always be read in its entirety, or 0 will be returned.

measurement_chars

A binary `sysfs` attribute that is either empty, or contains the channel measurement group dependent characteristics for the channel path, if the channel measurement group is 2 or 3. If not empty, it consists of five 32-bit values.

Examples:

- To turn measurements on issue:

```
# echo 1 > /sys/devices/css0/cm_enable
```

- To turn measurements off issue:

```
# echo 0 > /sys/devices/css0/cm_enable
```

Channel path ID information

All CHPIDs that are known to Linux are shown alongside the subchannels in the `/sys/devices/css0` directory.

The directories that represent the CHPIDs have the form:

`/sys/devices/css0/chp0.<chpid>`

where `<chpid>` is a two digit hexadecimal CHPID.

Example: `/sys/devices/css0/chp0.4a`

Setting a CHPID logically online or offline

Directories that represent CHPIDs contain a status attribute that you can use to set the CHPID logically online or offline.

When a CHPID has been set logically offline from a particular Linux instance, the CHPID is, in effect, offline for this Linux instance. A CHPID that is shared by multiple operating system instances can be logically online to some instances and offline to others. A CHPID can also be logically online to Linux while it has been varied off at the SE.

To set a CHPID logically online, set its status attribute to “online” by writing the value “on” to it. To set a CHPID logically offline, set its status attribute to “offline” by writing “off” to it. Issue a command of this form:

```
# echo <value> > /sys/devices/css0/chp0.<CHPID>/status
```

where:

<CHPID> is a two digit hexadecimal CHPID.

<value> is either “on” or “off”.

Examples:

- To set a CHPID 0x4a logically offline issue:

```
# echo off > /sys/devices/css0/chp0.4a/status
```

- To read the status attribute to confirm that the CHPID has been set logically offline issue:

```
# cat /sys/devices/css0/chp0.4a/status  
offline
```

- To set the same CHPID logically online issue:

```
# echo on > /sys/devices/css0/chp0.4a/status
```

- To read the status attribute to confirm that the CHPID has been set logically online issue:

```
# cat /sys/devices/css0/chp0.4a/status  
online
```

Configuring a CHPID on LPAR

For Linux on LPAR, directories that represent CHPIDs contain a configure attribute that you can use to query and change the configuration state of I/O channel-paths.

Supported configuration changes are:

- From standby to configured (“configure”).
- From configured to standby (“deconfigure”).

To configure a CHPID, set its configure attribute by writing the value “1” to it. To deconfigure a CHPID, set its configure attribute by writing “0” to it. Issue a command of this form:

```
# echo <value> > /sys/devices/css0/chp0.<CHPID>/configure
```

where:

<CHPID> is a two digit hexadecimal CHPID.

<value> is either “1” or “0”.

To query and set the configure value using commands, see “chchp - Change channel path status” on page 398 and “lschp - List channel paths” on page 457.

Examples:

- To set a channel path with the ID 0x40 to standby issue:

```
# echo 0 > /sys/devices/css0/chp0.40/configure
```

This operation is equivalent to performing a Configure Channel Path Off operation on the hardware management console.

- To read the configure attribute to confirm that the channel path has been set to standby issue:

```
# cat /sys/devices/css0/chp0.40/configure
0
```

- To set the same CHPID to configured issue:

```
# echo 1 > /sys/devices/css0/chp0.40/configure
```

This operation is equivalent to performing a Configure Channel Path On operation on the hardware management console.

- To read the status attribute to confirm that the CHPID has been set to configured issue:

```
# cat /sys/devices/css0/chp0.40/configure
1
```

CCW hotplug events

A hotplug event is generated when a CCW device appears or disappears with a machine check.

The hotplug events provide the following variables:

CU_TYPE	for the control unit type of the device that appeared or disappeared.
CU_MODEL	for the control unit model of the device that appeared or disappeared.
DEV_TYPE	for the type of the device that appeared or disappeared.
DEV_MODEL	for the model of the device that appeared or disappeared.
MODALIAS	for the module alias of the device that appeared or disappeared. The module alias is the same value that is contained in <code>/sys/devices/css0/<subchannel_id>/<device_bus_id>/modalias</code>

and is of the format

`ccw:t<cu_type>m<cu_model>` or

`ccw:t<cu_type>m<cu_model>dt<dev_type>dm<dev_model>`

Hotplug events can be used, for example, for:

- Automatically setting devices online as they appear
- Automatically loading driver modules for which devices have appeared

For information about the device driver modules see `/lib/modules/<kernel_version>/modules.ccwmap`. This file is generated when you install the Linux kernel (version `<kernel_version>`).

Chapter 3. Kernel and module parameters

Kernel and module parameters are used to configure the kernel and kernel modules.

Individual kernel parameters or module parameters are single keywords or keyword/value pairs of the form `keyword=<value>` with no blank. Blanks separate consecutive parameters.

Kernel parameters and module parameters are encoded as strings of ASCII characters. For tape or the z/VM reader as a boot device, the parameters can also be encoded in EBCDIC.

Use *kernel parameters* to configure the base kernel and any optional kernel parts that have been compiled into the kernel image. Use *module parameters* to configure separate kernel modules. Do not confuse kernel and module parameters. Although a module parameter can have the same syntax as a related kernel parameter, kernel and module parameters are specified and processed differently.

Where possible, this document describes kernel parameters with the device driver or feature to which they apply. Kernel parameters that apply to the base kernel or cannot be attributed to a particular device driver or feature are described in Chapter 45, “Selected kernel parameters,” on page 519. You can also find descriptions for most of the kernel parameters in `Documentation/kernel-parameters.txt` in the Linux source tree.

Separate kernel modules must be loaded before they can be used. Many modules are loaded automatically by Red Hat Enterprise Linux 6.3 when they are needed. To keep the module parameters in the context of the device driver or feature module to which they apply, this document describes module parameters as part of the syntax you would use to load the module with `modprobe`.

To find the separate kernel modules for Red Hat Enterprise Linux 6.3, list the contents of the subdirectories of `/lib/modules/<kernel-release>` in the Linux file system. In the path, `<kernel-release>` denotes the kernel level. You can query the value for `<kernel-release>` with `uname -r`.

Specifying kernel parameters

There are different methods for passing kernel parameters to the Linux kernel.

- Including kernel parameters in a boot configuration
- Using a kernel parameter file
- Specifying kernel parameters when booting Linux

Kernel parameters that you specify when booting Linux are not persistent. To define a permanent set of kernel parameters for a Linux instance, include these parameters in the boot configuration.

Note: Parameters that you specify on the kernel parameter line might interfere with parameters that Red Hat Enterprise Linux 6.3 sets for you. Read `/proc/cmdline` to find out which parameters were used to start a running Linux instance.

Including kernel parameters in a boot configuration

Use the **zipl** tool to create Linux boot configurations for IBM mainframe systems.

Which sources of kernel parameters you can use depends on the mode in which you run **zipl**. See “**zipl modes**” on page 322 for details.

Running **zipl** in configuration-file mode

In configuration-file mode, you issue the **zipl** command with command arguments that identify a section in a **zipl** configuration file.

You specify details about the boot configuration in the configuration file.

As shown in Figure 5, there are three sources of kernel parameters for **zipl** in configuration-file mode.




Figure 5. Sources of kernel parameters for **zipl** in configuration-file mode

In configuration-file mode, **zipl** concatenates the kernel parameters in the order:

1. Parameters specified in the kernel parameter file
2. Parameters specified in the **zipl** configuration file
3. Parameters specified on the command line

See “**zipl modes**” on page 322 for details about the **zipl** command modes.

Running **zipl** in command-line mode

In command-line mode, you specify the details about the boot configuration to be created as arguments for the **zipl** command.

As shown in Figure 6 on page 21, there are two sources of kernel parameters for **zipl** in command-line mode.




Figure 6. Sources of kernel parameters for zipl in command-line mode

In command-line mode, zipl concatenates the kernel parameters in the order:

1. Parameters specified in the kernel parameter file
2. Parameters specified on the command line

See “zipl modes” on page 322 for details about the **zipl** command modes.

Conflicting settings and limitations

There is an override order for conflicting kernel parameter settings and there are multiple length limitations.

If the resulting parameter string in the boot configuration contains conflicting settings, the last specification in the string overrides preceding ones.

The kernel parameter file can contain 895 characters of kernel parameters plus an end-of-line character.

In total, the parameter string in the boot configuration is limited to 895 characters. If your specifications exceed this limit, the parameter string in the boot configuration is truncated after the 895th character.

This limitation applies to the parameter string in the boot configuration. You can provide additional parameters when booting Linux. Linux accepts up to 4096 characters of kernel parameters in total. See “Adding kernel parameters to a boot configuration” on page 22.

Using a kernel parameter file

For booting Linux from the z/VM reader, you can use a kernel parameter file in the reader.

See “Using the z/VM reader” on page 354 and *Building Linux Systems under IBM VM*, REDP-0120 for more details.

Specifying kernel parameters when booting Linux

Depending on the boot device and whether you boot Linux in a z/VM guest virtual machine or in LPAR mode, you can provide kernel parameters when you start the boot process.

zipl interactive boot menu on DASD

When booting Linux with a zipl interactive boot menu on a DASD boot device, you can display the menu and specify kernel parameters as you select a boot configuration. See “Example for a DASD menu configuration on z/VM” on page 351 and “Example for a DASD menu configuration (LPAR)” on page 358 for details.

z/VM guest virtual machine with a CCW boot device

When booting Linux in a z/VM guest virtual machine from a CCW boot device, you can use the PARM parameter of the IPL command to specify kernel parameters. CCW boot devices include DASD, tape, the z/VM reader, and NSS.

For details, see the subsection of “Booting Linux in a z/VM guest virtual machine” on page 350 that applies to your boot device.

z/VM guest virtual machine with a SCSI boot device

When booting Linux in a z/VM guest virtual machine from a SCSI boot device, you can use the SET LOADDEV command with the SCPDATA option to specify kernel parameters. See “Using a SCSI device” on page 352 for details.

LPAR mode with a SCSI boot device

When booting Linux in LPAR mode from a SCSI boot device, you can specify kernel parameters in the **Operating system specific load parameters** field on the HMC Load panel. See Figure 64 on page 357.

Kernel parameters as entered from a CMS or CP session are interpreted as lowercase on Linux.

Adding kernel parameters to a boot configuration

When booting a Linux instance, you can specify kernel parameters that are used in addition to those in the boot configuration.

By default, the kernel parameters you specify when booting are concatenated to the end of the kernel parameters in your boot configuration. In total, the combined kernel parameter string used for booting can be up to 4096 characters.

If kernel parameters are specified in a combination of methods, they are concatenated in the following order:

1. Kernel parameters that have been included in the boot configuration with `zipl`
2. **DASD only:** `zipl` kernel parameters specified with the interactive boot menu
3. Depending on where you are booting Linux:
 - **z/VM:** kernel parameters specified with the PARM parameter for CCW boot devices; kernel parameters specified as SCPDATA for SCSI boot devices
 - **LPAR:** kernel parameters specified on the HMC Load panel for CCW boot devices

If the combined kernel parameter string contains conflicting settings, the last specification in the string overrides preceding ones. Thus, you can specify a kernel parameter when booting to override an unwanted setting in the boot configuration.

Examples:

- If the kernel parameters in your boot configuration include `possible_cpus=8` but you specify `possible_cpus=2` when booting, Linux uses `possible_cpus=2`.
- If the kernel parameters in your boot configuration include `resume=/dev/dasda2` to specify a disk from which to resume the Linux instance when it has been suspended, you can circumvent the resume process by specifying `noresume` when booting.

Replacing all kernel parameters in a boot configuration

Kernel parameters you specify when booting can completely replace the kernel parameters in your boot configuration.

To replace all kernel parameters in your boot configuration specify the new parameter string with a leading equal sign (=).

Example:

```
=zfcplib.device=0.0.3c3b,0x5005076303048335,0x4050407e00000000 root=/dev/sda1
```

Note: This feature is intended for expert users who want to test a set of parameters. When replacing all parameters, you might inadvertently omit parameters that the boot configuration requires. Furthermore, you might omit parameters other than kernel parameters that Red Hat Enterprise Linux 6.3 includes in the parameter string for use by the init process.

Read `/proc/cmdline` to find out with which parameters a running Linux instance has been started (see also “Displaying the current kernel parameter line”).

Examples for kernel parameters

Typical parameters used for booting Red Hat Enterprise Linux 6.3 configure the console and the suspend and resume function.

conmode=<mode>, **condev=<cuu>**, and **console=<name>**

to set up the Linux console. See “Console kernel parameter syntax” on page 305 for details.

resume=<partition>, **noresume**, **no_console_suspend**

to configure suspend and resume support (see Chapter 37, “Suspending and resuming Linux,” on page 365).

See Chapter 45, “Selected kernel parameters,” on page 519 for more examples of kernel parameters.

Displaying the current kernel parameter line

Read `/proc/cmdline` to find out with which kernel parameters a running Linux instance has been booted.

For example:

```
# cat /proc/cmdline
zfcplib.device=0.0.3c3b,0x5005076303048335,0x4050407e00000000 root=/dev/sda1
```

Apart from kernel parameters, which are evaluated by the Linux kernel, the kernel parameter line can contain parameters that are evaluated by user space programs, for example, `modprobe`.

See also “Displaying current IPL parameters” on page 361 about displaying the parameters that were used to IPL and boot the running Linux instance.

Kernel parameters for rebooting

When rebooting, you can use the current kernel parameters or an alternative set of kernel parameters.

By default, Linux uses the current kernel parameters for rebooting. See “Rebooting from an alternative source” on page 362 about how to set up Linux to use different kernel parameters for re-IPL and the associated reboot.

Specifying module parameters

How to specify module parameters depends on how the module is loaded, for example, automatically, through a tool, or from the command line.

You can specify module parameters with `modprobe`, on the kernel parameter line, or include them in a boot configuration. Avoid specifying the same parameter through multiple means.

Specifying module parameters with `modprobe`

If you load a module explicitly with a `modprobe` command, you can specify the module parameters as command arguments.

Module parameters that are specified as arguments to `modprobe` are effective until the module is unloaded only.

Note: Parameters that you specify as command arguments might interfere with parameters that Red Hat Enterprise Linux 6.3 sets for you.

Module parameters on the kernel parameter line

Parameters that the kernel does not recognize as kernel parameters are ignored by the kernel and made available to user space programs.

One of these programs is `modprobe`, which Red Hat Enterprise Linux 6.3 uses to load modules for you. `modprobe` interprets module parameters that are specified on the kernel parameter line if they are qualified with a leading module prefix and a dot.

For example, you can include a specification with `dasd_mod.dasd=` on the kernel parameter line. `modprobe` evaluates this specification as the `dasd=` module parameter when loading the `dasd_mod` module.

Including module parameters in a boot configuration

Module parameters for modules that are required early during the boot process must be included in the boot configuration.

Red Hat Enterprise Linux 6.3 uses an initial file system (`initramfs`) when booting. The `initramfs` does not contain device specifications. Instead it takes module parameters from **dracut** during the boot process. **dracut** obtains the module parameters by parsing the kernel parameter line for parameters with an “`rd_`” prefix.

Anaconda writes information about devices that need to be accessible during the boot process to `zipl.conf` for you. This includes the device with the root file system and, if configured, the swap partition that is used to resume a suspended system.

Follow these steps to provide module parameters for modules that are included in an `initramfs`:

1. With an “`rd_`” prefix, specify the module parameters in `zipl.conf`. For example, use `rd_DASD=` instead of `dasd=`.
2. Run **zipl** to include the new parameter line in your boot configuration.

See the `dracut` man page for more details about parameters with an “`rd_`” prefix.

Part 2. Storage

This part describes the storage device drivers for Red Hat Enterprise Linux 6.3 for System z.

Newest version: You can find the newest version of this book at www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

Restrictions: For prerequisites and restrictions see the System z architecture specific information in the Red Hat Enterprise Linux 6.3 release notes at docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

Chapter 4. DASD device driver	27
Features	27
What you should know about DASD.	28
Setting up the DASD device driver	37
Working with DASD devices	39
 Chapter 5. SCSI-over-Fibre Channel device driver	 61
Features	61
What you should know about zfcp	61
Setting up the zfcp device driver	67
Working with FCP devices, target ports, and SCSI devices	68
Logging I/O subchannel status information	86
Scenario for finding available LUNs	87
API provided by the zfcp HBA API support	87
 Chapter 6. Channel-attached tape device driver	 91
Features	91
What you should know about channel-attached tape devices	91
Setting up the tape device driver	95
Working with tape devices	95
Scenario: Using a tape block device	100
 Chapter 7. XPRAM device driver	 103
XPRAM features	103
What you should know about XPRAM.	103
Setting up the XPRAM device driver	104

Chapter 4. DASD device driver

The DASD device driver provides access to all real or emulated Direct Access Storage Devices (DASD) that can be attached to the channel subsystem of an IBM mainframe.

DASD devices include a variety of physical media on which data is organized in blocks or records or both. The blocks or records in a DASD can be accessed for read or write in random order.

Traditional DASD devices are attached to a control unit that is connected to a mainframe I/O channel. Today, these real DASD have been largely replaced by emulated DASD, such as the volumes of the IBM System Storage[®] DS8000[®] Turbo, or the volumes of the IBM System Storage DS6000[™]. These emulated DASD are completely virtual and the identity of the physical device is hidden.

SCSI disks attached through an FCP channel are not classified as DASD. They are handled by the zfcps driver (see Chapter 5, “SCSI-over-Fibre Channel device driver,” on page 61).

Features

The DASD device driver supports a wide range of disk devices and disk functions.

- The DASD device driver has no dependencies on the adapter hardware that is used to physically connect the DASDs to the System z hardware. You can use any adapter that is supported by the System z hardware (see www.ibm.com/systems/z/connectivity for more information).
- The DASD device driver supports ESS virtual ECKD-type disks
- The DASD device driver supports the control unit attached physical ECKD (Extended Count Key Data) and FBA (Fixed Block Access) devices as summarized in Table 4:

Table 4. Supported control unit attached DASD

Device format	Control unit type	Device type
ECKD	1750	3380 and 3390
ECKD	2107	3380 and 3390
ECKD	2105	3380 and 3390
ECKD	3990	3380 and 3390
ECKD	9343	9345
ECKD	3880	3390
FBA	6310	9336
FBA	3880	3370

All models of the specified control units and device types can be used with the DASD device driver. This includes large devices with more than 65520 cylinders, for example, 3390 Model A. Check the storage support statement to find out what works for a particular distribution.

- The DASD device driver provides a disk format with up to three partitions per disk. See “System z compatible disk layout” on page 29 for details.

- The DASD device driver provides an option for extended error reporting for ECKD devices. Extended error reporting can support high availability setups.
- The DASD device driver supports parallel access volume (PAV) and HyperPAV on storage devices that provide this feature.
- The DASD device driver supports High Performance FICON , including multitrack requests, on storage devices that provide this feature.
- The DASD device driver supports large volumes (devices with more than 65520 cylinders, for example, 3390 Model A), solid state devices, and encrypted devices.

What you should know about DASD

The DASD device driver supports various disk layouts with different partitioning capabilities. The DASD device naming scheme helps you to keep track of your DASDs and DASD device nodes.

The IBM label partitioning scheme

Linux on System z supports the same standard DASD format that is also used by traditional mainframe operating systems, but it also supports any other Linux partition table.

The DASD device driver is embedded into the Linux generic support for partitioned disks. This implies that you can have any kind of partition table known to Linux on your DASD.

Traditional mainframe operating systems (such as, z/OS®, z/VM, and z/VSE®) expect a standard DASD format. In particular, the format of the first two tracks of a DASD is defined by this standard and includes System z IPL, label, and for some layouts VTOC records. Partitioning schemes for platforms other than System z generally do not preserve these mainframe specific records.

Red Hat Enterprise Linux 6.3 for System z includes the IBM label partitioning scheme that preserves the System z IPL, label, and VTOC records. This partitioning scheme allows Linux to share a disk with other mainframe operating systems. For example, a traditional mainframe operating system could handle backup and restore for a partition that is used by Linux.

The following sections describe the layouts that are supported by the IBM label partitioning scheme:

- “System z compatible disk layout” on page 29
- “Linux disk layout” on page 31
- “CMS disk layout” on page 32

DASD partitions

Partitioning DASD has the same advantages as for other disk types, but there are some prerequisites and a special tool, **fdasd**.

A DASD partition is a contiguous set of DASD blocks that is treated by Linux as an independent disk and by the traditional mainframe operating systems as a data set.

With the Linux disk layout (LDL) and the CMS disk layout you always have a single partition only. This partition is defined by the LDL or CMS formatted area of the disk. With the compatible disk layout you can have up to three partitions.

There are several reasons why you might want to have multiple partitions on a DASD, for example:

- **Limit data growth.** Runaway processes or undisciplined users can consume disk space to an extent that the operating system runs short of space for essential operations. Partitions can help to isolate the space that is available to particular processes.
- **Encapsulate your data.** If a file system gets damaged, this damage is likely to be restricted to a single partition. Partitioning can reduce the scope of data damage.

Recommendations:

- Use **fdasd** to create or alter partitions on ECKD-type DASD that have been formatted with the compatible disk layout. If you use another partition editor, it is your responsibility to ensure that partitions do not overlap. If they do, data damage will occur.
- Leave no gaps between adjacent partitions to avoid wasting space. Gaps are not reported as errors, and can only be reclaimed by deleting and recreating one or more of the surrounding partitions and rebuilding the file system on them.

A disk need not be partitioned completely. You can begin by creating only one or two partitions at the start of your disk and convert the remaining space to a partition later.

There is no facility for moving, enlarging, or reducing partitions, because **fdasd** has no control over the file system on the partition. You only can delete and recreate them. Changing the partition table results in loss of data in all altered partitions. It is up to you to preserve the data by copying it to another medium.

System z compatible disk layout

DASDs that are formatted with the compatible disk layout can be accessed by traditional mainframe operating systems.

You can only format ECKD-type DASD with the compatible disk layout.

Figure 7 illustrates a DASD with the compatible disk layout.



Figure 7. Compatible disk layout

The IPL records, volume label (VOL1), and VTOC of disks with the compatible disk layout are on the first two tracks of the disks. These tracks are not intended for use by Linux applications. Apart from a slight loss in disk capacity this is transparent to the user.

Linux can address the device as a whole as `/dev/dasd<x>`, where `<x>` can be one to four letters that identify the individual DASD (see “DASD naming scheme” on page 33). See “DASD device nodes” on page 34 for alternative addressing possibilities.

Disks with the compatible disk layout can have one to three partitions. Linux addresses the first partition as `/dev/dasd<x>1`, the second as `/dev/dasd<x>2`, and the third as `/dev/dasd<x>3`.

You use the **dasdfmt** command (see “`dasdfmt` - Format a DASD” on page 423) to format a disk with the compatible disk layout. You use the **fdasd** command (see “`fdasd` - Partition a DASD” on page 438) to create and modify partitions.

Volume label

The volume label includes information about the disk layout, the VOLSER, and a pointer to the VTOC.

The DASD volume label is located in the third block of the first track of the device (cylinder 0, track 0, block 2). This block has a 4-byte key, and an 80-byte data area. The contents are:

key for disks with the compatible disk layout, contains the four EBCDIC characters “VOL1” to identify the block as a volume label.

label identifier

is identical to the key field.

VOLSER

is a name that you can use to identify the DASD device. A volume serial number (VOLSER) can be one to six EBCDIC characters. If you want to use VOLSERs as identifiers for your DASD, be sure to assign unique VOLSERs.

You can assign VOLSERs from Linux by using the **dasdfmt** or **fdasd** command. These commands enforce that VOLSERs:

- Are alphanumeric
- Are uppercase (by uppercase conversion)
- Contain no embedded blanks
- Contain no special characters other than \$, #, @, and %

Recommendation: Avoid special characters altogether.

Note: The VOLSER values SCRTCH, PRIVAT, MIGRAT or Lnnnnn (An “L” followed by five digits) are reserved for special purposes by other mainframe operating systems and should not be used by Linux.

These rules are more restrictive than the VOLSERs that are allowed by the traditional mainframe operating systems. For compatibility, Linux tolerates existing VOLSERs with lowercase letters and special characters other than \$, #, @, and %. You might have to enclose a VOLSER with special characters in apostrophes when specifying it, for example, as a command parameter.

VTOC address

contains the address of a standard IBM format 4 data set control block (DSCB). The format is: *cylinder* (2 bytes) *track* (2 bytes) *block* (1 byte).

All other fields of the volume label contain EBCDIC space characters (code 0x40).

VTOC

Instead of a regular Linux partition table, Red Hat Enterprise Linux 6.3 for System z, like other System z operating systems, uses a Volume Table Of Contents (VTOC) to keep an index of the partitions on a DASD.

The VTOC contains pointers to the location of every data set on the volume. These data sets form the Linux partitions.

The VTOC is located in the second track (cylinder 0, track 1). It contains a number of records, each written in a separate data set control block (DSCB). The number of records depends on the size of the volume:

- One DSCB that describes the VTOC itself (format 4)
- One DSCB that is required by other operating systems but is not used by Linux. **fdasd** sets it to zeroes (format 5).
- For volumes with more than 65534 cylinders, one DSCB (format 7)
- For each partition:
 - On volumes with 65534 or less cylinders, one DSCB (format 1)
 - On volumes with more than 65534 cylinders, one format 8 and one format 9 DSCB

The key of the format 1 or format 8 DSCB contains the data set name, which identifies the partition to z/OS, z/VM, and z/VSE.

The VTOC can be displayed with standard System z tools such as VM/DITTO. A Linux DASD with physical device number 0x0193, volume label “LNX001”, and three partitions might be displayed like this:

```

=====
                                VM/DITTO DISPLAY VTOC                                LINE 1 OF 5
                                SCROLL ==> PAGE

CUU,193 ,VOLSER,LNX001  3390, WITH  100 CYLS, 15 TRKS/CYL, 58786 BYTES/TRK

--- FILE NAME --- (SORTED BY =,NAME ,) ---- EXT   BEGIN-END   RELTRK,
1...5...10...15...20...25...30...35...40.... SQ   CYL-HD   CYL-HD   NUMTRKS
*** VTOC EXTENT ***
LINUX.VLNX001.PART0001.NATIVE                0     0  1     0  1     1,1
LINUX.VLNX001.PART0002.NATIVE                0     0  2     46 11    2,700
LINUX.VLNX001.PART0003.NATIVE                0    46 12     66 11    702,300
LINUX.VLNX001.PART0003.NATIVE                0    66 12     99 14   1002,498
*** THIS VOLUME IS CURRENTLY 100 PER CENT FULL WITH      0 TRACKS AVAILABLE

PF 1=HELP      2=TOP      3=END      4=BROWSE   5=BOTTOM   6=LOCATE
PF 7=UP        8=DOWN     9=PRINT   10=RGT/LEFT 11=UPDATE  12=RETRIEVE

```

In Linux, this DASD might appear so:

```

# ls -l /dev/dasda*
brw-rw---- 1 root disk 94, 0 Jan 27 09:04 /dev/dasda
brw-rw---- 1 root disk 94, 1 Jan 27 09:04 /dev/dasda1
brw-rw---- 1 root disk 94, 2 Jan 27 09:04 /dev/dasda2
brw-rw---- 1 root disk 94, 3 Jan 27 09:04 /dev/dasda3

```

where dasda represent the whole DASD and dasda1, dasda2, and dasda3 represent the individual partitions.

Linux disk layout

The Linux disk layout does not have a VTOC, and DASDs formatted with this layout cannot be accessed by traditional mainframe operating systems.

You can only format ECKD-type DASD with the Linux disk layout. Figure 8 on page 32 illustrates a disk with the Linux disk layout.



Figure 8. Linux disk layout

DASDs with the Linux disk layout either have an LNX1 label or are not labeled. The IPL records and volume label are not intended for use by Linux applications. Apart from a slight loss in disk capacity this is transparent to the user.

All remaining records are grouped into a single partition. You cannot have more than a single partition on a DASD that is formatted in the Linux disk layout.

Linux can address the device as a whole as `/dev/dasd<x>`, where `<x>` can be one to four letters that identify the individual DASD (see “DASD naming scheme” on page 33). Linux can access the partition as `/dev/dasd<x>1`.

You use the **dasdfmt** command (see “dasdfmt - Format a DASD” on page 423) to format a disk with the Linux disk layout.

CMS disk layout

The CMS disk layout only applies to Linux on z/VM. The disks are formatted using z/VM tools.

Both ECKD- or FBA-type DASD can have the CMS disk layout. Apart from accessing the disks as ECKD or FBA devices, you can also access them using DIAG calls.

Figure 9 illustrates two variants of the CMS disk layout.



Figure 9. CMS disk layout

The first variant contains IPL records, a volume label (CMS1), and a CMS data area. Linux treats DASD like this equivalent to a DASD with the Linux disk layout, where the CMS data area serves as the Linux partition.

The second variant is a CMS reserved volume. DASD like this have been reserved by a CMS RESERVE fn ft fm command. In addition to the IPL records and the volume label, DASD with the CMS disk layout also have CMS metadata. The CMS reserved file serves as the Linux partition.

Both variants of the CMS disk layout only allow a single Linux partition. The IPL record, volume label and (where applicable) the CMS metadata, are not intended for use by Linux applications. Apart from a slight loss in disk capacity this is transparent to the user.

Addressing the device and partition is the same for both variants. Linux can address the device as a whole as `/dev/dasd<x>`, where `<x>` can be one to four letters that identify the individual DASD (see “DASD naming scheme”). Linux can access the partition as `/dev/dasd<x>1`.

“Enabling DIAG calls to access DASDs” on page 43 describes how you can enable DIAG.

Disk layout summary

The available disk layouts differ in their support of device formats, DIAG calls as an access method, and the maximum number of partitions.

Table 5. Disk layout summary

Disk Layout	ECKD device format	FBA device format	DIAG call support (z/VM only)	Maximum number of partitions
CDL	Yes	No	No	3
LDL	Yes	No	Yes	1
CMS (z/VM only)	Yes	Yes	Yes	1

DASD naming scheme

The DASD naming scheme maps device names and minor numbers to whole DASDs and to partitions.

The DASD device driver uses the major number 94. For each configured device it uses 4 minor numbers:

- The first minor number always represents the device as a whole, including IPL, VTOC and label records.
- The remaining three minor numbers represent the up to three partitions.

With 1,048,576 (20-bit) available minor numbers, the DASD device driver can address 262,144 devices.

The DASD device driver uses a device name of the form `dasd<x>` for each DASD. In the name, `<x>` is one to four lowercase letters. Table 6 shows how the device names map to the available minor numbers.

Table 6. Mapping of DASD names to minor numbers

Name for device as a whole		Minor number for device as a whole		Number of devices
From	To	From	To	
dasda	dasdz	0	100	26
dasdaa	dasdzz	104	2804	676
dasdaaa	dasdzzz	2808	73108	17,576
dasdaaaa	dasdnwtl	73112	1048572	243,866

Table 6. Mapping of DASD names to minor numbers (continued)

Name for device as a whole		Minor number for device as a whole		Number of devices
From	To	From	To	
Total number of devices:				262,144

The DASD device driver also uses a device name for each partition. The name of the partition is the name of the device as a whole with a 1, 2, or 3 appended to identify the first, second, or third partition. The three minor numbers following the minor number of the device as a whole are the minor number for the first, second, and third partition.

Examples:

- “dasda” refers to the whole of the first disk in the system and “dasda1”, “dasda2”, and “dasda3” to the three partitions. The minor number for the whole device is 0. The minor numbers of the partitions are 1, 2, and 3.
- “dasdz” refers to the whole of the 101st disk in the system and “dasdz1”, “dasdz2”, and “dasdz3” to the three partitions. The minor number for the whole device is 100. The minor numbers of the partitions are 101, 102, and 103.
- “dasdaa” refers to the whole of the 102nd disk in the system and “dasdaa1”, “dasdaa2”, and “dasdaa3” to the three partitions. The minor number for the whole device is 104. The minor numbers of the partitions are 105, 106, and 107.

DASD device nodes

Red Hat Enterprise Linux 6.3 uses udev to create multiple device nodes for each DASD that is online.

Device nodes based on device names

udev creates device nodes that match the device names used by the kernel. These standard device nodes have the form `/dev/<name>`.

The mapping between standard device nodes and the associated physical disk space can change, for example, when you reboot Linux. To ensure that you access the intended physical disk space, you need device nodes that are based on properties that identify a particular DASD.

To help you identify a particular disk, udev creates additional devices nodes that are based on the disk's bus ID, the disk label (VOLSER), and information about the file system on the disk. The file system information can be a universally unique identifier (UUID) and, if available, the file system label.

Device nodes based on bus IDs

udev creates device nodes of the form

`/dev/disk/by-path/ccw-<device_bus_id>`

for whole DASD and

`/dev/disk/by-path/ccw-<device_bus_id>-part<n>`

for the <n>th partition.

Device nodes based on VOLSERs

udev creates device nodes of the form

`/dev/disk/by-id/ccw-<volser>`

for whole DASD and
`/dev/disk/by-id/ccw-<volser>-part<n>`

for the <n>th partition.

When using device nodes based on VOLSER, be sure that the VOLSERS in your environment are unique (see “Volume label” on page 30).

If you assign the same VOLSER to multiple devices, Linux can access all of them through the device nodes that are based on the corresponding device names. However, only one of them can be accessed through the VOLSER-based device node. This makes the node ambiguous and should be avoided.

Furthermore, if the VOLSER on the device that is addressed by the node is changed, the previously hidden device is not automatically addressed instead. This requires a reboot or the Linux kernel needs to be forced to reread the partition tables from disks, for example, by issuing:

```
# blockdev --rereadpt /dev/dasdzzz
```

You can assign VOLSERS to ECKD-type devices with **dasdfmt** when formatting or later with **fdasd** when creating partitions.

Device nodes based on file system information

udev creates device nodes of the form
`/dev/disk/by-uuid/<uuid>`

where <uuid> is the UUID for the file system in a partition.

If a file system label has been assigned, udev also creates a node of the form

`/dev/disk/by-label/<label>`

There are no device nodes for the whole DASD that are based on file system information.

When using device nodes based on file system labels, be sure that the labels in your environment are unique.

Additional device nodes

`/dev/disk/by-id` contains additional device nodes for the DASD and partitions, that are all based on a device identifier as contained in the `uid` attribute of the DASD.

Note: When using device nodes that are based on file system information and VOLSER be sure that they are unique for the scope of your Linux instance. This information can be changed by a user or it can be copied, for example when creating a backup disk. If two disks with the same VOLSER or UUID are online to the same Linux instance, the matching device node can point to either of these disks.

Example: For a DASD that is assigned the device name `dasdzzz`, has two partitions, a device bus-ID `0.0.b100` (device number `0xb100`), VOLSER `LNK001`, and a UUID `6dd6c43d-a792-412f-a651-0031e631caed` for the first and `f45e955d-741a-4cf3-86b1-380ee5177ac3` for the second partition, udev creates the following device nodes:

For the whole DASD:

- /dev/dasdzzz (standard device node according to the DASD naming scheme)
- /dev/disk/by-path/ccw-0.0.b100
- /dev/disk/by-id/ccw-LNX001

For the first partition:

- /dev/dasdzzz1 (standard device node according to the DASD naming scheme)
- /dev/disk/by-path/ccw-0.0.b100-part1
- /dev/disk/by-id/ccw-LNX001-part1
- /dev/disk/by-uuid/6dd6c43d-a792-412f-a651-0031e631caed

For the second partition:

- /dev/dasdzzz2 (standard device node according to the DASD naming scheme)
- /dev/disk/by-path/ccw-0.0.b100-part2
- /dev/disk/by-id/ccw-LNX001-part2
- /dev/disk/by-uuid/f45e955d-741a-4cf3-86b1-380ee5177ac3

Accessing DASD by udev-created device nodes

Use udev-created device nodes to access a particular physical disk space, regardless of the device name that is assigned to it.

The example in this section uses device nodes that are based on the bus ID. You can adapt this example to the other device nodes described in “DASD device nodes” on page 34. The device nodes you can use depend on your setup.

Example:

The examples in this section assume that udev provides device nodes as described in “DASD device nodes” on page 34. To assure that you are addressing a device with bus ID 0.0.b100 you could make substitutions like the following.

Instead of issuing:

```
# fdasd /dev/dasdzzz
```

issue:

```
# fdasd /dev/disk/by-path/ccw-0.0.b100
```

In the file system information in /etc/fstab you could replace the following specifications:


```
/dev/dasdzzz1 /temp1 ext3 defaults 0 0  
/dev/dasdzzz2 /temp2 ext3 defaults 0 0
```

with these specifications:

```
/dev/disk/by-path/ccw-0.0.b100-part1 /temp1 ext3 defaults 0 0  
/dev/disk/by-path/ccw-0.0.b100-part2 /temp2 ext3 defaults 0 0
```

Setting up the DASD device driver

Unless the DASD device driver modules are loaded for you during the boot process, load and configure them with the **modprobe** command.



Where:

dasd_mod

loads the device driver base module.

When loading the base module you can specify the `dasd=` parameter.

You can use the `eer_pages` parameter to determine the number of pages used for internal buffering of error records.

autodetect

causes the DASD device driver to allocate device names and the corresponding minor numbers to all DASD devices and set them online during the boot process. See “DASD naming scheme” on page 33 for the naming scheme.

The device names are assigned in order of ascending subchannel numbers. Auto-detection can yield confusing results if you change your I/O configuration and reboot, or if your Linux instance runs as a z/VM guest because the devices might appear with different names and minor numbers after rebooting.

probeonly

causes the DASD device driver to reject any “open” syscall with EPERM.

autodetect,probeonly

causes the DASD device driver to assign device names and minor numbers as for auto-detect. All devices regardless of whether or not they are accessible as DASD return EPERM to any “open” requests.

nopav suppresses parallel access volume (PAV and HyperPAV) enablement for Linux instances that run in LPAR mode. The **nopav** keyword has no effect for Linux on z/VM.

nofcx suppresses accessing the storage server using the I/O subsystem in transport mode (also known as High Performance FICON).

<device_bus_id>
specifies a single DASD.

<from_device_bus_id>-<to_device_bus_id>
specifies the first and last DASD in a range. All DASD devices with bus IDs in the range are selected. The device bus-IDs **<from_device_bus_id>** and **<to_device_bus_id>** need not correspond to actual DASD.

(ro) specifies that the given device or range is to be accessed in read-only mode.

(diag) forces the device driver to access the device (range) using the DIAG access method.

(erplog)
enables enhanced error recovery processing (ERP) related logging through syslogd. If **erplog** is specified for a range of devices, the logging is switched on during device initialization.

(failfast)
returns “failed” for an I/O operation when the last path to a DASD is lost. Use this option with caution (see “Switching immediate failure of I/O requests on or off” on page 47).

dasd_eckd_mod
loads the ECKD module.

dasd_fba_mod
loads the FBA module.

dasd_diag_mod
loads the DIAG module.

If you supply a DASD module parameter with device specifications **dasd=<device-list1>,<device-list2> ...** the device names and minor numbers are assigned in the order in which the devices are specified. The names and corresponding minor numbers are always assigned, even if the device is not present, or not accessible. For information about including device specifications in a boot configuration, see “Including module parameters in a boot configuration” on page 24.

If you use **autodetect** in addition to explicit device specifications, device names are assigned to the specified devices first and device-specific parameters, like **ro**, are honored. The remaining devices are handled as described for **autodetect**.

The DASD base component is required by the other modules. **modprobe** takes care of this dependency for you and ensures that the base module is loaded automatically, if necessary.

Hint: **modprobe** might return before udev has created all device nodes for the specified DASDs. If you need to assure that all nodes are present, for example in scripts, follow the **modprobe** command with:

```
# udevadm settle
```

For command details see the **modprobe** man page.

Example:

The following example specifies a range of DASD devices and two individual DASD devices:

```
modprobe dasd_mod dasd=0.0.7000-0.0.7002,0.0.7005(ro),0.0.7006
```

Table 7 shows the resulting allocation of device names:

Table 7. Example mapping of device names to devices

Name	To access
dasda	device 0.0.7000 as a whole
dasda1	the first partition on 0.0.7000
dasda2	the second partition on 0.0.7000
dasda3	the third partition on 0.0.7000
dasdb	device 0.0.7001 as a whole
dasdb1	the first partition on 0.0.7001
dasdb2	the second partition on 0.0.7001
dasdb3	the third partition on 0.0.7001
dasdc	device 0.0.7002 as a whole
dasdc1	the first partition on 0.0.7002
dasdc2	the second partition on 0.0.7002
dasdc3	the third partition on 0.0.7002
dasdd	device 0.0.7005 as a whole
dasdd1	the first partition on 0.0.7005 (read-only)
dasdd2	the second partition on 0.0.7005 (read-only)
dasdd3	the third partition on 0.0.7005 (read-only)
dasde	device 0.0.7006 as a whole
dasde1	the first partition on 0.0.7006
dasde2	the second partition on 0.0.7006
dasde3	the third partition on 0.0.7006

The following example specifies that High Performance FICON should be suppressed for all DASD:

```
modprobe dasd_mod dasd=nofcx,4711-4713
```

Working with DASD devices

You might have to prepare DASD for use, configure troubleshooting functions, or configure special device features for your DASDs.

- “Preparing an ECKD-type DASD for use” on page 40
- “Preparing an FBA-type DASD for use” on page 42
- “Accessing DASD by force” on page 42

- “Enabling DIAG calls to access DASDs” on page 43
- “Working with extended error reporting for ECKD” on page 45
- “Switching extended error reporting on and off” on page 45
- “Setting a DASD online or offline” on page 45
- “Enable and disable logging” on page 46
- “Switching immediate failure of I/O requests on or off” on page 47
- “Setting the timeout for I/O requests” on page 47
- “Working with DASD statistics in debugfs” on page 48
- “Accessing full ECKD tracks” on page 52
- “Handling lost device reservations” on page 54
- “Reading and resetting the reservation state” on page 55
- “Displaying DASD information” on page 56

Most of these tasks involve writing to and reading from device attributes in sysfs. This is useful on a running system where you want to make dynamic changes. If you want to make the changes persistent across IPLs, use the configuration file `/etc/zipl.conf` for DASDs that are part of the root file system and `/etc/dasd.conf` for data disks. An example of how to define a DASD device persistently is in *Red Hat Enterprise Linux 6.3 Installation Guide*. For a general discussion of configuration files, see *Red Hat Enterprise Linux 6.3 Deployment Guide*.

See “Working with newly available devices” on page 10 to avoid errors when working with devices that have become available to a running Linux instance.

Preparing an ECKD-type DASD for use

Before you can use an ECKD-type DASD as a Linux on System z disk, you must format it with a suitable disk layout and create a file system or define a swap space.

If you format the DASD with the compatible disk layout, you need to create one, two, or three partitions. You can then use your partitions as swap areas or to create a Linux file system.

Before you begin:

- The modules for the base component and the ECKD component of the DASD device driver must have been loaded.
- The DASD device driver must have recognized the device as an ECKD-type device.
- You need to know the device node through which the DASD can be addressed.

Perform these steps to prepare the DASD:

1. Format the device with the **`dasdfmt`** command (see “`dasdfmt` - Format a DASD” on page 423 for details). The formatting process can take hours for large DASD.

Tips:

- Use the default `-d cdl` option. This option formats the DASD with the IBM compatible disk layout that permits you to create partitions on the disk.
- Use the largest possible block size, ideally 4096; the net capacity of an ECKD DASD decreases for smaller block sizes. For example, a DASD formatted with a block size of 512 byte has only half of the net capacity of the same DASD formatted with a block size of 4096 byte.

- Use the `-p` option to display a progress bar.

Example:

```
dasdfmt -b 4096 -d cd1 -p /dev/dasdzzz
```

2. Proceed according to your chosen disk layout:

- If you have formatted your DASD with the Linux disk layout, skip this step and continue with step 3. You already have one partition and cannot add further partitions on your DASD.
- If you have formatted your DASD with the compatible disk layout use the **fdasd** command to create up to three partitions (see “fdasd – Partition a DASD” on page 438 for details).

Example: To start the partitioning tool in interactive mode for partitioning a device `/dev/dasdzzz` issue:

```
fdasd /dev/dasdzzz
```

If you create three partitions for a DASD `/dev/dasdzzz`, the device nodes for the partitions are: `/dev/dasdzzz1`, `/dev/dasdzzz2`, and `/dev/dasdzzz3`.

Result: **fdasd** creates the partitions and updates the partition table (see “VTOC” on page 30).

3. Depending on the intended use of each partition, create a file system on the partition or define it as a swap space.

Either: Create a file system of your choice. For example, use the Linux **mkfs.ext4** command to create an ext4 file system (see the man page for details).

Note: Do not make the block size of the file system smaller than that used for formatting the disk with the **dasdfmt** command.

Recommendation: Use the same block size for the file system that has been used for formatting.

Example:

```
# mkfs.ext4 -b 4096 /dev/DASDzzz1
```

Or: Define the partition as a swap space with the **mkswap** command (see the man page for details).

4. Mount each file system to the mount point of your choice in Linux and enable your swap partitions.

Example: To mount a file system in a partition `/dev/dasdzzz1` to a mount point `/mnt` and to enable a swap partition `/dev/dasdzzz2` issue:

```
# mount /dev/dasdzzz1 /mnt
# swapon /dev/dasdzzz2
```

If a block device supports barrier requests, journaling file systems like ext3 or reiserfs can make use of this feature to achieve better performance and data integrity. Barrier requests are supported for the DASD device driver and apply to ECKD, FBA, and the DIAG discipline.

Write barriers are used by file systems and are enabled as a file-system-specific option. For example, barrier support can be enabled for an ext3 file system by mounting it with the option `-o barrier=1`:

```
mount -o barrier=1 /dev/dasdzzz1 /mnt
```

Preparing an FBA-type DASD for use

Before you can use an FBA-type DASD as a Linux on System z disk, you must create a file system or define a swap space.

Note: To access FBA devices, use the DIAG access method (see “Enabling DIAG calls to access DASDs” on page 43 for more information).

Before you begin:

- The modules for the base component and the FBA component of the DASD device driver must have been loaded.
- The DASD device driver must have recognized the device as an FBA device.
- You need to know the device bus-ID or the device node through which the DASD can be addressed.

Perform these steps to prepare the DASD:

1. Depending on the intended use of the partition, create a file system on it or define it as a swap space.

Either: Create a file system of your choice. For example, use the Linux **mkfs.ext4** command to create an ext4 file system (see the man page for details).

Example:

```
mkfs.ext4 -b 4096 /dev/dasdzzz1
```

Or: Define the partition as a swap space with the **mkswap** command (see the man page for details).

2. Mount the file system to the mount point of your choice in Linux or enable your swap partition.

Example: To mount a file system in a partition `/dev/dasdzzz1` issue:

```
# mount /dev/dasdzzz1 /mnt
```

Accessing DASD by force

When a Linux instance boots in a mainframe environment, it can encounter DASDs that are locked by another system.

Such a DASD is referred to as “externally locked” or “boxed”. The Linux instance cannot analyze a DASD while it is externally locked.

To check if a DASD has been externally locked, read its availability attribute. This attribute should be “good”. If it is “boxed”, the DASD has been externally locked. Because boxed DASD might not be recognized as DASD, it might not show up in the device driver view in `sysfs`. If necessary, use the device category view instead (see “Device views in `sysfs`” on page 10).

Issue a command of this form:

```
# cat /sys/bus/ccw/devices/<device_bus_id>/availability
```

Example: This example shows that a DASD with device bus-ID 0.0.b110 (device number 0xb110) has been externally locked.

```
# cat /sys/bus/ccw/devices/0.0.b110/availability  
boxed
```

If the DASD is an ECKD-type DASD and if you know the device bus-ID, you can break the external lock and set the device online. This means that the lock of the external system is broken with the “unconditional reserve” channel command.

CAUTION:

Breaking an external lock can have unpredictable effects on the system that holds the lock.

To force a boxed DASD online write “force” to the online device attribute. Issue a command of this form:

```
# echo force > /sys/bus/ccw/devices/<device_bus_id>/online
```

If the external lock is successfully broken or if the lock has been surrendered by the time the command is processed, the device is analyzed and set online. If it is not possible to break the external lock (for example, because of a timeout, or because it is an FBA-type DASD), the device remains in the boxed state. This command might take some time to complete.

Example: To force a DASD with device number 0xb110 online issue:

```
# echo force > /sys/bus/ccw/devices/0.0.b110/online
```

For information about breaking the lock of a DASD that has already been analyzed see “tunedasd - Adjust DASD performance” on page 504.

Enabling DIAG calls to access DASDs

Linux on z/VM can use DIAG calls to access DASDs with the help of z/VM functions.

Before you begin: This section only applies to Linux instances and DASD for which all of the following are true:

- The Linux instance runs as a z/VM guest.
- The device can be of type ECKD with either LDL or CMS disk layout, or it can be a device of type FBA.
- The module for the DIAG component must be loaded.
- The module for the component that corresponds to the DASD type (dasd_eckd_mod or dasd_fba_mod) must be loaded.
- The DASD is offline.
- The DASD does not represent a parallel access volume alias device.

You can use DIAG calls to access both ECKD- and FBA-type DASD. You use the device's use_diag sysfs attribute to enable or switch off DIAG calls in a system that

is online. Set the `use_diag` attribute to “1” to enable DIAG calls. Set the `use_diag` attribute to “0” to switch off DIAG calls (this is the default).

Alternatively, you can specify “diag” on the command line, for example during IPL, to force the device driver to access the device (range) using the DIAG access method.

Issue a command of this form:

```
# echo <flag> > /sys/bus/ccw/devices/<device_bus_id>/use_diag
```

Where:

`<device_bus_id>`
identifies the DASD.

If DIAG calls are not available and you set the `use_diag` attribute to “1”, you will not be able to set the device online (see “Setting a DASD online or offline” on page 45).

Note: When switching between enabled and disabled DIAG calls on FBA-type DASD, first re-initialize the DASD, for example, with CMS format or by overwriting any previous content. Switching without initialization might cause data-integrity problems.

For more details about DIAG see *z/VM CP Programming Services*, SC24-6179.

Example:

In this example, DIAG calls are enabled for a DASD with device number 0xb100.

Note: You can only use the `use_diag` attribute when the device is offline.

1. Ensure that the driver is loaded:

```
# modprobe dasd_diag_mod
```

2. Identify the sysfs CCW-device directory for the device in question and change to that directory:

```
# cd /sys/bus/ccw/devices/0.0.b100/
```

3. Ensure that the device is offline:

```
# echo 0 > online
```

4. Enable the DIAG access method for this device by writing '1' to the `use_diag` sysfs attribute:

```
# echo 1 > use_diag
```

5. Use the `online` attribute to set the device online:

```
# echo 1 > online
```

Working with extended error reporting for ECKD

Use file operations on the character device of the extended error reporting module to obtain error records.

You can perform these file operations:

open

Multiple processes can open the node concurrently. Each process that opens the node has access to the records that are created from the time the node is opened. A process cannot access records that were created before the process opened the node.

close

You can close the node as usual.

read

Blocking read as well as non-blocking read is supported. When a record is partially read and then purged, the next read returns an I/O error -EIO.

poll

The poll operation is typically used in conjunction with non-blocking read.

Switching extended error reporting on and off

Control extended error reporting through the `eer_enabled` sysfs attribute.

Extended error reporting is turned off by default. To turn extended error reporting on, issue a command of this form:

```
# echo 1 > /sys/bus/ccw/devices/<device_bus_id>/eer_enabled
```

where `/sys/bus/ccw/devices/<device_bus_id>` represents the device in sysfs.

When it is enabled on a device, a specific set of errors will generate records and may have further side effects. The records are made available via a character device interface.

To switch off extended error reporting issue a command of this form:

```
# echo 0 > /sys/bus/ccw/devices/<device_bus_id>/eer_enabled
```

Setting a DASD online or offline

Use the **chccwdev** command or the `online` sysfs attribute of the device to set DASDs online or offline.

When Linux boots, it senses your DASD. Depending on your specification for the `"dasd="` parameter, it automatically sets devices online.

Use the **chccwdev** command ("**chccwdev** - Set a CCW device online" on page 396) to set a DASD online or offline. Alternatively, you can write `"1"` to the device's `online` attribute to set it online or `"0"` to set it offline.

When you set a DASD offline, the deregistration process is synchronous, unless the device is disconnected. For disconnected devices the deregistration process is asynchronous.

Examples:

- To set a DASD with device bus-ID 0.0.b100 online, issue:

```
# chccwdev -e 0.0.b100
```

or

```
# echo 1 > /sys/bus/ccw/devices/0.0.b100/online
```

- To set a DASD with device bus-ID 0.0.b100 offline, issue:

```
# chccwdev -d 0.0.b100
```

or

```
# echo 0 > /sys/bus/ccw/devices/0.0.b100/online
```

Dynamic attach and detach:

You can dynamically attach devices to a running Red Hat Enterprise Linux 6.3 for System z instance, for example, from z/VM.

When a DASD is attached, Linux attempts to initialize it according to the DASD device driver configuration. You can then set the device online. You can automate setting dynamically attached devices online by using CCW hotplug events (see “CCW hotplug events” on page 16).

Note

Do not detach a device that is still being used by Linux. Detaching devices might cause the system to hang or crash. Ensure that you unmount a device and set it offline before you detach it.

See “Working with newly available devices” on page 10 to avoid errors when working with devices that have become available to a running Linux instance.

Enable and disable logging

Use the `dasd=` kernel or module parameter or use the `erplog` sysfs attribute to enable or disable error recovery processing (ERP) logging.

You can enable and disable error recovery processing (ERP) logging on a running system. There are two methods for doing this:

- Enable logging during module load using the `dasd=` parameter.

For example, to define a device range (0.0.7000-0.0.7005) and switch on logging, change the parameter line to contain:

```
dasd=0.0.7000-0.0.7005(erplog)
```

- Use the sysfs attribute `erplog` to switch ERP-related logging on or off.

Logging can be enabled for a specific device by writing “1” to the `erplog` attribute, for example:

```
echo 1 > /sys/bus/ccw/devices/<device_bus_id>/erplog
```

To disable logging, write "0" to the `erpllog` attribute, for example:

```
echo 0 > /sys/bus/ccw/devices/<device_bus_id>/erpllog
```

Switching immediate failure of I/O requests on or off

Prevent devices in mirror setups from being blocked while paths are unavailable by making I/O requests fail immediately.

By default, if all path have been lost for a DASD, the corresponding device in Linux waits for one of the paths to recover. I/O requests are blocked while the device is waiting.

If the DASD is part of a mirror setup, this blocking might cause the entire virtual device to be blocked. You can use the `failfast` attribute to immediately return I/O requests as failed while no path to the device is available.

Use this attribute with caution and only in setups where a failed I/O request can be recovered outside the scope of a single DASD.

- You can switch on immediate failure of I/O requests when you load the base module of the DASD device driver:

For example, to define a device range (0.0.7000-0.0.7005) and enable immediate failure of I/O requests specify:

```
dasd=0.0.7000-0.0.7005(failfast)
```

- You can use the `sysfs` attribute `failfast` of a DASD to switch immediate failure of I/O requests on or off.

To switch on immediate failure of I/O requests, write "1" to the `failfast` attribute, for example:

```
echo 1 > /sys/bus/ccw/devices/<device_bus_id>/failfast
```

To switch off immediate failure of I/O requests, write "0" to the `failfast` attribute, for example:

```
echo 0 > /sys/bus/ccw/devices/<device_bus_id>/failfast
```

Setting the timeout for I/O requests

The timeout specifies how long Linux is to wait for a response from a storage server before considering an I/O requests failed and cancelling it.

The default timeout for DASD I/O requests depends on the type of DASD:

ECKD uses the default provided by the storage server.

FBA 300 s

DIAG 50 s

You can use the `expires` attribute of a DASD to change the timeout value for that DASD.

To find out the current timeout value issue a command of this form:

```
# cat /sys/bus/ccw/devices/<device_bus_id>/expires
```

To set the timeout to a different value issue a command of this form:

```
# echo <timeout> > /sys/bus/ccw/devices/<device_bus_id>/expires
```

where:

<timeout>

is the new timeout value in seconds. The value must be an integer in the range 1 to 40,000,000.

<device_bus_id>

is the device bus-ID of the DASD.

Example: This example reads the current timeout value and then sets it to 120 s.

```
# cat /sys/bus/ccw/devices/0.0.7008/expires
30
# echo 120 > /sys/bus/ccw/devices/0.0.7008/expires
```

Working with DASD statistics in debugfs

Gather DASD statistics and display the data with the **dasdstat** command.

Before you begin:

Instead of accessing raw DASD performance data in debugfs, you can use the **dasdstat** command to obtain more structured data (see “dasdstat - Display DASD performance statistics” on page 426).

The DASD performance data is contained in the following subdirectories of <mountpoint>/dasd, where <mountpoint> is the mount point of debugfs:

- A directory `global` that represents all available DASDs taken together.
- For each DASD, one directory with the name of the DASD block device with which the DASD is known to the DASD device driver (for example, `dasda`, `dasdb`, and `dasdc`).
- For each CCW device that corresponds to a DASD, a directory with the bus ID as the name.

Block devices that are not set up for PAV or HyperPAV map to exactly one CCW device and the corresponding directories contain the same statistics.

With PAV or HyperPAV, a bus ID can represent a base device or an alias device. Each base device is associated with a particular block device. The alias devices are not permanently associated with the same block device. At any one time, a DASD block device is associated with one or more CCW devices. Statistics that are based on bus ID, therefore, show additional detail for PAV and HyperPAV setups.

Each of these directories contains a file `statistics` that you can use to:

- Start and stop data gathering.
- Reset statistics counters.
- Read statistics.

To control data gathering at the scope of a directory in <mountpoint>/dasd, issue a command like this:


```
# echo <keyword> > <mountpoint>/dasd/<directory>/statistics
```

Where:

<directory>

is one of the directories in <mountpoint>/dasd.

<keyword>

specifies the action to be taken:

on to start data gathering.

off to stop data gathering.

reset to reset the statistics counters.

To read performance data, issue a command like this:

```
# cat <mountpoint>/dasd/<directory>/statistics
```

Examples for gathering and reading DASD statistics in debugfs

Use the **echo** command to start and stop data gathering for individual devices or across all DASDs. Use the **cat** command to access the raw performance data.

The following examples assume that debugfs has been mounted at /sys/kernel/debug, see “debugfs” on page xi.

- To start data gathering for summary data across all available DASDs:

```
# echo on > /sys/kernel/debug/dasd/global/statistics
```

- To stop data gathering for block device dasdb:

```
# echo off > /sys/kernel/debug/dasd/dasdb/statistics
```

- To reset the counters for CCW device 0.0.b301:

```
# echo reset > /sys/kernel/debug/dasd/0.0.b301/statistics
```

- To read performance data for dasda, assuming that the debugfs mount point is /sys/kernel/debug, issue:

[illegible]

Interpreting the data rows

The raw DASD performance data in the statistics directories in debugfs is organized into labelled data rows.

This section explains the raw data in the individual data rows of the statistics. Use the **dasdstat** command to obtain more structured data.

start_time

is the UNIX epoch time stamp when data gathering was started or when the counters were last reset.

Tip: Use the **date** tool to convert the time stamp to a more readily human readable format. See the **date** man page for details.

Single counters

have a single integer as the statistics data. All rows with labels that begin with `total` are of this data type.

The following rows show data for the sum of all requests, read and write:

total_requests

is the number of requests that have been processed.

total_sectors

is the sum of the sizes of all requests, in units of 512 byte sectors.

total_pav

is the number of requests that were processed through a PAV alias device.

total_hpf

is the number of requests that used High Performance FICON.

The following rows show data for read requests only:

total_read_requests

is the number of read requests that have been processed.

total read sectors

is the sum of the sizes of all read requests, in units of 512 byte sectors.

| **total_read_pav**

| is the number of read requests that were processed through a PAV
| alias device.

| **total_read_hpf**

| is the number of read requests that used High Performance
| FICON.

| **Linear histograms**

| have a series of 32 integers as the statistics data. The integers represent a
| histogram, with a linear scale, of the number of requests in the request
| queue each time a request has been queued. The first integer shows how
| often the request queue contained zero requests, the second integer shows
| how often the queue contained one requests, and the n-th value shows
| how often the queue contained n-1 requests.

| **histogram_ccw_queue_length**

| is the histogram data for all requests, read and write.

| **histogram_read_ccw_queue_length**

| is the histogram data for read requests only.

| **Logarithmic histograms**

| have a series of 32 integers as the statistics data. The integers represent a
| histogram with a logarithmic scale:

- | • The first integer always represents all measures of less than 4 units
- | • The second integer represents measures of 4 or more but less than 8
| units
- | • The third integer represents measures of 8 or more but less than 16 units
- | • The n-th integer ($1 < n < 32$) represents measures of 2^n or more but less
| than 2^{n+1} units
- | • The 32nd integer represents measures of 2^{32} ($= 4G = 4,294,967,296$) units
| or more.

| The following rows show data for the sum of all requests, read and write:

| **histogram_sectors**

| is the histogram data for request sizes. A unit is a 512 byte sector.

| **histogram_io_times**

| is the histogram data for the total time needed from creating the
| cqr to its completion in the DASD device driver and return to the
| block layer. A unit is a microsecond.

| **histogram_io_times_weighted**

| is the histogram data of the total time, as the measured for
| histogram_io_times, divided by the requests size in sectors. A unit
| is a microsecond/sector.

| This metric is deprecated and there is no corresponding histogram
| data for read requests.

| **histogram_time_build_to_ssch**

| is the histogram data of the time needed from creating the cqr to
| submitting the request to the subchannel. A unit is a microsecond.

| **histogram_time_ssch_to_irq**

| is the histogram data of the time needed from submitting the
| request to the subchannel until an interrupt indicates that the
| request has been completed. A unit is a microsecond.

| **histogram_time_ssch_to_irq_weighted**

| is the histogram data of the time needed from submitting the
| request to the subchannel until an interrupt indicates that the
| request has been completed, divided by the request size in 512 byte
| sectors. A unit is a microsecond/sector.

| This metric is deprecated and there is no corresponding histogram
| data for read requests.

| **histogram_time_irq_to_end**

| is the histogram data of the time needed from return of the request
| from the channel subsystem, until the request is returned to the
| blocklayer. A unit is a microsecond.

| The following rows show data for read requests only:

| **histogram_read_sectors**

| is the histogram data for read request sizes. A unit is a 512 byte
| sector.

| **histogram_read_io_times**

| is the histogram data, for read requests, for the total time needed
| from creating the cqr to its completion in the DASD device driver
| and return to the block layer. A unit is a microsecond.

| **histogram_read_time_build_to_ssch**

| is the histogram data, for read requests, of the time needed from
| creating the cqr to submitting the request to the subchannel. A unit
| is a microsecond.

| **histogram_read_time_ssch_to_irq**

| is the histogram data, for read requests, of the time needed from
| submitting the request to the subchannel until an interrupt
| indicates that the request has been completed. A unit is a
| microsecond.

| **histogram_read_time_irq_to_end**

| is the histogram data, for read requests, of the time needed from
| return of the request from the channel subsystem, until the request
| is returned to the blocklayer. A unit is a microsecond.

Accessing full ECKD tracks

In raw-track access mode, the DASD device driver accesses full ECKD tracks, including record zero and the count and key data fields.

With this mode, Linux can access an ECKD device regardless of the track layout. In particular, the device does not need to be formatted for Linux.

For example, with raw-track access mode Linux can create a backup copy of any ECKD device. Full-track access can also enable a special program that runs on Linux to access and process data on an ECKD device that is not formatted for Linux.

By default, the DASD device driver accesses only the data fields of ECKD devices. In default access mode, you can work with partitions, file systems, and files in the file systems on the DASD.

When using a DASD in raw-track access mode be aware that:

- In memory, each track is represented by 64 KB of data, even if the track occupies less physical disk space. Therefore, a disk in raw-track access mode appears bigger than in default mode.
- Programs must read or write data in multiples of complete 64 KB tracks. The minimum is a single track. The maximum is 8 tracks by default but can be extended to up to 16 tracks.

The maximum number of tracks depends on the maximum number of sectors as specified in the `max_sectors_kb` sysfs attribute of the DASD. This attribute is located in the block device branch of sysfs at `/sys/block/dasd<x>/queue/max_sectors_kb`. In the path, `dasd<x>` is the device name assigned by the DASD device driver.

To extend the maximum beyond 8 tracks, set the `max_sectors_kb` to the maximum amount of data to be processed in a single read or write operation. For example, to extend the maximum to reading or writing 16 tracks at a time, set `max_sectors_kb` to 1024 (16 x 64).

- Programs must only write valid ECKD tracks of 64 KB.
- Programs must use direct I/O to prevent the Linux block layer from splitting tracks into fragments. Open the block device with option `O_DIRECT` or work with programs that use direct I/O.

For example, the options `iflag=direct` and `oflag=direct` cause **dd** to use direct I/O. When using **dd**, also specify the block size with the `bs=` option. The block size determines the number of tracks that are processed in a single I/O operation. The block size must be a multiple of 64 KB and can be up to 1024 KB. Specifying a larger block size often results in better performance.

Tools cannot directly work with partitions, file systems, or files within a file system. For example, **fdasd** and **dasdfmt** cannot be used.

Before you begin:

- This section applies to ECKD type DASD only.
- The DASD has to be offline when you change the access mode.
- DIAG access must not be enabled for the device.

To change the access mode issue a command of this form:

```
# echo <switch> > /sys/bus/ccw/devices/<device_bus_id>/raw_track_access
```

where:

`<switch>`

is 1 to activate raw data access and 0 to deactivate raw data access.

`<device_bus_id>`

identifies the DASD.

Example:

The following example creates a backup of a DASD 0.0.7009 on a DASD 0.0.70a1.

The initial commands ensure that both devices are offline and that DIAG calls are not enabled for either of them. The subsequent commands activate the raw-track access mode for the two devices and set them both online. The **lsdasd** command that follows shows the mapping between device bus-IDs and device names.

The **dd** command for the copy operation specifies direct I/O for both the input and output device and the block size of 1024 KB. After the copy operation is completed, both devices are set offline. The access mode for the original device is then set back to the default and the device is set back online.

```
#cat /sys/bus/ccw/devices/0.0.7009/online
1
# chccwdev -d 0.0.7009
#cat /sys/bus/ccw/devices/0.0.7009/use_diag
0
#cat /sys/bus/ccw/devices/0.0.70a1/online
0
#cat /sys/bus/ccw/devices/0.0.70a1/use_diag
0
# echo 1 > /sys/bus/ccw/devices/0.0.7009/raw_track_access
# echo 1 > /sys/bus/ccw/devices/0.0.70a1/raw_track_access
# chccwdev -e 0.0.7009,0.0.70a1
# lsdasd 0.0.7009 0.0.70a1
Bus-ID      Status      Name      Device  Type  BlkSz  Size      Blocks
=====
0.0.7009    active      dasdf     94:20   ECKD  4096   7043MB    1803060
0.0.70a1    active      dasdj     94:36   ECKD  4096   7043MB    1803060
# echo 1024 > /sys/block/dasdf/queue/max_sectors_kb
# echo 1024 > /sys/block/dasdj/queue/max_sectors_kb
# dd if=/dev/dasdf of=/dev/dasdj bs=1024k iflag=direct oflag=direct
# chccwdev -d 0.0.7009,0.0.70a1
# echo 0 > /sys/bus/ccw/devices/0.0.7009/raw_track_access
# chccwdev -e 0.0.7009
```

Handling lost device reservations

A DASD reservation by your Linux instance can be lost if another system unconditionally reserves this DASD.

This other system then has exclusive I/O access to the DASD for the duration of the unconditional reservation. Such unconditional reservations can be useful for handling error situations where:

- Your Linux instance cannot gracefully release the DASD.
- Another system requires access to the DASD, for example, to perform recovery actions.

After the DASD is released by the other system, your Linux instance might process pending I/O requests and write faulty data to the DASD. How to prevent pending I/O requests from being processed depends on the reservation policy. There are two reservation policies:

- ignore** All I/O operations for the DASD are blocked until the DASD is released by the second system. When using this policy, reboot your Linux instance before the other system releases the DASD. This policy is the default.
- fail** All I/O operations are returned as failed until the DASD is set offline or until the reservation state is reset. When using this policy, set the DASD offline and back online after the problem has been resolved. See “Reading and resetting the reservation state” on page 55 about resetting the reservation state to resume operations.

Set the reservation policy with a command of this form:

```
# echo <policy> > /sys/bus/ccw/devices/<device_bus_id>/reservation_policy
```

where:

`<device_bus_id>`
specifies the DASD.

`<policy>`
is one of the available policies, ignore or fail.

Examples:

- The command of this example sets the reservation policy for a DASD with bus ID 0.0.7009 to fail.

```
# echo fail > /sys/bus/ccw/devices/0.0.7009/reservation_policy
```

- This example shows a small scenario. The first two commands confirm that the reservation policy of the DASD is fail and that the reservation has been lost to another system. Assuming that the error that had occurred has already been resolved and that the other system has released the DASD, operations with the DASD are resumed by setting it offline and back online.

```
# cat /sys/bus/ccw/devices/0.0.7009/reservation_policy
fail
# cat /sys/bus/ccw/devices/0.0.7009/last_known_reservation_state
lost
# chccwdev -d 0.0.7009
# chccwdev -e 0.0.7009
```

Reading and resetting the reservation state

How the DASD device driver handles I/O requests depends on the `last_known_reservation_state` sysfs attribute of the DASD.

This attribute reflects the reservation state as held by the DASD device driver and can differ from the actual reservation state. Use the **tunedasd -Q** command to find out the actual reservation state. The `last_known_reservation_state` sysfs attribute can have the following values:

none The DASD device driver has no information about the device reservation state. I/O requests are processed as usual. If the DASD has been reserved by another system, the I/O requests remain in the queue until they time out, or until the reservation is released.

reserved

The DASD device driver holds a valid reservation for the DASD and I/O requests are processed as usual. The DASD device driver changes this state if notified that the DASD is no longer reserved to this system. The new state depends on the reservation policy (see “Handling lost device reservations” on page 54):

ignore The state is changed to none.

fail The state is changed to lost.

lost The DASD device driver had reserved the DASD, but subsequently another system has unconditionally reserved the DASD (see “Handling lost device reservations” on page 54). The device driver processes only requests that query the actual device reservation state. All other I/O requests for the device are returned as failed.

When the error that has led another system to unconditionally reserve the DASD has been resolved and the DASD has been released by this other system there are two methods for resuming operations:

- Setting the DASD offline and back online.
- Resetting the reservation state of the DASD.

Attention: Do not resume operations by resetting the reservation state unless your system setup maintains data integrity on the DASD despite:

- The I/O errors caused by the unconditional reservation
- Any changes to the DASD through the other system

You reset the reservation state by writing `reset` to the `last_known_reservation_state` sysfs attribute of the DASD. Resetting is possible only for the `fail` reservation policy (see “Handling lost device reservations” on page 54) and only while the value of the `last_known_reservation_state` attribute is `lost`.

To find out the reservation state of a DASD issue a command of this form:

```
# cat /sys/bus/ccw/devices/<device_bus_id>/last_known_reservation_state
```

where `<device_bus_id>` specifies the DASD.

Example:

The command in this example queries the reservation state of a DASD with bus ID `0.0.7009`.

```
# cat /sys/bus/ccw/devices/0.0.7009/last_known_reservation_state
reserved
```

Displaying DASD information

Use tools to display information about your DASDs, or read the attributes of the devices in sysfs.

There are several methods to display DASD information:

- Use **lsdasd -l** (see “lsdasd - List DASD devices” on page 461) to display summary information about the device settings and the device geometry of multiple DASDs.
- Use **dasdview** (see “dasdview - Display DASD structure” on page 429) to display details about the contents of a particular DASD.
- Read information about a particular DASD from sysfs, as described in this section.

The sysfs representation of a DASD is a directory of the form `/sys/bus/ccw/devices/<device_bus_id>`, where `<device_bus_id>` is the bus ID of the DASD. This sysfs directory contains a number of attributes with information about the DASD.

Table 8. DASD device attributes

Attribute	Explanation
alias	<p>1 if the DASD is a parallel access volume (PAV) alias device. 0 if the DASD is a PAV base device or has not been set up as a PAV device.</p> <p>For an example of how to use PAV see <i>How to Improve Performance with PAV</i>, SC33-8414 on developerWorks® at www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html</p> <p>This attribute is read-only.</p>
discipline	<p>Indicates the base discipline, ECKD or FBA, that is used to access the DASD. If DIAG is enabled, this attribute might read DIAG instead of the base discipline.</p> <p>This attribute is read-only.</p>
eer_enabled	<p>1 if the DASD is enabled for extended error reporting, 0 if it is not enabled (see “Switching extended error reporting on and off” on page 45).</p>
erplug	<p>1 if error recovery processing (ERP) logging is enabled, 0 if ERP logging is not enabled (see “Enable and disable logging” on page 46).</p>
expires	<p>Indicates the time, in seconds, that Linux waits for a response to an I/O request for the DASD. If this time expires, Linux considers a request failed and cancels it (see “Setting the timeout for I/O requests” on page 47).</p>
failfast	<p>1 if I/O operations are returned as failed immediately when the last path to the DASD is lost. 0 if a wait period for a path to return expires before an I/O operation is returned as failed. (see “Switching immediate failure of I/O requests on or off” on page 47).</p>
online	<p>1 if the DASD is online, 0 if it is offline (see “Setting a DASD online or offline” on page 45).</p>
raw_track_access	<p>1 if the DASD is in raw-track access mode, 0 if it is in default access mode (see “Accessing full ECKD tracks” on page 52)</p>
readonly	<p>1 if the DASD is read-only, 0 if it can be written to. This attribute is a device driver setting and does not reflect any restrictions imposed by the device itself. This attribute is ignored for PAV alias devices.</p>

Table 8. DASD device attributes (continued)

Attribute	Explanation
status	<p>Reflects the internal state of a DASD device. Values can be:</p> <p>unknown Device detection has not started yet.</p> <p>new Detection of basic device attributes is in progress.</p> <p>detected Detection of basic device attributes has finished.</p> <p>basic The device is ready for detecting the disk layout. Low level tools can set a device to this state when making changes to the disk layout, for example, when formatting the device.</p> <p>unformatted The disk layout detection has found no valid disk layout. The device is ready for use with low level tools like dasdfmt.</p> <p>ready The device is in an intermediate state.</p> <p>online The device is ready for use.</p>
uid	<p>A device identifier of the form <code><vendor>.<serial>.<subsystem_id>.<unit_address>.<minidisk_identifier></code> where</p> <p><code><vendor></code> is the specification from the vendor attribute.</p> <p><code><serial></code> is the serial number of the storage system.</p> <p><code><subsystem_id></code> is the ID of the logical subsystem to which the DASD belongs on the storage system.</p> <p><code><unit_address></code> is the address used within the storage system to identify the DASD.</p> <p><code><minidisk_identifier></code> is an identifier that the z/VM system assigns to distinguish between minidisks on the DASD. This part of the uid is only present for Linux on z/VM and if the z/VM version and service level support this identifier.</p> <p>This attribute is read-only.</p>
use_diag	<p>1 if DIAG calls are enabled, 0 if DIAG calls are not enabled (see “Enabling DIAG calls to access DASDs” on page 43). Do not enable DIAG calls for PAV alias devices.</p>
vendor	<p>Identifies the manufacturer of the storage system that contains the DASD.</p> <p>This attribute is read-only.</p>

There are some more attributes that are common to all CCW devices (see “Device directories” on page 9).

Issue a command of this form to read an attribute:

```
# cat /sys/bus/ccw/devices/<device_bus_id>/<attribute>
```

where *<attribute>* is one of the attributes of Table 8 on page 57.

Example:

The following sequence of commands reads the attributes for a DASD with a device bus-ID 0.0.b100:

```
# cat /sys/bus/ccw/devices/0.0.b100/alias
0
# cat /sys/bus/ccw/devices/0.0.b100/discipline
ECKD
# cat /sys/bus/ccw/devices/0.0.b100/eer_enabled
0
# cat /sys/bus/ccw/devices/0.0.b100/erplog
0
# cat /sys/bus/ccw/devices/0.0.b100/expires
30
# cat /sys/bus/ccw/devices/0.0.b100/failfast
0
# cat /sys/bus/ccw/devices/0.0.b100/online
1
# cat /sys/bus/ccw/devices/0.0.b100/raw_track_access
0
# cat /sys/bus/ccw/devices/0.0.b100/readonly
1
# cat /sys/bus/ccw/devices/0.0.b100/status
online
# cat /sys/bus/ccw/devices/0.0.b100/uid
IBM.7500000092461.e900.8a
# cat /sys/bus/ccw/devices/0.0.b100/use_diag
1
# cat /sys/bus/ccw/devices/0.0.b100/vendor
IBM
```

Chapter 5. SCSI-over-Fibre Channel device driver

The SCSI-over-Fibre Channel device driver for Linux on System z (zfc device driver) supports virtual QDIO-based System z SCSI-over-Fibre Channel adapters (FCP devices) and attached SCSI devices (LUNs).

System z adapter hardware typically provides multiple channels, with one port each. You can configure a channel to use the Fibre Channel Protocol (FCP). This *FCP channel* is then virtualized into multiple FCP devices. Thus, an FCP device is a virtual QDIO-based System z SCSI-over-Fibre Channel adapter with a single port.

A single physical port supports multiple FCP devices. Using NPIV you can define virtual ports and establish a one-to-one mapping between your FCP devices and virtual ports (see “N_Port ID Virtualization for FCP channels” on page 67).

On Linux, an FCP device is represented by a CCW device that is listed under `/sys/bus/ccw/drivers/zfc`. Do not confuse FCP devices with SCSI devices. A SCSI device is a disk device that is identified by a LUN.

Features

The zfc device driver supports a wide range of SCSI devices, various hardware adapters, specific topologies, and specific features that depend on the System z hardware.

- Linux on System z can use various SAN-attached SCSI device types, including SCSI disks, tapes, CD-ROMs, and DVDs. For a list of supported SCSI devices, see www.ibm.com/systems/z/connectivity
- SAN access through the following FCP adapters:
 - FICON Express[®]
 - FICON Express2
 - FICON Express4
 - FICON Express8 (as of System z10[™])

You can order hardware adapters as features for mainframe systems.

See *Fibre Channel Protocol for Linux and z/VM on IBM System z*, SG24-7266 for more details about using FCP with Linux on System z.

- The zfc device driver supports switched fabric and point-to-point topologies.

For information about SCSI-3, the Fibre Channel Protocol, and Fibre Channel related information, see www.t10.org and www.t11.org

What you should know about zfc

The zfc device driver is a low-level or host-bus adapter driver that supplements the Linux SCSI stack.

Figure 10 on page 62 illustrates how the device drivers work together.




Figure 10. Device drivers supporting the FCP environment

sysfs structures for FCP devices and SCSI devices

FCP devices are CCW devices. In the sysfs device driver view, remote target ports with their LUNs are nested below the FCP devices.

When Linux is booted, it senses the available FCP devices and creates directories of the form:

```
/sys/bus/ccw/drivers/zfc/<device_bus_id>
```

where *<device_bus_id>* is the device bus-ID that corresponds to an FCP device. You use the attributes in this directory to work with the FCP device.

Example: `/sys/bus/ccw/drivers/zfc/0.0.3d0c`

The zfc device driver automatically adds port information when the FCP device is set online and when remote storage ports (*target ports*) are added. Each added target port extends this structure with a directory of the form:

```
/sys/bus/ccw/drivers/zfc/<device_bus_id>/<wwpn>
```

where *<wwpn>* is the worldwide port name (WWPN) of the target port. You use the attributes of this directory to work with the port.

Example: `/sys/bus/ccw/drivers/zfc/0.0.3d0c/0x500507630300c562`

You can extend this structure by adding logical units (usually SCSI devices) to the ports (see “Configuring SCSI devices” on page 78). For each unit you add you get a directory of the form:

```
/sys/bus/ccw/drivers/zfc/<device_bus_id>/<wwpn>/<fcp_lun>
```

where *<fcp_lun>* is the logical unit number (LUN) of the SCSI device. You use the attributes in this directory to work with an individual SCSI device.

Example: `/sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/0x4010403200000000`




Figure 11. SCSI device in sysfs

Figure 11 illustrates how the path to the sysfs representation of a SCSI device is derived from properties of various components in an IBM mainframe FCP environment.

Information about zfcp objects and their associated objects in the SCSI stack is distributed over the sysfs tree. To ease the burden of collecting information about zfcp devices, ports, units, and their associated SCSI stack objects, a command called `lszfcp` is provided with the s390utils RPM. See “lszfcp - List zfcp devices” on page 476 for more details about the command.

See also “Mapping the representations of a SCSI device in sysfs” on page 79.

SCSI device nodes

User space programs access SCSI devices through device nodes.

SCSI device names are assigned in the order in which the devices are detected. In a typical SAN environment, this can mean a seemingly arbitrary mapping of names to actual devices that can change between boots. Therefore, using standard device nodes of the form `/dev/<device_name>` where `<device_name>` is the device name that the SCSI stack assigns to a device, can be a challenge.

Red Hat Enterprise Linux 6.3 provides udev to create device nodes for you that allow you to identify the corresponding actual device.

Device nodes based on device names

udev creates device nodes that match the device names used by the kernel. These standard device nodes have the form `/dev/<name>`.

The examples in this chapter use standard device nodes as assigned by the SCSI stack. These nodes have the form `/dev/sd<x>` for entire disks and `/dev/sd<x><n>` for partitions. In these node names `<x>` represents one or more letters and `<n>` is an integer. See `Documentation/devices.txt` in the Linux source tree for more information about the SCSI device naming scheme.

To help you identify a particular device, udev creates additional device nodes that are based on the device's bus ID, the device label, and information about the file system on the device. The file system information can be a universally unique identifier (UUID) and, if available, the file system label.

Device nodes based on bus IDs

udev creates device nodes of the form

```
/dev/disk/by-path/ccw-<device_bus_id>-zfc<wwpn>:<lun>
```

for whole SCSI device and

```
/dev/disk/by-path/ccw-<device_bus_id>-zfc<wwpn>:<lun>-part<n>
```

for the <n>th partition, where WWPN is the world wide port number of the target port and LUN is the logical unit number representing the target SCSI device.

Device nodes based on file system information

udev creates device nodes of the form

```
/dev/disk/by-uuid/<uuid>
```

where <uuid> is a unique file-system identifier (UUID) for the file system in a partition.

If a file system label has been assigned, udev also creates a node of the form

```
/dev/disk/by-label/<label>
```

There are no device nodes for the whole SCSI device that are based on file system information.

Additional device nodes

/dev/disk/by-id contains additional device nodes for the SCSI device and partitions, that are all based on a unique SCSI identifier generated by querying the device.

Example: For a SCSI device that is assigned the device name sda, has two partitions labeled boot and SWAP-sda2, a device bus-ID 0.0.3c1b (device number 0x3c1b), and a UUID 7eaf9c95-55ac-4e5e-8f18-065b313e63ca for the first and b4a818c8-747c-40a2-bfa2-acaa3ef70ead for the second partition, udev creates the following device nodes:

For the whole SCSI device:

- /dev/sda (standard device node according to the SCSI device naming scheme)
- /dev/disk/by-path/ccw-0.0.3c1b-zfc<0x500507630300c562:0x401040ea00000000>
- /dev/disk/by-id/scsi-36005076303ffc56200000000000010ea
- /dev/disk/by-id/wwn-0x6005076303ffc562000000000000010ea

For the first partition:

- /dev/sda1 (standard device node according to the SCSI device naming scheme)
- /dev/disk/by-path/ccw-0.0.3c1b-zfc<0x500507630300c562:0x401040ea00000000>-part1
- /dev/disk/by-uuid/7eaf9c95-55ac-4e5e-8f18-065b313e63ca
- /dev/disk/by-label/boot
- /dev/disk/by-id/scsi-36005076303ffc56200000000000010ea-part1
- /dev/disk/by-id/wwn-0x6005076303ffc562000000000000010ea-part1

For the second partition:

- /dev/sda2 (standard device node according to the SCSI device naming scheme)

- /dev/disk/by-path/ccw-0.0.3c1b-zfcp-0x500507630300c562:0x401040ea00000000-part2
- /dev/disk/by-uuid/b4a818c8-747c-40a2-bfa2-acaa3ef70ead
- /dev/disk/by-label/SWAP-sda2
- /dev/disk/by-id/scsi-36005076303ffc56200000000000010ea-part2
- /dev/disk/by-id/wwn-0x6005076303ffc562000000000000010ea-part2

Device nodes by-uuid use a unique file-system identifier that does not relate to the partition number.

Partitioning a SCSI device

You can partition SCSI devices that are attached through an FCP channel in the same way that you can partition SCSI attached devices on other platforms.

Use the **fdisk** command to partition a SCSI disk, not **fdasd**.

udev creates device nodes for partitions automatically. For the SCSI disk /dev/sda, the partition device nodes are called /dev/sda1, /dev/sda2, /dev/sda3, and so on.

Example:

To partition a SCSI disk with a device node /dev/sda issue:

```
# fdisk /dev/sda
```

zfcp HBA API (FC-HBA) support

The zfcp host bus adapter API (HBA API) provides an interface for SAN management clients that run on System z.

As shown in Figure 12 on page 66, the zfcp HBA API support includes a user space library.




Figure 12. *zfcP HBA API support modules*

The SNIA (Storage Networking Industry Association) library can interface with the zFCP HBA API. The SNIA library is part of Red Hat Enterprise Linux 6.3. It is available as software package `libhbaapi`, which is automatically installed when installing the zfcP HBA API with `yum install s390utils-libzfcphbaapi`.

In a Linux on System z environment HBAs are usually virtualized and are shown as *FCP devices*. FCP devices are represented by CCW devices that are listed in `/sys/bus/ccw/drivers/zfcP`. Do not confuse FCP devices with SCSI devices. A SCSI device is a disk device that is identified by a LUN.

The default method in Red Hat Enterprise Linux 6.3 is for applications to use the zFCP HBA API library indirectly through the SNIA HBA API.

For information about setting up the HBA API support, see “Installing the zfcP HBA API library” on page 68.

FCP LUN access control

Access control software on the FCP channel can restrict LUN access for Linux instances on System z.

As of IBM System z10

FCP LUN access control is not supported.

For more information about FCP LUN Access Control, visit The IBM Resource Link® website at

<http://www.ibm.com/servers/resourceLink>

The Resource Link page requires registration. If you are not a registered user of Resource Link, you will need to register and then log in. In the navigation area,

click **Tools**, then in the Servers column on the ACT page, click the link **Configuration Utility for FCP LUN Access Control**.

N_Port ID Virtualization for FCP channels

Through N_Port ID Virtualization (NPIV), the sole port of an FCP channel appears as multiple, distinct ports with separate port identification.

NPIV support can be configured on the SE per CHPID and LPAR for an FCP channel. The zfcplib device driver supports NPIV error messages and adapter attributes. See “Displaying FCP device and channel information” on page 70 for the Fibre Channel adapter attributes.

For more details, see the connectivity page at www.ibm.com/systems/z/connectivity/fcp.html

See also the chapter on NPIV in *How to use FC-attached SCSI devices with Linux on System z*, SC33-8413.

N_Port ID Virtualization is available as of IBM System z9.

Setting up the zfcplib device driver

Configure the zfcplib device driver through module parameters. You might also have to install the zfcplib HBA API library.

zfcplib module parameters

You configure the zfcplib device driver through module parameters when the device driver module is loaded.

zfcplib module parameter syntax

```
modprobe zfcplib device=<device_bus_id>,<wwpn>,<fcp_lun>
dbfsize=4 queue_depth=32
dbfsize=<pages> queue_depth=<depth>
```

where:

<device_bus_id>

specifies the FCP device through which the SCSI device is attached.

<wwpn>

specifies the target port through which the SCSI device is accessed.

<fcp_lun>

specifies the LUN of the SCSI device.

<pages>

specifies the number of pages to be used for the debug feature.

The debug feature is available for each FCP device and the following areas:

hba	FCP device
san	Storage Area Network
rec	Error Recovery Process
scsi	SCSI

The value given is used for all areas. The default is 4, that is, four pages are used for each area and FCP device. In the following example the dbfszsize is increased to 6 pages:

```
zfcplib.dbfszsize=6
```

This results in six pages being used for each area and FCP device.

queue_depth=<depth>

specifies the number of commands that can be issued simultaneously to a SCSI device. The default is 32. The value you set here will be used as the default queue depth for new SCSI devices. You can change the queue depth for each SCSI device using the queue_depth sysfs attribute, see “Setting the queue depth” on page 82.

Installing the zfcplib HBA API library

You need several packages to use the zfcplib HBA API library.

Before you begin: To use the HBA API support you need the following packages:

- The zfcplib HBA API library RPM, s390utils-libzfcplibhbaapi.
- The SNIA library RPM, libhbaapi.

You can install the s390utils-libzfcplibhbaapi RPM using **yum**. **Yum** automatically installs all dependent packages such as libhbaapi.

Follow these steps to access the library from a client application:

1. The SNIA library expects a configuration file called `/etc/hba.conf` that contains the path to the vendor-specific library `libzfcplibhbaapi.so`. Ensure that the `/etc/hba.conf` file exists and contains a line of the form:

```
<library name> <library pathname>
```

For example:

```
libzfcplibhbaapi /usr/lib64/libzfcplibhbaapi-2.1.so
```

2. The client application must link `libHBAAPI`.
3. The client application must issue the **HBA_LoadLibrary()** call as the first call to load the library. The vendor-specific library, in turn, supplies the function **HBA_RegisterLibrary** that returns all function pointers to the common library and thus makes them available to the application.

Working with FCP devices, target ports, and SCSI devices

Depending on the scope of a task, you must work with FCP devices, target ports, or SCSI devices. Set an FCP device online before you attempt to perform any other tasks.

- Working with FCP devices
 - “Setting an FCP device online or offline” on page 69
 - “Displaying FCP device and channel information” on page 70
 - “Recovering a failed FCP device” on page 73
 - “Finding out whether NPIV is in use” on page 74
- Working with target ports
 - “Scanning for ports” on page 74
 - “Displaying port information” on page 75

- “Recovering a failed port” on page 77
- “Removing ports” on page 77
- Working with SCSI devices
 - “Configuring SCSI devices” on page 78
 - “Mapping the representations of a SCSI device in sysfs” on page 79
 - “Displaying information about SCSI devices” on page 80
 - “Setting the queue depth” on page 82
 - “Recovering a failed SCSI device” on page 83
 - “Updating the information about SCSI devices” on page 84
 - “Setting the SCSI command timeout” on page 84
 - “Controlling the SCSI device state” on page 85
 - “Removing SCSI devices” on page 86

Most of these tasks involve writing to and reading from device attributes in sysfs. This is useful on a running system where you want to make dynamic changes. If you want to make the changes persistent across IPLs, use the configuration file `/etc/zipl.conf` for FCP devices that are part of the root file system and `/etc/zfc.conf` for data disks. An example of how to define an FCP device persistently is in *Red Hat Enterprise Linux 6.3 Installation Guide*. For a general discussion of configuration files, see *Red Hat Enterprise Linux 6.3 Deployment Guide*.

Setting an FCP device online or offline

By default, FCP devices are offline. Set an FCP device online before you perform any other tasks.

See “Working with newly available devices” on page 10 to avoid errors when working with devices that have become available to a running Linux instance.

Use the **chccwdev** command (“chccwdev - Set a CCW device online” on page 396) to set an FCP device online or offline. Alternatively, you can write “1” to an FCP device’s online attribute to set it online, or “0” to set it offline.

Setting an FCP device online registers it with the Linux SCSI stack. It also automatically runs the scan for ports in the SAN and waits for this port scan to complete. To check if setting the FCP device online was successful you can use a script that first sets the FCP device online and after this operation completes checks if the WWPN of a remote storage port has appeared in sysfs.

When you set an FCP device offline, the port and LUN subdirectories are preserved. Setting an FCP device offline in sysfs interrupts the communication between Linux and the FCP channel. After a timeout has expired, the port and LUN attributes indicate that the ports and LUNs are no longer accessible. The transition of the FCP device to the offline state is synchronous, unless the device is disconnected.

For disconnected devices, writing 0 to the online sysfs attribute triggers an asynchronous deregistration process. When this process is completed, the device with its ports and LUNs is no longer represented in sysfs.

When the FCP device is set back online, the SCSI device names and minor numbers are freshly assigned. The mapping of devices to names and numbers might be different from what they were before the FCP device was set offline.

Examples:

- To set an FCP device with bus ID 0.0.3d0c online issue:

```
# chccwdev -e 0.0.3d0c
```

or

```
# echo 1 > /sys/bus/ccw/drivers/zfcp/0.0.3d0c/online
```

- To set an FCP device with bus ID 0.0.3d0c offline issue:

```
# chccwdev -d 0.0.3d0c
```

or

```
# echo 0 > /sys/bus/ccw/drivers/zfcp/0.0.3d0c/online
```

Displaying FCP device and channel information

For each online FCP device, there is a number of read-only attributes in sysfs that provide information about the corresponding FCP channel.

Before you begin: The FCP device must be online for the FCP channel information to be valid.

The following tables summarize the relevant attributes.

Table 9. Attributes with Fibre Channel adapter hardware information

Attribute	Explanation
card_version	Version number that identifies a particular hardware feature.
hardware_version	Number that identifies a hardware version for a particular feature. The initial hardware version of a feature is zero. This version indicator is increased only for hardware modifications of the same feature. Appending hardware_version to card_version results in a hierarchical version indication for a physical adapter card.
lic_version	Microcode level.
in_recovery	Shows if the FCP channel is in recovery (0 or 1).
peer_wwnn	WWNN of peer for a point-to-point connection.
peer_wwpn	WWPN of peer for a point-to-point connection.
peer_d_id	Destination ID of the peer for a point-to-point connection.

Table 10. Attributes with FCP device information

Attribute	Explanation
in_recovery	Shows if the FCP channel is in recovery (0 or 1).

For the attributes availability, cmb_enable, and cutype, see “Device directories” on page 9. The status attribute is reserved.

Table 11. Relevant transport class attributes, fc_host attributes

Attribute	Explanation
maxframe_size	Maximum frame size of adapter.
node_name	Worldwide node name (WWNN) of adapter.
permanent_port_name	WWPN associated with the physical port of the FCP channel.
port_id	A unique ID (N_Port_ID) assigned by the fabric. In an NPIV setup, each virtual port is assigned a different port_id.
port_name	WWPN associated with the FCP device. If N_Port ID Virtualization is not available, the WWPN of the physical port (see permanent_port_name).
port_type	Port type indicating topology of port.
serial_number	Serial number of adapter.
speed	Speed of FC link.
supported_classes	Supported FC service class.
supported_speeds	Supported speeds.
tgid_bind_type	Target binding type.

Table 12. Relevant transport class attributes, fc_host statistics

Attribute	Explanation
reset_statistics	Writeable attribute to reset statistic counters.
seconds_since_last_reset	Seconds since last reset of statistic counters.
tx_frames	Transmitted FC frames.
tx_words	Transmitted FC words.
rx_frames	Received FC frames.
rx_words	Received FC words.
lip_count	Number of LIP sequences.
nos_count	Number of NOS sequences.
error_frames	Number of frames received in error.
dumped_frames	Number of frames lost due to lack of host resources.
link_failure_count	Link failure count.
loss_of_sync_count	Loss of synchronization count.
loss_of_signal_count	Loss of signal count.
prim_seq_protocol_err_count	Primitive sequence protocol error count.
invalid_tx_word_count	Invalid transmission word count.
invalid_crc_count	Invalid CRC count.
fc_p_input_requests	Number of FCP operations with data input.
fc_p_output_requests	Number of FCP operations with data output.
fc_p_control_requests	Number of FCP operations without data movement.
fc_p_input_megabytes	Megabytes of FCP data input.
fc_p_output_megabytes	Megabytes of FCP data output.

Issue a command of this form to read an attribute:

```
# cat /sys/bus/ccw/drivers/zfcp/<device_bus_id>/<attribute>
```

where:

<device_bus_id>

specifies an FCP device that corresponds to the FCP channel.

<attribute>

is one of the attributes in Table 9 on page 70 or Table 10 on page 70.

To read attributes of the associated SCSI host use:

```
# cat /sys/class/fc_host/<host_name>/<attribute>
```

where:

<host_name>

is the ID of the SCSI host.

<attribute>

is one of the attributes in Table 11 on page 71.

To read the statistics' attributes:

```
# cat /sys/class/fc_host/<host_name>/statistics/<attribute>
```

where:

<host_name>

is the ID of the SCSI host.

<attribute>

is one of the attributes in Table 12 on page 71.

Examples:

- In this example, information is displayed about an FCP channel that corresponds to an FCP device with bus ID 0.0.3d0c:

```
# cat /sys/bus/ccw/drivers/zfcp/0.0.3d0c/hardware_version
0x00000000
# cat /sys/bus/ccw/drivers/zfcp/0.0.3d0c/lic_version
0x00009111
```

- Alternatively you can use **lszfcp** (see “lszfcp - List zfcp devices” on page 476) to display attributes of an FCP channel:


```
# lszfcp -b 0.0.3d0c -a
0.0.3d0c host0
Bus = "ccw"
  availability      = "good"
  card_version      = "0x0003"
  cmb_enable        = "0"
  cotype            = "1731/03"
  devtype           = "1732/03"
  failed            = "0"
  hardware_version  = "0x00000000"
  in_recovery       = "0"
  lic_version       = "0x00000600"
  modalias          = "ccw:t1731m03dt1732dm03"
  online            = "1"
  peer_d_id         = "0x0000000"
  peer_wwnn         = "0x0000000000000000"
  peer_wwpn         = "0x0000000000000000"
  status           = "0x5400082e"
Class = "fc_host"
  maxframe_size     = "2112 bytes"
  node_name         = "0x5005076400cd6aad"
  permanent_port_name = "0x5005076401c08f98"
  port_id           = "0x650f13"
  port_name         = "0x5005076401c08f98"
  port_type         = "NPort (fabric via point-to-point)"
  serial_number     = "IBM020000000D6AAD"
  speed             = "2 Gbit"
  supported_classes  = "Class 2, Class 3"
  supported_speeds   = "1 Gbit, 2 Gbit"
  tgtid_bind_type    = "wwpn (World Wide Port Name)"
Class = "scsi_host"
  cmd_per_lun       = "1"
  host_busy         = "0"
  proc_name         = "zfcp"
  sg_tablesize      = "538"
  state             = "running"
  unchecked_isa_dma = "0"
  unique_id         = "0"
```

Recovering a failed FCP device

Failed FCP devices are automatically recovered by the zfcp device driver. You can read the `in_recovery` attribute to check if recovery is under way.

Before you begin: The FCP device must be online.

Issue a command of this form:

```
# cat /sys/bus/ccw/drivers/zfcp/<device_bus_id>/in_recovery
```

The value is "1" if recovery is under way and "0" otherwise. If the value is "0" for a non-operational FCP device, recovery might have failed or the device driver might have failed to detect that the FCP device is malfunctioning.

To find out if recovery has failed read the `failed` attribute. Issue a command of this form:

```
# cat /sys/bus/ccw/drivers/zfcp/<device_bus_id>/failed
```

The value is "1" if recovery has failed and "0" otherwise.

You can start or restart the recovery process for the FCP device by writing "0" to the `failed` attribute. Issue a command of this form:

```
# echo 0 > /sys/bus/ccw/drivers/zfcp/<device_bus_id>/failed
```

Example:

In the following example, an FCP device with a device bus-ID 0.0.3d0c is malfunctioning. The first command reveals that recovery is not already under way. The second command manually starts recovery for the FCP device:

```
# cat /sys/bus/ccw/drivers/zfcp/0.0.3d0c/in_recovery
0
# echo 0 > /sys/bus/ccw/drivers/zfcp/0.0.3d0c/failed
```

Finding out whether NPIV is in use

The FCP setup runs in NPIV mode if the applicable `permanent_port_name` and `port_name` are not the same and are not NULL.

The `port_type` attribute of the FCP device indicates the mode accordingly.

Example:

To find out if the FCP setup is running in NPIV mode, check the `port_type` attribute of the FCP device, for example:

```
# cat /sys/bus/ccw/drivers/zfcp/0.0.1940/host0/fc_host/host0/port_type
NPIV VPORT
```

Alternatively, compare the values of the `permanent_port_name` attribute and the `port_name`. You can use `lszfcp` (see “`lszfcp` - List zfcp devices” on page 476) to list the FCP device attributes:

```
# lszfcp -b 0.0.1940 -a
0.0.1940 host0
Bus = "ccw"
    availability      = "good"
    ...
Class = "fc_host"
    maxframe_size    = "2112 bytes"
    node_name        = "0x5005076400c1ebae"
    permanent_port_name = "0x50050764016219a0"
    port_id          = "0x65ee01"
    port_name        = "0xc05076ffef805388"
    port_state       = "Online"
    port_type        = "NPIV VPORT"
    serial_number    = "IBM0200000001EBAE"
    ...
```

The `port_type` attribute directly indicates that NPIV is used. The example also shows that `permanent_port_name` is different from `port_name`.

Scanning for ports

Although newly available target ports are discovered, you might want to trigger a port scan to re-create accidentally removed port information or to assure that all ports are present.

Before you begin: The FCP device must be online.

The zfcplib device driver automatically adds port information to sysfs when the FCP device is set online and when target ports are added. Scanning for ports might take some time to complete. Commands that you issue against ports or LUNs while scanning is in progress are delayed and processed when port scanning is completed.

Use the port_rescan attribute if a remote storage port was accidentally deleted from the adapter configuration or if you are unsure whether all ports have been added to sysfs.

Issue a command of this form:

```
# echo 1 > /sys/bus/ccw/drivers/zfcplib/<device_bus_id>/port_rescan
```

where:

<device_bus_id>

specifies the FCP device through which the target ports are attached.

List the contents of /sys/bus/ccw/drivers/zfcplib/<device_bus_id> to find out which ports are currently configured for the FCP device.

Example:

In this example, a port with WWPN 0x500507630303c562 has already been configured for an FCP device with bus ID 0.0.3d0c. An additional target port with WWPN 0x500507630300c562 is automatically configured by triggering a port scan.

```
# ls /sys/bus/ccw/drivers/zfcplib/0.0.3d0c/0x*
0x500507630303c562
# echo 1 > /sys/bus/ccw/drivers/zfcplib/0.0.3d0c/port_rescan
# ls /sys/bus/ccw/drivers/zfcplib/0.0.3d0c/0x*
0x500507630303c562
0x500507630300c562
```

Displaying port information

For each target port, there is a number of read-only sysfs attributes with port information.

Table 13 summarizes the relevant attributes.

Table 13. Attributes with port information

Attribute	Explanation
access_denied	Flag that indicates if the port access is restricted by access control software on the FCP channel (see “FCP LUN access control” on page 66). The value is “1” if access is denied and “0” if access is permitted.
in_recovery	Shows if port is in recovery (0 or 1).

Table 14. Transport class attributes with port information

Attribute	Explanation
node_name	WWNN of the remote port (target port).

Table 14. Transport class attributes with port information (continued)

Attribute	Explanation
port_name	WWPN of remote port.
port_id	Destination ID of remote port.
port_state	State of remote port.
roles	Role of remote port (usually FCP target).
scsi_target_id	Linux SCSI ID of remote port.
supported_classes	Supported classes of service.

Issue a command of this form to read an attribute:

```
# cat /sys/bus/ccw/drivers/zfcp/<device_bus_id>/<wwpn>/<attribute>
```

where:

<device_bus_id>

specifies the FCP device.

<wwpn>

is the WWPN of the target port.

<attribute>

is one of the attributes in Table 13 on page 75.

To read attributes of the associated fc_host use a command of this form:

```
# cat /sys/class/fc_remote_port/<rport_name>/<attribute>
```

where:

<rport_name>

is the name of the remote port.

<attribute>

is one of the attributes in Table 14 on page 75.

With the HBA API package installed, you can also use the **zfcp_ping** and **zfcp_show** commands to find out more about your ports. Install the **s390utils-libzfcphbaapi** RPM to get the HBA API library. See “Tools for investigating your SAN configuration” on page 88.

Examples:

- In this example, information is displayed for a target port 0x500507630300c562 that is attached through an FCP device with bus ID 0.0.3d0c:

```
# cat /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/access_denied
0
```

- To display transport class attributes of a target port you can use **lszfcp**:

```
# lszfcp -p 0x500507630300c562 -a
0.0.3d0c/0x500507630300c562 rport-0:0-0
Class = "fc_remote_ports"
  dev_loss_tmo      = "60"
  fast_io_fail_tmo  = "off"
  maxframe_size     = "2048 bytes"
  node_name         = "0x5005076303ffc562"
  port_id           = "0x652113"
  port_name         = "0x500507630300c562"
  port_state        = "Online"
  roles             = "FCP Target"
  scsi_target_id    = "0"
  supported_classes = "Class 2, Class 3"
```

Recovering a failed port

Failed target ports are automatically recovered by the zfc device driver. You can read the `in_recovery` attribute to check if recovery is under way.

Before you begin: The FCP device must be online.

Issue a command of this form:

```
# cat /sys/bus/ccw/drivers/zfc/<device_bus_id>/<wwpn>/in_recovery
```

where the variables are the same as in “Configuring SCSI devices” on page 78.

The value is “1” if recovery is under way and “0” otherwise. If the value is “0” for a non-operational port, recovery might have failed or the device driver might have failed to detect that the port is malfunctioning.

To find out if recovery has failed read the `failed` attribute. Issue a command of this form:

```
# cat /sys/bus/ccw/drivers/zfc/<device_bus_id>/<wwpn>/failed
```

The value is “1” if recovery has failed and “0” otherwise.

You can start or restart the recovery process for the port by writing “0” to the `failed` attribute. Issue a command of this form:

```
# echo 0 > /sys/bus/ccw/drivers/zfc/<device_bus_id>/<wwpn>/failed
```

Example:

In the following example, a port with WWPN 0x500507630300c562 that is attached through an FCP device with bus ID 0.0.3d0c is malfunctioning. The first command reveals that recovery is not already under way. The second command manually starts recovery for the port:

```
# cat /sys/bus/ccw/drivers/zfc/0.0.3d0c/0x500507630300c562/in_recovery
0
# echo 0 > /sys/bus/ccw/drivers/zfc/0.0.3d0c/0x500507630300c562/failed
```

Removing ports

To remove a port from an FCP device, write the WWPN of the port to the `port_remove` attribute of the FCP device.

Before you begin: The FCP device must be online.

List the contents of `/sys/bus/ccw/drivers/zfc/<device_bus_id>` to find out which ports are currently configured for the FCP device.

Issue a command of this form:

```
# echo <wwpn> > /sys/bus/ccw/drivers/zfc/<device_bus_id>/port_remove
```

where:

<device_bus_id>

specifies the FCP device.

<wwpn>

is the WWPN of the port to be removed.

You cannot remove a port while SCSI devices are configured for it (see “Configuring SCSI devices”) or if the port is in use, for example, by error recovery. Note that the next port scan will attach a removed port again if the port is available. If you do not want this, consider zoning.

Example:

In this example, two ports with WWPN 0x500507630303c562 and 0x500507630300c562 have been configured for an FCP device with bus ID 0.0.3d0c. The port with WWPN 0x500507630303c562 is removed.

```
# ls /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x*
0x500507630303c562
0x500507630300c562
# echo 0x500507630303c562 > /sys/bus/ccw/drivers/zfcp/0.0.3d0c/port_remove
# ls /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x*
0x500507630300c562
```

Configuring SCSI devices

To configure a SCSI device for a target port write the device's LUN to the port's `unit_add` attribute.

Issue a command of this form:

```
# echo <fcp_lun> > /sys/bus/ccw/drivers/zfcp/<device_bus_id>/<wwpn>/unit_add
```

where:

<fcp_lun>

is the LUN of the SCSI device to be configured. The LUN is a 16 digit hexadecimal value padded with zeroes, for example 0x4010403300000000.

<device_bus_id>

specifies the FCP device.

<wwpn>

is the WWPN of the target port.

This command starts a process with multiple steps:

1. It creates a directory in `/sys/bus/ccw/drivers/zfcp/<device_bus_id>/<wwpn>` with the LUN as the directory name.
2. It initiates the registration of the SCSI device with the Linux SCSI stack. The FCP device must be online for this step.
3. It waits until the Linux SCSI stack registration has completed successfully or returned an error. It then returns control to the shell. A successful registration creates a sysfs entry in the SCSI branch (see “Mapping the representations of a SCSI device in sysfs” on page 79).

To check if a SCSI device is registered for the configured LUN, check for a directory with the name of the LUN in `/sys/bus/scsi/devices`. If there is no SCSI device for this LUN, the LUN is not valid in the storage system, or the FCP device is offline in Linux.

To find out which LUNs are currently configured for the port, list the contents of `/sys/bus/ccw/drivers/zfcp/<device_bus_id>/<wwpn>`.

Example:

In this example, a target port with WWPN 0x500507630300c562 is attached through an FCP device with bus ID 0.0.3d0c. A SCSI device with LUN 0x4010403200000000 is already configured for the port. An additional SCSI device with LUN 0x4010403300000000 is added to the port.

```
# ls /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/0x*
0x4010403200000000
# echo 0x4010403300000000 > /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/unit_add
# ls /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/0x*
0x4010403200000000
0x4010403300000000
```

Mapping the representations of a SCSI device in sysfs

Each SCSI device that is configured is represented by multiple directories in sysfs, in particular, within the zfcp branch and within the SCSI branch.

For details about the directory in the zfcp branch see “Configuring SCSI devices” on page 78.

The directory in the sysfs SCSI branch has the following form:

`/sys/bus/scsi/devices/<scsi_host_no>:0:<scsi_id>:<scsi_lun>`

where:

`<scsi_host_no>` is the SCSI host number that corresponds to the FCP device.

`<scsi_id>` is the SCSI ID of the target port.

`<scsi_lun>` is the LUN of the SCSI device.

The values for `<scsi_id>` and `<scsi_lun>` depend on the storage device. Often, they are single-digit numbers but for some storage devices they have numerous digits.

Figure 13 shows how the directory name is composed of attributes of consecutive directories in the sysfs zfcp branch. You can find the name of the directory in the sysfs SCSI branch by reading the corresponding attributes in the zfcp branch. Use `lszfcp` (see “lszfcp - List zfcp devices” on page 476) to map the two




Figure 13. SCSI devices in sysfs

representations of a SCSI device.

The `hba_id`, `wwpn`, and `fcplun` attributes of the SCSI device in the SCSI branch match the names of the `<device_bus_id>`, `<wwpn>`, and `<fcplun>` directories for the same SCSI device in the zfcp branch.

Example:

This example shows how you can use **lszfc** to display the name of the SCSI device that corresponds to a zfc unit, for example:

```
# lszfc -l 0x4010403200000000  
0.0.3d0c/0x500507630300c562/0x4010403200000000 0:0:0:0
```

In the example, the output informs you that the unit with the LUN 0x4010403200000000, which is configured on a port with the WWPN 0x500507630300c562 for an FCP device with bus ID 0.0.3d0c, maps to SCSI device "0:0:0:0".

To confirm that the SCSI device belongs to the zfc unit:

```
# cat /sys/bus/scsi/devices/0:0:0:0/hba_id  
0.0.3d0c  
# cat /sys/bus/scsi/devices/0:0:0:0/wwpn  
0x500507630300c562  
# cat /sys/bus/scsi/devices/0:0:0:0/fcp_lun  
0x4010403200000000
```

Displaying information about SCSI devices

For each SCSI device, there is a number of read-only attributes in sysfs that provide information for the device.

Table 15 summarizes the read-only attributes that indicate if the device access is restricted by access control software on the FCP channel.

Table 15. Attributes with device access information

Attribute	Explanation
access_denied	Flag that indicates if access to the device is restricted by access control software on the FCP channel. The value is "1" if access is denied and "0" if access is permitted. (See "FCP LUN access control" on page 66).
access_shared	Flag that indicates if access to the device is shared or exclusive. The value is "1" if access is shared and "0" if access is exclusive. (See "FCP LUN access control" on page 66).
access_readonly	Flag that indicates if write access to the device is permitted or if access is restricted to read-only. The value is "1" if access is restricted read-only and "0" if write access is permitted. (See "FCP LUN access control" on page 66).
in_recovery	Shows if unit is in recovery (0 or 1)

Table 16 lists further read-only attributes with information about the SCSI device.

Table 16. SCSI device class attributes

Attribute	Explanation
device_blocked	Flag that indicates if device is in blocked state (0 or 1).
iocounterbits	The number of bits used for I/O counters.
iodone_cnt	The number of completed or rejected SCSI commands.

Table 16. SCSI device class attributes (continued)

Attribute	Explanation
ioerr_cnt	The number of SCSI commands that completed with an error.
iorequest_cnt	The number of issued SCSI commands.
queue_type	The type of queue for the SCSI device. The value can be one of the following: <ul style="list-style-type: none"> • none • simple • ordered
model	The model of the SCSI device, received from inquiry data.
rev	The revision of the SCSI device, received from inquiry data.
scsi_level	The SCSI revision level, received from inquiry data.
type	The type of the SCSI device, received from inquiry data.
vendor	The vendor of the SCSI device, received from inquiry data.
fcp_lun	The LUN of the SCSI device in 64-bit format.
hba_id	The bus ID of the SCSI device.
wwpn	The WWPN of the remote port.

Issue a command of this form to read an attribute:

```
# cat /sys/bus/ccw/drivers/zfcp/<device_bus_id>/<wwpn>/<fcp_lun>/<attribute>
```

where:

<device_bus_id>	specifies the FCP device.
<wwpn>	is the WWPN of the target port.
<fcp_lun>	is the FCP LUN of the SCSI device.
<attribute>	is one of the attributes in Table 15 on page 80.

Use the **lszfcp** command (see “lszfcp - List zfcp devices” on page 476) to display information about the associated SCSI device.

Alternatively, you can use **sysfs** to read the information. To read attributes of the associated SCSI device use a command of this form:

```
# cat /sys/class/scsi_device/<device_name>/<attribute>
```

where:

<device_name>	is the name of the associated SCSI device.
<attribute>	is one of the attributes in Table 16 on page 80.

Tip: For SCSI tape devices you can display a summary of this information by using the **lstape** command (see “lstape - List tape devices” on page 471).

Examples:

- In this example, information is displayed for a SCSI device with LUN 0x4010403200000000 that is accessed through a target port with WWPN 0x500507630300c562 and is attached through an FCP device 0.0.3d0c. For the device, shared read-only access is permitted.

```
# cat /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/0x4010403200000000/access_denied
0
# cat /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/0x4010403200000000/access_shared
1
# cat /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/0x4010403200000000/access_readonly
1
```

For the device to be accessible, the `access_denied` attribute of the target port, `0x500507630300c562`, must also be “0” (see “Displaying port information” on page 75).

- You can use **lszfcp** to display attributes of a SCSI device:

```
# lszfcp -l 0x4010403200000000 -a
0.0.3d0c/0x500507630300c562/0x4010403200000000 0:0:0:0
Class = "scsi_device"
device_blocked = "0"
fcplun         = "0x4010403200000000"
hba_id         = "0.0.3d0c"
iocounterbits  = "32"
iodone_cnt     = "0x111"
ioerr_cnt      = "0x1"
iorequest_cnt  = "0x111"
model          = "2107900"
queue_depth    = "32"
queue_type     = "simple"
rev            = ".203"
scsi_level     = "6"
state          = "running"
timeout        = "30"
type           = "0"
vendor         = "IBM"
wwpn           = "0x500507630300c562"
```

Setting the queue depth

The Linux SCSI code automatically adjusts the queue depth as necessary. Changing the queue depth is usually a storage server requirement.

Check the documentation of the storage server used or contact your storage server support group to establish if there is a need to change this setting.

The value of the `queue_depth` kernel parameter (see “zfcp module parameters” on page 67) is used as the default queue depth of new SCSI devices. You can query the queue depth by issuing a command of this form:

```
# cat /sys/bus/scsi/devices/<SCSI device>/queue_depth
```

Example:

```
# cat /sys/bus/scsi/devices/0:0:19:1086537744/queue_depth
16
```

You can change the queue depth of each SCSI device by writing to the `queue_depth` attribute, for example:

```
# echo 8 > /sys/bus/scsi/devices/0:0:19:1086537744/queue_depth
# cat /sys/bus/scsi/devices/0:0:19:1086537744/queue_depth
8
```

This is useful on a running system where you want to make dynamic changes. If you want to make the changes persistent across IPLs you can:

- Use the kernel or module parameter.
- Write a udev rule to change the setting for each new SCSI device.

Linux forwards SCSI commands to the storage server until the number of pending commands exceeds the queue depth. If the server lacks the resources to process a SCSI command, Linux queues the command for a later retry and decreases the queue depth counter. Linux then waits for a defined ramp-up period. If no indications of resource problems occur within this period, Linux increases the queue depth counter until reaching the previously set maximum value. To query the current value for the queue ramp-up period in milliseconds:

```
# cat /sys/bus/scsi/devices/0:0:13:1086537744/queue_ramp_up_period
120000
```

To set a new value for the queue ramp-up period in milliseconds:

```
# echo 1000 > /sys/bus/scsi/devices/0:0:13:1086537744/queue_ramp_up_period
```

Recovering a failed SCSI device

Failed SCSI devices are automatically recovered by the zfcplib device driver. You can read the `in_recovery` attribute to check if recovery is under way.

Before you begin: The FCP device must be online.

Issue a command of this form:

```
# cat /sys/bus/ccw/drivers/zfcp/<device_bus_id>/<wwpn>/<fcplun>/in_recovery
```

where the variables have the same meaning as in “Configuring SCSI devices” on page 78.

The value is “1” if recovery is under way and “0” otherwise. If the value is “0” for a non-operational SCSI device, recovery might have failed or the device driver might have failed to detect that the SCSI device is malfunctioning.

To find out if recovery has failed read the `failed` attribute. Issue a command of this form:

```
# cat /sys/bus/ccw/drivers/zfcp/<device_bus_id>/<wwpn>/<fcplun>/failed
```

The value is “1” if recovery has failed and “0” otherwise.

You can start or restart the recovery process for the SCSI device by writing “0” to the `failed` attribute. Issue a command of this form:

```
# echo 0 > /sys/bus/ccw/drivers/zfcp/<device_bus_id>/<wwpn>/<fcplun>/failed
```

Example:

In the following example, SCSI device with LUN 0x4010403200000000 is malfunctioning. The SCSI device is accessed through a target port with WWPN 0x500507630300c562 and attached through an FCP device with bus ID 0.0.3d0c. The first command reveals that recovery is not already under way. The second command manually starts recovery for the SCSI device:

```
# cat /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/0x4010403200000000/in_recovery
0
# echo 0 > /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/0x4010403200000000/failed
```

Updating the information about SCSI devices

Use the `rescan` attribute of the SCSI device to detect changes to a storage device on the storage server that are made after the device has been discovered.

The initial information about the available SCSI devices is discovered automatically when LUNs first become available.

Before you begin: The FCP device must be online.

To update the information about a SCSI device issue a command of this form:

```
# echo <string> > /sys/bus/scsi/devices/<scsi_host_no>:0:<scsi_id>:<scsi_lun>/rescan
```

where *<string>* is any alphanumeric string and the other variables have the same meaning as in “Mapping the representations of a SCSI device in sysfs” on page 79.

Example:

In the following example, the information about a SCSI device 1:0:18:1086537744 is updated:

```
# echo 1 > /sys/bus/scsi/devices/1:0:18:1086537744/rescan
```

Setting the SCSI command timeout

You can change the timeout if the default is not suitable for your storage system.

Before you begin: The FCP device must be online.

There is a timeout for SCSI commands. If the timeout expires before a SCSI command has completed, error recovery starts. The default timeout is 30 seconds. You can change the timeout if the default is not suitable for your storage system.

To find out the current timeout, read the `timeout` attribute of the SCSI device:

```
# cat /sys/bus/scsi/devices/<scsi_host_no>:0:<scsi_id>:<scsi_lun>/timeout
```

where the variables have the same meaning as in “Mapping the representations of a SCSI device in sysfs” on page 79.

The attribute value specifies the timeout in seconds.

To set a different timeout, enter a command of this form:

```
# echo <timeout> > /sys/bus/scsi/devices/<scsi_host_no>:0:<scsi_id>:<scsi_lun>/timeout
```

where *<timeout>* is the new timeout in seconds.

Example:

In the following example, the timeout of a SCSI device 1:0:18:1086537744 is first read and then set to 45 seconds:

```
# cat /sys/bus/scsi/devices/1:0:18:1086537744/timeout
30
# echo 45 > /sys/bus/scsi/devices/1:0:18:1086537744/timeout
```

Controlling the SCSI device state

You can use the state attribute of the SCSI device to set a SCSI device back online if it has been set offline by error recovery.

Before you begin: The FCP device must be online.

If the connection to a storage system is working but the storage system has a problem, the error recovery might end with taking the SCSI device offline. This condition is indicated by a message like “Device offlined - not ready after error recovery”.

To find out the current state of the device, read the state attribute:

```
# cat /sys/bus/scsi/devices/<scsi_host_no>:0:<scsi_id>:<scsi_lun>/state
```

where the variables have the same meaning as in “Mapping the representations of a SCSI device in sysfs” on page 79. The state can be:

running	The SCSI device can be used for running regular I/O requests.
cancel	The data structure for the device is being removed.
deleted	Follows the cancel state when the data structure for the device is being removed.
quiesce	No I/O requests are sent to the device, only special requests for managing the device. This state is used when the system is suspended.
offline	Error recovery for the SCSI device has failed.
blocked	Error recovery is in progress and the device cannot be used until the recovery process is completed.

To set an offline device online again, write running to the state attribute. Issue a command of this form:

```
# echo running > /sys/bus/scsi/devices/<scsi_host_no>:0:<scsi_id>:<scsi_lun>/state
```

Example:

In the following example, SCSI device 1:0:18:1086537744 is offline and set online again:

```
# cat /sys/bus/scsi/devices/1:0:18:1086537744/state
offline
# echo running > /sys/bus/scsi/devices/1:0:18:1086537744/state
```

Removing SCSI devices

Use the `unit_remove` sysfs attribute of the appropriate target port to remove a SCSI device.

Follow these steps to remove a SCSI device:

1. Optional: To manually unregister the SCSI device, write “1” to the `delete` attribute of the directory that represents the device in the sysfs SCSI branch. See “Mapping the representations of a SCSI device in sysfs” on page 79 for information about how to find this directory. Issue a command of this form:

```
# echo 1 > /sys/bus/scsi/devices/<device>/delete
```

2. Remove the SCSI device from the target port by writing the device's LUN to the port's `unit_remove` attribute. Issue a command of this form:

```
# echo <fcp_lun> > /sys/bus/ccw/drivers/zfcp/<device_bus_id>/<wwpn>/unit_remove
```

where the variables have the same meaning as in “Configuring SCSI devices” on page 78. Removing a LUN with `unit_remove` automatically unregisters the SCSI device first.

Example:

The following example removes a SCSI device with LUN 0x4010403200000000, accessed through a target port with WWPN 0x500507630300c562 and attached through an FCP device with bus ID 0.0.3d0c. The corresponding directory in the sysfs SCSI branch is assumed to be `/sys/bus/scsi/devices/0:0:1:1`.

1. Optionally, unregister the SCSI device:

```
# echo 1 > /sys/bus/scsi/devices/0:0:1:1/delete
```

2. Remove the SCSI device (if not done in previous step) and the LUN:

```
# echo 0x4010403200000000 > /sys/bus/ccw/drivers/zfcp/0.0.3d0c/0x500507630300c562/unit_remove
```

Logging I/O subchannel status information

When severe errors occur for an FCP device, the FCP device driver triggers a set of log entries with I/O subchannel status information.

The log entries are available through the SE Console Actions Work Area with the View Console Logs function. In the list of logs, the FCP channel entries have the prefix 1F00. The content of the entries is intended for support specialists.

Scenario for finding available LUNs

There are several steps from setting an FCP device online to listing the available LUNs.

1. Check for available FCP devices of type 1732/03:

```
# lscss -t 1732/03
Device    Subchan.  DevType CU Type Use  PIM PAM POM  CHPIDs
-----
0.0.3c02  0.0.0015  1732/03 1731/03 yes  80  80  ff   36000000 00000000
```

Another possible type would be, for example, 1732/04.

2. Set the FCP device online:

```
# chccwdev -e 0.0.3c02
```

A port scan is performed automatically when the FCP device is set online.

3. Optional: Confirm that the FCP device is available and online:

```
# lszfcp
0.0.3c02 host0
```

4. Optional: List the available ports:

```
# lszfcp -P
0.0.3c02/0x50050763030bc562 rport-0:0-0
0.0.3c02/0x500507630310c562 rport-0:0-1
0.0.3c02/0x500507630040727b rport-0:0-10
0.0.3c02/0x500507630e060521 rport-0:0-11
...
```

5. Scan for available LUNs on FCP device 0.0.3c02, port 0x50050763030bc562:

```
# lsluns -p 0x50050763030bc562
Scanning for LUNs on adapter 0.0.3c02
at port 0x50050763030bc562:
0x4010400000000000
0x4010400100000000
0x4010400200000000
0x4010400300000000
0x4010400400000000
0x4010400500000000
0x4010400600000000
...
```

API provided by the zfc HBA API support

The `s390utils-libzfcphbaapi` RPM provides the HBA API for the zfc device driver.



This section provides information for those who want to program SAN management clients that run on Red Hat Enterprise Linux 6.3 for System z.

Functions provided

The zfc HBA API implements Fibre Channel - HBA API (FC-HBA) functions as defined in the FC-HBA specification.

You can find the FC-HBA specification at www.t11.org. The following functions are available:

- `HBA_GetVersion()`
- `HBA_LoadLibrary()`
- `HBA_FreeLibrary()`
- `HBA_RegisterLibrary()`
- `HBA_RegisterLibraryV2()`
- `HBA_GetNumberOfAdapters()`
- `HBA_RefreshInformation()`
- `HBA_RefreshAdapterConfiguration()`
- `HBA_GetAdapterName()`
- `HBA_OpenAdapter()`
- `HBA_CloseAdapter()`
- `HBA_GetAdapterAttributes()`
- `HBA_GetAdapterPortAttributes()`
- `HBA_GetDiscoveredPortAttributes()`
- `HBA_GetPortStatistics()`
- `HBA_GetFcpTargetMapping()`
- `HBA_GetFcpTargetMappingV2()`
- `HBA_SendScsiInquiry()`
- `HBA_ScsiInquiryV2()`
- `HBA_SendReportLUNs()`
- `HBA_ScsiReportLUNsV2()`
- `HBA_SendReadCapacity()`
- `HBA_ScsiReadCapacityV2()`
- `HBA_SendCTPassThru()`
- `HBA_SendCTPassThruV2()`
- `HBA_GetRNIDMgmtInfo()`
- `HBA_SendRNID()`
- `HBA_SendRNIDV2()`
- `HBA_GetEventBuffer()`

All other FC-HBA functions return status code `HBA_STATUS_ERROR_NOT_SUPPORTED` where possible.

Note: ZFCP HBA API for Linux 2.6 can access only FCP devices, ports and units that are configured in the operating system.

Tools for investigating your SAN configuration

As of version 2.1, the HBA API package includes tools that can help you to investigate your SAN configuration and to solve configuration problems.

zfcplib

to probe a port in the SAN.

zfcplib

to retrieve information about the SAN topology and details about the SAN components.

See *How to use FC-attached SCSI devices with Linux on System z*, SC33-8413 for details.

Environment variables

The zfcplib HBA API support uses environment variables for logging errors in the zfcplib HBA API library.

LIB_ZFCP_HBAAPI_LOG_LEVEL

to specify the log level. If not set or set to zero there is no logging (default). If set to an integer value greater than 1, logging is enabled.

LIB_ZFCP_HBAAPI_LOG_FILE

specifies a file for the logging output. If not specified stderr is used.

Chapter 6. Channel-attached tape device driver

The tape device driver supports channel-attached tape devices on Red Hat Enterprise Linux 6.3 for System z.

SCSI tape devices attached through an FCP channel are handled by the `zfc` device driver (see Chapter 5, “SCSI-over-Fibre Channel device driver,” on page 61).

Features

The tape device driver supports a range of channel-attached tape devices and functions of these devices.

- The tape device driver supports channel-attached tape drives that are compatible with IBM 3480, 3490, 3590, and 3592 magnetic tape subsystems. Various models of these device types are handled (for example, the 3490/10).
3592 devices that emulate 3590 devices are recognized and treated as 3590 devices.
- Character and block devices (see “Tape device modes and logical devices”).
- Control operations through `mt` (see “Using the `mt` command” on page 94).
- Message display support (see “`tape390_display` - display messages on tape devices and load tapes” on page 502).
- Encryption support (see “`tape390_crypt` - manage tape encryption” on page 498).
- Up to 128 physical tape devices.

What you should know about channel-attached tape devices

A naming scheme helps you to keep track of your tape devices, their modes of operation, and the corresponding device nodes.

Tape device modes and logical devices

The tape device driver supports up to 128 physical tape devices. Each physical tape device can be used in three different modes, which the tape device driver treats as separate logical devices.

Non-rewinding character device

Provides sequential (traditional) tape access without any caching done in the kernel.

You can use the character device in the same way as any other Linux tape device. You can write to it and read from it using normal Linux facilities such as GNU `tar`. You can perform control operations (such as rewinding the tape or skipping a file) with the standard tool `mt`. Most Linux tape software should work with the character device.

When the device is closed, the tape remains at the current position.

Rewinding character device

Provides tape access like the non-rewinding device, except that the tape is rewound when the device is closed.

Block device

Provides a read-only tape block device.

This device could be used for the installation of software in the same way as tapes are used under other operating systems on the System z platforms. (This is similar to the way most Linux software distributions are shipped on CD using the ISO9660 file system.)

It is advisable to use only the ISO9660 file system on System z tapes, because this file system is optimized for CD-ROM devices, which – just like 3480, 3490, or 3590 tape devices – cannot perform fast searches.

The ISO9660 file system image file need not be the first file on the tape but can start at any position. The tape must be positioned at the start of the image file before the mount command is issued to the tape block device.

The file system image must reside on a single tape. Tape block devices cannot span multiple tape volumes.

Tape naming scheme

The tape device driver assigns minor numbers along with an index number when a physical tape device comes online.

The naming scheme for tape devices is summarized in Table 17:

Table 17. Tape device names and minor numbers

Device	Names	Minor numbers
Non-rewinding character devices	ntibm<n>	2×<n>
Rewinding character devices	rtibm<n>	2×<n>+1
Block devices	btibm<n>	2×<n>

where <n> is the index number assigned by the device driver. The index starts from 0 for the first physical tape device, 1 for the second, and so on. The name space is restricted to 128 physical tape devices, so the maximum index number is 127 for the 128th physical tape device.

The index number and corresponding minor numbers and device names are not permanently associated with a specific physical tape device. When a tape device goes offline it surrenders its index number. The device driver assigns the lowest free index number when a physical tape device comes online. An index number with its corresponding device names and minor numbers can be reassigned to different physical tape devices as devices go offline and come online.

Tip: Use the **lstape** command (see “lstape - List tape devices” on page 471) to determine the current mapping of index numbers to physical tape devices.

When the tape device driver is loaded, it dynamically allocates a major number to channel-attached character tape devices and a major number to channel-attached block tape devices. The major numbers can but need not be the same. Different major number might be used when the device driver is reloaded, for example when Linux is rebooted.

For online tape devices directories provide information about the major/minor assignments. The directories have the form:

- /sys/class/tape390/ntibm<n>
- /sys/class/tape390/rtibm<n>
- /sys/block/btibm<n>

Each of these directories has a dev attribute. The value of the dev attribute has the form `<major>:<minor>`, where `<major>` is the major number for the character or block tape devices and `<minor>` is the minor number specific to the logical device.

Example:

In this example, four physical tape devices are present, with three of them online. The TapeNo column shows the index number and the BusID indicates the associated physical tape device. In the example, no index number has been allocated to the tape device in the first row. This means that the device is offline and, currently, no names and minor numbers are assigned to it.

```
# lsape --ccw-only
TapeNo  BusID      CuType/Model  DevType/DevMod  BlkSize  State   Op      MedState
0       0.0.01a1   3490/10       3490/40         auto     UNUSED  ---     UNLOADED
1       0.0.01a0   3480/01       3480/04         auto     UNUSED  ---     UNLOADED
2       0.0.0172   3590/50       3590/11         auto     IN_USE  ---     LOADED
N/A     0.0.01ac   3490/10       3490/40         N/A      OFFLINE ---     N/A
```

The resulting names and minor numbers are:

Table 18. Example names and minor numbers

Bus ID	Index (TapeNo)	Device	Device name	Minor number
0.0.01a1	0	non-rewind	ntibm0	0
		rewind	rtibm0	1
0.0.01a0	1	non-rewind	ntibm1	2
		rewind	rtibm1	3
0.0.0172	2	non-rewind	ntibm2	4
		rewind	rtibm2	5
0.0.01ac	not assigned	n/a	n/a	not assigned

For the online character devices, the major/minor assignments can be read from their respective representations in `/sys/class`:

```
# cat /sys/class/tape390/ntibm0/dev
254:0
# cat /sys/class/tape390/rtibm0/dev
254:1
# cat /sys/class/tape390/ntibm1/dev
254:2
# cat /sys/class/tape390/rtibm1/dev
254:3
# cat /sys/class/tape390/ntibm2/dev
254:4
# cat /sys/class/tape390/rtibm2/dev
254:5
```

In the example, the major number used for character devices is 254 the minor numbers are as expected for the respective device names.

Similarly, the major/minor assignments for the online block devices can be read from their respective representations in `/sys/block`:

```
# cat /sys/block/btibt0/dev
254:0
# cat /sys/block/btibt1/dev
254:2
# cat /sys/block/btibt2/dev
254:4
```

The minor numbers are as expected for the respective device names. In the example, the major number used for block devices is also 254.

Tape device nodes

Applications access tape devices by device nodes. Red Hat Enterprise Linux 6.3 uses udev to create three device nodes for each tape device.

The device nodes have the form `/dev/<name>`, where `<name>` is the device name according to “Tape naming scheme” on page 92.

For example, if you have two tape devices, udev will create the device nodes shown in Table 19:

Table 19. Tape device nodes

Node for	non-rewind device	rewind device	block device
First tape device	<code>/dev/ntibt0</code>	<code>/dev/rtibt0</code>	<code>/dev/btibt0</code>
Second tape device	<code>/dev/ntibt1</code>	<code>/dev/rtibt1</code>	<code>/dev/btibt1</code>

Using the `mt` command

There are differences between the MTIO interface for channel-attached tapes and other tape drives. Correspondingly, some operations of the `mt` command are different for channel-attached tapes.

The `mt` command handles basic tape control in Linux. See the man page for general information about `mt`.

Basic Linux tape control is handled by the `mt` utility. See the man page for general information about `mt`.

`setdensity`

has no effect because the recording density is automatically detected on channel-attached tape hardware.

`drvbuffer`

has no effect because channel-attached tape hardware automatically switches to unbuffered mode if buffering is unavailable.

`lock / unlock`

have no effect because channel-attached tape hardware does not support media locking.

`setpartition / mkpartition`

have no effect because channel-attached tape hardware does not support partitioning.


status returns a structure that, aside from the block number, contains mostly SCSI-related data that does not apply to the tape device driver.

- load** does not automatically load a tape but waits for a tape to be loaded manually.
- offline** or **rewoffl** or **eject** all include expelling the currently loaded tape. Depending on the stacker mode, it might attempt to load the next tape (see “Loading and unloading tapes” on page 99 for details).

Setting up the tape device driver

You must load the appropriate tape device driver module before you can work with tape devices.

Use the **modprobe** command to ensure that any other required modules are loaded in the correct order.



See the **modprobe** man page for details about **modprobe**.

To load the tape device driver module automatically at boot time, see the section on persistent module loading in *Red Hat Enterprise Linux 6.3 Deployment Guide*

Working with tape devices

Typical tasks for working with tape devices include displaying tape information, controlling compression, and loading and unloading tapes.

- Setting a tape device online or offline
- Displaying tape information
- Enabling compression
- Loading and unloading tapes

For information about working with the channel measurement facility, see Chapter 40, “Channel measurement facility,” on page 379.

For information about displaying messages on a tape device's display unit, see “tape390_display - display messages on tape devices and load tapes” on page 502.

See “Working with newly available devices” on page 10 to avoid errors when working with devices that have become available to a running Linux instance.

Setting a tape device online or offline

Set a tape device online or offline with the **chccwdev** command or through the `online sysfs` attribute of the device.

Setting a physical tape device online makes all corresponding logical devices accessible:

- The non-rewind character device
- The rewind character device

- The block device (if supported)

At any time, the device can be online to a single Linux instance only. You must set the tape device offline to make it accessible to other Linux instances in a shared environment.

Use the **chccwdev** command (see “chccwdev - Set a CCW device online” on page 396) to set a tape online or offline. Alternatively, you can write “1” to the device's online attribute to set it online or “0” to set it offline.

When a physical tape device is set online, the device driver assigns an index number to it. This index number is used in the standard device nodes (see “Tape device nodes” on page 94) to identify the corresponding logical devices. The index number is in the range 0 to 127. A maximum of 128 physical tape devices can be online concurrently.

If you are using the standard device nodes, you need to find out which index number the tape device driver has assigned to your tape device. This index number, and consequently the associated standard device node, can change after a tape device has been set offline and back online.

If you need to know the index number, issue a command of this form:

```
# lstape --ccw-only <device_bus_id>
```

where *<device_bus_id>* is the device bus-ID that corresponds to the physical tape device. The index number is the value in the TapeNo column of the command output.

Examples:

- To set a physical tape device with device bus-ID 0.0.015f online, issue:

```
# chccwdev -e 0.0.015f
```

or

```
# echo 1 > /sys/bus/ccw/devices/0.0.015f/online
```

To find the index number the tape device driver has assigned, issue:

```
# lstape 0.0.015f --ccw-only
TapeNo  BusID      CuType/Model  DevType/Model  BlkSize  State   Op      MedState
2        0.0.015f      3480/01       3480/04        auto    UNUSED  ---    LOADED
```

In the example, the assigned index number is “2”. The standard device nodes for working with the device until it is set offline are then:

- /dev/ntibm2 for the non-rewinding device
- /dev/rtibm2 for the rewinding device
- /dev/btibm2 for the block device

- To set a physical tape device with device bus-ID 0.0.015f offline, issue:

```
# chccwdev -d 0.0.015f
```


or

```
# echo 0 > /sys/bus/ccw/devices/0.0.015f/online
```

Displaying tape information

Use the **lstape** command to display summary information about your tape devices, or read tape information from sysfs.

Alternatively, you can read tape information from sysfs. Each physical tape device is represented in a sysfs directory of the form

```
/sys/bus/ccw/devices/<device_bus_id>
```

where *<device_bus_id>* is the device bus-ID that corresponds to the physical tape device. This directory contains a number of attributes with information about the physical device. The attributes: *blocksize*, *state*, *operation*, and *medium_state*, might not show the current values if the device is offline.

Table 20. Tape device attributes

Attribute	Explanation	
online	“1” if the device is online or “0” if it is offline (see “Setting a tape device online or offline” on page 95)	
cmb_enable	“1” if channel measurement block is enabled for the physical device or “0” if it is not enabled (see Chapter 40, “Channel measurement facility,” on page 379)	
cutype	Type and model of the control unit	
devtype	Type and model of the physical tape device	
blocksize	Currently used block size in bytes or “0” for auto	
state	State of the physical tape device, either of:	
	UNUSED	Device is not in use and is currently available to any operating system image in a shared environment
	IN_USE	Device is being used as a character device by a process on this Linux image
	BLKUSE	Device is being used as a block device by a process on this Linux image
	OFFLINE	The device is offline.
operation	NOT_OP	Device is not operational
	The current tape operation, for example:	
	---	No operation
	WRI	Write operation
	RFO	Read operation
	MSN	Medium sense
Several other operation codes exist, for example, for rewind and seek.		

Table 20. Tape device attributes (continued)

Attribute	Explanation
medium_state	The current state of the tape cartridge: <ul style="list-style-type: none"> 1 Cartridge is loaded into the tape device 2 No cartridge is loaded 0 The tape device driver does not have information about the current cartridge state

Issue a command of this form to read an attribute:

```
# cat /sys/bus/ccw/devices/<device_bus_id>/<attribute>
```

where *<attribute>* is one of the attributes of Table 20 on page 97.

Example:

The following **lstape** command displays information about a tape device with bus ID 0.0.015f:

```
# lstape 0.0.015f --ccw-only
TapeNo  BusID      CuType/Model  DevType/Model  BlkSize  State  Op    MedState
2        0.0.015f    3480/01      3480/04       auto    UNUSED ---    LOADED
```

This sequence of commands reads the same information from sysfs:

```
# cat /sys/bus/ccw/devices/0.0.015f/online
1
# cat /sys/bus/ccw/devices/0.0.015f/cmb_enable
0
# cat /sys/bus/ccw/devices/0.0.015f/cutype
3480/01
# cat /sys/bus/ccw/devices/0.0.015f/devtype
3480/04
# cat /sys/bus/ccw/devices/0.0.015f/blocksize
0
# cat /sys/bus/ccw/devices/0.0.015f/state
UNUSED
# cat /sys/bus/ccw/devices/0.0.015f/operation
---
# cat /sys/bus/ccw/devices/0.0.015f/medium_state
1
```

Enabling compression

Control Improved Data Recording Capability (IDRC) compression with the **mt** command provided by the RPM **mt-st**.

Compression is off after the tape device driver has loaded. To switch compression on, issue:

```
# mt -f <node> compression
```

or

```
# mt -f <node> compression 1
```

where *<node>* is the device node for a character device, for example, */dev/ntibm0*.

To switch compression off, issue:

```
# mt -f <tape> compression 0
```

Any other numeric value has no effect, and any other argument switches compression off.

Example:

To switch on compression for a tape device with a device node */dev/ntibm0* issue:

```
# mt -f /dev/ntibm0 compression 1
```

Loading and unloading tapes

Unload tapes with the **mt** command. How to load tapes depends on the stacker mode of your tape hardware.

Unload tapes by issuing a command of this form:

```
# mt -f <node> unload
```

where *<node>* is one of the character device nodes.

Whether or not you can load tapes from your Linux instance depends on the stacker mode of your tape hardware. There are three possible modes:

manual

Tapes must always be loaded manually by an operator. You can use the **tape390_display** command (see “**tape390_display** - display messages on tape devices and load tapes” on page 502) to display a short message on the tape device's display unit when a new tape is required.

automatic

If there is another tape present in the stacker, the tape device automatically loads a new tape when the current tape is expelled. You can load a new tape from Linux by expelling the current tape with the **mt** command.

system

The tape device loads a tape when instructed from the operating system. From Linux, you can load a tape with the **tape390_display** command (see “**tape390_display** - display messages on tape devices and load tapes” on page 502). You cannot use the **mt** command to load a tape.

Example:

To expel a tape from a tape device that can be accessed through a device node */dev/ntibm0*, issue:

```
# mt -f /dev/ntibm0 unload
```

Assuming that the stacker mode of the tape device is “system” and that a tape is present in the stacker, you can load a new tape by issuing:

```
# tape390_display -l "NEW TAPE" /dev/ntibm0
```

“NEW TAPE” is a message that is displayed on the tape devices display unit until the tape device receives the next tape movement command.

Scenario: Using a tape block device

An ISO9660 file system is to be created as the second file on a tape.

This scenario uses the **mt** and **mkisofs** commands. See the respective man pages for details.

Assumptions: The following assumptions are made:

- The required tape device driver modules have either been compiled into the kernel or have already been loaded.
 - The ISO9660 file system support has been compiled into the kernel.
 - A tape device is attached through a device bus-ID 0.0.015f.
1. Create a Linux directory, `somedir`, and fill it with the contents of the file system:

```
# mkdir somedir
# cp <contents> somedir
```

2. Set the tape online:

```
# chccwdev -e 0.0.015f
```

3. If you are using standard device nodes, find out which index number the tape device driver has assigned to it. You can skip this step if you are using udev-created device nodes that distinguish devices by device bus-ID rather than the index number.

```
# lstape 0.0.015f --ccw-only
TapeNo  BusID      CuType/Model  DevType/Model  BlkSize  State   Op      MedState
1        0.0.015f    3480/01      3480/04        auto    UNUSED  ---     LOADED
```

The index number is shown in the `TapeNo` column of the command output, “1” in the example. The standard device nodes are therefore `/dev/ntibm1`, `/dev/rtibm1`, and `/dev/btibm1`.

4. Insert a tape.
5. Ensure the tape is positioned at the correct position on the tape. For example, to set it to the beginning of the second file, issue:

```
# mt -f /dev/ntibm1 rewind
# mt -f /dev/ntibm1 fsf 1
```

`fsf` skips a specified number of files, one in the example.

6. Set the block size of the character driver. (The block size 2048 bytes is commonly used on ISO9660 CD-ROMs.)

```
# mt -f /dev/ntibm1 setblk 2048
```

7. Write the file system to the character device driver:

```
# mkisofs -l -f -o file.iso somedir  
# dd if=file.iso of=/dev/ntibm1 bs=2048
```

8. Set the tape to the beginning of the file:

```
# mt -f /dev/ntibm1 rewind  
# mt -f /dev/ntibm1 fsf 1
```

9. Now you can mount your new file system as a block device:

```
# mount -t iso9660 -o ro,block=2048 /dev/btibm1 /mnt
```

Chapter 7. XPRAM device driver

With the XPRAM block device driver Red Hat Enterprise Linux 6.3 for System z can access expanded storage. Thus XPRAM can be used as a basis for fast swap devices and/or fast file systems. Expanded storage can be swapped in or out of the main storage in 4 KB blocks. All XPRAM devices provide a block size of 4096 bytes.

XPRAM features

The XPRAM device driver provides the following features:

- Automatic detection of expanded storage.
If expanded storage is not available, XPRAM fails gracefully with a log message reporting the absence of expanded storage.
- The expanded storage can be divided into up to 32 partitions.

What you should know about XPRAM

This section provides information about XPRAM partitions and the device nodes that make them accessible.

XPRAM partitions and device nodes

The XPRAM device driver uses major number 35. The standard device names are of the form `slram<n>`, where `<n>` is the corresponding minor number.

You can use the entire available expanded storage as a single XPRAM device or divide it into up to 32 partitions. Each partition is treated as a separate XPRAM device.

If the entire expanded storage is used a single device, the device name is `slram0`. For partitioned expanded storage, the `<n>` in the device name denotes the (n+1)th partition. For example, the first partition is called `slram0`, the second `slram1`, and the 32nd partition is called `slram31`.

Table 21. XPRAM device names, minor numbers, and partitions

Minor	Name	To access
0	slram0	the first partition or the entire expanded storage if there are no partitions
1	slram1	the second partition
2	slram2	the third partition
...
<n>	slram<n>	the (<n>+1)th partition
...
31	slram31	the 32nd partition

The device nodes that you need to access these partitions are created by `udev` when you load the XPRAM device driver module. The nodes are of the form

/dev/slram<n>, where <n> is the index number of the partition. In addition, to the device nodes udev creates a symbolic link of the form /dev/xpram<n> that points to the respective device node.

XPRAM use for diagnosis

Issuing an IPL command to reboot Linux does not reset expanded storage, so it is persistent across IPLs and could be used, for example, to store diagnostic information. The expanded storage is reset when logging off the z/VM guest virtual machine or when deactivating the LPAR.

Reusing XPRAM partitions

You might be able to reuse existing file systems or swap devices on an XPRAM device or partition after reloading the XPRAM device driver (for example, after rebooting Linux). For file systems or swap devices to be reusable, the XPRAM kernel or module parameters for the new device or partition must match the parameters of the previous use of XPRAM.


If you change the XPRAM parameters, you must create a new file system (for example with **mke2fs**) or a new swap device for each partition that has changed. A device or partition is considered changed if its size has changed. All partitions following a changed partition are also considered changed even if their sizes are unchanged.

Setting up the XPRAM device driver

This section describes how to load the XPRAM device driver and how to split the available expanded storage into partitions.

You can optionally partition the available expanded storage by using the `devs` and `sizes` module parameters when you load the `xpram` module.

XPRAM module parameter syntax



where:

<number_of_partitions>

is an integer in the range 1 to 32 that defines how many partitions the expanded storage is split into.

<partition_size>

specifies the size of a partition. The *i*-th value defines the size of the *i*-th partition.

Each size is a non-negative integer that defines the size of the partition in KB or a blank. Only decimal values are allowed and no magnitudes are accepted.

You can specify up to **<number_of_partitions>** values. If you specify less values than **<number_of_partitions>**, the missing values are interpreted as blanks. Blanks are treated like zeros.

Any partition defined with a non-zero size is allocated the amount of memory specified by its size parameter.

Any remaining memory is divided as equally as possible among any partitions with a zero or blank size parameter, subject to the two constraints that blocks must be allocated in multiples of 4K and addressing constraints may leave un-allocated areas of memory between partitions.

Examples

- The following specification allocates the extended storage into four partitions. Partition 1 has 2 GB (2097152 KB), partition 4 has 4 GB (4194304 KB), and partitions 2 and 3 use equal parts of the remaining storage. If the total amount of extended storage was 16 GB, then partitions 3 and 4 would each have approximately 5 GB.

```
# modprobe xpram devs=4 sizes=2097152,0,0,4194304
```

- The following specification allocates the extended storage into three partitions. The partition 2 has 512 KB and the partitions 1 and 3 use equal parts of the remaining extended storage.

```
# modprobe xpram devs=3 sizes=,512
```

- The following specification allocates the extended storage into two partitions of equal size.

```
# modprobe xpram devs=2
```

See the **modprobe** man page for details about **modprobe**.

To load the XPRAM device driver module automatically at boot time, see the section on persistent module loading in *Red Hat Enterprise Linux 6.3 Deployment Guide*

Part 3. Networking

This part describes the network device drivers for Red Hat Enterprise Linux 6.3 for System z.

Newest version: You can find the newest version of this book at www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

Restrictions: For prerequisites and restrictions see the System z architecture specific information in the Red Hat Enterprise Linux 6.3 release notes at docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

Chapter 8. qeth device driver for OSA-Express (QDIO) and HiperSockets.	
Device driver functions	111
What you should know about the qeth device driver	114
Setting up the qeth device driver	120
Working with qeth devices	121
Working with qeth devices in layer 3 mode	137
Scenario: VIPA – minimize outage due to adapter failure	147
Scenario: Virtual LAN (VLAN) support	152
HiperSockets Network Concentrator	156
Setting up for DHCP with IPv4	161
Setting up Linux as a LAN sniffer	162
Chapter 9. OSA-Express SNMP subagent support	165

What you need to know about osasnmppd	165
Setting up osasnmppd	166
Working with the osasnmppd subagent	170

Chapter 10. LAN channel station device driver	173
What you should know about LCS	173
Setting up the LCS device driver	174
Working with LCS devices	174

Chapter 11. CTCM device driver	179
Features	179
What you should know about CTCM	179
Setting up the CTCM device driver	181
Working with CTCM devices	181
Scenarios	187

An example network setup that uses some available network setup types is shown in Figure 14.




Figure 14. Networking example

In the example there are three Linux instances; two of them run as z/VM guests in one LPAR and a third Linux instance runs in another LPAR. Within z/VM, Linux instances can be connected through a guest LAN or VSWITCH. Within and

between LPARs, you can connect Linux instances through HiperSockets. OSA-Express cards running in either non-QDIO mode (called LCS here) or in QDIO mode can connect the System z mainframe to an external network.

Table 22 lists which control units and device type combinations are supported by the network device drivers.

Table 22. Supported device types, control units, and corresponding device drivers

Device type	Control unit	Device driver	Comment
1732/01	1731/01	qeth	OSA configured as OSD
1732/02	1731/02	qeth	OSA configured as OSX
1732/03	1731/02	qeth	OSA configured as OSM
1732/05	1731/05	qeth	HiperSockets
1732/06	1732/06	qeth	OSA configured as OSN
0000/00	3088/01	lcs	P/390
0000/00	3088/08	ctcm	Virtual CTC under z/VM
0000/00	3088/1e	ctcm	FICON channel
0000/00	3088/1f	lcs	2216 Nways Multiaccess Connector
0000/00	3088/1f	ctcm	ESCON channel
0000/00	3088/60	lcs	OSA configured as OSE (non-QDIO)

Chapter 8. qeth device driver for OSA-Express (QDIO) and HiperSockets

The qeth device driver supports a multitude of network connections, for example, connections through Open Systems Adapters (OSA), HiperSockets, guest LANs, and virtual switches.

Real connections using OSA-Express

A System z mainframe offers OSA-Express adapters, which are real LAN-adapter hardware, see Figure 15. These adapters provide connections to the outside world, but can also connect virtual systems (between LPARs or between z/VM guest virtual machines) within the mainframe. The qeth driver supports these adapters if they are defined to run in queued direct I/O (QDIO) mode (defined as OSD or OSN in the hardware configuration). OSD-devices are the standard System z LAN-adapters, while OSN-devices serve as NCP-adapters. For details about OSA-Express in QDIO mode, see *OSA-Express Customer's Guide and Reference*, SA22-7935.




Figure 15. OSA-Express adapters are real LAN-adapter hardware

The OSA-Express LAN adapter may serve as a Network Control Program (NCP) adapter for an internal ESCON/CDLC interface to another mainframe operating system. This feature is exploited by the IBM Communication Controller for Linux (CCL) introduced with System z9. Note that the OSA CHPID type does not support any additional network functions and its only purpose is to provide a bridge between the CDLC and QDIO interfaces to connect to the Linux NCP. For more details see the *IBM Communication Controller Migration Guide*, SG24-6298.

As of zEnterprise, the qeth device driver supports CHPIDs of type OSM and OSX. CHPID OSM (OSA-Express for Unified Resource Manager) provides connectivity to the intranode management network (INMN) from Unified Resource Manager functions to a z196 or z114 CPC. CHPID OSX (OSA-Express for zBX) provides connectivity to and access control for the intraensemble data network (IEDN), which is managed by Unified Resource Manager functions and connects z196 or z114 CPCs and zBXs

within an ensemble. See *zEnterprise System Introduction to Ensembles*, GC27-2609 and *zEnterprise System Ensemble Planning and Configuring Guide*, GC27-2608 for more details.

HiperSockets

A System z mainframe offers internal connections called *HiperSockets*. These simulate QDIO network adapters and provide high-speed TCP/IP communication for operating system instances within and across LPARs. For details about HiperSockets, see *HiperSockets Implementation Guide*, SG24-6816.

Virtual connections for Linux on z/VM

z/VM offers virtualized LAN-adapters that enable connections between z/VM guest virtual machines and the outside world. It allows definitions of simulated network interface cards (NICs) attached to certain z/VM guest virtual machines. The NICs can be connected to a simulated LAN segment called *guest LAN* for z/VM internal communication between z/VM guest virtual machines, or they can be connected to a virtual switch called *VSWITCH* for external LAN connectivity.

Guest LAN

Guest LANs represent a simulated LAN segment that can be connected to simulated network interface cards. There are three types of guest LANs:

- Simulated OSA-Express in layer 3 mode
- Simulated HiperSockets (layer 3) mode
- Simulated Ethernet in layer 2 mode

Each guest LAN is isolated from other guest LANs on the same system (unless some member of one LAN group acts as a router to other groups).

Virtual switch

A virtual switch (VSWITCH) is a special-purpose guest LAN that provides external LAN connectivity through an additional OSA-Express device served by z/VM without the need for a routing virtual machine, see Figure 16.




Figure 16. Virtual switch

A dedicated OSA adapter can be an option, but is not required for a VSWITCH.

From a Linux point of view there is no difference between guest LAN- and VSWITCH-devices; thus Linux talks about guest LAN-devices independently of their z/VM-attachment to a guest LAN or VSWITCH.

For information about guest LANs, virtual switches, and virtual HiperSockets, see *z/VM Connectivity*, SC24-6174.

The qeth network device driver supports the System z OSA-Express4, OSA-Express3, OSA-Express2, and OSA-Express features and HiperSockets as shown in Table 23:

Table 23. The qeth device driver support for HiperSockets and OSA-Express features

Feature	z196 and z114	System z10	System z9
HiperSockets	Yes	Yes	Yes (layer 3 only)
OSA-Express4	Gigabit Ethernet 10 Gigabit Ethernet	Not supported	Not supported
OSA-Express3	Gigabit Ethernet 10 Gigabit Ethernet 1000Base-T Ethernet	Gigabit Ethernet 10 Gigabit Ethernet 1000Base-T Ethernet	Not supported
OSA-Express2	Gigabit Ethernet 1000Base-T Ethernet	Gigabit Ethernet 10 Gigabit Ethernet 1000Base-T Ethernet	Gigabit Ethernet 10 Gigabit Ethernet 1000Base-T Ethernet
OSA-Express	Not supported	Not supported	Fast Ethernet Gigabit Ethernet 1000Base-T Ethernet

Note: Unless otherwise indicated, OSA-Express refers to OSA-Express, OSA-Express2, OSA-Express3, and OSA-Express4.

Device driver functions

The qeth device driver supports many networking transport protocol functions, as well as offload functions and problem determination functions.

The qeth device driver supports functions listed in Table 24 and Table 25 on page 113.

Table 24. Real connections

Function	OSA Layer 2	OSA Layer 3	HiperSockets Layer 2 Ethernet	HiperSockets Layer 3 Ethernet
Basic device or protocol functions				
IPv4/multicast/broadcast	Yes/Yes/Yes	Yes/Yes/Yes	Yes/Yes/Yes	Yes/Yes/Yes
IPv6/multicast	Yes/Yes	Yes/Yes	Yes/Yes	Yes/Yes
Non-IP traffic	Yes	Yes	Yes	No
VLAN IPv4/IPv6/non IP	sw/sw/sw	hw/sw/sw	sw/sw/sw	hw/sw/No
Linux ARP	Yes	No (hw ARP)	Yes	No
Linux neighbor solicitation	Yes	Yes	Yes	No
Unique MAC address	Yes (random)	No	Yes	Yes
Change MAC address	Yes	No	Yes	No

Table 24. Real connections (continued)

Function	OSA Layer 2	OSA Layer 3	HiperSockets Layer 2 Ethernet	HiperSockets Layer 3 Ethernet
Promiscuous mode	No	No	No	<ul style="list-style-type: none"> • Yes (for sniffer=1) • No (for sniffer=0)
MAC headers send/receive	Yes/Yes	faked/faked	Yes/Yes	faked/faked
ethtool support	Yes	Yes	Yes	Yes
Bonding	Yes	No	Yes	No
Priority queueing	Yes	Yes	Yes	Yes
Secondary unicast MAC address	Yes	No	Yes	No
Offload features				
TCP segmentation offload (TSO)	No	Yes	No	No
Inbound (rx) checksum	No	Yes	No	No
Outbound (tx) checksum	No	Yes	No	No
OSA/QETH specific features				
Special device driver setup for VIPA	No	required	No	Yes
Special device driver setup for proxy ARP	No	required	No	Yes
Special device driver setup for IP takeover	No	required	No	Yes
Special device driver setup for routing IPv4/IPv6	No/No	required/required	No/No	Yes/Yes
Receive buffer count	Yes	Yes	Yes	Yes
Direct connectivity to z/OS	Yes by HW	Yes	No	Yes
SNMP support	Yes	Yes	No	No
Multiport support	Yes	Yes	No	No
Data connection isolation	Yes	Yes	No	No
Problem determination				
Hardware trace	No	Yes	No	No
Legend: No Function not supported or not required. Yes Function supported. hw Function performed by hardware. sw Function performed by software. faked Function will be simulated. required Function requires special setup.				

Table 25. Guest LAN connections

Function	OSA Layer 2	OSA Layer 3	HiperSockets (Layer 3)
Basic device or protocol features			
IPv4/multicast/broadcast	Yes/Yes/Yes	Yes/Yes/Yes	Yes/Yes/Yes
IPv6/multicast	Yes/Yes	Yes/Yes	No/No
Non-IP traffic	Yes	No	No
VLAN IPv4/IPv6/non IP	sw/sw/sw	hw/sw/No	hw/No/No
Linux ARP	Yes	No (hw ARP)	No
Linux neighbor solicitation	Yes	Yes	No
Unique MAC address	Yes	No	Yes
Change MAC address	Yes	No	No
Promiscuous mode	Yes	Yes	No
MAC headers send/receive	Yes/Yes	faked/faked	faked/faked
ethtool support	Yes	Yes	Yes
Bonding	Yes	No	No
Priority queueing	Yes	Yes	Yes
Secondary unicast MAC address	Yes	No	No
Offload features	No	No	No
OSA/QETH specific features			
Special device driver setup for VIPA	No	required	required
Special device driver setup for proxy ARP	No	required	required
Special device driver setup for IP takeover	No	required	required
Special device driver setup for routing IPv4/IPv6	No/No	required/required	required/required
Receive buffer count	Yes	Yes	Yes
Direct connectivity to z/OS	No	Yes	Yes
SNMP support	No	No	No
Multiport support	No	No	No
Data connection isolation	No	No	No
Problem determination			
Hardware trace	No	No	No
Legend: No Function not supported or not required. Yes Function supported. hw Function performed by hardware. sw Function performed by software. faked Function will be simulated. required Function requires special setup.			

What you should know about the qeth device driver

Interface names are assigned to qeth group devices, which map to subchannels and their corresponding device numbers and device bus-IDs. An OSA-Express adapter can handle both IPv4 and IPv6 packets.

Layer 2 and layer 3

The qeth device driver consists of a common core and two device disciplines: layer 2 and layer 3.

In layer 2 mode, OSA routing to the destination Linux instance is based on MAC addresses. A local MAC address is assigned to each interface of a Linux instance and registered in the OSA Address Table. These MAC addresses are unique and different from the MAC address of the OSA adapter. See “MAC headers in layer 2 mode” on page 117 for details.

In layer 3 mode, all interfaces of all Linux instances share the MAC address of the OSA adapter. OSA routing to the destination Linux instance is based on IP addresses. See “MAC headers in layer 3 mode” on page 118 for details.

The layer 2 discipline (qeth_l2)

The layer 2 discipline supports:

- OSA and OSA guest LAN devices
- OSA for NCP devices
- HiperSockets devices (as of System z10)
- OSM devices for Unified Resource Manager
- OSX for OSA-Express devices for zBX

The layer 2 discipline is the default setup for OSA. On HiperSockets the default continues to be layer 3. OSA guest LANs are layer 2 by default, while HiperSockets guest LANs are always layer 3. See “Setting the layer2 attribute” on page 125 for details.

The layer 3 discipline (qeth_l3)

The layer 3 discipline supports:

- OSA and OSA guest LAN devices running in layer 3 mode (with faked link layer headers)
- HiperSockets and HiperSockets guest LAN devices running in layer 3 mode (with faked link layer headers)
- OSX for OSA-Express devices for zBX

This discipline supports those devices that are not capable of running in layer 2 mode. Not all Linux networking features are supported and others need special setup or configuration. See Table 30 on page 122. Some performance-critical applications might benefit from being layer 3.

Keep layer 2 and layer 3 guest LANs separate and keep layer 2 and layer 3 HiperSockets LANs separate. Layer 2 and layer 3 interfaces cannot communicate within a HiperSockets LAN or guest LAN.

qeth group devices

The qeth device driver requires three I/O subchannels for each HiperSockets CHPID or OSA-Express CHPID in QDIO mode. One subchannel is for control reads, one for control writes, and the third is for data.

The qeth device driver uses the QDIO protocol to communicate with the HiperSockets and OSA-Express adapter.




Figure 17. I/O subchannel interface

The three device bus-IDs that correspond to the subchannel triplet are grouped as one qeth group device. The following rules apply for the device bus-IDs:

- read** no specific rules.
- write** must be the device bus-ID of the read subchannel plus one.
- data** can be any free device bus-ID on the same CHPID.

You can configure different triplets of device bus-IDs on the same CHPID differently. For example, if you have two triplets on the same CHPID they can have different attribute values for priority queueing.

Overview of the steps for setting up a qeth group device

You need to perform several steps before user-space applications on your Linux instance can use a qeth group device.

Before you begin: Find out how the hardware is configured and which qeth device bus-IDs are on which CHPID, for example by looking at the IOCDS. Identify the device bus-IDs that you want to group into a qeth group device. The three device bus-IDs must be on the same CHPID.

Perform these steps to allow user-space applications on your Linux instance to use a qeth group device:

1. Create the qeth group device.
After booting Linux, each qeth device bus-ID is represented by a subdirectory in `/sys/bus/ccw/devices/`. These subdirectories are then named with the bus IDs of the devices. For example, a qeth device with bus IDs 0.0.fc00, 0.0.fc01, and 0.0.fc02 is represented as `/sys/bus/ccw/drivers/qeth/0.0.fc00`
2. Configure the device.
3. Set the device online.
4. Activate the device and assign an IP address to it.

These tasks and the configuration options are described in detail in “Working with qeth devices” on page 121.

qeth interface names and device directories

The qeth device driver automatically assigns interface names to the qeth group devices and creates the corresponding sysfs structures.

According to the type of CHPID and feature used, the naming scheme uses the following base names:

eth<*n*> for Ethernet features.
hsi<*n*> for HiperSockets devices.
osn<*n*> for ESCON/CDLC bridge (OSA NCP).

where <*n*> is an integer that uniquely identifies the device. When the first device for a base name is set online it is assigned 0, the second is assigned 1, the third 2, and so on. Each base name is counted separately.

For example, the interface name of the first Ethernet feature that is set online is “eth0”, the second “eth1”, and so on. When the first HiperSockets device is set online, it is assigned the interface name “hsi0”.

While an interface is online, it is represented in sysfs as:
`/sys/class/net/<interface>`

The qeth device driver shares the name space for Ethernet interfaces with the LCS device driver. Each driver uses the name with the lowest free identifier <*n*>, regardless of which device driver occupies the other names. For example, if the first qeth Ethernet feature is set online and there is already one LCS Ethernet feature online, the LCS feature is named “eth0” and the qeth feature is named “eth1”. See also “LCS interface names” on page 173.

The mapping between interface names and the device bus-ID that represents the qeth group device in sysfs is preserved when a device is set offline and back online. However, it can change when rebooting, when devices are ungrouped, or when devices appear or disappear with a machine check.

“Finding out the interface name of a qeth group device” on page 130 and “Finding out the bus ID of a qeth interface” on page 130 provide information about mapping device bus-IDs and interface names.

Support for IP Version 6 (IPv6)

The qeth device driver supports IPv6 in many network setups.

IPv6 is supported on:

- Ethernet interfaces of the OSA-Express adapter running in QDIO mode.
- HiperSockets layer 2 and layer 3 interfaces.
- z/VM guest LAN interfaces running in QDIO or HiperSockets layer 3 mode.
- z/VM guest LAN and VSWITCH interfaces in layer 2.

There are noticeable differences between the IP stacks for versions 4 and 6. Some concepts in IPv6 are different from IPv4, such as neighbor discovery, broadcast, and Internet Protocol security (IPsec). IPv6 uses a 16-byte address field, while the addresses under IPv4 are 4 bytes in length.

Stateless autoconfiguration generates unique IP addresses for all Linux instances, even if they share an OSA-Express adapter with other operating systems.

Be aware of the IP version when specifying IP addresses and when using commands that return IP version specific output (for example, `qetharp`).

MAC headers in layer 2 mode

In LAN environments, data packets find their destination through Media Access Control (MAC) addresses in their MAC header.

In LAN environments, data packets find their destination through Media Access Control (MAC) addresses in their MAC header (see Figure 18).




Figure 18. Standard IPv4 processing

MAC address handling as shown in Figure 18) applies to non-mainframe environments and a mainframe environment with an OSA-Express adapter where the layer2 option is enabled.

The layer2 option keeps the MAC addresses on incoming packets. Incoming and outgoing packets are complete with a MAC header at all stages between the Linux network stack and the LAN as shown in Figure 18. This layer2-based forwarding requires unique MAC addresses for all concerned Linux instances.

In layer 2 mode, the Linux TCP/IP stack has full control over the MAC headers and the neighbor lookup. The Linux TCP/IP stack does not configure IPv4 or IPv6 addresses into the hardware, but requires a unique MAC address for the card. Users working with a directly attached OSA-card should assign a unique MAC-address themselves.

For Linux instances that are directly attached to an OSA-Express adapter in QDIO mode, you should assign the MAC addresses yourself. You can add a line `LLADDR='<MAC address>'` to the configuration file `/etc/sysconfig/network-scripts/ifcfg-<if-name>`. Alternatively, you can change the MAC address by issuing the command:

```
ip link set addr <MAC address> dev <interface>
```

Note: Be sure not to assign the MAC address of the OSA-Express adapter to your Linux instance.

For OSX and OSM CHPIDs you cannot set your own MAC addresses. Linux uses the MAC addresses defined by the Unified Resource Manager.

For HiperSockets connections, a MAC address is generated. For most purposes the generated address is adequate, however you can change the address using the `ip` command should you need to.

For connections within a QDIO based z/VM guest LAN environment, z/VM assigns the necessary MAC addresses to its guests.

MAC headers in layer 3 mode

Because a qeth layer 3 mode device driver is an Ethernet offload engine for IPv4 and a partial Ethernet offload engine for IPv6 there are some special things to understand about the layer 3 mode.

To support IPv6 and protocols other than IPv4 the device driver registers a layer 3 card as an Ethernet device to the Linux TCP/IP stack.

In layer 3 mode, the OSA-Express adapter in QDIO mode removes the MAC header with the MAC address from incoming IPv4 packets and uses the registered IP addresses to forward a packet to the recipient TCP/IP stack. Thus the OSA-Express adapter is able to deliver IPv4 packets to the correct Linux images. Apart from broadcast packets, a Linux image can only get packets for IP addresses it has configured in the stack and registered with the OSA-Express adapter.

Because the OSA-Express QDIO microcode builds MAC headers for outgoing IPv4 packets and removes them from incoming IPv4 packets, the operating systems' network stacks only send and receive IPv4 packets without MAC headers.

This can be a problem for applications that expect MAC headers. For examples of how such problems can be resolved see “Setting up for DHCP with IPv4” on page 161.

Outgoing frames

The qeth device driver registers the layer 3 card as an Ethernet device. Therefore, the Linux TCP/IP stack will provide complete Ethernet frames to the device driver.

If the hardware does not require the Ethernet frame (for example, for IPv4) the driver removes the Ethernet header prior to sending the frame to the hardware. If necessary information like the Ethernet target address is not available (because of the offload functionality) the value is filled with the hardcoded address FAKELL.

Table 26. Ethernet addresses of outgoing frames

Frame	Destination address	Source address
IPv4	FAKELL	Real device address
IPv6	Real destination address	Real device address
Other packets	Real destination address	Real device address

Incoming frames

The device driver provides Ethernet headers for all incoming frames.

If necessary information like the Ethernet source address is not available (because of the offload functionality) the value is filled with the hardcoded address FAKELL.

Table 27. Ethernet addresses of incoming frames

Frame	Destination address	Source address
IPv4	Real device address	FAKELL
IPv6	Real device address	FAKELL
Other packets	Real device address	Real source address

Note that if a source or destination address is a multicast or broadcast address the device driver can provide the corresponding (real) Ethernet multicast or broadcast address even when the packet was delivered or sent through the offload engine. Always providing the link layer headers enables packet socket applications like **tcpdump** to work properly on a qeth layer 3 device without any changes in the application itself (the patch for libpcap is no longer required).

While the faked headers are syntactically correct, the addresses are not authentic, and hence applications requiring authentic addresses will not work. Some examples are given in Table 28.

Table 28. Applications that react differently to faked headers

Application	Support	Reason
tcpdump	Yes	Displays only frames, fake Ethernet information is displayed.
iptables	Partially	As long as the rule does not deal with Ethernet information of an IPv4 frame.
dhcp	Yes	Is non-IPv4 traffic.

IP addresses

The network stack of each operating system that shares an OSA-Express adapter in QDIO mode registers all its IP addresses with the adapter.

Whenever IP addresses are deleted from or added to a network stack, the device drivers download the resulting IP address list changes to the OSA-Express adapter.

For the registered IP addresses, the OSA-Express adapter off-loads various functions, in particular also:

- Handling MAC addresses and MAC headers
- ARP processing

ARP:

The OSA-Express adapter in QDIO mode responds to Address Resolution Protocol (ARP) requests for all registered IPv4 addresses.

ARP is a TCP/IP protocol that translates 32-bit IPv4 addresses into the corresponding hardware addresses. For example, for an Ethernet device, the hardware addresses are 48-bit Ethernet Media Access Control (MAC) addresses. The mapping of IPv4 addresses to the corresponding hardware addresses is defined in the ARP cache. When it needs to send a packet, a host consults the ARP cache of its network adapter to find the MAC address of the target host.

If there is an entry for the destination IPv4 address, the corresponding MAC address is copied into the MAC header and the packet is added to the appropriate interface's output queue. If the entry is not found, the ARP functions retain the

IPv4 packet, and broadcast an ARP request asking the destination host for its MAC address. When a reply is received, the packet is sent to its destination.

Notes:

1. On an OSA-Express adapter in QDIO mode, do not set the NO_ARP flag on the Linux Ethernet device. The device driver disables the ARP resolution for IPv4. Because the hardware requires no neighbor lookup for IPv4, but neighbor solicitation for IPv6, the NO_ARP flag is not allowed on the Linux Ethernet device.
2. On HiperSockets, which is a full Ethernet offload engine for IPv4 and IPv6 and supports no other traffic, the device driver sets the NO_ARP flag on the Linux Ethernet interface. Do not remove this flag from the interface.


Setting up the qeth device driver

No module parameters exist for the qeth device driver. qeth devices are set up using sysfs.

Loading the qeth device driver modules

You must load the qeth device driver before you can work with qeth devices.

Use the **modprobe** command to load the qeth device driver to automatically load all required additional modules in the correct order:



where:

qeth is the core module that contains common functions used for both layer 2 and layer 3 disciplines.

qeth_l2 is the module that contains layer 2 discipline-specific code.

qeth_l3 is the module that contains layer 3 discipline-specific code.

When a qeth device is configured for a particular discipline the driver tries to automatically load the corresponding discipline module.

Switching the discipline of a qeth device

To switch the discipline of a device the network interface must be shut down and the device must be offline.

If the new discipline is accepted by the device driver the old network interface will be deleted. When the new discipline is set online the first time the new network interface is created.

Removing the modules

Removing a module is not possible if there are cross dependencies between the discipline modules and the core module.

To release the dependencies from the core module to the discipline module all devices of this discipline must be ungrouped. Now the discipline module can be removed. If all discipline modules are removed the core module can be removed.

Working with qeth devices

Typical tasks that you need to perform when working with qeth devices include creating group devices, finding out the type of a network adapter, and setting a device online or offline.

Most of these tasks involve writing to and reading from attributes of qeth group devices in sysfs. This is useful on a running system where you want to make dynamic changes. If you want to make the changes persistent across IPLs, use the interface configuration files. Network configuration parameters are defined in `/etc/sysconfig/network-scripts/ifcfg-<if_name>`. An example of how to define a qeth device persistently is in *Red Hat Enterprise Linux 6.3 Installation Guide*. For a general discussion of network configuration files, see *Red Hat Enterprise Linux 6.3 Deployment Guide*.

Table 29 and Table 30 on page 122 serve as both a task overview and a summary of the attributes and the possible values you can write to them. Underlined values are defaults.

Tip: Use the `znetconf` command to configure devices instead of using the attributes directly (see “`znetconf` - List and configure network devices” on page 516).

Not all attributes are applicable to each device. Some attributes apply only to HiperSockets or only to OSA-Express CHPIDs in QDIO mode, other attributes are applicable to IPv4 interfaces only. See the task descriptions for the applicability of each attribute.

OSA for NCP handles NCP-related packets. Most of the attributes do not apply to OSA for NCP devices. The attributes that apply are:

- `if_name`
- `card_type`
- `buffer_count`
- `recover`

Table 29. qeth tasks and attributes common to layer2 and layer3.

Task	Corresponding attributes	Possible attribute values
“Creating a qeth group device” on page 124	<code>group</code>	n/a
“Removing a qeth group device” on page 125	<code>ungroup</code>	0 or 1
“Setting the layer2 attribute” on page 125	<code>layer2</code>	0 or 1, see “Layer 2 and layer 3” on page 114 ¹
“Enabling and disabling TCP segmentation offload” on page 141	<code>large_send</code>	<u>no</u> <u>TSO</u>

Table 29. *qeth tasks and attributes common to layer2 and layer3 (continued).*

Task	Corresponding attributes	Possible attribute values
"Using priority queueing" on page 126	priority_queueing	prio_queueing_prec prio_queueing_tos no_prio_queueing no_prio_queueing:0 no_prio_queueing:1 no_prio_queueing:2 no_prio_queueing:3
"Specifying the number of inbound buffers" on page 127	buffer_count	integer in the range 8 to 128, the default is 64 for OSA devices and 128 for HiperSockets devices
"Specifying the relative port number" on page 128	portno	integer, either 0 or 1, the default is 0
"Configuring a HiperSockets device for AF_IUCV addressing" on page 128	hsuid	1 to 8 characters
"Finding out the type of your network adapter" on page 129	card_type	n/a, read-only
"Setting a device online or offline" on page 129	online	0 or 1
"Finding out the interface name of a qeth group device" on page 130	if_name	n/a, read-only
"Finding out the bus ID of a qeth interface" on page 130	none	n/a
"Activating an interface" on page 131	none	n/a
"Deactivating an interface" on page 133	none	n/a
"Recovering a device" on page 133	recover	1
"Isolating data connections" on page 133	isolation	none, drop, forward
"Starting and stopping collection of QETH performance statistics" on page 135	performance_stats	0 or 1
"Capturing a hardware trace" on page 136	hw_trap	arm disarm

¹A value of -1 means that the layer has not been set and that the default layer setting is used when the device is set online.

Table 30. *qeth tasks and attributes in layer 3 mode*

Task	Corresponding attributes	Possible attribute values
"Setting up a Linux router" on page 137	route4 route6	primary_router secondary_router primary_connector secondary_connector multicast_router no_router
"Turning inbound checksum calculations on and off" on page 140	checksumming	hw_checksumming sw_checksumming no_checksumming
"Turning outbound checksum calculations on and off" on page 141	none	n/a
"Faking broadcast capability" on page 142	fake_broadcast ¹	0 or 1

Table 30. *qeth tasks and attributes in layer 3 mode (continued)*

Task	Corresponding attributes	Possible attribute values
"Taking over IP addresses" on page 142	ipa_takeover/enable	<u>0</u> or 1 or toggle
	ipa_takeover/add4 ipa_takeover/add6 ipa_takeover/del4 ipa_takeover/del6	IPv4 or IPv6 IP address and mask bits
	ipa_takeover/invert4 ipa_takeover/invert6	<u>0</u> or 1 or toggle
"Configuring a device for proxy ARP" on page 146	rxip/add4 rxip/add6 rxip/del4 rxip/del6	IPv4 or IPv6 IP address
"Configuring a device for virtual IP address (VIPA)" on page 147	vipa/add4 vipa/add6 vipa/del4 vipa/del6	IPv4 or IPv6 IP address
"Setting up a HiperSockets network traffic analyzer" on page 162	sniffer	<u>0</u> or 1
¹ not valid for HiperSockets		

Tip: Use the **qethconf** command instead of using the attributes for IPA, proxy ARP, and VIPA directly (see "qethconf - Configure qeth devices" on page 492).

sysfs provides multiple paths through which you can access the qeth group device attributes. For example, if a device with bus ID 0.0.a100 corresponds to interface eth0:

```
/sys/bus/ccwgroup/drivers/qeth/0.0.a100
/sys/bus/ccwgroup/devices/0.0.a100
/sys/devices/qeth/0.0.a100
/sys/class/net/eth0/device
```

all lead to the attributes for the same device. For example, the following commands are all equivalent and return the same value:

```
# cat /sys/bus/ccwgroup/drivers/qeth/0.0.a100/if_name
eth0
# cat /sys/bus/ccwgroup/devices/0.0.a100/if_name
eth0
# cat /sys/devices/qeth/0.0.a100/if_name
eth0
# cat /sys/class/net/eth0/device/if_name
eth0
```

However, the path through `/sys/class/net` is available only while the device is online. Furthermore, it might lead to a different device if the assignment of interface names changes after rebooting or when devices are ungrouped and new group devices created.

Tip: Work through one of the paths that are based on the device bus-ID.

The following sections describe the tasks in detail.

Creating a qeth group device

Use the **znetconf** command to configure network devices . Alternatively, you can use sysfs.

For information about the **znetconf** command, see “znetconf - List and configure network devices” on page 516.

Before you begin: You need to know the device bus-IDs that correspond to the read, write, and data subchannel of your OSA-Express CHPID in QDIO mode or HyperSockets CHPID as defined in the IOCDS of your mainframe.

To define a qeth group device, write the device numbers of the subchannel triplet to `/sys/bus/ccwgroup/drivers/qeth/group`. Issue a command of the form:

```
# echo <read_device_bus_id>,<write_device_bus_id>,<data_device_bus_id> > /sys/bus/ccwgroup/drivers/qeth/group
```

Result: The qeth device driver uses the device bus-ID of the read subchannel to create a directory for a group device:

```
/sys/bus/ccwgroup/drivers/qeth/<read_device_bus_id>
```

This directory contains a number of attributes that determine the settings of the qeth group device. The following sections describe how to use these attributes to configure a qeth group device.

Example:

In this example, a single OSA-Express CHPID in QDIO mode is used to connect a Linux instance to a network.

Mainframe configuration:




Figure 19. Mainframe configuration

Linux configuration:

Assuming that 0.0.aa00 is the device bus-ID that corresponds to the read subchannel:

```
# echo 0.0.aa00,0.0.aa01,0.0.aa02 > /sys/bus/ccwgroup/drivers/qeth/group
```

This command results in the creation of the following directories in sysfs:

- `/sys/bus/ccwgroup/drivers/qeth/0.0.aa00`
- `/sys/bus/ccwgroup/devices/0.0.aa00`

- /sys/devices/qeth/0.0.aa00

Both the command and the resulting directories would be the same for a HiperSockets CHPID.

Removing a qeth group device

Use the ungroup sysfs attribute to remove a qeth group device.

Before you begin: The device must be set offline before you can remove it.

To remove a qeth group device, write "1" to the ungroup attribute. Issue a command of the form:

```
echo 1 > /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/ungroup
```

Example:

This command removes device 0.0.aa00:

```
echo 1 > /sys/bus/ccwgroup/drivers/qeth/0.0.aa00/ungroup
```

Setting the layer2 attribute

If the detected hardware is known to be exclusively run in a discipline (for example, OSN needs the layer 2 discipline) the corresponding discipline module is automatically requested.

The qeth device driver attempts to load the layer 3 discipline for HiperSockets devices and layer 2 for non-HiperSockets devices.

You can make use of the layer 2 mode for almost all device types, however, note the following about layer 2 to layer 3 conversion:

real OSA-Express

Hardware is able to convert layer 2 to layer 3 traffic and vice versa and thus there are no restrictions.

HiperSockets

HiperSockets on layer 2 are supported as of System z10. There is no support for layer 2 to layer 3 conversion and, thus, no communication is possible between HiperSockets layer 2 interfaces and HiperSockets layer 3 interfaces. Do not include HiperSockets layer 2 interfaces and HiperSockets layer 3 interfaces in the same LAN.

z/VM guest LAN

Linux has to configure the same mode as the underlying z/VM virtual LAN definition. The z/VM definition "Ethernet mode" is available for VSWITCHes and for guest LANs of type QDIO.

Before you begin: If you are using the layer2 option within a QDIO based guest LAN environment, you cannot define a VLAN with ID "1", because ID "1" is reserved for z/VM use.

The qeth device driver separates the configuration options in sysfs regarding to the device discipline. Hence the first configuration action after grouping the device must be the configuration of the discipline. To set the discipline, issue a command of the form:

```
echo <integer> > /sys/devices/qeth/<device_bus_id>/layer2
```

where <integer> is

- 0 to turn the layer2 attribute off; this results in the layer 3 discipline.
- 1 to turn the layer2 attribute on; this results in the layer 2 discipline (default).

If the layer2 attribute has a value of -1 the layer has not been set and the default layer setting is used when the device is set online.

If you configured the discipline successfully, additional configuration attributes are displayed (for example route4 for the layer 3 discipline) and can be configured. If an OSA device is not configured for a discipline but is set online, the device driver assumes it is a layer 2 device and tries to load the layer 2 discipline.

Note: To change a configured layer2 attribute, the network interface must be shut down and the device must be set offline.

For information about layer2, see:

- *OSA-Express Customer's Guide and Reference*, SA22-7935
- *OSA-Express Implementation Guide*, SG25-5848
- *Networking Overview for Linux on zSeries®*, REDP-3901
- *z/VM Connectivity*, SC24-6174

Using priority queueing

An OSA-Express CHPID in QDIO mode has up to four output queues (queues 0 to 3). The priority queueing feature gives these queues different priorities (queue 0 having the highest priority).

Before you begin:

- This section applies to OSA-Express CHPIDs in QDIO mode only.
- The device must be offline while you set the queueing options.

Queueing is relevant mainly to high traffic situations. When there is little traffic, queueing has no impact on processing. The qeth device driver can put data on one or more of the queues. By default, the driver uses queue 2 for all data.

You can determine how outgoing IP packages are assigned to queues by setting a value for the priority_queueing attribute of your qeth device. Issue a command of the form:

```
# echo <method> > /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/priority_queueing
```

where <method> can be any of these values:

prio_queueing_prec

to base the queue assignment on the two most significant bits of each packet's IP header precedence field.

prio_queueing_tos

to select a queue according to the IP type of service that is assigned to packets

by some applications. The service type is a field in the IP datagram header that can be set with a **setsockopt** call. Table 31 shows how the qeth device driver maps service types to the available queues:

Table 31. IP service types and queue assignment for type of service queueing

Service type	Queue
Low latency	0
High throughput	1
High reliability	2
Not important	3

no_prio_queueing

causes the qeth device driver to use queue 2 for all packets. This is the default.

no_prio_queueing:0

causes the qeth device driver to use queue 0 for all packets.

no_prio_queueing:1

causes the qeth device driver to use queue 1 for all packets.

no_prio_queueing:2

causes the qeth device driver to use queue 2 for all packets. This is equivalent to the default.

no_prio_queueing:3

causes the qeth device driver to use queue 3 for all packets.

Example:

To configure queueing by type of service for device 0.0.a110 issue:

```
# echo prio_queueing_tos > /sys/bus/ccwgroup/drivers/qeth/0.0.a110/priority_queueing
```

Specifying the number of inbound buffers

Depending on the amount of available storage and the amount of traffic, you can assign from 8 to 128 inbound buffers for each qeth group device.

Before you begin: The device must be offline while you specify the number of inbound buffers.

By default, the qeth device driver assigns 64 inbound buffers to OSA devices and 128 to HiperSockets devices.

The Linux memory usage for inbound data buffers for the devices is: (number of buffers) × (buffer size).

The buffer size is equivalent to the frame size which is:

- For an OSA-Express CHPID in QDIO mode or an OSA-Express CHPID in OSN mode: 64 KB
- For HiperSockets: depending on the HiperSockets CHPID definition, 16 KB, 24 KB, 40 KB, or 64 KB

Set the `buffer_count` attribute to the number of inbound buffers you want to assign. Issue a command of the form:

```
# echo <number> > /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/buffer_count
```

Example:

In this example, 64 inbound buffers are assigned to device 0.0.a000.

```
# echo 64 > /sys/bus/ccwgroup/drivers/qeth/0.0.a000/buffer_count
```

Specifying the relative port number

Use the portno sysfs attribute to specify the relative port number.

Before you begin:

- This section applies to adapters that, per CHPID, show more than one port to Linux.
- The device must be offline while you specify the relative port number.

By default, the qeth group device uses port 0. To use a different port, issue a command of the form:

```
# echo <integer> > /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/portno
```

Where *<integer>* is either 0 or 1.

Example:

In this example, port 1 is assigned to the qeth group device.

```
# echo 1 > /sys/bus/ccwgroup/drivers/qeth/0.0.a000/portno
```

Configuring a HiperSockets device for AF_IUCV addressing

Use the hsuid attribute of a HiperSockets device to identify it to the AF_IUCV addressing family support (see “Setting up HiperSockets devices for AF_IUCV addressing” on page 250). The identifier is case sensitive.

Before you begin: Support for AF_IUCV based connections through real HiperSockets requires Completion Queue Support.

The identifier must adhere to these rules:

- It must be 1 to 8 characters.
- It must be unique across your environment.
- It must not match any z/VM user ID in your environment. The AF_IUCV addressing family support also supports z/VM IUCV connections.

To set an identifier, issue a command like this:

```
# echo <value> > /sys/bus/ccwgroup/drivers/qeth/0.0.a007/hsuid
```

Example: In this example MYHOST01 is set as the identifier for a HiperSockets device with bus ID 0.0.a007.


```
# echo MYHOST01 > /sys/bus/ccwgroup/drivers/qeth/0.0.a007/hsuid
```

Finding out the type of your network adapter

Use the `card_type` attribute to find out the type of the network adapter through which your device is connected.

You can find out the type of the network adapter through which your device is connected. To find out the type read the device's `card_type` attribute. Issue a command of the form:

```
# cat /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/card_type
```

The `card_type` attribute gives information about both the type of network adapter and also about the type of network link (if applicable) available at the card's ports. See Table 32 for details.

Table 32. Possible values of `card_type` and what they mean

Value of <code>card_type</code>	Adapter type	Link type
OSD_10GIG	OSA card in OSD mode	10 Gigabit Ethernet
OSD_1000		Gigabit Ethernet, 1000BASE-T
OSD_100		Fast Ethernet
OSD_GbE_LANE		Gigabit Ethernet, LAN Emulation
OSD_FE_LANE		Fast Ethernet, LAN Emulation
OSD_Express		Unknown
OSN	OSA for NCP	ESCON/CDLC bridge or N/A
OSM	OSA-Express for Unified Resource Manager	1000BASE-T
OSX	OSA-Express for zBX	10 Gigabit Ethernet
HiperSockets	HiperSockets, CHPID type IQD	N/A
GuestLAN QDIO	Guest LAN based on OSA	N/A
GuestLAN Hiper	Guest LAN based on HiperSockets	N/A
Unknown	Other	

Example:

To find the `card_type` of a device 0.0.a100 issue:

```
# cat /sys/bus/ccwgroup/drivers/qeth/0.0.a100/card_type
OSD_100
```

Setting a device online or offline

Use the `online device group` attribute to set a device online or offline.

To set a `qeth` group device online set the `online device group` attribute to "1". To set a `qeth` group device offline set the `online device group` attribute to "0". Issue a command of the form:

```
# echo <flag> > /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/online
```

Setting a device online associates it with an interface name (see “Finding out the interface name of a qeth group device”).

Setting a device offline closes this network device. If IPv6 is active, you will lose any IPv6 addresses set for this device. After setting the device online, you can restore lost IPv6 addresses only by issuing the **ip** or **ifconfig** commands again.

Example:

To set a qeth device with bus ID 0.0.a100 online issue:

```
# echo 1 > /sys/bus/ccwgroup/drivers/qeth/0.0.a100/online
```

To set the same device offline issue:

```
# echo 0 > /sys/bus/ccwgroup/drivers/qeth/0.0.a100/online
```

Finding out the interface name of a qeth group device

When a qeth group device is set online, an interface name is assigned to it.

Use the **lsqeth -p** command (see “lsqeth - List qeth-based network devices” on page 467) to obtain a mapping for all qeth interfaces and devices.

Alternatively, you can use sysfs. To find out the interface name of a qeth group device for which you know the device bus-ID read the group device's `if_name` attribute.

Issue a command of the form:

```
# cat /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/if_name
```

Example:

```
# cat /sys/bus/ccwgroup/drivers/qeth/0.0.a100/if_name
eth0
```

Finding out the bus ID of a qeth interface

Use the **lsqeth -p** command to obtain a mapping for all qeth interfaces and devices. Alternatively, you can use sysfs.

For information about the **lsqeth -p** command, see “lsqeth - List qeth-based network devices” on page 467.

For each network interface, there is a directory in sysfs under `/sys/class/net/`, for example, `/sys/class/net/eth0` for interface `eth0`. This directory contains a symbolic link “device” to the corresponding device in `/sys/devices`.

Read this link to find the device bus-ID of the device that corresponds to the interface.

Example:

To find out which device bus-ID corresponds to an interface eth0 issue, for example:

```
# readlink /sys/class/net/eth0/device
../../../../devices/qeth/0.0.a100
```

In this example, eth0 corresponds to the device bus-ID 0.0.a100.

Activating an interface

Use the **ip** command or equivalent to activate an interface.

Before you begin:

- You need to know the interface name of the qeth group device (see “Finding out the interface name of a qeth group device” on page 130).
- You need to know the IP address you want to assign to the device.

The MTU size defaults to the correct settings for HiperSockets and to 1492 bytes for OSA-Express CHPIDs in QDIO mode.

In most cases 1492 bytes is well suited for OSA-Express CHPIDs in QDIO mode. If your network is laid out for jumbo frames, increase the MTU size to a maximum of 8992 bytes.

For HiperSockets, the maximum MTU size is restricted by the maximum frame size as announced by the licensed internal code (LIC). The maximum MTU is equal to the frame size minus 8 KB. Hence, the possible frame sizes of 16 KB, 24 KB, 40 KB, or 64 KB result in maximum corresponding MTU sizes of 8 KB, 16 KB, 32 KB, or 56 KB.

The MTU size defaults to the correct settings for both HiperSockets and OSA-Express CHPIDs in QDIO mode. As a result, you need not specify the MTU size when activating the interface.

Note that, on heavily loaded systems, MTU sizes exceeding 8 KB can lead to memory allocation failures for packets due to memory fragmentation. A symptom of this problem are messages of the form "order-N allocation failed" in the system log; in addition, network connections will drop packets, in extreme cases to the extent that the network is no longer usable.

As a workaround, use MTU sizes at most of 8 KB (minus header size), even if the network hardware allows larger sizes (for example, HiperSockets or 10 Gigabit Ethernet).

You activate or deactivate network devices with **ip** or an equivalent command. For details of the **ip** command see the **ip** man page.

Examples:

- This example activates a HiperSockets CHPID with broadcast address 192.168.100.255:

```
# ip addr add 192.168.100.10/24 dev hsi0
# ip link set dev hsi0 up
```

- This example activates an OSA-Express CHPID in QDIO mode with broadcast address 192.168.100.255:

```
# ip addr add 192.168.100.11/24 dev eth0
# ip link set dev eth0 up
```

- This example reactivates an interface that had already been activated and subsequently deactivated:

```
# ip link set dev eth0 up
```

- This example activates an OSA-Express2 CHPID defined as an OSN type CHPID for OSA NCP:

```
# ip link set dev osn0 up
```

Confirming that an IP address has been set under layer 3

There may be circumstances that prevent an IP address from being set, most commonly if another system in the network has set that IP address already.

The Linux network stack design does not allow feedback about IP address changes. If **ip** or an equivalent command fails to set an IP address on an OSA-Express network CHPID, a query with **ip** shows the address as being set on the interface although the address is not actually set on the CHPID.

There are usually failure messages about not being able to set the IP address or duplicate IP addresses in the kernel messages. You can find these messages in the output of the **dmesg** command. In Red Hat Enterprise Linux 6.3, you can also find the messages in `/var/log/messages`.

If you are not sure whether an IP address was set properly or experience a networking problem, check the messages or logs to see if an error was encountered when setting the address. This also applies in the context of HiperSockets and to both IPv4 and IPv6 addresses. It also applies to whether an IP address has been set for IP takeover, for VIPA, or for proxy ARP.

Duplicate IP addresses

The OSA-Express adapter in QDIO mode recognizes duplicate IP addresses on the same OSA-Express adapter or in the network using ARP and prevents duplicates.

Several setups require duplicate addresses:

- To perform IP takeover you need to be able to set the IP address to be taken over. This address exists prior to the takeover. See “Taking over IP addresses” on page 142 for details.
- For proxy ARP you need to register an IP address for ARP that belongs to another Linux instance. See “Configuring a device for proxy ARP” on page 146 for details.
- For VIPA you need to assign the same virtual IP address to multiple devices. See “Configuring a device for virtual IP address (VIPA)” on page 147 for details.

You can use the **qethconf** command (see “qethconf - Configure qeth devices” on page 492) to maintain a list of IP addresses that your device can take over, a list of IP addresses for which your device can handle ARP, and a list of IP addresses that can be used as virtual IP addresses, regardless of any duplicates on the same OSA-Express adapter or in the LAN.

Deactivating an interface

You can deactivate an interface with **ip** or an equivalent command or by setting the network device offline.

While setting a device offline involves actions on the attached device, deactivating only stops the interface logically within Linux.

To deactivate an interface with **ip**, Issue a command of the form:

```
# ip link set dev <interface_name> down
```

Example:

To deactivate eth0 issue:

```
# ip link set dev eth0 down
```

Recovering a device

You can use the recover attribute of a qeth group device to recover it in case of failure.

For example, error messages in `/var/log/messages` might inform you of a malfunctioning device. Issue a command of the form:

```
# echo 1 > /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/recover
```

Example:

```
# echo 1 > /sys/bus/ccwgroup/drivers/qeth/0.0.a100/recover
```

Isolating data connections

You can restrict communications between operating system instances that share the same OSA port on an OSA adapter.

A Linux instance can configure the OSA adapter to prevent any direct package exchange between itself and other operating system instances that share the same OSA adapter. This ensures a higher degree of isolation than VLANs.

For example, if three Linux instances share an OSA adapter, but only one instance (Linux A) needs to be isolated, then Linux A declares its OSA adapter (QDIO Data Connection to the OSA adapter) to be isolated. Any packet being sent to or from Linux A must pass at least the physical switch to which the shared OSA adapter is connected. The two other instances could still communicate directly through the OSA adapter without the external switch in the network path (see Figure 20 on page 134).




Figure 20. Linux instances sharing a port on an OSA adapter with and without isolation

QDIO data connection isolation is configured as a policy. The policy can take the following values:

1. none: No isolation. This is the default.
2. ISOLATION_DROP: All packets from guests sharing the same OSA adapter to the guest having this policy configured are dropped automatically. The same holds for all packets sent by the guest having this policy configured to guests on the same OSA card. All packets to or from the isolated guest need to have a target that is not hosted on the OSA card. You can accomplish this by a router hosted on a separate machine or a separate OSA adapter.
3. ISOLATION_FORWARD: This policy results in a similar behavior as ISOLATION_DROP. The only difference is that packets are forwarded to the connected switch instead of being dropped.

You can configure the policy regardless of whether the device is online. If the device is online, the policy is configured immediately. If the device is offline, the policy is configured when the device comes online.

The policy is implemented as a sysfs attribute called isolation. Note that the attribute appears in sysfs regardless of whether the hardware supports the feature.

Examples:

- To check the current isolation policy:

```
# cat /sys/devices/qeth/0.0.f5f0/isolation
```

- To set the isolation policy to ISOLATION_DROP:

```
# echo "drop" > /sys/devices/qeth/0.0.f5f0/isolation
```

- To set the isolation policy to ISOLATION_FORWARD:

```
# echo "forward" > /sys/devices/qeth/0.0.f5f0/isolation
```

- To set the isolation policy to none:

```
# echo "none" > /sys/devices/qeth/0.0.f5f0/isolation
```

See *z/VM Connectivity*, SC24-6174 for information about setting up data connection isolation on a VSWITCH.

Starting and stopping collection of QETH performance statistics

Use the `performance_stats` attribute to start and stop collection of QETH performance statistics.

For QETH performance statistics there is a device group attribute called `/sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/performance_stats`.

This attribute is initially set to 0, that is QETH performance data is not collected. To start collection for a specific QETH device, write 1 to the attribute, for example:

```
echo 1 > /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/performance_stats
```

To stop collection write 0 to the attribute, for example:

```
echo 0 > /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/performance_stats
```

Stopping QETH performance data collection for a specific QETH device is accompanied by a reset of current statistic values to zero.

To display QETH performance statistics, use the **ethtool** command. See the **ethtool** man page for details. The following example shows statistic and device driver information:

```
# ethtool -S eth0
NIC statistics:
  rx skbs: 86
  rx buffers: 85
  tx skbs: 86
  tx buffers: 86
  tx skbs no packing: 86
  tx buffers no packing: 86
  tx skbs packing: 0
  tx buffers packing: 0
  tx sg skbs: 0
  tx sg frags: 0
  rx sg skbs: 0
  rx sg frags: 0
  rx sg page allocs: 0
  tx large kbytes: 0
  tx large count: 0
  tx pk state ch n->p: 0
  tx pk state ch p->n: 0
  tx pk watermark low: 2
  tx pk watermark high: 5
  queue 0 buffer usage: 0
  queue 1 buffer usage: 0
  queue 2 buffer usage: 0
  queue 3 buffer usage: 0
  rx handler time: 856
  rx handler count: 84
  rx do_QDIO time: 16
  rx do_QDIO count: 11
  tx handler time: 330
  tx handler count: 87
  tx time: 1236
  tx count: 86
  tx do_QDIO time: 997
  tx do_QDIO count: 86

# ethtool -i eth0
driver: qeth_l3
version: 1.0
firmware-version: 087a
bus-info: 0.0.f5f0/0.0.f5f1/0.0.f5f2
```

Capturing a hardware trace

Hardware traces are intended for use by the IBM service organization. Hardware tracing is turned off by default. Only turn on the hardware tracing feature when instructed to do so by IBM service.

When errors occur on an OSA-Express adapter, both software and hardware traces must be collected. The hardware tracing feature requests a hardware trace if an error is detected. This makes it possible to correlate the hardware trace with the device driver trace. If the hardware tracing feature is activated, traces are captured automatically, but you can also start the capturing yourself.

Before you begin:

- The OSA-Express adapter must support the hardware tracing feature.
- The qeth device must be online to return valid values of the `hw_trap` attribute.

To activate or deactivate the hardware tracing feature, issue a command of the form:

```
# echo <value> > /sys/devices/qeth/<device_bus_id>/hw_trap
```

Where `<value>` can be:

arm If the hardware tracing feature is supported, write `arm` to the `hw_trap` sysfs attribute to activate it. The `hw_trap` sysfs attribute has the value `arm` if the hardware tracing feature is present and activated.

disarm

Write `disarm` to the `hw_trap` sysfs attribute to turn the hardware tracing feature off. The `hw_trap` sysfs attribute has the value `disarm` if the hardware tracing feature is not present or is turned off. This is the default.

trap (Write only) Capture a hardware trace. Hardware traces are captured automatically, but if asked to do so by IBM service, you can start the capturing yourself by writing `trap` to the `hw_trap` sysfs attribute. The hardware trap function must be set to `arm`.

Examples:

In this example the hardware tracing feature is activated for `qeth` device `0.0.a000`:

```
# echo arm > /sys/devices/qeth/0.0.a000/hw_trap
```

In this example a trace capture is started on `qeth` device `0.0.a000`:

1. Check that the `hw_trap` sysfs attribute is set to `arm`:

```
# cat /sys/devices/qeth/0.0.a000/hw_trap
arm
```

2. Start the capture:

```
# echo trap > /sys/devices/qeth/0.0.a000/hw_trap
```

Working with `qeth` devices in layer 3 mode

This section applies to `qeth` devices in layer 3 mode.

See “Setting the layer2 attribute” on page 125 about setting the mode. See “Layer 2 and layer 3” on page 114 for general information about the layer 2 and layer 3 disciplines.

Setting up a Linux router

By default, your Linux instance is not a router. Depending on your IP version, IPv4 or IPv6 you can use the `route4` or `route6` attribute of your `qeth` device to define it as a router.

Before you begin:

- A suitable hardware setup is in place that permits your Linux instance to act as a router.
- The Linux instance is set up as a router.

You can set the `route4` or `route6` attribute dynamically, while the `qeth` device is online.

The same values are possible for `route4` and `route6` but depend on the type of CHPID:

Table 33. Summary of router setup values

Router specification	OSA-Express CHPID in QDIO mode	HiperSockets CHPID
primary_router	Yes	No
secondary_router	Yes	No
primary_connector	No	Yes
secondary_connector	No	Yes
multicast_router	Yes	Yes
no_router	Yes	Yes

Both types of CHPIDs honor:

multicast_router

causes the qeth driver to receive all multicast packets of the CHPID. For a unicast function for HiperSockets see “HiperSockets Network Concentrator” on page 156.

no_router

is the default. You can use this value to reset a router setting to the default.

An OSA-Express CHPID in QDIO mode honors the following values:

primary_router

to make your Linux instance the principal connection between two networks.

secondary_router

to make your Linux instance a backup connection between two networks.

A HiperSockets CHPID honors the following values, provided the microcode level supports the feature:

primary_connector

to make your Linux instance the principal connection between a HiperSockets network and an external network (see “HiperSockets Network Concentrator” on page 156).

secondary_connector

to make your Linux instance a backup connection between a HiperSockets network and an external network (see “HiperSockets Network Concentrator” on page 156).

Note: To configure Linux running in a z/VM guest virtual machine or in an LPAR as a router, IP forwarding must be enabled in addition to setting the route4 or route6 attribute.

For IPv4, this can be done by issuing:

```
# sysctl -w net.ipv4.conf.all.forwarding=1
```

For IPv6, this can be done by issuing:

```
# sysctl -w net.ipv6.conf.all.forwarding=1
```

Example:

In this example, two Linux instances, “Linux P” and “Linux S”, running on an IBM mainframe use OSA-Express to act as primary and secondary routers between two networks. IP forwarding needs to be enabled for Linux in an LPAR or as a z/VM guest to act as a router. In Red Hat Enterprise Linux 6.3 you can set IP forwarding permanently in `/etc/sysctl.conf` or dynamically with the `sysctl` command.

Mainframe configuration:




Figure 21. Mainframe configuration

It is assumed that both Linux instances are configured as routers in their LPARs or in z/VM.

Linux P configuration:

To create the qeth group devices:

```
# echo 0.0.0400,0.0.0401,0.0.0402 > /sys/bus/ccwgroup/drivers/qeth/group
# echo 0.0.0200,0.0.0201,0.0.0202 > /sys/bus/ccwgroup/drivers/qeth/group
```

To make Linux P a primary router for IPv4:

```
# echo primary_router > /sys/bus/ccwgroup/drivers/qeth/0.0.0400/route4
# echo primary_router > /sys/bus/ccwgroup/drivers/qeth/0.0.0200/route4
```

Linux S configuration:

To create the qeth group devices:

```
# echo 0.0.0404,0.0.0405,0.0.0406 > /sys/bus/ccwgroup/drivers/qeth/group
# echo 0.0.0204,0.0.0205,0.0.0206 > /sys/bus/ccwgroup/drivers/qeth/group
```

To make Linux S a secondary router for IPv4:

```
# echo secondary_router > /sys/bus/ccwgroup/drivers/qeth/0.0.0404/route4
# echo secondary_router > /sys/bus/ccwgroup/drivers/qeth/0.0.0204/route4
```

In this example, qeth device 0.01510 is defined as a primary router for IPv6:

```
/sys/bus/ccwgroup/drivers/qeth # cd 0.0.1510
# echo 1 > online
# echo primary_router > route6
# cat route6
primary_router
```

See “HiperSockets Network Concentrator” on page 156 for further examples.

Configuring offload operations

Some operations can be offloaded to the OSA adapter, thus relieving the burden on the host CPU.

The qeth device driver supports offloading the following operations:

- Inbound (receive) checksum calculations
- Outbound (send) checksum calculations
- Large send (TCP segmentation offload)

Offload operations are supported for OSA connections on layer 3 only. VLAN interfaces inherit offload settings from their base interface.

The offload operations can be set using the Linux **ethtool** command. See the **ethtool** man page for details. The following example shows the default offload settings:

```
# ethtool -k eth0
Offload parameters for eth0:
rx-checksumming: on
tx-checksumming: off
scatter-gather: off
tcp-segmentation-offload: off
udp-fragmentation-offload: off
generic-segmentation-offload: off
generic-receive-offload: on
large-receive-offload: off
```

Note: With Red Hat Enterprise Linux 6.2, the defaults for rx-checksumming and for generic-receive-offload have changed from off to on.

Turning inbound checksum calculations on and off

A checksum calculation is a form of redundancy check to protect the integrity of data. In general, checksum calculations are used for network data.

The qeth device driver supports offloading checksum calculations on inbound packets to the OSA feature. To enable or disable checksum calculations by the OSA feature, issue a command of this form:

```
# ethtool -K <interface_name> rx <value>
```

where *<value>* is on or off.

Examples:

- To let the OSA feature calculate the inbound checksum for network device eth0, issue

```
# ethtool -K eth0 rx on
```

- To let the host CPU calculate the inbound checksum for network device eth0, issue

```
# ethtool -K eth0 rx off
```

Turning outbound checksum calculations on and off

The qeth device driver supports offloading outbound (send) checksum calculations to the OSA feature.

You can enable or disable the OSA feature calculating the outbound checksums by using the **ethtool** command. Issue a command of the form:

```
# ethtool -K <interface_name> tx <value>
```

where *<value>* is on or off.

Attention: When outbound checksum calculations are offloaded, the OSA feature performs the checksum calculations. Offloaded checksum calculations only applies to packets that go out to the LAN or come in from the LAN. Linux instances that share an OSA port exchange packages directly. The packages are forwarded by the OSA adapter but do not go out on the LAN and no checksum offload is performed. The qeth device driver cannot detect this, and so cannot issue any warning about it.

Example:

- To let the OSA feature calculate the outbound checksum for network device eth0, issue

```
# ethtool -K eth0 tx on
```

- To let the host CPU calculate the outbound checksum for network device eth0, issue

```
# ethtool -K eth0 tx off
```

Enabling and disabling TCP segmentation offload

Offloading the TCP segmentation operation from the Linux network stack to the adapter can lead to enhanced performance for interfaces with predominately large outgoing packets.

To support TCP segmentation offload (TSO), a network device must support outbound (TX) checksumming and scatter gather. For this reason, you must turn on scatter gather and outbound checksumming prior to configuring TSO. All three options can be turned on or off with a single **ethtool** command of the form:

```
# ethtool -K <interface_name> tx <value> sg <value> tso <value>
```

where *<value>* is either on or off.

Examples:

- To offload the TCP segmentation operation for a network device eth0 issue:

```
# ethtool -K eth0 tx on sg on tso on
```

- To disable offloading the TCP segmentation operation for a network device eth0 issue:

```
# ethtool -K eth0 tx off sg off tso off
```

Attention: When TCP segmentation is offloaded, the OSA feature performs the calculations. Offloaded calculations apply only to packets that go out to the LAN or come in from the LAN. Linux instances that share an OSA port exchange packages directly. The packages are forwarded by the OSA adapter but do not go out on the LAN and no TCP segmentation calculation is performed. The qeth device driver cannot detect this, and so cannot issue any warning about it.

Faking broadcast capability

It is possible to fake the broadcast capability for devices that do not support broadcasting.

Before you begin:

- This section applies to devices that do not support broadcast only.
- The device must be offline while you enable faking broadcasts.

For devices that support broadcast, the broadcast capability is enabled automatically.

To find out if a device supports broadcasting, use the **ip** command. If the resulting list shows the BROADCAST flag the device supports broadcast. This example shows that the device eth0 supports broadcast:

```
# ip -s link show dev eth0
3: eth0: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1492 qdisc pfifo_fast qlen 1000
    link/ether 00:11:25:bd:da:66 brd ff:ff:ff:ff:ff:ff
    RX: bytes    packets  errors  dropped overrun mcast
    236350      2974    0       0       0       9
    TX: bytes    packets  errors  dropped carrier collsns
    374443      1791    0       0       0       0
```

Some processes, for example, the *gated* routing daemon, require the devices' broadcast capable flag to be set in the Linux network stack. To set this flag for devices that do not support broadcast set the `fake_broadcast` attribute of the qeth group device to "1". To reset the flag set it to "0".

Issue a command of the form:

```
# echo <flag> > /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/fake_broadcast
```

Example:

In this example, a device 0.0.a100 is instructed to pretend that it has broadcast capability.

```
# echo 1 > /sys/bus/ccwgroup/drivers/qeth/0.0.a100/fake_broadcast
```

Taking over IP addresses

You can configure IP takeover if the layer2 option (see "MAC headers in layer 2 mode" on page 117) is not enabled. If you have enabled the layer2 option, you can configure for IP takeover as you would in a distributed server environment.

Taking over an IP address overrides any previous allocation of this address to another LPAR. If another LPAR on the same CHPID has already registered for that IP address, this association is removed.

An OSA-Express CHPID in QDIO mode can take over IP addresses from any System z operating system. IP takeover for HiperSockets CHPIDs is restricted to taking over addresses from other Linux instances in the same Central Electronics Complex (CEC).

IP address takeover between multiple CHPIDs requires ARP for IPv4 and Neighbor Discovery for IPv6. OSA-Express handles ARP transparently, but not Neighbor Discovery.

There are three stages to taking over an IP address:

Stage 1: Ensure that your qeth group device is enabled for IP takeover

Stage 2: Activate the address to be taken over for IP takeover

Stage 3: Issue a command to take over the address

Stage 1: Enabling a qeth group device for IP takeover

For OSA-Express and HiperSockets CHPIDs, both the qeth group device that is to take over an IP address and the device that surrenders the address must be enabled for IP takeover.

By default, qeth devices are not enabled for IP takeover. To enable a qeth group device for IP address takeover set the enable device group attribute to “1”. To switch off the takeover capability set the enable device group attribute to “0”. In sysfs, the enable attribute is located in a subdirectory ipa_takeover. Issue a command of the form:

```
# echo <flag> > /sys/bus/ccwgroup/drivers/qeth/<device_bus_id>/ipa_takeover/enable
```

Example:

In this example, a device 0.0.a500 is enabled for IP takeover:

```
# echo 1 > /sys/bus/ccwgroup/drivers/qeth/0.0.a500/ipa_takeover/enable
```

Stage 2: Activating and deactivating IP addresses for takeover

The qeth device driver maintains a list of IP addresses that qeth group devices can take over or surrender. To enable Linux to take over an IP-address or to surrender an address, the address must be added to this list.

Use the **qethconf** command to add IP addresses to the list.

To display the list of IP addresses that are activated for IP takeover issue:

```
# qethconf ipa list
```

To activate an IP address for IP takeover, add it to the list. Issue a command of the form:

```
# qethconf ipa add <ip_address>/<mask_bits> <interface_name>
```

To deactivate an IP address delete it from the list. Issue a command of the form:

```
# qethconf ipa del <ip_address>/<mask_bits> <interface_name>
```

In these commands, *<ip_address>/<mask_bits>* is the range of IP addresses to be activated or deactivated. See “qethconf - Configure qeth devices” on page 492 for more details about the **qethconf** command.

IPv4 example:

In this example, there is only one range of IP addresses (192.168.10.0 to 192.168.10.255) that can be taken over by device hsi0.

```
# qethconf ipa list
ipa add 192.168.10.0/24 hsi0
```

The following command adds a range of IP addresses that can be taken over by device eth0.

```
# qethconf ipa add 192.168.11.0/24 eth0
qethconf: Added 192.168.11.0/24 to /sys/class/net/eth0/device/ipa_takeover/add4.
qethconf: Use "qethconf ipa list" to check for the result
```

Listing the activated IP addresses now shows both ranges of addresses.

```
# qethconf ipa list
ipa add 192.168.10.0/24 hsi0
ipa add 192.168.11.0/24 eth0
```

The following command deletes the range of IP addresses that can be taken over by device eth0.

```
# qethconf ipa del 192.168.11.0/24 eth0
qethconf: Deleted 192.168.11.0/24 from /sys/class/net/eth0/device/ipa_takeover/del4.
qethconf: Use "qethconf ipa list" to check for the result
```

IPv6 example:

The following command adds one range of IPv6 addresses, fec0:0000:0000:0000:0000:0000:0000:0000 to fec0:0000:0000:0000:FFFF:FFFF:FFFF:FFFF, that can be taken over by device eth2:

```
qethconf ipa add fec0::/64 eth2
qethconf: Added fec0:0000:0000:0000:0000:0000:0000:0000/64 to
sysfs entry /sys/class/net/eth2/device/ipa_takeover/add6.
qethconf: For verification please use "qethconf ipa list"
```

Listing the activated IP addresses now shows the range of addresses:

```
qethconf ipa list
...
ipa add fec0:0000:0000:0000:0000:0000:0000:0000/64 eth2
```

The following command deletes the IPv6 address range that can be taken over by eth2:

```
qethconf ipa del fec0:0000:0000:0000:0000:0000:0000:0000/64 eth2:
qethconf: Deleted fec0:0000:0000:0000:0000:0000:0000:0000/64 from
sysfs entry /sys/class/net/eth2/device/ipa_takeover/del6.
qethconf: For verification please use "qethconf ipa list"
```


Stage 3: Issuing a command to take over the address

To complete taking over a specific IP address and remove it from the CHPID or LPAR that previously held it, issue an **ip addr** or equivalent command.

Before you begin:

- Both the device that is to take over the IP address and the device that is to surrender the IP address must be enabled for IP takeover. This rule applies to the devices on both OSA-Express and HiperSockets CHPIDs. (See “Stage 1: Enabling a qeth group device for IP takeover” on page 143).
- The IP address to be taken over must have been activated for IP takeover (see “Stage 2: Activating and deactivating IP addresses for takeover” on page 143).

IPv4 example:

To make a device hsi0 take over IP address 192.168.10.22 issue:

```
# ip addr add 192.168.10.22 dev hsi0
```

For IPv4, the IP address you are taking over must be different from the one that is already set for your device. If your device already has the IP address it is to take over, you must issue two commands: First remove the address to be taken over if it is already there. Then add the IP address to be taken over.

For example, to make a device hsi0 take over IP address 192.168.10.22 if hsi0 is already configured to have IP address 192.168.10.22 issue:

```
# ip addr del 192.168.10.22 dev hsi0
# ip addr add 192.168.10.22 dev hsi0
```

IPv6 example:

To make a device eth2 take over fec0::111:25ff:febd:d9da/64 issue:

```
ip addr add fec0::111:25ff:febd:d9da/64 nodad dev eth2
```

For IPv6, setting the **nodad** (no duplicate address detection) option ensures that the eth2 interface uses the IP address fec0::111:25ff:febd:d9da/64. Without the **nodad** option, the previous owner of the IP address might prevent the takeover by responding to a duplicate address detection test.

The IP address you are taking over must be different from the one that is already set for your device. If your device already has the IP address it is to take over you must issue two commands: First remove the address to be taken over if it is already there. Then add the IP address to be taken over.

For example, to make a device eth2 take over IP address fec0::111:25ff:febd:d9da/64 when eth2 is already configured to have that particular IP address issue:

```
ip addr del fec0::111:25ff:febd:d9da/64 nodad dev eth2
ip addr add fec0::111:25ff:febd:d9da/64 nodad dev eth2
```

Be aware of the information in “Confirming that an IP address has been set under layer 3” on page 132 when using IP takeover.

Configuring a device for proxy ARP

You can configure a device for proxy ARP if the layer2 option is not enabled. If you have enabled the layer2 option, you can configure for proxy ARP as you would in a distributed server environment.

For information about the layer2 option, see “MAC headers in layer 2 mode” on page 117.

Before you begin: This section applies to qeth group devices that have been set up as routers only.

The qeth device driver maintains a list of IP addresses for which a qeth group device handles ARP and issues gratuitous ARP packets. For more information about proxy ARP, see

www.sjdwjewis.com/linux/proxyarp

Use the **qethconf** command to display this list or to change the list by adding and removing IP addresses (see “qethconf - Configure qeth devices” on page 492).

Be aware of the information in “Confirming that an IP address has been set under layer 3” on page 132 when working with proxy ARP.

Example:

Figure 22 shows an environment where proxy ARP is used.




Figure 22. Example of proxy ARP usage

G1, G2, and G3 are instances of Linux on z/VM (connected, for example, through a guest LAN to a Linux router R), reached from GW (or the outside world) via R. R is the ARP proxy for G1, G2, and G3. That is, R agrees to take care of packets destined for G1, G2, and G3. The advantage of using proxy ARP is that GW does not need to know that G1, G2, and G3 are behind a router.

To receive packets for 1.2.3.4, so that it can forward them to G1 1.2.3.4, R would add 1.2.3.4 to its list of IP addresses for proxy ARP for the interface that connects it to the OSA adapter.

```
# qethconf parp add 1.2.3.4 eth0
qethconf: Added 1.2.3.4 to /sys/class/net/eth0/device/rxip/add4.
qethconf: Use "qethconf parp list" to check for the result
```

After issuing similar commands for the IP addresses 1.2.3.5 and 1.2.3.6 the proxy ARP configuration of R would be:

```
# qethconf parp list
parp add 1.2.3.4 eth0
parp add 1.2.3.5 eth0
parp add 1.2.3.6 eth0
```

Configuring a device for virtual IP address (VIPA)

You can configure a device for VIPA if the layer2 option is not enabled. If you have enabled the layer2 option, you can configure for VIPA as you would in a distributed server environment.

For information about the layer2 option, see “MAC headers in layer 2 mode” on page 117.

Before you begin: This section does not apply to HiperSockets.

System z use VIPAs to protect against certain types of hardware connection failure. You can assign VIPAs that are independent from particular adapter. VIPAs can be built under Linux using *dummy* devices (for example, “dummy0” or “dummy1”).

The qeth device driver maintains a list of VIPAs that the OSA-Express adapter accepts for each qeth group device. Use the **qethconf** utility to add or remove VIPAs (see “qethconf - Configure qeth devices” on page 492).

For an example of how to use VIPA, see “Scenario: VIPA – minimize outage due to adapter failure.”

Be aware of “Confirming that an IP address has been set under layer 3” on page 132 when working with VIPAs.

Scenario: VIPA – minimize outage due to adapter failure

Using VIPA you can assign IP addresses that are not associated with a particular adapter. This minimizes outage caused by adapter failure.

This scenario describes how to use:

- Standard VIPA
- Source VIPA (version 2.0.0 and later)

Standard VIPA is usually sufficient for applications, such as web servers, that do *not* open connections to other nodes. Source VIPA is used for applications that open connections to other nodes. Source VIPA Extensions enable you to work with multiple VIPAs per destination in order to achieve multipath load balancing.

Notes:

1. See the information in “Confirming that an IP address has been set under layer 3” on page 132 concerning possible failure when setting IP addresses for OSA-Express features in QDIO mode (qeth driver).
2. The configuration file layout for Source VIPA has changed since the 1.x versions. In the 2.0.0 version a policy is included. For details see the README and the man pages provided with the package.

Standard VIPA

VIPA is a facility for assigning an IP address to a system, instead of to individual adapters. It is supported by the Linux kernel. The addresses can be in IPv4 or IPv6 format.

Usage: These are the main steps you must follow to set up VIPA in Linux:

1. Create a dummy device with a *virtual IP address*.
2. Ensure that your service (for example, the Apache web server) listens to the virtual IP address assigned in step 1.
3. Set up *routes* to the virtual IP address, on clients or gateways. To do so, you can use either:
 - Static routing (shown in the example of Figure 23).
 - Dynamic routing. For details of how to configure routes, you must see the documentation delivered with your *routing daemon* (for example, zebra or gated).

If outage of an adapter occurs, you must *switch adapters*.

- Under static routing:
 1. Delete the route that was set previously.
 2. Create an alternative route to the virtual IP address.
- Under dynamic routing, see the documentation delivered with your *routing daemon* for details.

Example of how to set up standard VIPA

This is an example of how to set up standard VIPA.

This example assumes static routing is being used, and shows you how to:

1. Configure VIPA under static routing.
2. Switch adapters when an adapter outage occurs.

Figure 23 shows the network adapter configuration used in the example.




Figure 23. Example of using Virtual IP Address (VIPA)

1. Define the real interfaces

```
[server]# ip addr add 10.1.0.2/16 dev eth0
[server]# ip link set dev eth0 up
[server]# ip addr add 10.2.0.2/16 dev eth1
[server]# ip link set dev eth1 up
```

2. If the dummy component has not been compiled into the kernel, ensure that the dummy module has been loaded. If necessary, load it by issuing:

```
[server]# modprobe dummy
```

3. Create a dummy interface with a virtual IP address 9.164.100.100 and a netmask 255.255.255.0:

```
[server]# ip addr add 9.164.100.100/24 dev dummy0
[server]# ip link set dev dummy0 up
```

4. Enable the network devices for this VIPA so that it accepts packets for this IP address.

```
[server]# qethconf vipa add 9.164.100.100 eth0
qethconf: Added 9.164.100.100 to /sys/class/net/eth0/device/vipa/add4.
qethconf: Use "qethconf vipa list" to check for the result
[server]# qethconf vipa add 9.164.100.100 eth1
qethconf: Added 9.164.100.100 to /sys/class/net/eth1/device/vipa/add4.
qethconf: Use "qethconf vipa list" to check for the result
```

For IPv6, the address is specified in IPv6 format:

```
[server]# qethconf vipa add 2002::1234:5678 eth0
qethconf: Added 2002:0000:0000:0000:0000:0000:1235:5678 to /sys/class/net/eth0/device/vipa/add6.
qethconf: Use "qethconf vipa list" to check for the result
[server]# qethconf vipa add 2002::1235:5678 eth1
qethconf: Added 2002:0000:0000:0000:0000:0000:1235:5678 to /sys/class/net/eth1/device/vipa/add6.
qethconf: Use "qethconf vipa list" to check for the result
```

5. Ensure that the addresses have been set:

```
[server]# qethconf vipa list
vipa add 9.164.100.100 eth0
vipa add 9.164.100.100 eth1
```

6. Ensure that your service (such as the Apache web server) listens to the virtual IP address.
7. Set up a route to the virtual IP address (static routing), so that VIPA can be reached via the gateway with address 10.1.0.2.

```
[router]# ip route add 9.164.100.100 via 10.1.0.2
```

Now assume that an adapter outage occurs. You must then:

1. Delete the previously-created route.

```
[router]# ip route del 9.164.100.100
```

2. Create the alternative route to the virtual IP address.

```
[router]# ip route add 9.164.100.100 via 10.2.0.2
```

Source VIPA

Source VIPA is particularly suitable for high-performance environments. It selects one source address out of a range of source addresses when it replaces the source address of a socket.

Purpose:

The reason for using several source addresses lies in the inability of some operating system kernels to do load balancing among several connections with the same source and destination address over several interfaces.

To achieve load balancing, a policy has to be selected in the policy section of the configuration file of Source VIPA (/etc/src_vipa.conf). This policy section also allows to specify several source addresses used for one destination. Source VIPA then applies the source address selection according to the rules of the policy selected in the configuration file.

This Source VIPA solution does not affect kernel stability. Source VIPA is controlled by a configuration file containing flexible rules for when to use Source VIPA based on destination IP address ranges.

Note: This implementation of Source VIPA applies to IPv4 only.

Usage:

To install:

Source VIPA is delivered as part of the s390utils package. Install the package as usual.

Configuration:

With Source VIPA version 2.0.0 the configuration file has changed: the policy section was added. The default configuration file is /etc/src_vipa.conf.

/etc/src_vipa.conf or the file pointed to by the environment variable SRC_VIPA_CONFIG_FILE, contains lines such as the following:

```
# comment
D1.D2.D3.D4/MASK POLICY S1.S2.S3.S4 [T1.T2.T3.T4 [...]]
.INADDR_ANY P1-P2 POLICY S1.S2.S3.S4 [T1.T2.T3.T4 [...]]
.INADDR_ANY P POLICY S1.S2.S3.S4 [T1.T2.T3.T4 [...]]
```

D1.D2.D3.D4/MASK specifies a range of destination addresses and the number of bits set in the subnet mask (MASK). As soon as a socket is opened and connected to these destination addresses and the application does not do an explicit bind to a source address, Source VIPA does a bind to one of the source addresses specified (S, T, [...]) using the policy selected in the configuration file to distribute the source addresses. See “Policies” on page 151 for available load distribution policies. Instead of IP addresses in dotted notation, hostnames can also be used and will be resolved using DNS.

.INADDR_ANY P1-P2 POLICY S1.S2.S3.S4 or .INADDR_ANY P POLICY S1.S2.S3.S4 causes bind calls with .INADDR_ANY as a local address to be intercepted if the port the socket is bound to is between P1 and P2 (inclusive). In this case, .INADDR_ANY will be replaced by one of the source addresses specified (S, T, [...]), which can be 0.0.0.0.

All `.INADDR_ANY` statements will be read and evaluated in order of appearance. This means that multiple `.INADDR_ANY` statements can be used to have bind calls intercepted for every port outside a certain range. This is useful, for example, for `rlogin`, which uses the bind command to bind to a local port but with `.INADDR_ANY` as a source address to use automatic source address selection. See “Policies” for available load distribution policies.

The default behavior for all ports is that the kind of bind calls will not be modified.

Policies:

With Source VIPA Extensions you provide a range of dummy source addresses for replacing the source addresses of a socket. The policy selected determines which method is used for selecting the source addresses from the range of dummy addresses..

onevipa

Only the first address of all source addresses specified is used as source address.

random

The source address used is selected randomly from all the specified source addresses.

llr (local round robin)

The source address used is selected in a round robin manner from all the specified source addresses. The round robin takes place on a per-invocation base: each process is assigned the source addresses round robin independently from other processes.

rr:ABC

Stands for round robin and implements a global round robin over all Source VIPA instances sharing the same configuration file. All processes using Source VIPA access an IPC shared memory segment to fulfil a global round robin algorithm. This shared memory segment is destroyed when the last running Source VIPA ends. However, if this process does not end gracefully (for example, is ended by a `kill` command), the shared memory segment (size: 4 bytes) can stay in the memory until it is removed by `ipcrm`. The tool `ipcs` can be used to display all IPC resources and to get the key or id used for `ipcrm`. ABC are UNIX permissions in octal writing (for example, 700) that are used to create the shared memory segment. This permission mask should be as restrictive as possible. A process having access to this mask can cause an imbalance of the round robin distribution in the worst case.

lc

Attempts to balance the number of connections per source address. This policy always associates the socket with the VIPA that is least in use. If the policy cannot be parsed correctly, the policy is set to round robin per default.

Enabling an application:

The command:

```
src_vipa.sh <application and parameters>
```

enables the Source VIPA functionality for the application. The configuration file is read once the application is started. It is also possible to change the starter script

and run multiple applications using different Source VIPA settings in separate files. To do this, define and export a `SRC_VIPA_CONFIG_FILE` environment variable that points to the separate file before invoking an application.

Notes:

1. `LD_PRELOAD` security prevents `setuid` executables to be run under Source VIPA; programs of this kind can only be run when the real UID is 0. The ping utility is usually installed with `setuid` permissions.
2. The maximum number of VIPAs per destination is currently defined as 8.

Example:

Figure 24 shows a configuration where two applications with VIPA 9.164.100.100 and 9.164.100.200 are to be set up for Source VIPA with a local round robin policy.




Figure 24. Example of using source VIPA

The required entry in the Source VIPA configuration file is:

```
9.0.0.0/8 lrr 9.164.100.100 9.164.100.200
```

Scenario: Virtual LAN (VLAN) support

VLAN technology works according to IEEE Standard 802.1Q by logically segmenting the network into different broadcast domains so that packets are switched only between ports designated for the same VLAN.

By containing traffic originating on a particular LAN to other LANs within the same VLAN, switched virtual networks avoid wasting bandwidth, a drawback inherent in traditional bridged/switched networks where packets are often forwarded to LANs that do not require them.

The qeth device driver for OSA-Express (QDIO) and HiperSockets supports priority tags as specified by IEEE Standard 802.1Q for both layer 2 and layer 3.

Introduction to VLANs

VLANs increase traffic flow and reduce overhead by allowing you to organize your network by traffic patterns rather than by physical location.

In a conventional network topology, such as that shown in the following figure, devices communicate across LAN segments in different broadcast domains using routers. Although routers add latency by delaying transmission of data while using more of the data packet to determine destinations, they are preferable to building a single broadcast domain, which could easily be flooded with traffic.




Figure 25. Conventional routed network

By organizing the network into VLANs through the use of Ethernet switches, distinct broadcast domains can be maintained without the latency introduced by multiple routers. As the following figure shows, a single router can provide the interfaces for all VLANs that appeared as separate LAN segments in the previous figure.




Figure 26. Switched VLAN network

The following figure shows how VLANs can be organized logically, according to traffic flow, rather than being restricted by physical location. If workstations 1-3 communicate mainly with the small server, VLANs can be used to organize only these devices in a single broadcast domain that keeps broadcast traffic within the group. This reduces traffic both inside the domain and outside, on the rest of the

network.




Figure 27. VLAN network organized for traffic flow

Configuring VLAN devices

VLANs are configured using the **vconfig** command. See the **vconfig** man page for details.

Information about the current VLAN configuration is available by listing the files in

`/proc/net/vlan/*`

with `cat` or `more`. For example:

```
bash-2.04# cat /proc/net/vlan/config
VLAN Dev name | VLAN ID
Name-Type: VLAN_NAME_TYPE_RAW_PLUS_VID_NO_PAD bad_proto_rcvd: 0
eth2.100      | 100    | eth2
eth2.200      | 200    | eth2
eth2.300      | 300    | eth2
bash-2.04# cat /proc/net/vlan/eth2.300
eth2.300 VID: 300 REORDER_HDR: 1 dev->priv_flags: 1
          total frames received: 10914061
          total bytes received: 1291041929
          Broadcast/Multicast Rcvd: 6

          total frames transmitted: 10471684
          total bytes transmitted: 4170258240
          total headroom inc: 0
          total encap on xmit: 10471684
Device: eth2
INGRESS priority mappings: 0:0 1:0 2:0 3:0 4:0 5:0 6:0 7:0
EGRESS priority Mappings:
bash-2.04#
```

Example: Creating two VLANs

VLANs are allocated in an existing interface representing a physical Ethernet LAN.

The following example creates two VLANs, one with ID 3 and one with ID 5.

```
ip addr add 9.164.160.23/19 dev eth1
ip link set dev eth1 up
vconfig add eth1 3
vconfig add eth1 5
```

The vconfig commands have added interfaces "eth1.3" and "eth1.5", which you can then configure:

```
ip addr add 1.2.3.4/24 dev eth1.3
ip link set dev eth1.3 up
ip addr add 10.100.2.3/16 dev eth1.5
ip link set dev eth1.5 up
```

The traffic that flows out of eth1.3 will be in the VLAN with ID=3 (and will not be received by other stacks that listen to VLANs with ID=4).

The internal routing table will ensure that every packet to 1.2.3.x goes out via eth1.3 and everything to 10.100.x.x via eth1.5. Traffic to 9.164.1xx.x will flow through eth1 (without a VLAN tag).

To remove one of the VLAN interfaces:

```
ip link set dev eth1.3 down
vconfig rem eth1.3
```

Example: Creating a VLAN with five Linux instances

An example of how to set up a VLAN with five Linux instances.

The following example illustrates the definition and connectivity test for a VLAN comprising five different Linux systems (two LPARs, two z/VM guest virtual machines, and one x86 system), each connected to a physical Ethernet LAN through eth1:

- LINUX1: LPAR

```
vconfig add eth1 5
ip addr add 10.100.100.1/24 dev eth1.5
ip link set dev eth1.5 up
```

- LINUX2: LPAR

```
vconfig add eth1 5
ip addr add 10.100.100.2/24 dev eth1.5
ip link set dev eth1.5 up
```

- LINUX3: z/VM guest

```
vconfig add eth1 5
ip addr add 10.100.100.3/24 dev eth1.5
ip link set dev eth1.5 up
```

- LINUX4: z/VM guest

```
vconfig add eth1 5
ip addr add 10.100.100.4/24 dev eth1.5
ip link set dev eth1.5 up
```

- LINUX5: x86

```
vconfig add eth1 5
ip addr add 10.100.100.5/24 dev eth1.5
ip link set dev eth1.5 up
```

Test the connections:

```
ping 10.100.100.1          // Unicast-PING
...
ping 10.100.100.5
ping -I eth1.5 224.0.0.1    // Multicast-PING
ping -b 10.100.100.255      // Broadcast-PING
```

HiperSockets Network Concentrator

This section describes how to configure a HiperSockets Network Concentrator on a QETH device in layer 3 mode.

Before you begin: This section applies to IPv4 only. The HiperSockets Network Concentrator connector settings are available in layer 3 mode only.

The HiperSockets Network Concentrator connects systems to an external LAN within one IP subnet using HiperSockets. HiperSockets Network Concentrator connected systems appear as if they were directly connected to the LAN. This helps to reduce the complexity of network topologies resulting from server consolidation. HiperSockets Network Concentrator allows to migrate systems from the LAN into a System z Server environment, or systems connected by a different HiperSockets Network Concentrator into a System z Server environment, without changing the network setup. Thus, HiperSockets Network Concentrator helps to simplify network configuration and administration.

Design:

A connector Linux system forwards traffic between the external OSA interface and one or more internal HiperSockets interfaces. This is done via IPv4 forwarding for unicast traffic and via a particular bridging code (xcec_bridge) for multicast traffic.

A script named `ip_watcher.pl` observes all IP addresses registered in the HiperSockets network and sets them as Proxy ARP entries (see “Configuring a device for proxy ARP” on page 146) on the OSA interfaces. The script also establishes routes for all internal systems to enable IP forwarding between the interfaces.

All unicast packets that cannot be delivered in the HiperSockets network are handed over to the connector by HiperSockets. The connector also receives all multicast packets to bridge them.

Setup:

The setup principles for configuring the HiperSockets Network Concentrator are as follows:

leaf nodes

The leaf nodes do not require a special setup. To attach them to the HiperSockets network, their setup should be as if they were directly attached to the LAN. They do not have to be Linux systems.

connector systems

In the following, HiperSockets Network Concentrator IP refers to the subnet of the LAN that is extended into the HiperSockets net.

- If you want to support forwarding of all packet types, define the OSA interface for traffic into the LAN as a multicast router (see “Setting up a Linux router” on page 137).
- All HiperSockets interfaces involved must be set up as connectors: set the route4 attributes of the corresponding devices to “primary_connector” or to “secondary_connector”. Alternatively, you can add the OSA interface name to the start script as a parameter. This option results in HiperSockets Network Concentrator ignoring multicast packets, which are then not forwarded to the HiperSockets interfaces.
- IP forwarding must be enabled for the connector partition. This can be achieved with the command

```
sysctl -w net.ipv4.ip_forward=1
```

Alternatively, you can enable IP forwarding in the /etc/sysctl.conf configuration file to activate IP forwarding for the connector partition automatically after booting.

- The network routes for the HiperSockets interface must be removed, a network route for the HiperSockets Network Concentrator IP subnet has to be established via the OSA interface. To achieve this, the IP address 0.0.0.0 can be assigned to the HiperSockets interface while an address used in the HiperSockets Network Concentrator IP subnet is to be assigned to the OSA interface. This sets the network routes up correctly for HiperSockets Network Concentrator.
- To *start* HiperSockets Network Concentrator, run the script `start_hsync.sh`. You can specify an interface name as optional parameter. This makes HiperSockets Network Concentrator use the specified interface to access the LAN. There is no multicast forwarding in that case.
- To *stop* HiperSockets Network Concentrator, use the command `killall ip_watcher.pl` to remove changes caused by running HiperSockets Network Concentrator.

Availability setups:

If a connector system fails during operation, it can simply be restarted. If all the startup commands are executed automatically, it will instantaneously be operational again after booting. Two common availability setups are mentioned here:

One connector partition and one monitoring system

As soon as the monitoring system cannot reach the connector for a specific timeout (for example, 5 seconds), it restarts the connector. The connector itself monitors the monitoring system. If it detects (with a longer timeout than the monitoring system, for example, 15 seconds) a monitor system failure, it restarts the monitoring system.

Two connector systems monitoring each other

In this setup, there is an active and a passive system. As soon as the passive system detects a failure of the active connector, it takes over operation. In order to do this it needs to reset the other system to release all OSA resources for the multicast_router operation. The failed system can then be restarted manually or automatically, depending on the

configuration. The passive backup HiperSockets interface can either switch into `primary_connector` mode during the failover, or it can be setup as `secondary_connector`. A `secondary_connector` takes over the connecting functionality, as soon as there is no active `primary_connector`. This setup has a faster failover time than the first one.

Hints:

- The MTU of the OSA and HiperSockets link should be of the same size. Otherwise multicast packets not fitting in the link's MTU are discarded as there is no IP fragmentation for multicast bridging. Warnings are printed to `/var/log/messages` or a corresponding syslog destination.
- The script `ip_watcher.pl` prints error messages to the standard error descriptor of the process.
- `xcec-bridge` logs messages and errors to syslog. On Red Hat Enterprise Linux 6.3 this creates entries in `/var/log/messages`.
- Registering all internal addresses with the OSA adapter can take several seconds for each address.
- To shut down the HiperSockets Network Concentrator functionality, simply issue `killall ip_watcher.pl`. This removes all routing table and Proxy ARP entries added while using HiperSockets Network Concentrator.

Notes:

1. Broadcast bridging is active only on OSA or HiperSockets hardware that can handle broadcast traffic without causing a bridge loop. If you see the message "Setting up broadcast echo filtering for ... failed" in the message log when setting the qeth device online, broadcast bridging is not available.
2. Unicast packets are routed by the common Linux IPv4 forwarding mechanisms. As bridging and forwarding are done at the IP Level, the IEEE 802.1q VLAN and the IPv6 protocol are not supported.

Examples for setting up a network concentrator

An example of a network environment with a network concentrator.

Figure 28 shows a network environment where a Linux instance C acts as a network concentrator that connects other operating system instances on a HiperSockets LAN to an external LAN.




Figure 28. HiperSockets network concentrator setup

Setup for the network concentrator C:

The HiperSockets interface hsi0 (device bus-ID 0.0.a1c0) has IP address 10.20.30.51, and the netmask is 255.255.255.0. The default gateway is 10.20.30.1.

Issue:

```
# echo primary_connector > /sys/bus/ccwgroup/drivers/qeth/0.0.a1c0/route4
```

The OSA-Express CHPID in QDIO mode interface eth0 (with device bus-ID 0.0.a1c4) has IP address 10.20.30.11, and the netmask is 255.255.255.0. The default gateway is 10.20.30.1.

Issue:

```
# echo multicast_router > /sys/bus/ccwgroup/drivers/qeth/0.0.a1c4/route4
```

To enable IP forwarding issue:

```
# sysctl -w net.ipv4.ip_forward=1
```

To remove the network routes for the HiperSockets interface issue:

```
# ip route del 10.20.30/24
```

To start the HiperSockets network concentrator run the script `start_hsync.sh`. Issue:

```
# start_hsync.sh &
```

Setup for G:

No special setup required. The HiperSockets interface has IP address 10.20.30.54, and the netmask is 255.255.255.0. The default gateway is 10.20.30.1.

Setup for workstation:

No special setup required. The network interface IP address is 10.20.30.120, and the netmask is 255.255.255.0. The default gateway is 10.20.30.1.

Figure 29 shows the example of Figure 28 on page 158 with an additional mainframe. On the second mainframe a Linux instance D acts as a HiperSockets network concentrator.




Figure 29. Expanded HiperSockets network concentrator setup

The configuration of C, G, and the workstation remain the same as for Figure 28 on page 158.

Setup for the network concentrator D:

The HiperSockets interface hsi0 has IP address 0.0.0.0.

Assuming that the device bus-ID of the HiperSockets interface is 0.0.a1d0, issue:

```
# echo primary_connector > /sys/bus/ccwgroup/drivers/qeth/0.0.a1d0/route4
```

The OSA-Express CHPID in QDIO mode interface eth0 has IP address 10.20.30.50, and the netmask is 255.255.255.0. The default gateway is 10.20.30.1.

D is not configured as a multicast router, it therefore only forwards unicast packets.

To enable IP forwarding issue:

```
# sysctl -w net.ipv4.ip_forward=1
```

Tip: See *Red Hat Enterprise Linux 6.3 Installation Guide* for information about using configuration files to automatically enable IP forwarding when booting.

To start the HiperSockets network concentrator run the script `start_hsync.sh`. Issue:


```
# start_hsync.sh &
```

Setup for H:

No special setup required. The HiperSockets interface has IP address 10.20.30.55, and the netmask is 255.255.255.0. The default gateway is 10.20.30.1.

Setting up for DHCP with IPv4

For connections through an OSA-Express adapter in QDIO mode, the OSA-Express adapter offloads ARP, MAC header, and MAC address handling.

For information about MAC headers, see “MAC headers in layer 3 mode” on page 118.

Because a HiperSockets connection does not go out on a physical network, there are no ARP, MAC headers, and MAC addresses for packets in a HiperSockets LAN. The resulting problems for DHCP are the same in both cases and the fixes for connections through the OSA-Express adapter also apply to HiperSockets.

Dynamic Host Configuration Protocol (DHCP) is a TCP/IP protocol that allows clients to obtain IP network configuration information (including an IP address) from a central DHCP server. The DHCP server controls whether the address it provides to a client is allocated permanently or is leased temporarily. DHCP specifications are described by RFC 2131 “Dynamic Host Configuration Protocol” and RFC 2132 “DHCP options and BOOTP Vendor Extensions”, which are available at

www.ietf.org

Two types of DHCP environments have to be taken into account:

- DHCP using OSA-Express adapters in QDIO mode
- DHCP in a z/VM guest LAN

For information about setting up DHCP for a Linux instance in a z/VM guest LAN environment, see Redpaper *Linux on IBM eServer™ zSeries and S/390: TCP/IP Broadcast on z/VM Guest LAN*, REDP-3596 at

www.ibm.com/redbooks

This book discusses *dhclient* and *dhcp* as examples of a DHCP client and a DHCP server you can use.

Required options for using dhclient with layer3

You must configure the DHCP client program *dhclient* to use it on Linux on System z with layer3.

- Run the DHCP client with an option that instructs the DHCP server to broadcast its response to the client.

Because the OSA-Express adapter in QDIO mode forwards packets to Linux based on IP addresses, a DHCP client that requests an IP address cannot receive the response from the DHCP server without this option.

- Run the DHCP client with an option that specifies the client identifier string.

By default, the client uses the MAC address of the network interface. Hence, without this option, all Linux instances that share the same OSA-Express adapter in QDIO mode would also have the same client identifier.

See the documentation for `dhclient` about how to select these options.

You need no special options for the DHCP server program, `dhcp`. You need no special options for using `dhcp`.

Setting up Linux as a LAN sniffer

You can set up a Linux instance to act as a LAN sniffer, for example, to make data on LAN traffic available to tools like **tcpdump** or Wireshark.

The LAN sniffer can be:

- A HiperSockets Network Traffic Analyzer for LAN traffic between LPARs
- A LAN sniffer for LAN traffic between z/VM guest virtual machines, for example, through a z/VM virtual switch (VSWITCH)

Setting up a HiperSockets network traffic analyzer

A HiperSockets network traffic analyzer (NTA) runs in an LPAR and monitors LAN traffic between LPARs.

HiperSockets NTA is available to trace both layer 3 and layer 2 network traffic, but the analyzing device itself must be configured as a layer 3 device. The analyzing device is a dedicated NTA device and cannot be used as a regular network interface.

Before you begin:

- On the SE, the LPARs must be authorized for analyzing and being analyzed.

Tip: SE authorization changes for the HiperSockets network traffic analyzer require recreating the device by un-grouping and regrouping (see “Removing a qeth group device” on page 125 and “Creating a qeth group device” on page 124). Do any authorization changes before configuring the NTA device.

- You need a traffic dumping tool such as **tcpdump**.
- You need a mainframe system that supports HiperSockets network traffic analyzer. HiperSockets network traffic analyzer became available for System z10 in March 2010.

Linux setup:

Ensure that the qeth device driver module has been loaded.

Perform the following steps:

1. Configure a HiperSockets interface dedicated to analyzing with the `layer2` sysfs attribute set to 0 and the `sniffer` sysfs attribute set to 1. For example, assuming the HiperSockets interface is `hsi0` with device bus-ID `0.0.a1c0`:

```
# znetconf -a a1c0 -o layer2=0 -o sniffer=1
```

The **znetconf** command also sets the device online. For more information about **znetconf**, see “znetconf - List and configure network devices” on page 516. The qeth device driver automatically sets the `buffer_count` attribute to 128 for the analyzing device.

2. Activate the device (no IP address is needed):

```
# ip link set hsi0 up
```

3. Switch the interface into promiscuous mode:

```
# tcpdump -i hsi0
```

The device is now set up as a HiperSockets network traffic analyzer.

Hint: A HiperSockets network traffic analyzer with no free empty inbound buffers might have to drop packets. Dropped packets are reflected in the "dropped counter" of the HiperSockets network traffic analyzer interface and reported by **tcpdump**.

Example:

```
# ip -s link show dev hsi0
...
RX: bytes  packets  errors  dropped overrun mcast
223242    6789      0       5         0      176
...
# tcpdump -i hsi0
tcpdump: verbose output suppressed, use -v or -vv for full protocol decode
listening on hsi1, link-type EN10MB (Ethernet), capture size 96 bytes
...
5 packets dropped by kernel
```

Setting up a z/VM guest LAN sniffer

You can set up a guest LAN sniffer for guest LANs that are defined through a z/VM virtual switch and for other types of z/VM guest LANs.

If a virtual switch connects to a VLAN that includes nodes outside the z/VM system, these external nodes are beyond the scope of the sniffer.

For information about VLANs and z/VM virtual switches, see *z/VM Connectivity*, SC24-6174.

Before you begin:

- You need class B authorization on z/VM.
- The Linux instance to be set up as a guest LAN sniffer must run as a guest of the same z/VM system as the guest LAN you want to investigate.

Linux setup:

Ensure that the qeth device driver has been loaded.

z/VM setup:

Ensure that the z/VM guest virtual machine on which you want to set up the guest LAN sniffer is authorized for the switch or guest LAN and for promiscuous mode.

For example, if your guest LAN is defined through a z/VM virtual switch, perform the following steps on your z/VM system:

1. Check if the z/VM guest virtual machine already has the required authorizations. Enter a CP command of this form:

```
q vswitch <switchname> promisc
```

where *<switchname>* is the name of the virtual switch. If the output lists the z/VM guest virtual machine as authorized for promiscuous mode, no further setup is required.

2. If the output from step 1 does not list the guest virtual machine, check if the guest is authorized for the virtual switch. Enter a CP command of this form:

```
q vswitch <switchname> acc
```

where *<switchname>* is the name of the virtual switch.

If the output lists the z/VM guest virtual machine as authorized, you must temporarily revoke the authorization for the switch before you can grant authorization for promiscuous mode. Enter a CP command of this form:

```
set vswitch <switchname> revoke <userid>
```

where *<switchname>* is the name of the virtual switch and *<userid>* identifies the z/VM guest virtual machine.

3. Authorize the Linux instance for the switch and for promiscuous mode. Enter a CP command of this form:

```
set vswitch <switchname> grant <userid> promisc
```

where *<switchname>* is the name of the virtual switch and *<userid>* identifies the z/VM guest virtual machine.

For details about the CP commands used in this section and for commands you can use to check and assign authorizations for other types of guest LANs, see *z/VM CP Commands and Utilities Reference*, SC24-6175.

Chapter 9. OSA-Express SNMP subagent support

The OSA-Express Simple Network Management Protocol (SNMP) subagent (osasnmpd) supports management information bases (MIBs) for the OSA-Express features.

The subagent supports OSA-Express features as shown in Table 23 on page 111.

This subagent capability through the OSA-Express features is also called *Direct SNMP* to distinguish it from another method of accessing OSA SNMP data through OSA/SF, a package for monitoring and managing OSA features that does not run on Linux.

To use the osasnmpd subagent you need:

- An OSA-Express feature running in QDIO mode with the latest textual MIB file for the appropriate LIC level (recommended)
- The qeth device driver for OSA-Express (QDIO)
- The osasnmpd subagent from the s390utils RPM
- The net-snmp package delivered with Red Hat Enterprise Linux 6

What you need to know about osasnmpd

The osasnmpd subagent requires a master agent to be installed on a Linux system.

You get the master agent from the net-snmp package. The subagent uses the Agent eXtensibility (AgentX) protocol to communicate with the master agent.

net-snmp is an Open Source project that is owned by the Open Source Development Network, Inc. (OSDN). For more information about net-snmp visit: net-snmp.sourceforge.net

When the master agent (snmpd) is started on a Linux system, it binds to a port (default 161) and awaits requests from SNMP management software. Subagents can connect to the master agent to support MIBs of special interest (for example, OSA-Express MIB). When the osasnmpd subagent is started, it retrieves the MIB objects of the OSA-Express features currently present on the Linux system. It then registers with the master agent the object IDs (OIDs) for which it can provide information.

An OID is a unique sequence of dot-separated numbers (for example, .1.3.6.1.4.1.2) that represents a particular information. OIDs form a hierarchical structure. The longer the OID, that is the more numbers it is made up of, the more specific is the information that is represented by the OID. For example, .1.3.6.1.4.1.2 represents all IBM-related network information while ..1.3.6.1.4.1.2.6.188 represents all OSA-Express-related information.

A MIB corresponds to a number of OIDs. MIBs provide information about their OIDs including textual representations the OIDs. For example, the textual representation of .1.3.6.1.4.1.2 is .iso.org.dod.internet.private.enterprises.ibm.

The structure of the MIBs might change when updating the OSA-Express licensed internal code (LIC) to a newer level. If MIB changes are introduced by a new LIC

level, you need to download the appropriate MIB file for the LIC level (see “Downloading the IBM OSA-Express MIB”), but you do not need to update the subagent. Place the updated MIB file in a directory that is searched by the master agent.




Figure 30. OSA-Express SNMP agent flow

Figure 30 illustrates the interaction between the snmpd master agent and the osasnmpr subagent.

Example: This example shows the processes running after the snmpd master agent and the osasnmpr subagent have been started. When you start osasnmpr, a daemon called osasnmpr starts. In the example, PID 687 is the SNMP master agent and PID 729 is the OSA-Express SNMP subagent process:

```

ps -ef | grep snmp
USER      PID      1  0 11:57 pts/1    00:00:00 snmpd
root      729     659  0 13:22 pts/1    00:00:00 osasnmpr

```

When the master agent receives an SNMP request for an OID that has been registered by a subagent, the master agent uses the subagent to collect any requested information and to perform any requested operations. The subagent returns any requested information to the master agent. Finally, the master agent returns the information to the originator of the request.

Setting up osasnmpr

You need to download the IBM OSA-Express MIB and configure access control before you use can the osasnmpr subagent.

- Downloading the IBM OSA-Express MIB
- Configuring access control

Downloading the IBM OSA-Express MIB

Keep your MIB file up to date by downloading the latest version.

Perform the following steps to download the IBM OSA-Express MIB. The MIB file is valid only for hardware that supports the OSA-Express adapter.

1. Go to www.ibm.com/servers/resourceLink

A user ID and password are required. You can apply for a user ID if you do not yet have one.

2. Sign in.
3. Select **Library** from the navigation area.
4. Under **Library shortcuts**, select **Open Systems Adapter (OSA) Library**.
5. Follow the link for **OSA-Express Direct SNMP MIB module**.
6. Select and download the MIB for your LIC level.
7. Rename the MIB file to the name specified in the MIBs definition line and use the extension .txt.

Example: If the definition line in the MIB looks like this:

```
==>IBM-OSA-MIB DEFINITIONS ::= BEGIN
```

Rename the MIB to IBM-OSA-MIB.txt.

8. Place the MIB into /usr/share/snmp/mibs.

If you want to use a different directory, be sure to specify the directory in the snmp.conf configuration file (see step 10 on page 169).

Result: You can now make the OID information from the MIB file available to the master agent. This allows you to use textual OIDs instead of numeric OIDs when using master agent commands.

See also the FAQ (How do I add a MIB to the tools?) for the master agent package at

net-snmp.sourceforge.net/FAQ.html

Configuring access control

To start successfully, the subagent requires at least read access to the standard MIB-II on the local node.

During subagent startup or when network interfaces are added or removed, the subagent has to query OIDs from the interfaces group of the standard MIB-II.

This section gives an example of how you can use the snmpd.conf and snmp.conf configuration files to assign access rights using the View-Based Access Control Mechanism (VACM). The following access rights are assigned on the local node:

- General read access for the scope of the standard MIB-II
- Write access for the scope of the OSA-Express MIB
- Public local read access for the scope of the interfaces MIB

The example is intended for illustration purposes only. Depending on the security requirements of your installation, you might need to define your access differently. See the snmpd man page for a more information about assigning access rights to snmpd.

1. See the Red Hat Enterprise Linux 6.3 documentation to find out where you need to place the snmpd.conf file. Some of the possible locations are:
 - /etc
 - /etc/snmp
2. Open snmpd.conf with your preferred text editor. There might be a sample in `usr/share/doc/packages/net-snmp/EXAMPLE.conf`
3. Find the security name section and include a line of this form to map a community name to a security name:

```
com2sec <security-name> <source> <community-name>
```

where:

<security-name>

is given access rights through further specifications within `snmpd.conf`.

<source>

is the IP-address or DNS-name of the accessing system, typically a Network Management Station.

<community-name>

is the community string used for basic SNMP password protection.

Example:

```
#      sec.name      source      community
com2sec osasec      default    osacom
com2sec pubsec      localhost  public
```

4. Find the group section. Use the security name to define a group with different versions of the master agent for which you want to grant access rights. Include a line of this form for each master agent version:

```
group <group-name> <security-model> <security-name>
```

where:

<group-name>

is a group name of your choice.

<security-model>

is the security model of the SNMP version.

<security-name>

is the same as in step 3 on page 167.

Example:

```
#      groupName      securityModel  securityName
group  osagroup       v1            osasec
group  osagroup       v2c          osasec
group  osagroup       usm          osasec
group  osasnmppd      v2c          pubsec
```

Group “`osasnmppd`” with community “`public`” is required by `osasnmppd` to determine the number of network interfaces.

5. Find the view section and define your views. A view is a subset of all OIDs. Include lines of this form:

```
view <view-name> <included|excluded> <scope>
```

where:

<view-name>

is a view name of your choice.

<included|excluded>

indicates whether the following scope is an inclusion or an exclusion statement.

<scope>

specifies a subtree in the OID tree.

Example:

#	name	incl/excl	subtree	mask(optional)
view	allview	included	.1	
view	osaview	included	.1.3.6.1.4.1.2	
view	ifmibview	included	interfaces	
view	ifmibview	included	system	

View “allview” encompasses all OIDs while “osaview” is limited to IBM OIDs. The numeric OID provided for the subtree is equivalent to the textual OID “.iso.org.dod.internet.private.enterprises.ibm”. View “ifmibview” is required by osasnmppd to determine the number of network interfaces.

Tip: Specifying the subtree with a numeric OID leads to better performance than using the corresponding textual OID.

6. Find the access section and define access rights. Include lines of this form:

```
access <group-name> "" any noauth exact <read-view> <write-view> none
```

where:

<group-name>

is the group you defined in step 4 on page 168.

<read-view>

is a view for which you want to assign read-only rights.

<write-view>

is a view for which you want to assign read-write rights.

Example:

#	group	context	sec.model	sec.level	prefix	read	write	notif
access	osagroup	""	any	noauth	exact	allview	osaview	none
access	osasnmppd	""	v2c	noauth	exact	ifmibview	none	none

The access line of the example gives read access to the “allview” view and write access to the “osaview”. The second access line gives read access to the “ifmibview”.

7. Also include the following line to enable the AgentX support:

```
master agentx
```

AgentX support is compiled into the net-snmp master agent.

8. Save and close snmpd.conf.

9. Open snmp.conf with your preferred text editor.

10. Include a line of this form to specify the directory to be searched for MIBs:

```
mibdirs +<mib-path>
```

Example: mibdirs +/usr/share/snmp/mibs

11. Include a line of this form to make the OSA-Express MIB available to the master agent:

```
mibs +<mib-name>
```

where <mib-name> is the stem of the MIB file name you assigned in “Downloading the IBM OSA-Express MIB” on page 166.

Example: mibs +IBM-OSA-MIB

12. Define defaults for the version and community to be used by the snmp commands. Add lines of this form:

```
defVersion <version>
defCommunity <community-name>
```

where *<version>* is the SNMP protocol version and *<community-name>* is the community you defined in step 3 on page 167.

Example:

```
defVersion 2c
defCommunity osacom
```

These default specifications simplify issuing master agent commands.

13. Save and close `snmp.conf`.

Working with the `osasnmppd` subagent

Working with the `osasnmppd` subagent includes starting it, checking the log file, issuing queries, and stopping the subagent.

This section describes the following tasks:

- Starting the `osasnmppd` subagent
- Checking the log file
- Issuing queries
- Stopping `osasnmppd`

Starting the `osasnmppd` subagent

Use the **`osasnmppd`** command to start the `osasnmppd` subagent.

After downloading `osasnmppd` package and setting up the `osasnmppd` subagent, start the subagent using the command:

```
# osasnmppd
```

The `osasnmppd` subagent, in turn, starts a daemon called `osasnmppd`.

For command options see the **`osasnmppd`** command manpage.

If you restart the master agent, you must also restart the subagent. When the master agent is started, it does not look for already running subagents. Any running subagents must also be restarted to be register with the master agent.

Checking the log file

Warnings and messages are written to the log file of either the master agent or the OSA-Express subagent. It is good practice to check these files at regular intervals.

Example: This example assumes that the default subagent log file is used. The lines in the log file show the messages after a successful OSA-Express subagent initialization.

```
# cat /var/log/osasnmppd.log
IBM OSA-E NET-SNMP 5.1.x subagent version 1.3.0
Jul 14 09:28:41 registered Toplevel OID .1.3.6.1.2.1.10.7.2.
Jul 14 09:28:41 registered Toplevel OID .1.3.6.1.4.1.2.6.188.1.1.
Jul 14 09:28:41 registered Toplevel OID .1.3.6.1.4.1.2.6.188.1.3.
Jul 14 09:28:41 registered Toplevel OID .1.3.6.1.4.1.2.6.188.1.4.
Jul 14 09:28:41 registered Toplevel OID .1.3.6.1.4.1.2.6.188.1.8.
OSA-E microcode level is 611 for interface eth0
Initialization of OSA-E subagent successful...
```

Issuing queries

You can issue queries against your SNMP setup.

This topic provides some examples of what SNMP queries might look like. For more comprehensive information about the master agent commands see the `snmpcmd` man page.

The commands can use either numeric or textual OIDs. While the numeric OIDs might provide better performance, the textual OIDs are more meaningful and give a hint on which information is requested.

The query examples in this section assume an interface, `eth0`, for which the CHPID is 6B. You can use the `lsqeth` command to find the mapping of interface names to CHPIDs.

- To list the `ifIndex` and interface description relation (on one line):

```
# snmpget -v 2c -c osacom localhost interfaces.ifTable.ifEntry.ifDescr.6
interfaces.ifTable.ifEntry.ifDescr.6 = eth0
```

Using this GET request you can see that `eth0` has the `ifIndex` 6 assigned.

- To find the CHPID numbers for your OSA devices:

```
# snmpwalk -OS -v 2c -c osacom localhost .1.3.6.1.4.1.2.6.188.1.1.1.1
IBM-OSA-MIB::ibmOSAExpChannelNumber.6 = Hex-STRING: 00 6B
IBM-OSA-MIB::ibmOSAExpChannelNumber.7 = Hex-STRING: 00 7A
IBM-OSA-MIB::ibmOSAExpChannelNumber.8 = Hex-STRING: 00 7D
```

The first line of the command output, with index number 6, corresponds to CHPID 0x6B of our `eth0` example. The example assumes that the community `osacom` has been authorized as described in “Configuring access control” on page 167.

If you have provided defaults for the SNMP version and the community (see step 12 on page 169), you can omit the `-v` and `-c` options:

```
# snmpwalk -OS localhost .1.3.6.1.4.1.2.6.188.1.1.1.1
IBM-OSA-MIB::ibmOSAExpChannelNumber.6 = Hex-STRING: 00 6B
IBM-OSA-MIB::ibmOSAExpChannelNumber.7 = Hex-STRING: 00 7A
IBM-OSA-MIB::ibmOSAExpChannelNumber.8 = Hex-STRING: 00 7D
```

You can obtain the same output by substituting the numeric OID `.1.3.6.1.4.1.2.6.188.1.1.1.1` with its textual equivalent:

.iso.org.dod.internet.private.enterprises.ibm.ibmProd.ibmOSAMib.ibmOSAMibObjects.ibmOSAExpChannelTable.ibmOSAExpChannelEntry.ibmOSAExpChannelNumber

You can shorten this somewhat unwieldy OID to the last element, `ibmOsaExpChannelNumber`:

```
# snmpwalk -OS localhost ibmOsaExpChannelNumber
IBM-OSA-MIB::ibmOSAExpChannelNumber.6 = Hex-STRING: 00 6B
IBM-OSA-MIB::ibmOSAExpChannelNumber.7 = Hex-STRING: 00 7A
IBM-OSA-MIB::ibmOSAExpChannelNumber.8 = Hex-STRING: 00 7D
```

- To find the port type for the interface with index number 6:

```
# snmpwalk -OS localhost .1.3.6.1.4.1.2.6.188.1.4.1.2.6
IBM-OSA-MIB::ibmOsaExpEthPortType.6 = INTEGER: fastEthernet(81)
```

`fastEthernet(81)` corresponds to card type `OSD_100`.

Using the short form of the textual OID:

```
# snmpwalk -OS localhost ibmOsaExpEthPortType.6
IBM-OSA-MIB::ibmOsaExpEthPortType.6 = INTEGER: fastEthernet(81)
```

Specifying the index, 6 in the example, limits the output to the interface of interest.

Stopping osasnmppd

The subagent can be stopped by sending either a SIGINT or SIGTERM signal to the thread.

Avoid stopping the subagent with **kill -9** or with **kill -SIGKILL**. These commands do not allow the subagent to unregister the OSA-Express MIB objects from the SNMP master agent. This can cause problems when restarting the subagent.

If you have saved the subagent PID to a file when you started it, you can consult this file for the PID. Otherwise you can issue a **ps** command to find it out.

Example: The osasnmppd subagent starts a daemon called osasnmppd. To stop osasnmppd, issue the kill command for either the daemon or its PID:

```
# ps -ef | grep snmp
USER      PID      1  0 11:57 pts/1    00:00:00 snmpd
root      729    659  0 13:22 pts/1    00:00:00 osasnmppd
# killall osasnmppd
```

Chapter 10. LAN channel station device driver

The LAN channel station device driver (LCS device driver) supports Open Systems Adapters (OSA) features in non-QDIO mode.

Table 34 shows the supported OSA-Express features.

Table 34. The LCS device driver supported OSA features

Feature	z196, z114, and System z10	System z9
OSA-Express3	1000Base-T Ethernet	Not supported
OSA-Express2	1000Base-T Ethernet	1000Base-T Ethernet
OSA-Express	Not supported	Fast Ethernet 1000Base-T Ethernet

The LCS device driver supports automatic detection of Ethernet connections. The LCS device driver can be used for Internet Protocol, version 4 (IPv4) only.

What you should know about LCS

Interface names are assigned to LCS group devices, which map to subchannels and their corresponding device numbers and device bus-IDs.

LCS group devices

The LCS device driver requires two I/O subchannels for each LCS interface, a read subchannel and a write subchannel. The corresponding bus IDs must be configured for control unit type 3088.




Figure 31. I/O subchannel interface

The device bus-IDs that correspond to the subchannel pair are grouped as one LCS group device. The following rules apply for the device bus-IDs:

read must be even.

write must be the device bus-ID of the read subchannel plus one.

LCS interface names

When an LCS group device is set online, the LCS device driver automatically assigns an Ethernet interface name to it.

The naming scheme uses the base name `eth<n>`, where `<n>` is an integer that uniquely identifies the device. For example, the interface name of the first Ethernet feature that is set online is “eth0”, the second “eth1”, and so on.

The LCS device driver shares the name space for Ethernet interfaces with the qeth device driver. Each driver uses the name with the lowest free identifier `<n>`, regardless of which device driver occupies the other names. For example, if at the time the first LCS Ethernet feature is set online, there is already one qeth Ethernet feature online, the qeth feature is named “eth0” and the LCS feature is named “eth1”. See also “qeth interface names and device directories” on page 115.

Setting up the LCS device driver

There are no module parameters for the LCS device driver.

You need to load the `lcs` module before you can work with LCS devices. Load the `lcs` module with the `modprobe` command to ensure that any other required modules are loaded in the correct order:

```
# modprobe lcs
```

Working with LCS devices

Typical tasks that you need to perform when working with LCS devices include creating an LCS group device, specifying a timeout, or activating an interface.

This section describes typical tasks that you need to perform when working with LCS devices.

- Creating an LCS group device
- Removing an LCS group device
- Specifying a timeout for LCS LAN commands
- Setting an LCS group device online or offline
- Activating and deactivating an interface
- Recovering a device

Most of these tasks involve writing to and reading from device attributes in `sysfs`. This is useful on a running system where you want to make dynamic changes. If you want to make the changes persistent across IPLs, use the interface configuration files. Network configuration parameters are defined in `/etc/sysconfig/network-scripts/ifcfg-<if_name>`. An example of how to define an LCS device persistently is in *Red Hat Enterprise Linux 6.3 Installation Guide*. For a general discussion of network configuration files, see *Red Hat Enterprise Linux 6.3 Deployment Guide*.

Creating an LCS group device

Use the group attribute to create an LCS group device.

Before you begin: You need to know the device bus-IDs that correspond to the read and write subchannel of your OSA card as defined in the IOCDs of your mainframe.

To define an LCS group device, write the device bus-IDs of the subchannel pair to `/sys/bus/ccwgroup/drivers/lcs/group`. Issue a command of this form:

```
# echo <read_device_bus_id>,<write_device_bus_id> > /sys/bus/ccwgroup/drivers/lcs/group
```

Result: The lcs device driver uses the device bus-ID of the read subchannel to create a directory for a group device:

```
/sys/bus/ccwgroup/drivers/lcs/<read_device_bus_id>
```

This directory contains a number of attributes that determine the settings of the LCS group device. The following sections describe how to use these attributes to configure an LCS group device.

Example:

Assuming that 0.0.d000 is the device bus-ID that corresponds to a read subchannel:

```
# echo 0.0.d000,0.0.d001 > /sys/bus/ccwgroup/drivers/lcs/group
```

This command results in the creation of the following directories in sysfs:

- /sys/bus/ccwgroup/drivers/lcs/0.0.d000
- /sys/bus/ccwgroup/devices/0.0.d000
- /sys/devices/lcs/0.0.d000

Note: When the device subchannels are added, device types 3088/08 and 3088/1f can be assigned to either the CTCM or the LCS device driver.

To check which devices have been assigned to which device driver, issue the following commands:

```
# ls -l /sys/bus/ccw/drivers/ctcm  
# ls -l /sys/bus/ccw/drivers/lcs
```

To change a faulty assignment, use the unbind and bind attributes of the device. For example, to change the assignment for device bus-IDs 0.0.2000 and 0.0.2001 issue the following commands:

```
# echo 0.0.2000 > /sys/bus/ccw/drivers/ctcm/unbind  
# echo 0.0.2000 > /sys/bus/ccw/drivers/lcs/bind  
# echo 0.0.2001 > /sys/bus/ccw/drivers/ctcm/unbind  
# echo 0.0.2001 > /sys/bus/ccw/drivers/lcs/bind
```

Removing an LCS group device

Use the ungroup attribute to remove an LCS group device.

Before you begin: The device must be set offline before you can remove it.

To remove an LCS group device, write "1" to the ungroup attribute. Issue a command of the form:

```
echo 1 > /sys/bus/ccwgroup/drivers/lcs/<device_bus_id>/ungroup
```

Example:

This command removes device 0.0.d000:

```
echo 1 > /sys/bus/ccwgroup/drivers/lcs/0.0.d000/ungroup
```

Specifying a timeout for LCS LAN commands

Use the `lancmd_timeout` attribute to set a timeout an LCS LAN command.

You can specify a timeout for the interval that the LCS device driver waits for a reply after issuing a LAN command to the LAN adapter. For older hardware the replies may take a longer time. The default is 5 s.

To set a timeout issue a command of this form:

```
# echo <timeout> > /sys/bus/ccwgroup/drivers/lcs/<device_bus_id>/lancmd_timeout
```

where `<timeout>` is the timeout interval in seconds in the range from 1 to 60.

Example:

In this example, the timeout for a device 0.0.d000 is set to 10 s.

```
# echo 10 > /sys/bus/ccwgroup/drivers/lcs/0.0.d000/lancmd_timeout
```

Setting an LCS group device online or offline

Use the `online` device group attribute to set an LCS device online or offline.

To set an LCS group device online, set the `online` device group attribute to “1”. To set a LCS group device offline, set the `online` device group attribute to “0”. Issue a command of this form:

```
# echo <flag> > /sys/bus/ccwgroup/drivers/lcs/<device_bus_id>/online
```

Setting a device online associates it with an interface name. Setting the device offline preserves the interface name.

Read `/var/log/messages` or issue **dmesg** to find out which interface name has been assigned. You will need to know the interface name to activate the network interface.

For each online interface, there is a symbolic link of the form `/sys/class/net/<interface_name>/device` in `sysfs`. You can confirm that you have found the correct interface name by reading the link.

Example:

To set an LCS device with bus ID 0.0.d000 online issue:

```
# echo 1 > /sys/bus/ccwgroup/drivers/lcs/0.0.d000/online
# dmesg
...
lcs: LCS device eth0 without IPv6 support
lcs: LCS device eth0 with Multicast support
...
```


The interface name that has been assigned to the LCS group device in the example is `eth0`. To confirm that this is the correct name for our group device issue:

```
# readlink /sys/class/net/eth0/device
../../../../devices/lcs/0.0.d000
```

To set the device offline issue:

```
# echo 0 > /sys/bus/ccwgroup/drivers/lcs/0.0.d000/online
```

Activating and deactivating an interface

Use the **ip** command or equivalent to activate or deactivate an interface.

Before you can activate an interface you need to have set the group device online and found out the interface name assigned by the LCS device driver (see “Setting an LCS group device online or offline” on page 176).

You activate or deactivate network devices with **ip** or an equivalent command. For details of the **ip** command see the **ip** man page.

Examples:

- This example activates an Ethernet interface:

```
# ip addr add 192.168.100.10/24 dev eth0
# ip link set dev eth0 up
```

- This example deactivates the Ethernet interface:

```
# ip link set dev eth0 down
```

- This example reactivates an interface that had already been activated and subsequently deactivated:

```
# ip link set dev eth0 up
```

Recovering a device

You can use the `recover` attribute of an LCS group device to recover it in case of failure.

For example, error messages in `/var/log/messages` might inform you of a malfunctioning device. Issue a command of the form:

```
# echo 1 > /sys/bus/ccwgroup/drivers/lcs/<device_bus_id>/recover
```

Example:

```
# echo 1 > /sys/bus/ccwgroup/drivers/lcs/0.0.d100/recover
```

Chapter 11. CTCM device driver

The CTCM device driver provides Channel-to-Channel (CTC) connections and CTC-based Multi-Path Channel (MPC) connections. The CTCM device driver is required by Communications Server for Linux.

CTC connections are high-speed point-to-point connections between two operating system instances on System z.

Communications Server for Linux uses MPC connections to connect Red Hat Enterprise Linux 6.3 to VTAM® on traditional mainframe operating systems.

Deprecated connection type

CTC connections are deprecated. Do not use for new network setups.

This does not apply to MPC connections to VTAM, which are not deprecated.

Features

The CTCM device driver provides different kinds of CTC connections between mainframes, z/VM guests, and LPARs.

The CTCM device driver provides:

- MPC connections to VTAM on traditional mainframe operating systems.
- ESCON or FICON CTC connections (standard CTC and basic CTC) between mainframes in basic mode, LPARs or z/VM guests.
For more information about FICON, see Redpaper *FICON CTC Implementation*, REDP-0158.
- Virtual CTCA connections between guests of the same z/VM system.
- CTC connections to other Linux instances or other mainframe operating systems.

What you should know about CTCM

The CTCM device driver assigns network interface names to CTCM group devices.

CTCM group devices

The CTCM device driver requires two I/O subchannels for each interface, a read subchannel and a write subchannel.

The CTCM device driver requires two I/O subchannels for each interface, a read subchannel and a write subchannel (see Figure 32 on page 180). The device bus-IDs that correspond to the two subchannels must be configured for control unit type 3088.




Figure 32. I/O subchannel interface

The device bus-IDs that correspond to the subchannel pair are grouped as one CTCM group device. There are no constraints on the device bus-IDs of read subchannel and write subchannel, in particular, it is possible to group non-consecutive device bus-IDs.

On the communication peer operating system instance, read and write subchannels are reversed. That is, the write subchannel of the local interface is connected to the read subchannel of the remote interface and vice versa.

Depending on the protocol, the interfaces can be CTC interfaces or MPC interfaces. MPC interfaces are used by Communications Server for Linux and connect to peer interfaces that run under VTAM. For more information about Communications Server for Linux and on using MPC connections, go to www.ibm.com/software/network/commserver/linux.

Interface names assigned by the CTCM device driver

When a CTCM group device is set online, the CTCM device driver automatically assigns an interface name to it. The interface name depends on the protocol.

If the protocol is set to 4, you get an MPC connection and the interface names are of the form `mpc<n>`.

If the protocol is set to 0, 1, or 3, you get a CTC connection and the interface name is of the form `ctc<n>`.

`<n>` is an integer that identifies the device. When the first device is set online it is assigned 0, the second is assigned 1, the third 2, and so on. The devices are counted separately for CTC and MPC.

Network connections

If your CTC connection is to a router or z/VM TCP/IP service machine, you can connect to an external network.

This section applies to CTC interfaces only.

Figure 33 on page 181 shows a CTC interface connected to a network.




Figure 33. Network connection

Setting up the CTCM device driver

There are no module parameters for the CTCM device driver. You need to load the `ctcm` module before using it.

Load it with the **modprobe** command to ensure that any other required modules are loaded:

```
# modprobe ctcm
```

Working with CTCM devices

Typical tasks that you need to perform when working with CTCM devices include creating an CTCM group device, setting the protocol, and activating an interface.

This section describes typical tasks that you need to perform when working with CTCM devices.

- Creating a CTCM group device
- Removing a CTCM group device
- Displaying the channel type
- Setting the protocol
- Setting a device online or offline
- Setting the maximum buffer size (CTC only)
- Activating and deactivating a CTC interface (CTC only)
- Recovering a lost CTC connection (CTC only)

See the Communications Server for Linux documentation for information about configuring and activating MPC interfaces.

Creating a CTCM group device

Use the `group` attribute to create a CTCM group device.

Before you begin: You need to know the device bus-IDs that correspond to the local read and write subchannel of your CTCM connection as defined in your IOCDs.

To define a CTCM group device, write the device bus-IDs of the subchannel pair to `/sys/bus/ccwgroup/drivers/ctcm/group`. Issue a command of this form:

```
# echo <read_device_bus_id>,<write_device_bus_id> > /sys/bus/ccwgroup/drivers/ctcm/group
```

Result: The CTCM device driver uses the device bus-ID of the read subchannel to create a directory for a group device:

```
/sys/bus/ccwgroup/drivers/ctcm/<read_device_bus_id>
```

This directory contains a number of attributes that determine the settings of the CTCM group device.

Example:

Assuming that device bus-ID 0.0.2000 corresponds to a read subchannel:

```
# echo 0.0.2000,0.0.2001 > /sys/bus/ccwgroup/drivers/ctcm/group
```

This command results in the creation of the following directories in sysfs:

- /sys/bus/ccwgroup/drivers/ctcm/0.0.2000
- /sys/bus/ccwgroup/devices/0.0.2000
- /sys/devices/ctcm/0.0.2000

Note: When the device subchannels are added, device types 3088/08 and 3088/1f can be assigned to either the CTCM or the LCS device driver.

To check which devices have been assigned to which device driver, issue the following commands:

```
# ls -l /sys/bus/ccw/drivers/ctcm
# ls -l /sys/bus/ccw/drivers/lcs
```

To change a faulty assignment, use the unbind and bind attributes of the device. For example, to change the assignment for device bus-IDs 0.0.2000 and 0.0.2001 issue the following commands:

```
# echo 0.0.2000 > /sys/bus/ccw/drivers/lcs/unbind
# echo 0.0.2000 > /sys/bus/ccw/drivers/ctcm/bind
# echo 0.0.2001 > /sys/bus/ccw/drivers/lcs/unbind
# echo 0.0.2001 > /sys/bus/ccw/drivers/ctcm/bind
```

Removing a CTCM group device

Use the ungroup attribute to remove a CTCM group device.

Before you begin: The device must be set offline before you can remove it.

To remove a CTCM group device, write "1" to the ungroup attribute. Issue a command of the form:

```
# echo 1 > /sys/bus/ccwgroup/drivers/ctcm/<device_bus_id>/ungroup
```

Example:

This command removes device 0.0.2000:

```
echo 1 > /sys/bus/ccwgroup/drivers/ctcm/0.0.2000/ungroup
```

Displaying the channel type

Use the `type` attribute to display the channel type of a CTCM group device.

Issue a command of this form to display the channel type of a CTCM group device:

```
# cat /sys/bus/ccwgroup/drivers/ctcm/<device_bus_id>/type
```

where `<device_bus_id>` is the device bus-ID that corresponds to the CTCM read channel. Possible values are: CTC/A, ESCON, and FICON.

Example:

In this example, the channel type is displayed for a CTCM group device with device bus-ID 0.0.f000:

```
# cat /sys/bus/ccwgroup/drivers/ctcm/0.0.f000/type
ESCON
```

Setting the protocol

Use the `protocol` attribute to set the protocol.

Before you begin: The device must be offline while you set the protocol.

The type of interface depends on the protocol. Protocol 4 results in MPC interfaces with interface names `mpc<n>`. Protocols 0, 1, or 3 result in CTC interfaces with interface names of the form `ctc<n>`.

To choose a protocol set the `protocol` attribute to one of the following values:

- 0 This protocol provides compatibility with peers other than OS/390®, or z/OS, for example, a z/VM TCP service machine. This is the default.
- 1 This protocol provides enhanced package checking for Linux peers.
- 3 This protocol provides for compatibility with OS/390 or z/OS peers.
- 4 This protocol provides for MPC connections to VTAM on traditional mainframe operating systems.

Issue a command of this form:

```
# echo <value> > /sys/bus/ccwgroup/drivers/ctcm/<device_bus_id>/protocol
```

Example:

In this example, the protocol is set for a CTCM group device 0.0.2000:

```
# echo 4 > /sys/bus/ccwgroup/drivers/ctcm/0.0.2000/protocol
```

Setting a device online or offline

Use the `online` device group attribute to set a CTCM device online or offline.

To set a CTCM group device online, set the online device group attribute to “1”. To set a CTCM group device offline, set the online device group attribute to “0”. Issue a command of this form:

```
# echo <flag> > /sys/bus/ccwgroup/drivers/ctcm/<device_bus_id>/online
```

Setting a group device online associates it with an interface name. Setting the group device offline and back online with the same protocol preserves the association with the interface name. If you change the protocol before setting the group device back online, the interface name can change as described in “Interface names assigned by the CTCM device driver” on page 180.

You will need to know the interface name to access the CTCM group device. To determine the assigned interface name use the **znetconf -c** command. For each online interface the interface name is shown in the Name column. Alternatively, to determine the assigned interface name issue a command of the form:

```
# ls /sys/devices/ctcm/<device_bus_id>/net/
```

For each online interface, there is a symbolic link of the form `/sys/class/net/<interface_name>/device` in `sysfs`. You can confirm that you have found the correct interface name by reading the link.

Example:

To set a CTCM device with bus ID 0.0.2000 online issue:

```
# echo 1 > /sys/bus/ccwgroup/drivers/ctcm/0.0.2000/online
```

To determine the interface name issue:

```
# znetconf -c
```

Device IDs	Type	Card Type	CHPID Drv. Name	State
0.0.2000,0.0.2001	3088/08	CTC/A	ctcm ctc0	online

or

```
# ls /sys/devices/ctcm/0.0.2000/net/
ctc0
```

The interface name that has been assigned to the CTCM group device in the example is `mpc0`. To confirm that this is the correct name for our group device issue:

```
# readlink /sys/class/net/mpc0/device
../../../../0.0.2000
```

To set group device 0.0.2000 offline issue:

```
# echo 0 > /sys/bus/ccwgroup/drivers/ctcm/0.0.2000/online
```


Setting the maximum buffer size

Use the buffer device group attribute to set a maximum buffer size for a CTCM group device.

Before you begin:

- This section applies to CTC interfaces only. MPC interfaces automatically use the highest possible maximum buffer size.
- The device must be online when setting the buffer size.

You can set the maximum buffer size for a CTC interface. The permissible range of values depends on the MTU settings. It must be in the range *<minimum MTU + header size>* to *<maximum MTU + header size>*. The header space is typically 8 byte. The default for the maximum buffer size is 32768 byte (32 KB).

Changing the buffer size is accompanied by an MTU size change to the value *<buffer size - header size>*.

To set the maximum buffer size issue a command of this form:

```
# echo <value> > /sys/bus/ccwgroup/drivers/ctcm/<device_bus_id>/buffer
```

where *<value>* is the number of bytes you want to set. If you specify a value outside the valid range, the command is ignored.

Example:

In this example, the maximum buffer size of a CTCM group device 0.0.f000 is set to 16384 byte.

```
# echo 16384 > /sys/bus/ccwgroup/drivers/ctcm/0.0.f000/buffer
```

Activating and deactivating a CTC interface

Use **ip** or an equivalent command to activate or deactivate an interface.

Before you begin activating a CTC interface:

- This section applies to CTC interfaces only. For information about how to activate MPC interfaces see the Communications Server for Linux documentation.
- You need to know the interface name (see “Setting a device online or offline” on page 183).

Use **ip** or an equivalent command to activate the interface:

Syntax for setting an IP address for a CTC interface with the ip command

```
➤ ip address add <ip_address> dev <interface>
└─ peer <peer_ip_address>
```

Syntax for activating a CTC interface with the ip command

```
➤ ip link set dev <interface> up
└─ mtu 32760
└─ mtu <max_transfer_unit>
```

Where:

<interface>

is the interface name that was assigned when the CTCM group device was set online.

<ip_address>

is the IP address you want to assign to the interface.

<peer_ip_address>

is the IP address of the remote side.

<max_transfer_unit>

is the size of the largest IP packet which may be transmitted. Be sure to use the same MTU size on both sides of the connection. The MTU must be in the range of 576 byte to 65,536 byte (64 KB).

To deactivate an interface issue a command of this form:

```
# ip link set dev <interface> down
```

Examples:

- This example activates a CTC interface `ctc0` with an IP address `10.0.51.3` for a peer with address `10.0.50.1` and an MTU of `32760`.

```
# ip addr add 10.0.51.3 dev ctc0 peer 10.0.50.1
# ip link set dev ctc0 up mtu 32760
```

- This example deactivates `ctc0`:

```
# ip link set dev ctc0 down
```

Recovering a lost CTC connection

If one side of a CTC connection crashes, you cannot simply reconnect after a reboot. You also need to deactivate the interface of the peer of the crashed side.

This section applies to CTC interfaces only.

Proceed like this to recover a lost CTC connection:

1. Reboot the crashed side.
2. Deactivate the interface on the peer (see “Activating and deactivating a CTC interface” on page 185).
3. Activate the interface on the crashed side and on the peer (see “Activating and deactivating a CTC interface” on page 185).

If the connection is between a Linux instance and a non-Linux instance, activate the interface on the Linux instance first. Otherwise you can activate the interfaces in any order.

If the CTC connection is uncoupled, you must couple it again and re-configure the interface of both peers using **ip** (see “Activating and deactivating a CTC interface” on page 185).

Scenarios

Typical use cases of CTC connections include connecting to a peer in a different LPAR and connecting Linux instances running as z/VM guests to each other.

This section provides some typical scenarios for CTC connections:

- Connecting to a peer in a different LPAR
- Connecting Linux on z/VM to another guest of the same z/VM system

Connecting to a peer in a different LPAR

A Linux instance and a peer run in LPAR mode on the same or on different mainframes and are to be connected with a CTC FICON or CTC ESCON network interface.

Assumptions:

- Locally, the read and write channels have been configured for type 3088 and use device bus-IDs 0.0.f008 and 0.0.f009.
- IP address 10.0.50.4 is to be used locally and 10.0.50.5 for the peer.

Figure 34 illustrates a CTC setup with a peer in a different LPAR.




Figure 34. CTC scenario with peer in a different LPAR

1. Create a CTCM group device. Issue:

```
# echo 0.0.f008,0.0.f009 > /sys/bus/ccwgroup/drivers/ctcm/group
```

2. Confirm that the device uses CTC FICON or CTC ESCON:

```
# cat /sys/bus/ccwgroup/drivers/ctcm/0.0.f008/type
ESCON
```

In this example, ESCON is used. You would proceed the same for FICON.

3. Select a protocol. The choice depends on the peer.

If the peer is ...	Choose ...
Linux	1
z/OS or OS/390	3
Any other operating system	0

Assuming that the peer is Linux:

```
# echo 1 > /sys/bus/ccwgroup/drivers/ctcm/0.0.f008/protocol
```

4. Set the CTCM group device online and find out the assigned interface name:

```
# echo 1 > /sys/bus/ccwgroup/drivers/ctcm/0.0.f008/online
# ls /sys/devices/ctcm/0.0.f008/net/
ctc0
```

In the example, the interface name is ctc0.

5. Assure that the peer interface is configured.
6. Activate the interface locally and on the peer. If you are connecting two Linux instances, either instance can be activated first. If the peer is not Linux, activate the interface on Linux first. To activate the local interface:

```
# ip addr add 10.0.50.4 dev ctc0 peer 10.0.50.5
# ip link set dev ctc0 up
```

Connecting Linux on z/VM to another guest of the same z/VM system

A virtual CTCA connection is to be set up between an instance of Linux on z/VM and another guest of the same z/VM system.

Assumptions:

- The guest ID of the peer is “guestp”.
- A separate subnet has been obtained from the TCP/IP network administrator. The Linux instance will use IP address 10.0.100.100 and the peer will use IP address 10.0.100.101.

Figure 35 on page 189 illustrates a CTC setup with a peer in the same z/VM.




Figure 35. CTC scenario with peer in the same z/VM

1. Define two virtual channels to your user ID. The channels can be defined in the z/VM user directory using directory control SPECIAL statements, for example:

```
special f004 ctca
special f005 ctca
```

Alternatively, you can use the CP commands:

```
define ctca as f004
define ctca as f005
```

2. Assure that the peer interface is configured.
3. Connect the virtual channels. Assuming that the read channel on the peer corresponds to device number 0xf010 and the write channel to 0xf011 issue:

```
couple f004 to guestp f011
couple f005 to guestp f010
```

Be sure that you couple the read channel to the peers write channel and vice versa.

4. From your booted Linux instance, create a CTCM group device. Issue:

```
# echo 0.0.f004,0.0.f005 > /sys/bus/ccwgroup/drivers/ctcm/group
```

5. Confirm that the group device is a virtual CTCA device:

```
# cat /sys/bus/ccwgroup/drivers/ctcm/0.0.f004/type
CTC/A
```

6. Select a protocol. The choice depends on the peer.

If the peer is ...	Choose ...
Linux	1
z/OS or OS/390	3
Any other operating system	0

Assuming that the peer is Linux:

```
# echo 1 > /sys/bus/ccwgroup/drivers/ctcm/0.0.f004/protocol
```

7. Set the CTCM group device online and find out the assigned interface name:

```
# echo 1 > /sys/bus/ccwgroup/drivers/ctcm/0.0.f004/online
# ls /sys/devices/ctcm/0.0.f004/net/
ctc1
```

In the example, the interface name is ctc1.

8. Activate the interface locally and on the peer. If you are connecting two Linux instances, either can be activated first. If the peer is not Linux, activate the local interface first. To activate the local interface:

```
# ip addr add 10.0.100.100 dev ctc1 peer 10.0.100.101
# ip link set dev ctc1 up
```

Be sure that the MTU on both sides of the connection is the same. If necessary change the default MTU (see “Activating and deactivating a CTC interface” on page 185).

9. Ensure that the buffer size on both sides of the connection is the same. For the Linux side see “Setting the maximum buffer size” on page 185. If the peer is not Linux, see the operating system documentation of the peer.

Part 4. z/VM virtual server integration

This part describes device drivers and features that help to effectively run and manage a z/VM-based virtual Linux server farm.

Newest version: You can find the newest version of this book at
www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

Restrictions: For prerequisites and restrictions see the System z architecture specific information in the Red Hat Enterprise Linux 6.3 release notes at
docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

Chapter 12. z/VM concepts	193	Changing the contents of a DCSS.	231
Performance monitoring for z/VM guest virtual machines	193	Chapter 19. Shared kernel support	233
Cooperative memory management background	195	What you should know about NSS	233
Chapter 13. Writing kernel APPLDATA records	197	Kernel parameter for creating an NSS	233
Setting up the APPLDATA record support.	197	Working with a Linux NSS.	233
Working with the APPLDATA record support	198	Chapter 20. Watchdog device driver	237
APPLDATA monitor record layout	199	Features	237
Programming interfaces	202	What you should know about the watchdog device driver	237
Chapter 14. Writing z/VM monitor records	203	Setting up the watchdog device driver	238
Features	203	External programming interfaces	239
Setting up the z/VM *MONITOR record writer device driver	203	Chapter 21. z/VM CP interface device driver	241
Working with the z/VM *MONITOR record writer	204	What you should know about the z/VM CP interface	241
Chapter 15. Reading z/VM monitor records	207	Setting up the z/VM CP interface	241
Features	207	Using the device node	242
What you should know about the z/VM *MONITOR record reader device driver	207	Chapter 22. Deliver z/VM CP special messages as uevents	243
Setting up the z/VM *MONITOR record reader device driver	207	Setting up the CP special message device driver	243
Working with the z/VM *MONITOR record reader	209	Working with CP special messages	244
Chapter 16. z/VM recording device driver	213	Chapter 23. AF_IUCV address family support	249
Features	213	Features	249
What you should know about the z/VM recording device driver	213	Setting up the AF_IUCV address family support	250
Setting up the z/VM recording device driver.	214	Addressing AF_IUCV sockets in applications.	251
Working with z/VM recording devices.	214	Chapter 24. Cooperative memory management	253
Scenario: Connecting to the *ACCOUNT service.	217	Setting up cooperative memory management.	253
Chapter 17. z/VM unit record device driver	221	Working with cooperative memory management	254
What you should know about the z/VM unit record device driver	221		
Working with z/VM unit record devices	221		
Chapter 18. z/VM DCSS device driver	223		
Features	223		
What you should know about DCSS.	223		
Setting up the DCSS device driver	224		
Avoiding overlaps with your guest storage	225		
Working with DCSS devices	226		

Chapter 12. z/VM concepts

This chapter contains information that is not strictly needed to run the functionality in question, however, it might help you understand some of the background.

Performance monitoring for z/VM guest virtual machines

You can monitor the performance of z/VM guest virtual machines and their guest operating systems with performance monitoring tools on z/VM or on Linux. These tools can be your own, IBM tools such as the Performance Toolkit for VM, or third party tools. The guests being monitored require agents that write monitor data.

Monitoring on z/VM

z/VM monitoring tools need to read performance data. For monitoring Linux instances, this data is APPLDATA monitor records. Linux instances need to write these records for the tool to read, as shown in Figure 36.




Figure 36. Linux instances write APPLDATA records for performance monitoring tools

Both user space applications and the Linux kernel can write performance data to APPLDATA records. Applications use the monwriter device driver to write APPLDATA records. The Linux kernel can be configured to collect system level data such as memory, CPU usage, and network related data, and write it to data records.

For file system size data there is a command, `mon_fsstatd`, a user space tool that uses the monwriter device driver to write file system size information as defined records.

For process data there is a command, `mon_procd`, a user space tool that uses the monwriter device driver to write system information as defined records.

In summary, Red Hat Enterprise Linux 6.3 for System z supports writing and collecting performance data as follows:

- The Linux kernel can write z/VM monitor data for Linux instances, see Chapter 13, “Writing kernel APPLDATA records,” on page 197.
- Linux applications running on z/VM guests can write z/VM monitor data, see Chapter 14, “Writing z/VM monitor records,” on page 203.
- You can collect monitor file system size information, see “mon_fsstatd – Monitor z/VM guest file system size” on page 478.
- You can collect system information about up to 100 concurrently running processes. see “mon_procd – Monitor Linux on z/VM” on page 483.

Monitoring on Linux

For performance monitoring on Linux, you can use a tool such as Tivoli® OMEGAMON®, or write your own software, and set up a Linux instance to read the monitor data as shown in Figure 37. A Linux instance can read the monitor data using the monreader device driver.




Figure 37. Performance monitoring using monitor DCSS data

In summary, Linux on System z supports reading performance data in the form of read access to z/VM monitor data for Linux instances. For more details, see Chapter 15, “Reading z/VM monitor records,” on page 207.

Further information

- See *z/VM Getting Started with Linux on System z*, SC24-6194, the chapter about monitoring performance for information about using the CP Monitor and the Performance Toolkit for VM.
- See *z/VM Saved Segments Planning and Administration*, SC24-6229 for general information about DCSSs (z/VM keeps monitor records in a DCSS).
- See *z/VM Performance*, SC24-6208 for information about creating a monitor DCSS.
- See *z/VM CP Commands and Utilities Reference*, SC24-6175 for information about the CP commands used in the context of DCSSs and for controlling the z/VM monitor system service.
- For the layout of the monitor records see Chapter 13, “Writing kernel APPLDATA records,” on page 197 and visit www.ibm.com/vm/pubs/ctlblk.html

For more information about performance monitoring on z/VM, visit

Cooperative memory management background

This section gives some background information about cooperative memory management (CMM, or "cmm1"). For information about setting it up, see Chapter 24, "Cooperative memory management," on page 253.

In a virtualized environment it is common practice to give the virtual machines more memory than is actually available to the hypervisor. Linux has the tendency to use all of its available memory. As a result, the hypervisor (z/VM) might start swapping.

To avoid excessive z/VM swapping, the memory available to Linux can be reduced. CMM allocates pages to page pools that make the pages unusable to Linux. There are two such page pools as shown in Figure 38.




Figure 38. Page pools

The two page pools are:

A static page pool

The page pool is controlled by a resource manager that changes the pool size at intervals according to guest activity as well as overall memory usage on z/VM (see Figure 39).




Figure 39. Static page pool. The size of the pool is static for the duration of an interval.

A timed page pool

Pages are released from this pool at a speed set in the *release rate* (see Figure 40 on page 196). According to guest activity and overall memory usage on z/VM, a resource manager adds pages at intervals. If no pages are added and the release rate is not zero, the pool will empty.




Figure 40. Timed page pool. Pages are freed at a set release rate.

The external resource manager that controls the pools can be the z/VM resource monitor (VMRM) or a third party systems management tool.

VMRM controls the pools over a message interface. Setting up the external resource manager is beyond the scope of this book. For more information, see the chapter on VMRM in *z/VM Performance*, SC24-6109.

Third party tools can use a Linux daemon that receives commands for the memory allocation through TCP/IP. The daemon, in turn, uses the a /proc-based interface. You can use the /proc interface to read the pool sizes. This is useful for diagnostics.

Chapter 13. Writing kernel APPLDATA records

z/VM is a convenient point for collecting z/VM guest performance data and statistics for an entire server farm. Linux instances can export such data to z/VM by means of APPLDATA monitor records. z/VM regularly collects these records. The records are then available to z/VM performance monitoring tools.

A virtual CPU timer on the Linux instance to be monitored controls when data is collected. The timer only accounts for busy time to avoid unnecessarily waking up an idle guest. The APPLDATA record support comprises several modules. A base module provides an intra-kernel interface and the timer function. The intra-kernel interface is used by *data gathering modules* that collect actual data and determine the layout of a corresponding APPLDATA monitor record (see “APPLDATA monitor record layout” on page 199).

For an overview of performance monitoring support, see “Performance monitoring for z/VM guest virtual machines” on page 193.


Setting up the APPLDATA record support

There are no module parameters for the monitor stream support. This section describes how to load those components of the support that have been compiled as separate modules and how to set up your z/VM guest for the APPLDATA record support.

Loading data gathering modules

The data gathering components have been compiled as separate modules. Use the **modprobe** command to load any required modules. See the **modprobe** man page for command details.

APPLDATA record support module parameter syntax



where `appldata_mem`, `appldata_os`, and `appldata_net_sum` are the modules for gathering memory related data, operating system related data, and network related data.

Enabling your z/VM guest for data gathering

To enable your Linux instance for data gathering ensure that the user directory of the guest virtual machine includes the option `APPLMON`.

Working with the APPLDATA record support

You control the monitor stream support through the procfs. You can set the timer interval and switch on or off data collection. APPLDATA monitor records are produced if both a particular data gathering module and the monitoring support in general are switched on.

Switching the support on or off

You switch on or off the monitoring support by writing “1” (on) or “0” (off) to `/proc/sys/appldata/timer`.

To read the current setting issue:

```
# cat /proc/sys/appldata/timer
```

To switch on the monitoring support issue:

```
# echo 1 > /proc/sys/appldata/timer
```

To switch off the monitoring support issue:

```
# echo 0 > /proc/sys/appldata/timer
```

Activating or deactivating individual data gathering modules

You can activate or deactivate the data gathering modules individually. Each data gathering module has a procfs entry that contains a value “1” if the module is active and “0” if the module is inactive. The entries are:

`/proc/sys/appldata/mem` for the memory data gathering module

`/proc/sys/appldata/os` for the CPU data gathering module

`/proc/sys/appldata/net_sum` for the net data gathering module

To check if a module is active look at the content of the corresponding procfs entry.

To activate a data gathering module write “1” to the corresponding procfs entry. To deactivate a data gathering module write “0” to the corresponding procfs entry.

Issue a command of this form:

```
# echo <flag> > /proc/sys/appldata/<data_type>
```

where `<data_type>` is one of `mem`, `os`, or `net_sum`.

Note: An active data gathering module produces APPLDATA monitor records only if the monitoring support is switched on (see “Switching the support on or off”).

Example

To find out if memory data gathering is active issue:

```
# cat /proc/sys/appldata/mem
0
```

In the example, memory data gathering is off. To activate memory data gathering issue:

```
# echo 1 > /proc/sys/appldata/mem
```

To deactivate the memory data gathering module issue:

```
# echo 0 > /proc/sys/appldata/mem
```

Setting the sampling interval

You can set the time that lapses between consecutive data samples. The time you set is measured by the virtual CPU timer. Because the virtual timer slows down as the guest idles, the time sampling interval in real time can be considerably longer than the value you set.

The value in `/proc/sys/appldata/interval` is the sample interval in milliseconds. The default sample interval is 10 000 ms. To read the current value issue:

```
# cat /proc/sys/appldata/interval
```

To set the sample interval to a different value write the new value (in milliseconds) to `/proc/sys/appldata/interval`. Issue a command of this form:

```
# echo <interval> > /proc/sys/appldata/interval
```

where *<interval>* is the new sample interval in milliseconds. Valid input must be greater than 0 and less than $2^{31} - 1$. Input values greater than $2^{31} - 1$ produce unpredictable results.

Example

To set the sampling interval to 20 s (20000 ms) issue:

```
# echo 20000 > /proc/sys/appldata/interval
```

APPLDATA monitor record layout

This section describes the layout of the APPLDATA monitor records that can be provided to z/VM. Each of the modules that can be installed with the base module corresponds to a type of record:

- Memory data (see Table 35 on page 200)
- Processor data (see Table 36 on page 201)
- Networking (see Table 37 on page 202)

z/VM can identify the records by their unique product ID. The product ID is an EBCDIC string of this form: "LINUXKRNL<record ID>260100". The *<record ID>* is treated as a byte value, not a string.

The records contain data of the following types:

- u32** unsigned 4 byte integer
- u64** unsigned 8 byte integer

Table 35. APPLDATA_MEM_DATA record (Record ID 0x01)

Offset (Decimal)	Offset (Hex)	Type	Name	Description
0	0x0	u64	timestamp	TOD timestamp generated on the Linux side after record update
8	0x8	u32	sync_count_1	After z/VM collected the record data, sync_count_1 and sync_count_2 should be the same. Otherwise, the record has been updated on the Linux side while z/VM was collecting the data. As a result, the data might be inconsistent.
12	0xC	u32	sync_count_2	
16	0x10	u64	pgpgin	Data read from disk (in KB)
24	0x18	u64	pgpgout	Data written to disk (in KB)
32	0x20	u64	pswpin	Pages swapped in
40	0x28	u64	pswpout	Pages swapped out
48	0x30	u64	sharedram	Shared RAM in KB, set to 0
56	0x38	u64	totalram	Total usable main memory size in KB
64	0x40	u64	freeram	Available memory size in KB
72	0x48	u64	totalhigh	Total high memory size in KB
80	0x50	u64	freehigh	Available high memory size in KB
88	0x58	u64	bufferram	Memory reserved for buffers, free cache in KB
96	0x60	u64	cached	Size of used cache, without buffers in KB
104	0x68	u64	totalswap	Total swap space size in KB
112	0x70	u64	freeswap	Free swap space in KB
120	0x78	u64	pgalloc	Page allocations
128	0x80	u64	pgfault	Page faults (major+minor)
136	0x88	u64	pgmajfault	Page faults (major only)

Table 36. APPLDATA_OS_DATA record (Record ID 0x02)

Offset (Decimal)	Offset (Hex)	Type (size)	Name	Description
0	0x0	u64	timestamp	TOD timestamp generated on the Linux side after record update.
8	0x8	u32	sync_count_1	After z/VM collected the record data, sync_count_1 and sync_count_2 should be the same. Otherwise, the record has been updated on the Linux side while z/VM was collecting the data. As a result, the data might be inconsistent.
12	0xC	u32	sync_count_2	See sync_count_1.
16	0x10	u32	nr_cpus	Number of virtual CPUs.
20	0x14	u32	per_cpu_size	Size of the per_cpu_data for each CPU (= 36).
24	0x18	u32	cpu_offset	Offset of the first per_cpu_data (= 52).
28	0x1C	u32	nr_running	Number of runnable threads.
32	0x20	u32	nr_threads	Number of threads.
36	0x24	3 × u32	avenrun[3]	Average number of running processes during the last 1 (1st value), 5 (2nd value) and 15 (3rd value) minutes. These values are "fake fix-point", each composed of 10 bits integer and 11 bits fractional part. See note 1 at the end of this table.
48	0x30	u32	nr_iowait	Number of blocked threads (waiting for I/O).
52	0x34	See note 2.	per_cpu_data	Time spent in user, kernel, idle, nice, etc for every CPU. See note 3 at the end of this table.
52	0x34	u32	per_cpu_user	Timer ticks spent in user mode.
56	0x38	u32	per_cpu_nice	Timer ticks spent with modified priority.
60	0x3C	u32	per_cpu_system	Timer ticks spent in kernel mode.
64	0x40	u32	per_cpu_idle	Timer ticks spent in idle mode.
68	0x44	u32	per_cpu_irq	Timer ticks spent in interrupts.
72	0x48	u32	per_cpu_softirq	Timer ticks spent in softirqs.
76	0x4C	u32	per_cpu_iowait	Timer ticks spent while waiting for I/O.
80	0x50	u32	per_cpu_steal	Timer ticks "stolen" by hypervisor.
84	0x54	u32	cpu_id	The number of this CPU.

Notes:

1. The following C-Macros are used inside Linux to transform these into values with two decimal places:

```
#define LOAD_INT(x) ((x) >> 11)
#define LOAD_FRAC(x) LOAD_INT(((x) & ((1 << 11) - 1)) * 100)
```
2. nr_cpus * per_cpu_size
3. per_cpu_user through cpu_id are repeated for each CPU

Table 37. APPLDATA_NET_SUM_DATA record (Record ID 0x03)

Offset (Decimal)	Offset (Hex)	Type	Name	Description
0	0x0	u64	timestamp	TOD timestamp generated on the Linux side after record update
8	0x8	u32	sync_count_1	After z/VM collected the record data, sync_count_1 and sync_count_2 should be the same. Otherwise, the record has been updated on the Linux side while z/VM was collecting the data. As a result, the data might be inconsistent.
12	0xC	u32	sync_count_2	See sync_count_1.
16	0x10	u32	nr_interfaces	Number of interfaces being monitored
20	0x14	u32	padding	Unused. The next value is 64-bit aligned, so these 4 byte would be padded out by compiler
24	0x18	u64	rx_packets	Total packets received
32	0x20	u64	tx_packets	Total packets transmitted
40	0x28	u64	rx_bytes	Total bytes received
48	0x30	u64	tx_bytes	Total bytes transmitted
56	0x38	u64	rx_errors	Number of bad packets received
64	0x40	u64	tx_errors	Number of packet transmit problems
72	0x48	u64	rx_dropped	Number of incoming packets dropped because of insufficient space in Linux buffers
80	0x50	u64	tx_dropped	Number of outgoing packets dropped because of insufficient space in Linux buffers
88	0x58	u64	collisions	Number of collisions while transmitting

Programming interfaces



This section provides information for those who want to program against the monitor stream.

The monitor stream support base module exports two functions:

- `appldata_register_ops()` to register data gathering modules
- `appldata_unregister_ops()` to undo the registration of data gathering modules

Both functions receive a pointer to a struct `appldata_ops` as parameter. Additional data gathering modules that want to plug into the base module must provide this data structure. You can find the definition of the structure and the functions in `arch/s390/appldata/appldata.h` in the Linux source tree.

See “APPLDATA monitor record layout” on page 199 for an example of APPLDATA data records that are to be sent to z/VM.

Tip: include the `timestamp`, `sync_count_1`, and `sync_count_2` fields at the beginning of the record as shown for the existing APPLDATA record formats.

Chapter 14. Writing z/VM monitor records

Applications can easily write monitor data in the form of APPLDATA records to the z/VM *MONITOR stream by using the monitor stream application device driver. This character device enables writing of z/VM *MONITOR APPLDATA records.

For an overview of performance monitoring support, see “Performance monitoring for z/VM guest virtual machines” on page 193.

The monitor stream application device driver interacts with the z/VM monitor APPLDATA facilities for performance monitoring. A better understanding of these z/VM facilities might help when using this device driver. See *z/VM Performance*, SC24-6208 for information about monitor APPLDATA.

Features

The monitor stream application device driver provides the following functions:

- An interface to the z/VM monitor stream.
- A means of writing z/VM monitor APPLDATA records.


Setting up the z/VM *MONITOR record writer device driver

This section describes the parameters that you can use to configure the monitor stream write support.

Module parameters

The monitor stream application device driver is compiled as a separate module that you need to load before you can work with it. This section describes how to load and configure the monwriter module.

Monitor stream application device driver module parameter syntax



where *NUMBUFS* is the maximum number of monitor sample and configuration data buffers that can exist in the Linux guest at one time. The default is 255.

Example

To load the monwriter module and set the maximum number of buffers to NUMBUFS, use the following command:

```
# modprobe monwriter max_bufs=NUMBUFS
```

Setting up the z/VM guest virtual machine

Set these options in the z/VM user directory entry of the virtual machine in which the application using this device driver will run:

- OPTION APPLMON

Issue the following CP commands in order to have CP collect the respective types of monitor data:

- MONITOR SAMPLE ENABLE APPLDATA ALL
- MONITOR EVENT ENABLE APPLDATA ALL

You can either log in to the z/VM console in order to issue the CP commands (in which case the commands would have to be preceded by #CP), or use the **vmcp** command for issuing CP commands from your Linux instance.

See *z/VM CP Commands and Utilities Reference*, SC24-6175 for information about the CP MONITOR command.

Working with the z/VM *MONITOR record writer

This device driver writes to the z/VM monitor stream through the z/VM CP instruction DIAG X'DC'. See *z/VM CP Programming Services*, SC24-6179 for more information about the DIAG X'DC' instruction and the different monitor record types (sample, config, event).

The application writes monitor data by passing a `monwrite_hdr` followed by monitor data (except in the case of the STOP function, which requires no monitor data). The `monwrite_hdr`, as described in `monwriter.h`, is filled in by the application and includes the DIAG X'DC' function to be performed, the product identifier, the header length, and the data length.

All records written to the z/VM monitor stream begin with a product identifier. This device driver uses the product ID. The product ID is a 16-byte structure of the form `ppppppppffnvvrrmm`, where:

PPPPPPP

is a fixed ASCII string, for example, LNXAPPL.

ff

is the application number (hexadecimal number). This number can be chosen by the application, but to reduce the possibility of conflicts with other applications, a request for an application number should be submitted to the IBM z/VM Performance team at

www.ibm.com/vm/perf

n

is the record number as specified by the application

vv, rr, and mm

can also be specified by the application. A possible use could be for specifying version, release, and modification level information, allowing changes to a certain record number when the layout has been changed, without changing the record number itself.

The first seven bytes of the structure (LNXAPPL) are filled in by the device driver when it writes the monitor data record to the CP buffer. The last nine bytes contain information that is supplied by the application on the `write()` call when writing the data.

The `monwrite_hdr` structure that must be written before any monitor record data is defined as follows:

```
/* the header the app uses in its write() data */
struct monwrite_hdr {
    unsigned char mon_function;
    unsigned short applid;
    unsigned char record_num;
    unsigned short version;
    unsigned short release;
    unsigned short mod_level;
    unsigned short datalen;
    unsigned char hdrlen;
}__attribute__((packed));
```

The following function code values are defined:

```
/* mon_function values */
#define MONWRITE_START_INTERVAL 0x00 /* start interval recording */
#define MONWRITE_STOP_INTERVAL 0x01 /* stop interval or config recording */
#define MONWRITE_GEN_EVENT 0x02 /* generate event record */
#define MONWRITE_START_CONFIG 0x03 /* start configuration recording */
```

Writing data

Before an application can write monitor records it must issue `open()` to open the device driver. Then the application must issue `write()` calls to start or stop the collection of monitor data and to write any monitor records to buffers that CP can access.

Using the `monwrite_hdr` structure

The structure `monwrite_hdr` is used to pass DIAG x'DC' functions and the application-defined product information to the device driver on `write()` calls. When the application calls `write()`, the data it is writing consists of one or more `monwrite_hdr` structures, each followed by monitor data (except if it is a STOP function, which is followed by no data).

The application can write to one or more monitor buffers. A new buffer is created by the device driver for each record with a unique product identifier. To write new data to an existing buffer, an identical `monwrite_hdr` should precede the new data on the `write()` call.

The `monwrite_hdr` also includes fields for the header length (useful for calculating the data offset from the beginning of the `hdr`) and the data length (length of the following monitor data, if any.) See `/usr/include/asm/monwriter.h` for the definition of `monwrite_hdr`.

Stopping data writing

When the application has finished writing monitor data, it needs to issue `close()` to close the device driver.

Chapter 15. Reading z/VM monitor records

Monitoring software on Linux can access z/VM guest data through the z/VM *MONITOR record reader device driver.

z/VM uses the z/VM monitor system service (*MONITOR) to collect monitor records from agents on its guests. z/VM writes the records to a discontinuous saved segment (DCSS). See *z/VM Saved Segments Planning and Administration*, SC24-6229 for general information about DCSSs.

The z/VM *MONITOR record reader device driver uses IUCV to connect to *MONITOR and accesses the DCSS as a character device.

For an overview of performance monitoring support, see “Performance monitoring for z/VM guest virtual machines” on page 193.

Features

The z/VM *MONITOR record reader device driver supports the following devices and functions:

- Read access to the z/VM *MONITOR DCSS.
- Reading *MONITOR records for z/VM.
- Access to *MONITOR records as described on www.ibm.com/vm/pubs/ct1blk.html
- Access to the records provided by the Linux monitor stream (see Chapter 13, “Writing kernel APPLDATA records,” on page 197).

What you should know about the z/VM *MONITOR record reader device driver

The data that is collected by *MONITOR depends on how you have set up the service. The z/VM *MONITOR record reader device driver only reads data from the monitor DCSS; it does not control the system service.

z/VM only supports a single monitor DCSS. All monitoring software that requires monitor records from z/VM uses the same DCSS to read *MONITOR data. Usually, a DCSS called "MONDCSS" is already defined and used by existing monitoring software. If this is the case, you must also use MONDCSS. See “Assuring that the DCSS is addressable for your Linux instance” on page 208 for information about checking whether MONDCSS exists.

Setting up the z/VM *MONITOR record reader device driver

This section describes how to set up a Linux instance for accessing an existing monitor DCSS with the z/VM *MONITOR record reader device driver.

Setting up the monitor system service and the monitor DCSS on z/VM is beyond the scope of this book. See *z/VM Performance*, SC24-6208 for information about creating a monitor DCSS.

Before you begin: Some of the CP commands you need to use for setting up the z/VM *MONITOR record reader device driver require class E authorization.

Providing the required user directory entries for your z/VM guest

The z/VM guest where your Linux instance is to run must be permitted to establish an IUCV connection to the z/VM *MONITOR system service. Ensure that the guest entry in the user directory includes the statement:

```
IUCV *MONITOR
```

If the DCSS is restricted, you also need the statement:

```
NAMESAVE <dcss>
```

where <dcss> is the name of the DCSS that is used for the monitor records. You can find out the name of an existing monitor DCSS by issuing the following CP command from a z/VM guest virtual machine with privilege class E:

```
q monitor
```

See *z/VM CP Commands and Utilities Reference*, SC24-6175 for information about the CP commands used in the context of DCSSs and for controlling the z/VM monitor system service.

Assuring that the DCSS is addressable for your Linux instance

The DCSS address range must not overlap with the storage of your z/VM guest virtual machine. To find out the start and end address of the DCSS, issue the following CP command from a z/VM guest virtual machine with privilege class E:

```
q nss map
```

the output gives you the start and end addresses of all defined DCSSs in units of 4 kilobyte pages:

```
00: FILE FILENAME FILETYPE MINSIZE BEGPAG ENDPAG TYPE CL #USERS PARMREGS VMGROUP
...
00: 0011 MONDCSS CPDCSS N/A 09000 097FF SC R 00003 N/A N/A
...
```

If the DCSS overlaps with the guest storage follow the procedure in “Avoiding overlaps with your guest storage” on page 225.

Specifying the monitor DCSS name


By default, the z/VM *MONITOR record reader device driver assumes that the monitor DCSS on z/VM is called MONDCSS. If you want to use a different DCSS name you need to specify it. Specify the DCSS name as a module parameter when you load the module.

Module parameter

This section describes how to load the monitor read support. It also tells you how to specify a DCSS name, if applicable.

Load the monitor read support module with **modprobe** to assure that any other required modules are also loaded. You need IUCV support if you want to use the monitor read support.

monitor stream support module parameter syntax



where *<dcss>* is the name of the DCSS that z/VM uses for the monitor records.

Example: To load the monitor read support module and specify MYDCSS as the DCSS issue:

```
modprobe monreader mondcss=mydcss
```

z/VM *MONITOR record device node

Red Hat Enterprise Linux 6.3 creates a device node for you using udev. The device node is called `/dev/monreader` and is a miscellaneous character device that you can use to access the monitor DCSS.

Working with the z/VM *MONITOR record reader

This section describes how to work with the monitor read support.

- Opening and closing the character device
- Reading monitor records

Opening and closing the character device

Only one user can open the character device at any one time. Once you have opened the device you need to close it to make it accessible to other users.

The open function can fail (return a negative value) with one of the following values for `errno`:

EBUSY

The device has already been opened by another user.

EIO

No IUCV connection to the z/VM MONITOR system service could be established. An error message with an IPUSER SEVER code is printed into `syslog`. See *z/VM Performance*, SC24-6208 for details about the codes.

Once the device is opened, incoming messages are accepted and account for the message limit. If you keep the device open indefinitely, expect to eventually reach the message limit (with error code `EOverflow`).

Reading monitor records

There are two alternative methods for reading:

- Non-blocking read in conjunction with polling
- Blocking read without polling

Reading from the device provides a 12-byte monitor control element (MCE), followed by a set of one or more contiguous monitor records (similar to the output of the CMS utility MONWRITE without the 4K control blocks). The MCE contains information about:

- The type of the following record set (sample/event data)
- The monitor domains contained within it
- The start and end address of the record set in the monitor DCSS

The start and end address can be used to determine the size of the record set, the end address is the address of the last byte of data. The start address is needed to handle "end-of-frame" records correctly (domain 1, record 13), that is, it can be used to determine the record start offset relative to a 4K page (frame) boundary.

See "Appendix A: *MONITOR" in *z/VM Performance*, SC24-6208 for a description of the monitor control element layout. For the layout of the monitor records go to www.ibm.com/vm/pubs/ctlblk.html and click the link to the monitor record format for your z/VM version. Also see Chapter 13, "Writing kernel APPLDATA records," on page 197.

The layout of the data stream provided by the monreader device is as follows:

```

...
<0 byte read>
<first MCE>
<first set of records>  \
                        |...   | - data set
                        |
<last MCE>
<last set of records>  /
<0 byte read>
...

```

There may be more than one combination of MCE and a corresponding record set within one data set. The end of each data set is indicated by a successful read with a return value of 0 (0 byte read). Received data is not to be considered valid unless a complete record set is read successfully, including the closing 0-Byte read. You are advised to always read the complete set into a user space buffer before processing the data.

When designing a buffer, allow for record sizes up to the size of the entire monitor DCSS, or use dynamic memory allocation. The size of the monitor DCSS will be printed into syslog after loading the module. You can also use the (Class E privileged) CP command Q NSS MAP to list all available segments and information about them (see "Assuring that the DCSS is addressable for your Linux instance" on page 208).

Error conditions are indicated by returning a negative value for the number of bytes read. In case of an error condition, the errno variable can be:

EIO Reply failed. All data read since the last successful read with 0 size is not valid. Data will be missing. The application must decide whether to continue reading subsequent data or to exit.

EFAULT

Copy to user failed. All data read since the last successful read with 0 size is not valid. Data will be missing. The application must decide whether to continue reading subsequent data or to exit.

EAGAIN

Occurs on a non-blocking read if there is no data available at the moment. There is no data missing or damaged, retry or use polling for non-blocking reads.

EOVERFLOW

Message limit reached. The data read since the last successful read with 0 size is valid but subsequent records might be missing. The application must decide whether to continue reading subsequent data or to exit.

Chapter 16. z/VM recording device driver

The z/VM recording device driver enables Linux on z/VM to read from the CP recording services and, thus, act as a z/VM wide control point. The z/VM recording device driver uses the z/VM CP RECORDING command to collect records and IUCV to transmit them to the Linux instance.

Features

The z/VM recording device driver supports the following devices and functions:

- Reading records from the CP error logging service, *LOGREC.
- Reading records from the CP accounting service, *ACCOUNT.
- Reading records from the CP diagnostic service, *SYMPTOM.
- Automatic and explicit record collection (see “Starting and stopping record collection” on page 215).

For general information about CP recording system services refer to *z/VM CP Programming Services*, SC24-6179.

What you should know about the z/VM recording device driver

The z/VM recording device driver is a character device driver that is grouped under the IUCV category of device drivers (see “Device categories” on page 7). There is one device for each recording service. The devices are created for you when the z/VM recording device driver module is loaded.

z/VM recording device nodes

Each recording service has a name that corresponds to the name of the service as shown in Table 38:

Table 38. z/VM recording device names

z/VM recording service	Standard device name
*LOGREC	logrec
*ACCOUNT	account
*SYMPTOM	symptom

Reading records

The read function returns one record at a time. If there is no record, the read function waits until a record becomes available.

Each record begins with a 4 byte field containing the length of the remaining record. The remaining record contains the binary z/VM data followed by the four bytes X'454f5200' to mark the end of the record. These bytes build the zero terminated ASCII string “EOR”, which is useful as an eye catcher.




Figure 41. Record structure

Figure 41 illustrates the structure of a complete record as returned by the device. If the buffer assigned to the read function is smaller than the overall record size, multiple reads are required to obtain the complete record.

The format of the z/VM data (*LOGREC) depends on the record type described in the common header for error records HDRREC.

For more information about the z/VM record layout, see the *CMS and CP Data Areas and Control Blocks* documentation at www.ibm.com/vm/pubs/ctlblk.html

Setting up the z/VM recording device driver

This section provides information about the guest authorization you need to be able to collect records and on how to load the device driver module.

Authorizing the z/VM guest virtual machine

The z/VM guest virtual machine on which your Linux instance runs must be authorized to:

- Use the z/VM CP RECORDING command.
- Connect to the IUCV services to be used: one or more of *LOGREC, *ACCOUNT, and *SYMPTOM.

Loading the z/VM recording device driver

There are no module parameters for the z/VM recording device driver.

You need to load the z/VM recording device driver module before you can work with z/VM recording devices. Load the `vmlogrdr` module with the `modprobe` command to ensure that any other required modules are loaded in the correct order:

```
# modprobe vmlogrdr
```

Working with z/VM recording devices

This section describes typical tasks that you need to perform when working with z/VM recording devices.

- Starting and stopping record collection
- Purging existing records
- Querying the z/VM recording status
- Opening and closing devices
- Reading records

Starting and stopping record collection

By default, record collection for a particular z/VM recording service begins when the corresponding device is opened and stops when the device is closed.

You can use a device's autorecording attribute to be able to open and close a device without also starting or stopping record collection. You can use a device's recording attribute to start and stop record collection regardless of whether the device is opened or not.

Be aware that you cannot start record collection if a device is open and there are already existing records. Before you can start record collection for an open device you must read or purge any existing records for this device (see “Purging existing records” on page 216).

To be able to open a device without starting record collection and to close a device without stopping record collection write “0” to the devices autorecording attribute. To restore the automatic starting and stopping of record collection write “1” to the devices autorecording attribute. Issue a command of this form:

```
# echo <flag> > /sys/bus/iucv/drivers/vmlogrdr/<device>/autorecording
```

where *<flag>* is either 0 or 1, and *<device>* is one of: logrec, symptom, or account.

To explicitly switch on record collection write “1” to the devices recording attribute. To explicitly switch off record collection write “0” to the devices recording attribute. Issue a command of this form:

```
# echo <flag> > /sys/bus/iucv/drivers/vmlogrdr/<device>/recording
```

where *<flag>* is either 0 or 1, and *<device>* is one of: logrec, symptom, or account.

You can read the both the autorecording and the recording attribute to find the current settings.

Examples

- In this example, first the current setting of the autorecording attribute of the logrec device is checked, then automatic recording is switched off:

```
# cat /sys/bus/iucv/drivers/vmlogrdr/logrec/autorecording
1
# echo 0 > /sys/bus/iucv/drivers/vmlogrdr/logrec/autorecording
```

- In this example record collection is started explicitly and later stopped for the account device:

```
# echo 1 > /sys/bus/iucv/drivers/vmlogrdr/account/recording
...
# echo 0 > /sys/bus/iucv/drivers/vmlogrdr/account/recording
```

To confirm whether recording is on or off, use the `recording_status` attribute as described in “Querying the z/VM recording status” on page 216.

Purging existing records

By default, existing records for a particular z/VM recording service are purged automatically when the corresponding device is opened or closed.

You can use a device's autopurge attribute to prevent records from being purged when a device is opened or closed. You can use a device's purge attribute to purge records for a particular device at any time without having to open or close the device.

To be able to open or close a device without purging existing records write "0" to the device's autopurge attribute. To restore automatic purging of existing records write "1" to the device's autopurge attribute. You can read the autopurge attribute to find the current setting. Issue a command of this form:

```
# echo <flag> > /sys/bus/iucv/drivers/vmlogrdr/<device>/autopurge
```

where <flag> is either 0 or 1, and <device> is one of: logrec, symptom, or account.

To purge existing records for a particular device without opening or closing the device write "1" to the device's purge attribute. Issue a command of this form:

```
# echo 1 > /sys/bus/iucv/drivers/vmlogrdr/<device>/purge
```

where <device> is one of: logrec, symptom, or account.

Examples

- In this example, the setting of the autopurge attribute for the logrec device is checked first, then automatic purging is switched off:

```
# cat /sys/bus/iucv/drivers/vmlogrdr/logrec/autopurge
1
# echo 0 > /sys/bus/iucv/drivers/vmlogrdr/logrec/autopurge
```

- In this example, the existing records for the symptom device are purged:

```
# echo 1 > /sys/bus/iucv/drivers/vmlogrdr/symptom/purge
```

Querying the z/VM recording status

You can use the recording_status attribute of the z/VM recording device driver representation in sysfs to query the z/VM recording status.

Example

This example runs the z/VM CP command QUERY RECORDING and returns the complete output of that command. This list will not necessarily have an entry for all three services and there might be additional entries for other guests.

```
# cat /sys/bus/iucv/drivers/vmlogrdr/recording_status
```

This will result in output similar to the following:

RECORDING	COUNT	LMT	USERID	COMMUNICATION
EREP ON	00000000	002	EREP	ACTIVE
ACCOUNT ON	00001774	020	DISKACNT	INACTIVE
SYMPTOM ON	00000000	002	OPERSYMP	ACTIVE
ACCOUNT OFF	00000000	020	LINUX31	INACTIVE

where the lines represent:

- The service
- The recording status
- The number of queued records
- The number of records that will result in a message to the operator
- The guest that is or was connected to that service and the current status of that connection

A detailed description of the QUERY RECORDING command can be found in the *z/VM CP Commands and Utilities Reference*, SC24-6175.

Opening and closing devices

You can open, read, and release the device. You cannot open the device multiple times. Each time the device is opened it must be released before it can be opened again.

You can use a device's autorecord attribute (see “Starting and stopping record collection” on page 215) to enable automatic record collection while a device is open.

You can use a device's autopurge attribute (see “Purging existing records” on page 216) to enable automatic purging of existing records when a device is opened and closed.

Scenario: Connecting to the *ACCOUNT service.

This scenario demonstrates autorecording, turning autorecording off, purging records, and starting recording.

1. Query the status of z/VM recording. As root, issue the following command:

```
# cat /sys/bus/iucv/drivers/vmlogrdr/recording_status
```

The results depend on the system, but should be similar to the following:

RECORDING	COUNT	LMT	USERID	COMMUNICATION
EREP ON	00000000	002	EREP	ACTIVE
ACCOUNT ON	00001812	020	DISKACNT	INACTIVE
SYMPTOM ON	00000000	002	OPERSYMP	ACTIVE
ACCOUNT OFF	00000000	020	LINUX31	INACTIVE

2. Open /dev/account with an appropriate application. This will connect the guest to the *ACCOUNT service and start recording. The entry for *ACCOUNT on guest LINUX31 will change to ACTIVE and ON:

```
# cat /sys/bus/iucv/drivers/vmlogrdr/recording_status
```

RECORDING	COUNT	LMT	USERID	COMMUNICATION
EREP ON	00000000	002	EREP	ACTIVE
ACCOUNT ON	00001812	020	DISKACNT	INACTIVE
SYMPTOM ON	00000000	002	OPERSYMP	ACTIVE
ACCOUNT ON	00000000	020	LINUX31	ACTIVE

3. Switch autopurge and autorecord off:

```
# echo 0 > /sys/bus/iucv/drivers/vmlogrdr/account/autopurge
```

```
# echo 0 > /sys/bus/iucv/drivers/vmlogrdr/account/autorecording
```

4. Close the device by ending the application that reads from it and check the recording status. Note that while the connection is INACTIVE, RECORDING is still ON:

```
# cat /sys/bus/iucv/drivers/vmlogrdr/recording_status
```

RECORDING	COUNT	LMT	USERID	COMMUNICATION
EREP ON	00000000	002	EREP	ACTIVE
ACCOUNT ON	00001812	020	DISKACNT	INACTIVE
SYMPTOM ON	00000000	002	OPERSYMP	ACTIVE
ACCOUNT ON	00000000	020	LINUX31	INACTIVE

5. The next status check shows that some event created records on the *ACCOUNT queue:

```
# cat /sys/bus/iucv/drivers/vmlogrdr/recording_status
```

RECORDING	COUNT	LMT	USERID	COMMUNICATION
EREP ON	00000000	002	EREP	ACTIVE
ACCOUNT ON	00001821	020	DISKACNT	INACTIVE
SYMPTOM ON	00000000	002	OPERSYMP	ACTIVE
ACCOUNT ON	00000009	020	LINUX31	INACTIVE

6. Switch recording off:

```
# echo 0 > /sys/bus/iucv/drivers/vmlogrdr/account/recording
```

```
# cat /sys/bus/iucv/drivers/vmlogrdr/recording_status
```

RECORDING	COUNT	LMT	USERID	COMMUNICATION
EREP ON	000000000	002	EREP	ACTIVE
ACCOUNT ON	00001821	020	DISKACNT	INACTIVE
SYMPTOM ON	00000000	002	OPERSYMP	ACTIVE
ACCOUNT OFF	00000009	020	LINUX31	INACTIVE

7. Try to switch it on again, and check whether it worked by checking the recording status:

```
# echo 1 > /sys/bus/iucv/drivers/vmlogrdr/account/recording
```

```
# cat /sys/bus/iucv/drivers/vmlogrdr/recording_status
```

RECORDING	COUNT	LMT	USERID	COMMUNICATION
EREP ON	000000000	002	EREP	ACTIVE
ACCOUNT ON	00001821	020	DISKACNT	INACTIVE
SYMPTOM ON	00000000	002	OPERSYMP	ACTIVE
ACCOUNT OFF	00000009	020	LINUX31	INACTIVE

Recording did not start, in the message logs you may find a message:

vmlogrdr: recording response: HPCRC8087I Records are queued for user LINUX31 on the *ACCOUNT recording queue and must be purged or retrieved before recording can be turned on.

Note that this kernel message has priority 'debug' so it might not be written to any of your log files.

8. Now remove all the records on your *ACCOUNT queue either by starting an application that reads them from /dev/account or by explicitly purging them:

```
# echo 1 > /sys/bus/iucv/drivers/vmlogrdr/account/purge
```

```
# cat /sys/bus/iucv/drivers/vmlogrdr/recording_status
RECORDING    COUNT    LMT    USERID    COMMUNICATION
EREP ON      00000000  002    EREP      ACTIVE
ACCOUNT ON   00001821  020    DISKACNT  INACTIVE
SYMPTOM ON   00000000  002    OPERSYMP  ACTIVE
ACCOUNT OFF  00000000  020    LINUX31   INACTIVE
```

9. Now we can start recording, check status again:

```
# echo 1 > /sys/bus/iucv/drivers/vmlogrdr/account/recording
```

```
# cat /sys/bus/iucv/drivers/vmlogrdr/recording_status
RECORDING    COUNT    LMT    USERID    COMMUNICATION
EREP ON      00000000  002    EREP      ACTIVE
ACCOUNT ON   00001821  020    DISKACNT  INACTIVE
SYMPTOM ON   00000000  002    OPERSYMP  ACTIVE
ACCOUNT ON   00000000  020    LINUX31   INACTIVE
```

Chapter 17. z/VM unit record device driver

The z/VM unit record device driver provides Linux on z/VM with access to virtual unit record devices. Unit record devices comprise punch card readers, card punches, and line printers. Linux access is limited to virtual unit record devices with default device types (2540 for reader and punch, 1403 for printer).

To write Linux files to the virtual punch or printer (that is, to the corresponding spool file queues) or to receive z/VM reader files (for example CONSOLE files) to Linux files, use the **vmur** command that is part of the s390utils RPM (see “vmur - Work with z/VM spool file queues” on page 509).

What you should know about the z/VM unit record device driver

The z/VM unit record device driver is compiled as a separate module, vmur.

To load the vmur module automatically at boot time, see the section on persistent module loading in *Red Hat Enterprise Linux 6.3 Deployment Guide*

z/VM unit record device nodes

When the vmur module is loaded, it registers a character device. The following device nodes are created for a unit record device when it is set online:

- Reader: /dev/vmrdr-0.0.<device_number>
- Punch: /dev/vmpun-0.0.<device_number>
- Printer: /dev/vmprt-0.0.<device_number>

Working with z/VM unit record devices

After loading the vmur module, the required virtual unit record devices need to be set online. For example, to set the devices with device bus-IDs 0.0.000c, 0.0.000d, and 0.0.000e online, issue:

```
# chccwdev -e 0.0.000c-0.0.000e
```

When unloading vmur (with **modprobe -r**) the respective unit record device nodes must not be open, otherwise the error message Module vmur is in use is displayed.

Serialization is implemented per device; only one process can open a given device node at a given time.

Chapter 18. z/VM DCSS device driver

The z/VM discontinuous saved segments (DCSS) device driver provides disk-like fixed block access to z/VM discontinuous saved segments.

Features

The DCSS device driver facilitates:

- Initializing and updating ext2 compatible file system images in z/VM saved segments for use with the xip option of the ext2 file system.
- Implementing a read-write RAM disk that can be shared among multiple Linux instances that run as guests of the same z/VM system. For example, such a RAM disk can provide a shared file system.

What you should know about DCSS

This section provides information about the DCSS device names and nodes.

Important

DCSSs occupy spool space. Be sure that you have enough spool space available (multiple times the DCSS size).

DCSS naming scheme

The standard device names are of the form `dcssblk<n>`, where `<n>` is the corresponding minor number. The first DCSS device that is added is assigned the name `dcssblk0`, the second `dcssblk1`, and so on. When a DCSS device is removed, its device name and corresponding minor number are free and can be reassigned. A DCSS device that is added always receives the lowest free minor number.

DCSS device nodes

User space programs access DCSS devices by device nodes. Red Hat Enterprise Linux 6.3 provides `udev` to create standard DCSS device nodes of the form `/dev/<device_name>`, for example:

```
/dev/dcssblk0
/dev/dcssblk1
...
```

Accessing a DCSS in exclusive-writable mode

You need to access a DCSS in exclusive-writable mode, for example, when creating or updating the DCSS.

To access a DCSS in exclusive-writable mode at least one of the following conditions must apply:

- The DCSS fits below the maximum definable address space size of the z/VM guest virtual machine.

For large read-only DCSS, you can use suitable guest sizes to restrict exclusive-writable access to a specific z/VM guest virtual machine with a sufficient maximum definable address space size.

- The z/VM user directory entry for the z/VM guest virtual machine includes a NAMESAVE statement for the DCSS. See *z/VM CP Planning and Administration*, SC24-6178 for more information about the NAMESAVE statement.
- The DCSS has been defined with the LOADNSHR operand. See “DCSS options” about saving DCSSs with optional properties.

See *z/VM CP Commands and Utilities Reference*, SC24-6175 for information about the LOADNSHR operand.

DCSS options

The z/VM DCSS device driver always saves DCSSs with default properties. Any options that have previously been defined are removed. For example, a DCSS that has been defined with the LOADNSHR operand no longer has this property after being saved through the z/VM DCSS device driver.

To save a DCSS with optional properties, you must unmount the DCSS device, then use the CP DEFSEG and SAVESEG commands to save the DCSS. See “Workaround for saving DCSSs with optional properties” on page 230 for an example.


See *z/VM CP Commands and Utilities Reference*, SC24-6175 for information about DCSS options.

Further information

- For information about DCSS see *z/VM Saved Segments Planning and Administration*, SC24-6229
- For related z/VM information see *z/VM CP Commands and Utilities Reference*, SC24-6175.
- For an example of how the xip option for the ext2 file system and DCSS can be used see *How to use Execute-in-Place Technology with Linux on z/VM*, SC34-2594 on developerWorks at:
www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

Setting up the DCSS device driver

Before you can load and use DCSSs, you must load the the DCSS block device driver. Use the segments module parameter to load one or more DCSSs when the DCSS device driver is loaded.



<dcss>

specifies the name of a DCSS as defined on the z/VM hypervisor. The specification for <dcss> is converted from ASCII to uppercase EBCDIC.

- : the colon (:) separates DCSSs within a set of DCSSs to be mapped to a single DCSS device. You can map a set of DCSSs to a single DCSS device if the DCSSs in the set form a contiguous memory space.

You can specify the DCSSs in any order. The name of the first DCSS you specify is used to represent the device under /sys/devices/dcssblk.

(local)

sets the access mode to exclusive-writable after the DCSS or set of DCSSs have been loaded.

- , the comma (,) separates DCSS devices.

Examples

The following command loads the DCSS device driver and three DCSSs: DCSS1, DCSS2, and DCSS3. DCSS2 is accessed in exclusive-writable mode.

```
# modprobe dcssblk segments="dcss1,dcss2(local),dcss3"
```

The following command loads the DCSS device driver and four DCSSs: DCSS4, DCSS5, DCSS6, and DCSS7. The device driver creates two DCSS devices. One device maps to DCSS4 and the other maps to the combined storage space of DCSS5, DCSS6, and DCSS7 as a single device.

```
# modprobe dcssblk segments="dcss4,dcss5:dcss6:dcss7"
```

Avoiding overlaps with your guest storage

Ensure that your DCSSs do not overlap with the memory of your z/VM guest virtual machine (guest storage). To find the start and end addresses of the DCSSs, enter the following CP command; this command requires privilege class E:

```
#cp q nss map
```

the output gives you the start and end addresses of all defined DCSSs in units of 4 kilobyte pages:

```
00: FILE FILENAME FILETYPE MINSIZE BEGPAG ENDPAG TYPE CL #USERS PARMREGS VMGROUP
...
00: 0011 MONDCSS CPDCSS N/A 09000 097FF SC R 00003 N/A N/A
...
```

If all DCSSs that you intend to access are located above the guest storage, you do not need to take any action.

If any DCSS that you intend to access with your guest machine overlaps with the guest storage, redefine the guest storage as two or more discontinuous storage extents such that the storage gap with the lowest address range covers all your DCSSs' address ranges.

Notes:

1. You cannot place a DCSS into a storage gap other than the storage gap with the lowest address range.

2. A z/VM guest that has been defined with one or more storage gaps cannot access a DCSS above the guest storage.

From a CMS session, use the DEF STORE command to define your guest storage as discontinuous storage extents. Ensure that the storage gap between the extents covers all your DCSSs' address ranges. Issue a command of this form:

```
DEF STORE CONFIG 0.<storage_gap_begin> <storage_gap_end>.<storage above gap>
```

where:

<storage_gap_begin>

is the lower limit of the storage gap. This limit must be at or below the lowest address of the DCSS with the lowest address range.

Because the lower address ranges are required for memory management functions make the lower limit at least 128 MB. The lower limit for the DCSS increases with the total memory size and 128 MB is not an exact value but it is an approximation that is sufficient for most cases.

<storage_gap_end>

is the upper limit of the storage gap. The upper limit must be above the upper limit of the DCSS with the highest address range.

<storage above gap>

is the amount of storage above the storage gap. The total guest storage is $\text{<storage_gap_begin> + <storage above gap>}$.

All values can be suffixed with M to provide the values in megabyte. See *z/VM CP Commands and Utilities Reference*, SC24-6175 for more information about the DEF STORE command.

Example

To make a DCSS that starts at 144 MB and ends at 152 MB accessible to a z/VM guest with 512 MB guest storage:

```
DEF STORE CONFIG 0.140M 160M.372M
```

This specification is one example of how a suitable storage gap can be defined. In this example, the storage gap ranges from 140 MB to 160 MB and thus covers the entire DCSS range. The total guest storage is 140 MB + 372 MB = 512 MB.

Working with DCSS devices

This section describes typical tasks that you need to perform when working with DCSS devices:

- Adding a DCSS device
- Listing the DCSSs that map to a particular device
- Finding the minor number for a DCSS device
- Setting the access mode
- Saving updates to a DCSS or set of DCSSs
- Removing a DCSS device

Adding a DCSS device

Before you begin:

- You need to have set up one or more DCSSs on z/VM and know the names assigned to the DCSSs on z/VM.
- If you use the watchdog device driver, turn off the watchdog before adding a DCSS device. Adding a DCSS device can result in a watchdog timeout if the watchdog is active.
- You cannot concurrently access overlapping DCSSs.
- You cannot access a DCSS that overlaps with your z/VM guest virtual storage (see “Avoiding overlaps with your guest storage” on page 225).
- If a z/VM guest has been defined with multiple storage gaps, you can only add DCSSs that are located in the storage gap with the lowest address range.
- If a z/VM guest has been defined with one or more storage gaps, you cannot add a DCSS that is located above the guest storage.

To add a DCSS device enter a command of this form:

```
# echo <dcss-list> > /sys/devices/dcssblk/add
```

<dcss-list>

the name, as defined on z/VM, of a single DCSS or a colon (:) separated list of names of DCSSs to be mapped to a single DCSS device. You can map a set of DCSSs to a single DCSS device if the DCSSs in the set form a contiguous memory space. You can specify the DCSSs in any order. The name of the first DCSS you specify is used to represent the device under /sys/devices/dcssblk.

Examples

To add a DCSS called “MYDCSS” enter:

```
# echo MYDCSS > /sys/devices/dcssblk/add
```

To add three DCSSs “MYDCSS1”, “MYDCSS2”, and “MYDCSS3” as a single device enter:

```
# echo MYDCSS2:MYDCSS1:MYDCSS3 > /sys/devices/dcssblk/add
```

In sysfs, the resulting device is represented as /sys/devices/dcssblk/MYDCSS2.

Listing the DCSSs that map to a particular device

To list the DCSSs that map to a DCSS device, issue a command like this:

```
# cat /sys/devices/dcssblk/<dcss-name>/seglst
```

where <dcss-name> is the DCSS name that represents the DCSS device.

Examples

In this example, DCSS device MYDCSS maps to a single DCSS, “MYDCSS”.

```
# cat /sys/devices/dcssblk/MYDCSS/seglst
MYDCSS
```

In this example, DCSS device MYDCSS2 maps to three DCSSs, “MYDCSS1”, “MYDCSS2”, and “MYDCSS3”.

```
# cat /sys/devices/dcssblk/MYDCSS2/seclist
MYDCSS2
MYDCSS1
MYDCSS3
```

Finding the minor number for a DCSS device

When you add a DCSS device, a minor number is assigned to it. Unless you use dynamically created device nodes as provided by udev, you might need to know the minor device number that has been assigned to the DCSS (see “DCSS naming scheme” on page 223).

When you add a DCSS device, a directory of this form is created in sysfs:

```
/sys/devices/dcssblk/<dcss-name>
```

where <dcss-name> is the DCSS name that represents the DCSS device.

This directory contains a symbolic link, block, that helps you to find out the device name and minor number. The link is of the form ../../../../block/dcssblk<n>, where dcssblk<n> is the device name and <n> is the minor number.

Example

To find out the minor number assigned to a DCSS device that is represented by the directory /sys/devices/dcssblk/MYDCSS issue:

```
# readlink /sys/devices/dcssblk/MYDCSS/block
../../../../block/dcssblk0
```

In the example, the assigned minor number is “0”.

Setting the access mode

You might want to access the DCSS device with write access to change the content of the DCSS or set of DCSSs that map to the device. There are two possible write access modes to the DCSS device:

shared

In the shared mode, changes to DCSSs are immediately visible to all z/VM guests that access them. Shared is the default.

Note: Writing to a shared DCSS device bears the same risks as writing to a shared disk.

exclusive-writable

In the exclusive-writable mode you write to private copies of DCSSs. A private copy is writable, even if the original DCSS is read-only. Changes you make to a private copy are invisible to other guests until you save the changes (see “Saving updates to a DCSS or set of DCSSs” on page 229).

After saving the changes to a DCSS, all guests that open the DCSS access the changed copy. z/VM retains a copy of the original DCSS for those guests that continue accessing it, until the last guest has stopped using it.

To access a DCSS in the exclusive-writable mode the maximum definable storage size of your z/VM virtual machine must be above the upper limit

of the DCSS. Alternatively, suitable authorizations must be in place (see “Accessing a DCSS in exclusive-writable mode” on page 223).

For either access mode the changes are volatile until they are saved (see “Saving updates to a DCSS or set of DCSSs”).

Set the access mode before you open the DCSS device. To set the access mode to exclusive-writable set the DCSS device's shared attribute to “0”. To reset the access mode to shared set the DCSS device's shared attribute to “1”.

Issue a command of this form:

```
# echo <flag> > /sys/devices/dcscblk/<dcsc-name>/shared
```

where *<dcsc-name>* is the DCSS name that represents the DCSS device.

You can read the shared attribute to find out the current access mode.

Example

To find out the current access mode of a DCSS device represented by the DCSS name “MYDCSS”:

```
# cat /sys/devices/dcscblk/MYDCSS/shared
1
```

“1” means that the current access mode is shared. To set the access mode to exclusive-writable issue:

```
# echo 0 > /sys/devices/dcscblk/MYDCSS/shared
```

Saving updates to a DCSS or set of DCSSs

Before you begin:

- Saving a DCSS as described in this section results in a default DCSS, without optional properties. For DCSSs that have been defined with options (see “DCSS options” on page 224), see “Workaround for saving DCSSs with optional properties” on page 230.
- If you use the watchdog device driver, turn off the watchdog before saving updates to DCSSs. Saving updates to DCSSs can result in a watchdog timeout if the watchdog is active.
- Do not place save requests before you have accessed the DCSS device.

To place a request for saving changes permanently on the spool disk write “1” to the DCSS device's save attribute. If a set of DCSSs has been mapped to the DCSS device, the save request applies to all DCSSs in the set.

Issue a command of this form:

```
# echo 1 > /sys/devices/dcscblk/<dcsc-name>/save
```

where *<dcsc-name>* is the DCSS name that represents the DCSS device.

Saving is delayed until you close the device.

You can check if a save request is waiting to be performed by reading the contents of the save attribute.

You can cancel a save request by writing “0” to the save attribute.

Example

To check if a save request exists for a DCSS device that is represented by the DCSS name “MYDCSS”:

```
# cat /sys/devices/dcsslk/MYDCSS/save
0
```

The “0” means that no save request exists. To place a save request issue:

```
# echo 1 > /sys/devices/dcsslk/MYDCSS/save
```

To purge an existing save request issue:

```
# echo 0 > /sys/devices/dcsslk/MYDCSS/save
```

Workaround for saving DCSSs with optional properties

Note: This section applies to DCSSs with special options only. The workaround in this section is error-prone and requires utmost care. Erroneous parameter values for the described CP commands can render a DCSS unusable. Only use this workaround if you really need a DCSS with special options.

Perform the following steps to save a DCSS with optional properties:

1. Unmount the DCSS.

Example: Enter this command to unmount a DCSS with the device node /dev/dcsslk0:

```
# umount /dev/dcsslk0
```

2. Use the CP DEFSEG command to newly define the DCSS with the required properties.

Example: Enter this command to newly define a DCSS, mydcss, with the range 80000-9ffff, segment type sr, and the loadnshr operand:

```
# vmcp defseg mydcss 80000-9ffff sr loadnshr
```

Note: If your DCSS device maps to multiple DCSSs as defined to z/VM, you must perform this step for each DCSS. Be sure to specify the command correctly with the correct address ranges and segment types. Incorrect specifications can render the DCSS unusable.

3. Use the CP SAVESEG command to save the DCSS.

Example: Enter this command to save a DCSS mydcss:

```
# vmcp saveseg mydcss
```

Note: If your DCSS device maps to multiple DCSSs as defined to z/VM you must perform this step for each DCSS. Omitting this step for individual DCSSs can render the DCSS device unusable.

See *z/VM CP Commands and Utilities Reference*, SC24-6175 for details about the DEFSEG and SAVESEG CP commands.

Removing a DCSS device

Before you begin: A DCSS device can only be removed when it is not in use.

You can remove the DCSS or set of DCSSs that are represented by a DCSS device from your Linux system by issuing a command of this form:

```
# echo <dcss-name> > /sys/devices/dcsslk/remove
```

where *<dcss-name>* is the DCSS name that represents the DCSS device.

If you have created your own device nodes, you can keep the nodes for reuse. Be aware that the major number of the device might change when you unload and reload the DCSS device driver. When the major number of your device has changed, existing nodes become unusable.

Example

To remove a DCSS device that is represented by the DCSS name “MYDCSS” issue:

```
# echo MYDCSS > /sys/devices/dcsslk/remove
```

Changing the contents of a DCSS

The following scenario describes how you can use the DCSS block device driver to change the contents of a DCSS.

Assumptions:

- The Linux instance runs as a z/VM guest with class E user privileges.
- A DCSS has been set up and can be accessed in exclusive-writable mode by the Linux instance.
- The DCSS does not overlap with the guest's main storage.
- There is only a single DCSS named “MYDCSS”.
- The DCSS block device driver has been set up and is ready to be used.

Note: The description in this scenario can readily be extended to changing the content of a set of DCSSs that form a contiguous memory space. The only change to the procedure would be mapping the DCSSs in the set to a single DCSS device in step 1. The assumptions about the set of DCSSs would be that the contiguous memory space formed by the set does not overlap with the guest storage and that only the DCSSs in the set are added to the Linux instance.

Perform the following steps to change the contents of a DCSS:

1. Add the DCSS to the block device driver.

```
# echo MYDCSS > /sys/devices/dcsslk/add
```

2. Ensure that there is a device node for the DCSS block device. If it is not created for you, for example by udev, create it yourself.
 - Find out the major number used for DCSS block devices. Read `/proc/devices`:

```
# cat /proc/devices
...
Block devices
...
254 dcssblk
...
```

The major number in the example is 254.

- Find out the minor number used for MYDCSS. If MYDCSS is the first DCSS that has been added the minor number is 0. To be sure you can read a symbolic link that is created when the DCSS is added.

```
# readlink /sys/devices/dcssblk/MYDCSS/block
../../../../block/dcssblk0
```

The trailing 0 in the standard device name `dcssblk0` indicates that the minor number is, indeed, 0.

- Create the node with the **mknod** command:

```
# mknod /dev/dcssblk0 b 254 0
```

3. Set the access mode to exclusive-write.

```
# echo 0 > /sys/devices/dcssblk/MYDCSS/shared
```

4. Mount the file system in the DCSS on a spare mount point.

```
# mount /dev/dcssblk0 /mnt
```

5. Update the data in the DCSS.

6. Create a save request to save the changes.

```
# echo 1 > /sys/devices/dcssblk/MYDCSS/save
```

7. Unmount the file system.

```
# umount /mnt
```

The changes to the DCSS are now saved. When the last z/VM guest stops accessing the old version of the DCSS, the old version is discarded. Each guest that opens the DCSS accesses the updated copy.

8. Remove the device.

```
# echo MYDCSS > /sys/devices/dcssblk/remove
```

9. If you have created your own device node, you can optionally clean it up.

```
# rm -f /dev/dcssblk0
```

Chapter 19. Shared kernel support

You can save a Linux kernel in a z/VM named saved system (NSS). Through an NSS, z/VM makes operating system code in shared real memory pages available to z/VM guest virtual machines. Multiple instances of Linux on z/VM can then boot from the NSS and run from the single copy of the Linux kernel in memory.

For a z/VM guest virtual machine a shared kernel in an NSS amounts to a fast boot device. In a virtual Linux server farm with multiple z/VM guest virtual machines sharing the NSS, the NSS can help to reduce paging and enhance performance.

What you should know about NSS

Before you create an NSS you need to have a Linux system that supports kernel sharing installed on a conventional boot device, for example, a DASD or SCSI disk. You create the NSS when you use a special boot parameter to boot the Linux system from this original boot device.

For more information about NSS and the CP commands used in this section see:

- *z/VM CP Commands and Utilities Reference*, SC24-6175 at the IBM Publications Center (see “Finding IBM books” on page xiv).
- *z/VM Virtual Machine Operation*, SC24-6241 at the IBM Publications Center (see “Finding IBM books” on page xiv).

Kernel parameter for creating an NSS

You create an NSS with a shared kernel by booting a Linux system with shared kernel support with the `savesys=` parameter.

kernel parameter syntax

►—savesys=<nss_name>—◄

where <nss_name> is the name you want to assign to the NSS. The name can be one to eight characters long and must consist of alphabetic or numeric characters. Be sure not to assign a name that matches any of the device numbers used at your installation.

Note: If <nss_name> contains non-alphanumeric characters, the NSS might be created successfully. However, this name might not work in CP commands. Always use alphanumeric characters for the name.

Working with a Linux NSS

This section describes how you can create and maintain a Linux NSS. For information about booting Linux from an NSS see “Using a named saved system” on page 354. Note that Kexec is disabled for Linux instances booted from a kernel NSS.

For each task described in this section you need a z/VM guest virtual machine that runs with class E privileges.

Creating or updating a Linux NSS using zipl

Perform these steps to create a new Linux NSS or to update an existing Linux NSS:

1. Boot the Linux instance from which you want to create the new NSS or the Linux instance from which you want to update an existing NSS.
2. Add `savesys=<nssname>` to the kernel parameters in your boot configuration, where `<nssname>` is the name for the new NSS to be created or of the existing NSS to be updated. For example, you can add the `savesys=` parameter to a kernel parameter file (see “Including kernel parameters in a boot configuration” on page 20 for details).
The NSS name must be 1 - 8 alphanumeric characters, for example, 73248734, LNXNSS, or NSS1. Be sure not to assign a name that matches a device number used at your installation.
3. Issue a **zipl** command to write the modified boot configuration to the boot device (Chapter 35, “Initial program loader for System z - zipl,” on page 321).
4. Close down Linux.
5. Issue an IPL command to boot Linux from the device that holds the Linux kernel. During the IPL process, the NSS is created or updated and Linux is rebooted from the NSS.

You can now use the NSS to boot Linux in your z/VM guest virtual machines. See “Using a named saved system” on page 354 for details.

Creating or updating a Linux NSS from the CP command line

You can create or update a Linux NSS without adding kernel parameters to the boot configuration and without running **zipl**.

To boot Linux and save it as an NSS issue an IPL command of this form:

```
IPL <devno> PARM savesys=<nssname>
```

In the command, `<devno>` specifies the CCW device that holds the Linux instance to be saved as an NSS; and `<nssname>` is the name for the new NSS to be created or the name of an existing NSS to be updated.

If your IPL device is an FCP device, you cannot use the PARM parameter. Instead, use the z/VM CP `LOADDEV` command to specify the `savesys=` kernel parameter as `SCPDATA` (see “Using a SCSI device” on page 352).

The name must be 1 - 8 alphanumeric characters, for example, 73248734, LNXNSS, or NSS1. Be sure not to assign a name that matches a device number used at your installation.

During the IPL process, the NSS is created and Linux is booted from the NSS.

Example: To create an NSS from a Linux instance that has been installed on a device with bus ID 0.0.1234, enter:

```
IPL 1234 PARM savesys=1nxs
```

For information about the PARM attribute, see “Specifying kernel parameters when booting Linux” on page 21.

You can now use the NSS to boot Linux in your z/VM guest virtual machines. See “Using a named saved system” on page 354 for details.

Deleting a Linux NSS

Issue a CP PURGE NSS NAME command to delete an NSS. For example, issue a command of this form

```
PURGE NSS NAME <nssname>
```

where <nssname> is the name of the NSS you want to delete.

Result: The NSS is removed from storage when the last Linux instance that is already using it is closed down. You cannot IPL new Linux instances from the NSS anymore.

Chapter 20. Watchdog device driver

The watchdog device driver provides Linux watchdog applications with access to the z/VM watchdog timer.

Watchdog applications can be used to set up automated restart mechanisms for Linux on z/VM. Watchdog-based restart mechanisms are an alternative to a networked heartbeat in conjunction with STONITH.

A watchdog application that communicates directly with the z/VM control program (CP) does not require a third operating system to monitor a heartbeat. The watchdog device driver enables you to set up a restart mechanism of this form.

Features

The watchdog device driver provides:

- Access to the z/VM watchdog timer.
- An API for watchdog applications (see “External programming interfaces” on page 239).

What you should know about the watchdog device driver

The watchdog function comprises the watchdog timer that runs on z/VM and a watchdog application that runs on the Linux instance being controlled. While the Linux instance operates satisfactorily, the watchdog application reports a positive status to the z/VM watchdog timer at regular intervals. The watchdog application uses a miscellaneous character device to pass these status reports to the z/VM timer (Figure 42).




Figure 42. Watchdog application and timer

The watchdog application typically derives its status by monitoring, critical network connections, file systems, and processes on the Linux instance. If a given time elapses without a positive report being received by the watchdog timer, the watchdog timer assumes that the Linux instance is in an error state. The watchdog timer then triggers a predefined action from CP against the Linux instance. Examples of possible actions are: shutting down Linux, rebooting Linux, or initiating a system dump. For information about setting the default timer and performing other actions, see “External programming interfaces” on page 239.

Note: Loading or saving a DCSS can take a long time during which the virtual machine does not respond, depending on the size of the DCSS. This may

cause a watchdog to timeout and restart the guest. You are advised not to use the watchdog in combination with loading or saving DCSSs.

You can find an example watchdog application at www.ibiblio.org/pub/linux/system/daemons/watchdog/!INDEX.html


See also the generic watchdog documentation in the Linux kernel source tree under Documentation/watchdog.

Setting up the watchdog device driver

This section describes the parameters that you can use to configure the watchdog device driver and how to assure that the required device node exists.

Module parameters

This section describes how to load and configure the watchdog device driver module.



where:

`<command>`

is the command to be issued by CP if the Linux instance fails. The default “IPL” reboots the guest with the previous boot parameters.

Instead of rebooting the same system, you could also boot from an alternate IPL device (for example, a dump device). You can also specify multiple commands to be issued, see “Examples” on page 239 for details. For more information about CP commands see *z/VM CP Commands and Utilities Reference*, SC24-6175.

The specification for `<command>`:

- Can be up to 230 characters long
- Needs to be enclosed by quotes if it contains any blanks or newline characters
- Is converted from ASCII to uppercase EBCDIC

`<conceal_flag>`

turns on and off the protected application environment where the guest is protected from unexpectedly entering CP READ. “0” turns off the protected environment, “1” enables it. The default is “0”.

For details, see the “SET CONCEAL” section of *z/VM CP Commands and Utilities Reference*, SC24-6175.

`<nowayout_flag>`

determines what happens when the watchdog device node is closed by the watchdog application.

If the flag is set to "1" (default), the z/VM watchdog timer keeps running and triggers the command specified for `<command>` if no positive status report is received within the given time interval. If the character "V" is written to the device and the flag is set to "0", the z/VM watchdog timer is stopped and the Linux instance continues without the watchdog support.

Examples

The following command loads the watchdog module and determines that, on failure, the Linux instance is to be IPLed from a device with devno 0xb1a0. The protected application environment is not enabled. The watchdog application can close the watchdog device node after writing "V" to it. As a result the watchdog timer becomes ineffective and does not IPL the guest.

```
modprobe vmwatchdog cmd="ipl b1a0" nowayout=0
```

The following example shows how to specify multiple commands to be issued.

```
printf "cmd1\ncmd2\ncmd3" > /sys/module/vmwatchdog/parameters/cmd
```

To verify that your commands have been accepted, issue:

```
cat /sys/module/vmwatchdog/parameters/cmd
cmd1
cmd2
cmd3
```

You cannot specify multiple commands as module parameters while loading the module.

Watchdog device node

The watchdog application on Linux needs a misc character device to communicate with the z/VM watchdog timer. This device node is created by udev and is called `/dev/watchdog`.

External programming interfaces



This section provides information for those who want to program watchdog applications that work with the watchdog device driver.

For information about the API see the following files in the Linux source tree:

- `Documentation/watchdog/watchdog-api.txt`
- `include/linux/watchdog.h`

The default watchdog timeout is 60 seconds, the minimum timeout that can be set through the IOCTL `SETTIMEOUT` is 15 seconds.

The following IOCTLs are supported:

- `WDIOC_GETSUPPORT`
- `WDIOC_SETOPTIONS` (`WDIOS_DISABLECARD`, `WDIOS_ENABLECARD`)

- WDIOC_GETTIMEOUT
- WDIOC_SETTIMEOUT
- WDIOC_KEEPAIVE

Chapter 21. z/VM CP interface device driver

Using the z/VM CP interface device driver (vmcp), you can send control program (CP) commands to the z/VM hypervisor and display the response. The vmcp device driver only works for Linux on z/VM.

What you should know about the z/VM CP interface

The z/VM CP interface driver (vmcp) uses the CP diagnose X'08' to send commands to CP and to receive responses. The behavior is similar but not identical to #cp on a 3270 console. There are two ways of using the z/VM CP interface driver:

- Through the /dev/vmcp device node
- Through a user space tool (see “vmcp - Send CP commands to the z/VM hypervisor” on page 507)

You must load the vmcp module before you can use vmcp. If your Linux guest runs under z/VM, you can configure the startup scripts to load the vmcp kernel module automatically during boot. See the section on persistent module loading in *Red Hat Enterprise Linux 6.3 Deployment Guide* for information about how to do this.

The vmcp device driver only works under z/VM and cannot be loaded if the Linux system runs in an LPAR.

Differences between vmcp and a 3270 console

Most CP commands behave identically with vmcp and on a 3270 console. However, some commands show a different behavior:

- Diagnose X'08' (see *z/VM CP Programming Services*, SC24-6179) requires you to specify a response buffer in conjunction with the command. As the size of the response is not known beforehand the default response buffer used by vmcp might be too small to hold the full response and as a result the response is truncated.
- On a 3270 console the CP command is executed on virtual CPU 0. The vmcp device driver uses the CPU that is scheduled by the Linux kernel. For CP commands that depend on the CPU number (like trace) you should specify the CPU, for example: cpu 3 trace count.
- Some CP commands do not return specific error or status messages through diagnose X'08'. These messages are only returned on a 3270 console. For example, the command vmcp link user1 1234 123 mw might return the message DASD 123 LINKED R/W in a 3270 console. This message will not appear when using vmcp. For details, see the z/VM help system or *z/VM CP Commands and Utilities Reference*, SC24-6175.

Setting up the z/VM CP interface

There are no module parameters for the vmcp device driver.

You must load the vmcp module before you can work with the z/VM CP interface device driver. You can use the **modprobe** command to load the module:

```
# modprobe vmcp
```

Using the device node

You can send a command to z/VM CP by writing to the vmcp device node. When writing to the device node you must:

- Omit the newline character at the end of the command string. For example, use **echo -n** when writing directly from a terminal session.
- Write the command in the same case as required on z/VM.
- Escape characters that need escaping in the environment where you issue the command.

Example:

The following command attaches a device to your z/VM guest virtual machine. The asterisk (*) is escaped to prevent the command shell from interpreting it.

```
# echo -n ATTACH 1234 \* > /dev/vmcp
```



You can also use the vmcp device node directly from an application using open, write (to issue the command), read (to get the response), ioctl (to get and set status) and close. The following ioctls are supported:

Table 39. The vmcp ioctls

Name	Code definition	Description
VMCP_GETCODE	_IOR (0x10, 1, int)	Queries the return code of z/VM.
VMCP_SETBUF	_IOW(0x10, 2, int)	Sets the buffer size (the device driver has a default of 4 KB; vmcp calls this ioctl to set it to 8 KB instead).
VMCP_GETSIZE	_IOR(0x10, 3, int)	Queries the size of the response.

Chapter 22. Deliver z/VM CP special messages as uevents

The `smsgiucv_app` kernel device driver receives z/VM CP special messages (MSG) and delivers these messages to user space as udev events (uevents). The device driver only receives messages starting with "APP". The generated uevents contain the message sender and content as environment variables. This is illustrated in Figure 43.




Figure 43. CP special messages as uevents in user space

You can restrict the received special messages to a particular z/VM user ID. CP special messages are discarded if the specified sender does not match the sender of the CP special message.

Setting up the CP special message device driver

The z/VM user ID does not require special authorizations to receive CP special messages. CP special messages can be issued from the local z/VM guest virtual machine or from other guest virtual machines. You can issue special messages from Linux or from a CMS or CP session.

This section describes the parameters that you can use to configure the special message device driver. See the Chapter 3, "Kernel and module parameters," on page 19 chapter for more details about specifying kernel and module parameters.

Module parameters

This section describes how to load and configure the CP special message device driver.

msgiucv_app syntax

```
modprobe msgiucv_app [sender=<user_ID>]
```

Where:

sender = <user_ID>

permits CP special messages from the specified z/VM user ID only. CP special messages are discarded if the specified sender does not match the sender of the CP special message. If the **sender** option is empty or not set, CP special messages are accepted from any z/VM user ID.

Lowercase characters are converted to uppercase.

To receive messages from several user IDs leave the sender= parameter empty, or do not specify it, and then filter with udev rules (see “Example” on page 246).

To load the msgiucv_app module automatically at boot time, see the section on persistent module loading in *Red Hat Enterprise Linux 6.3 Deployment Guide*.

Working with CP special messages

This section describes typical tasks that you need to perform when working with special messages.

- “Sending CP special messages”
- “Accessing CP special messages through uevent environment variables”
- “Writing udev rules for handling CP special messages” on page 245

Sending CP special messages

- To send a CP special message to LXGUEST1 from Linux, enter a command of the following form:

```
# vmcp MSG LXGUEST1 APP "<message text>"
```

- To send a CP special message to LXGUEST1, enter the following command from a CP or CMS session:

```
#CP MSG LXGUEST1 APP <message text>
```

The special messages cause uevents to be generated. See “Writing udev rules for handling CP special messages” on page 245 for information about handling the uevents.

Accessing CP special messages through uevent environment variables

When the device driver creates a uevent for a CP special message, the driver defines the following environment variables:

MSG_ID

Specifies the message prefix. The MSG_ID environment variable is always set to APP, which is the prefix assigned to the msgiucv_app device driver.

MSG_SENDER

Specifies the z/VM user ID that has sent the CP special message.

Use MSG_SENDER in udev rules for filtering the z/VM user ID if you want to accept CP special messages from different senders. All alphabetic characters in the z/VM user ID are uppercase characters.

MSG_TEXT

Contains the message text of the CP special message. The APP prefix and leading whitespaces are removed.

Writing udev rules for handling CP special messages

When using the msgiucv_app device driver, uevents with the following actions are triggered:

change events

The msgiucv_app device driver generates change uevents for each CP special message that has been received.

For example, the special message:

```
#CP MSG LXGUEST1 APP THIS IS A TEST MESSAGE
```

might trigger the following uevent:

```
UEVENT[1263487666.708881] change /devices/iucv/msgiucv_app (iucv)
ACTION=change
DEVPATH=/devices/iucv/msgiucv_app
SUBSYSTEM=iucv
MSG_SENDER=MAINT
MSG_ID=APP
MSG_TEXT=THIS IS A TEST MESSAGE
DRIVER=MSGIUCV
SEQNUM=1493
```

add and remove events

In addition to the change event for received CP special messages, generic add and remove events are generated when the module is loaded or unloaded, for example:

```
UEVENT[1263487583.511146] add /module/msgiucv_app (module)
ACTION=add
DEVPATH=/module/msgiucv_app
SUBSYSTEM=module
SEQNUM=1487

UEVENT[1263487583.514622] add /devices/iucv/msgiucv_app (iucv)
ACTION=add
DEVPATH=/devices/iucv/msgiucv_app
SUBSYSTEM=iucv
DRIVER=MSGIUCV
SEQNUM=1488

UEVENT[1263487628.955149] remove /devices/iucv/msgiucv_app (iucv)
ACTION=remove
DEVPATH=/devices/iucv/msgiucv_app
SUBSYSTEM=iucv
SEQNUM=1489

UEVENT[1263487628.957082] remove /module/msgiucv_app (module)
ACTION=remove
DEVPATH=/module/msgiucv_app
SUBSYSTEM=module
SEQNUM=1490
```

With the information from the uevents, you can create custom udev rules to trigger actions depending on the settings of the `SMSG_*` environment variables (see “Accessing CP special messages through uevent environment variables” on page 244).

When writing udev rules, use the add and remove uevents to initialize and clean up resources. To handle CP special messages, write udev rules that match change uevents. For more details about writing udev rules, see the udev man page.

Example

The following example shows how to process CP special messages using udev rules. The example contains rules for actions, one for all senders and one for the MAINT, OPERATOR, and LNXADM senders only.

The rules are contained in a block that matches uevents from the `smsgiucv_app` device driver. If there is no match, processing ends:

```
#
# Sample udev rules for processing CP special messages.
#
#
DEVPATH!="*/smsgiucv_app", GOTO="smsgiucv_app_end"

# ----- Rules for CP messages go here -----

LABEL="smsgiucv_app_end"
```

The example uses the **vmur** command. If the **vmur** kernel module has been compiled as a separate module, this module must be loaded first. Then the z/VM virtual punch device is activated.

```
# --- Initialization ---

# load vmcp
SUBSYSTEM=="module", ACTION=="add", RUN+="/sbin/modprobe --quiet vmcp"
# load vmur and set the virtual punch device online
SUBSYSTEM=="module", ACTION=="add", RUN+="/sbin/modprobe --quiet vmur"
SUBSYSTEM=="module", ACTION=="add", RUN+="/sbin/chccwdev -e d"
```

The following rule accepts messages from all senders. The message text must match the string `UNAME`. If it does, the output of the **uname** command (the node name and kernel version of the Linux instance) is sent back to the sender.

```
# --- Rules for all senders ----

# UNAME: tell the sender which kernel is running
ACTION=="change", ENV{SMSG_TEXT}=="UNAME", \
    PROGRAM="/bin/uname -n -r", \
    RUN+="/sbin/vmcp msg $env{SMSG_SENDER} '$result'"
```

In the following example block rules are defined to accept messages from certain senders only. If no sender matches, processing ends. The message text must match the string `DMESG`. If it does, the environment variable `PATH` is set and the output

of the **dmesg** command is sent into the z/VM reader of the sender. The name of the spool file is LINUX DMESG.

```
# --- Special rules available for particular z/VM user IDs ---

ENV{MSG_SENDER}!="MAINT|OPERATOR|LNxADM", GOTO="smsgiucv_app_end"

# DMESG: punch dmesg output to sender
ACTION=="change", ENV{MSG_TEXT}=="DMESG", \
    ENV{PATH}="/bin:/sbin:/usr/bin:/usr/sbin", \
    RUN+="/bin/sh -c 'dmesg |fold -s -w 74 |vmur punch -r -t -N LINUX.DMESG -u $env{MSG_SENDER}'"
```

Chapter 23. AF_IUCV address family support

The AF_IUCV address family provides an addressing mode for communications between applications that run on System z mainframes.

This addressing mode can be used for connections through real HiperSockets and through the z/VM Inter-User Communication Vehicle (IUCV).

Support for AF_IUCV based connections through real HiperSockets requires Completion Queue Support.

HiperSockets facilitate connections between applications across LPARs within a System z mainframe. In particular, an application running on an instance of Linux on System z can communicate with:

- Itself
- Other applications running on the same Linux instance
- An application on an instance of Linux on System z in another LPAR

IUCV facilitates connections between applications across z/VM guest virtual machines within a z/VM system. In particular, an application running on Linux on z/VM can communicate with:

- Itself
- Other applications running on the same Linux instance
- Applications running on other instances of Linux on z/VM, within the same z/VM system
- Applications running on a z/VM guest other than Linux, within the same z/VM system
- The z/VM control program (CP)

The AF_IUCV address family supports stream-oriented sockets (SOCK_STREAM) and connection-oriented datagram sockets (SOCK_SEQPACKET). Stream-oriented sockets can fragment data over several packets. Sockets of type SOCK_SEQPACKET always map a particular socket write or read operation to a single packet.

Features

The AF_IUCV address family provides socket connections for HiperSockets and IUCV.

For all instances of Linux on System z, the AF_IUCV address family provides:

- Multiple outgoing socket connections for real HiperSockets
- Multiple incoming socket connections for real HiperSockets

For instances of Linux on z/VM, the AF_IUCV address family also provides:

- Multiple outgoing socket connections for IUCV
- Multiple incoming socket connections for IUCV
- Socket communication with applications utilizing CMS AF_IUCV support

Setting up the AF_IUCV address family support

You need to authorize your z/VM guest virtual machine and load those components that have been compiled as separate modules.

There are no module parameters for the AF_IUCV address family support.

Setting up HiperSockets devices for AF_IUCV addressing

In AF_IUCV addressing mode, HiperSockets devices are identified through their `hsuid sysfs` attribute.

You set up a HiperSockets devices for AF_IUCV by assigning a value to this attribute (see “Configuring a HiperSockets device for AF_IUCV addressing” on page 128).

Setting up your z/VM guest virtual machine for IUCV

You need to specify certain required IUCV statements for your z/VM guest virtual machine.

For details and for general IUCV setup information for z/VM guest virtual machines see *z/VM CP Programming Services*, SC24-6179 and *z/VM CP Planning and Administration*, SC24-6178.

Granting IUCV authorizations:

Use the IUCV statement to grant the necessary authorizations.

IUCV ALLOW

allows any other z/VM virtual machine to establish a communication path with this z/VM virtual machine. With this statement, no further authorization is required in the z/VM virtual machine that initiates the communication.

IUCV ANY

allows this z/VM guest virtual machine to establish a communication path with any other z/VM guest virtual machine.

IUCV <user ID>

allows this z/VM guest virtual machine to establish a communication path to the z/VM guest virtual machine with the z/VM user ID <user ID>.

You can specify multiple IUCV statements. To any of these IUCV statements you can append the `MSGLIMIT <limit>` parameter. <limit> specifies the maximum number of outstanding messages that are allowed for each connection that is authorized by the statement. If no value is specified for `MSGLIMIT`, AF_IUCV requests 65 535, which is the maximum supported by IUCV.

Setting a connection limit:

Use the `OPTION` statement to limit the number of concurrent connections.

OPTION MAXCONN <maxno>

<maxno> specifies the maximum number of IUCV connections allowed for this virtual machine. The default is 64. The maximum is 65 535.

Example:

These sample statements allow any z/VM guest virtual machine to connect to your z/VM guest virtual machine with a maximum of 10 000 outstanding messages for each incoming connection. Your z/VM guest virtual machine is permitted to connect to all other z/VM guest virtual machines. The total number of connections for your z/VM guest virtual machine cannot exceed 100.

```
IUCV ALLOW MSGLIMIT 10000
IUCV ANY
OPTION MAXCONN 100
```

Loading the IUCV modules

Red Hat Enterprise Linux 6.3 loads the `af_iucv` module when an application requests a socket in the `AF_IUCV` domain.

You can also use the **modprobe** command to load the `AF_IUCV` address family support module `af_iucv`:

```
# modprobe af_iucv
```

Addressing AF_IUCV sockets in applications

To use `AF_IUCV` sockets in applications, you need to code a special `AF_IUCV` `sockaddr` structure.



This section provides information for those who want to use connections that are based on `AF_IUCV` addressing in their applications.

The primary difference between `AF_IUCV` sockets and TCP/IP sockets is how communication partners are identified (for example, how they are named). To use the `AF_IUCV` support in an application, code a `sockaddr` structure with `AF_IUCV` as the socket address family and with `AF_IUCV` address information.

```
struct sockaddr_iucv {
    sa_family_t    siucv_family;    /* AF_IUCV */
    unsigned short siucv_port;      /* reserved */
    unsigned int   siucv_addr;      /* reserved */
    char           siucv_nodeid[8]; /* reserved */
    char           siucv_userid[8]; /* guest user id */
    char           siucv_name[8];   /* application name */
};
```

Where:

siucv_family

is set to `AF_IUCV` (= 32).

siucv_port, siucv_addr, and siucv_nodeid

are reserved for future use. The `siucv_port` and `siucv_addr` fields must be zero. The `siucv_nodeid` field must be set to exactly eight blanks.

siucv_userid

specifies a HiperSockets device or a z/VM guest virtual machine. This specification implicitly sets the connection type for the socket to a HiperSockets connection or to a z/VM IUCV connection.

This field must be eight characters long and, if necessary, padded at the end with blanks.

For HiperSockets connections, the `siucv_userid` field specifies the identifier that is set with the `hsuid` sysfs attribute of the HiperSockets device. For bind

this is the identifier of a local device, and for connect this is the identifier of the HiperSockets device of the communication peer.

For IUCV connections, the `siucv_userid` field specifies a z/VM user ID. For bind this is the identifier of the local z/VM guest virtual machine, and for connect this is the identifier of the z/VM guest virtual machine for the communication peer.

Tip: For bind you can also specify eight blanks. The AF_IUCV address family support then automatically substitutes the local z/VM user ID for you.

siucv_name

is set to the application name by which the socket is known. Servers advertise application names and clients use these application names to connect to servers. This field must be eight characters long and, if necessary, padded with blanks at the end.

Similar to TCP or UDP ports, application names distinguish distinct applications on the same operating system instance. Do not call bind for names beginning with `lnxhvc`. These names are reserved for the z/VM IUCV HVC device driver.

For details see the `af_iucv` man page.

Chapter 24. Cooperative memory management

Cooperative memory management (CMM, or "cmm1") can reduce the memory that is available to an instance of Linux on z/VM. CMM allocates pages to page pools that are not available to Linux. A diagnose code indicates to z/VM that the pages in the page pools are out of use. z/VM can then immediately reuse these pages for other z/VM guests.

To set up CMM, you need to:

1. Load the cmm module.
2. Set up a resource management tool that controls the page pool. This can be the z/VM resource monitor (VMRM) or a third party systems management tool.

This chapter describes how to set up CMM. For background information about CMM, see "Cooperative memory management background" on page 195.

You can also use the **cpuplugd** command to define rules for cmm behavior, see "Basic configuration file for memory control" on page 417.

Setting up the external resource manager is beyond the scope of this book. For more information, see the chapter on VMRM in *z/VM Performance*, SC24-6208.


Setting up cooperative memory management

This section describes how to set up Linux on z/VM to participate in the cooperative memory management.

Loading the cooperative memory management module

The cooperative memory management support is compiled as a module, cmm. Use the **modprobe** command to load the module. See the **modprobe** man page for command details.

cooperative memory management module parameter syntax



where *<user_ID>* specifies the z/VM guest virtual machine that is permitted to send messages to the module through the special messages interface. The default z/VM user ID is VMRMSVM, which is the default for the VMRM service machine.

To load the cmm module automatically at boot time, see the section on persistent module loading in *Red Hat Enterprise Linux 6.3 Deployment Guide*.

Example:

To load the cooperative memory management module and allow the z/VM guest virtual machine TESTID to send messages:

```
# modprobe cmm sender=TESTID
```

Working with cooperative memory management

After it has been set up, CMM works through the resource manager. No further actions are necessary. The following information is given for diagnostic purposes.

To reduce the Linux memory size, CMM allocates pages to page pools that make the pages unusable to Linux. There are two such page pools, a static pool and a timed pool. You can use the `procfs` interface to read the sizes of the page pools.

Reading the size of the static page pool

To read the current size of the static page pool:

```
# cat /proc/sys/vm/cmm_pages
```

Reading the size of the timed page pool

To read the current size of the timed page pool:

```
# cat /proc/sys/vm/cmm_timed_pages
```

Part 5. System resources

This section describes device drivers and features that help to manage the resources of your real or virtual hardware.

Newest version: You can find the newest version of this book at www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

Restrictions: For prerequisites and restrictions see the System z architecture specific information in the Red Hat Enterprise Linux 6.3 release notes at docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

Chapter 25. Managing CPUs.	257
CPU capability change	257
Activating standby CPUs and deactivating operating CPUs	257
Examining the CPU topology	258
CPU polarization	259
 Chapter 26. Managing hotplug memory.	 261
What you should know about memory hotplug	261
Setting up hotplug memory	262
Performing memory management tasks	262
 Chapter 27. Large page support	 265
Setting up large page support	265
Working with large page support.	265
 Chapter 28. S/390 hypervisor file system	 267
Directory structure	267
Setting up the S/390 hypervisor file system	270
Working with the S/390 hypervisor file system	270
 Chapter 29. ETR and STP based clock synchronization	 273
Setting up clock synchronization	273
Switching clock synchronization on and off	274
 Chapter 30. Identifying the System z hardware	 277

Chapter 25. Managing CPUs

You can read CPU capability, activate standby CPUs, and examine the CPU topology using the CPU attributes in sysfs.

The attributes that govern CPUs are available in sysfs under:

```
/sys/devices/system/cpu/cpu<N>
```

where <N> is the number of the CPU.

CPU capability change

When the CPUs of a mainframe heat or cool, the Linux kernel generates a uevent for all affected online CPUs. You can read the CPU capability in:

```
/sys/devices/system/cpu/cpu<N>/capability
```

The capability value is an unsigned integer as defined in the system information block (SYSIB) 1.2.2 (see *z/Architecture Principles of Operation*, SA22-7832). A smaller value indicates a proportionally greater CPU capacity. Beyond that, there is no formal description of the algorithm used to generate this value. The value is used as an indication of the capability of the CPU relative to the capability of other CPU models.

Activating standby CPUs and deactivating operating CPUs

A CPU on an LPAR can be in a configured, standby, or reserved state. Under Linux, on IPL only CPUs that are in a configured state are brought online and used. The kernel operates only with configured CPUs. You can change the state of standby CPUs to configured state and vice versa.

Reserved CPUs cannot be used without manual intervention and therefore are not recognized.

Before you begin:

- To put a CPU into standby state the underlying hypervisor needs to support this operation.
- Be aware that daemon processes like **cpuplugd** can change the state of any CPU at any time. This can interfere with manual changes.

To configure or deconfigure a CPU its physical address needs to be known. Because the sysfs interface is used to configure a CPU by its sysfs entry this requires a static mapping of physical to logical CPU numbers. The physical address of a CPU can be found in the address attribute of a logical CPU:

```
# cat /sys/devices/system/cpu/cpu<N>/address
```

For example:

```
# cat /sys/devices/system/cpu/cpu0/address  
0
```

To activate a standby CPU:

1. Only present CPUs have a sysfs entry. If you add a CPU to the system the kernel automatically detects it. You can force the detection of a CPU using the rescan attribute. To rescan, write any string to the rescan attribute, for example:

```
echo 1 > /sys/devices/system/cpu/rescan
```

When new CPUs are found new sysfs entries are created and they are in the configured or standby state depending on how the hypervisor added them.

2. Change the state of the CPU to configured by writing "1" to its configure attribute:

```
echo 1 > /sys/devices/system/cpu/cpu<X>/configure
```

where <X> is any CPU in standby state.

3. Bring the CPU online by writing "1" to its online attribute:

```
echo 1 > /sys/devices/system/cpu/cpu<X>/online
```

To deactivate an operating CPU:

1. Bring the CPU offline by writing "0" to its online attribute:

```
echo 0 > /sys/devices/system/cpu/cpu<X>/online
```

2. Change the state of the CPU to standby by writing "0" to its configure attribute:

```
echo 0 > /sys/devices/system/cpu/cpu<X>/configure
```

Examining the CPU topology

If supported by your hardware, an interface is available that you can use to get information about the CPU topology of an LPAR. Use this, for example, to optimize the Linux scheduler, which bases its decisions on which process gets scheduled to which CPU. Depending on the workload, this might increase cache hits and therefore overall performance.

Note: By default CPU topology support is enabled in the Linux kernel. If it is not suitable for your workload, disable the support by specifying the kernel parameter `topology=off` in your `parmfile` or `zipl.conf`. See “Specifying kernel parameters” on page 19 for information about how to do this.

The common code attributes `core_siblings` and `core_id` are visible for all online CPUs:

```
/sys/devices/system/cpu/cpu<N>/topology/core_siblings  
/sys/devices/system/cpu/cpu<N>/topology/core_id
```

The attributes `core_siblings` contains a CPU mask that tells you which CPUs (including the current one) are close to each other. If a machine reconfiguration causes the CPU topology to change, change uevents are created for each online CPU. All CPUs that have the same `core_siblings` CPU mask have the same `core_id`.

If the kernel also supports standby CPU activation/deactivation (see “Activating standby CPUs and deactivating operating CPUs” on page 257), the `core_siblings` CPU mask also contains the CPUs that are in a configured, but offline state. Updating the mask after a reconfiguration might take up to a minute.

With zEnterprise, the book topology level was added above the core level. The `book_siblings` and `book_id` files describe which CPUs on different cores belong to the same book:

```
# cat /sys/devices/system/cpu/cpu1/topology/book_siblings
00000000,0000001f
# cat /sys/devices/system/cpu/cpu1/topology/book_id
2
```

The CPU masks contained in the `book_siblings` file are always a superset of the `core_siblings` file. All CPUs that have the same `book_siblings` CPU mask have the same `book_id`. If there are several books present in a configuration, the `core_ids` are only unique per book.

CPU polarization

You can optimize the operation of a vertical SMP environment by adjusting the SMP factor based on the workload demands. During peak workloads the operating system may operate on a large n-way, with all CPUs busy, whereas at other times it may fall back to a single processor. This limits the performance effects of context switches, TLB flushes, cache poisoning, as well as dispatcher workload balancing and the like, by delivering better processor affinity for particular workloads.

Horizontal CPU polarization means that the underlying hypervisor will dispatch each virtual CPU of all z/VM guest virtual machines for the same amount of time.

If vertical CPU polarization is active then the hypervisor will dispatch certain CPUs for a longer time than others for maximum performance. For example, if a guest has three virtual CPUs, each of them with a share of 33%, then in case of vertical CPU polarization all of the processing time would be combined to a single CPU which would run all the time, while the other two CPUs would get nearly no CPU time.

There are three types of vertical CPUs: high, medium, and low. Low CPUs hardly get any real CPU time, while high CPUs get a full real CPU. Medium CPUs get something in between.

Note: Running a system with different types of vertical CPUs may result in significant performance regressions. If possible, use only one type of vertical CPUs. Set all other CPUs offline and deconfigure them.

Use the dispatching attribute to switch between horizontal and vertical CPU polarization. To switch between the two modes write a 0 for horizontal polarization (the default) or a 1 for vertical polarization to the dispatching attribute.

```
/sys/devices/system/cpu/dispatching
```

The polarization of each CPU can be seen from the polarization attribute of each CPU:

```
/sys/devices/system/cpu/cpu<N>/polarization
```

Its contents is one of:

- `horizontal` - each of the guests' virtual CPUs is dispatched for the same amount of time.
- `vertical:high` - full CPU time is allocated.
- `vertical:medium` - medium CPU time is allocated.
- `vertical:low` - very little CPU time is allocated.
- `unknown`

When switching polarization the polarization attribute might contain the value `unknown` until the configuration change is done and the kernel has figured out the new polarization of each CPU.

Chapter 26. Managing hotplug memory

You can dynamically increase or decrease the memory for your running Linux instance. To make memory available as hotplug memory you must define it to your LPAR or z/VM. Hotplug memory is supported by z/VM 5.4 with the PTF for APAR VM64524 and by later z/VM versions.

What you should know about memory hotplug

This section explains how hotplug memory is represented in sysfs and how rebooting Linux affects hotplug memory.

How memory is represented in sysfs

The memory with which Linux is started is the *core memory*. On the running Linux system, additional memory can be added as *hotplug memory*. The Linux kernel requires core memory to allocate its own data structures.

In sysfs, both the core memory of a Linux instance and the available hotplug memory are represented in form of memory sections of equal size. Each section is represented as a directory of the form `/sys/devices/system/memory/memory<n>`, where `<n>` is an integer. You can find out the section size by reading the `/sys/devices/system/memory/block_size_bytes` attribute.

In the naming scheme, the memory sections with the lowest address ranges are assigned the lowest integer numbers. Accordingly, the core memory begins with `memory0`. The hotplug memory sections follow the core memory sections.

You can infer where the hotplug memory begins by calculating the number of core memory sections from the size of the base memory and the section size. For example, for a core memory of 512 MB and a section size of 128 MB, the core memory is represented by 4 sections, `memory0` through `memory3`. In this example, the first hotplug memory section is `memory4`. Another Linux instance with a core memory of 1024 MB and access to the same hotplug memory, represents this first hotplug memory section as `memory8`.

The hotplug memory is available to all operating system instances within the z/VM system or LPARs to which it has been defined. The state `sysfs` attribute of a memory section indicates whether the section is in use by your own Linux system. The state attribute does not indicate whether a section is in use by another operating system instance. Attempts to add memory sections that are already in use fail.

Hotplug memory and reboot

The original core memory is preserved as core memory and hotplug memory is freed when rebooting a Linux instance.

When you perform an IPL after shutting down Linux, always use `ipl clear` to preserve the original memory configuration.

Further information

For more information about memory hotplug, see `Documentation/memory-hotplug.txt` in the Linux source tree.

Setting up hotplug memory

Before you can use hotplug memory on your Linux instance, you must define this memory as hotplug memory on your physical or virtual hardware.

Defining hotplug memory to an LPAR

You use the hardware management console (HMC) to define hotplug memory as *reserved storage* on an LPAR.

For information about defining reserved storage for your LPAR see the *Processor Resource/Systems Manager™ Planning Guide*, SB10-7041 for your mainframe.

Defining hotplug memory to z/VM

In z/VM, you define hotplug memory as *standby storage*. There is also *reserved storage* in z/VM, but other than reserved memory defined for an LPAR, reserved storage defined in z/VM is not available as hotplug memory.

For information about defining standby memory for z/VM guests see the “DEFINE STORAGE” section in *z/VM CP Commands and Utilities Reference*, SC24-6175.

Performing memory management tasks

This section describes typical memory management tasks.

- Finding out the memory section size
- Displaying the available memory sections
- Adding memory
- Removing memory

Finding out the memory section size

You can find out the size of your memory sections by reading `/sys/devices/system/memory/block_size_bytes`. This `sysfs` attribute contains the section size in byte in hexadecimal notation.

Example:

```
# cat /sys/devices/system/memory/block_size_bytes
8000000
```

This hexadecimal value corresponds to 128 MB.

Displaying the available memory sections

You can find out if a memory section is online or offline by reading its `state` attribute. The following example shows how you can get an overview of all available memory sections:

```
# grep -r --include="state" "line" /sys/devices/system/memory/  
/sys/devices/system/memory/memory0/state:online  
/sys/devices/system/memory/memory1/state:online  
/sys/devices/system/memory/memory2/state:online  
/sys/devices/system/memory/memory3/state:online  
/sys/devices/system/memory/memory4/state:offline  
/sys/devices/system/memory/memory5/state:offline  
/sys/devices/system/memory/memory6/state:offline  
/sys/devices/system/memory/memory7/state:offline
```

Online sections are in use by your Linux instance. An offline section can be free to be added to your Linux instance but it might also be in use by another Linux instance.

Adding memory

You add a hotplug memory section by writing `online` to its `sysfs` state attribute.

Example:

Enter the following command to add a memory section `memory5`:

```
# echo online > /sys/devices/system/memory/memory5/state
```

Adding the memory section fails, if the memory section is already in use. The state attribute changes to `online` when the memory section has been added successfully.

Suspend and resume:

Do not add hotplug memory if you intend to suspend the Linux instance before the next IPL. Any changes to the original memory configuration prevent suspension, even if you restore the original memory configuration by removing memory sections that have been added. See Chapter 37, “Suspending and resuming Linux,” on page 365 for more information about suspending and resuming Linux.

Removing memory

You remove a hotplug memory section by writing `offline` to its `sysfs` state attribute.

Avoid removing core memory. The Linux kernel requires core memory to allocate its own data structures.

Example:

Enter the following command to remove a memory section `memory5`:

```
# echo offline > /sys/devices/system/memory/memory5/state
```

The hotplug memory functions first relocate memory pages to free the memory section and then remove it. The state attribute changes to `offline` when the memory section has been removed successfully.

The memory section is not removed if it cannot be freed completely.

Chapter 27. Large page support

Large page support entails support for the Linux hugetlbfs file system. This virtual file system is backed by larger memory pages than the usual 4 K pages; for System z the hardware page size is 1 MB.

Applications using large page memory will save a considerable amount of page table memory. Another benefit from the support might be an acceleration in the address translation and overall memory access speed.

Setting up large page support

This section describes the parameters that you can use to configure large page support.

Kernel parameters

This section describes how to configure large page support. You configure large page support by adding parameters to the kernel parameter line.

Large page support kernel parameter syntax

►—hugepages=<number>—————◄◄

where:

number

is the number of large pages to be allocated at boot time.

Note: If you specify more pages than available, Linux will reserve as many as possible. This will most probably leave too few general pages for the boot process and might stop your system with an out-of-memory error.

Working with large page support

This section describes typical tasks that you need to perform when working with large page support.

- The "hugepages=" kernel parameter should be specified with the number of large pages to be allocated at boot time. To read the current number of large pages, issue:

```
cat /proc/sys/vm/nr_hugepages
```

- To change the number of large pages dynamically during run-time, write to procfs:

```
echo 12 > /proc/sys/vm/nr_hugepages
```

If there is not enough contiguous memory available to fulfill the request, the maximum number of large pages will be reserved.

- To obtain information about amount of large pages currently available and the large page size, issue:

```
cat /proc/meminfo  
  
...  
HugePages_Total: 20  
HugePages_Free: 14  
Hugepagesize: 1024 KB  
...
```

- To see if hardware large page support is enabled (indicated by the word "edat" in the "features" line), issue:

```
cat /proc/cpuinfo  
  
...  
features : esan3 zarch stfle msa ldisp eimm dfp edat  
...
```

The large page memory can be used through `mmap()` or SysV shared memory system calls, more detailed information can be found in the Linux kernel source tree under `Documentation/vm/hugetlbpage.txt`, including implementation examples.

To make a Java program use the large page feature, specify the Java `-Xlp` option.

Chapter 28. S/390 hypervisor file system

The S/390[®] hypervisor file system provides a mechanism to access LPAR and z/VM hypervisor data.

Directory structure

When the hypfs file system is mounted the accounting information is retrieved and a file system tree is created with a full set of attribute files containing the CPU information.

The recommended mount point for the hypervisor file system is `/sys/hypervisor/s390`.

Figure 44 illustrates the file system tree that is created for LPAR.




Figure 44. The hypervisor file system for LPAR

LPAR directories and attributes

The directories and attributes have the following meaning for the LPAR hypervisor:

update

Write-only file to trigger an update of all attributes.

cpus/ Directory for all physical CPUs.

cpus/<cpu ID>

Directory for one physical CPU. `<cpu ID>` is the logical (decimal) CPU number.

type Type name of physical CPU, such as CP or IFL.

mgmtime
Physical-LPAR-management time in microseconds (LPAR overhead).

hyp/ Directory for hypervisor information.

hyp/type
Type of hypervisor (LPAR hypervisor).

systems/
Directory for all LPARs.

systems/<lpar name>/
Directory for one LPAR.

systems/<lpar name>/cpus/<cpu ID>/
Directory for the virtual CPUs for one LPAR. The <cpu ID> is the logical (decimal) CPU number.

type Type of the logical CPU, such as CP or IFL.

mgmtime
LPAR-management time. Accumulated number of microseconds during which a physical CPU was assigned to the logical CPU and the CPU time was consumed by the hypervisor and was not provided to the LPAR (LPAR overhead).

cputime
Accumulated number of microseconds during which a physical CPU was assigned to the logical CPU and the CPU time was consumed by the LPAR.

onlinetime
Accumulated number of microseconds during which the logical CPU has been online.

Note: For older machines the `onlinetime` attribute might be missing. In general, user space applications should be prepared that attributes are missing or new attributes are added to the file system. To check the content of the files you can use tools such as `cat` or `less`.

z/VM directories and attributes

The directories and attributes have the following meaning for the z/VM hypervisor:

update
Write-only file to trigger an update of all attributes.

cpus/ Directory for all physical CPUs.

cpus/count
Total current CPUs.

hyp/ Directory for hypervisor information.

hyp/type
Type of hypervisor (z/VM hypervisor).

systems/
Directory for all z/VM guest virtual machines.

systems/<guest name>/
Directory for one z/VM guest virtual machine.

systems/<guest name>/onlinetime_us
Time in microseconds that the guest virtual machine has been logged on.

systems/<guest name>/cpus/
Directory for the virtual CPUs for one guest virtual machine.

capped
Flag that shows whether CPU capping is on for the guest virtual machine (0 = off, 1 = soft, 2 = hard).

count Total current virtual CPUs in the guest virtual machine.

cputime_us
Number of microseconds where the guest virtual machine CPU was running on a physical CPU.

dedicated
Flag that shows if the guest virtual machine has at least one dedicated CPU (0 = no, 1 = yes).

weight_cur
Current share of guest virtual machine (1-10000); 0 for ABSOLUTE SHARE guests.

weight_max
Maximum share of guest virtual machine (1-10000); 0 for ABSOLUTE SHARE guests.

weight_min
Minimum share of guest virtual machine (1-10000); 0 for ABSOLUTE SHARE guests.

systems/<guest name>/samples/
Directory for sample information for one guest virtual machine.

cpu_delay
Number of CPU delay samples attributed to the guest virtual machine.

cpu_using
Number of CPU using samples attributed to the guest virtual machine.

idle Number of idle samples attributed to the guest virtual machine.

mem_delay
Number of memory delay samples attributed to the guest virtual machine.

other Number of other samples attributed to the guest virtual machine.

total Number of total samples attributed to the guest virtual machine.

systems/<guest name>/mem/
Directory for memory information for one guest virtual machine.

max_KiB
Maximum memory in KiB (1024 bytes).

min_KiB
Minimum memory in KiB (1024 bytes).

share_KiB

Guest estimated core working set size in KiB (1024 bytes).

used_KiB

Resident memory in KiB (1024 bytes).

To check the content of the files you can use tools such as `cat` or `less`.

Setting up the S/390 hypervisor file system

To use the file system, it has to be mounted. You can do this either manually with the `mount` command or with an entry in `/etc/fstab`.

To mount the file system manually issue the following command:

```
# mount none -t s390_hypfs <mount point>
```

where `<mount point>` is where you want the file system mounted. Preferably, use `/sys/hypervisor/s390`.

If you want to put hypfs into your `/etc/fstab` you can add the following line:

```
none <mount point> s390_hypfs defaults 0 0
```

Note that if your z/VM system does not support DIAG 2fc, the `s390_hypfs` will not be activated and it is not possible to mount the file system. You will see an error message like the following:

```
mount: unknown filesystem type 's390_hypfs'
```

To get data for all z/VM guests, privilege class B is required for the guest, where hypfs is mounted. For non-class B guests, only data for the local guest is provided.

Working with the S/390 hypervisor file system

This section describes typical tasks that you need to perform when working with the S/390 hypervisor file system.

- Defining access permissions
- Updating hypfs information

Defining access permissions

If no mount options are specified, the files and directories of the file system get the uid and gid of the user who mounted the file system (normally root). It is possible to explicitly define uid and gid using the mount options `uid=<number>` and `gid=<number>`.

Example: You can define `uid=1000` and `gid=2000` with the following mount command:

```
# mount none -t s390_hypfs -o "uid=1000,gid=2000" <mount point>
```

Alternatively, you can add the following line to the `/etc/fstab` file:

```
none <mount point> s390_hypfs uid=1000,gid=2000 0 0
```

The first mount defines uid and gid. Subsequent mounts automatically have the same uid and gid setting as the first one.

The permissions for directories and files are as follows:

- Update file: 0220 (--w--w----
- Regular files: 0440 (-r--r-----)
- Directories: 0550 (dr-xr-x---

Updating hypfs information

You trigger the update process by writing something into the update file at the top level hypfs directory. For example, you can do this by writing the following:

```
echo 1 > update
```

During the update the whole directory structure is deleted and rebuilt. If a file was open before the update, subsequent reads will return the old data until the file is opened again. Within one second only one update can be done. If within one second more than one update is triggered, only the first one is done and the subsequent write system calls return -1 and errno is set to EBUSY.

If an application wants to ensure consistent data, the following should be done:

1. Read modification time through `stat(2)` from the update attribute.
2. If data is too old, write to the update attribute and go to 1.
3. Read data from file system.
4. Read modification time of the update attribute again and compare it with first timestamp. If the timestamps do not match then go to 2.

Chapter 29. ETR and STP based clock synchronization

Your Linux instance might be part of an extended remote copy (XRC) setup that requires synchronization of the Linux time-of-day (TOD) clock with a timing network.

Linux on System z supports external time reference (ETR) and system time protocol (STP) based TOD synchronization. ETR and STP work independently of one another. If both ETR and STP are enabled, Linux might use either to synchronize the clock.

For more information about ETR see the IBM Redbooks® technote at www.ibm.com/redbooks/abstracts/tips0217.html

For information about STP see www.ibm.com/systems/z/advantages/pso/stp.html

Both ETR and STP support are included in the Linux kernel. No special build options are required.

ETR requires at least one ETR unit that is connected to an external time source. For availability reasons, many installations use a second ETR unit. The ETR units correspond to two ETR ports on Linux. Always set both ports online if two ETR units are available.


Attention: Be sure that a reliable timing signal is available before enabling clock synchronization. With enabled clock synchronization, Linux expects regular timing signals and might stop indefinitely to wait for such signals if it does not receive them.

Setting up clock synchronization

This section describes the kernel parameters that you can use to set up synchronization for your Linux TOD clock. These kernel parameters specify the initial synchronization settings. On a running Linux instance you can change these settings through attributes in sysfs (see “Switching clock synchronization on and off” on page 274).

Enabling ETR based clock synchronization

Use the `etr=` kernel parameter to set ETR ports online when Linux is booted. ETR based clock synchronization is enabled if at least one ETR port is online.



Switching STP based clock synchronization on and off

To switch on STP based clock synchronization set `/sys/devices/system/stp/online` to "1". To switch off STP based clock synchronization set this attribute to "0".

Example: To switch off STP based clock synchronization enter:

```
# echo 0 > /sys/devices/system/stp/online
```

Chapter 30. Identifying the System z hardware

In installations with several System z mainframes, you might need to identify the particular hardware system on which a Linux instance is running. Two attributes in `/sys/firmware/ocf` can help you to identify the hardware.

cpc_name

contains the name assigned to the central processor complex (CPC). This is the name that identifies the mainframe system on a hardware management console (HMC).

hmc_network

contains the name of the HMC network to which the mainframe system is connected.

The two attributes contain the empty string if the Linux instance runs as a guest of a hypervisor that does not support the operations command facility (OCF) communication parameters interface.

Use the **cat** command to read these attributes.

Example:

```
# cat /sys/firmware/ocf/cpc_name
Z05
# cat /sys/firmware/ocf/hmc_network
SNA00
```

Part 6. Security

This part describes device drivers and features that support security aspects of Red Hat Enterprise Linux 6.3 for System z.

Newest version: You can find the newest version of this book at www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

Restrictions: For prerequisites and restrictions see the System z architecture specific information in the Red Hat Enterprise Linux 6.3 release notes at docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

Chapter 31. Generic cryptographic device driver 281

Features	281
What you should know about zcrypt	282
Setting up the z90crypt device driver	285
Working with cryptographic devices.	287
External programming interfaces	291

Chapter 32. Pseudo-random number device driver. 293

What you should know about the pseudo-random number device driver	293
Setting up the pseudo-random number device driver	293
Reading pseudo-random numbers	293

Chapter 33. Data execution protection for user processes 295

Features	295
What you should know about the data execution protection feature	295
Enabling the data execution protection feature	295
Working with the data execution protection feature	296

Chapter 31. Generic cryptographic device driver

The generic cryptographic device driver (zcrypt) supports cryptographic coprocessor and accelerator hardware.

Some cryptographic processing in Linux can be off-loaded from the CPU and performed by dedicated coprocessors or accelerators. Several of these coprocessors and accelerators are available offering a range of features. The generic cryptographic device driver (z90crypt) is required when one or more of these devices are available in the hardware.

Features

The cryptographic device driver supports a range of hardware and software functions.

Supported devices

The cryptographic device driver supports several cryptographic coprocessors and accelerators.

- Crypto Express2 Coprocessor (CEX2C)
- Crypto Express2 Accelerator (CEX2A)
- Crypto Express3 Coprocessor (CEX3C)
- Crypto Express3 Accelerator (CEX3A)

Note: For z/VM 6.1 and 5.4 the PTF for APAR VM64656 is required for support of CEX3C and CEX3A cards. To correct a shared feature problem, the PTF for APAR VM64727 is required. To use the protected key functionality under z/VM and CCA you require APAR VM64793.

For information about setting up your cryptographic environment on Linux under z/VM, see *Security on z/VM*, SG24-7471 and *Security for Linux on System z*, SG24-7728.

Supported facilities

The cryptographic device driver supports several cryptographic operations.

- Clear key encryption and decryption using the Rivest-Shamir-Adleman (RSA) exponentiation operation using either a modulus-exponent (Mod-Expo) or Chinese-Remainder Theorem (CRT) key.
CEX3A feature support of RSA keys with 4096 bit length became available for z196 with MCL N29766.021 in December, 2010.
- Secure key encryption and decryption - see *Secure Key Solution with the Common Cryptographic Architecture Application Programmer's Guide*, SC33-8294. You can obtain this book at www.ibm.com/security/cryptocards/pciicc/library.shtml.
- Generation of long random numbers, see "Generating and accessing long random numbers" on page 290.

What you should know about zcrypt

Your use of zcrypt and the cryptographic hardware might need additional software. There are special considerations for Linux on z/VM, for performance, and for specific cryptographic operations.

Cryptographic devices for Linux on z/VM

A z/VM guest virtual machine can either have one or more dedicated cryptographic devices or one shared cryptographic device, but not both.

Dedicated devices

Each dedicated device maps to exactly one hardware device. The device representations in Linux on z/VM show the type of the actual hardware.

Shared device

The shared device can map to one or more hardware devices. The device representation in Linux on z/VM shows the type of the most advanced of these hardware devices. Generally, cryptographic accelerators (CEX3A, CEX2A, PCICA) are considered more advanced than coprocessors (CEX3C, CEX2C, PCIXCC, PCICC).

As a consequence, Linux on z/VM with access to a shared cryptographic accelerator can either observe an accelerator or a coprocessor, but not both.

Software components

You need several software components to run programs that use the zcrypt device driver for clear key encryption.

- The device driver module z90crypt
- The libica library, unless applications call the device driver directly.

You can use the libica library for generation of RSA key pairs, symmetric and asymmetric encryption, and message hashing.

For more information about libica, see “The libica library” on page 286.

- The openCryptoki library if applications use the PKCS #11 API.

To run programs that use the z90crypt device driver for secure key encryption, you need:

- The device driver module
- The CCA library, see “The CCA library” on page 286

Figure 45 on page 283 shows a simplified overview of the software relationships.




Figure 45. z90crypt device driver interfaces

In Figure 45, applications A, B, and C exemplify three common configurations.

Application A

uses secure key encryption. See *Secure Key Solution with the Common Cryptographic Architecture Application Programmer's Guide*, SC33-8294 for more details and specific setups. You can obtain this book at www.ibm.com/security/cryptocards/pciecc/library.shtml.

Application B

uses clear key cryptography through the openssl engine and the libica library. This setup requires the openssl-ibmca RPM.

Application C

uses clear key cryptography through the openCryptoki PKCS #11 API and the libica library. Java applications need the IBM PKCS #11 provider to access this API.

You can obtain the provider from developerWorks: Go to www.ibm.com/developerworks/java/jdk/security/index.html, click the link for your Java version, and search for "PKCS".

Independent of the cryptographic device driver, the CCA library and libica can address CP Assist for Cryptographic Function (CPACF).

See "The libica library" on page 286, "The openCryptoki library" on page 286, and "The CCA library" on page 286 for more information about these libraries.

See "Setting up the z90crypt device driver" on page 285 for information about setting up the different components.

Hardware and software prerequisites

Support for the Crypto Express2 and Crypto Express3 features depends on the System z hardware.

- The CEX2A and CEX2C features are supported on System z10 and System z9.
- The CEX3A and CEX3C features are supported on z196, z114, and System z10 (as of October 2009).

You require the following software:

- For the CEX3C and CEX3A features, you require APAR VM64656 for Linux on z/VM 6.1 or 5.4. To correct a shared coprocessor problem, APAR VM64727 is required.
- For the secure key cryptographic functions on the CEX2C and CEX3C features, you must use the CCA library. To use the protected key functionality under z/VM and CCA you require APAR VM64793. You can download the CCA library from the IBM cryptographic coprocessor web page at www.ibm.com/security/cryptocards

Note: The CCA library works with 64-bit applications only.

For information about CEX2C and CEX3C feature coexistence and how to use CCA functions, see *Secure Key Solution with the Common Cryptographic Architecture Application Programmer's Guide*, SC33-8294. You can obtain this book at www.ibm.com/security/cryptocards/pciicc/library.shtml.

- For the clear key cryptographic functions, you should use the libica library.

Ensuring the correct length for RSA encryption requests

Cryptographic coprocessors might reject RSA encryption requests for which the numerical value of the data to be encrypted is greater than the modulus.

Such requests are then processed in software by libica functions instead and no performance gain can be expected through hardware acceleration.

Load balancing

To maximize performance, the device driver uses a load balancing algorithm to distribute requests across all available AP bus devices.

The algorithm uses a list holding all AP bus devices sorted by increasing utilization. A new request will be submitted to the AP bus device with the lowest utilization. The increased load will move this device further toward the end of the device list after a re-sort is done. When a device completes processing a request, the device will move up toward the beginning of the device list. To take in account different processing speeds per device type, each device has a speed rating assigned which is also used to calculate the device utilization.

The z90crypt device driver assigns work to cryptographic devices according to device type in the following order:

1. CEX3A
2. CEX2A
3. CEX3C
4. CEX2C

Setting up for the 31-bit compatibility mode

31-bit applications can access the 64-bit zcrypt driver by using the 31-bit compatibility mode.

Notes:

1. The CCA library works with 64-bit applications only.
2. Clear key encryption and decryption with 4096-bit key length, as introduced with CEX3, works on 64-bit systems only.

Setting up the z90crypt device driver


Configure the zcrypt device driver through the `domain=` and the `poll_thread=` module parameters. You might also have to set up libraries.

For information about setting up cryptographic hardware on your mainframe, see *zSeries Crypto Guide Update*, SG24-6870.

Monolithic module parameters

You can configure the cryptographic device driver when you load the z90crypt module.

z90crypt module syntax



where

<domain>

is an integer in the range from 0 to 15 that identifies the cryptographic domain for the Linux instance.

The default (“domain=-1”) causes the device driver to attempt to autodetect and use the domain index with the maximum number of devices.

You need to specify the domain parameter only if you are running Linux in an LPAR for which multiple cryptographic domains have been defined.

<poll_thread>

is an integer argument and enables a polling thread to tune cryptographic performance. Valid values are 1 (enabled) or 0 (disabled, this is the default).

The z90crypt driver can run with or without polling thread. When running with the polling thread, one CPU constantly polls the cryptographic cards for finished cryptographic requests while requests are being processed. The polling thread will sleep when no cryptographic requests are being processed. This mode uses the cryptographic cards as much as possible at the cost of blocking one CPU during cryptographic operations.

Without polling thread the cryptographic cards are polled at a much lower rate, resulting in higher latency and reduced throughput for cryptographic requests but without a noticeable CPU load.

Note: If you are running Linux in an LPAR on a z10 EC or later, AP interrupts are used instead of the polling thread. The polling thread is disabled when AP interrupts are available. See “Using AP adapter interrupts” on page 289.

See the **modprobe** man page for command details.

Examples:

- This example loads the z90crypt device driver module if Linux runs in an LPAR with only one cryptographic domain:

```
# modprobe z90crypt
```

- This example loads the z90crypt device driver module and makes z90crypt operate within the cryptographic domain “1”:

```
# modprobe z90crypt domain=1
```

The libica library

The libica RPMs are included with Red Hat Enterprise Linux 6.3.

Use the **icainfo** (“icainfo - Show available libica functions” on page 455) command to find out which libica functions are available to your Linux system. Use **icastats** (see “icastats - Show libica functions” on page 456) to find out how your Linux system uses these libica library functions.

See *libica Programmer’s Reference*, SC34-2602 for details about the libica functions.

The openCryptoki library

The openCryptoki RPMs are included with Red Hat Enterprise Linux 6.3.

Note: To be able to configure openCryptoki (with pkcsconf) user root must be a member of group pkcs11.

See *Security on z/VM*, SG24-7471 for setup information about the openCryptoki library.

The CCA library

You can obtain the CCA library for Linux on System z from the IBM Cryptographic Hardware website.

Go to

www.ibm.com/security/cryptocards

Note that two CCA libraries are involved in secure key cryptography; one comes with the CEX2C or CEX3C hardware feature, the other needs to be installed and run on Linux. The two libraries communicate through the device driver.

The library is available from the software download page for the Cryptographic Coprocessor. Install the RPM and see the readme file. The readme explains where files are located, what users are defined, and how to proceed.

See *Secure Key Solution with the Common Cryptographic Architecture Application Programmer’s Guide*, SC33-8294, for additional installation and setup instructions, feature coexistence information, and how to use CCA functions. You can obtain this book at

www.ibm.com/security/cryptocards/pciicc/library.shtml

z90crypt device node

User-space programs access cryptographic devices through a single device node.

In Red Hat Enterprise Linux 6.3 udev creates the device node `/dev/z90crypt` for you. The device node `z90crypt` is assigned to the miscellaneous devices.

Working with cryptographic devices

Typically, cryptographic devices are not directly accessed by users but through user programs. Some tasks can be performed through the `sysfs` interface.

- “Displaying `z90crypt` information”
- “Starting `z90crypt`” on page 288
- “Setting devices online or offline” on page 288
- “Setting the polling thread” on page 288
- “Using AP adapter interrupts” on page 289
- “Setting the polling timer” on page 289
- “Generating and accessing long random numbers” on page 290
- “Dynamically adding and removing cryptographic adapters” on page 290

Displaying `z90crypt` information

Use the `lszcrypt` command to display status information about your cryptographic devices; alternatively, you can use `sysfs`.

For information about `lszcrypt` see “`lszcrypt` - Display `zcrypt` devices” on page 474.

Each cryptographic adapter is represented in a `sysfs` directory of the form `/sys/bus/ap/devices/card<XX>`

where `<XX>` is the device index for each device. The valid device index range is hex 00 to hex 3f. For example device 0x1a can be found under `/sys/bus/ap/devices/card1a`. The `sysfs` directory contains a number of attributes with information about the cryptographic adapter.

Table 40. Cryptographic adapter attributes

Attribute	Explanation								
depth	Read-only attribute representing the input queue length for this device.								
hwtype	Read-only attribute representing the hardware type for this device. The following values are defined: <table><tr><td>6</td><td>CEX2A cards</td></tr><tr><td>7</td><td>CEX2C cards</td></tr><tr><td>8</td><td>CEX3A cards</td></tr><tr><td>9</td><td>CEX3C cards</td></tr></table>	6	CEX2A cards	7	CEX2C cards	8	CEX3A cards	9	CEX3C cards
6	CEX2A cards								
7	CEX2C cards								
8	CEX3A cards								
9	CEX3C cards								
modalias	Read-only attribute representing an internally used device bus-ID.								
request_count	Read-only attribute representing the number of requests already processed by this device.								
type	Read-only attribute representing the type of this device. The following types are defined: <ul style="list-style-type: none">• CEX2C• CEX2A• CEX3A• CEX3C								

Starting z90crypt

In Red Hat Enterprise Linux 6.3, you start the z90crypt device driver using the **modprobe** command.

```
# modprobe z90crypt
```

This command loads the z90crypt device driver module if Linux runs in an LPAR with only one cryptographic domain.

Setting devices online or offline

Use the **chzcrypt** command to set cryptographic devices online or offline.

Examples:

- To set cryptographic devices (in decimal notation) 0, 1, 4, 5, and 12 online issue:

```
# chzcrypt -e 0 1 4 5 12
```

- To set all available cryptographic devices offline issue:

```
# chzcrypt -d -a
```

For more information about **chzcrypt** see “chzcrypt - Modify the zcrypt configuration” on page 408.

Alternatively, write 1 to the online sysfs attribute of a cryptographic device to set the device online, or write 0 to set the device offline.

Examples:

- To set a cryptographic device with bus device 0x3e online issue:

```
# echo 1 > /sys/bus/ap/devices/card3e/online
```

- To set a cryptographic device with bus device 0x3e offline issue:

```
# echo 0 > /sys/bus/ap/devices/card3e/online
```

- To check the online status of the cryptographic device with bus ID 0x3e issue:

```
# cat /sys/bus/ap/devices/card3e/online
```

The value is 1 if device is online or 0 otherwise.

Setting the polling thread

For Linux on z/VM or for Linux instances in LPAR mode on mainframe systems earlier than System z10, enabling the polling thread can improve cryptographic performance.

For Linux in LPAR mode on IBM mainframe systems as of System z10, see “Using AP adapter interrupts” on page 289. If AP interrupts are available, it is not possible to activate the polling thread.

Depending on the workload, enabling the polling thread can increase cryptographic performance. For Linux on z/VM, the polling thread is deactivated by default.

The z90crypt device driver can run in two modes: with or without the polling thread. When running with the polling thread, one CPU constantly polls the cryptographic cards for finished cryptographic requests while requests are being processed. The polling thread will sleep when no cryptographic requests are currently being processed. This mode will utilize the cryptographic cards as much as possible at the cost of blocking one CPU during cryptographic operations. Without the polling thread, the cryptographic cards are polled at a much lower rate, resulting in higher latency and reduced throughput for cryptographic requests, but without a noticeable CPU load.

Examples:

- To activate a polling thread for a device 0x3e issue:

```
# echo 1 > /sys/bus/ap/devices/card3e/poll_thread
```

- To deactivate a polling thread for a cryptographic device with bus device 0x3e issue:

```
# echo 0 > /sys/bus/ap/devices/card3e/poll_thread
```

Using AP adapter interrupts

To improve cryptographic performance for Linux instances that run in LPAR mode on an IBM System z10 or later mainframe, use AP interrupts.

Using AP interrupts instead of the polling thread frees one CPU while cryptographic requests are processed.

During module initialization the z90crypt device driver checks whether AP adapter interrupts are supported by the hardware. If so, AP polling is disabled and the interrupt mechanism is automatically used.

To tell whether AP adapter interrupts are used, a sysfs attribute called `ap_interrupt` is defined. The read-only attribute can be found at the AP bus level.

Example:

To read the `ap_interrupt` attribute for a device 0x3e issue:

```
# cat /sys/bus/ap/devices/card3e/ap_interrupt
```

The attribute shows 1 if interrupts are used, 0 otherwise.

Setting the polling timer

Request polling is supported at nanosecond intervals.

You can set the polling time by using the sysfs attribute `poll_timeout`. The read-write attribute can be found at the AP bus level.

Example:

To read the `poll_timeout` attribute for the ap bus issue:

```
# cat /sys/bus/ap/poll_timeout
```

To set the `poll_timeout` attribute for the ap bus to poll, for example, every microsecond, issue:

```
# echo 1000 > /sys/bus/ap/poll_timeout
```

Generating and accessing long random numbers

Applications can access large amounts of random number data through a character device.

Before you begin:

- At least one CEX3C or CEX2C feature must be installed in the system and be configured as coprocessor. The CCA library on the CEX3C or CEX2C feature must be version 3.30 or later.
- Linux on z/VM needs a dedicated cryptographic coprocessor or a shared cryptographic device that is backed only by coprocessors.
- Automatic creation of the random number character device requires udev.
- The cryptographic device driver `z90crypt` must be loaded.

If `z90crypt` detects at least one CEX3C or CEX2C feature capable of generating long random numbers, a new miscellaneous character device is registered and can be found under `/proc/misc` as `hw_random`.

Reading from the character device or the symbolic link returns the hardware generated long random numbers. However, do not read excess amounts of random number data from this character device as the data rate is limited due to the cryptographic hardware architecture.

Removing the last available CEX3C or CEX2C feature while `z90crypt` is loaded automatically removes the random number character device. Reading from the random number character device while all CEX3C or CEX2C features are set offline results in an input/output error (EIO). After at least one CEX3C or CEX2C feature is set online again reading from the random number character device continues to return random number data.

Dynamically adding and removing cryptographic adapters

On an LPAR, you can add or remove cryptographic adapters without the need to reactivate the LPAR after a configuration change.

z/VM does not support dynamically adding or removing cryptographic adapters.

Linux attempts to detect new cryptographic adapters and set them online every time a configuration timer expires. Read or modify the expiration time through the `sysfs` attribute `/sys/bus/ap/config_time`.

Adding or removing of cryptographic adapters to or from an LPAR is transparent to applications using clear key functions. If a cryptographic adapter is removed while cryptographic requests are being processed, `z90crypt` automatically re-submits lost requests to the remaining adapters. Special handling is required for secure key.

Secure key requests are usually submitted to a dedicated cryptographic coprocessor. If this coprocessor is removed, lost or new requests cannot be submitted to a different coprocessor. Therefore, dynamically adding and removing adapters with a secure key application requires support within the application. For more information about secure key cryptography, see *Secure Key Solution with the Common Cryptographic Architecture Application Programmer's Guide*, SC33-8294. You can obtain this book at

www.ibm.com/security/cryptocards/pciecc/library.shtml

External programming interfaces

Applications can directly access the zcrypt device driver through an API.



This section provides information for those who want to program against the cryptographic device driver or against the available cryptographic libraries.

If you want to circumvent libica and directly access the zcrypt device driver, see the cryptographic device driver header file available from the source RPM:

`/usr/include/asm-s390/zcrypt.h`

For information about the library APIs, see the following files in the Linux source tree:

- The libica library `/usr/include/ica_api.h`
- The openCryptoki library `/usr/include/opencryptoki/pkcs11.h`
- The CCA library `/opt/IBM/<prod>/include/csulincl.h`, where `<prod>` is specific to the particular hardware product.

`ica_api.h`, `pkcs11.h`, and `csulincl.h` are present after their libraries have been installed. Install RPMs `opencryptoki-devel-<version>` and `libica-devel-<version>`.

Chapter 32. Pseudo-random number device driver

The pseudo-random number device driver is a character device driver that provides user-space applications with pseudo-random numbers generated by the pseudo-random number generator of the System z CP Assist for Cryptographic Function (CPACF).

What you should know about the pseudo-random number device driver

The pseudo-random number device provides pseudo-random numbers similar to the Linux pseudo-random number device `/dev/urandom` but provides a better performance.

Setting up the pseudo-random number device driver

There are no module parameters for the pseudo-random number device driver device driver.

You must load the pseudo-random number module before you can work with it. Use the **modprobe** command to load the module:

```
# modprobe prng
```

Device node

User-space programs access the pseudo-random-number device through a device node, `/dev/prandom`. Red Hat Enterprise Linux 6.3 provides udev to create it for you.

Making the device node accessible to non-root users

By default, only user root can read from the pseudo-random number device. Add the following udev rule to automatically extend access to the device to other users.

```
KERNEL=="prandom", MODE="0444", OPTIONS="last_rule"
```

Reading pseudo-random numbers

The pseudo-random number device is read-only. You can obtain random numbers by using any of these functions:

- `read (/dev/prandom, buffer, bytes)`
- `cat`
- `dd`

Example: In this example `bs` specifies the block size in bytes for transfer, and `count` the number of records with block size. The bytes are written to the output file.

```
dd if=/dev/prandom of=<output file name> bs=<xxxx> count=<nnnn>
```

Chapter 33. Data execution protection for user processes

The data execution protection feature, similarly to the NX feature on other architectures, provides data execution protection for user processes. The data execution protection prevents, for example, stack-overflow exploits and generally makes a system insensitive to buffer-overflow attacks in user space. Using this feature you can switch the addressing modes of kernel and user space. The switch of the addressing modes is a prerequisite to enable the execute protection.

Features

The data execution protection feature provides the following functions:

- Switch the kernel/user space addressing modes
- Data execution protection for user processes

What you should know about the data execution protection feature

This feature is implemented in software, with some hardware support on IBM System z9-109 EC and BC hardware. The hardware support is an instruction that allows copying data between arbitrary address spaces. Without this hardware support, a manual page-table walk is used for kernel-user-copy functions. A manual page-table walk has a negative performance impact if you enable the feature through the kernel parameter. Selecting the config options does not have this negative effect.

Enabling the data execution protection feature

Use the `noexec` kernel parameter to enable the data execution protection feature.

Kernel parameter for data execution protection



If set to `on`, `noexec` enables data execution protection and sets the address mode for user processes to secondary. This address mode is required for data execution protection. Do not override this setting with a subsequent `user_mode` parameter (see “`user_mode` - Set address mode for user space processes” on page 531). If you specify both `noexec` and `user_mode`, the address mode is set according to the parameter specified last.

If set to `off`, `noexec` switches off data execution protection and uses `home` as the address mode for user space processes. This is the default.

Working with the data execution protection feature

This section describes typical tasks that you need to perform when working with the data execution protection feature.

- Enabling and disabling stack execution protection

Enabling and disabling stack execution protection

To prevent stack overflow exploits, the stack of a binary or shared library must be marked as not executable. Do this with the **execstack** user-space tool (part of the prelink package) which sets, clears, or queries the executable stack flag of ELF binaries and shared libraries (GNU_STACK).

Examples

Set and query the executable stack flag (stack is executable):

```
# execstack -s /usr/bin/find
# execstack -q /usr/bin/find
X /usr/bin/find
```

Clear and query the executable stack flag (stack is not executable):

```
# execstack -c /usr/bin/find
# execstack -q /usr/bin/find
- /usr/bin/find
```

To determine the presence of the flag, use the **readelf** command, which is part of the binutils package. To change the flag, however, you need the **execstack** utility.

Set and query the executable stack flag (stack is executable, note the "RWE" meaning "read/write/execute"):

```
# execstack -s /usr/bin/find
# readelf -a /usr/bin/find | grep GNU_STACK -A 1
GNU_STACK      0x0000000000000000 0x0000000000000000 0x0000000000000000
                  0x0000000000000000 0x0000000000000000 RWE    8
```

Clear and query the executable stack flag (stack is not executable, note the "RW" meaning "read/write"):

```
# execstack -c /usr/bin/find
# readelf -a /usr/bin/find | grep GNU_STACK -A 1
GNU_STACK      0x0000000000000000 0x0000000000000000 0x0000000000000000
                  0x0000000000000000 0x0000000000000000 RW      8
```

Part 7. Booting and shutdown

This section describes device drivers and features that are used in the context of booting and shutting down Linux.

Newest version: You can find the newest version of this book at www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

Restrictions: For prerequisites and restrictions see the System z architecture specific information in the Red Hat Enterprise Linux 6.3 release notes at docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

Chapter 34. Console device drivers	299
Console features	300
What you should know about the console device	
drivers	301
Setting up the console device drivers	305
Working with Linux terminals.	311

Chapter 35. Initial program loader for System z	
- zipl	321
Usage	321
Parameters	338
Configuration file structure.	341

Chapter 36. Booting Linux	347
IPL and booting	347
Control point and boot medium	348
Menu configurations	348
Boot data.	349
Booting Linux in a z/VM guest virtual machine	350
Booting Linux in LPAR mode	355
Displaying current IPL parameters	361
Rebooting from an alternative source	362

Chapter 37. Suspending and resuming Linux	365
Features	365
What you should know about suspend and resume	365
Setting up Linux for suspend and resume	367
Suspending a Linux instance	368
Resuming a suspended Linux instance	369

Chapter 38. Shutdown actions	371
The shutdown configuration in sysfs	372
Configuring z/VM CP commands as a shutdown	
action	373

Chapter 34. Console device drivers

The Linux on System z console device drivers support terminal devices for basic Linux control, for example, for booting Linux, for troubleshooting, and for displaying Linux kernel messages.

The only interface to a Linux instance in an LPAR before the boot process is completed is the Hardware Management Console (HMC), see Figure 46. After the boot process has completed, you typically use a network connection to access Linux through a user login, for example, in an ssh session. The possible connections depend on the configuration of your particular Linux instance.




Figure 46. Hardware Management Console

With Linux on z/VM, you typically use a 3270 terminal or terminal emulator to log in to z/VM first. From the 3270 terminal you IPL the Linux boot device. Again, after boot you typically use a network connection to access Linux through a user login rather than a 3270 terminal.

Console features

The console device drivers support the following:

HMC applets

You can use two applets.

Operating System Messages

This is a line-mode terminal. See Figure 47 for an example.

Integrated ASCII Console

This is a full-screen mode terminal.

These HMC applets are accessed through the service-call logical processor (SCLP) console interface.

3270 terminal

This can be physical 3270 terminal hardware or a 3270 terminal emulation.

z/VM can use the 3270 terminal as a 3270 device or perform a protocol translation and use it as a 3215 device. As a 3215 device it is a line-mode terminal for the United States code page (037).

The iucvconn program

You can use the iucvconn program from Linux on z/VM to access terminal devices on other Linux instances that run as guests of the same z/VM system.

See *How to Set up a Terminal Server Environment on z/VM*, SC34-2596 for information about the iucvconn program.

The console device drivers support these terminals as output devices for Linux kernel messages.




Figure 47. Linux kernel messages on the HMC Operating System Messages applet

What you should know about the console device drivers

This section defines some of the terms used in the context of the console device drivers and provides information about console device names and nodes, about terminal modes, and about how console devices are accessed.

About the terminology

Terminal and *console* have special meanings in Linux.

A Linux terminal

is an input/output device through which users interact with Linux and Linux applications. Login programs and shells typically run on Linux terminals and provide access to the Linux system.

The Linux console

is an output device that displays Linux kernel messages.

A mainframe terminal

is any device that gives a user access to operating systems and applications running on the mainframe. This could be a physical device such as a 3270 terminal hardware linked to the mainframe through a controller, or it can be a terminal emulator on a workstation connected through a network. For example, you access z/OS through a mainframe terminal.

The HMC

is a device that gives a system programmer control over the hardware resources, for example the LPARs. The HMC is a web application on a web server that is connected to the support element (SE). The HMC can be accessed from the SE but more commonly is accessed from a workstation within a secure network.

Console device

in the context of the console device drivers, a device, as seen by Linux, to which Linux kernel messages can be directed.

On the mainframe, the Linux console and Linux terminals can both be connected to a mainframe terminal.

Before you have a Linux terminal - the zipl boot menu

Depending on your setup, a zipl boot menu might be displayed when you perform an IPL. The zipl boot menu is part of the boot loader that loads the Linux kernel. Do not confuse the zipl boot menu with the Linux terminal, which has not been set up at this point. The zipl boot menu is very limited in its functionality, for example, there is no way to specify uppercase letters as all input is converted to lowercase. For more details about booting Linux, see Chapter 36, “Booting Linux,” on page 347. For more details about the zipl boot menu, see Chapter 35, “Initial program loader for System z - zipl,” on page 321.

Device and console names

Each terminal device driver can provide a single console device. Table 41 lists the terminal device drivers with the corresponding device names and console names.

Table 41. Device and console names

Device driver	Device name	Console name
SCLP line-mode terminal device driver	sclp_line0	ttyS0
SCLP VT220 terminal device driver	ttysclp0	ttyS1

Table 41. Device and console names (continued)

Device driver	Device name	Console name
3215 line-mode terminal device driver	ttyS0	ttyS0
3270 terminal device driver	tty0.0.009	tty3270
z/VM IUCV HVC device driver	hvc0 to hvc7	hvc0

As shown in Table 41 on page 301, the console with name `ttyS0` can be provided either by the SCLP console device driver or by the 3215 line-mode terminal device driver. The system environment and settings determine which device driver provides `ttyS0`. For details see the information about the `conmode` parameter in “Console kernel parameter syntax” on page 305).

Of the terminal devices that are provided by the z/VM IUCV HVC device driver only `hvc0` is associated with a console.

You require a device node to make a terminal device available to applications, for example to a login program (see “Device nodes”).

Device nodes

Applications access terminal devices by *device nodes*. Table 42 shows all device nodes that `udev` can create for Linux instances running in LPAR mode or as z/VM guests. Which of these device nodes are actually created depends on the `conmode` and `hvc_iucv` kernel parameters (see “Console kernel parameter syntax” on page 305).

Table 42. Device nodes created by `udev`

Device driver	On LPAR	On z/VM
SCLP line-mode terminal device driver	<code>/dev/sclp_line0</code>	<code>/dev/sclp_line0</code>
SCLP VT220 terminal device driver	<code>/dev/ttysclp0</code>	<code>/dev/ttysclp0</code>
3215 line-mode terminal device driver	n/a	<code>/dev/ttyS0</code>
3270 terminal device driver	<code>/dev/tty0.0.0009</code>	<code>/dev/tty0.0.0009</code>
z/VM IUCV HVC device driver	n/a	<code>/dev/hvc0</code> to <code>/dev/hvc7</code>

Terminal modes

The Linux terminals provided by the console device drivers include line-mode terminals, block-mode terminals, and full-screen mode terminals.

On a full-screen mode terminal, pressing any key immediately results in data being sent to the terminal. Also, terminal output can be positioned anywhere on the screen. This allows for advanced interactive capability when using terminal based applications like the `vi` editor.

On a line-mode terminal, the user first types a full line and then presses `Enter` to let the system know that a line has been completed. The device driver then issues a read to get the completed line, adds a new line and hands over the input to the generic TTY routines.

The terminal provided by the 3270 terminal device driver is a traditional IBM mainframe block-mode terminal. Block-mode terminals provide full-screen output

support and users can type input in predefined fields on the screen. Other than on typical full-screen mode terminals, no input is passed on until the user presses Enter. The terminal provided by the 3270 terminal device driver provides limited support for full-screen applications. For example, the ned editor is supported, but not vi.

Table 43 summarizes when to expect which terminal mode.

Table 43. Terminal modes

Accessed through	Environment	Device driver	Mode
Operating System Messages applet on the HMC	LPAR	SCLP line-mode terminal device driver	Line mode
z/VM emulation of the HMC Operating System Messages applet	z/VM	SCLP line-mode terminal device driver	Line mode
Integrated ASCII Console applet on the HMC	z/VM or LPAR	SCLP VT220 terminal device driver	Full-screen mode
3270 terminal hardware or emulation	z/VM with CONMODE=3215	3215 line-mode terminal device driver	Line mode
3270 terminal hardware or emulation	z/VM with CONMODE=3270	3270 terminal device driver	Block mode
iucvconn program	z/VM	z/VM IUCV HVC device driver	Full-screen mode

The 3270 terminal device driver provides three different views. See “Switching the views of the 3270 terminal device driver” on page 313 for details.

How console devices are accessed

How you can access console devices depends on your environment. The diagrams in the following sections omit device drivers that are not relevant for the particular access scenario.

Using the HMC for Linux in an LPAR

Figure 48 shows the possible terminal devices for Linux instances that run directly in an LPAR.




Figure 48. Accessing terminal devices on Linux in an LPAR from the HMC

The **Operating System Messages** applet accesses the device provided by the SCLP line-mode terminal device driver. The **Integrated ASCII console** applet accesses the device provided by the SCLP VT220 terminal device driver.

Using the HMC for Linux on z/VM

If the ASCII system console has been attached to the z/VM guest virtual machine where the Linux instance runs, you can access the ttyS1 terminal device from the HMC **Integrated ASCII Console** applet (see Figure 49).




Figure 49. Accessing terminal devices from the HMC for Linux on z/VM

Using 3270 terminal hardware or a 3270 terminal emulation

For Linux on z/VM, you can use 3270 terminal hardware or a 3270 terminal emulation to access a console device. Figure 50 illustrates how z/VM can handle the 3270 communication.




Figure 50. Accessing terminal devices from a 3270 device

Note: Figure 50 shows two console devices with the name ttyS0. Only one of these devices can be present at any one time.

CONMODE=3215

performs a translation between the 3270 protocol and the 3215 protocol and connects the 3270 terminal hardware or emulation to the 3215 line-mode terminal device driver in the Linux kernel.

CONMODE=3270

connects the 3270 terminal hardware or emulation to the 3270 terminal device driver in the Linux kernel.

VINPUT

is a z/VM CP command that directs input to the ttyS0 device provided by the SCLP line-mode terminal device driver. In a default z/VM environment, ttyS0 is provided by the 3215 line-mode terminal device driver. You can use the

conmode kernel parameter to make the SCLP line-mode terminal device driver provide ttyS0 (see “Console kernel parameter syntax”).

Using iucvconn on Linux on z/VM

On Linux on z/VM, you can access the terminal devices that are provided by the z/VM IUCV Hypervisor Console (HVC) device driver.




Figure 51. Accessing terminal devices from a peer Linux instance

As illustrated in Figure 51, you access the devices with the `iucvconn` program from another Linux instance. Both Linux instances are guests of the same z/VM system. IUCV provides the communication between the two Linux instances. With this setup, you can access terminal devices on Linux instances with no external network connection.


Note: Of the terminal devices provided by the z/VM IUCV HVC device driver only `hvc0` can be activated to receive Linux kernel messages.

Setting up the console device drivers

This section describes the kernel parameters that you can use to configure the console device drivers. It also describes settings for initializing terminal devices for user logins.

Console kernel parameter syntax

You can use the `conmode=` and `console=` kernel parameters to configure the console device drivers. The `hvc_iucv=` and `hvc_iucv_allow=` kernel parameters apply to terminal devices that are provided by the z/VM IUCV HVC device driver only.



where:

conmode

specifies which one of the line-mode or block-mode terminal devices is present and provided by which device driver.

A Linux kernel might include multiple console device drivers that can provide a line-mode terminal:

- SCLP line-mode terminal device driver
- 3215 line-mode terminal device driver
- 3270 terminal device driver

On a running Linux instance, only one of these device drivers can provide a device. Table 44 shows how the device driver that is used by default depends on the environment.

Table 44. Default device driver for the line-mode terminal device

Mode	Default
LPAR	SCLP line-mode terminal device driver
z/VM	3215 line-mode terminal device driver or 3270 terminal device driver, depending on the z/VM guest's console settings (the CONMODE field in the output of #CP QUERY TERMINAL). If the device driver you specify with the <code>conmode=</code> kernel parameter contradicts the CONMODE z/VM setting, z/VM is reconfigured to match the specification for the kernel parameter.

You can use the `conmode` parameter to override the default.

sclp or hwc

specifies the SCLP line-mode terminal device driver.

You need this specification if you want to use the z/VM CP VINPUT command ("Using a z/VM emulation of the HMC Operating System Messages applet" on page 317).

3270

specifies the 3270 device driver.

3215

specifies the 3215 device driver.

console=<console_name>

specifies which devices are to be activated to receive Linux kernel messages. If present, ttyS0 is always activated to receive Linux kernel messages and, by default, it is also the *preferred* console.

The preferred console is used as an initial terminal device, beginning at the stage of the boot process when the 'init'-program is called. Messages issued by programs that are run at this stage are therefore only displayed on the preferred console. Multiple terminal devices can be activated to receive Linux kernel messages but only one of the activated terminal devices can be the preferred console.

Be aware that there is no ttyS0 if you specify conmode=3270.

If you want terminal devices other than ttyS0 to be activated to receive Linux kernel messages specify a console statement for each of these other devices. The last console statement designates the preferred console.

If you specify one or more console parameters and you want to keep ttyS0 as the preferred console, add a console parameter for ttyS0 as the last console parameter. Otherwise you do not need a console parameter for ttyS0.

<console_name> is the console name associated with the terminal device to be activated to receive Linux kernel messages. Of the terminal devices provided by the z/VM IUCV HVC device driver only hvc0 can be activated. Specify the console names as shown in Table 41 on page 301.

hvc_iucv=<number_of_devices>

specifies the number of terminal devices provided by the z/VM IUCV HVC device driver. <number_of_devices> is an integer in the range 0 to 8. Specify 0 to switch off the z/VM IUCV HVC device driver.

hvc_iucv_allow=<z/VM user ID>,<z/VM user ID>, ...

specifies an initial list of z/VM guest virtual machines that are allowed to connect to HVC terminal devices. If this parameter is omitted, any z/VM guest virtual machine that is authorized to establish the required IUCV connection is also allowed to connect. On the running system, you can change this list with the **chiucvallow** command. See *How to Set up a Terminal Server Environment on z/VM*, SC34-2596 for more information.

Examples

- To activate ttyS1 in addition to ttyS0, and to use ttyS1 as the preferred console, add the following specification to the kernel command line:

```
console=ttyS1
```

- To activate ttyS1 in addition to ttyS0, and to keep ttyS0 as the preferred console, add the following specification to the kernel command line:

```
console=ttyS1 console=ttyS0
```

- To use an emulated HMC Operating System Messages applet in a z/VM environment specify:
`conmode=sc1p`
- To activate hvc0 in addition to ttyS0, use hvc0 as the preferred console, configure the z/VM IUCV HVC device driver to provide four devices, and limit the z/VM guest virtual machines that can connect to HVC terminal devices to lxtserv1 and lxtserv2, add the following specification to the kernel command line:
`console=hvc0 hvc_iucv=4 hvc_iucv_allow=lxtserv1,lxtserv2`

Setting up a z/VM guest virtual machine for iucvconn

Because the iucvconn program uses z/VM IUCV to access Linux, you must set up your z/VM guest virtual machine for IUCV. See “Setting up your z/VM guest virtual machine for IUCV” on page 250 for details.

For information about accessing Linux through the iucvtty program rather than through the z/VM IUCV HVC device driver see *How to Set up a Terminal Server Environment on z/VM*, SC34-2596 or the man pages for the **iucvtty** and **iucvconn** commands.

Setting up a line-mode terminal

The line-mode terminals are primarily intended for booting Linux. The preferred user access to a running Red Hat Enterprise Linux 6.3 instance is through a user login that runs, for example, in an ssh session. See “Terminal modes” on page 302 for information about the available line-mode terminals.

Tip: If the terminal does not provide the expected output, ensure that `dumb` is assigned to the `TERM` environment variable. For example, enter the following command on the bash shell:

```
# export TERM=dumb
```

Setting up a full-screen mode terminal

The full-screen terminal can be used for full-screen text editors, such as `vi`, and terminal-based full-screen system administration tools. See “Terminal modes” on page 302 for information about the available full-screen mode terminals.

Tip: If the terminal does not provide the expected output, ensure that `linux` is assigned to the `TERM` environment variable. For example, enter the following command on the bash shell:

```
# export TERM=linux
```

Setting up a terminal provided by the 3270 terminal device driver

The terminal provided by the 3270 terminal device driver is neither a line-mode terminal nor a typical full-screen mode terminal. The terminal provides limited support for full-screen applications. For example, the `ned` editor is supported, but not `vi`.

Tip: If the terminal does not provide the expected output, ensure that `linux` is assigned to the `TERM` environment variable. For example, enter the following command on the bash shell:

```
# export TERM=linux
```

Enabling a terminal for user logins

You can enable a terminal for a standard login through the `/etc/sysconfig/init` configuration file. Specify the device node of the terminal as the value for the `ACTIVE_CONSOLES` parameter (see “Device nodes” on page 302).

Important

The default entry `ACTIVE_CONSOLES=/dev/console` enables logins at the preferred console. This entry ensures that at least one terminal device is set up for user logins. When changing this default be aware that:

- Multiple logins on the same terminal render the terminal inaccessible. Do not inadvertently configure two logins on the preferred console, one explicitly through the terminal-specific device node and a second one through the generic `/dev/console`. To be sure, remove `/dev/console` from the `ACTIVE_CONSOLES` parameter.
- At least one operational terminal device must be set up for logins.

The terminal that is associated with the preferred console and the availability of terminals in general differ depending on your environment and on your kernel parameters (see “Console kernel parameter syntax” on page 305).

LPAR example: `ACTIVE_CONSOLES=/dev/sclp_line0`

z/VM example: `ACTIVE_CONSOLES=/dev/ttyS0`

To enable multiple terminals for user logins, specify multiple device nodes separated by blanks and enclosed by double quotes (“”).

z/VM example: `ACTIVE_CONSOLES="/dev/ttyS0 /dev/hvc0 /dev/hvc1"`

The z/VM examples assume the default `conmode=3215` kernel parameter setting.

Alternatively, you can use Upstart jobs to enable terminals for user logins. With Upstart jobs, you can specify a particular getty program and you can prevent respawns for non-operational terminals.

Using Upstart to enable user logins

To enable user logins with Upstart, create an Upstart job file with a file name of the form `<job-name>.conf` and with the following content:

```
start on stopped rc RUNLEVEL=[2345]
stop on runlevel [01]

respawn
exec /sbin/mingetty --noclear <dev>
```

Place the Upstart job file in `/etc/init/`.

In the sample file, *<dev>* specifies the device node of the terminal, omitting the leading */dev/* (see “Device nodes” on page 302). For example, instead of specifying */dev/sclp_line0*, specify *sclp_line0*.

With *mingetty* you must explicitly export the *TERM* environment variable with the terminal name as explained in “Setting up a full-screen mode terminal” on page 308. The terminal name indicates the capabilities of the terminal device. Examples for terminal names are *linux*, *dumb*, *xterm*, or *vt220*.

Instead of *mingetty*, you can use *agetty*, which can set the *TERM* environment variable at startup.

To set the *TERM* environment variable to *linux* and enable user logins with Upstart create an Upstart job file with the following content:

```
start on stopped rc RUNLEVEL=[2345]
stop on runlevel [01]

respawn
exec /sbin/agetty -L 9600 linux <dev>
```

Preventing respawns for non-operational terminals

If you enable user logins on a terminal that is not available or not operational, the *init* program keeps respawning the *getty* program. Failing respawns increase system and logging activities.

The availability of some terminals depends on the environment where the Linux instance runs, LPAR or z/VM, and on terminal-related kernel parameters. See the explanations for the *conmode=* and *hvc_iucv=* kernel parameters in “Console kernel parameter syntax” on page 305 for more information.

You can use *ttyrun* to provide Upstart jobs for terminals that might or might not be present. The *ttyrun* program prevents respawns if the specified terminal is not available or not operational. With suitable Upstart jobs in place, you can freely change kernel parameters that affect the presence of terminals. You can also use Upstart job files with *ttyrun* to be used for multiple Linux instances with different terminal configurations.

By default, *ttyrun* runs quietly. Use the verbose option, *-V*, to obtain syslog messages, for example, if a terminal device is not available.

To use *ttyrun* with an Upstart job file for *mingetty*, use a file of this form:

```
start on stopped rc RUNLEVEL=[2345]
stop on runlevel [01]

respawn
normal exit <value>
exec /sbin/ttyrun -e <value> <dev> /sbin/mingetty --noclear %t
```

To use *ttyrun* with an Upstart job file for *agetty*, use a file of this form:

```
start on stopped rc RUNLEVEL=[2345]
stop on runlevel [01]

respawn
normal exit <value>
exec /sbin/ttyrun -e <value> <dev> /sbin/agetty -L 9600 <term> %t
```

where:

<value>

specifies an integer in the range 1 to 255. See the `ttyrun` man page for details.

<dev>

specifies the device node of the terminal, omitting the leading `/dev/` (see “Device nodes” on page 302). For example, instead of specifying `/dev/sc1p_line0`, specify `sc1p_line0`.

<term>

specifies the terminal name. With `mingetty` you must explicitly export the `TERM` environment variable with the terminal name as explained in “Setting up a full-screen mode terminal” on page 308. The terminal name indicates the capabilities of the terminal device. Examples for terminal names are `linux`, `dumb`, `xterm`, or `vt220`.

%t

is a variable that the `ttyrun` program resolves to the device node that is specified for **<dev>**.

See the `init(5)` man page for details about the individual lines in the Upstart job file.

Example:

To enable terminal device `hvc0` for user logins with `mingetty` and to take into account that the terminal might not be operational, the complete Upstart job file could look like this:

```
start on stopped rc RUNLEVEL=[2345]
stop on runlevel [01]
```

```
respawn
normal exit 123
exec /sbin/ttyrun -V -e 123 hvc0 /sbin/mingetty --noclear %t
```

The verbose option, `-V`, causes a syslog entry if the `hvc0` terminal device is not available.

Enabling `hvc1` through `hvc7`, requires a similar Upstart job file for each terminal device, with the respective device node specified on the `exec` line. These terminal devices are operational only in a `z/VM` environment. In addition, they depend on the `hvc_iucv=` kernel parameter (see “Console kernel parameter syntax” on page 305).

Setting up the code page for an x3270 emulation on Linux

If you are accessing `z/VM` from Linux by using the `x3270` terminal emulation, add the following settings to the `.Xdefaults` file to get the correct code translation:

```
! X3270 keymap and charset settings for Linux
x3270.charset: us-intl
x3270.keymap: circumfix
x3270.keymap.circumfix: :<key>asciicircum: Key("^")\n
```

Working with Linux terminals

This section describes typical tasks that you need to perform when working with Linux terminals.

- “Using the terminal applets on the HMC” on page 312
- “Accessing terminal devices over `z/VM` IUCV” on page 312
- “Switching the views of the 3270 terminal device driver” on page 313

- “Setting a CCW terminal device online or offline” on page 314
- “Entering control and special characters on line-mode terminals” on page 315
- “Using the magic sysrequest functions” on page 315
- “Using a z/VM emulation of the HMC Operating System Messages applet” on page 317
- “Using a 3270 terminal in 3215 mode” on page 319

Using the terminal applets on the HMC

This section applies to both the line-mode terminal and the full-screen mode terminal on the HMC:

- On an HMC you can only open each applet once.
- Within an LPAR, there can only be one active terminal session for each applet, even if multiple HMCs are used.
- A particular Linux instance supports only one active terminal session for each applet.
- Security hint: Always end a terminal session by explicitly logging off (for example, type “exit” and press Enter). Simply closing the applet leaves the session active and the next user opening the applet resumes the existing session without a logon.
- Slow performance of the HMC is often due to a busy console or increased network traffic.

The following applies to the full-screen mode terminal only:

- Output that is written by Linux while the terminal window is closed is not displayed. Therefore, a newly opened terminal window is always blank. For most applications, like login or shell prompts, it is sufficient to press Enter to obtain a new prompt.
- The terminal window only shows 24 lines and does not provide a scroll bar. To scroll up press Shift+PgUp, to scroll down press Shift+PgDn.

Accessing terminal devices over z/VM IUCV

This section describes how to access hypervisor console (HVC) terminal devices, which are provided by the z/VM IUCV HVC device driver. For information about accessing terminal devices that are provided by the iucvtty program see *How to Set up a Terminal Server Environment on z/VM*, SC34-2596.

You access HVC terminal devices from a Linux instance where the iucvconn program is installed. The Linux instance with the terminal device to be accessed and the Linux instance with the iucvconn program must both run as guests of the same z/VM system. The two z/VM guest virtual machines must be configured such that z/VM IUCV communication is permitted between them.

Perform these steps to access a HVC terminal device over z/VM IUCV:

1. Open a terminal session on the Linux instance where the iucvconn program is installed.
2. Enter a command like this:

```
# iucvconn <guest_ID> <terminal_ID>
```

where:

<guest_ID>

specifies the z/VM guest virtual machine on which the Linux instance with the HVC terminal device to be accessed runs.

<terminal_ID>

specifies an identifier for the terminal device to be accessed. HVC terminal device names are of the form `hvcn` where *n* is an integer in the range 0-7. The corresponding terminal IDs are `lnxhvcn`.

Example: To access HVC terminal device `hvc0` on a Linux instance that runs on a z/VM guest virtual machine `LXGUEST1`, enter:

```
# iucvconn LXGUEST1 lnxhvc0
```

For more details and further parameters of the **iucvconn** command see the **iucvconn** man page or *How to Set up a Terminal Server Environment on z/VM*, SC34-2596.

3. Press Enter to obtain a prompt.

Output that is written by Linux while the terminal window is closed is not displayed. Therefore, a newly opened terminal window is always blank. For most applications, like login or shell prompts, it is sufficient to press Enter to obtain a new prompt.

Security hint: Always end terminal sessions by explicitly logging off (for example, type “exit” and press Enter). If logging off results in a new login prompt, press Control and Underscore (Ctrl+_), then press d to close the login window. Simply closing the terminal window for a `hvc0` terminal device that has been activated for Linux kernel messages leaves the device active and the terminal session can be reopened without a login.

Switching the views of the 3270 terminal device driver

The 3270 terminal device driver provides three different views. Use function key 3 (PF3) to switch between the views (see Figure 52).




Figure 52. Switching views of the 3270 terminal device driver

The Linux kernel messages view is available only if the terminal device has been activated for Linux kernel messages. The full-screen application view is available only if there is an application that uses this view, for example, the `ned` editor.

Be aware that the 3270 terminal only provides limited full-screen support. The full-screen application view of the 3270 terminal is not intended for applications that require vt220 capabilities. The application itself needs to create the 3270 data stream.

For the Linux kernel messages view and the terminal I/O view you can use the PF7 key to scroll backward and the PF8 key to scroll forward. The scroll buffers are fixed at 4 pages (16 KB) for the Linux kernel messages view and 5 pages (20 KB) for the terminal I/O view. When the buffer is full and more terminal data needs to be printed, the oldest lines are removed until there is enough room. The number of lines in the history, therefore, vary. Scrolling in the full-screen application view depends on the application.

You cannot issue z/VM CP commands from any of the three views provided by the 3270 terminal device driver. If you want to issue CP commands, use the PA1 key to switch to the CP READ mode.

Setting a CCW terminal device online or offline

This section applies to Linux on z/VM.

The 3270 terminal device driver uses CCW devices and provides them as CCW terminal devices. A CCW terminal device can be:

- The tty3270 terminal device that can be activated for receiving Linux kernel messages.

If this device exists, it comes online early during the Linux boot process. In a default z/VM environment, the device number for this device is 0009. In sysfs it is represented as `/sys/bus/ccw/drivers/3270/0.0.0009`. You need not set this device online and you must not set it offline.

- CCW terminal devices through which users can log in to Linux with the CP DIAL command.

These devices are defined with the CP DEF GRAF command. They are represented in sysfs as `/sys/bus/ccw/drivers/3270/0.<n>.<devno>` where `<n>` is the subchannel set ID and `<devno>` is the virtual device number. By setting these devices online you enable them for user logins. If you set a device offline it can no longer be used for user login.

See *z/VM CP Commands and Utilities Reference*, SC24-6175 for more information about the DEF GRAF and DIAL commands.

You can use the **chccwdev** command (see “chccwdev - Set a CCW device online” on page 396) to set a CCW terminal device online or offline. Alternatively, you can write “1” to the device's online attribute to set it online, or “0” to set it offline.

Examples

- To set a CCW terminal device 0.0.7b01 online issue:

```
# chccwdev -e 0.0.7b01
```

Alternatively issue:

```
# echo 1 > /sys/bus/ccw/drivers/3270/0.0.7b01/online
```

- To set a CCW terminal device 0.0.7b01 offline issue:

```
# chccwdev -d 0.0.7b01
```

Alternatively issue:

```
# echo 0 > /sys/bus/ccw/drivers/3270/0.0.7b01/online
```

Entering control and special characters on line-mode terminals

Line-mode terminals do not have a control (Ctrl) key. Without a control key you cannot enter control characters directly. Also, pressing the Enter key adds a newline character to your input string which is not expected by some applications.

Table 45 summarizes how you can use the caret character (^) to enter some control characters and to enter strings without appended newline characters.

Table 45. Control and special characters on line-mode terminals

For the key combination	Type this	Usage
Ctrl+C	^c	Cancel the process that is currently running in the foreground of the terminal.
Ctrl+D	^d	Generate an end of file (EOF) indication.
Ctrl+Z	^z	Stop a process.
n/a	^n	Suppresses the automatic generation of a new line. This makes it possible to enter single characters, for example those characters that are needed for yes/no answers in some utilities.

Note: For a 3215 line-mode terminal in 3215 mode you must use United States code page (037).

Using the magic sysrequest functions

To call the magic sysrequest functions on a line-mode terminal enter the two characters “^_” (caret and hyphen) followed by a third character that specifies the particular function.

You can also call the magic sysrequest functions from the hvc0 terminal device if it is present and has been activated to receive Linux kernel messages. To call the magic sysrequest functions from hvc0 enter the single character Ctrl+o followed by the character for the particular function.

Table 46 provides an overview of the commands for the magic sysrequest functions:

Table 46. Magic sysrequest commands

On line-mode terminals enter	On hvc0 enter	To
^~b	Ctrl+o b	Re-IPL immediately (see “lsreipl - List IPL and re-IPL settings” on page 469).
^~s	Ctrl+o s	Emergency sync all file systems.
^~u	Ctrl+o u	Emergency remount all mounted file systems read-only.
^~t	Ctrl+o t	Show task info.
^~m	Ctrl+o m	Show memory.
^~ followed by a digit (0 to 9)	Ctrl+o followed by a digit (0 to 9)	Set the console log level.

Table 46. Magic sysrequest commands (continued)

On line-mode terminals enter	On hvc0 enter	To
<code>^~e</code>	<code>Ctrl+o e</code>	Send the TERM signal to end all tasks except init.
<code>^~i</code>	<code>Ctrl+o i</code>	Send the KILL signal to end all tasks except init.

Note: In Table 46 on page 315 `Ctrl+o` means pressing o while holding down the control key.

Table 46 on page 315 lists the main magic sysrequest functions that are known to work on Linux on System z. For a more complete list of functions see `Documentation/sysrq.txt` in the Linux source tree. Some of the listed functions might not work on your system.

Activating and deactivating the magic sysrequest function

From a Linux terminal or a command prompt, enter the following command to activate the magic sysrequest function:

```
echo 1 > /proc/sys/kernel/sysrq
```

Enter the following command to deactivate the magic sysrequest function:

```
echo 0 > /proc/sys/kernel/sysrq
```

Alternatively you can use `sysctl` to activate and deactivate the magic sysrequest function. To check how the magic sysrequest function is set, issue:

```
# sysctl kernel.sysrq
kernel.sysrq = 1
```

In Red Hat Enterprise Linux 6.3 the magic sysrequest function is turned on by default. To turn it off using `sysctl`, issue:

```
# sysctl -w kernel.sysrq=0
```

Triggering magic sysrequest functions from procfs

If you are working from a terminal that does not support a key sequence or combination to call magic sysrequest functions, you can trigger the functions through `procfs`. Write the character for the particular function to `/proc/sysrq-trigger`.

You can use this interface even if the magic sysrequest functions have not been activated as described in “Activating and deactivating the magic sysrequest function.”

Example: To set the console log level to 9 enter:

```
# echo 9 > /proc/sysrq-trigger
```

Using a z/VM emulation of the HMC Operating System Messages applet

The preferred terminal devices for Linux instances that run as z/VM guests are provided by the 3215 or 3270 terminal device drivers. Alternatively, you can use the **Operating System Messages** applet emulation; for example, if the 3215 terminal is not operational.

The emulation requires a terminal device that is provided by the SCLP line-mode terminal device driver. To use the emulation, you must override the default device driver for z/VM environments (see “Console kernel parameter syntax” on page 305).

For the emulation you use the z/VM CP VINPUT command instead of the graphical user interface at the service element or HMC. Type any input to the operating system with a leading CP VINPUT.

The examples in the sections that follow show the input line of a 3270 terminal or terminal emulator (for example, x3270). Omit the leading #CP if you are in CP read mode. For more information about VINPUT see *z/VM CP Commands and Utilities Reference*, SC24-6175.

Priority and non-priority commands

VINPUT commands require a VMSG (non-priority) or PVMSG (priority) specification. Operating systems that honour this specification process priority commands with a higher priority than non-priority commands.

The hardware console driver is capable to accept both if supported by the hardware console within the specific machine or virtual machine.

Linux does not distinguish priority and non-priority commands.

Example: The specifications:

```
#CP VINPUT VMSG LS -L
```

and

```
#CP VINPUT PVMSG LS -L
```

are equivalent.

Case conversion

All lowercase characters are converted by z/VM to uppercase. To compensate for this, the console device driver converts all input to lowercase.

For example, if you type VInput VMSG echo \$PATH, the device driver gets ECHO \$PATH and converts it into echo \$path.

Linux and bash are case sensitive and require some specifications with uppercase characters. To include uppercase characters in a command, use the percent sign (%) as a delimiter. The console device driver interprets characters that are enclosed by percent signs as uppercase.

Examples: In the following examples, the first line shows the user input, the second line shows what the device driver receives after the case conversion by CP, and the third line shows the command processed by bash:

-

```
#cp vinput vmsg ls -l
CP VINPUT VMSG LS -L
ls -l
...
```

- The following input would result in a bash command that contains a variable \$path, which is not defined in lowercase:

```
#cp vinput vmsg echo $PATH
CP VINPUT VMSG ECHO $PATH
echo $path
...
```

To obtain the correct bash command enclose a the uppercase string with the conversion escape character:

```
#cp vinput vmsg echo $%PATH%
CP VINPUT VMSG ECHO $%PATH%
echo $PATH
...
```

Using the escape character

The quotation mark (") is the standard CP escape character (see “Using a 3270 terminal in 3215 mode” on page 319). To include the escape character in a command passed to Linux, you need to type it twice.

Example: The following command passes an string in quotation marks to be echoed.

```
#cp vinput pvmsg echo ""here is ""$0
CP VINPUT PVMSG ECHO "HERE IS "$0
echo "here is "$0
here is -bash
```

In the example, \$0 resolves to the name of the current process.

Using the end of line character

To include the end of line character in the command passed to Linux, you need to specify it with a leading escape character. If you are using the standard settings according to “Using a 3270 terminal in 3215 mode” on page 319, you need to specify "# to pass # to Linux.

If you specify the end of line character without a leading escape character, z/VM CP interprets it as an end of line character that ends the **VINPUT** command.

Example: In this example a number sign is intended to mark the begin of a comment in the bash command but is misinterpreted as the beginning of a second command:

```
#cp vinput pvmsg echo ""N%umber signs start bash comments"" #like this one
CP VINPUT PVMSG ECHO "%N%UMBER SIGNS START BASH COMMENTS"
LIKE THIS ONE
HPCMD001E Unknown CP command: LIKE
...
```

The escape character prevents the number sign from being interpreted as an end of line character:

```
#cp vinput pvmsg echo ""N%umber signs start bash comments"" "#like this one
VINPUT PVMSG ECHO "%N%UMBER SIGNS START BASH COMMENTS" #LIKE THIS ONE
echo "Number signs start bash comments" #like this one
Number signs start bash comments
```

Simulating the Enter and Spacebar keys

You can use the **CP VINPUT** command to simulate the Enter and Spacebar keys.

Simulate the Enter key by entering a blank followed by `\n`:

```
#CP VINPUT VMSG \n
```

Simulate the Spacebar key by entering two blanks followed by `\n`:

```
#CP VINPUT VMSG  \n
```

Using a 3270 terminal in 3215 mode

The z/VM control program (CP) defines five characters as line editing symbols. Use the **CP QUERY TERMINAL** command to see the current settings.

The default line editing symbols depend on your terminal emulator. You can reassign the symbols by changing the settings of **LINEND**, **TABCHAR**, **CHARDEL**, **LINEDEL**, or **ESCAPE** with the **CP TERMINAL** command. Table 47 shows the most commonly used settings:

Table 47. Line edit characters

Character	Symbol	Usage
#	LINEND	The end of line character allows you to enter several logical lines at once.
	TABCHAR	The logical tab character.
@	CHARDEL	The character delete symbol deletes the preceding character.
[or ¢	LINEDEL	The line delete symbol deletes everything back to and including the previous LINEND symbol or the start of the input. “[” is common for ASCII terminals and “¢” for EBCDIC terminals.
"	ESCAPE	The escape character allows you to enter a line edit symbol as a normal character.

To enter a line edit symbol you need to precede it with the escape character. In particular, to enter the escape character you must type it twice.

Examples

The following examples assume the settings of Table 47 with the opening bracket character (|) as the delete line character.

- To specify a tab character specify:
"|
- To specify a the double quote character specify:
""
- If you type the character string:
#CP HALT#CP ZIPL 190[#CP IPL 1@290 PARM vmpoff=""MSG OP REBOOT"#IPL 290""

the actual commands received by CP are:

```
CP HALT
CP IPL 290 PARM vmpoff=""MSG OP REBOOT"#IPL 290"
```

Chapter 35. Initial program loader for System z - zipl

zipl can be used to prepare a device for one of the following purposes:

- Booting Linux (as a Linux program loader)
- Dumping

For more information about the dump tools that **zipl** installs and on using the dump functions, see *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607.

- Loading a data file to initialize a discontinuous saved segment (DCSS)

You can simulate a **zipl** command to test a configuration before you apply the command to an actual device (see “dry-run” on page 324).

zipl supports the following devices:

- Enhanced Count Key Data (ECKD) DASDs with fixed block Linux disk layout (ldl)
- ECKD DASDs with z/OS-compliant compatible disk layout (cdl)
- Fixed Block Access (FBA) DASDs
- Magnetic tape subsystems compatible with IBM3480, IBM3490, or IBM3590 (boot and dump devices only)
- SCSI with PC-BIOS disk layout

Usage

zipl base functions

The **zipl** base functions can be invoked with one of the following options on the command line or in a configuration file:

Table 48. zipl base functions

Base function	Command line short option	Command line long option	Configuration file option
Install a boot loader	-i	--image	image=
See “Preparing a boot device” on page 325 for details.			
Prepare a DASD or tape dump device	-d	--dumpto	dumpto=
See “Preparing a DASD or tape dump device” on page 331 for details.			
Prepare a list of ECKD volumes for a multi-volume dump	-M	--mvdump	mvdump=
See “Preparing a multi-volume dump on ECKD DASD” on page 332 for details.			

Table 48. *zipl* base functions (continued)

Base function	Command line short option	Command line long option	Configuration file option
Prepare a SCSI dump device See “Preparing a dump device on a SCSI disk” on page 334 for details.	-D	--dumptofs	dumptofs=
Prepare a device to load a file to initialize discontinuous named saved segments See “Installing a loader to initialize a discontinuous named saved segment (DCSS)” on page 336 for details.	-s	--segment	segment=
Install a menu configuration See “Installing a menu configuration” on page 337 for details.	-m	--menu	(None)

zipl modes

zipl operates in one of two modes:

Command-line mode


If a **zipl** command is issued with a base function other than installing a menu configuration (see “Installing a menu configuration” on page 337), the entire configuration must be defined using command-line parameters. See the following base functions for how to specify command-line parameters:

- “Preparing a boot device” on page 325
- “Preparing a DASD or tape dump device” on page 331
- “Preparing a multi-volume dump on ECKD DASD” on page 332
- “Preparing a dump device on a SCSI disk” on page 334
- “Installing a loader to initialize a discontinuous named saved segment (DCSS)” on page 336


Configuration-file mode

If a **zipl** command is issued either without a base function or to install a menu configuration, a configuration file is accessed. See “Configuration file structure” on page 341 for more information.

zipl syntax overview



parameters when omitting base function:



Notes:

- 1 You can change the default configuration file with the ZIPLCONF environment variable.
- 2 If no configuration is specified, **zipl** uses the configuration specified in the [defaultboot] section of the configuration file (see “Configuration file structure” on page 341).
- 3 In conjunction with a boot configuration or with a SCSI dump configuration only.
- 4 In conjunction with a boot configuration or a menu configuration only.

Where:

-c *<config_file>*

specifies the configuration file to be used.

<configuration>

specifies a single configuration section in a configuration file.

-P *<parameters>*

can optionally be used to provide:

kernel parameters

in conjunction with a boot configuration section. See “How kernel parameters from different sources are combined” on page 327 for information about how kernel parameters specified with the -P option are combined with any kernel parameters specified in the configuration file.

SCSI system dumper parameters

in conjunction with a SCSI dump configuration section. See “How SCSI system dumper parameters from different sources are combined” on page 336

page 336 for information about how parameters specified with the `-P` option are combined with any parameters specified in the configuration file.

If you provide multiple parameters, separate them with a blank and enclose them within single quotes (') or double quotes (").

- a in conjunction with a boot configuration section, adds kernel image, kernel parameter file, and initial RAM disk to the bootmap file. Use this option when these files are spread across multiple disks to ensure that they are available at IPL time. Specifying this option significantly increases the size of the bootmap file created in the target directory.
- n suppresses confirmation prompts that require operator responses to allow unattended processing (for example, when processing DASD or tape dump configuration sections).
- V provides verbose command output.
- dry-run**
simulates a **zipl** command. Use this option to test a configuration without overwriting data on your device.

During simulation, **zipl** performs all command processing and issues error messages where appropriate. Data is temporarily written to the target directory and is cleared up when the command simulation is completed.
- v displays version information.
- h displays help information.

The basic functions and their parameters are described in detail in the following sections.

See “Parameters” on page 338 for a summary of the short and long command line options and their configuration file equivalents.

Examples

- To process the default configuration in the default configuration file (`/etc/zipl.conf`, unless specified otherwise with the environment variable `ZIPLCONF`) issue:

```
# zipl
```

- To process the default configuration in a configuration file `/etc/myxmp.conf` issue:

```
# zipl -c /etc/myxmp.conf
```

- To process a configuration [myconf] in the default configuration file issue:

```
# zipl myconf
```

- To process a configuration [myconf] in a configuration file `/etc/myxmp.conf` issue:


```
# zipl -c /etc/myxmp.conf myconf
```

- To simulate processing a configuration [myconf] in a configuration file `/etc/myxmp.conf` issue:

```
# zipl --dry-run -c /etc/myxmp.conf myconf
```

Preparing a boot device

zipl command line syntax for preparing a boot device



Notes:

- 1 Additional parameters used only if `-t` specifies a logical device as a target. See "Using base device parameters" on page 329.

To prepare a device as a boot device you must specify:

The location `<image>`

of the Linux kernel image on the file system.

A target `<directory>` or `<tape_node>`

zipl installs the boot loader code on the device containing the specified directory `<directory>` or to the specified tape device `<tape_node>`.

Optionally, you can also specify:

A kernel image address `<image_addr>`

to which the kernel image is loaded at IPL time. The default address is `0x10000`.

The RAM disk location `<ramdisk>`

of an initial RAM disk image (`initrd`) on the file system.

A RAM disk image address `<initrd_addr>`

to which the RAM disk image is loaded at IPL time. If you do not specify this parameter, **zipl** investigates the location of other components and calculates a suitable address for you.

Kernel parameters

to be used at IPL time. If you provide multiple parameters, separate them with a blank and enclose them within single quotes (') or double quotes (").

You can specify parameters *<parameters>* directly on the command line. Instead or in addition, you can specify a location *<parmfile>* of a kernel parameter file on the file system. See “How kernel parameters from different sources are combined” on page 327 for a discussion of how **zipl** combines multiple kernel parameter specifications.

A parameter address *<parm_addr>*

to which the kernel parameters are loaded at IPL time. The default address is 0x1000.

An option **-a**

to add the kernel image, kernel parameter file, and initial RAM disk to the bootmap file. Use this option when these files are spread across multiple disks to ensure that they are available at IPL time. This option is available on the command line only. Specifying this option significantly increases the size of the bootmap file created in the target directory.

See “Parameters” on page 338 for a summary of the parameters including the long options you can use on the command line.

Figure 53 summarizes how you can specify a boot configuration within a configuration file section. Required specifications are shown in bold. See “Configuration file structure” on page 341 for a more comprehensive discussion of the configuration file.

```
[<section_name>]
image=<image>,<image_addr>
ramdisk=<ramdisk>,<initrd_addr>
parmfile=<parmfile>,<parm_addr>
parameters=<parameters>
# Next line for devices other than tape only
target=<directory>
# Next line for tape devices only
tape=<tape_node>
```

Figure 53. *zipl* syntax for preparing a boot device — configuration file mode

Example

The following command identifies the location of the kernel image as `/boot/mnt/image-2`, identifies the location of an initial RAM disk as `/boot/mnt/initrd`, specifies a kernel parameter file `/boot/mnt/parmf-2`, and writes the required boot loader code to `/boot`. At IPL time, the initial RAM disk is to be loaded to address 0x900000, rather than an address that is calculated by **zipl**. Kernel image, initial RAM disk, and the kernel parameter file are to be copied to the bootmap file on the target directory `/boot` rather than being referenced.

zipl -i /boot/mnt/image-2 -r /boot/mnt/initrd,0x900000 -p /boot/mnt/parmf-2 -t /boot -a

An equivalent section in a configuration file might look like this:

```
[boot2]
image=/boot/mnt/image-2
ramdisk=/boot/mnt/initrd,0x900000
paramfile=/boot/mnt/parmf-2
target=/boot
```

There is no configuration file equivalent for option -a. To use this option for a boot configuration in a configuration file it needs to be specified with the **zipl** command that processes the configuration.

If the configuration file is called `/etc/myxmp.conf`:

```
# zipl -c /etc/myxmp.conf boot2 -a
```

How kernel parameters from different sources are combined

zipl allows for multiple sources of kernel parameters when preparing boot devices.

In command-line mode there are two possible sources of kernel parameters that are processed in the order:

1. Kernel parameter file (specified with the -p or --parmfile option)
2. Parameters specified on the command line (specified with the -P or --parameters option)

In configuration file mode there are three possible sources of kernel parameters that are processed in the order:

1. Kernel parameter file (specified with the parmfile= option)
2. Parameters specified in the configuration section (specified with the parameters= option)
3. Parameters specified on the command line (specified with the -P or --parameters option)

Parameters from different sources are concatenated and passed to the kernel in one string. At IPL time, the combined kernel parameter string is loaded to address 0x1000, unless an alternate address is provided.

For a more detailed discussion of various sources of kernel parameters see “Including kernel parameters in a boot configuration” on page 20.

Preparing a logical device as a boot device

A *logical device* is a block device that represents one or more real devices. If your boot directory is located on a logical DASD or SCSI device, **zipl** cannot detect all required information about the underlying real device or devices and needs additional input.

Logical devices can be, for example, two DASDs combined into a logical mirror volume, or a linear mapping of a partition to a real device, or a more complex mapping hierarchy. Logical devices are controlled by a device mapper.

Blocks on the logical device must map to blocks on the underlying real device or devices linearly, that is, if two blocks on the logical device are adjacent, they need to be adjacent on the underlying real devices as well. This excludes mappings such as “striping”.

You always boot from a real device. **zipl** must be able to write to that device, starting at block 0. In a logical device setup, starting at the top of the mapping hierarchy, the first block device that grants access to block 0 (and subsequent blocks) is the *base device*, see Figure 54.




Figure 54. Definition of base device

A base device can have the following mappings:

- A mapping to a part of a real device that contains block 0
- A mapping to one complete real device
- A mapping to multiple real devices.

For a mapping to multiple real devices all the real devices must share the device characteristics and contain the same data (for example, a mirror setup). The mapping can also be to parts of the devices as long as the parts contain block 0. The mapping must not combine multiple devices into one large device.

The **zipl** command needs the device node of the base device and information about the physical characteristics of the underlying real devices. For most logical boot devices, there is a helper script that automatically provides all the required information to **zipl** for you (see “Using a helper script”).

If you decide not to use the supplied helper script, or want to write your own helper script, you can use parameters to supply the base device information to **zipl**, see “Using base device parameters” on page 329 and “Writing your own helper script” on page 330.

Using a helper script

zipl provides a helper script, `zipl_helper.device-mapper`, that detects the required information and provides it to **zipl** for you. To use the helper script run **zipl** as usual, specifying the parameters for the kernel image, parameter file, initial RAM disk, and target. See “Preparing a boot device” on page 325 for details about the parameters.

Assuming an example device for which the location of the kernel image is `/boot/image-5`, the location of an initial RAM disk as `/boot/initrd-5`, a kernel parameter file `/boot/parmf-5`, and which writes the required boot loader code to `/boot` and is a device mapper device, the command then becomes:

```
# zipl -i /boot/image-5 -r /boot/initrd-5 -p /boot/parmf-5 -t /boot
```

The corresponding configuration file section becomes:

```
[<section_name>]
image=<image>,<image_addr>
ramdisk=<ramdisk>,<initrd_addr>
parmfile=<parmfile>,<parm_addr>
parameters=<parameters>
target=<directory>
targetbase=<targetbase_node>
targettype=LDL|CDL|FBA|SCSI
# Next line for target types LDL and CDL only
targetgeometry=<cylinders>,<heads>,<sectors>
targetblocksize=<targetblocksize>
targetoffset=<targetoffset>
```

Figure 55. zipl syntax for preparing a logical device as a boot device — configuration file mode

Example for using base device parameters

The example command in this section identifies the location of the kernel image as `/boot/image-5`, identifies the location of an initial RAM disk as `/boot/initrd-5`, specifies a kernel parameter file `/boot/parmf-5`, and writes the required boot loader code to `/boot`.

The command specifies the following information about the base device: the device node is `/dev/dm-3`, the device has the compatible disk layout, there are 6678 cylinders, there are 15 heads, there are 12 sectors, and the topmost logical device in the mapping hierarchy begins with an offset of 24 blocks from the start of the base device.

```
# zipl -i /boot/image-5 -r /boot/initrd-5 -p /boot/parmf-5 -t /boot --targetbase /dev/dm-3 \
# --targettype CDL --targetgeometry 6678,15,12 --targetblocksize=4096 --targetoffset 24
```

Note: Instead of using the continuation sign (`\`) at the end of the first line, you might want to specify the entire command on a single line.

An equivalent section in a configuration file might look like this:

```
[boot5]
image=/boot/image-5
ramdisk=/boot/initrd-5
paramfile=/boot/parmf-5
target=/boot
targetbase=/dev/dm-3
targettype=CDL
targetgeometry=6678,15,12
targetblocksize=4096
targetoffset=24
```

Writing your own helper script

You can write your own helper script for device drivers that provide logical devices. The helper script must conform to the following specifications:

- The script must accept the name of the target directory as an argument. From this specification it must determine a suitable base device. See “Using base device parameters” on page 329.
- The script must write the following base device parameter=`<value>` pairs to stdout as ASCII text. Each pair must be written on a separate line.
 - **targetbase**=`<targetbase_node>`

- **targettype**=<type> where type can be LDL, CDL, FBA, or SCSI.
- **targetgeometry**= <cylinders>,<heads>,<sectors> (For LDL and CDL only)
- **targetblocksize**=<blocksize>
- **targetoffset**=<offset>

See “Using base device parameters” on page 329 for the meaning of the base device parameters.

- The script must be named `zipl_helper.<device>` where <device> is the device name as specified in `/proc/devices`.
- The script must be located in `/lib/s390-tools`.

Preparing a DASD or tape dump device

zipl command line syntax for preparing a DASD or tape dump device

```

>> zipl -d <dump_device> [,<size>] [-n]

```

To prepare a DASD or tape dump device you must specify:

The device node <dump_device>

of the DASD partition or tape device to be prepared as a dump device. **zipl** deletes all data on the partition or tape and installs the boot loader code there.

Notes:

1. If the dump device is an ECKD disk with fixed-block layout (ldl), a dump overwrites the dump utility. You must reinstall the dump utility before you can use the device for another dump.
2. If the dump device is a tape, FBA disk, or ECKD disk with the compatible disk layout (cdl), you do not need to reinstall the dump utility after every dump.

Optionally, you can also specify:

An option -n

to suppress confirmation prompts to allow unattended processing (for example, from a script). This option is available on the command line only.

A limit <size>

for the amount of memory to be dumped. The value is a decimal number that can optionally be suffixed with K for kilobytes, M for megabytes, or G for gigabytes. The value is rounded to the next megabyte boundary.

If you limit the dump size below the amount of memory used by the system to be dumped, the resulting dump is incomplete.

DASD or tape dump devices are not formatted with a file system so no target directory can be specified. See *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607 for details about processing these dumps.

See “Parameters” on page 338 for a summary of the parameters including the long options you can use on the command line.

```
[<section_name>]  
dumpto=<dump_device>,<size>
```

```
# zip1 -d /dev/dasdc1 -n
```

```
# zipl -c /etc/myxmp.conf dumpdasd -n
```

```

➤—zipl—┐—M <dump_device_list>—┐—┐
        └─f─┘                      └─.<size>┘ └─n┘

```

332 Device Drivers, Features, and Commands - Red Hat Enterprise Linux 6.3

An option **-n**

to suppress confirmation prompts to allow unattended processing (for example, from a script). This option is available on the command line only.

A limit **<size>**

for the amount of memory to be dumped. The value is a decimal number that can optionally be suffixed with K for kilobytes, M for megabytes, or G for gigabytes. The value is rounded to the next megabyte boundary.

If you limit the dump size below the amount of memory used by the system to be dumped, the resulting dump is incomplete.

DASD or tape dump devices are not formatted with a file system so no target directory can be specified. See *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607 for details about processing these dumps.

See “Parameters” on page 338 for a summary of the parameters including the long options you can use on the command line.

Figure 57 summarizes how you can specify a multi-volume DASD dump configuration in a configuration file. See “Configuration file structure” on page 341 for a more comprehensive discussion of the configuration file.

```
[<section_name>]
mvdump=<dump_device_list>,<size>
```

Figure 57. *zipl* syntax for preparing DASD devices for a multi-volume dump — configuration file mode

Example

The following command prepares two DASD partitions `/dev/dasdc1`, `/dev/dasdd1` for a multi-volume dump and suppresses confirmation prompts that require an operator response:

```
# zipl -M sample_dump_conf -n
```

where the `sample_dump_conf` file contains the two partitions separated by line breaks:

```
/dev/dasdc1
/dev/dasdd1
```

An equivalent section in a configuration file might look like this:

```
[multi_volume_dump]
mvdump=sample_dump_conf
```


There is no configuration file equivalent for option `-n`. To use this option for a multi-volume DASD dump configuration in a configuration file it needs to be specified with the **zipl** command that processes the configuration.

If the configuration file is called `/etc/myxmp.conf`:

```
# zipl -c /etc/myxmp.conf multi_volume_dump -n
```

Preparing a dump device on a SCSI disk

Before you begin: At least one partition, the *target partition*, must be available to zipl.



The target partition contains the target directory and is accessed to load the SCSI system dumper tool at IPL time. Dumps are written as files to a *dump partition*.

The dump and target partition can but need not be the same partition. Preferably, dump and target partition are two separate partitions.

The target and dump partitions must be formatted with a file system supported by the SCSI Linux system dumper tool. Unlike DASD and tape, creating a dump device on SCSI disk does not destroy the contents of the target partition. See *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607 for more details.

To prepare a SCSI disk as a dump device, you must specify:

The dump partition *<dump_partition>*
to which the dumps are written.

A target *<directory>*
to which the SCSI system dumper components are written. **zipl** uses the target directory to determine the dump device (target partition).

Optionally, you can also specify:

SCSI system dumper parameters

You can specify parameters *<parameters>* directly on the command line. Instead or in addition, you can specify a location *<parmfile>* of a parameter file on the file system. See “How SCSI system dumper parameters from different sources are combined” on page 336 for a discussion of how multiple parameter specifications are combined.

dump_dir=/*<directory>*

Path to the directory (relative to the root of the dump partition) where the dump file is to be written. This directory is specified with a leading slash. The directory must exist when the dump is initiated.

Example: If the dump partition is mounted as /dumps, and the parameter “dump_dir=/mydumps” is defined, the dump directory would be accessed as “/dumps/mydumps”.

The default is `"/"` (the root directory of the partition).

dump_compress=gzip|none

Dump compression option. Compression can be time-consuming on slower systems with a large amount of memory.

The default is “none”.

dump_mode=interactive | auto

Action taken if there is no room on the file system for the new dump file. “interactive” prompts the user to confirm that the dump with the lowest number is to be deleted. “auto” automatically deletes this file.

The default is “interactive”.

If you provide multiple parameters, separate them with a blank and enclose them within single quotes (') or double quotes (").

A limit <size>

for the amount of memory to be dumped. The value is a decimal number that can optionally be suffixed with K for kilobytes, M for megabytes, or G for gigabytes. The value is rounded to the next megabyte boundary.

If you limit the dump size below the amount of memory used by the system to be dumped, the resulting dump is incomplete.

See “Parameters” on page 338 for a summary of the parameters including the long options you can use on the command line.

Figure 58 summarizes how you can specify a SCSI dump configuration in a configuration file. Required specifications are shown in bold. See “Configuration file structure” on page 341 for a more comprehensive discussion of the configuration file.

```
[<section_name>]
dumptofs=<dump_partition>
parmfile=<parmfile>,<parm_addr>
parameters=<parameters>
target=<directory>
```

Figure 58. *zipl syntax for preparing a SCSI dump device — configuration file mode*

Example

The following command prepares a SCSI partition /dev/sda2 as a dump device and a directory /boot as the target directory. Dumps are to be written to a directory mydumps, relative to the mount point. There is to be no compression but instead the oldest dump will be automatically deleted if there is not enough space for the new dump.

```
# zipl -D /dev/sda2 -P 'dumpdir=/mydumps dump_compress=none dump_mode=auto' -t /boot
```

An equivalent section in a configuration file might look like this:

```
[dumpscsi]
dumptofs=/dev/sda2
parameters='dumpdir=/mydumps dump_compress=none dump_mode=auto'
target=/boot
```

In both the command line and configuration file examples the parameter specifications “dump_compress=none dump_mode=auto” could be omitted because they correspond to the defaults.

If the configuration file is called `/etc/myxmp.conf`, the **zipl** command that processes the configuration would be:

```
# zipl -c /etc/myxmp.conf dumpscsi
```

How SCSI system dumper parameters from different sources are combined

zipl allows for multiple sources of SCSI system dumper parameters.

In command-line mode there are two possible sources of parameters that are processed in the order:

1. Parameter file (specified with the `-p` or `--parmfile` option)
2. Parameters specified on the command line (specified with the `-P` or `--parameters` option)

In configuration file mode there are three possible sources of parameters that are processed in the order:

1. Parameter file (specified with the `parmfile=` option)
2. Parameters specified in the configuration section (specified with the `parameters=` option)
3. Parameters specified on the command line (specified with the `-P` or `--parameters` option)

Parameters from different sources are concatenated and passed to the SCSI system dumper in one string. If the same parameter is specified in multiple sources, the value that is encountered last is honored. At IPL time, the combined parameter string is loaded to address (0x1000).

Installing a loader to initialize a discontinuous named saved segment (DCSS)

zipl command line syntax for loading a DCSS

```
►►—zipl— -s <segment_file>,<seg_addr>— -t <directory>—————►◄
```

To prepare a device for loading a data file to initialize discontinuous named saved segments, you must specify:

The source file `<segment_file>`
to be loaded at IPL time.

The segment address `<seg_addr>`
to which the segment is to be written at IPL time.

A target `<directory>`
zipl installs the boot loader code on the device containing the specified directory `<directory>`.

After the segment has been loaded, the system is put into the *disabled wait state*. No Linux instance is started.

See “Parameters” on page 338 for a summary of the parameters including the long options you can use on the command line.

Figure 59 summarizes how you can specify a file to be loaded to a DCSS within a configuration file section. See “Configuration file structure” on page 341 for a more comprehensive discussion of the configuration file.

```
[<section_name>]
segment=<segment_file>,<seg_addr>
target=<directory>
```

Figure 59. *zipl syntax for loading a DCSS — configuration file mode*

Example

The following command prepares a device for loading a file `/boot/segment` to a DCSS at address `0x40000000` when IPLed. The boot loader code is written to `/boot`:

```
# zipl -s /boot/segment,0x40000000 -t /boot
```

An equivalent section in a configuration file might look like this:

```
[segment]
segment=/boot/segment,0x40000000
target=/boot
```

If the configuration file is called `/etc/myxmp.conf`, the **zipl** command that processes the configuration would be:

```
# zipl -c /etc/myxmp.conf segment
```

Installing a menu configuration

To prepare a menu configuration you need a configuration file that includes at least one menu.

zipl syntax for installing a menu configuration

Diagram illustrating the **zipl** command syntax for installing a menu configuration:

```
➤—zipl— -m <menu_name>— [ -c /etc/zipl.conf (1) ] [ -c <config_file> ] [ -a ]—➤
```

Notes:

- 1 You can change the default configuration file with the `ZIPLCONF` environment variable.

Where:

-m or **--menu**

specifies the menu that defines the menu configuration in the configuration file.

`<config_file>`

specifies the configuration file where the menu configuration is defined. The default, `/etc/zipl.conf`, can be changed with the `ZIPLCONF` environment variable.

-a or --add-files

specifies that the kernel image file, `parmfile`, and initial RAM disk image are added to the bootmap files in the respective target directories rather than being referenced. Use this option if the files are spread across disks to ensure that the files are available at IPL time. Specifying this option significantly increases the size of the bootmap file created in the target directory.

Example

Using the example of a configuration file in “Example” on page 343, you could install a menu configuration with:

```
# zipl -m menu1
```

Parameters

This section provides an overview of the options and how to specify them on the command line or in the configuration file.

Command line short option Command line long option	Explanation
Configuration file option	
-a --add-files n/a	Causes kernel image , kernel parameter file, and initial RAM disk to be added to the bootmap file in the target directory rather than being referenced from this file. Use this option when these files are spread across multiple disks to ensure that they are available at IPL time. Specifying this option significantly increases the size of the bootmap file created in the target directory.
-c <code><config_file></code> --config= <code><config_file></code> n/a	Specifies the configuration file. You can change the default configuration file <code>/etc/zipl.conf</code> with the environment variable <code>ZIPLCONF</code> .
<code><configuration></code> n/a n/a	Specifies a configuration section to be read and processed from the configuration file.
-d <code><dump_device></code> [, <code><size></code>] --dumpto= <code><dump_device></code> [, <code><size></code>] dumpto= <code><dump_device></code> [, <code><size></code>]	Specifies the DASD partition or tape device to which a dump is to be written after IPL. The optional size specification limits the amount of memory to be dumped. The value is a decimal number that can optionally be suffixed with K for kilobytes, M for megabytes, or G for gigabytes. The value is rounded to the next megabyte boundary. If you limit the dump size below the amount of memory used by the system to be dumped, the resulting dump is incomplete. If no limit is provided, all of the available physical memory is dumped. See “Preparing a DASD or tape dump device” on page 331 and <i>Using the Dump Tools on Red Hat Enterprise Linux 6.3</i> , SC34-2607 for details.

Command line short option Command line long option	Explanation
Configuration file option	
-D <dump_partition>[,<size>] or --dumptofs =<dump_partition>[,<size>] dumptofs =<dump_partition>[,<size>]	<p>Specifies the partition to which a SCSI dump file is to be written. This partition must be formatted with a file system supported by the SCSI Linux system dumper tool. The dump partition must be on the same physical SCSI disk as the target partition. It can but need not be the partition that also contains the target directory (target partition).</p> <p>The optional size specification limits the amount of memory to be dumped. The value is a decimal number that can optionally be suffixed with K for kilobytes, M for megabytes, or G for gigabytes. The value is rounded to the next megabyte boundary. If you limit the dump size below the amount of memory used by the system to be dumped, the resulting dump is incomplete. If no limit is provided, all of the available physical memory is dumped.</p> <p>See “Preparing a dump device on a SCSI disk” on page 334 and <i>Using the Dump Tools on Red Hat Enterprise Linux 6.3</i>, SC34-2607 for details.</p>
-h --help n/a	<p>Displays help information.</p>
-i <image>[,<image_addr>] --image =<image>[,<image_addr>] image =<image>[,<image_addr>]	<p>Specifies the location of the Linux kernel image on the file system and, optionally, in memory after IPL. The default memory address is 0x10000.</p> <p>See “Preparing a boot device” on page 325 for details.</p>
-m <menu_name> --menu =<menu_name> n/a	<p>Specifies the name of the menu that defines a menu configuration in the configuration file (see “Menu configurations” on page 342).</p>
-M <dump_device_list>[,<size>] --mvdump =<dump_device_list>[,<size>] mvdump =<dump_device_list>[,<size>]	<p>Specifies a file with a list of DASD partitions to which a dump is to be written after IPL.</p> <p>The optional size specification limits the amount of memory to be dumped. The value is a decimal number that can optionally be suffixed with K for kilobytes, M for megabytes, or G for gigabytes. The value is rounded to the next megabyte boundary. If you limit the dump size below the amount of memory used by the system to be dumped, the resulting dump is incomplete. If no limit is provided, all of the available physical memory is dumped.</p> <p>See “Preparing a multi-volume dump on ECKD DASD” on page 332 and <i>Using the Dump Tools on Red Hat Enterprise Linux 6.3</i>, SC34-2607 for details.</p>
-n --noninteractive n/a	<p>Suppresses all confirmation prompts (for example, when preparing a DASD or tape dump device).</p>

Command line short option Command line long option	Explanation
Configuration file option	
-p <parmfile>[,<parm_addr>] --parmfile =<parmfile>[,<parm_addr>]	In a boot configuration, specifies the location of a kernel parameter file.
parmfile =<parmfile>[,<parm_addr>]	<p>In a SCSI dump configuration, specifies the location of a parameter file with SCSI system dumper parameters (see “Preparing a dump device on a SCSI disk” on page 334).</p> <p>You can specify multiple sources of kernel or SCSI system dumper parameters. See “How SCSI system dumper parameters from different sources are combined” on page 336 and “How kernel parameters from different sources are combined” on page 327 for more information.</p> <p>The optional <parm_addr> specifies the memory address where the combined kernel parameter list is to be loaded at IPL time. This specification is ignored for SCSI dump configuration, SCSI system dumper parameters are always loaded to the default address 0x1000.</p>
-P <parameters> --parameters =<parameters>	In a boot configuration, specifies kernel parameters.
parameters =<parameters>	<p>In a SCSI dump configuration, specifies SCSI system dumper parameters (see “Preparing a dump device on a SCSI disk” on page 334)</p> <p>Individual parameters are single keywords or have the form <i>key=value</i>, without spaces. If you provide multiple parameters, separate them with a blank and enclose them within single quotes (') or double quotes (").</p> <p>You can specify multiple sources of kernel or SCSI system dumper parameters. See “How SCSI system dumper parameters from different sources are combined” on page 336 and “How kernel parameters from different sources are combined” on page 327 for more information.</p>
-r <ramdisk>[,<initrd_addr>] --ramdisk =<ramdisk>[,<initrd_addr>] ramdisk =<ramdisk>[,<initrd_addr>]	Specifies the location of the initial RAM disk (initrd) on the file system and, optionally, in memory after IPL. If you do not specify a memory address, zipl investigates the location of other components and calculates a suitable address for you.
-s <segment_file>,<seg_addr> or --segment =<segment_file>,<seg_addr>	Specifies the segment file to load at IPL time and the memory location for the segment.
segment =<segment_file>,<seg_addr>	See “Installing a loader to initialize a discontinuous named saved segment (DCSS)” on page 336 for details.
-t <directory> --target =<directory>	Specifies the target directory where zipl creates boot-relevant files. The boot loader is installed on the disk containing the target directory. For a SCSI dump device, this partition must have been formatted with a file system supported by the SCSI system dumper (for example, ext3 or ext4).
target =<directory>	
none --targetbase =<targetbase_node>	For logical boot devices, specifies the device node of the base device, either using the standard device name or in form of the major and minor number separated by a colon (:).
targetbase =<targetbase_node>	See “Using base device parameters” on page 329 for details.

Command line short option Command line long option	Explanation
Configuration file option	
none --targetblocksize=<targetblocksize>	For logical boot devices, specifies the bytes per block of the base device.
targetblocksize=<targetblocksize>	See “Using base device parameters” on page 329 for details.
none --targetgeometry=<cylinders>,<heads>,<sectors>	For logical boot devices that map to ECKD type base devices, specifies the disk geometry of the base device in cylinders, heads, and sectors.
targetgeometry=<cylinders>,<heads>,<sectors>	See “Using base device parameters” on page 329 for details.
none --targetoffset=<targetoffset>	For logical boot devices, specifies the offset in blocks between the start of the physical device and the start of the logical device.
targetoffset=<targetoffset>	See “Using base device parameters” on page 329 for details.
none --targettype=<type>	For logical boot devices, specifies the device type of the base device.
targettype=<type>	See “Using base device parameters” on page 329 for details.
-T <tape_node> --tape=<tape_node>	Specifies the tape device where zipl installs the boot loader code.
tape=<tape_node>	
-v --version	Prints version information.
n/a	
-V --verbose	Provides more detailed command output.
n/a	

If you call **zipl** in configuration file mode without specifying a configuration file, the default `/etc/zipl.conf` is used. You can change the default configuration file with the environment variable `ZIPLCONF`.

Configuration file structure

A configuration file contains:

[defaultboot]

a default section that defines what is to be done if the configuration file is called without a section specification.

[<configuration>]

one or more sections that describe IPL configurations.

:<menu_name>

optionally, one or more menu sections that describe menu configurations.

A configuration file section consists of a section identifier and one or more option lines. Option lines are valid only as part of a section. Blank lines are permitted, and lines beginning with '#' are treated as comments and ignored. Option

specifications consist of keyword=value pairs. There can but need not be blanks before and after the equal sign (=) of an option specification.

Default section

The default section consists of the section identifier **[defaultboot]** followed by a single option line. The option line specifies one of these mutually exclusive options:

default=<section_name>

where <section_name> is one of the IPL configurations described in the configuration file. If the configuration file is called without a section specification, an IPL device is prepared according to this IPL configuration.

defaultmenu=<menu_name>

where <menu_name> is the name of a menu configuration described in the configuration file. If the configuration file is called without a section specification, IPL devices are prepared according to this menu configuration.

Examples

- This default specification points to a boot configuration “boot1” as the default.

```
[defaultboot]
default=boot1
```
- This default specification points to a menu configuration with a menu “menu1” as the default.

```
[defaultboot]
defaultmenu=menu1
```

IPL configurations

An IPL configuration has a section identifier that consists of a section name within square brackets and is followed by one or more option lines. Each configuration includes one of the following mutually exclusive options that determine the type of IPL configuration:

image=<image>

Defines a boot configuration. See “Preparing a boot device” on page 325 for details.

dump=<dump_device>

Defines a DASD or tape dump configuration. See “Preparing a DASD or tape dump device” on page 331 for details.

mvdump=<dump_device_list>

Defines a multi-volume DASD dump configuration. See “Preparing a multi-volume dump on ECKD DASD” on page 332 for details.

dumpofs=<dump_partition>

Defines a SCSI dump configuration. See “Preparing a dump device on a SCSI disk” on page 334 for details.

segment=<segment_file>

Defines a DCSS load configuration. See “Installing a loader to initialize a discontinuous named saved segment (DCSS)” on page 336 for details.

Menu configurations

For DASD and SCSI devices, you can define a menu configuration. A menu configuration has a section identifier that consists of a menu name with a leading colon. The identifier is followed by one or more lines with references to IPL configurations in the same configuration file and one or more option lines.

target=<directory>

specifies a device where a boot loader is installed that handles multiple IPL configurations. For menu configurations, the target options of the referenced IPL configurations are ignored.

<i>=<configuration>

specifies a menu item. A menu includes one and more lines that specify the menu items.

<configuration> is the name of an IPL configuration that is described in the same configuration file. You can specify multiple boot configurations. For SCSI target devices, you can also specify one or more SCSI dump configurations. You cannot include DASD dump configurations as menu items.

<i> is the configuration number. The configuration number sequentially numbers the menu items beginning with "1" for the first item. When initiating an IPL from a menu configuration, you can specify the configuration number of the menu item you want to use.

default=<n>

specifies the configuration number of one of the configurations in the menu to define it as the default configuration. If this option is omitted, the first configuration in the menu is the default configuration.

prompt=<flag>

in conjunction with a DASD target device, determines whether the menu is displayed when an IPL is performed. Menus cannot be displayed for SCSI target devices.

For prompt=1 the menu is displayed, for prompt=0 it is suppressed. If this option is omitted, the menu is not displayed. Independent of this parameter, the operator can force a menu to be displayed by specifying "prompt" in place of a configuration number for an IPL configuration to be used.

If the menu of a menu configuration is not displayed, the operator can either specify the configuration number of an IPL configuration or the default configuration is used.

timeout=<seconds>

in conjunction with a DASD target device and a displayed menu, specifies the time in seconds, after which the default configuration is IPLed, if no configuration has been specified by the operator. If this option is omitted or if "0" is specified as the timeout, the menu stays displayed indefinitely on the operator console and no IPL is performed until the operator specifies an IPL configuration.

Example

Figure 60 on page 344 shows a sample configuration file that defines multiple configuration sections and two menu configurations.

```

[defaultboot]
defaultmenu=menu1

# First boot configuration (DASD)
[boot1]
ramdisk=/boot/initrd
parameters='root=/dev/ram0 ro'
image=/boot/image-1
target=/boot

# Second boot configuration (SCSI)
[boot2]
image=/boot/mnt/image-2
ramdisk=/boot/mnt/initrd,0x900000
parmfile=/boot/mnt/parmf-2
target=/boot

# Third boot configuration (DASD)
[boot3]
image=/boot/mnt/image-3
ramdisk=/boot/mnt/initrd
parmfile=/boot/mnt/parmf-3
target=/boot

# Configuration for dumping to tape
[dumptape]
dumppto=/dev/rtibm0

# Configuration for dumping to DASD
[dumpdasd]
dumppto=/dev/dasdc1

# Configuration for multi-volume dumping to DASD
[multi_volume_dump]
mvdump=sample_dump_conf

# Configuration for dumping to SCSI disk
# Separate IPL and dump partitions
[dumpscsi]
target=/boot
dumpptofs=/dev/sda2
parameters="dump_dir=/mydumps dump_compress=none dump_mode=auto"

# Menu containing the SCSI boot and SCSI dump configurations
:menu1
1=dumpscsi
2=boot2
target=/boot
default=2

# Menu containing two DASD boot configurations
:menu2
1=boot1
2=boot3
target=/boot
default=1
prompt=1
timeout=30

# Configuration for initializing a DCSS
[segment]
segment=/boot/segment,0x800000
target=/boot

```

Figure 60. /etc/zipl.conf example

The following commands assume that the configuration file of our sample is the default configuration file.

- Call **zipl** to use the default configuration file settings:

```
# zipl
```

Result: **zipl** reads the default option from the [defaultboot] section and selects the :menu1 section. It then installs a menu configuration with a boot configuration and a SCSI dump configuration.

- Call **zipl** to install a menu configuration (see also “Installing a menu configuration” on page 337):

```
# zipl -m menu2
```

Result: **zipl** selects the :menu2 section. It then installs a menu configuration with two DASD boot configurations. “Example for a DASD menu configuration on z/VM” on page 351 and “Example for a DASD menu configuration (LPAR)” on page 358 illustrate what this menu looks like when it is displayed.

- Call **zipl** to install a boot loader for boot configuration [boot2]:

```
# zipl boot2
```

Result: **zipl** selects the [boot2] section. It then installs a boot loader that will load copies of /boot/mnt/image-2, /boot/mnt/initrd, and /boot/mnt/parmf-2.

- Call **zipl** to prepare a tape that can be IPLed for a tape dump:

```
# zipl dumptape
```

Result: **zipl** selects the [dumptape] section and prepares a dump tape on /dev/rtribm0.

- Call **zipl** to prepare a DASD dump device:

```
# zipl dumpdasd -n
```

Result: **zipl** selects the [dumpdasd] section and prepares the dump device /dev/dasdc1. Confirmation prompts that require an operator response are suppressed.

- Call **zipl** to prepare a SCSI dump device:

```
# mount /dev/sda1 /boot
# mount /dev/sda2 /dumps
# mkdir /dumps/mydumps
# zipl dumpscsi
# umount /dev/sda1
# umount /dev/sda2
```

Result: **zipl** selects the [dumpscsi] section and prepares the dump device /dev/sda1. The associated dump file will be created uncompressed in directory /mydumps on the dump partition. If space is required, the lowest-numbered dump file in the directory will be deleted.

- Call **zipl** to install a loader to initialize named saved segments:

```
# zipl segment
```

Result: **zipl** installs segment loader that will load the contents of file `/boot/segment` to address `0x800000` at IPL time and then put the processor into the disabled wait state.

Chapter 36. Booting Linux

This chapter provides a general overview of how to boot Linux in an LPAR or in a z/VM guest virtual machine. For details about defining a Linux virtual machine, see *z/VM Getting Started with Linux on System z*, SC24-6194, the chapter about creating your first Linux virtual machine.

IPL and booting

On System z, you usually start booting Linux by performing an Initial Program Load (IPL). Figure 61 summarizes the main steps.




Figure 61. IPL and boot process

The IPL process accesses the IPL device and loads the Linux boot loader code to the mainframe memory. The boot loader code then gets control and loads the Linux kernel. At the end of the boot process Linux gets control.

If your Linux instance is to run in an LPAR, you can circumvent the IPL and use the service element (SE) to copy the Linux kernel to the mainframe memory (see “Loading Linux from a DVD or from an FTP server” on page 358).

Apart from starting a boot process, an IPL can also be used for:

- Writing out system storage (dumping)
See *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607 for more information about dumps.
- Loading a discontinuous saved segment (DCSS)
See *How to use Execute-in-Place Technology with Linux on z/VM*, SC34-2594 for more information about DCSSs.

You can find the latest copies of these documents on developerWorks at:

Use the **zipl** tool to prepare DASD, SCSI, and tape devices as IPL devices for booting Linux, for dumping, or for loading a DCSS. See Chapter 35, “Initial program loader for System z - zipl,” on page 321 for more information about **zipl**.

Control point and boot medium

The control point from where you can start the boot process depends on the environment where your Linux is to run. If your Linux instance is to run in LPAR mode, the control point is the mainframe's Support Element (SE) or an attached Hardware Management Console (HMC). For Linux on z/VM, the control point is the control program (CP) of the hosting z/VM.

The media that can be used as boot devices also depend on where Linux is to run. Table 49 provides an overview of the possibilities:

Table 49. Boot media

	DASD	tape	SCSI	NSS	z/VM reader	CD-ROM/FTP
z/VM guest	✓	✓	✓	✓	✓	
LPAR	✓	✓	✓			✓

DASDs, tapes on channel-attached tape devices, and SCSI device that are attached through an FCP channel can be used for both LPAR and z/VM guests. A SCSI device can be a disk or an FC-attached CD-ROM or DVD drive. Named saved systems (NSS) and the z/VM reader are available only in a z/VM environment.

If your Linux runs in LPAR mode, you can also boot from a CD-ROM drive on the SE or HMC, or you can obtain the boot data from a remote FTP server.

Menu configurations

In Red Hat Enterprise Linux 6.3, you use **zipl** to prepare a DASD or SCSI boot disk. You can also define a menu configuration. A boot device with a menu configuration can hold the code for multiple boot configurations. For SCSI disks, the menu can also include one or more SCSI system dumpers.

Each boot and dump configuration in a menu is associated with a configuration number. At IPL time, you can specify a configuration number to select the configuration to be used.

For menu configurations on DASD, you can display a menu with the configuration numbers (see “Example for a DASD menu configuration on z/VM” on page 351 and “Example for a DASD menu configuration (LPAR)” on page 358). For menu configurations on SCSI disks, you need to know the configuration numbers without being able to display the menus.

See “Menu configurations” on page 342 for information about defining menu configurations.

Boot data

Generally, you need the following to boot Linux:

- A kernel image
- Boot loader code
- Kernel parameters
- An initial RAM disk image

For sequential I/O boot devices (z/VM reader and tape) the order in which this data is provided is significant. For random access devices there is no required order.

Kernel image

On Red Hat Enterprise Linux 6.3, kernel images are installed into the `/boot` directory and are named `mlinuz-<version>.s390x`. See *Red Hat Enterprise Linux 6.3 Installation Guide* for information about where to find the images and how to start an installation.

Boot loader code

Red Hat Enterprise Linux 6.3 kernel images are compiled to contain boot loader code for IPL from z/VM reader devices.

If you want to boot a kernel image from a device that does not correspond to the included boot loader code, you can provide alternate boot loader code separate from the kernel image.

Use **zipl** to prepare boot devices with separate DASD, SCSI, or tape boot loader code. You can then boot from DASD, SCSI, or tape regardless of the boot loader code in the kernel image.

Kernel parameters

The kernel parameters are in form of an ASCII text string of up to 895 characters. If the boot device is tape or the z/VM reader, the string can also be encoded in EBCDIC.

Individual kernel parameters are single keywords or keyword/value pairs of the form `keyword=<value>` with no blank. Blanks are used to separate consecutive parameters.

If you use the **zipl** command to prepare your boot device, you can provide kernel parameters on the command line, in a parameter file, and in a **zipl** configuration file.

See Chapter 3, “Kernel and module parameters,” on page 19, Chapter 35, “Initial program loader for System z - zipl,” on page 321, or the **zipl** and `zipl.conf` man pages for more details.

Initial RAM disk image

An initial RAM disk holds files, programs, or modules that are not included in the kernel image but are required for booting.

For example, booting from DASD requires the DASD device driver. If you want to boot from DASD but the DASD device driver has not been compiled into your kernel, you need to provide the DASD device driver module on an initial RAM disk.

Red Hat Enterprise Linux 6.3 provides a ramdisk located in `/boot` and named `initramfs-<kernel version>.s390x.img`. When a ramdisk is installed or modified, you must call **zipl** to update the boot record.

Booting Linux in a z/VM guest virtual machine

You boot Linux in a z/VM guest virtual machine by issuing CP commands from a CMS or CP session.

This section provides summary information for booting Linux in a z/VM guest virtual machine. For more detailed information about z/VM guest environments for Linux see *z/VM Getting Started with Linux on System z*, SC24-6194.

Using tape

Before you begin: You need a tape that is prepared as a boot device.

A tape boot device must contain the following in the specified order:

1. Tape boot loader code
The tape boot loader code is included in the `s390utils` RPM.
2. Tape mark
3. Kernel image
4. Tape mark
5. Kernel parameters (optional)
6. Tape mark
7. Initial RAM disk (optional)
8. Tape mark
9. Tape mark

All tape marks are required even if an optional item is omitted. For example, if you do not provide an initial RAM disk image, the end of the boot information is marked with three consecutive tape marks. **zipl** prepared tapes conform to this layout. See “Preparing a boot device” on page 325 for information about preparing a tape with **zipl**.

Perform these steps to start the boot process:

1. Establish a CMS or CP session with the z/VM guest virtual machine where you want to boot Linux.
2. Ensure that the boot device is accessible to your z/VM guest virtual machine.
3. Ensure that the correct tape is inserted and rewound.
4. Issue a command of this form:

```
#cp i <devno> parm <kernel_parameters>
```

where

`<devno>`

is the device number of the boot device as seen by the guest virtual machine.

parm *<kernel_parameters>*

is an optional 64-byte string of kernel parameters to be concatenated to the end of the existing kernel parameters used by your boot configuration (see “Preparing a boot device” on page 325 for information about the boot configuration).

See also “Specifying kernel parameters when booting Linux” on page 21.

Using DASD

Before you begin:

You need a DASD boot device prepared with **zipl** (see “Preparing a boot device” on page 325).

Perform these steps to start the boot process:

1. Establish a CMS or CP session with the z/VM guest virtual machine where you want to boot Linux.
2. Ensure that the boot device is accessible to your z/VM guest virtual machine.
3. Issue a command of this form:

```
#cp i <devno> loadparm <n> parm <kernel_parameters>
```

where:

<devno>

specifies the device number of the boot device as seen by the guest.

loadparm *<n>*

is applicable to menu configurations only. Omit this parameter if you are not working with a menu configuration.

Configuration number “0” specifies the default configuration. Depending on the menu configuration, omitting this option might display the menu or select the default configuration. Specifying “prompt” instead of a configuration number forces the menu to be displayed.

Displaying the menu allows you to specify additional kernel parameters (see “Example for a DASD menu configuration on z/VM”). These additional kernel parameters are appended to the parameters you might have provided in a parameter file. The combined parameter string must not exceed 895 bytes.

See “Menu configurations” on page 342 for more details about menu configurations.

parm *<kernel_parameters>*

is an optional 64-byte string of kernel parameters to be concatenated to the end of the existing kernel parameters used by your boot configuration (see “Preparing a boot device” on page 325 for information about the boot configuration).

See also “Specifying kernel parameters when booting Linux” on page 21.

Example for a DASD menu configuration on z/VM

This example illustrates how menu2 in the sample configuration file in Figure 60 on page 344 displays on the z/VM guest virtual machine console:

```
00: zIPL interactive boot menu
00:
00: 0. default (boot1)
00:
00: 1. boot1
00: 2. boot3
00:
00: Note: VM users please use '#cp vi vmsg <number> <kernel-parameters>'
00:
00: Please choose (default will boot in 30 seconds): #cp vi vmsg 2
```

You choose a configuration by specifying the configuration number. For example, to boot configuration boot3 specify

```
#cp vi vmsg 2
```

You can also specify additional kernel parameters by appending them to the configuration number. For example, you can specify:

```
#cp vi vmsg 2 maxcpus=1 mem=64m
```

These parameters are concatenated to the end of the existing kernel parameters used by your boot configuration when booting Linux.

Using a SCSI device

A SCSI device can be a disk or an FC-attached CD-ROM or DVD drive.

Before you begin: You need a SCSI boot device prepared with **zipl** (see “Preparing a boot device” on page 325).

Perform these steps to start the boot process:

1. Establish a CMS or CP session with the z/VM guest virtual machine where you want to boot Linux.
2. Ensure that the FCP channel that provides access to the SCSI boot disk is accessible to your z/VM guest virtual machine.
3. Specify the target port and LUN of the SCSI boot disk. Enter a command of this form:

```
#cp set loaddev portname <wwpn> lun <lun>
```

where:

<wwpn>

specifies the world wide port name (WWPN) of the target port in hexadecimal format. A blank separates the first eight digits from the final eight digits.

<lun>

specifies the LUN of the SCSI boot disk in hexadecimal format. A blank separating the first eight digits from the final eight digits.

Example: To specify a WWPN 0x5005076300c20b8e and a LUN 0x5241000000000000:

```
#cp set loaddev portname 50050763 00c20b8e lun 52410000 00000000
```

4. **Optional for menu configurations:** Specify the boot configuration (boot program in z/VM terminology) to be used. Enter a command of this form:


```
#cp set loaddev bootprog <n>
```

where <n> specifies the configuration number of the boot configuration. Omitting the bootprog parameter or specifying the value 0 selects the default configuration. See “Menu configurations” on page 342 for more details about menu configurations.

Example: To select a configuration with configuration number 2 from a menu configuration:

```
#cp set loaddev bootprog 2
```

5. **Optional:** Specify kernel parameters.

```
#cp set loaddev scpdata <APPEND|NEW> '<kernel_parameters>'
```

where:

<kernel_parameters>

specifies a set of kernel parameters to be stored as system control program data (SCPDATA). When booting Linux, these kernel parameters are concatenated to the end of the existing kernel parameters used by your boot configuration.

<kernel_parameters> must contain ASCII characters only. If characters other than ASCII characters are present, the boot process ignores the SCPDATA.

<kernel_parameters> as entered from a CMS or CP session is interpreted as lowercase on Linux. If you require uppercase characters in the kernel parameters, run the SET LOADDEV command from a REXX script instead. In the REXX script, use the “address command” statement. See *REXX/VM Reference*, SC24-6221 and *REXX/VM User's Guide*, SC24-6222 for details.

Optional: APPEND

appends kernel parameters to existing SCPDATA. This is the default.

Optional: NEW

replaces existing SCPDATA.

Examples:

- To append kernel parameter noresume to the current SCPDATA:

```
#cp set loaddev scpdata 'noresume'
```

- To replace the current SCPDATA with the kernel parameters resume=/dev/sda2 and no_console_suspend:

```
#cp set loaddev scpdata NEW 'resume=/dev/sda2 no_console_suspend'
```

For a subsequent IPL command, these kernel parameters are concatenated to the end of the existing kernel parameters in your boot configuration.

6. Start the IPL and boot process by entering a command of this form:

```
#cp i <devno>
```

where *<devno>* is the device number of the FCP channel that provides access to the SCSI boot disk.

Tip: You can specify the target port and LUN of the SCSI boot disk, a boot configuration, and SCPDATA all with a single SET LOADDEV command. See *z/VM CP Commands and Utilities Reference*, SC24-6175 for more information about the SET LOADDEV command.

Using a named saved system

To boot your z/VM guest from an NSS, *<nss_name>*, enter an IPL command of this form:

```
#cp i <nss_name> parm <kernel_parameters>
```

where:

<nss_name>

The NSS name can be one to eight characters long and must consist of alphabetic or numeric characters. Examples of valid names include: 73248734, NSSCSITE, or NSS1234.

parm *<kernel_parameters>*

is an optional 56-byte string of kernel parameters to be concatenated to the end of the existing kernel parameters used by your boot configuration (see “Preparing a boot device” on page 325 for information about the boot configuration).

See also “Specifying kernel parameters when booting Linux” on page 21.

Using the z/VM reader

This section provides a summary of how to boot Linux from a z/VM reader. For more details refer to Redpaper *Building Linux Systems under IBM VM*, REDP-0120.

Before you begin:

You need the following files, all in record format fixed 80:

- Linux kernel image with built-in z/VM reader boot loader code. This is the case for the default Red Hat Enterprise Linux 6.3 kernel.
- Kernel parameters (optional)
- Initial RAM disk image (optional)

Proceed like this to boot Linux from a z/VM reader:

1. Establish a CMS session with the guest where you want to boot Linux.
2. Transfer the kernel image, kernel parameters, and the initial RAM disk image to your guest. You can obtain the files from a shared minidisk or use:
 - The z/VM sendfile facility.
 - An FTP file transfer in binary mode.

Files that are sent to your reader contain a file header that you need to remove before you can use them for booting. Receive files that you obtain through your z/VM reader to a minidisk.

3. Set up the reader as a boot device.
 - a. Ensure that your reader is empty.
 - b. Direct the output of the punch device to the reader. Issue:

```
spool pun * rdr
```

- c. Use the CMS PUNCH command to transfer each of the required files to the reader. Be sure to use the “no header” option to omit the file headers.

First transfer the kernel image.

Second transfer the kernel parameters.

Third transfer the initial RAM disk image, if present.

For each file, issue a command of this form:

```
pun <file_name> <file_type> <file_mode> (noh
```

- d. Optionally, ensure that the contents of the reader remain fixed.

```
change rdr all keep nohold
```

If you omit this step, all files are deleted from the reader during the IPL that follows.

4. Issue the IPL command:

```
ipl 000c clear parm <kernel_parameters>
```

where:

0x000c

is the device number of the reader.

parm <kernel_parameters>

is an optional 64-byte string of kernel parameters to be concatenated to the end of the existing kernel parameters used by your boot configuration (see “Preparing a boot device” on page 325 for information about the boot configuration).

See also “Specifying kernel parameters when booting Linux” on page 21.

Booting Linux in LPAR mode

You can boot Linux in LPAR mode from a Hardware Management Console (HMC) or Support Element (SE). The following description refers to an HMC, but the same steps also apply to an SE.

Booting from DASD, tape, or SCSI

Before you begin:

- You need a boot device prepared with **zipl** (see “Preparing a boot device” on page 325).
- For booting from a SCSI boot device, you need to have the SCSI IPL feature (FC9904) installed.

Perform these steps to boot from a DASD, tape, or SCSI boot device:

1. In the navigation pane of the HMC expand **Systems Management** and **Servers** and select the mainframe system you want to work with. A table of LPARs is displayed on the **Images** tab in the content area.
2. Select the LPAR where you want to boot Linux.

3. In the **Tasks** area, expand **Recovery** and click **Load** (see Figure 62).




Figure 62. Load task on the HMC

4. Proceed according to your boot device.
 - For booting from tape:
 - a. Select **Load type** "Normal" (see Figure 63).

Load - H42:H42LP05

CPC: H42:H42LP05

Image: H42:H42LP05

Load type: ☒ Normal ☐ Clear ☐ SCSI ☐ SCSI dump

☐ Store status

Load address: *E711

Load parameter:

Time-out value: 60 60 to 600 seconds

Worldwide port name: 0

Logical unit number: 0

Boot program selector: 0

Boot record logical block address: 0

Operating system specific load parameters:

OK Reset Cancel Help

Figure 63. Load panel for booting from tape or DASD

- b. Enter the device number of the tape boot device in the **Load address** field.

For booting from DASD:

- Select **Load type** “Normal” (see Figure 63 on page 356).
- Enter the device number of the DASD boot device in the **Load address** field.
- If the boot configuration is part of a **zipl** created menu configuration, enter the configuration number that identifies your DASD boot configuration within the menu in the **Load parameter** field.

Configuration number “0” specifies the default configuration. Depending on the menu configuration, omitting this option might display the menu or select the default configuration. Specifying “prompt” instead of a configuration number forces the menu to be displayed.

Displaying the menu allows you to specify additional kernel parameters (see “Example for a DASD menu configuration (LPAR)” on page 358). These additional kernel parameters are appended to the parameters you might have provided in a parameter file. The combined parameter string must not exceed 895 bytes.

See “Menu configurations” on page 342 for more details about menu configurations.

For booting from a SCSI device:

A SCSI device can be a disk or an FC-attached CD-ROM or DVD drive.

- Select **Load type** “SCSI” (see Figure 64).

The screenshot shows a configuration window titled "Load - H42:H42LP05". It contains the following fields and controls:

- CPC:** H42:H42LP05
- Image:** H42:H42LP05
- Load type:** Radio buttons for Normal, Clear, **SCSI** (selected), and SCSI dump.
- ☐ **Store status**
- Load address:** Text field containing "3C00" with a "*" icon to its left.
- Load parameter:** Empty text field.
- Time-out value:** Spin box showing "60" with a range of "60 to 600 seconds".
- Worldwide port name:** Text field containing "500507630300c562".
- Logical unit number:** Text field containing "4010403c00000000".
- Boot program selector:** Text field containing "0".
- Boot record logical block address:** Text field containing "0".
- Operating system specific load parameters:** Text area containing "noresume".

At the bottom are buttons for OK, Reset, Cancel, and Help.

Figure 64. Load panel with SCSI feature enabled — for booting from a SCSI device

- Enter the device number of the FCP channel through which the SCSI device is accessed in the **Load address** field.
- Enter the WWPN of the SCSI device in the **World wide port name** field.
- Enter the LUN of the SCSI device in the **Logical unit number** field.
- If the boot configuration is part of a **zipl** created menu configuration, enter the configuration number that identifies your SCSI boot configuration

within the menu in the **Boot program selector** field. Configuration number “0” specifies the default configuration. For example, an installation from DVD is typically done with boot program selector 2.

See “Menu configurations” on page 342 for more details about menu configurations.

- f. **Optional:** Type kernel parameters in the **Operating system specific load parameters** field. These parameters are concatenated to the end of the existing kernel parameters used by your boot configuration when booting Linux.

Use ASCII characters only. If you enter characters other than ASCII characters, the boot process ignores the data in the **Operating system specific load parameters** field.

- g. Accept the defaults for the remaining fields.

- 5. Click **OK** to start the boot process.

Check the output on the preferred console (see “Console kernel parameter syntax” on page 305) to monitor the boot progress.

Example for a DASD menu configuration (LPAR)

This example illustrates how menu2 in the sample configuration file in Figure 60 on page 344 displays on the hardware console:

```
zIPL interactive boot menu

0. default (boot1)

1. boot1
2. boot3

Please choose (default will boot in 30 seconds):
```

You choose a configuration by specifying the configuration number. For example, to boot configuration boot3, issue:

```
# 2
```

You can also specify additional kernel parameters by appending them to this command. For example:

```
# 2 maxcpus=1 mem=64m
```

Loading Linux from a DVD or from an FTP server

You can use the SE to copy the Linux kernel image directly to your LPARs memory. This process bypasses IPL and does not require a boot loader. The SE performs the tasks that are normally done by the boot loader code. When the Linux kernel has been loaded, Linux is started using restart PSW.

As a source, you can use the SE's CD-ROM/DVD drive or any device on a remote system that you can access through FTP from your SE. If you access the SE remotely from an HMC, you can also use the CD-ROM drive of the system where your HMC runs.

The installation process requires a file with a mapping of the location of installation data in the file system of the DVD or FTP server and the memory

locations where the data is to be copied. For Red Hat Enterprise Linux 6.3 this file is called `generic.ins` and located in the root directory of the file system on the DVD.

1. In the navigation pane of the HMC expand **Systems Management** and **Servers** and select the mainframe system you want to work with. A table of LPARs is displayed on the **Images** tab in the content area.
2. Select the LPAR where you want to boot Linux.
3. In the **Tasks** area, expand **Recovery** and click **Load from Removable Media or Server** (see Figure 65).




Figure 65. Load from Removable Media or Server task on the HMC

4. Specify the source of the code to be loaded.
For loading from a CD-ROM drive:
 - a. Select **Hardware Management Console CD-ROM/DVD** (see Figure 66 on page 360).




Figure 66. Load from Removable Media or Server panel

- b. Leave the **File location** field blank.

For loading from an FTP server:

- a. Select the **FTP Source** radio button.
 - b. Enter the IP address or host name of the FTP server where the install code resides in the **Host computer** entry field.
 - c. Enter your user ID for the FTP server in the **User ID** entry field.
 - d. Enter your password for the FTP server in the **Password** entry field.
 - e. If required by your FTP server, enter your account information in the **Account** entry field.
 - f. Enter the path for the directory where the `generic.ins` resides in the file location entry field. You can leave this field blank if the file resides in the FTP server's root directory.
5. Click **Continue** to display the “Select Software to Install” panel (Figure 67).




Figure 67. Select Software to Install panel

6. Select the `generic.ins` file.
7. Click **OK** to start loading Linux.

At this point the kernel has started and the Red Hat Enterprise Linux 6.3 boot process continues.

Displaying current IPL parameters

To display the IPL parameters, use the command **lsreipl** (see “lsreipl - List IPL and re-IPL settings” on page 469). Alternatively, a sysfs user-space interface is available: `/sys/firmware/ipl/ipl_type`

The `/sys/firmware/ipl/ipl_type` file contains the device type from which the kernel was booted. The following values are possible:

ccw The IPL device is a CCW device, for example, a DASD or the z/VM reader.

fcpl The IPL device is an FCP device.

nss The IPL device is a z/VM named saved system.

unknown

The IPL device is not known.

Depending on the IPL type, additional files might reside in `/sys/firmware/ipl/`.

If the device is a CCW device, the additional files `device` and `loadparm` are present.

device Contains the bus ID of the CCW device used for IPL, for example:

```
# cat /sys/firmware/ipl/device
0.0.1234
```

loadparm

Contains up to 8 characters for the loadparm used for IPL, for example:

```
# cat /sys/firmware/ipl/loadparm
1
```

parm

Contains additional kernel parameters specified with the PARM parameter when booting with the z/VM CP IPL command, for example:

```
# cat /sys/firmware/ipl/parm
noresume
```

See also “Specifying kernel parameters when booting Linux” on page 21.

A leading equal sign (=) indicates that the existing kernel parameters used by the boot configuration were ignored and the kernel parameters of the `parm` attribute were the only kernel parameters used for booting Linux. See “Replacing all kernel parameters in a boot configuration” on page 22.

If the device is FCP, a number of additional files are present (also see Chapter 5, “SCSI-over-Fibre Channel device driver,” on page 61 for details):

device Contains the bus ID of the FCP device used for IPL, for example:

```
# cat /sys/firmware/ipl/device
0.0.50dc
```

wwpn Contains the WWPN used for IPL, for example:

```
# cat /sys/firmware/ipl/wwpn
0x5005076300c20b8e
```

lun Contains the LUN used for IPL, for example:

```
# cat /sys/firmware/ipl/lun
0x5010000000000000
```

br_lba Contains the logical block address of the boot record on the boot device (usually 0).

bootprog

Contains the boot program number.

scp_data

Contains additional kernel parameters used when booting from a SCSI device (see “Using a SCSI device” on page 352 and “Bootting from DASD, tape, or SCSI” on page 355). A leading equal sign (=) indicates that the existing kernel parameters used by the boot configuration were ignored and the kernel parameters of the scp_data attribute where the only kernel parameters used for booting Linux.

```
# cat /sys/firmware/ipl/scp_data
noresume
```

binary_parameter

Contains the information of the preceding files in binary format.

Rebooting from an alternative source

When you reboot Linux, the system conventionally boots from the last used location. However, you can configure an alternative device to be used for re-IPL instead of the last used IPL device. When the system is re-IPLed, the alternative device is used to boot the kernel.

To configure the re-IPL device, use the **chreipl** tool (see “chreipl - Modify the re-IPL configuration” on page 402).

Alternatively, you can use a sysfs interface. The virtual configuration files are located under `/sys/firmware/reipl`. To configure, write strings into the configuration files. The following re-IPL types can be set with the `/sys/firmware/reipl/reipl_type` attribute:

- **ccw**: For ccw devices such as ESCON- or FICON-attached DASDs.
- **fcp**: For FCP SCSI devices, including SCSI disks and CD or DVD drives (Hardware support is required.)
- **nss**: For Named Saved Systems (z/VM only)

For each supported re-IPL type a sysfs directory is created under `/sys/firmware/reipl` that contains the configuration attributes for the device. The directory name is the same as the name of the re-IPL type.

When Linux is booted, the re-IPL attributes are set by default to the values of the boot device, which can be found under `/sys/firmware/ipl`.

Attributes for ccw

The attributes for re-IPL type ccw under `/sys/firmware/reipl/ccw` are:

- `device`: Device number of the re-IPL device. For example 0.0.4711.

Note: IPL is possible only from subchannel set 0.

- `loadparm`: Up to eight characters for the loadparm used to select the boot configuration in the `zipl` menu (if available).
- `parm`: A 64-byte string containing kernel parameters that is concatenated to the boot command line. The `PARM` parameter can only be set for Linux on z/VM. See also “Specifying kernel parameters when booting Linux” on page 21.

A leading equal sign (=) means that the existing kernel parameter line in the boot configuration is ignored and the boot process uses the kernel parameters in the `parm` attribute only. See also “Replacing all kernel parameters in a boot configuration” on page 22.

Attributes for fcp

The attributes for re-IPL type fcp under `/sys/firmware/reipl/fcp` are:

- `device`: Device number of the FCP device used for re-IPL. For example 0.0.4711.

Note: IPL is possible only from subchannel set 0.

- `wwpn`: World wide port number of the FCP re-IPL device.
- `lun`: Logical unit number of the FCP re-IPL device.
- `bootprog`: Boot program selector. Used to select the boot configuration in the `zipl` menu (if available).
- `br_lba`: Boot record logical block address. Master boot record. Is always 0 for Linux.
- `scp_data`: Kernel parameters to be used for the next FCP re-IPL.

A leading equal sign (=) means that the existing kernel parameter line in the boot configuration is ignored and the boot process uses the kernel parameters in the `scp_data` attribute only. See also “Replacing all kernel parameters in a boot configuration” on page 22.

Attributes for nss

The attributes for re-IPL type nss under `/sys/firmware/reipl/nss` are:

- `name`: Name of the NSS. The NSS name can be 1-8 characters long and must consist of alphabetic or numeric characters. Examples of valid names include: 73248734, NSSCSITE, or NSS1234.
- `parm`: A 56-byte string containing kernel parameters that is concatenated to the boot command line. (Note the difference in length compared to ccw.) See also “Specifying kernel parameters when booting Linux” on page 21.

A leading equal sign (=) means that the existing kernel parameter line in the boot configuration is ignored and the boot process uses the kernel parameters in the `parm` attribute only. See also “Replacing all kernel parameters in a boot configuration” on page 22.

Kernel panic settings

Set the attribute `/sys/firmware/shutdown_actions/on_panic` to `reipl` to make the system re-IPL with the current re-IPL settings in case of a kernel panic. See also the **dumpconf** tool described in *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607 on the developerWorks website at

Examples

- To configure an FCP re-IPL device 0.0.4711 with a LUN 0x4711000000000000 and a WWPN 0x5005076303004711 with an additional kernel parameter noresume:

```
# echo 0.0.4711 > /sys/firmware/reipl/fcp/device
# echo 0x5005076303004711 > /sys/firmware/reipl/fcp/wwpn
# echo 0x4711000000000000 > /sys/firmware/reipl/fcp/lun
# echo 0 > /sys/firmware/reipl/fcp/bootprog
# echo 0 > /sys/firmware/reipl/fcp/br_lba
# echo "noresume" > /sys/firmware/reipl/fcp/scp_data
# echo fcp > /sys/firmware/reipl/reipl_type
```

Note: IPL is possible only from subchannel set 0.

- To set up re-IPL from a Linux NSS with different parameters:

1. Change to the reipl sysfs directory:

```
# cd /sys/firmware/reipl/
```

2. Set the reipl_type to nss:

```
# echo nss > reipl_type
```

3. Setup the attributes in the nss directory:

```
# echo LNXNSS > name
# echo "dasd=0150 root=/dev/dasda1" > parm
```

- To specify additional kernel parameters for Linux re-IPL, follow these steps:

1. Change to the sysfs directory appropriate for the next re-IPL:

```
# cd /sys/firmware/reipl/${cat /sys/firmware/reipl/reipl_type}
/sys/firmware/reipl/ccw
```

2. Use the echo command to output the parameter string into the parm attribute:

```
# echo "noresume" > parm
```

Chapter 37. Suspending and resuming Linux

With suspend and resume support, you can stop a running Linux on System z instance and later continue operations.

When Linux is suspended, data is written to a swap partition. The resume process uses this data to make Linux continue from where it left off when it was suspended. A suspended Linux instance does not require memory or processor cycles.

Features

Linux on System z suspend and resume support applies to both Linux on z/VM and Linux instances that run directly in an LPAR.

After a Linux instance has been suspended, you can run another Linux instance in the z/VM guest virtual machine or in the LPAR where the suspended Linux instance was running.

What you should know about suspend and resume

This section describes the prerequisites for suspending a Linux instance and makes you aware of activities that can cause resume to fail.

Prerequisites for suspending a Linux instance

Before a Linux instance is suspended, suspend and resume support checks for conditions that might prevent resuming the suspended Linux instance. You cannot suspend a Linux instance if the check finds prerequisites that are not fulfilled.

The following prerequisites must be fulfilled regardless of whether a Linux instance runs directly in an LPAR or as a z/VM guest:

- All tape device nodes must be closed and online tape drives must be unloaded.
- The Linux instance must not have used any hotplug memory since it was last booted.
- No program must be in a prolonged uninterruptible sleep state.
Programs can assume this state while waiting for an outstanding I/O request to complete. Most I/O requests complete in a very short time and do not compromise suspend processing. An example of an I/O request that can take too long to complete is rewinding a tape.

For Linux on z/VM, the following additional prerequisites must be fulfilled:

- No discontinuous saved segment (DCSS) device must be accessed in exclusive-writable mode.
You must remove all DCSSs of segment types EW, SW, and EN by writing the DCSS name to the sysfs remove attribute.
You must remove all DCSSs of segment types SR and ER that are accessed in exclusive-writable mode or change their access mode to shared.
For details see “Removing a DCSS device” on page 231 and “Setting the access mode” on page 228.
- All device nodes of the z/VM recording device driver must be closed.

- All device nodes of the z/VM unit record device driver must be closed.
- No watchdog timer must run and the watchdog device node must be closed.

Precautions while a Linux instance is suspended

There are conditions outside the control of the suspended Linux instance that can cause resume to fail. In particular:

- The CPU configuration must remain unchanged between suspend and resume.
- The data that is written to the swap partition when the Linux instance is suspended must not be compromised.

In particular, be sure that the swap partition is not used if another operating system instance runs in the LPAR or z/VM guest virtual machine after the initial Linux instance has been suspended.

- If the Linux instance uses expanded storage (XPRAM), this expanded storage must remain unchanged until the Linux instance is resumed.

If the size or content of the expanded memory is changed before the Linux instance is resumed or if the expanded memory is unavailable when the Linux instance is resumed, resuming fails with a kernel panic.

- If an instance of Linux on z/VM uses one or more DCSSs these DCSSs must remain unchanged until the Linux instance is resumed.

If the size, location, or content of a DCSS is changed before the Linux instance is resumed, resuming fails with a kernel panic.

- For an instance of Linux on z/VM with a Linux kernel that is a named saved system (NSS), the NSS must remain unchanged until the Linux instance is resumed.

If the size, location, or content of the NSS is changed before the Linux instance is resumed, resuming fails.

- Take special care when replacing a DASD and, thus, making a different device available at a particular device bus-ID.

You might intentionally replace a device with a backup device. Changing the device also changes its UID-based device nodes. Expect problems if you run an application that depends on UID-based device nodes and you exchange one of the DASD the application uses. In particular, you cannot use multipath tools when the UID changes.

- The SCSI configuration must remain unchanged until the Linux instance is resumed.
- Generally, avoid changes to the real or virtual hardware configuration between suspending and resuming a Linux instance.
- Disks that hold swap partitions or the root file system must be present when resuming the Linux instance.

Handling of devices that are unavailable when resuming

Devices that were available when the Linux instance was suspended might be unavailable when resuming. If such unavailable devices were offline when the Linux instance was suspended, they are de-registered and the device name can be assigned to other devices.

If unavailable devices were online when the Linux instance was suspended, handling depends on the respective device driver. DASD and FCP devices remain registered as disconnected devices. The device name and the device configuration are preserved. Devices that are controlled by other device drivers are de-registered.

Handling of devices that become available at a different subchannel

The mapping between subchannels and device bus-IDs can change if the real or virtual hardware is restarted between suspending and resuming Linux.

If the subchannel changes for a DASD or FCP device, the device configuration is changed to reflect the new subchannel. This change is accomplished without de-registration. Thus, device name and device configuration are preserved.

If the subchannel changes for any other device, the device is de-registered and registered again as a new device.

Setting up Linux for suspend and resume

This section describes the kernel parameters you can use for setting up suspend and resume support. It also provides information about the swap partition you need to suspend and resume a Linux instance.

Kernel parameters

This section describes the kernel parameters you need to configure support for suspend and resume.

suspend and resume kernel parameter syntax

```
▶▶—resume=<device_node>—[ no_console_suspend ]—[ noresume ]—▶▶
```

where:

resume=<device_node>

specifies the standard device node of the swap partition with the data that is required for resuming the Linux instance.

no_console_suspend

prevents Linux consoles from being suspended early in the suspend process. Without this parameter, you cannot see the kernel messages that are issued by the suspend process.

noresume

boots the kernel without resuming a previously suspended Linux instance. Add this parameter to circumvent the resume process, for example, if the data written by the previous suspend process is damaged.

Example:

To use a partition `/dev/dasda2` as the swap partition and prevent Linux consoles from being suspended early in the suspend process specify:

```
resume=/dev/dasda2 no_console_suspend
```

Setting up a swap partition

During the suspend process, Linux writes data to a swap partition. This data is required later to resume Linux. Set up a swap partition that is at least the size of the available LPAR memory or the memory of the z/VM guest virtual machine.

Do not use this swap partition for any other operating system that might run in the LPAR or z/VM guest virtual machine while the Linux instance is suspended.

You cannot suspend a Linux instance while most of the memory and most of the swap space are in use. If there is not sufficient remaining swap space to hold the data for resuming the Linux instance, suspending the Linux instance fails. To assure sufficient swap space you might have to configure two swap partitions, one partition for regular swapping and another for suspending the Linux instance. Configure the swap partition for suspending the Linux instance with a lower priority than the regular swap partition.

Use the `pri=` parameter to specify the swap partitions in `/etc/fstab` with different priorities. See the `swapon` man page for details.

The following example shows two swap partitions with different priorities:

```
# cat /etc/fstab
...
/dev/dasdb1 swap swap pri=-1 0 0
/dev/dasdc1 swap swap pri=-2 0 0
```

In the example, the partition to be used for the resume data is `/dev/dasdc1`.

You can check your current swap configuration by reading `/proc/swaps`.

```
# cat /proc/swaps
Filename      Type      Size      Used      Priority
/dev/dasdb1   partition 7212136   71056     -1
/dev/dasdc1   partition 7212136   0         -2
```

Configuring for fast resume

The more devices are available to a Linux instance, the longer it takes to resume the instance after it has been suspended. With a thousand or more available devices, the resume process can take longer than an IPL. If the duration of the resume process is critical for a Linux instance with many devices, include unused devices in the exclusion list (see “`cio_ignore` - List devices to be ignored” on page 520).

Suspending a Linux instance

Attention: Only suspend a Linux instance for which you have specified the `resume=` kernel parameter. Without this parameter, you cannot resume the suspended Linux instance.

Enter the following command to suspend a Linux instance:

```
# echo disk > /sys/power/state
```

On the Linux console you might see progress indications until the console itself is suspended. Most of these messages require log level 7 or higher to be printed. See

“Using the magic sysrequest functions” on page 315 about setting the log level. You cannot see such progress messages if you suspend the Linux instance from an ssh session.

Resuming a suspended Linux instance

Boot Linux to resume a suspended Linux instance. Use the same kernel, initial RAM disk, and kernel parameters that you used to first boot the suspended Linux instance.

You must reestablish any terminal session for HVC terminal devices and for terminals provided by the iucv tty program. You also must reestablish all ssh sessions that have timed out while the Linux instance was suspended.

If resuming the Linux instance fails, boot Linux again with the `noresume` kernel parameter. The boot process then ignores the data that was written to the swap partition and starts Linux without resuming the suspended instance.

Chapter 38. Shutdown actions

There are several triggers that can cause Linux to shut down. For each shutdown trigger (see Table 50), you can configure a specific shutdown action to be taken as a response.

Table 50. Shutdown triggers and default action overview

Trigger	Command or condition	Default shutdown action
halt	Linux shutdown -H command	stop
poff	Linux poweroff or shutdown -P command	stop
reboot	Linux reboot or shutdown -r command	reipl
restart	<ul style="list-style-type: none">• PSW restart on the HMC for Linux in LPAR mode• z/VM CP system restart command for Linux on z/VM	stop
panic	Linux kernel panic	stop

The available shutdown actions are summarized in Table 51:

Table 51. Shutdown actions

Action	Explanation	See also
stop	For panic or restart, enters a disabled wait state. For all other shutdown triggers, stops all CPUs.	n/a
ipl	Performs an IPL according to the specifications in <code>/sys/firmware/ipl</code> .	“Displaying current IPL parameters” on page 361
reipl	Performs an IPL according to the specifications in <code>/sys/firmware/reipl</code> .	“Rebooting from an alternative source” on page 362
dump	Creates a dump according to the specifications in <code>/sys/firmware/dump</code> .	<i>Using the Dump Tools on Red Hat Enterprise Linux 6.3, SC34-2607</i>
dump_reipl	Performs the dump action followed by the reipl action.	<i>Using the Dump Tools on Red Hat Enterprise Linux 6.3, SC34-2607</i>
vmcmd	For Linux on z/VM, issues one or more z/VM CP commands according to the specifications in <code>/sys/firmware/vmcmd</code> .	“Configuring z/VM CP commands as a shutdown action” on page 373

Use **lsshut** to find out which shutdown action is configured for each shutdown trigger, see “lsshut - List the current system shutdown actions” on page 470.

Use the applicable command to configure the shutdown action for a shutdown trigger:

- For halt, power off, and reboot use **chshut**, see “chshut - Control the system shutdown actions” on page 406
- For restart and panic use **dumpconf**, see *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607

Possible overrides:

- Red Hat Enterprise Linux 6.3 maps halt to poff. The action specified for halt is ignored and the action specified for poff is triggered instead. You can change this by editing the file `/etc/sysconfig/shutdown` and replacing `HALT="auto"` with `HALT="halt"`.
- If kdump has been set up for a Linux instance, kdump is started to create a dump, regardless of the shutdown actions specified for restart and panic. With kdump, these settings act as a backup that is used only if kdump fails.

Note: kdump is not a shutdown action that you can set as a sysfs attribute value for a shutdown trigger. See *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607 about how to set up kdump.

The shutdown configuration in sysfs

The configured shutdown action for each shutdown trigger is stored in a sysfs attribute `/sys/firmware/shutdown_actions/on_<trigger>` (see Figure 68).




Figure 68. sysfs branch with shutdown action settings

The preferred way to read or change these settings is using the **lsshut**, **chshut**, and **dumpconf** commands. Alternatively, you can read and write to the `/sys/firmware/shutdown_actions/on_<trigger>` attributes.

Examples:

- This command reads the shutdown setting for the poff shutdown trigger.

```
# cat /sys/firmware/shutdown_actions/on_poff
stop
```

- This command changes the setting for the restart shutdown trigger to ipl:

```
# echo ipl > /sys/firmware/shutdown_actions/on_restart
```

Details for the ipl, reipl, dump, and vmcmd shutdown actions are contained in the corresponding subdirectories in `/sys/firmware`. For example, `/sys/firmware/ipl` contains specifications for an IPL device and other IPL parameters.

Configuring z/VM CP commands as a shutdown action

Before you start: This section applies to Linux on z/VM only.

Two attributes are required to set a z/VM CP command as a shutdown action for a trigger *<trigger>*:

- `/sys/firmware/shutdown_actions/on_<trigger>` must be set to `vmcmd`.
- `/sys/firmware/vmcmd/on_<trigger>` specifies the z/VM CP command.

Example:

The commands in this example configure the z/VM CP LOGOFF command as the shutdown action for the `poff` shutdown trigger:

```
# echo vmcmd > /sys/firmware/shutdown_actions/on_poff
# echo LOGOFF > /sys/firmware/vmcmd/on_poff
```

Figure 69 illustrates this example.




Figure 69. sysfs branch with shutdown action settings

Use the **chshut** and **dumpconf** commands to change your settings. As an alternative, you can write directly to the sysfs attributes. The values of the attributes in the `/sys/firmware/vmcmd` directory must conform to these rules:

- The value must be a valid z/VM CP command.
- The commands, including any z/VM user IDs or device numbers, must be specified with uppercase characters.
- Commands that include blanks must be delimited by double quotation marks (`"`).
- The value must not exceed 127 characters.

You can specify multiple z/VM CP commands separated by the newline character `"\n"`. Each newline is counted as one character. When writing values with multiple commands, use this syntax to ensure that the newline character is processed correctly:

```
# echo -e <cmd1>\n<cmd2>... | cat > /sys/firmware/vmcmd/on_<trigger>
```

where <cmd1>\n<cmd2>... are two or more z/VM CP commands and on_<trigger> is one of the attributes in the vmcmd directory.

Example:

The commands in this example configure two z/VM CP commands as the shutdown action for the poff shutdown trigger. First a message is sent to user OPERATOR, and then the LOGOFF command is issued.

```
# echo vmcmd > /sys/firmware/shutdown_actions/on_poff
# echo -e "MSG OPERATOR Going down\nLOGOFF" | cat > /sys/firmware/vmcmd/on_poff
```

The **-e echo** option and redirect through **cat** are required because of the newline character.

Part 8. Diagnostics and troubleshooting

This section describes device drivers and features that are used in the context of diagnostics and problem solving.

Newest version: You can find the newest version of this book at www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

Restrictions: For prerequisites and restrictions see the System z architecture specific information in the Red Hat Enterprise Linux 6.3 release notes at docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

Chapter 39. Logging I/O subchannel status information.	377
Example	377
Chapter 40. Channel measurement facility.	379
Features	379
Setting up the channel measurement facility	379
Working with the channel measurement facility	380
Chapter 41. Control program identification	383
Working with the CPI support.	383
Chapter 42. Activating automatic problem reporting	387
Setting up the Call Home support	387
Activating the Call Home support	387
Chapter 43. Avoiding common pitfalls	389
Ensuring correct channel path status	389
Determining channel path usage	389
Configuring LPAR I/O devices	389
Using cio_ignore	390
Excessive guest swapping	390
Including service levels of the hardware and the hypervisor	390
Bootting stops with disabled wait state	391
Preparing for dump-on-panic	391
Multipath failover causes kernel panic	391

Chapter 39. Logging I/O subchannel status information

When investigating I/O subchannels, support specialists might request operation status information for the subchannel. The channel subsystem offers a logging facility that creates a set of log entries with such information. From Linux, you can trigger this logging facility through sysfs.

The log entries are available through the SE Console Actions Work Area with the View Console Logs function. The entries differ dependent on the device and model that is connected to the subchannel. On the SE, the entries are listed with a prefix that identifies the model. The content of the entries is intended for support specialists.

To create a log entry issue a command of this form:

```
# echo 1 > /sys/devices/css0/<subchannel-bus-id>/logging
```

where *<subchannel-bus-id>* is the bus ID of the I/O subchannel that corresponds to the I/O device for which you want to create a log entry.

To find out how your I/O devices map to subchannels you can use, for example, the **lscss** command.

Example

In this example, first the subchannel for an I/O device with bus ID 0.0.3d07 is identified, then logging is initiated.

```
# lscss -d 0.0.3d07
Device  Subchan.  DevType CU Type Use  PIM PAM POM  CHPIDs
-----
0.0.3d07 0.0.000c 1732/01 1731/01    80 80 ff  05000000 00000000
# echo 1 > /sys/devices/css0/0.0.000c/logging
```

Chapter 40. Channel measurement facility

The System z architecture provides a channel measurement facility to collect statistical data about I/O on the channel subsystem. Data collection can be enabled for all CCW devices. User space applications can access this data through the sysfs.

Features


The channel measurement facility provides the following features:

- Basic channel measurement format for concurrently collecting data on up to 4096 devices. (Note that specifying 4096 or more channels causes high memory consumption and enabling data collection might not succeed.)
- Extended channel measurement format for concurrently collecting data on an unlimited number of devices.
- Data collection for all channel-attached devices, except those using QDIO (that is, except qeth and SCSI-over-Fibre channel attached devices)

Setting up the channel measurement facility

You can configure the channel measurement facility by adding parameters to the kernel parameter file.

Channel measurement facility kernel parameters



Note: If you specify both parameter=value pairs, separate them with a blank.

where:

cmf.format

defines the format, “0” for basic and “1” for extended, of the channel measurement blocks. The default, “-1”, assigns a format depending on the hardware. For System z9 and System z10 mainframes the extended format is used.

cmf.maxchannels=<no_channels>

limits the number of devices for which data measurement can be enabled concurrently with the basic format. The maximum for <no_channels> is 4096. A warning will be printed if more than 4096 channels are specified. The channel measurement facility might still work; however, specifying more than 4096 channels causes a high memory consumption.

For the extended format there is no limit and any value you specify is ignored.

Working with the channel measurement facility

This section describes typical tasks you need to perform when working with the channel measurement facility.

- Enabling, resetting, and switching off data collection
- Reading data

Enabling, resetting, and switching off data collection

Use a device's `cmb_enable` attribute to enable, reset, or switch off data collection. To enable data collection, write “1” to the `cmb_enable` attribute. If data collection has already been enabled, this resets all collected data to zero.

Issue a command of this form:

```
# echo 1 > /sys/bus/ccw/devices/<device_bus_id>/cmb_enable
```

where `/sys/bus/ccw/devices/<device_bus_id>` represents the device in sysfs.

When data collection is enabled for a device, a subdirectory `/sys/bus/ccw/devices/<device_bus_id>/cmf` is created that contains several attributes. These attributes contain the collected data (see “Reading data”).

To switch off data collection issue a command of this form:

```
# echo 0 > /sys/bus/ccw/devices/<device_bus_id>/cmb_enable
```

When data collection for a device is switched off, the subdirectory `/sys/bus/ccw/devices/<device_bus_id>/cmf` and its content are deleted.

Example:

In this example, data collection for a device `/sys/bus/ccw/devices/0.0.b100` is already active and reset:

```
# cat /sys/bus/ccw/devices/0.0.b100/cmb_enable
1
# echo 1 > /sys/bus/ccw/devices/0.0.b100/cmb_enable
```

Reading data

While data collection is enabled for a device, the directories that represent it in sysfs contain a subdirectory, `cmf`, with several read-only attributes. These attributes hold the collected data. To read one of the attributes issue a command of this form:

```
# cat /sys/bus/ccw/devices/<device-bus-id>/cmf/<attribute>
```

where `/sys/bus/ccw/devices/<device-bus-id>` is the directory that represents the device, and `<attribute>` the attribute to be read. Table 52 on page 381 summarizes the available attributes.

Table 52. Attributes with collected I/O data

Attribute	Value
ssch_rsch_count	An integer representing the ssch rsch count value.
sample_count	An integer representing the sample count value.
avg_device_connect_time	An integer representing the average device connect time, in nanoseconds, per sample.
avg_function_pending_time	An integer representing the average function pending time, in nanoseconds, per sample.
avg_device_disconnect_time	An integer representing the average device disconnect time, in nanoseconds, per sample.
avg_control_unit_queuing_time	An integer representing the average control unit queuing time, in nanoseconds, per sample.
avg_initial_command_response_time	An integer representing the average initial command response time, in nanoseconds, per sample.
avg_device_active_only_time	An integer representing the average device active only time, in nanoseconds, per sample.
avg_device_busy_time	An integer representing the average value device busy time, in nanoseconds, per sample.
avg_utilization	A percent value representing the fraction of time that has been spent in device connect time plus function pending time plus device disconnect time during the measurement period.
avg_sample_interval	An integer representing the average time, in nanoseconds, between two samples during the measurement period. Can be "-1" if no measurement data has been collected.
avg_initial_command_response_time	An integer representing the average time in nanoseconds between the first command of a channel program being sent to the device and the command being accepted. Available in extended format only.
avg_device_busy_time	An integer representing the average time in nanoseconds of the subchannel being in the "device busy" state when initiating a start or resume function. Available in extended format only.

Example:

To read the avg_device_busy_time attribute for a device /sys/bus/ccw/devices/0.0.b100:

```
# cat /sys/bus/ccw/devices/0.0.b100/cmf/avg_device_busy_time
21
```

Chapter 41. Control program identification

This section applies to Linux instances in LPAR mode only.

If your Linux instance runs in LPAR mode, you can assign names to your Linux instance and sysplex using:

- The `/etc/sysconfig/cpi` configuration file provided by Red Hat Enterprise Linux 6.3
- The sysfs interface `/sys/firmware/cpi`
- The control program identification (CPI) module, `sclp_cpi`

The names are used, for example, to identify the Linux instance or the sysplex on the HMC. This section describes how to set the system and sysplex names using sysfs.

Red Hat Enterprise Linux 6.3 provides an init script, `/etc/init.d/cpi`, to set the system and sysplex name automatically during system boot.

Working with the CPI support

This section describes typical tasks that you need to perform when working with CPI support.

- Loading the CPI module
- “Defining a sysplex name” on page 384
- “Defining a system name” on page 384
- “Displaying the system type” on page 384
- “Displaying the system level” on page 384
- “Sending system data to the SE” on page 385

Loading the CPI module

You can provide the system name and the sysplex name as parameters when you load the CPI module, but the preferred method is to edit the `/etc/sysconfig/cpi` configuration file. When loading the CPI module the following is sent to the SE:

- System name (if provided)
- Sysplex name (if provided)
- System type (automatically set to "LINUX")
- System level (automatically set to the value of `LINUX_VERSION_CODE`)

CPI module parameter syntax

```
➤—modprobe— sclp_cpi—┐ system_name=<system>—┐ sysplex_name=<sysplex>—┐➤
```

where:

system_name = <system>

specifies an eight-character system name of the following set: A-Z, 0-9, \$, @, # and blank. The specification is converted to uppercase.

sysplex_name = <sysplex>

specifies an eight-character sysplex name of the following set: A-Z, 0-9, \$, @, # and blank. The specification is converted to uppercase.

Defining a system name

Use the attribute `system_name` in `sysfs` to specify a system name:

```
/sys/firmware/cpi/system_name
```

The system name is a string consisting of up to eight characters of the following set: A-Z, 0-9, \$, @, # and blank.

Example:

```
# echo LPAR12 > /sys/firmware/cpi/system_name
```

This attribute is intended for setting the name only. To confirm the current system name, check the HMC.

Defining a sysplex name

Use the attribute `sysplex_name` in `sysfs` to specify a sysplex name:

```
/sys/firmware/cpi/sysplex_name
```

The sysplex name is a string consisting of up to eight characters of the following set: A-Z, 0-9, \$, @, # and blank.

Example:

```
# echo SYSPLEX1 > /sys/firmware/cpi/sysplex_name
```

This attribute is intended for setting the name only. To confirm the current sysplex name, check the HMC.

Displaying the system type

The attribute `system_type` in `sysfs` provides the system type:

```
/sys/firmware/cpi/system_type
```

Example:

```
# cat /sys/firmware/cpi/system_type
LINUX
```

For Red Hat Enterprise Linux the system type is LINUX.

Displaying the system level

The attribute `system_level` in `sysfs` provides the operating system version:

```
/sys/firmware/cpi/system_level
```

The information is displayed in the format:

0x0000000000aabbcc

where:

aa kernel version

bb kernel patch level

cc kernel sublevel

Example: Linux kernel 2.6.32 displays as

```
# cat /sys/firmware/cpi/system_level  
0x000000000020620
```

Sending system data to the SE

Use the attribute set in sysfs to send data to the service element:

/sys/firmware/cpi/set

To send the data in attributes `sysplex_name`, `system_level`, `system_name`, and `system_type` to the SE, write an arbitrary string to the set attribute.

Example:

```
# echo 1 > /sys/firmware/cpi/set
```

Chapter 42. Activating automatic problem reporting

You can activate automatic problem reporting for situations where Linux experiences a kernel panic. Linux then uses the Call Home function to send automatically collected problem data to the IBM service organization through the Service Element. Hence a system crash automatically leads to a new Problem Management Record (PMR) which can be processed by IBM service.

Before you begin:

- The Linux instance must run in an LPAR.
- You need a hardware support agreement with IBM to report problems to RETAIN[®].

Setting up the Call Home support

To set up the Call Home support, load the `sclp_async` module with the `modprobe` command.

```
# modprobe sclp_async
```

There are no module parameters for `sclp_async`.

Activating the Call Home support

When the `sclp_async` module is loaded, you can control it through the `sysctl` interface or `procfs`.

To activate the support, set the `callhome` attribute to 1. To deactivate the support, set the `callhome` attribute to 0. Issue a command of this form:

```
# echo <flag> > /proc/sys/kernel/callhome
```

This is equivalent to:

```
# sysctl -w kernel.callhome=<flag>
```

To persistently enable the `callhome` feature across reboots, add "`kernel.callhome=1`" to the `/etc/sysctl.conf` file. The kernel module must be loaded before the `sysctl.conf` file is processed.

Linux cannot check if the Call Home function is supported by the hardware.

Example:

To activate the Call Home support issue:

```
# echo 1 > /proc/sys/kernel/callhome
```

To deactivate the Call Home support issue:

```
# echo 0 > /proc/sys/kernel/calldone
```

Chapter 43. Avoiding common pitfalls

This chapter lists some common problems and describes how to avoid them.

Ensuring correct channel path status

Ensure that you have varied the path offline before performing a planned task on it, such as:

- Pulling out or plugging in a cable on a path.
- Configuring a path off or on at the SE.

To vary the path offline, issue a command of the form:

```
echo off > /sys/devices/css0/chp0.<chpid>/status
```

After the operation has finished and the path is available again, vary the path online using a command of the form:

```
echo on > /sys/devices/css0/chp0.<chpid>/status
```

If an unplanned change in path availability occurred (such as unplanned cable pulls or a temporary path malfunction), the PIM/PAM/POM values (as obtained through `lscss`) may not be as expected. To update the PIM/PAM/POM values, vary one of the paths leading to the affected devices using:

```
echo off > /sys/devices/css0/chp0.<chpid>/status  
echo on > /sys/devices/css0/chp0.<chpid>/status.
```

Rationale: Linux does not always receive a notification (machine check) when the status of a path changes (especially a path becoming online again). To make sure Linux has up-to-date information about the usable paths, path verification is triggered through the Linux vary operation.

Determining channel path usage

To determine the usage of a specific channel path on LPAR, for example, to check whether traffic is distributed evenly over all channel paths, use the channel path measurement facility. See “Channel path measurement” on page 13 for details.

Configuring LPAR I/O devices

A Linux LPAR should only contain those I/O devices that it uses. Achieve this by:

- Adding only the needed devices to the IOCDs
- Using the `cio_ignore` kernel parameter to ignore all devices that are not currently in use by this LPAR.

If more devices are needed later, they can be dynamically removed from the list of devices to be ignored. For a description on how to use the `cio_ignore` kernel parameter and the `/proc/cio_ignore` dynamic control, see “`cio_ignore` - List devices to be ignored” on page 520 and “Changing the exclusion list” on page 521.

Rationale: Numerous unused devices can cause:

- Unnecessary high memory usage due to device structures being allocated.
- Unnecessary high load on status changes, because hot-plug handling must be done for every device found.

Using cio_ignore

With cio_ignore, essential devices might have been hidden. For example, if Linux does not boot under z/VM and does not show any message except

```
HCPGIR450W CP entered; disabled wait PSW 00020001 80000000 00000000 00144D7A
```

check if cio_ignore is used and verify that the console device, which is typically device number 0.0.0009, is not ignored.

Excessive guest swapping

If an instance of Linux on z/VM seems to be swapping and not making any progress, you might try to set the timed page pool size and the static page pool size to zero:

```
# echo 0 > /proc/sys/vm/cmm_timed_pages
# echo 0 > /proc/sys/vm/cmm_pages
```

If you see a temporary relief, the guest does not have enough memory. Try increasing the guest memory.

If the problem persists, z/VM might be out of memory.

If you are using cooperative memory management (CMM), unload the cooperative memory management module:

```
# modprobe -r cmm
```

See Chapter 24, “Cooperative memory management,” on page 253 for more details about CMM.

Including service levels of the hardware and the hypervisor

The service levels of the different hardware cards, the LPAR level and the z/VM service level are valuable information for problem analysis. If possible, include this information with any problem you report to IBM service.

A /proc interface that provides a list of service levels is available. To see the service levels issue:

```
# cat /proc/service_levels
```

Example for a z/VM system with a QETH adapter:

```
# cat /proc/service_levels
VM: z/VM Version 5 Release 2.0, service level 0801 (64-bit)
qeth: 0.0.f5f0 firmware level 087d
```

Booting stops with disabled wait state

On Red Hat Enterprise Linux 6.3, a processor type check is automatically run at every kernel startup. If the check determines that Red Hat Enterprise Linux 6.3 is not compatible with the hardware, it stops the boot process with a disabled wait PSW with an address of zero.

If this happens, ensure that you are running Red Hat Enterprise Linux 6.3 on supported hardware. See the Red Hat Enterprise Linux 6.3 release notes at http://docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

Preparing for dump-on-panic

You might want to consider setting up your system to automatically create a dump after a kernel panic. Configuring and using dump-on-panic has the following advantages:

- You have a dump disk prepared ahead of time.
- You do not have to reproduce the problem since a dump will be triggered automatically immediately after the failure.

See Chapter 38, “Shutdown actions,” on page 371 for details.

Multipath failover causes kernel panic

In a multipath setup where SCSI disks are attached over multiple paths, failover might trigger a kernel panic.

To remedy this, try increasing the value for `fast_fail` to, for example, 5 seconds and `dev_loss_tmo` to, for example, 120 seconds.

Part 9. Reference

This section describes commands, kernel parameters, kernel options, and Linux use of z/VM DIAG calls.

Newest version: You can find the newest version of this book at
www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

Restrictions: For prerequisites and restrictions see the System z architecture specific information in the Red Hat Enterprise Linux 6.3 release notes at
docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

Chapter 44. Commands for Linux on System z	395
Generic command options	395
chccwdev - Set a CCW device online	396
chchp - Change channel path status	398
chmem - Set memory online or offline	400
chreipl - Modify the re-IPL configuration	402
chshut - Control the system shutdown actions	406
chzcrypt - Modify the zcrypt configuration	408
cmsfs-fuse - Mount a z/VM CMS file system.	410
cpuplugd - Control CPUs and memory.	415
dasdfmt - Format a DASD	423
dasdstat - Display DASD performance statistics	426
dasdview - Display DASD structure.	429
fdasd - Partition a DASD	438
hyptop - Display hypervisor performance data	446
icainfo - Show available libica functions	455
icastats - Show libica functions	456
lschp - List channel paths	457
lscss - List subchannels	459
lsdasd - List DASD devices.	461
lsluns - Discover LUNs in Fibre Channel SANs	463
lsmem - Show online status information about memory blocks.	465
lsqeth - List qeth-based network devices	467
lsreipl - List IPL and re-IPL settings	469
lsshut - List the current system shutdown actions	470
lstape - List tape devices	471
lszcrypt - Display zcrypt devices	474
lszfcf - List zfcf devices.	476
mon_fsstatd - Monitor z/VM guest file system size	478
mon_procd - Monitor Linux on z/VM	483
qetharp - Query and purge OSA and HiperSockets ARP data.	490
qethconf - Configure qeth devices	492
scsi_logging_level - Set and get the SCSI logging level	495
tape390_crypt - manage tape encryption	498
tape390_display - display messages on tape devices and load tapes	502
tunedasd - Adjust DASD performance	504
vmcp - Send CP commands to the z/VM hypervisor	507
vmur - Work with z/VM spool file queues	509
znetconf - List and configure network devices	516

Chapter 45. Selected kernel parameters	519
cio_ignore - List devices to be ignored	520
cmma - Reduce hypervisor paging I/O overhead	524
maxcpus - Restrict the number of CPUs Linux can use at IPL	525
mem - Restrict memory usage.	526
possible_cpus - Limit the number of CPUs Linux can use	527
ramdisk_size - Specify the ramdisk size	528
ro - Mount the root file system read-only	529
root - Specify the root device	530
user_mode - Set address mode for user space processes.	531
vdso - Optimize system call performance	532
vmhalt - Specify CP command to run after a system halt	533
vmpanic - Specify CP command to run after a kernel panic.	534
vmpoff - Specify CP command to run after a power off.	535
vmreboot - Specify CP command to run on reboot	536

Chapter 46. Linux diagnose code use	537
--	------------

Chapter 44. Commands for Linux on System z

This chapter describes commands to configure and work with the Red Hat Enterprise Linux 6.3 for System z device drivers and features.

Some commands come with an init script or a configuration file or both. Init scripts are installed in `/etc/init.d/` and configuration files are installed in `/etc/sysconfig/`. You can extract any missing files from the `etc` subdirectory in the `s390utils` RPM.

Commands described elsewhere:

- For the **zipl** command, see Chapter 35, “Initial program loader for System z - zipl,” on page 321.
- For commands and tools related to creating and analyzing system dumps, see *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607.
- For commands related to terminal access over IUCV connections, see *How to Set up a Terminal Server Environment on z/VM*, SC34-2596.

Generic command options

The following options are supported by all commands described in this section and, for simplicity, have been omitted from some of the syntax diagrams:


-h or **--help**

to display help information for the command.

--version

to display version information for the command.

The syntax for these options is:



where `command` can be any of the commands described in this section.


See “Understanding syntax diagrams” on page xii for general information about reading syntax diagrams.

chccwdev - Set a CCW device online

This command is used to set CCW devices (See “Device categories” on page 7) online or offline.

Before making any changes, **chccwdev** uses `cio_settle` to ensure that `sysfs` reflects the latest device status information and includes newly available devices.

Format



Where:

-e or --online
sets the device online.

-d or **--offline**
sets the device offline.

-f or **--forceonline**
forces a boxed device online, if this is supported by the device driver.

-a or **--attribute** *<name>=<value>*
sets the attribute specified in *<name>* to the given *<value>*.

Setting the “online” attribute has the same effect as using the **-e** or **-d** options.

`<device_bus_id>`
identifies the device to be set online or offline. `<device_bus_id>` is a device number with a leading "0.n.", where n is the subchannel set ID. Input will be converted to lowercase.

`<from_device_bus_id>-<to_device_bus_id>`
identifies a range of devices. Note that if not all devices in the given range exist, the command will be limited to the existing ones. If you specify a range with no existing devices, you will get an error message.

-h or **--help**
displays help information for the command. To view the man page, enter **man chccwdev**.

-v or --version
displays version information for the command.

Examples

- To set a CCW device 0.0.b100 online issue:

```
# chccwdev -e 0.0.b100
```

- Alternatively, using **-a** to set a CCW device 0.0.b100 online, issue:

```
# chccwdev -a online=1 0.0.b100
```

- To set all CCW devices in the range 0.0.b200 through 0.0.b2ff online issue:

```
# chccwdev -e 0.0.b200-0.0.b2ff
```

- To set a CCW device 0.0.b100 and all CCW devices in the range 0.0.b200 through 0.0.b2ff offline issue:

```
# chccwdev -d 0.0.b100,0.0.b200-0.0.b2ff
```

- To set several CCW devices in different ranges and different subchannel sets offline, issue:

```
# chccwdev -a online=0 0.0.1000-0.0.1100,0.1.7000-0.1.7010,0.0.1234,0.1.4321
```


chchp - Change channel path status

Use this command to set channel paths online or offline. The actions are equivalent to performing a Configure Channel Path Off or Configure Channel Path On operation on the hardware management console.

The channel path status that results from a configure operation is persistent across IPLs.

Note: Changing the configuration state of an I/O channel path might affect the availability of I/O devices as well as trigger associated functions (such as channel-path verification or device scanning) which in turn can result in a temporary increase in processor, memory, and I/O load.

Format



Where:

-c or **--configure** *<value>*
sets the device to configured (1) or standby (0).

Note: Setting the configured state to standby can stop running I/O operations.

-v or **--vary** *<value>*
changes the logical channel-path state to online (1) or offline (0).

Note: Setting the logical state to offline can stop running I/O operations.

-a or **--attribute** *<key>* = *<value>*
changes the channel-path sysfs attribute *<key>* to *<value>*. The *<key>* can be the name of any available channel-path sysfs attribute (that is, "configure" or "status"), while *<value>* can take any valid value that can be written to the attribute (for example, "0" or "offline"). This is a more generic way of modifying the state of a channel-path through the sysfs interface. It is intended for cases where sysfs attributes or attribute values are available in the kernel but not in **chchp**.

0.<id> and **0.<id> - 0.<id>**
where *<id>* is a hexadecimal, two-digit, lower-case identifier for the channel path. An operation can be performed on more than one channel path by specifying multiple identifiers as a comma-separated list, or a range, or a combination of both.

--version
displays the version number of **chchp** and exits.

-h or **--help**

displays a short help text, then exits.

Examples

- To set channel path 0.19 into standby state issue:

```
# chchp -a configure=0 0.19
```

- To set the channel path with the channel path ID 0.40 to the standby state, write "0" to the configure file using the **chchp** command:

```
# chchp --configure 0 0.40  
Configure standby 0.40... done.
```

- To set a channel-path to the configured state, write "1" to the configure file using the **chchp** command:

```
# chchp --configure 1 0.40  
Configure online 0.40... done.
```

- To set channel-paths 0.65 to 0.6f to the configured state issue:

```
# chchp -c 1 0.65-0.6f
```

- To set channel-paths 0.12, 0.7f and 0.17 to 0.20 to the logical offline state issue:

```
# chchp -v 0 0.12,0.7f,0.17-0.20
```

chmem - Set memory online or offline

The **chmem** command sets a particular size or range of memory online or offline.

Setting memory online can fail if the hypervisor does not have enough memory left, for example because memory was overcommitted. Setting memory offline can fail if Linux cannot free the memory. If only part of the requested memory can be set online or offline, a message tells you how much memory was set online or offline instead of the requested amount.

Format

chmem syntax

```

>> chmem [-e] [-d] <size> [<start>--<end>]

```

Where:

-e or **--enable**

sets the specified memory online.

-d or **--disable**

sets the specified memory offline.

<size>

specifies an amount of memory to be set online or offline. A numeric value without a unit or a numeric value immediately followed by **m** or **M** is interpreted as MB (1024 x 1024 bytes). A numeric value immediately followed by **g** or **G** is interpreted as GB (1024 x 1024 x 1024 bytes).

The size must be aligned to the memory block size, as shown in the output of the **lsmem** command.

<start>--<end>

specifies a memory range to be set online or offline. **<start>** is the hexadecimal address of the first byte and **<end>** is the hexadecimal address of the last byte in the memory range.

The range must be aligned to the memory block size, as shown in the output of the **lsmem** command.

-v or **--version**

displays the version number of **chmem**, then exits.

-h or **--help**

displays a short help text, then exits. To view the man page, enter **man chmem**.

Examples

- This command requests 1024 MB of memory to be set online.

```
# chmem --enable 1024
```

- This command requests 2 GB of memory to be set online.


```
# chmem --enable 2g
```

- This command requests the memory range starting with 0x00000000e4000000 and ending with 0x00000000f3ffffff to be set offline.


```
# chmem --disable 0x00000000e4000000-0x00000000f3ffffff
```

chreipl - Modify the re-IPL configuration

Use the **chreipl** tool to modify the re-IPL configuration for Linux on System z. You can configure a particular device as the reboot device. For **zipl** boot menu configurations, you can set the boot menu entry to be used for the next reboot. You can also specify additional kernel parameters for the next reboot.

Format

chreipl syntax



Notes:

- 1 You can specify the **<device_bus_id>**, **<wwpn>**, and **<lun>** in any order if you use the corresponding command options.
- 2 **-L** can be used if the device node or directory maps to a DASD; **-b** can be used if the device node or directory maps to a SCSI disk.

Where:

<device_bus_id> or **-d <device_bus_id>** or **--device <device_bus_id>**
 specifies the device bus-ID of a CCW re-IPL device or of the FCP device through which a SCSI re-IPL device is attached.

<wwpn> or **-w <wwpn>** or **--wwpn <wwpn>**
 specifies the world wide port name (WWPN) of a SCSI re-IPL device.

<lun> or **-l <lun>** or **--lun <lun>**
 specifies the logical unit number (LUN) of a SCSI re-IPL device.

<node>
 specifies a device node of a DASD, SCSI, or logical device mapper re-IPL device. See "Preparing a logical device as a boot device" on page 327 for more information about logical boot devices.

<dir>
 specifies a directory in the Linux file system on the re-IPL device.

nss

declares that the following parameters refer to a z/VM named saved system (NSS).

<name> or **-n <name>** or **--name <name>**

specifies the name of an NSS as defined on the z/VM system.

-L or **--loadparm <parameter>**

specifies the entry in the boot menu to be used for the next reboot. This parameter applies only if the re-IPL device is a DASD with a **zipl** boot menu configuration.

Omitting this parameter eliminates an existing selection in the boot configuration. Depending on your boot menu configuration, a **zipl** interactive boot menu might be displayed during the re-IPL process or the default configuration is used. See “Example for a DASD menu configuration on z/VM” on page 351, “Example for a DASD menu configuration (LPAR)” on page 358, and “Menu configurations” on page 342 for details.

-b or **--bootprog <n>**

specifies the entry in the boot menu to be used for the next reboot. This parameter applies only if the re-IPL device is a SCSI disk with a **zipl** boot menu configuration.

Omitting this parameter eliminates an existing selection in the boot configuration and the default boot configuration is used.

-p or **--bootparms**

specifies boot parameters for the next reboot. The boot parameters, which typically are kernel parameters, are appended to the kernel parameter line in the boot configuration. The number of characters you can specify depends on your environment and re-IPL device as shown in Table 53.

Table 53. Maximum characters for additional kernel parameters

Virtual hardware where Linux runs	DASD re-IPL device	SCSI re-IPL device	NSS re-IPL device
z/VM guest virtual machine	64	3452	56
LPAR	none	3452	n/a

If you omit this parameter, the existing boot parameters in the next boot configuration are used without any changes.

-h or **--help**

displays help information for the command. To view the man page, enter **man chreipl**.

-v or **--version**

displays version information.

For disk-type re-IPL devices, the command accepts but does not require an initial statement:

ccw

declares that the following parameters refer to a DASD re-IPL device.

fcp

declares that the following parameters refer to a SCSI re-IPL device.

node

declares that the following parameters refer to a disk re-IPL device that is

identified by a device node or by a directory in the Linux file system on that device. The disk device can be a DASD or a SCSI disk.

Examples

This section illustrates common uses for **chreipl**.

- The following commands all configure the same DASD as the re-IPL device, assuming that the device bus-ID of the DASD is 0.0.7e78, that the standard device node is /dev/dasdc, that udev has created an alternative device node /dev/disk/by-path/ccw-0.0.7e78, that /mnt/boot is located on the Linux file system in a partition of the DASD.
 - Using the bus ID:


```
# chreipl 0.0.7e78
```
 - Using the bus ID and the optional ccw statement:


```
# chreipl ccw 0.0.7e78
```
 - Using the bus ID, the optional statement and the optional **--device** keyword:


```
# chreipl ccw --device 0.0.7e78
```
 - Using the standard device node:


```
# chreipl /dev/dasdc
```
 - Using the udev-created device node:


```
# chreipl /dev/disk/by-path/ccw-0.0.7e78
```
 - Using a directory within the file system on the DASD:


```
# chreipl /mnt/boot
```
- The following commands all configure the same SCSI disk as the re-IPL device, assuming that the device bus-ID of the FCP device through which the device is attached is 0.0.1700, the WWPN of the storage server is 0x500507630300c562, and the LUN is 0x401040b300000000. Further it is assumed that the standard device node is /dev/sdb, that udev has created an alternative device node /dev/disk/by-id/scsi-36005076303fffc56200000000000010b4, and that /mnt/fcpboot is located on the Linux file system in a partition of the SCSI disk.
 - Using bus ID, WWPN, and LUN:


```
# chreipl 0.0.1700 0x500507630300c562 0x401040b300000000
```
 - Using bus ID, WWPN, and LUN with the optional fcp statement:


```
# chreipl fcp 0.0.1700 0x500507630300c562 0x401040b300000000
```
 - Using bus ID, WWPN, LUN, the optional statement, and keywords for the parameters. Note that when using the keywords the parameters can be specified in any order:


```
# chreipl fcp --wwpn 0x500507630300c562 -d 0.0.1700 --lun 0x401040b300000000
```
 - Using the standard device node:

```
# chreipl /dev/sdb
```

- Using the udev-created device node:

```
# chreipl /dev/disk/by-id/scsi-36005076303ffc56200000000000010b4
```

- Using a directory within the file system on the SCSI disk:

```
# chreipl /mnt/fcpboot
```

- To configure a DASD with bus ID 0.0.7e78 as the re-IPL device, using the first entry of the **zipl** boot menu:

```
# chreipl 0.0.7e78 -L 1
Re-IPL type: ccw
Device:      0.0.7e78
Loadparm:    "1"
Bootparms:   ""
```

- To configure a DASD with bus ID 0.0.7e78 as the re-IPL device and adding mem=512M to the existing kernel parameters in the boot configuration:

```
# chreipl 0.0.7e78 -p "mem=512M"
Re-IPL type: ccw
Device:      0.0.7e78
Loadparm:    ""
Bootparms:   "mem=512M"
```

- To configure an NSS LINUX1 as the re-IPL device:

```
# chreipl nss LINUX1
```

chshut - Control the system shutdown actions


Use the **chshut** command to change the shutdown actions for the following shutdown triggers:

- halt
- poff
- reboot

The shutdown triggers restart and panic are handled by the dumpconf service script, see *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607 for details.

Linux on System z performs shutdown actions according to sysfs attribute settings within the /sys/firmware directory structure. The **chshut** command sets a shutdown action for a shutdown trigger by changing the corresponding sysfs attribute setting. See Chapter 38, “Shutdown actions,” on page 371 for more information about the sysfs attributes and the shutdown actions.

Format



Where:

halt

sets an action for the halt shutdown trigger.

In Red Hat Enterprise Linux 6.3, by default, halt is mapped to poff. You can undo this mapping by editing the file /etc/sysconfig/shutdown and replacing HALT="auto" with HALT="halt".

poff

sets an action for the poff shutdown trigger.

reboot

sets an action for the reboot shutdown trigger.

ipl

sets IPL as the action to be taken.

reipl

sets re-IPL as the action to be taken.

stop

sets "stop" as the action to be taken.

vmcmd "<cp_command>"

sets the action to be taken to issuing a z/VM CP command. The command

must be specified in uppercase characters and enclosed in quotation marks. To issue multiple commands, repeat the `vmcmd` attribute with each command.

-h or --help

displays help information for the command. To view the man page, enter **man chshut**.

-v or --version

displays version information.

Examples

This section illustrates common uses for **chshut**.

- To make the system start again after a power off:

```
# chshut poff ip1
```

- To log off the z/VM guest virtual machine if the Linux **poweroff** command was run successfully:

```
# chshut poff vmcmd LOGOFF
```


- To send a message to z/VM user ID OPERATOR and automatically log off the z/VM guest virtual machine if the Linux **poweroff** command is run:

```
# chshut poff vmcmd "MSG OPERATOR Going down" vmcmd "LOGOFF"
```

chzcrypt - Modify the zcrypt configuration

Use the **chzcrypt** command to configure cryptographic adapters managed by zcrypt and modify zcrypt's AP bus attributes. To display the attributes, use “lszcrypt - Display zcrypt devices” on page 474.

Format



Where:

- e** or **--enable**
sets the given cryptographic adapters online.
- d** or **--disable**
sets the given cryptographic adapters offline.
- a** or **--all**
sets all available cryptographic adapters online or offline.
- <device ID>**
specifies a cryptographic adapter which will be set online or offline. A cryptographic adapter can be specified either in decimal notation or hexadecimal notation using a '0x' prefix.
- p** or **--poll-thread-enable**
enables zcrypt's poll thread.
- n** or **--poll-thread-disable**
disables zcrypt's poll thread.
- c <timeout>** or **--config-time <timeout>**
sets configuration timer for re-scanning the AP bus to <timeout> seconds.
- t <time>** or **--poll-timeout=<time>**
sets the high resolution polling timer to <time> nanoseconds. To display the value, use **lszcrypt -b**.
- V** or **--verbose**
displays verbose messages.
- h** or **--help**
displays short information about command usage.
- v** or **--version**
displays version information.

Examples

This section illustrates common uses for **chzcrypt**.

- To set the cryptographic adapters 0, 1, 4, 5, and 12 online (in decimal notation):

```
chzcrypt -e 0 1 4 5 12
```

- To set all available cryptographic adapters offline:

```
chzcrypt -d -a
```

- To set the configuration timer for re-scanning the AP bus to 60 seconds and disable zcrypt's poll thread:

```
chzcrypt -c 60 -n
```

cmsfs-fuse - Mount a z/VM CMS file system

Use the **cmsfs-fuse** command to mount the enhanced disk format (EDF) file system on a z/VM minidisk. In Linux, the minidisk is represented as a DASD and the file system is mounted as a **cmsfs-fuse** file system. The **cmsfs-fuse** file system translates the record-based file system on the minidisk into Linux semantics.

Through the **cmsfs-fuse** file system, the files on the minidisk become available to applications on Linux. Applications can read from and write to files on minidisks. Optionally, the **cmsfs-fuse** file system converts text files between EBCDIC on the minidisk and ASCII within Linux.

Attention: You can inadvertently damage files and lose data when directly writing to files within the **cmsfs-fuse** file system. To avoid problems when writing, multiple restrictions must be observed, especially with regard to linefeeds (see “restrictions for write” on page 413).


Tip: If you are unsure about how to safely write to a file on the **cmsfs-fuse** file system, copy the file to a location outside the **cmsfs-fuse** file system, edit the file, and then copy it back to its original location.

Use **fusermount** to unmount file systems that you have mounted with **cmsfs-fuse**. See the **fusermount** man page for details.

Before you begin:

- The fuse module must have been loaded, for example, with **modprobe fuse**.
- The FUSE library must have been installed on your system. Install the **fuse-libs** RPM delivered with Red Hat Enterprise Linux 6.3.
- The DASD must be online.
- Depending whether you intend to read, write, or both, you must have the appropriate permissions for the device node.
- Mounting a z/VM CMS file system requires sufficient virtual memory.
 - You can use the **ulimit** command to query and change your virtual memory settings. Consider setting the amount of virtual memory to “unlimited”. See the **ulimit** man page for details.
 - If the command fails because Linux does not have enough free memory, you might still be able to mount the disk after setting `/proc/sys/vm/overcommit_memory` to 1.

Format



Where:

-a or --ascii

treats all files on the minidisk as text files and converts them from EBCDIC to ASCII.

-t or --filetype

treats files with extensions as listed in the **cmsfs-fuse** configuration file as text files and converts them from EBCDIC to ASCII.

The **cmsfs-fuse** command uses `~/.cmsfs-fuse/filetypes.conf` as the configuration file. If this file within the user's home directory does not exist, the default configuration file `/etc/cmsfs-fuse/filetypes.conf` is used.

The `filetypes.conf` file lists one file type per line. Lines that start with a number sign (#) followed by a space are treated as comments and are ignored.

--from <code-page>

specifies the encoding of the files on the z/VM minidisk. If this option is not specified, code page CP1047 is used. Enter **iconv --list** to display a list of all available code pages.

--to <code-page>

specifies the encoding to which the files on the z/VM minidisk are converted in Linux. If this option is not specified, code page ISO-8859-1 is used. Enter **iconv --list** to display a list of all available code pages.

<mount-options>

options as available for the **mount** command. See the **mount** man page for details.

<fuse-options>

options for FUSE. The following options are supported by the **cmsfs-fuse** command. To use an option, it must also be supported by the version of FUSE that you have installed.

-d or -o debug

enables debug output (implies -f).

-f

runs the command as a foreground operation.

-o allow_other

allows access to other users.

-o allow_root

allows access to root.

-o nonempty

allows mounts over files and non-empty directories.

-o default_permissions

enables permission checking by the kernel.

-o max_read=<n>

sets maximum size of read requests.

-o kernel_cache

caches files in the kernel.

-o [no]auto_cache

enables or disables caching based on modification times.

-o umask=<mask>

sets file permissions (octal).

- o uid=<n>**
sets the file owner.
- o gid=<n>**
sets the file group.
- o max_write=<n>**
sets the maximum size of write requests.
- o max_readahead=<n>**
sets the maximum readahead value.
- o async_read**
performs reads asynchronously (default).
- o sync_read**
performs reads synchronously.
- o big_writes**
enables write operations with more than 4 KB.

<node>

the device node for the DASD that represents the minidisk in Linux.

<mount-point>

the mount point in the Linux file system where you want to mount the CMS file system.

-h or --help

displays help information for the command. To view the man page, enter **man cmsfs-fuse**.

-v or --version

displays version information for the command.

You can use the following extended attributes to handle the CMS characteristics of a file:

user.record_format

specifies the format of the file. The format is F for fixed record length files and V for variable record length files. This attribute can be set only for empty files. The default file format for new files is V.

user.record_lrecl

specifies the record length of the file. This attribute can be set only for an empty fixed record length file. A valid record length is an integer in the range 1-65535.

user.file_mode

specifies the CMS file mode of the file. The file mode consists of a mode letter from A-Z and mode number from 0-6. The default file mode for new files is A1.

You can use the following system calls to work with extended attributes:

listxattr

to list the current values of all extended attributes.

getxattr

to read the current value of a particular extended attribute.

setxattr

to set a particular extended attribute.

You can use these system calls through the **getfattr** and **setfattr** commands. For more details see the man pages of these commands and of the **listxattr**, **getxattr**, and **setxattr** system calls.

Restrictions

When working with files in the cmsfs-fuse file system, restrictions apply for the following system calls:

write Be aware of the following restrictions when writing to a file on the cmsfs-fuse file system:

Write location

Writing is supported only at the end of a file.

Padding

For fixed length record files, the last record is padded to make up a full record length. The padding character is zero in binary mode and the space character in ASCII mode.

Sparse files

Sparse files are not supported. To prevent the cp tool from writing in sparse mode specify **-sparse=never**.

Records and linefeeds with ASCII conversion (-a and -t)

In the ASCII representation of an EBCDIC file, a linefeed character determines the end of a record. Follow these rules about linefeed characters requirements when writing to EBCDIC files in ASCII mode:

For fixed record length files

Use linefeed characters to separate character strings of the fixed record length.

For variable record length files

Use linefeed characters to separate character strings. The character strings must not exceed the maximum record length.

The CMS file system does not support empty records. cmsfs-fuse adds a space to records that consist of a linefeed character only.

rename and creat

Uppercase file names are enforced.

truncate

Only shrinking of a file is supported. For fixed length record files, the new file size must be a multiple of the record length.

Examples

- To mount the CMS file system on the minidisk represented by the file node **/dev/dasde** at **/mnt**:

```
# cmsfs-fuse /dev/dasde /mnt
```

- To mount the CMS file system on the minidisk represented by the file node **/dev/dasde** at **/mnt** and enable EBCDIC to ASCII conversion for text files with extensions as specified in **~/.cmsfs-fuse/filetypes.conf** or **/etc/cmsfs-fuse/filetypes.conf** if the former does not exist:

```
# cmsfs-fuse -t /dev/dasde /mnt
```

- To mount the CMS file system on the minidisk represented by the file node /dev/dasde at /mnt and allow root to access the mounted file system:

```
# cmsfs-fuse -o allow_root /dev/dasde /mnt
```

- To unmount the CMS file system that has been mounted at /mnt:

```
# fusermount -u /mnt
```

- To show the record format of a file, PROFILE.EXEC, on a z/VM minidisk that is mounted on /mnt:

```
# getfattr -n user.record_format /mnt/PROFILE.EXEC  
F
```

- To set record length 80 for an empty fixed record format file, PROFILE.EXEC, on a z/VM minidisk that is mounted on /mnt:

```
# setfattr -n user.record_lrecl -v 80 /mnt/PROFILE.EXEC
```

cpuplugd - Control CPUs and memory

Use the **cpuplugd** command and a set of rules in a configuration file to dynamically:

- Enable or disable CPUs
- Linux on z/VM only: Add or remove memory.

Format

cpuplugd syntax

```

▶▶ cpuplugd [ -f ] [ -V ] -c <config file> ▶▶

```

Where:

-c or **--config** *<config file>*

specifies the path to the configuration file with the rules (see “Comments”).

After installing cpuplugd for the first time, you can find a sample configuration file at `/etc/sysconfig/cpuplugd`. If you are upgrading from a prior version of cpuplugd, see “Migrating old configuration files” on page 416.

-f or **--foreground**

runs in foreground.

-V or **--verbose**

displays verbose messages.

-h or **--help**

displays short information about command usage. displays help information for the command. To view the command man page, enter **man cpuplugd**. To view the man page for the configuration file, enter **man cpuplugd.conf**

-v or **--version**

displays version information.

Examples

- To start cpuplugd in daemon mode with a configuration file `/etc/sysconfig/cpuplugd`:

```
# cpuplugd -c /etc/sysconfig/cpuplugd
```

- To run cpuplugd in the foreground with verbose messages and with a configuration file `/etc/sysconfig/cpuplugd`:

```
# cpuplugd -V -f -c /etc/sysconfig/cpuplugd
```

Comments

The cpuplugd configuration file can specify rules for controlling the number of active CPUs and for controlling the amount of memory.

The configuration file contains:

- `<variable>=<value>` pairs
These pairs must be specified within one line. The maximum valid line length is 2048 characters. The values can be decimal numbers or algebraic or boolean expressions.
- Comments
Any part of a line that follows a number sign (#) is treated as a comment. There can be full comment lines with the number sign at the beginning of the line or comments can begin in mid-line.
- Empty lines

Attention: The configuration file samples in this section illustrate the syntax of the configuration file. Do not use the sample rules on production systems. Useful rules differ considerably, depending on the workload, resources, and requirements of the system for which they are designed.

Migrating old configuration files

With Red Hat Enterprise Linux 6.3, an enhanced version of cpuplugd has been introduced. This enhanced version includes extensions to the configuration file and a new sample configuration file, `/etc/sysconfig/cpuplugd`.

If a configuration file from a prior version of cpuplugd already exists at `/etc/sysconfig/cpuplugd`, this file is not replaced but complemented with new variables. The new sample configuration file is then copied to `/var/adm/fillup-templates/sysconfig.cpuplugd`.

The new sample file contains comments that describe the enhanced file layout. View the file to see this information. Consider merging the existing configuration file with a copy of the new sample file to obtain a configuration file with the existing rules, the new variables, and the new descriptions.

Basic configuration file for CPU control

The configuration file sample of Figure 70 has been simplified to contain only the required specifications for dynamically enabling or disabling CPUs.

```
UPDATE="10"
CPU_MIN="2"
CPU_MAX="10"

HOTPLUG = "idle < 10.0"
HOTUNPLUG = "idle > 100"
```

Figure 70. Simplified configuration file with CPU hotplug rules

In the configuration file:

UPDATE

specifies the time interval, in seconds, at which cpuplugd evaluates the rules and, if a rule is met, enables or disables CPUs. This variable is also required for controlling memory (see “Basic configuration file for memory control” on page 417).

In the example, the rules are evaluated every 10 seconds.

CPU_MIN

specifies the minimum number of CPUs. Even if the rule for disabling CPUs is met, cpuplugd does not reduce the number of CPUs to less than this number.

In the example, the number of CPUs cannot become less than 2.

CPU_MAX

specifies the maximum number of CPUs. Even if the rule for enabling CPUs is met, cpuplugd does not increase the number of CPUs to more than this number. If 0 is specified, the maximum number of CPUs is the number of CPUs available on the system.

In the example, the number of CPUs cannot become more than 10.

HOTPLUG

specifies the rule for dynamically enabling CPUs. The rule resolves to a boolean true or false. Each time this rule is true, cpuplugd enables one CPU, unless the number of CPUs has already reached the maximum specified with CPU_MAX.

Setting HOTPLUG to 0 disables dynamically adding CPUs.

In the example, a CPU is enabled when the idle times of all active CPUs sum up to less than 10.0%. See “Keywords for CPU hotplug rules” on page 419 for information about available keywords.

HOTUNPLUG

specifies the rule for dynamically disabling CPUs. The rule resolves to a boolean true or false. Each time this rule is true, cpuplugd disables one CPU, unless the number of CPUs has already reached the minimum specified with CPU_MIN.

Setting HOTUNPLUG to 0 disables dynamically removing CPUs.

In the example, a CPU is disabled when the idle times of all active CPUs sum up to more than 100%. See “Keywords for CPU hotplug rules” on page 419 for information about available keywords.

If one of these variables is set more than once, only the last occurrence is used. These variables are not case sensitive.

If both the HOTPLUG and HOTUNPLUG rule are met simultaneously, HOTUNPLUG is ignored.

Basic configuration file for memory control

This section applies to Linux on z/VM only.

The configuration file sample of Figure 71 has been simplified to contain only the required specifications for dynamically adding or taking away memory.

```
UPDATE="10"
CMM_MIN="0"
CMM_MAX="131072" # 512 MB
CMM_INC="10240" # 40 MB

MEMPLUG = "swaprate > 250"
MEMUNPLUG = "swaprate < 10"
```

Figure 71. Simplified configuration file with memory hotplug rules

In the configuration file:

UPDATE

specifies the time interval, in seconds, at which cpuplugd evaluates the rules

and, if a rule is met, adds or removes memory. This variable is also required for controlling CPUs (see “Basic configuration file for CPU control” on page 416).

In the example, the rules are evaluated every 10 seconds.

CMM_MIN

specifies the minimum amount of memory, in 4 KB pages, that Linux surrenders to the CMM static page pool (see “Cooperative memory management background” on page 195). Even if the MEMPLUG rule for taking memory from the CMM static page pool and adding it to Linux is met, cpuplugd does not decrease this amount.

In the example, the amount of memory that is surrendered to the static page pool can be reduced to 0.

CMM_MAX

specifies the maximum amount of memory, in 4 KB pages, that Linux surrenders to the CMM static page pool (see “Cooperative memory management background” on page 195). Even if the MEMUNPLUG rule for removing memory from Linux and adding it to the CMM static page pool is met, cpuplugd does not increase this amount.

In the example, the amount of memory that is surrendered to the static page pool cannot become more than 131072 pages of 4 KB (512 MB).

CMM_INC

specifies the amount of memory, in 4 KB pages, that is removed from Linux when the MEMUNPLUG rule is met. Removing memory from Linux increases the amount that is surrendered to the CMM static page pool.

In the example, the amount of memory that is removed from Linux is 10240 pages of 4 KB (40 MB) at a time.

CMM_DEC

Optional: specifies the amount of memory, in 4 KB pages, that is added to Linux when the MEMPLUG rule is met. Adding memory to Linux decreases the amount that is surrendered to the CMM static page pool.

If this variable is omitted, the amount of memory specified for CMM_INC is used.

In the example, CMM_DEC is omitted and the amount of memory added to Linux is 10240 pages of 4 KB (40 MB) at a time, as specified with CMM_INC.

MEMPLUG

specifies the rule for dynamically adding memory to Linux. The rule resolves to a boolean true or false. Each time this rule is true, cpuplugd adds the number of pages specified by CMM_DEC, unless the CMM static page pool has already reached the minimum specified with CMM_MIN.

Setting MEMPLUG to 0 disables dynamically adding memory to Linux.

In the example, memory is added to Linux if there are more than 250 swap operations per second. See “Keywords for memory hotplug rules” on page 420 for information about available keywords.

MEMUNPLUG

specifies the rule for dynamically removing memory from Linux. The rule resolves to a boolean true or false. Each time this rule is true, cpuplugd removes the number of pages specified by CMM_INC, unless the CMM static page pool has already reached maximum specified with CMM_MAX.

Setting MEMUNPLUG to 0 disables dynamically removing memory from Linux.

In the example, memory is removed from Linux when there are less than 10 swap operations per second. See “Keywords for memory hotplug rules” on page 420 for information about available keywords.

If any of these variables are set more than once, only the last occurrence is used. These variables are not case sensitive.

If both the MEMPLUG and MEMUNPLUG rule are met simultaneously, MEMUNPLUG is ignored.

CMM_DEC and CMM_INC can be set to a decimal number or to a mathematical expression that uses the same algebraic operators and variables as the MEMPLUG and MEMUNPLUG hotplug rules (see “Keywords for memory hotplug rules” on page 420 and “Writing more complex rules” on page 421).

Predefined keywords

There is a set of predefined keywords that you can use for CPU hotplug rules and a set of keywords that you can use for memory hotplug rules. All predefined keywords are case sensitive.

Keywords for CPU hotplug rules: You can use the following keywords in the CPU hotplug rules, HOTPLUG and HOTUNPLUG:

loadavg	is the current load average.
onumcpus	is the current number of online CPUs.
runnable_proc	is the current number of runnable processes.
user	is the current CPU user percentage.
nice	is the current CPU nice percentage.
system	is the current CPU system percentage.
idle	is the current CPU idle percentage.
iowait	is the current CPU iowait percentage.
irq	is the current CPU irq percentage.
softirq	is the current CPU softirq percentage.
steal	is the current CPU steal percentage.
guest	is the current CPU guest percentage.
guest_nice	is the current CPU guest_nice percentage.
cpustat.<name>	is data from /proc/stat and /proc/loadavg. In the keyword, <name> can be any of the previously listed keywords, for example, cpustat.idle. See the proc man page for more details about the data represented by these keywords.

With this notation, the keywords resolve to raw timer ticks since system start, not to current percentages. For example, `idle` resolves to the current idle percentage and `cpustat.idle` resolves to the total timer ticks spent idle. See “Using historical data” on page 420 about how to obtain average and percentage values.

loadavg, onumcpus, and runnable_proc are not percentages and resolve to the same values as cpustat.loadavg, cpustat.onumcpus, and cpustat.runnable_proc.

cpustat.total_ticks

is the total number of timer ticks since system start.

time

is the UNIX epoch time in the format “seconds.microseconds”.

Percentage values are accumulated for all online CPUs. Hence, the values for the percentages range from 0 to 100 × (number of online CPUs). To get the average percentage per CPU device, divide the accumulated value by the number of CPUs. For example, `idle / onumcpus` yields the average idle percentage per CPU.

Keywords for memory hotplug rules: You can use the following keywords in the memory hotplug rules, MEMPLUG and MEMUNPLUG:

apcr is the amount of page cache operations, `pgpin + pgpout`, from `/proc/vmstat` in 512 byte blocks per second.

freemem

is the amount of free memory in MB.

swaprate

is the number of swap operations, `pswpin + pswpout`, from `/proc/vmstat` in 4 KB pages per second.

meminfo.<name>

is the value for the symbol `<name>` as shown in the output of `cat /proc/meminfo`. The values are plain numbers but refer to the same units as those used in `/proc/meminfo`.

vmstat.<name>

is the value for the symbol `<name>` as shown in the output of `cat /proc/vmstat`.

Using historical data: Historical data is available for the keyword `time` and the sets of keywords `cpustat.<name>`, `meminfo.<name>`, and `vmstat.<name>` of “Keywords for CPU hotplug rules” on page 419 and “Keywords for memory hotplug rules.”

Use the suffixes [`<n>`] to retrieve the data of `<n>` intervals in the past, where `<n>` can range from 0 to 100.

Examples:

cpustat.idle

yields the current value for the counted idle ticks.

cpustat.idle[1]

yields the idle ticks as counted one interval ago.

cpustat.idle[5]

yields the idle ticks as counted 5 intervals ago.

cpustat.idle - cpustat.idle[5]

yields the idle ticks during the past 5 intervals.

time - time[1]

yields the length of an update interval in seconds.

cpustat.total_ticks - cpustat.total_ticks[5]

yields the total number of ticks during the past 5 intervals.

`(cpustat.idle - cpustat.idle[5]) / (cpustat.total_ticks - cpustat.total_ticks[5])`
yields the average ratio of idle ticks to total ticks during the past 5 intervals.

Multiplying this ratio with 100 yields the percentage of idle ticks during the last 5 intervals.

Multiplying this ratio with `100 * onumcpus` yields the accumulated percentage of idle ticks for all processors during the last 5 intervals.

Writing more complex rules

To specify rules you can use:

- The keywords of “Predefined keywords” on page 419
- Decimal numbers
- The mathematical operators
 - + addition
 - subtraction
 - * multiplication
 - / division
 - < less than
 - > greater than
- Parentheses (and) to group mathematical expressions
- The Boolean operators
 - & and
 - | or
 - ! not
- User-defined variables

You can specify complex calculations as user-defined variables, which can then be used in expressions. User-defined variables are case sensitive and must not match a pre-defined variable or keyword. In the configuration file, definitions for user-defined variables must precede their use in expressions.

Variable names consist of alphanumeric characters and the underscore (`_`) character. An individual variable name must not exceed 128 characters. All user-defined variable names and values, in total, must not exceed 4096 characters.

Examples

- `HOTPLUG = "loadavg > onumcpus + 0.75"`
- `HOTPLUG = "(loadavg > onumcpus + 0.75) & (idle < 10.0)"`
- ```
my_idle_rate = "(cpustat.idle - cpustat.idle[5]) / (cpustat.total_ticks - cpustat.total_ticks[5])"
my_idle_percent_total = "my_idle_rate * 100 * onumcpus"
...
HOTPLUG = "(loadavg > onumcpus + 0.75) & (my_idle_percent_total < 10.0)"
```

## Sample configuration file

The example in Figure 72 on page 422 includes multiple user-defined variables and values from `procs` to calculate the page scan rate and the cache size.

```
Required static variables
UPDATE="5"
CPU_MIN="2"
CPU_MAX="5"
CMM_MIN="0"
CMM_MAX="131072" # 512 MB

User-defined variables
pgscan_k="vmstat.pgscan_kswapd_dma + vmstat.pgscan_kswapd_normal + vmstat.pgscan_kswapd_movable"
pgscan_d="vmstat.pgscan_direct_dma + vmstat.pgscan_direct_normal + vmstat.pgscan_direct_movable"
pgscan_k1="vmstat.pgscan_kswapd_dma[1] + vmstat.pgscan_kswapd_normal[1] + vmstat.pgscan_kswapd_movable[1]"
pgscan_d1="vmstat.pgscan_direct_dma[1] + vmstat.pgscan_direct_normal[1] + vmstat.pgscan_direct_movable[1]"
pgscanrate="(pgscan_k + pgscan_d - pgscan_k1 - pgscan_d1) / (time - time[1])"
cache="meminfo.Cached + meminfo Buffers"

More required variables
CMM_INC: 10% of free memory + cache, in 4K pages
CMM_INC="(meminfo.MemFree + cache) / 40"
CMM_DEC: 10% of total memory in 4K pages
CMM_DEC="meminfo.MemTotal / 40"

Hotplug rules
HOTPLUG = "(loadavg > onumcpus + 0.75) & (idle < 10.0)"
HOTUNPLUG = "(loadavg < onumcpus - 0.25) | (idle > 50)"
Plug memory if page scan rate is above 20 pages / sec
MEMPLUG = "pgscanrate > 20"
Unplug memory while free memory is above 10% of total memory, or cache uses
more than 50% of total memory
MEMUNPLUG = "(meminfo.MemFree > meminfo.MemTotal / 10) | (cache > meminfo.MemTotal / 2)"
```

---

*Figure 72. Sample configuration file for CPU and memory hotplug*

**Attention:** The configuration file samples in this section illustrate the syntax of the configuration file. Do not use the sample rules on production systems. Useful rules differ considerably, depending on the workload, resources, and requirements of the system for which they are designed.

## dasdfmt - Format a DASD

Use this tool to low-level format ECKD-type direct access storage devices (DASD).


**dasdfmt** uses an `ioctl` call to the DASD driver to format tracks. A blocksize (hard sector size) can be specified. Remember that the formatting process can take quite a long time (hours for large DASD). Use the `-p` option to monitor the progress.

### CAUTION:

As on any platform, formatting irreversibly destroys data on the target disk. Be sure not to format a disk with vital data unintentionally.

## Format

### dasdfmt syntax



### Notes:

- 1 If neither the `-l` option nor the `-k` option are specified, a VOLSER is generated from the device number through which the volume is accessed.

Where:

**-b <block\_size> or --blocksize=<block\_size>**  
specifies one of the following block sizes in bytes: 512, 1024, 2048, or 4096.

If you do not specify a value for the block size, you are prompted. You can then press Enter to accept 4096 or specify a different value.

**Tip:** Set `<block_size>` as large as possible (ideally 4096); the net capacity of an ECKD DASD decreases for smaller block sizes. For example, a DASD formatted with a block size of 512 byte has only half of the net capacity of the same DASD formatted with a block size of 4096 byte.

**<node>**

specifies the device node of the device to be formatted, for example, `/dev/dasdzzz`. See “DASD naming scheme” on page 33 for more details about device nodes).

**-d <disklayout> or --disk\_layout=<disklayout>**  
formats the device with the compatible disk layout (cdl) or the Linux disk layout (ldl). If the parameter is not specified the default (cdl) is used.

**-L or --no\_label**  
valid for `-d ldl` only, where it suppresses the default LNX1 label.

**-l <volser> or --label=<volser>**  
specifies the volume serial number (see “VOLSER” on page 30) to be written to

the disk. If the VOLSER contains special characters, it must be enclosed in single quotes. In addition, any '\$' character in the VOLSER must be preceded by a backslash ('\').

- k** or **--keep\_volsr**  
keeps the volume serial number when writing the volume label (see “VOLSER” on page 30). This is useful, for example, if the volume serial number has been written with a z/VM tool and should not be overwritten.
- p** or **--progressbar**  
displays a progress bar. Do not use this option if you are using a line-mode terminal console driver (for example, a 3215 terminal device driver or a line-mode hardware console device driver).
- P** or **--percentage**  
displays one line for each formatted cylinder showing the number of the cylinder and percentage of formatting process. Intended for use by higher level interfaces.
- m** *<hashstep>* or **--hashmarks=<hashstep>**  
displays a number sign (#) after every *<hashstep>* cylinders are formatted. *<hashstep>* must be in the range 1 to 1000. The default is 10.  
  
The -m option is useful where the console device driver is not suitable for the progress bar (-p option).
- y** starts formatting immediately without prompting for confirmation.
- F** or **--force**  
formats the device without checking if it is mounted.
- v** displays extra information messages.
- t** or **--test**  
runs the command in test mode. Analyzes parameters and displays what would happen, but does not modify the disk.
- norecordzero**  
prevents a format write of record zero. This is an expert option: Subsystems in DASD drivers are by default granted permission to modify or add a standard record zero to each track when needed. Before revoking the permission with this option, you must ensure that the device contains standard record zeros on all tracks.
- V** or **--version**  
displays the version number of **dasdfmt** and exits.
- h** or **--help**  
displays an overview of the syntax. Any other parameters are ignored.

## Examples

- To format a 100 cylinder z/VM minidisk with the standard Linux disk layout and a 4 KB blocksize with device node `/dev/dasdc`:



```
dasdfmt -b 4096 -d ldl -p /dev/dasdc
Drive Geometry: 100 Cylinders * 15 Heads = 1500 Tracks

I am going to format the device /dev/dasdc in the following way:
 Device number of device : 0x192
 Labelling device : yes
 Disk label : LNX1
 Disk identifier : 0X0192
 Extent start (trk no) : 0
 Extent end (trk no) : 1499
 Compatible Disk Layout : no
 Blocksize : 4096

--->> ATTENTION! <---
All data of that device will be lost.
Type "yes" to continue, no will leave the disk untouched: yes
Formatting the device. This may take a while (get yourself a coffee).

cyl 100 of 100 |#####| 100%

Finished formatting the device.
Rereading the partition table... ok
#
```

- To format the same disk with the compatible disk layout (using the default value of the -d option).

```
dasdfmt -b 4096 -p /dev/dasdc
Drive Geometry: 100 Cylinders * 15 Heads = 1500 Tracks

I am going to format the device /dev/dasdc in the following way:
 Device number of device : 0x192
 Labelling device : yes
 Disk label : VOL1
 Disk identifier : 0X0192
 Extent start (trk no) : 0
 Extent end (trk no) : 1499
 Compatible Disk Layout : yes
 Blocksize : 4096

--->> ATTENTION! <---
All data of that device will be lost.
Type "yes" to continue, no will leave the disk untouched: yes
Formatting the device. This may take a while (get yourself a coffee).

cyl 100 of 100 |#####| 100%

Finished formatting the device.
Rereading the partition table... ok
#
```

## dasdstat - Display DASD performance statistics


Use this command to display DASD performance statistics, including statistics about Parallel Access Volume (PAV) and High Performance Ficon. This command includes and extends the performance statistics that is also available through the **tunedasd** command.

### Before you begin:

- debugfs must have been mounted, see “debugfs” on page xi.

## Format

### dasdstat syntax



### Notes:

- 1 Omit the **-e**, **-d**, and **-r** options to read statistics.

Where:

- e** or **--enable**  
starts statistics data collection.
- d** or **--disable**  
stops statistics data collection.
- r** or **--reset**  
sets the statistics counters to zero.
- l** or **--long**  
displays more detailed statistics information, for example, differentiates between read and write requests.
- V** or **--verbose**  
displays more verbose command information.
- c <colnum>** or **--columns <colnum>**  
formats the command output in a table with the specified number of columns. The default is 16. Each row gets wrapped after the specified number of lines.
- w <width>** or **--column-width <width>**  
sets the minimum width, in characters, of a column in the output table.
- i <directory>** or **--directory <directory>**  
specifies the directory that contains the statistics. The default is

`<mountpoint>/dasd`, where `<mountpoint>` is the mount point of debugfs. You need to specify this parameter if the **dasdstat** command cannot determine this mount point or if the statistics have been copied to another location.

`<item>`

limits the command to the specified items. For `<item>` you can specify:

- `global` for summary statistics for all available DASDs.
- The block device name by which a DASD is known to the DASD device driver.
- The bus ID by which a DASD is known as a CCW device. DASDs that are set up for PAV or HyperPAV have a CCW base device and, at any one time, can have one or more CCW alias devices for the same block device. Alias devices are not permanently associated with the same block device. Statistics that are based on bus ID, therefore, show additional detail for PAV and HyperPAV setups.

If you do not specify any individual item, the command applies to all DASD block devices, CCW devices, and to the summary.

**-v or --version**

displays the version number of **dasdstat**, then exits.

**-h or --help**

displays help information for the command.

## Examples

- This command starts data collection for `dasda`, `0.0.b301`, and for a summary of all available DASDs.

```
dasdstat -e dasda 0.0.b301 0.0.b302 global
```

- This command resets the statistics counters for `dasda`.

```
dasdstat -r dasda
```

- This command reads the summary statistics:

```

statistics data for statistic: global
start time of data collection: Wed Aug 17 09:52:47 CEST 2011

3508 dasd I/O requests
with 67616 sectors(512B each)
0 requests used a PAV alias device
3458 requests used HPF
 <4 8 16 32 64 128 256 512 1k 2k 4k 8k 16k 32k 64k 128k
 256 512 1M 2M 4M 8M 16M 32M 64M 128M 256M 512M 1G 2G 4G >4G
Histogram of sizes (512B secs)
 0 0 2456 603 304 107 18 9 3 8 0 0 0 0 0 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Histogram of I/O times (microseconds)
 0 0 0 0 0 0 100 1738 813 725 30 39 47 15 1 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Histogram of I/O time till ssch
 0 0 901 558 765 25 28 288 748 161 17 16 1 0 0 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Histogram of I/O time between ssch and irq
 0 0 0 0 0 0 316 2798 283 13 19 22 41 15 1 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Histogram of I/O time between irq and end
 0 3023 460 8 4 9 4 0 0 0 0 0 0 0 0 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
of req in chang at enqueueing (0..31)
 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31
 0 2295 319 247 647 0 0 0 0 0 0 0 0 0 0 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

```

For details about the data items, see “Interpreting the data rows” on page 50.

## dasdview - Display DASD structure

**dasdview** displays this DASD information on the system console:

- The volume label.
- VTOC details (general information, and FMT1, FMT4, FMT5, FMT7, and FMT8 labels).
- The content of the DASD, by specifying:
  - Starting point
  - Size


You can display these values in hexadecimal, EBCDIC, and ASCII format.

- Whether the data on the DASD is encrypted.
- Whether the disk is a solid state device.

If you specify a start point and size, you can also display the contents of a disk dump.

(See “The IBM label partitioning scheme” on page 28 for further information about partitioning.)

## Format



Where:

**-b <begin>** or **--begin=<begin>**

displays disk content on the console, starting from *<begin>*. The content of the disk are displayed as hexadecimal numbers, ASCII text, and EBCDIC text. If *<size>* is not specified, **dasdview** will take the default size (128 bytes). You can specify the variable *<begin>* as:

*<begin>*[k|m|b|t|c]

The default for *<begin>* is 0.

**dasdview** displays a disk dump on the console using the DASD driver. The DASD driver might suppress parts of the disk, or add information that is not relevant. This might occur, for example, when displaying the first two tracks of a disk that has been formatted as **cdl**. In this situation, the DASD driver will pad shorter blocks with zeros, in order to maintain a constant blocksize. All Linux applications (including **dasdview**) will process according to this rule.

Here are some examples of how this option can be used:

```

-b 32 (start printing at Byte 32)
-b 32k (start printing at kByte 32)
-b 32m (start printing at MByte 32)
-b 32b (start printing at block 32)
-b 32t (start printing at track 32)
-b 32c (start printing at cylinder 32)

```

**-s** *<size>* or **--size=***<size>*

displays a disk dump on the console, starting at *<begin>*, and continuing for **size** = *<size>*). The content of the dump are displayed as hexadecimal numbers, ASCII text, and EBCDIC text. If a start value (*begin*) is not specified, **dasdview** will take the default. You can specify the variable *<size>* as:

size[k|m|b|t|c]

The default for *<size>* is 128 bytes.

Here are some examples of how this option can be used:

```

-s 16 (use a 16 Byte size)
-s 16k (use a 16 kByte size)
-s 16m (use a 16 MByte size)
-s 16b (use a 16 block size)
-s 16t (use a 16 track size)
-s 16c (use a 16 cylinder size)

```

**-1** displays the disk dump using format 1 (as 16 Bytes per line in hexadecimal, ASCII and EBCDIC). A line number is not displayed. You can only use option **-1** together with **-b** or **-s**.

Option **-1** is the default.

**-2** displays the disk dump using format 2 (as 8 Bytes per line in hexadecimal, ASCII and EBCDIC). A decimal and hexadecimal byte count are also displayed. You can only use option **-2** together with **-b** or **-s**.

**-i** or **--info**

displays basic information such as device node, device bus-ID, device type, or geometry data.

**-x** or **--extended**

displays the information obtained by using **-i** option, but also open count, subchannel identifier, and so on.

**-j** or **--volser**

prints volume serial number (volume identifier).

**-l** or **--label**

displays the volume label.

**-c** or **--characteristics**

displays model-dependent device characteristics, for example disk encryption status or whether the disk is a solid state device.

**-t** *<spec>* or **--vtoc=***<spec>*

displays the VTOC's table-of-contents, or a single VTOC entry, on the console. The variable *<spec>* can take these values:

```

info displays overview information about the VTOC, such as a list of the
 data set names and their sizes.
f1 displays the contents of all format 1 data set control blocks (DSCBs).
f4 displays the contents of all format 4 DSCBs.
f5 displays the contents of all format 5 DSCBs.
f7 displays the contents of all format 7 DSCBs.
f8 displays the contents of all format 8 DSCBs.
all displays the contents of all DSCBs.

```

<node>

specifies the device node of the device for which you want to display information, for example, /dev/dasdzzz. See “DASD naming scheme” on page 33 for more details about device nodes).

**-h or --help**

displays short usage text on console. To view the man page, enter **man dasdview**.

**-v or --version**

displays version number on console, and exit.

## Examples

- To display basic information about a DASD:

```
dasdview -i /dev/dasdzzz
```

This displays:

```
--- general DASD information -----
device node : /dev/dasdzzz
busid : 0.0.0193
type : ECKD
device type : hex 3390 dec 13200

--- DASD geometry -----
number of cylinders : hex 64 dec 100
tracks per cylinder : hex f dec 15
blocks per track : hex c dec 12
blocksize : hex 1000 dec 4096
#
```

- To display device characteristics:

```
dasdview -c /dev/dasda
```

This displays:

```
encrypted disk : no
solid state device : no
```

- To include extended information:

```
dasdview -x /dev/dasdzzz
```

This displays:

```

--- general DASD information -----
device node : /dev/dasdzzz
busid : 0.0.0193
type : ECKD
device type : hex 3390 dec 13200

--- DASD geometry -----
number of cylinders : hex 64 dec 100
tracks per cylinder : hex f dec 15
blocks per track : hex c dec 12
blocksize : hex 1000 dec 4096

--- extended DASD information -----
real device number : hex 452bc08 dec 72530952
subchannel identifier : hex e dec 14
CU type (SenseID) : hex 3990 dec 14736
CU model (SenseID) : hex e9 dec 233
device type (SenseID) : hex 3390 dec 13200
device model (SenseID) : hex a dec 10
open count : hex 1 dec 1
req_queue_len : hex 0 dec 0
chanq_len : hex 0 dec 0
status : hex 5 dec 5
label_block : hex 2 dec 2
FBA_layout : hex 0 dec 0
characteristics_size : hex 40 dec 64
confdata_size : hex 100 dec 256

characteristics : 3990e933 900a5f80 dff72024 0064000f
 : e000e5a2 05940222 13090674 00000000
 : 00000000 00000000 24241502 dfce0001
 : 0677080f 007f4a00 1b350000 00000000

configuration_data : dc010100 4040f2f1 f0f54040 40c9c2d4
 : f1f3f0f0 f0f0f0f0 f0c6c3f1 f1f30509
 : dc000000 4040f2f1 f0f54040 40c9c2d4
 : f1f3f0f0 f0f0f0f0 f0c6c3f1 f1f30500
 : d4020000 4040f2f1 f0f5c5f2 f0c9c2d4
 : f1f3f0f0 f0f0f0f0 f0c6c3f1 f1f3050a
 : f0000001 4040f2f1 f0f54040 40c9c2d4
 : f1f3f0f0 f0f0f0f0 f0c6c3f1 f1f30500
 : 00000000 00000000 00000000 00000000
 : 00000000 00000000 00000000 00000000
 : 00000000 00000000 00000000 00000000
 : 00000000 00000000 00000000 00000000
 : 00000000 00000000 00000000 00000000
 : 00000000 00000000 00000000 00000000
 : 800000a1 00001e00 51400009 0909a188
 : 0140c009 7cb7efb7 00000000 00000800

#

```



- To display volume label information:

```
dasdview -l /dev/dasdzzz
```

This displays:

```
--- volume label -----
volume label key : ascii 'ã00ñ'
 : ebcdic 'VOL1'
 : hex e5d6d3f1

volume label identifier : ascii 'ã00ñ'
 : ebcdic 'VOL1'
 : hex e5d6d3f1

volume identifier : ascii 'ðçðñûó'
 : ebcdic '0X0193'
 : hex f0e7f0f1f9f3

security byte : hex 40

VTOC pointer : hex 0000000101
 (cyl 0, trk 1, blk 1)

reserved : ascii '@@@@'
 : ebcdic ' '
 : hex 4040404040

CI size for FBA : ascii '@@@@'
 : ebcdic ' '
 : hex 40404040

blocks per CI (FBA) : ascii '@@@@'
 : ebcdic ' '
 : hex 40404040

labels per CI (FBA) : ascii '@@@@'
 : ebcdic ' '
 : hex 40404040

reserved : ascii '@@@@'
 : ebcdic ' '
 : hex 40404040

owner code for VTOC : ascii '@@@@@@@@@@@@@@@@'
 : ebcdic ' '
 : hex 40404040 40404040 40404040 4040

reserved : ascii '@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@'
 : ebcdic ' '
 : hex 40404040 40404040 40404040 40404040
 40404040 40404040 40404040 40

#
```

- To display partition information:

```
dasdview -t info /dev/dasdzzz
```

This displays:

```
--- VTOC info -----
The VTOC contains:
 3 format 1 label(s)
 1 format 4 label(s)
 1 format 5 label(s)
 0 format 7 label(s)
Other S/390 and zSeries operating systems would see the following data sets:
```

| data set                           | start   | end     |
|------------------------------------|---------|---------|
| LINUX.V0X0193.PART0001.NATIVE      | trk     | trk     |
| data set serial number : '0X0193'  | 2       | 500     |
| system code : 'IBM LINUX '         | cyl/trk | cyl/trk |
| creation date : year 2001, day 317 | 0/ 2    | 33/ 5   |
| LINUX.V0X0193.PART0002.NATIVE      | trk     | trk     |
| data set serial number : '0X0193'  | 501     | 900     |
| system code : 'IBM LINUX '         | cyl/trk | cyl/trk |
| creation date : year 2001, day 317 | 33/ 6   | 60/ 0   |
| LINUX.V0X0193.PART0003.NATIVE      | trk     | trk     |
| data set serial number : '0X0193'  | 901     | 1499    |
| system code : 'IBM LINUX '         | cyl/trk | cyl/trk |
| creation date : year 2001, day 317 | 60/ 1   | 99/ 14  |

```
#
```

- To display VTOC information:

```
dasdview -t f4 /dev/dasdzzz
```

This displays:

```
--- VTOC format 4 label -----
DS4KEYCD : 04...
DS4IDFMT : dec 244, hex f4
DS4HPCHR : 0000000105 (cyl 0, trk 1, blk 5)
DS4DSREC : dec 7, hex 0007
DS4HCCHH : 00000000 (cyl 0, trk 0)
DS4NOATK : dec 0, hex 0000
DS4VTOCI : dec 0, hex 00
DS4NOEXT : dec 1, hex 01
DS4SMSFG : dec 0, hex 00
DS4DEVAC : dec 0, hex 00
DS4DSCYL : dec 100, hex 0064
DS4DSTRK : dec 15, hex 000f
DS4DEVTK : dec 58786, hex e5a2
DS4DEVI : dec 0, hex 00
DS4DEVL : dec 0, hex 00
DS4DEVK : dec 0, hex 00
DS4DEVFG : dec 48, hex 30
DS4DEVTL : dec 0, hex 0000
DS4DEVDT : dec 12, hex 0c
DS4DEVDB : dec 0, hex 00
DS4AMTIM : hex 0000000000000000
DS4AMCAT : hex 000000
DS4R2TIM : hex 0000000000000000
res1 : hex 0000000000
DS4F6PTR : hex 0000000000
DS4VTOCE : hex 01000000000100000001
 typeind : dec 1, hex 01
 seqno : dec 0, hex 00
 llimit : hex 00000001 (cyl 0, trk 1)
 ulimit : hex 00000001 (cyl 0, trk 1)
res2 : hex 00000000000000000000
DS4EFLVL : dec 0, hex 00
DS4EFPTR : hex 0000000000 (cyl 0, trk 0, blk 0)
res3 : hex 00000000000000000000
#
```

## dasdview

- To print the contents of a disk to the console starting at block 2 (volume label):

```
dasdview -b 2b -s 128 /dev/dasdzzz
```

This displays:

| HEXADECIMAL |          |          |          | EBCDIC           | ASCII              |
|-------------|----------|----------|----------|------------------|--------------------|
| 01....04    | 05....08 | 09....12 | 13....16 | 1.....16         | 1.....16           |
| E5D6D3F1    | E5D6D3F1 | F0E7F0F1 | F9F34000 | VOL1VOL10X0193?. | ?????????????@.    |
| 00000101    | 40404040 | 40404040 | 40404040 | .....            | .....              |
| 40404040    | 40404040 | 40404040 | 40404040 | ???????????????  | @@@@@@@@@@@@@@@@@@ |
| 40404040    | 40404040 | 40404040 | 40404040 | ???????????????  | @@@@@@@@@@@@@@@@@@ |
| 40404040    | 40404040 | 40404040 | 40404040 | ???????????????  | @@@@@@@@@@@@@@@@@@ |
| 40404040    | 88001000 | 10000000 | 00808000 | ???h.....        | @@@@?.....         |
| 00000000    | 00000000 | 00010000 | 00000200 | .....            | .....              |
| 21000500    | 00000000 | 00000000 | 00000000 | ?.....           | !.....             |

- To display the contents of a disk on the console starting at block 14 (first FMT1 DSCB) using format 2:

```
dasdview -b 14b -s 128 -2 /dev/dasdzzz
```

This displays:

| BYTE<br>DECIMAL | BYTE<br>HEXADECIMAL | HEXADECIMAL |          |   |   |   |   |   |   | EBCDIC<br>12345678 | ASCII<br>12345678 |
|-----------------|---------------------|-------------|----------|---|---|---|---|---|---|--------------------|-------------------|
|                 |                     | 1           | 2        | 3 | 4 | 5 | 6 | 7 | 8 |                    |                   |
| 57344           | E000                | D3C9D5E4    | E74BE5F0 |   |   |   |   |   |   | LINUX.V0           | ?????K??          |
| 57352           | E008                | E7F0F1F9    | F34BD7C1 |   |   |   |   |   |   | X0193.PA           | ?????K??          |
| 57360           | E010                | D9E3F0F0    | F0F14BD5 |   |   |   |   |   |   | RT0001.N           | ?????K?           |
| 57368           | E018                | C1E3C9E5    | C5404040 |   |   |   |   |   |   | ATIVE???           | ?????@@@          |
| 57376           | E020                | 40404040    | 40404040 |   |   |   |   |   |   | ????????           | @@@@@@@@@@        |
| 57384           | E028                | 40404040    | F1F0E7F0 |   |   |   |   |   |   | ????10X0           | @@@@????          |
| 57392           | E030                | F1F9F300    | 0165013D |   |   |   |   |   |   | 193.????           | ???.?e?=-         |
| 57400           | E038                | 63016D01    | 0000C9C2 |   |   |   |   |   |   | ??_?...IB          | c?m?...??         |
| 57408           | E040                | D440D3C9    | D5E4E740 |   |   |   |   |   |   | M?LINUX?           | ?@?????@          |
| 57416           | E048                | 40404065    | 013D0000 |   |   |   |   |   |   | ???????..          | @@@e?=-..         |
| 57424           | E050                | 00000000    | 88001000 |   |   |   |   |   |   | ...h.??.           | ...?.?..          |
| 57432           | E058                | 10000000    | 00808000 |   |   |   |   |   |   | ?...??.            | ?...??.           |
| 57440           | E060                | 00000000    | 00000000 |   |   |   |   |   |   | .....              | .....             |
| 57448           | E068                | 00010000    | 00000200 |   |   |   |   |   |   | .?....?.           | .?....?.          |
| 57456           | E070                | 21000500    | 00000000 |   |   |   |   |   |   | ??.?....           | !?.?....          |
| 57464           | E078                | 00000000    | 00000000 |   |   |   |   |   |   | .....              | .....             |

- To see what is at block 1234 (in this example there is nothing there):

```
dasdview -b 1234b -s 128 /dev/dasdzzz
```

This displays:

| HEXADECIMAL                         |          |          |          | EBCDIC   | ASCII    |
|-------------------------------------|----------|----------|----------|----------|----------|
| 01....04 05....08 09....12 13....16 |          |          |          | 1.....16 | 1.....16 |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |
| 00000000                            | 00000000 | 00000000 | 00000000 | .....    | .....    |

- To try byte 0 instead:

```
dasdview -b 0 -s 64 /dev/dasdzzz
```

This displays:

| HEXADECIMAL                         |          |          |          | EBCDIC    | ASCII    |
|-------------------------------------|----------|----------|----------|-----------|----------|
| 01....04 05....08 09....12 13....16 |          |          |          | 1.....16  | 1.....16 |
| C9D7D3F1                            | 000A0000 | 0000000F | 03000000 | IPL1..... | ??...    |
| 00000001                            | 00000000 | 00000000 | 40404040 | .....     | .....    |
| 40404040                            | 40404040 | 40404040 | 40404040 | ????????  | ???????? |
| 40404040                            | 40404040 | 40404040 | 40404040 | ????????  | ???????? |

## fdasd – Partition a DASD

Use **fdasd** to manage partitions on ECKD-type DASD that have been formatted with the compatible disk layout (see “dasdfmt - Format a DASD” on page 423). With **fdasd** you can create, change, and delete partitions, and also change the volume serial number.

**fdasd** checks that the volume has a valid volume label and VTOC. If either is missing or incorrect, **fdasd** recreates it. See “System z compatible disk layout” on page 29 for details about the volume label and VTOC.

Calling **fdasd** with a node, but without options, enters interactive mode. In interactive mode, you are given a menu through which you can display DASD information, add or remove partitions, or change the volume identifier. Your changes are not written to disk until you type the “write” option on the menu. You may quit without altering the disk at any time prior to this.


**Note:** To partition a SCSI disk, use **fdisk** rather than **fdasd**.

**Before you begin:** The disk must be formatted with **dasdfmt** with the (default) **-d cdl** option.

For more information about partitions see “The IBM label partitioning scheme” on page 28.

**Attention:** Careless use of **fdasd** can result in loss of data.

## Format



Where:

- h** or **--help**  
displays help on command line arguments.
- v** or **--version**  
displays the version of **fdasd**.
- s** or **--silent**  
suppresses messages.

**-r** or **--verbose**

displays additional messages that are normally suppressed.

**-a** or **--auto**

auto-creates one partition using the whole disk in non-interactive mode.

**-k** or **--keep\_serial**

keeps the volume serial number when writing the volume label (see "VOLSER" on page 30). This is useful, for example, if the volume serial number has been written with a z/VM tool and should not be overwritten.

**-l** *<volser>* or **--label** *<volser>*

specifies the volume serial number (see "VOLSER" on page 30).

A volume serial consists of one through six alphanumeric characters or the following special characters:

\$ # @ %

All other characters are ignored. Avoid using special characters in the volume serial. This may cause problems accessing a disk by VOLSER. If you must use special characters, enclose the VOLSER in single quotation marks. In addition, any '\$' character in the VOLSER must be preceded by a backslash ('\').

For example, specify:

```
-l 'a@b\c$#'
```

to get:

```
A@B$C#
```

VOLSER is interpreted as an ASCII string and is automatically converted to uppercase, padded with blanks and finally converted to EBCDIC before being written to disk.

Do not use the following reserved volume serials:

- SCRTCH
- PRIVAT
- MIGRAT
- Lnnnnn (L followed by a five digit number)

These are used as keywords by other operating systems (z/OS).

Omitting this parameter causes **fdasd** to prompt for it, if it is needed.

**-c** *<conf\_file>* or **--config** *<conf\_file>*

creates several partitions in non-interactive mode, controlled by the plain text configuration file *<conf\_file>*.

For each partition you want to create, add one line of the following format to *<conf\_file>*:

```
[x,y]
```

where x is the first track and y is the last track of that partition. You can use the keyword **first** for the first possible track on disk and, correspondingly, the keyword **last** for the last possible track on disk.

The following sample configuration file allows you to create three partitions:

```
[first,1000]
[1001,2000]
[2001,last]
```

## fdasd

**-i** or **--volser**

displays the volume serial number and exits.

**-p** or **--table**

displays the partition table and exits.

**<node>**

specifies the device node of the DASD you want to partition, for example, /dev/dasdzzz. See “DASD naming scheme” on page 33 for more details about device nodes.

## Processing

### fdasd menu

If you call **fdasd** in the interactive mode (that is, with just a node), the following menu appears:

```
Command action
m print this menu
p print the partition table
n add a new partition
d delete a partition
v change volume serial
t change partition type
r re-create VTOC and delete all partitions
u re-create VTOC re-using existing partition sizes
s show mapping (partition number - data set name)
q quit without saving changes
w write table to disk and exit

Command (m for help):
```

#### Menu commands:

**m** re-displays the **fdasd** command menu.

#### DASD information:

- Number of cylinders
- Number of tracks per cylinder
- Number of blocks per track
- Block size
- Volume label
- Volume identifier
- Number of partitions defined

#### Partition information:

- Linux node
- Start track
- End track
- Number of tracks
- Partition ID
- Partition type

There is also information about the free disk space that is not used for a partition.

**n** adds a new partition to the DASD. You will be asked to give the start track and the length or end track of the new partition.



- d** deletes a partition from the DASD. You will be asked which partition to delete.
- v** changes the volume identifier. You will be asked to enter a new volume identifier. See “VOLSER” on page 30 for the format.
- t** changes the partition type. You will be asked to identify the partition to be changed. You will then be asked for the new partition type (Linux native or swap). Note that this type is a guideline; the actual use Linux makes of the partition depends on how it is defined with the `mkswap` or `mkxxfs` tools. The main function of the partition type is to describe the partition to other operating systems so that, for example, swap partitions can be skipped by backup programs.
- r** recreates the VTOC and thereby deletes all partitions.
- u** recreates all VTOC labels without removing all partitions. Existing partition sizes will be reused. This is useful to repair damaged labels or migrate partitions created with older versions of **fdasd**.
- s** displays the mapping of partition numbers to data set names. For example:
 

```
Command (m for help): s

device: /dev/dasdzzz
volume label ...: VOL1
volume serial ..: 0X0193

WARNING: This mapping may be NOT up-to-date,
 if you have NOT saved your last changes!

/dev/dasdzzz1 - LINUX.V0X0193.PART0001.NATIVE
/dev/dasdzzz2 - LINUX.V0X0193.PART0002.NATIVE
/dev/dasdzzz3 - LINUX.V0X0193.PART0003.NATIVE
```
- q** quits **fdasd** without updating the disk. Any changes you have made (in this session) will be discarded.
- w** writes your changes to disk and exits. After the data is written Linux will reread the partition table.

## Examples

### Example using the menu

This section gives an example of how to use **fdasd** to create two partitions on a z/VM minidisk, change the type of one of the partitions, save the changes and check the results.

In this example, we will format a z/VM minidisk with the compatible disk layout. The minidisk has device number 193.

1. Call **fdasd**, specifying the minidisk:

```
fdasd /dev/dasdzzz
```

**fdasd** reads the existing data and displays the menu:

```

reading volume label: VOL1
reading vtoc : ok

Command action
 m print this menu
 p print the partition table
 n add a new partition
 d delete a partition
 v change volume serial
 t change partition type
 r re-create VTOC and delete all partitions
 u re-create VTOC re-using existing partition sizes
 s show mapping (partition number - data set name)
 q quit without saving changes
 w write table to disk and exit
Command (m for help):

```

2. Use the p option to verify that no partitions have yet been created on this DASD:

```

Command (m for help): p

Disk /dev/dasdzzz:
cylinders: 100
tracks per cylinder ..: 15
blocks per track: 12
bytes per block: 4096
volume label: VOL1
volume serial: 0X0193
max partitions: 3

----- tracks -----
 Device start end length Id System
 2 1499 1498 unused

```

3. Define two partitions, one by specifying an end track and the other by specifying a length. (In both cases the default start tracks are used):

```

Command (m for help): n
First track (1 track = 48 KByte) ([2]-1499):
Using default value 2
Last track or +size[c|k|M] (2-[1499]): 700
You have selected track 700

```

```

Command (m for help): n
First track (1 track = 48 KByte) ([701]-1499):
Using default value 701
Last track or +size[c|k|M] (701-[1499]): +400
You have selected track 1100

```

4. Check the results using the p option:

Command (m for help): **p**

Disk /dev/dasdzzz:  
 cylinders .....: 100  
 tracks per cylinder ..: 15  
 blocks per track .....: 12  
 bytes per block .....: 4096  
 volume label .....: VOL1  
 volume serial .....: 0X0193  
 max partitions .....: 3

|               | ----- tracks ----- |      |        |    |              |
|---------------|--------------------|------|--------|----|--------------|
| Device        | start              | end  | length | Id | System       |
| /dev/dasdzzz1 | 2                  | 700  | 699    | 1  | Linux native |
| /dev/dasdzzz2 | 701                | 1100 | 400    | 2  | Linux native |
|               | 1101               | 1499 | 399    |    | unused       |

### 5. Change the type of a partition:

Command (m for help): **t**

Disk /dev/dasdzzz:  
 cylinders .....: 100  
 tracks per cylinder ..: 15  
 blocks per track .....: 12  
 bytes per block .....: 4096  
 volume label .....: VOL1  
 volume serial .....: 0X0193  
 max partitions .....: 3

|               | ----- tracks ----- |      |        |    |              |
|---------------|--------------------|------|--------|----|--------------|
| Device        | start              | end  | length | Id | System       |
| /dev/dasdzzz1 | 2                  | 700  | 699    | 1  | Linux native |
| /dev/dasdzzz2 | 701                | 1100 | 400    | 2  | Linux native |
|               | 1101               | 1499 | 399    |    | unused       |

change partition type  
 partition id (use 0 to exit):

Enter the ID of the partition you want to change; in this example partition 2:

partition id (use 0 to exit): **2**

### 6. Enter the new partition type; in this example type 2 for swap:

current partition type is: Linux native

1 Linux native  
 2 Linux swap

new partition type: **2**

### 7. Check the result:

```
Command (m for help): p
```

```
Disk /dev/dasdzzz:
 cylinders: 100
 tracks per cylinder ..: 15
 blocks per track: 12
 bytes per block: 4096
 volume label: VOL1
 volume serial: 0X0193
 max partitions: 3
```

```
----- tracks -----
 Device start end length Id System
/dev/dasdzzz1 2 700 699 1 Linux native
/dev/dasdzzz2 701 1100 400 2 Linux swap
 1101 1499 399 unused
```

#### 8. Write the results to disk using the w option:

```
Command (m for help): w
writing VTOC...
rereading partition table...
#
```

### Example using options

You can partition using the **-a** or **-c** option without entering the menu mode. This is useful for partitioning using scripts, if you need to partition several hundred DASDs, for example.

With the **-a** option you can create one large partition on a DASD:

```
fdasd -a /dev/dasdzzz
auto-creating one partition for the whole disk...
writing volume label...
writing VTOC...
rereading partition table...
#
```

This will create a partition as follows:

```
 Device start end length Id System
/dev/dasdzzz1 2 1499 1498 1 Linux native
```

Using a configuration file you can create several partitions. For example, the following configuration file, `config`, creates three partitions:

```
[first,500]
[501,1100]
[1101,last]
```

Submitting the command with the **-c** option creates the partitions:

```
fdasd -c config /dev/dasdzzz
parsing config file 'config'...
writing volume label...
writing VTOC...
rereading partition table...
#
```

This creates partitions as follows:

| Device        | start | end  | length | Id | System       |
|---------------|-------|------|--------|----|--------------|
| /dev/dasdzzz1 | 2     | 500  | 499    | 1  | Linux native |
| /dev/dasdzzz2 | 501   | 1100 | 600    | 2  | Linux native |
| /dev/dasdzzz3 | 1101  | 1499 | 399    | 3  | Linux native |

## hyptop - Display hypervisor performance data

The **hyptop** command provides a dynamic real-time view of a hypervisor environment on System z. It works with both the z/VM and the LPAR PR/SM hypervisor. Depending on the available data it shows, for example, CPU and memory information about LPARs or z/VM guest virtual machines. The **hyptop** command provides two main windows:


- A list of systems that the hypervisor is currently running (sys\_list).
- One system in more detail (sys).

You can run **hyptop** in interactive mode (default) or in batch mode with the **-b** option.

**Before you begin.** The following things are required to run **hyptop**:

- The debugfs file system must be mounted, see “debugfs” on page xi.
- The Linux kernel must have the required support to provide the performance data. Check that `<debugfs mount point>/s390_hypfs` is available after mounting debugfs.
- The hyptop user must have read permission for the required debugfs files:
  - z/VM: `<debugfs mount point>/s390_hypfs/diag_2fc`
  - LPAR: `<debugfs mount point>/s390_hypfs/diag_204`
- To monitor all LPARs or z/VM guest virtual machines, your system must have additional permissions:
  - For z/VM: The guest virtual machine must be class B.
  - For LPAR: On the HMC or SE security menu of the LPAR activation profile, select the **Global performance data control** checkbox.

## Format



Where:

- w** *<window name>* or **--window=***<window name>*  
selects the window to display, either *sys* or *sys\_list*. Use the options **--sys**, **--fields**, and **--sort** to modify the current window. The last window specified with the **--window** option will be used as the start window. The default window is *sys\_list*.
- s** *<system>* or **--sys=***<system>*  
selects systems for the current window. If you specify this option, only the selected systems are shown in the window. For the *sys* window you can only specify one system.
- f** *<field>[:<unit>]* or **--fields=***<field>[:<unit>]*  
selects fields and units in the current window. The *<field>* variable is a one letter unique identifier for a field (for example "c" for CPU time). The *<unit>* variable specifies the unit used for the field (for example "us" for microseconds). See "Error conditions" on page 449 for definitions. If the **--fields** option is specified, only the selected fields are shown.
- S** *<field>* or **--sort=***<field>*  
selects the field used to sort the data in the current window. To reverse the sort order, specify the option twice. See "Error conditions" on page 449 for definitions.
- t** *<type>* or **--cpu\_types=***<type>*  
selects CPU types that are used for CPU time calculations. See "Results" on page 451 for definitions.
- b** or **--batch\_mode**  
uses batch mode. This can be useful for sending output from hyptop to another program, a file, or a line mode terminal. In this mode no user input is accepted.
- d** *<seconds>* or **--delay=***<seconds>*  
specifies the delay between screen updates.
- n** *<iterations>* or **--iterations=***<iterations>*  
specifies the maximum number of screen updates before ending.
- h** or **--help**  
prints usage information, then exits. To view the man page, enter **man hyptop**.
- v** or **--version**  
displays the version of **hyptop**, then exits.

## Usage

### Navigating between windows

When you start the **hyptop** command, the `sys_list` window opens in normal mode. Data is updated at regular intervals, sorted by CPU time. You can navigate between the windows as shown in Figure 73.




Figure 73. *hyptop* window navigation overview

To navigate between the windows, use the and arrow keys. The windows have two modes, normal mode and select mode.

You can get online help for every window by pressing the key. Press in the `sys_list` window to exit `hyptop`.

Instead of using the arrow keys, you can use letter keys (equivalent to the vi editor navigation) in all windows as listed in Table 54.

Table 54. Using letter keys instead of arrow keys

| Arrow key | Letter key equivalent |
|-----------|-----------------------|
|           |                       |
|           |                       |
|           |                       |
|           |                       |

### Selecting data

To enter select mode press the key. The display is frozen so that you can select rows. Select rows by pressing the and keys and mark the rows with the Spacebar. Marked rows are displayed in bold font. Leave the select mode by pressing the key.

To see the details of one system, enter select mode in the `sys_list` window, then navigate to the row for the system you want to look at, and press the key. This opens the `sys` window for the system. The key always returns you to the previous window.

To scroll any window press the and keys or the Page Up and Page Down keys. Jump to the end of a window by pressing the + keys and to the beginning by pressing the key.

### Sorting data

The `sys` window or `sys_list` window table is sorted according to the values in the selected column. Select a column by pressing the hot key of the column. This key



is underlined in the heading. If you press the hot key again, the sort order is reversed. Alternatively, you can select columns with the `<` and `>` keys.

### Filtering data

From the `sys` or `sys_list` window you can access the fields selection window and the CPU-type selection window as shown in Figure 74.




Figure 74. Accessing the fields and CPU-type selection windows

Use the `T` key to toggle between the CPU-type selection window and the main window. Use the `F` key to toggle between the fields selection window and the main window. You can also use the `←` key to return to the main window from the CPU types and fields windows.

In the fields and CPU-type selection windows, press the field or CPU type identifier key (see “LPAR fields,” “z/VM fields” on page 450, and “Results” on page 451) to select or de-select. Selected rows are bold and de-selected rows are grey. When you return to the main window, the data is filtered according to your field and CPU type selections.

## Error conditions

Different fields are supported depending whether your hypervisor is LPAR PR/SM or z/VM. The fields might also be different depending on machine type, z/VM version, and kernel version. Each field has a unique one letter identifier that can be used in interactive mode to enable the field in the field selection window, or to select the sort field in the `sys` or `sys_list` window. You can also select fields and sort data using the `--fields` and `--sort` command line options.

### LPAR fields

The following fields are available under LPAR in both the `sys_list` and `sys` windows:

| Identifier | Column label | Explanation                |
|------------|--------------|----------------------------|
| c          | cpu          | CPU time per second        |
| m          | mgm          | Management time per second |
| C          | Cpu+         | Total CPU time             |
| M          | Mgm+         | Total management time      |
| o          | online       | Online time                |

In the `sys_list` window only:

| Identifier | Column label | Explanation                     |
|------------|--------------|---------------------------------|
| y          | system       | Name of the LPAR (always shown) |
| #          | #cpu         | Number of CPUs                  |

In the sys window only:

| Identifier | Column label | Explanation                          |
|------------|--------------|--------------------------------------|
| i          | cpuid        | CPU identifier (always shown)        |
| p          | type         | CPU type. See “Results” on page 451  |
| v          | visual       | Visualization of CPU time per second |

## z/VM fields

The following fields are available under z/VM.

In the sys\_list and sys windows:

| Identifier | Column label | Explanation         |
|------------|--------------|---------------------|
| c          | cpu          | CPU time per second |
| C          | Cpu+         | Total CPU time      |
| o          | online       | Online time         |

In the sys\_list window only:

| Identifier | Column label | Explanation                                           |
|------------|--------------|-------------------------------------------------------|
| y          | system       | Name of the z/VM guest virtual machine (always shown) |
| #          | #cpu         | Number of CPUs                                        |
| u          | memuse       | Used memory                                           |
| a          | memmax       | Maximum memory                                        |
| n          | wmin         | Minimum weight                                        |
| r          | wcur         | Current weight                                        |
| x          | wmax         | Maximum weight                                        |

In the sys window only:

| Identifier | Column label | Explanation                          |
|------------|--------------|--------------------------------------|
| i          | cpuid        | CPU identifier (always shown)        |
| v          | visual       | Visualization of CPU time per second |

## Units

Depending on the field type the values can be displayed in different units. In the sys\_list and sys windows, the units are displayed under the column headings in parenthesis. Each unit can be specified through the **--fields** command line option. Units can also be selected interactively. To change a unit enter select mode in the fields window select the field where the unit should be changed and press the "+" or "-" keys to go through the available units. The following units are supported:

Units of time:

| Unit | Explanation                       |
|------|-----------------------------------|
| us   | Microseconds ( $10^{-6}$ seconds) |
| ms   | Milliseconds ( $10^{-3}$ seconds) |

| Unit | Explanation                                          |
|------|------------------------------------------------------|
| %    | Hundreds of a second ( $10^{-2}$ seconds) or percent |
| s    | Seconds                                              |
| m    | Minutes                                              |
| hm   | Hours and minutes                                    |
| dhm  | Days, hours, and minutes                             |

Units of memory:

| Unit | Explanation                     |
|------|---------------------------------|
| KiB  | Kibibytes (1 024 bytes)         |
| MiB  | Mebibytes (1 048 576 bytes)     |
| GiB  | Gibibytes (1 073 741 824 bytes) |

Other units:

| Unit | Explanation     |
|------|-----------------|
| str  | String          |
| #    | Count or number |
| vis  | Visualization   |

## Results

Enable or disable CPU types in interactive mode in the `cpu_types` window. The CPU types can also be specified with the `--cpu_types` command line option.

The calculation of the CPU data uses CPUs of the specified types only. For example, if you want to see how much CPU time is consumed by your Linux systems, enable CPU type IFL.

On z/VM the processor type is always UN and you cannot select the type.

In an LPAR the following CPU types can be selected either interactively or with the `--cpu_types` command line option:

| Identifier | Column label | Explanation                                                                  |
|------------|--------------|------------------------------------------------------------------------------|
| i          | IFL          | Integrated Facility for Linux. On older machines IFLs might be shown as CPs. |
| p          | CP           | CP processor type.                                                           |
| u          | UN           | Unspecified processor type (other than CP or IFL).                           |

## Examples

- To start **hyptop** with the `sys_list` window in interactive mode, enter:

```
hyptop
```

- If your Linux instance is running in an LPAR that has permission to see the other LPARs, the output will look like the following:

## hyptop

```
12:30:48 | CPU-T: IFL(18) CP(3) UN(3) ?=help
system #cpu cpu mgm Cpu+ Mgm+ online
(str) (#) (%) (%) (hm) (hm) (dhm)
S05LP30 10 461.14 10.18 1547:41 8:15 11:05:59
S05LP33 4 133.73 7.57 220:53 6:12 11:05:54
S05LP50 4 99.26 0.01 146:24 0:12 10:04:24
S05LP02 1 99.09 0.00 269:57 0:00 11:05:58
TRX2CFA 1 2.14 0.03 3:24 0:04 11:06:01
S05LP13 6 1.36 0.34 4:23 0:54 11:05:56
TRX1 19 1.22 0.14 13:57 0:22 11:06:01
TRX2 20 1.16 0.11 26:05 0:25 11:06:00
S05LP55 2 0.00 0.00 0:22 0:00 11:05:52
S05LP56 3 0.00 0.00 0:00 0:00 11:05:52
 413 823.39 23.86 3159:57 38:08 11:06:01
```

- If your Linux instance runs in a z/VM guest virtual machine that has permission to see the other z/VM guest virtual machines, the output will look like the following:

```
12:32:21 | CPU-T: UN(16) ?=help
system #cpu cpu Cpu+ online memuse memmax wcur
(str) (#) (%) (hm) (dhm) (GiB) (GiB) (#)
T6360004 6 100.31 959:47 53:05:20 1.56 2.00 100
DTCVSW1 1 0.00 0:00 53:16:42 0.01 0.03 100
T6360002 6 0.00 166:26 40:19:18 1.87 2.00 100
OPERATOR 1 0.00 0:00 53:16:42 0.00 0.03 100
T6360008 2 0.00 0:37 30:22:55 0.32 0.75 100
T6360003 6 0.00 3700:57 53:03:09 4.00 4.00 100
NSLCF1 1 0.00 0:02 53:16:41 0.03 0.25 500
PERFSVM 1 0.00 0:53 2:21:12 0.04 0.06 0
TCPIP 1 0.00 0:01 53:16:42 0.01 0.12 3000
DIRMAINT 1 0.00 0:04 53:16:42 0.01 0.03 100
DTCVSW2 1 0.00 0:00 53:16:42 0.01 0.03 100
RACFVM 1 0.00 0:00 53:16:42 0.01 0.02 100
 75 101.57 5239:47 53:16:42 15.46 22.50 3000
```

At the top of the sys and sys\_list windows the CPU types currently used for CPU time calculation are displayed.

- To start **hyptop** with the sys window showing performance data for LPAR MYLPAR, enter:

```
hyptop -w sys -s mylpar
```

The result will look like the following:

```
11:18:50 MYLPAR CPU-T: IFL(0) CP(24) UN(2) ?=help
cpuid type cpu mgm visual
(#)- (str) (%) (%) (vis)
0 CP 50.78 0.28 #####
1 CP 62.76 0.17 #####
2 CP 71.11 0.48 #####
3 CP 32.38 0.24 #####
4 CP 64.35 0.32 #####
5 CP 67.61 0.40 #####
6 CP 70.95 0.35 #####
7 CP 62.16 0.41 #####
8 CP 70.48 0.25 #####
9 CP 56.43 0.20 #####
10 CP 0.00 0.00
11 CP 0.00 0.00
12 CP 0.00 0.00
13 CP 0.00 0.00
=:V:N 609.02 3.10
```

- To start **hyptop** with the sys\_list window in batch mode, enter:

```
hyptop -b
```

- To start **hyptop** with the sys\_list window in interactive mode with the fields CPU time (in milliseconds) and online time (unit default) and sort the output according to online time, enter:

```
hyptop -f c:ms,o -S o
```

- To start **hyptop** with the sys\_list window in batch mode with update delay 5 seconds and 10 iterations, enter:

```
hyptop -b -d 5 -n 10
```

- To start **hyptop** with the sys\_list window and use only CPU types IFL and CP for CPU time calculation, enter:




```
hyptop -t ifl,cp
```

## Scenario

To start **hyptop** with the sys window with system MYLPAR with the fields CPU time (unit milliseconds) and Total CPU time (unit default) and sort the output reversely according to the Total CPU time, follow these steps:

- Start hyptop.


```
hyptop
```

- Go to select mode by pressing the  key. The display will freeze.
- Navigate to the row for the system you want to look (in the example MYLPAR) at using the  and  keys.

```
12:15:00 | CPU-T: IFL(18) CP(3) UN(3) ?=help
system #cpu cpu mgm Cpu+ Mgm+ online
(str) (#) (%) (%) (hm) (hm) (dhm)
MYLPAR 4 199.69 0.04 547:41 8:15 11:05:59
S05LP33 4 133.73 7.57 220:53 6:12 11:05:54
S05LP50 4 99.26 0.01 146:24 0:12 10:04:24
S05LP02 1 99.09 0.00 269:57 0:00 11:05:58
...
S05LP56 3 0.00 0.00 0:00 0:00 11:05:52
413 823.39 23.86 3159:57 38:08 11:06:01
```

- Open the sys window for MYLPAR by pressing the  key.

```
12:15:51 MYLPAR CPU-T: IFL(18) CP(3) UN(2) ?=help
cpuid type cpu mgm visual
(#) (str) (%) (%) (vis)
0 IFL 99.84 0.02 #####
1 IFL 99.85 0.02 #####
2 IFL 0.00 0.00
3 IFL 0.00 0.00
=:V:N 199.69 0.04
```

- Press the  key to go to the fields selection window:

```

Select Fields and Units ?=help
K S ID UNIT AGG DESCRIPTION
p * type str none CPU type
c * cpu % sum CPU time per second
m * mgm % sum Management time per second
C cpu+ hm sum Total CPU time
M mgm+ hm sum Total management time
o online dhm max Online time
v * visual vis none Visualization of CPU time per second

```

Ensure that CPU time per second and Total CPU time are selected and for CPU time microseconds are used as unit:

- Press the **P** key, the **M** key, and the **V** key to disable CPU type, Management time per second, and Visualization.
- Press the **C** key to enable Total CPU time.
- Then select the CPU time per second row by pressing the **→** and **↓** keys.
- Press the minus key (-) to switch from the percentage (%) unit to the microseconds (ms) unit.

```

Select Fields and Units ?=help
K S ID UNIT AGG DESCRIPTION
p type str none CPU type
c * cpu ms sum CPU time per second
m mgm % sum Management time per second
C * cpu+ hm sum Total CPU time
M mgm+ hm sum Total management time
o online dhm max Online time
v visual vis none Visualization of CPU time per second

```

Press the **←** key twice to return to the sys window.

- To sort by Total CPU time and list the values from low to high, press the **Shift** + **C** keys twice:

```

13:44:41 MYLPAR CPU-T: IFL(18) CP(3) UN(2) ?=help
cpuid cpu Cpu+
(#)- (ms) (hm)
2 0.00 0:00
3 0.00 0:00
1 37.48 492:55
0 23.84 548:52
=:^:N 61.33 1041:47

```

You can do all of these steps in one by entering the command:

```
hyptop -w sys -s mylpar -f c:ms,C -S C -S C
```

## icainfo - Show available libica functions

Use this command to find out which libica functions are available on your Linux system.

### Format

#### icainfo syntax

```
►—icainfo—◄
```

Where:

**-q or --quiet**

suppresses an explanatory introduction to the list of functions in the command output.

**-v or --version**

displays the version number of **icainfo**, then exits.

**-h or --help**

displays help information for the command.

### Examples

- To show which libica functions are available on your Linux system enter:

```
icainfo
The following CP Assist for Cryptographic Function (CPACF) operations are
supported by libica on this system:
SHA-1: yes
SHA-256: yes
SHA-512: yes
DES: yes
TDES-128: yes
TDES-192: yes
AES-128: yes
AES-192: yes
AES-256: yes
PRNG: yes
```

- To list the libica functions without the introduction enter:

```
icainfo -q
SHA-1: yes
SHA-256: yes
SHA-512: yes
DES: yes
TDES-128: yes
TDES-192: yes
AES-128: yes
AES-192: yes
AES-256: yes
PRNG: yes
```

## icastats - Show libica functions

Use this command to find out whether libica uses hardware acceleration features or works with software fallbacks. The command also shows which specific functions of libica are used.

### Format

#### icastats syntax

```
►►—icastats— --reset —————◄◄
```

Where:

#### **--reset**

sets the function counters to zero.

#### **-h** or **--help**

displays help information for the command.

### Examples

- To display the current use of libica functions issue:

```
icastats
```

| function | # hardware | # software |
|----------|------------|------------|
| SHA1     | 33210      | 49815      |
| SHA224   | 171992     | 328312     |
| SHA256   | 189565     | 440615     |
| SHA384   | 172081     | 323235     |
| SHA512   | 205170     | 266679     |
| RANDOM   | 6716896    | 0          |
| MOD EXPO | 29         | 53         |
| RSA CRT  | 15         | 18         |
| DES ENC  | 2366808    | 0          |
| DES DEC  | 2366808    | 0          |
| 3DES ENC | 0          | 0          |
| 3DES DEC | 0          | 0          |
| AES ENC  | 576713     | 414708     |
| AES DEC  | 576688     | 414700     |



## lschp - List channel paths

Use this command to display information about channel paths.

### Format

#### lschp syntax

```

>> lschp [---help---version] <<

```

Where:

- v or --version**  
displays the version number of **lschp** and exits.
- h or --help**  
displays a short help text, then exits.

Output column description:

#### CHPID

Channel-path identifier.

#### Vary

Logical channel-path state:

- 0 = channel-path is not used for I/O.
- 1 = channel-path is used for I/O.

#### Cfg.

Channel-path configure state:

- 0 = stand-by
- 1 = configured
- 2 = reserved
- 3 = not recognized

#### Type

Channel-path type identifier.

#### Cmg

Channel measurement group identifier.

#### Shared

Indicates whether a channel-path is shared between LPARs:

- 0 = channel-path is not shared
- 1 = channel-path is shared

A column value of '-' indicates that a facility associated with the corresponding channel-path attribute is not available.

### Examples

- To query the configuration status of channel path ID 0.40 issue:


```
lschp
CHPID Vary Cfg. Type Cmg Shared
=====
...
...
0.40 1 1 1b 2 1
...
...
```

The value under Cfg. shows that the channel path is configured (1).

## lscss - List subchannels

This command is used to gather subchannel information from sysfs and display it in a summary format.

### Format



Where:

**-s or --short**

strips the “0.n.” from the device bus-IDs in the command output.

**-t or --devtype**

limits the output to information about the specified device types and, if provided, the specified model.

**<devicetype>**

specifies a device type.

**<model>**

is a specific model of the specified device type.

### Examples

- This command lists all subchannels:

```

lscss
Device Subchan. DevType CU Type Use PIM PAM POM CHPIDs

0.0.5C44 0.0.0000 3390/0A 3990/E9 yes C0 C0 FF 40410000 00000000
0.0.5C45 0.0.0001 3390/0A 3990/E9 yes C0 C0 FF 40410000 00000000
0.0.F5B4 0.0.0002 1732/01 1731/01 yes 80 80 FF 71000000 00000000
0.0.F5B5 0.0.0003 1732/01 1731/01 yes 80 80 FF 71000000 00000000
0.0.F5B6 0.0.0004 1732/01 1731/01 yes 80 80 FF 71000000 00000000
0.0.0191 0.0.0005 3390/0A 3990/E9 C0 C0 FF 40410000 00000000
0.0.0009 0.0.0006 0000/00 3215/00 80 80 FF 00000000 00000000
0.0.000C 0.0.0007 0000/00 2540/00 80 80 FF 00000000 00000000
0.0.000D 0.0.0008 0000/00 2540/00 80 80 FF 00000000 00000000
0.0.000E 0.0.0009 0000/00 1403/00 80 80 FF 00000000 00000000
0.0.0190 0.0.000A 3390/0A 3990/E9 C0 C0 FF 40410000 00000000
0.0.019D 0.0.000B 3390/0A 3990/E9 C0 C0 FF 40410000 00000000
0.0.019E 0.0.000C 3390/0A 3990/E9 C0 C0 FF 40410000 00000000
0.0.0592 0.0.000D 3390/0A 3990/E9 C0 C0 FF 40410000 00000000
0.0.0480 0.0.000E 3480/04 3480/01 80 80 FF 10000000 00000000
0.0.0A38 0.0.000F 3590/11 3590/50 80 80 FF 10000000 00000000

```

- This command lists subchannels with an attached 3480 model 04 or 3590 tape device and strips the “0.n.” from the device and subchannel bus-IDs in the command output:

lscss


```
lscss -s -t 3480/04,3590
```

| Device | Subchan. | DevType | CU      | Type | Use | PIM | PAM | POM      | CHPIDs   |
|--------|----------|---------|---------|------|-----|-----|-----|----------|----------|
| 0480   | 000E     | 3480/04 | 3480/01 |      | 80  | 80  | FF  | 10000000 | 00000000 |
| 0A38   | 000F     | 3590/11 | 3590/50 |      | 80  | 80  | FF  | 10000000 | 00000000 |

## lsdasd - List DASD devices

This command is used to gather information about DASD devices from sysfs and display it in a summary format.

### Format



Where:

- a** or **--offline**  
includes devices that are currently offline.
- b** or **--base**  
omits PAV alias devices. Lists only base devices.
- s** or **--short**  
strips the "0.n." from the device bus-IDs in the command output.
- v** or **--verbose**  
Obsolete. This option has no effect on the output.
- l** or **--long**  
extends the output to include UID and attributes.
- c** or **--compat**  
creates output of this command as with versions earlier than 1.7.0.
- u** or **--uid**  
includes and sorts output by UID.
- version**  
displays the version of the command.
- <device\_bus\_id>**  
limits the output to information about the specified devices only.
- h** or **--help**  
displays a short help text, then exits.

## Examples

- The following command lists all DASD (including offline DASDs):

```
lsdsd -a
Bus-ID Status Name Device Type BlkSz Size Blocks
=====
0.0.0190 offline
0.0.0191 offline
0.0.019d offline
0.0.019e offline
0.0.0592 offline
0.0.4711 offline
0.0.4712 offline
0.0.4f2c offline
0.0.4d80 active dasda 94:0 ECKD 4096 4695MB 1202040
0.0.4f19 active dasdb 94:4 ECKD 4096 23034MB 5896800
0.0.4d81 active dasdc 94:8 ECKD 4096 4695MB 1202040
0.0.4d82 active dasdd 94:12 ECKD 4096 4695MB 1202040
0.0.4d83 active dasde 94:16 ECKD 4096 4695MB 1202040
```

- The following command shows information only for the DASD with device number 0x4d80 and strips the “0.n.” from the bus IDs in the output:

```
lsdsd -s 4d80
Bus-ID Status Name Device Type BlkSz Size Blocks
=====
4d80 active dasda 94:0 ECKD 4096 4695MB 1202040
```


- The following command shows only online DASDs in the format of **lsdsd** versions earlier than 1.7.0:

```
lsdsd -c
0.0.4d80(ECKD) at (94: 0) is dasda : active at blocksize 4096, 1202040 blocks, 4695 MB
0.0.4f19(ECKD) at (94: 4) is dasdb : active at blocksize 4096, 5896800 blocks, 23034 MB
0.0.4d81(ECKD) at (94: 8) is dasdc : active at blocksize 4096, 1202040 blocks, 4695 MB
0.0.4d82(ECKD) at (94: 12) is dasdd : active at blocksize 4096, 1202040 blocks, 4695 MB
0.0.4d83(ECKD) at (94: 16) is dasde : active at blocksize 4096, 1202040 blocks, 4695 MB
```

## Isluns - Discover LUNs in Fibre Channel SANs

Use the `Isluns` command to discover and scan LUNs in Fibre Channel Storage Area Networks (SANs).

### Format



Where:

- c** or **--ccw <device\_bus\_id>**  
shows LUNs for a specific FCP device.
- p** or **--port <wwpn>**  
shows LUNs for the port with the specified WWPN.
- a** or **--active**  
shows the currently active LUNs. A bracketed "x" indicates that the corresponding disk is encrypted.
- v** or **--version**  
displays the version number of **Isluns** and exits.
- h** or **--help**  
displays an overview of the syntax.

### Examples

- This example shows all LUNs for port 0x500507630300c562:

```

Isluns --port 0x500507630300c562
Scanning for LUNs on adapter 0.0.5922
 at port 0x500507630300c562:
 0x4010400000000000
 0x4010400100000000
 0x4010400200000000
 0x4010400300000000
 0x4010400400000000
 0x4010400500000000

```

- This example shows all LUNs for an FCP device with bus ID 0.0.5922:

```
lsluns -c 0.0.5922
 at port 0x500507630300c562:
 0x4010400000000000
 0x4010400100000000
 0x4010400200000000
 0x4010400300000000
 0x4010400400000000
 0x4010400500000000
 at port 0x500507630303c562:
 0x4010400000000000
 0x4010400100000000
 0x4010400200000000
 0x4010400300000000
 0x4010400400000000
 0x4010400500000000
```

- This example shows all active LUNs:

```
lsluns -a
adapter = 0.0.5922
 port = 0x500507630300c562
 lun = 0x401040a200000000 /dev/sg0 Disk IBM:2107900
 lun = 0x401040a300000000(x) /dev/sg1 Disk IBM:2107900
 lun = 0x401040a400000000 /dev/sg2 Disk IBM:2107900
 lun = 0x401040a500000000 /dev/sg3 Disk IBM:2107900
 port = 0x500507630303c562
 lun = 0x401040a400000000 /dev/sg4 Disk IBM:2107900
 lun = 0x401040a500000000 /dev/sg5 Disk IBM:2107900
adapter = 0.0.593a
 port = 0x500507630307c562
 lun = 0x401040b000000000 /dev/sg6 Disk IBM:2107900
 lun = 0x401040b300000000 /dev/sg7 Disk IBM:2107900
 ...
```

The (x) in the output indicates that the device is encrypted.



## lsmem - Show online status information about memory blocks

The **lsmem** command lists the ranges of available memory with their online status. The listed memory blocks correspond to the memory block representation in sysfs. The command also shows the memory block size, the device size, and the amount of memory in online and offline state.

### Format

#### lsmem syntax

```

▶▶ lsmem [-a]

```

Where:

**-a or --all**

lists each individual memory block, instead of combining memory blocks with similar attributes.

**-v or --version**

displays the version number of **lsmem**, then exits.

**-h or --help**

displays a short help text, then exits. To view the man page, enter **man lsmem**.

The columns in the command output have this meaning:

**Address range**

Start and end address of the memory range.

**Size** Size of the memory range in MB (1024 x 1024 bytes).

**State** Indication of the online status of the memory range. State on->off means that the address range is in transition from online to offline.

**Removable**

yes if the memory range can be set offline, no if it cannot be set offline. A dash (-) means that the range is already offline.

**Device**

Device number or numbers that correspond to the memory range.

Each device represents a memory unit for the hypervisor in control of the memory. The hypervisor cannot reuse a memory unit unless the corresponding memory range is completely offline. For best memory utilization, each device should either be completely online or completely offline.

The **chmem** command with the size parameter automatically chooses the best suited device or devices when setting memory online or offline. The device size depends on the hypervisor and on the amount of total online and offline memory.

## Examples

- The output of this command, shows ranges of adjacent memory blocks with similar attributes.

```
lsmem
Address range Size (MB) State Removable Device
=====
0x0000000000000000-0x000000000fffffffff 256 online no 0
0x0000000010000000-0x000000002fffffffff 512 online yes 1-2
0x0000000030000000-0x000000003fffffffff 256 online no 3
0x0000000040000000-0x000000006fffffffff 768 online yes 4-6
0x0000000070000000-0x00000000fffffffff 2304 offline - 7-15

Memory device size : 256 MB
Memory block size : 256 MB
Total online memory : 1792 MB
Total offline memory: 2304 MB
```

- The output of this command, shows each memory block as a separate range.

```
lsmem -a
Address range Size (MB) State Removable Device
=====
0x0000000000000000-0x000000000fffffffff 256 online no 0
0x0000000010000000-0x000000001fffffffff 256 online yes 1
0x0000000020000000-0x000000002fffffffff 256 online yes 2
0x0000000030000000-0x000000003fffffffff 256 online no 3
0x0000000040000000-0x000000004fffffffff 256 online yes 4
0x0000000050000000-0x000000005fffffffff 256 online yes 5
0x0000000060000000-0x000000006fffffffff 256 online yes 6
0x0000000070000000-0x000000007fffffffff 256 offline - 7
0x0000000080000000-0x000000008fffffffff 256 offline - 8
0x0000000090000000-0x000000009fffffffff 256 offline - 9
0x00000000a0000000-0x00000000afffffffff 256 offline - 10
0x00000000b0000000-0x00000000bfffffffff 256 offline - 11
0x00000000c0000000-0x00000000cfffffffff 256 offline - 12
0x00000000d0000000-0x00000000dfffffffff 256 offline - 13
0x00000000e0000000-0x00000000efffffffff 256 offline - 14
0x00000000f0000000-0x00000000fffffffff 256 offline - 15

Memory device size : 256 MB
Memory block size : 256 MB
Total online memory : 1792 MB
Total offline memory: 2304 MB
```

## lsqeth - List qeth-based network devices

Use this command to display a summary of information about qeth-based network devices.

**Before you begin:** To be able to use this command you must also have installed **qethconf** (see “qethconf - Configure qeth devices” on page 492). You install **qethconf** and **lsqeth** with the **s390utils** RPM.

### Format

#### lsqeth syntax

```

>> lsqeth [-p] [<interface>]

```

Where:

**-p** or **--proc**

displays the interface information in the former `/proc/qeth` format. This option can generate input to tools that expect this particular format.

**<interface>**

limits the output to information about the specified interface only.

**-h** or **--help**

displays a short help text, then exits.

### Examples

- The following command lists information about interface `eth0` in the default format:

```

lsqeth eth0
Device name : eth0

card_type : OSD_100
cdev0 : 0.0.f5a2
cdev1 : 0.0.f5a3
cdev2 : 0.0.f5a4
chpid : B5
online : 1
portname : OSAPORT
portno : 0
route4 : no
route6 : no
checksumming : hw checksumming
state : UP (LAN ONLINE)
priority_queueing : always queue 2
fake_broadcast : 0
buffer_count : 64
layer2 : 0
large_send : no
isolation : none
sniffer : 0

```

- The following command lists information about all qeth-based interfaces in the former `/proc/qeth` format:

## lsqeth

```
lsqeth -p
devices
```

|                                | CHPID | interface | cardtype     | port | chksum | prio-q'ing | rtr4 | rtr6 | lay'2 | cnt |
|--------------------------------|-------|-----------|--------------|------|--------|------------|------|------|-------|-----|
| 0.0.833f/0.0.8340/0.0.8341 xFE | hsi0  |           | HiperSockets | 0    | sw     | always_q_2 | no   | no   | 0     | 128 |
| 0.0.f5a2/0.0.f5a3/0.0.f5a4 xB5 | eth0  |           | OSD_100      | 0    | hw     | always_q_2 | no   | no   | 0     | 64  |
| 0.0.fba2/0.0.fba3/0.0.fba4 xB0 | eth1  |           | OSD_100      | 0    | sw     | always_q_2 | no   | no   | 1     | 64  |

## lsreipl - List IPL and re-IPL settings

Use this command to find out which boot device and which options will be used if you issue the reboot command. You can also display information about the current boot device.

### Format

#### lsreipl syntax

```

▶▶—lsreipl—┐
 └─i─┘

```

Where:

- i** or **--ipl**  
displays the IPL setting.
- v** or **--version**  
displays the version number of **lsreipl** and exits.
- h** or **--help**  
displays an overview of the syntax. Any other parameters are ignored.

By default the re-IPL device is set to the current IPL device. Use the **chreipl** command to change the re-IPL settings.

### Examples

- This example shows the current re-IPL settings:

```

lsreipl
Re-IPL type: fcp
WWPN: 0x500507630300c562
LUN: 0x401040b300000000
Device: 0.0.1700
bootprog: 0
br_lba: 0
Bootparms: ""

```

# lsshut - List the current system shutdown actions

Use this command to see how the Linux instance is configured for the following system shutdown triggers: halt, poff, reboot, restart, and panic. See Chapter 38, “Shutdown actions,” on page 371 for details.

If the action is kdump, a second action might be listed. This second action is the backup action that is taken if kdump fails. See *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607 for details about using kdump.

## Format



- Where:
- h or --help**  
displays a short help text, then exits.
  - v or --version**  
displays the version number of **lsshut** and exits.

## Examples

- To query the configuration issue:

```
lsshut
Trigger Action
=====
Halt stop
Power off vmcmd (LOGOFF)
Reboot reipl
Restart kdump,dump_reipl
Panic kdump,dump_reipl
```

## lstape - List tape devices


This command is used to gather information about CCW-attached tape devices and tape devices attached to the SCSI bus from sysfs (see “Displaying tape information” on page 97) and display it in a summary format.

For information about SCSI tape devices, the command uses the following sources for the information displayed:

- The IBMTape or the open source lin\_tape driver.
- The sg\_inq command from the scsi/sg3\_utils package.
- The st (SCSI tape) device driver in the Linux kernel.

If you use the IBMTape or lin\_tape driver, the sg\_inq utility is required. If sg\_inq is missing, certain information about the IBMTape or lin\_tape driver cannot be displayed.

## Format



Where:

**-s or --shortid**

strips the “0.n.” from the device bus-IDs in the command output. For CCW-attached devices only.

**-t or --type**

limits the output to information about the specified type or types of CCW-attached devices only.

**--ccw-only**

limits the output to information about CCW-attached devices only.

**--scsi-only**

limits the output to information about tape devices attached to the SCSI bus.

**--online | --offline**

limits the output to information about online or offline CCW-attached tape devices only.

## lstape

`<device_bus_id>`

limits the output to information about the specified tape device or devices only.

**--verbose**

For tape devices attached to the SCSI bus only. Prints the serial of the tape as well as information about the FCP connection as an additional text line following each SCSI tape in the list.

**-h** or **--help**

displays a short help text.

**--version**

displays the version of the command.

### Output attributes

The attributes in the output provide this data:

Table 55. Output for *lstape*

| Attribute | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Generic   | SCSI generic device file for the tape drive (for example /dev/sg0). This attribute is empty if the <b>sg_inq</b> command is not available.                                                                                                                                                                                                                                                                                                                                                  |
| Device    | Main device file for accessing the tape drive, for example: <ul style="list-style-type: none"><li>• /dev/st0 for a tape drive attached through the Linux st device driver</li><li>• /dev/sch0 for a medium changer device attached through the Linux changer device driver</li><li>• /dev/IBMchanger0 for a medium changer attached through the IBMtape or lin_tape device driver</li><li>• /dev/IBMtape0 for a tape drive attached through the IBMtape or lin_tape device driver</li></ul> |
| Target    | The ID in Linux used to identify the SCSI device.                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Vendor    | The vendor field from the tape drive.                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Model     | The model field from the tape drive.                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Type      | "Tapedrv" for a tape driver or "changer" for a medium changer.                                                                                                                                                                                                                                                                                                                                                                                                                              |
| State     | The state of the SCSI device in Linux. This is an internal state of the Linux kernel, any state other than "running" can indicate problems.                                                                                                                                                                                                                                                                                                                                                 |
| HBA       | The FCP device to which the tape drive is attached.                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| WWPN      | The WWPN (World Wide Port Name) of the tape drive in the SAN.                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Serial    | The serial number field from the tape drive.                                                                                                                                                                                                                                                                                                                                                                                                                                                |

### Examples

- This command displays information about all tapes found, here one CCW-attached tape and one tape and changer device configured for zFCP:

```
#> lstape
FICON/ESCON tapes (found 1):
TapeNo BusID CuType/Model DevType/Model BlkSize State Op MedState
0 0.0.0480 3480/01 3480/04 auto UNUSED --- UNLOADED

SCSI tape devices (found 2):
Generic Device Target Vendor Model Type State
sg4 IBMchanger0 0:0:0:0 IBM 03590H11 changer running
sg5 IBMtape0 0:0:0:1 IBM 03590H11 tapedrv running
```



If only the generic tape driver (st) and the generic changer driver (ch) are loaded, the output will list those names in the device section:

```
#> lstape
FICON/ESCON tapes (found 1):
TapeNo BusID CuType/Model DevType/Model BlkSize State Op MedState
0 0.0.0480 3480/01 3480/04 auto UNUSED --- UNLOADED

SCSI tape devices (found 2):
Generic Device Target Vendor Model Type State
sg0 sch0 0:0:0:0 IBM 03590H11 changer running
sg1 st0 0:0:0:1 IBM 03590H11 tapedrv running
```

- This command displays information about all available CCW-attached tapes.

```
lstape --ccw-only
TapeNo BusID CuType/Model DevType/DevMod BlkSize State Op MedState
0 0.0.0132 3590/50 3590/11 auto IN_USE --- LOADED
1 0.0.0110 3490/10 3490/40 auto UNUSED --- UNLOADED
2 0.0.0133 3590/50 3590/11 auto IN_USE --- LOADED
3 0.0.012a 3480/01 3480/04 auto UNUSED --- UNLOADED
N/A 0.0.01f8 3480/01 3480/04 N/A OFFLINE --- N/A
```

- This command limits the output to tapes of type 3480 and 3490.

```
lstape -t 3480,3490
TapeNo BusID CuType/Model DevType/DevMod BlkSize State Op MedState
1 0.0.0110 3490/10 3490/40 auto UNUSED --- UNLOADED
3 0.0.012a 3480/01 3480/04 auto UNUSED --- UNLOADED
N/A 0.0.01f8 3480/01 3480/04 N/A OFFLINE --- N/A
```

- This command limits the output to those tapes of type 3480 and 3490 that are currently online.

```
lstape -t 3480,3490 --online
TapeNo BusID CuType/Model DevType/DevMod BlkSize State Op MedState
1 0.0.0110 3490/10 3490/40 auto UNUSED --- UNLOADED
3 0.0.012a 3480/01 3480/04 auto UNUSED --- UNLOADED
```

- This command limits the output to the tape with device bus-ID 0.0.012a and strips the “0.n.” from the device bus-ID in the output.

```
lstape -s 0.0.012a
TapeNo BusID CuType/Model DevType/DevMod BlkSize State Op MedState
3 012a 3480/01 3480/04 auto UNUSED --- UNLOADED
```

- This command limits the output to SCSI devices but gives more details. Note that the serial numbers are only displayed if the **sg\_inq** command is found on the system.

```
#> lstape --scsi-only --verbose
Generic Device Target Vendor Model Type State
HBA WWPN
sg0 st0 0:0:0:1 IBM 03590H11 tapedrv running
 0.0.1708 0x500507630040727b NO/INQ
sg1 sch0 0:0:0:2 IBM 03590H11 changer running
 0.0.1708 0x500507630040727b NO/INQ
```

## lszcrypt - Display zcrypt devices


Use the **lszcrypt** command to display information about cryptographic adapters managed by zcrypt and zcrypt's AP bus attributes. To set the attributes, use “chzcrypt - Modify the zcrypt configuration” on page 408. The following information can be displayed for each cryptographic adapter:

- The card type
- The online status
- The hardware card type
- The hardware queue depth
- The request count

The following AP bus attributes can be displayed:

- The AP domain
- The configuration timer
- The poll thread status

### Format



Where:

**-V, -VV or --verbose**

increases the verbose level for cryptographic adapter information. The maximum verbose level is two (-VV). At verbose level one (-V) card type and online status are displayed. At verbose level two card type, online status, hardware card type, hardware queue depth, and request count are displayed.

**<device ID>**

specifies the cryptographic adapter which will be displayed. A cryptographic adapter can be specified either in decimal notation or hexadecimal notation using a '0x' prefix. If no adapters are specified information about all available adapters will be displayed.

**-b or --bus**

displays the AP bus attributes.

**-h or --help**

displays short information about command usage.

**-v or --version**

displays version information.

### Examples

This section illustrates common uses for **lszcrypt**.

- To display information about all available cryptographic adapters:

```
lszcrypt
```

This displays, for example:

```
card00: CEX2A
card01: CEX2A
card02: CEX2C
card03: CEX2C
card04: CEX2C
card05: CEX2C
card06: CEX3C
card07: CEX3C
card08: CEX3C
card09: CEX3A
card0a: CEX3C
card0b: CEX3A
```

- To display card type and online status of all available cryptographic adapters:

```
lszcrypt -V
```

This displays, for example:

```
card00: CEX2A online
card01: CEX2A online
card02: CEX2C online
card03: CEX2C online
card04: CEX2C online
card05: CEX2C online
card06: CEX3C online
card07: CEX3C online
card08: CEX3C online
card09: CEX3A online
card0a: CEX3C online
card0b: CEX3A online
```

- To display card type, online status, hardware card type, hardware queue depth, and request count for cryptographic adapters 0, 1, 10, and 12 (in decimal notation):

```
lszcrypt -VV 0 1 10 12
```

This displays, for example:

```
card00: CEX2A online hwtype=6 depth=8 request_count=0
card01: CEX2A online hwtype=6 depth=8 request_count=0
card0a: CEX3C online hwtype=9 depth=8 request_count=0
card0c: CEX3A online hwtype=9 depth=8 request_count=0
```

- To display AP bus information:

```
lszcrypt -b
```


This displays, for example:

```
ap_domain=8
ap_interrupts are enabled
config_time=30 (seconds)
poll_thread is disabled
poll_timeout=250000 (nanoseconds)
```

## lszfc - List zfc devices

This command is used to gather information about zfc devices, ports, units, and their associated class devices from sysfs and to display it in a summary format.

### Format



Where:

- H** or **--hosts**  
shows information about hosts.
- P** or **--ports**  
shows information about ports.
- D** or **--devices**  
shows information about SCSI devices.
- a** or **--attributes**  
shows all attributes (implies -V).
- V** or **--verbose**  
shows sysfs paths of associated class and bus devices.
- b** or **--busid** *<device\_bus\_id>*  
limits the output to information about the specified device.
- p** or **--wwpn** *<port\_name>*  
limits the output to information about the specified port name.
- l** or **--lun** *<lun>*  
limits the output to information about the specified LUN.
- s** or **--sysfs** *<mount\_point>*  
specifies the mount point for sysfs.
- v** or **--version**  
displays version information.
- h** or **--help**  
displays a short help text.

## Examples

- This command displays information about all available hosts, ports, and SCSI devices.

```
lszfcp -H -D -P
0.0.3d0c host0
0.0.500c host1
...
0.0.3c0c host5
0.0.3d0c/0x500507630300c562 rport-0:0-0
0.0.3d0c/0x50050763030bc562 rport-0:0-1
0.0.3d0c/0x500507630303c562 rport-0:0-2
0.0.500c/0x50050763030bc562 rport-1:0-0
...
0.0.3c0c/0x500507630303c562 rport-5:0-2
0.0.3d0c/0x500507630300c562/0x4010403200000000 0:0:0:0
0.0.3d0c/0x500507630300c562/0x4010403300000000 0:0:0:1
0.0.3d0c/0x50050763030bc562/0x4010403200000000 0:0:1:0
0.0.3d0c/0x500507630303c562/0x4010403200000000 0:0:2:0
0.0.500c/0x50050763030bc562/0x4010403200000000 1:0:0:0
...
0.0.3c0c/0x500507630303c562/0x4010403200000000 5:0:2:0
```

- This command limits the output to the FCP device with bus ID 0.0.3d0c:

```
lszfcp -D -b 0.0.3d0c
0.0.3d0c/0x500507630300c562/0x4010403200000000 0:0:0:0
0.0.3d0c/0x500507630300c562/0x4010403300000000 0:0:0:1
0.0.3d0c/0x50050763030bc562/0x4010403200000000 0:0:1:0
0.0.3d0c/0x500507630303c562/0x4010403200000000 0:0:2:0
```

## mon\_fsstatd – Monitor z/VM guest file system size

The **mon\_fsstatd** command is a user space daemon that collects physical file system size data from Linux on z/VM and periodically writes the data as defined records to the z/VM monitor stream using the monwriter character device driver. You can start the daemon with a service script `/etc/init.d/mon_statd` or call it manually. When it is called with the service utility, it reads the configuration file `/etc/sysconfig/mon_statd`.

### Before you begin:


- Install the monwriter device driver and set up z/VM to start the collection of monitor sample data. See Chapter 14, “Writing z/VM monitor records,” on page 203 for information about the setup for and usage of the monwriter device driver.
- Customize the configuration file `/etc/sysconfig/mon_statd` if you plan to call it with the service utility.

## Format

You can run the **mon\_fsstatd** command in two ways:

- Calling `mon_statd` with the service utility. This method will read the configuration file `/etc/sysconfig/mon_statd`. The `mon_statd` service script also controls other daemons, such as `mon_procd`.
- Calling `mon_fsstatd` from a command line.

### Service utility syntax



Where:

#### **start**

enables monitoring of guest file system size, using the configuration in `/etc/sysconfig/mon_statd`.

#### **stop**

disable monitoring of guest file system size.

#### **status**

show current status of guest file system size monitoring.

#### **restart**

stops and restarts monitoring. Useful to re-read the configuration file when it was changed.

### Configuration file keywords:

**FSSTAT\_INTERVAL="*<n>*"**


Specifies the desired sampling interval in seconds.

**FSSTAT="yes | no"**

Specifies whether to enable the mon\_fsstatd daemon. Set to "yes" to enable the daemon. Anything other than "yes" will be interpreted as "no".

## Command-line syntax

### mon\_fsstatd command-line syntax



Where:

- i or --interval <seconds>**  
specifies the desired sampling interval in seconds.
- a or --attach**  
runs the daemon in the foreground.
- h or --help**  
displays help information for the command.
- v or --version**  
displays version information for the command.

## Examples

### Examples of service utility use

Example configuration file for mon\_statd (/etc/sysconfig/mon\_statd).

- This example sets the sampling interval to 30 seconds and enables the mon\_fsstatd daemon:

```

FSSTAT_INTERVAL="30"
FSSTAT="yes"

```

Example of mon\_statd use (note that your output may look different and include messages for other daemons, such as mon\_procd):

- To enable guest file system size monitoring:

```

> service mon_statd start
...
Starting mon_fsstatd: [OK]
...

```

- To display the status:

```

> service mon_statd status
...
mon_fsstatd (pid 1075, interval: 30) is running.
...

```

- To disable guest file system size monitoring:

```
> service mon_statd stop
...
Stopping mon_fsstatd: [OK]
...
```

- To display the status again and check that monitoring is now disabled:

```
> service mon_statd status
...
mon_fsstatd is not running
...
```

- To restart the daemon and re-read the configuration file:

```
> service mon_statd restart
...
stopping mon_fsstatd: [OK]
starting mon_fsstatd: [OK]
...
```

## Examples of command-line use

- To start mon\_fsstatd with default setting:

```
> mon_fsstatd
```

- To start mon\_fsstatd with a sampling interval of 30 seconds:

```
> mon_fsstatd -i 30
```

- To start mon\_fsstatd and have it run in the foreground:

```
> mon_fsstatd -a
```

- To start mon\_fsstatd with a sampling interval of 45 seconds and have it run in the foreground:

```
> mon_fsstatd -a -i 45
```

## Usage

### Processing monitor data

The feature writes physical file system size data for Linux on z/VM to the z/VM monitor stream. The following is the format of the file system size data that is passed to the z/VM monitor stream. One sample monitor record is written for each physical file system mounted at the time of the sample interval. The monitor data in each record contains a header (a time stamp, the length of the data, and an offset) followed by the file system data (as obtained from statvfs). The file system data fields begin with "fs\_".

Table 56. File system size data format

| Type  | Name        | Description                                                                                               |
|-------|-------------|-----------------------------------------------------------------------------------------------------------|
| __u64 | time_stamp  | Time at which the file system data was sampled.                                                           |
| __u16 | data_len    | Length of data following the header.                                                                      |
| __u16 | data_offset | Offset from start of the header to start of file system data (that is, to the fields beginning with fs_). |



Table 56. File system size data format (continued)

| Type               | Name        | Description                                                                                                                                                                                       |
|--------------------|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| __u16              | fs_name_len | Length of the file system name. If the file system name was too long to fit in the monitor record, this is the length of the portion of the name that is contained in the monitor record.         |
| char [fs_name_len] | fs_name     | The file system name. If the name is too long to fit in the monitor record, the name is truncated to the length in the fs_name_len field.                                                         |
| __u16              | fs_dir_len  | Length of the mount directory name. If the mount directory name was too long to fit in the monitor record, this is the length of the portion of the name that is contained in the monitor record. |
| char[fs_dir_len]   | fs_dir      | The mount directory name. If the name is too long to fit in the monitor record, the name is truncated to the length in the fs_dir_len field.                                                      |
| __u16              | fs_type_len | Length of the mount type. If the mount type is too long to fit in the monitor record, this is the length of the portion that is contained in the monitor record.                                  |
| char[fs_type_len]  | fs_type     | The mount type (as returned by getmntent). If the type is too long to fit in the monitor record, the type is truncated to the length in the fs_type_len field.                                    |
| __u64              | fs_bsize    | File system block size.                                                                                                                                                                           |
| __u64              | fs_fsize    | Fragment size.                                                                                                                                                                                    |
| __u64              | fs_blocks   | Total data blocks in file system.                                                                                                                                                                 |
| __u64              | fs_bfree    | Free blocks in fs.                                                                                                                                                                                |
| __u64              | fs_bavail   | Free blocks avail to non-superuser.                                                                                                                                                               |
| __u64              | fs_files    | Total file nodes in file system.                                                                                                                                                                  |
| __u64              | fs_ffree    | Free file nodes in fs.                                                                                                                                                                            |
| __u64              | fs_favail   | Free file nodes available to non-superuser.                                                                                                                                                       |
| __u64              | fs_flag     | Mount flags.                                                                                                                                                                                      |

Use the time\_stamp to correlate all file systems that were sampled in a given interval.

### Reading the monitor data

As described in the monwriter documentation, all records written to the z/VM monitor stream begin with a product identifier. The product ID is a 16-byte structure of the form pppppppffnvvrrmm, where for records written by mon\_fsstatd, these values will be:

#### PPPPPPP

is a fixed ASCII string LNXAPPL.

**ff** is the application number for mon\_fsstatd = x'0001'.

**n** is the record number = x'00'.

**vv** is the version number = x'0000'.

**rr** is reserved for future use and should be ignored.

**mm** is reserved for mon\_fsstatd and should be ignored.

**Note:** Though the mod\_level field (mm) of the product ID will vary, there is no relationship between any particular mod\_level and file system. The mod\_level field should be ignored by the reader of this monitor data.

There are many tools available to read z/VM monitor data. One such tool is the Linux monreader character device driver. See Chapter 15, “Reading z/VM monitor records” for more information about monreader.

### Further information

- See *z/VM Saved Segments Planning and Administration*, SC24-6229 for general information about DCSSs.
- See *z/VM CP Programming Services*, SC24-6179 for information about the DIAG x'DC' instruction.
- See *z/VM CP Commands and Utilities Reference*, SC24-6175 for information about the CP commands.
- See *z/VM Performance*, SC24-6208 for information about monitor APPLDATA.

## mon\_procd – Monitor Linux on z/VM

The **mon\_procd** command is a user space daemon that writes system summary information and information of each process for up to 100 concurrent processes that are managed by an instance of Linux on z/VM to the z/VM monitor stream using the monwriter character device driver. You can start the daemon with a service script `/etc/init.d/mon_statd` or call it manually. When it is called with the service utility, it reads the configuration file `/etc/sysconfig/mon_statd`.

### Before you begin:

- Install the monwriter device driver and set up z/VM to start the collection of monitor sample data. See Chapter 14, “Writing z/VM monitor records,” on page 203 for information about the setup for and usage of the monwriter device driver.
- Customize the configuration file `/etc/sysconfig/mon_statd` if you plan to call it with the service utility.
- The Linux instance on which the proc\_mond daemon runs requires a z/VM guest virtual machine with the `OPTION APPLMON` statement in the CP directory entry.


## Format

You can run the **mon\_procd** command in two ways:

- Calling **mon\_procd** with the service utility. Use this method when you have the `mon_statd` service script installed in `/etc/init.d`. This method will read the configuration file `/etc/sysconfig/mon_statd`. The `mon_statd` service script also controls other daemons, such as `mon_fsstatd`.
- Calling **mon\_procd** manually from a command line.

### Service utility syntax

#### mon\_statd service utility syntax



Where:

#### start

enables monitoring of guest process data, using the configuration in `/etc/sysconfig/mon_statd`.

#### stop

disables monitoring of guest process data.

#### status

shows current status of guest process data monitoring.

#### restart


stops and restarts guest process data monitoring. Useful in order to re-read the configuration file when it has changed.

**Configuration file keywords:****PROC\_INTERVAL="*<n>*"**

Specifies the desired sampling interval in seconds.

**PROC="yes | no"**

Specifies whether to enable the mon\_procd daemon. Set to "yes" to enable the daemon. Anything other than "yes" will be interpreted as "no".

**Command-line syntax****mon\_procd command-line syntax**

Where:

**-i or --interval *<seconds>***

specifies the desired sampling interval in seconds.

**-a or --attach**

runs the daemon in the foreground.

**-h or --help**

displays help information for the command.

**-v or --version**

displays version information for the command.

**Examples****Examples of service utility use**

Example configuration file for mon\_statd (/etc/sysconfig/mon\_statd).

- This example sets the sampling interval to 30 seconds and enables the mon\_procd:

```

PROC_INTERVAL="30"
PROC="yes"

```

Example of mon\_statd use (note that your output might look different and include messages for other daemons, such as mon\_fsstatd):

- To enable guest process data monitoring:

```

> service mon_statd start
...
Starting mon_procd: [OK]
...

```

- To display the status:

```

> service mon_statd status
...
mon_procd (pid 1075, interval: 30) is running.
...

```

- To disable guest process data monitoring:

```
> service mon_statd stop
...
Stopping mon_procd: [OK]
...
```

- To display the status again and check that monitoring is now disabled:

```
> service mon_statd status
...
mon_procd is not running
...
```

- To restart the daemon and re-read the configuration file:

```
> service mon_statd restart
...
stopping mon_procd: [OK]
starting mon_procd: [OK]
...
```

## Examples of command-line use

- To start mon\_procd with default setting:

```
> mon_procd
```

- To start mon\_procd with a sampling interval of 30 seconds:

```
> mon_procd -i 30
```

- To start mon\_procd and have it run in the foreground:

```
> mon_procd -a
```

- To start mon\_procd with a sampling interval of 45 seconds and have it run in the foreground:

```
> mon_procd -a -i 45
```

## Usage

### Processing monitor data

The mon\_procd daemon writes system summary information and information of each process for up to 100 processes currently being managed by an instance of Linux on z/VM to the z/VM monitor stream. At the time of the sample interval, one sample monitor record is written for system summary data, then one sample monitor record is written for each process for up to 100 processes currently being managed by the Linux instance. If more than 100 processes exist in a Linux instance at a given time, processes are sorted by the sum of CPU and memory usage percentage values and only the top 100 processes' data is written to the z/VM monitor stream.

The monitor data in each record begins with a header (a time stamp, the length of the data, and the offset). The data after the header depends on the field "record number" of the 16-bit product ID and can be summary data or process data. See "Reading the monitor data" on page 488 for details. The following is the format of system summary data passed to the z/VM monitor stream.

Table 57. System summary data format

| Type    | Name          | Description                                                                                                  |
|---------|---------------|--------------------------------------------------------------------------------------------------------------|
| __u64   | time_stamp    | Time at which the process data was sampled.                                                                  |
| __u16   | data_len      | Length of data following the header.                                                                         |
| __u16   | data_offset   | Offset from start of the header to the start of the process data.                                            |
| __u64   | uptime        | Uptime of the Linux instance.                                                                                |
| __u32   | users         | Number of users on the Linux instance.                                                                       |
| char[6] | loadavg_1     | Load average over the last one minute.                                                                       |
| char[6] | loadavg_5     | Load average over the last five minutes.                                                                     |
| char[6] | loadavg_15    | Load average over the last 15 minutes.                                                                       |
| __u32   | task_total    | total number of tasks on the Linux instance.                                                                 |
| __u32   | task_running  | Number of running tasks.                                                                                     |
| __u32   | task_sleeping | Number of sleeping tasks.                                                                                    |
| __u32   | task_stopped  | Number of stopped tasks.                                                                                     |
| __u32   | task_zombie   | Number of zombie tasks.                                                                                      |
| __u32   | num_cpus      | Number of CPUs.                                                                                              |
| __u16   | puser         | A number representing (100 * percentage of total CPU time used for normal processes executing in user mode). |
| __u16   | pnice         | A number representing (100 * percentage of total CPU time used for niced processes executing in user mode).  |
| __u16   | psystem       | A number representing (100 * percentage of total CPU time used for processes executing in kernel mode).      |
| __u16   | pidle         | A number representing (100 * percentage of total CPU idle time).                                             |
| __u16   | piowait       | A number representing (100 * percentage of total CPU time used for I/O wait).                                |
| __u16   | pirq          | A number representing (100 * percentage of total CPU time used for interrupts).                              |
| __u16   | psoftirq      | A number representing (100 * percentage of total CPU time used for softirqs).                                |
| __u16   | psteal        | A number representing (100 * percentage of total CPU time spent in stealing).                                |
| __u64   | mem_total     | Total memory in KB.                                                                                          |
| __u64   | mem_used      | Used memory in KB.                                                                                           |
| __u64   | mem_free      | Free memory in KB.                                                                                           |
| __u64   | mem_buffers   | Memory in buffer cache in KB.                                                                                |
| __u64   | mem_pgpgin    | Data read from disk in KB.                                                                                   |
| __u64   | mem_pgpgout   | Data written to disk in KB.                                                                                  |
| __u64   | swap_total    | Total swap memory in KB.                                                                                     |
| __u64   | swap_used     | Used swap memory in KB.                                                                                      |
| __u64   | swap_free     | Free swap memory in KB.                                                                                      |

Table 57. System summary data format (continued)

| Type  | Name         | Description               |
|-------|--------------|---------------------------|
| __u64 | swap_cached  | Cached swap memory in KB. |
| __u64 | swap_pswpin  | Pages swapped in.         |
| __u64 | swap_pswpout | Pages swapped out.        |

The following is the format of a process information data passed to the z/VM monitor stream.

Table 58. Process data format

| Type            | Name        | Description                                                                                                 |
|-----------------|-------------|-------------------------------------------------------------------------------------------------------------|
| __u64           | time_stamp  | Time at which the process data was sampled.                                                                 |
| __u16           | data_len    | Length of data following the header.                                                                        |
| __u16           | data_offset | Offset from start of the header to the start of the process data.                                           |
| __u32           | pid         | ID of the process.                                                                                          |
| __u32           | ppid        | ID of the process parent.                                                                                   |
| __u32           | euid        | Effective user ID of the process owner.                                                                     |
| __u16           | tty         | Device number of the controlling terminal or 0.                                                             |
| __s16           | priority    | Priority of the process                                                                                     |
| __s16           | nice        | Nice value of the process.                                                                                  |
| __u32           | processor   | Last used processor.                                                                                        |
| __u16           | pcpu        | A number representing (100 * percentage of the elapsed cpu time used by the process since last sampling).   |
| __u16           | pmem        | A number representing (100 * percentage of physical memory used by the process).                            |
| __u64           | total_time  | Total cpu time the process has used.                                                                        |
| __u64           | ctotal_time | Total cpu time the process and its dead children has used.                                                  |
| __u64           | size        | Total virtual memory used by the task in KB.                                                                |
| __u64           | swap        | Swapped out portion of the virtual memory in KB.                                                            |
| __u64           | resident    | Non-swapped physical memory used by the task in KB.                                                         |
| __u64           | trs         | Physical memory devoted to executable code in KB.                                                           |
| __u64           | drs         | Physical memory devoted to other than executable code in KB.                                                |
| __u64           | share       | Shared memory used by the task in KB.                                                                       |
| __u64           | dt          | Dirty page count.                                                                                           |
| __u64           | majflt      | Number of major page faults occurred for the process.                                                       |
| char            | state       | Status of the process.                                                                                      |
| __u32           | flags       | The process current scheduling flags.                                                                       |
| __u16           | ruser_len   | Length of real user name of the process owner and should not be larger than 64.                             |
| char[ruser_len] | ruser       | Real user name of the process owner. If the name is longer than 64, the name is truncated to the length 64. |

Table 58. Process data format (continued)

| Type                   | Name         | Description                                                                                                               |
|------------------------|--------------|---------------------------------------------------------------------------------------------------------------------------|
| __u16                  | euser_len    | Length of effective user name of the process owner and should not be larger than 64.                                      |
| char[euser_len]        | euser        | Effective user name of the process owner. If the name is longer than 64, the name is truncated to the length 64.          |
| __u16                  | egroup_len   | Length of effective group name of the process owner and should not be larger than 64.                                     |
| char[egroup_len]       | egroup       | Effective group name of the process owner. If the name is longer than 64, the name is truncated to the length 64.         |
| __u16                  | wchan_len    | Length of sleeping in function's name and should not be larger than 64.                                                   |
| char[wchan_len]        | wchan_name   | Name of sleeping in function or '-'. If the name is longer than 64, the name is truncated to the length 64.               |
| __u16                  | cmd_len      | Length of command name or program name used to start the process and should not be larger than 64.                        |
| char[cmd_len]          | cmd          | Command or program name used to start the process. If the name is longer than 64, the name is truncated to the length 64. |
| __u16                  | cmd_line_len | Length of command line used to start the process and should not be larger than 1024.                                      |
| char<br>[cmd_line_len] | cmd_line     | Command line used to start the process. If the name is longer than 1024, the name is truncated to the length 1024.        |

Use the time\_stamp to correlate all process information that were sampled in a given interval.

## Reading the monitor data

As described in the monwriter documentation, all records written to the z/VM monitor stream begin with a product identifier. The product ID is a 16-byte structure of the form pppppppffnvvrrmm, where for records written by mon\_procd, these values will be:

### PPPPPPP

is a fixed ASCII string LNXAPPL.

**ff** is the application number for mon\_procd = x'0002'.

**n** is the record number as follows:

- x'00' indicates summary data.
- x'01' indicates process data.

**vv** is the version number = x'0000'.

**rr** is the release number, which can be used to mark different versions of process APPLDATA records.

**mm** is reserved for mon\_procd and should be ignored.

**Note:** Though the mod\_level field (mm) of the product ID will vary, there is no relationship between any particular mod\_level and process. The mod\_level field should be ignored by the reader of this monitor data.



This item uses at most 101 monitor buffer records from the monwriter device driver. Since a maximum number of buffers is set when a monwriter module is loaded, the maximum number of buffers must not be less than the sum of buffer records used by all monwriter applications.

There are many tools available to read z/VM monitor data. One such tool is the Linux monreader character device driver. See Chapter 15, “Reading z/VM monitor records” for more information about monreader.

### Further information

- See *z/VM Saved Segments Planning and Administration*, SC24-6229 for general information about DCSSs.
- See *z/VM CP Commands and Utilities Reference*, SC24-6175 for information about the CP commands.
- See *z/VM Performance*, SC24-6208 for information about monitor APPLDATA.


## qetharp - Query and purge OSA and HiperSockets ARP data

Use the **qetharp** command to query and purge address data such as MAC and IP addresses from the ARP cache of the OSA and HiperSockets hardware. For OSA hardware, **qetharp** can also modify the cache.

**Before you begin:**

- The **qetharp** command applies only to devices in layer 3 mode (see “Layer 2 and layer 3” on page 114).
- The **qetharp** command supports IPv6 only for real HiperSockets and z/VM guest LAN HiperSockets.
- ForHiperSockets, z/VM guest LAN and VSWITCH interfaces, the **qetharp** command supports only the **--query** option.

### Format



Where:

**-q** or **--query**  
shows the address resolution protocol (ARP) information about the specified network interface. Depending on the device that the interface has been assigned to, this information is obtained from an OSA feature's ARP cache or a HiperSockets ARP cache.

The default command output shows symbolic host names and only includes numerical addresses for host names that cannot be resolved. Use the **-n** option to show numerical addresses instead of host names.

By default, **qetharp** omits IPv6 related information. Use the **-6** option to include IPv6 information for HiperSockets.

**-n** or **--numeric**  
shows numeric addresses instead of trying to determine symbolic host names. This option can only be used in conjunction with the **-q** option.

**-c** or **--compact**  
limits the output to numeric addresses only. This option can only be used in conjunction with the **-q** option.

**-6** or **--ipv6**  
includes IPv6 information for HiperSockets. For real HiperSockets, shows the IPv6 addresses. For guest LAN HiperSockets, shows the IPv6 to MAC address mappings. This option can only be used with the **-q** option.

**<interface>**  
specifies the qeth interface to which the command applies.

- a** or **--add**  
adds a static ARP entry to the OSA adapter card. Static entries can be deleted with **-d**.
- d** or **--delete**  
deletes a static ARP entry from the OSA adapter card. Static entries are created with **-a**.
- p** or **--purge**  
flushes the ARP cache of the OSA. The cache contains dynamic ARP entries, which the OSA adapter creates through ARP queries. After flushing the cache, the OSA adapter creates new dynamic entries. This option works only with OSA devices. qetharp returns immediately.
- i** *<ip\_address>* or **--ip** *<ip\_address>*  
specifies the IP address to be added to or removed from the OSA adapter card.
- m** *<mac\_address>* or **--mac** *<mac\_address>*  
specifies the MAC address to be added to the OSA adapter card.
- v** or **--version**  
shows version information and exits
- h** or **--help**  
displays usage information and exits. To view the man page, enter **man qetharp**.

## Examples

- Show all ARP entries of the OSA defined as eth0:

```
qetharp -q eth0
```

- Show all ARP entries of the HiperSockets interface defined as hsi0 including IPv6 entries:

```
qetharp -6q hsi0
```

- Show all ARP entries of the OSA defined as eth0, without resolving host names:

```
qetharp -nq eth0
```

- Show all ARP entries including IPv6 entries of the HiperSockets interface defined as hsi0, including IPv6 entries, without resolving host names:

```
qetharp -n6q hsi0
```

- Flush the OSA ARP cache for eth0:

```
qetharp -p eth0
```

- Add a static entry for eth0 and IP address 1.2.3.4 to the OSA ARP cache, using MAC address aa:bb:cc:dd:ee:ff:

```
qetharp -a eth0 -i 1.2.3.4 -m aa:bb:cc:dd:ee:ff
```

- Delete the static entry for eth0 and IP address 1.2.3.4 from the OSA ARP cache.

```
qetharp -d eth0 -i 1.2.3.4
```

## qethconf - Configure qeth devices


The qethconf configuration tool is a bash shell script that simplifies configuring qeth devices (see Chapter 8, “qeth device driver for OSA-Express (QDIO) and HiperSockets,” on page 109) for:

- IP address takeover
- VIPA (virtual IP address)
- Proxy ARP

You cannot use this command in conjunction with the layer2 option.

From the arguments that are specified, **qethconf** assembles the function command and redirects it to the corresponding sysfs attributes. You can also use **qethconf** to list the already defined entries.

### Format



The qethconf command has these function keywords:

**ipa**  
configures qeth for IP address takeover (IPA).

**vipa**  
configures qeth for virtual IP address (VIPA).

**parp** or **rxip**  
configures qeth for proxy ARP.

The qethconf command has these action keywords:

**add**  
adds an IP address or address range.

**del**  
deletes an IP address or address range.

**inv4**  
inverts the selection of address ranges for IPv4 address takeover. This makes the list of IP addresses that has been specified with qethconf add and qethconf del an exclusion list.

**inv6**  
inverts the selection of address ranges for IPv6 address takeover. This makes the list of IP addresses that has been specified with qethconf add and qethconf del an exclusion list.

**list**

lists existing definitions for specified qeth function.

**list\_all**

lists existing definitions for IPA, VIPA, and proxy ARP.

**<ip\_addr>**

IP address. Can be specified in one of these formats:

- IP version 4 format, for example, 192.168.10.38
- IP version 6 format, for example, FE80::1:800:23e7:f5db
- 8- or 32-character hexadecimals prefixed with -x, for example, -xc0a80a26

**<mask\_bits>**

specifies the number of bits that are set in the network mask. Allows you to specify an address range.

**Example:** A *<mask\_bits>* of 24 corresponds to a network mask of 255.255.255.0.

**<interface>**

specifies the name of the interface associated with the specified address or address range.

**list\_msg**

lists **qethconf** messages and explanations.

**-h or --help**

displays help information.

**-v or --version**

displays version information.

## Examples

- List existing proxy ARP definitions:

```
qethconf parp list
parp add 1.2.3.4 eth0
```

- Assume responsibility for packages destined for 1.2.3.5:

```
qethconf parp add 1.2.3.5 eth0
qethconf: Added 1.2.3.5 to /sys/class/net/eth0/device/rxip/add4.
qethconf: Use "qethconf parp list" to check for the result
```

Confirm the new proxy ARP definitions:

```
qethconf parp list
parp add 1.2.3.4 eth0
parp add 1.2.3.5 eth0
```

- Configure eth0 for IP address takeover for all addresses that start with 192.168.10:

```
qethconf ipa add 192.168.10.0/24 eth0
qethconf: Added 192.168.10.0/24 to /sys/class/net/eth0/device/ipa_takeover/add4.
qethconf: Use "qethconf ipa list" to check for the result
```

Display the new IP address takeover definitions:

## qethconf

```
qethconf ipa list
ipa add 192.168.10.0/24 eth0
```

- Configure VIPA for eth1:

```
qethconf vipa add 10.99.3.3 eth1
qethconf: Added 10.99.3.3 to /sys/class/net/eth1/device/vipa/add4.
qethconf: Use "qethconf vipa list" to check for the result
```

Display the new VIPA definitions:

```
qethconf vipa list
vipa add 10.99.3.3 eth1
```

- List all existing IPA, VIPA, and proxy ARP definitions.


```
qethconf list_all
parp add 1.2.3.4 eth0
parp add 1.2.3.5 eth0
ipa add 192.168.10.0/24 eth0
vipa add 10.99.3.3 eth1
```

## scsi\_logging\_level - Set and get the SCSI logging level

This command is used to create, set, or get the SCSI logging level.

The SCSI logging feature is controlled by a 32 bit value – the SCSI logging level. This value is divided into 3-bit fields describing the log level of a specific log area. Due to the 3-bit subdivision, setting levels or interpreting the meaning of current levels of the SCSI logging feature is not trivial. The `scsi_logging_level` script helps with both tasks.

### Format



Where:

- a** or **--all** *<level>*  
specifies value for all SCSI\_LOG fields.
- E** or **--error** *<level>*  
specifies SCSI\_LOG\_ERROR.
- T** or **--timeout** *<level>*  
specifies SCSI\_LOG\_TIMEOUT.
- S** or **--scan** *<level>*  
specifies SCSI\_LOG\_SCAN.
- M** or **--midlevel** *<level>*  
specifies SCSI\_LOG\_MLQUEUE and SCSI\_LOG\_MLCOMPLETE.
- mlqueue** *<level>*  
specifies SCSI\_LOG\_MLQUEUE.
- mlcomplete** *<level>*  
specifies SCSI\_LOG\_MLCOMPLETE.
- L** or **--lowlevel** *<level>*  
specifies SCSI\_LOG\_LLQUEUE and SCSI\_LOG\_LLCOMPLETE.

## scsi\_logging\_level

- llqueue** *<level>*  
specifies SCSI\_LOG\_LLQUEUE.
- llcomplete** *<level>*  
specifies SCSI\_LOG\_LLCOMPLETE.
- H** or **--highlevel** *<level>*  
specifies SCSI\_LOG\_HLQUEUE and SCSI\_LOG\_HLCOMPLETE.
- hlqueue** *<level>*  
specifies SCSI\_LOG\_HLQUEUE.
- hlcomplete** *<level>*  
specifies SCSI\_LOG\_HLCOMPLETE.
- I** or **--ioctl** *<level>*  
specifies SCSI\_LOG\_IOCTL.
- v** or **--version**  
displays version information.
- h** or **--help**  
displays help text.
- s** or **--set**  
creates and sets the logging level as specified on the command line.
- g** or **--get**  
gets the current logging level.
- c** or **--create**  
creates the logging level as specified on the command line.

You can specify several SCSI\_LOG fields by using several options. When multiple options specify the same SCSI\_LOG field the most specific option has precedence.

## Examples

- This command prints the logging word of the SCSI logging feature and each logging level.

```
#> scsi_logging_level -g
Current scsi logging level:
dev.scsi.logging_level = 0
SCSI_LOG_ERROR=0
SCSI_LOG_TIMEOUT=0
SCSI_LOG_SCAN=0
SCSI_LOG_MLQUEUE=0
SCSI_LOG_MLCOMPLETE=0
SCSI_LOG_LLQUEUE=0
SCSI_LOG_LLCOMPLETE=0
SCSI_LOG_HLQUEUE=0
SCSI_LOG_HLCOMPLETE=0
SCSI_LOG_IOCTL=0
```

- This command sets all logging levels to 3:



```
#> scsi_logging_level -s -a 3
New scsi logging level:
dev.scsi.logging_level = 460175067
SCSI_LOG_ERROR=3
SCSI_LOG_TIMEOUT=3
SCSI_LOG_SCAN=3
SCSI_LOG_MLQUEUE=3
SCSI_LOG_MLCOMPLETE=3
SCSI_LOG_LLQUEUE=3
SCSI_LOG_LLCOMPLETE=3
SCSI_LOG_HLQUEUE=3
SCSI_LOG_HLCOMPLETE=3
SCSI_LOG_IOCTL=3
```

- This command sets SCSI\_LOG\_HLQUEUE=3, SCSI\_LOG\_HLCOMPLETE=2 and assigns all other SCSI\_LOG fields the value 1.

```
scsi_logging_level --hlqueue 3 --highlevel 2 --all 1 -s
New scsi logging level:
dev.scsi.logging_level = 174363209
SCSI_LOG_ERROR=1
SCSI_LOG_TIMEOUT=1
SCSI_LOG_SCAN=1
SCSI_LOG_MLQUEUE=1
SCSI_LOG_MLCOMPLETE=1
SCSI_LOG_LLQUEUE=1
SCSI_LOG_LLCOMPLETE=1
SCSI_LOG_HLQUEUE=3
SCSI_LOG_HLCOMPLETE=2
SCSI_LOG_IOCTL=1
```

---

## tape390\_crypt - manage tape encryption

Use this command to enable and disable tape encryption for a channel attached tape device, as well as to specify key encrypting keys (KEK) by means of labels or hashes.

For 3592 tape devices, it is possible to write data in an encrypted format. The encryption keys are stored on an encryption key manager (EKM) server, which can run on any machine with TCP/IP and Java support. The EKM communicates with the tape drive over the tape control unit using TCP/IP. The control unit acts as a proxy and forwards the traffic between the tape drive and the EKM. This type of setup is called out-of-band control-unit based encryption.

The EKM creates a data key that encrypts data. The data key itself is encrypted with KEKs and is stored in so called external encrypted data keys (EEDKs) on the tape medium.

You can store up to two EEDKs on the tape medium. The advantage of having two EEDKs is that one EEDK can contain a locally available KEK and the other can contain the public KEK of the location or company to where the tape is to be transferred. Then the tape medium can be read in both locations.

When the tape device is mounted, the tape drive sends the EEDKs to the EKM, which tries to unwrap one of the two EEDKs and sends back the extracted data key to the tape drive.

Linux can address KEKs by specifying either hashes or labels. Hashes and labels are stored in the EEDKs.



**Note:** If a tape has been encrypted, it cannot be used for IPL.

### Prerequisites

To use tape encryption you need:

- A 3592 crypto-enabled tape device and control unit configured as system-managed encryption.
- A crypto-enabled 3590 channel-attached tape device driver. See Chapter 6, “Channel-attached tape device driver,” on page 91.
- A key manager. See *Encryption Key Manager Component for the Java(TM) Platform Introduction, Planning, and User's Guide*, GA76-0418 for more information.

### Format

**tape390\_crypt syntax****Keys:****Notes:**

- 1 The -k or --key operand can be specified maximally twice.

Where:

**-q or --query**

displays information about the tape's encryption status. If encryption is active and the medium is encrypted, additional information about the encryption keys is displayed.

**-e or --encryption**

sets tape encryption on or off.

**-k or --key**

sets tape encryption keys. You can only specify the -k option if the tape medium is loaded and rewound. While processing the -k option, the tape medium is initialized and all previous data contained on the tape medium is lost.

You can specify the -k option twice, because the tape medium can store two EEDKs. If you specify the -k option once, two identical EEDKs are stored.

**<value>**

specifies the key encrypting key (KEK), which can be up to 64 characters long. The keywords **label** or **hash** specify how the KEK in **<value>** is to be stored on the tape medium. The default store type is **label**.

**-d or --delimiter**

specifies the character that separates the KEK in **<value>** from the store type (label or hash). The default delimiter is ":" (colon).

**<char>**

is a character separating the KEK in **<value>** from the store type (label or hash).

**-f or --force**

specifies that no prompt message is to be issued before writing the KEK information and initializing the tape medium.

**<node>**

specifies the device node of the tape device.

## tape390\_crypt

### **-h** or **--help**

displays help text. For more information, enter the command `man tape390_crypt`.

### **-v** or **--version**

displays information about the version.

## Examples

This example shows a query of tape device `/dev/ntibm0`. Initially, encryption for this device is off. Encryption is then turned on, and the status is queried again.

```
tape390_crypt -q /dev/ntibm0
ENCRYPTION: OFF
MEDIUM: NOT ENCRYPTED

tape390_crypt -e on /dev/ntibm0

tape390_crypt -q /dev/ntibm0
ENCRYPTION: ON
MEDIUM: NOT ENCRYPTED
```

Then two keys are set, one in label format and one in hash format. The status is queried and there is now additional output for the keys.

```
tape390_crypt -k my_first_key:label -k my_second_key:hash /dev/ntibm0
---->> ATTENTION! <<----
All data on tape /dev/ntibm0 will be lost.
Type "yes" to continue: yes
SUCCESS: key information set.

tape390_crypt -q /dev/ntibm0
ENCRYPTION: ON
MEDIUM: ENCRYPTED
KEY1:
 value: my_first_key
 type: label
 ontape: label
KEY2:
 value: my_second_key
 type: label
 ontape: hash
```

## Usage scenarios

The following scenarios illustrate the most common use of tape encryption. In all examples `/dev/ntibm0` is used as the tape device.

### Using default keys for encryption:

1. Load the cartridge. If the cartridge is already loaded:
  - Switch encryption off:  
`tape390_crypt -e off /dev/ntibm`
  - Rewind:  
`mt -f /dev/ntibm0 rewind`
2. Switch encryption on:  
`tape390_crypt -e on /dev/ntibm0`
3. Write data.

### Using specific keys for encryption:

1. Load the cartridge. If the cartridge is already loaded, rewind:  
`mt -f /dev/ntibm0 rewind`

2. Switch encryption on:  
`tape390_crypt -e on /dev/ntibm0`
3. Set new keys:  
`tape390_crypt -k key1 -k key2 /dev/ntibm0`
4. Write data.

**Writing unencrypted data:**

1. Load the cartridge. If the cartridge is already loaded, rewind:  
`mt -f /dev/ntibm0 rewind`
2. If encryption is on, switch encryption off:  
`tape390_crypt -e off /dev/ntibm0`
3. Write data.

**Appending new files to an encrypted cartridge:**

1. Load the cartridge
2. Switch encryption on:  
`tape390_crypt -e on /dev/ntibm0`
3. Position the tape.
4. Write data.


**Reading an encrypted tape:**

1. Load the cartridge
2. Switch encryption on:  
`tape390_crypt -e on /dev/ntibm0`
3. Read data.

## tape390\_display - display messages on tape devices and load tapes

This command is used to display messages on a physical tape device's display unit, optionally in conjunction with loading a tape.

### Format



Where:

#### **-l or --load**

instructs the tape unit to load the next indexed tape from the automatic tape loader (if installed); ignored if there is no loader installed or if the loader is not in “system” mode. The loader “system” mode allows the operating system to handle tape loads.

#### **-t or --type**

The possible values have the following meanings:

##### **standard**

displays the message or messages until the physical tape device processes the next tape movement command.

##### **load**

displays the message or messages until a tape is loaded; if a tape is already loaded, the message is ignored.

##### **unload**

displays the message or messages while a tape is loaded; if no tape is loaded, the message is ignored.

##### **reload**

displays the first message while a tape is loaded and the second message when the tape is removed. If no tape is loaded, the first message is ignored and the second message is displayed immediately. The second message is displayed until the next tape is loaded.

##### **noop**

is intended for test purposes only. It accesses the tape device but does not display the message or messages.

#### **-b or --blink**

causes <message1> to be displayed repeatedly for 2 seconds with a half-second pause in between.

#### **<message1>**

is the first or only message to be displayed. The message can be up to 8 byte.

**<message2>**

is a second message to be displayed alternately with the first, at 2 second intervals. The message can be up to 8 byte.

**<node>**

is a device node of the target tape device.

**-q or --quiet**

suppresses all error messages.

**-h or --help**

displays help text.

**-v or --version**

displays information about the version.

#### Notes:

1. Symbols that can be displayed include:

##### Alphabetic characters:

A through Z (uppercase only) and spaces. Lowercase letters are converted to uppercase.

##### Numeric characters:

0 1 2 3 4 5 6 7 8 9

##### Special characters:

@ \$ # , . / ' ( ) \* & + - = % : \_ < > ? ;

The following are included in the 3490 hardware reference but might not display on all devices: | ¢

2. If only one message is defined, it remains displayed until the tape device driver next starts to move or the message is updated.
3. If the messages contain spaces or shell-sensitive characters, they must be enclosed in quotation marks.

## Examples

The following examples assume that you are using standard devices nodes and not device nodes created by udev:

- Alternately display “BACKUP” and “COMPLETE” at two second intervals until device /dev/ntibm0 processes the next tape movement command:

```
tape390_display BACKUP COMPLETE /dev/ntibm0
```

- Display the message “REM TAPE” while a tape is in the physical tape device followed by the message “NEW TAPE” until a new tape is loaded:

```
tape390_display --type reload "REM TAPE" "NEW TAPE" /dev/ntibm0
```

- Attempts to unload the tape and load a new tape automatically, the messages are the same as in the previous example:

```
tape390_display -l -t reload "REM TAPE" "NEW TAPE" /dev/ntibm0
```


## tunedasd - Adjust DASD performance

Use **tunedasd** to:

- Display and reset DASD performance statistics
- Query and set a DASD's cache mode
- Reserve and release DASD
- Breaking the lock of a known DASD (for accessing a boxed DASD while booting Linux see "Accessing DASD by force" on page 42)

**Before you begin:** For the performance statistics, data gathering must have been switched on by writing "on" to /proc/dasd/statistics.

### Format



Where:

**<node>**

specifies a device node for the DASD to which the command is to be applied.

**-g** or **--get\_cache**

gets the current caching mode of the storage controller. This option applies to ECKD only.

**-c <mode>** or **--cache <mode>**

sets the caching mode on the storage controller to **<mode>**. This option applies to ECKD only.

Today's ECKD devices support the following behaviors:

|                   |                               |
|-------------------|-------------------------------|
| <b>normal</b>     | for normal cache replacement. |
| <b>bypass</b>     | to bypass cache.              |
| <b>inhibit</b>    | to inhibit cache.             |
| <b>sequential</b> | for sequential access.        |
| <b>prestage</b>   | for sequential prestage.      |
| <b>record</b>     | for record access.            |

For details, see *IBM TotalStorage Enterprise Storage Server® System/390® Command Reference 2105 Models E10, E20, F10, and F20, SC26-7295*.



- n** *<cylinders>* or **--no\_cyl** *<cylinders>*  
 specifies the number of cylinders to be cached. This option applies to ECKD only.
- Q** or **--query\_reserve**  
 queries the reserve status of the device. The status can be:
- |                 |                                                                                                      |
|-----------------|------------------------------------------------------------------------------------------------------|
| <b>none</b>     | the device is not reserved.                                                                          |
| <b>implicit</b> | the device is not reserved, but there is a contingent or implicit allegiance to this Linux instance. |
| <b>other</b>    | the device is reserved to another operating system instance.                                         |
| <b>reserved</b> | the device is reserved to this Linux instance.                                                       |
- For details see the “Storage Control Reference” of the attached storage server.
- This option applies to ECKD only.
- S** or **--reserve**  
 reserves the device. This option applies to ECKD only.
- L** or **--release**  
 releases the device. This option applies to ECKD only.
- 0** or **--slock**  
 reserves the device unconditionally. This option applies to ECKD only.
- Note:** This option is to be used with care as it breaks any existing reserve by another operating system.
- R** or **--reset\_prof**  
 resets the profile information of the device.
- P** or **--profile**  
 displays a usage profile of the device.
- I** *<row>* or **--prof\_item** *<row>*  
 prints the usage profile item specified by *<row>*. *<row>* can be one of:
- |                |                                                                     |
|----------------|---------------------------------------------------------------------|
| <b>reqs</b>    | number of DASD I/O requests                                         |
| <b>sects</b>   | number of 512 byte sectors                                          |
| <b>sizes</b>   | histogram of sizes                                                  |
| <b>total</b>   | histogram of I/O times                                              |
| <b>totsect</b> | histogram of I/O times per sector                                   |
| <b>start</b>   | histogram of I/O time till ssch                                     |
| <b>irq</b>     | histogram of I/O time between ssch and irq                          |
| <b>irqsect</b> | histogram of I/O time between ssch and irq per sector               |
| <b>end</b>     | histogram of I/O time between irq and end                           |
| <b>queue</b>   | number of requests in the DASD internal request queue at enqueueing |
- v** or **--version**  
 displays version information.
- h** or **--help**  
 displays help information.

## Examples

- The following sequence of commands first checks the reservation status of a DASD and then reserves it:

```
tunedasd -Q /dev/dasdzzz
none
tunedasd -S /dev/dasdzzz
Reserving device </dev/dasdzzz>...
Done.
tunedasd -Q /dev/dasdzzz
reserved
```

- This example first queries the current setting for the cache mode of a DASD with device node /dev/dasdzzz and then sets it to 1 cylinder “prestige”.

```
tunedasd -g /dev/dasdzzz
normal (0 cyl)
tunedasd -c prestige -n 2 /dev/dasdzzz
Setting cache mode for device </dev/dasdzzz>...
Done.
tunedasd -g /dev/dasdzzz
prestige (2 cyl)
```

- In this example two device nodes are specified. The output is printed for each node in the order in which the nodes were specified.

```
tunedasd -g /dev/dasdzzz /dev/dasdzzy
prestige (2 cyl)
normal (0 cyl)
```

- The following command prints the usage profile of a DASD.

```
tunedasd -P /dev/dasdzzz

19617 dasd I/O requests
with 4841336 sectors(512B each)

 <4 8 16 32 64 128 256 512 1k 2k 4k 8k 16k 32k 64k 128k
 256 512 1M 2M 4M 8M 16M 32M 64M 128M 256M 512M 1G 2G 4G >4G
Histogram of sizes (512B secs)
 0 0 441 77 78 87 188 18746 0 0 0 0 0 0 0 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Histogram of I/O times (microseconds)
 0 0 0 0 0 0 0 0 235 150 297 18683 241 3 4 4
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Histogram of I/O times per sector
 0 0 0 18736 333 278 94 78 97 1 0 0 0 0 0 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Histogram of I/O time till ssch
 19234 40 32 0 2 0 0 3 40 53 128 85 0 0 0 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Histogram of I/O time between ssch and irq
 0 0 0 0 0 0 0 0 387 208 250 18538 223 3 4 4
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Histogram of I/O time between ssch and irq per sector
 0 0 0 18803 326 398 70 19 1 0 0 0 0 0 0 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Histogram of I/O time between irq and end
 18520 735 246 68 43 4 1 0 0 0 0 0 0 0 0 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
of req in chang at enqueueing (1..32)
 0 19308 123 30 25 130 0 0 0 0 0 0 0 0 0 0
 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
```

- The following command prints a row of the usage profile of a DASD. The output is on a single line as indicated by the (cont...) (... cont) in the illustration:

```
tunedasd -P -I irq /dev/dasdzzz
0| 0| 0| 0| 0| 0| 503| 271|(cont...)
(... cont) 267 18544 224 3 4 0| 0|(cont...)
(... cont) 0 0 0 0 0| 0|(cont...)
(... cont) 0 0 0 0 0| 0|(cont...)
```

## vmcp - Send CP commands to the z/VM hypervisor

Use **vmcp** to:


- Send control program (CP) commands to the z/VM hypervisor.
- Display the response from z/VM.

The **vmcp** command expects the command line as a parameter and returns the response to stdout. Error messages are written to stderr.

You can issue **vmcp** commands using the `/dev/vmcp` device node (see Chapter 21, “z/VM CP interface device driver,” on page 241) or from a command prompt in a terminal session. In both cases, you must load the **vmcp** module.

**Before you begin:** Ensure that **vmcp** is loaded by issuing: **modprobe vmcp**.

### Format



Where:

**-h** or **--help**

displays help information.

**-v** or **--version**

displays version information.

**-k** or **--keepcase**

preserves the case of the characters in the specified command string. By default, the command string is converted to uppercase characters.

**-b <size>** or **--buffer <size>**

specifies the buffer size in bytes for the response from z/VM CP. Valid values are from 4096 (or 4k) up to 1048756 (or 1M). By default, **vmcp** allocates an 8192 byte (8k) buffer. You can use k and M to specify kilo- and megabytes.

**<command>**

specifies the command you want to send to CP.

If the command completes successfully, **vmcp** returns 0. Otherwise, **vmcp** returns one of the following values:

1. CP returned a non-zero response code.
2. The specified buffer was not large enough to hold CP's response. The command was executed, but the response was truncated. You can use the **--buffer** option to increase the response buffer.
3. Linux reported an error to **vmcp**. See the error message for details.
4. The options passed to **vmcp** were erroneous. See the error messages for details.

## Examples

- To get your user ID issue:

```
vmcp query userid
```

- To attach the device 1234 to your guest, issue:

```
vmcp attach 1234 *
```

- If you add the following line to `/etc/sudoers`:

```
ALL ALL=NOPASSWD:/sbin/vmcp indicate
```

every user on the system can run the indicate command using:

```
sudo vmcp indicate
```

- If you need a larger response buffer, use the `--buffer` option:

```
vmcp --buffer=128k q 1-ffff
```

## vmur - Work with z/VM spool file queues

The **vmur** command provides all functions required to work with z/VM spool file queues:

### Receive

Read data from the z/VM reader file queue. The command performs the following steps:

- Places the reader queue file to be received at the top of the queue.
- Changes the reader queue file attribute to NOHOLD.
- Closes the z/VM reader after reading the file.

### Punch or print

Write data to the z/VM punch or printer file queue and transfer it to another user's virtual reader, optionally on a remote z/VM node. The data is sliced up into 80-byte or 132-byte chunks (called *records*) and written to the punch or printer device. If the data length is not an integer multiple of 80 or 132, the last record is padded with 0x00.

### List

Display detailed information about one or all files on the specified spool file queue.

**Purge** Remove one or all files on the specified spool file queue.

**Order** Position a file at the top of the specified spool file queue.

The **vmur** command provides strict serialization of all its functions other than list, which does not affect a file queue's contents or sequence. Thus concurrent access to spool file queues is blocked in order to prevent unpredictable results or destructive conflicts.

For example, this serialization prevents a process from issuing `vmur purge -f` while another process is executing `vmur receive 1234`. However, **vmur** is not serialized against concurrent CP commands issued through **vmcp**: if one process is executing `vmur receive 1234` and another process issues `vmcp purge rdr 1234`, then the received file might be incomplete. To avoid such unwanted effects use **vmur** exclusively when working with z/VM spool file queues.





The **vmur** command detects z/VM reader queue files in:

- VMDUMP format as created by CP VMDUMP.
- NETDATA format as created by CMS SENDFILE or TSO XMIT.

### Before you begin:

- Ensure that vmcp module is loaded by issuing: `modprobe vmcp`
- To use the receive, punch, and print functions, the vmur device driver must be loaded and the corresponding unit record devices must be set online.

## Format

**vmur syntax****OptA:****OptB:****OptC:**

Where:

**re** or **receive**

specifies that a file on the z/VM reader queue is to be received.

**pun** or **punch**

specifies that a file is to be written to the z/VM punch queue.

**li** or **list**

specifies that information about one or all files on a z/VM spool file queue is to be listed.

**pur** or **purge**

specifies that one or all files on a z/VM spool file queue is to be purged.

**or** or **order**

specifies that a file on a z/VM spool file queue is to be ordered, that is to be placed on top of the queue.

**Note:** The short forms given for receive, punch, print, list, purge, and order are the shortest forms possible. As is common in z/VM, you can use any form of these keywords that contain the minimum form. For example, vmur re, vmur rec, or vmur rece are all equivalent.

**-d** or **--device**

specifies the device node of the virtual unit record device.

- If omitted in the receive function, /dev/vmrdr-0.0.000c is assumed.
- If omitted in the punch function, /dev/vmpun-0.0.000d is assumed.
- If omitted in the print function, /dev/vmprt-0.0.000e is assumed.

**-q** or **--queue**

specifies the z/VM spool file queue to be listed, purged or ordered. If omitted, the reader file queue is assumed.

**-t** or **--text**

specifies a text file requiring EBCDIC-to-ASCII conversion (or vice versa) according to character sets IBM037 and ISO-8859-1.

- For the receive function: specifies to receive the reader file as text file, that is, perform EBCDIC-to-ASCII conversion and insert an ASCII line feed character (0x0a) for each input record read from the z/VM reader. Trailing EBCDIC blanks (0x40) in the input records are stripped.
- For the punch or print function: specifies to punch the input file as text file, that is, perform ASCII-to-EBCDIC conversion and pad each input line with trailing blanks to fill up the record. The record length is 80 for a punch and 132 for a printer. If an input line length exceeds 80 for punch or 132 for print, an error message is issued.

The **--text** and the **--blocked** attributes are mutually exclusive.

**-b** *<sep, pad>* or **--blocked** *<sep, pad>*

specifies that the file has to be received or written using the blocked mode. As parameter for the **-b** option, specify the hex codes of the separator and the padding character. Example:

```
--blocked 0xSS,0xPP
```

Use this option if you need to use character sets other than IBM037 and ISO-8859-1 for conversion.

- For the receive function: All trailing padding characters are removed from the end of each record read from the virtual reader and the separator character is inserted afterwards. The receive function's output can be piped to **iconv** using the appropriate character sets. Example:

```
vmur rec 7 -b 0x25,0x40 -0 | iconv -f EBCDIC-US -t ISO-8859-1 > myfile
```

- For the punch or print function: The separator is used to identify the line end character of the file to punch or print. If a line has less characters than the record length of the used unit record device, the residual of the record is filled up with the specified padding byte. If a line exceeds the record size, an error is printed. Example:

```
iconv test.txt -f ISO-8859-1 -t EBCDIC-US | vmur pun -b 0x25,0x40 -N test
```

- c** or **--convert**  
converts the VMDUMP spool file into a format appropriate for further analysis with crash.
- r** or **--rdr**  
specifies that the punch or print file is to be transferred to a reader.
- u** *<user>* or **--user** *<user>*  
specifies the z/VM user ID to whose reader the data is to be transferred. If user is omitted, the data is transferred to your own machine's reader. The user option is only valid if the -r option has been specified.
- n** *<node>* or **--node** *<node>*  
specifies the z/VM node ID of the z/VM system to which the data is to be transferred. Remote Spooling Communications Subsystem (RSCS) must be installed on the z/VM systems and the specified node ID must be defined in the RSCS machine's configuration file. If node is omitted, the data is transferred to the specified user at your local z/VM system. The node option is only valid, if the -u option has been specified.
- f** or **--force**  
suppresses confirmation messages.
- For the receive function: specifies that *<outfile>* is to be overwritten without displaying any confirmation message.
  - For the purge function: specifies that the spool files specified are to be purged without displaying any confirmation message.
  - For the punch or print option: convert Linux input file name to valid spool file name automatically without any error message.
- 0** or **--stdout**  
specifies that the reader file's contents are written to standard output.
- N** or **--name**  
specifies a name and, optionally, a type for the z/VM spool file to be created by the punch or print option. To specify a type, after the file name enter a period followed by the type. For example:
- ```
# vmur pun -r /boot/parmfile -N myname.mytype
```
- Both the name and the type must comply to z/VM file name rules (that is, must be one to eight characters long).
- If omitted, the Linux input file name (if any) is used instead. Use the --force option to enforce valid spool file names and types.
- H** or **--hold**
specifies that the spool file to be received remains in the reader queue. If omitted, the spool file is purged.
- <spoolid>*
denotes the spool ID that identifies a file belonging to z/VM's reader, punch or printer queue. The spool ID must be a decimal number in the range 0-9999. If the spool ID is omitted in the list or purge function, all files in the queue are listed or purged.
- <outfile>*
specifies the name of the output file to receive the reader spool file's data. If both *<outfile>* and --stdout are omitted, name and type of the spool file to be received (see the NAME and TYPE columns in **vmur list** output) are taken to

build the output file `<name>.<type>`. If the spool file to be received is an unnamed file, an error message is issued.

`<file>`

specifies the file data to be punched or printed. If file is omitted, the data is read from standard input.

-h or **--help**

displays short information about command usage. To view the man page, issue `man vmur`.

-v or **--version**

displays version information.

Examples

This section illustrates common scenarios for unit record devices. In all examples the following device nodes are used:

- `/dev/vmrdr-0.0.000c` as virtual reader.
- `/dev/vmpun-0.0.000d` as virtual punch.

Besides the `vmur` device driver and the **vmur** command these scenarios require that:

- The `vmcp` module must be loaded.
- The **vmcp** and **vmconvert** commands from the `s390utils` package must be available.

Create and read a guest memory dump

1. Produce a dump of the z/VM guest virtual machine memory:

```
# vmcp vmdump
```

Depending on the memory size this command might take some time to complete.

2. List the spool files for the reader to find the spool ID of the dump file, `VMDUMP`. In the example, the spool ID of `VMDUMP` is 463.

```
# vmur li
```

ORIGINID	FILE	CLASS	RECORDS	CPY	HOLD	DATE	TIME	NAME	TYPE	DIST
T6360025	0463	V	DMP	00020222	001	NONE	06/11 15:07:42	VMDUMP	FILE	T6360025

3. Read and convert the `VMDUMP` spool file to a file in the current working directory of the Linux file system:

```
# vmur rec 463 -c linux_dump
```

Using FTP to receive and convert a dump file: You can use the `--convert` option together with the `--stdout` option to receive a `VMDUMP` spool file straight from the z/VM reader queue, convert it, and send it to another host using FTP:

1. Establish an FTP session with the target host and log in.
2. Enter the FTP command binary.
3. Enter the FTP command:

```
put |"vmur re <spoolid> -c -0" <filename_on_target_host>
```

Log and read the z/VM guest virtual machine console

1. Begin console spooling:

```
# vmcp sp cons start
```

2. Produce output to the z/VM console (for example, with CP TRACE).
3. Stop console spooling, close the file with the console output, and transfer the file to the reader queue. In the resulting CP message, the spool ID follows the FILE keyword. In the example, the spool ID is 398:

```
# vmcp sp cons stop close \* rdr
RDR FILE 0398 SENT FROM T6360025 CON WAS 0398 RECS 1872 CPY 001 T NOHOLD NOKEEP
```

4. Read the file with the console output into a file in the current working directory on the Linux file system:

```
# vmur re -t 398 linux_cons
```

Prepare the z/VM reader as an IPL device for Linux

1. Send the kernel parameter file, parmfile, to the z/VM punch device and transfer the file to the reader queue. The resulting message shows the spool ID of the parameter file.

```
# vmur pun -r /boot/parmfile
Reader file with spoolid 0465 created.
```

2. Send the kernel image file to the z/VM punch device and transfer the file to the reader queue. The resulting message shows the spool ID of the kernel image file.

```
# vmur pun -r /boot/vmlinuz -N image
Reader file with spoolid 0466 created.
```

3. Optional: Check the spool IDs of image and parmfile in the reader queue. In this example, the spool ID of parmfile is 465 and the spool ID of image is 466.

```
# vmur li
```

ORIGINID	FILE	CLASS	RECORDS	CPY	HOLD	DATE	TIME	NAME	TYPE	DIST
T6360025	0463	V	DMP	00020222	001	NONE	06/11 15:07:42	VMDUMP	FILE	T6360025
T6360025	0465	A	PUN	00000002	001	NONE	06/11 15:30:31	parmfile		T6360025
T6360025	0466	A	PUN	00065200	001	NONE	06/11 15:30:52	image		T6360025

4. Move image to the first and parmfile to the second position in the reader queue:

```
# vmur or 465
# vmur or 466
```

5. Configure the z/VM reader as the re-IPL device:

```
# echo 0.0.000c > /sys/firmware/reipl/ccw/device
```

6. Boot Linux from the z/VM reader:

```
# reboot
```

Send a file to different z/VM guest virtual machines

This scenario describes how to send a file called `lnxprofile.exec` from the file system of an instance of Linux on z/VM to other z/VM guest virtual machines. For example, `lnxprofile.exec` could contain the content of a PROFILE EXEC file with CP and CMS commands to customize z/VM guest virtual machines for running Linux.

1. Send `lnxprofile.exec` to two z/VM guest virtual machines: z/VM user ID `t2930020` at node `boet2930` and z/VM user ID `t6360025` at node `boet6360`.

```
vmur pun lnxprofile.exec -t -r -u t2930020 -n boet2930 -N PROFILE
vmur pun lnxprofile.exec -t -r -u t6360025 -n boet6360 -N PROFILE
```

2. Log on to `t2930020` at `boet2930`, IPL CMS, and issue the CP command:

```
QUERY RDR ALL
```

The command output shows the spool ID of PROFILE in the FILE column.

3. Issue the CMS command:

```
RECEIVE <spoolid> PROFILE EXEC A (REPL
```

In the command, `<spoolid>` is the spool ID of PROFILE found in step 2.

4. Repeat steps 2 and 3 for `t6360025` at `boet6360`.

Send a file to a z/VSE instance

To send `lserv.job` to user ID `vseuser` at node `vse01sys`, issue:

```
vmur pun lserv.job -t -r -u vseuser -n vse01sys -N LSERV
```

znetconf - List and configure network devices

The **znetconf** command:

- Lists potential network devices.
- Lists configured network devices.
- Automatically configures and adds network devices.
- Removes network devices.


For automatic configuration, **znetconf** first builds a channel command word (CCW) group device from sensed CCW devices. It then configures any specified option through the sensed network device driver and sets the new network device online.

During automatic removal, **znetconf** sets the device offline and removes it.

Attention: Removing all network devices might lead to complete loss of network connectivity. Unless you can access your Linux instance from a terminal server on z/VM (see *How to Set up a Terminal Server Environment on z/VM*, SC34-2596), you might require the HMC or a 3270 terminal session to restore the connectivity.

Before you begin: The qeth, ctcn or lcs device drivers must be loaded. If needed, the **znetconf** command attempts to load the particular device driver.

Format



Where:

-a or --add

configures the network device with the specified device bus-ID. You can enter a list of device bus-IDs separated by commas. The **znetconf** command does not check the validity of the combination of device bus-IDs.

<device bus-ID>

specifies the device bus-ID of the CCW devices constituting the network device. If a device bus-ID begins with "0.0.", you can abbreviate it to the final four hexadecimal digits. For example, you can abbreviate 0.0.f503 to f503.

-A or --add-all

configures all potential network devices. After running **znetconf -A**, enter

znetconf -c to see which devices have been configured. You can also enter **znetconf -u** to display devices that have not been configured.

- e** or **--except**
omits the specified devices when configuring all potential network devices or removing all configured network devices.
- o** or **--option** *<attribute>=<value>*
configures devices using the specified sysfs option.
- d** or **--driver** *<driver name>*
configures devices using the specified device driver. Valid values are qeth, lcs, ctc, or ctm.
- n** or **--non-interactive**
answers all confirmation questions with "Yes".
- r** or **--remove**
removes the network device with the specified device bus-ID. You can enter a list of device bus-IDs separated by a comma. You can only remove configured devices as listed by **znetconf -c**.
- R** or **--remove-all**
removes all configured network devices. After successfully running this command, all devices listed by **znetconf -c** become potential devices listed by **znetconf -u**.
- u** or **--unconfigured**
lists all network devices that are not yet configured.
- c** or **--configured**
lists all configured network devices.
- h** or **--help**
displays short information about command usage. To view the man page, enter **man znetconf**.
- v** or **--version**
displays version information.

If the command completes successfully, **znetconf** returns 0. Otherwise, 1 is returned.

Examples

- To list all potential network devices:

```
# znetconf -u
Device IDs           Type   Card Type  CHPID Drv.
-----
0.0.f500,0.0.f501,0.0.f502 1731/01 OSA (QDIO) 00   qeth
0.0.f503,0.0.f504,0.0.f505 1731/01 OSA (QDIO) 01   qeth
```

- To configure device 0.0.f503:

```
znetconf -a 0.0.f503
```

or

```
znetconf -a f503
```

- To configure the potential network device 0.0.f500 with the layer2 option with the value 0 and the portname option with the value myname:

```
znetconf -a f500 -o layer2=0 -o portname=myname
```

- To list configured network devices:

```
znetconf -c
Device IDs          Type      Card Type      CHPID Drv. Name State
-----
0.0.f500,0.0.f501,0.0.f502 1731/01 GuestLAN QDIO 00    qeth eth2 online
0.0.f503,0.0.f504,0.0.f505 1731/01 GuestLAN QDIO 01    qeth eth1 online
0.0.f5f0,0.0.f5f1,0.0.f5f2 1731/01 OSD_1000    76    qeth eth0 online
```

- To remove network device 0.0.f503:

```
znetconf -r 0.0.f503
```

or

```
znetconf -r f503
```

- To remove all configured network devices except the devices with bus IDs 0.0.f500 and 0.0.f5f0:

```
znetconf -R -e 0.0.f500 -e 0.0.f5f0
```

- To configure all potential network devices except the device with bus ID 0.0.f503:

```
znetconf -A -e 0.0.f503
```

Chapter 45. Selected kernel parameters

The kernel parameters in this section affect Linux in general and are beyond the scope of an individual device driver or feature. Device driver-specific kernel parameters are described in the setting up section of the respective device driver chapter.

See Chapter 3, “Kernel and module parameters,” on page 19 for information about specifying kernel parameters.

Examples

- This example specifies that all devices in the range 0.0.b100 through 0.0.b1ff, and the device 0.0.a100 are to be ignored.

```
cio_ignore=0.0.b100-0.0.b1ff,0.0.a100
```

- This example specifies that all devices are to be ignored.

```
cio_ignore=all
```

- This example specifies that all devices but the range 0.0.b100 through 0.0.b1ff, and the device 0.0.a100 are to be ignored.

```
cio_ignore=all,!0.0.b100-0.0.b1ff,!0.0.a100
```

- This example specifies that all devices in the range 0.0.1000 through 0.0.1500 are to be ignored, except for those in the range 0.0.1100 through 0.0.1120.

```
cio_ignore=0.0.1000-0.0.1500,!0.0.1100-0.0.1120
```

This is equivalent to the following specification:

```
cio_ignore=0.0.1000-0.0.10ff,0.0.1121-0.0.1500
```

- This example specifies that all devices in range 0.0.1000 through 0.0.1100 as well as all devices in range 0.1.7000 through 0.1.7010, plus device 0.0.1234 and device 0.1.4321 are to be ignored.

```
cio_ignore=0.0.1000-0.0.1100, 0.1.7000-0.1.7010, 0.0.1234, 0.1.4321
```

Changing the exclusion list

When a Linux on System z instance boots, it senses and analyzes all available I/O devices. You can use the `cio_ignore` kernel parameter to list specifications for devices that are to be ignored.

On a running Linux instance, you can view and change the exclusion list through a `procfs` interface.

After booting Linux you can display the exclusion list by issuing:

```
# cat /proc/cio_ignore
```

To add device specifications to the exclusion list issue a command of this form:

```
# echo add <device_list> > /proc/cio_ignore
```

When you add specifications for a device that has already been sensed and analyzed, there is no immediate effect of adding it to the exclusion list. For example, the device still appears in the output of the `lscss` command and can be set online. However, if the device subsequently becomes unavailable, it is ignored when it reappears. For example, if the device is detached in z/VM it is ignored when it is attached again.

To make all devices that are in the exclusion list and that are currently offline unavailable to Linux issue a command of this form:

```
# echo purge > /proc/cio_ignore
```

This command does not make devices unavailable if they are online.

cio_ignore

To remove device specifications from the exclusion list issue a command of this form:


```
# echo free <device_list> > /proc/cio_ignore
```

When you remove device specifications from the exclusion list, the corresponding devices are sensed and analyzed if they exist. Where possible, the respective device driver is informed, and the devices become available to Linux.


Note: After the echo command completes successfully, some time might elapse until the freed device becomes available to Linux. To confirm that a device has become available to Linux verify that the sysfs attribute `/sys/bus/ccw/devices/<device-bus-ID>/online` is present.

In these commands, `<device_list>` follows this syntax:

<device_list>:



<device_spec>:



Where the keywords and variables have the same meaning as in “Format” on page 520.

Note: The dynamically changed exclusion list is only taken into account when a device in this list is newly made available to the system, for example after it has been defined to the system. It does not have any effect on setting devices online or offline within Linux.

Examples:

- This command removes all devices from the exclusion list.

```
# echo free all > /proc/cio_ignore
```

- This command adds all devices in the range 0.0.b100 through 0.0.b1ff and device 0.0.a100 to the exclusion list.

```
# echo add 0.0.b100-0.0.b1ff,0.0.a100 > /proc/cio_ignore
```

- This command lists the ranges of devices that are ignored by common I/O.

```
# cat /proc/cio_ignore  
0.0.0000-0.0.a0ff  
0.0.a101-0.0.b0ff  
0.0.b200-0.0.ffff
```

- This command removes all devices in the range 0.0.b100 through 0.0.b1ff and device 0.0.a100 from the exclusion list.

```
# echo free 0.0.b100-0.0.b1ff,0.0.a100 > /proc/cio_ignore
```

- This command removes the device with bus ID 0.0.c104 from the exclusion list.

```
# echo free 0.0.c104 > /proc/cio_ignore
```

- This command adds the device with bus ID 0.0.c104 to the exclusion list.

```
# echo add 0.0.c104 > /proc/cio_ignore
```

- This command makes all devices that are in the exclusion list and that are currently offline unavailable to Linux.

```
# echo purge > /proc/cio_ignore
```


cmma - Reduce hypervisor paging I/O overhead

Usage

Reduces hypervisor paging I/O overhead.

You can use Collaborative Memory Management Assist (CMMA, or "cmm2") on System z9 and later IBM mainframe systems. With this support, the z/VM control program and guest virtual machines can communicate attributes for specific 4K-byte blocks of guest memory. This exchange of information helps both the z/VM host and the guest virtual machines to optimize their use and management of memory.

Format



Examples

This example switches the CMMA support on:

```
cmma=on
```

This is equivalent to:

```
cmma=yes
```

maxcpus - Restrict the number of CPUs Linux can use at IPL

Usage

Restricts the number of CPUs that Linux can use at IPL. For example, if there are four CPUs then specifying maxcpus=2 will cause the kernel to use only two CPUs. See also “possible_cpus - Limit the number of CPUs Linux can use” on page 527.

Format

maxcpus syntax

►►—maxcpus=<number>—◄◄

Examples

maxcpus=2

mem - Restrict memory usage

Usage

Restricts memory usage to the size specified. You can use the K, M, or G suffix to specify the value in kilobyte, megabyte, or gigabyte.

Format



Examples

```
mem=64M
```

Restricts the memory Linux can use to 64 MB.

```
mem=123456K
```

Restricts the memory Linux can use to 123456 KB.

possible_cpus - Limit the number of CPUs Linux can use

Usage

Specifies the number of maximum possible and usable CPUs that Linux can add to the system. See also “maxcpus - Restrict the number of CPUs Linux can use at IPL” on page 525.

Format

possible_cpus syntax

▶▶—possible_cpus=<number>————▶◀

Examples

```
possible_cpus=8
```

ramdisk_size - Specify the ramdisk size

Usage

Specifies the size of the ramdisk in kilobytes.

Format

ramdisk_size syntax

▶▶—ramdisk_size=<size>————▶◀

Examples

```
ramdisk_size=32000
```

ro - Mount the root file system read-only

Usage

Mounts the root file system read-only.

Format

ro syntax

▶▶—ro—▶◀

root - Specify the root device

Usage

Tells Linux what to use as the root when mounting the root file system.

Format

root syntax

►►—root=<*rootdevice*>————►◄

Examples

This example makes Linux use /dev/dasda1 when mounting the root file system:


```
root=/dev/dasda1
```

user_mode - Set address mode for user space processes

Usage

Sets the address mode for user space processes.

Format



Use this parameter if you are running an application that requires an address mode other than the default mode. The default address mode for user space processes is `home`.

Address mode `primary` can degrade performance on mainframe systems earlier than System z9.

Address mode `secondary` enables the data execution protection if your kernel has been built with the data execution protection feature. This has a negative performance impact on mainframe systems earlier than System z9. See Chapter 33, “Data execution protection for user processes,” on page 295 for more information about data execution protection.

Note: The `noexec` kernel parameter also sets the address mode (see “Enabling the data execution protection feature” on page 295). If you specify both `user_mode` and `noexec`, the address mode is set according to the parameter specified last.

vdso - Optimize system call performance

Usage

The kernel virtual dynamic shared object (vdso) support optimizes performance of the `gettimeofday`, `clock_gettime`, and `clock_getres` system calls. The vdso support is a shared library that the kernel maps to all dynamically linked programs. The glibc detects the presence of the vdso and uses the functions provided in the library.

The vdso support is included in the Linux on System z kernel.

Format



As the vdso library is mapped to all user-space processes, this change is visible in user space. In the unlikely event that a user-space program does not work with the vdso support, you can switch the support off.

Examples

This example switches the vdso support off:

```
vdso=0
```

vmhalt - Specify CP command to run after a system halt

Usage

Specifies a command to be issued to CP after a system halt. This command applies only to Linux on z/VM.

Format

vmhalt syntax

►►—vmhalt=<COMMAND>—————►◄

Examples

This example specifies that an initial program load of CMS should follow the Linux "halt" command:

```
vmhalt="CPU 00 CMD I CMS"
```

Note: The command must be entered in uppercase.

vmpanic - Specify CP command to run after a kernel panic

Usage

Specifies a command to be issued to CP after a kernel panic. This command applies only to Linux on z/VM.

Note: Ensure that the **dumpconf** service is disabled when using this kernel parameter. Otherwise **dumpconf** will override the setting.

Format

vmpanic syntax

▶▶—vmpanic=<COMMAND>————▶◀

Examples

This example specifies that a VMDUMP should follow a kernel panic:

```
vmpanic="VMDUMP"
```

Note: The command must be entered in uppercase.

vmpoff - Specify CP command to run after a power off

Usage

Specifies a command to be issued to CP after a system power off. This command applies only to Linux on z/VM.

Format

vmpoff syntax

►►—vmpoff=<COMMAND>—————►◄

Examples

This example specifies that CP should clear the guest virtual machine after the Linux "power off" or "halt -p" command:

```
vmpoff="SYSTEM CLEAR"
```

Note: The command must be entered in uppercase.

vmreboot - Specify CP command to run on reboot

Usage

Specifies a command to be issued to CP on reboot. This command applies only to Linux on z/VM.

Format

vmreboot syntax

►►—vmreboot=<COMMAND>————►◄

Examples

This example specifies a message to be sent to the z/VM guest virtual machine OPERATOR if a reboot occurs:

```
vmreboot="MSG OPERATOR Reboot system"
```

Note: The command must be entered in uppercase.

Chapter 46. Linux diagnose code use

Red Hat Enterprise Linux 6.3 for System z issues several diagnose instructions to the hypervisor (LPAR or z/VM). Table 59 lists all diagnoses which are used by the Linux kernel or a kernel module.

Linux can fail if you change the privilege class of the diagnoses marked as **required** using the MODIFY diag command in z/VM.

Table 59. Linux diagnoses

Number	Description	Linux use	Required/ Optional
0x008	z/VM CP command console interface	<ul style="list-style-type: none">• The vmcp command• The 3215 and 3270 console drivers• The z/VM recording device driver (vmlogrdr)• smsgiucv	Required
0x010	Release pages	CMM	Required
0x014	Input spool file manipulation	The vmur device driver	Required
0x044	Voluntary time-slice end	In the kernel for spinlock and udelay	Required
0x064	Allows Linux to attach a DCSS	The DCSS block device driver (dcssblk), xip, and the MONITOR record device driver (monreader).	Required
0x09c	Voluntary time slice yield	Spinlock.	Optional
0x0dc	Monitor stream	The APPLDATA monitor record and the MONITOR stream application support (monwriter).	Required
0x204	LPAR Hypervisor data	The hypervisor file system (hypfs).	Required
0x210	Retrieve device information	<ul style="list-style-type: none">• The common I/O layer• The DASD driver DIAG access method• The vmur device driver	Required
0x224	CPU type name table	The hypervisor file system (hypfs).	Required
0x250	Block I/O	The DASD driver DIAG access method.	Required
0x258	Page-reference services	In the kernel, for pfault.	Optional
0x288	Virtual machine time bomb	The watchdog device driver.	Required
0x2fc	Hypervisor cpu and memory accounting data	The hypervisor file system (hypfs).	Required
0x308	Re-ipl	Re-ipl and dump code.	Required

Required means that a function is not available without the diagnose; optional means that the function is available but there might be a performance impact.

Accessibility

Accessibility features help users who have a disability, such as restricted mobility or limited vision, to use information technology products successfully.

Documentation accessibility

The Linux on System z publications are in Adobe Portable Document Format (PDF) and should be compliant with accessibility standards. If you experience difficulties when you use the PDF file and want to request a Web-based format for this publication, use the Reader Comment Form in the back of this publication, send an email to eservdoc@de.ibm.com, or write to:

IBM Deutschland Research & Development GmbH
Information Development
Department 3248
Schoenaicher Strasse 220
71032 Boeblingen
Germany

In the request, be sure to include the publication number and title.

When you send information to IBM, you grant IBM a nonexclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

IBM and accessibility

See the IBM Human Ability and Accessibility Center for more information about the commitment that IBM has to accessibility at

www.ibm.com/able

Notices

This information was developed for products and services offered in the U.S.A. IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information about the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A.

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law:

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

Trademarks

IBM, the IBM logo, and `ibm.com` are trademarks or registered trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies. A current list of IBM trademarks is available on the Web at "Copyright and trademark information" at

www.ibm.com/legal/copytrade.shtml

Adobe is either a registered trademark or trademark of Adobe Systems Incorporated in the United States, and/or other countries.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Java and all Java-based trademarks and logos are trademarks or registered trademarks of Oracle and/or its affiliates.

Glossary

This glossary includes IBM product terminology as well as selected other terms and definitions.

Additional information can be obtained in:

- The American National Standard Dictionary for Information Systems, ANSI X3.172-1990, copyright 1990 by the American National Standards Institute (ANSI). Copies may be purchased from the American National Standards Institute, 11 West 42nd Street, New York, New York 10036.
- The ANSI/EIA Standard-440-A, Fiber Optic Terminology. Copies may be purchased from the Electronic Industries Association, 2001 Pennsylvania Avenue, N.W., Washington, DC 20006.
- The Information Technology Vocabulary developed by Subcommittee 1, Joint Technical Committee 1, of the International Organization for Standardization and the International Electrotechnical Commission (ISO/IEC JTC1/SC1).
- The IBM Dictionary of Computing, New York: McGraw-Hill, 1994.
- Internet Request for Comments: 1208, Glossary of Networking Terms
- Internet Request for Comments: 1392, Internet Users' Glossary
- The Object-Oriented Interface Design: IBM Common User Access Guidelines , Carmel, Indiana: Que, 1992.

Numerics

10 Gigabit Ethernet. An Ethernet network with a bandwidth of 10000-Mbps.

3215. IBM console printer-keyboard.

3270. IBM information display system.

3370, 3380 or 3390. IBM direct access storage device (disk).

3480, 3490, 3590. IBM magnetic tape subsystem.

9336 or 9345. IBM direct access storage device (disk).

A

address space. The range of addresses available to a computer program or process. Address space can refer to physical storage, virtual storage, or both.

auto-detection. Listing the addresses of devices attached to a card by issuing a query command to the card.

C

CCL.

The Communication Controller for Linux on System z (CCL) replaces the 3745/6 Communication Controller so that the Network Control Program (NCP) software can continue to provide business critical functions like SNI, XRF, BNN, INN, and SSCP takeover. This allows you to leverage your existing NCP functions on a "virtualized" communication controller within the Linux on System z environment.

cdl. compatible disk layout. A disk structure for Linux on System z which allows access from other System z operating systems. This replaces the older **ldl**.

CEC. (Central Electronics Complex). A synonym for **CPC**.

channel subsystem. The programmable input/output processors of the System z, which operate in parallel with the CPU.

checksum. An error detection method using a check byte appended to message data

CHPID. channel path identifier. In a channel subsystem, a value assigned to each installed channel path of the system that uniquely identifies that path to the system.

Glossary

Console. (1) In Linux, an output device for kernel messages. (2) In the context of IBM mainframes, a device that gives a system programmer control over the hardware resources, for example the LPARs.

CPC. (Central Processor Complex). A physical collection of hardware that includes main storage, one or more central processors, timers, and channels. Also referred to as a *CEC*.

CRC. cyclic redundancy check. A system of error checking performed at both the sending and receiving station after a block-check character has been accumulated.

CSMA/CD. carrier sense multiple access with collision detection

CTC. channel to channel. A method of connecting two computing devices.

CUU. control unit and unit address. A form of addressing for System z devices using device numbers.

D

DASD. direct access storage device. A mass storage medium on which a computer stores data.

device driver. (1) A file that contains the code needed to use an attached device. (2) A program that enables a computer to communicate with a specific peripheral device; for example, a printer, a videodisc player, or a CD-ROM drive. (3) A collection of subroutines that control the interface between I/O device adapters and the processor.

DIAGNOSE. (1) In z/VM, a set of instructions that programs running on z/VM guest virtual machines can call to request CP services. (2) In an LPAR, a set of instructions that programs running in the LPAR can call to request hypervisor services.

E

ECKD. extended count-key-data device. A disk storage device that has a data transfer rate faster than some processors can utilize and that is connected to the processor through use of a speed matching buffer. A specialized channel program is needed to communicate with such a device.

ESCON. enterprise systems connection. A set of IBM products and services that provide a dynamically connected environment within an enterprise.

Ethernet. A 10-Mbps baseband local area network that allows multiple stations to access the transmission medium at will without prior coordination, avoids contention by using carrier sense and deference, and resolves contention by using collision detection and delayed retransmission. Ethernet uses CSMA/CD.

F

Fast Ethernet (FENET). Ethernet network with a bandwidth of 100 Mbps

FBA. fixed block architecture. A type of DASD emulated by z/VM.

FDDI. fiber distributed data interface. An American National Standards Institute (ANSI) standard for a 100-Mbps LAN using optical fiber cables.

fibre channel. A technology for transmitting data between computer devices. It is especially suited for attaching computer servers to shared storage devices and for interconnecting storage controllers and drives.

FTP. file transfer protocol. In the Internet suite of protocols, an application layer protocol that uses TCP and Telnet services to transfer bulk-data files between machines or hosts.

G

Gigabit Ethernet (GbE). An Ethernet network with a bandwidth of 1000-Mbps

H

hardware console. A service-call logical processor that is the communication feature between the main processor and the service processor.

Host Bus Adapter (HBA). An I/O controller that connects an external bus, such as a Fibre Channel, to the internal bus (channel subsystem).

In a Linux environment HBAs are normally virtual and are shown as an FCP device.

HMC. hardware management console. A console used to monitor and control hardware such as the System z microprocessors.

HFS. hierarchical file system. A system of arranging files into a tree structure of directories.

I

intraensemble data network (IEDN). A private 10 Gigabit Ethernet network for application data communications within an ensemble. Data communications for workloads can flow over the IEDN within and between nodes of an ensemble. All of the physical and logical resources of the IEDN are configured, provisioned, and managed by the Unified Resource Manager.

intranode management network (INMN). A private 1000BASE-T Ethernet network operating at 1 Gbps that is required for the Unified Resource Manager to

manage the resources within a single zEnterprise node. The INMN connects the Support Element (SE) to the zEnterprise 196 (z196) or zEnterprise 114 (z114) and to any attached zEnterprise BladeCenter Extension (zBX).

ioctl system call. Performs low-level input- and output-control operations and retrieves device status information. Typical operations include buffer manipulation and query of device mode or status.

IOCS. input / output channel subsystem. See channel subsystem.

IP. internet protocol. In the Internet suite of protocols, a connectionless protocol that routes data through a network or interconnected networks and acts as an intermediary between the higher protocol layers and the physical network.

IP address. The unique 32-bit address that specifies the location of each device or workstation on the Internet. For example, 9.67.97.103 is an IP address.

IPIP. IPv4 in IPv4 tunnel, used to transport IPv4 packets in other IPv4 packets.

IPL. initial program load (or boot). (1) The initialization procedure that causes an operating system to commence operation. (2) The process by which a configuration image is loaded into storage at the beginning of a work day or after a system malfunction. (3) The process of loading system programs and preparing a system to run jobs.

IPv6. IP version 6. The next generation of the Internet Protocol.

IUCV. inter-user communication vehicle. A z/VM facility for passing data between virtual machines and z/VM components.

K

kernel. The part of an operating system that performs basic functions such as allocating hardware resources.

kernel module. A dynamically loadable part of the kernel, such as a device driver or a file system.

kernel image. The kernel when loaded into memory.

L

LCS. LAN channel station. A protocol used by OSA.

ldl. Linux disk layout. A basic disk structure for Linux on System z. Now replaced by cdl.

LDP. Linux Documentation Project. An attempt to provide a centralized location containing the source material for all open source Linux documentation.

Includes user and reference guides, HOW TOs, and FAQs. The homepage of the Linux Documentation Project is

www.linuxdoc.org

Linux. a variant of UNIX which runs on a wide range of machines from wristwatches through personal and small business machines to enterprise systems.

Linux on System z. the port of Linux to the IBM System z architecture.

LPAR. logical partition of System z.

LVS (Linux virtual server). Network sprayer software used to dispatch, for example, http requests to a set of web servers to balance system load.

M

MAC. medium access control. In a LAN this is the sub-layer of the data link control layer that supports medium-dependent functions and uses the services of the physical layer to provide services to the logical link control (LLC) sub-layer. The MAC sub-layer includes the method of determining when a device has access to the transmission medium.

Mbps. million bits per second.

MIB (Management Information Base). (1) A collection of objects that can be accessed by means of a network management protocol. (2) A definition for management information that specifies the information available from a host or gateway and the operations allowed.

MTU. maximum transmission unit. The largest block which may be transmitted as a single unit.

Multicast. A protocol for the simultaneous distribution of data to a number of recipients, for example live video transmissions.

N

NIC. network interface card. The physical interface between the IBM mainframe and the network.

O

OSA-Express. Abbreviation for Open Systems Adapter-Express networking features. These include 10 Gigabit Ethernet, Gigabit Ethernet, and Fast Ethernet.

OSM. OSA-Express for Unified Resource Manager. A CHPID type that provides connectivity to the intranode management network (INMN) from z196 or z114 to Unified Resource Manager functions. Uses OSA-Express3 1000BASE-T Ethernet exclusively operating at 1 Gbps.

Glossary

OSPF. open shortest path first. A function used in route optimization in networks.

OSX. OSA-Express for zBX. A CHPID type that provides connectivity and access control to the intraensemble data network (IEDN) from z196 or z114 to zBX.

P

POR. power-on reset

POSIX. Portable Operating System Interface for Computer Environments. An IEEE operating system standard closely related to the UNIX system.

R

router. A device or process which allows messages to pass between different networks.

S

SE. support element. (1) An internal control element of a processor that assists in many of the processor operational functions. (2) A hardware unit that provides communications, monitoring, and diagnostic functions to a central processor complex.

SNA. systems network architecture. The IBM architecture that defines the logical structure, formats, protocols, and operational sequences for transmitting information units through, and controlling the configuration and operation of, networks. The layered structure of SNA allows the ultimate origins and destinations of information (the users) to be independent of and unaffected by the specific SNA network services and facilities that are used for information exchange.

SNMP (Simple Network Management Protocol). In the Internet suite of protocols, a network management protocol that is used to monitor routers and attached networks. SNMP is an application layer protocol. Information about devices managed is defined and stored in the application's Management Information Base (MIB).

Sysctl. system control programming manual control (frame). A means of dynamically changing certain Linux kernel parameters during operation.

T

Telnet. A member of the Internet suite of protocols which provides a remote terminal connection service. It allows users of one host to log on to a remote host and interact as if they were using a terminal directly attached to that host.

Terminal. A physical or emulated device, associated with a keyboard and display device, capable of sending and receiving information.

U

UNIX. An operating system developed by Bell Laboratories that features multiprogramming in a multiuser environment. The UNIX operating system was originally developed for use on minicomputers but has been adapted for mainframes and microcomputers.

V

V=R. In z/VM, a guest whose real memory (virtual from a z/VM perspective) corresponds to the real memory of z/VM.

V=V. In z/VM, a guest whose real memory (virtual from a z/VM perspective) corresponds to virtual memory of z/VM.

Virtual LAN (VLAN). A group of devices on one or more LANs that are configured (using management software) so that they can communicate as if they were attached to the same wire, when in fact they are located on a number of different LAN segments. Because VLANs are based on logical rather than physical connections, they are extremely flexible.

volume. A data carrier that is usually mounted and demounted as a unit, for example a tape cartridge or a disk pack. If a storage unit has no demountable packs the volume is the portion available to a single read/write mechanism.

Z

z114. IBM zEnterprise 114

z196. IBM zEnterprise 196

zBX. IBM zEnterprise BladeCenter Extension

zEnterprise. IBM zEnterprise System. A heterogeneous hardware infrastructure that can consist of a zEnterprise 196 (z196) or a zEnterprise 114 (z114) and an attached IBM zEnterprise BladeCenter Extension (zBX) Model 002, managed as a single logical virtualized system by the Unified Resource Manager.

zSeries. The family of IBM enterprise servers that demonstrate outstanding reliability, availability, scalability, security, and capacity in today's network computing environments.

Bibliography

The publications listed in this chapter are considered useful for a more detailed study of the topics contained in this book.

Linux on System z publications

Current versions of all Linux on System z publications can be found at
www.ibm.com/developerworks/linux/linux390/documentation_red_hat.html

- *Device Drivers, Features, and Commands on Red Hat Enterprise Linux 6.3*, SC34-2597
- *Using the Dump Tools on Red Hat Enterprise Linux 6.3*, SC34-2607
- *How to use FC-attached SCSI devices with Linux on System z*, SC33-8413
- *How to Improve Performance with PAV*, SC33-8414
- *How to use Execute-in-Place Technology with Linux on z/VM*, SC34-2594
- *How to Set up a Terminal Server Environment on z/VM*, SC34-2596
- *libica Programmer's Reference*, SC34-2602

Red Hat Enterprise Linux 6.3 publications

The documentation for Red Hat Enterprise Linux 6.3 can be found at
http://docs.redhat.com/docs/en-US/Red_Hat_Enterprise_Linux

- *Red Hat Enterprise Linux 6.3 Deployment Guide*
- *Red Hat Enterprise Linux 6.3 Installation Guide*

z/VM publications

The publication numbers listed are for z/VM version 6. For the complete library including other versions, see

www.ibm.com/vm/library

- *z/VM Connectivity*, SC24-6174
- *z/VM CP Commands and Utilities Reference*, SC24-6175
- *z/VM CP Planning and Administration*, SC24-6178
- *z/VM CP Programming Services*, SC24-6179
- *z/VM Getting Started with Linux on System z*, SC24-6194
- *z/VM Performance*, SC24-6208
- *z/VM Saved Segments Planning and Administration*, SC24-6229
- *z/VM Systems Management Application Programming*, SC24-6234
- *z/VM TCP/IP Planning and Customization*, SC24-6238
- *z/VM Virtual Machine Operation*, SC24-6241
- *REXX/VM Reference*, SC24-6221
- *REXX/VM User's Guide*, SC24-6222

IBM Redbooks publications

You can search for, view, or download Redbooks publications, Redpapers, Hints and Tips, draft publications and additional materials, as well as order hardcopy Redbooks or CD-ROMs, at

www.ibm.com/redbooks

- *IBM zEnterprise Unified Resource Manager*, SG24-7921
- *Building Linux Systems under IBM VM*, REDP-0120
- *FICON CTC Implementation*, REDP-0158
- *Networking Overview for Linux on zSeries*, REDP-3901
- *Linux on IBM eServer zSeries and S/390: TCP/IP Broadcast on z/VM Guest LAN*, REDP-3596
- *Linux on IBM eServer zSeries and S/390: VSWITCH and VLAN Features of z/VM 4.4*, REDP-3719
- *Security on z/VM*, SG24-7471
- *IBM Communication Controller Migration Guide*, SG24-6298
- *Problem Determination for Linux on System z*, SG24-7599
- *Fibre Channel Protocol for Linux and z/VM on IBM System z*, SG24-7266

Other System z publications

- *zEnterprise System Introduction to Ensembles*, GC27-2609
- *zEnterprise System Ensemble Planning and Configuring Guide*, GC27-2608
- *System z Application Programming Interfaces*, SB10-7030
- *IBM TotalStorage Enterprise Storage Server System/390 Command Reference 2105 Models E10, E20, F10, and F20*, SC26-7295
- *Processor Resource/Systems Manager Planning Guide*, SB10-7041
- *z/Architecture Principles of Operation*, SA22-7832

Networking publications

- *HiperSockets Implementation Guide*, SG24-6816
- *OSA-Express Customer's Guide and Reference*, SA22-7935
- *OSA-Express Implementation Guide*, SG25-5848

Security related publications

- *zSeries Crypto Guide Update*, SG24-6870
- *Secure Key Solution with the Common Cryptographic Architecture Application Programmer's Guide*, SC33-8294

ibm.com® resources

- For CMS and CP Data Areas, Control Block information, and the layout of the z/VM monitor records see
www.ibm.com/vm/pubs/ctlblk.html
- For I/O connectivity on System z information, see
www.ibm.com/systems/z/connectivity
- For Communications server for Linux information, see
www.ibm.com/software/network/commserver/linux
- For information about performance monitoring on z/VM, see
www.ibm.com/vm/perf
- For cryptographic coprocessor information, see

www.ibm.com/security/cryptocards

- (Requires registration.) For information for planning, installing, and maintaining IBM Systems, see www.ibm.com/servers/resourcelink
- For information about STP, see www.ibm.com/systems/z/advantages/pso/stp.html

Finding IBM books

For the referenced IBM books, links have been omitted to avoid pointing to a particular edition of a book. You can locate the latest versions of the referenced IBM books through the IBM Publications Center at

www.ibm.com/shop/publications/order

Index

Special characters

/debug, mount point xi
/proc, mount point xi
/sys, mount point xi
/sys/kernel/debug, mount point xi
*ACCOUNT, z/VM record 213
*LOGREC, z/VM record 213
*SYMPTOM, z/VM record 213

Numerics

10 Gigabit Ethernet 111
 SNMP 165
1000Base-T Ethernet
 LAN channel station 173
 SNMP 165
1000Base-T, Ethernet 111
1750, control unit 27
2105, control unit 27
2107, control unit 27
3088, control unit 173, 179
31-bit
 z90crypt 284
3270 emulation 311
3270 terminal device driver 308
 switching the views of 313
3370, DASD 27
3380, DASD 27
3390, DASD 27
3480 tape drive 91
3490 tape drive 91
3590 tape drive 91
3592 tape drive 91
3880, control unit 27
3990, control unit 27
6310, control unit 27
9336, DASD 27
9343, control unit 27
9345, DASD 27

A

access control
 FCP LUN 66
access_denied
 zfcf attribute (port) 75
 zfcf attribute (SCSI device) 80
access_shared
 zfcf attribute 80
accessibility 539
ACCOUNT, z/VM record 213
actions, shutdown 371
activating standby CPU 257
ACTIVE_CONSOLES 309
add, DCSS attribute 227
adding and removing cryptographic
 adapters 290
Address Resolution Protocol
 See ARP

AF_IUCV
 addressing sockets in
 applications 251
 set up devices for addressing 250
AF_IUCV address family 249
 features 249
 set up support for 250
af_iucv, kernel module 251
AgentX protocol 165
alias
 DASD attribute 57
AP
 devices 7
ap_interrupt
 cryptographic adapter attribute 289
API
 cryptographic 291
 FC-HBA 65
APPLDATA, monitor stream 197
applet
 emulation of the HMC Operating
 System Messages 317
applications
 addressing AF_IUCV sockets in 251
ARP 119
 proxy ARP 146
 query/purge OSA-Express ARP
 cache 490
attributes
 device 9
 for CCW devices 9
 for subchannels 13
 qeth 121, 122
auto-detection
 DASD 37
 LCS 173
autoconfiguration, IPv6 116
autopurge, z/VM recording
 attribute 216
autorecording, z/VM recording
 attribute 215
availability
 common CCW attribute 9
 DASD attribute 42
avg_*, cmf attributes 381
avg_control_unit_queuing_time, cmf
 attribute 381
avg_device_active_only_time, cmf
 attribute 381
avg_device_busy_time 381
avg_device_busy_time, cmf attribute 381
avg_device_connect_time, cmf
 attribute 381
avg_device_disconnect_time, cmf
 attribute 381
avg_function_pending_time, cmf
 attribute 381
avg_initial_command_response_time, cmf
 attribute 381
avg_sample_interval, cmf attribute 381
avg_utilization, cmf attribute 381

B

base name
 network interfaces 4
binutils, package 296
block device
 tape 91
block_size_bytes, memory attribute 262
blocksize, tape attribute 97
book_id
 CPU sysfs attribute 259
book_siblings
 CPU sysfs attribute 259
boot devices 348
 logical 327
 preparing 321
boot loader code 349
boot menu
 DASD, LPAR example 358
 DASD, z/VM example 351
 zipl 337
booting Linux 347
 troubleshooting 391
buffer_count, qeth attribute 127
buffer, CTCM attribute 185
bus ID 9

C

Call Home
 callhome attribute 387
callhome
 Call Home attribute 387
capability change, CPU 257
card_type, qeth attribute 129
card_version, zfcf attribute 70
case conversion 317
CCA library 286
CCW
 channel measurement facility 379
 common attributes 9
 devices 7
 group devices 7
 hotplug events 16
 setting devices online/offline 396,
 456
CCW terminal device
 switching on- or offline 314
CD-ROM, loading Linux 358
CEX2A (Crypto Express2) 281
CEX2C (Crypto Express2) 281
CEX3A (Crypto Express3) 281
CEX3C (Crypto Express3) 281
change, CPU capability 257
channel measurement facility 379
 cmb_enable attribute 380
 features 379
 kernel parameters 379
 read-only attributes 380
channel path
 changing status 398

- channel path (*continued*)
 - determining usage 389
 - ensuring correct status 389
 - list 457
 - planned change in availability 389
 - unplanned change in availability 389
- character device, tape 91
- chccwdev, Linux command 396
- chchp, Linux command 398
- Chinese-Remainder Theorem 281
- chmem, Linux command 400
- CHPID
 - in sysfs 14
 - online attribute 15
- chpids, subchannel attribute 13
- chreipl, Linux command 402
- chshut, Linux command 406
- chzcrypt, Linux command 408
- cio_ignore
 - disabled wait 390
- cio_ignore, procs interface 521
- cio_ignore=, kernel parameter 520
- cio_settle 10
- clear key cryptography 283
- clock synchronization 273
- cmb_enable
 - cmf attribute 380
 - common CCW attribute 9
 - tape attribute 97
- cmd=, module parameters 238
- cmd.format=, kernel parameter 379
- cmf.maxchannels=, kernel parameter 379
- cmm
 - avoid swapping with 195
 - background information 195
- CMM
 - unload module 390
- cmm, kernel module 253
- CMMA 524
- mma=, kernel parameter 524
- CMS disk layout 32
- CMS1 labeled disk 32
- cmsfs-fuse, Linux command 410
- code page 411
 - for x3270 311
- Collaborative Memory Management Assist 524
- commands, Linux
 - chccwdev 396
 - chchp 398
 - chmem 400
 - chreipl 402
 - chshut 406
 - chzcrypt 408
 - cmsfs-fuse 410
 - cpuplugd 415
 - dasdfmt 423
 - dasdstat 426
 - dasdview 429
 - dmesg 5
 - dumpconf 372
 - fdasd 438
 - hyptop 446
 - icainfo 455
 - icastats 456
 - ip 4
- commands, Linux (*continued*)
 - lschp 457
 - lscss 459
 - lsdasd 461
 - lsmem 465
 - lsqeth 467
 - lsreipl 469
 - lsshut 470
 - lstape 471
 - lszcrypt 474
 - lszfcf 476
 - mon_fsstatd 478
 - mon_procd 483
 - qetharp 490
 - qethconf 492
 - readlink 5
 - scsi_logging_level 495
 - tape390_crypt 498
 - tape390_display 502
 - tunedasd 504
 - vmcp 507
 - vmur 509
 - zipl 321
 - znetconf 516
- commands, z/VM
 - sending from Linux 507
- communication facility
 - Inter-User Communication Vehicle 249
- compatibility mode, z90crypt 284
- compatible disk layout 29
- compression, tape 98
- conceal=, module parameters 238
- configuration file for CPU and memory hotplug 421
- configure LPAR I/O devices 389
- conmode=, kernel parameter 306
- console
 - definition 301
 - device names 301
 - device nodes 302
 - mainframe versus Linux 301
- console device driver
 - kernel parameter 307
 - overriding default driver 306
 - restricting access to HVC terminal devices 307
 - specifying preferred console 307
 - specifying the number of HVC terminal devices 307
- console device drivers 299
 - device and console names 301
 - features 300
 - terminal modes 302
- console=, kernel parameter 307
- control characters 315
- control program identification 383
- control unit
 - 1750 27
 - 2105 27
 - 2107 27
 - 3880 27
 - 3990 27
 - 6310 27
 - 9343 27
- cooperative memory management 253
 - set up 253
- core_id
 - CPU sysfs attribute 258
- core_siblings
 - CPU sysfs attribute 258
- CP Assist for Cryptographic Function 293
- CP commands
 - send to z/VM hypervisor 507
 - VINPUT 319
- CP Error Logging System Service 213
- CP VINPUT 319
- CP1047 411
- cpc_name attribute 277
- CPI
 - set attribute 385
 - sysplex_name attribute 384
 - system_level attribute 384
 - system_name attribute 384
 - system_type attribute 384
- CPI (control program identification) 383
- CPU capability change 257
- CPU configuration 415
- CPU hotplug rules 419
- CPU hotplug, sample configuration file 421
- CPU sysfs attribute
 - book_id 259
 - book_siblings 259
 - core_id 258
 - core_siblings 258
 - dispatching 260
 - polarization 260
- CPU, activating standby 257
- CPU, deactivating operating 258
- cpuplugd, Linux command 415
- CRT 281
- Crypto Express2 281
- Crypto Express3 281
- cryptographic 291
- cryptographic adapter
 - attributes 287
- cryptographic adapters
 - adding and removing dynamically 290
- cryptographic device driver
 - See zcrypt
 - API 291
 - features 281
 - hardware and software prerequisites 283
 - setup 285
- cryptographic devices
 - See also zcrypt
 - for Linux on z/VM 282
- csulincl.h 291
- CTC
 - activating an interface 185
- CTC interface
 - recovery 186
- CTCM
 - buffer attribute 185
 - device driver 179
 - group attribute 181
 - online attribute 184
 - protocol attribute 183
 - subchannels 179
 - type attribute 183

CTCM (*continued*)
 ungroup attribute 182
 cutype
 common CCW attribute 9
 tape attribute 97

D

DASD

access by udev-created device
 nodes 36
 access by VOLSER 35
 alias attribute 57
 availability attribute 42
 boot menu, LPAR example 358
 boot menu, z/VM example 351
 booting from 351, 355
 boxed 42
 control unit attached devices 27
 device driver 27
 device names 33
 discipline attribute 57
 displaying information 429
 displaying overview 461
 eer_enabled attribute 45
 erplog attribute 46
 expires attribute 47
 extended error reporting 28
 failfast attribute 47
 features 27
 forcing online 42
 formatting ECKD 423
 last_known_reservation_state
 attribute 55
 module parameter 37
 online attribute 45, 46
 partitioning 438, 446
 partitions on 28
 performance statistics 426
 performance tuning 504
 raw_track_access attribute 52
 readonly attribute 57
 reservation_policy attribute 54
 statistics 48
 status attribute 58
 uid attribute 58
 use_diag attribute 43, 58
 vendor attribute 58
 virtual 27
 dasd=
 module parameter 37
 dasdfmt, Linux command 423
 dasdstat, Linux command 426
 dasdview, Linux command 429
 dbfsz=, module parameters 67
 DCSS
 access mode 228
 add attribute 227
 device driver 223
 device names 223
 device nodes 223
 loader 336
 minor number 228
 remove attribute 231
 save attribute 229
 shared attribute 229

dcssblk.segments=, module
 parameter 224
 deactivating operating CPU 258
 decryption 281
 depth
 cryptographic adapter attribute 287
 determine channel path usage 389
 device bus-ID 9
 of a qeth interface 130
 device driver
 crypto 281
 CTCM 179
 DASD 27
 DCSS 223
 HyperSockets 109
 in sysfs 11
 LCS 173
 monitor stream application 203
 network 107
 OSA-Express (QDIO) 109
 overview 8
 pseudo-random number 293
 qeth 109
 SCSI-over-Fibre Channel 61
 smsgiucv_app 243
 tape 91
 vmcp 241
 vmur 221
 watchdog 237
 XPRAM 103
 z/VM *MONITOR record reader 207
 z/VM recording 213
 z90crypt 281
 zfcf 61
 device names 3
 console 301
 DASD 33
 DCSS 223
 random number 293
 tape 92
 vmur 221
 XPRAM 103
 z/VM *MONITOR record 209
 z/VM recording 213
 device nodes 3
 console 302
 DCSS 223
 random number 293
 SCSI 63
 tape 94
 vmcp 241
 vmur 221
 watchdog 239
 z/VM *MONITOR record 209
 z/VM recording 213
 z90crypt 287
 zfcf 63
 device numbers 3
 device special file
See device nodes
 device_blocked
 zfcf attribute (SCSI device) 80
 devices
 alias 57
 attributes 9
 base 57
 corresponding interfaces 5

devices (*continued*)
 ignoring 520
 in sysfs 9
 working with newly available 10
 devs=, module parameter 104
 devtype
 common CCW attribute 9
 tape attribute 97
 dhcp 162
 DHCP 161
 required options 161
 Direct Access Storage Device
See DASD
 Direct SNMP 165
 disabled wait
 booting stops with 391
 cio_ignore 390
 discipline
 DASD attribute 57
 discontinuous saved segments
See DCSS
 dispatching
 CPU sysfs attribute 260
 dmesg 5
 Documentation directory xi
 domain=
 module parameter 285
 drivers
See device driver
 dump
 creating automatically after kernel
 panic 391
 dump device
 DASD and tape 331
 ECKD DASD 332
 SCSI 334
 dumpconf, Linux command 372
 dumped_frames, zfcf attribute 71
 DVD, loading Linux 358
 Dynamic Host Configuration Protocol
See DHCP
 dynamic routing, and VIPA 148

E

EBCDIC 19
 conversion through cmsfs-fuse 410
 kernel parameters 349
 ECKD 27
 devices 27
 edit characters, z/VM console 319
 EEDK 498
 eer_enabled
 DASD attribute 45
 EKM 498
 emulation of the HMC Operating System
 Messages applet 317
 enable, qeth IP takeover attribute 143
 encoding 411
 encryption 281
 CCA library 286
 libica library 286
 openCryptoki library 286
 performance
 load balancing 284
 RSA requests 284
 encryption key manager 498

- end of line character 318
- Enterprise Storage Server 27
- environment variables
 - TERM 308
 - ZIPLCONF 341
- erplug, DASD attribute 46
- Error Logging System Service 213
- error_frames, zfcip attribute 71
- escape character
 - for terminals 318
- ESS 27
- Ethernet 111
 - interface name 116
 - LAN channel station 173
- etr
 - online attribute 274
- ETR 273
- etr=, kernel parameter 273
- execution protection feature 295
- expanded memory 103
- expires, DASD attribute 47
- ext2 223
- extended error reporting, DASD 28
- extended remote copy 273
- external encrypted data key 498
- external time reference 273

F

- failed
 - zfcip attribute (channel) 73
 - zfcip attribute (port) 77
 - zfcip attribute (SCSI device) 83
- failfast, DASD attribute 47
- fake_broadcast, qeth attribute 142
- Fast Ethernet
 - LAN channel station 173
- FBA devices 27
- FC-HBA 65
- FCP 61
 - channel 61
 - debugging 67
 - device 61
 - traces 67
- FCP LUN access control 66
- fcp_control_requests zfcip attribute 71
- fcp_input_megabytes zfcip attribute 71
- fcp_input_requests zfcip attribute 71
- fcp_lun
 - zfcip attribute (SCSI device) 81
- fcp_lun, zfcip attribute 79
- fcp_output_megabytes zfcip attribute 71
- fcp_output_requests zfcip attribute 71
- fdasd, Linux command 438
- feature
 - execution protection 295
- Fibre Channel 61
- file system
 - hugetlbfs 265
- file systems
 - cmsfs-fuse for z/VM minidisk 410
 - ext2 223
 - ISO9660 92
 - sysfs 7
 - tape 92
 - xip option 223
- FTP server, loading Linux 358

- full-screen mode terminal 308

G

- generating random numbers 290
- getxattr 412
- giga xi
- Gigabit Ethernet 111
 - SNMP 165
- group
 - CTCM attribute 181
 - LCS attribute 174
 - qeth attribute 124
- group devices
 - CTCM 179
 - LCS 173
 - qeth 115
- guest LAN sniffer 163
- guest swapping 390

H

- hardware
 - service level 390
- Hardware Management Console
 - See HMC
- hardware status, z90crypt 288
- hardware_version, zfcip attribute 70
- HBA API 65
- hba_id
 - zfcip attribute (SCSI device) 81
- hba_id, zfcip attribute 79
- High Performance FICON,
 - suppressing 38
- high resolution polling timer 408
- HiperSockets
 - device driver 109
 - interface name 116
- HiperSockets Network Concentrator 156
- HMC 299
 - as terminal 312
 - derfinition 301
 - for booting Linux 348
 - Integrated ASCII console applet 303, 304
 - Operating System Messages
 - applet 303
 - using in LPAR 303
 - using on z/VM 304
- HMC Operating System Messages applet
 - emulation of the 317
- hmc_network attribute 277
- hotplug
 - CCW devices 16
 - memory 261
- hotplug rules
 - CPU 419
 - memory 420
- hotplug, sample configuration file for
 - CPU and memory 421
- hsuid, qeth attribute 128
- hugepages=, kernel parameters 265
- hugetlbfs
 - virtual file system 265
- HVC device driver 305
- hvc_iucv_allow=, kernel parameter 307

- hvc_iucv=, kernel parameter 307
- hw_trap, qeth attribute 136
- hwtype
 - cryptographic adapter attribute 287
- hypervisor
 - service level 390
- hyptop, Linux command 446

I

- IBM compatible disk layout 29
- IBM label partitioning scheme 28
- IBM TotalStorage Enterprise Storage
 - Server 27
- ica_api.h 291
- icainfo, Linux command 455
- icastats, Linux command 456
- IDRC compression 98
- if_name, qeth attribute 130
- Improved Data Recording Capability
 - compression 98
- in_recovery
 - zfcip attribute (channel) 73
 - zfcip attribute (port) 75, 77
 - zfcip attribute (SCSI device) 80, 83
- in_recovery, zfcip attribute 70
- inbound checksum
 - offload operation 140
- Initial Program Load
 - See IPL
- initial RAM disk 349
- Integrated ASCII console applet
 - on HMC 303
- interface
 - MTIO 94
 - network 4
- interface names
 - ctc 180
 - mpc 180
 - overview 4
 - qeth 116, 130
 - versus devices 5
 - vmur 221
- interfaces 291
 - FC-HBA 65
- invalid_crc_count zfcip attribute 71
- invalid_tx_word_count zfcip attribute 71
- iocounterbits
 - zfcip attribute 80
- iodone_cnt
 - zfcip attribute (SCSI device) 80
- ioerr_cnt
 - zfcip attribute (SCSI device) 81
- iorequest_cnt
 - zfcip attribute (SCSI device) 81
- ip 4
- IP address
 - confirming 132
 - duplicate 132
 - takeover 142
 - virtual 147
- IP, service types 127
- ipa_takeover, qeth attributes 142
- IPL 347
 - displaying current settings 469
- NSS 234

- IPL devices
 - for booting 348
 - preparing 321
- IPv6
 - stateless autoconfiguration 116
 - support for 116
- ISO-8859-1 411
- ISO9660 file systems 92
- isolation, qeth attribute 133
- IUCV
 - accessing terminal devices over 312
 - authorizations 250
 - enablement 250
 - maximum number of
 - connections 250
 - OPTION MAXCONN 250
- iucvconn 300
 - set up a z/VM guest virtual machine
 - for 308
 - using on z/VM 305
- iucv tty 308

J

- journaling file systems
 - write barrier 42

K

- KEK 498
- kernel image 349
- kernel module 19
 - af_iucv 251
 - appldata_mem 197
 - appldata_net_sum 197
 - appldata_os 197
 - cmm 253
 - ctcm 181
 - dasd_diag_mod 38
 - dasd_eckd_mod 38
 - dasd_fba_mod 38
 - dasd_mod 37
 - dcssblk 224
 - lcs 174
 - monreader 208
 - monwriter 203
 - prng 293
 - qeth 120
 - qeth_l2 120
 - qeth_l3 120
 - sclp_async 387
 - sclp_cpi 383
 - tape_34xx 95
 - tape_3590 95
 - vmlogrdr 214
 - vmur 221
 - vmwatchdog 238
 - xpram 104
 - z90crypt 285
 - zfcf 67
- kernel panic 363
 - creating dump automatically
 - after 391
- kernel parameter file
 - for z/VM reader 21

- kernel parameter line
 - length limit for booting 22
 - length limit, zi pl 21
- kernel parameters 19, 349
 - and zi pl 327
 - channel measurement facility 379
 - cio_ignore= 520
 - cmf.format= 379
 - cmf.maxchannels= 379
 - mma= 524
 - conflicting 21
 - conmode= 306
 - console= 307
 - encoding 19
 - etr= 273
 - general 519
 - hugepages= 265
 - hvc_iucv_allow= 307
 - hvc_iucv= 307
 - maxcpus= 525
 - mem= 526
 - no_console_suspend 367
 - noresume 367
 - possible_cpus= 527
 - ramdisk_size= 528
 - resume= 367
 - root= 530
 - savesys= 233
 - specifying 19
 - stp= 274
 - vdso= 532
 - vmhalt= 533
 - vmpanic= 534
 - vmppoff= 535
 - vmreboot= 536
 - zi pl 20
- kernel sharing 233
- kernel source tree xi
- key encrypting key 498
- kilo xi

L

- LAN
 - sniffer 162
 - z/VM guest LAN sniffer 163
- LAN channel station
 - See LCS
- LAN, virtual 152
- lancmd_timeout, LCS attribute 176
- large page support 265
- last_known_reservation_state, DASD
 - attribute 55
- layer2, qeth attribute 117
- lcs
 - recover attribute 177
- LCS
 - activating an interface 177
 - device driver 173
 - group attribute 174
 - lancmd_timeout attribute 176
 - online attribute 176
 - subchannels 173
 - ungroup attribute 175
- libica
 - available functions 455
- libica library 286

- lic_version, zfcf attribute 70
- line edit characters, z/VM console 319
- line-mode terminal 308
 - control characters 315
 - special characters 315
- link_failure_count, zfcf attribute 71
- Linux
 - as LAN sniffer 162
- Linux device special file
 - See device nodes
- Linux disk layout 31
- Linux in LPAR mode, booting 355
- Linux on z/VM
 - booting 350
 - reducing memory of 195
- lip_count, zfcf attribute 71
- listxattr 412
- LNX1 labeled disk 31
- load balancing
 - encryption 284
- LOADDEV 352
- login at terminals 309
- LOGREC, z/VM record 213
- long random numbers 290
- loss_of_signal_count, zfcf attribute 71
- loss_of_sync_count, zfcf attribute 71
- LPAR
 - I/O devices, configuring 389
- LPAR Linux, booting 355
- lschp, Linux command 457
- lscss, Linux command 459
- lsdasd, Linux command 461
- lsmem, Linux command 465
- lsqeth
 - command 130
- lsqeth, Linux command 467
- lsreipl, Linux command 469
- lsshut, Linux command 470
- lstape, Linux command 471
- lszcrypt, Linux command 474
- lszfcf, Linux command 476

M

- MAC addresses 117
- MAC header
 - layer2 for qeth 117
- magic sysrequest functions 315
- procfcs 316
- major number 3
 - DASD devices 33
 - pseudo-random number 293
 - tape devices 92
 - XPRAM 103
- management information base 165
- maxcpus=, kernel parameter 525
- maxframe_size
 - zfcf attribute 71
- Media Access Control (MAC)
 - addresses 117
- Medium Access Control (MAC)
 - header 118
- medium_state, tape attribute 98
- mega xi
- mem=, kernel parameter 526
- memory
 - block_size_bytes attribute 262

- memory (*continued*)
 - displaying 465
 - guest, reducing 195
 - hotplug 261
 - setting online and offline 400
- memory hotplug rules 420
- memory hotplug, sample configuration
 - file 421
- memory, expanded 103
- memory, state attribute 262
- menu configuration 337, 342
 - z/VM example 351
- MIB (management information
 - base) 165
- minor number 3
 - DASD devices 33
 - DCSS devices 228
 - pseudo-random number 293
 - tape devices 92
 - XPRAM 103
- modalias
 - cryptographic adapter attribute 287
- mode terminal
 - full-screen 308
- model
 - zfc attribute (SCSI device) 81
- modprobe 19
- module
 - See* kernel module
- module parameter 19
 - sender= 243
- module parameters
 - cmd= 238
 - conceal= 238
 - CPI 383
 - dasd= 37
 - dbfsize= 67
 - dcssblk.segments= 224
 - devs= 104
 - domain= 285
 - mondcss= 203, 209
 - nowayout= 238
 - poll_thread= 285
 - queue_depth= 67
 - sizes= 104
 - system_name= 383
 - XPRAM 104
 - z90crypt 285
- modulus-exponent 281
- mon_fsstatd, command 478
- mon_procd, command 483
- mondcss=, module parameters 203, 209
- monitor stream 197
 - module activation 198
 - on/off 198
 - sampling interval 199
- monitor stream application
 - device driver 203
- mount point
 - debugfs xi
 - procfs xi
 - sysfs xi
- mt-st, package 98
- MTIO interface 94
- MTU
 - qeth 131

- multicast_router, value for qeth router
 - attribute 138
- multiple subchannel set 11

N

- name
 - devices
 - See* device names
 - network interface
 - See* base name
- named saved system 233
 - See* NSS
- net-snmp 165
- network
 - device drivers 107
 - interface names 4
- Network Concentrator 156
- network interfaces 4
- no_console_suspend, kernel
 - parameters 367
- no_prio_queueing, value for qeth
 - priority_queueing attribute 126
- no_router, value for qeth router
 - attribute 138
- node_name
 - zfc attribute 71
 - zfc attribute (port) 75
- node, device
 - See* device nodes
- non-operational terminals
 - preventing re-spawns for 310
- non-priority commands 317
- non-rewinding tape device 91
- noresume, kernel parameters 367
- nos_count, zfc attribute 71
- notices 541
- nowayout=, module parameters 238
- NPIV
 - example 74
 - FCP channel mode 74
 - for FCP channels 67
- NSS 354
- NSS (named saved system) 233
- numbers, random 290

O

- object ID 165
- offline
 - CHPID 15
 - devices 9
- offload operations
 - inbound checksum 140
 - outbound checksum 140
 - TCP segmentation offload (TSO) 140
- OID (object ID) 165
- online
 - CHPID 15
 - common CCW attribute 9
 - cryptographic adapter attribute 288
 - CTCM attribute 184
 - DASD attribute 45, 46
 - etr attribute 274
 - LCS attribute 176
 - qeth attribute 129

- online (*continued*)
 - stp attribute 275
 - tape attribute 96, 97
 - TTY attribute 314
 - zfc attribute 69
- Open Source Development Network,
 - Inc. 165
- openCryptoki 286
- openCryptoki, library 286
- openssl-ibmca, package 283
- operating CPU, deactivating 258
- Operating System Messages applet
 - emulation of the HMC 317
 - on HMC 303
- operation, tape attribute 97
- OPTION MAXCONN 250
- OSA-Express
 - device driver 109
 - LAN channel station 173
 - SNMP subagent support 165
- osasnmpd, OSA-Express SNMP
 - subagent 165
- OSDN (Open Source Development
 - Network, Inc.) 165
- outbound checksum
 - offload operation 140

P

- page pool
 - static 195
 - timed 195
- parallel access volume (PAV) 57
- parameter
 - kernel and module 19
- PARM
 - IPL parameter 234
- partition
 - on DASD 28
 - schemes for DASD 28
 - table 31
 - XPRAM 103
- PAV (parallel access volume) 57
- PAV enablement, suppression 38
- peer_d_id, zfc attribute 70
- peer_wwnn, zfc attribute 70
- peer_wwpn, zfc attribute 70
- performance
 - DASD 48, 426
- permanent_port_name, zfc attribute 71,
 - 74
- permissions
 - S/390 hypervisor file system 270
- physical_s_id, zfc attribute 74
- pimpampom, subchannel attribute 13
- PKCS #11 API 282, 286
- planned changes in channel path
 - availability 389
- polarization
 - CPU sysfs attribute 260
 - values 260
- poll thread
 - disable using chcrypt 408
 - enable using chcrypt 408
- poll_thread
 - cryptographic adapter attribute 288

- poll_thread=
 - module parameter 285
- poll_timeout
 - cryptographic adapter attribute 289
 - set using chcrypt 408
- port_id
 - zfc attribute (port) 76
- port_id, zfc attribute 71
- port_name
 - zfc attribute (port) 76
- port_name, zfc attribute 71
- port_remove, zfc attribute 77
- port_rescan, zfc attribute 74
- port_state
 - zfc attribute (port) 76
- port_type, zfc attribute 71
- portno, qeth attribute 128
- possible_cpus=, kernel parameter 527
- power/state attribute 368
- preferred console 307
- prerequisites 1
- pri=, fstab parameter 368
- prim_seq_protocol_err_count, zfc attribute 71
- primary_connector, value for qeth router attribute 138
- primary_router, value for qeth router attribute 138
- prio_queueing, value for qeth priority_queueing attribute 126
- priority command 317
- priority_queueing, qeth attribute 126
- processors
 - cryptographic 7
- procs
 - appldata 198
 - cio_ignore 521
 - magic sysrequest function 316
 - VLAN 154
- protocol, CTCM attribute 183
- proxy ARP 146
- proxy ARP attributes 123
- pseudo-random number
 - device driver 293
 - device names 293
 - device nodes 293
- PSW
 - disabled wait 391
- purge, z/VM recording attribute 216
- PVMSG 317

Q

- QDIO 115
- qeth
 - activating an interface 131
 - auto-detection 115
 - buffer_count attribute 127
 - card_type attribute 129
 - configuration tool 492
 - device driver 109
 - displaying device overview 467
 - enable attribute for IP takeover 143
 - fake_broadcast attribute 142
 - group attribute 124
 - hsuid attribute 128
 - hw_trap attribute 136

- qeth (*continued*)
 - if_name attribute 130
 - ipa_takeover attributes 142
 - isolation attribute 133
 - layer2 attribute 117
 - MTU 131
 - online attribute 129
 - portno attribute 128
 - priority_queueing attribute 126
 - problem determination attribute 122
 - proxy ARP attributes 123
 - recover attribute 133
 - route4 attribute 137
 - route6 attribute 137
 - sniffer attributes 123
 - subchannels 115
 - summary of attributes 121, 122
 - TCP segmentation offload 141
 - ungroup attribute 125
 - VIPA attributes 123
- qeth interfaces, mapping 5
- qetharp, Linux command 490
- qethconf, Linux command 492
- queue_depth, zfc attribute 82
- queue_depth=, module parameters 67
- queue_ramp_up_period, zfc attribute 82
- queue_type
 - zfc attribute (SCSI device) 81
- queueing, priority 126

R

- RAM disk, initial 349
- ramdisk_size=, kernel parameter 528
- random number
 - device driver 293
 - device names 293
 - device nodes 293
- raw_track_access, DASD attribute 52
- readlink, Linux command 5
- readonly
 - DASD attribute 57
- recording, z/VM recording attribute 215
- recover, lcs attribute 177
- recover, qeth attribute 133
- recovery, CTC interfaces 186
- relative port number
 - qeth 128
- Remote Spooling Communications Subsystem 512
- remove, DCSS attribute 231
- request_count
 - cryptographic adapter attribute 287
- rescan
 - zfc attribute (SCSI device) 84
- reservation_policy, DASD attribute 54
- reset_statistics
 - zfc attribute 71
- respawn prevention 310
- restrictions 1
- resume 365
- resume=, kernel parameters 367
- rev
 - zfc attribute (SCSI device) 81
- rewinding tape device 91
- Rivest-Shamir-Adleman 281

- ro, kernel parameter 529
- roles
 - zfc attribute (port) 76
- root=, kernel parameter 530
- route4, qeth attribute 137
- route6, qeth attribute 137
- router
 - IPv4 router settings 137
 - IPv6 router settings 137
- RPM
 - binutils 296
 - mt-st 98
 - openCryptoki 286
 - openssl-ibmca 283
 - s390utils-libzfcphbaapi 68
 - sg3_utils 471
- RSA 281
- RSA encryption
 - correct length of requests 284
- RSA exponentiation 281
- RSCS 512
- rx_frames, zfc attribute 71
- rx_words, zfc attribute 71

S

- s_id, zfc attribute 74
- S/390 hypervisor file system 267
 - defining access rights 270
- s390utils-libzfcphbaapi, package 68
- sample configuration file for CPU and memory hotplug 421
- sample_count, cmf attribute 381
- save, DCSS attribute 229
- savesys=, kernel parameters 233
- scdp_cpi
 - kernel module 383
- SCSI
 - multipath devices 65
- SCSI devices, in sysfs 79
- SCSI system dumper 334
- scsi_host_no, zfc attribute 79
- scsi_id, zfc attribute 79
- scsi_level
 - zfc attribute (SCSI device) 81
- scsi_logging_level, Linux command 495
- scsi_lun, zfc attribute 79
- scsi_target_id
 - zfc attribute (port) 76
- SCSI-over-Fibre Channel
 - See* zfc
- SCSI-over-Fibre Channel device driver 61
- SCSI, booting from 352, 355
- SE (Support Element) 348
- secondary_unicast 112, 113
- secondary_connector, value for qeth router attribute 138
- secondary_router, value for qeth router attribute 138
- seconds_since_last_reset
 - zfc attribute 71
- secure key encryption 283
- segmentation offload, TCP 141
- sender=, module parameter 243
- serial_number, zfc attribute 71

- service levels
 - reporting to IBM Support 390
- service types, IP 127
- set, CPI attribute 385
- setsockopt 127
- setxattr 412
- sg3_utils, package 471
- shared kernel 233
- shared, DCSS attribute 229
- shutdown actions 371
- Simple Network Management Protocol 165
- sizes=, module parameter 104
- smsgiucv_app
 - device driver 243
- sniffer
 - attributes 123
- sniffer, guest LAN 163
- SNMP 165
- special characters
 - line-mode terminals 315
 - z/VM console 319
- special file
 - See* device nodes
- speed, zfcpx attribute 71
- ssch_rsch_count, cmf attribute 381
- standby CPU, activating 257
- state
 - memory attribute 262
 - zfcpx attribute (SCSI device) 85
- state attribute, power management 368
- state, tape attribute 97
- stateless autoconfiguration, IPv6 116
- static page pool 195
 - reading the size of the 254
- static page pool size
 - setting to avoid guest swapping 390
- static routing, and VIPA 148
- statistics
 - DASD 48, 426
- status
 - DASD attribute 58
- status, CHPID attribute 15
- storage
 - memory hotplug 261
- stp
 - online attribute 275
- STP 273
- stp=, kernel parameter 274
- subchannel
 - multiple set 11
- subchannel set ID 11
- subchannels
 - CCW and CCW group devices 7
 - CTCM 179
 - displaying overview 459
 - in sysfs 12
 - LCS 173
 - qeth 115
- support
 - AF_IUCV address family 249
- Support Element 348
- supported_classes
 - zfcpx attribute (port) 76
- supported_classes, zfcpx attribute 71
- supported_speeds, zfcpx attribute 71
- suspend 365

- swap partition
 - for suspend resume 367
 - priority 368
- swapping
 - avoiding 195
- SYMPTOM, z/VM record 213
- syntax diagrams xii
- sysfs 7
- sysplex_name, CPI attribute 384
- system states
 - displaying current settings 470
- system time 273
- system time protocol 273
- system_level, CPI attribute 384
- system_name, CPI attribute 384
- system_name=, module parameter 383
- system_type, CPI attribute 384

T

- tape
 - block device 91
 - blocksize attribute 97
 - booting from 350, 355
 - character device 91
 - cmb_enable attribute 97
 - cutype attribute 97
 - device names 92
 - device nodes 94
 - devtype attribute 97
 - display support 502
 - displaying overview 471
 - encryption support 498
 - file systems 92
 - IDRC compression 98
 - loading and unloading 99
 - medium_state attribute 98
 - MTIO interface 94
 - online attribute 96, 97
 - operation attribute 97
 - state attribute 97
- tape device driver 91
- tape390_crypt, Linux command 498
- tape390_display, Linux command 502
- TCP segmentation offload 141
- TCP segmentation offload (TSO)
 - offload operation 140
- TCP/IP
 - ARP 119
 - DHCP 161
 - point-to-point 179
 - service machine 180
- TERM, environment variable 308
- terminal
 - 3270, switching the views of 313
 - accessing over IUCV 312
 - CCW, switching device on- or offline 314
 - enabling user logins with /etc/sysconfig/init 309
 - enabling user logins with Upstart 309
 - line-mode 308
 - mainframe versus Linux 301
 - non-operational, preventing re-spawns for 310

- terminal (*continued*)
 - provided by the 3270 terminal device driver 308
- terminals
 - escape character 318
- tgid_bind_type, zfcpx attribute 71
- time-of-day clock 273
- timed page pool 195
 - reading the size of the 254
- timed page pool size
 - setting to avoid guest swapping 390
- timeout
 - zfcpx attribute (SCSI device) 84
- timeout for LCS LAN commands 176
- TOD clock 273
- trademarks 542
- troubleshooting 389
- TSO
 - offload operation 140
- TTY
 - console devices 301
 - online attribute 314
- ttyrun 310
- tunedasd, Linux command 504
- tx_frames, zfcpx attribute 71
- tx_words, zfcpx attribute 71
- type
 - cryptographic adapter attribute 287
 - zfcpx attribute (SCSI device) 81
- type, CTCM attribute 183

U

- uid
 - DASD attribute 58
- ungroup
 - CTCM attribute 182
 - LCS attribute 175
 - qeth attribute 125
- unit_add, zfcpx attribute 78
- unit_remove, zfcpx attribute 86
- unplanned changes in channel path
 - availability 389
- Upstart
 - user login to terminal 309
- use_diag
 - DASD attribute 58
- use_diag, DASD attribute 43
- user_mode, kernel parameter 531

V

- VACM (View-Based Access Control Mechanism) 167
- vdso=, kernel parameter 532
- vendor
 - DASD attribute 58
 - zfcpx attribute (SCSI device) 81
- View-Based Access Control Mechanism (VACM) 167
- VINPUT 317
 - CP command 318
- VIPA (virtual IP address)
 - attributes 123
 - description 147
 - example 148

VIPA (virtual IP address) *(continued)*
 static routing 148
 usage 148
 virtual
 DASD 27
 IP address 147
 LAN 152
 virtual dynamic shared object 532
 VLAN (virtual LAN) 152
 vmcp
 device driver 241
 device nodes 241
 vmcp, Linux command 507
 vmhalt=, kernel parameter 533
 vmpanic=, kernel parameter 534
 vmpoff=, kernel parameter 535
 vmreboot=, kernel parameter 536
 VMRM 196
 VMSG 317
 vmur
 device driver 221
 device names 221
 device nodes 221
 vmur, kernel module 221
 vmur, Linux command 509
 VOL1 labeled disk 29
 VOLSER, DASD device access by 35
 volume label 30
 Volume Table Of Contents 31
 VTOC 31

W

watchdog
 device driver 237
 device node 239
 write barrier 42
 wwpn
 zfc attribute (SCSI device) 81
 wwpn, zfc attribute 74, 79

X

x3270 code page 311
 XPRAM
 device driver 103
 features 103
 module parameter 104
 partitions 103
 XRC, extended remote copy 273

Z

z/VM
 guest LAN sniffer 163
 monitor stream 197
 z/VM *MONITOR record
 device name 209
 device node 209
 z/VM *MONITOR record reader
 device driver 207
 z/VM console, line edit characters 319
 z/VM discontinuous saved segments
See DCSS
 z/VM reader
 booting from 354

z/VM recording
 device names 213
 device nodes 213
 z/VM recording device driver 213
 autopurge attribute 216
 autorecording attribute 215
 purge attribute 216
 recording attribute 215
 z/VM spool file queues 509
 z90crypt
 device driver 281
 device nodes 287
 hardware status 288
 module parameter 285
 starting device driver 288
 z90crypt sysfs attribute
 poll_thread 288
 zcrypt configuration 408, 474
 zfc
 access_denied attribute (port) 75
 access_denied attribute (SCSI device) 80
 access_shared attribute 80
 card_version attribute 70
 device driver 61
 device nodes 63
 device_blocked attribute (SCSI device) 80
 dumped_frames attribute 71
 error_frames attribute 71
 failed attribute (channel) 73
 failed attribute (port) 77
 failed attribute (SCSI device) 83
 fcp_control_requests attribute 71
 fcp_input_megabytes attribute 71
 fcp_input_requests attribute 71
 fcp_lun attribute 79
 fcp_lun attribute (SCSI device) 81
 fcp_output_megabytes attribute 71
 fcp_output_requests attribute 71
 hardware_version attribute 70
 hba_id attribute 79
 hba_id attribute (SCSI device) 81
 in_recovery attribute 70
 in_recovery attribute (channel) 73
 in_recovery attribute (port) 75, 77
 in_recovery attribute (SCSI device) 80, 83
 invalid_crc_count attribute 71
 invalid_tx_word_count attribute 71
 iocounterbits attribute 80
 iodone_cnt attribute (SCSI device) 80
 ioerr_cnt attribute (SCSI device) 81
 iorequest_cnt attribute (SCSI device) 81
 lic_version attribute 70
 link_failure_count attribute 71
 lip_count attribute 71
 loss_of_signal_count attribute 71
 loss_of_sync_count attribute 71
 maxframe_siz attribute 71
 model attribute (SCSI device) 81
 node_name attribute 71
 node_name attribute (port) 75
 nos_count attribute 71
 online attribute 69
 peer_d_id attribute 70

zfc *(continued)*
 peer_wwnn attribute 70
 peer_wwpn attribute 70
 permanent_port_name attribute 71, 74
 physical_s_id attribute 74
 port_id attribute 71
 port_id attribute (port) 76
 port_name attribute 71
 port_name attribute (port) 76
 port_remove attribute 77
 port_rescan attribute 74
 port_state attribute (port) 76
 port_type attribute 71
 prim_seq_protocol_err_count attribute 71
 queue_depth attribute 82
 queue_ramp_up_period attribute 82
 queue_type attribute (SCSI device) 81
 rescan attribute (SCSI device) 84
 reset_statistics attribute 71
 rev attribute (SCSI device) 81
 roles attribute (port) 76
 rx_frames attribute 71
 rx_words attribute 71
 s_id attribute 74
 scsi_host_no attribute 79
 scsi_id attribute 79
 scsi_level attribute (SCSI device) 81
 scsi_lun attribute 79
 scsi_target_id attribute (port) 76
 seconds_since_last_reset attribute 71
 serial_number attribute 71
 speed attribute 71
 state attribute (SCSI device) 85
 supported_classes attribute 71
 supported_classes attribute (port) 76
 supported_speeds attribute 71
 tgid_bind_type attribute 71
 timeout attribute (SCSI device) 84
 tx_frames attribute 71
 tx_words attribute 71
 type attribute (SCSI device) 81
 unit_add attribute 78
 unit_remove attribute 86
 vendor attribute (SCSI device) 81
 wwpn attribute 74, 79
 wwpn attribute (SCSI device) 81
 zfc HBA API 65
 zfc traces 67
 zi
 and kernel parameters 327
 base functions 321
 configuration file 341
 Linux command 321
 menu configurations 342
 parameters 338
 zi
 boot menu 301
 ZIPLCONF, environment variable 341
 znetconf, Linux command 516

Readers' Comments — We'd Like to Hear from You

**Linux on System z
Device Drivers, Features, and Commands
on Red Hat Enterprise Linux 6.3**

Publication No. SC34-2597-03

We appreciate your comments about this publication. Please comment on specific errors or omissions, accuracy, organization, subject matter, or completeness of this book. The comments you send should pertain to only the information in this manual or product and the way in which the information is presented.

For technical questions and information about products and prices, please contact your IBM branch office, your IBM business partner, or your authorized remarketer.

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute your comments in any way it believes appropriate without incurring any obligation to you. IBM or any other organizations will only use the personal information that you supply to contact you about the issues that you state on this form.

Comments:

Thank you for your support.

Submit your comments using one of these channels:

- Send your comments to the address on the reverse side of this form.
- Send your comments via email to: eservdoc@de.ibm.com

If you would like a response from IBM, please fill in the following information:

Name

Address

Company or Organization

Phone No.

Email address



Cut or Fold
Along Line

Fold and Tape

Please do not staple

Fold and Tape

PLACE
POSTAGE
STAMP
HERE

IBM Deutschland Research & Development GmbH
Information Development
Department 3248
Schoenaicher Strasse 220
71032 Boeblingen
Germany

Fold and Tape

Please do not staple

Fold and Tape

Cut or Fold
Along Line



SC34-2597-03

