

Power Systems

Adapters for the 9080-M9S

IBM

Note

Before using this information and the product it supports, read the information in [“Safety notices” on page v](#), [“Notices” on page 41](#), the *IBM Systems Safety Notices* manual, G229-9054, and the *IBM Environmental Notices and User Guide*, Z125-5823.

This edition applies to IBM® Power Systems servers that contain the POWER9™ processor and to all associated models.

© **Copyright International Business Machines Corporation 2018, 2021.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

- Safety notices.....V**

- Installing PCIe adapters..... 1**
 - Preparing the system..... 1
 - Installing an adapter..... 8
 - Preparing the system for operation.....17
 - Related procedures for installing adapters..... 22
 - Avoiding electric shock..... 22
 - Handling static-sensitive devices..... 23
 - Updating the worldwide port name..... 23
 - Removing and replacing the tailstock on an adapter 23
 - Hot-plug manager access for AIX..... 28
 - Installing the AIX device driver software..... 31
 - Installing or replacing an adapter with the system power turned on in a Virtual I/O Server.....32
 - Verifying that the hot-plug adapter tools are installed for the Linux operating system..... 35
 - Checking the amount of remaining life in NVMe devices..... 36

- Notices.....41**
 - Accessibility features for IBM Power Systems servers..... 42
 - Privacy policy considerations 43
 - Trademarks..... 43
 - Electronic emission notices..... 43
 - Class A Notices..... 43
 - Class B Notices..... 47
 - Terms and conditions.....49

Safety notices

Safety notices may be printed throughout this guide:

- **DANGER** notices call attention to a situation that is potentially lethal or extremely hazardous to people.
- **CAUTION** notices call attention to a situation that is potentially hazardous to people because of some existing condition.
- **Attention** notices call attention to the possibility of damage to a program, device, system, or data.

World Trade safety information

Several countries require the safety information contained in product publications to be presented in their national languages. If this requirement applies to your country, safety information documentation is included in the publications package (such as in printed documentation, on DVD, or as part of the product) shipped with the product. The documentation contains the safety information in your national language with references to the U.S. English source. Before using a U.S. English publication to install, operate, or service this product, you must first become familiar with the related safety information documentation. You should also refer to the safety information documentation any time you do not clearly understand any safety information in the U.S. English publications.

Replacement or additional copies of safety information documentation can be obtained by calling the IBM Hotline at 1-800-300-8751.

German safety information

Das Produkt ist nicht für den Einsatz an Bildschirmarbeitsplätzen im Sinne § 2 der Bildschirmarbeitsverordnung geeignet.

Laser safety information

IBM servers can use I/O cards or features that are fiber-optic based and that utilize lasers or LEDs.

Laser compliance

IBM servers may be installed inside or outside of an IT equipment rack.



DANGER: When working on or around the system, observe the following precautions:

Electrical voltage and current from power, telephone, and communication cables are hazardous. To avoid a shock hazard: If IBM supplied the power cord(s), connect power to this unit only with the IBM provided power cord. Do not use the IBM provided power cord for any other product. Do not open or service any power supply assembly. Do not connect or disconnect any cables or perform installation, maintenance, or reconfiguration of this product during an electrical storm.



- The product might be equipped with multiple power cords. To remove all hazardous voltages, disconnect all power cords. For AC power, disconnect all power cords from their AC power source. For racks with a DC power distribution panel (PDP), disconnect the customer's DC power source to the PDP.
- When connecting power to the product ensure all power cables are properly connected. For racks with AC power, connect all power cords to a properly wired and grounded electrical outlet. Ensure that the outlet supplies proper voltage and phase rotation according to the system rating plate. For racks with a DC power distribution panel (PDP), connect the customer's DC power source to the PDP. Ensure that the proper polarity is used when attaching the DC power and DC power return wiring.
- Connect any equipment that will be attached to this product to properly wired outlets.

- When possible, use one hand only to connect or disconnect signal cables.
- Never turn on any equipment when there is evidence of fire, water, or structural damage.
- Do not attempt to switch on power to the machine until all possible unsafe conditions are corrected.
- When performing a machine inspection: Assume that an electrical safety hazard is present. Perform all continuity, grounding, and power checks specified during the subsystem installation procedures to ensure that the machine meets safety requirements. Do not attempt to switch power to the machine until all possible unsafe conditions are corrected. Before you open the device covers, unless instructed otherwise in the installation and configuration procedures: Disconnect the attached AC power cords, turn off the applicable circuit breakers located in the rack power distribution panel (PDP), and disconnect any telecommunications systems, networks, and modems.
- Connect and disconnect cables as described in the following procedures when installing, moving, or opening covers on this product or attached devices.

To Disconnect: 1) Turn off everything (unless instructed otherwise). 2) For AC power, remove the power cords from the outlets. 3) For racks with a DC power distribution panel (PDP), turn off the circuit breakers located in the PDP and remove the power from the Customer's DC power source. 4) Remove the signal cables from the connectors. 5) Remove all cables from the devices.

To Connect: 1) Turn off everything (unless instructed otherwise). 2) Attach all cables to the devices. 3) Attach the signal cables to the connectors. 4) For AC power, attach the power cords to the outlets. 5) For racks with a DC power distribution panel (PDP), restore the power from the Customer's DC power source and turn on the circuit breakers located in the PDP. 6) Turn on the devices.



- Sharp edges, corners and joints may be present in and around the system. Use care when handling equipment to avoid cuts, scrapes and pinching. (D005)

(R001 part 1 of 2):



DANGER: Observe the following precautions when working on or around your IT rack system:

- Heavy equipment—personal injury or equipment damage might result if mishandled.
- Always lower the leveling pads on the rack cabinet.
- Always install stabilizer brackets on the rack cabinet if provided, unless the earthquake option is to be installed.
- To avoid hazardous conditions due to uneven mechanical loading, always install the heaviest devices in the bottom of the rack cabinet. Always install servers and optional devices starting from the bottom of the rack cabinet.
- Rack-mounted devices are not to be used as shelves or work spaces. Do not place objects on top of rack-mounted devices. In addition, do not lean on rack mounted devices and do not use them to stabilize your body position (for example, when working from a ladder).



- Stability hazard:
 - The rack may tip over causing serious personal injury.
 - Before extending the rack to the installation position, read the installation instructions.
 - Do not put any load on the slide-rail mounted equipment mounted in the installation position.
 - Do not leave the slide-rail mounted equipment in the installation position.
- Each rack cabinet might have more than one power cord.
 - For AC powered racks, be sure to disconnect all power cords in the rack cabinet when directed to disconnect power during servicing.

- For racks with a DC power distribution panel (PDP), turn off the circuit breaker that controls the power to the system unit(s), or disconnect the customer’s DC power source, when directed to disconnect power during servicing.
- Connect all devices installed in a rack cabinet to power devices installed in the same rack cabinet. Do not plug a power cord from a device installed in one rack cabinet into a power device installed in a different rack cabinet.
- An electrical outlet that is not correctly wired could place hazardous voltage on the metal parts of the system or the devices that attach to the system. It is the responsibility of the customer to ensure that the outlet is correctly wired and grounded to prevent an electrical shock. (R001 part 1 of 2)

(R001 part 2 of 2):



CAUTION:

- Do not install a unit in a rack where the internal rack ambient temperatures will exceed the manufacturer's recommended ambient temperature for all your rack-mounted devices.
- Do not install a unit in a rack where the air flow is compromised. Ensure that air flow is not blocked or reduced on any side, front, or back of a unit used for air flow through the unit.
- Consideration should be given to the connection of the equipment to the supply circuit so that overloading of the circuits does not compromise the supply wiring or overcurrent protection. To provide the correct power connection to a rack, refer to the rating labels located on the equipment in the rack to determine the total power requirement of the supply circuit.
- *(For sliding drawers.)* Do not pull out or install any drawer or feature if the rack stabilizer brackets are not attached to the rack or if the rack is not bolted to the floor. Do not pull out more than one drawer at a time. The rack might become unstable if you pull out more than one drawer at a time.



- *(For fixed drawers.)* This drawer is a fixed drawer and must not be moved for servicing unless specified by the manufacturer. Attempting to move the drawer partially or completely out of the rack might cause the rack to become unstable or cause the drawer to fall out of the rack. (R001 part 2 of 2)



CAUTION: Removing components from the upper positions in the rack cabinet improves rack stability during relocation. Follow these general guidelines whenever you relocate a populated rack cabinet within a room or building.

- Reduce the weight of the rack cabinet by removing equipment starting at the top of the rack cabinet. When possible, restore the rack cabinet to the configuration of the rack cabinet as you received it. If this configuration is not known, you must observe the following precautions:
 - Remove all devices in the 32U position and above.
 - Ensure that the heaviest devices are installed in the bottom of the rack cabinet.

- Ensure that there are little-to-no empty U-levels between devices installed in the rack cabinet below the 32U level, unless the received configuration specifically allowed it.
- If the rack cabinet you are relocating is part of a suite of rack cabinets, detach the rack cabinet from the suite.
- If the rack cabinet you are relocating was supplied with removable outriggers they must be reinstalled before the cabinet is relocated.
- Inspect the route that you plan to take to eliminate potential hazards.
- Verify that the route that you choose can support the weight of the loaded rack cabinet. Refer to the documentation that comes with your rack cabinet for the weight of a loaded rack cabinet.
- Verify that all door openings are at least 760 x 2083 mm (30 x 82 in.).
- Ensure that all devices, shelves, drawers, doors, and cables are secure.
- Ensure that the four leveling pads are raised to their highest position.
- Ensure that there is no stabilizer bracket installed on the rack cabinet during movement.
- Do not use a ramp inclined at more than 10 degrees.
- When the rack cabinet is in the new location, complete the following steps:
 - Lower the four leveling pads.
 - Install stabilizer brackets on the rack cabinet or in an earthquake environment bolt the rack to the floor.
 - If you removed any devices from the rack cabinet, repopulate the rack cabinet from the lowest position to the highest position.
- If a long-distance relocation is required, restore the rack cabinet to the configuration of the rack cabinet as you received it. Pack the rack cabinet in the original packaging material, or equivalent. Also lower the leveling pads to raise the casters off of the pallet and bolt the rack cabinet to the pallet.

(R002)

(L001)



DANGER: Hazardous voltage, current, or energy levels are present inside any component that has this label attached. Do not open any cover or barrier that contains this label. (L001)

(L002)




DANGER: Rack-mounted devices are not to be used as shelves or work spaces. Do not place objects on top of rack-mounted devices. In addition, do not lean on rack-mounted devices and do not use them to stabilize your body position (for example, when working from a ladder). Stability hazard:

- The rack may tip over causing serious personal injury.
- Before extending the rack to the installation position, read the installation instructions.

- Do not put any load on the slide-rail mounted equipment mounted in the installation position.
- Do not leave the slide-rail mounted equipment in the installation position.

(L002)

(L003)



or



or





or



or






 **DANGER:** Multiple power cords. The product might be equipped with multiple AC power cords or multiple DC power cables. To remove all hazardous voltages, disconnect all power cords and power cables. (L003)


(L007)




 **CAUTION:** A hot surface nearby. (L007)

(L008)



 **CAUTION:** Hazardous moving parts nearby. (L008)

All lasers are certified in the U.S. to conform to the requirements of DHHS 21 CFR Subchapter J for class 1 laser products. Outside the U.S., they are certified to be in compliance with IEC 60825 as a class 1 laser product. Consult the label on each part for laser certification numbers and approval information.

 **CAUTION:** This product might contain one or more of the following devices: CD-ROM drive, DVD-ROM drive, DVD-RAM drive, or laser module, which are Class 1 laser products. Note the following information:

- Do not remove the covers. Removing the covers of the laser product could result in exposure to hazardous laser radiation. There are no serviceable parts inside the device.
- Use of the controls or adjustments or performance of procedures other than those specified herein might result in hazardous radiation exposure.

(C026)



CAUTION: Data processing environments can contain equipment transmitting on system links with laser modules that operate at greater than Class 1 power levels. For this reason, never look into the end of an optical fiber cable or open receptacle. Although shining light into one end and looking into the other end of a disconnected optical fiber to verify the continuity of optic fibers may not injure the eye, this procedure is potentially dangerous. Therefore, verifying the continuity of optical fibers by shining light into one end and looking at the other end is not recommended. To verify continuity of a fiber optic cable, use an optical light source and power meter. (C027)



CAUTION: This product contains a Class 1M laser. Do not view directly with optical instruments. (C028)



CAUTION: Some laser products contain an embedded Class 3A or Class 3B laser diode. Note the following information:

- Laser radiation when open.
- Do not stare into the beam, do not view directly with optical instruments, and avoid direct exposure to the beam. (C030)

(C030)



CAUTION: The battery contains lithium. To avoid possible explosion, do not burn or charge the battery.

Do Not:

- Throw or immerse into water
- Heat to more than 100 degrees C (212 degrees F)
- Repair or disassemble

Exchange only with the IBM-approved part. Recycle or discard the battery as instructed by local regulations. In the United States, IBM has a process for the collection of this battery. For information, call 1-800-426-4333. Have the IBM part number for the battery unit available when you call. (C003)



CAUTION: Regarding IBM provided VENDOR LIFT TOOL:

- Operation of LIFT TOOL by authorized personnel only.
- LIFT TOOL intended for use to assist, lift, install, remove units (load) up into rack elevations. It is not to be used loaded transporting over major ramps nor as a replacement for such designated tools like pallet jacks, walkies, fork trucks and such related relocation practices. When this is not practicable, specially trained persons or services must be used (for instance, riggers or movers).
- Read and completely understand the contents of LIFT TOOL operator's manual before using. Failure to read, understand, obey safety rules, and follow instructions may result in property damage and/or personal injury. If there are questions, contact the vendor's service and support. Local paper manual must remain with machine in provided storage sleeve area. Latest revision manual available on vendor's web site.
- Test verify stabilizer brake function before each use. Do not over-force moving or rolling the LIFT TOOL with stabilizer brake engaged.
- Do not raise, lower or slide platform load shelf unless stabilizer (brake pedal jack) is fully engaged. Keep stabilizer brake engaged when not in use or motion.
- Do not move LIFT TOOL while platform is raised, except for minor positioning.
- Do not exceed rated load capacity. See LOAD CAPACITY CHART regarding maximum loads at center versus edge of extended platform.
- Only raise load if properly centered on platform. Do not place more than 200 lb (91 kg) on edge of sliding platform shelf also considering the load's center of mass/gravity (CoG).
- Do not corner load the platforms, tilt riser, angled unit install wedge or other such accessory options. Secure such platforms -- riser tilt, wedge, etc options to main lift shelf or forks in all four (4x or all other provisioned mounting) locations with provided hardware only, prior to use. Load objects are designed to slide on/off smooth platforms without appreciable force, so take care not

to push or lean. Keep riser tilt [adjustable angling platform] option flat at all times except for final minor angle adjustment when needed.

- Do not stand under overhanging load.
- Do not use on uneven surface, incline or decline (major ramps).
- Do not stack loads.
- Do not operate while under the influence of drugs or alcohol.
- Do not support ladder against LIFT TOOL (unless the specific allowance is provided for one following qualified procedures for working at elevations with this TOOL).
- Tipping hazard. Do not push or lean against load with raised platform.
- Do not use as a personnel lifting platform or step. No riders.
- Do not stand on any part of lift. Not a step.
- Do not climb on mast.
- Do not operate a damaged or malfunctioning LIFT TOOL machine.
- Crush and pinch point hazard below platform. Only lower load in areas clear of personnel and obstructions. Keep hands and feet clear during operation.
- No Forks. Never lift or move bare LIFT TOOL MACHINE with pallet truck, jack or fork lift.
- Mast extends higher than platform. Be aware of ceiling height, cable trays, sprinklers, lights, and other overhead objects.
- Do not leave LIFT TOOL machine unattended with an elevated load.
- Watch and keep hands, fingers, and clothing clear when equipment is in motion.
- Turn Winch with hand power only. If winch handle cannot be cranked easily with one hand, it is probably over-loaded. Do not continue to turn winch past top or bottom of platform travel. Excessive unwinding will detach handle and damage cable. Always hold handle when lowering, unwinding. Always assure self that winch is holding load before releasing winch handle.
- A winch accident could cause serious injury. Not for moving humans. Make certain clicking sound is heard as the equipment is being raised. Be sure winch is locked in position before releasing handle. Read instruction page before operating this winch. Never allow winch to unwind freely. Freewheeling will cause uneven cable wrapping around winch drum, damage cable, and may cause serious injury.
- This TOOL must be maintained correctly for IBM Service personnel to use it. IBM shall inspect condition and verify maintenance history before operation. Personnel reserve the right not to use TOOL if inadequate. (C048)

Power and cabling information for NEBS (Network Equipment-Building System) GR-1089-CORE

The following comments apply to the IBM servers that have been designated as conforming to NEBS (Network Equipment-Building System) GR-1089-CORE:

The equipment is suitable for installation in the following:

- Network telecommunications facilities
- Locations where the NEC (National Electrical Code) applies

The intrabuilding ports of this equipment are suitable for connection to intrabuilding or unexposed wiring or cabling only. The intrabuilding ports of this equipment *must not* be metallically connected to the interfaces that connect to the OSP (outside plant) or its wiring. These interfaces are designed for use as intrabuilding interfaces only (Type 2 or Type 4 ports as described in GR-1089-CORE) and require isolation from the exposed OSP cabling. The addition of primary protectors is not sufficient protection to connect these interfaces metallically to OSP wiring.

Note: All Ethernet cables must be shielded and grounded at both ends.

The ac-powered system does not require the use of an external surge protection device (SPD).

The dc-powered system employs an isolated DC return (DC-I) design. The DC battery return terminal *shall not* be connected to the chassis or frame ground.

The dc-powered system is intended to be installed in a common bonding network (CBN) as described in GR-1089-CORE.

Installing adapters in the 9080-M9S system

Find information about installing adapters in the IBM Power® System E980 (9080-M9S) server.

About this task

Note: Installing this feature is a customer task. You can complete this task yourself, or contact a service provider to complete the task for you. You might be charged a fee by the service provider for this service.

If your system is managed by the Hardware Management Console (HMC), use the HMC to complete the steps for installing an adapter in the system. For instructions, see [Installing a part by using the HMC](http://www.ibm.com/support/knowledgecenter/POWER9/p9haj/hmcinstall.htm) (www.ibm.com/support/knowledgecenter/POWER9/p9haj/hmcinstall.htm).

If your system is not managed by an HMC, complete the steps in the following procedures to install an adapter in the system.

Preparing the 9080-M9S system to install an adapter

To prepare the system to install an adapter, complete the steps in this procedure.

Before you begin

Note: If you are installing a PCIe3 cable adapter to attach your server to an EMX0 PCIe3 expansion drawer, you must ensure that you have the correct PCIe3 cable adapter and expansion drawer cable that works with the PCIe3 6-slot fanout module that you have in your EMX0 PCIe3 expansion drawer.

- If you have a CCIN **50CB** PCIe3 6-slot fanout module:
 - You must use one of the following PCIe3 cable adapters:
 - FC EJ08 (CCIN 2CE2)
 - FC EJ07 (CCIN 6B52)
 - FC EJ05 (CCIN 2B1C)
 - You must use one of the following expansion drawer cables: FC ECC6, FC ECC7, FC ECC8, FC ECC9, FC ECCR, FC ECCS, FC ECCX, FC ECCY, or FC ECCZ.
- If you have a CCIN **50CD** PCIe3 6-slot fanout module:
 - You must install one of the following PCIe3 cable adapters:
 - FC EJ19 (CCIN 6B53)
 - FC EJ1R (CCIN 58FF)
 - FC EJ20 (CCIN 2CF5)
 - You must use one of the following expansion drawer cables: FC ECCR, FC ECCS, FC ECCX, FC ECCY, or FC ECCZ.

Procedure

1. If you are installing a PCIe3 cable adapter with the system power turned on, you must install the PCIe3 cable adapter by using the HMC. Otherwise, you must install the PCIe3 cable adapter with the system power turned off.
2. Ensure that the required software is installed to support the new feature. See the [Power Systems Prerequisites](#) website.

Important: If you are installing a PCIe3 cable adapter and want to connect an EMX0 PCIe3 expansion drawer via the HMC, you must have the HMC driver 9.1.921.0 or later installed.

3. Take appropriate precautions for avoiding electric shock and for handling static-sensitive devices. For more information, see [“Avoiding electric shock”](#) on page 22 and [“Handling static-sensitive devices”](#) on page 23.
4. If you are installing a PCIe3 cable adapter, ensure that the target slot is Unassigned in the I/O properties field for the managed server you are working on.
5. If applicable, open the rack door at the rear of the system.
6. Review the following figures that show the locations of the adapter and cassette slots and the locations of the LEDs for the adapters. The adapter cassettes that contain the adapters are installed in the rear of the system.

The number of the adapter slots that are available in the system depends on the number of system processors in the system. For the adapter placement information for the available slots in this system, see [Adapter placement rules and slot priorities for the 9080-M9S](#).

The adapter locations have six digits. The cassette locations have four digits.




Figure 1. Locations for the adapters and cassettes in the 9080-M9S system

The adapter has three LEDs that indicate the following status:

- A power/activity LED (green)
- An identify function LED (amber) for the adapter (labeled C1)
- An identify function LED (amber) for the cassette (labeled with an exclamation mark)




Figure 2. Adapter LED locations in a 9080-M9S system

7. Choose from the following options:

- If you want to install an adapter when the system power is turned off, continue with step “8” on [page 3](#).
- If the system power is turned on and if the AIX® operating system controls the slot, continue with step “11” on [page 5](#).
- If the system power is turned on and if the IBM i operating system controls the slot, continue with step “12” on [page 5](#).
- If the system power is turned on and if the Linux® operating system controls the slot, continue with step “13” on [page 6](#).

8. To prepare the system to install an adapter when the system is powered off, complete the following steps:

- a) Activate the identify function. For instructions, see [Identifying a part \(www.ibm.com/support/knowledgecenter/POWER9/p9haj/sal.htm\)](http://www.ibm.com/support/knowledgecenter/POWER9/p9haj/sal.htm).
- b) Physically verify that the slot you identified is where you want to install the adapter.
 - Use the blue identify LED on the enclosure to locate the system. Ensure that the serial number of the system matches the serial number to be serviced.
 - Look for a flashing amber LED, which identifies the unoccupied slot that was selected by using the identify function.

- c) Stop the system. For instructions, see [Stopping a system](http://www.ibm.com/support/knowledgecenter/POWER9/p9haj/crustopsys.htm) (www.ibm.com/support/knowledgecenter/POWER9/p9haj/crustopsys.htm).
9. If you chose to complete this repair with the power off, label and disconnect both UPIC cables from the system control unit.
- UPIC cable locations are P1-C1-T1 and P1-C2-T1.
- a. Remove the white plastic lock **(A)** from the plug housing.




Figure 3. Removing the UPIC cable lock

- b. Push down on the blue cable latch **(B)** and pull out the UPIC cable from the system control unit.




Figure 4. Removing the UPIC cable from the system control unit

10. Continue with step “14” on page 7.
11. To prepare the system to install an adapter by using the AIX operating system, complete the following steps:
 - a) Log in to the console as root user to access the Hot Plug Manager.
 - b) At the command line, type `smitty`.
 - c) Select **Devices > PCI Hot Plug Manager** and press Enter.
The **PCI Hot-Plug Manager** menu displays.

For more information about the menu options in the **PCI Hot-Plug Manager** screen, see [Hot-plug manager menu \(www.ibm.com/support/knowledgecenter/POWER9/p9hak/p9hak_hotplug_menu.htm\)](http://www.ibm.com/support/knowledgecenter/POWER9/p9hak/p9hak_hotplug_menu.htm).
 - d) From the PCI Hot-Plug Manager menu, select **Add a PCI Hot-Plug Adapter**, and then press Enter.
 - e) Select the appropriate slot from the list that is displayed on the screen, and then press Enter.
 - f) Physically verify that the slot you identified is where you want to install the adapter.
 - Use the blue identify LED on the enclosure to locate the system. Ensure that the serial number of the system matches the serial number to be serviced.
 - Look for a flashing amber LED, which identifies the unoccupied slot that was selected by using the identify function.
 - g) Continue with step “14” on page 7.
12. To prepare the system to install an adapter by using the IBM i operating system, complete the following steps:
 - a) If necessary, start a System Service Tools (SST) session by typing `stsrst` on the command line of the Main Menu and then press Enter.

- b) Type your service tools user ID and service tools password on the **System Service Tools Sign On** display, and then press Enter.
 - c) Select **Start a service tool > Hardware service manager > Packaging hardware resources (system, frames, cards)**.
 - d) Type 9 (Hardware contained within package) in the **System Unit** field or **Expansion Unit** field of the unit where you are installing the adapter. Press Enter.
 - e) Select the **Include empty positions** option.
 - f) Select **Concurrent Maintenance** for the slot in which you want to install the adapter, and then press Enter.
 - g) Select the **Toggle LED blink off/on** option. A light-emitting diode (LED) flashes identifying the slot that you selected.
 - h) Physically verify that the slot you identified is where you want to install the adapter.
 - Use the blue identify LED on the enclosure to locate the system. Ensure that the serial number of the system matches the serial number to be serviced.
 - Look for a flashing amber LED, which identifies the unoccupied slot that was selected by using the identify function.
 - i) Select the **Toggle LED blink off/on** option to stop the LED from flashing.
 - j) Continue with step “14” on page 7.
13. To prepare the system to install an adapter by using the Linux operating system, complete the following steps:
- a) Log in to the system console as the root user.
 - b) Run the following command to list the available slots:

```
lsslot -c pci -a
```

The following screen is an example of the information that is displayed by this command:

```
# Slot                Description                Device(s)
U7879.001.DQD014E-P1-C1 PCI-X capable, 64 bit, 133MHz slot Empty
U7879.001.DQD014E-P1-C4 PCI-X capable, 64 bit, 133MHz slot Empty
U7879.001.DQD014E-P1-C5 PCI-X capable, 64 bit, 133MHz slot Empty
```

- c) Record the empty adapter slot where you want to install the adapter.
 - d) Complete the following steps to prepare the slot to accept an adapter:
 - i) Type the following command:


```
drmgr -c pci -a -s locationcode
```

Where *locationcode* is the location of the adapter slot. For example, the location might be U7879.001.DQD014E-P1-C3.
 - ii) Press Enter. A fast-flashing amber LED at the rear of the system near the adapter indicates that the slot is identified.
 - iii) Physically verify that the slot you identified is where you want to install the adapter.
- Notes:**
- Use the blue identify LED on the enclosure to locate the system. Ensure that the serial number of the system matches the serial number to be serviced.
 - Look for the flashing amber LED, which identifies the slot that was selected by using the identify function.
- e) Physically verify that the slot you identified is where you want to install the adapter.

- Use the blue identify LED on the enclosure to locate the system. Ensure that the serial number of the system matches the serial number to be serviced.
 - Look for a flashing amber LED, which identifies the unoccupied slot that was selected by using the identify function.
14. At the rear of the system, put the cable management bracket in the service position as shown in the following figure.
- a) Pull out the quarter-turn fasteners **(B)** and turn them to disengage them while you lift the cable management bracket **(A)** to its raised position.
 - b) Turn the quarter-turn fasteners **(B)** to engage and lock the bracket into position.




Figure 5. Placing the cable management bracket in the raised service position

15. Attach the electrostatic discharge (ESD) wrist strap.
- The ESD wrist strap must be connected to an unpainted metal surface until the service procedure is completed, and if applicable, until the service access cover is replaced.



Attention:

- Attach an electrostatic discharge (ESD) wrist strap to the front ESD jack, to the rear ESD jack, or to an unpainted metal surface of your hardware to prevent the electrostatic discharge from damaging your hardware.

- When you use an ESD wrist strap, follow all electrical safety procedures. An ESD wrist strap is used for static control. It does not increase or decrease your risk of receiving electric shock when using or working on electrical equipment.
- If you do not have an ESD wrist strap, just prior to removing the product from ESD packaging and installing or replacing hardware, touch an unpainted metal surface of the system for a minimum of 5 seconds. If at any point in this service process you move away from the system, it is important to again discharge yourself by touching an unpainted metal surface for at least 5 seconds before you continue with the service process.

Installing an adapter in the 9080-M9S system

To install an adapter in the system, complete the steps in this procedure.

Procedure

1. Ensure that you have the electrostatic discharge (ESD) wrist strap on and that the ESD clip is plugged into a ground jack or connected to an unpainted metal surface. If not, do so now.
2. If necessary, remove the adapter from the antistatic package.

Attention: Avoid touching the components and gold connectors on the adapter.

3. Place the adapter, component-side up, on a flat, antistatic surface.



Attention: A pin on the tailstock of the adapter resembles a removable screw. Do not remove this pin. It is required for correct alignment and seating.

4. Remove the adapter cassette from the slot:
 - a) Press in on the latch release (**A**) as shown in the following figure.
The latch is released.
 - b) Rotate the latch in the direction shown.
The cassette is released from the slot.
 - c) Pull the cassette straight out from the slot.




Figure 6. Removing the adapter cassette from the 9080-M9S system

5. Remove the side cover from the cassette.
 - a) Press the release button on the side cover and slide the cover in the direction that is shown.
 - b) Lift the side cover off the cassette.




Figure 7. Removing the side cover from the adapter cassette for the 9080-M9S system

6. Remove the top cover from the cassette.
 - a) Press the release button on the top cover and slide the cover in the direction that is shown.
 - b) Lift the top cover off the cassette.




Figure 8. Removing the top cover from the adapter cassette for the 9080-M9S system

7. Remove the tailstock filler from the cassette.

- a) Pull the tailstock filler away from the cassette in the direction that is shown.
- b) Save the tailstock filler for a future use.

You must have a tailstock filler in an empty cassette in a system to ensure proper airflow.




Figure 9. Removing a tailstock filler from the cassette for the 9080-M9S system

8. Insert the adapter into the cassette.

a) Choose from the following options:

- If you do not have adapter retainers, continue with the next step.
- If you have adapter retainers, complete the following steps:
 - i) Ensure that the retainer latches (**A**) are in the open position by pushing up on the latch in the direction that is shown in the following figure.
 - ii) Slide up the retainers and remove them from the cassette and then discard them.





Figure 10. Opening the adapter retainers for the 9080-M9S system so you can slide them off and discard them.

Note: The adapter retainers are not needed.

- b) Press the adapter firmly into its connector as shown in the following figure, ensuring that it is seated.



P9HAK929-0

Figure 11. Installing an adapter in a cassette for the 9080-M9S system

Note: Ensure that the adapter is secured in the adapter retainer channel.

9. Replace the top cover on the cassette.
 - a) Lower the top cover on the top of the cassette.
 - b) Slide the top cover in the direction that is shown in the following figure until it latches securely.





Figure 12. Replacing the top cover on the adapter cassette for the 9080-M9S system

10. Replace the side cover on the cassette.

a) Place the side cover on the side of the cassette.

b) Slide the side cover in the direction that is shown in the following figure until it latches securely.



P9HAK904-0

Figure 13. Replacing the side cover on the adapter cassette for the 9080-M9S system

11. Slide the cassette into the slot by completing the following steps:



Attention:

Ensure proper alignment when you insert a adapter cassette into the system.

- a) Align the cassette on the cassette rail in the cassette slot.
- b) Slide the cassette forward until the cassette is fully seated.
- c) To lock the adapter in its slot, rotate the adapter latch **(A)** in the direction that is shown in the following figure.




Figure 14. Installing a cassette in the 9080-M9S system

Preparing the 9080-M9S system for operation after installing an adapter

To prepare the system for operation after installing an adapter, complete the steps in this procedure.

Procedure

1. Ensure that you have the electrostatic discharge (ESD) wrist strap on and that the ESD clip is plugged into a ground jack or connected to an unpainted metal surface. If not, do so now.
2. If you installed a PCIe3 cable adapter, and want to connect an EMX0 PCIe3 expansion drawer to your system, continue with [Connecting an EMX0 PCIe Gen3 I/O expansion drawer to your system](http://www.ibm.com/support/knowledgecenter/POWER9/p9egp/p9egp_connect_kickoff.htm) (http://www.ibm.com/support/knowledgecenter/POWER9/p9egp/p9egp_connect_kickoff.htm).

If you have an HMC-managed 9040-MR9 or 9080-M9S system, you can connect and activate the expansion drawer cable when the system power is turned on. Otherwise, you must connect the cable with the system power turned off. The cable is activated when you start the system.

3. Connect any cables or transceivers to the adapter.
4. Route the cables through the cable management bracket.
5. Put the cable management bracket in the operating position as shown in the following figure.
 - a) Pull out the quarter-turn fasteners **(B)** and turn them to disengage them while moving the cable management bracket **(A)** to its lower position.
 - b) Turn the quarter-turn fasteners **(B)** to engage and lock the bracket into position.




Figure 15. Placing the cable management bracket in the lowered operating position

6. Close the rack door at the rear of the system.
7. To complete the procedure with the power on, access the ASMI and run the Cable Plugging Validation utility to validate only the UPIC cables.
 - a) If you are already connected to the ASMI, go to the next step. Otherwise, access the ASMI by choosing one of the following options:
 - For HMC Version 10.1.1020.0, or earlier, click **Resources > All Systems** and select the system being serviced. Then, click **Actions > View All Actions > Launch Advanced System Management (ASM)**.
 - For HMC Version 10.2.1030.0, or later, click **System resources > Systems** and select the system being serviced. Then, click **Connections and operations > Launch Advanced System Management (ASM)**.
 - b) In the navigation area, expand **System Service Aids > Cable Plugging Validation**. Then, click **Validate UPIC Cables**. The system verifies that the UPIC cables are present.

Note: Older firmware levels do not support validating the UPIC cables while the system is at FSP standby. You can skip this step if it is not available.
 - c) Expand **System Service Aids > Cable Plugging Validation**. In the **Display Cable Status** section, select **UPIC Cables** and click **Continue**. The system validates that the UPIC cables are installed in the correct locations and displays a table with the results. Ensure that the plugging status is OK for each cable in the displayed table. If the status is OK, no further action is required. If the status is


not OK, review the error logs, correct the problems, and repeat steps b and c as needed until the status is OK for all cables.

- d) Exit the ASMI.
 - e) Continue with step [“10” on page 19](#).
8. When the service processor comes up to the Flexible Service Processor (FSP) standby state (the power-on LED on the control panel is flashing slowly), continue to the next step.
9. Access the ASMI and run the Cable Plugging Validation utility to validate all of the cables.
- a) If you are already connected to the ASMI, go to the next step. Otherwise, access the ASMI by choosing one of the following options:
 - For HMC Version 10.1.1020.0, or earlier, click **Resources > All Systems** and select the system being serviced. Then, click **Actions > View All Actions > Launch Advanced System Management (ASM)**.
 - For HMC Version 10.2.1030.0, or later, click **System resources > Systems** and select the system being serviced. Then, click **Connections and operations > Launch Advanced System Management (ASM)**.
 - b) In the navigation area, expand **System Service Aids > Cable Plugging Validation**. Then, click **Validate Cables**. The system verifies that the expected cables are present.
 - c) If your configuration includes two or more nodes, expand **System Service Aids > Cable Plugging Validation**. Then, click **Verify Node Position**. Otherwise, if your configuration includes only one node, continue to the next step.

If the system is cabled correctly, the blue identify LED on each system node will light up, in sequence, from the top node to the bottom node. If the LEDs do not light up in sequence, the FSP cables need to be re-installed.
 - d) Expand **System Service Aids > Cable Plugging Validation**. Then, select **All of the above** in the **Display Cable Status** section and click **Continue**. The system validates that the cables are installed in the correct locations. Expand **System Service Aids > Cable Plugging Validation** to display a table with the results. Ensure that the plugging status is OK for each cable in the displayed table. If the status is OK, no further action is required. If the status is not OK, review the error logs, correct the problems, and repeat steps b, c and d as needed until the status is OK for all cables.
 - e) Exit the ASMI.
10. Choose from the following options:
- If you completed this procedure with the system power turned off, continue with step [“11” on page 19](#).
 - If you completed the procedure with the system power turned on and used the AIX operating system, continue with step [“12” on page 20](#).
 - If you completed the procedure with the system power turned on and used the IBM i operating system, continue with step [“13” on page 21](#).
 - If you completed the procedure with the system power turned on and used the Linux operating system, continue with step [“17” on page 21](#).
11. If the system power is turned off, complete the following steps:
- a) If you chose to complete this repair with the power off, using your labels, reconnect the UPIC cables to the system control unit.

UPIC cable locations are P1-C1-T1 and P1-C2-T1.


 - i) Ensure that the white plastic lock is pulled back from the plug housing.
 - ii) Plug the UPIC cable (**A**) into the previously identified location in the system control unit by inserting the cable into the connector until it locks into place.



P9IAD620-0

Figure 16. Replacing the UPIC cable into the system control unit

iii) Push the white plastic lock (**B**) onto the plug housing.



P9IAD621-0

Figure 17. Replacing the UPIC cable into the system control unit

- iv) Lightly pull on the UPIC cable from both attachment points to ensure it is locked into place. Pull the cable connector; do not pull on the wire. The cables should be firmly attached to the system.
 - b) Start the system. For instructions, see [Starting a system](http://www.ibm.com/support/knowledgecenter/POWER9/p9haj/crustartsys.htm) (www.ibm.com/support/knowledgecenter/POWER9/p9haj/crustartsys.htm).
 - c) Continue with step “18” on page 21.
12. If you are using the AIX operating system, you must configure the adapter by completing the following steps:
- a) Install the AIX device drivers for the installed adapter.
For instructions, see [Installing the AIX device driver software](#).

- b) On the console, enter `cfgmgr` to configure the adapter.
- c) Continue with step [“18” on page 21](#).
13. If you are using the IBM i operating system, return to the **Hardware Resource Concurrent Maintenance** display and select **Power on domain**.
- The message `Power on complete` is shown.
14. Did you replace a PCIe3 x8 non-volatile memory SSD NVMe adapter?
- **Yes:** Continue with step [“15” on page 21](#).
 - **No:** Continue with step [“18” on page 21](#).
15. If you installed a PCIe3 x8 non-volatile memory SSD NVMe adapter and the logical partition that controls the adapter is running the IBM i operating system, complete the following steps to prepare the NVMe adapter for operation:
- a) Start the IBM i System Service Tools (STRSST), and specify the user name and password.
 - b) On the System Service Tools (SST) display, select **Work with disk units > Work with disk configuration > Work with NVM Devices > Delete existing NVM Namespaces**.
 - c) Select the NVMe device that you installed.
 - d) Choose from the following options:
 - If no namespaces are listed, press F12 to return to the SST main menu and continue with the next step.
 - If there are namespaces listed, complete the following steps:
 - i) Select **4=Delete Namespace** for each of the listed namespaces.
 - ii) Press F10 to confirm the deletion of the namespaces.
 - iii) Press F12 to return to the SST main menu.
 - e) On the System Service Tools (SST) display, select **Work with disk units > Work with disk configuration > Work with NVM Devices > Create NVM Namespaces**.
 - f) Select the NVMe device that you installed.
 - g) On the **Create NVM Namespaces** display, select the quantity and capacity of the namespaces (disk units) that you want to create on the newly installed NVMe device.
 - h) Press F10 to confirm the creation of the namespaces.
 - i) Press F12 to return to the SST main menu.
16. Continue with step [“18” on page 21](#).
17. If you are using the Linux operating system, complete the following steps:
- a) In the Linux session on the console, press Enter after you install or replace the adapter to put the slot into the action state.
 - b) Enter the slot information with the **lsslot** command, as shown in the following example.
For example, if the slot in which you installed the adapter was U7879.001.DQD014E-P1-C3.
Enter **lsslot -c pci -s U7879.001.DQD014E-P1-C3**
- The following screen is an example of the information that is displayed by this command:

```
# Slot                Description                Device(s)
U7879.001.DQD014E-P1-C3 PCI-X capable, 64 bit, 133MHz slot 0001:40:01.0
```

18. Verify the installed part.
- If you replaced the part because of a service action, verify the installed part. For instructions, see [Verifying a repair](http://www.ibm.com/support/knowledgecenter/POWER9/p9ect/pxect_verifyrepair.htm) (www.ibm.com/support/knowledgecenter/POWER9/p9ect/pxect_verifyrepair.htm).

- If you installed the part for any other reason, verify the installed part. For instructions, see [Verifying the installed part](http://www.ibm.com/support/knowledgecenter/POWER9/p9haj/pxhaj_hsmverify.htm) (www.ibm.com/support/knowledgecenter/POWER9/p9haj/pxhaj_hsmverify.htm).
19. Turn off the identify LED. For instructions, see [Deactivating an identify LED](http://www.ibm.com/support/knowledgecenter/POWER9/p9haj/p9haj_turn_off_identify_led.htm) (www.ibm.com/support/knowledgecenter/POWER9/p9haj/p9haj_turn_off_identify_led.htm).

Related procedures for installing adapters

Find procedures that are related to installing adapters.

Avoiding electric shock

Find information about precautions you should take to avoid electric shock when working on our around a computer system.



DANGER: When working on or around the system, observe the following precautions:

Electrical voltage and current from power, telephone, and communication cables are hazardous. To avoid a shock hazard: If IBM supplied the power cord(s), connect power to this unit only with the IBM provided power cord. Do not use the IBM provided power cord for any other product. Do not open or service any power supply assembly. Do not connect or disconnect any cables or perform installation, maintenance, or reconfiguration of this product during an electrical storm.



- The product might be equipped with multiple power cords. To remove all hazardous voltages, disconnect all power cords. For AC power, disconnect all power cords from their AC power source. For racks with a DC power distribution panel (PDP), disconnect the customer's DC power source to the PDP.
- When connecting power to the product ensure all power cables are properly connected. For racks with AC power, connect all power cords to a properly wired and grounded electrical outlet. Ensure that the outlet supplies proper voltage and phase rotation according to the system rating plate. For racks with a DC power distribution panel (PDP), connect the customer's DC power source to the PDP. Ensure that the proper polarity is used when attaching the DC power and DC power return wiring.
- Connect any equipment that will be attached to this product to properly wired outlets.
- When possible, use one hand only to connect or disconnect signal cables.
- Never turn on any equipment when there is evidence of fire, water, or structural damage.
- Do not attempt to switch on power to the machine until all possible unsafe conditions are corrected.
- When performing a machine inspection: Assume that an electrical safety hazard is present. Perform all continuity, grounding, and power checks specified during the subsystem installation procedures to ensure that the machine meets safety requirements. Do not attempt to switch power to the machine until all possible unsafe conditions are corrected. Before you open the device covers, unless instructed otherwise in the installation and configuration procedures: Disconnect the attached AC power cords, turn off the applicable circuit breakers located in the rack power distribution panel (PDP), and disconnect any telecommunications systems, networks, and modems.
- Connect and disconnect cables as described in the following procedures when installing, moving, or opening covers on this product or attached devices.

To Disconnect: 1) Turn off everything (unless instructed otherwise). 2) For AC power, remove the power cords from the outlets. 3) For racks with a DC power distribution panel (PDP), turn off the circuit breakers located in the PDP and remove the power from the Customer's DC power source. 4) Remove the signal cables from the connectors. 5) Remove all cables from the devices.

To Connect: 1) Turn off everything (unless instructed otherwise). 2) Attach all cables to the devices. 3) Attach the signal cables to the connectors. 4) For AC power, attach the power cords to the outlets. 5) For racks with a DC power distribution panel (PDP), restore the power from the Customer's DC power source and turn on the circuit breakers located in the PDP. 6) Turn on the devices.



- Sharp edges, corners and joints may be present in and around the system. Use care when handling equipment to avoid cuts, scrapes and pinching. (D005)

Handling static-sensitive devices

Find information about precautions you must take to prevent damage to electronic components from static electricity discharge.

Electronic boards, adapters, media drives, and disk drives are sensitive to static electricity discharge. These devices are wrapped in antistatic bags to prevent this damage. Take the following precautions to prevent damage to these devices from static electricity discharge.

- Attach a wrist strap to an unpainted metal surface of your hardware to prevent electrostatic discharge from damaging your hardware.
- When you are using a wrist strap, follow all electrical safety procedures. A wrist strap is for static control. It does not increase or decrease your risk of receiving electric shock when you are using or working on electrical equipment.
- If you do not have a wrist strap, before you remove the product from ESD packaging and installing or replacing hardware, touch an unpainted metal surface of the system for a minimum of 5 seconds.
- Do not remove the device from the antistatic bag until you are ready to install the device in the system.
- With the device still in its antistatic bag, touch it to the metal frame of the system.
- Grasp cards and boards by the edges. Avoid touching the components and gold connectors on the adapter.
- If you need to lay the device down while it is out of the antistatic bag, lay it on the antistatic bag. Before you pick it up again, touch the antistatic bag and the metal frame of the system at the same time.
- Handle the devices carefully to prevent permanent damage.

Updating the worldwide port name for a new 5735 IOA

If you exchange a 5735 Fibre Channel input/output adapter (IOA), the IBM external storage subsystem must be updated to use the worldwide port name (WWPN) of the new 5735 IOA. Any SAN hardware that uses the WWPN zoning might also need updating.

For instructions on how to update the external storage subsystem or SAN hardware configurations, see the documentation for those systems.

The WWPN for the Fibre Channel IOA can be found by using the Hardware Service Manager in SST or DST to display details about the 5735 IOA Logical Hardware Resource information, and use the port worldwide name field.

The 16-digit WWPN can also be determined by appending the digits 1000 to the beginning of the 12-digit IEEE address that is found on the tailstock label of the Fibre Channel IO adapter.

Removing and replacing the tailstock on an adapter

Find information about removing and replacing the tailstock on an adapter. You can replace the tailstock on an adapter if the adapter has a different tailstock.

Before you begin

You must have removed the adapter or the adapter filler from the system.

About this task

The tailstock for individual adapters can be either tall (high-profile) or short (low-profile). New systems ship with the correct tailstock on the cards already installed. Through unique feature codes, a

miscellaneous equipment specification (MES) also ships with the correct sized tailstock. For repairs, however, replacement parts usually ship with high-profile tailstock. If the failed adapter was a low-profile adapter installed in the system, then you must exchange the tall tailstock that was shipped on the replacement card with the low-profile tailstock from the failed card.

Note: A Phillips screwdriver is required to complete the procedure.

To remove and replace an adapter tailstock, choose from the following options:

- [Removing the tailstock from a failed adapter or adapter filler](#)
- [Removing the tailstock from a new adapter](#)
- [Replacing the tailstock in a new adapter](#)

Procedure

Removing the tailstock from a failed adapter or adapter filler

1. Ensure that you have the electrostatic discharge (ESD) wrist strap on and that the ESD clip is plugged into a ground jack or connected to an unpainted metal surface. If not, do so now.
2. Using a Phillips screwdriver, unscrew the two screws **(A)** that attach the tailstock **(B)** to the adapter, as shown in [Figure 18 on page 24](#).





Figure 18. Removing the low-profile tailstock from an adapter

3. Detach the tailstock from the adapter and place the tailstock and the screws on a flat, static-protective surface.
4. If you are removing the tailstock from a 4-Port 10/100/1000 Base-TX adapter, there is only one screw to remove. After removing the screw, disengage the tabs from the card hardware and remove the tailstock.

5. If you are removing the tailstock from an Ethernet or Fibre Channel adapter that has small form-factor pluggable (SFP) transceivers, you must first remove the SFP transceivers.

To remove the SFP transceivers, complete the following steps:

- a) Place the card flat on a static-protective surface.
- b) Open the latch **(A)** by rotating it down and away from the card as shown in [Figure 19](#) on [page 25](#).
- c) Slide the transceiver **(B)** out of the adapter hardware.
- d) Repeat for the other transceiver.



P9HAK000-0

Figure 19. Removing SFP transceivers from adapters

6. If necessary, remove the adapter from the antistatic package.

Attention: Avoid touching the components and gold connectors on the adapter.

Removing the tailstock from a new adapter

7. Ensure that you have the electrostatic discharge (ESD) wrist strap on and that the ESD clip is plugged into a ground jack or connected to an unpainted metal surface. If not, do so now.
8. Using a Phillips screwdriver, unscrew the two retaining screws **(A)** that attach the high-profile tailstock **(B)** to the new adapter, as shown in [Figure 20](#) on [page 26](#).




Figure 20. Removing the high-profile tailstock from a new adapter

9. If the new adapter is a 4-Port 10/100/1000 Base-TX adapter, see [“4” on page 24](#) for removing the tailstock and then return here.
10. If the new adapter is an Ethernet or Fibre Channel adapter, see [“5” on page 25](#) for removing the tailstock and then return here.
11. Detach the tailstock from the new adapter and store the tailstock and its screws in the antistatic package that the new adapter shipped in.

Replacing the tailstock in a new adapter

12. Ensure that you have the electrostatic discharge (ESD) wrist strap on and that the ESD clip is plugged into a ground jack or connected to an unpainted metal surface. If not, do so now.
13. Place the adapter, component-side up, on a flat, antistatic surface.



Attention: A pin on the tailstock of the adapter resembles a removable screw. Do not remove this pin. It is required for correct alignment and seating.

14. Using a Phillips screwdriver and the two retaining screws (**B**), attach the tailstock (**A**) from the failed adapter onto the new adapter, as shown in [Figure 21 on page 27](#).




Figure 21. Attaching the low-profile tailstock to an adapter

15. If the new adapter is a 4-Port 10/100/1000 Base-TX Express adapter, first engage the tailstock with the tabs on the card hardware. After the tailstock is attached, secure the tailstock with its screw.
16. If the new adapter is an Ethernet or Fibre Channel adapter, you must attach the SFP transceivers after you replace the tailstock.

To attach the SFP transceivers, complete the following steps:

- a) Place the card flat on a static-protective surface.
- b) Slide the transceiver **(A)** into the adapter hardware.
- c) With the latch **(B)** in the open position, push the latch by rotating it up and toward the card as shown in [Figure 22 on page 28](#).
- d) Repeat for the other transceiver.




Figure 22. Replacing SFP transceivers in the adapter

17. Put the failed adapter in the shipping material and return it.

What to do next

Return to the procedure that sent you here.

Hot-plug manager access for AIX

Find information about how to service adapters with the system power on in AIX.

The instructions for servicing adapters with the system power on in AIX refer you to these procedures when it is appropriate to perform them.

Note: For an adapter to be serviced with the system power on, both the adapter and the system unit must support hot-plug procedures. To identify adapters that are hot-pluggable in the system you are servicing, refer to the following placement information: adapter placement.

Accessing the hot-plug management functions

Find information about how to use the hot-plug manager to service adapters with the system power turned on in AIX.

About this task

Note: Procedures that are completed with the system power turned on also known as hot-plug procedures. The hot-plug procedure for an adapter in an AIX system requires the system administrator to take the adapter offline before starting the procedure. Before taking an adapter offline, the devices attached to the adapter must be taken offline as well. This action prevents a service representative or user from causing an unexpected outage for system users.

To access the hot-plug menus, complete the following steps:

Procedure

1. Log in as root user.
2. At the command line, type smitty.
3. Select **Devices**.
4. Select **PCI Hot Plug Manager** and press Enter.

The **PCI Hot-Plug Manager** menu displays.

For details about the menu options in the **PCI Hot-Plug Manager** screen, see [“PCI hot-plug manager menu”](#) on page 29.

What to do next

Return to the procedure that directed you here.

PCI hot-plug manager menu

Find information about how to use the PCI Hot Plug Manager to service PCI adapters with the system power on in AIX. The following options are available from the PCI Hot Plug Manager menu.

Note: For information about the PCI slot LED states, see [“Component LEDs”](#) on page 30.

Menu option	Description
List PCI hot-plug slots	Provides a descriptive list of all slots that support PCI hot-plug capability. If the listing for a slot indicates it holds an unknown device, select the Install/configure Devices added after IPL to configure the adapter in that slot.
Add a PCI hot-plug adapter	Allows the user to add a new PCI hot-plug-capable adapter to the slot with the system turned on. You will be asked to identify the PCI slot that you have selected prior to the actual operation. The selected PCI slot will go into the Action state and finally into the On state. Note: The system will indicate the slot holds an unknown device until you perform the Install/configure devices added after IPL option to configure the adapter.
Replace/remove a PCI hot-plug adapter	Allows the user to remove an existing adapter, or replace an existing adapter with an identical one. For this option to work, the adapter must be in the Defined state (see the "Unconfigure a Device" option). You will be asked to identify the PCI slot prior to the actual operation. The selected PCI slot will go into the Action state.
Identify a PCI hot-plug slot	Allows the user to identify a PCI slot. The selected PCI slot will go into the Identify state. See “Component LEDs” on page 30.
Unconfigure a device	Allows the user to put an existing PCI adapter into the Defined state if the device is no longer in use. This step must be completed successfully before starting any removal or replacement operation. If this step fails, the customer must take action to release the device.
Configure a defined device	Allows a new PCI adapter to be configured into the system if software support is already available for the adapter. The selected PCI slot will go into the On state.
Install/configure devices added after IPL	The system attempts to configure any new devices and tries to find and install any required software from a user-selected source.

The add, remove, and replace functions return information to the user indicating whether the operation was successful. If additional instructions are provided on the screen, complete the recommended actions. If the instructions do not resolve the problem, do the following:

- If the adapter is listed as Unknown, perform the **Install/configure devices Added After IPL** option to configure the adapter.
- If you receive a warning indicating that needed device packages are not installed, the system administrator must install the specified packages before you can configure or diagnose the adapter.
- If you receive a failure message indicating a hardware error, the problem might be either the adapter or the PCI slot. Isolate the problem by retrying the operation in a different PCI slot, or trying a different adapter in the slot. If you determine that you have failing hardware, call your service representative.
- *Do not* use **Install/configure devices added after IPL** if your system is set up to run HACMP clustering. Consult with your system administrator or software support to determine the correct method to configure the replacement device.

Component LEDs

Individual LEDs are located on or near the failing components. Use the information in this section to interpret the LEDs.

The LEDs are located either on the component itself or on the carrier of the component (for example, memory card, fan, memory module, or processor). LEDs are either green or amber.

Green LEDs indicate either of the following:

- Electrical power is present.
- Activity is occurring on a link. (The system could be sending or receiving information.)

Amber LEDs indicate a fault or identify condition. If your system or one of the components on your system has an amber LED turned on or flashing, identify the problem and take the appropriate action to restore the system to normal.

Resetting the LEDs in AIX

Individual LEDs are located on or near the failing components. You can use this procedure to reset the LEDs after you have completed a repair action.

About this task

After the repair action is complete, perform the following tasks:

Procedure

1. Log in as root user.
2. At the command line, type `diag`.
3. Select **Task Selection**.
4. Select **Log Repair Action**.
5. Select the device that was repaired.
6. Press F10 to exit diagnostics.

Results

If the Attention LED remains on after you have completed the repair action and reset the LEDs, call for service support.

Installing the AIX device driver software

Find information about how to install the AIX device driver software for a PCIe adapter.

Before you begin

If you are installing the AIX operating system at this time, install the adapter before you install the operating system. When you install the AIX operating system, the adapter device driver is automatically installed and the following procedure does not apply to your situation.

About this task

If you are installing only the device driver for a PCIe adapter, perform these steps:

Procedure

1. Log in to the system unit as root user.
2. Insert the media containing the device driver software (for example, the CD) into the media device.
If your system does not have a CD-ROM drive, refer to your system documentation for performing a Network Installation Management (NIM) installation.
3. Type the following command at the System Management Interface Tool (SMIT) fast path: `smit devinst`.
Press Enter. The Install Additional Device Software window appears with **INPUT device / directory for software** option highlighted.
4. Type the name of the input device that you are using, or press **F4** to select the input device from a list.
Press Enter. The **Install Additional Device Software** window is shown with the **SOFTWARE to install** option highlighted.
5. Press **F4** to select **List**.
6. Type `/` to display the **Find** window.
7. Type the device package name, and press Enter.
The device driver software is shown.
8. Press **F7** to select the highlighted device driver software, and press Enter.
The **Install Additional Device Software** window is displayed. The entry fields are automatically updated.
Press Enter twice to confirm. The **Command Status** window is displayed.
 - The message **RUNNING** is highlighted to indicate that the installation and configuration command is in progress.
 - When **RUNNING** changes to **OK**, scroll to the bottom of the page and locate the installation summary.
 - After a successful installation, **SUCCESS** is displayed in the **Result** column of the installation summary at the bottom of the page.
9. Remove the installation media from the drive.
10. Press **F10** to exit SMIT.
11. To verify that the device driver is installed, complete the following steps:
 - a) If necessary, log in as root user.
 - b) At the command line, type `lslpp -l devices.xxxxxxxxxx` where `xxxxxxxxxx` is the device package name.
Press Enter.
The following example shows when the adapter device driver is installed.

File set	Level	State	Description
Path: /usr/lib/objrepos devices.xxxxxxxxxx	5.3.8.0	COMMITTED	Adapter name software

Verify that the file sets are installed at the AIX version level you are running. Level 5.3.8.0 is an example. If no data is displayed on your screen, the adapter device driver was not installed correctly. Try reinstalling the driver.

Installing or replacing an adapter with the system power turned on in a Virtual I/O Server

Find information about how to install or replace an adapter in the Virtual I/O Server logical partition.

Before you begin

The Virtual I/O Server includes a Hot Plug Manager that is similar to the Hot Plug Manager in the AIX operating system. The Hot Plug Manager allows you to hot plug adapters into the system and then activate them for the logical partition without having to reboot the system. Use the Hot Plug Manager for adding, identifying, or replacing adapters in the system that are currently assigned to the Virtual I/O Server.

Prerequisites:

- If you are installing a new adapter, an empty system slot must be assigned to the Virtual I/O Server logical partition. This task can be done through dynamic logical partitioning (DLPAR) operations.
- If you are using a Hardware Management Console (HMC), you must also update the logical partition profile of the Virtual I/O Server so that the new adapter is configured to the Virtual I/O Server after you restart the system.
- If you are installing a new adapter, ensure that you have the software required to support the new adapter and determine whether there are any existing PTF prerequisites to install. For information about software prerequisites, see the [IBM Prerequisite website](http://www-912.ibm.com/e_dir/eServerPrereq.nsf) (http://www-912.ibm.com/e_dir/eServerPrereq.nsf).

About this task

Choose from the following tasks:

- [“Installing an adapter” on page 32](#)
- [“Replacing an adapter” on page 33](#)
- [“Unconfiguring storage adapters” on page 33](#)
- [“Preparing the client logical partitions” on page 34](#)

Installing an adapter

About this task

To install an adapter with the system power on in Virtual I/O Server, complete the following steps:

Procedure

1. From the Hot Plug Manager, select **Add a PCIe Hot Plug Adapter**, then press Enter.
The Add a Hot-Plug Adapter window is displayed.
2. Select the appropriate empty slot from those listed, and press Enter.
A fast-blinking amber LED located at the back of the server near the adapter indicates that the slot has been identified.

3. Follow the instructions on the screen to install the adapter until the LED for the specified slot is set to the Action state.
 - a. Set the adapter LED to the action state so that the indicator light for the adapter slot flashes
 - b. Physically install the adapter
 - c. Finish the adapter installation task in **diagmenu**.
4. Enter **cfgdev** to configure the device for the Virtual I/O Server.

Results

If you are installing a PCIe, Fibre Channel adapter, it is now ready to be attached to a SAN and have LUNs assigned to the Virtual I/O Server for virtualization.

Replacing an adapter

Before you begin

Prerequisite: Before you can remove or replace a storage adapter, you must unconfigure that adapter. See [“Unconfiguring storage adapters”](#) on page 33 for instructions.

About this task

To replace an adapter with the system power turned on in Virtual I/O Server, complete the following steps:

Procedure

1. From the PCIe Hot Plug Manager, select **Unconfigure a Device**, then press Enter.
2. Press F4 (or Esc +4) to display the **Device Names** menu.
3. Select the adapter you are removing in the **Device Names** menu.
4. In the **Keep Definition** field, use the Tab key to answer Yes. In the **Unconfigure Child Devices** field, use the Tab key again to answer YES, then press Enter.
5. Press Enter to verify the information on the **ARE YOU SURE** screen. Successful unconfiguration is indicated by the OK message displayed next to the Command field at the top of the screen.
6. Press F4 (or Esc +4) twice to return to the Hot Plug Manager.
7. Select **replace/remove PCIe Hot Plug adapter**.
8. Select the slot that has the device to be removed from the system.
9. Select **replace**.

A fast-blinking amber LED located at the back of the machine near the adapter indicates that the slot has been identified.
10. Press Enter which places the adapter in the action state, meaning it is ready to be removed from the system.

Unconfiguring storage adapters

About this task

Before you can remove or replace a storage adapter, you must unconfigure that adapter. Storage adapters are generally parent devices to media devices, such as disk drives or tape drives. Removing the parent requires that all attached child devices either be removed or placed in the define state.

Unconfiguring a storage adapter involves the following tasks:

- Closing all applications that are using the adapter you are removing, replacing, or moving
- Unmounting file systems

- Ensuring that all devices connected to the adapter are identified and stopped
- Listing all slots that are currently in use or a slot that is occupied by a specific adapter
- Identifying the adapter's slot location
- Making parent and child devices unavailable
- Making the adapter unavailable

If the adapter supports physical volumes that are in use by a client logical partition, then You can perform steps on the client logical partition before unconfiguring the storage adapter. For instructions, see [“Preparing the client logical partitions” on page 34](#). For example, the adapter might be in use because the physical volume was used to create a virtual target device, or it might be part of a volume group used to create a virtual target device.

To unconfigure SCSI, SSA, and Fibre Channel storage adapters, complete the following steps:

Procedure

1. Connect to the Virtual I/O Server command-line interface.
2. Enter `oem_setup_env` to close all applications that are using the adapter you are unconfiguring.
3. Type `lsslot -c PCI` to list all the hot plug slots in the system unit and display their characteristics.
4. Type `lsdev -C` to list the current state of all the devices in the system unit.
5. Type `umount` to unmount previously mounted file systems, directories, or files using this adapter.
6. Type `rmdev -l adapter -R` to make the adapter unavailable.



Attention: Do not use the `-d` flag with the `rmdev` command for hot plug operations because this action removes your configuration.

Preparing the client logical partitions

About this task

If the virtual target devices of the client logical partitions are not available, the client logical partitions can fail or they might be unable to perform I/O operations for a particular application. If you use the HMC to manage the system, you might have redundant Virtual I/O Server logical partitions, which allow for Virtual I/O Server maintenance and avoid downtime for client logical partitions. If you are replacing an adapter on the Virtual I/O Server and your client logical partition is dependent on one or more of the physical volumes accessed by that adapter, then You can take action on the client before you unconfigure the adapter.

The virtual target devices must be in the define state before the Virtual I/O Server adapter can be replaced. Do not remove the virtual devices permanently.

Procedure

To prepare the client logical partitions so that you can unconfigure an adapter, complete the following steps depending on your situation.

<i>Table 2. Situations and steps for preparing the client logical partitions</i>	
Situation	Steps
You have redundant hardware on the Virtual I/O Server for the adapter.	No action is required on the client logical partition.
HMC-managed systems only: You have redundant Virtual I/O Server logical partitions that, in conjunction with virtual client adapters, provide multiple paths to the physical volume on the client logical partition.	No action is required on the client logical partition. However, path errors might be logged on the client logical partition.

Table 2. Situations and steps for preparing the client logical partitions (continued)

Situation	Steps
HMC-managed systems only: You have redundant Virtual I/O Server logical partitions that, in conjunction with virtual client adapters, provide multiple physical volumes that are used to mirror a volume group.	<p>See the procedures for your client operating system. For example, for AIX, see Replacing a disk on the Virtual I/O Server in the Advanced POWER® Virtualization Best Practices Redpaper.</p> <p>The procedure for Linux is similar to this procedure for AIX. For example, for AIX, see Replacing a disk on the Virtual I/O Server in the Advanced POWER Virtualization Best Practices Redpaper.</p> <p>The procedure for Linux is similar to this procedure for AIX.</p>
You do not have redundant Virtual I/O Server logical partitions.	<p>Shut down the client logical partition.</p> <p>For systems that are managed by the HMC, see Stopping a system (www.ibm.com/support/knowledgecenter/POWER9/p9haj/stopsyshmc.htm).</p>

Verifying that the hot-plug adapter tools are installed for the Linux operating system

Find information about how to verify that the hot-plug adapter tools are installed on your Linux system so you can then verify the adapter is installed.

Before you begin

Note: The hot-plug adapter tools are **not** available for the 5105-22E system.

Procedure

1. Enter the following command to verify that the hot-plug adapter tools are installed: `rpm -aq | grep powerpc-utils`.

If the command does not list any `powerpc-utils` packages, the Hot Plug tools are not installed.

2. Enter the following command to ensure that the `rpaphp` driver is loaded: `ls -l /sys/bus/pci/slots/`

The directory should contain data.

- If the directory is empty, the driver is not loaded or the system does not contain hot-plug adapter slots. The following is an example of the information displayed by this command:

```
drwxr-xr-x 15 root root 0 Feb 16 23:31 .
drwxr-xr-x  5 root root 0 Feb 16 23:31 ..
drwxr-xr-x  2 root root 0 Feb 16 23:31 0000:00:02.0
drwxr-xr-x  2 root root 0 Feb 16 23:31 0000:00:02.2
drwxr-xr-x  2 root root 0 Feb 16 23:31 0000:00:02.4
drwxr-xr-x  2 root root 0 Feb 16 23:31 0001:00:02.0
drwxr-xr-x  2 root root 0 Feb 16 23:31 0001:00:02.2
drwxr-xr-x  2 root root 0 Feb 16 23:31 0001:00:02.4
drwxr-xr-x  2 root root 0 Feb 16 23:31 0001:00:02.6
drwxr-xr-x  2 root root 0 Feb 16 23:31 0002:00:02.0
drwxr-xr-x  2 root root 0 Feb 16 23:31 0002:00:02.2
drwxr-xr-x  2 root root 0 Feb 16 23:31 0002:00:02.4
drwxr-xr-x  2 root root 0 Feb 16 23:31 0002:00:02.6
```

- If the directory does not exist, run the following command to mount the filesystem: `mount -t sysfs sysfs /sys`

3. Ensure the following tools are available in the `/usr/sbin` directory.

- lsslot
 - drmgr -c pci
4. Return to the procedure that sent you here.

Checking the amount of remaining life in NVMe devices

Learn how to use operating system commands to find the amount of remaining life in an NVMe device.

Using the operating system commands

The AIX, IBM i, and Linux operating systems have commands that you can use to determine the amount of life that is remaining in an NVMe device.

Running the AIX command to check the amount of remaining life in NVMe devices

Find information about using the AIX operating system to find the amount of remaining life in an NVMe device.

About this task

To find the amount of remaining life in an NVMe device by using the AIX operating system, complete the steps in this procedure.

Procedure

1. If the system has logical partitions, complete this procedure from the logical partition that owns the NVMe device
2. To use the AIX operating system to find the remaining life on an NVMe device, complete the following steps:
 - a) From the AIX command line, type `diag` and press Enter.
 - b) From the Function Selection menu, select **Task Selection > NVMe general health information**.
 - c) Select the NVMe device that you want to check remaining life for and press Enter.
 - d) View the **Percentage of NVM subsystem life used** field.

Is the value in the **Percentage of NVM subsystem life used** field 100%?

 - **Yes:** Continue with the next step.
 - **No:** Continue with step “4” on page 36.
3. The NVMe device is nearing its end of life and must be replaced. The NVMe device will soon reach the limit for the number of write operations that are supported. Write operations to the NVMe device become slower over time, and at some point the NVMe device becomes a read-only device. When the operating system writes data to a read-only device, the write operations are rejected, and the operating system considers the device as if a failure occurred. To support normal write operations, the NVMe device must be replaced.

Note: Failure of IBM NVMe devices is covered in the standard warranty and during the maintenance period only for devices that have not reached the maximum number of write cycles. Devices that reach this limit might fail to operate according to specifications and must be replaced. This replacement cost is not covered under the standard warranty or during the maintenance period.

This ends the procedure.
4. Does the **Critical Warning** field show **Available spare space has fallen below threshold**?
 - **Yes:** Continue with the next step.
 - **No:** A service action is not required. **This ends the procedure.**
5. The NVMe device is nearing its end of life and must be replaced. The NVMe device will soon reach the limit for the number of write operations that are supported. Write operations to the NVMe device

become slower over time, and at some point the NVMe device becomes a read-only device. When the operating system writes data to a read-only device, the write operations are rejected, and the operating system considers the device as if a failure occurred. To support normal write operations, schedule maintenance to replace the NVMe device at your earliest convenience.

Note: Failure of IBM NVMe devices is covered in the standard warranty and during the maintenance period only for devices that have not reached the maximum number of write cycles. Devices that reach this limit might fail to operate according to specifications and must be replaced. This replacement cost is not covered under the standard warranty or during the maintenance period.

This ends the procedure.

Running the IBM i command to check the amount of remaining life in NVMe devices

Find information about using the IBM i operating system to find the amount of remaining life in an NVMe device.

About this task

To find the amount of remaining life in an NVMe device by using the IBM i operating system, complete the steps in this procedure.

Procedure

1. If the system has logical partitions, complete this procedure from the logical partition that owns the NVMe device
2. To use the IBM i operating system to find the remaining life on an NVMe device, complete the following steps:
 - a) Sign on to an IBM i session with the security officer (QSECOFR) user profile.
 - b) To create an NVMe device report in a spool file, type the following command at the command line of the IBM i operating system and press Enter.

```
CALL PGM(QSMGSSTD) PARM('NVMEGAUGE' X'00000009' 'SSTD0100' X'00000000')
```

- c) To display the contents of the spool file, type `wrksp1f` at the command line of the IBM i operating system and press Enter.
The spool file contains a report of the NVMe devices.
- d) View the **Percentage Used** field.
Is the value in the **Percentage Used** field 100%?
 - Yes: Continue with the next step.
 - No: Continue with step [“4” on page 37](#).

3. The NVMe device is nearing its end of life and must be replaced. The NVMe device will soon reach the limit for the number of write operations that are supported. Write operations to the NVMe device become slower over time, and at some point the NVMe device becomes a read-only device. When the operating system writes data to a read-only device, the write operations are rejected, and the operating system considers the device as if a failure occurred. To support normal write operations, the NVMe device must be replaced.

Note: Failure of IBM NVMe devices is covered in the standard warranty and during the maintenance period only for devices that have not reached the maximum number of write cycles. Devices that reach this limit might fail to operate according to specifications and must be replaced. This replacement cost is not covered under the standard warranty or during the maintenance period.

This ends the procedure.

4. Is the value in the **Available spare space** field equal 1?

- **Yes:** Continue with the next step.
 - **No:** A service action is not required. **This ends the procedure.**
5. The NVMe device is nearing its end of life and must be replaced. The NVMe device will soon reach the limit for the number of write operations that are supported. Write operations to the NVMe device become slower over time, and at some point the NVMe device becomes a read-only device. When the operating system writes data to a read-only device, the write operations are rejected, and the operating system considers the device as if a failure occurred. To support normal write operations, schedule maintenance to replace the NVMe device at your earliest convenience.

Note: Failure of IBM NVMe devices is covered in the standard warranty and during the maintenance period only for devices that have not reached the maximum number of write cycles. Devices that reach this limit might fail to operate according to specifications and must be replaced. This replacement cost is not covered under the standard warranty or during the maintenance period.

This ends the procedure.

Running the Linux smart-log command to check the amount of remaining life in NVMe devices

Find information about using the Linux operating system smart-log command to find the amount of remaining life in an NVMe device.

About this task

To find the amount of remaining life in an NVMe device by using the Linux operating system smart-log command, complete the steps in this procedure.

Procedure

1. If the system has logical partitions, complete this procedure from the logical partition that owns the NVMe device
2. To use the Linux operating system to find the remaining life on an NVMe device, complete the following steps:
 - a) From the Linux command line, type the following command and press Enter.

```
nvme smart-log /dev/nvmeX -H
```

where *nvmeX* is the resource name of the NVMe device.

- b) View the **Percentage used** field.

Is the value in the **Percentage used** field 100%?

 - **Yes:** Continue with the next step.
 - **No:** Continue with step “4” on page 38.
3. The NVMe device is nearing its end of life and must be replaced. The NVMe device will soon reach the limit for the number of write operations that are supported. Write operations to the NVMe device become slower over time, and at some point the NVMe device becomes a read-only device. When the operating system writes data to a read-only device, the write operations are rejected, and the operating system considers the device as if a failure occurred. To support normal write operations, the NVMe device must be replaced.

Note: Failure of IBM NVMe devices is covered in the standard warranty and during the maintenance period only for devices that have not reached the maximum number of write cycles. Devices that reach this limit might fail to operate according to specifications and must be replaced. This replacement cost is not covered under the standard warranty or during the maintenance period.

This ends the procedure.

4. In the **critical_warning** portion of the command output, is the **Available Spare** field displayed?

- **Yes:** Continue with the next step.
 - **No:** Continue with step “6” on page 39.
5. Is the **Available Spare** field equal to 1?
- **Yes:** The NVMe device has low spares. Continue with step “7” on page 39.
 - **No:** A service action is not required. **This ends the procedure.**
6. Complete the following steps to determine if the NVMe device has low spares:
- a) View the **critical_warning** field.
 - b) The **critical_warning** field is a hexadecimal number. Convert the hexadecimal number to a binary number.
 - c) Is the rightmost digit of the binary number equal to 1?
 - **Yes:** The NVMe device has low spares. Continue with the next step.
 - **No:** A service action is not required. **This ends the procedure.**
7. The NVMe device is nearing its end of life and must be replaced. The NVMe device will soon reach the limit for the number of write operations that are supported. Write operations to the NVMe device become slower over time, and at some point the NVMe device becomes a read-only device. When the operating system writes data to a read-only device, the write operations are rejected, and the operating system considers the device as if a failure occurred. To support normal write operations, schedule maintenance to replace the NVMe device at your earliest convenience.
- Note:** Failure of IBM NVMe devices is covered in the standard warranty and during the maintenance period only for devices that have not reached the maximum number of write cycles. Devices that reach this limit might fail to operate according to specifications and must be replaced. This replacement cost is not covered under the standard warranty or during the maintenance period.
- This ends the procedure.**

Notices

This information was developed for products and services offered in the US.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing
IBM Corporation
North Castle Drive, MD-NC119
Armonk, NY 10504-1785
US*

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product and use of those websites is at your own risk.

IBM may use or distribute any of the information you provide in any way it believes appropriate without incurring any obligation to you.

The performance data and client examples cited are presented for illustrative purposes only. Actual performance results may vary depending on specific configurations and operating conditions.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

Statements regarding IBM's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

All IBM prices shown are IBM's suggested retail prices, are current and are subject to change without notice. Dealer prices may vary.

This information is for planning purposes only. The information herein is subject to change before the products described become available.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to actual people or business enterprises is entirely coincidental.

If you are viewing this information in softcopy, the photographs and color illustrations may not appear.

The drawings and specifications contained herein shall not be reproduced in whole or in part without the written permission of IBM.

IBM has prepared this information for use with the specific machines indicated. IBM makes no representations that it is suitable for any other purpose.

IBM's computer systems contain mechanisms designed to reduce the possibility of undetected data corruption or loss. This risk, however, cannot be eliminated. Users who experience unplanned outages, system failures, power fluctuations or outages, or component failures must verify the accuracy of operations performed and data saved or transmitted by the system at or near the time of the outage or failure. In addition, users must establish procedures to ensure that there is independent data verification before relying on such data in sensitive or critical operations. Users should periodically check IBM's support websites for updated information and fixes applicable to the system and related software.

Homologation statement

This product may not be certified in your country for connection by any means whatsoever to interfaces of public telecommunications networks. Further certification may be required by law prior to making any such connection. Contact an IBM representative or reseller for any questions.

Accessibility features for IBM Power Systems servers

Accessibility features assist users who have a disability, such as restricted mobility or limited vision, to use information technology content successfully.

Overview

The IBM Power Systems servers include the following major accessibility features:

- Keyboard-only operation
- Operations that use a screen reader

The IBM Power Systems servers use the latest W3C Standard, [WAI-ARIA 1.0](http://www.w3.org/TR/wai-aria/) (www.w3.org/TR/wai-aria/), to ensure compliance with [US Section 508](http://www.access-board.gov/guidelines-and-standards/communications-and-it/about-the-section-508-standards/section-508-standards) (www.access-board.gov/guidelines-and-standards/communications-and-it/about-the-section-508-standards/section-508-standards) and [Web Content Accessibility Guidelines \(WCAG\) 2.0](http://www.w3.org/TR/WCAG20/) (www.w3.org/TR/WCAG20/). To take advantage of accessibility features, use the latest release of your screen reader and the latest web browser that is supported by the IBM Power Systems servers.

The IBM Power Systems servers online product documentation in IBM Knowledge Center is enabled for accessibility. The accessibility features of IBM Knowledge Center are described in the [Accessibility](http://www.ibm.com/support/knowledgecenter/doc/kc_help.html#accessibility) section of the IBM Knowledge Center help (www.ibm.com/support/knowledgecenter/doc/kc_help.html#accessibility).

Keyboard navigation

This product uses standard navigation keys.

Interface information

The IBM Power Systems servers user interfaces do not have content that flashes 2 - 55 times per second.

The IBM Power Systems servers web user interface relies on cascading style sheets to render content properly and to provide a usable experience. The application provides an equivalent way for low-vision users to use system display settings, including high-contrast mode. You can control font size by using the device or web browser settings.

The IBM Power Systems servers web user interface includes WAI-ARIA navigational landmarks that you can use to quickly navigate to functional areas in the application.

Vendor software

The IBM Power Systems servers include certain vendor software that is not covered under the IBM license agreement. IBM makes no representation about the accessibility features of these products. Contact the vendor for accessibility information about its products.

Related accessibility information

In addition to standard IBM help desk and support websites, IBM has a TTY telephone service for use by deaf or hard of hearing customers to access sales and support services:

TTY service
800-IBM-3383 (800-426-3383)
(within North America)

For more information about the commitment that IBM has to accessibility, see [IBM Accessibility \(www.ibm.com/able\)](http://www.ibm.com/able).

Privacy policy considerations

IBM Software products, including software as a service solutions, (“Software Offerings”) may use cookies or other technologies to collect product usage information, to help improve the end user experience, to tailor interactions with the end user, or for other purposes. In many cases no personally identifiable information is collected by the Software Offerings. Some of our Software Offerings can help enable you to collect personally identifiable information. If this Software Offering uses cookies to collect personally identifiable information, specific information about this offering’s use of cookies is set forth below.

This Software Offering does not use cookies or other technologies to collect personally identifiable information.

If the configurations deployed for this Software Offering provide you as the customer the ability to collect personally identifiable information from end users via cookies and other technologies, you should seek your own legal advice about any laws applicable to such data collection, including any requirements for notice and consent.

For more information about the use of various technologies, including cookies, for these purposes, see IBM’s Privacy Policy at <http://www.ibm.com/privacy> and IBM’s Online Privacy Statement at <http://www.ibm.com/privacy/details/us/en/> in the section entitled “Cookies, Web Beacons and Other Technologies”.

Trademarks

IBM, the IBM logo, and [ibm.com](http://www.ibm.com)[®] are trademarks or registered trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies. A current list of IBM trademarks is available on the web at [Copyright and trademark information](#).

The registered trademark Linux is used pursuant to a sublicense from the Linux Foundation, the exclusive licensee of Linus Torvalds, owner of the mark on a worldwide basis.

Electronic emission notices

Class A Notices

The following Class A statements apply to the IBM servers that contain the POWER9 processor and its features unless designated as electromagnetic compatibility (EMC) Class B in the feature information.

When attaching a monitor to the equipment, you must use the designated monitor cable and any interference suppression devices supplied with the monitor.

Canada Notice

CAN ICES-3 (A)/NMB-3(A)

European Community and Morocco Notice

This product is in conformity with the protection requirements of Directive 2014/30/EU of the European Parliament and of the Council on the harmonization of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of non-IBM option cards.

This product may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.

Warning: This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference.

Germany Notice

Deutschsprachiger EU Hinweis: Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2014/30/EU zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022 / EN 55032 Klasse A ein.

Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung von IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung von IBM gesteckt/eingebaut werden.

EN 55032 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden:

"Warnung: Dieses ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funk-Störungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen zu ergreifen und dafür aufzukommen."

Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten

Dieses Produkt entspricht dem "Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG)". Dies ist die Umsetzung der EU-Richtlinie 2014/30/EU in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) (bzw. der EMC Richtlinie 2014/30/EU) für Geräte der Klasse A

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Einhaltung der EMV Vorschriften ist der Hersteller:

International Business Machines Corp.

New Orchard Road

Armonk, New York 10504

Tel: 914-499-1900

Der verantwortliche Ansprechpartner des Herstellers in der EU ist:

IBM Deutschland GmbH

Technical Relations Europe, Abteilung M456

IBM-Allee 1, 71139 Ehningen, Germany

Tel: +49 (0) 800 225 5426

email: HalloIBM@de.ibm.com

Generelle Informationen:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 / EN 55032 Klasse A.

Japan Electronics and Information Technology Industries Association (JEITA) Notice

(一社) 電子情報技術産業協会 高調波電流抑制対策実施
要領に基づく定格入力電力値： Knowledge Centerの各製品の
仕様ページ参照

This statement applies to products less than or equal to 20 A per phase.

高調波電流規格 JIS C 61000-3-2 適合品

This statement applies to products greater than 20 A, single phase.

高調波電流規格 JIS C 61000-3-2 準用品

本装置は、「高圧又は特別高圧で受電する需要家の高調波抑制対策ガイドライン」対象機器（高調波発生機器）です。

- 回路分類：6（単相、PFC回路付）
- 換算係数：0

This statement applies to products greater than 20 A per phase, three-phase.

高調波電流規格 JIS C 61000-3-2 準用品

本装置は、「高圧又は特別高圧で受電する需要家の高調波抑制対策ガイドライン」対象機器（高調波発生機器）です。

- 回路分類：5（3相、PFC回路付）
- 換算係数：0

Japan Voluntary Control Council for Interference (VCCI) Notice

この装置は、クラスA 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

Korea Notice

이 기기는 업무용 환경에서 사용할 목적으로 적합성평가를 받은 기기로서 가정용 환경에서 사용하는 경우 전파간섭의 우려가 있습니다.

People's Republic of China Notice

声 明

此为 A 级产品,在生活环境中,
该产品可能会造成无线电干扰。
在这种情况下,可能需要用户对其
干扰采取切实可行的措施。

Russia Notice

ВНИМАНИЕ! Настоящее изделие относится к классу А.
В жилых помещениях оно может создавать
радиопомехи, для снижения которых необходимы
дополнительные меры

Taiwan Notice

警告使用者：

此為甲類資訊技術設備，
於居住環境中使用時，可
能會造成射頻擾動，在此
種情況下，使用者會被要
求採取某些適當的對策。

IBM Taiwan Contact Information:

台灣IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路7號3樓
電話：0800-016-888

United States Federal Communications Commission (FCC) Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. Proper cables and connectors are available from IBM-authorized dealers. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party:
International Business Machines Corporation
New Orchard Road
Armonk, NY 10504
Contact for FCC compliance information only: fccinfo@us.ibm.com

Class B Notices

The following Class B statements apply to features designated as electromagnetic compatibility (EMC) Class B in the feature installation information.

When attaching a monitor to the equipment, you must use the designated monitor cable and any interference suppression devices supplied with the monitor.

Canada Notice

CAN ICES-3 (B)/NMB-3(B)

European Community and Morocco Notice

This product is in conformity with the protection requirements of Directive 2014/30/EU of the European Parliament and of the Council on the harmonization of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of non-IBM option cards.

German Notice

Deutschsprachiger EU Hinweis: Hinweis für Geräte der Klasse B EU-Richtlinie zur Elektromagnetischen Verträglichkeit

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2014/30/EU zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022/ EN 55032 Klasse B ein.

Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung von IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung von IBM gesteckt/eingebaut werden.

Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten

Dieses Produkt entspricht dem "Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG)". Dies ist die Umsetzung der EU-Richtlinie 2014/30/EU in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) (bzw. der EMC Richtlinie 2014/30/EU) für Geräte der Klasse B

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Einhaltung der EMV Vorschriften ist der Hersteller:
International Business Machines Corp.
New Orchard Road
Armonk, New York 10504
Tel: 914-499-1900

Der verantwortliche Ansprechpartner des Herstellers in der EU ist:
IBM Deutschland GmbH
Technical Relations Europe, Abteilung M456
IBM-Allee 1, 71139 Ehningen, Germany

Tel: +49 (0) 800 225 5426
email: HalloIBM@de.ibm.com

Generelle Informationen:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55032 Klasse B

Japan Electronics and Information Technology Industries Association (JEITA) Notice

(一社) 電子情報技術産業協会 高調波電流抑制対策実施
要領に基づく定格入力電力値 : Knowledge Centerの各製品の
仕様ページ参照

This statement applies to products less than or equal to 20 A per phase.

高調波電流規格 JIS C 61000-3-2 適合品

This statement applies to products greater than 20 A, single phase.

高調波電流規格 JIS C 61000-3-2 準用品

本装置は、「高圧又は特別高圧で受電する需要家の高調波抑制対策ガイドライン」対象機器（高調波発生機器）です。

- 回路分類 : 6 (単相、PFC回路付)
- 換算係数 : 0

This statement applies to products greater than 20 A per phase, three-phase.

高調波電流規格 JIS C 61000-3-2 準用品

本装置は、「高圧又は特別高圧で受電する需要家の高調波抑制対策ガイドライン」対象機器（高調波発生機器）です。

- 回路分類 : 5 (3相、PFC回路付)
- 換算係数 : 0

Japan Voluntary Control Council for Interference (VCCI) Notice

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

VCCI-B

Taiwan Notice

台灣IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路7號3樓
電話：0800-016-888

United States Federal Communications Commission (FCC) Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult an IBM-authorized dealer or service representative for help.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. Proper cables and connectors are available from IBM-authorized dealers. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party:

International Business Machines Corporation
New Orchard Road
Armonk, New York 10504
Contact for FCC compliance information only: fccinfo@us.ibm.com

Terms and conditions

Permissions for the use of these publications are granted subject to the following terms and conditions.

Applicability: These terms and conditions are in addition to any terms of use for the IBM website.

Personal Use: You may reproduce these publications for your personal, noncommercial use provided that all proprietary notices are preserved. You may not distribute, display or make derivative works of these publications, or any portion thereof, without the express consent of IBM.

Commercial Use: You may reproduce, distribute and display these publications solely within your enterprise provided that all proprietary notices are preserved. You may not make derivative works of these publications, or reproduce, distribute or display these publications or any portion thereof outside your enterprise, without the express consent of IBM.

Rights: Except as expressly granted in this permission, no other permissions, licenses or rights are granted, either express or implied, to the publications or any information, data, software or other intellectual property contained therein.

IBM reserves the right to withdraw the permissions granted herein whenever, in its discretion, the use of the publications is detrimental to its interest or, as determined by IBM, the above instructions are not being properly followed.

You may not download, export or re-export this information except in full compliance with all applicable laws and regulations, including all United States export laws and regulations.

IBM MAKES NO GUARANTEE ABOUT THE CONTENT OF THESE PUBLICATIONS. THE PUBLICATIONS ARE PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, AND FITNESS FOR A PARTICULAR PURPOSE.

