

Command-Line Interface Reference Guide



Command-Line Interface Reference Guide

Note: Before using this information and the product it supports, read the general information in "Getting help and technical assistance," on page 489, "Notices" on page 493, the *Warranty Information* document, and the *Safety Information* and Environmental Notices and User Guide documents on the IBM Documentation CD.

Twenty-seventh Edition (October 2012)

© Copyright IBM Corporation 2012. US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Chapter 1. Introduction	
Before you begin	<u>,</u>
Accessibility features for the BladeCenter	
management module	<u>)</u>

Chapter 2. Using the command-line

interface		•	-	•	. 5
Command-line interface guidelines					. 5
Selecting the command target					. 6
Commands and user authority					. 8
Cabling the management module					. 12
Networked connection					. 13
Direct connection					. 13
Serial connection					. 14
Starting the command-line interface					. 14
IPv6 addressing for initial connection.					. 15
Telnet connection					. 16
Serial connection					. 17
Secure Shell (SSH) connection					. 18
BladeCenter unit configuration					. 20
Configuring the management module					. 21
Starting an SOL session					. 22
Ending an SOL session					. 23
Chapter 3. Command reference					25
Alphabetic command list					. 25
Command list by function					. 27
Command syntax					. 29
accseccfg command.					. 30
advfailover command					. 40
airfilter command (BladeCenter S only	7)				42

C	mmand syntax	•				•	•	•	•	•	. 29	
	accseccfg command.										. 30	
	advfailover command	1.									. 40	
	airfilter command (Bl	ad	еC	ent	er	S of	nly).			. 42	
	alarm command (Blac	de	Cei	nte	rТ	and	d H	IT (onl	y).	. 43	
	alertcfg command .										. 51	
	alertentries command	ι.									. 53	
	autoftp command .										. 60	
	baydata command .										. 63	
	bofm command										. 66	
	boot command										. 72	
	bootmode command										. 74	
	bootseq command .										. 75	
	buildidcfg command										. 80	
	chconfig command .										. 87	
	chlog command										. 93	
	chmanual command										. 95	
	cin command										. 97	
	cinstatus command										. 102	
	clear command	•					•				. 103	
	clearlog command.	•					•				. 105	
	clock command										. 106	
	config command .										. 111	
	console command .							•			. 115	
	dhcpinfo command										. 117	
	displaylog command							•			. 119	
	displaysd command	•	•								. 124	
	dns command										. 126	

env (environment) co	omr	nar	nd								131
ethoverusb command	1.										137
eventinfo command											138
events command .											140
exit command											143
feature command .											144
files command											147
fuelg command.											149
groups command .											159
health command .											163
help command											166
history command	•	•			•					•	168
identify (location LE)	י רו	rom	mz	and						•	169
ifconfig command					-					•	171
info (configuration in	nfor	ma	tior	1) (om	m:	and		•	•	203
iocomp command	101	mu	101		.011		1110	L	•	•	206
kym (keyboard vide	0 r	• •	160)	\cdot	mr	nar	nd	•	•	•	208
Idancfa command	0, 1	1100	10C)		,1111	iiui	ia	•	•	•	210
led command	•	·	•	•	•	•	•	•	•	•	210
list (system physical	• 	fia	• 1183	· tio	n) (•	• • • • •	1	•	220
mead command	con	ing	ura	10		.011	11110	anc	1		225
medactlag command	•	•	•	•	•	•	•	•	•	•	221
monalarta command	•	·	•	•	•	•	•	•	·	•	220
monalerts command	•	1	•	•	•	•	•	•	·	•	229
int (media tray) com	mai	lu	•	•	•	•	•	•	·	•	239
nat command	• • • • • •	•	•	•	•		•	•	•	•	241
ntp (network time pr	oto	COL) CC	omi	mai	na	•	•	·	·	245
ping command	•	·	•	•	•	•	•	•	•	•	248
pmpolicy command	·	·	•	•	•	•	•	•	·	·	251
portctg command .	·	·	•	•	•	•	•	•	•	·	253
ports command.	·	·	•	·	•	•	•	•	•	·	255
power command .	·	·	•	•	•	•	•	•	•	·	272
rdoc command	·	·	•	•	•	•	•	•	•	·	278
read command	·	·	•	•	•	•	•	•	•	·	280
remaccetg command	•	•	•	•	•	•	•	•	•	•	283
remotechassis comma	and		•	•	•	•	•	•	•	•	285
reset command	•	•	•	•	•	•	•	•	•	•	288
scale command.	•	•	•	•	•	•	•	•	•	•	293
sddump command	•	•	•	•	•	•	•	•	•	•	301
sdemail command.	•	•	•	•	•	•	•	•	•	•	303
security command.	•	•	•	•	•	•	•	•	•	·	305
service command .	•	•	•	•	•	•	•	•	•	•	306
shutdown command	•	•	•	•	•	•	•	•	•	•	308
slp command	•	•	•	•	•	•	•	•	•	•	309
smtp command									•	•	311
snmp command .	•	•	•	•	•		•	•		•	314
sol (serial over LAN)	со	mn	nan	d						•	330
sshcfg command .											337
sslcfg command .											339
syslog command .											349
tcpcmdmode comma	nd										353
telnetcfg (Telnet conf	igu	rati	on)) cc	mr	nar	nd				356
temps command .											357
trespass command.											358
uicfg command											361
update (update firmy	var	e) c	om	ıma	and						365
uplink (management	ma	odu	le f	fail	ove	r) (con	nm	and	ł	375

users command									379
vlan command									402
volts command									412
write command									413
zonecfg command.									415
8									
Chapter 4. Error mes	sa	ae	s						419
Common errors		3-	-						421
accessed a command errors	•	•	•	•	•	•	•	• •	/23
advfailover command error	•	•	•	•	•	•	•	• •	120
alarm command errors	.0	•	•	•	•	•	•	• •	121
alartic command arrang	·	•	•	•	•	•	•	• •	426
alertentrice command errors.	•	•	•	•	•	•	•	• •	420
alertentries command arrays	5	•	•	•	•	•	•	• •	420
haudata command arrange	·	•	•	•	•	•	•	• •	427
baydata command errors	·	•	•	•	•	•	•	• •	42/
both command errors .	·	·	•	•	•	•	•	• •	428
boot command errors.	·	·	•	•	•	•	•	• •	429
bootmode command errors	·	•	•	•	•	•	•	• •	429
bootseq command errors	·	·	•	•	•	•	•	• •	430
buildidctg command errors		·	•	•	•	•	•	• •	430
chconfig command errors	•	•	•	•	•	•	•	• •	431
chlog command errors .	•	•	•	•	•	•	•		432
chmanual command errors									433
cin command errors									433
clear command errors .			•				•		435
clearlog command errors									435
clock command errors .									435
config command errors .									436
console command errors.									437
dhcpinfo command errors									438
displaylog command errors	5.								438
displaysd command errors									439
dns command errors									440
env command errors									440
ethoverusb command error	s								440
eventinfo command errors									441
events command errors	•	•	•	•	•	•	•	• •	441
exit command errors	•	•	•	•	•	•	•	• •	442
feature command errors	•	•	•	•	•	•	•	• •	442
files command errors	·	•	•	•	•	•	•	• •	114
fueld command errors	·	•	•	•	•	•	•	• •	115
rueig command errors .	·	•	•	•	•	•	•	• •	445
boolth command errors	·	•	•	•	•	•	•	• •	440
help command arrays	·	•	•	•	•	•	•	• •	440
help command errors.	·	•	•	•	•	•	•	• •	449
history command errors.	·	·	•	•	•	•	•	• •	449
identify command errors	·	·	•	•	•	•	•	• •	449
ifconfig command errors	·	·	•	•	•	•	•	• •	450
info command errors	·	·	•	•	•	•	•	• •	454
locomp command errors.	·	·	•	•	•	•	•	• •	455
kvm command errors	·	·	•	•	•	•	•	• •	455
Idapcfg command errors.	•	•	•	•		•	•		455
led command errors	•	•	•	•			•		456
list command errors						•	•		457
mcad command errors .									457
modactlog command errors	3								457
monalerts command errors									457
monalertsleg command err	ors								458
mt command errors									458
nat command errors									458
ntp command errors									459
ping command errors .									459

pmpolicy command errors	•	•	•				460
portcfg command errors.							460
ports command errors .							460
power command errors .							462
rdoc command errors							462
read command errors							463
remacccfg command errors	5.						464
remotechassis command en	rror	s					464
reset command errors .							465
scale command errors .							465
sddump command errors							466
sdemail command errors							467
security command errors							467
service command errors.							467
shutdown command errors	s.						468
slp command errors							468
smtp command errors .							468
snmp command errors .							469
sol command errors							470
sshcfg command errors .							471
sslcfg command errors .							472
syslog command errors .							474
tcpcmdmode command er	rors						475
telnetcfg command errors							475
temps command errors .							476
thres command errors .							476
trespass command errors							476
uicfg command errors .							477
update command errors.							478
uplink command errors .							480
users command errors .							481
vlan command errors.							485
volts command errors .							486
write command errors .							486
zonecfg command errors							487
U U							

Appendix. Getting help and technical

Appendix: detting help and teenhed	
assistance 4	89
Before you call	489
Using the documentation	490
Getting help and information from the World Wide	
Web	490
How to send DSA data to IBM	490
Creating a personalized support web page	490
Software service and support	491
Hardware service and support	491
IBM Taiwan product service	491
*	
Notices	93
Trademarks	493
Important notes	494
Particulate contamination	495
Documentation format	496
Telecommunication regulatory statement	496
Electronic emission notices	496
Federal Communications Commission (FCC)	
statement.	496
Industry Canada Class A emission compliance	
statement	497

Avis de conformité à la réglementation	
d'Industrie Canada	497
Australia and New Zealand Class A statement	497
European Union EMC Directive conformance	
statement	497
Germany Class A statement	497
Japan VCCI Class A statement	498
Korea Communications Commission (KCC)	
statement	499

Russia Electromagnetic Interference (EMI) Class	
A statement	499
People's Republic of China Class A electronic	
emission statement	499
Taiwan Class A compliance statement	499
-	
Index	01

Chapter 1. Introduction

This topic provides a short introduction to the BladeCenter advanced management module command-line interface. Information about the command-line interface for management modules other than the advanced management module is in a separate document.

The IBM[®] BladeCenter[®] advanced management-module command-line interface (CLI) provides direct access to BladeCenter management functions as an alternative to using the web-based user interface. Using the command-line interface, you can issue commands to control the power and configuration of the management module and other components that are in a BladeCenter unit.

All IBM BladeCenter units are referred to throughout this document as the BladeCenter unit. All management modules are referred to throughout this document as the management module. Unless otherwise noted, all commands can be run on all management-module and BladeCenter unit types.

- When a command is labeled "BladeCenter H only", it can run on all types of BladeCenter H units (BladeCenter H and BladeCenter HT).
- When a command is labeled "BladeCenter T only", it can run on all types of BladeCenter T units (BladeCenter T and BladeCenter HT).
- When a command is labeled "Blade Center S only", it can run on all types of BladeCenter S units.

The command-line interface also provides access to the text-console command prompt on each blade server through a serial over LAN (SOL) connection. See the *IBM BladeCenter Serial Over LAN Setup Guide* for information about SOL and setup instructions.

You access the management-module CLI by establishing a Telnet connection to the IP address of the management module or through a Secure Shell (SSH) connection. You can initiate connections from the client system by using standard remote communication software; no special programs are required. Users are authenticated by the management module before they can issue commands. You enter commands one at a time; however, you can use command scripting to enter multiple commands. The interface does not support keyboard shortcuts, except for the special key sequence, Esc (, that terminates an SOL session.

The most recent versions of all BladeCenter documentation are available from http://www.ibm.com/systems/support/.

IBM Redbooks publications are developed and published by the IBM International Technical Support Organization (ITSO). The ITSO develops and delivers skills, technical know-how, and materials to IBM technical professionals, Business Partners, clients, and the marketplace in general. For IBM Redbooks publications for your BladeCenter, go to http://www.redbooks.ibm.com/portals/bladecenter.

Before you begin

The following hardware and software is required for the command-line interface:

Hardware:

No special hardware is required to use the management-module command-line interface.

To use the SOL feature, an Ethernet I/O module that supports SOL must be installed in I/O-module bay 1. You can use the console command to control a blade server through SOL only on blade server types that support SOL functionality and have an integrated service processor firmware level of version 1.00 or later. See the *IBM BladeCenter Serial Over LAN Setup Guide* for information.

Firmware:

Make sure that you are using the latest versions of device drivers, firmware, and BIOS code for your blade server, management module, and other BladeCenter components. Go to http://www.ibm.com/systems/ support/ for the latest information about upgrading the device drivers, firmware, and BIOS code for BladeCenter components. The latest instructions are in the documentation that comes with the updates.

The management-module CLI is supported by BladeCenter management-module firmware level version 1.08 or later. All versions of BladeCenter T management-module firmware and advanced management module firmware support the command-line interface. The SOL feature has additional firmware requirements. See the *IBM BladeCenter Serial Over LAN Setup Guide* for information.

Accessibility features for the BladeCenter management module

Accessibility features help users who have a disability, such as restricted mobility or limited vision, to use information technology products successfully.

Accessibility features

Accessibility for the BladeCenter management module interface is provided through the command-line interface. The remote control video feed is not accessible to a screen reader.

The BladeCenter Information Center is accessibility-enabled. The accessibility features of the information center include:

- Keyboard-only operation
- Interfaces that are commonly used by screen readers. (The Java access bridge must be installed to make Java applets available to the JAWS screen reader.)
- The attachment of alternative input and output devices

Keyboard navigation

This product uses standard Microsoft[®] Windows[®] navigation keys.

Related accessibility information

You can view the publications for IBM BladeCenter in Adobe[®] Portable Document Format (PDF) using the Adobe Acrobat[®] Reader. The PDFs are provided on a CD

that is packaged with the product, or you can access them through the IBM BladeCenter Information Center.

IBM and accessibility

See the IBM Human Ability and Accessibility Center for more information about the commitment that IBM has to accessibility.

Chapter 2. Using the command-line interface

This topic tells you how to use the management module command-line interface.

The IBM management-module command-line interface (CLI) provides a convenient method for entering commands that manage and monitor BladeCenter components. This chapter contains the following information about using the command-line interface:

- "Command-line interface guidelines"
- "Selecting the command target" on page 6
- "Commands and user authority" on page 8
- "Cabling the management module" on page 12
- "Starting the command-line interface" on page 14
- "BladeCenter unit configuration" on page 20
- "Configuring the management module" on page 21
- "Starting an SOL session" on page 22
- "Ending an SOL session" on page 23

See Chapter 3, "Command reference," on page 25 for detailed information about commands that are used to monitor and control BladeCenter components. Command-line interface error messages are in Chapter 4, "Error messages," on page 419. See the *IBM BladeCenter Serial Over LAN Setup Guide* for SOL setup instructions and the documentation for your operating system for information about commands that you can enter through an SOL connection.

Command-line interface guidelines

This topic gives general guidelines for using the BladeCenter command-line interface.

All commands have the following basic structure:

command -option parameter

Some commands do not require options and some command options do not require parameters. You can add multiple options to a command on one line to avoid repeating the same command. Options that display a value and options that set a value must not be used together in the same command. The following examples illustrate valid command option syntax:

- command
- command -option_set
- command -option_set parameter
- command -option1_set parameter -option2_set parameter

The information for each option is returned in the order in which it was entered and is displayed on separate lines. Observe the following general guidelines when you use the command-line interface:

Case sensitivity

All commands, command options, and predefined command option parameters are case sensitive.

Note: If you receive a Command not found error, make sure that you are typing the command in the correct case. For a list of valid commands, type help or ?.

Data types

The ip_address data type uses a predefined formatted string of xxx.xxx.xxx, where xxx is a number from 0 to 255.

- Delimiters
 - Options are delimited with a minus sign.
 - In a command that requires parameters, a single space is expected between an option and its parameter. Any additional spaces are ignored.
- Output format
 - Failed commands generate failure messages.
 - Successful commands are indicated by the message OK or by the display of command results.
- Strings
 - Strings that contain spaces must be enclosed in quotation marks, for example, snmp -cn "John B. Doe".
 - String parameters can be mixed case.
- The help command lists all commands and a brief description of each command. You can also issue the help command by typing ?. Adding the -h parameter to any command displays its syntax.
- You can use the Up Arrow and Down Arrow keys in the command-line interface to access the last eight commands that you entered.

Selecting the command target

This topic describes command targets and the persistent command environment.

You can use the command-line interface to target commands to the management module or to other devices in the BladeCenter unit. The command-line prompt indicates the persistent command environment: the environment in which commands are entered unless they are otherwise redirected. When a command-line interface session is started, the persistent command environment is system; this indicates that commands are being directed to the BladeCenter unit.

Command targets are specified hierarchically, as shown in the following illustration. This illustration shows command targets for all management module and BladeCenter unit types.



You can change the persistent command environment for the remainder of a command-line interface session by using the env command (see "env (environment) command" on page 131). When you list the target as a command attribute by using the -T option, you change the target environment for the command that you are entering, temporarily overriding the persistent command environment. You can specify target environments by using the full path name or by using a partial path name that is based on the persistent command environment. Full path names always begin with "system". The levels in a path name are divided using a colon (:).

For example:

- Use the -T system:mm[1] option to redirect a command to the management module in bay 1.
- Use the -T system:switch[1] option to redirect a command to the I/O (switch) module in I/O (switch) module bay 1.
- Use the -T sp option to redirect a command to the integrated service processor in the blade server in blade server bay 3, when the persistent command environment is set to the blade server in blade server bay 3.

Most management-module commands must be directed to the primary management module. If only one management module is installed in the BladeCenter unit, it always acts as the primary management module. Either management module can function as the primary management module; however, only one management module can be primary at one time. You can determine which management module is acting as the primary management module by using the list command (see "list (system physical configuration) command" on page 225).

Commands and user authority

This topic lists command-line interface commands and the user authority levels needed to run them.

Some commands in the command-line interface can be executed only by users who are assigned a required level of authority. Users with Supervisor command authority can execute all commands. Commands that display information do not require any special command authority; however, users can be assigned restricted read-only access, as follows:

- Users with Operator command authority can execute all commands that display information.
- Users with Chassis Operator custom command authority can execute commands that display information about the common BladeCenter unit components.
- Users with Blade Operator custom command authority can execute commands that display information about the blade servers.
- Users with Switch Operator custom command authority can execute commands that display information about the I/O modules.

Table 1 on page 9 shows the command-line interface commands and their required authority levels. To use the table, observe the following guidelines:

- The commands in this table apply only to the command variants that set values or cause an action and require a special command authority: display variants of the commands do not require any special command authority.
- If a command requires only one command authority at a time, each of the applicable command authorities is indicated by a dot (•). If a command requires a combination of two or more command authorities, the applicable command authorities are indicate by ◊ or ‡. For example, the boot -c command is available to a user with the Supervisor command authority and to a user with both the Blade Administration and Blade Remote Presence command authorities.

Important: Command authority definitions might change between firmware versions. Make sure that the command authority level for each user is correct after you update the management-module firmware.

Notes:

- 1. LDAP (lightweight directory access protocol) authority levels are not supported by management modules other than the advanced management module.
- **2.** LDAP authority levels are not supported by the management-module web interface.
- **3**. To use the LDAP authority levels, you must make sure that the version of LDAP security that is used by the management module is set to v2 (enhanced role-based security model). See "Idapcfg command" on page 210 for information.

Table 1. Command authority relationships

	Authority												
Command	Supervisor	Chassis Account Management	Chassis Log Management	Chassis Administration	Chassis Configuration	Blade Administration	Blade Configuration	Blade Remote Presence	I/O Module Administration	I/O Module Configuration			
accseccfg	•				•								
advfailover	•				•								
airfilter	•	•	•	•	•								
alarm -c, -r, -s	•				•		•			•			
alarm -q -g	•					•		•					
alertcfg	•				•								
alertentries	•				•								
alertentries -test	•		•	•	•	•	•	•	•	•			
autoftp	•				•								
baydata	•						•						
bofm	•				•								
boot (blade server)	•					•							
boot -c	•					\diamond		\diamond					
boot -p	•					•							
bootmode	•						•						
bootseq	•						•						
buildidcfg	•					•	•	•					
chconfig	•				•								
chlog	•				•								
chmanual	•	•	•	•	•	•	•	•	•	•			
cin	•	\diamond			\diamond								
clear	•			\diamond	\diamond				‡	‡			
clearlog	•		•										
clock	•				•								
config (blade server)	•						•						
config (management module or BladeCenter unit)	•				•								
console	•							•					
displaylog -lse	•		•										
dns	•				•								

Table 1. Command authority relationships (continued)

	Authority											
Command	Supervisor	Chassis Account Management	Chassis Log Management	Chassis Administration	Chassis Configuration	Blade Administration	Blade Configuration	Blade Remote Presence	I/O Module Administration	I/O Module Configuration		
ethoverusb	•					•						
events -che	•	•	•	•	•	•	•	•	•	•		
events -che -add -rm	•				•							
feature	•			•								
files -d	•			•	•	•	•		•	•		
fuelg	•				•							
groups	•				•							
identify	•				•		•					
ifconfig (blade server target)	•						•					
ifconfig (blade server ISMP, management module, and system targets)	•				•							
ifconfig (I/O module target)	•									•		
ifconfig -pip (I/O module target)	•								•	•		
kvm -b	•							•				
kvm -local	•				•							
ldapcfg	•				•							
led -info, -d, -loc (system target)	•	•	•	•	•							
led -info, -loc (blade server target)	•					•	•	•				
mcad	•				•							
monalerts	•				•							
mt -b	•							•				
mt -local, -remote	•				•							
nat	•									•		
ntp	•				•							
ping -i (see Note 1)	•								•	•		
pmpolicy	•				•							
portcfg	•				•							
ports	•				•							

Table 1. Command authority relationships (continued)

				_	Auth	ority			-	_
Command	Supervisor	Chassis Account Management	Chassis Log Management	Chassis Administration	Chassis Configuration	Blade Administration	Blade Configuration	Blade Remote Presence	I/O Module Administration	I/O Module Configuration
ports (I/O module target)										•
power -on, -off, -softoff, -cycle	•					•			•	
power -on -c, -cycle -c	•					\diamond		\diamond		
power -wol, -local	•				•		•			
power -fp (global)	•				•					
power -fp (I/O module)	•								•	
rdoc	•							•		
read	•				•					
remacccfg	•				•					
reset (blade server or ISMP)	•					•				
reset (I/O module)	•								•	
reset (management module)	•			•						
reset -c, -clr, -dg, -ddg, -sft, (blade server)	•					\diamond		\diamond		
reset -sms (blade server)	•					•				
reset -exd, -full, -std (I/O module)	•								•	
reset -f, -standby, -force (management module)	•			•						
scale	•					•				
sddump	•					•				
sdemail	•	•	•	•	•	•	•	•	•	•
security	•				•					
service	•				•					
shutdown	•					•				
slp	•				•					
smtp	•				•					
snmp	•				•					

Table 1. Command authority relationships (continued)

	Authority									
Command	Supervisor	Chassis Account Management	Chassis Log Management	Chassis Administration	Chassis Configuration	Blade Administration	Blade Configuration	Blade Remote Presence	I/O Module Administration	I/O Module Configuration
sol	•				•		•			
sshcfg	•				•					
sslcfg	•				•					
syslog	•				•					
tcpcmdmode	•				•					
telnetcfg	•				•					
trespass	•				•					
uicfg	•				•					
update	•			•		•			•	
uplink	•				•					
users	•	•								
users -disable, -enable, -unlock	•	•		•	•					
vlan	•				•					
write	•				•					
zonecfg	•									•

Note:

 All users can execute the ping -i command directed to a specific IP address. Users with Supervisor, Operator (general operator), I/O Module Administration, I/O Module Configuration, or I/O Module Operator authority can execute the ping -i command option with no arguments or ping a specific IP address that is identified using its index number.

Cabling the management module

This topic describes how to cable the management module.

You must connect a client system to the management module to configure and manage operation of the BladeCenter unit. All management modules support a remote management and console (Ethernet) connection. The advanced management module also supports connection through the serial management port.

You can manage the BladeCenter unit by using by using the command-line interface that you access through Telnet or through the serial management port. You can also use the graphical user interface that is provided by the management-module web interface to manage the BladeCenter unit and blade servers that support KVM. To make management connections to blade servers that do not support KVM, use an SOL session through the management-module command-line interface.

To access the management-module command-line interface, you need the following equipment and information:

- A system with Ethernet or serial connection capability. To facilitate connections at multiple locations, you can use a notebook computer.
- The management-module MAC address (listed on the label on the management module).
- For networked connection to the management module, you need a standard Ethernet cable and a local Ethernet network port (facility connection).
- For direct connection of a system to the advanced management-module remote management and console (Ethernet) connector, you can use either a standard Ethernet cable or an Ethernet crossover cable.
- For serial connection of a system to the advanced management-module serial connector, you need a serial cable. See the *Installation Guide* for your management module for cabling information and instructions.

For information about accessing the management-module web interface, see the *BladeCenter Advanced Management Module User's Guide*.

The following topics describe how to cable to the management module to perform initial configuration of the BladeCenter unit. See the *Installation Guide* for your management module for specific cabling instructions.

Networked connection

This topic describes how to connect the management module to a network.

Connect one end of a Category 5 or higher Ethernet cable to the remote management and console (Ethernet) connector of the management module. Connect the other end of the Ethernet cable to the facility network.

Direct connection

This topic tells you how to connect a client computer directly to the management module.

Connect one end of a Category 5 or higher Ethernet cable or a Category 5 or higher Ethernet crossover cable to the remote management and console (Ethernet) connector of the management module. Connect the other end of the cable to the Ethernet connector on the client system.

Note: An advanced management module can perform an automatic media dependent interface (MDI) crossover, eliminating the need for crossover cables or cross-wired (MDIX) ports. You might have to use a crossover cable to connect your system to the advanced management module if the network interface card in the client system is very old.

Serial connection

You can connect a serial cable to the advanced management module.

Connect one end of a serial cable to the serial connector on the management module. Connect the other end of the serial cable to the serial connector on the client system. See the *Installation Guide* for your management module for cabling information and instructions.

Starting the command-line interface

Access the management-module command-line interface from a client system by establishing a Telnet connection to the IP address of the management module or by establishing a Secure Shell (SSH) connection.

For the advanced management module, you can also access the command-line interface using a serial connection. You can establish up to 20 separate Telnet, serial, or SSH sessions to the BladeCenter management module, giving you the ability to have 20 command-line interface sessions active at the same time.

Although a remote network administrator can access the management-module command-line interface through Telnet, this method does not provide a secure connection. As a secure alternative to using Telnet to access the command-line interface, use a serial or SSH connection. SSH ensures that all data that is sent over the network is encrypted and secure.

The following SSH clients are available. Although some SSH clients have been tested, support or nonsupport of any particular SSH client is not implied.

- The SSH clients that are distributed with operating systems such as Linux, AIX[®], and UNIX (see your operating-system documentation for information). The SSH client of Red Hat Linux 8.0 Professional was used to test the command-line interface.
- The SSH client of cygwin (see http://www.cygwin.com for information)
- Putty (see http://www.chiark.greenend.org.uk/~sgtatham/putty for information)

The following table shows the types of encryption algorithms that are supported, depending on the client software version that is being used.

Algorithm	SSH version 2.0 clients
Public key exchange	Diffie-Hellman-group 1-sha-1
Host key type	DSA - 2048-bit
Bulk cipher algorithms	3-des-cbc or blowfish-cbc
MAC algorithms	Hmac-sha1

The following topics describe how to connect your system to the management module to perform initial configuration of the BladeCenter unit. The management module has the following default settings:

Note: The advanced management module does not have a fixed static IPv6 IP address by default. For initial access to the advanced management module in an IPv6 environment, users can either use the IPv4 IP address or the IPv6 link-local address. See "IPv6 addressing for initial connection" for information about determining IPv6 addressing for initial connection.

- IPv4 IP address: 192.168.70.125 (primary and secondary management module)
- IPv4 Subnet: 255.255.255.0
- User ID: USERID (all capital letters)
- Password: PASSW0RD (note the number zero, not the letter O, in PASSW0RD)

For IPv4, the system that you are connecting to the management module must be configured to operate on the same subnet as the BladeCenter management module. If the IP address of the management module is outside of your local domain, you must change the Internet protocol properties on the system that you are connecting.

Note: For advanced management modules, the available password options depend on the password options that are configured for the BladeCenter unit.

IPv6 addressing for initial connection

When using IPv6 addressing, the only way to initially connect to the advanced management module is by using the IPv6 link-local address.

The link-local address is a unique IPv6 address for the advanced management module that is automatically generated based on its MAC address. It is of the form: FE80::3BA7:94FF:FE07:CBD0.

The link-local address for the advanced management module can be determined in one of the following ways:

- Some advanced management modules will list the link-local address on a label that is attached to the advanced management module.
- If you are able to log in to the management module command-line interface (CLI) using IPv4 addressing, the link-local address can be viewed using the ifconfig command (see "ifconfig command" on page 171 for information).
- If you are able to log in to the management module web interface using IPv4 addressing, the link-local address can be viewed in the Primary Management Module, IPv6 section of the **MM Control** → **Network Interfaces** page (see the *BladeCenter Advanced Management Module User's Guide* for information).

If the advanced management module does not have a label listing the link-local address and you are unable to access the advanced management module using IPv4, complete the following steps to calculate link-local address:

- Write down the MAC address of the advanced management module. It is on a label on the management module, below the IP reset button. The label reads MMxxxxxxxxx, where xxxxxxxxx is the MAC address. For example, 39-A7-94-07-CB-D0
- 2. Split the MAC address into two parts and insert FF-FE in the middle. For example,

39-A7-94-**FF-FE**-07-CB-D0

- **3**. Convert the two hexadecimal digits at the left end of the string to binary. For example,
 - **39**-A7-94-FF-FE-07-CB-D0
 - 00111001-A7-94-FF-FE-07-CB-D0
- 4. Invert the value for bit 7 of the binary string. For example,
 - 00111001-A7-94-FF-FE-07-CB-D0
 - 00111011-A7-94-FF-FE-07-CB-D0
- 5. Convert the binary digits at the left end of the string back to hexadecimal. For example,
 - 00111011-A7-94-FF-FE-07-CB-D0
 - 3B-A7-94-FF-FE-07-CB-D0
- 6. Combine the hexadecimal digit pairs into 4-digit groups. For example,
 - 3B-A7-94-FF-FE-07-CB-D0
 - 3BA7-94FF-FE07-CBD0
- 7. Replace dash (-) separators with colon (:) separators. For example,
 - 3BA7-94FF-FE07-CBD0
 - 3BA7:94FF:FE07:CBD0
- 8. Add FE80:: to the left of the string. For example,

FE80::3BA7:94FF:FE07:CBD0

For a MAC address of 39-A7-94-07-CB-D0, the link-local address used for initial IPv6 access is FE80::3BA7:94FF:FE07:CBD0.

Telnet connection

This topic tells you how to establish a Telnet session with the management module.

To log on to the management module by using Telnet, complete the following steps:

From a command-line prompt on the network-management workstation, type telnet *ip_address* (where *ip_address* is the management module IP address), and press Enter. For the first connection to the management module, use the default IP address of the management module; if a new IP address has been assigned to the management module, use that one instead.

Note: The factory-defined static IPv4 IP address is 192.168.70.125, the default IPv4 subnet address is 255.255.255.0, and the default host name is MM*xxxxxxxxx*, where *xxxxxxxxxx* is the burned-in MAC address. The MAC address is on a label on the management module, below the IP reset button. See "IPv6 addressing for initial connection" on page 15 for information about determining IPv6 addressing for initial connection.

2. At the login prompt, type the management-module user ID. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module web access. The default management-module user name is USERID, and the default password is PASSW0RD (note the number zero, not the letter O, in PASSW0RD).

The CLI command prompt is displayed. You can now enter commands for the management module.

Serial connection

You can set up a serial connection with the management module.

After you connect a serial cable from the management module to the client system, complete the following steps:

- 1. Open a terminal session on the client system, and make sure that the serial port settings for the client system match the settings for the serial port on the management module. The default management-module serial port settings are as follows:
 - Baud rate (BPS): 57600
 - Data bits: 8
 - Parity: no parity
 - Stop bits: 1
 - Flow control: none
- 2. If any of the serial port settings for the client system were changed, reset the management module (see the *Installation Guide* for your management module for instructions).
- **3**. At the login prompt, type the management-module user ID. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module web access. The default management-module user name is USERID, and the default password is PASSW0RD (note the number zero, not the letter O, in PASSW0RD).

The CLI command prompt is displayed. You can now enter commands for the management module.

Secure Shell (SSH) connection

This topic tell you how to establish a Secure Shell (SSH) connection with the management module.

To log on to the management module using SSH, complete the following steps:

- 1. Make sure that the SSH service on the network-management workstation is enabled. See your operating-system documentation for instructions.
- 2. Make sure that the SSH server on the BladeCenter management module is enabled. See the *BladeCenter Advanced Management Module User's Guide* for instructions.
- **3.** Start an SSH session to the management module, using the SSH client of your choice. For example, if you are using the cygwin client, from a command prompt on the network-management workstation, type ssh *ip_address* (where *ip_address* is the management module IP address), and press Enter. For the first connection to the management module, use the default IP address of the management module; if a new IP address has been assigned to the management module, use that one instead.

Note: The factory-defined static IPv4 IP address is 192.168.70.125, the default IPv4 subnet address is 255.255.255.0, and the default host name is MM*xxxxxxxxx*, where *xxxxxxxxxx* is the burned-in MAC address. The MAC address is on a label on the management module, below the IP reset button. See "IPv6 addressing for initial connection" on page 15 for information about determining IPv6 addressing for initial connection.

4. Type the management-module user ID when you are prompted. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module web access. The default management-module user name is USERID, and the default password is PASSW0RD (note the number zero, not the letter O, in PASSW0RD).

The CLI command prompt is displayed. You can now enter commands for the management module.

Using the Secure Shell server

This topic tells you how to use the management module Secure Shell server.

The following SSH clients are available. Although some SSH clients have been tested, support or nonsupport of any particular SSH client is not implied.

- The SSH clients that are distributed with operating systems such as Linux, AIX[®], and UNIX[®] (see your operating-system documentation for information).
- The SSH client of cygwin (see http://www.cygwin.com for information).

If you are using the Secure Shell client that is based on OpenSSH, such as the client that is included in Red Hat Linux version 7.3, to start an interactive command-line Secure Shell session to a management module with network address 192.168.70.2, type a command similar to the following example:

ssh -x -l USERID 192.168.70.2

where -x indicates no X Window System forwarding and -l indicates that the session is to use the login ID USERID.

The advanced management module supports non-interactive Secure Shell sessions. This is most useful when it is combined with public key authentication. Use this capability to issue a single CLI command by adding the command to the end of the ssh command. For example, to get a list of the current users of the advanced management module type

ssh -l USERID 192.168.70.2 users -T mm[1] -curr

If the CLI command requires special characters such as quotation marks, you must escape them so that they are not consumed by the command shell on your client system. For example, to set a new trespass warning, type a command similar to the following example:

ssh -l USERID 192.168.70.2 trespass -T mm[1] -tw \"New WARNING\"

To start a Serial over LAN text redirection session to a blade server, the process is similar, but in this case you must specify that the Secure Shell server session uses a pseudo-terminal (PTY) to get the correct output formatting and keystroke handling. In the following example, which starts a Serial over LAN session to the blade server in slot 2, the -t SSH client option specifies that a PTY is to be allocated.

ssh -t -l USERID 192.168.70.1 console -T blade[2]

Using SMASH

You can use the System Management Architecture for Server Hardware Command Line Protocol (SMASH CLP) for the advanced management module. See the *IBM SMASH Proxy Installation and User's Guide* for more information.

To start an interactive SMASH CLP session by using an SSH client such as OpenSSH client with an advanced management module with networking address 192.168.70.2, type a command similar to the following example:

ssh -p 50022 -l USERID 192.168.70.2

where -p 50022 specifes TCP port 50022, the default port number for Secure SMASH on the advanced management module, and -1 USERID specifies one of the 12 local account login IDs.

The advanced management module supports non-interactive Secure SMASH sessions. This is most useful when it is combined with public key authentication. Use this capability to issue a single SMASH CLP command. To start a non-interactive SMASH session, you must specify that the Secure SMASH server uses a pseudo-terminal (PTY). If you fail to specify a PTY for the session the Input Redirection not Supported error message is displayed. For example, to get a list of the SMASH-addressable entities, type a command similar to the following example:

ssh -t -p 50022 -l USERID 192.168.70.2 show /modular1

where -t specifies that a PTY is required for the session and show /modular1 is the SMASH command that is to be executed on the advanced management module.

If you are using a Telnet client to start an interactive SMASH CLP session, you must specify the correct TCP port number. By default, the port that is assigned to the SMASH protocol is 50023.

SSH CLI exit codes

The SSH CLI commands return exit codes.

All CLI commands that are run in an SSH client single-command environment provide exit codes to indicate their outcomes. The following table shows exit codes that are supported; other exit codes are reserved for future use.

Table 2. SSH CLI exit codes

Name	Value (decimal)	Description
EX_OK	0	Successful command execution.
EX_USAGE	64	Command-line usage error: syntax error, wrong command arguments or number of arguments, or invalid command target.
EX_DATAERR	65	Input data error: invalid configuration file or SSH key parsing error.
EX_NOINPUT	66	The input file does not exist or is not readable.
EX_UNAVAILABLE	69	The command-line interface is not available: CLI oversubscribed, CLI disabled, or the data returned by a command has an unexpected value.
EX_SOFTWARE	70	Internal software error. Check the management-module event log for other error indications.
EX_TEMPFAIL	75	The command could not perform a write operation because the device or management module was not in the correct state. Check for conflicting tasks or conditions and try to run the command again.
CLI_ERR_NOT_AUTHORIZED	126	Authorization error: the user does not have sufficient privileges to execute command.
CLI_ERR_CNF	127	Command not found.

BladeCenter unit configuration

You must configure the BladeCenter unit for command-line interface operation.

The BladeCenter unit automatically detects the modules and blade servers that are installed and stores the vital product data (VPD). When the BladeCenter unit is started, the management module automatically configures the remote management port of the management module, so that you can configure and manage BladeCenter components. You configure and manage BladeCenter components remotely by using the management-module command-line interface (CLI) or the management-module web interface.

To communicate with network resources and with the I/O modules in the BladeCenter unit, you must configure IP addresses for the management module and I/O modules. You can configure management-module IP addresses by using the web interface or command-line interface. You can configure the I/O modules through the management-module web interface or through an external I/O-module port that is enabled through the management module, using a Telnet interface, a serial connection, or a web browser. See the documentation that comes with each I/O module for information and instructions.

To communicate with the blade servers for functions such as deploying an operating system or application program over a network, you must also configure at least one external (in-band) port on an Ethernet switch module in I/O-module bay 1 or 2.

Note: If a pass-thru module is installed in I/O-module bay 1 or 2 (instead of an Ethernet I/O module), you must configure the network switch that the pass-thru module is connected to; see the documentation that comes with the network switch for instructions.

Configuring the management module

You must configure the management module for command-line interface operation.

You configure only the primary (active) management module. The standby (redundant) management module, if present, receives the configuration and status information automatically from the primary management module when necessary. The configuration information in this topic applies to the primary management module, which might be the only management module in the BladeCenter unit.

If the management module that you installed is a replacement for the only management module in the BladeCenter unit and you saved the configuration file before you replaced the management module, you can apply the saved configuration file to the replacement management module. For advanced management modules, see "read command" on page 280 for information about applying a saved configuration file.

For the primary management module to communicate, you must configure the IP address for the external Ethernet (remote management) port (eth0) of the management module. The initial automatic management module configuration enables a remote console to connect to the management module to configure the port completely and to configure the rest of the BladeCenter unit.

Note: The internal Ethernet ports (eth1) for the advanced management module cannot be configured.

After you connect the primary management module to the network, the Ethernet port connection is configured in one of the following ways. Either of these actions enables the Ethernet connection on the primary management module.

- If you have an accessible, active, and configured dynamic host configuration protocol (DHCP) server on the network, the IP address, gateway address, subnet mask, and DNS server IP address are set automatically. The host name is set to the management-module MAC address by default, and the domain server cannot change it.
- If the DHCP server does not respond within 2 minutes after the port is connected, the management module uses the factory-defined static IP address and default subnet address.

Note: If the management-module DHCP setting is set to try the DHCP server and then use the static IP address, the management module uses the static IP address when the DHCP server is not available during management-module startup. When this occurs, the IP address might not be reachable if multiple management modules were started with the same static IP address.

Important: You cannot connect your system to the management module by using the factory-defined static IP address and default subnet address until at least 3 minutes after management-module startup.

Note: If the IP configuration is assigned by the DHCP server, you can use the MAC address of the management-module network interface to find out what IP

address is assigned.

To configure the management-module Ethernet ports, complete the following steps:

- 1. Connect your system to the management-module command-line interface (see "Starting the command-line interface" on page 14 for more information).
- 2. Configure the external Ethernet interface (eth0), using the ifconfig command (see "ifconfig command" on page 171 for instructions).

Notes:

- The internal Ethernet management port on each I/O module provides for communication with the management module. You configure this port by configuring the IP address for the I/O module (see the *BladeCenter Advanced Management Module User's Guide* and the *User's Guide* for your I/O module type for information and instructions). Some types of I/O modules, such as the pass-thru module, have no management port. See the documentation that comes with each I/O module to determine what else you must configure in the I/O module.
- For I/O-module communication with a remote management station, such as an IBM[®] Systems Director management server, through the management-module external Ethernet port, the I/O-module internal network interface and the management-module internal and external interfaces must be on the same subnet.
- To communicate with the blade servers for functions such as deploying an operating system or application program, you also must configure at least one external (in-band) port on an Ethernet I/O module.

Starting an SOL session

After you start a Telnet or SSH session to the BladeCenter management module, you can start an SOL session to any individual blade server that supports SOL.

Note: Serial over LAN (SOL) must be enabled for both the BladeCenter unit and the blade server before you can start an SOL session with the blade server. See "sol (serial over LAN) command" on page 330 and the *BladeCenter Serial over LAN Setup Guide* for information about setting up and enabling SOL.

Because you can start up to 20 separate web interface, Telnet, serial, or SSH sessions to the BladeCenter management module, simultaneous SOL sessions can be active for each blade server installed in the BladeCenter unit.

Start an SOL session by using the console command, from the command line, indicating the target blade server. For example, to start an SOL connection to the blade server in blade bay 6, type

console -T system:blade[6]

Note: A blade server assembly that occupies more than one blade server bay is identified by the lowest bay number that it occupies.

After an SOL session is started, all commands are sent to the blade server that is specified by the console command until the SOL session is ended, regardless of the persistent command target that was in effect before the SOL session.

See "sol (serial over LAN) command" on page 330 and the *IBM BladeCenter Serial* over LAN Setup Guide for information about configuring a blade server for SOL. See

your operating-system documentation for information about SOL commands that you can enter by using the command-line interface.

Ending an SOL session

To end an SOL session, press Esc followed by an opening parenthesis.

When the SOL session ends, the command-line interface returns to the persistent command target that was in effect before the SOL session. If you want to end the Telnet or SSH command-line session, type exit.

Note: Exiting an SOL session does not stop the flow of serial data.

Chapter 3. Command reference

This topic contains command function, usage information, and examples.

Commands in "Command syntax" on page 29 are listed in alphabetic order. The commands are also listed in the following two topics:

- "Alphabetic command list"
- "Command list by function" on page 27

Adding a -h, -help, or ? option to a command displays syntax help for that command. For example, to display help for the environment command, type one of the following commands:

- env -h
- env -help
- env ?

You can target a command to a device other than the one that is set as the default by adding a -T option to a command. See "Selecting the command target" on page 6 for information.

Alphabetic command list

In alphabetic order, the commands are as follows:

- "accseccfg command" on page 30
- "advfailover command" on page 40
- "airfilter command (BladeCenter S only)" on page 42
- "alarm command (BladeCenter T and HT only)" on page 43
- "alertcfg command" on page 51
- "alertentries command" on page 53
- "autoftp command" on page 60
- "baydata command" on page 63
- "bofm command" on page 66
- "boot command" on page 72
- "bootmode command" on page 74
- "bootseq command" on page 75
- "buildidcfg command" on page 80
- "chconfig command" on page 87
- " "chlog command" on page 93
- "chmanual command" on page 95
- "cin command" on page 97
- "cinstatus command" on page 102
- "clear command" on page 103
- "clearlog command" on page 105
- "clock command" on page 106
- "config command" on page 111
- "console command" on page 115
- "dhcpinfo command" on page 117
- "displaylog command" on page 119
- "displaysd command" on page 124
- "dns command" on page 126
- "env (environment) command" on page 131
- "ethoverusb command" on page 137

- "eventinfo command" on page 138
- "events command" on page 140
- "exit command" on page 143
- "feature command" on page 144
- "files command" on page 147
- "groups command" on page 159
- "fuelg command" on page 149
- "health command" on page 163
- "help command" on page 166
- "history command" on page 168
- "identify (location LED) command" on page 169
- "ifconfig command" on page 171
- "info (configuration information) command" on page 203
- "iocomp command" on page 206
- "kvm (keyboard, video, mouse) command" on page 208
- "ldapcfg command" on page 210
- "led command" on page 220
- "list (system physical configuration) command" on page 225
- "mcad command" on page 227
- "modactlog command" on page 228
- "monalerts command" on page 229
- "mt (media tray) command" on page 239
- "nat command" on page 241
- "ntp (network time protocol) command" on page 245
- "ping command" on page 248
- "pmpolicy command" on page 251
- "portcfg command" on page 253
- "ports command" on page 255
- "power command" on page 272
- "rdoc command" on page 278
- "read command" on page 280
- "read command" on page 280
- "remacccfg command" on page 283
- "remotechassis command" on page 285
- "reset command" on page 288
- "scale command" on page 293
- "sddump command" on page 301
- "sdemail command" on page 303
- "security command" on page 305
- "service command" on page 306
- "shutdown command" on page 308
- "slp command" on page 309
- "smtp command" on page 311
- "snmp command" on page 314
- "sol (serial over LAN) command" on page 330
- "sshcfg command" on page 337
- "sslcfg command" on page 339
- "syslog command" on page 349
- "tcpcmdmode command" on page 353
- "telnetcfg (Telnet configuration) command" on page 356
- "temps command" on page 357
- "trespass command" on page 358
- "uicfg command" on page 361
- "update (update firmware) command" on page 365
- "uplink (management module failover) command" on page 375
- "users command" on page 379

- "vlan command" on page 402
- "volts command" on page 412
- "write command" on page 413
- "zonecfg command" on page 415

Command list by function

By function, the commands are as follows:

• Built-in commands

Use these commands to perform top-level functions within the command-line interface:

- "env (environment) command" on page 131
- "help command" on page 166
- "history command" on page 168
- "list (system physical configuration) command" on page 225
- Common commands

Use these commands to monitor and control operation of BladeCenter components:

- "cinstatus command" on page 102
- "health command" on page 163
- "info (configuration information) command" on page 203
- "iocomp command" on page 206
- "modactlog command" on page 228
- "ping command" on page 248
- "temps command" on page 357
- "volts command" on page 412
- Configuration commands

Use these commands to view and configure network settings, Ethernet interfaces, and other functions:

- "accseccfg command" on page 30
- "advfailover command" on page 40
- "alertcfg command" on page 51
- "alertentries command" on page 53
- "autoftp command" on page 60
- "baydata command" on page 63
- "bofm command" on page 66
- "bootmode command" on page 74
- "bootseq command" on page 75
- "buildidcfg command" on page 80
- "cin command" on page 97
- "cinstatus command" on page 102
- "clock command" on page 106
- "config command" on page 111
- "dhcpinfo command" on page 117
- "displaysd command" on page 124
- "dns command" on page 126
- "ethoverusb command" on page 137
- "feature command" on page 144
- "files command" on page 147
- "groups command" on page 159
- "health command" on page 163
- "ifconfig command" on page 171
- "info (configuration information) command" on page 203
- "iocomp command" on page 206

- "kvm (keyboard, video, mouse) command" on page 208
- "ldapcfg command" on page 210
- "mcad command" on page 227
- "modactlog command" on page 228
- "monalerts command" on page 229
- "mt (media tray) command" on page 239
- "nat command" on page 241
- "ntp (network time protocol) command" on page 245
- "pmpolicy command" on page 251
- "ping command" on page 248
- "portcfg command" on page 253
- "ports command" on page 255
- "read command" on page 280
- "rdoc command" on page 278
- "remotechassis command" on page 285
- "scale command" on page 293
- "sddump command" on page 301
- "security command" on page 305
- "service command" on page 306
- "slp command" on page 309
- "chconfig command" on page 87
- "chmanual command" on page 95
- "smtp command" on page 311
- "snmp command" on page 314
- "sol (serial over LAN) command" on page 330
- "sshcfg command" on page 337
- "sslcfg command" on page 339
- "tcpcmdmode command" on page 353
- "telnetcfg (Telnet configuration) command" on page 356
- "temps command" on page 357
- "trespass command" on page 358
- "uicfg command" on page 361
- "uplink (management module failover) command" on page 375
- "users command" on page 379
- "volts command" on page 412
- "zonecfg command" on page 415
- Discovery commands

Use these commands to locate other resources on the network:

- "ping command" on page 248
- "remotechassis command" on page 285

Event log commands

Use these commands to view and clear primary management-module event log entries:

- "clearlog command" on page 105
- "displaylog command" on page 119
- "eventinfo command" on page 138
- "events command" on page 140
- "modactlog command" on page 228
- "chlog command" on page 93
- "syslog command" on page 349
LED commands

Use these commands to monitor and control operation of BladeCenter unit LEDs:

- "identify (location LED) command" on page 169
- "led command" on page 220
- Memory commands

Use these commands to reset the management-module configuration and perform firmware updates:

- "clear command" on page 103
- "update (update firmware) command" on page 365
- Power-control commands

Use these commands to control operation of the BladeCenter unit, blade servers, and I/O (switch) modules:

- "boot command" on page 72
- "power command" on page 272
- "reset command" on page 288
- "shutdown command" on page 308
- Power-management commands

Use these commands to monitor power consumption of the BladeCenter unit and installed components:

- "fuelg command" on page 149
- "pmpolicy command" on page 251
- "volts command" on page 412

• Save and restore configuration commands

Use these commands to save and restore the management-module configuration:

- "read command" on page 280
- "write command" on page 413
- Session commands

Use these commands to start an SOL connection to the command console of a specific blade server or to end a command console session:

- "console command" on page 115
- "exit command" on page 143
- Systems-management commands (BladeCenter T only)

Use these commands to manage alarms for monitored parameters of the BladeCenter T unit:

- "alarm command (BladeCenter T and HT only)" on page 43

Command syntax

Each of the following topics describes a command-line interface command and its syntax. Each command description also includes an example of command use.

accseccfg command

This command displays and configures account security settings for the advanced management module.

Table 3.	accseccfa	command
rabic 0.	accounty	communa

Function	What it does	Command	Valid targets
Display account security settings	Displays the user account security settings for the advanced management module. Returned values: • Default security settings used (legacy high or custom)	accseccfg	-T system:mm[x] where x is the primary management-module bay number.
	 -am: user authentication method (local, ldap, localldap, or ldaplocal) 		
	 -alt: authentication logging timeout (in seconds) 		
	• -cp: complex password (on, off)		
	• -ct: CLI inactivity session timeout (in seconds)		
	 -dc: minimum different characters in the password (when -cp is enabled) 		
	 -de: default administration password expiration (on, off) 		
	 -ia: account inactivity alert time period (in days) 		
	• -ici: log new login events from same user (on, off)		
	 -id: account inactivity disable time period (in days) 		
	• -lf: maximum login failures		
	 -lp: lockout period after maximum login failures (in minutes) 		
	 -mls: maximum simultaneous user sessions 		
	 -pc: password change on first access (on, off) 		
	 -pe: password expiration time period (in days) 		
	• -pi: minimum password change interval (in hours)		
	• -pr: password required (on, off)		
	-rc: password reuse cycle		
	 -wt: web inactivity session timeout (in minutes, none, or based on length of user session) 		

Table 3. accseccfg command (continued)

Function	What it does	Command	Valid targets
Set account defaults to legacy level	Sets management-module account security to a predefined legacy set of default values. Legacy default values: • -alt: retains set value • -am: retains set value • -cp: off • -ct: retains set value • -dc: 0 • -de: off • -ia: 0 • -ici: retains set value • -id: 0 • -lf: 5 • -lp: 2 • -mls: retains set value • -pc: off • -pe: 0 • -pi: 0 • -pr: off • -rc: 0 • -wt: retains set value	accseccfg -legacy This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
	 Note: The user who is running the accseccfg -legacy command must have a password assigned. The -legacy option must be run alone and not in conjunction with any other accseccfg command options. 		

Table 3. accseccfg command (continued)

Function	What it does	Command	Valid targets
Set account defaults to high level	Sets management-module account security to a predefined high set of default values. High default values are: -am: retains set value -cp: on -ct: retains set value -dc: 2 -de: on -ia: 120 -id: 180 -If: 5 -lp: 60 -pc: on -pe: 90 -pi: 24 -pr: on -rc: 5 -wt: retains set value Note: The user who is running the accseccfg -high command must have a password assigned. The -high option must be run alone and not in conjunction with any other accseccfg command options.	accseccfg -high This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.
Set authentication logging timeout	Sets a custom value for the amount of time that the management module will not log repeated logins by the same user.	accseccfg -alt <i>timeout</i> where <i>timeout</i> is 0, 5, 30, 60, 300, 600, 1800, 3600, 43200, or 86400 seconds. If a value of none is entered, login logging is disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 3. accseccfg command (continued)

Function	What it does	Command	Valid targets
Set user authentication method	Sets a custom value for management module user authentication method.	accseccfg -am <i>method</i> where <i>method</i> is • local • ldap • localldap • ldaplocal This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		authority" on page 8 for additional information.	
Enable / disable complex password	Enables or disables the complex password for management-module user authentication. Note: Enabling the complex password also turns on the password required (-pr) command option.	 accseccfg -cp state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[<i>x</i>] where <i>x</i> is the primary management-module bay number.
Set CLI inactivity timeout	Sets the custom value for management-module CLI inactivity session timeout.	 accseccfg -ct <i>timeout</i> where <i>timeout</i> is from 0 to 4,294,967,295 seconds, inclusive. This command can only be run by users who have the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 3. accsecctg command (con	tinued)
---------------------------------	---------

Function	What it does	Command	Valid targets
Set minimum number of different characters for password	Sets custom value for the minimum number of different characters to be used in a management-module password. Note: The minimum number of different characters applies only when complex passwords are enabled.	accseccfg -dc <i>number</i> where <i>number</i> is from 0 to 15, inclusive. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		authority" on page 8 for additional information.	
Enable / disable default administration password expiration	Enables or disables the default administration password expiration for the management module.	 accseccfg -de state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set account inactivity alert time	Sets custom value for management module account inactivity alert time. Note: The accseccfg -ia value must be less than the accseccfg -id value.	 accseccfg -ia time where time is from 0 to 365 days, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 3. accseccfg command (continued)

Function	What it does	Command	Valid targets
Set state for logging of login events from same IP address	Enables or disables logging of new login events from the same user from the same IP address. Note: This value applies only if the value set by the -alt command option is set to something other than 0 or none.	accseccfg -ici <i>state</i> where <i>state</i> is on or off. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		additional information.	
Set account inactivity	Sets the custom value for	accseccfg -id <i>time</i>	-T system:mm[x]
disable time	management-module account inactivity disable time. Note: The accseccfg -id value must be greater than the accseccfg -ia value.	 where <i>time</i> is from 0 to 365 days, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	where <i>x</i> is the primary management-module bay number.
Set maximum number of login failures	Sets the custom value for the maximum number of login failures before the management module locks out a user.	 accseccfg -lf number where number is from 0 to 10, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 3. accseccfg command (continued)

Function	What it does	Command	Valid targets
Set lockout period	Sets the custom value for management-module account lockout period, used when the maximum number of login failures is exceeded.	 accseccfg -lp time where time is from 0 to 2880 minutes, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[<i>x</i>] where <i>x</i> is the primary management-module bay number.
Set maximum LDAP sessions for user	Sets the custom value for the maximum number of simultaneous login sessions allowed for a single LDAP user	 accseccfg -mls max_sessions where max_sessions is from 0 to 20, inclusive. This command can only be run by users who have the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable password change at first login	Enables or disables the mandatory password change at first management-module login.	 accseccfg -pc state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 3. accseccfg command (continued)

Function	What it does	Command	Valid targets
Set password expiration time	Sets custom value for the management module password expiration time.	 accseccfg -pe time where time is from 0 to 365 days, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set password minimum change interval	Sets custom value for the minimum amount of time between management module password changes.	accseccfg -pi <i>time</i> where <i>time</i> is from 0 to 1440 hours, inclusive, and less than password expiration period when that period is greater than 0. This command can only be run by users who have the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.
Enable / disable password required	 Enables or disables the password required for management module. Notes: The user that is running the accseccfg -pr command must have a password assigned. Disabling password required also turns off the complex password (-cp) command option. 	 accseccfg -pr state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 3. accseccfg command (continued)

Function	What it does	Command	Valid targets
Set password reuse cycle	Sets custom value for the management module password reuse cycle. This setting determines how many times a password must be changed before being reused.	accseccfg -rc number_reuses where number_reuses is from 0 to 5, inclusive. This command can only be run by users who have the following command authorities: • Supervisor • Chassis configuration See "Commands and user	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		additional information.	
Set web interface inactivity timeout	Sets custom value for management module web interface inactivity session timeout.	accseccfg -wt <i>timeout</i> where <i>timeout</i> is 1, 5, 10, 15, or 20 minutes, none (no timeout), or user (user picks timeout each time they log in to the web interface). This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example:

To disable management-module authentication logging timeout, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type accseccfg -alt none

To set management-module account security to use the high level defaults, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type accseccfg -high

To display the account security settings for the management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

accseccfg

```
The following example shows the information that is returned from these
commands:
system:mm[1]> accseccfg -alt none
0K
system:mm[1]> accseccfg -high
0ĸ
system:mm[1]> accseccfg
-high
-alt 600
-am local
-cp on
-ct 0
-dc 2
-de on
-ia 120
-ici on
-id 180
-lf 5
-1p 60
-mls 5
-pc on
-pe 90
-pi 24
-pr on
-rc 5
-wt user
system:mm[1]>
```

advfailover command

This command displays and configures the advanced failover settings for the advanced management module.

Table 4.	advfailover	command
rubio i.	aavianovoi	oonnana

Function	What it does	Command	Valid targets
Display management module advanced failover settings	 Displays the advanced failover settings for the management module. Possible return values are: off - disable network interface for the standby management module swap - enable the standby management module network interface and swap IP addresses between the two management modules during failover noswap - enable the standby management module network interface and do not swap IP addresses between the two management module network interface and do not swap IP addresses between the two management modules during failover Note: This command does not apply to the BladeCenter S unit, 	advfailover	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
	which supports only a single advanced management module.		
Disable network interface for standby management module	Disables the network interface for the standby management module, preventing failover.	advfailover -ip off This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information	-T system:mm[x] where x is the primary management-module bay number.
Enable network interface and allow IP address swap during failover	Enables the network interface for the standby management module and allows the IP addresses to swap between the two management modules during failover.	advfailover -ip swap This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.

Table 4. advfailover command (continued)

Function	What it does	Command	Valid targets
Enable network interface and prevent IP address swap during failover	Enables the network interface for the standby management module and prevents the IP addresses from swapping between the two management modules during failover.	 advfailover -ip noswap This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Example:

To disable the network interface for the standby management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

advfailover -ip off

To display the management module advanced failover setting, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

advfailover

The following example shows the information that is returned from these two commands:

```
system:mm[1]> advfailover -ip off
OK
system:mm[1]> advfailover
-ip off
system:mm[1]>
```

airfilter command (BladeCenter S only)

This command sets the interval for air filter change notifications for a BladeCenter S unit.

Function	What it does	Command	Valid targets
Display air filter change notification interval	Displays the frequency of the chassis air filter reminder.	airfilter	-T system:mm[x] where x is the primary management-module bay number.
Set air filter change notification interval	Configures the frequency of the chassis air filter reminder. Note: The 1 month replacement interval is recommended for environments with a high amount of dust. Replacement every 3 months is recommended for environments with medium amounts of dust. Replacement every 6 months is recommended for environments with low amounts of dust.	 airfilter -freq <i>frequency</i> where <i>frequency</i> is the interval, in months, between reminders to change the chassis air filter. Valid values are 0, 1, 3, and 6. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management Chassis log management Chassis configuration Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example: To view the current notification interval, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type airfilter

To set the notification interval to three months, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type airfilter -freq 3

The following example shows the information that is returned when these commands are entered:

```
system:mm[1]> airfilter
-freq 1
system:mm[1]>
system:mm[1]> airfilter -freq 3
OK
system:mm[1]>
```

alarm command (BladeCenter T and HT only)

This command displays alarm information, acknowledges alarms, and clears alarms for the specified command target.

Function	What it does	Command	Valid targets
Display all alarms	Display all alerts generated by the target component. When directed to the BladeCenter unit, the command returns a summary of alarms for all BladeCenter components. When directed to a component installed in the BladeCenter unit, the command returns a detailed alarm listing for that component. Detailed alarm listings include an alarm key that can be used to acknowledge or clear an alarm.	alarm -q	 -T system -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.
Display power alarms	Display all power related alerts generated by the target component. When directed to the BladeCenter unit, the command returns a summary of alarms for all BladeCenter components. When directed to a component installed in the BladeCenter unit, the command returns a detailed alarm listing for that component. Detailed alarm listings include an alarm key that can be used to acknowledge or clear an alarm. Note: The -p option can be combined with the -q option to query power related alarms.	alarm -p	-T system -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.
Display alarm information (specified by alarm generator ID)	Display information for alarm specified by the generator ID.	alarm -q -g <i>value</i> where <i>value</i> is the generator ID. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration • Blade remote presence See "Commands and user authority" on page 8 for additional information.	 T system:mm[x] T system:blade[x] T system:switch[x] T system:power[x] T system:blower[x] Where x is the primary management-module, blade server, I/O module, power module, or blower bay number.

Table 6. alarm command (continued)

Function	What it does	Command	Valid targets
Display alarm information (specified by alarm ID)	Display information for alarm specified by the alarm ID.	alarm -q -a <i>value</i> where <i>value</i> is the alarm ID.	 T system:mm[x] T system:blade[x] T system:switch[x] T system:power[x] T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.
Display detailed alarm information (specified by generator information)	Display detailed information for alarm specified by the alarm generator information. Information returned includes the alarm description that is shown by the management-module web interface and other information such as the alarm severity, power source, software indicator, and an alarm key.	alarm -q -o <i>value</i> where <i>value</i> is the generator information.	 -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.
Display alarm information (specified by complete alarm key)	Display information for alarm specified by the complete alarm key.	 alarm -q -k m:g:o:a where m:g:o:a is the complete alarm key: m is the module ID g is the generator ID o is the generator information a is the alarm ID 	 -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.

Table 6. alarm command (continued)

Function	What it does	Command	Valid targets
Acknowledge alarm (specified by alarm generator ID)	Acknowledge the alarm specified by the generator ID.	 alarm -r -g value where value is the generator ID. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration (for management module, power module, or blower) Blade configuration (for blade server) I/O module configuration (for I/O module) See "Commands and user authority" on page 8 for 	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.
Acknowledge alarm (specified by generator information)	Acknowledge the alarm specified by the generator information.	 additional information. alarm -r -o value where value is the generator information. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration (for management module, power module, or blower) Blade configuration (for blade server) I/O module configuration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.

Function	What it does	Command	Valid targets
Acknowledge alarm (specified by alarm ID)	Acknowledge the alarm specified by the alarm ID.	 alarm -r -a value where value is the alarm ID. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration (for management module, power module, or blower) Blade configuration (for blade server) I/O module configuration (for I/O module) See "Commands and user authority" on page 8 for 	 -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.
Acknowledge alarm (specified by complete alarm key)	Acknowledge the alarm specified by the complete alarm key.	 additional information. alarm -r -k m:g:o:a where m:g:o:a is the complete alarm key: m is the module ID g is the generator ID o is the generator information a is the alarm ID This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration (for management module, power module, or blower) Blade configuration (for blade server) I/O module configuration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.

Table 6.	alarm	command	(continued)
----------	-------	---------	-------------

Function	What it does	Command	Valid targets
Clear alarm (specified by alarm generator ID)	Clear the alarm specified by the generator ID.	 alarm -c -g value where value is the generator ID. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration (for management module, power module, or blower) Blade configuration (for blade server) I/O module configuration (for I/O module) See "Commands and user authority" on page 8 for 	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.
Clear alarm (specified by generator information)	Clear the alarm specified by the generator information.	 alarm -c -o value where value is the generator information. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration (for management module, power module, or blower) Blade configuration (for blade server) I/O module configuration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.

Table 6.	alarm	command	(continued)
----------	-------	---------	-------------

Function	What it does	Command	Valid targets
Clear alarm (specified by alarm ID)	Clear the alarm specified by the alarm ID.	 alarm -c -a value where value is the alarm ID. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration (for management module, power module, or blower) Blade configuration (for blade server) I/O module configuration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.
Clear alarm (specified by complete alarm key)	Clear the alarm specified by the complete alarm key.	 alarm -c -k m:g:o:a where m:g:o:a is the complete alarm key: m is the module ID g is the generator ID o is the generator information a is the alarm ID This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration (for management module, power module, or blower) Blade configuration (for blade server) I/O module configuration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.

Table 6. alarm command (continued)

Function	What it does	Command	Valid targets
Function Set alarm	What it does Set an alarm for the specified target, including severity level and description.	Command alarm -s -l level desc where • level is the severity level: - CRT (critical) - MJR (major) - MNR (minor) • desc is a short text description of the alarm This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration (for management module, power module, or blower) • Blade configuration (for blade server) • I/O module configuration (for I/O module)	Valid targets -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.
		See "Commands and user authority" on page 8 for additional information.	

Example: To display the alarm status for the BladeCenter T unit, while the BladeCenter T unit is set as the persistent command environment, at the system> prompt, type

alarm -q

To display the power alarm status for the BladeCenter T unit, while the BladeCenter T unit is set as the persistent command environment, at the system> prompt, type

alarm -p

To display detailed power alarm status for the power module in power bay 2, while the BladeCenter T unit is set as the persistent command environment, at the system> prompt, type

alarm -T system:power[2] -q

The following example shows the information that is returned from a series of alarm commands.

system> alarm -q Alarms Summary List Module ACK Severity Power Software _____ No Yes mm[1] No Major No power[2] No Critical No system> alarm -q -p Alarms Summary List
 Module
 ACK
 Severity
 Power
 Software
 power[2] No Critical Yes No system> alarm -q -T mm[1] Alarms Detailed List ACK Severity PWR SW Descript Key No Major No No (05/21/08, 13:46:11) Insufficient chassis power 255:81:1:2:3 No Minor No No (05/21/08, 13:45:26) Event log full 255:81:1:1:1

system>

alertcfg command

This command displays and configures the global remote alert settings for the advanced management module.

Table 7	alertcfg	command
---------	----------	---------

Function	What it does	Command	Valid targets
Display global remote alert settings	Displays the global remote alert settings for the advanced management module.	alertcfg	-T system:mm[x] where x is the primary management-module bay number.
Set remote alert retry delay interval and number of retries	Sets the remote alert retry delay interval and permitted number of retries.	 alertcfg -dr <i>delay</i> -rl <i>limit</i> where: <i>delay</i> is from 0.5 minutes to 4.0 minutes, inclusive, in 0.5 minute increments. If you enter a value less than 0.5 minute, the retry interval will be set to 0.5 minute. If you enter a value greater than 4.0 minutes, the retry interval will be set to 4.0 minutes. <i>limit</i> is the remote alert retry limit, ranging from 0 to 8. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Include / exclude service information with email alerts	Enables or disables inclusion of service information with email alerts.	 alertcfg -si state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 7. alertcfg command (continued)

Function	What it does	Command	Valid targets
Set remote alert retry limit	Sets the maximum number of times the system will attempt to send a remote alert, if previous attempts were unsuccessful.	alertcfg -rl value where value is from 0 to 8, inclusive. If you enter a value of 0, no retries will be attempted. If you enter a value greater than 8, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example: To view the remote alert configuration, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type alertcfg

To set the retry interval to 3.5 minutes, include service information in the alert, and set the remote alert retry limit to 7, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type alertcfg -dr 3.5 -si enabled -rl 7

The following example shows the information that is returned from these commands:

```
system:mm[1]> alertcfg
-dr 2.0
-si disabled
-rl 6
system:mm[1]> alertcfg -dr 3.5 -si enabled -rl 7
OK
system:mm[1]> alertcfg
-dr 3.5
-si enabled
-rl 7
system:mm[1]>
```

alertentries command

This command manages the recipients of alerts generated by the primary management module.

Table 8.	alertentries	command
10010 01	alontontinoo	oonnana

Function	What it does	Command	Valid targets
Display alert properties for all recipients	 Displays alert properties for all management-module alert recipients. Returned values for each alert recipient are: recipient name notification method (Email over LAN/Systems Director comp./SNMP over LAN) type of alerts received (Receives critical alerts only/Receives all alerts/Disabled) 	alertentries	-T system:mm[x] where x is the primary management-module bay number.
Display alert properties for alert recipients	 Displays alert properties for the specified management-module alert recipient profile. Returned values are: -status alert_recipient_status (on/off) -n alert_recipient_name -f alert_type (critical/none) -t notification_method (email/director/snmp) -e email_address (used for email notifications) -i static_IP_addr/hostname (used for IBM Systems Director notifications) 	alertentries -recip_number where recip_number is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list.	-T system:mm[x] where x is the primary management-module bay number.
Delete alert recipient	Delete the specified alert recipient.	alertentries -recip_number -del where recip_number is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list. It is possible to delete an empty alert recipient. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.

Table 8. alertentries command (continued)

Function	What it does	Command	Valid targets
Create alert recipient	Create the specified alert recipient.	alertentries	-T system:mm[x]
	All fields must be specified when creating an alert recipient.	-recip_number -n recip_name -status alert_status -f filter_type -t notification_method -e email_addr -i ip_addr/hostname	where <i>x</i> is the primary management-module bay number.
		 <i>tp_addr/hostname</i> <i>recip_number</i> is a number from 1 to 12 that corresponds to an unused recipient number in the "Display alert properties for all recipients" list. <i>recip_name</i> is a alphanumeric string up to 31 characters in length containing any character, including spaces, except for angle brackets (< and >). If the string includes spaces it must be enclosed in double-quotes. <i>alert_status</i> is on or off for receipt of alerts. <i>filter_type</i> filters the alert types received: critical (receive critical alerts only) or none (receive all alerts). <i>notification_method</i> is email, director (IBM Systems Director) or snmp. For email, you must specify an email address (-e argument). For director you must specify an email address (-i argument). If snmp is selected, the -e and -i arguments are not needed. <i>email_addr</i> is a valid email address string up to 63 characters in length. 	
		(continued on next page)	

Table 8. alertentries command (continued)

Function	What it does	Command	Valid targets
Create alert recipient (continued)		 <i>ip_addr/hostname</i> is a valid static IP address or an alphanumeric hostname string for the recipient that is up to 49 characters in length that can include periods (.), hyphens (-), and underscores (_). This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information 	
Set alert recipient name	Sets a name for the specified alert recipient.	<pre>alertentries -recip_number -n recip_name where: • recip_number is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list. • recip_name is a alphanumeric string up to 31 characters in length that can include any character, including spaces, except for angle brackets (< and >). If the name includes spaces, it must be enclosed in double-quotes. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where x is the primary management-module bay number.

Table 8. alertentries command (continued)

Function	What it does	Command	Valid targets
Set alert recipient status	Sets status for the specified alert recipient. The status determines if a recipient will receive alarm notifications.	 alertentries -recip_number -status alert_status where: recip_number is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list. alert_status is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		authority" on page 8 for additional information.	
Set alert types received	Filters the types of alert that are received by the specified alert recipient.	 alertentries -recip_number -f filter_type where: recip_number is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list. alert_type filters the alert types received: critical (receive critical alerts only) or none (receive all alerts). This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 8. alertentries command (continued)

Function	What it does	Command	Valid targets
Set alert notification method	Sets the alert notification method for the specified alert recipient.	<pre>alertentries -recip_number -t notification_method where: • recip_number is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list. • notification_method is - email - director (IBM Systems Director) - snmp</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	
Set alert recipient email address	Sets the email address for the specified alert recipient. This email address is used to send alerts to the recipient via email. The email address can be set only if the alert notification method (-t option) is set to email. The -t and -e options can be combined within the same command.	 alertentries -recip_number -e email_addr where: recip_number is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list. email_addr is a valid email_addr is a valid email address string up to 63 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 8. alertentries command (continued)

Function	What it does	Command	Valid targets
Set alert recipient IP address or hostname	Sets the IP address or hostname used to send alert notifications to the specified alert recipient using IBM Systems Director. The IP address or hostname used to send alert notifications can be set only if the alert notification method (-t option) is set to director (IBM Systems Director). The -t and -i options can be combined within the same command.	 al ertentries <i>recip_number</i> - i <i>ip_addr/hostname</i> where: <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list. <i>ip_addr/hostname</i> is a valid static IP address or an alphanumeric hostname string up to 49 characters in length that can include periods (.), hyphens (-), and underscores (_). This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Generate test alert	 Generates a test alert to verify correct alert response. Notes: The alertentries -test command option must be used alone. If autoftp is enabled, sending a test alert will cause the system to send out service data as well. 	alertentries -test This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis log management • Chassis administration • Chassis configuration • Blade administration • Blade configuration • Blade remote presence • I/O module administration • I/O module configuration • See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example: To view the configuration for alert recipient 1, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

alertentries -1

To configure alert recipient 2 to receive only critical alert notifications by email, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
alertentries -2 -n test2 -status on -f critical -t email -e test2@us.ibm.com
```

To configure alert recipient 3 to receive all alert notifications through IBM Systems Director, while management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type

```
alertentries -3 -n test3 -status on -f none -t director -i 192.168.70.140
```

To configure alert recipient 4 to receive all alert notifications through SNMP, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

alertentries -4 -n test4 -status on -f none -t snmp

The following example shows the information that is returned from these commands:

```
system:mm[1]> alertentries -1
-status on
-n test1
-f critical
-t email
-e test1@us.ibm.com
system:mm[1]> alertentries -2 -n test2 -status on -f critical -t email
-e test2@us.ibm.com
OK
system:mm[1]> alertentries -3 -n test3 -status on -f none -t director
-i 192.168.70.140
OK
system:mm[1]> alertentries -4 -n test4 -status on -f none -t snmp
OK
system:mm[1]>
```

autoftp command

This command displays and configures the automated FTP/TFTP problem report settings for the advanced management module.

Table 9. autoftp command

Function	What it does	Command	Valid targets
Display call-home settings for autoftp call home	Displays the Automated FTP/TFTP Problem Report settings that allow the advanced management module to automatically put service data onto a specified server when a call home event is detected.	autoftp	-T system:mm[x] where x is the primary management-module bay number.

Table 9. autoftp command (continued)

Function	What it does	Command	Valid targets
Configure call-home settings for autoftp call home	Configures the Automated FTP/TFTP Problem Report settings that allow the advanced management module to automatically put service data onto a specified server when a call home event is detected. Note: The system will wait five days before sending duplicate events if they are left unacknowledged in the activity log.	 autoftp -m mode -i ip_address -p port -u "user_name" -pw "password" where: mode is one of the following automated problem reporting modes: ftp tftp disabled ip_address is the IP address of the FTP or TFTP server port is the FTP or TFTP transmission port, a number from 1 to 65535, inclusive. If you enter a value outside this range, an error message will be displayed. "user_name" is the quote-delimited FTP User Name for automated problem reporting (63 characters maximum). "password" is the quote-delimited FTP password for automated problem reporting (63 characters maximum). Notes: For FTP, all fields must be set. For TFTP, only -i and -p are needed. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system:mm[x] where x is the primary management-module bay number.

Example:

```
To view the settings of the automated call-home message feature, while
management module 1 is set as the persistent command environment, at the
system:mm[1]> prompt, type
autoftp
```

To configure the automated call-home message feature to report call-home events using TFTP to tftp.ibm.com over transmission port 69, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type autoftp -m tftp -i tftp.ibm.com -p 69

The following example shows the information that is returned from these commands:

```
system:mm[1]> autoftp
-m ftp
-i ftp.ibm.com
-p 6
-u smlite
system:mm[1]> autoftp -m tftp -i tftp.ibm.com -p 69
OK
system:mm[1]>
```

baydata command

This command allows a user to set, assign, and display informational data assigned to the blade server bays.

Function	What it does	Command	Valid targets
Display bay data for all blade servers	Displays blade server bay data for bay number, bay data status, and defined bay data for all bays.	baydata	-T system
Display blade server bay data for a specific bay	Displays the information assigned to the specified blade bay using the -b option.	 baydata -b bay_num where bay_num is the number of the specific bay to display. The bay number must be within the scope assigned to the user. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system
Clear bay data	Clears the blade bay definition strings for all bays.	 baydata -clear The bay number must be within the scope assigned to the user. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system

Table 10. baydata command

Table 10. baydata command (continued)

Function	What it does	Command	Valid targets
Clear bay data for specific bay	Clears the blade bay definition strings for the specified blade bay.	 baydata -b bay_num clear where bay_num is the number of the specified bay to clear of data. The bay number must be within the scope of the user. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for 	-T system
		additional information.	
Set bay data	Sets blade bay data for all blade servers within the user's scope. This information can include: data about drivers or software, the BladeCenter unit shelf number and IP address, and whether the blade server is a master or member in a high-availability system. Note: To apply changes to the BIOS/SMBIOS structure, power-off and power-on the blade server, restart the blade server, or remove and reinstall the blade server.	baydata -data "data_definition" where "data definition" is the ASCII string of up to 60 characters enclosed in double quotation marks-"data definition". The quotation marks are not stored. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade configuration See "Commands and user authority" on page 8 for additional information.	-T system
Table 10. baydata command (continued)

Function	What it does	Command	Valid targets
Set blade bay data definition for specific blade server	Sets blade bay data for the specified blade server using the -b option. Note: To apply changes to the BIOS/SMBIOS structure, power-off and power-on the blade server, restart the blade server, or remove and reinstall the blade server. If the command is issued to a specific bay, data is written to that blade server if it is in the user's scope.	 baydata -b bay_num -data "data_definition" where: bay_num is the blade bay where "data definition" is the quote-delimited ASCII string of up to 60 characters This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system

Example: To view the bay data for all blades, while the management module is set as the persistend command environment, at the system> prompt, type baydata

The following example shows the information that is returned from this command:

syste	em>	baydat	ta	
Bay	Sta	atus		Definition
1	Uns	support	ted	
2	No	blade	present	
3	No	blade	present	
4	No	blade	present	
5	No	blade	present	
6	No	blade	present	
7	No	blade	present	
8	No	blade	present	
9	No	blade	present	
10	No	blade	present	
11	No	blade	present	
12	No	blade	present	
13	No	blade	present	
14	No	blade	present	
syste	em>			

bofm command

This command applies a new BladeCenter Open Fabric Manager (BOFM) configuration to all the specified BladeCenter units, bays, and ports.

Notes:

- 1. Open Fabric Manager is not a standard management module feature; it is offered and documented separately. See the *BladeCenter Open Fabric Manager Installation and Users Guide* for more detailed information.
- 2. If the number of advanced management module TCP command mode connections is zero, or if all available TCP command mode connections are in use, a connection failure message is generated by the BOFM feature. Make sure that the advanced management module TCP command mode connection limit is positive and that no more than the available number of connections are in use. See the *BladeCenter Open Fabric Manager Installation and Users Guide* for additional information.

Table 11. bofm command

Function	What it does	Command	Valid targets
Function Apply BOFM configuration to specified BladeCenter units, bays, and ports	What it does Copies a configuration file from a TFTP server to the specified management module, which then configures BladeCenter units, blade servers, and I/O modules. The configuration file is a comma-separated values (CSV) file that assigns IP addresses and other values to BladeCenter units, bays, and ports.	 Command bofm -1 <i>filename</i> -i <i>ip_address</i> where: <i>filename</i> is the name of the configuration file. <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server where the configuration file is located. Note: Both the -1 <i>filename</i> option and the -i <i>ip_address</i> option need to be specified. This command can only be run by users who have 	Valid targets -T system:mm[x] where x is the primary management-module bay number.
		 run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user 	
		authority" on page 8 for additional information.	

Function	What it does	Command	Valid targets
Function Apply BOFM configuration to specified BladeCenter units, bays and ports while ignoring duplicate lines in the configuration file	What it does Copies a configuration file from a TFTP server to the specified management module, which then configures BladeCenter units, blade servers, and I/O modules, even if it encounters duplicate lines in the configuration file. The configuration file is a comma-separated values (CSV) file that assigns IP addresses and other values to BladeCenter units, bays, and ports.	 Command bofm -1 <i>filename</i> -i <i>ip_address</i> -d off where: <i>filename</i> is the name of the configuration file. <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server where the configuration file is located. The -d off option causes bofm to ignore duplicate lines in the configuration file. Note: Both the -1 <i>filename</i> option and the -i 	Valid targets -T system:mm[x] where x is the primary management-module bay number.
		 <i>ip_address</i> option need to be specified. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	

Table 11. bofm command (continued)

Table 11. bofm command (continued)

Function	What it does	Command	Valid targets
Apply BOFM configuration to specified BladeCenter units, bays, and ports unless there are duplicate lines in the configuration file	Copies a configuration file from a TFTP server to the specified management module, which then configures BladeCenter units, blade servers, and I/O modules, but halts the operation if it encounters duplicate lines in the configuration file. The configuration file is a comma-separated values (CSV) file that assigns IP addresses and other values to BladeCenter units, bays, and ports.	 bofm -1 <i>filename</i> -i <i>ip_address</i> -d on where: <i>filename</i> is the name of the configuration file. <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server where the configuration file is located. The -d on option halts bofm if there are duplicate lines in the configuration file. Note: Both the -1 <i>filename</i> option and the -i <i>ip_address</i> option need to be specified. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 11	. bofm	command	(continued)
----------	--------	---------	-------------

Function	What it does	Command	Valid targets
Apply BOFM configuration to specified BladeCenter units, bays, and ports even if the bays are powered on	Copies a configuration file from a TFTP server to the specified management module, which then configures BladeCenter units, blade servers, and I/O modules, after checking to make sure that the bays are not powered on. The configuration file is a comma-separated values (CSV) file that assigns IP addresses and other values to BladeCenter units, bays, and ports.	 bofm -1 <i>filename</i> -i <i>ip_address</i> -p on where: <i>filename</i> is the name of the configuration file. <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server where the configuration file is located. The -p on option halts the bofm command if bays are powered on. Note: Both the -1 <i>filename</i> option and the -i <i>ip_address</i> option need to be specified. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 11. bofm command (continued)

Function	What it does	Command	Valid targets
Apply BOFM configuration to specified BladeCenter units, bays, and ports unless bays are powered on	Copies a configuration file from a TFTP server to the specified management module, which then configures BladeCenter units, blade servers, and I/O modules, without checking if the bays are powered on. The configuration file is a comma-separated values (CSV) file that assigns IP addresses and other values to BladeCenter units, bays, and ports. Note: Do not change the BOFM configuration while a blade server is powered on.	 bofm -1 <i>filename</i> -i <i>ip_address</i> -p off where: <i>filename</i> is the name of the configuration file. <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server where the configuration file is located. The -p off option forces BOFM to apply the configuration file to blade servers that are powered on. Note: Both the -1 <i>filename</i> option and the -i <i>ip_address</i> option need to be specified. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Function	What it does	Command	Valid targets
Apply BOFM configuration to specified BladeCenter units, bays, and ports (verbose)	Copies a configuration file from a TFTP server to the specified management module, which then configures BladeCenter units, blade servers, and I/O modules, a process which might take several minutes. The detailed information is shown after the update is complete.	 bofm -1 <i>filename</i> -i <i>ip_address</i> -v <i>where:</i> <i>filename</i> is the name of the configuration file. <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server where the configuration file is located. 	-T system:mm[x] where x is the primary management-module bay number.
		Note: Both the -1 <i>filename</i> option and the -i <i>ip_address</i> option need to be specified. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information	

Table 11. bofm command (continued)

To apply a new BOFM configuration file to a set of BladeCenter units and view details of the procedure, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

bofm -i 9.148.8.2 -l apply.csv -v

The following example shows the information that is returned from this command:

```
system:mm[1]> bofm -i 9.148.8.2 -l apply.csv -v
TFTP file upload successful.
Starting to apply new BOFM configuration on MM
Percent complete: 100%
Status: Confirmed configuration change.
Percent complete: 100%
Status: Configuration applied.
Applying new BOFM configuration on MM - Completed.
system:mm[1]>
```

boot command

This command resets blade servers with several different restart options.

Table 12. boot command

Function	What it does	Command	Valid targets
Reset blade server	Performs an immediate reset and restart of the specified blade server.	boot	-T system:blade[x]
	This command will start a blade server that is turned off.	This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration	where <i>x</i> is the blade server bay number.
		See "Commands and user authority" on page 8 for additional information.	
Reset blade server to command console	Resets the specified blade server, causing it to open a command console with an SOL session when it restarts. This command will start a blade server that is turned off.	 boot -c This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration and blade remote presence See "Commands and user authority" on page 8 for 	-T system:blade[x] where <i>x</i> is the blade server bay number.
Power cycle	Cycles power for the specified blade server. If the blade server is off, it will turn on. If the blade server is on, it will turn off and then turn on.	 additional information. boot -p powercycle This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade server bay number.
Reset blade server	Performs an immediate reset and restart of the specified blade server. This command will start a blade server that is turned off.	 boot -p reset This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade server bay number.

Example: To boot the blade server in blade bay 3, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type boot -T system:blade[3]

The following example shows the information that is returned: system:mm[1]> boot -T system:blade[3] OK system:mm[1]>

bootmode command

This command sets and displays the boot mode settings for blade servers installed in the BladeCenter unit that support this feature.

Table	13.	bootmode	command
-------	-----	----------	---------

Function	What it does	Command	Valid targets
Display blade server boot mode	Displays the boot mode settings of the specified blade server. Note: This command will execute only on blade servers that support the bootmode feature.	bootmode	-T system:blade[x] where <i>x</i> is the blade server bay number.
Set blade server boot mode	 Sets the copy of firmware that the specified blade server will use to boot: Temporary: booting from the temporary copy is recommended since it typically contains the latest enhancements and fixes. Permanent: booting from the permanent copy should be used only when booting from the temporary copy is no longer possible. Changes to the boot mode setting take effect after the next restart of the blade server. Note: This command will execute only on blade servers that support the bootmode feature. 	 bootmode -p mode where mode is: temp for temporary firmware copy. perm for permanent firmware copy. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade server bay number.

Example: To view the boot mode of the blade server in bay 2, while this blade server is set as the persistent command environment, at the system:blade[2]> prompt, type bootmode

To set the boot mode of the blade server in bay 2 to permanent, while this blade server is set as the persistent command environment, at the system:blade[2]> prompt, type

```
bootmode -p perm
```

The following example shows the information that is returned from these commands:

```
system:blade[2]> bootmode
active: temporary
pending: Invalid boot mode type
system:blade[2]> bootmode -p perm
Set the blade boot mode to permanent succeeded.
The setting will become active after the next reboot of the blade.
system:blade[2]> bootmode
active: temporary
pending: permanent
system:blade[2]>
```

bootseq command

This command sets and displays the boot sequence settings for blade servers installed in the BladeCenter unit.

Table	14.	bootseq	command
-------	-----	---------	---------

Function	What it does	Command	Valid targets
Display blade server	Displays the boot sequence of the	bootseq	-T system:blade[x]
boot sequence	specified blade server. Possible		
_	return values are:		where <i>x</i> is the blade
	floppy (diskette drive)		server bay number.
	• usbdisk (USB device)		
	• iscsi (iSCSI)		
	iscsicrt (iSCSI critical)		
	nw (network)		
	nodev (no device)		
	• hd0 (hard disk drive 0)		
	• hd1 (hard disk drive 1)		
	hd2 (hard disk drive 2		
	• hd3 (hard disk drive 3)		
	• hd4 (hard disk drive 4)		
	cd (CD-ROM drive)		
	• usb (media tray)		
	hyper (hypervisor)		
	• uefi (unified extensible firmware		
	interface)		
	• legacy (UEFI-specified legacy		
	sequence)		

Table 14. bootseq command (continued)

Function	What it does	Command	Valid targets
Set boot sequence for	Sets the boot sequence of the	bootseq <i>devicelist</i>	-T system:blade[x]
blade server	specified blade server.	where <i>devicelist</i> has one or	where r is the blade
		where <i>uebicensi</i> has one of	compar hav number
		devices execited in order	server bay number.
		of proformacy	
		• floony for the diskette	
		drive	
		(non POWER based	
		hlade servers only)	
		• usbdisk for a USB	
		device (not supported	
		by all blade servers)	
		• is csi for is CSI	
		• iscsicrt for iSCSI	
		critical	
		• nw for network - PXF	
		• nodey for no device	
		 hd0 for hard disk drive 	
		hd1 for hard disk drive	
		1	
		 hd2 for hard disk drive 	
		2	
		 hd3 for hard disk drive 	
		3	
		hd4 for hard disk drive	
		4	
		• cd for the CD-ROM	
		drive	
		• usb for the media tray	
		(non-POWER-based	
		blade servers installed	
		in BladeCenter T units	
		only)	
		hyper for hypervisor	
		(only for blade servers	
		that use hypervisor	
		virtualization)	
		 uefi for unified 	
		extensible firmware	
		interface (UEFI) (only	
		for blade servers that	
		support this feature)	
		• legacy for the	
		UEFI-specified legacy	
		boot sequence (only for	
		blade servers that	
		support this feature)	
		(continued on next page)	

Table 14. bootseq command (continued)

Function	What it does	Command	Valid targets
Set boot sequence for		A boot sequence of up to	
blade server		four boot devices can be	
		specified. If fewer than	
(continued)		four devices are specified,	
		the remaining items in the	
		sequence are set to nodev.	
		This command can only	
		be run by users who have	
		one or more of the	
		following command	
		authorities.	
		Supervisor	
		Blade configuration	
		See "Commands and user authority" on page 8 for additional information.	

Table 14. bootseq command (continued)

Function	What it does	Command	Valid targets
Set boot sequence for all blade servers	Sets the same boot sequence for all blade servers installed in the BladeCenter unit.	 bootseq -all <i>devicelist</i> where <i>devicelist</i> has one or more of the following boot devices specified, in order of preference: floppy for the diskette drive (non-POWER-based blade servers only) usbdisk for a USB device (not supported by all blade servers) iscsi for iSCSI iscsicrt for iSCSI critical nw for network - PXE nodev for no device hd0 for hard disk drive 0 hd1 for hard disk drive 1 hd2 for hard disk drive 3 hd4 for hard disk drive 4 cd for the CD-ROM drive usb for the media tray (non-POWER-based blade servers installed in BladeCenter T units only) hyper for hypervisor (only for blade servers that use hypervisor virtualization) uef i for unified extensible firmware interface (only for blade servers that support this feature) 	-T system:blade[x] where x is the blade server bay number.

Table 14. bootseq command (continued)

Function	What it does	Command	Valid targets
Set boot sequence for all blade servers (continued)		 legacy for the UEFI-specified legacy boot sequence (only for blade servers that support this feature) 	
		A boot sequence of up to four boot devices can be specified. If fewer than four devices are specified, the remaining items in the sequence are set to nodev.	
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade configuration	
		See "Commands and user authority" on page 8 for additional information.	

Example: To set a boot sequence of diskette drive, CD-ROM drive, and hard disk drive 0 for the blade server in blade bay 3, while the blade server in blade bay 3 is set as the persistent command environment, at the system:blade[3]> prompt, type bootseq floppy cd hd0

To display the boot sequence for the blade server in blade bay 3, while the blade server in blade bay 3 is set as the persistent command environment, at the system:blade[3]> prompt, type bootseq

The following example shows the information that is returned from these two commands:

system:blade[3]> bootseq floppy cd hd0 OK system:blade[3]> bootseq floppy cd hd0 nodev system:blade[3]>

buildidcfg command

This command creates, displays, and configures the list of firmware build IDs for the blade servers.

Table	15.	buildidcfa	command
rubio	10.	bunuluoig	oommuna

Function	What it does	Command	Valid targets
Display blade server firmware build IDs	Displays list of blade server firmware build IDs. Note: The build ID list must be built using the -create command option before it can be displayed.	buildidcfg	-T system
Create blade server build ID list	Creates an initial firmware build ID list for all blade servers installed in the BladeCenter unit. Note: The build ID list contains information for only those blade servers that have VPD which is fully accessible by the advanced management module. Any blade servers with VPD that is unavailable or failed will be ignored and not appear in the list	 buildidcfg -create This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration Blade configuration Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system

Table 15. buildidcfg command (continued)

Add blade server build Adds a new blade server firmware build ID entry to the list. manufacturer -mt Note: All options must be specified when adding a new firmware build ID entry. The arguments for manufacturer, machine type, firmware type, and build ID cannot be blank or unspecified; however, the argument for build revision can be blank or not set. build id -rev build rev • Materia • Materia • Materia • Materia • Bank or not set. • Materia • Materia • Materia • Bank or not set. • Materia • Materia • Materia • Materia • Materia • Materia
build revision, up to 31 characters in length, enclosed in quotation marks. The firmware build revision can contain spaces, but no leading or trailing spaces are allowed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration • Blade configuration • Blade remote presence See "Commands and user authority" on page 8 for
Blade configuration Blade remote presence

Table 15. buildidcfg command (continued)

Function	What it does	Command	Valid targets
Update blade server build ID list entry - manufacturer	 Update the manufacturer for the specified blade server firmware build ID entry. Note: The <i>index</i> number for each entry in the list is found by running the buildidcfg command with no options. The argument for manufacturer cannot be blank or unspecified. 	 buildidcfg -ub index -mfg manufacturer where: index is the index of the build ID list entry. manufacturer is a manufacturer name, up to 31 characters in length, enclosed in quotation marks. The manufacturer name can contain spaces, but no leading or trailing spaces are allowed. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration Blade remote presence 	-T system
		authority" on page 8 for additional information.	
Update blade server build ID list entry - machine type	 Update the machine type for the specified blade server firmware build ID entry. Note: The <i>index</i> number for each entry in the list is found by running the buildidcfg command with no options. The argument for machine type cannot be blank or unspecified. 	 buildidcfg -ub index -mt machine_type where: index is the index of the build ID list entry. machine_type is a machine type, up to 31 characters in length, enclosed in quotation marks. The machine type can contain spaces, but no leading or trailing spaces are allowed. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system

Table 15. buildidcfg command (continued)

Function	What it does	Command	Valid targets
Update blade server build ID list entry - firmware type	 Update the firmware type for the specified blade server firmware build ID entry. Note: The <i>index</i> number for each entry in the list is found by running the buildidcfg command with no options. The argument for firmware type cannot be blank or unspecified. 	 buildidcfg -ub <i>index</i> -ft <i>firmware_type</i> where: <i>index</i> is the index of the build ID list entry. <i>firmware_type</i> is bios, diags, or bmc. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system
Update blade server build ID list entry - firmware build ID	 Update the firmware build ID for the specified blade server firmware build ID entry. Note: The <i>index</i> number for each entry in the list is found by running the buildidcfg command with no options. The argument for build ID cannot be blank or unspecified. 	 buildidcfg -ub index -id build_id where: index is the index of the build ID list entry. build_id is a firmware build ID, up to 31 characters in length, enclosed in quotation marks. The firmware build ID can contain spaces, but no leading or trailing spaces are allowed. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration Blade remote presence See "Commands and user authority" on page 8 for additional information.	-T system

Table 15. buildidcfg command (continued)

Function	What it does	Command	Valid targets
Update blade server build ID list entry - firmware build revision	 Update the firmware build revision for the specified blade server firmware build ID entry. Note: The <i>index</i> number for each entry in the list is found by running the buildidcfg command with no options. The argument for the build revision can be blank or not set. 	 buildidcfg -ub <i>index</i> -rev <i>build_rev</i> <i>index</i> is the index of the build ID list entry. <i>build_rev</i> is a firmware build revision, up to 31 characters in length, enclosed in quotation marks. The firmware build revision can contain spaces, but no leading or trailing spaces are allowed. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system
Delete all entries from blade server build ID list	Delete all blade server firmware build ID entries from the list.	 buildidcfg -db all This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration Blade configuration Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system

Table 15.	buildidcfg	command	(continued)
-----------	------------	---------	-------------

Function	What it does	Command	Valid targets
Delete entry from blade server build ID list	Delete a specific blade server firmware build ID entry from the list. Note: The <i>index</i> number for each entry in the list is found by running the buildidcfg command with no options.	 buildidcfg -db <i>index</i> where <i>index</i> is the index number of a specific build ID list entry to delete. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration Blade configuration Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system
Import blade server build ID list	Import a firmware build ID list from file.	buildidcfg -import <i>filename</i>	-T system
	The file name to import must specify a qualified location for the build ID list image that indicates the protocol to be used. For example, tftp://192.168.0.1/tmp/ buildid.txt.	where <i>filename</i> is a qualified location of up to 256 characters in length that indicates the protocol to be used (tftp, ftp, ftps, http, or https) and contains any character except the percent sign (%) or double-quote ("). This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration • Blade remote presence See "Commands and user authority" on page 8 for	
		authority" on page 8 for additional information.	

Table 15. buildidcfg command (continued)

Function	What it does	Command	Valid targets
Export blade server build ID list	Export the current build ID list to a specified TFTP server.	buildidcfg -export <i>ip_address</i>	-T system
		where <i>ip_address</i> is a valid IP address.	
		This command can only	
		be run by users who have	
		one or more of the	
		authorities:	
		 Supervisor 	
		Blade administration	
		Blade configuration	
		Blade remote presence	
		See "Commands and user authority" on page 8 for additional information.	

Example: To create the initial build ID list, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type buildidcfg -create

To view the build ID list, while the BladeCenter unitis set as the persistent command environment, at the system> prompt, type buildidcfg

The following example shows the information that is returned from these commands:

system> OK	> buildidcfg -	create			
System		March for a True a	F ²		Devideden
Index	Manufacture	Machine Type	Firmware Type	BUILD ID	Revision
1	IBM	8853	Blade Sys Mgmt Processor	BCB158A	1.18
2	IBM	8853	Diagnostics	BCYT28AUS	1.06
		0050			
3	IBM	8853	FW/BIOS	BCE141AUS	1.1/
4	TDM	7071	Diada Cua Manut Duadaaaa		1 20
4	IBM	/9/1	Blade Sys Mgmt Processor	BAB155A	1.32
Б	ТРМ	7071	Diagnostics		1 06
5	1 DI'I	/9/1	Dragnostres	DATISTAUS	1.00
6	TRM	7071	FW/BIOS	RAF155AUS	1 10
0	1.01.1	/ 5/ 1	I W/ D103	DALIJJAUJ	1.10

system>

chconfig command

This command configures the BladeCenter unit Service Advisor feature.

Table	16.	chconfig	command
-------	-----	----------	---------

Function	What it does	Command	Valid targets
Display Service Advisor configuration	Displays the contact information for the Service Advisor feature. Service Advisor resides on your advanced management module and monitors your BladeCenter unit for hardware events. Upon detecting a hardware events. Upon detecting a hardware event, Service Advisor captures the event, error logs, and service data, and can automatically report the event to IBM support. To send call home event to IBM support, you must enable and configure Service Advisor. For each call home event IBM receives, a service ticket will opened, and a follow-up call will be made. This feature will generate a message to IBM when events occur in the BladeCenter unit or one of its components that usually can be resolved without additional problem determination. Note: The system will wait five days before sending duplicate events if they are left unacknowledged in the activity log.	chconfig	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display / accept Service Advisor terms and conditions	Displays or accepts the terms of the Service Advisor terms and conditions.	 chconfig -1i <i>license</i> where <i>license</i> is view to view the Service Advisor terms and conditions. accept to accept the Service Advisor terms and conditions. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 16. chconfig command (continued)

Function	What it does	Command	Valid targets
Enable / disable Service Advisor terms and conditions	 Enables or disables the call-home terms and conditions. Notes: All contact information fields are required before the Service Advisor can be enabled. Call Home will connect to IBM through HTTPS and HTTP. HTTP Proxy fields must be set to permit for outbound traffic. Service Advisor also needs to set up DNS server address on the advanced management module. Changing the Service Advisor setting from disabled to enabled will automatically trigger a test call home and the Service Advisor Activity Log will record this test call home. 	 chconfig -sa setting -sc support_center where setting is enable to activate the Service Advisor terms and conditions. disable to suspend the Service Advisor terms and conditions. disable to suspend the Service Advisor terms and conditions. support_center is the 2-character ISO 3166 country code of the IBM support center location. For example, the country code for the United States is US. Notes: Go to http://www.iso.org/ iso/country_codes/ iso_3166_code_lists/ for a complete list of country codes. Valid country codes must refer to countries that have IBM support centers. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Function	What it does	Command	Valid targets
Function Set contact information for Service Advisor	What it does Sets contact information for the Service Advisor.	Command chconfig -co "company" -cn "name" -cph "phone" -ce email -ca "address" -cci "city" -cs state -sc support_center -cz "postalcode" where: • "company" is the quote-delimited contact company name, of up to 30 characters in length.	Valid targets -T system:mm[x] where <i>x</i> is the primary management-module bay number.
		 <i>"name"</i> is the quote-delimited contact name, of 1 to 30 characters in length. <i>"phone"</i> is the quote-delimited contact phone number, of 5 to 30 characters in length. <i>email</i> is email address of the contact person in the form userid@hostname (30 characters maximum). The userid can be alphanumeric 	
		characters, ".", "-", or "_" but must begin and end with alphanumeric characters. The hostname can be alphanumeric characters, ".", "-", or "_". It must contain at least two domain items. Every domain item should begin and end with an alphanumeric character and the last domain item should be from 2 to 20 alphabetic	
		 characters. <i>"address"</i> is the quote-delimited street address of the machine location, of 1 to 30 characters in length. <i>"city"</i> is the quote-delimited city of the machine location, of 1 to 30 characters in length. (continued on next page) 	

Table 16. chconfig command (continued)

Function	What it does	Command	Valid targets
Set contact information for Service Advisor (continued)		 <i>state</i> is the state of the machine location, of 2 to 3 characters in length. <i>"postalcode"</i> is the quote-delimited postal code of the machine location, of 1 to 9 alphanumeric characters in length. 	
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	

Function	What it does	Command	Valid targets
Function Set up HTTP proxy for Service Advisor	What it does Sets up HTTP proxy for Service Advisor.	Command chconfig -ps setting -loc hostname -po port -u "username" -pw "password" where: • setting is enabled or disabled • hostname is the fully qualified host name or IP address of the HTTP proxy, of 1 to 63 characters in length.	Valid targets -T system:mm[x] where x is the primary management-module bay number.
		 <i>port</i> is the port of the HTTP proxy, a number from 1 to 65535, inclusive. <i>"username"</i> is the quote-delimited user name, of 1 to 30 characters in length. <i>"password"</i> is the quote-delimited password of the HTTP proxy, of up to 15 characters in length 	
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	

Table 16. chconfig command (continued)

To accept the Service Advisor terms and conditions, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type chconfig -li accept

To display the current configuration of the Service Advisor, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type chconfig

The following example shows the information that is returned from these two commands:

```
system:mm[1]> chconfig -li accept
0K
system:mm[1]> chconfig
-sa enabled
-sc US
-ca No 399, Keyuan Rd,
-cci Dallas
-ce bob@cn.ibm.com
-cn bob
-co IBM
-cph 800-555-1111
-cs TX
-cz 75210
-loc google.cn
-po 8080
-ps disabled
-u User-001
system:mm[1]>
```

chlog command

This command is used to display up to five call-home activity log entries and to mark a call-home event entry as acknowledged or unacknowledged.

Table 17. chlog (display call-home activity log) command

Function	What it does	Command	Valid targets
Display call-home activity log entries	 Displays the last five entries from the call-home activity log. Notes: The entries are displayed in reverse chronological order (most recent call-home entry first). The system will wait 5 days before sending duplicate events if they are not acknowledged as corrected in the activity log. Call-home events are usually those that can be resolved without additional problem determination. 	chlog	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display FTP/TFTP server call-home activity log entries	 Displays the last five FTP/TFTP server entries from the call-home activity log. Notes: The entries are displayed in reverse chronological order (most recent call-home entry first). The system will wait 5 days before sending duplicate events if they are not acknowledged as corrected in the activity log. 	chlog -f	-T system:mm[x] where x is the primary management-module bay number.
Display IBM Support call-home activity log entries	 Displays the last five IBM Support entries from the call-home activity log. Notes: The entries are displayed in reverse chronological order (most recent call-home entry first). The system will wait 5 days before sending duplicate events if they are not acknowledged as corrected in the activity log. Call-home events are usually those that can be resolved without additional problem determination. 	chlog -s	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Function	What it does	Command	Valid targets
Acknowledge / unacknowledge call-home activity log entries	Marks the selected call-home event as acknowledged (yes) or unacknowledged (no) when the call-home event has been corrected. Note: The system will wait five days before sending duplicate events if they are left unacknowledged in the activity log.	 chlog -index -ack option where: index is the index of the call-home event entry option is yes or no This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 17. chlog (display call-home activity log) command (continued)

Example: To display five call-home activity log entries, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type chlog

To mark the call-home event with index number 14 as acknowledged, type chlog -14 -ack yes

The following example shows the information that is returned from these two commands:

```
system:mm[1]> chlog
Index Ack Send Result Assigned Num Event ID Sev Source
Time Message
14 No Success NULL 0x00016802 I CHASSIS
06/04/08 09:11:11 Test Call Home generated by USERID.
15 No Pending NULL 0x00016802 I CHASSIS
06/04/08 09:11:12 Test Call Home generated by USERID.
system:mm[1]>chlog -14 -ack yes
0K
system:mm[1]>
```

chmanual command

This command tests the BladeCenter unit call-home feature setup.

Table 18.	chmanual	command
10010 101	onnanaan	oonninana

Function	What it does	Command	Valid targets
Function Create call-home problem message	What it does Create a call-home problem message for a management module or blade server.	Command chmanual -desc "description" where "description" is a quote-delimited problem description of 1 to 100 characters in length. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis account management • Chassis log management • Chassis configuration • Blade administration • Blade remote presence • I/O module administration • I/O module configuration	Valid targets -T system -T system:blade[x] where x is the blade server bay number.
		See "Commands and user authority" on page 8 for additional information	

Table 18. chmanual command (continued)

Function	What it does	Command	Valid targets
Generate call-home test call home	Manually generate a test call-home event that transmits the sample call-home problem message.	 chmanual -test This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management Chassis log management Chassis log management Chassis configuration Blade administration Blade configuration Blade remote presence I/O module administration I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system

To create a call-home test message, at the system:> prompt, type chmanual -desc "This is a test."

To manually send a test message, while the system is set as the persistent command environment, at the system> prompt, type chmanual -test

The following example shows the information that is returned from these two commands:

system> chmanual -desc "This is a test." OK system> chmanual -test OK system>

cin command

This command can be used to view and configure the chassis internal network for up to 14 supported chassis internal network (CIN) configurations, globally, or for specified entries. You can define a CIN by creating a pool of VLAN (virtual local area network) ID/IP address pairs, each of which is a CIN entry.

Table 19. cin command

Function	What it does	Command	Valid targets
Display CIN configuration table	 Displays the configuration table for the chassis internal network. Possible return values are: Global CIN enabled or disabled status CIN index VLAN ID IP address index entry enabled or disabled status 	cin	-T system
Set global CIN state	Sets the global state of CIN to enabled or disabled.	 cin -global -en state where state is on off This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management and chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system
Clear all CIN configuration entries	Deletes all CIN configuration entries.	 cin all -clear This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management and chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system

Table 19. cin command (continued)

Function	What it does	Command	Valid targets
Turn all index entries on or off	Turns all CIN index entries on or off.	 cin all -en state where state is on off This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management and chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system
Delete CIN configuration entry	Deletes the specified CIN configuration entry.	 cin -entry_index -clear where entry_index is a number between 1 and 14 (inclusive). This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management and chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system
Set CIN configuration entry to enable or disable	Enables or disables a CIN configuration entry. If you enable or disable a non-existent entry, the action is ignored and no error message is returned.	 cin -entry_index -en state where: entry_index is a number between 1 and 14, and state is on off This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management and chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system

Table 19. cin command (continued)

Function	What it does	Command	Valid targets
Create a CIN configuration entry	Creates a CIN index entry. If the CIN index is currently empty, both -id and -ip must be specified. Note: The VLAN ID must be different from that of the blade server management module.	 cin -entry_index -id vlan_id -ip ip_address where: entry_index is a number between 1 and 14, vlan_id is a VLAN ID number between 3 and 4094 (inclusive), ip_address is a valid IP address. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management and chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system
Specify valid IP address for CIN index entry	 Specifies the IP address of the CIN index entry. The CIN IP address must be a valid IP address. An error is displayed if the IP address is invalid. Note: If the index is not empty, the IP address can be specified separately. CIN entries cannot have matching IP addresses unless they are 0.0.0.0. and have different VLAN IDs. If the CIN IP address is 0.0.0, the blade server IP address for CIN which is configured in the blade server operating system cannot be in the same subnet as that of the advanced management module. The IP address cannot be multi-cast and cannot match the IP address of the management module. 	 cin <i>-entry_index</i> -ip <i>ip_address</i> where: <i>entry_index</i> is a number between 1 and 14 <i>ip_address</i> is a valid IP address. You can overwrite parameters of an existing definition; for example, cin -1 -ip 0.0.0 overwrites the current CIN IP address of the first cin entry. If the entry does not exist, an error is returned. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management and chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system

Table 19. cin command (continued)

Function	What it does	Command	Valid targets
Specify VLAN ID for CIN entry	Set the VLAN ID for the specified CIN entry.	cin -entry_index -id vlan_id	-T system
	 Note: If the index is not empty, the ID can be specified separately. The VLAN ID must be different from that of the management module. 	 where: <i>entry_index</i> is a number between 1 and 14 <i>vlan_id</i> is a number between 3 and 4094 (inclusive). This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management and chassis configuration See "Commands and user authority" on page 8 for additional information. 	

To view chassis internal network information for the management module, while this management module is set at the persistent command environment, at the system> prompt, type

cin

The following example shows the information that is returned from this command:

```
system> cin
-global -en off
Index 1
-id 11
-ip 11.1.1.1
-en on
Index 2
-id 12
-ip 22.1.1.1
-en on
Index 3
not used
Index 4
not used
Index 5
not used
Index 6
not used
Index 7
not used
```
Index 8 not used Index 9 not used Index 10 not used Index 11 not used Index 12 -id 123 -ip 23.1.1.1 -en on Index 13 not used Index 14 not used system>

cinstatus command

This command displays a table listing the VLAN ID, the IP address, the MAC address, and the status of each chassis internal network (CIN) connection.

Table 20. cinstatus command

Function	What it does	Command	Valid targets
Display entries of the CIN status table	Reads entries of the CIN status table, five at a time. Each entry of the table returns:	cinstatus	-T system
	CIN VLAN ID		
	CIN IP address		
	CIN MAC address		
	CIN status text		
Display status of first five CIN entries	Displays the first five entries of the CIN status table.	cinstatus -f	-T system
Display entire CIN status table	Displays all the entries in the CIN status table.	cinstatus -a	-T system

Note: An asterisk * next to an IP address indicates a learned entry.

Example:

To display five entries of the CIN status table, while the BladeCenter unit is set as the persistent environment, at the system> prompt, type cinstatus

The following example shows the information that is returned from this command system> cinstatus

-	Note:	: * next	to	ΙP	address	indicates	a lea	arned entry	
	VLAN	IP Addr	ess		MAC	Address		Status	
1. 2. 3. 4. 5.	4094 4094 4 4093 4094	0.0.0.1 0.0.0.2 0.0.0.0 0.0.0.1 0.0.0.0						Not Operational Not Operational Operational Not Operational Operational	

Last entry reached system>

clear command

This command restores the primary management module configuration or an I/O (switch) module configuration to the default settings.

The command must always include the -cnfg or -config option.

Table 21. clear command

Function	What it does	Command	Valid targets
Restore default configuration of primary management module and keep logs	Restores the default configuration of the primary management module, retaining log information; then, resets the management module. No results are returned from this command because it resets the management module. When you restore the management-module configuration, the Ethernet configuration method is set to a value of dthens. After the management module resets, this causes the management module to try dhcp configuration and then default to the static IP configuration, which might cause the management module to remain offline for longer than normal. See the "ifconfig command" on page 171 for information.	 clear -cnfg This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration and chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Restore default configuration of I/O module	Restores the configuration of the specified I/O module to the default settings.	 clear -cnfg This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration and I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where <i>x</i> is the I/O-module bay number.

Example: To restore the primary management-module configuration to default settings and retain log information, while management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type clear -cnfg

No results are returned from this command. After the management module resets, you will need to start a new command-line session.

clearlog command

This command clears the management-module audit event log, the system event log, or both.

Function	What it does	Command	Valid targets
Clear management-module event log	Clears the management-module event log and displays a message confirming that the specified event log was cleared.	 clearlog This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis log management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Clear advanced management-module audit or system event log	 Clears the management-module audit event log, the system event log, or both, and displays a message confirming that the specified event log was cleared. Notes: Audit log events are created by the actions of users. If the <i>log_type</i> is not specified, this command will clear both logs. Although system events and audit events are stored internally in separate log files, they are presented to the user as a single log that can be filtered. 	<pre>clearlog -l log_type where log_type is audit or system. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis log management See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 22. clearlog (clear management-module event log) command

Example: To clear the management-module audit log, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type clearlog -1 audit

The following example shows the information that is returned: system:mm[1]> clearlog -1 audit OK system:mm[1]>

clock command

This command configures and displays the advanced management-module clock settings.

Table 23.	clock	command
-----------	-------	---------

Function	What it does	Command	Valid targets
Display advanced management module clock information	 Displays the following information for the advanced management module clock: current date and time GMT (Greenwich-Mean Time) offset daylight-savings time setting 	clock	-T system:mm[x] where x is the primary management-module bay number.
Set advanced management module date	Sets the date for the advanced management module clock.	 clock -d <i>date</i> where <i>date</i> is the current calendar date in mm/dd/yyyy format. The month and day can be input as single digits. The year must be a four-digit number between 2000 and 2089, inclusive. This command can only be run by users who have the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information 	-T system:mm[x] where x is the primary management-module bay number.
Set advanced management module time	Sets the time for the advanced management module clock.	clock -t <i>time</i> where <i>time</i> is the current time in 24-hour hh:mm:ss format. The hours, minutes, and seconds can all be input as single digits. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 23. clock command (continued)

Function	What it does	Command	Valid targets
Set advanced	Sets the time for the advanced	clock -g <i>offset</i>	-T system:mm[x]
Function Set advanced management module clock GMT offset	What it does Sets the time for the advanced management module clock.	Command clock -g offset where offset is a value between +12 and -12, in hours and minutes. Positive offsets are entered using the form: GMT+hh:mm, +hh:mm, +hh, hh:mm, or hh; where, the hours and minutes can be input as single digits. Negative offsets are entered using the form: GMT-hh:mm, -hh:mm, or -hh; where, the hours and minutes can be input as single digits. Valid offsets are: • GMT+0:00 • GMT+1:00 • GMT+2:00 • GMT+3:30 • GMT+4:00 • GMT+5:30 • GMT+5:30 • GMT+5:30 • GMT+5:00 • GMT+5:30 • GMT+6:00 • GMT+9:00 • GMT+9:00 • GMT+11:00 • GMT+12:00 • GMT+12:00 • GMT+12:00 • GMT+12:00 • GMT-12:00 • GMT-2:00 • GMT-2:	Valid targets -T system:mm[x] where x is the primary management-module bay number.
		• GMT-6:00 • GMT-5:00 • GMT-4:00	
		• GMT-3:30 • GMT-3:00 • GMT-2:00	
		• GMT-1:00	
		(continueu on next puge)	

Table 23. clock command (continued)

Function	What it does	Command	Valid targets
Set advanced management module clock GMT offset (continued)		For some time zones that use daylight-savings time (GMT +10, +2, -5, -6, -7, -8, -9), a special value for the -dst option must be specified to identify the correct daylight-savings time scheme to use in that	
		time zone. This command can only be run by users who have the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	

Function	What it does	Command	Valid targets
Set advanced management module clock daylight-savings time mode	Sets the daylight-savings time mode for the advanced management module clock.	<pre>clock -dst dst_mode where dst_mode is one of the following: • off • on • for GMT+2:00: - off - ee (Eastern Europe) - gtb (Great Britain) - egt (Egypt) - fle (Finland) • for GMT+10:00: - off - ea (Eastern Australia) - tas (Tasmania) - vlad (Vladivostok) • for GMT-9:00 to GMT-5:00: - off - uc (United States and Canada) - other (other locations) • for GMT-4:00: - off - can (Canada) - other (other locations)</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		Daylight-savings time is not observed in the following GMT offsets: GMT+4:00, GMT+4:30, GMT+5:30, GMT+4:30, GMT+5:30, GMT+4:00, GMT+7:00, GMT+8:00, GMT+11:00, GMT+12:00, GMT-11:00, and GMT-10:00. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	

Table 23. clock command (continued)

Example: To set the management-module for operation in the US Eastern time zone in compliance with new daylight-savings time rules, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

clock -g +5 -dst uc

To display the clock information for the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

clock

The following example shows the information that is returned from these two commands:

```
system:mm[1]> clock -g +5 -dst uc
OK
system:mm[1]> clock
10/17/2006 02:27:11 GMT+5:00 dst uc
system:mm[1]>
```

config command

This command sets and displays the name of the advanced management module or blade server and the location and contact name for the advanced management module.

Function	What it does	Command	Valid targets
Display name of blade server	Displays the name of the specified blade server.	config	-T system:blade[x] where x is the blade server bay number.
Display name of management module	Displays the following information for the command target: • Name • Location • Contact name	config	-T system:mm[x] where x is the primary management-module bay number.
Display identifying information for BladeCenter unit	Displays the following information for the command target: • Universally unique identifier • Serial number • Type/model	config	-T system
Set name of management module or blade server	Sets the name of the primary management module or specified blade server.	 config -name name where name is up to 15 characters in length. Blade server names cannot contain angle brackets ("<" and ">"), and advanced management module names can only contain alphanumeric characters, hyphens, pound signs, underscores, and periods. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration (for management module) Blade configuration (for blade server) See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] -T system:blade[x] where x is the primary management-module or a blade server bay number.

Table 24. config command

Table 24. config command (continued)

Function	What it does	Command	Valid targets
Set location of management module	Sets the location of the primary advanced management module.	 config -loc "location" where "location" is up to 47 characters in length and contained within double-quotes. Advanced management module locations can contain any character other than "<" and ">". This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		authority" on page 8 for additional information.	
Set contact name for advanced management module	Sets the contact name for the primary advanced management module.	config -contact "contact_name" where "contact_name" is up to 47 characters in length and contained within double-quotes. Advanced management module contact names can contain any character other than "<" and ">". This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 24. config command (continued)

Function	What it does	Command	Valid targets
Set universally unique identifier (UUID) for BladeCenter unit	 Sets the universally unique identifier for the BladeCenter unit. Notes: Change the -uuid value only if you are certain it was not programmed correctly on the hardware. To prevent disrupting the operation of IBM Systems Director, you should edit this field only if the midplane of your system has been replaced with a new midplane that does not have this information programmed on it. If you change the UUID on an existing system to a random new value, IBM Systems Director will treat this as a new system, distinct from the one identified by the old UUID. Changes to the UUID take effect after the next restart of the advanced management module. 	 config -uuid "unique_id" where "unique_id" is 32 hexadecimal digits and is contained within double-quotes. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system
Set type/model for BladeCenter unit	 Sets the type or model designator for the BladeCenter unit. Notes: Change the -tm value only if you are certain it was not programmed correctly on the hardware. To prevent disrupting the operation of IBM Systems Director, you should edit this field only if the midplane of your system has been replaced with a new midplane that does not have this information programmed on it. Changes to the type/model take effect after the next restart of the advanced management module. 	<pre>config -tm "type_model" where "type_model" is up to seven characters in length and contained within double-quotes. Advanced management module type / model designators can contain any character other than "<" and ">". This command can only be run by users who have the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system

Table 24. config command (continued)

Function	What it does	Command	Valid targets
Set serial number for BladeCenter unit	 Sets the serial number for the BladeCenter unit. Notes: Change the -sn value only if you are certain it was not programmed correctly on the hardware. To prevent disrupting the operation of IBM Systems Director, you should edit this field only if the midplane of your system has been replaced with a new midplane that does not have this information programmed on it. Changes to the serial number take effect after the next restart of the advanced management module. 	<pre>config -sn "serial_number" where "serial_number" is up to seven characters in length and contained within double-quotes. Advanced management module serial numbers can contain any character other than "<" and ">". This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system

Example:

To set the management module name to IBM_lab, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type config -name IBM_lab

To display the management module name, location, and contact name, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

config

The following example shows the information that is returned from these two commands:

```
system:mm[1]> config -name IBM_lab
OK
system:mm[1]> config
-name IBM_lab
-contact John_Doe
-loc Main_Lab
system:mm[1]>
```

console command

This command sets up a serial over LAN connection to the command console of a blade server.

To end an SOL session, press Esc followed by an open parenthesis:

Esc (

Table 25. console command

Function	What it does	Command	Valid targets
Create SOL session with blade server	Creates an SOL connection to the specified blade server. Note: The advanced management module supports a persistent SOL connection that remains intact until you escape from the SOL console, or another user uses the override option to take over your SOL console. A persistent command, if dropped, automatically attempts to reconnect.	console This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade remote presence See "Commands and user authority" on page 8 for additional information.	-T system:blade[x] where x is the blade server bay number.
Create override SOL session with blade server	Creates an SOL connection to the specified blade server, with the override option enabled. This enables you to end an existing SOL session to that blade server and start a new one. Note: The advanced management module supports combing this is option with the -l option to override an existing session, and not reconnect if the connection drops.	console -0 This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade remote presence See "Commands and user authority" on page 8 for additional information.	-T system:blade[x] where x is the blade server bay number.
Create non-persistent SOL session with blade server	Creates an SOL connection to the specified blade server for users who do not want to use a persistent session. Note: This option can be combined with the -o option to override an existing session, and not reconnect if the connection drops.	 console -1 This command can only be run by users who have one or more of the following command authorities: Supervisor Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade server bay number.

Example: To start an SOL connection to the blade server in blade bay 14, while this
blade server is set as the persistent command environment, at the system:mm[x]>
prompt, type
console -T system:blade[14]

dhcpinfo command

This command displays the IP configuration that is assigned by a DHCP server to the primary management module external network interface, blade server management network interfaces, and I/O module DHCPv6 server.

Note: The dhcpinfo command does not apply to management module channel eth1, which always uses a static IP configuration.

Table 26. dhcpinfo command

Function	What it does	Command	Valid targets
Display Ethernet channel 0 DHCP configuration for management module	If the IP configuration for management module eth0 is assigned by a DHCP server, the configuration that is assigned by the DHCP server and DHCP server information is displayed. If the IP configuration for eth0 is <i>not</i> assigned by a DHCP server, an error message is displayed. Possible configuration values returned are: • -server <i>dhcp_ip_address</i> • -n <i>hostname</i> • -i <i>ip_address</i> • -g gateway_address • -g gateway_address • -ds1 primary_dns_ip_address • -dns2 secondary_dns_ip_address • -dns3 tertiary_dns_ip_address • -dns61 IPv6_address • -dns61 IPv6_primary_dns_ip_address • -dns62 IPv6_secondary_dns_ip_address • -dns63 IPv6_tertiary_dns_ip_address	dhcpinfo -eth0	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display management network DHCP configuration for blade server	If the IPv6 configuration for the specified blade server management network Ethernet channel is assigned by a DHCP server, the IPv6 IP address is displayed. If the IP configuration for the specified blade server management network Ethernet channel is <i>not</i> assigned by a DHCP server, an error message is displayed.	dhcpinfo -eth <i>x</i> where <i>x</i> is the blade server management network channel number to display.	-T system:blade[x] where <i>x</i> is the blade server bay number.
Display DHCP configuration for I/O module	If the IPv6 configuration for the specified I/O module is assigned by a DHCP server, the IPv6 IP address is displayed. If the IPv6 configuration for the I/O module is <i>not</i> assigned by a DHCP server, an error message is displayed.	dhcpinfo	-T system:switch[x] where x is the I/O-module bay number.

Example: To display the DHCP server assigned network settings that do not support IPv6 for Ethernet channel 0, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type dhcpinfo -eth0

The following example shows the information that is returned:

system:mm[1]> dhcpinfo -eth0
-server 192.168.70.29
-n MM00096BCA0C80
-i 192.168.70.183
-g 192.168.70.29
-s 255.255.255.0
-d linux-sp.raleigh.ibm.com
-dns1 192.168.70.29
-dns2 0.0.0
-dns3 0.0.0
system:mm[1]>

To display the DHCP server assigned network settings that support IPv6 for Ethernet channel 0, while management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type

dhcpinfo -eth0

The following example shows the information that is returned:

system:mm[1]> dhcpinfo -eth0
DHCP is disabled
-server6 FE80:0000:0000:0000:0202:55FF:FE21:0F23
-i6 2000:1013:0000:0000:DDDD:CCCC:D7C8:F925
-d6 datacentertech.net
-dns61 2000:1013:0000:0000:0000:0000:0100:0100
-dns62 2000:1013:0000:0000:0000:0000:0100:0101
-dns63 2000:1013:0000:0000:0000:0000:0100:0102
system:mm[1]>

displaylog command

This command displays management-module event log entries.

Note: Event descriptions and suggested user actions for items shown by the displaylog command can be viewed using the "eventinfo command" on page 138.

Table 27. displaylog (display management-module event log) command

Function	What it does	Command	Valid targets
Display management-module event log entries	Displays five entries from the management-module event log. The first time the command is executed, the five most recent log entries are displayed. Each subsequent time the command is issued, the next five entries in the log display.	displaylog	-T system:mm[x] where x is the primary management-module bay number.
Display management-module event log entries (reset counter)	Resets the counter and displays the first five most recent entries in the management-module event log.	displaylog -f	-T system:mm[x] where x is the primary management-module bay number.
Display log entries with Event ID	Displays log entries with Event ID.	displaylog -e	-T system:mm[x] where x is the primary management-module bay number.
Display log entries with their call-home flag	Displays log entries with their call-home flag.	displaylog -c	-T system:mm[x] where x is the primary management-module bay number.
Display all management-module event log entries	Displays all entries in the management module event log.	displaylog -a	-T system:mm[x] where x is the primary management-module bay number.
Display all event log filters	Displays all filters that can be used to control management module event log output.	displaylog -filters	-T system:mm[x] where x is the primary management-module bay number.

Function	What it does	Command	Valid targets
Display event log entries filtered by date	 Displays management module event log information that meets the specified date filter criteria. Note: This command displays the first five most recent entries in the management-module event log that meet the specified filter criteria. Adding the -a option to the command displays all entries that meet the specified filter criteria. If the filter criteria entered does not match the criteria previously specified, this resets the counter and displays the first five most recent log entries that match the specified filter criteria. The index number displayed for each filtered log entry might not match the index number shown for the same log entry displayed in an unfiltered list. 	displaylog -date <i>date_filter</i> where <i>date_filter</i> is a pipe () separated list of date filters in mm/dd/yy format.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display event log entries filtered by severity level	 Displays management module event log information that meets the specified severity level filter criteria. Note: This command displays the first five most recent entries in the management-module event log that meet the specified filter criteria. Adding the -a option to the command displays all entries that meet the specified filter criteria. If the filter criteria entered does not match the criteria previously specified, this resets the counter and displays the first five most recent log entries that match the specified filter criteria. The index number displayed for each filtered log entry might not match the index number shown for the same log entry displayed in an unfiltered list. 	<pre>displaylog -sev severity_filter where severity_filter is a pipe () separated list of severity filters: • I (information) • E (error) • W (warning)</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display event log entries filtered by source	Displays management module log information that stored in the audit log.	displaylog -src Audit	-T system:mm[x] where x is the primary management-module bay number.

Table 27. displaylog (display management-module event log) command (continued)

Function	What it does	Command	Valid targets
Display event log entries filtered by every flag except the one specified	 Displays management module log information that is stored in logs other than the specified log. Note: This command displays the first five most recent entries in the management-module event log that meet the specified filter criteria. Adding the -a option to the command displays all entries that meet the specified filter criteria. If the filter criteria entered does not match the criteria previously specified, this resets the counter and displays the first five most recent log entries that match the specified filter criteria. The index number displayed for each filtered log entry might not match the index number shown for the same log entry displayed in an unfiltered list. 	displaylog -src !filter_out where filter_out is the category of event log entries that is not to be displayed. Use the displaylog -filters command to discover excludable event log categories.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display audit log entries filtered by source	 Displays management module audit log information that meets the specified source filter criteria. Note: This command displays the first five most recent entries in the management-module event log that meet the specified filter criteria. Adding the -a option to the command displays all entries that meet the specified filter criteria. If the filter criteria entered does not match the criteria previously specified, this resets the counter and displays the first five most recent log entries that match the specified filter criteria. The index number displayed for each filtered log entry might not match the index number shown for the same log entry displayed in an unfiltered list. 	displaylog -src <i>source_filter</i> where <i>source_filter</i> is a pipe () separated list of source filters. To specify a range of blade servers as the source, use a hyphen (-), as follows: Blade_01-08.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 27. displaylog (display management-module event log) command (continued)

Function	What it does	Command	Valid targets
Display log entries filtered by call-home flag	 Displays log entries that meet the specified call-home events filter criteria. Note: This command displays the five most recent entries in the management-module event log that meet the specified filter criteria. Adding the -a option to the command displays all entries that meet the specified filter criteria. If the filter criteria entered does not match the criteria previously specified, this resets the counter and displays the first five most recent log entries that match the specified filter criteria. The index number displayed for each filtered log entry might not match the index number shown for the same log entry displayed in an unfiltered list. 	displaylog -ch <i>option</i> where <i>option</i> are: • C (call home) • N (no call home)	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display the state of the log state event option	Displays the state (enabled or disabled) of the log state event option, which generates an event when the event log becomes 75% or 100% full.	displaylog -lse	-T system:mm[x] where x is the primary management-module bay number.
Enable / disable monitoring of event log state	Enables or disables the monitoring of the event log state to generate an event when the log becomes 75% or 100% full. Note: The displaylog -lse command must be run exclusive of other log-reading command options (-f, -a, -filters, -date, -sev, - src, -i, and -l).	 displaylog -lse state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis log management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Save event log to TFTP server	Saves the event log with the specified filename to the specified TFTP server. Note: The -i and -l command options must be run together and exclusive of other command options.	 displaylog -i ip_address -1 filename where: ip_address is the IPv4 or IPv6 IP address of the TFTP server where the event log is being saved. filename is the name of the event log file. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 27. displaylog (display management-module event log) command (continued)

Example:

To display all log entries generated by the management module in bay 1 other than those in the audit log, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

displaylog -src !Audit -T mm[1]

To display audit log entries generated by the management module in bay 1, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

displaylog -src Audit -T mm[1]

The following example shows the information that is returned from these commands:

system>	display	log -src !Αι	udit -T mm[1]		
1	Ι	SERVPROC	08/04/08	14:18:06	Recovery Event log full
2	Ι	SERVPROC	08/04/08	14:18:06	Alarm Manager removed a MNR alert during recovery of Event log full
(There a	are no mo	ore entries	in the event	: log.)	
system>	display	log -src aud	lit -T mm[1]		
1	Ι	Audit	08/04/08	14:28:38	Remote logoff successful for user 'spdev'from Telnet at IP 9.44.124.157
2	Ι	Audit	08/04/08	14:28:18	Remote login successful for user 'spdev' from Telnet at IP 9.44.124.157
3	Ι	Audit	08/04/08	14:18:15	Audit log cleared by 'spdev'.
(There a system>	are no mo	ore entries	in the event	: log.)	

displaysd command

This command captures and displays service information.

Service information for the management modules includes BladeCenter VPD, the management-module event log, connection status, and self-test results. If multiple user interface sessions issue the displaysd command, the commands will be processed in the order that they are received. Some types of service information are displayed for only the primary management module.

Table 28. displaysd command

Function	What it does	Command	Valid targets
Capture and display service information	Capture and display service information on page from the primary or standby management module.	displaysd	-T system:mm[x] where x is the primary or standby management-module bay number.
Display management module connection and self-test status	Displays connection status and latest self-test results for the primary management module.	displaysd -mmstat	-T system:mm[x] where x is the primary management-module bay number.
Save service information to TFTP server	Saves service information from primary management module with the specified filename to the specified TFTP server. Note: The -save and -i command options must be run together.	 displaysd -save filename i ipaddress where: filename is the location where service information will be saved. The filename should use a .tgz extension to allow support personnel to identify the file. ip_address is the IPv4 or IPv6 IP address of the TFTP server. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display all blade server SRC records	Displays a list of the most recent (up to 32) SRCs for the specified blade server. Note: SRC information is available for only those blade servers that support this feature.	displaysd -src list	-T system:blade[x] where x is the blade serverbay number.
Display specific blade server SRC record	Displays a specific SRC, based on the specified record number, for the specified blade server. Note: SRC information is available for only those blade servers that support this feature.	displaysd -src <i>index</i> where <i>index</i> is the SRC record number to display, between 1 and 32.	-T system:blade[x] where x is the blade serverbay number.

Example: To capture and display service information from the management module in bay 1, while the chassis is set as the persistent command environment, at the system> prompt, type displaysd -T system:mm[1]

```
displaysd -i system:mm[1]
```

To capture service information from the management module in bay 1 and save it to a file named sdc.tgz on a TFTP server with a IP address of 9.67.22.176, while the chassis is set as the persistent command environment, at the system> prompt, type displaysd -T system:mm[1] -save sdc.tgz -i 9.67.22.176

The following example shows the information that is returned from these commands:

```
system> displaysd -T system:mm[1]
SPAPP Capture Available
Time: 10/04/2005 21:47:43
UUID: Not Available
•
•
system> displaysd -T system:mm[1] -save sdc.tgz -i 9.67.22.176
OK
system>
```

Note: If a large amount of service information is available, display could exceed the capacity of your command-prompt window, resulting in loss of information displayed at the start of the data set. If this happens, you will need to clear the management-module event log to reduce the amount of information being captured.

dns command

This command configures and displays the management-module DNS settings.

Table 29. dns command

Function	What it does	Command	Valid targets
Display DNS configuration of management module	Displays the current DNS configuration of the management module. Possible return values are: • enabled • disabled • -i1 IPv4_first_ip_address • -i2 IPv4_second_ip_address • -i3 IPv4_third_ip_address • -i61 IPv6_first_ip_address • -i63 IPv6_third_ip_address • -i63 IPv6_third_ip_address • -ddns dynamic_DNS_state (enabled/disabled) • -p DNS_server_priority (ipv4/ipv6)	dns	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
DNS - enable / disable	Enables or disables the management-module DNS configuration.	 dns -state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Dynamic DNS - enable / disable	Enables or disables dynamic DNS for the management module.	 dns -ddns state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 29. dns command (continued)

Function	What it does	Command	Valid targets
DNS first IPv4 IP	Sets the first IPv4 IP address.	dns -i1 <i>ip_address</i>	-T system:mm[x]
address - set		where <i>ip_address</i> is the first IP address in dotted decimal IP address format.	where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
DNS second IPv4 IP	Sets the second IPv4 IP address.	dns -i2 <i>ip_address</i>	-T system:mm[x]
autress - set		where <i>ip_address</i> is the second IP address in dotted decimal IP address format.	where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities:SupervisorChassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
DNS third IPv4 IP	Sets the third IPv4 IP address.	dns -i3 <i>ip_address</i>	-T system:mm[x]
address - set		where <i>ip_address</i> is the third IP address in dotted decimal IP address format.	where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	

Table 29. dns command (continued)

Function	What it does	Command	Valid targets
DNS first IPv6 IP	Sets the first IPv6 IP address.	dns -i61 <i>ip_address</i>	-T system:mm[x]
auuress - set		where <i>ip_address</i> is the first IP address in IPv6 format.	where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
DNS second IPv6 IP	Sets the second IPv6 IP address.	dns -i62 <i>ip_address</i>	-T system:mm[x]
autiess - set		where <i>ip_address</i> is the second IP address in IPv6 format.	where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
DNS third IPv6 IP	Sets the third IPv6 IP address.	dns -i63 <i>ip_address</i>	-T system:mm[x]
auuress - sei		where <i>ip_address</i> is the third IP address in IPv6 format.	where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	

Table 29. dns command (continued)

Function	What it does	Command	Valid targets
DNS server priority - set	Sets the DNS server priority for the	dns -p <i>priority</i>	-T system:mm[x]
	management module to IPv4 or		
	IPv6	where <i>priority</i> is ipv4 or	where <i>x</i> is the primary
		ipv6.	management-module
			bay number.
		This command can only	5
		be run by users who have	
		one or more of the	
		following command	
		authorities:	
		Supervisor	
		Chassis configuration	
		See "Commands and user authority" on page 8 for additional information	

Example: To set the first IP address of the management-module DNS server to 192.168.70.29 and enable DNS on the primary management module that does not have IPv6 support, while management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type

dns -i1 192.168.70.29 -on

To display the DNS status of the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

dns

The following example shows the information that is returned from these two commands:

system:mm[1]> dns -i1 192.168.70.29 -on Changes to the network settings will take effect after the next reset of the MM. system:mm[1]> dns Enabled -i1 192.168.70.29 -i2 0.0.0.0 -i3 0.0.0.0 system:mm[1]>

To display the DNS status of a primary management module that supports IPv6, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

dns

The following example shows the information that is returned from this command: system:mm[1]> dns Enabled =nabled -i1 192.168.70.230 -i2 0.0.00 -i3 0.0.00 -i61 2002:1013::211:25ff:fec3:227d -i62 :: -i63 :: -ddns disabled -p ipv4 system:mm[1]>

env (environment) command

This command sets the persistent environment for commands that are entered during the remainder of the current session.

The persistent command environment is indicated by the command prompt. When you start the command-line interface, the persistent command environment is the BladeCenter unit, denoted as system by the command prompt. You can target a single command to an environment other than the one that is set as the default by adding a -T option to the command that includes a valid target destination (see "Selecting the command target" on page 6 for information). Target environments can be specified using the full path name, or using a partial path name based on the persistent command environment. Full path names always begin with system. The levels in a path name are divided by using a colon (:).

The following table lists BladeCenter components and the command paths that are supported as targets by the env command.

Table 30. Components and command paths

Component	Target path
BladeCenter unit	system
Management module	system:mm[x]
Blade server	system:blade[x]
Blade server integrated system management processor (BMC or service processor)	system:blade[x]:sp
Blade server I/O-expansion card	system:blade[x]:exp[y]
Blade server management card	system:blade[x]:mgmtcrd
Blade server microprocessor	system:blade[x]:cpu[y]
Blade server storage expansion unit	system:blade[x]:be[y]
Blade server high-speed expansion card	system:blade[x]:hsec[y]
Blade server memory	system:blade[x]:memory[y]
Blade server mezzanine for double-width form factor	system:blade[x]:sb
Blade server concurrent KVM feature card	system:blade[x]:ckvm
I/O (switch) module	system:switch[x]
Power module	system:power[x]
Blower	system:blower[x]
Media tray	system:mt[x]
Media tray battery backup unit	system:mt[x]:bbu[y]
Alarm panel (BladeCenter HT only)	system:tap
Multiplexer expansion module (BladeCenter HT only)	system:mux[x]
Network clock module (BladeCenter HT only)	system:ncc[x]
Storage module (BladeCenter S unit only)	system:storage[x]
Storage module disk drive (BladeCenter S unit only)	system:storage[x]:disk[y]

Table 31. env (environment) command

Function	What it does	Command	Valid targets
Set BladeCenter unit as command target	Sets the BladeCenter unit as the persistent target for commands during the current session. This is the persistent command environment you are in at the beginning of each command-line interface session, indicated by the system> prompt.	env env -T system	The env command can be directed to any installed device.
Set management module as command target	Sets the management module as the persistent target for commands during the current session.	env -T system:mm[x] where x is the bay (1 or 2) that identifies the management module.	The env command can be directed to any installed device, in this case -T system:mm[x] where <i>x</i> is the management-module bay number.
Set blade server as command target	Sets the specified blade server as the persistent target for commands during the current session.	env -T system:blade[x] where x is the blade bay that identifies the blade server. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies.	The env command can be directed to any installed device, in this case -T system:blade[x] where x is the blade bay that identifies the blade server.

Table 31. env (environment) command (continued)

Function	What it does	Command	Valid targets
Set blade server sub-component as command target	Sets the specified sub-component on the specified blade server as the persistent target for commands during the current session. Valid sub-components are: • Integrated system management processor (BMC or service processor) • I/O-expansion card • Microprocessor • Storage expansion unit • High-speed expansion card • Memory • Mezzanine assembly for double-width form factor blade servers	 env -T system:blade[x]:comp where x is the blade bay that identifies the blade server on which the sub-component is installed. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies. where comp is the sub-component: sp for BMC or service processor exp[x] for I/O-expansion card (where x identifies the expansion card) cpu[x] for microprocessor (where x identifies the microprocessor) be[x] for storage expansion unit (where x identifies the microprocessor) be[x] for storage expansion unit (where x identifies the expansion unit) ckvm for concurrent KVM feature card hsec[x] for high-speed expansion card) memory[x] for memory (where x identifies the high-speed expansion card) 	The env command can be directed to any installed device, in this case -T system:blade[x]:comp where x is the blade bay that identifies the blade server on which the integrated system management processor is installed. where comp is the sub-component: • sp for BMC or service processor • exp[x] for I/O-expansion card (where x identifies the expansion card) • cpu[x] for microprocessor (where x identifies the microprocessor) • be[x] for storage expansion unit (where x identifies the microprocessor) • be[x] for storage expansion unit (where x identifies the expansion unit) • ckvm for concurrent KVM feature card • hsec[x] for high-speed expansion card (where x identifies the high-speed expansion card) • memory[x] for memory (where x identifies the memory module) • mgmtcrd for management card • sb for mezzanine assembly for double-width form factor blade servers)

Table 31. env (environment) command (continued)

Function	What it does	Command	Valid targets
Set I/O module as command target	Sets the specified I/O module as the persistent target for commands during the current session.	env -T system:switch[x] where x is the I/O-module bay where the I/O module is installed.	The env command can be directed to any installed device, in this case -T system:switch[x] where x is the I/O-module bay where the I/O module is installed.
Set power module as command target	Sets the specified power module as the persistent target for commands during the current session.	env -T system:power[x] where x is the power module bay where the power module is installed.	The env command can be directed to any installed device, in this case -T system:power[x] where x is the power module bay where the power module is installed.
Set blower as command target	Sets the specified blower as the persistent target for commands during the current session.	env -T system:blower[x] where x is the blower bay where the blower is installed.	The env command can be directed to any installed device, in this case -T system:blower[x] where <i>x</i> is the blower bay where the blower is installed.
Set media tray as command target	Sets the media tray as the persistent target for commands during the current session.	env -T system:mt[x] where x is the media-tray bay where the media tray is installed.	The env command can be directed to any installed device, in this case -T system:mt[x] where x is the media-tray bay where the media tray is installed.
Set media tray battery backup unit as command target	Sets the specified battery backup unit on the specified media tray as the persistent target for commands during the current session.	env -T system:mt[x]:bbu[y] where x is the media tray on which the battery backup unit is installed. where y is the battery backup unit number:	The env command can be directed to any installed device, in this case -T system:mt[x]:bbu[y] where x is the media tray on which the battery backup unit is installed. where y is the battery backup unit number:

Function	What it does	Command	Valid targets
Set alarm panel as command target (BladeCenter HT units only)	Sets the alarm panel as the persistent target for commands during the current session.	env -T system:tap	The env command can be directed to any installed device, in this case
Set multiplexer expansion module as command target (BladeCenter HT units only)	Sets the multiplexer expansion module as the persistent target for commands during the current session.	env -T system:mux[x] where x is the multiplexer expansion module number.	The env command can be directed to any installed device, in this case -T system:mux[x] where x is the multiplexer expansion module number.
Set network clock module as command target (BladeCenter HT units only)	Sets the network clock module as the persistent target for commands during the current session.	env -T system:ncc[x] where x is the network clock module number.	The env command can be directed to any installed device, in this case -T system:ncc[x] where <i>x</i> is the network clock module number.
Set storage module as command target (BladeCenter S units only)	Sets the storage module as the persistent target for commands during the current session.	env -T system:storage[x] where x is the storage-module bay where the storage module is installed.	The env command can be directed to any installed device, in this case -T system:storage[x] where x is the storage-module bay where the storage module is installed.
Set storage module disk drive as command target (BladeCenter S units only)	Sets the specified disk drive in the specified storage module as the persistent target for commands during the current session.	env -T system:storage[x]:disk[y] where x is the storage module on which the disk drive is installed. where y is the disk drive number:	The env command can be directed to any installed device, in this case -T system:storage[x]: disk[y] where x is the storage module on which the disk drive is installed. where y is the disk drive number:

Table 31. env (environment) command (continued)

Example: To set the persistent target of commands to the service processor on the blade server in blade bay 5, while the BladeCenter unit is set as the default command target, at the system> prompt, type

```
env -T system:blade[5]:sp
```

```
The following example shows the information that is returned:
system> env -T system:blade[5]:sp
OK
system:blade[5]:sp>
```

To set the persistent target of commands to the service processor on the blade server in blade bay 5, while the BladeCenter unit is set as the default command target, at the system> prompt, you can also type env -T blade[5]:sp

The following example shows the information that is returned: system> env -T blade[5]:sp OK system:blade[5]:sp>

To issue the reset command on the blade server in blade bay 5, while the management module is set as the default command target, at the system:mm[x]> prompt, type reset -T system:blade[5]
ethoverusb command

This command sets and displays the setting for the Ethernet-over-USB command interface of a blade server service processor, for blade servers that support this feature.

Function	What it does	Command	Valid targets
Display blade server Ethernet-over-USB setting	Displays the Ethernet-over-USB command interface setting for the service processor of the specified blade server. Note: This command will execute only on blade servers that support an Ethernet-over-USB command interface for the service processor.	ethoverusb	-T system:blade[x] where <i>x</i> is the blade server bay number.
Set blade server Ethernet-over-USB setting	Enables or disables the Ethernet-over-USB command interface setting for the service processor of the specified blade server. Note: This command will execute only on blade servers that support an Ethernet-over-USB command interface for the service processor.	ethoverusb -s <i>state</i> where <i>state</i> is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration See "Commands and user authority" on page 8 for additional information.	-T system:blade[x] where <i>x</i> is the blade server bay number.

Example: To view the Ethernet-over-USB command interface setting for the service processor of the blade server in bay 2, while this blade server is set as the persistent command environment, at the system:blade[2]> prompt, type ethoverusb

To disable the Ethernet-over-USB command interface setting for the service processor of the blade server in bay 2, while this blade server is set as the persistent command environment, at the system:blade[2]> prompt, type ethoverusb -s disabled

```
system:blade[2]> ethoverusb
enabled
system:blade[2]> ethoverusb -s disabled
OK
system:blade[2]> ethoverusb
disabled
system:blade[2]>
```

eventinfo command

This command displays advanced management module event information and suggested user actions. See the *BladeCenter Advanced Management Module Messages Guide* for a complete list of all non-device specific events and recommended actions, sorted by event ID. Device specific event information is in the documentation for the device.

Table 55. evenunio command	Table 33.	eventinfo	command
----------------------------	-----------	-----------	---------

Function	What it does	Command	Valid targets
Display event description and user action	Displays the event description and suggested user action for the specified event ID.	eventinfo - <i>id</i> where <i>id</i> is the event ID displayed from the "displaylog command" on page 119.	-T system:mm[x] where x is the primary management-module bay number.
		Event IDs are of the form 0x <i>nnnnnnn</i> , where <i>nnnnnnn</i> is a hexadecimal number that identifies the specific event (the 0x prefix is not entered). Leading zeros need not be entered when using the event info command: in this example, specifying an event ID of 00104204, or 104204 would return the same result.	
Display event description	Displays the event description for the specified event ID.	eventinfo - <i>id</i> -d where <i>id</i> is the event ID displayed from the "displaylog command" on page 119. Event IDs are of the form 0x <i>nnnnnnn</i> , where <i>nnnnnnn</i> is a hexadecimal number that identifies the specific event (the 0x prefix is not entered). Leading zeros need not be entered when using the eventinfo command: in this example, specifying an event ID of 00104204, or 104204 would return the same result.	-T system:mm[x] where x is the primary management-module bay number.

Table 33. eventinfo command (continued)

Function	What it does	Command	Valid targets
Display event user action	Displays the suggested user action for the specified event ID.	eventinfo - <i>id</i> -u where <i>id</i> is the event ID displayed from the "displaylog command" on page 119. Event IDs are of the form 0xnnnnnn, where nnnnnnn is a hexadecimal number that identifies the specific event (the 0x prefix is not entered). Leading zeros need not be entered when using the eventinfo command: in this example, specifying an event ID of 00104204, or 104204 would return the same result.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example: To view the event description and suggested user action for an event with an ID of 0x00104204, while the BladeCenter unit is set as the persistent command environment, at the system:> prompt, type eventinfo -T mm[1] -00104204

The following example shows the information that is returned from this command:

system> eventinfo -T mm[1] -00104204 Event Description: The primary advanced management module was reset. Recommended Action: Information only; no action is required. system>

events command

This command manages the Call Home events exclusion list for the advanced management module.

Table 34.	events	command
-----------	--------	---------

Function	What it does	Command	Valid targets
Display Call Home events list and free space	Displays a list of Call Home event IDs that will not be reported by the Call Home feature, and how many more events can be added to this Call Home events exclusion list. This Call Home exclusion list allows a maximum of 20 events.	 events -che This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management Chassis log management Chassis configuration Blade administration Blade configuration Blade remote presence I/O module administration I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Add a Call Home event to the Call Home Exclusion list	Adds a Call Home event to the Call Home exclusion list. Events on this list are specified by an event ID, and are not included in the Call Home reports. Note: The Service Advisor terms and conditions must first be accepted, or the Automated FTP/TFTP Report of Service Data must be enabled before using this command.	 events -che -add event_ID where event_ID is an eight-digit hexadecimal number with an optional prefix of 0x or 0X. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 34. events command (continued)

Function	What it does	Command	Valid targets
Function Remove a Call Home event from the Call Home Exclusion list	What it does Removes a Call Home event from the Call Home exclusion list. Events removed from this list are included in the Call Home reports. Note: The Service Advisor terms and conditions must first be accepted, or the Automated FTP/TFTP Report of Service Data must be enabled before using this command.	Command events -che -rm <i>event_ID</i> where <i>event_ID</i> is • an eight-digit hexadecimal number with an optional prefix of 0x or 0X to remove a single Call Home event • all to remove all the Call Home events from the exclusion list This command can only	Valid targets -T system:mm[x] where <i>x</i> is the primary management-module bay number.
		 be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	

Example: To view the Call Home exclusion list and the number of remaining events can be added to the list, while the BladeCenter unit is set as the persistent command environment, at the system:> prompt, type events -T mm[1] -che

To add Call Home event number 0x00020003 to the Call Home exclusion list, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

events -T mm[1] -che -add 0x00020003

To remove Call Home event number 0x00020001 from the Call Home exclusion list, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

events -T mm[1] -che -rm 0x00020001

```
system> events -T mm[1] -che
A maximum of 20 events can be added to this exclusion list, currently
18 more events can be added.
Call Home Exclusion List is illustrated as follows:
           Event ID
Index
1
            0x00020001
2
            0x00020002
system> events -T mm[1] -che -add 0x00020003
0K
system> events -T mm[1] -che
A maximum of 20 events can be added to this exclusion list, currently
17 more events can be added.
Call Home Exclusion List is illustrated as follows:
Index
           Event ID
            0x00020001
1
 2
            0x00020002
```

```
3 0x00020003

system> events -T mm[1] -che -rm 0x00020001

OK

system> events -T mm[1] -che

A maximum of 20 events can be added to this exclusion list, currently

18 more events can be added.

Call Home Exclusion List is illustrated as follows:

Index Event ID

1 0x00020002

2 0x00020003

system>
```

exit command

This command exits the command-line interface, terminating the current session.

Table 35. exit command

Function	What it does	Command	Valid targets
Exit	Terminates the current command-line interface session.	exit Note: You can also use the Ctrl-D key combination to end the current session and exit the command-line interface.	Any installed device.

Example: To terminate the current command-line interface session, type exit

feature command

This command manages licensing for advanced features for the advanced management module.

Table 36.	feature	command
-----------	---------	---------

Function	What it does	Command	Valid targets
Display feature list and license status	Displays a list of advanced features for the management module and their licensing status.	feature	-T system:mm[x] where x is the primary management-module bay number.
Add a feature license	Adds a license for a management module advanced feature. Features on this list are specified using the feature index number that appears at the left of the feature list.	 feature -index -add -key lisc_key where: index is the number for the feature at the left of the feature list displayed by the feature command. lisc_key is the 7-character part number of the feature. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Remove a feature license	Removes a license for a management module advanced feature. Features on this list are specified using the feature index number that appears at the left of the feature list.	 feature <i>-index</i> -remove where <i>index</i> is the number for the feature at the left of the feature list displayed by the feature command. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 36. feature command (continued)

Function	What it does	Command	Valid targets
Import datacenter feature licenses	Import a datacenter feature licensing file for use by the BladeCenter unit. The file name to import must specify a qualified location for the licensing file that indicates the protocol to be used. For example, tftp://192.168.0.1/license.csv	feature -apply file_location where file_location is a qualified location for the license file of up to 256 characters in length that indicates the protocol to be used (tftp, ftp, ftps, http, or https) and contains any character except the percent sign ($\%$) or double-quote (\triangle). This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis administration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Export datacenter feature licenses	Export a BladeCenter feature licensing file for use by other BladeCenter units in the datacenter. The file name to export must specify a qualified location for the licensing file that indicates the protocol to be used. For example, tftp://192.168.0.1/license.csv Note: While the licensing file is exporting, a string of periods will display on the screen to indicate progress; a new period being added every three seconds.	feature -retrieve file_location where file_location is a qualified location for the license file of up to 256 characters in length that indicates the protocol to be used (tftp, ftp, ftps, http, or https) and contains any character except the percent sign ($\%$) or double-quote (\triangle). This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis administration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.

Example: To view the feature list, while the BladeCenter unit is set as the persistent command environment, at the system:> prompt, type feature -T mm[1]

To remove the license for the first feature in the list, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type feature -T mm[1] -1 -remove

To export a licensing file to the location tftp://10.11.20.23/IBMtest.csv, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

```
feature -retrieve -T mm[1] tftp://10.11.20.23/IBMtest.csv
```

```
system> feature -T mm[1]
1. IBM BladeCenter Open Fabric Manager
-serial 2304369
License Status: Active
system> feature -T mm[1] -1 -remove
OK
system> feature -T mm[1]
1. IBM BladeCenter Open Fabric Manager
License Status: No License
system> feature -retrieve -T mm[1] tftp://10.11.20.23/IBMtest.csv
....
OK
system>
```

files command

This command manages files uploaded to the advanced management module.

Function	What it does	Command	Valid targets
Display file list and free space	Displays a list of files and space remaining in the advanced management module file system.	files	-T system:mm[x] where x is the primary management-module bay number.
Delete file	Deletes a file from the advanced management module file system. Note: This command can only be used to delete files: it will not delete directories.	files -d <i>filename</i> where <i>filename</i> is a valid, existing filename of less than 256 characters in length. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis administration • Blade administration • Blade configuration • I/O module administration • I/O module configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.

Table 37. files command

Example: To view the files and remaining space in the management module file system, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type files

To delete the file tftproot/tftp_file.pkt from the management module file system, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type files -d tftproot/tftp file.pkt The following example shows the information that is returned from these commands:

system:mm[1]> files

12288 Thu Jan 05 13:28:23 2006 lost+found/ 1024 Thu Jul 06 19:32:51 2006 tftproot/ 1024 Thu Jul 06 19:34:15 2006 tftproot/manu/ 1024 Thu Jul 06 19:34:15 2006 tftproot/manu/manu2/ 0 Sat Aug 19 09:22:02 2006 tftproot/tftp_file.pkt 0 Sun Oct 01 07:57:19 2006 tftproot/.Do_not_delete_this_directory 0 Tue Dec 15 11:07:19 2009 test 0 Thu Apr 13 23:45:40 2006 bob.pkt 1024 Tue Feb 02 15:29:17 2010 pubkeys/ 426 Tue Feb 02 15:29:17 2010 pubkeys/ssh_key.pub 5652 Fri May 12 00:56:36 2006 asm.cfg Total space: 73108480 bytes Used: 24576 bytes Available: 73083904 bytes system:mm[1]> files -d tftproot/tftp_file.pkt 0K system:mm[1]>

fuelg command

This command displays power domain information, listing the power modules that are installed in the BladeCenter unit and information about how the power in each domain is used. This command also configures the power domain policies for power redundancy loss and limiting fan noise during thermal events.

Note: For scripting purposes, the -qm and -os fuelg options for management modules other than the advanced management module are supported by the advanced management module.

Table 38. fuelg command

Function	on What it does Command Va		Valid targets
Display power domain status overview	Displays health status, total power usage, total dc power available, total ac power in use, thermal response (acoustic mode) settings, total thermal output in BTU/hour, and the polling intervals used for trending for all power domains. Note: For the BladeCenter S unit, output will indicate whether the chassis is running in 220 V ac or 110 V ac mode.	fuelg	-T system
Display blade server power status overview	 Displays the power management and capping setting (on/off) and power management capability for the specified blade server. Depending on the power management capability of the specified blade server, the following information will also display: CPU duty cycles Effective and maximum CPU speeds Power capping value (minimum and maximum) Maximum, minimum, and average power levels Time when above data was captured Power saver mode status (on, off) 	fuelg	-T system:blade[x] where x is the blade-server bay number.
Display I/O module power status	Displays the maximum, minimum, and average power information for the specified I/O module.	fuelg	-T system:switch[x] where x is the I/O-module bay number.
Display blower power status and temperature	Displays the maximum power, minimum power, average power, and current temperature information for the specified blower module.	fuelg	-T system:blower[x] where x is the blower bay number.
Display media tray temperature	Displays the current temperature for the specified media tray.	fuelg	-T system:mt[x] where x is the media tray number.

Table 38. fuelg command (continued)

Function	What it does	Command	Valid targets
Display detailed power domain status	 Displays detailed status and usage information for the specified power domains, including the policy setting for that domain, the maximum power limit, and the power in use. The valid states for components in the domain are: * - blade server might throttle C - communication error D - discovering Hib - hibernate NP - module is not present SB - standby T - throttled U - unable to power up Note: For the BladeCenter S, output will indicate whether the chassis is running in 220 V ac or 110 V ac mode. 	 fuelg <i>domain</i> where <i>domain</i> is: pd1 for power domain 1. pd2 for power domain 2. If no <i>domain</i> is specified, a status overview for all power domains displays. Note: The BladeCenter S unit has only one power domain. Use either pd or pd1 to specify the power domain for the BladeCenter S unit. 	-T system

Table 38. fuelg command (continued)

Function	What it does	Command	Valid targets
Set power domain redundancy loss policy	Sets how the BladeCenter unit responds to a condition that could cause a loss of redundant pow Note: For the BladeCenter S, output will indicate whether the chassis is running in 220 V or 110 V ac mode.er.	 fuelg domain -pm policy where: domain is: pd1 for power domain nd2 for power domain pd2 for power domain pd2 for power domain pd2 for power domain nd0 domain is specified, the policy is applied to all power domains. policy of: nonred (default) allows loss of redundancy. redwoperf prevents components from turning on that will cause loss of power redundancy. redwperf power throttles components to maintain power redundancy and prevents components from turning on that will cause loss of power redundancy and prevents components from turning on that will cause loss of power redundancy. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system
Display power trending for specified time period and power domain	Displays power trending information for the selected time interval and selected power domain for the BladeCenter unit.	 fuelg domain -pt period where: domain is: pd1 for power domain 1. pd2 for power domain 2. If no domain is specified, the period is applied to all power domains. period is 1, 6, 12, or 24 hours. 	-T system

Table 38. fuelg command (continued)

Function	What it does	Command	Valid targets
Display power trending for specified time period	Displays power trending information for the selected time interval for the specified command target.	fuelg -pt <i>period</i> where <i>period</i> is 1, 6, 12, or 24 hours.	<pre>-T system -T system:blade[x] -T system:switch[x] -T system:blower[x] where x is the blade server, I/O module, or blower bay number.</pre>
Set power polling interval	Sets the amount of time between thermal and power samples that are taken to build trending data.	 fuelg -int <i>interval</i> where <i>interval</i> is between 10 and 60 minutes, inclusive, in 5-minute increments. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system
Display thermal trending for specified time period	Displays thermal trending information for the selected time interval for the specified command target.	fuelg -tt <i>period</i> where <i>period</i> is 1, 6, 12, or 24 hours.	-T system:mt[x] -T system:blower[x] where x is the blade server or blower bay number.

Function	What it does	Command	Valid targets
Thermal event response (acoustic mode)	Sets the acoustic mode of BladeCenter-unit blowers response to thermal events.	 fuelg -am setting where the acoustic-mode setting of: off (default) allows blowers to increase speed to provide additional cooling. on keeps blowers at a fixed speed and power throttles BladeCenter components to reduce power consumption (only for BladeCenter components that support power throttling). 	-T system
		 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for 	
Thermal event response (Telco environment)	Sets the Telco environment of the BladeCenter-unit blowers response to thermal events. Note: When the environment mode is set to nebs, the -am mode is automatically turned off.	 additional information. fuelg -e environment where the thermal-event response environment of: nebs allows blowers to increase speed to provide additional cooling. enterprise allows acoustic mode. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system

Table 38. fuelg command (continued)

Table 38. fuelg command (continued)

Function	What it does	Command	Valid targets
Set power capping value for blade server	Sets the power capping value for a specified blade server that support this feature. Note: A blade server must be turned on before you can set its power capping value.	fuelg -pcap <i>setting</i> where the power capping <i>setting</i> is a numeric value that falls within the range of power capping values displayed when running the fuelg -T blade[x] command on a blade server.	-T system:blade[x] where x is the blade-server bay number.
		This command can only be run by users who have one or more of the following command authorities:SupervisorChassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Power management and capping - enable or disable for blade server	Turns power management and capping for the specified blade server on or off. Note: A blade server must be turned on before you can enable power management and capping for it.	 fuelg -pme setting where a setting of: off (default) disables power management and capping for the blade server. on enables power management and capping for the blade server. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system:blade[x] where x is the blade-server bay number.
		See "Commands and user authority" on page 8 for additional information.	

Table 38. fuelg command (continued)

Function	What it does	Command	Valid targets
Static low power saver mode - enable or disable for blade server	 Turns the static low power saver mode for the specified blade server on or off. Notes: A blade server must be turned on before you can enable power saver mode for it. Not all blade servers support the power saver mode. 	 fuelg -ps setting where a setting of: off (default) disables power saver mode for the blade server. on enables power saver mode for the blade server. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade-server bay number.
Dynamic power optimizer - enable or disable for blade server	 Turns dynamic power optimizer for the specified blade server on or off. Notes: A blade server must be turned on before you can enable dynamic power optimizer for it. Not all blade servers support the dynamic power optimizer. 	 fuelg -dps setting where a setting of: off (default) disables dynamic power optimizer for the blade server. on enables dynamic power optimizer for the blade server. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.

Table 38. fuelg command (continued)

Function	What it does	Command	Valid targets
Favor performance over power - enable or disable for blade server	 Turns the favor performance over power feature on or off for the specified blade server. Notes: A blade server must be turned on before you can enable the favor performance over power feature for it. Not all blade servers support the favor performance over power feature. This feature can only be active if the dynamic power optimizer is enabled. 	 fuelg - fpop setting where a setting of: off (default) disables favor performance over power for the blade server. on enables favor performance over power for the blade server. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade-server bay number.

Example: To view a power domain status overview, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type fuelg

To view the detailed power domain status for power domain 1, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

fuelg pd1

To view BladeCenter unit power trending information for the past 6 hours, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

fuelg -pt 6

To view the power status for the blade server in blade bay 1, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

fuelg -T blade[1]

The following example shows the information that is returned from these commands when the fuelg command is run on an advanced management module.

system> fuelg
Note: All power values are displayed in Watts.

Bay 2: 3160 Power Management Policy: Basic Power Management Power in Use: 1313 (+/- 16.0%) Total Power: 4000 Allocated Power (Max): 1423 Remaining Power: 2577 Power Domain 2 _____ Status: Power domain status is good. Modules: Bay 3: 2880 Bay 4: 2880 Power Management Policy: Basic Power Management Power in Use: 73 (+/- 16.0%) Total Power: 4000 Allocated Power (Max): 1082 Remaining Power: 2918 -am on -e enterprise -int 10 system> fuelg pd1 Maximum Power Limit: 1450 856 Power In Use: Power -- Allocated Power --State Current Max Min Bay(s) Module Chassis Components Midplane 0n 10 10 10 1 Media Tray 1 0n 10 10 10 Chassis Cooling Devices 1 Chassis Cooling Device 1 0n 11 68 68 2 Chassis Cooling Device 2 3 Chassis Cooling Device 3 0n 11 68 68 0n 11 68 68 4 Chassis Cooling Device 4 0n 11 68 68 Power Module Cooling Devices 1 PM Cooling Device 1 0n 10 10 10 2 PM Cooling Device 2 10 0n 10 10 3 PM Cooling Device 3 0n 10 10 10 4 PM Cooling Device 4 (NP) 0 10 10 Storage 1 Storage Module 1 (NP) 0 120 120 2 Storage Module 2 0n 0 100 100 Management Module 1 SN#YK168082H25F 0n 25 25 25 I/O Modules 1 Ethernet SM 0n 45 45 45 2 Ethernet SM 0n 45 45 45 3 I/O Module 3 (NP) 0 45 45 4 Server Conn Mod 0n 45 45 45 Blades 1 Maui A 0n 236 236 236 (100%, 100%, 100%, 100%)LewisA1-LS21 (T) (CA) 71 2 0n 75 75 3 Lucas 55 (T) (CA) 0n 66 76 76 4 Mongoose-2 (T) (CA) 0n 108 127 121 5 Crichton8 (T) (CA) 0n 99 109 108 6 Mongoose-3 (T) (CA) 0n 142 34 34 Domain totals: Allocated Power 856 1414 1407 Note: (T) means "throttled", (U) means "unable to power up",

* means "the blade may throttle", (NP) means "the module is not present",

(D) means "discovering", (C) means "comm error", (SB) means "Standby"

(CA) means "capped max power allocation"

-pm nonred

system> [.] Date	fuelg -pt Time	6 Avg Pwr			
07/17/07	08:09:44	2930			
07/17/07	08:24:44	2926			
07/17/07	08:39:48	2916			
07/17/07	08:54:44	2906			
07/17/07	09:09:44	2922			
07/17/07	09:24:44	2926			
07/17/07	09:39:44	2926			
07/17/07	09:54:44	2926			
07/17/07	10:09:44	2914			
07/17/07	10:24:44	2928			
07/17/07	10:39:48	2930			
07/17/07	10:54:44	2914			
0//1//0/	11:09:43	2/62			
0//1//0/	11:24:44	2924			
0//1//0/	11:39:44	2926			
0//1//0/	11:54:44	2932			
0//1//0/	12:09:44	2928			
07/17/07	12:24:44	2922			
07/17/07	12:39:43	2/02			
07/17/07	12:04:43	2770			
07/17/07	12.24.44	2776			
07/17/07	13:24:44	2768			
07/17/07	12.59.44	2/00			
0//1//0/	13:34:47	2920			
system> ·	fuelg -T l	blade[1]			
-pme off					
PM Capab	ility: Dy	namic Pow	er Measurement	with	capping
Effective	e CPU Spe	ed: 2955	MHZ		
Maximum (LPU Speed	: 3000 MH	Z		
-pcap 190) (min: 1	/4, max:	280)		
Maximum I	Power: 2.	35 20			
Munnamum I	ower: 1	99 26			
Average I	rower: 2.	33 37/17/07	12.50.05		
Data Capi	lurea at (9//1//0/	13:39:05		
system					

groups command

This command displays and configures Active Directory groups of the primary management module. This group information is used only when LDAP servers are enabled for authentication with local authorization.

Table 39. groups (Active Directory groups) command

Function	What it does	Command	Valid targets
Display all Active Directory groups	Displays all Active Directory groups, up to 16, configured for the BladeCenter unit.	groups	-T system:mm[x] where x is the primary management-module bay number.
Display specific Active Directory group	Displays information for the specified Active Directory group.	groups <i>-group_num</i> where <i>group_num</i> is a number from 1 to 16, inclusive, that identifies the Active Directory group.	-T system:mm[x] where x is the primary management-module bay number.
Set Active Directory group name	Sets a name for the specified Active Directory group.	 groups -group_num -n group_name where: group_num is a number from 1 to 16, inclusive, that identifies the Active Directory group. group_name is a alphanumeric string up to 63 characters in length that can include periods (.) and underscores (_). Each of the 16 group names must be unique. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Function	What it does	Command	Valid targets
Set Active Directory group authority level	Sets the authority level for the specified Active Directory group.	<pre>groups -group_num -a group_authority where: • group_num is a number from 1 to 16, inclusive, that identifies the Active Directory group. • group_authority uses the following syntax: - operator (Operator) - rbs:levels:scope where the levels are one or more of the following authority levels, separated by a vertical bar (): - super (Supervisor) - cam (Chassis User Account Management) - clm (Chassis Log Management) - co (Chassis Operator) - cc (Chassis Configuration) - ca (Chassis Administration) - bo (Blade Operator) - brp (Blade Remote Present) - bc (Blade Configuration) - ba (Blade Administration) - ba (Chasis Configuration) - ba (Chasis Administration) - ba (Chase Remote Present) - bc (Chase Remote Present) - bc (Chase Remote Present) - bc (Chase Remote Present) - bc (Chase Remote Present) - ba (Chase Remote Present) - ba</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 39. groups (Active Directory groups) command (continued)

Function	What it does	Command	Valid targets
Set Active Directory group authority level (continued)		 where the <i>scope</i> is one or more of the following devices, separated by a vertical bar (). Ranges of devices are separated by a dash (-). <i>cn</i> (Chassis <i>n</i>, where <i>n</i> is 1 for the Active Directory environment.) <i>bn</i> (Blade <i>n</i>, where <i>n</i> is a valid blade bay number in the chassis) <i>sn</i> (I/O module <i>n</i>, where <i>n</i> is a valid I/O module bay number in the chassis) This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	
Delete Active Directory group	Delete the specified Active Directory group.	groups -group_num -clear where group_num is a number from 1 to 16, inclusive, that identifies the Active Directory group. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 39. groups (Active Directory groups) command (continued)

Example: To create Active Directory group number 3 with a group name of group3 that has supervisor rights to all BladeCenter components, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

groups -3 -n group3 -a rbs:super:c1|b1-b14|s1-s4

To display information for group3, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type groups -3

```
system:mm[1]> groups -3 -n group3 -a rbs:super:c1|b1-b14|s1-s4
OK
system:mm[1]> groups -3
-n group3
-a Role:supervisor
Blades:1|2|3|4|5|6|7|8|9|10|11|12|13|14
Chassis:1
Modules:1|2|3|4
system:mm[1]>
```

health command

This command displays the current health status of the command target. It can also be used to display the alerts that are active for the command target.

You can only specify one command target each time you run the health command.

Table 40. health command

Function	What it does	Command	Valid targets
Display health status	 Displays the current health status of the command target. Return values are different for the BladeCenter and BladeCenter T configurations. Possible return values for the BladeCenter configuration are: ok warning critical Possible return values for the BladeCenter T configurations are: ok marning critical Possible return values for the BladeCenter T configurations are: ok minor major critical 	health	 T system T system:mm[x] T system:blade[x] T system:switch[x] T system:power[x] T system:blower[x] T system:storagex] (for BladeCenter S units) where x is the primary management-module, blade server, I/O module, power module, blower bay, or storage bay number.
Display health status for tree	Displays the current health status of the tree structure of devices present in the BladeCenter unit, starting at the command target level. If management-module bays are part of the tree, they will be identified as primary or standby (redundant). Return values are different for the BladeCenter and BladeCenter T configurations. • Possible return values for the BladeCenter configuration are: - ok - warning - critical • Possible return values for the BladeCenter T configurations are: - ok - minor - major - critical	 health -1 <i>depth</i> where <i>depth</i> 1 displays health status of the current command target 2, all, or a displays a full tree display, starting at the command target level 	 -T system -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.

Table 40. health command (continued)

Function	What it does	Command	Valid targets
Display health status and alerts	 Displays the current health status and active alerts for the command target. Return values are different for the BladeCenter and BladeCenter T configurations. Possible return values for the health status of the BladeCenter configuration are: ok warning critical Possible return values for the health status of the BladeCenter T configuration are: ok warning critical Possible return values for the health status of the BladeCenter T configurations are: ok minor major critical Active alert information provides short text descriptions of alerts that are active for each monitored component. The total amount of information returned from the health -f command is limited to 1024 bytes. 	health -f	-T system -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.
Display results with timestamp (BladeCenter E units only)	Adds display of timestamp information to status command output.	health -t Note: The -t option must be used with the -f option.	 -T system -T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x] where x is the primary management-module, blade server, I/O module, power module, or blower bay number.

Example: To display the overall health status of the BladeCenter T unit, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

health

To display the health status of all components installed in the BladeCenter T unit, that are valid command targets, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

health -l a

To display the health status of the blade server installed in blade bay 5, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

health -T system:blade[5]

To display the health status and alerts for all components installed in the BladeCenter T unit, that are valid command targets, while the BladeCenter T unit is set as the default command target, at the system> prompt, type health -l a -f

```
system> health
system:major
system> health -l a
system: Major
         mm[1]
                   :
                              0K
        blade[1] :
                              0K
        blade[3] :
                              0K
                              Minor
        blade[5] :
         power[1]
                              0K
                  :
         power[2]
                              Minor
                  :
         blower[1] :
                              0K
         blower[2] :
                              0K
         blower[3] :
                              0K
         blower[4] :
                              0K
         switch[1] :
                              Major
system> health -T system:blade[5]
system: blade[5] :
                              Minor
system> health -l a -f
system: Major
        blade[5] :
                              Minor
          5V over voltage
          CPU1 temperature warning
         power[2] :
                              Minor
          5V over voltage
         switch[1] :
                              Major
          temperature fault
system>
```

help command

This command displays a list of all commands that are available in the command-line interface with a brief description of each command.

You can also issue the help command by typing ?. Adding a -h, -help, or ? option to a command displays syntax help for the command.

Table 41. help command

Function	What it does	Command	Valid targets
Help	Displays a list of commands and a	help	Any installed device.
	brief description of each command.	?	Any installed device.

Example: To display a list of commands, while the advanced management module in bay 1 is set as the default command target, at the system:mm[1]> prompt, type help

The following example shows the information that is returned:

system> help	
?	 Display commands
accseccfg	 View/edit account security config
advfailover	 View/edit advanced failover mode
alertcfg	 Displays/Configures the global remote alert settings
alertentries	 View/edit remote alert recipients
autoftp	 View/Edit auto ftp/tftp setting
baydata	 View/edit Blade Bay Data string
bofm	 Apply new BOFM configuration
boot	 Boot target
bootmode	 Boot mode
bootseq	 View/edit the blade boot sequence settings
buildidcfg	 View/Edit the Blade Firmware Build ID List
chconfig	 View/edit Service Advisor Settings
chlog	 Display Service Advisor Activity Log entires
chmanual	 Manually generate call home request
cin	 Displays/Configures Chassis Internal Network
cinstatus	 Displays Status of Chassis Internal Network
clear	 Clear the config
clearlog	 Clear the event log
clock	 View/edit date, time, GMT offset, and dst setting
config	 View/edit general settings
console	 Start SOL session to a blade
dhcpinfo	 View DHCP server assigned settings
displaylog	 Display log entries
displaysd	 Display service data
dns	 View/edit DNS config
env	 Set persistent command target
ethoverusb	 View/edit the status of a blade SP's interface on Ethernet-over-USB
eventinfo	 Display event description and user action
events	 View/edit Events config
exit	 Log off
feature	 View/edit licensed features
files	 Displays and deletes files stored on the AMM
fuelg	 Power management
groups	 View/edit Active Directory groups
health	 View system health status
help	 Display command list
history	 Display command history
identify	 Control target location LED
ifconfig	 View/edit network interface config
info	 Display identity and config of target
iocomp	 View I/O compatibility for blades and switches
kvm	 Controls the kvm owner

ldapcfg -- View/edit LDAP config led -- Display and control Leds list -- Display installed targets mcad -- Displays and configures MCAD modactlog -- Displays module activity log monalerts -- Displays and configures monitored alerts mt -- Controls the media tray owner nat -- Display and configure NAT ntp -- View/edit NTP config ping -- Pings targeted switch module pmpolicy -- View/edit power management policy settings portcfg -- Serial port configuration ports -- Port configuration power -- Control target power rdoc -- Controls the remote DiskOnCard read -- Restore configuration from the chassis or a file remotechassis -- Chassis discovered over the network reset -- Reset target scale -- Display and configure the settings of scalable complexes sddump -- Initiate service data dump sdemail -- Send service information using email security -- View/edit security config service -- Enable debugging by service personnel shutdown -- Shutdown target slp -- View/edit SLP parameters smtp -- View/edit SMTP config snmp -- View/edit SNMP config sol -- View SOL status and view/edit SOL config sshcfg -- View/edit SSH config sslcfg -- View/edit SSL config syslog -- View/edit syslog config tcpcmdmode -- View/edit TCP command mode config telnetcfg -- View/edit telnet config temps -- View temperatures trespass -- View/edit trespassing warning config uicfg -- View/edit user interface configuration update -- Update firmware from remote location uplink -- View/edit failover on network uplink loss config users -- View/edit user login profiles volts -- View voltages write -- Save configuration to chassis or a local file zonecfg -- Zone configuration for I/O modules Type "Type "<command> -h" for individual command syntax help. [] is used for indexing (by bay number) < > denotes a variable { } denotes optional arguments denotes choice system>

To obtain help about the env command, type one of the following commands:

env -h

- env -help
- env ?

history command

This command displays the last eight commands that were entered, allowing the user to choose and re-enter one of these commands.

You choose the command to re-enter from the displayed list by typing an exclamation point (!) followed immediately by the numeric designation the command is assigned in the list. You can also recall one of the past eight previously entered commands using the up-arrow and down-arrow keys.

Table 42. history command

Function	What it does	Command	Valid targets
Command history	Displays the last eight commands that were entered.	history	Any installed device.
Re-enter previous command using numeric designation	Re-enters a numerically-specified command from the command history.	! <i>x</i> where <i>x</i> is the number of the command (0 - 7) to re-enter from the command history list.	Any installed device.

Example: To display a list of the last eight commands entered, while management module 1 is set as the default command target, at the system:mm[1]> prompt, type history

To re-enter the command designated by "2" in the command history, type 12

```
system:mm[1]> history
0 dns
1 dns -on
2 dns
3 dns -i1 192.168.70.29
4 dns
5 dns -i1 192.168.70.29 -on
6 dns
7 history
system:mm[1]> !2
Enabled
-i1 192.168.70.29
-i2 0.0.0.0
-i3 0.0.0.0
system:mm[1]>
```

identify (location LED) command

This command controls operation of the location LED in a blade server or in the BladeCenter unit. It can also be used to display the state of a location LED.

Table 43. identify (location LED) command

Function	What it does	Command	Valid targets
Display location LED state	Displays the current state of the location LED in the command target. Possible LED states are: • off • on • blink	identify	-T system -T system:blade[x] where <i>x</i> is the blade bay number.
Set location LED state	Sets the state of the location LED in the command target.	 identify -s state where state is on off blink This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration (for BladeCenter unit) Blade configuration (for blade server) See "Commands and user authority" on page 8 for additional information. 	-T system -T system:blade[x] where <i>x</i> is the blade bay number.
Turn on BladeCenter unit location LED for specified period of time	Turns on the location LED in the BladeCenter unit for a specified period of time before turning it off automatically.	<pre>identify -s on -d time where time is the number of seconds the location LED will remain lit. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system

Example: To display the status of the location LED in the blade server in blade bay 4, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

```
identify -T system:blade[4]
```

To light the location LED in the blade server in blade bay 4, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type identify -s on -T system:blade[4]

The following example shows the information that is returned from a series of identify commands:

```
system> identify -T system:blade[4]
-s off
system> identify -s on -T system:blade[4]
OK
system> identify -T system:blade[4]
-s on
system>
```

ifconfig command

This command configures and displays the network interface settings for the management-module Ethernet interface, I/O-module Ethernet interface, and the blade server integrated system management processors and installed options.

Function	What it does	Command	Valid targets
Display primary management module Ethernet channel 0 configuration	Displays the current configuration of Ethernet channel 0 for the primary management module. Possible return values are: • enabled • disabled • -i static_ip_address (dotted decimal IPv4 IP address format) • -g gateway_address (dotted decimal IPv4 IP address format) • -s subnet_mask (dotted decimal IPv4 IP address format) • -s subnet_mask (dotted decimal IPv4 IP address format) • -n hostname • -c config_method • -r data_rate • -d duplex_mode • -m mtu • -l locally_administered_mac_addr • -b burnedin_mac_address • -dn domain_name • -ipv6 ipv6_state • -i6 static_ip_address (IPv6 format) • -p6 address_prefix_length • -g6 gateway-default_route • -dhcp6 dhcpv6_state • -sa6 ipv6_stateless_autoconfig_state If IPv6 is enabled, the link-local address link_local_address (for IPv6 connection) also displays. If IPv6 and stateless auto-configuration (-sa6) are both enabled, the Stateless auto-config IP Addresses / Prefix Length address_table (table listing auto-generated IPv6 addresses and their prefix lengths) also displays.	ifconfig -eth0	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 44. ifconfig command

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Display standby	Displays the current configuration	ifconfig -eth0 -o	-T system:mm[x]
management module	of Ethernet channel 0 for the		
Ethernet channel 0	standby management module.		where <i>x</i> is the primary
configuration	Note: This option does not apply		management-module
	to the BladeCenter S unit.Possible		bay number.
	return values are:		Note: Even though
	• enabled		this command displays
	• disabled		information for the
	• -i <i>static_ip_address</i> (dotted		standby management
	decimal IPv4 IP address format)		module, it still must
	• -g gateway_address (dotted		specify the primary
	decimal IPv4 IP address format)		management module
	• -s subnet_mask (dotted decimal		as the command target.
	IPv4 IP address format)		
	• -n nostname		
	- C config_method		
	• -r uuu_rute • d dunlar mode		
	• -m mtu		
	 -11 mu -1 locally administered mac addr 		
	 -b hurnedin mac address 		
	-dn domain name		
	 -ipv6 ipv6 state 		
	• -ipv6static <i>static ipv6 state</i>		
	• -i6 <i>static_ip_address</i> (IPv6 format)		
	• -p6 address_prefix_length		
	• -g6 gateway-default_route		
	-dhcp6 dhcpv6_state		
	• -sa6 ipv6_stateless_autoconfig_state		
	If IPv6 is enabled, the link-local		
	address <i>link_local_address</i> (for IPv6		
	connection) also displays.		
	If IPv6 and stateless		
	auto-configuration (-sa6) are both		
	enabled, the Stateless auto-config IP		
	Addresses / Prefix Length		
	address_table (table listing		
	auto-generated IPv6 addresses and		
	their prefix lengths) also displays.		
Function	What it does	Command	Valid targets
---	--	---	---
Set management module Ethernet channel 0 static IP address (IPv4)	Sets the IPv4 static IP address for Ethernet channel 0 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.	<pre>ifconfig -eth0 -i ip_address where ip_address is the static IP address for Ethernet channel 0 in dotted decimal IP address format.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		authority" on page 8 for additional information.	
Set management module Ethernet channel 0 static IP address (IPv6)	Sets the IPv6 static IP address for Ethernet channel 0 for the management module.	<pre>ifconfig -eth0 -i6 ip_address where ip_address is the static IP address for Ethernet channel 0 in IPv6 format. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set standby management module Ethernet channel 0 static IP address (IPv4)	Sets the IPv4 static IP address for Ethernet channel 0 for the standby management module. Note: This option does not apply to the BladeCenter S unit.	<pre>ifconfig -eth0 -o -i ip_address where ip_address is the static IP address for Ethernet channel 0 in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number. Note: Even though this command displays information for the standby management module, it still must specify the primary management module as the command target.

Table 44.	ifconfig	command	(continued)
-----------	----------	---------	-------------

Function	What it does	Command	Valid targets
Set standby management module Ethernet channel 0 static IP address (IPv6)	Sets the IPv6 static IP address for Ethernet channel 0 for the standby management module. Note: This option does not apply to the BladeCenter S unit.	<pre>ifconfig -eth0 -o -i6 ip_address where ip_address is the static IP address for Ethernet channel 0 in IPv6 format. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for</pre>	-T system:mm[x] where x is the primary management-module bay number. Note: Even though this command displays information for the standby management module, it still must specify the primary management module as the command target.
Set management module Ethernet channel 0 gateway IP address (IPv4)	Sets the IPv4 gateway IP address for Ethernet channel 0 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.	additional information. ifconfig -eth0 -g <i>ip_address</i> where <i>ip_address</i> is the gateway IP address for Ethernet channel 0 in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.
Set management module Ethernet channel 0 gateway/default route (IPv6)	Sets the IPv6 gateway/default route for Ethernet channel 0 for the management module.	<pre>ifconfig -eth0 -g6 ip_address where ip_address is the gateway/default route for Ethernet channel 0 in IPv6 format. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set management module Ethernet channel 0 subnet mask (IPv4)	Sets the IPv4 subnet mask for Ethernet channel 0 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.	<pre>ifconfig -eth0 -s sub_mask where sub_mask is the subnet mask for Ethernet channel 0 in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management module Ethernet channel 0 hostname	Sets the host name for Ethernet channel 0 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.	 ifconfig -eth0 -n hostname where hostname is the host name for Ethernet channel 0. The hostname can be a string up to 63 characters in length that includes alphanumeric characters, hyphens, and underscores. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set standby management module Ethernet channel 0 hostname	Sets the host name for Ethernet channel 0 for the standby management module. Note: This option does not apply to the BladeCenter S unit.	 ifconfig -eth0 -o -n hostname where hostname is the host name for Ethernet channel 0. The hostname can be a string up to 63 characters in length that includes alphanumeric characters, hyphens, and underscores. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number. Note: Even though this command displays information for the standby management module, it still must specify the primary management module as the command target.
Set management module Ethernet channel 0 configuration method	 Sets the configuration method for Ethernet channel 0 for the management module. A value of dthens will try the DHCP configuration and default to the static IP configuration if DHCP is unsuccessful after 2 minutes. Note: If the management module DHCP setting is set to try the DHCP setting is set to try the DHCP server and then use the static IP address, the management module will use the static IP address when the DHCP server is not available during management module start up. When this occurs, the IP address might not be reachable if multiple management modules were started with the same static IP address. Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module. 	<pre>ifconfig -eth0 -c config_method where config_method is dhcp static dthens This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 44. ifconfig command (continued)
------------------------------	------------

Function	What it does	Command	Valid targets
Set management module Ethernet channel 0 data rate	Sets the data rate for Ethernet channel 0 for the management module.	<pre>ifconfig -eth0 -r data_rate where data_rate is auto 10 100</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities:SupervisorChassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set management module Ethernet channel 0 duplex mode	Sets the duplex mode for Ethernet channel 0 for the management module.	<pre>ifconfig -eth0 -d duplex_mode where duplex_mode is auto half full This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management module Ethernet channel 0 MTU	Sets the MTU (maximum transmission unit) for Ethernet channel 0 for the management module.	 ifconfig -eth0 -m mtu where mtu is between 60 and 1500, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 44.	ifconfig	command	(continued)
-----------	----------	---------	-------------

Set management module Ethernet channel 0 static MAC address (locally administered)Sets the locally administered MAC address for Ethernet channel 0 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.if config -eth0 -1 address-T system:mm[x]Where address is the locally administered MAC address for Ethernet channel 0 for the management module take effect after the next reset of the primary management module.where address is the locally administered MAC address for Ethernet channel 0. The MAC address is 6 bytes in length, hexadecimal, separated by colons. The MAC address (the first byte must be even)T system:mm[x]This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration-T system:mm[x]	Function	What it does	Command	Valid targets
See "Commands and user	Set management module Ethernet channel 0 static MAC address (locally administered)	Sets the locally administered MAC address to the specified MAC address for Ethernet channel 0 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.	 ifconfig -eth0 -1 address where address is the locally administered MAC address for Ethernet channel 0. The MAC address is 6 bytes in length, hexadecimal, separated by colons. The MAC address can not be a multicast address (the first byte must be even). This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system:mm[x] where <i>x</i> is the standby management-module bay number.
authority" on page 8 for additional information.			authority" on page 8 for additional information.	
Set standby management module Ethernet channel 0 static MAC address (locally administered)Sets the locally administered MAC address to the specified MAC address for Ethernet channel 0 for the standby management module. Note: This option is not available on the BladeCenter S.if config -eth0 -o -1 address is the locally address is the locally administered MAC address for Ethernet channel 0. The MAC address is 6 bytes in length, hexadecimal, separated by colons. The MAC address can not be a multicast address (the first byte must be even)T system:m[x] where x is the pri management-mod bay number. Note: Even thoug this command dis specify the primar management mod as the command to specify the primar management mod as the command a the standby management mod address is 6 bytes in length, hexadecimal, separated by colons. The MAC address can not be a multicast address (the first byte must be even)T system:m[x] where x is the pri management-mod bay number. Note: Even thoug this command and the specify the primar management mod as the command to See "Commands and user authority" on page 8 for	Set standby management module Ethernet channel 0 static MAC address (locally administered)	Sets the locally administered MAC address to the specified MAC address for Ethernet channel 0 for the standby management module. Note: This option is not available on the BladeCenter S.	ifconfig -eth0 -o -l address where address is the locally administered MAC address for Ethernet channel 0. The MAC address is 6 bytes in length, hexadecimal, separated by colons. The MAC address can not be a multicast address (the first byte must be even). This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for	-T system:mm[x] where x is the primary management-module bay number. Note: Even though this command displays information for the standby management module, it still must specify the primary management module as the command target.

Function	What it does	Command	Valid targets
Set management module Ethernet channel 0 domain name	Sets the domain name for Ethernet channel 0 for Ethernet channel 0 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.	<pre>ifconfig -eth0 -dn domain where domain is an alphanumeric string up to 127 characters in length. The domain name must contain at least one dot (.). This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable IPv6 addressing for management module Ethernet channel 0	Enable or disable IPv6 addressing for Ethernet channel 0 for the management module.	 additional information. ifconfig -eth0 -ipv6 state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Enable / disable static IPv6 configuration for management module Ethernet channel 0	Enable or disable static IPv6 configuration for Ethernet channel 0 for the management module.	<pre>ifconfig -eth0 -ipv6static state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 44.	ifconfig	command	(continued)
-----------	----------	---------	-------------

Function	What it does	Command	Valid targets
Set management module Ethernet channel 0 address prefix length	Sets the IPv6 address prefix length for Ethernet channel 0 for the management module.	 ifconfig -eth0 -p6 length where length is between 1 and 128 (inclusive). This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		additional information.	
Enable / disable DHCPv6 for management module Ethernet channel 0	Enable or disable static DHCPv6 for Ethernet channel 0 for the management module.	 ifconfig -eth0 -dhcp6 state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[<i>x</i>] where <i>x</i> is the primary management-module bay number.
Enable / disable IPv6 stateless auto-configuration for management module for Ethernet channel 0	Enable or disable IPv6 stateless auto-configuration for Ethernet channel 0 for the management module.	 ifconfig -eth0 -sa6 state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Display primary management module Ethernet channel 1 configuration	 Displays the current configuration of Ethernet channel 1 for the primary management module. Possible return values are: up (enabled) down (disabled) -i static_ip_address (dotted decimal IPv4 IP address format) -g gateway_address (dotted decimal IPv4 IP address format) -s subnet_mask (dotted decimal IPv4 IP address format) -r data_rate -d duplex_mode -m mtu -l locally_administered_mac_addr -b burnedin_mac_address 	ifconfig -eth1	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management module Ethernet channel 1 static IP address (IPv4)	Sets the static IP address (IPv4) for Ethernet channel 1 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.	<pre>ifconfig -eth1 -i ip_address where ip_address is the static IP address for Ethernet channel 1 in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where x is the primary management-module bay number.
Set management module Ethernet channel 1 gateway IP address (IPv4)	Sets the gateway IP address (IPv4) for Ethernet channel 1 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.	 ifconfig -eth1 -g <i>ip_address</i> where <i>ip_address</i> is the gateway IP address for Ethernet channel 1 in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 44. ifconfig of	command	(continued)
-----------------------	---------	-------------

Function	What it does	Command	Valid targets
Set management module Ethernet channel 1 subnet mask (IPv4)	Sets the subnet mask (IPv4) for Ethernet channel 1 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.	<pre>ifconfig -eth1 -s sub_mask where sub_mask is the subnet mask for Ethernet channel 1 in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		authority" on page 8 for additional information.	
Set management module Ethernet channel 1 data rate	Sets the data rate for Ethernet channel 1 for the management module.	<pre>ifconfig -eth1 -r data_rate where data_rate is auto 10 100 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management module Ethernet channel 1 duplex mode	Sets the duplex mode for Ethernet channel 1 for the management module.	<pre>ifconfig -eth1 -d duplex_mode where duplex_mode is auto half full This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set management module Ethernet channel 1 MTU	Sets the MTU (maximum transmission unit) for Ethernet channel 1 for the management module.	<pre>ifconfig -eth1 -m mtu where mtu is between 60 and 1500, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management module Ethernet channel 1 static MAC address (locally administered)	Sets the locally administered MAC address to the specified MAC address for Ethernet channel 1 for the management module. Note: Changes made to the IP configuration of the primary management module take effect after the next reset of the primary management module.	 ifconfig -eth1 -l address where address is the locally administered MAC address for Ethernet channel 1. The MAC address is 6 bytes in length, hexadecimal, separated by colons. The MAC address can not be a multicast address (the first byte must be even). This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the standby management-module bay number.
Enable management module Ethernet channel 1	Enables the Ethernet channel 1 interface for the management module.	 ifconfig -eth1 -up This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Disable management module Ethernet channel 1	Disables the Ethernet channel 1 interface for the management module.	 ifconfig -eth1 -down This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display cKVM and network configuration status for blade server	 Displays the cKVM status and network status for the specified blade server. Valid cKVM states include: Enabled If the blade server supports network configuration, this command also displays the NIC numbers (such as -eth0 and -eth1), NIC states (up or down), and other NIC configuration information for the blade server and all network cards connected to the blade server. 	ifconfig	-T system:blade[x] where <i>x</i> is the blade-server bay number.
Display network configuration information for network card	Displays the NIC number (such as -eth0 and -eth1), NIC state (up or down), and other NIC configuration information for the specified network card in the specified blade server.	ifconfig -eth <i>x</i> where <i>x</i> is the NIC number.	-T system:blade[x] where x is the blade-server bay number.
Set I/O module for blade server management traffic	Sets the I/O module that will be used to route management traffic for the specified blade server. Note: This command will run only if the target blade server supports manual configuration of its management network interface.	 ifconfig -eth1 -i IO_bay where IO_bay is the bay number of the I/O module that should be used to route management traffic. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Enable / disable cKVM feature for blade server	Enable or disable cKVM feature for the specified blade server. Note: The cKVM feature requires special hardware and is not available for all blade servers.	 ifconfig -ckvm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.
Set blade server Ethernet channel static IP address (IPv4)	Sets the IPv4 static IP address for the specified Ethernet channel of the specified blade server. Note: This command will run only if the target blade server supports manual configuration of its management network interface.	 ifconfig -ethx -i ip_address where: x is the NIC number. ip_address is the static IP address for Ethernet channel x in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set blade server Ethernet channel static IP address (IPv6)	 Sets the IPv6 static IP address for the specified Ethernet channel of the specified blade server. Note: This command will run only if the target blade server supports manual IPv6 configuration of its management network interface. A static IPv6 configuration ID is required for network interfaces that support more than one static configuation. 	 ifconfig -ethx -i6 <i>ip_address</i> -id <i>id</i> where: x is the NIC number. <i>ip_address</i> is the static IP address for Ethernet channel x in IPv6 format. <i>id</i> is the static IPv6 configuration ID. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.
Set blade server Ethernet channel gateway IP address (IPv4)	Sets the IPv4 gateway IP address for the specified Ethernet channel of the specified blade server. Note: This command will run only if the target blade server supports manual configuration of its management network interface.	 ifconfig -ethx -g <i>ip_address</i> where: <i>x</i> is the NIC number. <i>ip_address</i> is the gateway IP address for Ethernet channel <i>x</i> in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set blade server Ethernet channel gateway/default route (IPv6)	 Sets the IPv6 gateway/default route for the specified Ethernet channel of the specified blade server. Note: This command will run only if the target blade server supports manual IPv6 configuration of its management network interface A static IPv6 configuration ID is required for network interfaces that support more than one static configuation. 	 ifconfig -ethx -g6 <i>ip_address</i> -id <i>id</i> where: <i>x</i> is the NIC number. <i>ip_address</i> is the gateway/default route for Ethernet channel <i>x</i> in IPv6 format. <i>id</i> is the static IPv6 configuration ID. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.
Set blade server Ethernet channel subnet mask (IPv4)	Sets the IPv4 subnet mask for the specified Ethernet channel of the specified blade server. Note: This command will run only if the target blade server supports manual configuration of its management network interface.	 ifconfig -ethx -s sub_mask where: x is the NIC number. sub_mask is the subnet mask for Ethernet channel x in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set blade server Ethernet channel configuration method	 Sets the configuration method for the specified Ethernet channel of the specified blade server. A value of dthens will try the DHCP configuration and default to the static IP configuration if DHCP is unsuccessful after 2 minutes. Note: This command will run only if the target blade server supports manual configuration of its management network interface. If the DHCP setting is set to try the DHCP server and then use the static IP address, the NIC will use the static IP address when the DHCP server is not available during start up. When this occurs, the IP address might not be reachable if multiple devices were started with the same static IP address. Blade servers based on the Power PC chip, including the JS12 and JS22, only support the static and DHCP options. 	<pre>ifconfig -ethx -c config_method where: x is the NIC number. config_method is _ dhcp _ static _ dthens This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:blade[x] where x is the blade-server bay number.
Set management module Ethernet channel VLAN ID	Sets the VLAN ID for the specified Ethernet channel of the specified blade server. Note: This command will run only if the target blade server supports manual configuration of its management network interface.	 ifconfig -ethx -v vlan_id where: x is the NIC number. vlan_id is from 1 to 4095, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade-server bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set state for blade server Ethernet channel VLAN ID	Enables or disables the VLAN ID for the specified Ethernet channel of the specified blade server. Note: This command will run only if the target blade server supports manual configuration of its management network interface.	 ifconfig -ethx -ve state where: x is the NIC number. state is enable or disable. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration 	-T system:blade[x] where x is the blade-server bay number.
		See "Commands and user authority" on page 8 for additional information.	
Set blade server Ethernet channel hostname	Sets the host name for the specified Ethernet channel of the specified blade server. Note: This command will run only if the target blade server supports manual configuration of its management network interface.	 if config -ethx -n hostname where: x is the NIC number. hostname is the host name. The hostname can be a string up to 63 characters in length that includes alphanumeric characters, hyphens, and underscores. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information.	-T system:blade[x] where <i>x</i> is the blade-server bay number.
Enable blade server Ethernet channel	Enables the specified Ethernet channel interface of the specified blade server. Note: This command will run only if the target blade server supports manual configuration of its management network interface.	 ifconfig -ethx -up where x is the NIC number. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Disable blade server Ethernet channel	Disables the specified Ethernet channel interface of the specified blade server. Note: This command will run only if the target blade server supports manual configuration of its management network interface.	 ifconfig -ethx -down where x is the NIC number. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade-server bay number.
Enable / disable IPv6 addressing for blade server	Enable or disable IPv6 addressing for the specified Ethernet channel interface of the specified blade server. Note: This command will run only if the target blade server supports manual IPv6 configuration of its management network interface.	 ifconfig -ethx -ipv6 state where: x is the NIC number. state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.
Set blade server address prefix length	 Sets the IPv6 address prefix length for the specified Ethernet channel interface of the specified blade server. Note: This command will run only if the target blade server supports manual IPv6 configuration of its management network interface. A static IPv6 configuration ID is required for network interfaces that support more than one static configuation. 	 ifconfig -ethx -p6 length -id id where: x is the NIC number. length is between 1 and 128 (inclusive). id is the static IPv6 configuration ID. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade-server bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Enable / disable DHCPv6 for blade server	Enable or disable static DHCPv6 for the specified Ethernet channel interface of the specified blade server. Note: This command will run only if the target blade server supports manual IPv6 configuration of its management network interface.	 ifconfig -ethx -dhcp6 state where: x is the NIC number. state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information 	-T system:blade[x] where x is the blade-server bay number.
Enable / disable IPv6 stateless auto-configuration for blade server	Enable or disable IPv6 stateless auto-configuration for the specified Ethernet channel interface of the specified blade server. Note: This command will run only if the target blade server supports manual IPv6 configuration of its management network interface.	 ifconfig -ethx -sa6 state where: x is the NIC number. state is enabled or disabled This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade-server bay number.
Set blade server ISMP static IP address (IPv4)	Sets the IPv4 static IP address for the integrated system management processor (ISMP) of the specified blade server. Note: This command will run only if the target blade server supports manual configuration of its management network interface.	 ifconfig -i <i>ip_address</i> where <i>ip_address</i> is the static IP address for the blade server ISMP in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x]:sp where x is the blade-server bay number.

Function	What it does	Command	Valid targets
Display network settings for BladeCenter unit	Displays network settings for the BladeCenter unit. Valid return values are: • -v VLAN-id • -maxv enabled/disabled	ifconfig	-T system
Enable / disable multiple video sessions for blade servers	Set state to allow only a single remote video session or allow up to four remote video sessions for each	ifconfig -maxv <i>state</i> where <i>state</i> is enabled (allow multiple video	-T system
	blade server.	sessions) or disabled (allow only one video session).	
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
VLAN ID for	Sets the VLAN ID for the	ifconfig -v VLAN-id	-T system
BladeCenter unit	BladeCenter unit.	where <i>VLAN-id</i> is from 1 to 4095, inclusive. If you enter a value outside this range, an error will be displayed.	
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set state for BladeCenter unit VLAN ID	Enables or disables the VLAN ID for the BladeCenter unit.	ifconfig -ve state	-T system
		where <i>state</i> is enabled or disabled.	
		This command can only be run by users who have one or more of the following command authorities:SupervisorChassis configuration	
		See "Commands and user authority" on page 8 for additional information.	

Table 44. if config command (continued)

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Enable / disable global cKVM feature for BladeCenter unit	Enable or disable cKVM feature globally for the BladeCenter unit. (This is the same as running the ifconfig -ckvm enable command directed to each blade server.) Note: The cKVM feature requires special hardware and is not available for all blade servers.	 ifconfig -ckvm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system
Display network settings for I/O module	 Displays network settings for the specified I/O module. Valid return values are: I/O-module type -i <i>ip_address</i> (dotted decimal IPv4 IP address format) -s <i>subnet_mask</i> (dotted decimal IPv4 IP address format) -g <i>gateway_address</i> (dotted decimal IPv4 IP address format) -em <i>ext_mgt_status</i> -ep <i>ext_port_status</i> -pm <i>enabled/disabled</i> (protected mode) -pip <i>enabled/disabled</i> -c <i>config_method</i> -ipv6 <i>ipv6_state</i> -i6 <i>static_ip_address</i> (IPv6 format) -g6 <i>gateway_default_route</i> (IPv6 format) -g6 <i>gateway_default_route</i> (IPv6 format) -g6 <i>gateway_default_route</i> (IPv6 format) -g6 <i>gateway_default_route</i> (IPv6 format) If IPv6 is enabled, the link-local address <i>link_local_address</i> (for IPv6 connection) also displays. If IPv6 and stateless auto-config IP Addresses / Prefix Length <i>address_table</i> (table listing auto-generated IPv6 addresses and their prefix lengths) also displays. 	ifconfig	-T system:switch[x] where x is the I/O-module bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set starting IP address for I/O module (IPv4)	Sets the IPv4 IP addresses for the specified I/O module.	ifconfig -i <i>ip_address</i> where <i>ip_address</i> is the IP address of the specified I/O module in dotted decimal IP address format. This command can only be run by users who have one or more of the	-T system: switch[x] where <i>x</i> is the I/O-module bay number.
		following command authorities: • Supervisor • I/O module configuration	
		authority" on page 8 for additional information.	
Set starting IP address for I/O module (IPv6)	Sets the IPv6 static IP address for the specified I/O module.	ifconfig -i6 <i>ip_address</i> where <i>ip_address</i> is the static IP address for the	-T system:switch[x] where x is the I/O-module bay
		specified I/O module in IPv6 format.	number.
		 This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration 	
		See "Commands and user authority" on page 8 for additional information.	
Set I/O-module gateway	Sets the gateway IPv4 IP address	ifconfig -g <i>ip_address</i>	-T system:switch[x]
	for the specified 1/ O module.	where <i>ip_address</i> is the gateway IP address for the I/O module in dotted decimal IP address format.	where <i>x</i> is the I/O-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • I/O module configuration	
		See "Commands and user authority" on page 8 for additional information.	

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set I/O-module gateway IP address (IPv6)	Sets the IPv6 gateway/default route for the specified I/O module.	<pre>ifconfig -g6 ip_address where ip_address is the gateway IP address for the I/O module in IPv6 format. This command can only be run by users who have one or more of the following command authorities: • Supervisor</pre>	-T system:switch[x] where x is the I/O-module bay number.
		 I/O module configuration See "Commands and user authority" on page 8 for additional information. 	
Keep new IP address configuration for I/O-module after reset	Retains a new IP address configuration after the specified I/O module is reset. Note: Make sure a valid New Static IP Configuration is entered for this I/O module so that when the module's factory defaults are restored, or when a reset is initiated by a source other than the management module, the New Static IP Configuration will be configured. In these cases management module communication with the I/O module will be preserved.	 ifconfig -pip enabled This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.
Revert to old IP address configuration for I/O-module after reset	Reverts IP address to old configuration after the specified I/O module is reset. Note: The factory default IP configuration will become active when the I/O module is reset to factory defaults by either the management module or the I/O module. If an I/O module reset is initiated by a source other than the management module, then the previous IP configuration will be in affect. In both of these cases the management module will lose IP communications with the I/O module.	 ifconfig -pip disabled This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set I/O-module subnet	Sets the IPv4 subnet mask for the	ifconfig -s <i>sub_mask</i>	-T system:switch[x]
mask (IPV4)	specified 1/O module.	where <i>sub_mask</i> is the subnet mask for the I/O module in dotted decimal IP address format.	where <i>x</i> is the I/O-module bay number.
		 This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration 	
		See "Commands and user authority" on page 8 for additional information.	
Enable / disable external	Enables or disables external	ifconfig -em state	-T system:switch[x]
management for I/O module	specified I/O module.	where <i>state</i> is enabled or disabled.	where <i>x</i> is the I/O-module bay number.
		 This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration 	
		See "Commands and user authority" on page 8 for additional information.	
Enable / disable external	Enables or disables external ports	ifconfig -ep state	-T system:switch[x]
ports for 1/O module	for the specified I/O module.	where <i>state</i> is enabled or disabled.	where <i>x</i> is the I/O-module bay number.
		 This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration 	
		See "Commands and user authority" on page 8 for additional information.	

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Enable / disable protected mode for I/O module	Enables or disables protected mode for the specified I/O module.	 ifconfig -pm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user 	-T system:switch[x] where x is the I/O-module bay number.
		authority" on page 8 for additional information.	
Enable / disable IPv6 addressing for I/O module	Enable or disable IPv6 addressing for the specified I/O module.	 ifconfig -ipv6 state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.
Enable / disable static IPv6 configuration for I/O module	Enable or disable static IPv6 configuration for the specified I/O module.	<pre>ifconfig -ipv6static state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • I/O module configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:switch[x] where <i>x</i> is the I/O-module bay number.

Table 44. if config command (continued)

Function	What it does	Command	Valid targets
Set I/O module address prefix length	Sets the IPv6 address prefix length for the specified I/O module.	 ifconfig -p6 <i>length</i> where <i>length</i> is between 1 and 128 (inclusive). This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for 	-T system:switch[x] where <i>x</i> is the I/O-module bay number.
		additional information.	
Enable / disable DHCPv6 for I/O module	Enable or disable static DHCPv6 for the specified I/O module.	 ifconfig -dhcp6 state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.
Enable / disable IPv6 stateless auto-configuration for I/O module	Enable or disable IPv6 stateless auto-configuration for the specified I/O module.	 ifconfig -sa6 state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.

Function	What it does	Command	Valid targets
Set IP addresses for RAID controller and SAS system (IPv4) (BladeCenter S units only)	Sets IPv4 IP addresses for RAID controller and SAS system.	<pre>ifconfig -i ip_address_a -ir ip_address_b where • ip_address_a is the IP address of the specified SAS system in dotted doginal ID address</pre>	-T system:switch[x] where <i>x</i> is the RAID controller bay number.
		 <i>ip_address_b</i> is the IP address of the associated RAID controller in dotted decimal IP address format. 	
		 This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration 	
		See "Commands and user authority" on page 8 for additional information.	
Set gateway IP addresses	Sets the IPv4 gateway IP addresses	ifconfig -g <i>ip_address_a</i>	-T system:switch[x]
SAS system (IPv4)	system.	where	where <i>x</i> is the RAID controller bay number.
(BladeCenter S units only)		 <i>ip_address_a</i> is the gateway IP address of the specified SAS system in dotted decimal IP address format. <i>ip_address_b</i> is the gateway IP address of the associated RAID controller in dotted decimal IP address format. 	
		 This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration 	
		See "Commands and user authority" on page 8 for additional information.	

Table 44. ifconfig command (continued)

Function	What it does	Command	Valid targets
Set subnet masks for RAID controller and SAS system (IPv4) (BladeCenter S units only)	Sets the IPv4 subnet masks for the RAID controller and SAS system.	 ifconfig -s sub_mask_a -sr sub_mask_b where sub_mask_a is the subnet mask of the specified SAS system in dotted decimal IP address format. sub_mask_b is the subnet mask of the associated RAID controller in dotted decimal IP address format. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where <i>x</i> is the RAID controller bay number.

Example:

To display the configuration for Ethernet channel 0, that does not support IPv6, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

ifconfig -eth0

To set the IPv4 static IP address for Ethernet channel 0 to 192.168.70.133, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type ifconfig -eth0 -i 192.168.70.133 -c static

To set the IPv4 IP addresses for the BladeCenter S SAS subsystem to 9.186.10.16 and the IPv4 IP address for the RAID controller to 9.186.10.17, while switch module 3 is set as the persistent command environment, at the system:switch[3]> prompt, type

ifconfig -i 9.186.10.16 -ir 9.186.10.17

To set the IPv4 gateway address for the BladeCenter S SAS subsystem to 9.186.10.1 and the IPv4 gateway address for the RAID controller to 9.186.11.1, while switch module 3 is set as the persistent command environment, at the system:switch[3]> prompt, type

ifconfig -g 9.186.10.1 -gr 9.186.11.1

The following example shows the information that is returned from these commands:

```
system:mm[1]> ifconfig -eth0
Enabled
-i 10.10.10.10
-g 0.0.0.0
-s 255.255.255.0
-n MM00096BCA0C80
-c Try DHCP server. If it fails, use static IP config.
-r Auto
-d Auto
-m 1500
-1 00:00:00:00:00:00
-b 00:09:6B:CA:0C:80
system:mm[1]> ifconfig -eth0 -i 192.168.70.133 -c static
Changes to the network settings will take effect after the next reset of the MM.
system:mm[1]>
system:switch[3]>ifconfig -i 9.186.10.16 -ir 9.186.10.17
0K
system:switch[3]>ifconfig -g 9.186.10.1 -gr 9.186.11.1
0K
system:mm[1]>
```

To display the configuration for Ethernet channel 0, that supports IPv6, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type ifconfig -eth0

The following example shows the information that is returned from these commands:

```
system:mm[1]> ifconfig -eth0
Enabled
-i 10.13.3.230
-g 10.13.1.1
-s 255.255.0.0
-n primaryAMM
-c static
-r auto
-d auto
-m 1500
-1 00:00:00:00:00:00
-b 00:14:5E:DF:0F:CE
-dn primaryAMM.com
-ipv6 enabled
-ipv6static disabled
-i6 6::6
-p6 1
-g6 ::
-dhcp6 enabled
-sa6 enabled
Link-local address: fe80::214:5eff:fedf:fce
Stateless auto-config IP Addresses Prefix Length
```

2000:1013::214:5eff:fedf:fce 2001:1013::214:5eff:fedf:fce 2002:1013::214:5eff:fedf:fce system:mm[1]>	64 64 64
---	----------------

info (configuration information) command

This command displays information about BladeCenter components and their configuration, and how to reload the component information.

Table 45. info (configuration information) command

Function	What it does	Command	Valid targets
Display component	Displays identification and	info	-T system
information	configuration information for the	Note Only one target at a	-T system:mm[x]
	command target.	time can be viewed with	-T system:blade[x]
		the info command.	-T system:blower[x]
			-T system:ncc[x]
			-T system:mux[x]
			-T system:tap
			-T system:blade[x]: exp[y]
			-T system:blade[x]: mgmtcrd
			-T system:blade[x]:sp
			-T system:blade[x]: be[y]
			-T system:blade[x]: be[y]:exp[z]
			-T system:blade[x]: be[y]:hsec[z]
			-T system:blade[x]:sb
			-T system:blade[x]: cpu[y]
			-T system:blade[x]: memory[y]
			-T system:blade[x]: hsec[y]
			-T system:blade[x]:ckvm
			-T system:switch[x]
			-T system:power[x]
			-T system:mt[x]
			-T system:mt[x]: bbu[y]
			-T system:storage[x]
			-T system:storage[x]: disk[y]
			(continued on next page)

Function	What it does	Command	Valid targets
Display component			_
information			where:
(continued)			 <i>x</i> is the management-module bay number, blade server bay number, I/O-module bay number, microprocessor number, power module bay number, media-tray bay number, storage bay number , or daughter-card number.
			• <i>y</i> or <i>z</i> is the:
			 blade server storage expansion unit number (be).
			 blade server I/O expansion card number (exp).
			 microprocessor number (CPU).
			 memory DIMM number.
			 high-speed expansion card number (hsec).
			 battery backup unit number (bbu).
			(disk).
Display management channel path information	Displays the management channel path information for the BladeCenter unit.	info -path	-T system
Reload component information for firmware	Reloads vital product data (VPD) for firmware.	info -reload fw	-T system
Reload component information for hardware	Reloads vital product data (VPD) for hardware.	info -reload hw	-T system
Reload information on MAC addresses	Reloads vital product data (VPD) for MAC addresses.	info -reload mac	-T system
Reload WWN and GUID information	Reloads vital product data (VPD) for world-wide name (WWN) and globally-unique identifier (GUID).	info -reload wwn	-T system
Reload all component information	Forces reload of all VPD and MAC address information.	info -reload all	-T system

Table 45. info (configuration information) command (continued)

Notes:

- The command target -T system:blade[x]:exp[y] is shown with a line break before the :exp[y]. When this command target is entered, the entire entry must all be on one line.
- 2. This command returns vital product data (VPD) information that is unique for each command target. For some targets, additional VPD information is available when using the advanced management module.
- 3. Even if the command target is specified, the -reload option acts globally, reloading information not just for the specified target but for all targets in the corresponding category; for example, all MAC addresses are reloaded for all targets when the command is info -reload mac with system:blade[x] as the target.

Example: To view the information about an advanced management module in management-module bay 1, while this management module is set as the persistent command environment, at the system:mm[1]> prompt, type

info

The following example shows the information that might be returned from the info command:

system:mm[1]> info

```
Name: AMM KP
Manufacturer: Not Available (Not Available)
Manufacturer ID: 288
Product ID: 1
Mach type/model: Management Module
Mach serial number: Not Available
Manuf date: 3005
Hardware rev: 51
Part no.: 26R099000000
FRU no.: 25R5777
FRU serial no.: 0J1U9E584130
CLEI: Not Available
AMM firmware
       Build ID: BPET30U
       File name:
Rel date:
                      CNETCMUS.PKT
                       08-09-07
       Rev:
                        30
AMM firmware (Flashed - pending restart)
       Build ID: BPET30x
       File name:
Rel date:
                       CNETCMUS.PKT
                       09-09-08
                        30
       Rev:
system:mm[1]>
```

iocomp command

Table 46. iocomp command

This command displays the compatibility between all blade servers and their I/O modules. It can also display detailed interface information for an individual blade server or I/O module.

Function	What it does	Command	Valid targets
Display compatibility between all blade servers and I/O modules	Displays I/O module compatibility information for all blade servers and I/O modules.	iocomp	-T system
Display blade server compatibility details	Displays detailed I/O module compatibility information for the specified blade server.	iocomp	-T system:blade[x] where x is the blade server bay number.
Display I/O module compatibility details	Displays detailed compatibility information for the specified I/O module.	iocomp	-T system:switch[x] where x is the I/O-module bay number.

Example: To view I/O module compatibility information for all blade servers and I/O modules, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

iocomp -T system

To view I/O module compatibility information for the blade server in blade bay 1, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

iocomp -T system:blade[1]

To view I/O module compatibility information for the I/O module in bay 2, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type iocomp -T system:switch[2]

The following example shows the information that is returned from these commands:

syst	em:mm[1]> iocomp	-T	system		
Blades					
1	xPert1	0K			
2	xPert2	0K			
3	Development	0K			
4	Marketing	0K			
5	xpert3	0K			
6	Sales	0K			
7	xPert4	0K			
9	xPert5	0K			
11	Finance	0K			
12	HR	0K			
13	xPert6	0K			
14	xPert7	0K			
T/0	Modules				
1	OK				
2	0K				
3	0K				
4	0K				
-	* · ·				

IOM 1OnEthernet Switch ModuleEthernetOKIOM 2OnEthernet Switch ModuleEthernetOKsystem:mm[1]> iocomp -T system:switch[1]BayPowerFabric TypeCompatBlade 1OnEthernetOKBlade 2OnEthernetOKBlade 3OnEthernetOKBlade 4OnEthernetOKBlade 5OffEthernetOKBlade 6OnEthernetOKBlade 7OnEthernetOKBlade 9OnEthernetOKBlade 11OnEthernetOKBlade 12OnEthernetOKBlade 13OnEthernetOK	system:mm[Bay	l]> iocomp Power	-T system:blade Fabric Type	[1]	Fabric on Blade	Compt
Blade 1OnEthernetOKBlade 2OnEthernetOKBlade 3OnEthernetOKBlade 3OnEthernetOKBlade 4OnEthernetOKBlade 5OffEthernetOKBlade 6OnEthernetOKBlade 7OnEthernetOKBlade 9OnEthernetOKBlade 11OnEthernetOKBlade 12OnEthernetOKBlade 13OnEthernetOK	IOM 1 ON IOM 2 ON system:mm[Bay	n Et n Et L]> iocomp Power	hernet Switch Mo hernet Switch Mo -T system:switc Fabric Type	dule dule h[1] Co	Ethernet Ethernet mpat	ОК ОК
Blade 14 On Ethernet OK	Blade 1 Blade 2 Blade 3 Blade 4 Blade 5 Blade 6 Blade 6 Blade 7 Blade 9 Blade 11 Blade 12 Blade 13 Blade 14	On On On On Off On On On On On On On	Ethernet Ethernet Ethernet Ethernet Ethernet Ethernet Ethernet Ethernet Ethernet Ethernet Ethernet Ethernet Ethernet Ethernet Ethernet	0K 0K 0K 0K 0K 0K 0K 0K 0K 0K 0K 0K 0K	abric	

kvm (keyboard, video, mouse) command

This command sets and displays the blade server that is in control of the BladeCenter unit shared KVM.

Table 47. kvm com	mand
-------------------	------

Function	What it does	Command	Valid targets
Display KVM owner	Displays the number of the blade server that has KVM ownership and the global local KVM switching state for all blade servers. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies. A return value of 0 indicates that no owner is set.	kvm	-T system
Set KVM owner	Sets a blade server as the KVM owner.	kvm -b blade_server where blade_server is the blade-bay number that identifies the blade server. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies. A setting of 0 sets no owner. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade remote presence See "Commands and user authority" on page 8 for additional information.	-T system
Enable / disable local KVM switching globally	Enable or disable local KVM switching globally for all blade servers.	 kvm -local state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system
Example:

To set the KVM owner to the blade server in blade bay 1, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

kvm -T system -b 1

To display the KVM owner and global local KVM switching state for all blade servers, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
kvm -T system
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> kvm -T system -b 1
OK
system:mm[1]> kvm -T system
-b 1
-local enabled
system:mm[1]>
```

Idapcfg command

This command sets and displays the LDAP configuration settings for the advanced management module.

Table 48. Idapcfg command

Function	What it does	Command	Valid targets
Display LDAP settings	Displays the LDAP settings for the management module.	ldapcfg	-T system:mm[x] where x is the primary management-module bay number.
Set LDAP security	Sets version of LDAP security used	ldapcfg -v version	-T system:mm[x]
version	 by the management module. Note: If the version is set to v1, the following values must also be set: A group filter using the -gf command option. A group search attribute using the -gsa command option. A login permission attribute using the -lpa command option. If the version is set to v2, the LDAP name must also be set using the -t command option. 	 where <i>version</i> is: v1 for old user permission model v2 for the enhanced role-based security model This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	where <i>x</i> is the primary management-module bay number.

Table 48. Idapcfg command (continued)

Function	What it does	Command	Valid targets
Set LDAP group filter	Sets the group filter for the management module that can be used for authentication during LDAP server login. Note: For a group filter to be used, LDAP security must be set to v1 using the -v command option.	Idapcfg -gf "filter"where "filter" is aquote-delimited string ofup to 511 characters inlength and consists of oneor more group names. Thecolon (:) character is usedto delimit multiple groupnames. Leading spacesand trailing spaces areignored. Consecutivespaces are treated as asingle space. The wildcardcharacter (*) is notsupported for securityreasons. A group namecan be specified as a fulldomain name or by usingthe common name (cn)portion.This command can onlybe run by users who haveone or more of thefollowing commandauthorities:• Supervisor• Chassis configurationSee "Commands and userauthority" on page 8 foradditional information	-T system:mm[x] where x is the primary management-module bay number.
Set LDAP group search attribute	Sets the group search attribute that represents groups of user IDs stored on the LDAP server. On Active Directory servers, the group search attribute is typically set to "memberOf". On eDirectory servers, it is typically set to "groupMembership". In an OpenLDAP server environment, users are typically assigned to groups whose objectClass equals "PosixGroup". In this case, the group search attribute identifies members of a particular PosixGroup that is typically "memberUid". Note: For a group search attribute to be used, LDAP security must be set to v1 using the -v command option.	 ldapcfg -gsa "GSA" where "GSA" is a quote-delimited alphanumeric string of up to 23 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 48. Idapcfg command (continued)

Function	What it does	Command	Valid targets
Set LDAP login permission attribute	Sets the login permission attribute that is used to determine retrieve user permissions on the LDAP server. Note: For a login permission attribute to be used, LDAP security must be set to v1 using the -v command option.	 ldapcfg -lpa "permission" where "permission" is a quote-delimited alphanumeric string up to 23 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	
Set LDAP name	Sets the LDAP name for the management module. Note: For an LDAP name to be used, LDAP security must be set to v2 using the -v command option.	<pre>ldapcfg -t name where name is an alphanumeric string up to 63 characters in length containing any character except for angle brackets (< and >) and spaces. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for </pre>	-T system:mm[x] where x is the primary management-module bay number.

Table 48. Idapcfg command (continued)

Function	What it does	Command	Valid targets
Set LDAP server	Sets the method to use for	ldapcfg -server method	-T system:mm[x]
discovery method	 discovering LDAP servers that provide user authentication. Note: If the dns method is specified, the following values must also be set: A domain name using the -dn command option. A forest name using the -fn command option. If the preconf method is specified, the following values must also be set: An LDAP server hostname or IP address using the -i1, -i2, and -i3 command options. A port for each LDAP server hostname or IP address using the -p1, -p2, and -p3 command options. 	 where <i>method</i> is: dns for dynamic discovery preconf to use an LDAP server that was manually pre-configured This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	where <i>x</i> is the primary management-module bay number.
Set LDAP server domain name	Sets the search domain to use for Domain Controller (DC) dynamic discovery.	 ldapcfg -dn <i>domain</i> where <i>domain</i> is an alphanumeric string up to 255 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Set LDAP server forest name	Sets the forest name to use for Global Catalog (GC) dynamic discovery.	 ldapcfg -fn <i>forestname</i> where <i>forestname</i> is an alphanumeric string up to 63 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 48. Idapcfg command (continued)

Function	What it does	Command	Valid targets
First LDAP server host name or IP address - set	Checks syntax and sets the first LDAP server host name or IP address to use for pre-configured LDAP server discovery. Note: A port for this LDAP server hostname or IP address must be set using the -p1 command option.	ldapcfg -i1 hostname/ip_address where hostname/ip_address is the first host name or IP address, up to 255 characters in length. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user	-T system:mm[<i>x</i>] where <i>x</i> is the primary management-module bay number.
Second LDAP server	Checks syntax and sets the second	authority" on page 8 for additional information.	-T_svstem:mm[x]
host name or IP address - set	LDAP server host name or IP address to use for pre-configured LDAP server discovery. Note: A port for this LDAP server hostname or IP address must be set using the -p2 command option.	hostname/ip_address where hostname/ip_address is the second host name or IP address, up to 255 characters in length. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	where <i>x</i> is the primary management-module bay number.
Third LDAP server host name or IP address - set	Checks syntax and sets the third LDAP server host name or IP address to use for pre-configured LDAP server discovery. Note: A port for this LDAP server hostname or IP address must be set using the -p3 command option.	 ldapcfg -i3 hostname/ip_address where hostname/ip_address is the third host name or IP address, up to 255 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 48. Idapcfg command (continued)

Function	What it does	Command	Valid targets
Fourth LDAP server host name or IP address - set	Checks syntax and sets the fourth LDAP server host name or IP address to use for pre-configured LDAP server discovery. Note: A port for this LDAP server hostname or IP address must be set using the -p4 command option.	 ldapcfg -i4 hostname/ip_address where hostname/ip_address is the fourth host name or IP address, up to 255 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
First LDAP server port number - set	Sets the port number of the first LDAP server to use for pre-configured LDAP server discovery.	additional information. Idapcfg -p1 <i>port</i> where <i>port</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.
Second LDAP server port number - set	Sets the port number of the second LDAP server to use for pre-configured LDAP server discovery.	 ldapcfg -p2 <i>port</i> where <i>port</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 48. Idapcfg command (continued)

Function	What it does	Command	Valid targets
Third LDAP server port	Sets the port number of the third	ldapcfg -p3 <i>port</i>	-T system:mm[x]
number - set	LDAP server to use for preconfigured LDAP server discovery.	where <i>port</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities:SupervisorChassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Fourth LDAP server port	Sets the port number of the fourth	ldapcfg -p4 port	-T system:mm[x]
number - set	Iber - set LDAP server to use for preconfigured LDAP server discovery.	where <i>port</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set LDAP root distinguished name	Sets the root distinguished name for the root entry of the LDAP directory tree that is used as the base object for all searches.	ldapcfg -rd "name" where "name" is up to 255 characters in length and contained within double-quotes. Names can contain any character, including spaces.	-T system:mm[x] where x is the primary management-module bay number.
		 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	
		See "Commands and user authority" on page 8 for additional information.	

Table 48. Idapcfg command (continued)

Function	What it does	Command	Valid targets
Set LDAP UID search attribute	Sets the UID search attribute that represents the user IDs stored on the LDAP server. On Active Directory servers, the UID search attribute is typically set to "sAMAccountName". On Novell eDirectory and OpenLDAP servers, it is typically set to "uid".	<pre>ldapcfg -usa "UID" where "UID" is up to 23 characters in length and contained within double-quotes. The UID can contain only letters, numbers, spaces, and the following characters: "-", "(", ")", "+", ",", ",", "/", ":", and"?". This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set LDAP server binding method	 Sets the binding method for initial connection to the LDAP server. Note: If the binding method is set to anon, a UID search attribute must be set using the -usa command option. If the binding method is set to cc, the following values must also be set: A UID search attribute using the -usa command option A client distinguished name using the -cd command option. A client password using the -p and -cp command options. 	 ldapcfg -bm version where version is: anon for anonymous cc for configured credentials lc for login credentials This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set LDAP server to be used for authentication only	Enables the authentication mode to use the LDAP server for authentication only with local authorization. This automatically disables the authentication mode that uses the LDAP Server for both authentication and authorization. LDAP server authentication uses the settings configured by the "groups command" on page 159.	 ldapcfg -aom state where state is enabled or disabled This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 48. Idapcfg command (continued)

Function	What it does	Command	Valid targets
Set LDAP client distinguished name	Sets the client distinguished name (DN) for initial connection to the LDAP server. Note: A client password must also be set using the -p and -cp command options.	<pre>ldapcfg -cd domain where domain is an alphanumeric string up to 255 characters in length containing any character except for angle brackets (< and >) and spaces. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set LDAP client distinguished name password	Sets the client distinguished name password for initial connection to the LDAP server. Note: The passwords must be specified by both the -p and -cp command options and must match.	 ldapcfg -p password where password is an alphanumeric string up to 15 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set (confirm) LDAP client distinguished name password	Sets, for confirmation purposes, the client distinguished name password for initial connection to the LDAP server. Note: The passwords must be specified by both the -p and -cp command options and must match.	 ldapcfg -cp <i>password</i> where <i>password</i> is an alphanumeric string up to 15 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Note: The -ds, -sd, and -sn options for the ldapcfg command have been deleted and replaced by the -dn and -fn command options. To implement this transition,

the items specified for dynamic discovery have changed and must be modified to match the syntax required by the new command options.

Example:

To display the management module LDAP settings, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type ldapcfg

To enable the authentication mode to use the LDAP server for authentication only with local authorization, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
ldapcfg -aom enabled
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> ldapcfg
-server preconf
 Parameters for '-server dns' configuration:
   -dn
   -fn test fn
 Parameters for '-server preconf' configuration:
   -i1
   -p1
   -i2
   -p2
   -i3
   -p3
   -i4 192.168.1.23
   -p4 11
Miscellaneous Parameters:
-rd 11
-usa
-bm cc
-aom enabled
 Parameters for '-bm cc' configuration:
   -cd
-v v1
 Parameters for '-v v1' configuration:
   -gf
   -gsa
   -lpa
 Parameters for '-v v2' configuration:
   -t
system:mm[1]> ldapcfg -aom enabled
0K
system:mm[1]>
```

led command

This command displays and sets the LED states for a specified command target, if this command target supports the LED.

Table 49. le	ed command
--------------	------------

Function	What it does	Command	Valid targets
Display various LED states	 Displays various LED states. Values returned are: status of all LEDs on the target blade and its subcomponents status of info LED status of location LED (on/off/blink) status of the identification LED of the system for a specified number of seconds 	led	-T system -T system:blade[x] where <i>x</i> is the blade server number.
Display state for fanpack fault LED	Displays the state of the fan pack fault LED of the BladeCenter HT unit.	led	-T system:power[x] where x is the power module (fanpack) number.
Display state for blower fault LED	Displays the state of the blower fault LED of the BladeCenter HT unit.	led	-T system:blower[x] where <i>x</i> is the blower number.
Display front panel LED state for blade server	Displays the state of the front panel LEDs on the specified blade server.	led	-T system:blade[x] where x is the blade server number.
Display external port link status LED state for I/O module	Displays state of the external and internal port link status LEDs for the specified I/O module.	led	-T system:switch[x] where <i>x</i> is the I/O module (switch) bay number.
Display fault LED state (for BladeCenter HT units only)	 Displays the state of the fault LED for the specified command target. Possible return values are: The state of the requested LED is on The state of the requested LED is off 	led -e	 T system:tap T system:ncc[x] T system:mux[x] T system:mt[x] where x is the alarm panel module, network clock module, multiplexer expansion module, or media tray number.
Display safe-to-remove LED state (for BladeCenter HT units only)	Displays the state of the safe-to-remove LED, that is on the BladeCenter unit and some components, for the specified command target. Possible return values are: • on • off	led -r	 -T system:tap -T system:ncc[x] -T system:mux[x] where x is the alarm panel module, network clock module, or multiplexer expansion module.

Table 49. led command (continued)

Function	What it does	Command	Valid targets
Display LED state for blade server and all sub-components	Displays the state of all LEDs on the specified blade server and its subcomponents. Possible return values are: • on • off • blink	1ed -1	-T system:blade[x] where x is the blade server number.
Turn off information LED	Turns off the information LED, that is on the BladeCenter unit and some components, for the specified command target	 led -info off This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management (for BladeCenter unit, network clock module, multiplexer expansion module, or media tray) Chassis log management (for BladeCenter unit, network clock module, multiplexer expansion module, or media tray) Chassis administration (for BladeCenter unit, network clock module, multiplexer expansion module, or media tray) Chassis configuration (for BladeCenter unit, network clock module, multiplexer expansion module, or media tray) Chassis configuration (for BladeCenter unit, network clock module, multiplexer expansion module, or media tray) Blade configuration (for blade server) Blade configuration (for blade server) Blade remote presence (for blade server) See "Commands and user authority" on page 8 for additional information. 	<pre>-T system -T system:blade[x] -T system:ncc[x] (for BladeCenter HT units only) -T system:mux[x] (for BladeCenter HT units only) -T system:mt[x] where x is the blade server, network clock module, multiplexer expansion module, or media tray number.</pre>

Table 49. led command (continued)

Function	What it does	Command	Valid targets
Function Set location LED state	What it does Sets the state of the location LED, that is on the BladeCenter unit and some blade servers, for the command target.	Command led -loc state where state is • on • off • blink Note: A state of blink can only be used for the -T system command target and for the blade servers. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis account management (for BladeCenter unit) • Chassis log management (for BladeCenter unit) • Chassis administration (for BladeCenter unit) • Chassis configuration (for BladeCenter unit) • Chassis configuration (for BladeCenter unit) • Blade administration (for blade server) • Blade configuration (for	<pre>Valid targets -T system -T system:blade[x] where x is the blade bay number.</pre>
		 (for BladeCenter unit) Blade administration (for blade server) Blade configuration (for blade server) Blade remote presence (for blade server) 	
		See "Commands and user authority" on page 8 for additional information.	

Table 49. led command (continued)

Function	What it does	Command	Valid targets
Turn on location LED for specified period of time	Turns on the location LED, that is on the BladeCenter unit and some blade servers, for a specified period of time before turning it off automatically.	led -loc on -d <i>time</i> where <i>time</i> is the number of seconds the location LED will remain lit.	-T system
		 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management Chassis log management Chassis administration Chassis configuration 	
		See "Commands and user authority" on page 8 for additional information.	

Example: To display the failure LED status for the blade server in bay 1, while the BladeCenter HT unit is set as the persistent command environment, at the system> prompt, type

led -T system:blade[1]

To display status of the front-panel LEDs for the blade server in bay 1, while the BladeCenter HT unit is set as the persistent command environment, at the system> prompt, type

led -T blade[1]

To display status of all LEDs for the blade server in bay 1, while the BladeCenter HT unit is set as the persistent command environment, at the system> prompt, type

led -l -T blade[1]

The following example shows the information that is returned from these commands:

system> led -T hs21 345678	blade[1]		
Error:	off		
Information:	off		
KVM:	off		
MT:	off		
Location:	blink		
system> led -T	blade[1] -l		
Component	Label	State	Location
Processor1	CPU1	Off	System board
Processor2	CPU2	Off	System board
Blade1	Fault	Off	Front panel
Blade2	Information	Off	Front panel
Blade3	Location	Blink	Front panel
Blade4	Power	0n	Front panel
	KVM	Off	Front panel
Blade5	Media Tray	Off	Front panel

Blade7	Over Temp	Off	System board
Blade8	N/A	Off	System board
Blade1	N/A	Off	System board
Storage1	DASD1	Off	System board
Memory1	DIMM1	Off	System board
Memory2	DIMM2	Off	System board
Memory3	DIMM3	Off	System board
Memory4	DIMM4	Off	System board
Memory5	DIMM5	Off	System board
Memory6	DIMM6	Off	System board
Memory7	DIMM7	Off	System board
Memory8	DIMM8	Off	System board
Panel1	N/A	Off	System board
Expansion1	N/A	Off	FRU
	N/A	Off	FRU
Expansion2	N/A	Off	FRU
	N/A	Off	FRU
	N/A	Off	FRU
	N/A	Off	FRU
Expansion3 system>	N/A	Off	FRU

list (system physical configuration) command

This command displays a list of devices present within the command target. It can be used to determine how many management modules are installed in the BladeCenter unit and which management module is set as primary.

Table 50. list (system physical configuration) command

Function	What it does	Command	Valid targets
View command target	Displays the current command target. If a management-module bay is the current command target, it will be identified as primary or standby (redundant).	list	Any installed device.
View system configuration tree	Displays the tree structure of devices present in the BladeCenter unit, starting at the command target level. If management-module bays are part of the tree, they will be identified as primary or standby (redundant). For components that have been assigned a name, this name will be displayed next to the component bay number.	 list -1 <i>depth</i> where <i>depth</i> is all or a for full tree display, starting at the command target level 1 to display the current command target 2 displays the content of the current command target plus one level below it 	Any installed device.

Example: To display a list of devices installed in the BladeCenter unit, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

list -l a

(This is the command syntax that can be used to determine the primary management module.)

The following example shows the information that is returned when the command is run on an advanced management module:

```
system> list -l a
system
        mm[1]
                  primary
        mm[2]
                  standby
        power[1]
        power[2]
        power[3]
        power[4]
        blower[1]
        blower[2]
        switch[1]
        switch[2]
        switch[3]
        switch[4]
        blade[1] Accounting
                sp
                cpu[1]
                cpu[2]
        blade[2] HR
                sp
                cpu[1]
                cpu[2]
        blade[3] Development
                sp
```

Note: The BladeCenter S unit supports one management module. The list command for this unit does not refer to primary and standby management modules.

mcad command

This command configures and displays the auto-discovery setting for the BladeCenter unit management channel.

Note: See the *BladeCenter Advanced Management Module User's Guide* for additional information about management channel auto discovery.

Table 51. mcad command

Function	What it does	Command	Valid targets
Display management channel auto-discovery status for BladeCenter unit	Displays the auto-discovery setting for the BladeCenter unit management channel. Valid states include: • Enabled • Disabled	mcad	-T system:mm[x] where x is the primary management-module bay number.
Enable / disable management channel auto-discovery for BladeCenter unit	Enable or disable management channel auto-discovery for the BladeCenter unit.	 mcad -e state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example:

To display the auto-discovery setting for the BladeCenter unit management channel, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

```
mcad -T mm[1]
```

To enable management channel auto-discovery for the BladeCenter unit, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

mcad -T mm[1] -e enabled

The following example shows the information that is returned from these commands:

```
system> mcad -T mm[1]
-e disabled
system> mcad -T mm[1] -e enabled
OK
system>
```

modactlog command

This command displays information about modules installed in all of the blade servers.

Table 52. modactlog command

Function	What it does	Command	Valid targets
Display blade server	Displays a list of modules installed	modactlog	-T system
module information and	in all blade servers, along with		
activity	their activity and VPD information.		

Example: To view the list of modules installed in all blade servers, along with their activity and VPD information, while the BladeCenter unit is set as the default command target, at the system> prompt, type modactlog

The following example shows the information that is returned from this command:

syste Bay	em> modactlog Name	FRU Number	FRU Serial No	Manuf. ID	Action	Timestamp
 14 11 syste	Fibre Channel Expansion Card cKVM card em>	59P6624 13N0842	J1RJH3CY18N YK328064418F	SLRM IBM	Added Added	15:51:18 02/09/2007 15:51:07 02/09/2007

Note: The BladeCenter S unit will also display information about the Direct Serial Attach Module and the storage modules.

monalerts command

This command displays and configures alerts that are monitored by the advanced management module.

Important: The monalertsleg command is no longer supported by the advanced management module firmware. Legacy alert monitoring that uses the monalertsleg command must transition to use of the monalerts command. Existing legacy alert settings are automatically mapped to the new alert categories as part of the transition.

Function	What it does	Command	Valid targets
Display monitored alert states	Displays the state of all alerts being monitored by the management module.	monalerts	-T system:mm[x] where x is the primary management-module bay number.
Set state for enhanced legacy alert categories	 Enables enhanced legacy alert categories. If enhanced legacy alert categories are enabled, alerts are configured using the monalerts command. If enhanced legacy alert categories can not be disabled once they have been enabled. 	 monalerts -ec state where state is enabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for all critical alerts	Enables or disables monitoring of all critical alerts.	 monalerts -ca state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 53. monalerts command

Table 53. monalerts command (continued)

Function	What it does	Command	Valid targets
Set monitoring state for blade device critical alerts	Enables or disables monitoring of blade device critical alerts.	<pre>monalerts -cb state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for I/O-module critical alerts	Enables or disables monitoring of I/O-module critical alerts.	<pre>monalerts -ciom state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where x is the primary management-module bay number.
Set monitoring state for storage-module critical alerts (BladeCenter S units only)	Enables or disables monitoring of storage-module critical alerts.	 monalerts -cstg state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Function	What it does	Command	Valid targets
Set monitoring state for chassis or system management critical alerts	Enables or disables monitoring of chassis or system management critical alerts.	<pre>monalerts -ccsm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for cooling device critical alerts	Enables or disables monitoring of cooling device critical alerts.	 monalerts -ccd state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for power module critical alerts	Enables or disables monitoring of power module critical alerts.	 monalerts -cpm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 53. monalerts command (continued)

Table 53.	monalerts command	(continued)
-----------	-------------------	-------------

Function	What it does	Command	Valid targets
Set monitoring state for all warning alerts	Enables or disables monitoring of all warning alerts.	<pre>monalerts -wa state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for blade device warning alerts	Enables or disables monitoring of blade device warning alerts.	<pre>monalerts -wb state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for I/O-module warning alerts	Enables or disables monitoring of I/O-module warning alerts.	<pre>monalerts -wiom state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Function	What it does	Command	Valid targets
Set monitoring state for storage-module warning alerts (BladeCenter S units only)	Enables or disables monitoring of storage-module warning alerts.	 monalerts -wstg state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for chassis or system management warning alerts	Enables or disables monitoring of chassis or system management warning alerts.	<pre>monalerts -wcsm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for event log warning alerts	Enables or disables monitoring of event log warning alerts.	<pre>monalerts -wel state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 53. monalerts command (continued)

Table 53. monalerts command (continued)

Function	What it does	Command	Valid targets
Set monitoring state for cooling device warning alerts	Enables or disables monitoring of cooling device warning alerts.	<pre>monalerts -wcd state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for power module warning alerts	Enables or disables monitoring of power module warning alerts.	<pre>monalerts -wpm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for all informational alerts	Enables or disables monitoring of all informational alerts.	<pre>monalerts -ia state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 53.	monalerts	command	(continued)
-----------	-----------	---------	-------------

Function	What it does	Command	Valid targets
Set monitoring state for blade device informational alerts	Enables or disables monitoring of blade device informational alerts.	<pre>monalerts -ib state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where x is the primary management-module bay number.
Set monitoring state for I/O-module informational alerts	Enables or disables monitoring of I/O-module informational alerts.	<pre>monalerts -iiom state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where x is the primary management-module bay number.
Set monitoring state for storage-module informational alerts (BladeCenter S units only)	Enables or disables monitoring of storage-module informational alerts.	 monalerts -istg state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 53. monalerts command (continued)

Function	What it does	Command	Valid targets
Set monitoring state for chassis or system management informational alerts	Enables or disables monitoring of chassis or system management informational alerts.	<pre>monalerts -icsm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for power state informational alerts	Enables or disables monitoring of power state (on/off) informational alerts.	<pre>monalerts -ipon state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for inventory change informational alerts	Enables or disables monitoring of inventory change (installed components) informational alerts.	<pre>monalerts -iinv state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 53.	monalerts	command	(continued)
-----------	-----------	---------	-------------

Function	What it does	Command	Valid targets
Set monitoring state for event log informational alerts	Enables or disables monitoring of event log informational alerts.	<pre>monalerts -iel state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for network change informational alerts	Enables or disables monitoring of network change informational alerts.	<pre>monalerts -inc state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for user activity informational alerts	Enables or disables monitoring of user activity informational alerts.	 monalerts -iua state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 53. monalerts command (continued)

Function	What it does	Command	Valid targets
Set monitoring state for cooling device informational alerts	Enables or disables monitoring of cooling device informational alerts.	 monalerts -icd state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set monitoring state for power module informational alerts	Enables or disables monitoring of power module informational alerts.	 monalerts -ipm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example: To enable monitoring of all critical alerts and event log warning alerts and disable monitoring of all informational alerts, while management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type monalerts -ca enabled -wel enabled -ia disabled

The following example shows the information that is returned from this command: system:mm[1]> monalerts -ca enabled -wel enabled -ia disabled OK system:mm[1]>

mt (media tray) command

This command sets and displays the blade server that is in control of the BladeCenter unit shared media tray.

Function	What it does	Command	Valid targets
Display media tray owner	Displays the number of the blade server that has media tray ownership and the global local and remote media tray switching states for all blade servers. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies. A return value of 0 indicates that no owner is set.	mt	-T system
Set media tray owner	Sets a blade server as the media tray owner.	 mt -b <i>blade_server</i> where <i>blade_server</i> is the blade bay that identifies the blade server. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies. A setting of 0 sets no owner. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system
Enable / disable local media tray switching globally	Enable or disable local media tray switching globally for all blade servers.	 mt -local <i>state</i> where <i>state</i> is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system

Table 54. mt command (continued)

Function	What it does	Command	Valid targets
Function Enable / disable remote media tray switching globally	What it does Enable or disable remote media tray switching globally for all blade servers.	Commandmt -remote statewhere state is enabled ordisabled.This command can onlybe run by users who haveone or more of thefollowing commandauthorities:• Supervisor• Chassis configurationSee "Commands and user	-T system
		authority" on page 8 for additional information.	

Example:

To set the media tray owner to the blade server in blade bay 1, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
mt -T system -b 1
```

To display the media tray owner and the global local and remote media tray switching states for all blade servers, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
mt -T system
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> mt -T system -b 1
OK
system:mm[1]> mt -T system
-b 1
-local enabled
-remote enabled
system:mm[1]>
```

nat command

This command sets and displays the network address table (NAT) settings for the specified I/O module.

Notes:

- 1. If the nat command is directed to an I/O module that does not support the network address table, the "NAT configuration is not supported on this I/O module" message is returned.
- 2. When setting values for an empty row in the network address table, all options must be specified together using a single command.

Function	What it does	Command	Valid targets
Display I/O-module network protocol settings	Displays the network port settings for the specified I/O module. Returned values include those in Table 56 on page 244.	nat	-T system:switch[x] where x is the I/O-module bay number.
Reset I/O-module network protocol settings	Resets all network address table settings for the specified I/O module to the default values. Default values are in Table 56 on page 244. You must activate any changes to the network protocol settings before they take effect.	 nat -reset This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where <i>x</i> is the I/O-module bay number.
Activate I/O-module network protocol settings	Activates all network port settings for the specified I/O module, putting them into effect.	 nat -activate This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.

Table 55. nat command

Table 55.	nat command	(continued)
-----------	-------------	-------------

Function	What it does	Command	Valid targets
Set protocol name for row in I/O-module NAT table	Sets a protocol name for the specified row in the NAT table for the specified I/O module.	 nat -index -pn protocol_name where: index is a number from 1 to 10 that corresponds to a row in the NAT table. protocol_name is a text string with a maximum length of 19 characters and no spaces. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where <i>x</i> is the I/O-module bay number.
Set protocol ID for row in NAT table	Sets a protocol ID for the specified row in the NAT table for the specified I/O module.	 nat -index -pi protocol_id where: index is a number from 1 to 10 that corresponds to a row in the NAT table. protocol_id is TCP or UDP. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system: switch [x] where x is the I/O-module bay number.

Table 55. nat command (continued)

Function	What it does	Command	Valid targets
Set internal port number for row in NAT table	Sets the internal port number for the specified row in the NAT table for the specified I/O module.	 nat -index -ip port_number where: index is a number from 1 to 10 that corresponds to a row in the NAT table. port_number is between 1 and 65534, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for 	-T system:switch[x] where <i>x</i> is the I/O-module bay number.
Set external port number for row in NAT table	Sets the external port number for the specified row in the NAT table for the specified I/O module.	 additional information. nat -index -ep port_number where: index is a number from to 10 that corresponds to a row in the NAT table. port_number is between 1000 and 65534, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where <i>x</i> is the I/O-module bay number.

Table 55. nat command (continued)

Function	What it does	Command	Valid targets
Set state for row in NAT table	Enables or disables the specified row in the NAT table for the specified I/O module.	 nat <i>-index</i> -en <i>state</i> where: <i>index</i> is a number from 1 to 10 that corresponds to a row in the NAT table. <i>state</i> is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system: switch [x] where x is the I/O-module bay number.

Table 56. Default NAT table values for nat command

Index	Protocol Name	Protocol ID	Internal Port	External Port	State
muex	1 vuine	1101000112	internal i ort	External 1 oft	State
1	HTTP	ТСР	80	1080	Enabled
2	TELNET	ТСР	23	1023	Enabled
3	HTTPS	TCP	43	1043	Enabled
4	SSH	TCP	22	1022	Enabled
5	SNMP	UDP	161	1161	Enabled
6 through 10			Unset		

Example:

To display network protocol settings for the I/O module in I/O-module bay 3, while I/O-module bay 3 is set as the persistent command environment, at the system:switch[3]> prompt, type

nat

The following example shows the information that is returned from this command: system:switch[3]> nat

Index	Protocol Name	Protocol ID	Internal Port	External Port	Enabled
1	HTTP	ТСР	80	1080	enabled
2	TELNET	ТСР	23	1023	enabled
3	HTTPS	ТСР	43	1043	enabled
4	SSH	ТСР	22	1022	enabled
5	SNMP	UDP	161	1161	enabled
system:	switch[3]>				
ntp (network time protocol) command

This command configures and displays the management-module network time protocol (NTP) settings.

Table 57.	ntp	command
-----------	-----	---------

Function	What it does	Command	Valid targets
Display management module NTP settings	 Displays the NTP settings for the specified I/O module. Possible return values are: -en <i>state</i> (enabled, disabled) -i <i>ipaddress/hostname</i> (IP address or hostname of the NTP server) -f <i>update_frequency</i> (NTP update frequency, in minutes) -v3en <i>state</i> (enabled, disabled) -v3 key_info (NTP v3 authentication entry) 	ntp	-T system:mm[x] where x is the primary management-module bay number.
Enable / disable NTP	Enables or disables NTP for the management-module.	 ntp -en state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
NTP server IP address or hostname - set	Checks syntax and sets the IP address or hostname of the NTP server.	 ntp -i <i>ipaddress/hostname</i> where <i>ipaddress/hostname</i> is the IP address or hostname of the NTP server. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 57. ntp command (continued)

Function	What it does	Command	Valid targets
NTP update frequency - set	Sets how often the management module clock is automatically updated by the NTP server.	 ntp -f <i>time</i> where <i>time</i> is the NTP update frequency, in minutes with a maximum value of 45000. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
NTP - Enable / disable V3 authentication	Enables or disables V3 authentication between the management-module and the NTP server. Note: The NTP server authentication key must be set, using the ntp -v3 command option, before enabling V3 authentication.	ntp -v3en <i>state</i> where <i>state</i> is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
NTP server authentication key - set	 Sets the v3 authentication key that the management module uses to access the NTP server. The authentication key contains the following values: Key index: An NTP server can be configured with one or more key entries. The key index specifies which key the server expects the client to authenticate with. Key type: The advanced management module supports only the MD5 key type. Key: The key is an 8-character ASCII string. 	 ntp -v3 key_index key_type key where: key_index is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed. key_type is M (MD5). key is a 8-character ASCII string. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 57. ntp command (continued)

Function	What it does	Command	Valid targets
NTP clock- synchronize	Synchronizes the management-module clock with the NTP server. (You must configure a valid NTP server before you can synchronize.)	 ntp -synch This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

To display NTP settings for the management module, while management module 2 is set as the persistent command environment, at the system:mm[2]> prompt, type ntp

The following example shows the information that is returned from this command:

```
system:mm[2]> ntp
-en enabled
-i timeserver
-f 5
-v3en disabled
-v3 Not configured
NTP is disabled.
system:mm[2]>
```

ping command

This command tests the internal communication path between the advanced management module and a BladeCenter component by sending it a ping request.

Table 58. ping command

Function	What it does	Command	Valid targets
Display I/O module IP addresses	Displays a list of IP addresses for the specified I/O module.	 ping -i This command can only be run by users who have one or more of the following command authorities: Supervisor, Operator (general operator, not chassis operator) I/O module administration, I/O module configuration I/O module operator See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where <i>x</i> is the I/O-module bay number.
Ping IP address	Pings the specified IP address to test communication between it and the management module. Note: This command tests communication paths, including IP addresses outside of the BladeCenter unit.	<pre>ping -i ip_address where ip_address is the IP address for a component installed in the BladeCenter unit. All users can attempt to ping a specific IP address.</pre>	This command will attempt to ping the specified IP address, regardless of command target, including IP addresses outside of the BladeCenter unit.

Table 58. ping command (continued)

Function	What it does	Command	Valid targets
Ping I/O-module IP address	Pings the specified IP address of an I/O module to test communication.	 ping -i <i>index</i> where <i>index</i> is the index number for the I/O-module IP address to ping. Use the ping -i command, with no arguments, to list available IP addresses and their index numbers. This command can only be run by users who have one or more of the following command authorities: Supervisor, Operator (general operator, not chassis operator) I/O module administration, I/O module configuration I/O module operator See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.

Example: To display list of IP addresses for the I/O module in bay 1, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

ping -i -T switch[1]

To ping the first IP address of the I/O module in bay 1 using an index number, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

ping -i 1 -T switch[1]

To ping the first IP address of the I/O module in bay 1 using an IP address, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

ping -i 10.13.3.171

The following example shows the information that is returned from these commands:

system> ping -i -T switch[1]
1. 10.13.3.171
2. FE80:0000:0000:0000:0218:B1FF:FE9F:9000
system> ping -i 1 -T switch[1]
Reply from 10.13.3.171: bytes=64 time=4.150ms
Reply from 10.13.3.171: bytes=64 time=0.392ms
Reply from 10.13.3.171: bytes=64 time=0.400ms
Reply from 10.13.3.171: bytes=64 time=0.389ms
system> ping -i 10.13.3.171
Reply from 10.13.3.171: bytes=64 time=0.418ms
Reply from 10.13.3.171: bytes=64 time=0.417ms
Reply from 10.13.3.171: bytes=64 time=0.362ms
Reply from 10.13.3.171: bytes=64 time=6.90ms
system>

pmpolicy command

This command displays and sets the power management policies for the BladeCenter unit.

Table 59.	pmpolicv	command
rubic cc.	pripolicy	oonnana

Function	What it does	Command	Valid targets
Display power management policy	Displays the current power management policy for all domains.	pmpolicy	-T system
Display power management policy for a BladeCenter S unit	Displays both the current and available power management policies for a BladeCenter S unit, that has a single power domain.	pmpolicy <i>domain</i> where <i>domain</i> is pd	-T system
Display power management policy for domain	Displays both the current and available power management policies for the specified power domain in a BladeCenter unit that supports two power domains.	<pre>pmpolicy domain where domain is: pd1 (power domain 1) pd2 (power domain 2)</pre>	-T system
Set power management policy for domain	Set power management policy for specified power domain.	 pmpolicy domain -pm policy where domain is: pd1 (power domain 1) pd2 (power domain 2) where policy is: acred (ac power source redundancy policy - BladeCenter S units only) acredov (ac power source redundancy policy, with blade throttling - BladeCenter S units only) redwoperf (power module redundancy, no oversubscription) redwperf (power module redundancy with power throttling) nonred (no power management policy) This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system

To view the current policy and the available policies for a power domain 1, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

pmpolicy pd1

The following example shows the output generated by this command. system> pmpolicy pd1

```
Power Domain 1
-----
*** Current Policy ***
Power Management Policy:
       Power Module Redundancy with Blade Throttling Allowed (redwperf)
Description:
        Very similar to Power Module Redundancy. This policy allows you to
        draw more total power; however, capable blades may be allowed to
       throttle down if one Power Module fails.
Power Supply Failure Limit:
                                 1
Maximum Power Limit (Watts):
                               3380
Your Estimated Utilization:
                                  5%
*** Available Policies ***
Power Management Policy:
       Power Module Redundancy (redwoperf)
Description:
       Intended for a single AC power source into the chassis where each
        Power Module is on its own dedicated circuit. Total allowed power
       draw is limited to one less than the number of Power Modules when
       more than one Power Module is present. One Power Module can fail
       without affecting blade operation. Multiple Power Module failures can
        cause the chassis to power off. Note that some blades may not be
       allowed to power on if doing so would exceed the policy power limit.
Power Supply Failure Limit:
                                 1
                               2880
Maximum Power Limit (Watts):
Your Estimated Utilization:
                                  6%
Power Management Policy:
       Basic Power Management (nonred)
Description:
        Total allowed power is higher than other policies and is limited only
        by the total power capacity of all the Power Modules up to the
       maximum of chassis power rating. This is the least conservative
       approach, since it does not provide any protection for AC power
       source or Power Module failure. If any single power supply fails,
       blade and/or chassis operation may be affected.
Power Supply Failure Limit:
                                  0
Maximum Power Limit (Watts):
                               3520
Your Estimated Utilization:
                                  5%
NOTE:
Power Supply Failure Limit: This is the maximum number of power supplies
                             that can fail while still guaranteeing the
                             operation of the domain in the selected policy.
 Your Estimated Utilization: The estimated utilization is based on the maximum
                             power limit allowed in this policy and the current
                             aggregated power in use of all components in the
                             domain.
```

system>

portcfg command

This command configures and displays the settings for the advanced management-module serial port.

rabie co. pertorg communation	Table	60.	portcfg	command
-------------------------------	-------	-----	---------	---------

Function	What it does	Command	Valid targets
Display management-module serial port configuration	Displays the current configuration of the management-module serial port. Possible return values are: • -b baud_rate • -p parity • -s stop_bits	portcfg -coml	-T system:mm[x] where x is the primary management-module bay number.
Set management-module serial port baud rate	Checks syntax and sets the baud (communications) rate of the management-module serial port.	<pre>portcfg -com1 -b baud_rate where baud_rate is 2400, 4800, 9600, 19200, 38400, or 57600. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management-module serial port parity	Checks syntax and sets the parity of the management-module serial port.	portcfg -com1 -p parity where parity is • none • odd • even • mark • space This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.

Table 60. portcfg command (continued)

Function	What it does	Command	Valid targets
Set management-module	Checks syntax and sets the number	<pre>portcfg -com1 -s stop_bits</pre>	-T system:mm[x]
serial port stop bits	management-module serial port.	where <i>stop_bits</i> is 1 or 2.	where x is the primary
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	

To display the configuration for the management-module serial port, while management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type

portcfg -com1

To set the baud rate for the management-module serial port to 9600, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type portcfg -com1 -b 9600

The following example shows the information that is returned from these two commands:

```
system:mm[1]> portcfg -com1
-b 2400
-p none
-s 1
system:mm[1]> portcfg -com1 -b 9600
These configuration changes will become active after the next reset of the MM.
system:mm[1]>
```

ports command

This command sets and displays the network port configuration settings for the advanced management module.

Note: Changes to the -ftpdp, -ftpe, -ftpp, -httpp, -httpsp, -rpp, -smashse, -smashsp, -smashte, -smashtp, -snmplae, -snmp3ae, -snmpap, -snmpte, -snmptp, -sshe, -sshp, -tcme, -telnete, -telnetp, -telnett, or -tftpp settings become active immediately. Changes to the remaining settings become active after the next reset of the advanced management module.

Function	tion What it does		Valid targets
Display network port settings	Displays the network port settings for the management module. Returned values are: • -ftpp <i>FTP_prt_num</i> • -httpp <i>HTTP_prt_num</i> • -httpsp <i>HTTPS_prt_num</i> • -slpp <i>SLP_prt_num</i> • -slpp <i>SLP_prt_num</i> • -smashsp <i>secSMASH_SSH_prt_num</i> • -smashtp <i>SMASH_telnet_prt_num</i> • -smapap <i>SNMP_agent_prt_num</i> • -snmptp <i>SNMP_traps_prt_num</i> • -snmptp <i>SNMP_traps_prt_num</i> • -sshp <i>SSH_prt_num</i> • -stcmp <i>secure_tcmp</i> • -tcmp <i>TCP_cmd_md_port</i> • -telnetp <i>_Telnet_prt_num</i> • ftpe <i>FTP_state</i> • -httpse <i>HTTPS_prt_state</i> • httpse <i>HTTPS_prt_state</i> • rde <i>rd_state</i> • -rde <i>rd_state</i> • -rde <i>rd_state</i> • -smashte <i>SMASH_telnet_state</i> • -smashte <i>SMASH_telnet_state</i> • -smashte <i>SMASH_telnet_state</i> • -smashte <i>SMASH_telnet_state</i> • -snmp1ae <i>SNMPv1_agent_state</i> • -snmp1ae <i>SNMPv1_agent_state</i> • -snmp1ae <i>SNMPv1_agent_state</i> • -snmp1ae <i>SNMPv1_agent_state</i> • -snmp1ae <i>SNMPv1_agent_state</i> • -stcme <i>secure_TCP_cmd_mode</i> • -tcme <i>TCP_cmd_mode_state</i> • -telnete <i>Telnet_prt_state</i> • -telnete <i>Telnet_prt_state</i> • -telnete <i>Telnet_prt_state</i> • -telnete <i>Telnet_prt_state</i> • -telnete <i>Telnet_prt_state</i> • -telnete <i>Telnet_prt_state</i>	ports	-T system:mm[x] where x is the primary management-module bay number.
Display open management module ports	Displays the management module ports that are currently open.	ports -open	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 61. ports command

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Reset network port	Resets all network port settings for	ports -reset	-T system:mm[x]
Settings	default values. Default values are: - ftpp: 21 - ftpdp: 20 - httpp: 80 - httpsp: 443 - rpp: 3900 - slpp: 427 - tcmp: 6090 - smashtp: 50023 - smashsp: 50022 - snmpap: 161 - snmptp: 162 - sshp: 22 - stcmp: 6091 - telnetp: 23 - tftpp: 69	This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	where <i>x</i> is the primary management-module bay number.
Set FTP port number	Sets the port number for the	ports -ftpp FTP_prt_num	-T system:mm[x]
	management module FTP port.	where <i>FTP_prt_num</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set FTP data port number	Sets the port number for the management module FTP data	ports -ftpdp FTP_data_prt_num	-T system:mm[x]
	port.	where <i>FTP_data_prt_num</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Set HTTP port number	Sets the port number for the management module HTTP port.	<pre>ports -httpp HTTP_prt_num where HTTP_prt_num is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information</pre>	-T system:mm[x] where x is the primary management-module bay number.
Set HTTPS port number	Sets the port number for the management module HTTPS port.	ports -httpsp <i>HTTPS_prt_num</i> where <i>HTTPS_prt_num</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set Remote Presence port number	Sets the remote presence port number for the management module remote presence port.	<pre>ports -rpp rpp_prt_num where rpp_prt_num is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Set SLP port number	Sets the SLP port number.	<pre>ports -slpp SLP_prt_num</pre>	-T system:mm[x]
		where <i>SLP_prt_num</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set SMASH Telnet port number	Sets the port number for the management module SMASH command-line processor over Telnet port.	<pre>ports -smashtp SMASH_telnet_prt_num where SMASH_telnet_prt_num is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Set SNMP agent port number	Sets the port number for the management module SNMP agent port.	ports -snmpap SNMP_agent_prt_num where SNMP_agent_prt_num is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set SNMP traps port number	Sets the port number for the management module SNMP traps port.	<pre>ports -snmptp SNMP_traps_prt_num where SNMP_traps_prt_num is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where x is the primary management-module bay number.

Table 61.	ports	command	(continued)
-----------	-------	---------	-------------

Function	What it does	Command	Valid targets
Set command mode port number	Sets the TCP command mode port number.	ports -tcmp TCP_cmd_md_prt_num	-T system:mm[x]
		where <i>TCP_cmd_md_prt_num</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set secure command	Sets the secure TCP command	ports -stcmp secure_tcmp	-T system:mm[x]
mode port number	mode port number.	where <i>secure_tcmp</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set SSH port number	Sets the port number for the	ports -sshp SSH_prt_num	-T system:mm[x]
	management module 55ri port.	where <i>SSH_prt_num</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Set Telnet port number	Sets the port number for the management module Telnet port.	ports -telnetp Telnet prt num	-T system:mm[x]
		where <i>Telnet_prt_num</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set TFTP port number	Sets the port number for the	ports -tftpp	-T system:mm[x]
	inanagement moutie friff port.	where <i>TFTP_prt_num</i> is from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Enable / disable FTP	Enables or disables FTP for the management module.	ports -ftpe <i>state</i>	-T system:mm[x]
		where <i>state</i> is on or off.	where <i>x</i> is the primary
		This command can only be run by users who have one or more of the following command authorities:SupervisorChassis configuration	bay number.
		See "Commands and user authority" on page 8 for additional information.	

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Enable / disable HTTPS port	Enables or disables the management module HTTPS port.	 ports -httpse state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set KVM port state	Sets the KVM port state to on or off.	<pre>ports -kvme state where state is on or off. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable NTP	Enables or disables NTP for the management module.	 ports -ntpe state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Enable / disable RDE	Enables or disables remote disk for the management module.	 ports -rde state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable RDOCE	Enables or disables remote disk on card for the management module.	 ports -rdoce state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Enable / disables SLP	Enables or disables SLP for the management module.	<pre>ports -slpe state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where x is the primary management-module bay number.

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Enable / disable secure SMASH over SSH	Enables or disables the secure SMASH command-line processor over SSH for the management module.	 ports -smashse state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable SMASH over Telnet	Enables or disables SMASH command-line processor over Telnet for the management module.	<pre>ports -smashte state where state is on or off. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable SNMPv1 agent	Enables or disables the SNMPv1 agent for the management module.	<pre>ports -snmplae state where state is on or off. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Enable / disable SNMPv3 agent	Enables or disables the SNMPv3 agent for the management module.	<pre>ports -snmp3ae state where state is on or off. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for • different in formation</pre>	-T system:mm[x] where x is the primary management-module bay number.
Enable / disable SNMP traps	Enables or disables the SNMP traps for the management module.	 ports -snmpte state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable SSH port	Enables or disables the management module SSH port.	 ports -sshe <i>state</i> where <i>state</i> is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Enable / disable TCP command mode	Enables or disables the TCP command mode for the management module.	<pre>ports -tcme state where state is on or off. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set number of TCP command mode connections	Turns the TCP command mode on or off, or sets the maximum number of connections explicitly. Note: Any number of connections (1 through 20) displays a status of on. Zero connections displays a status of off.	ports -tcme port_mode where port_mode is on (1 connection), off (no connections), or a number between 0 and 20, inclusive, that indicates the maximum number of TCP session connections. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable secure TCP command mode	Enables or disables the secure TCP command mode for the management module.	 ports -stcme <i>state</i> where <i>state</i> is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Set number of secure TCP command mode connections	 Turns the secure TCP command mode on or off, or sets the maximum number of connections. Notes: On a write operation, the maximum number of connections can be set explicitly (0-20), or it can be turned on (1 connection) or off (0 connections). On a read operation, off means 0 connections, and on means 1 or more connections. The total session count of TCM and STCM is limited to 20. 	<pre>ports -stcme port_mode where port_mode is on (1 connection), off (no connections), or a number between 0 and 20, inclusive, that indicates the maximum number of TCP session connections. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable Telnet port	Enables or disables the management module Telnet port.	 ports -telnete state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable TFTP	Enables or disables TFTP for the management module.	 ports -tftpe <i>state</i> where <i>state</i> is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 61.	ports	command	(continued)
-----------	-------	---------	-------------

Function	What it does	Command	Valid targets
Set FTP timeout	Sets the FTP timeout value for the	ports -ftpt <i>timeout</i>	-T system:mm[x]
	management module.	where <i>timeout</i> is from 0 seconds (no timeout) to 4294295967 seconds, inclusive.	where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set TCP command-mode	Sets the TCP command-mode	ports -tcmt <i>timeout</i>	-T system:mm[x]
timeout timeout value for module.	module.	where <i>timeout</i> is from 0 seconds (no timeout) to 4294295967 seconds, inclusive.	where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set Telnet port timeout	Sets the Telnet port timeout value	ports -telnett <i>timeout</i>	-T system:mm[x]
fc	for the management module.	where <i>timeout</i> is from 0 seconds (no timeout) to 4294295967 seconds, inclusive.	where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Display network port settings for I/O module	Displays the network port settings for the I/O module. These settings can include: • cable compatibility • cable length • cable type • data rate • label • port index • port media • port width • protocol • speed • speed setting • available speeds • state • state setting • type • vendor Note: Other device specific values might be returned.	ports	-T system:switch[x] where x is the I/O-module bay number.
Enable or disable port for I/O module	Enables or disables specified port on specified I/O module.	 ports -port_index -state state where port_index is from 1 to 65535, inclusive. state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module configuration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where <i>x</i> is the I/O module bay number.

Table 61. ports command (continued)

Function	What it does	Command	Valid targets
Sets speed of port for I/O module	Sets speed of specified port on I/O modules that support this feature.	<pre>ports -port_index -speed speed_setting where • port_index is from 1 to 65535, inclusive. • speed_setting specifies the port speed, in terms of: - multiplier - units, m or g for megabits or gigabits - duplex mode, h or f for half or full For example, 100mh sets the port speed to 100 Mbps half-duplex. This command can only be run by users who have one or more of the following command authorities: • Supervisor • I/O module configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:switch[x] where x is the I/O-module bay number.

To display the management module network port settings, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

ports

To disable FTP for the management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type ports -ftpe off

The following example shows the information that is returned from these two commands:

```
system:mm[1]> ports
-ftpp 21
-ftpdp 20
-httpp 80
-httpsp 443
-rpp 3900
-slpp 427
-smashsp 50022
-smashtp 50023
-snmpap 161
-snmptp 162
-sshp 22
```

```
-stcmp 6091
-tcmp 6090
-telnetp 23
-tftpp 69
-ftpe on
-httpse off
-kvme on
-ntpe off
-rde off
-rdoce on
-slpe on
-smashse on
-smashte on
-snmplae on
-snmp3ae on
-snmpte on
-sshe off
-stcme off
-tcme off
-telnete on
-tftpe off
-tcmt 0
-telnett 10000
-ftpt 300
system:mm[1]> ports -ftpe off
Changes to -sshe, -sshp, -smashse, -smashte, -smashsp, -telnete, -telnetp, -telnett, -smashtp, -snmpte, -tcme, -tcmp, -tcmt, -stcme, -stcmp, -rpp,
-httpp,-httpse, -httpsp, -ftpe or -tftpe will become active immediately.
0K
system>
```

power command

This command turns on and turns off blade servers and I/O modules. For advanced management modules installed in BladeCenter HT units, it also turns on and turns off the alarm panel module and network clock module.

Table 62. power command

Function	What it does	Command	Valid targets
Power on	Turns on the specified command target.	 power -on This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration (for blade server) I/O module administration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	 -T system:blade[x] -T system:switch[x] -T system:tap (BladeCenter HT units only) -T system:ncc[x] (BladeCenter HT units only) where x is the blade server, I/O-module bay, or network clock module number.
Power on to command console	Opens a command console with an SOL session when the specified blade server is turned on.	 power -on -c This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration and blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade server bay number.
Power off	Turns off the specified command target.	 power -off This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration (for blade server) I/O module administration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	 T system:blade[x] T system:switch[x] T system:tap (BladeCenter HT units only) T system:ncc[x] (BladeCenter HT units only) where x is the blade server, I/O-module bay, or network clock module number.

Table 62. power command (continued)

Function	What it does	Command	Valid targets
Shutdown and power off blade server	Shuts down the operating system and turns off the specified blade server.	 power -softoff This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade server number.
Power cycle	Cycles power for the specified blade server or I/O module. If the blade server or I/O module is off, it will turn on. If the blade server or I/O module is on, it will turn off and then turn on.	 power -cycle This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration (for blade server) I/O module administration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] -T system:switch[x] where x is the blade server or I/O-module bay number.
Power cycle to command console	Cycles power for the specified blade server. If the blade server is off, it opens a command console with an SOL session when it is turned on. If the blade server is on, it will turn off and then turn on.	 power -cycle -c This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration and blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade server bay number.
Display power state	Displays the current power state for the specified blade server or I/O module. Possible return values are off, on, standby, or hibernate.	power -state	-T system:blade[x] -T system:switch[x] where x is the blade server or I/O-module bay number.

Table 62. power command (continued)

Function	What it does	Command	Valid targets
Enable / disable Wake on LAN globally	Enables or disables Wake on LAN globally for all blade servers.	 power -wol state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user 	-T system
		authority" on page 8 for additional information.	
Enable / disable Wake on LAN for blade server	Enables or disables Wake on LAN for the specified blade server.	 power -wol state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade server bay number.
Enable / disable local power control globally	Enables or disables local power control globally for all blade servers.	 power -local state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system

Table 02. power command (commucu)	Table 62.	power	command	(continued)
-----------------------------------	-----------	-------	---------	-------------

Function	What it does	Command	Valid targets
Enable / disable local power control for blade server	Enables local power control for the specified blade server.	 power -local state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade server bay number.
Set automatic power-on policy for BladeCenter unit	Sets the automatic power-on policy for the BladeCenter unit. Changes to the power-on policy setting take effect after the next cold start of the BladeCenter unit.	 power -ap <i>policy</i> where <i>policy</i> is: restore: all blade servers that were previously on will be powered on auto: when power is applied to the BladeCenter unit, all blade servers will be powered on manual: all blade servers will remain off until manually powered on This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system
Display fast POST setting for I/O module	Displays the current fast POST setting for specified I/O module. Note: This target works only for some I/O modules.	power	-T system:switch[x] where x is the I/O-module bay number.

Table 62. power command (continued)

Function	What it does	Command	Valid targets
Enable / disable fast POST for I/O module	Enables or disables fast POST globally for the specified I/O module. Note: This option works only for some I/O modules.	 power -fp state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.
Display POST status for I/O module	 Displays the POST status for the specified I/O module. If the command is run while POST is in progress, it returns the level of POST that is currently in process. If the command is run after POST is complete, it displays one of the following return values: The POST results could not be read. message displays if there was an internal error during POST. The POST results not complete: hex_code message displays if POST results are not available after POST completes. If POST returns valid results, one of the following messages displays: <i>hex_code</i>: Base internal function failure detected. <i>hex_code</i>: Internal interface failure detected. <i>hex_code</i>: External interface failure detected. <i>hex_code</i>: Cannot decode POST successfully. <i>hex_code</i>: Cannot decode POST result code. The Invalid POST results. message displays if none of the above conditions is true. 	power -state -post	-T system: switch [x] where x is the I/O-module bay number.

To display the power state for the blade server in blade bay 5, while this blade server is set as the persistent command environment, at the system:blade[5]> prompt, type

power -state

To turn on the blade server in blade bay 5, while this blade server is set as the persistent command environment, at the system:blade[5]> prompt, type power -on

To display the power state for the blade server in blade bay 5 again, while this blade server is set as the persistent command environment, at the system:blade[5]> prompt, type
power -state

The following example shows the information that is returned from these three commands:

```
system:blade[5]> power -state
Off
system:blade[5]> power -on
OK
system:blade[5]> power -state
On
system:blade[5]>
```

rdoc command

This command displays volume information for remote disk-on-card local storage on the advanced management module. The command also allows you to mount, unmount, or map a file image to this device.

Function	What it does	Command	Valid targets
Display advanced management module volume information	Displays the remote disk-on-card volume information for local storage on the advanced management module. Volume information returned includes: • Health condition • Size • Amount of free space	rdoc	-T system:mm[x] where <i>x</i> is the primary management module bay number.
Map file as advanced management module volume image	Maps the specified file as the active image for the remote disk-on-card local storage volume on the advanced management module.	 rdoc -map <i>filename</i> where <i>filename</i> is the name of the file to be mapped as the active remote disk-on-card image. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system:mm[<i>x</i>] where <i>x</i> is the primary management module bay number.
Mount advanced management module volume	Mounts the remote disk-on-card local storage volume on the advanced management module. Note: The advanced management module will only mount the first partition, if the volume has multiple partitions.	 rdoc -mount This command can only be run by users who have one or more of the following command authorities: Supervisor Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management module bay number.
Unmount advanced management module volume	Unmounts the remote disk-on-card local storage volume on the advanced management module.	 rdoc -unmount This command can only be run by users who have one or more of the following command authorities: Supervisor Blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management module bay number.

Example: To display volume information for local storage on the advanced management module in bay 1, while this management module is set as the persistent command environment, at the system:mm[1]> prompt, type rdoc

The following example shows the information that is returned from this command: system:mm[1]> rdoc Volume 0 Health: good Volume Size: 73108480 (Bytes) Free Size: 69120000 (Bytes) system:mm[1]>

read command

This command restores the management-module configuration that was previously saved to the BladeCenter unit chassis or to a file.

Configurations are saved to the BladeCenter unit chassis or to a file using the "write command" on page 413.

Table 64. read command

Function	What it does	Command	Valid targets
Display management-module automatic configuration setting	Displays the automatic configuration setting (-auto command option) of the management module.	read	-T system:mm[x] where x is the primary management-module bay number.
Restore management-module configuration from BladeCenter unit midplane	Restores the management-module configuration from an image that was previously saved to the BladeCenter unit midplane.	 read -config chassis This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Restore management-module configuration from file (no encryption)	Restores the management-module configuration from an image that was previously saved to a file while data encryption was not enabled for the BladeCenter unit.	 additional information. read -config file -1 <i>filename</i> -i <i>ip_address</i> where: <i>filename</i> is the name of the configuration file. <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server where the configuration file is located. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Function	What it does	Command	Valid targets
---	--	--	--
Restore management-module configuration from file (encryption)	Restores the management-module configuration from an image that was previously saved to a file while data encryption was enabled for the BladeCenter unit. Note: When a configuration file was created with a pass-phrase (encryption enabled), if this configuration file is restored on the same management module, the pass-phrase entered during restoration is ignored.	 read -config file -1 filename -i ip_address -p passphrase where: filename is the name of the configuration file. ip_address is the IPv4 or IPv6 IP address of the TFTP server where the configuration file is located. "passphrase" is the quote-delimited pass-phrase that was used to save the original configuration file. Maximum pass-phrase length is 1600 characters. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable automatic management-module configuration	Enables automatic configuration of the management module, based on settings stored in the BladeCenter unit midplane, when the management module is installed. Note: The -auto option can only be used when the management-module configuration was stored to the BladeCenter unit midplane.	 read -config chassis -auto on This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 64. read command (continued)

Table 64. read command (continued)

Function	What it does	Command	Valid targets
Disable automatic management-module configuration	Disables automatic configuration of the management module, based on settings stored in the BladeCenter unit midplane, when the management module is installed.	 read -config chassis -auto off This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example:

To restore the management-module configuration from an image previously saved to the BladeCenter unit chassis, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

read -config chassis

The following example shows the information that is returned from this command:

system:mm[1]> read -config chassis
OK
Configuration restore from the chassis was successful
Restart the MM for the new settings to take effect
system:mm[1]>

remacccfg command

This command displays and configures the remote presence access to one of the BladeCenter units from the chassis.

Table 65.	remacccfg	command

Function	What it does	Command	Valid targets
Display remote presence access	Displays the current settings for the remote presence access.	 remacccfg This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set remote presence disconnection mode	 Sets the remote presence disconnection mode. Notes: The current connected client cannot be disconnected if no mode is specified (nodisconnection as default). If forcedisconnection or accessrequest is specified, the current connected client can be disconnected directly without any request or after getting a disconnection request and the disconnection is allowed. 	<pre>remacccfg -mode mode where mode is nodisconnection, forcedisconnection, or accessrequest. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set session timeout interval	Sets the custom value for the remote presence session timeout. Note: If no value is specified, the default value of 60 minutes will be used.	 remacccfg -sto timeout where timeout is from 1 to 30,000 minutes, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 65. remacccfg command (continued)

Function	What it does	Command	Valid targets
Set session request timeout interval	Sets the custom value for the remote presence session request timeout. Note: If no value is specified, the default value of 60 seconds will be used.	 remacccfg -srto timeout where timeout is from 1 to 255 seconds, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set session request retry timeout interval	Sets the custom value for the remote presence session request retry timeout. Note: If no value is specified, the default value of 60 seconds will be used.	<pre>remacccfg -srrto timeout where timeout is from 1 to 255 seconds, inclusive. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set session lost timeout interval	Sets the custom value for the remote presence session lost timeout. Note: If no value is specified, the default value of 10 minutes will be used.	 remacccfg -slto timeout where timeout is from 1 to 255 minutes, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

remotechassis command

This command displays and manages the list of BladeCenter units that the management module discovers on the network.

Note: The advanced management module that runs the remote hassis command is also included in all lists.

Table 66. remotechassis command

Function	What it does	Command	Valid targets
Display complete list	Displays a list of all BladeCenter units that the management module discovers on the network. The list includes the following information about each BladeCenter unit: • Name • IP address • Status • Firmware level • Type • Serial number • FRU number • Chassis serial number • Chassis FRU number • Chassis machine-type model (MTM) • Chassis UUID	remotechassis	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display list grouped by health status	Displays a list of names for BladeCenter units that the management module discovers on the network. The list is grouped by health status.	remotechassis -health	-T system:mm[x] where x is the primary management-module bay number.
Display list filtered by IP address	Displays a list of BladeCenter units that the management module discovers on the network, filtered by the specified IP address. The list includes the following information about each BladeCenter unit: • Name • IP address • Status • Firmware level • Type • Serial number • FRU number • Chassis serial number • Chassis FRU number • Chassis machine-type model (MTM) • Chassis UUID	remotechassis -ip <i>ip_address</i> where <i>ip_address</i> is an IP address pattern that uses the asterisk (*) as a wildcard (for example; 201.47.123.*).	-T system:mm[x] where x is the primary management-module bay number.

Table 66. remotechassis command (continued)

Function	What it does	Command	Valid targets
Display list filtered by name	Displays a list of BladeCenter units that the management module discovers on the network, filtered by the specified name. The list includes the following information about each BladeCenter unit: • Name • IP address • Status • Firmware level • Type • Serial number • FRU number • Chassis serial number • Chassis FRU number • Chassis FRU number • Chassis machine-type model (MTM)	remotechassis -name <i>name</i> where <i>name</i> is a name pattern that uses the asterisk (*) as a wildcard (for example; WebServer*).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Clear list	Clears the list of BladeCenter units that the management module discovered on the network.	remotechassis -clear	-T system:mm[x] where x is the primary management-module bay number.

Example:

To list all BladeCenter units on the network with a name starting with "WebServer", while management module 1, that does not support IPv6, is set as the persistent command environment, at the system:mm[1]> prompt, type remotechassis -name WebServer*

The following example shows the information that is returned from this command:

system:mm[1]> remotechassis -name WebServer*
Running chassis discovery...

Running chussi	5 015000019
Name:	WebServer001
IP:	145.48.204.212
Status:	normal
Firmware:	BPET25L,CNETMNUS.PKT,01-08-07,37,1
Type:	management-module
Serial:	0J1M9E585630
FRU:	25R5777
Chassis Serial	: 23A2343
Chassis FRU:	25R5780R5780
Chassis MTM:	8852222
Chassis UUID:	4E349451FA8011D9B10C89E0183AD13D
Name:	WebServer002
IP:	145.48.204.222
Status:	normal
Firmware:	BPET25L,CNETMNUS.PKT,01-08-07,37,1
Type:	management-module
Serial:	0JIM9E585656
FRU:	25R5777
Chassis Serial	: 23A2356
Chassis FRU:	25R5780R5780

To list all BladeCenter units on the network with a name starting with "SYSTEM*", while management module 1, that supports IPv6, is set as the persistent command environment, at the system:mm[1]> prompt, type remotechassis -name SYSTEM*

The following example shows the information that is returned from this command: system:mm[1]> remote chassis -name SYSTEM* Running chassis discovery...

Running chassis	
Name: IP: IPv6: Status: Firmware: Type: Serial: FRU: Chassis Serial: Chassis FRU:	SYSTEM 10.13.1.190 2002:1013::211:25ff:fec3:227c 2001:1013::211:25ff:fec3:227c 2000:1013::211:25ff:fec3:227c fe80::211:25ff:fec3:227c 2000:1013::a1be:a348:7672:2def 2000:1013::1:191 critical BPET002,CNETMNUS.PKT,02-17-10,1 management-module YK118165A117 39Y9661 KQWPLB9 44X2302 2000:01
Chassis MTM: Chassis UUID:	8852HC1 E13112E1829448E29999DA2066681D89
Name: IP: IPv6:	SYSTEM 10.13.1.30 2000:1013::fc58:325c:c8b4:9c4c 2000:1013::214:5eff:fed0:2e1c 2000:1013::1:30 fe80::5652:ff:fe69:d763 2002:1013::211:25ff:fec3:8cfa 2000:1013::211:25ff:fec3:8cfa 2000:1013::211:25ff:fec3:8cfa fe80::211:25ff:fec3:8cfa
Status: Firmware: Type: Serial: FRU: Chassis Serial: Chassis FRU: Chassis MTM: Chassis UUID:	attention BPET54A, CNETMNUS.PKT, 02-17-10,84 management-module-telco YK118269Y115 39Y9661 23A0052 42C3673 87501RZ B5BAEC01A10B11DB9F3BC1BE8FFF3B3C
<pre>system:mm[1]></pre>	

reset command

This command resets blade servers, blade server integrated system management processors (service processors), I/O modules, or the primary management module. For advanced management modules installed in BladeCenter HT units, it also resets the multiplexer expansion module.

Table 67. reset command

Function	What it does	Command	Valid targets
Reset	Performs an immediate reset and restart of the specified device.	 reset This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration (for blade server or blade server ISMP) I/O module administration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] -T system:switch[x] -T system:blade[x]:sp where x is the blade server or I/O-module bay number.
Reset primary management module	Performs an immediate reset and restart of the primary management module.	 reset This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Reset standby management module	Performs an immediate reset of the standby management module. Note: This option does not apply to the BladeCenter S unit.	 reset -standby This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number. Note: Even though this command resets the standby management module, it still must specify the primary management module as the command target.

Table 67. reset command (continued)	Table 67.	reset command	(continued)
-------------------------------------	-----------	---------------	-------------

Function	What it does	Command	Valid targets
Reset blade server to	Opens a command console with an SOL session when the specified	reset -c	-T system:blade[x]
	blade server is reset.	 This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration and blade remote presence See "Commands and user authority" on page 8 for a dditional information 	where <i>x</i> is the blade server bay number.
Reset with failover	Resets the specified command	reset -f	-T system:mm[x]
	target, enabling failover if a redundant (stanfdby) component for the command target is present. An error message is displayed if you try to failover a management module when a standby management module is not installed or if the firmware in the one of the management modules is updating. Note: This option does not apply to the BladeCenter S unit.	 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration See "Commands and user authority" on page 8 for additional information. 	-T system:mux[x] (for advanced management modules in BladeCenter HT units only) where <i>x</i> is the primary management-module bay or multiplexer expansion module number.
Reset management module with forced failover	Resets the primary management module with failover to the standby management module. An error message is displayed if you try to force failover for a management module when a standby management module is not installed or if the firmware in the primary management module is updating. Note: This option does not apply to the BladeCenter S unit.	 reset -force This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Reset I/O module with standard diagnostics	Performs an immediate reset and restart of the specified device, running standard diagnostics on the I/O module after it restarts. Running the reset -std command gives the same result as running the reset command on a I/O module.	 reset -std This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where <i>x</i> is the I/O-module bay number.

Table 67. reset command (continued)

Function	What it does	Command	Valid targets
Reset I/O module with extended diagnostics	Performs an immediate reset and restart of the specified device, running extended diagnostics on the I/O module after it restarts.	 reset -exd This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.
Reset I/O module with full diagnostics	Performs an immediate reset and restart of the specified device, running full diagnostics on the I/O module after it restarts.	 reset -full This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.
Restart blade server with NMI	 Performs an immediate reset and restart of the specified blade server. Command results depend on the blade server model that is specified: For a JS12 or JS22 blade server, this option is not available. For a JS20 blade server, the command performs an immediate reset and restart of the specified blade server with non-maskable interrupt (NMI). For all other blade servers, the command performs an immediate reset and restart of the specified blade server. 	 reset -sft This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration and blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade server bay number.

Table 67. reset command (continued)

Function	What it does	Command	Valid targets
Restart blade server and clear NVRAM	 Performs an immediate reset and restart of the specified blade server. Command results depend on the blade server model that is specified: For a JS21 blade server, the command performs an immediate reset and restart of the specified JS21 blade server and clears all settings stored in non-volatile memory (NVRAM). For all other blade servers, this option is not available. 	 reset -clr This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration and blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade server bay number.
Restart blade server and run diagnostics	 Performs an immediate reset and restart of the specified blade server. Command results depend on the blade server model that is specified: For a JS12 or JS22 blade server, this option is not available. For a JS20 blade server, the command performs an immediate reset and restart of the specified JS20 blade server and runs diagnostics. For all other blade servers, the command performs an immediate reset and restart of the specified JS20 blade server and runs diagnostics. 	 reset -dg This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration and blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade server bay number.
Restart blade server and run diagnostics using default boot sequence	 Performs an immediate reset and restart of the specified blade server. Command results depend on the blade server model that is specified: For a JS12 or JS22 blade server, this option is not available. For a JS20 blade server, the command performs an immediate reset and restart of the specified JS20 blade server and runs diagnostics using the default boot sequence configured for the blade server. For all other blade servers, the command performs an immediate reset and restart of the specified JS20 blade server and runs diagnostics using the default boot sequence configured for the blade server. For all other blade servers, the command performs an immediate reset and restart of the specified blade server. 	 reset -ddg This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration and blade remote presence See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where x is the blade server bay number.

Table 67. reset command (continued)

Function	What it does	Command	Valid targets
Restart blade server and enter SMS menu	Performs an immediate reset and restart of the specified blade server and enters the System Management Services (SMS) firmware menu. Note: This option applies to all JS <i>xx</i> blade servers other than the JS20 blade server.	 reset -sms This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade server bay number.

Example: To reset the service processor on the blade server in blade bay 5, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

reset

The following example shows the information that is returned: system> reset -T blade[5]:sp

OK system≻

scale command

This command sets and displays the partition control and configuration settings for multiple blade servers or nodes in a scalable complex, for blade servers installed in the BladeCenter unit that support this feature.

Note:

- The scale command will execute only on blade servers that support scalable complexes.
- All blade servers in a scalable complex must be at the same firmware level. When scripting firmware updates for blade servers in a scalable complex, make sure that the update commands are included for each node in the complex.

Function	What it does	Command	Valid targets
Display all scalable complex information	Displays all scalable complex information for the BladeCenter unit.	scale	-T system
Display information for specific scalable complex	 Displays information for the specified scalable complex. Note: The <i>complex_id</i> is found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	scale -compid <i>complex_id</i> where <i>complex_id</i> is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex.	-T system
Display information for specific node in a scalable complex	 Displays information for a specific node in the scalable complex. Note: The <i>complex_id</i> and <i>node_id</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	<pre>scale -node node_id -compid complex_id where : node_id is the checksum or blade server bay number, of the node. complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex.</pre>	-T system
Display information for specific partition in a scalable complex	 Displays information for a specific node in the scalable complex. Note: The <i>complex_id</i> and <i>partition_id</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems 	<pre>scale -compid complex_id -partition partition_id where : complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. partition_id is a partition identifier, assigned by the blade complex.</pre>	-T system

Table 68. scale command

Table 68. scale command (continued)

Function	What it does	Command	Valid targets
Automatically create partition in scalable complex	 Automatically creates a partition in the scalable complex. Note: Creating a partition with nodes (blade servers) that are enabled for Blade Open Fabric Manager (BOFM) might cause loss of ports configured for Open Fabric Manager. The <i>complex_id</i> is found by running the scale command with no options. The <i>-compid</i> command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	<pre>scale -auto -compid complex_id where complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration See "Commands and user authority" on page 8 for additional information.</pre>	-T system
Automatically create stand-alone partition in scalable complex	 Automatically creates a stand-alone partition in the scalable complex. Single blade servers set up as a stand-alone partition will perform consistently if they are installed in another BladeCenter unit. Note: Creating a partition with nodes (blade servers) that are enabled for Blade Open Fabric Manager (BOFM) might cause loss of ports configured for Open Fabric Manager. The <i>complex_id</i> and <i>pri_node_chksum</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	 scale -auto pri_node_chksum -compid complex_id pri_node_chksum is a checksum that identifies the node where the partition is to be created. complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system

Table 68. scale command (continued)

Function	What it does	Command	Valid targets
Create stand-alone partition in scalable complex	 Creates stand-alone partitions for specified blade servers or nodes in the scalable complex. Single blade servers set up as a stand-alone partition will perform consistently if they are installed in another BladeCenter unit. Note: Creating a partition with nodes (blade servers) that are enabled for Blade Open Fabric Manager (BOFM) might cause loss of ports configured for Open Fabric Manager. The comma-separated-value format of this command is primarily used to create stand-alone partitions, since these systems are not contiguous like blade-server systems. For blade-server systems. For blade server bay numbers, but these bay numbers must be contiguous. The checksums, blade server bay numbers and <i>complex_id</i> are found by running the scale command with no options. The namespace for a node checksum and blade server bay numbers end complex are found option is required for only blade-server systems. 	 scale -create <i>id_x,id_y</i> -compid <i>complex_id</i> <i>id_x</i> and <i>id_y</i> are checksums or blade server bay numbers, separated by commas, that identify the node where the partition is to be created. The list can contain one or more comma-separated values. Both checksums and bay numbers can be used in the same list. <i>complex_id</i> is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system

Table 68. scale command (continued)

Function	What it does	Command	Valid targets
Create partition in scalable complex	 Creates partitions for specified blade servers in the scalable complex. Note: Creating a partition with nodes (blade servers) that are enabled for Blade Open Fabric Manager (BOFM) might cause loss of ports configured for Open Fabric Manager. For blade-server systems, a contiguous range of blade-server bays can be specified. The blade server bay numbers and <i>complex_id</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	 scale -create start_bay-end_bay -compid complex_id start_bay and end_bay are blade server bay numbers, separated by a hyphen, that identify the range of blade server bays where partitions are to be created. The range can contain a single bay number. complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system
Delete all partitions from scalable complex	 Deletes all partitions in the scalable complex. Note: All partitions must be powered off to delete them. The blade server bay numbers and <i>complex_id</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	<pre>scale -delete -compid complex_id where complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration See "Commands and user authority" on page 8 for additional information.</pre>	-T system

Table 68. scale command (continued)

Function	What it does	Command	Valid targets
Delete partition from scalable complex	 Deletes a specific partition in the scalable complex. Note: A partition must be powered off to delete it. The <i>complex_id</i> and <i>partition_id</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	<pre>scale -delete -compid complex_id -partid partition_id where : • complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. • partition_id is a partition identifier, assigned by the blade complex. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration See "Commands and user authority" on page 8 for additional information</pre>	-T system
Set partition mode to stand alone	 Sets the mode for a specific partition in the scalable complex to standalone. A partition set to stand-alone mode operates as a single blade server system. Single blade servers set up as a stand-alone partition will perform consistently if they are installed in another BladeCenter unit. Note: A partition must be powered off to change its mode. The <i>complex_id</i> and <i>partition_id</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	<pre>scale -mode standalone -compid complex_id -partid partition_id where : • complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. • partition_id is a partition identifier, assigned by the blade complex. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration See "Commands and user authority" on page 8 for additional information.</pre>	-T system

Table 68. scale command (continued)

Function	What it does	Command	Valid targets
Set partition mode to partition	 Sets the mode for a specific partition in the scalable complex to partition. Note: A partition must be powered off to change its mode. The <i>complex_id</i> and <i>partition_id</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	<pre>scale -mode partition -compid complex_id -partid partition_id where : • complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. • partition_id is a partition identifier, assigned by the blade complex. • This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration See "Commands and user authority" on page 8 for additional information.</pre>	-T system
Power on partition in scalable complex	 Turns on a specific partition in the scalable complex. Note: The <i>complex_id</i> and <i>partition_id</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	 scale -on -compid complex_id -partid partition_id where : complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. partition_id is a partition identifier, assigned by the blade complex. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system

Table 68. scale command (continued)

Function	What it does	Command	Valid targets
Power off partition in scalable complex	 Turns off a specific partition in the scalable complex. Note: The <i>complex_id</i> and <i>partition_id</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	 scale -off -compid complex_id -partid partition_id where : complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. partition_id is a partition identifier, assigned by the blade complex. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system
Power cycle partition in scalable complex	 Cycles power for a specific partition in the scalable complex. If the partition is off, it will turn on. If the partition is on, it will turn off and then turn on. Note: The <i>complex_id</i> and <i>partition_id</i> are found by running the scale command with no options. The -compid command option is required for only blade-server systems that can have multiple scalable complexes defined in the same BladeCenter unit. This option does not need to be specified for stand-alone systems. 	<pre>scale -cycle -compid complex_id -partid partition_id where : • complex_id is a unique complex identifier (hexadecimal string of four alphanumeric characters), assigned by the blade complex. • partition_id is a partition identifier, assigned by the blade complex. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Blade administration See "Commands and user authority" on page 8 for additional information.</pre>	-T system

Example: To view all scalable complexes in the system, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type scale

To power on a partition targeted by the complex ID "06EC" and the partition ID "1", while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type scale -on -compid 06EC -partid 1

The following example shows the information that is returned from these commands:

```
system> scale
--- Complex ID: 06EC ---
Partition ID: 1
Assigned Nodes:
-----
       Bay: 2
       Name: HX5 SDV #3
        Processors/Memory: 2 Intel Xeon/4 DIMMs 2GB
       Logical Node ID: 0
        Status: powered on
        Mode: partition
       Primary: Yes
       Bay: 3
        Name: HX5 SDV #4
        Processors/Memory: 2 Intel Xeon/4 DIMMs 2GB
        Logical Node ID: 1
        Status: powered on
       Mode: partition
        Primary: No
system> scale -on -compid 06EC -partid 1
Note: The power operation may take a few moments to complete.
0K
system>
```

sddump command

This command initiates a dump of service data from blade servers that support this function.

Table	69.	sddump	commano
-------	-----	--------	---------

Function	What it does	Command	Valid targets
Dump service data	Dumps service data of the specified type from the specified blade server target. Note: Data dumps can be initiated, but are not collected, from the advanced management module.	 sddump -init <i>type</i> where <i>type</i> is: sd for a service data dump. sp for a service processor data dump. pf for a platform data dump. pt for a partition data dump. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade server bay number.
Get service data	Collects and displays service data, from the last generated service-data dump, of the specified type from the specified blade server target.	 sddump -coll <i>type</i> where <i>type</i> is: sd to collect and display service data from last dump. sp to collect and display service processor data from last dump. pf to collect and display platform data from last dump. pt to collect and display partition data from last dump. pt to collect and display partition data from last dump. This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade server bay number.

Example: To initiate a data dump from the service processor of the blade server in bay 2, while this blade server is set as the persistent command environment, at the system:blade[2]> prompt, type

sddump -init sp

The following example shows the information that is returned from this command: system:blade[2]> sddump -init sp OK system:blade[2]>

sdemail command

This command sends an email with the service information to the specified recipients.

Function	What it does	Command	Valid targets
Send service information using email to specified recipients	Send an email with service information to the specified recipients. You assign a subject and an email address. When you run this command, it attaches the service log to the message.	sdemail -subj "subject" -to address where: • "subject" is a quote-delimited text string up to 119 characters in length. • address is the recipients email address. Multiple addresses separated with a comma can be entered (119 characters maximum). This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis account management • Chassis log management • Chassis configuration • Blade administration • Blade remote presence • I/O module administration • I/O module configuration See "Commands and user authority" on page 8 for	-T system:mm[x] where <i>x</i> is the primary management module bay number.

Table 70. sdemail command

Example:

To send a service information email message, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type sdemail -to mail@cn.ibm.com -subj "Blade 8 Reboot" The following example shows the information that is returned from this command: system:mm[1]> sdemail -to mail@cn.ibm.com -subj "Blade 8 Reboot" OK

security command

This command enables and displays the state of the data encryption feature for sensitive information stored in the advanced management module, such as passwords and keys.

Once enabled, the security feature can not be disabled without resetting all management module settings to their default configuration.

Table 71. security command

Function	What it does	Command	Valid targets
Display management module security setting	Displays the security setting for management module data encryption (on or off).	security	-T system:mm[x] where x is the primary management-module bay number.
Enable data encryption for management module	Enables data encryption for the management module. Attention: If you enable data encryption, you can not disable it without resetting the management module to the default configuration.	 security -e This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Example:

To enable data encryption for the management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type security -e

To display the data encryption setting for the management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

security

The following example shows the information that is returned from these two commands:

```
system:mm[1]> security -e
OK
system:mm[1]> security
-e on
system:mm[1]>
```

service command

This command configures and displays the management-module service setting.

Table 72. service command

Function	What it does	Command	Valid targets
Display service setting	Displays the service setting for technician debug of the advanced management module with a USB key (enable or disable).	service	-T system:mm[x] where x is the primary management-module bay number.
Enable technician debug	Configure service setting to enable technician debug of the advanced management module with a USB key.	 service -enable This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Disable technician debug	Configure service setting to disable (default setting) technician debug of the advanced management module with a USB key.	 service -disable This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Example:

To enable technician debug of the advanced management module with a USB key, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

service -enable

To display the service setting of the advanced management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

service

The following example shows the information that is returned from these two commands:

system:mm[1]> service -enable
OK
system:mm[1]> service
Debug with USB key: Enabled
system:mm[1]>

shutdown command

This command forces a blade server to shut down.

Table 73. shutdown command

Function	What it does	Command	Valid targets
Shutdown blade server	Forces a shutdown for the specified blade server.	 shutdown -f This command can only be run by users who have one or more of the following command authorities: Supervisor Blade administration See "Commands and user authority" on page 8 for additional information. 	-T system:blade[x] where <i>x</i> is the blade server bay number.

Example:

To force a shutdown for the blade server in blade bay 5, while this blade server is set as the persistent command environment, at the system:blade[5]> prompt, type shutdown -f

The following example shows the information that is returned from this command: system:blade[5]> shutdown -f OK system:blade[5]>

slp command

This command sets and displays the service location protocol (SLP) settings for the management module.

Table 74.	slp	command
-----------	-----	---------

Function	What it does	Command	Valid targets
Display management-module SLP settings	Displays the SLP settings for the primary management module. Returned values are: • -t address_type • -i multicast_addr	slp	-T system:mm[x] where x is the primary management-module bay number.
Set management-module SLP address type	Sets the SLP address type for the primary management module.	<pre>slp -t address_type where address_type is multicast or broadcast. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management-module SLP multicast address	Sets the SLP multicast address for the primary management module.	 slp -i multicast_addr where multicast_addr is the multicast IP address. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example:

To set the SLP address type of the advanced management module to multicast, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

slp -t multicast

To display the SLP settings of the advanced management module, while management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type

slp

The following example shows the information that is returned from these two commands:

```
system:mm[1]> slp -t multicast
OK
system:mm[1]> slp
-t multicast
-i 255.255.255.255
system:mm[1]>
```

smtp command

This command configures and displays the management-module SMTP settings.

Table 75. smtp command

Function	What it does	Command	Valid targets
Display SMTP server host name or IP address	Displays the SMTP server host name or IP address.	smtp	-T system:mm[x] where x is the primary management-module bay number.
Server host name or IP address - set	Checks syntax and sets the server host name or IP address.	<pre>smtp -s hostname/ip_address where hostname/ip_address is the host name or IP address of the server. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 75. smtp command (continued)

Function	What it does	Command	Valid targets
SMTP e-mail server domain name - set	Checks syntax and sets the SMTP e-mail server domain name.	smtp -d <i>domainname</i> where <i>domainname</i> is a valid domain name that meets the following criteria:	-T system:mm[x] where x is the primary management-module bay number.
		• Alphanumeric string up to 63 characters in length.	
		• Can contain dots (.), dashes (-), or underscores (_).	
		• Must contain at least one dot.	
		• No consecutive dots are allowed.	
		• Quotes are not required.	
		• Value can be cleared by setting it to an empty, double-quote limited string ("").	
		 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	
		See "Commands and user authority" on page 8 for additional information.	

Example:

To set the SMTP server host name to us.ibm.com, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type smtp -s us.ibm.com

To display the SMTP configuration, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type smtp

The following example shows the information that is returned from these two commands:

system:mm[1]> smtp -s us.ibm.com
OK
system:mm[1]> smtp
-s us.ibm.com
system:mm[1]>

snmp command

This command configures and displays the management-module SNMP settings.

Table 76. snmp command

Function	What it does	Command	Valid targets
Display SNMP configuration of management module	Displays the current SNMP configuration of the management module.	snmp	-T system:mm[x] where x is the primary management-module bay number.
SNMPv1 agent - enable/disable	 Enables or disables the management-module SNMPv1 agent. Note: Before you can enable the SNMPv1 agent, the following must be specified: management module contact name management module location at least one community name at least one valid IP address for that community (see "config command" on page 111) 	 snmp -a -state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
SNMPv3 agent - enable/disable	 Enables or disables the management-module SNMPv3 agent. Note: Before you can enable the SNMPv3 agent, the following must be specified: management module contact name management module location (see "config command" on page 111) 	 snmp -a3 -state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
SNMP traps - enable/disable	Enables or disables the management-module SNMP traps.	 snmp -t -state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 76. snmp command (continued)

Function What it does C	Command	Valid targets
Function What it does C SNMP community 1 Sets the name of community 1. sr name - set wm wm . . .	Command Simp -c1 name where name is a descriptive name of community 1. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be yusers who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user withority" on page 8 for	Valid targets -T system:mm[x] where x is the primary management-module bay number.

Table 76. snmp command (continued)

Function	What it does	Command	Valid targets
SNMP community 1 first host name or IP address - set	Checks syntax and sets the first host name or IP address of community 1.	 snmp -c1i1 hostname/ip_address where hostname/ip_address is the first host name or IP address of community 1. The first IP address of the first community can be set to 0.0.0 if the community access type is set to GET (for all management module types) or SET. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Function	What it does	Command	Valid targets
---	---	--	---
SNMP Community 1, first host name - set access to SET (wildcard)	Sets the access type for community 1 to SET.	 snmp -cal set -clil 0.0.0 With the access type of SET, anyone can query the management information base (MIB) and set MIB values. Using 0.0.0.0 IP address with SET access allows open access to the management module for write (SET) operations. A 0.0.0.0 address cannot be a trap receiver. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system:mm[x] where x is the primary management-module bay number.
		authority" on page 8 for additional information.	

Table 76. snmp command (continued)

Function	What it does	Command	Valid targets
SNMP Community 1, first host name or IP address - set access to GET (wildcard)	Sets the access type for community 1 to GET.	 snmp -cal get -clil 0.0.0 With the access type of GET, anyone can query the MIB. Using 0.0.00 IP address with GET access allows open access to the management module for read (GET). A 0.0.0 address cannot be a trap receiver. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 76. snmp command (continued)

Function	What it does	Command	Valid targets
Function SNMP community 1 second host name or IP address - set	What it does Checks syntax and sets the second host name or IP address of community 1.	Command snmp -c1i2 hostname/ip_address where hostname/ip_address is the second host name or IP address of community 1. • Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. • If this argument is not specified, the snmp	Valid targets -T system:mm[x] where x is the primary management-module bay number.
		 specifical, the simp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	

Table 76. snmp command (continued)

Table 76. Shirip command (commueu)	Table 76.	snmp	command	(continued)
------------------------------------	-----------	------	---------	-------------

Function	What it does	Command	Valid targets
SNMP community 1 third host name or IP address - set	Checks syntax and sets the third host name or IP address of community 1.	 snmp -c1i3 hostname/ip_address where hostname/ip_address is the third host name or IP address of community 1. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
SNMPv3 community 1 view type - set	Sets the SNMPv3 view type for community 1.	<pre>snmp -cal type where type is get set trap This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 76. snmp command (continued)

Function	What it does	Command	Valid targets
SNMP community 2	Sets the name of community 2.	snmp -c2 name	-T system:mm[x]
name - ser		 where <i>name</i> is a descriptive name of community 2. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information 	where <i>x</i> is the primary management-module bay number.
SNMP community 2 first host name or IP address - set	Checks syntax and sets the first host name or IP address of community 2.	 snmp -c2i1 hostname/ip_address where hostname/ip_address is the first host name or IP address of community 2. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 76.	snmp	command	(continued)
			1 /

Function	What it does	Command	Valid targets
SNMP community 2 second host name or IP address - set	Checks syntax and sets the second host name or IP address of community 2.	 snmp -c2i2 hostname/ip_address where hostname/ip_address is the second host name or IP address of community 2. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Function	What it does	Command	Valid targets
SNMP community 2 third host name or IP address - set	Checks syntax and sets the third host name or IP address of community 2.	 snmp -c2i3 hostname/ip_address where hostname/ip_address is the third host name or IP address of community 2. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
SNMPv3 community 2 view type - set	Sets the SNMPv3 view type for community 2.	<pre>snmp -ca2 type where type is get set trap This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 76. snmp command (continued)

Table 76. snmp command (continued)

Function	What it does	Command	Valid targets
SNMP community 3	Sets the name of community 3.	snmp -c3 name	-T system:mm[x]
name - set		 where <i>name</i> is a descriptive name of community 3. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: 	where <i>x</i> is the primary management-module bay number.
		 Supervisor Chassis configuration See "Commands and user authority" on page 8 for 	
		additional information.	
SNMP community 3 first host name or IP address - set	Checks syntax and sets the first host name or IP address of community 3.	 snmp -c3i1 hostname/ip_address where hostname/ip_address is the first host name or IP address of community 3. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system:mm[x] where x is the primary management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	

Function	What it does	Command	Valid targets
SNMP community 3 second host name or IP address - set	Checks syntax and sets the second host name or IP address of community 3.	 snmp -c3i2 hostname/ip_address where hostname/ip_address is the second host name or IP address of community 3. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	

Table 76. snmp command (continued)

Table 76.	snmp	command	(continued)
			1 /

Function	What it does	Command	Valid targets
SNMP community 3 third host name or IP address - set	Checks syntax and sets the third host name or IP address of community 3.	 snmp -c3i3 hostname/ip_address where hostname/ip_address is the third host name or IP address of community 3. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
SNMPv3 community 3 view type - set	Sets the SNMPv3 view type for community 3.	<pre>snmp -ca3 type where type is get set trap This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 76. snmp command (continued)

Function	What it does	Command	Valid targets
Function SNMP contact name - set	What it does Sets the contact name.	Command snmp -cn contact_name where contact_name is the name of the party to be contacted when SNMP traps an event. • Arguments containing spaces must be enclosed in quotation marks No	Valid targets -T system:mm[x] where x is the primary management-module bay number.
		 In quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. 	
		 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	

Table 76. snmp command (continued)

Function	What it does	Command	Valid targets
SNMP location - set	Sets the location.	<pre>snmp -1 hostname/ip_address</pre>	-T system:mm[x]
		 where <i>hostname/ip_address</i> identifies the website supporting SNMP for this management module. Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. If this argument is not specified, the snmp command clears this option. You can also clear this option by assigning an empty string as its value. 	where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities:SupervisorChassis configuration	
		See "Commands and user authority" on page 8 for additional information.	

Example: To view the SNMP configuration, while advanced management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type snmp

To enable the SNMP agent and SNMP traps, while advanced management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type snmp -a -on -t -on

The following example shows the information that is returned from these two commands:

```
system:mm[1]> snmp
-a Enabled
-a3 Enabled
-t Enabled
-1 Raleigh,NC
-cn Mr. Smith
-c1 public
-c1i1 9.44.146.157
-c1i2 9.44.147.24
-c1i3 9.49.165.217
-cal set
-c2 private
-c2i1 9.42.226.4
-c2i2
-c2i3
-ca2 get
-c3 test
```

```
-c3i1 9.44.247.64
-c3i2
-c3i3
-ca3 getsystem:mm[1]> snmp -a -on -t -on
system:mm[1]>
```

sol (serial over LAN) command

This command configures SOL functions and indicates SOL status.

Table 77. sol (serial over LAN) command

Function	What it does	Command	Valid targets
Display SOL status	 Displays the SOL status for the targeted device: When the command target is the primary management module, it displays the following values: - status on/off (global SOL status) - c retry_count - e CLI_key_sequence - i retry_interval - r reset_blade_key_seq - s send_threshold - t accumulate_timeout - v VLAN_id 	sol	-T system:mm[x] -T system:blade[x] where x is the primary management-module or blade server bay number.
	 Note: For the advanced management module, the <i>VLAN_id</i> is identified as "VLAN ID". When the command target is a blade server, it displays the following: - status <i>enabled/disabled</i> (SOL status for the blade server) Status of any SOL sessions for that blade server: Not ready Ready Active 		
SOL retry interval - set	Sets the SOL retry interval to the input value.	 sol -i value where value is from 10 ms to 2550 ms, inclusive, in 10 ms increments. If you enter a value less than 10 ms, the retry interval will be set to 10 ms. If you enter a value greater than 2550 ms, the retry interval will be set to 2550 ms. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Function	What it does	Command	Valid targets
SOL retry count - set	Sets the SOL retry count to the input value.	 sol -c value where value is from 0 to 7, inclusive. If you enter a value of 0, no retries will be attempted. If you enter a value greater than 7, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
SOL send threshold - set	Sets the SOL send threshold to the input value. Setting the threshold value to 1 causes the blade server integrated system management processor to send an SOL packet as soon as the first character is received.	 sol -s value where value is from 1 to 251, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 77. sol (serial over LAN) command (continued)

Function	What it does	Command	Valid targets
SOL accumulate timeout	Sets the SOL accumulate timeout to	sol -t value	-T system:mm[x]
	the input value.	where <i>value</i> is from 5 ms to 1275 ms, inclusive. If you enter a value less than 5 ms, the accumulate timeout will be set to 5 ms. If you enter a value greater than 1275 ms, an error will be displayed.	where <i>x</i> is the primary management-module bay number.
		 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration Blade configuration 	
		See "Commands and user authority" on page 8 for additional information.	
SOL enable - global	Enables SOL globally for the BladeCenter unit. The global SOL enable command does not affect the SOL session status for each blade server.	 sol -status enabled This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system:mm[x] where x is the primary management-module bay number.
		• Blade configuration See "Commands and user authority" on page 8 for additional information.	
SOL enable - blade	Enables SOL for the specified blade	sol -status enabled	-T system:blade[x]
server	server.	This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration • Blade configuration	where <i>x</i> is the blade server bay number.
		See "Commands and user authority" on page 8 for additional information.	

Table 77.	sol	(serial	over	LAN)	command	(continued)
-----------	-----	---------	------	------	---------	-------------

Table 77.	sol (serial	over LAN) command	(continued)
-----------	-------------	----------	-----------	-------------

Function	What it does	Command	Valid targets
SOL disable - global	Disables SOL globally for the BladeCenter unit. The global SOL disable command does not affect the SOL session status for each blade server.	 sol -status disabled This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration Blade configuration See "Commands and user authority" on page 8 for 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		additional information.	
SOL disable - blade server	Disables SOL for the specified blade server.	 sol -status disabled This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration Blade configuration 	-T system:blade[x] where x is the blade server bay number.
		authority" on page 8 for additional information.	

Function	What it does	Command	Valid targets
CLI key sequence - set	Sets the key sequence that is used to enter the CLI while a Telnet session in SOL mode.	 sol -e value sol -e value where value is the key sequence. In this sequence, a ^ (the carat symbol) indicates a Ctrl that maps to control-key sequences; for example: ^[(the carat symbol followed by a left bracket) means Esc ^M (the carat symbol followed by a capitol M) means carriage return. Refer to an ASCII-to-key conversion table for a complete listing of control-key sequences. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 77. sol (serial over LAN) command (continued)

Function	What it does	Command	Valid targets
Reset blade server key sequence - set	Sets the key sequence that will reset a blade server while a Telnet session in SOL mode.	 sol -r value where value is the key sequence. In this sequence, a ^ (the carat symbol) indicates a Ctrl that maps to control-key sequences; for example: ^[(the carat symbol followed by a left bracket) means Esc ^M (the carat symbol followed by a capitol M) means carriage return. Refer to an ASCII-to-key conversion table for a complete listing of control-key sequences. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration Blade configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 77. sol (serial over LAN) command (continued)

Example:

To set the SOL accumulate timeout to 25 ms, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type sol -t 25

To set the reset blade server key sequence to Esc R Esc r Esc R, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type sol -r ^[R^[r^[R

To display the SOL settings for the management module, while the management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

sol

To display the SOL settings for the server blade in the third bay, while blade 3 is set as the persistent command environment, at the system:blade[3]> prompt, type sol

The following example shows the information that is returned from these commands:

```
system:mm[1]> sol -t 25
0K
system:mm[1]> sol
-status enabled
-c 3
-e ^[(
-i 250
-r ^[R^[r^[R
-s 250
-t 5
VLAN ID 4095
system:mm[1]>
system:blade[3]> sol
-status enabled
SOL Session: Not Ready
SOL retry interval: 250 ms
SOL retry count: 3
SOL bytes sent: 0
SOL bytes received: 0
SOL destination IP address: 10.10.10.80
SOL destination MAC: 00:00:00:00:00:00
SOL I/O module slot number: 0
SOL console user ID:
SOL console login from:
SOL console session started:
SOL console session stopped:
Blade power state: On
SOL recommended action: Internal network path between the AMM and this
blade server is currently not available. Please refer to AMM user guide for
troubleshooting information.
system:blade[3]>
```

sshcfg command

This command sets and displays the SSH status of the management module.

Table	78.	sshcfg	command
-------	-----	--------	---------

Function	What it does	Command	Valid targets
Display SSH status	 Displays the SSH status of the management module. Returned values are: -v1 off -cstatus: state of CLI SSH server (enabled, disabled) CLI SSH port number -sstatus: state of SMASH SSH server (enabled, disabled) SMASH SSH port number ssh-dss fingerprint ssh-rsa fingerprint number of SSH public keys installed number of locations available to store SSH keys Note: For scripting purposes, the "-v1 off" state is always displayed. 	sshcfg	-T system:mm[x] where x is the primary management-module bay number.
Display RSA host key information	Displays RSA host key information for the management module.	sshcfg -hk rsa	-T system:mm[x] where x is the primary management-module bay number.
Display DSA host key information	Displays DSA host key information for the management module.	sshcfg -hk dsa	-T system:mm[x] where x is the primary management-module bay number.
Generate host key	Generates a host key for the management module.	 sshcfg -hk gen This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 78. sshcfg command (continued)

Function	What it does	Command	Valid targets
Set state of CLI SSH server	Sets the state of the CLI SSH server for the management module.	 sshcfg -cstatus state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set state of SMASH SSH server	Sets the state of the SMASH SSH server for the management module.	sshcfg -sstatus <i>state</i> where <i>state</i> is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example:

To display SSH status, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type sshcfg

The following example shows the information that is returned from this command:

```
system:mm[1]> sshcfg
-v1 off
-cstatus enabled
CLI SSH port 22
-sstatus disabled
SMASH SSH port 50024
ssh-dss 2048 bit fingerprint: 27:ee:bd:a9:27:28:d8:a5:93:03:3d:8e:77:d0:38:2c
ssh-rsa 2048 bit fingerprint: 66:c9:73:4f:18:11:02:10:f3:05:6e:d7:27:05:a5:01
2 SSH public keys installed
10 locations available to store SSH public keys
system:mm[1]>
```

sslcfg command

This command sets and displays the Secure Sockets Layer (SSL) status of the advanced management module.

Table	79.	sslcfg	command
-------	-----	--------	---------

Function	What it does	Command	Valid targets
Display management module SSL status	Displays the SSL status of the specified management module. This status includes information about SSL certificates.	sslcfg	-T system:mm[x] where x is the primary or standby management-module bay number.
Set SSL certificate handling for standby management module	Enables or disables use of an additional SSL certificate for the standby management module. If disabled, the standby management module uses the same SSL certificate as the primary management module. Note: An additional SSL certificate can only be configured when management module advanced failover is set to "swap" and the standby management module has a valid SSL certificate set up.	 sslcfg -ac state where state is: on to use an additional certificate off to use the same certificate This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the standby management-module bay number.
Set SSL state for management module web server	Enables or disables SSL for the management module web server. Note: The SSL for the management module web server can only be enabled if a valid SSL certificate is set up.	 sslcfg -server state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary or standby management-module bay number.

Table 79. sslcfg command (continued)

Function	What it does	Command	Valid targets
Set SSL state for LDAP client	Enables or disables SSL for the LDAP client.	sslcfg -client state	-T system:mm[x]
	Note: The SSL for the LDAP client can only be enabled if a valid SSL certificate is set up.	 where <i>state</i> is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	where <i>x</i> is the primary or standby management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	

Table 79. sslcfg command (continued)

Function What it does	Command	Valid targets
Function What it does Generate self-signed certificate Generates a self-signed certificate for the management module web server or the LDAP client. The following values must be set when generating a self-signed certificate: • Country using the -c command option. • State or province using the -sp command option. • City or locality using the -c1 command option. • Organization name using the -on command option. • Organization name using the -on command option. • Management module host name using the -hn command option. • Note: This host name must match the host name that is used by a web browser to connect to the management module. The following optional values can be set when generating a self-signed certificate: • Contact person using the -cp command option. • Email address of the contact person using the -ea command option. • Unit within a company or organization using the -ou command option. • Additional information such as a surame using the -s command option. • Additional information such as a given name using the -gn command option. • Additional information such as a distinguished name qualifier using the -dq command option.	<pre>Command sslcfg -cert type -c country -sp "state" -cl "city" -on "org" -hn hostname -cp "name" -ea email -ou "org_unit" -s "surname" -gn "given_name" -in "initial" -dq "dn_qualifier" where the following required options are: • type is: - server for a management module web server certificate. - client for an LDAP client certificate. • country is two-character alphabetic code for the country. • "state" is a state or province name of up to 60 characters in length. • "city" is a city or locality name of up to 50 characters in length. • "org" is an organization name of up to 60 characters in length. • hostname is a valid host name of up to 60 characters in length. • hostname is a valid host name of up to 60 characters in length. • hostname is a valid host name of up to 60 characters. • "name" is up to 60 characters. • "surname" is up to 60 characters. • "surname" is up to 60 characters. • "given_name" is up to 60 characters. • "mane" is up to 60 characters. • "surname" is up to 60 characters. • "an_qualifier" is up to 60 characters. • "an_qualifier" is up to 60 characters. • "an_qualifier" is up to 60 characters. • "dn_qualifier" is up to 60 characters. • "cital" is up to 20 characters. • "dn_qualifier" is up to 60 characters. • "dn_qualifier" is up to 60 characters.</pre>	<pre>Valid targets -T system:mm[x] where x is the primary or standby management-module bay number.</pre>

Table 79. sslcfg command (continued)

Function	What it does	Command	Valid targets
Generate self-signed		This command can only	
certificate		be run by users who have	
		one or more of the	
(continued)		following command	
		authorities:	
		Supervisor	
		Chassis configuration	
		See "Commands and user	
		authority" on page 8 for	
		additional information.	

Table 79. sslcfg command (continued)

Function	What it does	Command	Valid targets
Function Generate CSR	 What it does Generates a certificate signing request (CSR) for the management module web server or the LDAP client. The following values must be set when generating a CSR: Country using the -c command option. State or province using the -sp command option. City or locality using the -c1 command option. Organization name using the -on command option. Management module host name using the -hn command option. Note: This host name must match the host name that is used by a web browser to connect to the management module. The following optional values can be set when generating a CSR: Contact person using the -cp command option. Email address of the contact person using the -ea command option. Unit within a company or organization using the -ou command option. Additional information such as a surname using the -s command option. Additional information such as a distinguished name qualifier using the -dq command option. Additional information such as a distinguished name qualifier using the -dq command option. 	Command sslcfg -csr type -c country -sp "state" -cl "city" -on "org" -hn hostname -cp "name" -ea email -ou "org_unit" -s "surname" -gn "given_name" -in "initial" -dq "dn_qualifier" -cpwd password -un "un_name" where the following required options are: • type is: - server for a management module web server CSR. - client for an LDAP client CSR. • country is two-character alphabetic code for the country. • "state" is a state or province name of up to 60 characters in length. • "org" is an organization name of up to 60 characters in length. • hostname is a valid host name of up to 60 characters in length. • hostname is a valid host name of up to 60 characters in length. • mane" is up to 60 characters. • "name" is up to 60 characters. • "surname" is up to 60 characters.	Valid targets -T system:mm[x] where x is the primary or standby management-module bay number.
1	(continuea on next page)	(continuea on next page)	

Table 79. sslcfg command (continued)

Function	What it does	Command	Valid targets
Generate CSR (continued)	 Additional information such as an unstructured name qualifier using the -un command option. 	 <i>"initial"</i> is up to 20 characters. <i>"dn_qualifier"</i> is up to 60 characters. <i>password</i> is between 6 and 30 characters. <i>"un_name"</i> is up to 60 characters. 	
		Note: Arguments that must be quote-delimited are shown in quotation marks.	
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Download certificate file	Downloads the specified certificate file. The IP address of the TFTP server for downloading an SSL self-signed certificate or CSR must be set using the -i command. The file name for downloading an SSL self-signed certificate or CSR can be set using the -1 command. If no file name is specified, the default file name for the file will be used.	<pre>sslcfg -dnld -cert -csr type -l filename -i ipaddress where: • type is - client for an LDAP client - server for a management module web server • filename is a valid filename of up to 256 characters in length containing any character except the percent sign (%), forward-slash (/), or double-quote ("). • ipaddress is the IPv4 or IPv6 IP address of the TFTP server. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for http://orecommend.com/ bits.commands.com/ set "Commands and user authority" on page 8 for</pre>	-T system:mm[x] where x is the primary or standby management-module bay number.

Table 79. sslcfg command (continued)

Table 79. sslcfg command (continued)

Function	What it does	Command	Valid targets
Function Import/download/ remove trusted certificate 1	What it does Perform the specified operation on trusted certificate 1 for the SSL client. Valid operations are: • import (upload) • download • remove The IP address of the TFTP server for uploading or downloading a trusted certificate must be set using the -i command. The file name for uploading or downloading a trusted certificate can be set using the -1 command.	Command sslcfg -tcl operation where operation is: • import • download • remove Note: The -tcl option must be used with the following options: • -i ipaddress • -1 filename where: • ipaddress is the IPv4 or IPv6 IP address of the TFTP server. • filename is a valid filename of up to 256	Valid targets -T system:mm[x] where <i>x</i> is the primary or standby management-module bay number.
		 containing any character except the percent sign (%), forward-slash (/), or double-quote ("). This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	

Table 79. sslcfg command (continued)

Function	What it does	Command	Valid targets
Function Import/download/ remove trusted certificate 2	What it does Perform the specified operation on trusted certificate 2 for the SSL client. Valid operations are: • import (upload) • download • remove The IP address of the TFTP server for uploading or downloading a trusted certificate must be set using the -i command.	Command sslcfg -tc2 operation where operation is: • import • download • remove Note: The -tc2 option must be used with the following options: • -i ipaddress • -1 filename	Valid targets -T system:mm[x] where x is the primary or standby management-module bay number.
	The file name for uploading or downloading a trusted certificate can be set using the -1 command.	 where: <i>ipaddress</i> is the IPv4 or IPv6 IP address of the TFTP server. <i>filename</i> is a valid filename of up to 256 characters in length containing any character except the percent sign (%), forward-slash (/), or double-quote ("). 	
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	

Table 79. sslcfg command (continued)

Function	What it does	Command	Valid targets
Function Import/download/ remove trusted certificate 3	What it does Perform the specified operation on trusted certificate 3 for the SSL client. Valid operations are: • import (upload) • download • remove The IP address of the TFTP server for uploading or downloading a trusted certificate must be set using the -i command. The file name for uploading or downloading a trusted certificate can be set using the -1 command. For importing a certificate "-1 <filename>" is required.</filename>	Command sslcfg -tc3 operation where operation is: • import • download • remove Note: The -tc3 option must be used with the following options: • -i ipaddress • -l filename where: • ipaddress is the IPv4 or IPv6 IP address of the TFTP server. • filename is a valid filename of up to 256 characters in length containing any character except the percent sign (%), forward-slash (/), or double-quote ("). This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	Valid targets -T system:mm[x] where <i>x</i> is the primary or standby management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	

Example: To view SSL information for the management module in bay 1, while this management module is set as the persistent command environment, at the system:mm[1] > prompt, type

sslcfg

The following example shows the information that is returned from this command:

```
system:mm[1]> sslcfg
-server disabled
-client disabled
SSL Server Certificate status:
A CA-signed certificate is installed
SSL Client Certificate status:
No certificate has been generated
SSL Client Trusted Certificate status:
Trusted Certificate 1: Not available
Trusted Certificate 2: Not available
Trusted Certificate 3: Not available
system:mm[1]>
```

syslog command

This command manages how the advanced management module handles transmission of event log messages to networked syslog event collectors.

Table 80. syslog command

Function	What it does	Command	Valid targets
Display syslog configuration	Displays the syslog event log transmission configuration of the advanced management module.	syslog	-T system:mm[x] where x is the primary management-module bay number.
Set syslog filter level	Set severity filtering levels for syslog event log transmission.	 syslog -sev level where level is: i selects error, warning, and informational logs w selects error and warning logs e selects error logs This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set syslog event log transmission state for collector 1	Enables or disables syslog event log transmission to collector 1.	 syslog -coll1 state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 80. syslog command (continued)

Function	What it does	Command	Valid targets
Set syslog event log transmission state for collector 2	Enables or disables syslog event log transmission to collector 2.	 syslog -coll2 state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		additional information.	
syslog event log collector 1 host name or IP address - set	Sets the host name or IP address for syslog event collector 1.	 syslog -i1 hostname/ip_address where hostname/ip_address is the collector 1 host name or IP address. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
syslog event log collector 2 host name or IP address - set	Sets the host name or IP address for syslog event collector 2.	 syslog -i2 hostname/ip_address where hostname/ip_address is the collector 2 host name or IP address. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 80.	syslog com	mand (continu	ed)
-----------	------------	---------------	-----

Function	What it does	Command	Valid targets
syslog event log collector 1 port number - set	Sets the port number for syslog event collector 1.	syslog -p1 <i>port</i> where <i>port</i> is the collector 1 port number from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed.	-T system:mm[x] where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities:SupervisorChassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
syslog event log collector 2 port number - set	Sets the port number for syslog event collector 2.	syslog -p2 <i>port</i> where <i>port</i> is the collector 2 port number from 1 to 65535, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	-T system:mm[x] where x is the primary management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	

Table 80. syslog command (continued)

Function	What it does	Command	Valid targets
Function Generate test message	What it does Generates a test syslog message to test the configuration. Note: The -test command options must be run exclusive of other command options.	Command syslog -test This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis account management • Chassis log	Valid targets -T system:mm[x] where <i>x</i> is the primary management-module bay number.
		 Chassis log management Chassis administration Chassis configuration Blade administration Blade configuration Blade remote presence I/O module administration I/O module configuration See "Commands and user 	
		authority" on page 8 for additional information.	

Example: To view the syslog event log transmission configuration of the primary advanced management module in bay 1, while this management module is set as the persistent command environment, at the system:mm[1]> prompt, type syslog

The following example shows the information that is returned from this command:

```
system:mm[1]> syslog
-sev 1
-coll1 enabled
-coll2 disabled
-i1 253.245.45.1
-i2
-p1 514
-p2 514
system:mm[1]>
```
tcpcmdmode command

This command displays and changes the timeout of the TCP command-mode sessions that are used by IBM Systems Director software for out-of-band communication with the management module. This command is also used to enable or disable the TCP command-mode sessions.

Function	What it does	Command	Valid targets
Display TCP command-mode session status and timeout	Displays the secure and non-secure TCP command-mode session status (maximum number of sessions) and timeout.	tcpcmdmode	-T system:mm[x] where x is the primary management-module bay number.
Set TCP command-mode session timeout	Sets the secure and non-secure TCP command-mode session timeout value.	 tcpcmdmode -t <i>timeout</i> where <i>timeout</i> is from 0 seconds (no timeout) to 4294967295 seconds, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Disable TCP command-mode sessions	Disables TCP command-mode sessions that are used by IBM Systems Director software for out-of-band communication with the management module. This applies to both read and write operations.	 tcpcmdmode -status θ This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 81. tcpcmdmode command

Table 81. tcpcmdmode command (continued)

Function	What it does	Command	Valid targets
Enable and set number of TCP command-mode sessions	Enables TCP command-mode and sets the maximum number of sessions that can be used by IBM Systems Director software for out-of-band communication with the management module. For read operations, all of the values from 1 to 20, inclusive, mean <i>enabled</i> . Note: The advanced management module supports a combined total of up to 20 secure and non-secure TCP command-mode sessions.	<pre>tcpcmdmode -status number_sessions where number_sessions is from 1 to 20, inclusive. (A value of 0 disables TCP command-mode sessions.) If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[<i>x</i>] where <i>x</i> is the primary management-module bay number.
Disable secure TCP command-mode sessions	Disables secure TCP command-mode sessions that are used by IBM Systems Director software for out-of-band communication with the management module. This applies to both read and write operations.	 tcpcmdmode -sstatus θ This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Enable and set number of secure TCP command-mode sessions	Enables secure TCP command-mode and sets the maximum number of sessions that can be used by IBM Systems Director software for out-of-band communication with the management module. For read operations, all of the values from 1 to 20, inclusive, mean <i>enabled</i> . Note: The advanced management module supports a combined total of up to 20 secure and non-secure TCP command-mode sessions.	<pre>tcpcmdmode -sstatus number_sessions where number_sessions is from 1 to 20, inclusive. (A value of 0 disables secure TCP command-mode sessions.) If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[<i>x</i>] where <i>x</i> is the primary management-module bay number.

Example: To enable a maximum of three TCP command-mode sessions for the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type

```
tcpcmdmode -status 3
```

To enable a maximum of five secure TCP command-mode sessions for the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
tcpcmdmode -sstatus 5
```

To set the TCP command-mode session timeout for the primary management module to 6 minutes, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type tcpcmdmode -t 360

To display the TCP command-mode session status and timeout for the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type tcpcmdmode

The following example shows the information that is returned from these commands:

```
system:mm[1]> tcpcmdmode -status 3
OK
system:mm[1]> tcpcmdmode -sstatus 5
OK
system:mm[1]> tcpcmdmode -t 360
OK
system:mm[1]> tcpcmdmode
-status 3 connections
-sstatus 5 connections
-t 360 seconds
system:mm[1]>
```

telnetcfg (Telnet configuration) command

This command displays and configures the command-line session parameters of the primary management module.

Table 82. telnetcfg (Telnet configuration) command

Function	What it does	Command	Valid targets
Display command-line session configuration	Displays the command-line session configuration of the primary management module.	telnetcfg	-T system:mm[x] where x is the primary management-module bay number.
Set command-line session timeout for primary management module	Sets the command-line session timeout value for the primary management module.	 telnetcfg -t <i>timeout</i> where <i>timeout</i> is from 0 seconds (no timeout) to 4294967295 seconds, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Example: To set the command-line session timeout for the primary management module to 6 minutes, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
telnetcfg -t 360
```

To display the command-line session configuration for the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type telnetcfg

The following example shows the information that is returned from these two commands:

```
system:mm[1]> telnetcfg -t 360
OK
system:mm[1]> telnetcfg
-t 360
system:mm[1]>
```

temps command

This command displays actual temperatures and temperature threshold values for BladeCenter components.

Table 8	3. tem	ips co	mmand
---------	--------	--------	-------

Function	What it does	Command	Valid targets
Display temperature values	 Displays the current temperature and temperature threshold settings for the specified component: The management module target displays the management module ambient temperature. The blade server target displays the temperature values for components in the specified blade server, such as microprocessors and expansion modules. The media tray target displays values for the temperature sensor in the media tray. 	temps	 -T system:mm[x] -T system:mlade[x] -T system:mt where x is the primary management-module or blade server bay number.

Example: To view the current temperature and temperature thresholds for the blade server in bay 3, while this blade server is set as the persistent command environment, at the system:blade[3]> prompt, type temps

The following example shows the information that is returned from this command: system:blade[3]> temps

			Hard	Warning	
Comp	Value	Warning	Shutdown	Reset	
CPU1	38.00	85.00	95.00	78.00	
CPU2	35.00	85.00	95.00	78.00	
BEM					
system:blade[3]>					

trespass command

This command sets and displays the status and message for the advanced management module trespass feature that can display a warning message to users when they log in.

Table 84.	trespass	command

Function	What it does	Command	Valid targets
Display status of management module trespass feature	 Displays status of the trespass feature for the management module. Possible return values are: -twe (on or off) -tw <i>warning_message</i> Note: The <i>warning_message</i> is shown only when the trespass feature is enabled (-twe on). 	trespass	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable management module trespass feature	Enables or disables trespass feature for management module.	 trespass -twe state where state is on or off. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set management module trespass message	Sets message that is displayed to users who log in to the management module when the trespass feature is enabled. Note: Setting a new <i>warning_message</i> permanently replaces the default warning message.	trespass -tw <i>"warning_message"</i> where <i>"warning_message"</i> is up to 1600 characters in length and enclosed in double-quotation marks. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See <i>"</i> Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.

Table 84. trespass command (continued)

Function	What it does	Command	Valid targets
Set management module trespass feature to default values	 Sets trespass feature to default values: -twe: off -tw (warning message): WARNING! This computer system and network is PRIVATE AND PROPRIETARY and may only be accessed by authorized users. Unauthorized use of this computer system or network is strictly prohibited and may be subject to criminal prosecution, employee discipline up to and including discharge, or the termination of vendor/service contracts. The owner, or its agents , may monitor any activity or communication on the computer system or network. The owner, or its agents, may retrieve any information stored within the computer system or network. By accessing and using this computer system or network, you are consenting to such monitoring and information retrieval for law enforcement and other purposes. Users should have no expectation of privacy as to any communication on or information stored within the computer system or network, including information stored locally or remotely on a hard drive or other media in use with this computer system or network. 	trespass -twd This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.

Example:

To enable the management module trespass feature, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type trespass -twe on

To set the trespass feature message to 'Authorized Access only', while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

trespass -tw "Authorized Access only"

To display the management module trespass feature status, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type trespass

The following example shows the information that is returned from these commands: system:mm[1]> trespass -twe on OK system:mm[1]> trespass -tw "Authorized Access only"

```
-tw OK
system:mm[1]> trespass
-twe on
-tw Authorized Access only
```

system:mm[1]>

uicfg command

This command displays and configures the management module user interface settings.

Table	85.	uicfg	command
-------	-----	-------	---------

Function	What it does	Command	Valid targets
Display management module user interface settings	Displays the user interface settings for the management module. Returned values indicate enabled or disabled status for the following interfaces: • -cli • -snmp • -tcm (TCP command mode) • -stcm (secure TCP command mode) • -web (web interface)	uicfg	-T system:mm[x] where x is the primary management-module bay number.
Enable / disable command-line interface	Enables or disables the management module command-line interface (using Telnet or SSH).	 uicfg -cli state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Enable / disable SNMPv1 and SNMPv3	Enables or disables SNMPv1 and SNMPv3 connections to the management module.	 uicfg -snmp state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 85. uicfg command (continued)

Function	What it does	Command	Valid targets
Enable / disable TCP command mode	Enables or disables TCP command mode (used by IBM Systems Director) for the management module.	 uicfg -tcm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set number of TCP command mode connections	Enable or disable the TCP command mode, or sets the maximum number of connections explicitly. Note: Any number of connections (1 through 20) displays a status of enabled. Zero connections displays a status of disabled.	 uicfg -tcm port_mode where port_mode is enabled (1 connection), disabled (no connections), or a number between 0 and 20, inclusive, that indicates the maximum number of non-secure TCP session connections. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable secure TCP command mode	Enables or disables secure TCP command mode (used by IBM Systems Director) for the management module.	 uicfg -stcm state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 85. uicfg command (continued)

Function	What it does	Command	Valid targets
Set number of secure TCP command mode connections	 Enable or disable the secure TCP command mode, or sets the maximum number of connections explicitly. Notes: On a write operation, the maximum number of connections can be set explicitly (0-20), or it can be enabled (1 connection) or disabled (0 connections). On a read operation, disabled means 0 connections, and enabled means 1 or more connections. The total session count of TCM and STCM is limited to 20. 	<pre>uicfg -stcm port_mode where port_mode is enabled (1 connection), disabled (no connections), or a number between 0 and 20, inclusive, that indicates the maximum number of secure TCP session connections. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable web interface	Enables or disables the management module web interface.	 uicfg -web state where state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Example: To disable Secure TCP command mode for the management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

uicfg -stcm disabled

To display the user interface configuration for the management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

uicfg

The following example shows the information that is returned from these two commands:

```
system:mm[1]> uicfg -stcm disabled
Warning: Communication with IBM Systems Director via Secure TCP Command Mode
has been disabled.
OK
system:mm[1]> uicfg
-cli enabled (telnet only)
-snmp enabled
-stcm enabled
-tcm disabled
-web enabled
system:mm[1]>
```

update (update firmware) command

This command updates firmware using the uniform resource locator (URL) of a TFTP, FTP, HTTP, or HTTPS server and displays information about firmware installed in BladeCenter components.

Important:

- Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
- Scalable complexes in a BladeCenter unit require a consistent firmware level on all blade servers in a complex. When scripting firmware updates for blade servers in a scalable complex, make sure that the update commands are included for each node in the complex.

Table 86. update (update firmware) command

Function	What it does	Command	Valid targets
Display firmware attributes	 Displays attributes of the firmware installed in the command target. Return values are: Firmware type Build ID Filename Release date Revision level Notes: When the command target is the primary management module, this command will return the values for the currently active firmware and for the pending firmware, that will become active after the next management module reboot. For standby advanced management modules, the returned value will also indicate if a firmware update is in progress and the percentage that is complete. For I/O modules that support it, this command will also display firmware image information. 	update -a	-T system:mm[x] -T system:blade[x]:sp -T system:switch[x] where x is the primary management-module number, standby management-module number, blade server bay number, or I/O module bay number.

Table 86.	update	(update	firmware)	command	(continued)
-----------	--------	---------	-----------	---------	-------------

Function	What it does	Command	Valid targets
Update firmware using URL	 Update firmware for the command target using a uniform resource locator (URL). Important: Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware (see "Commands and user authority" on page 8). Notes: Updating to older firmware levels may cause loss of certain functionality The JS22 or JS12 blade server firmware is too large to be updated using this command. See the User's Guide for your JS22 or JS12 blade server for information about updating firmware. 	 update -u U_R_L where U_R_L is fully qualified uniform resource locator of a tftp, ftp, http, or https server where the firmware update image is located. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration (for management module) Blade administration (for blade server) I/O module administration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] -T system:blade[x]:sp -T system:switch[x] where x is the primary management-module, blade server bay number, or I/O-module bay number.
Update firmware and reboot	Update firmware and reboot the advanced management module to use new firmware if the update succeeds. Important: Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware.	update -u <i>U_R_L</i> -r where <i>U_R_L</i> is fully qualified uniform resource locator of a tftp, ftp, http, or https server where the firmware update image is located. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis administration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module.

Table 86. update (update firmware) command (continued)

Function	What it does	Command	Valid targets
Update firmware (verbose)	 Update firmware for the command target, showing details of the firmware download and flash operations. The detailed information is not shown until the update is complete, which might take several minutes. Important: Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware levels may cause loss of certain functionality The JS22 or JS12 blade server firmware is too large to be updated using this command. See the <i>User's Guide</i> for your JS22 or JS12 blade server for information about updating firmware. 	 update -u U_R_L -v where U_R_L is fully qualified uniform resource locator of a tftp, ftp, http, or https server where the firmware update image is located. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration (for management module) Blade administration (for blade server) I/O module administration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] -T system:blade[x]:sp -T system:switch[x] where x is the primary management-module, blade server bay number, or I/O-module bay number.
Update I/O module firmware	Directly update I/O module firmware image. Note: Only some I/O modules have this capability.	 update -u U_R_L -img img_index Where: U_R_L is fully qualified uniform resource locator of a tftp, ftp, http, or https server where the firmware update image is located. img_index is the image index you are updating. Use the update -a command to list available images and their index numbers. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration 	-T system:switch[x] where x is the I/O-module bay number.

Function	What it does	Command	Valid targets
Update I/O module firmware (verbose)	Directly update I/O module firmware image, showing details of the firmware download and flash operations. The detailed information is not shown until the update is complete, which might take several minutes.	 update -u U_R_L -img img_index -v Where: U_R_L is fully qualified uniform resource locator of a tftp, ftp, http, or https server where the firmware update image is located. img_index is the image index to the I/O module firmware you are updating. Use the update -a command to list available images and their index numbers. This command can only be run by users who have 	-T system: switch[x] where x is the I/O-module bay number.
		 one or more of the following command authorities: Supervisor I/O module administration See "Commands and user authority" on page 8 for additional information. 	
Activate I/O module firmware	Directly activate I/O module firmware image. Note: Only some I/O modules have this capability.	<pre>update -activate img_index where img_index is the image index you are activating. Use the update -a command to list available images and their index numbers. This command can only be run by users who have one or more of the following command authorities: • Supervisor • I/O module administration See "Commands and user authority" on page 8 for additional information.</pre>	-T system: switch[x] where <i>x</i> is the I/O-module bay number.

Table 86. update (update firmware) command (continued)

Table 86.	update	(update	firmware)	command	(continued)
-----------	--------	---------	-----------	---------	-------------

Function	What it does	Command	Valid targets
Update and activate I/O module firmware	 Directly update I/O module and activate the firmware image. Notes: Only some I/O modules have this capability. The activate option can be used with the other options. You can flash first, then activate the specified index. The image index you activate can be different from the one you update. 	 update -u U_R_L - img img_index -activate img_index where: U_R_L is fully qualified uniform resource locator of a tftp, ftp, http, or https server where the firmware update image is located. img_index is the image index you are activating. Use the update -a command to list available images and their index numbers. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where x is the I/O-module bay number.

Function	What it does	Command	Valid targets
Update firmware (Obsolete command. See Note following table.)	Update firmware for the command target. Important: Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware. Note: The P6 blade server firmware is too large to be updated using this command. See the User's Guide for your P6 blade server for information about updating firmware.	 update -i ip_address -1 filelocation where: ip_address is the IPv4 or IPv6 IP address of the TFTP server. filelocation is the location of the firmware update file. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration (for management module) Blade administration (for blade server) I/O module administration (for I/O module) See "Commands and user authority" on page 8 for 	-T system:mm[x] -T system:blade[x]:sp -T system:switch[x] where x is the primary management-module, blade server bay number, or I/O (switch) module bay number.
Update firmware (verbose) (Obsolete command. See Note following table.)	Update firmware for the command target, showing details of the firmware download and flash operations. The detailed information is not shown until the update is complete, which might take several minutes. Important: Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware. Note: The P6 blade server firmware is too large to be updated using this command. See the <i>User's</i> <i>Guide</i> for your P6 blade server for information about updating firmware.	 additional information. update -i <i>ip_address</i> -1 <i>filelocation</i> -v where: <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server. <i>filelocation</i> is the location of the firmware update file. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis administration (for management module) Blade administration (for blade server) I/O module administration (for I/O module) See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] -T system:blade[x]:sp -T system:switch[x] where x is the primary management-module, blade server bay number, or I/O (switch) module bay number.

Table 86. update (update firmware) command (continued)

Function	What it does	Command	Valid targets
Update I/O module firmware (Obsolete command. See Note following table.)	Directly update I/O module firmware image. Note: Only some I/O modules have this capability.	 update -i <i>ip_address</i> -1 <i>filelocation</i> - img <i>img_index</i> <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server. <i>filelocation</i> is the location of the firmware update file. <i>img_index</i> is the image index you are updating. Use the update -a command to list available images and their index numbers. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration See "Commands and user authority" on page 8 for additional information. 	-T system:switch[x] where <i>x</i> is the I/O (switch) module bay number.

Table 86. update (update firmware) command (continued)

Function	What it does	Command	Valid targets
Update I/O module firmware (verbose) (Obsolete command. See Note following table.)	Directly update I/O module firmware image, showing details of the firmware download and flash operations. The detailed information is not shown until the update is complete, which might take several minutes. Note: Only some I/O modules have this capability.	 update -i ip_address -1 filelocation -img img_index -v where: ip_address is the IPv4 or IPv6 IP address of the TFTP server. filelocation is the location of the firmware update file. img_index is the image index to the I/O module firmware you are updating. Use the update -a command to list available images and their index numbers. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration 	-T system:switch[x] where <i>x</i> is the I/O (switch) module bay number.
Activate I/O module firmware (Obsolete command. See Note following table.)	Directly activate I/O module firmware image. Note: Only some I/O modules have this capability.	<pre>update -activate img_index where img_index is the image index you are activating. Use the update -a command to list available images and their index numbers. This command can only be run by users who have one or more of the following command authorities: • Supervisor • I/O module administration See "Commands and user authority" on page 8 for additional information.</pre>	-T system:switch[x] where <i>x</i> is the I/O (switch) module bay number.

Table 86. update (update firmware) command (continued)

Function	What it does	Command	Valid targets
Update and activate I/O module firmware (Obsolete command. See Note following table.)	 Directly update I/O module and activate the firmware image. Notes: Only some I/O modules have this capability. The activate option can be used with the other options. You can flash first, then activate the specified index. The image index you activate can be different from the one you update. 	 update -i <i>ip_address</i> -1 <i>filelocation</i> - img <i>img_index</i> -activate <i>img_index</i> where: <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server. <i>filelocation</i> is the location of the firmware update file. <i>img_index</i> is the image index you are activating. Use the update -a command to list available images and their index numbers. This command can only be run by users who have one or more of the following command authorities: Supervisor I/O module administration See "Commands and user authority" on page 8 for additional information. 	-T system: switch[x] where x is the I/O (switch) module bay number.

Table 86. update (update firmware) command (continued)

Note: The -i and -l options for the update command have been replaced by the -u command option. While the -i and -l options will remain active for a few releases before being removed, users are encouraged to transition to the -u option as soon as possible.

To accomplish this transition, the IP address and file location of the firmware update file or image, specified by the arguments to the -i and -l options, must be replaced by the -u option followed by an argument that specifies the fully qualified uniform resource locator (URL) of a tftp, ftp, http, or https server where the firmware update file or image is located.

Example: To update the advanced management module firmware from a TFTP server and reboot the advanced management module in management-module bay 1 after a successful update, type the following command at the system:> prompt. For this example, the IP address of the TFTP server is 9.37.177.215 and the firmware file containing the update is named CNETMNUS.pkt. The verbose mode and reboot flag are also specified.

update -u tftp://9.37.177.215/temp/CNETMNUS.pkt -T mm[1] -v -r

The following example shows the information that is returned from the update command:

```
system> update -u tftp://9.37.177.215/temp/CNETMNUS.pkt -T mm[1] -v -r
100% transferred (100/100)
transfer completed successfully
flashing firmware to target device
Starting flash packet preparation.
Flash preparation - packet percent complete 4.
Flash preparation - packet percent complete 8.
Flash preparation - packet percent complete 12.
Flash preparation - packet percent complete 16.
Flash preparation - packet percent complete 20.
Flash preparation - packet percent complete 24.
Flash preparation - packet percent complete 28.
Flash preparation - packet percent complete 32.
Flash preparation - packet percent complete 36.
Flash preparation - packet percent complete 40.
Flash preparation - packet percent complete 44.
Flash preparation - packet percent complete 50.
Flash preparation - packet percent complete 54.
Flash preparation - packet percent complete 58.
Flash preparation - packet percent complete 62.
Flash preparation - packet percent complete 66.
Flash preparation - packet percent complete 70.
Flash preparation - packet percent complete 74.
Flash preparation - packet percent complete 78.
Flash preparation - packet percent complete 82.
Flash preparation - packet percent complete 86.
Flash preparation - packet percent complete 90.
Flash preparation - packet percent complete 94.
Flash preparation - packet percent complete 98.
Flash operation phase starting.
Flashing - packet percent complete 34.
Flashing - packet percent complete 50.
Flashing - packet percent complete 82.
Update of AMM Main Application firmware was successful.
```

The new firmware will become active after the next reset of the MM.

Rebooting AMM...

uplink (management module failover) command

This command displays and configures the management-module uplink failover feature. If the external network interface of the primary management module fails, this feature forces a failover to the standby management module, if one is installed.

Note: This command does not apply to the BladeCenter S unit.

Function	What it does	Command	Valid targets
Display uplink failover status	Displays the management-module uplink failover status (enabled or disabled) and the failover delay.	uplink	-T system -T system:mm[x] where x is the primary management-module bay number.
Set physical network uplink failover delay	Sets the amount of time between detection of a management-module physical uplink failure and failover to the standby management module.	uplink -dps <i>delay</i> where <i>delay</i> is from 10 to 172800 seconds, inclusive. If you enter a value outside this range, an error will be displayed. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for	-T system -T system:mm[x] where <i>x</i> is the primary management-module bay number.
Enable / disable physical uplink failover	Enables or disables failover to the standby management module if the external physical network interface of the primary management module fails.	additional information. uplink -ep <i>state</i> where <i>state</i> is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system -T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 87. uplink command

Table 87. uplink command (continued)

Function	What it does	Command	Valid targets
Set logical network uplink failover delay	Sets the amount of time between detection of a management-module logical uplink failure and failover to the standby management module.	uplink -dls <i>delay</i> where <i>delay</i> is from 60 to 172800 seconds, inclusive. If you enter a value outside this range, an error will be displayed.	-T system -T system:mm[x] where <i>x</i> is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities:SupervisorChassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Enable / disable logical uplink failover	Enables or disables failover to the standby management module if the external logical network interface of the primary management module	uplink -el <i>state</i> where <i>state</i> is enabled or disabled.	<pre>-T system -T system:mm[x] where x is the primery</pre>
	fails. You must enter a non-zero IP address (-ip command option) or IPv6 IP address (-ip6 command option) for a device that the management module can access to check its logical network link before you can enable logical uplink failover.	 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	management-module bay number.
Set IP address to check logical network uplink	Sets the IPv4 IP address of the device that the management module accesses to check its logical network link.	uplink -ip <i>ip_address</i> where <i>ip_address</i> is a valid IPv4 IP address. You must enter a non-zero IPv4 IP address, in dotted decimal IP address format, before you can enable logical uplink failover. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system -T system:mm[x] where x is the primary management-module bay number.

Table 87. uplink command (continued)

Function	What it does	Command	Valid targets
Set IPv6 IP address to check logical network uplink	Sets the IPv6 IP address of the device that the management module accesses to check its logical network link.	uplink -ip6 <i>ip_address</i> where <i>ip_address</i> is a valid IPv6 IP address. You must enter a non-zero IP address, in IPv6 format, before you can enable logical uplink failover. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	-T system -T system:mm[x] where <i>x</i> is the primary management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	
Set logical link loss alert and failover policy	Sets the alert and failover policy for logical link loss to check either the IPv4 IP address, the IPv6 IP address, or both of these IP addresses. Note: The -alert command option applies only when both the -ip and -ip6 command options are set.	 uplink -alert setting where setting is: either to check either the IPv4 IP address or the IPv6 IP address. both to check both the IPv4 IP address and the IPv6 IP address. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system -T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example: To enable failover to the standby management module if the external physical network interface of a primary management module fails, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

uplink -ep enabled

To display the uplink failover configuration, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type uplink

The following example shows the information that is returned from these commands:

system:mm[1]> uplink -ep enabled OK system:mm[1]> uplink Failover on network uplink loss is enabled for physical detection Uplink delay for physical detection: 60 seconds

Failover on network uplink loss is enabled for logical detection Uplink delay for logical detection: 1800 seconds Destination IP for MM to check its logical link: 1.1.1.0 Destination IPv6 IP for MM to check its logical link: 1::2 Alert and failover if both IPv4 and IPv6 link checks fail system:mm[1]>

users command

This command displays and configures user accounts, also called user profiles, of the primary management module.

Important: Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware.

Table 88. users (management-module users) command

Function	What it does	Command	Valid targets
Display all user profiles	 Displays all 12 management-module user profiles. Returned values are: User name Authority level Current log in or log out state Password compliance State of account (active or inactive) Number of SSH public keys installed for user 	users	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display active users	 Displays all users that are currently logged in to the management module. Returned values include: User name User IP address Connection type (SNMPv1, SNMPv3, SSH, TCP command mode, Telnet, Web) Session ID 	users -curr	-T system:mm[x] where x is the primary management-module bay number.
Terminate user session	Terminates the specified user login session. Note: The session ID is found by running the users -curr command.	 users -ts sessionID where sessionID is a number that corresponds to the user session ID. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 88. users	(management-module	users) command	(continued)
-----------------	--------------------	----------------	-------------

Function	What it does	Command	Valid targets
Display single user profile	Displays the specified management-module user profile. Returned values are: • User name • Authority level • Context name • Authentication protocol • Privacy protocol • Access type • Hostname/IP address • Maximum simultaneous sessions allowed • Number of active sessions • Password compliance • Password expiration date • Account state • Number of SSH public keys installed for this user • Last time this user logged in	users <i>-user_number</i> where <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Delete user profile	Delete the specified management-module user profile.	users -user_number -clear where user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. It is possible to delete an empty user profile. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis account management See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where x is the primary management-module bay number.

Function	What it does	Command	Valid targets
Disable user account	Disable the specified management-module user account.	users -user_number -disable where user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.	-T system:mm[x] where x is the primary management-module bay number.
		 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management Chassis administration Chassis configuration 	
		See "Commands and user authority" on page 8 for additional information.	
Enable user profile	Enable a disabled management-module user account.	users -user_number -enable where user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis account management • Chassis configuration	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	

Table 88. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Unlock user profile	Unlock a locked management-module user account.	users -user_number -unlock where user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis account management • Chassis administration • Chassis configuration See "Commands and user authority" on page 8 for additional information.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 88. users (management-module users) command (continued)

Table 88. users	(management-module	users) command	(continued)
-----------------	--------------------	----------------	-------------

Function	What it does	Command	Valid targets
Create user profile	<pre>Vnar it does Create the specified management-module user profile. All fields must be specified when creating a user profile for the BladeCenter T management module. For management modules other than those installed in a BladeCenter T unit, only the following user-profile fields are required: -user_number -a user_number -p user_password </pre>	<pre>command users -user_number -n user_name -p user_password -a user_authority -cn context_name -ap auth_protocol -pp privacy_protocol -ppw privacy_protocol -ppw privacy_protocol -ppw privacy_protocol -ppw max_sessions where: • user_number is a number from 1 to 12 that corresponds to an unused user number in the "Display all user profiles" list. • user_name is an alphanumeric string up to 15 characters in length that can include periods (.) and underscores (_). Each of the 12 user names must be unique. • user_password can be blank or an alphanumeric string up to 15 characters in length that can include periods (.) and underscores (_), and must include at least one alphabetic and one non-alphabetic character. • user_authority is one of the following: – operator (read-only) – rbs (see Set user authority level for more information) (continued on next page)</pre>	-T system:mm[x] where x is the primary management-module bay number.
		1.0	

Table 88. users	(management-module users)) command	(continued)
-----------------	---------------------------	-----------	-------------

Function	What it does	Command	Valid targets
Create user profile (continued)		 context_name is an alphanumeric string up to 31 characters in length that can include periods (.) and underscores (_). auth_protocol choices are: md5 sha none privacy_protocol choices are: des aes none privacy_pwd is an alphanumeric string up to 31 characters in length that can include periods (.) and underscores (_). access_type choices are: get set trap ip_addr/hostname is up to 63 characters in length. max_sessions is a number from 0 to 20. 	
		 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management 	
		See "Commands and user authority" on page 8 for additional information.	

Function	What it does	Command	Valid targets
Function Set user name	What it does Sets a user name in the specified management-module user profile.	Command users -user_number -n user_name where: • user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. • user_name is a alphanumeric string up to 15 characters in length that can include periods (.) and underscores (_). Each of the 12 user names must be unique. This command can only be run by users who have one or more of the following command authorities: • Supervisor	Valid targets -T system:mm[x] where x is the primary management-module bay number.
		 Chassis account management See "Commands and user authority" on page 8 for additional information. 	

Table 88. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Set user password	Sets a user password in the specified management-module user profile.	 users -user_number -p user_password where: user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. user_password can be blank or an alphanumeric string up to 15 characters in length that can include periods (.) and underscores (_), and must include at least one alphabetic and one non-alphabetic character. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management 	-T system:mm[x] where x is the primary management-module bay number.

Table 88. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Change user password	Changes the user password in the specified management-module user profile. Note: Users can change their own password even if they do not have authority to manage accounts. The -op option is only used when changing your own password	 users -user_number -op old_password -p new_password where: user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. old_password is the current password for the specified user. new_password can be blank or an alphanumeric string up to 15 characters in length that can include periods (.) and underscores (_), and must include at least one alphabetic and one non-alphabetic character. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 88. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Function Set user authority level	What it does Sets a user authority level in the specified management-module user profile.	Command users -user_number -a user_authority where: • user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. • user_authority is one of the following: – operator (read-only) – rbs (custom) The custom authority level parameter is specified using the following syntax: rbs:levels:devices where the levels are one or more of the following authority levels, separated by a vertical bar (1): • super (Supervisor) • cam (Chassis User Account Management) • c0 (Chassis Cog Management) • c0 (Chassis Operator) • cc (Chassis Configuration) • ca (Chassis Administration) • bo (Blade Operator) • bo (Blade Configuration) • bo (Blade Configuration) • bo (Chase Configuration) • bo (Blade Configuration) • bo (Chase Configuration) • co (Chase Configuration) • co (Chase Configuration) • bo (Chase Configuration) • co (Chase Con	Valid targets -T system:mm[x] where x is the primary management-module bay number.
		 sc (I/O Module Configuration) sa (I/O Module Administration) (continued on next page) 	

Table 88. users (management-module users) command (continued)
Table 88. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Set user authority level (continued)	 Notes: The LDAP authority levels are not supported by the management-module web interface. To use the LDAP authority levels, make sure that the version of LDAP security used by the management module is set to v2 (enhanced role-based security model). See "Idapcfg command" on page 210 for information. 	 The <i>levels</i> can also include one or more of the following authority levels when using LDAP. brpv (Blade Remote Presence View Video) brpk (Blade Remote Presence KVM) brpr (Blade Remote Drive Read) crpru (Blade Remote Drive Read) crpru (Blade Remote Drive Read or Write) rps (Remote Presence Supervisor) where the <i>devices</i> are one or more of the following devices, separated by a vertical bar (). Ranges of devices are separated by a dash (-). <i>cn</i> (Chassis <i>n</i>, where <i>n</i> is a valid chassis number. Use c1 for single-chassis environments.) b<i>n</i> (Blade <i>n</i>, where <i>n</i> is a valid blade bay number in the chassis) <i>sn</i> (I/O module <i>n</i>, where <i>n</i> is a valid I/O module bay number in the chassis) This command can only be run by users who have one or more of the following command authorities: Supervisor 	
		See "Commands and user authority" on page 8 for additional information.	

Function	What it does	Command	Valid targets
Set maximum number of simultaneous sessions for user	Sets the maximum number of simultaneous login sessions for the specified user.	 users -user_number -ms max-session where: user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. max-session is a number from 0 to 20 that sets the maximum number of simultaneous sessions for the user. A value of 0 means that there is no session limit for the user. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.
Set SNMPv3 user context name	Sets an SNMPv3 context name in the specified management-module user profile. The context name defines the context the SNMPv3 user is working in. A context name can be shared by multiple users.	 users -user_number -cn context_name where: user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. context_name is a string up to 31 characters in length. Each of the 12 context names must be unique. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

 Table 88. users (management-module users) command (continued)
 Image: Continued

Function	What it does	Command	Valid targets
Set SNMPv3 user authentication protocol	Sets the SNMPv3 authentication protocol to be used for the specified management-module user profile.	<pre>users -user_number -ap auth_protocol where: • user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. • auth_protocol is:</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		 This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user 	
		authority" on page 8 for additional information.	
Set SNMPv3 user privacy protocol	Sets the SNMPv3 privacy protocol to be used for the specified management-module user profile. If the privacy protocol is set to none, no -ppw command option (privacy password) is required.	 users -user_number -pp privacy_protocol where: user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. privacy_protocol is: aes des none This command can only be run by users who have one or more of the 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		 following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	

Table 88. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Set privacy password for SNMPv3 user	Sets an SNMPv3 privacy password in the specified management-module user profile.	 users -user_number -ppw privacy_pwd where: user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. privacy_pwd is a string up to 31 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set access type for SNMPv3 user	 Sets an SNMPv3 access type for the specified management-module user profile. This command supports the following access types: get: the user can query Management Information Base (MIB) objects and receive traps. set: the user can query and set MIB objects and receive traps. trap: the user can only receive traps. 	<pre>users -user_number -at access_type where: • user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. • access_type is - get - set - trap This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis account management See "Commands and user authority" on page 8 for additional information.</pre>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 88. users (management-module users) command (continued)

Table 88. users	(management-module	users)	command	(continued)
-----------------	--------------------	--------	---------	-------------

Function	What it does	Command	Valid targets
Set IP address or hostname for SNMPv3 trap receiver	Sets the IP address or hostname that will receive SNMPv3 traps for the specified management-module user profile.	 users -user_number -i ip_addr/hostname where: user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. ip_addr/hostname is a valid static IP address or an alphanumeric hostname string up to 63 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Display SSH public key	Displays the entire specified SSH public key for the specified user in OpenSSH format. Note: The -pk and -e options must be used exclusive of all other users command options.	 users -user_number -pk -key_index -e where: user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. key_index identifies the key number from 1 to 12 to display. If the -key_index is all, then all keys for the user are displayed. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 88. users	(management-module	users) command	(continued)
-----------------	--------------------	----------------	-------------

Function	What it does	Command	Valid targets
Add SSH public key	 Adds an SSH public key for the specified user. Notes: The -pk and -add options must be used exclusive of all other users command options. The SSH Public Key is added to the first available storage location. Each advanced management module can support up to 12 SSH public keys. Each user is permitted a maximum of four SSH public keys, if the space is available. 	 users -user_number -pk -add key where: user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. key is a valid key in OpenSSH format. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Add specific SSH public key	Adds a specific SSH public key for the specified user. Note: The -pk and -add options must be used exclusive of all other users command options.	 users -user_number -pk -key_index -add key where: user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. key_index identifies the key number from 1 to 12 to add. key is a valid key in OpenSSH format. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Function	What it does	Command	Valid targets
Remove SSH public key	Removes an SSH public key for the specified user. Note: The -pk and -remove options must be used exclusive of all other users command options.	 users -user_number -pk -key_index -remove user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. key_index identifies the key number from 1 to 12 to remove. If the -key_index is "all", then all keys for the user are removed. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 88. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Upload SSH public key	Uploads a new SSH public key.	 users -user_number -pk -upld -i ip_addr/hostname -1 filename user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. ip_addr/hostname is a valid static IPv4 or IPv6 IP address or an alphanumeric hostname string up to 63 characters in length of the TFTP server. filename is the filename of the key file. Keys must be in OpenSSH format. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 88. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Replace SSH public key	Replaces an existing SSH public key.	 users -user_number -pk -key_index -upld -i ip_addr/hostname -1 filename user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. key_index identifies the key number from 1 to 12 to replace. ip_addr/hostname is a valid static IPv4 or IPv6 IP address or an alphanumeric hostname string up to 63 characters in length of the TFTP server. filename is the filename of the key file. Keys must be in OpenSSH format. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 88. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Download SSH public key	Downloads a specific SSH public key to a TFTP server. Note: The -pk and -dn1d options must be used exclusive of all other users command options.	 users -user_number -pk -key_index -dnld -i ip_addr/hostname -1 filename user_number is a number from 1 to 12 that corresponds to the user number assigned in the Display all user profiles list. key_index identifies the key number from 1 to 12 to upload. ip_addr/hostname is a valid static IPv4 or IPv6 IP address or an alphanumeric hostname string up to 63 characters in length of the TFTP server. filename is the filename of the key file. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 88. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
Connect to SSH public key	Accept connections from SSH public key host.	 users -user_number -pk -key_index -af from="list" user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. key_index identifies the key number from 1 to 12 to connect. "list" is a comma-separate list of hostnames and IP addresses. The list is an alphanumeric string up to 511 characters in length that can include alphanumeric characters, commas, asterisks, question marks, exclamation points, periods, and hyphens. The string must be enclosed in double-quotes. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management 	-T system:mm[x] where x is the primary management-module bay number.
		additional information.	

Table 88. users	(management-module	users)	command	(continued)
-----------------	--------------------	--------	---------	-------------

Function	What it does	Command	Valid targets
Comment SSH public key	Add comment to an SSH public key.	 users -user_number -pk -key_index -cm "comment" user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. key_index identifies the key number from 1 to 12 to comment. "comment" is up to 255 characters in length, enclosed in double-quotes. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis account management See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 88. users	(management-module users)) command	(continued)
-----------------	---------------------------	-----------	------------	---

Example: To create user number 3 with a user name of user3 who has supervisor rights to all BladeCenter components, while management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type

users -3 -n user3 -p passw0rd -a rbs:super:c1|b1-b14|s1-s4 -cn joe -ap md5 -pp des -ppw passw0rd -at get -I 192.168.70.129

Note: The entry beginning with users -3 -n... is shown with a line break after -pp des. When this command is entered, the entire entry must all be on one line.

To display all users, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type users

The following example shows the information that is returned from these commands:

Note: The entry beginning with users -3 -n... is shown with a line break after -a rbs:super:c1|b1-b14|s1-s4. When this command is entered, the entire entry must all be on one line.

```
system:mm[1]> users -3 -n user3 -p passw0rd -a rbs:super:c1|b1-b14|s1-s4
-cn joe -ap md5 -pp des -ppw passw0rd -at get -I 192.168.70.129
OK
system:mm[1]> users
0 active session(s)
Password compliant
Account active
```

```
Role:cam
  Blades:1|2|3|4|5|6|7|8|9|10|11|12|13|14
  Chassis:1
  Modules:12345678910
There are no SSH public keys installed for this user
2. kprevent
0 active session(s)
Password compliant
Account active
  Role:supervisor
  Blades:1234567891011121314
  Chassis:1
  Modules:12345678910
There are no SSH public keys installed for this user
3. johnh
0 active session(s)
Password compliant
Account active
   Role:supervisor
  Blades:1234567891011121314
  Chassis:1
  Modules:12345678910
There are no SSH public keys installed for this user
4. toms
1 active session(s)
Password compliant
Account active
  Role:supervisor
  Blades:1234567891011121314
  Chassis:1
  Modules:12345678910
Number of SSH public keys installed for this user: 3
5. <not used>
6. <not used>
7. <not used>
8. <not used>
9. <not used>
10. <not used>
11. <not used>
12. <not used>
system:mm[1]>
```

vlan command

This command configures and displays the VLAN (virtual local area network) settings of the management module.

Function	What it does	Command	Valid targets
Display VLAN settings	Displays the settings for V Note: The command issued by itself will display all entries, the global state, the commit timeout, and whether the current configuration has been committed.LAN.	 vl an This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Apply VLAN settings	Applies the configuration changes for VLAN. Note: Configuration changes must be committed before the commit timeout expires, otherwise the previous configuration will be restored.	 vlan -commit This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Apply VLAN settings timeout	Sets the custom value of the configuration changes timeout for VLAN.	 vlan -cto timeout where timeout is from 1 to 255 minutes, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 89.	vlan command	(continued)
-----------	--------------	-------------

Function	What it does	Command	Valid targets
Set global VLAN state	Sets the global state of VLAN to enabled or disabled.	 vlan -state <i>state</i> where <i>state</i> is enabled disabled This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set VLAN state	 Sets the custom state of the non-fixed entry for VLAN. Notes: <i>restart</i> is valid for non-fixed entries. <i>default</i> is valid for every entry. 	 vlan -vi vlan_entry_index state state where vlan_entry_index is the VLAN entry's index. state is enabled disabled default restart This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Delete global VLAN entry	Deletes all non-fixed VLAN entries.	 vlan -delete This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 89.	vlan command	(continued)
-----------	--------------	-------------

Function	What it does	Command	Valid targets
Delete VLAN entry	Deletes the specified VLAN entry.	vlan -vi <i>vlan_entry_index</i> -delete where <i>vlan_entry_index</i> is the VLAN entry's index.	-T system:mm[x] where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Display VLAN entry	Displays the VLAN entry.	vlan -vi <i>vlan_entry_index</i> where <i>vlan_entry_index</i> is the VLAN entry's index.	-T system:mm[x] where x is the primary management-module
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	bay number.
		See "Commands and user authority" on page 8 for additional information.	
Create VLAN entry	 Creates the VLAN entry. Notes: -vi and -vid must be set to create an entry. -state, and -n are optional. A default entry name is used if -n is not specified. 	 vlan -vi vlan_entry_index -vid vlan_id where vlan_entry_index is the VLAN entry's index. vlan_id is the number from 1 to 4,094, inclusive. 	-T system:mm[x] where x is the primary management-module bay number.
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	

Table 89. vlan command (continued)

Function	What it does	Command	Valid targets
Set VLAN ID	Sets the VLAN ID.	 vlan -vi vlan_entry_index -vid id where vlan_entry_index is the VLAN entry's index. id is the number from 1 to 4,094, inclusive. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set remote presence access	Enables or disabled the remote presence access. Note: Before enabling the remote presence access, you have to disable it on whichever VLAN it is enabled on.	 additional information. vl an -vi vlan_entry_index -rp state where vlan_entry_index is the VLAN entry's index. state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 89. vlan command (continued)

Function	What it does	Command	Valid targets
Set SOL access	Enables or disabled the SOL access. Note: Before enabling the SOL access, you have to disable it on whichever VLAN it is enabled on.	 vlan -vi vlan_entry_index -sol state where vlan_entry_index is the VLAN entry's index. 	-T system:mm[x] where x is the primary management-module bay number.
		• <i>state</i> is enabled or disabled.	
		This command can only be run by users who have one or more of the following command authorities: • Supervisor • Chassis configuration	
		See "Commands and user authority" on page 8 for additional information.	
Set VLAN tagging	Enables or disabled the VLAN tagging. Note: vlan -tag is only valid for the default entry.	 vlan -vi vlan_entry_index -tag state where vlan_entry_index is the VLAN entry's index. state is enabled or disabled. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
		See "Commands and user authority" on page 8 for additional information.	

Table 89.	vlan col	nmand	(continued)
-----------	----------	-------	-------------

Function	What it does	Command	Valid targets
Set VLAN entry name	Sets the VLAN entry name.	 vlan -vi vlan_entry_index n name where vlan_entry_index is the VLAN entry's index. name is the quote-delimited VLAN entry name, of 1 to 31 characters in length. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set VLAN configuration	Sets the IPv4 configuration method for VLAN. Note: It is not applied to the fixed entry.	 vl an -vi vlan_entry_index c method where vlan_entry_index is the VLAN entry's index. method is static. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 89. vlan command (continued)

Function	What it does	Command	Valid targets
Set VLAN IP address (IPv4)	Sets the IPv4 address for VLAN. Note: It is not applied to the fixed entry.	 vlan -vi vlan_entry_index -i ip_address where vlan_entry_index is the VLAN entry's index. ip_address is the IP address. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and user authority on page 8 for a set of the following commands and the foll	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set VLAN subnet (IPv4)	Sets the IPv4 subnet for VLAN. Note: It is not applied to the fixed entry.	 vlan -vi vlan_entry_index s subnet where vlan_entry_index is the VLAN entry's index. subnet is the subnet. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where x is the primary management-module bay number.

Table 89. vlan command (continued)

Function	What it does	Command	Valid targets
Set VLAN gateway (IPv4)	Sets the IPv4 gateway for VLAN. Note: It is not applied to the fixed entry.	 vlan -vi vlan_entry_index g gateway where vlan_entry_index is the VLAN entry's index. gateway is the gateway. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set VLAN subnet route	Sets the custom value of subnet route for VLAN. Note: It is not applied to the fixed entry.	 vlan -vi vlan_entry_index -srx subnet_route where vlan_entry_index is the VLAN entry's index. x is 1, 2, or 3. subnet_route is the subnet route. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 89. vlan command (continued)

Function	What it does	Command	Valid targets
Set VLAN subnet mask	Sets the custom value of subnet mask for VLAN. Note: It is not applied to the fixed entry.	 vlan -vi vlan_entry_index -smx subnet_mask where vlan_entry_index is the VLAN entry's index. x is 1, 2, or 3. 	-T system:mm[x] where x is the primary management-module bay number.
		 <i>subnet_mask</i> is the subnet mask. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration 	
		See "Commands and user authority" on page 8 for additional information.	

Example:

To change the name of VLAN entry 2 to VLAN-2, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type vlan -vi 2 -n "VLAN-2"

To apply the change, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

vlan -commit

To display the VLAN settings, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type vlan

The following example shows the information that is returned from these three commands:

```
system:mm[1]> vlan -vi 2 -n "VLAN-2"
All changes must be committed within 2 minutes using -commit.
0K
system:mm[1]> vlan -commit
0K
system:mm[1]> vlan
-state disabled
-cto 2
Default entry
-vi 1
-n VLAN-1
-state enabled
-vid 1
-sol enabled
-rp enabled
-tag disabled
I/O module access enabled
```

```
IPv4 config method: static
IPv4 address: 9.72.217.71
IPv4 subnet: 255.255.248.0
IPv4 gateway: 9.72.216.1
-vi 2
-n VLAN-2
-state disabled
-vid 1000
-sol disabled
-rp disabled
Tagging: enabled
-c static
-i 0.0.0.0
-s 0.0.0.0
-g 0.0.0.0
-sr1 0.0.0.0
-sm1 0.0.0.0
-sr2 0.0.0.0
-sm2 0.0.0.0
-sr3 0.0.0.0
-sm3 0.0.0.0
```

The current configuration has been committed. system:mm[1]>

volts command

This command displays actual voltages and voltage threshold values for BladeCenter components.

TADIE 90. VOIIS COMMAND	Table	90.	volts	command
-------------------------	-------	-----	-------	---------

Function	What it does	Command	Valid targets
Display voltage values	 Displays the current voltage and voltage threshold settings for the specified component: The management module target displays the voltage values for the BladeCenter unit. The blade server target displays the internal voltage values for the specified blade server. Note: The voltage values that display will vary based on BladeCenter unit and blade server type. 	volts	-T system:mm[x] -T system:blade[x] where <i>x</i> is the primary management-module or blade server bay number.

Example: To view the current voltage and voltage thresholds for the blade server in bay 3, while this blade server is set as the persistent command environment, at the system:blade[3]> prompt, type

volts

The following example shows the information that is returned from this command: system:blade[3]> volts

Source	Value	Warning
1.8V Sense 1.8VSB Sense 12V Sense 12VSB Sense 3.3V Sense	+1.79 +1.83 +12.33 +12.30 +3.31	(+1.61,+1.97) (+1.61,+1.97) (+10.79,+13.21) (+10.74,+13.19) (+2.96,+3.62)
system:blade[3]>	(14.35, 13.40)

write command

This command saves the management-module configuration to the chassis of the BladeCenter unit or to a file.

Table	91.	write	command

Function	What it does	Command	Valid targets
Save management-module configuration to chassis	Saves an image of the management-module configuration to the BladeCenter unit chassis.	 write -config chassis This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Save management-module configuration to file (no encryption)	Saves an image of the management-module configuration to a file while data encryption is not enabled for the BladeCenter unit.	 write -config file -1 <i>filename</i> -i <i>ip_address</i> where: <i>filename</i> is the name of the configuration file. <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server where the configuration file is located. Note: If the -1 <i>filename</i> option is not specified, the default filename of asm.cfg is used. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 91. write command (continued)

Function	What it does	Command	Valid targets
Save management-module configuration to file (encryption)	Saves an image of the management-module configuration to a file while data encryption is enabled for the BladeCenter unit. Note: When a configuration file is created with a pass-phrase (encryption enabled), if this configuration file is restored on the same management module, the pass-phrase entered during restoration is ignored.	 write -config file -1 <i>filename</i> -i <i>ip_address</i> -p <i>passphrase</i> where: <i>filename</i> is the name of the configuration file. <i>ip_address</i> is the IPv4 or IPv6 IP address of the TFTP server where the configuration file is located. <i>passphrase</i> is a double-quote delimited pass-phrase that will be needed to restore the configuration file. Maximum pass-phrase length is 1600 characters. Note: If the -1 <i>filename</i> option is not specified, the default filename of asm.cfg is used. This command can only be run by users who have one or more of the following command authorities: Supervisor Chassis configuration See "Commands and user authority" on page 8 for additional information. 	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Example:

To save the management-module configuration to an image on the BladeCenter chassis, while management module 1 is set as the persistent command environment, at the system:mm[1] > prompt, type write -config chassis

The following example shows the information that is returned from this command:

```
system:mm[1]> write -config chassis
0K
Configuration settings were successfully saved to the chassis
system:mm[1]>
```

zonecfg command

This command sets and displays the serial attached SCSI (SAS) device information for BladeCenter components that is stored in I/O modules that support this feature.

Function	What it does	Command	Valid targets
Display SAS zone list	Displays a list of SAS device zones and their information that is stored in the specified I/O module.	zonecfg	-T system:switch[x] where x is the I/O-module bay number.
Activate SAS zone - single SAS switch	Activates a SAS zone, selected by index number, for the specified SAS switch module. Note: If the I/O module is not in an operating condition that allows a zone to be activated, the command returns an advisory message.	<pre>zonecfg -activate zone where zone is the index number for a valid zone. Use the zonecfg command, with no options, to list valid zones and their index numbers. This command can only be run by users who have one or more of the following command authorities: • Supervisor • I/O module</pre>	-T system:switch[x] where <i>x</i> is the I/O-module bay number.
		configuration See "Commands and user authority" on page 8 for additional information.	
Activate SAS zone - all SAS switches	Activates a SAS zone, selected by index number, for all SAS switch modules. Note: If the I/O module is not in an operating condition that allows a zone to be activated, the command returns an advisory message.	<pre>zonecfg -activate zone where zone is the index number for a valid zone. Use the zonecfg command, with no options, on all I/O modules to determine the valid zones that are common to all SAS switch modules and their index numbers. This command can only be run by users who have one or more of the following command authorities: • Supervisor • I/O module configuration See "Commands and user</pre>	-T system
		authority" on page 8 for additional information.	

Table 92. zonecfg command (continued)

Function	What it does	Command	Valid targets
Display SAS zone information	Displays information about a SAS zone, selected by index number, that is stored in the specified I/O module.	zonecfg -view <i>zone</i> where <i>zone</i> is the index number for a valid zone.	-T system:switch[x] where x is the I/O-module bay number.

Note: If you install both RAID SAS (RSS) and Non-RAID SAS (NSS) mass storage devices, you can only power on and manage the zone configuration for one at a time.

Example: To view the list of SAS zones stored in the I/O module in bay 1, while this I/O module is set as the persistent command environment, at the system:switch[1]> prompt, type zonecfg

To activate SAS zone 5 for the I/O module in bay 1, while this I/O module is set as the persistent command environment, at the system:switch[1]> prompt, type zonecfg -activate 5

The following example shows the information that is returned from these commands:

system:switch[1]> zonecfg Index: 3 Name: Name3 Description string for zone config 3 Status: Inactive Type: Predefined Date: <mm> Index: 5 Name: Name5 Description string for zone config 5 Status: Inactive Type: Configurable Date: <mm> Index: 2 Name: Name2 Description string for zone config 2 Status: Inactive Type: Configurable Date: <mm> Index: 24 Name: Name24 Description string for zone config 24 Status: Active Type: Configurable Date: <mm> system:switch[1]> zonecfg Index: 3 Name: Name3 Description string for zone config 3

Index: 5

Status: Inactive
Type: Predefined
Date: <mm>

Name: Name5 Description string for zone config 5 Status: Pending Type: Configurable Date: <mm> Index: 2 Name: Name2 Description string for zone config 2 Status: Inactive Type: Configurable Date: <mm> Index: 24 Name: Name24 Description string for zone config 24 Status: Active Type: Configurable Date: <mm> system:switch[1]> zonecfg -activate 5 0K system:switch[1]>

Chapter 4. Error messages

This topic lists error messages for the BladeCenter command-line interface.

The command-line interface provides error messages specific to each command. The following topics list the common error messages that apply to all commands and command-specific error messages, along with their definitions.

- "Common errors" on page 421
- "accseccfg command errors" on page 423
- "advfailover command errors" on page 424
- "alarm command errors" on page 425
- "alertcfg command errors" on page 426
- "alertentries command errors" on page 426
- "autoftp command errors" on page 427
- "baydata command errors" on page 427
- "bofm command errors" on page 428
- "boot command errors" on page 429
- "bootmode command errors" on page 429
- "bootseq command errors" on page 430
- "buildidcfg command errors" on page 430
- "chconfig command errors" on page 431
- "chlog command errors" on page 432
- "chmanual command errors" on page 433
- "cin command errors" on page 433
- "clear command errors" on page 435
- "clearlog command errors" on page 435
- "clock command errors" on page 435
- "config command errors" on page 436
- "console command errors" on page 437
- "dhcpinfo command errors" on page 438
- "displaylog command errors" on page 438
- "displaysd command errors" on page 439
- "dns command errors" on page 440
- "env command errors" on page 440
- "ethoverusb command errors" on page 440
- "eventinfo command errors" on page 441
- "events command errors" on page 441
- "exit command errors" on page 442
- "feature command errors" on page 442
- "files command errors" on page 444
- "fuelg command errors" on page 445
- "groups command errors" on page 448
- "health command errors" on page 448
- "help command errors" on page 449

- "history command errors" on page 449
- "identify command errors" on page 449
- "ifconfig command errors" on page 450
- "info command errors" on page 454
- "iocomp command errors" on page 455
- "kvm command errors" on page 455
- "ldapcfg command errors" on page 455
- "led command errors" on page 456
- "list command errors" on page 457
- "modactlog command errors" on page 457
- "monalerts command errors" on page 457
- "monalertsleg command errors" on page 458
- "mcad command errors" on page 457
- "mt command errors" on page 458
- "nat command errors" on page 458
- "ntp command errors" on page 459
- "ping command errors" on page 459
- "pmpolicy command errors" on page 460
- "portcfg command errors" on page 460
- "ports command errors" on page 460
- "power command errors" on page 462
- "rdoc command errors" on page 462
- "read command errors" on page 463
- "remacccfg command errors" on page 464
- "remotechassis command errors" on page 464
- "reset command errors" on page 465
- "scale command errors" on page 465
- "sddump command errors" on page 466
- "sdemail command errors" on page 467
- "security command errors" on page 467
- "service command errors" on page 467
- "shutdown command errors" on page 468
- "slp command errors" on page 468
- "smtp command errors" on page 468
- "snmp command errors" on page 469
- "sol command errors" on page 470
- "sshcfg command errors" on page 471
- "sslcfg command errors" on page 472
- "syslog command errors" on page 474
- "tcpcmdmode command errors" on page 475
- "telnetcfg command errors" on page 475
- "temps command errors" on page 476
- "thres command errors" on page 476
- "trespass command errors" on page 476
- "uicfg command errors" on page 477

- "update command errors" on page 478
- "uplink command errors" on page 480
- "users command errors" on page 481
- "vlan command errors" on page 485
- "volts command errors" on page 486
- "write command errors" on page 486
- "zonecfg command errors" on page 487

Common errors

This topic lists error messages that apply to all commands.

Each command that has unique errors will also have a list of command-specific error messages.

Table 93. Common errors

Error message	Definition
Alarm panel card is not present in this slot.	The user tries to issue a command to an empty alarm panel card slot.
Backplane Mux card is not present in this slot.	The user tries to issue a command to an empty backplane mux card slot.
Command cannot be issued to this target. Type env - h for help on changing targets.	The user tries to issue a command to a target that does not support that command.
Command line contains extraneous arguments.	Extra command arguments were entered.
Duplicate option: <i>option</i> where <i>option</i> identifies the command option that was entered more than once.	A user tries to enter the same command option in a single command multiple times. For example, dns -i 192.168.70.29 -i
Each option can only be used once per command.	A user tries to enter the same command option in a single command multiple times. For example, env -T system:blade[4] -T system:blade[5].
Error: Command not recognized. Type 'help' to get a list of supported commands.	A user tries to enter a command that does not exist.
Error reading data for the option - <i>option</i> where <i>option</i> identifies the command option that is returning an error.	An error occurs while the management module is reading data of a option.
Error writing data for the option <i>option</i> where <i>option</i> identifies the command option that is returning an error.	An error occurs while the management module is writing a command option value.
Firmware update is in progress. Try again later.	Firmware update is in progress.
Illegal option: option	An illegal short command option is entered.
where <i>option</i> identifies the illegal short command option that was entered.	
Integer argument out of range (<i>range - range</i>) for <i>option</i> : <i>argument</i>	An integer is entered that is out of range.
 where: <i>range</i> identifies the range limits <i>option</i> identifies the command option <i>argument</i> identifies the integer that is out of range 	

Table 93. Common errors (continued)

Error message	Definition
Internal error.	An internal error occurs.
Invalid integer argument for option: argument	An invalid integer is entered.
where:<i>option</i> identifies the command option<i>argument</i> identifies the invalid argument	
Invalid option.	An invalid command option is entered.
Invalid option argument for option: argument	An invalid argument for a command option is entered.
where:<i>option</i> identifies the command option<i>argument</i> identifies the invalid argument	
Invalid option for this target: option	A user tries to issue a command with an invalid option
where <i>option</i> identifies the option that is invalid.	for the target.
Invalid parameter. Input must be numeric.	A user tries to enter a non-numeric argument.
Invalid syntax. Type <i>command</i> - h for help.	A user tries to enter a command that is not syntactically
where <i>command</i> identifies the command that is returning an error.	correct.
Invalid target path.	A user tries to issue a command to a target that is not valid.
Long option <i>option</i> requires an argument where <i>option</i> identifies the long command option that is missing an argument.	A long command option is entered without a required argument.
Missing option name	A dash (-) is entered without a command option name.
Network Clock card is not present in this slot.	The user tries to issue a command to an empty network card slot.
Read/write command error.	An error occurs while the management module is executing the command.
Short option <i>option</i> requires an argument where <i>option</i> identifies the short command option that is missing an argument	A short command option is entered without a required argument.
Syntax error. Type <i>command</i> -h for help.	A user tries to enter a command improperly.
where <i>command</i> identifies the command that is returning an error.	I I I
That blade is presently not available. Please try again shortly.	A user tries to connect to a blade that is already in use.
The argument for the option <i>arg</i> is outside the valid range.	A user tries to enter an arg outside the option's valid range.
where <i>arg</i> identifies the command option that is out of range.	
The target bay is empty.	The user tries to issue a command to an empty blade bay, blower bay, I/O-module bay, management-module bay, or power bay.

Table 93. Common errors (continued)

Error message	Definition
The target bay is out of range.	A user tries to issue a command to a target that is out of range for that target. For example, the env -T system:blade[15] command is out of range because the BladeCenter unit has only 14 blade bays.
The target slot is out of range.	The user tries to issue a command to a target which is out of range for that target.
There is no blade present in that bay.	The user tries to issue a command to an empty blade bay.
There is no blower present in that bay.	The user tries to issue a command to an empty chassis cooling unit bay.
There is no management module present in that bay.	The user tries to issue a command to an empty management module bay.
There is no power source present in that bay.	The user tries to issue a command to an empty power module bay.
There is no switch present in that bay.	The user tries to issue a command to an empty I/O module bay.
Unknown long option: <i>option</i> where <i>option</i> identifies the command option that is unknown.	A user tries to enter a long option that is not valid for the command.
Unknown option: option	An unknown option is used.
where <i>option</i> identifies the command option that is unknown.	
Unrecognized long option: option	An illegal long command option is entered.
where <i>option</i> identifies the illegal long command option that was entered.	
Unsupported target type.	A user tries to issue a command to an unsupported target.
User does not have the authority to issue this command.	A user lacks the authority level necessary to execute a command.

accseccfg command errors

This topic lists error messages for the accseccfg command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 94.	accseccfa	command	errors
10010 0 11	account	oonnana	011010

Error message	Definition
'Password required' is currently disabled.	A user without a password tries to change the security level to -high. User must have a password to perform this action.
'Password required' is currently enabled.	A user without a password tries to change the security level to -legacy. User must have a password to perform this action.
Reading account security level failed.	An error occurs while the management module is reading the security level.

Table 94. accseccfg command errors (continued)

Error message	Definition
Setting account defaults to high level failed.	An error occurs while the management module is setting the security level to -high.
Setting account defaults to legacy level failed.	An error occurs while the management module is setting the security level to -legacy.
The -high option cannot be used with other options.	The user tries to set the account security to high settings while changing individual option values.
The -legacy option cannot be used with other options.	The user tries to set the account security to legacy settings while changing individual option values.
The account inactivity disable time period must be greater than the account inactivity alert time period.	A user tries to set the account inactivity disable time period to be less than the account inactivity alert time period.
The argument for the option -dc is outside the valid range.	The user tries to set the -dc option to a value outside of its valid range.
The argument for the option -ia is outside the valid range.	The user tries to set the -ia option to a value outside of its valid range.
The argument for the option -id is outside the valid range.	The user tries to set the -id option to a value outside of its valid range.
The argument for the option -lf is outside the valid range.	The user tries to set the -lf option to a value outside of its valid range.
The argument for the option -lp is outside the valid range.	The user tries to set the -lp option to a value outside of its valid range.
The argument for the option -pe is outside the valid range.	The user tries to set the -pe option to a value outside of its valid range.
The argument for the option -rc is outside the valid range.	The user tries to set the -rc option to a value outside of its valid range.
The minimum password change interval must be less than the password expiration period (%d days or %d hours).	A user tries to set the -pc option to a value greater than the -pe option.
The password expiration period (%d days or %d hours) must be greater than the minimum password change interval.	A user tries to set the -pe option to a value less than the -pc option.
User must have a password to change the 'Password required' setting.	A user without a password tries to change the -pr option.

advfailover command errors

This topic lists error messages for the advfailover command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 95. advfailover command errors

Error message	Definition
Operation failed.	An error occurs while the management module is processing the command.
Operation not allowed, since the standby MM is not present.	The user tries to enable advanced failover when there is no standby management module installed in the BladeCenter unit.
Table 95. advfailover command errors (continued)

Error message	Definition
Unknown option: <i>option</i> where <i>option</i> identifies the illegal command option that was entered.	The user tries to enter an illegal command option.

alarm command errors

This topic lists error messages for the alarm command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 96. alarm command errors

Error message	Definition
A duplicate option is found in the requested command.	A duplicate argument is entered.
Alarm Description must be provided for setting an alarm.	The user tries to set an alarm without providing an alarm description.
Alarm ID must be from 1 to 255.	An invalid alarm ID is entered.
Category must be from 1 to 255.	An invalid category argument is entered.
Generator ID must be from 1 to 255.	An invalid generator ID is entered.
Generator ID must be provided.	A generator information ID is provided without a generator ID.
Module ID must be from 1 to 255.	An invalid module ID is entered.
No active alarm.	No active alarm is found for the command target.
No matching alarm.	No matching alarm is found for the command target.
Reading system health summary failed.	An error occurs while the management module is getting the system health summary.
Severity level must be provided for setting an alarm.	The user tries to set an alarm without specifying the severity level.
Software Generator ID must be from 1 to 255.	The user tries to enter an invalid generator information.
The entered Alarm Key is not in proper format.	The user tries to enter an invalid alarm key.
Unable to acknowledge the requested alarm.	An error occurs while the management module is acknowledging an alarm.
Unable to clear the requested alarm.	An error occurs while the management module is clearing an alarm.
Unable to set the requested alarm.	An error occurs while the management module is setting an alarm.

alertcfg command errors

This topic lists errors for the alertcfg command.

There are no unique errors for the alertcfg command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

alertentries command errors

This topic lists error messages for the alertentries command.

Table 97. alertentries command errors

Error message	Definition
-test must be used exclusive of other options.	The user tries to issue a command with the -test option at the same time as the other options.
An entry cannot be modified and deleted in the same command.	A user tries to modify an entry and delete it in the same command.
Arguments containing spaces must be enclosed in quotation marks.	A user tries to enter a string containing spaces that has an opening quotation mark without a closing quotation mark.
Enabling the application alert failed.	An error occurs while the management module is enabling the application alert.
Generating test alert failed.	An error occurs while the management module is generating a test alert.
Invalid input. Angle brackets are not allowed in the name field.	A user tries to enter a string parameter containing < or > for the -n (name) command option.
Invalid option.	An invalid command option is entered. This includes numeric options for the alert recipient that are not from 1 through 12.
Invalid parameter. Input must be numeric.	A user tries to enter a parameter value containing non-numeric characters for a command option requiring numeric input.
Restoring previous configured value for the application alert failed.	An error occurs while the management module is restoring previous configured value for the application alert.
Syntax errore can only be used in conjunction with the email argument.	A user tries to enter an invalid email address for the -e command option.
Syntax errori can only be used in conjunction with the director argument.	A user tries to enter an invalid IP address for the -i command option.
Syntax error. Type alertentries -h for help.	An alert entry number is entered without the leading dash (-).
The name must be less than 32 characters long.	A user tries to enter too many characters in an input field.
When creating a new entry, all options are required.	A required command option is missing when creating a user.

autoftp command errors

This topic lists errors for the autoftp command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 30. autolib command enois	Table 98.	autoftp	command	errors
---------------------------------	-----------	---------	---------	--------

Error message	Definition
Autoftp is disabled, -i, -p, -u and -pw options are invalid.	A user tries to enter -i, -p, -u, or -pw options when the FTP/TFTP mode is set to disabled.
Invalid FTP/TFTP address.	A user tries to enter an FTP or TFTP address that is not valid.
Invalid input. Address must be less than 64 characters.	A user tries to enter an address that is 64 or more characters long.
Invalid input. Password must be less than 64 characters.	A user tries to enter a password that is 64 or more characters long.
Invalid input. Userid must be less than 64 characters.	A user tries to enter a user id that is 64 or more characters long.
Password must be enclosed in quotation marks. Displayed when the argument of option -p is not quote_delimited.	A user tries to enter a password without quotation marks.
Read autoftp configuration failed.	The management module was unable to read the autoftp configuration.
Read autoftp mode failed.	The management module was unable to read the autoftp mode status.
The mode is tftp, -u and -pw options are invalid.	A user tries to enter a user name or password when the mode is set to TFTP.
User Name must be enclosed in quotation marks.	A user tries to enter a user name without quotation marks.
When disabling autoftp, the -i, -p, -u and -pw options are invalid.	A user tries to enter -i, -p, -u, or -pw options when setting the FTP/TFTP mode to disabled in the same command.
When setting -m to tftp, the -u and -pw options are invalid.	A user tries to enter a user name or password when setting the FTP/TFTP mode to TFTP in the same command.

baydata command errors

This topic lists error messages for the baydata command.

Table 99. baydata command errors

Error message	Definition
Error writing bay data to blade bay <i>bayNum</i> . where <i>bayNum</i> is the blade bay number.	An internal error occurs while the user is changing bay data for the specified blade server.
Invalid blade bay number	The command has an invalid bay number.

Table 99. baydata command errors (continued)

Error message	Definition
Invalid input. The bay data string must be less than the maximum number of characters allowed.	User enters bay data with -data option for a blade server that exceeds the maximum length of 60 characters.
The -clear and -data options cannot be used in the same command.	User issues a command with both -clear and -data options.
The bay data must be quote-delimited.	User enters bay data with -data option for a blade server without double quotation marks.
User not authorized to change bay data for bay number.	An unauthorized user issues a command to change bay data for the specified blade server.

bofm command errors

This topic lists errors for the bofm command.

Notes:

- 1. The BOFM command displays parsing errors and duplicate addresses that point to flaws in the comma-separated values (csv) configuration database file. The BladeCenter Open Fabric Manager is not a standard management module feature; it is offered and documented separately. See the *BladeCenter Open Fabric Manager Installation and Users Guide* for more detailed information.
- 2. If the number of advanced management module TCP command mode connections is zero, or if all available TCP command mode connections are in use, a connection failure message is generated by the BOFM feature. Make sure that the advanced management module TCP command mode connection limit is positive and that no more than the available number of connections are in use. See the *BladeCenter Open Fabric Manager Installation and Users Guide* for additional information.

Error message	Definition
Applying new configuration on MM failed.	An error occurs while the advanced management module is applying the BOFM configuration.
Confirming configuration change failed.	An error occurs while the advanced management module is confirming a configuration change.
File transfer failed.	An error occurs while transferring a file during file upload.
Getting BOFM status failed.	An error occurs while the advanced management module is getting BOFM status.
Getting duplicates failed.	An error occurs while the advanced management module is getting duplicates.
Getting parsing errors failed.	An error occurs while the advanced management module is getting parsing errors.
-i and -l are both required to upload a BOFM configuration file.	A user issues a command to apply BOFM configuration to the advanced management module without both -i and -l options.

Table 100. bofm command errors

Table 100. bofm command errors (continued)

Error message	Definition
Login failed.	Login fails while the management module is applying the BOFM configuration to the advanced management module.
Parsing errors.	An error occurs while the advanced management module is parsing the BOFM status.
Resetting BOFM configuration on MM failed.	An error occurs while the advanced management module is resetting the BOFM configuration.
Retrieving the file from TFTP server failed.	An error occurs while the advanced management module is retrieving the configuration file from a TFTP server.
Update Failed, there was a problem retrieving the file.	An error occurs while the advanced management module is uploading a file.

boot command errors

This topic lists errors for the boot command.

There are no unique errors for the boot command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

bootmode command errors

This topic lists errors for the bootmode command.

Table 101. bootmode command errors

Error message	Definition
Boot mode not supported on $blade[x]$ where x is the number of the blade-server bay.	The command is directed to a blade server that does not support the bootmode feature.
Error retrieving the boot mode of this blade.	The management module is unable read the boot mode of the blade server.
Set the blade boot mode to <i>option</i> failed where <i>option</i> is the selected boot mode.	The management module is unable to set the blade server boot mode to the specified value.

bootseq command errors

This topic lists error messages for the bootseq command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 102. bootseq command errors

Error message	Definition
Error writing boot sequence.	An error occurs while the management module is processing the command.
First device cannot be set to 'nodev'.	The user tries to set the first boot device to 'nodev'.
Invalid device for this blade or chassis.	The user tries to set a boot device to an invalid choice.
No duplicate settings are allowed.	The user tries to set multiple slots in the boot sequence to the same device.
Second device cannot be set to 'nodev' when third or fourth device is set.	The user tries to set the second boot device to 'nodev'.
Third device cannot be set to 'nodev' when fourth device is set.	The user tries to set the third boot device to 'nodev'.

buildidcfg command errors

This topic lists error messages for the buildidcfg command.

Table 103. buildidcfg command errors

Error message	Definition
-create must be used exclusive of other options.	A user tries to create the blade firmware build ID list while using another command option. The -create command option must be run alone.
Adding an entry failed. Please check for duplicates or an invalid format.	An error occurs while adding an entry to the blade firmware build ID list.
Build ID must be enclosed in quotation marks.	A user tries to enter a blade firmware build ID without quotation marks.
Build revision must be enclosed in quotation marks.	A user tries to enter a blade firmware build revision without quotation marks.
Error creating the initial build ID list.	An error occurs while creating the blade firmware build ID list.
Error removing all the build ID entries.	An error occurs while removing all blade firmware build ID list entries.
Error removing build ID entry <i>identifier</i> . where the <i>identifier</i> identifies the build ID entry specified.	An error occurs while removing a blade firmware build ID list entry.
Importing list failed. Check for duplicates or an invalid format on line <i>line_number</i>	An error occurs during blade firmware build ID list import.
where the <i>line_number</i> identifies the line number specified.	
Machine type must be enclosed in quotation marks.	A user tries to enter a machine type without quotation marks.

Table 103. buildidcfg command errors (continued)

Error message	Definition
Manufacturer must be enclosed in quotation marks.	A user tries to enter a manufacturer name without quotation marks.
Modifying entry <i>identifier</i> failed. Please check for duplicates or an invalid format. where the <i>identifier</i> identifies the entry specified.	A user tries to modify an blade firmware build ID list entry with duplicate or wrong information.
No entries in the list.	The blade firmware build ID list is empty.
Operating error "export <i>identifier</i> " where the <i>identifier</i> identifies the information to export.	An error occurs during blade firmware build ID list information export.
Operating error "import <i>identifier</i> " where the <i>identifier</i> identifies the information to import.	An error occurs during blade firmware build ID list information import.
Some required options for the –ab command are missing.	A user tries to add a blade firmware build ID list entry, but does not include all of the required options.

chconfig command errors

This topic lists errors for the chconfig command.

Table 104. chconfig command errors

Error message	Definition
Address must be enclosed in quotation marks.	A user tries to enter an address that is not enclosed in quotation marks
City must be enclosed in quotation marks.	A user tries to enter a city name that is not enclosed in quotation marks
IBM Support Center: invalid input. Please input 2 characters ISO country code for the IBM Support Center.	A user tries to enter a country code that is not valid.
Contact Company must be enclosed in quotation marks.	A user tries to enter a company name that is not enclosed in quotation marks
Contact Name must be enclosed in quotation marks.	A user tries to enter a contact name that is not enclosed in quotation marks
Email must be enclosed in quotation marks.	A user tries to enter an email that is not enclosed in quotation marks
Email: invalid input. Please make sure your input is not empty and within 30 characters.	A user tries to enter an email with a length that is not valid
Error to enable/disable Service Agent.	An error occurs while the advanced management module is enabling or disabling the service agent.
Error to enable Service Agent. You have not set all of the required contact Information fields yet.	A user tries to issue a command to enable a service agent that does not have the required contact information set.
HTTP Proxy is disabled now, you can not change proxy settings, please enable http proxy first.	A user tries to change proxy settings when the HTTP proxy is disabled.
Invalid HTTP Proxy location.	A user tries to enter a proxy address that is not a valid IP address or hostname
Invalid inputloc should be less than 64 characters.	A user tries to enter a proxy address that is 64 or more characters long.

Table 104. chconfig command errors (continued)

Error message	Definition
Invalid inputpw should be less than 16 characters.	A user tries to enter a proxy password that is 16 or more characters long.
Invalid input. Password may not contain angle brackets.	A user tries to enter a proxy password that contains "<" or "△>".
Invalid input. User Name must be less than 30 characters.	A user tries to enter a user name that is 30 or more characters long.
Invalid option argument for -li:	A user tries to use the -li option without the "view" or "accept" argument.
Terms and conditions is not accepted yet, please view and accept the terms and conditions first.	A user attempts to change the service advisor settings before accepting the terms and conditions.
The Terms and Conditions should be accepted first before using this command.	A user attempts to change the service manager settings before accepting the license agreement.
Phone number must be enclosed in quotation marks.	A user tries to enter a phone number that is not enclosed in quotation marks
Phone number: invalid input. Please make sure your input is not empty and 5-30 characters.	A user tries to enter a phone number that is not valid
Postalcode must be enclosed in quotation marks.	A user tries to enter a postal code that is not enclosed in quotation marks.
Postalcode: invalid input. Please make sure your input is not empty and within 9 characters.	A user tries to enter a postal code is not valid in length.
State must be enclosed in quotation marks and has 2 or 3 characters.	A user tries to enter a state that is not enclosed in quotation marks, or is not two or three characters in length.

chlog command errors

This topic lists errors for the chlog command.

Table 105. chlog command errors

Error message	Definition
-f must be used exclusive of other options.	The user tries to use the -f option at the same time as other options.
-s must be used exclusive of other options.	The user tries to use the -s option at the same time as other options.
A call home event with index <i>number</i> was not found. where <i>number</i> is the decimal number that specifies the serviceable activity log entry that the user is attempting to acknowledge or unacknowledge.	The management module was unable to find a specified call-home event activity log entry.
Error reading data for Terms and Conditions.	An error occurs while the management module is reading the terms and conditions information.
Fail to read Service Advisor Activity Log	The management module was unable to read the call-home event activity log.
Invalid syntax. Type 'chlog -h' for help.	A user fails to specify the parameter for the call-home activity log entry that they are attempting to acknowledge or unacknowledge.

Table 105. chlog command errors (continued)

Error message	Definition
Terms and Conditions not accepted yet.	The user attempts to view the call-home event activity log but has not yet accepted the Terms and Conditions.

chmanual command errors

This topic lists errors for the chmanual command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 106. chmanual command errors

Error message	Definition
-test must be used exclusive of other options	The user attempts to run this command with other options in addition to -test.
Error generating a manual Call Home	This command fails when the user attempts the manual call home operation.
Error generating a test Call Home	This command fails when the user attempts the test call home operation.
Invalid syntax. Type 'chmanual -h' for help.	The user attempts to use this command but uses improper syntax.
Problem description must be enclosed in quotation marks	The user attempts to run this command when the problem description is not enclosed in quotation marks.
Test Call Home should be operated on SYSTEM target	The user attempts to use this command when the command is not targeted on 'system' for test call home.
Terms and Conditions not accepted yet.	The user attempts to use this command but has not yet accepted the Terms and Conditions.
The Service Agent is disabled now, please enable it before calling 'chmanual'	The user attempts to use this command before the service advisor is enabled.

cin command errors

This topic lists error messages for the cin command.

Error message	Definition
-id cannot be the same as the blade management VLAN ID. Please try again.	A user tries to enter a command with a VLAN ID which is the same as the VLAN ID of the blade management.
-ip cannot be multicast. Please try again.	A user issues a command with an IP address which is the same as the IP address of the multicast.
-ip cannot be the same as the management module IP address. Please try again	A user tries to enter a command with an IP address which is the same as the IP address of the advanced management module.
An error occurred while changing CIN global status setting	An error occurs while user is changing CIN global status setting.
An error occurred while clearing CIN entry	An error occurs while the user is clearing a CIN entry.

Table 107. cin command errors

Table 107. cin command errors (continued)

Error message	Definition
An error occurred while enabling/disabling CIN entry.	An error occurs while the user is enabling/disabling a CIN entry.
An error occurred while setting CIN entry.	An error occurs while configuring a CIN entry.
Both -id and -ip are required for adding a CIN entry.	A user tries to enter a command to add an entry without both -id and -ip options.
CIN blade pair TLV get failed	An error occurs while the management module is getting CIN blade server configuration parameters.
CIN global TLV get failed.	An error occurs while the management module is getting a CIN global configuration parameter.
CIN command failed.	An error occurs while the management module is executing a CIN command.
cin <i>-index -</i> en <i>state</i> cannot be used with other options.	The user tries to enter a command with the -en option with along with other options.
 <i>index</i> identifies the cin index entry <i>state</i> is on or off 	
Duplicate CIN (-id, 0.0.0.0) pairs are not allowed. Please try again.	A user tries to enter a command with a duplicated -id/0.0.0.0 pair.
Duplicate -ip is not allowed. Please try again.	A user tries to enter a command with a duplicated IP address.
Internal error checking CIN entry.	An error occurs while the system checks user input for the CIN entry configuration.
Internal error getting CIN entry	An error occurs while the management module is getting CIN entry configuration parameters.
Invalid index parameter. Input must be numeric.	A user tries to enter a command with a non-numeric index.
Invalid index parameter. Input out of range.	A user tries to enter a command with an index which is out of range.
Invalid IP argument for an option. Enter 4 bytes separated by 3 dots.	A user tries to enter a command argument for IP address option which is invalid because it is too long, too short, or not numeric.
Invalid IP argument for an option. Too many bytes.	A user tries to enter a command with an invalid argument for IP address option which has more than four parts.
Invalid IP argument for an option. Too few bytes	A user tries to enter a command with an invalid argument for IP address option which has fewer than four parts.
Invalid IP argument for an option. Each byte has to be in the range (0-255).	A user tries to enter a command with an invalid argument for IP address option, each part of which is not in the range of 0-255.
Invalid option argument for -global -en:	A user issues a command with an invalid argument for -global -en option.
Invalid option argument for -en to enable an entry.	An error occurs while the user is enabling/disabling a CIN entry.

clear command errors

This topic lists error messages for the clear command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 108. clear command errors

Error message	Definition
Firmware update is in progress. Try again later.	The user tries to reset the management module to its default configuration during a firmware update. The error message displays and the management-module configuration does not reset.
Internal error resetting to defaults.	An error occurs while the management module is resetting the management module to its default configuration. The error message displays and the management-module configuration does not reset.

clearlog command errors

This topic lists error messages for the clearlog command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 109. clearlog command errors

Error message	Definition
Error clearing the event log.	An error occurs while the management module is clearing the event log.

clock command errors

This topic lists error messages for the clock command.

Table 110. clock command errors

Error message	Definition
GMT+2:00 requires one of the following dst values: off, ee, gtb, egt, or fle	The user tries to change the Greenwich mean-time (GMT) offset to +2:00 without adjusting the DST setting.
GMT+10:00 requires one of the following dst values: off, ea, tas, or vlad	The user tries to change the GMT offset to +10:00 without adjusting the DST setting.
GMT <i>offset</i> requires one of the following dst values: off, uc, other	The user tries to change the GMT offset to -9, -8, -7, -6, or -5 without adjusting the DST setting.
where offset is the daylight-savings time offset.	
Invalid dst setting for GMT+10:00: setting	The user tries to enter an invalid -dst setting for a GMT offset of 10.
where <i>setting</i> is the illegal daylight-savings time setting that was entered.	

Table 110. clock command errors (continued)

Error message	Definition
Invalid dst setting for GMT+2:00: <i>setting</i> where <i>setting</i> is the illegal daylight-savings time setting that was entered.	The user tries to enter an invalid -dst setting for a GMT offset of 2.
Invalid dst setting for GMT <i>offset: setting</i> where <i>setting</i> is the daylight-savings time offset and <i>setting</i> is the illegal daylight-savings time setting that was entered.	The user tries to enter an invalid -dst setting for a GMT offset of -9, -8, -7, -6, or -5.
Invalid dst setting. The gmt offset does not support dst.	The user tries to turn on dst for a GMT offset that does not support daylight-savings time.
Invalid input for -dst.	A user tries to enter an invalid argument for the option -dst.
Reading date and time failed.	An error occurs while the management module is reading the date and time.
Reading GMT offset failed.	An error occurs while the management module is reading the GMT offset.
Reading status of daylight savings time failed.	An error occurs while the management module is reading the daylight savings time status.
The gmt offset you entered does not support dst. Turning dst off.	A user tries to enter a GMT offset that does not support daylight savings time.

config command errors

This topic lists error messages for the config command.

Error message	Definition
Arguments containing spaces must be enclosed in quotation marks.	The user tries to enter an advanced management module Contact or Location without ending double quotes.
Contact must be enclosed in quotation marks.	The user tries to enter an advanced management module Contact without enclosing it in double quotes.
Invalid input. Contact may not contain angle brackets.	The user tries to enter an advanced management module Contact containing angle brackets ("<" and ">").
Invalid input. Location may not contain angle brackets.	The user tries to enter an advanced management module Location containing angle brackets ("<" and ">").
Invalid input. Name must be less than 16 characters.	The user tries to enter a name that is more than 15 characters in length.
Invalid input. Name may not contain angle brackets.	The user tries to enter a blade server name that contains angle brackets: "<" or ">".
Invalid input. Only alphanumeric characters, underscores, hyphens, pound signs, and periods are allowed.	The user tries to enter a name for the advanced management module that is not valid.
Invalid inputsn should have exactly seven alphanumeric characters.	The user tries to enter a serial number that is not exactly seven alphanumeric characters.

Table 111. config command errors

Table 111. config command errors (continued)

Error message	Definition
Invalid inputtm should have exactly seven alphanumeric characters.	The user tries to enter a type or model name that is not exactly seven alphanumeric characters.
Invalid inputuuid should have exactly 32 hex digits.	The user tries to enter a universally unique ID that is not exactly 32 hex digits.
Location must be enclosed in quotation marks.	The user tries to enter an advanced management module Location without enclosing it in double quotes.
Reading SNMPv1/SNMPv3 status failed.	An internal errors occurs while the advanced management module is reading the SNMPv1/v3status.
System location and contact must be defined when SNMPv1 or SNMPv3 agent is enabled.	The user tries to undefine the system location or contact information while an SNMPv1 or SNMPv3 agent is enabled.

console command errors

This topic lists error messages for the console command.

Table 112. console command errors

Error message	Definition
A SOL session socket was not available.	The command-line interface fails to establish an SOL connection to a blade server.
Error entering console mode.	An error occurs while the management module is trying to establish an SOL connection.
Global SOL is not enabled	SOL is not enabled globally.
Internal Error	An error occurs while the management module is processing the command.
SOL is not ready	The blade server is not available, or when a socket needed to establish a connection to the blade server is not available.
SOL on blade is not enabled	SOL is not enabled on the blade server where the user is trying to start an SOL session.
SOL session is already active	The user cannot start an SOL session with a blade server because an SOL session with that blade server is already in progress.
The maximum number of sessions to this blade has been reached.	The blade server has no available sessions for a user to connect to.
Unknown error occurred while attempting to connect.	An unknown error occurs when connecting to a blade server.

dhcpinfo command errors

This topic lists errors for the dhcpinfo command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 113. dhcpinfo command errors

Error message	Definition
Advanced failover must be enabled before viewing the standby MM's DHCPv6 config.	A user tries to view the configuration of the standby management module when advanced failover is disabled.
Command cannot be issued to this type of Blade. Type env –h for help on changing targets.	A user issues the dhcpinfo command to a blade server that does not support IPv6.
DHCPv6 information is not available.	DHCPv6 is enabled, but the command target is not receiving any DHCPv6 settings.
DHCPv6 is disabled	The DHCPv6 assigned configuration can not be retrieved because DHCPv6 is disabled.
IPv6 is disabled	The DHCPv6 assigned config can not be retrieved because IPv6 is disabled.
This management network interface is not installed.	A user issues the dhcpinfo command to a blade server that does not support a management network interface.

displaylog command errors

This topic lists error messages for the displaylog command.

Error message	Definition
(There are no more entries in the event log.)	There are no more event log entries to display.
-f and -a cannot be used at the same time.	The user tries to use the -f and -a options in the same command.
-l and -i options must be used exclusive of the other options.	The user tries to issue a command with the -l and -i options at the same time as other options.
-lse option must be used exclusive of the other options	The user tries to set the -lse option at the same time as other options.
Both -l and -i options must be provided to save event log.	The user tries to issue a command to save the event log without -l and -i provided.
Cannot open file: <i>filename</i> where <i>filename</i> is the name of the file that was entered when the error occurred.	An error occurs while the management module is trying to open a file.
Duplicate date filter: <i>filter</i>	The user tries to use duplicate date filters.
where <i>filter</i> is the duplicate date filter that was entered.	
Duplicate call home filter: <i>filter</i>	The user tries to use duplicate call-home filters.
where <i>filter</i> is N or C.	

Table 114. displaylog command errors

Table 114. displaylog command errors (continued)

Error message	Definition
Duplicate severity filter: <i>filter</i>	The user tries to use duplicate severity filters.
where <i>filter</i> is the duplicate severity filter that was entered.	
Duplicate source filter: <i>filter</i>	The user tries to use duplicate source filters.
where <i>filter</i> is the duplicate source filter that was entered.	
Invalid date filter: <i>filter</i>	The user tries to use an invalid date filter.
where <i>filter</i> is the invalid date filter that was entered.	
Invalid call home filter: <i>filter</i>	The user tries to use an invalid call-home filter.
where <i>filter</i> is the invalid filter that was entered.	
Invalid severity filter: filter	The user tries to use an invalid severity filter.
where <i>filter</i> is the invalid severity filter that was entered.	
Invalid source filter: <i>filter</i>	The user tries to use an invalid source filter.
where <i>filter</i> is the invalid source filter that was entered.	
Putting event log file <i>filename</i> to tftp server <i>ipaddress</i> failed	An error occurs while the management module is trying to put the event log file to TFTP server.
 where: <i>filename</i> is the name of the log file <i>ip_address</i> is the IP address of the TFTP server 	
Reading log entries failed.	An error occurs while the management module is reading log entries.

displaysd command errors

This topic lists error messages for the displaysd command.

Table 115. displaysd command errors

Error message	Definition
-save and -i must both be specified when saving the service data.	A user tries to save the service data without specifying both the file name and IP address of the TFTP server.
Can not get the SRC's detail information.	The advanced management module fails to get the SRC detail information.
Error retrieving blade type.	The advanced management module fails to read the blade server type.
Error transferring file.	An unspecified TFTP error occurs.
No additional information for this SRC.	The advanced management module tries to get the detail information of a SRC which does not have detail information.
Read/write command error.	An error occurs while the management module is processing the command.
The format of the received data is wrong.	The advanced management module receives wrongly formatted data.

dns command errors

This topic lists error messages for the dns command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 116. dns command errors

Error message	Definition
-on and -off cannot both be used in the same command.	A user tries to enable and disable DNS in the same command.
At least one address is required to enable DNS.	A user tries to enable DNS without configuring at least one address.
DNS State Can not be determined.	An error occurs while the management module is reading the DNS state.
Input length is greater than the maximum characters allowed.	A user tries to enter too many characters in an input field.
Invalid ip address	A user tries to set an invalid IP address.
IPv6 configuration changes will not take effect until IPv6 is enabled.	A user attempts to configure the IPv6 DNS settings while IPv6 is disabled.
Reading status of DNS failed.	An error occurs while the management module is reading the DNS state.
Reading status of interface failed.	An error occurs while the management module is reading the status of an interface.

env command errors

This topic lists errors for the env command.

There are no unique errors for the env command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

ethoverusb command errors

This topic lists errors for the ethoverusb command.

Error message	Definition
Blade SP's command interface on Ethernet-over-USB is not supported on blade <i>blade_number</i> where <i>blade_number</i> identifies the blade server.	The command is directed to a blade server that does not support Ethernet-over-USB.
Notice: This operation may take a short while to complete. Please view the status to determine when the operation has completed.	Confirmation message indicating that the command is processing and might take a short time to complete.

eventinfo command errors

This topic lists errors for the eventinfo command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 118. eventinfo command errors

Error message	Definition
Error reading eventinfo.	An error occurs when reading event information.
Invalid event ID.	A user attempts to enter an invalid event ID.

events command errors

This topic lists errors for the events command.

Table 119. events command errors

Error message	Definition
-add and -rm should be used exclusively of each other.	A user attempts to issue a command with both options -add and -rm.
Call Home Exclusion List has reached its maximum size of <i>max</i> entries. No more events can be added to the list.	A user attempts to add an entry while Call Home Exclusion List has reached its maximum size.
where <i>max</i> is a decimal number.	
Error reading ftp/tftp of Service Data configuration.	An error occurs while the management module is reading the FTP/TFTP service data configuration.
Error reading data for Terms and Conditions.	An error occurs while the management module is reading the terms and conditions data.
Event <i>id</i> already exists in Call Home Exclusion List. where <i>id</i> is a hexadecimal number that identifies a call-home event.	A user attempts to add an entry which already exists in Call Home Exclusion List.
Event <i>id</i> does not exist in the Call Home Exclusion List. where <i>id</i> is a hexadecimal number that identifies a call-home event.	A user attempts to remove an entry which does not exist in Call Home Exclusion List.
Event <i>id</i> is invalid to be added into Call Home Exclusion List.	A user attempts to add an entry with an invalid event id.
where <i>id</i> is a hexadecimal number that identifies a call-home event.	
ftp/tftp of Service Data must be enabled before using this command.	A user attempts to issue an events command while the FTP/TFTP Report of Service Data is disabled
Read Call Home Exclusion List failed.	An error occurs while the management module is reading the Call Home Exclusion List.
The terms and conditions should be accepted first before using this command.	A user attempts to issue an events command before the terms and conditions have been accepted.

exit command errors

This topic lists errors for the exit command.

There are no unique errors for the exit command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

feature command errors

This topic lists errors for the feature command.

Table 120. feature command errors

Error message	Definition	
-add option requires -key option	The user tries to add a feature license without specifyin the feature license key.	
-key option must contain 7 alphanumeric characters	An invalid value was entered for the -key option.	
Apply operation timed out	Applying a license file times out	
Error applying license file.	Applying a license file fails.	
Error getting errors.	An error occurs while retrieving errors when applying a license file.	
Error getting status.	An error occurs while getting status when applying or retrieving a license file.	
Error parsing license file.	An error occurs while applying or retrieving a license file.	
Error retrieving license file.	The license file fails to retrieve.	
Error transferring license file.	The license file fails to transfer.	
Failed to apply license to chassis <i>ip_address</i>	An error occurs while applying a license file.	
where <i>ip_address</i> is the IP address for the BladeCenter unit on which the operation is being performed		
Failed to login to chassis <i>ip_address</i>	An error occurs while applying a license file.	
where <i>ip_address</i> is the IP address for the BladeCenter unit on which the operation is being performed		
Failed to read license status	An error occur occurs while the advanced management module is reading the status of the feature license.	
Failed to remove license for chassis <i>ip_address</i>	An error occurs while applying a license file.	
where <i>ip_address</i> is the IP address for the BladeCenter unit on which the operation is being performed		
Failed to retrieve data for chassis <i>ip_address</i>	An error occurs while applying a license file.	
where <i>ip_address</i> is the IP address for the BladeCenter unit on which the operation is being performed		
Failed to retrieve status for chassis <i>ip_address</i>	An error occurs while applying a license file.	
where <i>ip_address</i> is the IP address for the BladeCenter unit on which the operation is being performed		
Failed to set license key	An error occur occurs while the advanced management module is setting the feature license key.	

Table 120. feature command errors (continued)

Error message	Definition
Failed to validate chassis serial number	An error occur occurs while the advanced management module is validating the BladeCenter unit serial number. Make sure that the serial number is correct and retry the command.
Internal error.	An error occurs while retrieving a license file.
Internal error. Something was wrong with the file.	An error occurs while applying a license file.
Invalid error data returned	Error data is not valid.
Invalid license key	An error occur occurs while the advanced management module is validating the feature license key. Make sure that the license key is correct and retry the command.
line <i>number</i> : CSV read error. where <i>number</i> indicates the line in the license file that is in error.	An error occurs while applying a license file. Error location in license file is specified in the error message.
line <i>number</i> : File open error. where <i>number</i> indicates the line in the license file that is in error.	An error occurs while applying a license file. Error location in license file is specified in the error message.
line <i>number</i> : Incomplete line. where <i>number</i> indicates the line in the license file that is in error.	An error occurs while applying a license file. Error location in license file is specified in the error message.
line <i>number</i> : Invalid IP. where <i>number</i> indicates the line in the license file that is in error.	An error occurs while applying a license file. Error location in license file is specified in the error message.
line <i>number</i> : Line too long. where <i>number</i> indicates the line in the license file that is in error.	An error occurs while applying a license file. Error location in license file is specified in the error message.
line <i>number</i> : Unknown error: <i>code</i> where <i>number</i> indicates the line in the license file that is in error and <i>code</i> indicates the type of error.	An error occurs while applying a license file. Error location in license file is specified in the error message.
Remove license failed	An error occur occurs while the advanced management module is removing a feature license.
Unknown error for chassis <i>ip_address</i>	Error type is unknown.
where <i>ip_address</i> is the IP address for the BladeCenter unit on which the operation is being performed	
Unknown error type	Error type is unknown.

files command errors

This topic lists error messages for the files command.

Table 121. files command errors

Error message	Definition	
%, /, and $\"$ are not allowed in the filename.	The user tries to enter a filename that is invalid.	
Directory does not exist.	The user tries to enter a directory that does not exist.	
Error deleting file <i>filename</i>	An error occurs while the management module is trying	
where <i>filename</i> is the name of the file that was entered for deletion.	to delete a file.	
Error deleting file <i>filename</i>	The user tries to delete a directory or delete a file that	
where <i>filename</i> is the name of the file that was entered for deletion.	does not exist.	
Error reading file list.	An error occurs while the management module is reading the directory file list.	
Error reading file system space.	An error occurs while the management module is reading the file system space.	
Error reading first file in dir <i>directory</i> .	An error occurs while the management module is	
where <i>directory</i> is the name of the directory that was entered.	reading the first file in the directory.	
File index out of sequence.	An error occurs while the management module is reading the index.	
File list exhausted.	An error occurs while the management module is reading the file list.	
File not found.	The specified file is not found.	
Filename must be less than 256 characters	The user tries to enter a filename that is longer than 256 characters.	
General, unknown error.	A command is rejected for unknown reasons.	
Invalid command sent.	The user tries to enter an invalid command.	
Invalid directory, filename.	The user tries to enter an invalid directory and filename.	
Invalid file or directory name.	The user tries to enter an invalid directory or filename.	
The directory name must be less than 256 characters.	A user tries to enter a directory name that is more than 256 characters in length.	
Unknown caller id.	The caller ID is not recognized.	
Unknown command.	The user tries to enter a command that is not recognized.	
Unknown directory path.	The user tries to enter a directory path that is not recognized.	

fuelg command errors

This topic lists error messages for the fuelg command.

Table 122. fuelg command errors

Error message	Definition	
-am cannot be enabled while -e is set to nebs.	The user attempts to enable the acoustic mode while the environment is set to nebs.	
-ps and -dps cannot be enabled at the same time.	The user attempts to enable -ps and idps at the same time.	
A power module failure in domain <i>domain_number</i> can result in an immediate shutdown.	A power module fails and the domain in which it is installed loses redundancy. The BladeCenter unit might turn itself off, based on the power management	
where <i>domain_number</i> identifies the power domain.	configuration.	
Blade <i>blade_number</i> is not allowed to power on because of insufficient power.	There is insufficient power available in the power domain to turn on this blade server.	
where <i>blade_number</i> identifies the blade server.		
Blade <i>blade_number</i> is throttled. where <i>blade_number</i> identifies the blade server.	The specified blade server has reduced power (power throttling) in response to a thermal event or oversubscription condition.	
Blade <i>blade_number</i> was instructed to power off due to power budget restrictions.	BladeCenter power management turns off a blade serve that is already on in response to a oversubscription condition.	
where <i>blade_number</i> identifies the blade server.		
Blade must be powered on to enable/disable dps.	The user attempts to enable or disable dynamic power server mode for a blade server while its power is off.	
Checking if power is preallocated to switch <i>number</i> failed.	An error occurs while the management module is checking if power is preallocated for the specified I/O module.	
where the <i>number</i> I/O-module bay number.		
Demand exceeds a single power module. Throttling can occur in power domain <i>domain_number</i> . where <i>domain_number</i> identifies the power domain.	The power requirements of components installed in a power domain exceed the level required for redundant operation. Power throttling of BladeCenter components might be able to correct the problem	
Effective CPU Speed not available.	An error occurs while the management module is reading the effective CPU Speed.	
Error reading blade power management capability.	An error occurs while the management module is reading the blade server power management capability.	
Error reading soft minimum.	An error occurs while the management module is reading the soft minimum value.	
Error reading soft minimum, using guaranteed minimum instead.	An error occurs while the management module is reading the soft minimum value.	
Error writing data for the option -pme	The user attempts to enable power management and	
Please make sure the blade is powered on	capping for a blade server that is turned off.	
Getting blade health state parameters failed.	An error occurs while the management module is reading the blade server health state parameters.	
Getting blade pcap maximum value failed.	An error occurs while the management module is reading the blade server power cap maximum value.	

Table 122. fuelg command errors (continued)

Error message	Definition
Getting blade pcap minimum value failed.	An error occurs while the management module is reading the blade server power cap minimum value.
Getting blade power cap level failed.	An error occurs while the management module is reading the blade server power cap level.
Getting data of domain 1 (or 2) failed.	An error occurs while the management module is reading the data of power domain 1 (or 2).
Getting domain latest power sample failed.	An error occurs while the management module is reading the latest power domain sample.
Getting duty cycle numbers failed.	An error occurs while the management module is reading the duty cycle numbers.
Getting duty cycle numbers of blade <i>blade_number</i> failed.	An error occurs while the management module is
where <i>blade_number</i> identifies the blade server.	reading the duty cycle numbers of specified blade server.
Getting dynamic power management capabilty of bladeblade_number failed.	An error occurs while the management module is reading the dynamic power management capability of specified blade server.
where <i>blade_number</i> identifies the blade server.	
Getting information of power <i>number</i> failed.	An error occurs while the management module is reading data of specified power module.
Cetting module domain man for blower number failed	An arror occurs while the management module is
where the <i>number</i> identifies the specified chassis cooling unit.	reading module domain map of specified chassis cooling unit.
Getting module domain map for midplane failed.	An error occurs while the management module is reading the module domain map for midplane.
Getting module domain map for MM <i>number</i> failed. where the <i>number</i> identifies the specified management module	An error occurs while the management module is reading the module domain map of specified management module.
Getting module domain map for mux <i>number</i> failed.	An error occurs while the management module is
where the <i>number</i> identifies the location of the component.	reading the module domain map of specified mux.
Getting module domain map for NCnumber failed.	An error occurs while the management module is reading the module domain map of specified network
where the <i>number</i> identifies the location of the component.	clock module.
Getting module domain map of mt <i>number</i> failed.	An error occurs while the management module is
where the <i>number</i> identifies the specified mt.	reading the module domain map of specified mt.
Getting module domain map of PM Cooling Device <i>number</i> failed.	An error occurs while the management module is reading the module domain map of specified power module Cooling Device
where <i>number</i> identifies the blade server.	
Getting module domain map of switch <i>number</i> failed.	An error occurs while the management module is reading the module domain map of specified I/O
where the <i>number</i> represents the specified I/O module.	module.
Getting module domain map of Telco alarm panel failed.	An error occurs while the management module is reading the module domain map of Telco alarm panel.

Table 122. fuelg command errors (continued)

Error message	Definition
Getting power management policy for domain <i>domain_number</i> failed	An error occurs while the management module is reading the power management policy of specified domain.
where <i>aomain_number</i> is the number of the domain that was entered.	
Getting power state of bladeblade_number failed.	An error occurs while the management module is
where <i>blade_number</i> identifies the blade server.	reading the power state of specified blade server.
Getting power values for blower <i>number</i> failed.	An error occurs while the management module is
where the <i>number</i> identifies the location of the component.	unit.
Getting power values for DSS <i>number</i> failed.	An error occurs while the management module is
where the <i>number</i> represents the specified DSS.	reading the power values of specified DSS.
Getting power values for MMnumber failed.	An error occurs while the management module is reading the power values of specified management
where the <i>number</i> identifies the location of the component.	module.
Getting power values for NCnumber failed.	An error occurs while the management module is
where the <i>number</i> represents the specified NC.	module.
Getting power values for switch <i>number</i> failed.	An error occurs while the management module is
where the <i>number</i> represents the specified I/O module.	reading the power values of specified 1/O module.
Getting power values of midplane within domain failed.	An error occurs while the management module is reading the power values of midplane within domain.
Getting power values of mt <i>number</i> within domain failed.	An error occurs while the management module is reading the power values within domain of specified
where the <i>number</i> represents the specified mt.	media tray.
Getting power values of mux <i>number</i> within domain failed.	An error occurs while the management module is reading the power values within domain of specified mux.
where the <i>number</i> represents the specified mux.	
Getting power values of PM Cooling Device <i>number</i> failed	An error occurs while the management module is reading the power values of specified power module cooling device.
where the <i>number</i> represents the specified PM cooling device.	
Getting power values of Telco alarm panel within domain failed.	An error occurs while the management module is reading the power values of Telco alarm panel within domain.
Getting status of domain <i>domain_number</i> failed	An error occurs while the management module is
where <i>domain_number</i> identifies the power domain.	reading the status of specified domain.
Getting the power control setting on blade failed.	An error occurs while the management module is reading the power control setting on blade server.
Invalid option for this blade: <i>option</i>	The user attempts to issue a command with an option which is invalid for the targeted blade server.
where <i>option</i> identifies the unacceptable option.	
Maximum CPU Speed not available.	An error occurs while the management module is reading maximum CPU Speed.

Table 122. fuelg command errors (continued)

Error message	Definition
pcap must be between <i>min</i> and <i>max</i> Watts.	The user input for power cap is out of the range.
where <i>min</i> and <i>max</i> represent the minimum and maximum wattage values permitted.	
Power value is not in the guaranteed capping range.	The user attempts to set a power value that is out of range.
Setting -e to nebs automatically disables -am, so "-am on" will be ignored.	The user attempts to set the environment to nebs and to enable the acoustic mode at the same time.
There are mismatched power modules in power domain <i>domain_number</i> .	The power modules installed in a power domain have different ratings.
where <i>domain_number</i> identifies the power domain.	
There is no thermal trending data to display.	An error occurs while the management module is reading thermal trending data.
There is no trending data to display.	An error occurs while the management module is reading power trending data.
Unable to change power management settings, domain may be oversubscribed.	An error occurs while the management module is configuring the power management policy.

groups command errors

This topic lists errors for the groups command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 123. groups command errors

Error message	Definition
When creating a new group, a group name and authority level must be specified.	A user tries to create a new group without specifying a group name or authority level.

health command errors

This topic lists errors for the health command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 124. health command errors

Error message	Definition
Getting system health summary failed.	An error occurs while the management module is
	reading the system health summary.

help command errors

This topic lists errors for the help command.

There are no unique errors for the help command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

history command errors

This topic lists errors for the history command.

There are no unique errors for the history command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

identify command errors

This section lists error messages for the identify command.

Table 125. identify command errors

Error message	Definition	
-d can only be used on the system target.	The user tries to issue a command with the -d option to a target other than system.	
-d can only be used with the -s on.	The user tries to issue a command with the -d option without -s on setting.	
Delay value must be less than <i>max</i>	The user input for option -d exceeds the maximum.	
where <i>max</i> is the preset maximum.		
Delay value must be less than 60.	A user tries to enter a -d value that is greater than 60 seconds.	
Error accessing remote LED.	An error occurs while the management module is accessing a remote LED.	
Error getting LED status.	An error occurs while the management module is reading the blade LED status.	
Error reading system LED state.	An error occurs while the management module is reading the system LED status.	
Error setting system LED.	An error occurs while the management module is setting the system LED.	
Error unknown command.	The user tries to enter unrecognized command.	
Identify: Error accessing remote LED.	An error occurs while the management module is processing the command.	
Identify: error getting LED status.	An error occurs while the management module is processing the command.	
Identify: error setting Management Module LED.	An error occurs while the management module is processing the command.	
Identify: Error unknown command.	An error occurs while the management module is processing the command.	
Identify: LED status not supported.	The user tries to get the status of an LED that is not supported by a blade server.	

Table 125. identify command errors (continued)

Error message	Definition
Identify: unknown LED state state	An LED state other than on, off, or blinking is returned.
where <i>state</i> identifies the LED state that was returned.	
Identify: Unknown return status <i>status</i> where the <i>status</i> value varies based on the problem that was encountered.	An error occurs while the management module is processing the command.
Syntax error.	The user tries to enter an invalid command option. Type identify -h for command help.
The chassis identification LED cannot be turned off at this time because one or more blades have their location LED active.	The user tries to turn off the chassis identification LED under conditions that do not permit this action.

ifconfig command errors

This topic lists error messages for the ifconfig command.

Table 126.	ifconfig	command	errors
------------	----------	---------	--------

Error message	Definition
-em cannot be reconfigured while Stacking Mode is enabled on the AMM.	The user tries to issue a command with the -em option while Stacking Mode is enabled on the advanced management module.
-ep cannot be reconfigured while Stacking Mode is enabled on the AMM.	The user tries to issue a command with the -ep option while Stacking Mode is enabled on the advanced management module.
-ipv6static, -dhcp6, and -sa6 can't all be disabled.	A user attempts to issue a command that disables -ipv6static, -dhcp6, and -sa6 at the same time.
<i>-option</i> is not supported by this type of I/O Module. where <i>option</i> is ir, gr, or sr.	The user tries to issue a command with an option -ir, -gr, or -sr which is not supported by the targeted I/O module.
-pip cannot be reconfigured while Stacking Mode is enabled on the AMM.	The user tries to issue a command with the -pip option while Stacking Mode is enabled on the advanced management module.
-up and -down can not be both used in same line.	The user tries to issue a command with both the -up and -down options.
Cannot apply network configuration. Blade in configuration phase.	An error occurs while the management module is setting the network configuration.
Configuration not supported on this I/O Module type.	The user tries to issue a command for the configuration which is not supported by targeted I/O module type.
Configuration not supported on this switch type.	The user tries to issue a command to an unsupported I/O module type.
Error converting the i6 address from string to bytes.	An error occurs while converting the i6 address from a string to bytes.
Enabling/Disabling new IP configuration failed.	An error occurs while the management module is enabling or disabling the new IP configuration.

Table 126. ifconfig command errors (continued)

Error message	Definition
Error reading gateway address.	An error occurs while the management module is reading the gateway address of a network interface (eth0 or eth1).
Error reading IP Address.	An error occurs while the management module is reading the IP address of the integrated system management processor on a blade server, or while reading the IP address of a network interface (eth0 or eth1).
Error reading data for Link-local address.	An error occurs while the management module is reading data for the link-local address.
Error reading data for Link-local address prefix length.	An error occurs while the management module is reading data for the link-local address prefix length.
Error reading data for Stateless auto-config IP Addresses.	An error occurs while the management module is reading the stateless auto-configuration IP address.
Error reading the burned-in MAC address.	An error occurs while the management module is reading the burned-in MAC address of a network interface (eth0 or eth1).
Error reading the data rate.	An error occurs while the management module is reading the data rate setting of a network interface (eth0 or eth1).
Error reading the DHCP configuration.	An error occurs while the management module is reading the DHCP setting of a network interface (eth0).
Error reading the duplex setting.	An error occurs while the management module is reading the duplex setting of a network interface (eth0 or eth1).
Error reading the hostname.	An error occurs while the management module is reading the host name of a network interface (eth0).
Error reading the locally administered MAC address.	An error occurs while the management module is reading the locally administered MAC address of a network interface (eth0 or eth1).
Error reading the maximum transmission unit.	An error occurs while the management module is reading the maximum transmission unit (MTU) setting of a network interface (eth0 or eth1).
Error reading the subnet mask.	An error occurs while the management module is reading the subnet mask of a network interface (eth0 or eth1).
Error writing IP Address.	An error occurs while the management module is setting the IP address of the integrated system management processor on a blade server.
Getting blade cKVM status for blade <i>blade_number</i> failed.	An error occurs while the management module is reading the cKVM status of targeted blade
where <i>blade_number</i> identifies the blade server.	
Getting interface status failed.	An error occurs while the management module is reading the interface status.
I/O Module is in Stacking Mode and cannot change its Gateway configuration.	The user tries to issue a command to change the Gateway configuration with the I/O Module in Stacking Mode.
I/O Module is in Stacking Mode and cannot change its IP configuration.	The user tries to issue a command to change the IP configuration with the I/O Module in Stacking Mode.

Table 126. if config command errors (continued)

Error message	Definition
I/O Module is in Stacking Mode and cannot change its Subnet configuration.	The user tries to issue a command to change Subnet configuration with I/O Module in Stacking Mode.
Invalid gateway address.	The user tries to enter an invalid gateway address.
Invalid hostname.	The user tries to enter an invalid hostname.
Invalid hostname arg for <i>option: hostname</i> . Consecutive dots	The user tries to enter consecutive periods (.) as part of a hostname.
 where: <i>option</i> identifies the command option <i>hostname</i> identifies the invalid hostname argument 	
Invalid hostname arg for <i>option: hostname</i> . Length has to be < 64 characters	The user tries to enter a hostname longer than 63 characters.
 where: <i>option</i> identifies the command option <i>hostname</i> identifies the invalid hostname argument 	
Invalid hostname arg for <i>option: hostname</i> . Only alphanumeric chars and allowed where: • <i>option</i> identifies the command option • <i>hostname</i> identifies the invalid hostname argument	The user tries to enter an hostname that contains invalid characters. Valid characters that can be used in a hostname are letters, numbers, periods (.), dashes (-), and underscores (_).
Invalid ip address.	 Displays for one of the following errors: A user tries to set the IP address of system:blade[1]:sp to an invalid IP address. A user tries to set an IP address whose last part is greater than 255 (the maximum number of blade servers). A user tries to enter an invalid IP address for the -i (static IP address) command option.
 Invalid IP arg for <i>option: ip_address.</i> Each byte has to be in the range (0-255) where: <i>option</i> identifies the command option <i>ip_address</i> identifies the invalid IP address argument 	The user tries to enter an IP address that is out of range. IP addresses must follow the standard format: <i>xxx.xxx.xxx</i> , where each <i>xxx</i> is a number from 0 to 255.
Invalid IP arg for <i>option</i> : <i>ip_address</i> . Enter 4 bytes separated by 3 dots where: • <i>option</i> identifies the command option • <i>ip_address</i> identifies the invalid IP address argument	The user tries to enter an IP address that is too long. IP addresses must follow the standard format: <i>xxx.xxx.xxx</i> , where each <i>xxx</i> is a number from 0 to 255.
 Invalid IP arg for <i>option: ip_address</i>. Too few bytes where: <i>option</i> identifies the command option <i>ip_address</i> identifies the invalid IP address argument 	The user tries to enter an IP address with too few bytes. IP addresses must follow the standard format: <i>xxx.xxx.xxx</i> , where each <i>xxx</i> is a number from 0 to 255.
Invalid IP arg for <i>option: ip_address.</i> Too many bytes where: • <i>option</i> identifies the command option • <i>ip_address</i> identifies the invalid IP address argument	The user tries to enter an IP address with too many bytes. IP addresses must follow the standard format: <i>xxx.xxx.xxx</i> , where each <i>xxx</i> is a number from 0 to 255.
invand mac address.	The user tries to enter an invalid MAC address.

Table 126. if config command errors (continued)

Error message	Definition
Invalid MAC arg for option: address. Invalid syntax	The user tries to enter an invalid MAC address.
where:<i>option</i> identifies the command option<i>address</i> identifies the invalid MAC address argument	
Invalid MAC arg for <i>option: address</i> . Multicast addresses not allowed	The user tries to enter a multicast address.
where:<i>option</i> identifies the command option<i>address</i> identifies the invalid MAC address argument	
Invalid MAC arg for option: address. Too few bytes	The user tries to enter a MAC address with too few
where:<i>option</i> identifies the command option<i>address</i> identifies the invalid MAC address argument	bytes.
Invalid MAC arg for option: address. Too many bytes	The user tries to enter a MAC address with too many
where:<i>option</i> identifies the command option<i>address</i> identifies the invalid MAC address argument	bytes.
Invalid option for ethernet interface.	A user tries to change a static property of eth1 (hostname, DHCP, data rate, duplex).
Invalid parameter. The locally administered MAC address cannot be a multicast address.	The user tries to set the locally administered MAC address to a multicast address.
Invalid parameter. The MTU must be between 60 and 1500, inclusive.	The user tries to enter an MTU outside the valid range.
Invalid parameter. Valid values for -c are dhcp, static, or dthens.	A user tries to enter an invalid parameter for the -c (Ethernet configuration method) command option.
Invalid parameter. Valid values for -d are auto, half, and full.	The user tries to enter an invalid parameter with the -d option.
Invalid parameter. Valid values for -r are auto, 10, and 100.	The user tries to enter an invalid parameter with the -r option.
Invalid subnet mask.	The user tries to enter an invalid subnet mask.
Maybe blade network configuration is still in discovery phase. Please check and try again.	An error occurs while the management module is reading the blade network configuration.
Option: -bsmp is not supported any more.	The user tries to direct the command to the -bsmp command target that is no longer supported.
Please check blade health status and try again.	An error occurs while the management module is reading the blade health status.
The target must be system:blade[1]:sp for this command	A user tries to issue the ifconfig -i <i>ip address</i> -T system:blade[x]:sp to a blade server other than blade[1].
	where <i>ip address</i> is a valid ip address and x identifies the selected blade server.
This target is no longer supported by the ifconfig command.	The user tries to direct the command to an invalid command target.
When setting $-i6$, $-p6$, or $-g6$, $-id$ must be included.	A user tries to configure a blade server static IPv6 configuration and does not include the static configuration ID number.

info command errors

This topic lists error messages for the info command.

Table 127. info command errors

Error message	Definition
Device not found	No VPD is available for the targeted device.
Getting blade H8 firmware VPD data of blade <i>blade_number</i> failed.	An error occurs while the management module is reading the blade H8 firmware VPD data of the targeted
where <i>blade_number</i> identifies the blade server.	
Getting compact flash cards information failed.	An error occurs while the management module is reading the compact flash cards information.
Getting firmware version of cKVM <i>bay_number</i> failed.	An error occurs while the management module is reading the firmware version of targeted cKVM.
where the <i>bay_number</i> specifies the cKVM.	
Getting firmware's VPD data of <i>type</i> failed.	An error occurs while the management module is reading the firmware's VPD data of targeted type.
Getting name of blade <i>blade_number</i> failed.	An error occurs while the management module is reading the name of the targeted blade server
where <i>blade_number</i> identifies the blade server.	reading the name of the tangeted blade berven
Getting name of mm <i>bay_number</i> failed.	An error occurs while the management module is reading the name of the targeted management module.
where the <i>bay_number</i> specifies the management module.	
Reload Firmware VPD failed.	An error occurs while the management module is reloading the firmware VPD.
Reload Hardware VPD failed.	An error occurs while the management module is reloading the hardware VPD.
Reload all failed.	An error occurs while the management module is reloading all VPD and MAC addresses.
Reload MAC address failed.	An error occurs while the management module is reloading the MAC address.
Reload WWN failed.	An error occurs while the management module is reloading WWN.
Status: Unable to read status.	An error occurs while the management module is reading the firmware update status.
Unable to read firmware VPD.	An error occurs while the management module is reading the firmware VPD.
Unable to read hardware VPD.	An error occurs while the management module is reading the hardware VPD.
Unknown device type.	The command is targeted to an unknown device type.

iocomp command errors

This topic lists errors for the iocomp command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 128. iocomp command errors

Error message	Definition
Error reading I/O Compatibility Detail for blade <i>blade_number</i>	An error occurs while the management module is reading I/O compatibility for targeted blade server.
where <i>blade_number</i> identifies the blade server.	
Error reading I/O Compatibility Detail for switch <i>bay_number</i>	An error occurs while the management module is reading I/O compatibility for targeted I/O module.
where the <i>bay_number</i> identifies the I/O module.	
ERROR!!! IOM <i>bay_number</i> reports incorrect width! sw_width = <i>sw_width</i>	An error occurs while the management module is reading I/O compatibility for targeted I/O module.
 where the <i>bay_number</i> identifies the I/O module <i>sw_width</i> identifies the invalid width 	
I/O Compatibility Detail or blade <i>blade_number</i> : unknown	An error occurs while the management module is getting the width of the targeted blade server.
where <i>blade_number</i> identifies the blade server.	

kvm command errors

This topic lists errors for the kvm command.

There are no unique errors for the kvm command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

Idapcfg command errors

This topic lists error messages for the ldapcfg command.

Error message	Definition
A Client DN password is configured, client DN must be configured too.	The user tries to issue a command to remove the client DN setting with the client DN password configured.
AMM target name is limited to 63 characters.	A user tries to set an advanced management module target name that is longer than 63 characters.
Argument of option <i>-arguments</i> must be enclosed in quotation marks.	The user tries to issue a command with arguments for the options that are not enclosed in quotation marks.
where <i>arguments</i> is the name of the improperly entered arguments	
Arguments containing spaces must be enclosed in quotation marks.	The user tries to issue a command with arguments for options without ending double quotes.

Table 129. Idapcfg command errors

Table 129. Idapcfg command errors (continued)

Error message	Definition
Both password and confirm password must be provided.	The user tries to issue a command without providing both the password and the confirm password.
Client DN password mismatch. Please reenter passwords.	The user tries to issue a command with both -p and -cp options, but their arguments do not match.
Client DN password mismatch. Please reenter passwords.	The user tries to issue a command with both -p and -cp options, but their arguments do not match.
If a Client DN password is configured, client DN must be configured too.	The user tries to issue a command to configure the client DN password while the client DN is not configured.
 Invalid option argument for <i>-option:argument. format</i> where: <i>option</i> identifies the option <i>argument</i> identifies the invalid argument <i>format</i> identifies the format of argument 	The user tries to issue a command with invalid arguments for the options which do not conform to the format specified.
You are configuring Client DN password, but no Client DN. Please configure a Client DN.	The user tries to issue a command to set Client DN password while the Client DN is not configured.
You must configure a Search Domain given your selection of ' <i>option</i> ' for Domain Source.	The user tries to issue a command for -ds <i>option</i> settings without the Source Domain configured.
where <i>option</i> is sd or ltsd.	

led command errors

This topic lists errors for the led command.

Error message	Definition
-d can only be used with the -loc on.	A user tries to issue a command to set the -d while the -loc setting is off.
Delay value must be less than <i>max</i> .	User input for the option -d exceeds the maximum.
where <i>max</i> is 60.	
Error getting LED status.	An error occurs while the management module is getting the system LED status.
Error reading system LED state.	An error occurs while the management module is reading the system LED state.
Error setting system LED.	An error occurs while the management module is configuring the system LED.
Invalid option argument for -loc.	A user tries to enter an invalid argument for the option -loc.
Error setting -loc for blade[slot]	An error occurs while setting location LED for the targeted blade.
-l can only be used by itself.	User issues a command with -l option inclusive of an argument or other options.
Error turning off information LED	An error occurs while the user is setting information LED to off.

Table 130. led command errors

Table 130. led command errors (continued)

Error message	Definition
The chassis location LED cannot be turned off at this time because one or more blades have their location LED active.	A user issues a command to turn off the chassis location LED under conditions when this is not allowed.

list command errors

This topic lists error messages for the list command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 131. list command errors

Error message	Definition
The level must be non-zero.	The user tries to enter a level of depth for tree-structure display of 0.

mcad command errors

This topic lists error messages for the mcad command.

There are no unique errors for the mcad command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

modactlog command errors

This topic lists errors for the modactlog command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 132. modactlog command errors

Error message	Definition
Unable to read the Module Activity Log.	No module activity log is found in the database.

monalerts command errors

This topic lists errors for the monalerts command.

Table 133. monalerts command errors

Error message	Definition
<i>-option</i> must be used exclusive of its sub-options. where <i>option</i> is -ca, -wa, or -ia.	A user tries to issue a command with the -ca, -wa, or -ia option at the same time as its sub-options.
Invalid syntaxec is only allowed to be enabled.	A user tries to disable -ec (legacy alerts).
Note: If -ec is disabled, monalertsleg should be used.	A user tries to issue a monalerts command with the -ec disabled setting.

monalertsleg command errors

This topic lists errors for the monalertsleg command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Important: The monalertsleg command is no longer supported by the advanced management module firmware. Legacy alert monitoring that uses the monalertsleg command must transition to use of the monalerts command.

Table 134. monalertsleg command errors

Error message	Definition
Invalid syntaxec is only allowed to be enabled.	A user tries to disable -ec (legacy alerts).
Note: If -ec is enabled, monalerts should be used.	A user tries to issue a monalertsleg command with the <i>-ec enable</i> setting.

mt command errors

This topic lists errors for the mt command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 135. mt command errors

Error message	Definition
Remote media tray switching must be enabled to change	A user tries to issue a command to change the media
the media tray owner.	tray owner while media tray switching is not enabled.

nat command errors

This topic lists error messages for the nat command.

Table 136. nat command errors

Error message	Definition
Adding code authority failed.	A user tries to add code authority.
External port: Valid range is 1000 through 65534.	The user tries to set the external port number to a value outside of its valid range.
I/O Module is in protected mode and cannot be restored to its default configuration.	The user tries to restore the default configuration of an I/O module while it is in protected mode.
I/O Module is in Protected Mode and cannot change its NAT configuration.	The user tries to change the configuration of an I/O module while it is in protected mode.
Internal port: Valid range is 1 through 65534.	The user tries to set the internal port number to a value outside of its valid range.
NAT configuration is not supported on this IO module.	The user tries to direct a nat command to an I/O module that does not support the network address table.
The first two rules' protocol names cannot be changed.	The user tries to change the protocol names for HTTP or Telnet.

Table 136. nat command errors (continued)

Error message	Definition
When creating a new rule, all fields must be specified.	The user does not specify all the fields when attempting to make a new rule.
Invalid input. '-pn' must be less than <i>maximum_number</i> characters.	The user tries to enter a protocol name with a string length of more than the maximum allowed.
where <i>maximum_number</i> is the maximum number of characters allowed for the protocol name.	

ntp command errors

This topic lists error messages for the ntp command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 137. ntp command errors

Error message	Definition
Invalid value passed to -en flag. Valid values are enable/disable	The user input for the <i>-en</i> option is invalid.
Please set NTP server name or IP address before enabling NTP	The user tries to enable NTP before setting the server name or IP address.
Please set NTP server name or IP address before synchronizing the clock	The user tries to synchronize the clock before setting the NTP server name or IP address.
Please set NTP update frequency before enabling NTP	The user tries to enable NTP before setting the update frequency.
Please set NTP v3 authentication entry before enabling NTP authentication	The user tries to enable NTP authentication before configuring the v3 authentication.

ping command errors

This topic lists errors for the ping command.

Table 138. ping command errors

Error message	Definition
Error reading IP address of switch <i>bay_number</i> where the <i>bay_number</i> designates the I/O module.	An error occurs while the management module is getting the current IP address of the targeted switch.
Error reading I/O Module's capabilities.	An error occurs while the management module is reading the I/O Module's capabilities.
Error reading I/O Module's second ip configuration.	An error occurs while the management module is reading the I/O Module's second ip configuration.
Error reading second IP address of I/O Module <i>bay_number</i> where the <i>bay_number</i> identifies the I/O module.	An error occurs while the management module is reading the second IP address of the I/O Module specified.

Table 138. ping command errors (continued)

Error message	Definition
The I/O module cannot be pinged while the IP config is protected.	The user tries to ping a protected member of an I/O module stack.

pmpolicy command errors

This topic lists errors for the pmpolicy command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 139. pmpolicy command errors

Error message	Definition
Error getting number of domains.	An error occurs while the advanced management module is getting the number of domains.
Getting current policy failed.	An error occurs while the advanced management module is getting the current policy for a domain.
Getting valid policies failed.	An error occurs while the advanced management module is getting the valid policies for power management.

portcfg command errors

This topic lists errors for the portcfg command.

There are no unique errors for the portcfg command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

ports command errors

This topic lists error messages for the ports command.

Table 140. ports command errors

Error message	Definition
A certificate must first be in place before SSL can be enabled.	The user tries to enable SSL before setting up a valid SSL certificate.
An SSH server key must first be in place before SSH can be enabled.	The user tries to enable SSH before setting up a valid SSH server key.
Duplicate port number entered.	The user tries to enter a command with a port number that is already in use.
Enabling SNMPv1 failed	The SNMPv1 configuration does not meet required criteria.
Enabling SNMPv3 failed	The SNMPv3 configuration does not meet required criteria.
Error: A community is configured without an IP address or host name. Please use 'snmp' command for snmp configuration.	Attempted to configure community without an IP address or host name.
Table 140. ports command errors (continued)

Error message	Definition
Error: A duplicate community name is configured. Please use 'snmp' command for snmp configuration.	Attempted to configure a community name that was already defined.
Error: At least one configured community is required to enable SNMPv1. Please use 'snmp' command for snmp configuration.	Attempted to enable SNMPv1 without configuring at least one community.
Error: IP address of 0.0.0, 0::0 is allowed only when the first community is configed as Get or Set access type. Please use 'snmp' command for snmp configuration.	IP address of 0.0.0.0 or 0::0 is allowed only when the first community is configured as a GET or SET access type.
Error: System contact must be defined to enable SNMPv1. Please use 'snmp' command for snmp configuration.	Attempted to enable SNMPv1 without defining a system contact.
Error: System location must be defined to enable SNMPv1. Please use 'snmp' command for snmp configuration.	Attempted to enable SNMPv1 without defining a system location.
Error: System contact must be defined to enable SNMPv3. Please use 'snmp' command for snmp configuration.	Attempted to enable SNMPv3 without defining a system contact.
Error: System location must be defined to enable SNMPv3. Please use 'snmp' command for snmp configuration.	Attempted to enable SNMPv3 without defining a system location.
Error sanity checking of SNMP configuration.	An error occurs while the management module is checking the SNMP configuration.
Invalid parameter. The timeout must be between 0 and 4294967295 seconds.	The user tries to enter a timeout that is outside of the valid range.
Maximum connections can not exceed 20.	A user attempts to configure more than 20 connections.
No valid server certificate is in place for Secure TCP Command Mode. Use the sslcfg command to generate a certificate.	A user tries to change the state of stcm without a valid certificate in place.
Port number out of range.	A user tries to enter a port number that is outside of the valid range.
Resetting all ports to default values failed.	An error occurs while the management module is resetting all ports to their default values.
Secure SMASH CLP cannot be enabled without a valid SSH server key in place.	The user tries to enable the secure SMASH CLP before setting up a valid SSH server key.
The <i>-prior</i> option has been deprecated. Please use the <i>-rpp</i> option instead.	The user tries to enter a command with a deprecated option, such as -kvmp, -rdp, -rdocp, or -sdsp.
where <i>prior</i> is kvmp, rdp, rdocp, or sdsp.	
The total number of secure and legacy connections of TCP Command Mode cannot exceed 20	A user attempted to configure more than 20 TCP Command Mode connections.
This I/O module does not support port speed configuration.	The user tries to enter a command for a speed configuration which not supported by the targeted I/O module.
Warning: Communication with IBM Director via Secure TCP Command Mode has been disabled.	A user has disabled the Secure TCP command mode.
Warning: Communication with IBM Director via TCP Command Mode has been disabled.	A user has disabled the TCP command mode.

power command errors

This topic lists error messages for the power command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 141. power command errors

Error message	Definition
Invalid POST results.	The POST results are not valid.
Not supported by this type of I/O module. Type env -h for help on changing targets.	The user attempts to apply the -fp option to an I/O module that does not support this option.
POST results could not be read.	An error occurs during POST.
POST results not complete: <i>hex_code</i> where the <i>hex_code</i> value varies based on the problem that was encountered.	The POST results are not available. See the documentation that comes with the device that failed to respond correctly to the power command for information about the <i>hex_code</i> value.
Powering on/off blade failed.	An error occurs while powering the blade server on or off.
Powering on/off I/O Module failed.	An error occurs while the management module is powering the I/O module on or off.
Powering on/off network clock failed.	An error occurs while the management module is powering the network clock on or off.
Powering on/off Telco Alarm Panel failed.	An error occurs while the management module is powering the Telco Alarm Panel on or off.
Resetting blade failed.	An error occurs while the management module is resetting the blade server.
Shutting down OS and powering off blade failed.	An error occurs while the management module is shutting down the operating system and powering off the blade server.
The I/O Module is powering off.	The user tries to power on, power off, or restart a RAID SAS module which is in the process of powering off. (BladeCenter S only)

rdoc command errors

This topic lists error messages for the rdoc command.

Table 142. rdoc command errors

Error message	Definition
Error getting rdoc status information.	An error occurred while retrieving status information.
Internal error. Please try again.	The command failed to execute.

read command errors

This topic lists error messages for the read command.

Table 143. read command errors

Error message	Definition
Both the -i and -l options must be specified with the -config file.	The user does not specify both the -i and -l options when restoring configuration from a file.
Configuration restore from the chassis failed: i2c bus read error.	An error occurs while the management module is restoring the management module configuration from the BladeCenter unit midplane due to an i2c read error.
Configuration restore from the chassis failed: operation not supported.	An error occurs while the management module is restoring the management module configuration from the BladeCenter unit midplane due to a failed system check.
Configuration restore from the chassis failed: NVRAM compression error.	An error occurs while the management module is restoring the management module configuration from the BladeCenter unit midplane due to an EEPROM compression error.
Configuration restore from the chassis failed: unsupported midplane data format.	An error occurs while the management module is restoring the management module configuration from the BladeCenter unit midplane due to an unsupported EEPROM format.
Could not retrieve encryption data from the configuration file successfully.	The user tries to enter a passphrase that does not match the one that was used to create the backup configuration file.
Error writing autoread flag.	An error occurs while the management module is writing autoread flag.
File transfer failed.	An error occurs while transferring a file during file upload.
Firmware update is in progress. Try again later.	The user tries to restore the management module configuration from the BladeCenter unit midplane while the management module firmware is updating.
Please make sure you enter the correct passphrase for this configuration file.	The user tries to enter a passphrase that does not match the one that was used to create the backup configuration file.
Resource allocation failure! Memory allocation failed for configuration read.	An error occurs while the management module is allocating memory.
The -auto option can only be used with the -config chassis.	The user tries to set the -auto option when restoring the configuration from a file.
The -config option and a config source is required.	The user tries to issue a command to read configuration from a file without specifying both the -config option and config source.
The -config option is required.	The user does not include a required -config option for the command.
The -i, -l, and -p options can only be used with the -config file.	The user tries to specify a TFTP server and a configuration file when restoring the configuration from the BladeCenter unit midplane.
The passphrase is greater than 1600 characters.	The user tries to input a passphrase that exceeds the maximum length.

Table 143. read command errors (continued)

Error message	Definition
The passphrase must be quote-delimited.	The user tries to input a passphrase that is not quote-delimited.
There was a problem retrieving the file.	TFTP encounters an error when transferring the configuration file.
Update Failed, there was a problem retrieving the file.	An error occurs while the advanced management module is uploading a file.

remacccfg command errors

This topic lists error messages for the remacccfg command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

remotechassis command errors

This topic lists error messages for the remotechassis command.

Table 144. remotechassis command errors

Error message	Definition
Clearing the internal discovered list of MM's failed.	An error occurs while the management module is clearing the internal discovered list of management modules.
Discovery cannot be run until SLP has been enabled.	The user tries to discover other BladeCenter units on the network when SLP is disabled.
Error running discovery.	An error occurs while the management module is running discovery.
Getting last discovery time failed.	An error occurs while the management module is reading last discovery time.
Getting the first entry of the internal discovered list of MM's failed.	An error occurs while the management module is reading the first entry of the internal discovered list of management modules.
Getting the internal discovered list of MM's failed.	An error occurs while the management module is reading the internal discovered list of management modules.
Unable to read SLP settings.	An error occurs while the management module is reading SLP settings.

reset command errors

This topic lists error messages for the reset command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 145. reset command errors

Error message	Definition
An error occurred while disabling failover.	An error occurs while the management module is disabling failover.
An error occurred while enabling failover.	An error occurs while the management module is enabling failover.
Firmware update is in progress. Try again later.	The user tries to reset the management module during a firmware update. The error message displays and the management module does not reset.
Rebooting blade failed.	An error occurs while the management module is rebooting the blade server.
Resetting and running standard/extended/full diagnostics for I/O module failed.	An error occurs while the management module is resetting and running diagnostics for the I/O module.
Resetting I/O module failed.	An error occurs while the management module is resetting the I/O module.
There is no backup management module installed.	A user tries to enable failover on a management-module reset and there is no standby management module.
Resetting blade <i>blade_number</i> with NMI not supported. where the <i>blade_number</i> identifies the blade server.	A user tries to reset a blade server that does not support non-maskable interrupts (NMI).
Resetting blade <i>blade_number</i> with NMI failed. where the <i>blade_number</i> identifies the blade server.	An error occurs while the management module is resetting a blade server with NMI.

scale command errors

This topic lists errors for the scale command.

Table 146. scale command errors

Error message	Definition
Auto-create partition failed: error_detail	An error occurs while creating a partition.
where <i>error_detail</i> provides additional information about the error.	
Clearing complex failed: error_detail	An error occurs while clearing a complex.
where <i>error_detail</i> provides additional information about the error.	
Create a partition failed: <i>error_detail</i>	An error occurs while creating a partition.
where <i>error_detail</i> provides additional information about the error.	

Table 146. scale command errors (continued)

Error message	Definition
Deleting a partition failed: error_detail	An error occurs while deleting a partition.
where <i>error_detail</i> provides additional information about the error.	
Getting complex information failed: error_detail	An error occurs while gathering complex information.
where <i>error_detail</i> provides additional information about the error.	
Invalid node slot.	A user tries to enter a slot number for a node or blade server that is not valid. Make sure that the node information specified is valid.
Invalid range of node slots.	A user tries to enter a range of slot numbers for a node or blade server that is not valid. Make sure that the node information specified is valid.
Power controlling a partition failed: <i>error_detail</i>	An error occurs while changing the power state of a
where <i>error_detail</i> provides additional information about the error.	partition.
Setting mode failed: error_detail	An error occurs while changing the power state of a
where <i>error_detail</i> provides additional information about the error.	partition.

sddump command errors

This topic lists errors for the sddump command.

Table 147.	sddump	command	errors
------------	--------	---------	--------

Error message	Definition
Initiate data collection of <i>type</i> type not supported on blade[<i>x</i>] where <i>type</i> is the type of data requested and <i>x</i> is the	The management module is unable to collect the requested data from the specified blade server.
number of the blade-server bay.	
Initiate data collection type failed.	The management module is unable initiate data collection of the JS12 or JS22 blade server.

sdemail command errors

This topic lists errors for the sdemail command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 148. sdemail command errors

Error message	Definition
-to must be specified.	A user tries to send a service data email message without specifying the recipient.
Error sending service data email.	An error occurs when the management module tries to send a service data email message.
Invalid email address.	A user tries to enter an email address that is not valid.
Invalid input. Email address must be less than 120 characters.	A user tries to enter an email address that is 120 or more characters long.
Invalid syntax. Please type 'sdemail -h' for help.	A user enters the sdemail command without specifying the required options.
Subject must be enclosed in quotation marks.	A user tries to send a service data email message with a subject option that is not enclosed in quotation marks.

security command errors

This topic lists errors for the security command.

There are no unique errors for the security command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

service command errors

This topic lists errors for the service command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 149. service command errors

Error message	Definition
Getting status of debug with USB key failed.	An error occurs while the management module is reading the status of debug with a USB key.

shutdown command errors

This topic lists errors for the shutdown command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 150. shutdown command errors

Error message	Definition
Invalid option. This command must have the -f option.	The user tries to issue a command without the -f option.

slp command errors

This topic lists errors for the slp command.

There are no unique errors for the slp command. See "Common errors" on page 421 for a list of error messages that apply to all commands.

smtp command errors

This topic lists error messages for the smtp command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 151. smtp command errors

Error message	Definition
Getting SMTP server host name or IP address failed.	An error occurs while the management module is reading the SMTP server host name or IP address.
Input length is greater than the maximum characters allowed.	A user tries to enter too many characters in an input field.
Invalid host name or ip address.	A user tries to set the SMTP host name or IP address to an invalid value.
Removing SMTP server name or IP address failed.	An error occurs while the management module is removing an SMTP server host name or IP address.
Setting SMTP server name or IP address failed.	An error occurs while the management module is setting an SMTP server host name or IP address.
SMTP server host name or IP address is not set.	A user tries to view the SMTP host name or IP address when the values are not set.

snmp command errors

This topic lists error messages for the snmp command.

Table 152. snmp command errors

Error message	Definition
Arguments containing spaces must be enclosed in quotation marks	A user tries to enter a string containing spaces that has an opening quotation mark without a closing quotation mark.
At least one configured community is required to enable SNMP.	A user tries to enable SNMP without configuring at least one community name.
Config failed. IP address of 0.0.0.0 is allowed only for the first host name in the first community.	A user tries to set an IP address of 0.0.0.0 for something other than the first host name of the first community.
Config failed. IP address of 0.0.0.0 is allowed only when the first community is configured as Get access type.	A user tries to set an IP address of 0.0.0.0 for the first host name of the first community when the first community is not configured with the Get access type.
Config failed. You defined a community without an IP address or host name.	A user tries to define a community without specifying an IP address or host name.
Config failed. You defined a duplicate community name.	A user tries to define a two communities with the same name.
Enabling/Disabling snmp interface failed.	An error occurs while the management module is enabling or disabling an snmp interface.
Enabling/Disabling snmp traps failed.	An error occurs while the management module is enabling or disabling the snmp traps.
Enabling/Disabling SNMPv3 Agent failed.	An error occurs while the management module is enabling or disabling the SNMPv3 Agent.
Input length is greater than the maximum characters allowed.	A user tries to enter too many characters in an input field.
Invalid community name.	A user tries to set a community name to an invalid value.
Invalid host name or ip address.	A user tries to set the SNMP host name or IP address to an invalid value.
Setting access type of <i>type</i> for SNMPv3 failed where <i>type</i> is the type of SNMPv3 access desired.	An error occurs while the management module is setting access type for an SNMPv3.
Setting location/contact of the SNMP agent failed.	An error occurs while the management module is setting the location or contact of the SNMP agent.

sol command errors

This topic lists error messages for the sol command.

Table 153. sol command errors

Error message	Definition
An error occurred while disabling SOL globally.	An error occurs while the management module is disabling SOL globally.
An error occurred while disabling SOL on that blade.	An error occurs while the management module is disabling SOL on a blade server.
An error occurred while enabling SOL globally.	An error occurs while the management module is enabling SOL globally.
An error occurred while enabling SOL on that blade.	An error occurs while the management module is enabling SOL on a blade server.
An error occurred while reading the global SOL status.	An error occurs while the management module is reading the global SOL status.
An error occurred while reading the SOL accumulate timeout.	An error occurs while the management module is reading the SOL accumulate timeout.
An error occurred while reading the SOL retry count.	An error occurs while the management module is reading the SOL retry count.
An error occurred while reading the SOL retry interval.	An error occurs while the management module is reading the SOL retry interval.
An error occurred while reading the SOL send threshold.	An error occurs while the management module is reading the SOL send threshold.
An error occurred while reading the SOL session status on that blade.	An error occurs while the management module is reading the SOL session status on a blade server.
An error occurred while reading the SOL VLAN ID.	An error occurs while the management module is reading the SOL VLAN ID.
An error occurred while setting the SOL accumulate timeout.	An error occurs while the management module is setting the SOL accumulate timeout.
An error occurred while setting the SOL blade reset sequence.	An error occurs while the management module is processing the command.
An error occurred while setting the SOL escape sequence.	An error occurs while the management module is processing the command.
An error occurred while setting the SOL retry count.	An error occurs while the management module is setting the SOL retry count.
An error occurred while setting the SOL retry interval.	An error occurs while the management module is setting the SOL retry interval.
An error occurred while setting the SOL send threshold.	An error occurs while the management module is setting the SOL send threshold.
An error occurred while setting the SOL vlan id.	An error occurs while the management module is processing the command.
Checking if this blade supports SOL failed.	An error occurs while the management module is checking if the selected blade supports SOL.
Invalid arg for -status. Must be on or off.	A user tries to enter an invalid argument for the -status command option.

Table 153. sol command errors (continued)

Error message	Definition
Invalid arg for -status. Must be enabled or off.	A user tries to enter an invalid argument for the -status command option.
Invalid parameter. The accumulate timeout must be between 1 and 251 inclusive.	A user tries to enter an accumulate timeout that is outside of the valid range.
Invalid parameter. The retry count must be between 0 and 7, inclusive.	A user tries to enter a retry count that is outside of the valid range.
Invalid parameter. The send threshold must be between 1 and 251 inclusive.	A user tries to enter a send threshold that is outside of the valid range.
Invalid parameter. The vlan id must be between 1 and 4095 inclusive.	A user tries to enter a VLAN ID that is out of range.
Retry interval range is too large. Setting to 2550.	A user tries to enter a retry interval that is greater than 2550 ms. If the user tries to enter a retry interval greater than 2550 ms, the retry interval will be set to 2550 ms.
Setting retry interval to 2500 failed.	An error occurs while the management module is setting the retry interval to 2550.
This blade does not support SOL.	A user tries to issue the SOL command to a blade server that does not support SOL.

sshcfg command errors

This topic lists errors for the sshcfg command.

Table 154. sshcfg command errors

Error message	Definition
Getting CLI SSH port failed.	An error occurs while the management module is reading the CLI SSH port.
Getting DSA host key failed.	An error occurs while the management module is reading the DSA host key.
Getting host key size failed.	An error occurs while the management module is reading the host key size.
Getting installed key status failed.	An error occurs while the management module is reading the installed key status.
Getting number of SSH public keys installed failed.	An error occurs while the management module is reading the number of SSH public keys installed.
Getting SMASH SSH port failed.	An error occurs while the management module is reading the SMASH SSH port.
When displaying host keys, -hk must be used by itself.	The user tries to issue a command to display the host keys with option -hk.

sslcfg command errors

This topic lists errors for the sslcfg command.

Table 155. sslcfg command errors

Error message	Definition
-dnld must be used with the -cert/-csr (server, client) as well as -i and optionally -l	A user tries to issue a download certificate or certificate signing request command without the -cert or -csr, and -i options.
-i must be provided to download a trusted certificate.	A user tries to issue a downloading trusted certificate command without the -i option.
-upld must be used with the -cert (server, client) as well as -i and -l	A user tries to issue an import certificate command without the -cert, -l and -i options.
Cannot open file: filename	An error occurs while the management module is trying
where <i>filename</i> is the name of the file that was entered for opening.	to open a file.
Cert generation for server/client failed	An error occurs while the management module is
where <i>server/client</i> specifies whether the certificate was being generated for a server or client.	generating a certificate for the server or client.
CLI map failed error = <i>error</i>	An error occurs while the management module is
where <i>error</i> specifies error.	mapping the file to memory.
Converting DER back to X509 format failed.	An error occurs while the management module is converting DER back to X509 format.
CSR generation for <i>server/client</i> failed where <i>server/client</i> specifies whether the certificate signing request was being generated for a server or client.	An error occurs while the management module is generating a certificate signing request for a server or client.
 Downloading <i>Cert/CSR</i> to tftp server <i>argument</i> is failed where: <i>Cert/CSR</i> specifies whether the user tried to download a certificate or certificate signing request. <i>argument</i> identifies the IP address of the tftp server 	An error occurs while the management module is downloading a certificate or certificate signing request to the tftp server for the SSL server or client.
Error: unknown application	An error occurs because an unknown certificate type is referred to.
Exporting Cert/CSR failed	An error occurs while the management module is
where <i>Cert/CSR</i> specifies whether the user tried to export a certificate or certificate signing request.	exporting a certificate or certificate signing request.
File transfer failed.	An error occurs while transferring a file during file upload.
 Getting <i>filename</i> from tfpt server <i>argument</i> failed where: <i>filename</i> identifies the name of the requested file <i>argument</i> identifies the IP address of the tftp server 	An error occurs while the management module is getting a file from the tftp server.

Table 155. sslcfg command errors (continued)

Error message	Definition
Getting certificate status of standby AMM failed.	An error occurs while the management module is reading the certificate status of the standby advanced management module.
Getting failover mode failed.	An error occurs while the management module is reading the failover mode.
Getting SSL Server/Client Certificate/CSR status failed.	An error occurs while the management module is reading the SSL server or client certificate or certificate signing request status.
Importing <i>certFileName</i> is failed	An error occurs while the management module is importing a certificate
where <i>certFileName</i> is the name of the certificate that was being imported.	
Input length is greater than the maximum characters allowed.	A user tries to issue a command with an invalid argument for the option. The length of the input is greater than maximum.
Invalid IP arg for <i>-option: argument</i> . Each byte has to be in the range (0-255)	A user tries to issue a command with an invalid argument for the IP Address option. One or more parts is not in the range of 0-255.
where:<i>option</i> identifies the command option<i>argument</i> identifies the invalid IP address argument	
Invalid IP arg for <i>-option: argument</i> . Enter 4 bytes separated by 3 dots	A user tries to issue a command with an invalid argument for the IP Address option. Invalid arguments could be too long, too short, or not numeric in all parts.
 <i>option</i> identifies the command option <i>argument</i> identifies the invalid IP address argument 	
Invalid IP arg for <i>-option: argument</i> . Too few bytes	A user tries to issue a command with an invalid argument for the IP Address option, an argument which
 <i>option</i> identifies the command option <i>argument</i> identifies the invalid IP address argument 	has fewer than four parts.
Invalid IP arg for <i>-option: argument</i> . Too many bytes	A user tries to issue a command with an invalid
where:<i>option</i> identifies the command option<i>argument</i> identifies the invalid IP address argument	has more than four parts.
Invalid option for Cert generation: -cpwd	A user tries to issue a command with an invalid option -cpwd for certification generation.
Invalid option for Cert generation: -un	A user tries to issue a command with an invalid option -un for certification generation.
IPs Swaps is not configured.	A user tries to issue a command for the SSL configuration against the Standby Server target without the IPs Swaps configured.
Missing required options.	A user tries to issue a command for the SSL configuration without entering all the required options.
No <i>Cert/CSR</i> available.	A user tries to issue a command to download a
where <i>Cert/CSR</i> specifies whether the user specified a certificate or certificate signing request.	nonexistent certificate of certificate signing request.

Table 155. sslcfg command errors (continued)

Error message	Definition
No tc <i>index</i> available. where <i>index</i> is the number of the selected trusted certificate.	A user tries to issue a command to remove or download a nonexistent trusted certificate.
No valid client certificate is in place. Type 'sslcfg -h' for syntax help of the SSLclient Certificate generation command.	A user tries to issue a command to enable the SSL client without a valid client certificate in place.
No valid server certificate is in place. Type 'sslcfg -h' for syntax help of the SSL server Certificate generation command.	A user tries to issue a command to enable the SSL server without a valid server certificate in place.
No valid trusted certificate is in place. Type 'sslcfg -h' for syntax help of the SSL trusted Certificate importing command.	A user tries to issue a command to enable the SSL client without a valid trusted certificate in place.
 Putting <i>filename</i> to tfpt server <i>ip_address</i> failed. where: <i>filename</i> identifies the command option <i>ip_address</i> identifies the IP address of the tftp server 	An error occurs while the management module is putting a file to the tftp server.
Update Failed, there was a problem retrieving the file.	An error occurs while the advanced management module is uploading a file.
Writing X509 format certificate to file failed.	An error occurs while the management module is writing the X509 format certificate to File.

syslog command errors

This topic lists errors for the syslog command.

Table 156. syslog command errors

Error message	Definition
Input length is greater than the maximum characters allowed.	A user tries to enter too many characters for an input field.
Invalid host name or ip address.	A user tries to enter an invalid hostname or ip address.
Port number out of range.	A user tries to enter an invalid port number.

tcpcmdmode command errors

This topic lists error messages for the tcpcmdmode command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 157. tcpcmdmode command errors

Error message	Definition
Error changing TCP command mode connection.	An error occurs while the management module is changing the TCP command mode Connection.
Error disabling tcpcmdmode.	An error occurs while the management module is disabling the TCP command mode.
Error enabling TCP command mode.	An error occurs while the management module is enabling the TCP command mode.
Invalid parameter. Input must be numeric.	A user tries to enter a parameter value for the -t (timeout) command option containing non-numeric characters. For example, tcpcmdmode -t 200m.
Invalid parameter. The timeout must be between 0 and 4294967295 seconds.	A user tries to enter a parameter value for the -t (timeout) command option that is outside of the valid range.
Maximum connections can not exceed <i>maximum</i> where <i>maximum</i> designates the total number of permitted connections.	A user attempted to configure more connections than the maximum number of connections supported.
No valid server certificate is in place for Secure TCP Command Mode. Use the sslcfg command to generate a certificate.	The user issues a command to enable the Secure TCP Command Mode when a valid server certificate is not in place.
The total number of secure and legacy connections of TCP Command Mode cannot exceed <i>maximum</i> where <i>maximum</i> designates the total number of permitted connections.	A user attempted to configure more TCP Command Mode connections than the maximum number of secure and legacy connections supported.
Warning: Communication with IBM Director via Secure TCP Command Mode has been disabled.	A user has disabled the Secure TCP command mode.
Warning: Communication with IBM Director via TCP Command Mode has been disabled.	A user has disabled the TCP command mode.

telnetcfg command errors

This topic lists error messages for the telnetcfg command.

Table 158. telnetcfg command errors

Error message	Definition
Invalid parameter. Input must be numeric.	A user tries to enter a Telnet timeout value containing non-numeric characters. For example, telnetcfg -t 200w.
Invalid parameter. The telnet timeout range must be less than 4294967295.	The user tries to enter a timeout value greater than 4294967295 seconds.

Table 158. telnetcfg command errors (continued)

Error message	Definition
Invalid parameter. The timeout must be between 0 and 4294967295 seconds.	A user tries to enter a Telnet timeout value that is out of range.

temps command errors

This topic lists errors for the temps command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 159. temps command errors

Error message	Definition
Blade <i>blade_number</i> : Too many SDRs found.	A database error occurs when too many SDRs are found.
where <i>blade_number</i> identifies the blade server.	
Getting power state of blade <i>blade_number</i> failed.	An error occurs while the management module is reading the power state of the specified blade server
where <i>blade_number</i> identifies the blade server.	reading the power state of the specified blade server.

thres command errors

This topic lists errors for the thres command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 160. threshold command errors

Error message	Definition
A duplicate option is found in the requested command.	The user tries to enter a duplicate argument.
Invalid threshold value.	The user tries to enter an invalid threshold value.
Unable to query the threshold request.	An error occurs during the query threshold request.
Unable to set the requested threshold.	An error occurs during the set threshold request.

trespass command errors

This topic lists error messages for the trespass command.

Table 161	. trespass	command	errors
-----------	------------	---------	--------

Error message	Definition
twe must be enabled to modify the trespassing warning.	The user tries to issue a command to modify the trespassing warning without the <i>-twe enabled</i> setting.
The trespassing warning must be quote-delimited.	The user tries to enter a trespassing warning that is not enclosed in double-quotation marks.
The trespassing warning is greater than 1600 characters.	The user tries to enter a trespassing warning that is longer than 1600 characters.

uicfg command errors

The following table lists error messages for the uicfg command.

Table 162. uicfg command errors

Error message	Definition
Enabling SNMPv1/v3 failed.	 The SNMPv1/v3 configuration does not meet required criteria. Possible configuration errors include: A community is configured without an IP address or host name. A duplicate community name is configured. At least one configured community is required to enable SNMPv1. IP address of 0.0.0.0 is allowed only for the first host name in the first community. IP address of 0.0.0.0 is allowed only when the first community is configured as GET or SET access type. System contact must be defined to enable SNMPv1/v3. System location must be defined to enable SNMPv1/v3.
Error sanity checking of SNMP configuration.	An error occurs while the management module is sanity-checking the SNMP configuration.
Maximum connections can not exceed <i>maximum</i> where <i>maximum</i> designates the total number of permitted connections.	A user has attempted to configure more connections than the maximum number of connections supported.
No valid server certificate is in place for Secure TCP Command Mode. Use the sslcfg command to generate a certificate.	The user issues a command to configure the Secure TCP Command Mode when a valid server certificate is not in place
Reading telnet/ssh/snmpv1/snmpv3 status failed.	An error occurs while the management module is reading the telnet, ssh, snmpv1, or snmpv3 status.
The total number of secure and legacy connections of TCP Command Mode cannot exceed <i>maximum</i> where <i>maximum</i> designates the total number of permitted connections.	A user attempted to configure more TCP Command Mode connections than the maximum number of secure and legacy connections supported.
Warning: Communication with IBM Director via Secure TCP Command Mode has been disabled.	A user has disabled the Secure TCP command mode.
Warning: Communication with IBM Director via TCP Command Mode has been disabled.	A user has disabled the TCP command mode.

update command errors

This topic lists error messages for the update command.

Table 163. update command erro	rs
--------------------------------	----

Error message	Definition
-r must be used with -u to update firmware to AMM and automatically reboot AMM if firmware update succeeds.	A user tries to enter a command with the -r option to update firmware to a primary advanced management module, but fails to include the -u option.
Cannot perform this command right now. The agent is not active.	A user tries to enter a command while the agent is not active.
Disabling failover failed.	An error occurs while the management module is turning off the automatic failover feature.
Error reading information for firmware image index.maximum	An error occurs while the management module is reading information for a specified firmware image.
where <i>index</i> specifies the firmware image.	
Error reading the number of firmware images.	An error occurs while the management module is reading the number of firmware images.
Flash operation failed.	An error occurs during the flash firmware update.
Flash operation failed status percentage	An error occurs during the flash firmware update.
where the <i>percentage</i> value varies based on when the problem was encountered.	
Flash operation not in process or status unavailable.	An error occurs during the flash firmware update.
Flash operation timed out <i>percentage</i> .	An error occurs during the flash firmware update.
where the <i>percentage</i> value varies based on when the problem was encountered.	
Flash preparation - error sending packet file <i>filename</i> .	An error occurs during the flash firmware update.
where <i>filename</i> identifies the file being updated.	
Flash preparation error. Packet percent complete <i>percentage</i> . Flash percent complete <i>percentage</i> .	An error occurs during the flash firmware update.
where the <i>percentage</i> value varies based on when the problem was encountered.	
Flash preparation error. Timeout on packet preparation operation <i>percentage</i> .	An error occurs during the flash firmware update.
where the <i>percentage</i> value varies based on when the problem was encountered.	
Flashing not supported on this target.	A user attempts to run the update command on a module that does not support flash firmware updates.
Getting data encryption setting failed. If data encryption is enabled and you are updating the firmware to a level which does not support data encryption, you will lose all your configuration settings as a result.	An error occurs while the management module is reading the data encryption setting.

Table 163. upda	ate command	errors	(continued)
-----------------	-------------	--------	-------------

Error message	Definition
Getting name of mm <i>bay_number</i> failed. where the <i>bay_number</i> identifies the management module specified.	An error occurs while the management module is reading the name of the management module in designated bay.
Invalid image index. Index must be less than <i>maximum</i> where <i>maximum</i> designates the largest permitted index value.	A user tries to enter an image index that is greater than the maximum permitted index value.
Invalid option.	 An invalid command option is entered. For the update command, invalid command option errors include: the -i (IP address) command option does not have an IP address parameter the -i (IP address) command option specifies an invalid IP address attempting to enter the -i (IP address) command option option without the -n (filename) command option the -n (filename) command option does not have a file name parameter attempting to enter the -n (filename) command option without the -i (IP address) command option the rempting to enter the -n (filename) command option without the -i (IP address) command option attempting to enter the -n (filename) command option without the -i (IP address) command option attempting to enter the -v (verbose) command option without the -i (IP address) command option and -n (filename) command option
Invalid syntax.	The user tries to execute a command without specifying a command option.
Management Module <i>bay_number</i> is not installed. where the <i>bay_number</i> identifies the management module specified.	The command is targeted to a management module bay where no management module is installed.
Rebooting AMM failed.	An error occurs while the advanced management module is trying to reboot.
Status: Unable to read status.	An error occurs while the management module is reading status.
 TFTP Error: error_code. where the error_code can have one of the following values: Access violation. Connection failure. Disk full or allocation exceeded. File already exists. File error. File error. File not found. Illegal option negotiation. Illegal TFTP operation. Unable to allocate memory. Unknown transfer ID. Unknown user. 	An error occurs when the user attempts to set up the TFTP connection.
where the <i>bay_number</i> and <i>name</i> identify the blade server by location and name.	rne command specifies an empty blade server bay or an error occurs when reading the VPD.

Table 163. update command errors (continued)

Error message	Definition
Unable to read I/O Module VPD bay <i>bay_number name</i> . where the <i>bay_number</i> and <i>name</i> identify the I/O module by location and name.	The command specifies an empty I/O-module bay or an error occurs when reading the VPD.
Unable to read MM VPD bay <i>bay_number name</i> . where the <i>bay_number</i> and <i>name</i> identify the management module by location and name.	The command specifies an empty management module bay or an error occurs when reading the VPD.
Unable to read VPD for Blade <i>blade_number name</i> . where the <i>blade_number</i> and <i>name</i> identify the blade server by location and name.	An error occurs while the management module is reading the VPD of the targeted blade server.
Unknown device type.	The command is targeted to an unknown device type.
Update error. Invalid destination.	A user tries to issue a command to a target that is not valid.
Update Failed, there was a problem retrieving the file.	The management module was unable to complete the update because it was unable to retrieve the file from the TFTP server.

uplink command errors

This topic lists error messages for the uplink command.

Table	164.	uplink	command	errors
-------	------	--------	---------	--------

Error message	Definition
-ip must be a valid IP address before enabling -el	A user tries to issue a command to enable the -el without a valid -ip setting.
A non-zero IP address must be set before enabling -el.	A user tries to enable -el while both -ip and -ip6 are zero.
At least one IP address must be non-zero when -el is enabled.	A user tries to set both -ip and -ip6 to zero while -el is enabled.
Error converting the IPv6 address from string to bytes.	An error occurs while converting the IPv6 address from a string to bytes.
Getting status of failver on Lose/Logical of Physical Link failed.	An error occurs while the management module is reading status of failver on Lose/Logical of Physical Link.
Invalid uplink delay value.	A user tries to enter a delay value that is less than 1 or greater than 255. For example, uplink -del 0.
No option argument for <i>option</i> where <i>option</i> is the command option for which no argument was specified.	A user tries to enter a command option without its required argument.
The option argument for <i>option</i> is out of the valid range (between 1 and 2880 minutes).	The user input for an option is out of the range.
where <i>option</i> is the number of minutes specified.	

Table 164. uplink command errors (continued)

Error message	Definition
The option argument for <i>option</i> is out of the valid range (between 10 and 172800 seconds).	The user input for an option is out of the range.
where <i>option</i> is the number of seconds specified.	

users command errors

This topic lists error messages for the users command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 165. users command errors

Error message	Definition
-af contains invalid characters. Only alphanumeric, comma, asterisk, question mark, hyphen, period, and exclamation point characters are valid.	The user input for the -af option is invalid.
-af must start with from=.	The user input for the -af option is invalid.
-cm is greater than 255 characters.	The user input for the -cm option exceeds the maximum.
-cm must be quote-delimited.	The user input for the -cm option is not quote-delimited.
An entry cannot be modified and deleted in the same command.	A user tries to simultaneously modify and delete a user in the same command.
Arguments containing spaces must be enclosed in quotation marks.	A user tries to enter a context name containing spaces that does not have opening and closing quotation marks.
Deleting user failed.	An error occurs while the management module is deleting an user.
Error converting RBS permissions.	An error occurs while the management module is converting permissions data to the role-based security (RBS) format.
Error creating user.	An error occurs while the management module is creating a user.
Error creating user: The authentication protocol cannot be none because the security settings require passwords.	The user tries to issue a command to create a user with no authentication protocol when the security settings require passwords.
Error reading certificate details.	An error occurs while the management module is reading certificate details.
Error reading key.	An error occurs while the management module is reading the key.
Error setting the access type.	An error occurs while the management module is setting the access type.
Error setting the authentication protocol.	An error occurs while the management module is setting the authentication protocol.
Error setting the authority level.	An error occurs while the management module is setting the authority level.
Error setting the context name.	An error occurs while the management module is setting the context name.
Error setting the hostname/IP address.	An error occurs while the management module is setting the hostname or IP address.

Table 165. users command errors (continued)

Error message	Definition	
Error setting the password.	An error occurs while the management module is setting the password.	
Error setting the password. The new password is not compliant.	The user tries to issue a command to set the new password which is not compliant.	
Error setting the privacy password.	An error occurs while the management module is setting the privacy password.	
Error setting the privacy protocol.	An error occurs while the management module is setting the privacy protocol.	
Error setting the username.	An error occurs while the management module is setting the username.	
Error transferring file.	An error occurs while the management module is transferring file.	
File transfer failed.	An error occurs while transferring a file during file upload.	
Getting a summary of all keys of user <i>index</i> failed.	An error occurs while the management module is	
where the <i>index</i> value varies based on the problem that was encountered.	reading a summary of all keys of the targeted user.	
Getting authority level of user <i>index</i> failed.	An error occurs while the management module is	
where the <i>index</i> value varies based on the problem that was encountered.	reading authority level of the targeted user.	
Getting role-based security level of user <i>index</i> failed.	An error occurs while the management module is	
where the <i>index</i> value varies based on the problem that was encountered.	reading role-based security level of the targeted user.	
Incorrect login permission option: permission	A user tries to specify an invalid login permission for the	
where the <i>permission</i> value varies based on the problem that was encountered.	-a command option.	
Invalid argument. Valid arguments for -at are read, write, and traps.	A user tries to set an invalid argument for the -at command option.	
Invalid argument. Valid choices are des or <none>.</none>	A user tries to set an invalid argument for the -pp command option.	
Invalid argument. Valid choices are md5, sha, or <none>.</none>	A user tries to set an invalid argument for the -ap command option.	
Invalid authority level.	This error message indicates one of the following errors:A user tries to set an authority level that is invalid.A user tries to set a custom authority level without specifying any customization information.	
Invalid device number (first number must be smaller): <i>device_A-device_B</i> .	A user specifies an invalid device range while trying to create or modify a user.	
where <i>device_A</i> and <i>device_B</i> identify the ends of the invalid device range being specified.		
Invalid device number: <i>device_number</i> .	A user provides a device number that is out of range	
where <i>device_number</i> identifies the device number that is invalid.	while trying to create or modify a user.	
Invalid hostname or ip address.	A user tries to set an invalid host name or IP address for the -i command option.	

Table 165. users command errors (continued)

Error message	Definition
Invalid key index for this command.	The user input for index is invalid.
Invalid rbs device: <i>device</i> .	A user specifies an invalid device while trying to create or modify a user.
where <i>device</i> identifies the device that is invalid.	
Invalid rbs device: Must specify device number	A user specifies an invalid device number while trying to create or modify a user.
Invalid rbs device list.	A user does not specify a device list while trying to create or modify a user.
Invalid rbs device (must be same device): <i>device</i> .	A user specifies an invalid device while trying to create or modify a user.
where <i>device</i> identifies the device that is invalid.	
Invalid rbs role: <i>role</i> .	A user specifies an invalid role while trying to create or modify a user.
where <i>role</i> identifies the role that is invalid.	
Invalid rbs role list.	A user fails to specify a role list while trying to modify or create a user.
Invalid username. The username can only contain numbers, letters, dots, and underscores.	The user tries to enter The username that contains invalid characters. Valid characters that can be used in a username are letters, numbers, periods (.), and underscores ($_$).
Max retries changing password reached.	The user tries to issue a command to change a password after the max retries of changing password limit is reached.
Must be set at least one rbs role for this user.	The user tries to issue a command to create a user without the rbs role settings.
Old password is incorrect.	The user tries to issue a command to change a password with an incorrect old password.
Old password must be specified by long option op.	The user tries to issue a command to change a password without the -op option.
Specify your new password with '-p' option.	The user tries to issue a command to change a password without the -p option.
Syntax errora option must have an argument.	A user tries to attempt to enter the command with an -a command option that has no argument.
Syntax errorat option must have an argument.	A user tries to attempt to enter the command with an -at command option that has no argument.
Syntax errorcn option must have an argument.	A user tries to attempt to enter the command with a -cn command option that has no argument.
Syntax errori option must have an argument.	A user tries to attempt to enter the command with an -i command option that has no argument.
Syntax errorn option must have an argument.	A user tries to attempt to enter the command with an -n command option that has no argument.
Syntax errorppw option must have an argument.	A user tries to attempt to enter the command with a -ppw command option that has no argument.
Syntax error. Multiple -a options found.	A user tries to enter the <i>-a</i> command option in a single command multiple times.
Syntax error. Multiple -ap options found.	A user tries to enter the -ap option flag in a single command multiple times.
Syntax error. Multiple -at options found.	A user tries to enter the -at option flag in a single command multiple times.

Table 165. users command errors (continued)

Error message	Definition
Syntax error. Multiple -cn options found.	A user tries to enter the -cn option flag in a single command multiple times.
Syntax error. Multiple -i options found.	A user tries to enter the -i option flag in a single command multiple times.
Syntax error. Multiple -n options found.	A user tries to enter the -n option flag in a single command multiple times.
Syntax error. Multiple -p options found.	A user tries to enter the -p option flag in a single command multiple times.
Syntax error. Multiple -pp options found.	A user tries to enter the -pp option flag in a single command multiple times.
Syntax error. Multiple -ppw options found.	A user tries to enter the -ppw option flag in a single command multiple times.
Syntax error. Type users -h for help.	A user tries to set an invalid value for a command option.
The context name must be less than 32 characters long.	A user tries to set a context name that is longer than 31 characters.
The -i and -l options must both be specified when using -upld.	The user tries to issue a -upld command without -i and -1.
The accept_from_string must be quote-delimited.	The user input for the -af option is not quote-delimited.
The key is greater than 6000 bytes.	The user input for the key exceeds the maximum.
The password must be at least 5 characters long, but no more than 15 characters long.	The user tries to enter a password that is too short or too long.
The password must contain at least one alphabetic and one non-alphabetic character.	The user tries to enter a password that does not have at least one alphabetic and one non-alphabetic character.
The privacy password must also be set when setting the privacy protocol.	Displays if the user tries to set the privacy protocol to des without a specifying a privacy password (-ppw command option).
The privacy password must be less than 32 characters long.	A user tries to set a privacy password that is longer than 31 characters.
The user index must be different than that of the current user.	The user tries to issue a command to delete the account of current user.
The username cannot be longer than 15 characters.	A user tries to set a user name that is longer than 15 characters.
There was a problem retrieving the file.	An error occurs while the management module is retrieving the file.
Unable to change password. The minimum password change interval has not expired. Please try again later.	The user tries to issue a command to change a password while the minimum password change interval has not expired.
Unable to read the complex password requirement.	An error occurs while the management module is reading the complex password requirement.
Unable to read the password required setting.	An error occurs while the management module is reading the password required setting.
Unexpected error: Unable to change password.	An error occurs while the management module is changing the password.
Update Failed, there was a problem retrieving the file.	An error occurs while the advanced management module is uploading a file.

Table 165. users command errors (continued)

Error message	Definition
When creating a new user, a username and authority level must be specified.	The user tries to issue a command to create a user without the -n and -a options.
When creating a new user, all options are required.	A user tries to create a new user without defining all of the command options and arguments.

vlan command errors

This topic lists error messages for the vlan command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 166. vlan command errors

Error message	Definition	
Error reading vlan config.	An error occurs while the management module is reading the global VLAN settings.	
Error reading vlan entry <i>index</i> .	An error occurs while the management module is	
where <i>index</i> is the VLAN entry's index.	reading a versivenity's settings.	
Name must be enclosed in quotation marks.	A user attempts to enter a name that does not have opening and closing quotation marks.	
Invalid syntaxcommit must be used by itself.	A user issues a command with -commit option inclusive of an argument or other options.	
Invalid syntaxcto must be used by itself.	A user issues a command with -cto option inclusive of other options.	
Invalid syntax. restart and default can only be used on individual, non-fixed entries.	A user attempts to use the restart or default on a fixed entry or global VLAN settings.	
Invalid syntaxdelete must be used by itself, or in combination with -vi.	A user issues a command with -delete option inclusive of other options, except for -vi.	
Error deleting vlan entry <i>index</i> .	An error occurs while the management module is	
where <i>index</i> is the VLAN entry's index.	deleting a VLAN entry.	
Invalid syntaxstate cannot be used on the fixed entry.	A user attempts to use -state on a fixed entry.	
Invalid syntaxc cannot be used on the fixed entry.	A user attempts to use -c on a fixed entry.	
Invalid syntaxi cannot be used on the fixed entry.	A user attempts to use -i on a fixed entry.	
Invalid syntaxg cannot be used on the fixed entry.	A user attempts to use -g on a fixed entry.	
Invalid syntaxs cannot be used on the fixed entry.	A user attempts to use -s on a fixed entry.	
Invalid syntaxsr1 cannot be used on the fixed entry.	A user attempts to use -sr1 on a fixed entry.	
Invalid syntaxsr2 cannot be used on the fixed entry.	A user attempts to use -sr2 on a fixed entry.	
Invalid syntaxsr3 cannot be used on the fixed entry.	A user attempts to use -sr3 on a fixed entry.	
Invalid syntaxsm1 cannot be used on the fixed entry.	A user attempts to use -sm1 on a fixed entry.	
Invalid syntaxsm2 cannot be used on the fixed entry.	A user attempts to use -sm2 on a fixed entry.	
Invalid syntaxsm3 cannot be used on the fixed entry.	A user attempts to use -sm3 on a fixed entry.	
Invalid syntaxtag cannot be used on non-default entries.	A user attempts to set the -tag option on a non-default entry.	

Table 166. vlan command errors (continued)

Error message	Definition
Invalid syntaxvid is needed to create a new entry.	A user attempts to create a new entry without specifying the -vid option.
Error writing -sol - currently assigned to another VLAN.	A user attempts to enable the -sol option on a VLAN entry without disabling it on another VLAN entry first.
Error writing -rp - currently assigned to another VLAN.	A user attempts to enable the -rp option on a VLAN entry without disabling it on another VLAN entry first.
Cannot enable VLAN - configuration incomplete.	A user attempts to enable a VLAN entry before configuring it completely.
Error writing -vid - the VLAN ID is a duplicate.	A duplicate VLAN ID is entered.
Error writing -i - the IP address is either a duplicate, or in the same subnet as another entry	A duplicate IP address is entered.

volts command errors

This topic lists errors for the volts command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 167. volts command errors

Error message	Definition
Getting power state of blade <i>blade_number</i> failed.	An error occurs while the management module is
where <i>blade_number</i> identifies the blade server.	reading the power state of the targeted blade server.

write command errors

This topic lists error messages for the write command.

See "Common errors" on page 421 for a list of error messages that apply to all commands.

Table 168. write command errors

Error message	Definition
Failed to save configuration settings to the chassis.	An error occurs while the management module is saving the management module configuration to the BladeCenter unit midplane.
Firmware update is in progress. Try again later.	A user tries to save the management module configuration to the BladeCenter unit midplane while the management module firmware is updating.
Getting security status failed.	An error occurs while the management module is reading the security status.
The -config option is required.	The user does not include a required -config option for the command.
The -i, -l, and -p options can only be used with the -config file.	The user tries to specify a TFTP server and a configuration file when saving the configuration to the BladeCenter unit midplane.
The -i option is required with the -config file.	A user tries to use the -i option with the -config chassis option.

Table 168. write command errors (continued)

Error message	Definition
The -p option is required when encryption is enabled.	The user tries to issue a command without the -p option while encryption is enabled.
Error creating file in memory.	The management module is unable to create the configuration file.
Error locking file.	The management module is unable to lock the configuration file.
Error opening file.	The management module is unable to open the configuration file.
Error transferring file.	The management module is unable to transfer the configuration file.
Error generating file.	The management module is unable to generate the configuration file.
Error allocating memory for file.	The management module is unable to allocate memory for the configuration file.
The passphrase is greater than 1600 characters.	The user input for the passphrase exceeds the maximum permitted length.
The passphrase must be quote-delimited.	The user input for the passphrase is not quote-delimited.

zonecfg command errors

This topic lists errors for the zonecfg command.

Table 169. zonecfg command errors

Error message	Definition	
Activating zone configuration xxx on I/O module yyy failed.	The management module is unable activate the specified zone configuration on the specified I/O module.	
Getting current active zone number failed.	An error occurs while the management module is reading the current active zone number.	
Getting specified configuration of switch <i>slot</i> failed. where <i>slot</i> identifies the targeted I/O module.	An error occurs while the management module is reading the specified configuration of the targeted I/O module.	
Getting zone configuration failed.	An error occurs while the management module is reading the zone configuration.	
Invalid slot number for this command.	The I/O module is not in slot 3 or 4.	
The index must be 32 or less.	The configuration index is bigger than 32.	
Zone configuration not supported on this switch type.	The user tries to use this command on a non-SAS switch module.	
The I/O Module is currently not powered on or in a fault state.	The user tries to show or activate a zone configuration for an RSS or NSS which is in the power-off state and a fault state.	
Error retrieving data for I/O module <i>bay_number</i> . where <i>bay_number</i> identifies the targeted I/O module.	An error occurs while the management module is reading the data for the specified I/O module.	

Appendix. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about IBM products, you will find a wide variety of sources available from IBM to assist you.

Use this information to obtain additional information about IBM and IBM products, determine what to do if you experience a problem with your IBM system or optional device, and determine whom to call for service, if it is necessary.

Before you call

Before you call, make sure that you have taken these steps to try to solve the problem yourself.

If you believe that you require IBM to perform warranty service on your IBM product, the IBM service technicians will be able to assist you more efficiently if you prepare before you call.

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Check for updated firmware and operating-system device drivers for your IBM product. The IBM Warranty terms and conditions state that you, the owner of the IBM product, are responsible for maintaining and updating all software and firmware for the product (unless it is covered by an additional maintenance contract). Your IBM service technician will request that you upgrade your software and firmware if the problem has a documented solution within a software upgrade.
- If you have installed new hardware or software in your environment, check http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/ to make sure that the hardware and software is supported by your IBM product.
- Go to http://www.ibm.com/supportportal/ to check for information to help you solve the problem.
- Gather the following information to provide to IBM Support. This data will help IBM Support quickly provide a solution to your problem and ensure that you receive the level of service for which you might have contracted.
 - Hardware and Software Maintenance agreement contract numbers, if applicable
 - Machine type number (IBM 4-digit machine identifier)
 - Model number
 - Serial number
 - Current system UEFI and firmware levels
 - Other pertinent information such as error messages and logs
- Go to http://www.ibm.com/support/entry/portal/Open_service_request/ to submit an Electronic Service Request. Submitting an Electronic Service Request will start the process of determining a solution to your problem by making the pertinent information available to IBM Support quickly and efficiently. IBM service technicians can start working on your solution as soon as you have completed and submitted an Electronic Service Request.

You can solve many problems without outside assistance by following the troubleshooting procedures that IBM provides in the online help or in the documentation that is provided with your IBM product. The documentation that comes with IBM systems also describes the diagnostic tests that you can perform. Most systems, operating systems, and programs come with documentation that contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

Using the documentation

Information about your IBM system and preinstalled software, if any, or optional device is available in the documentation that comes with the product. That documentation can include printed documents, online documents, readme files, and help files.

See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates. To access these pages, go to http://www.ibm.com/supportportal/.

Getting help and information from the World Wide Web

Up-to-date information about IBM products and support is available on the World Wide Web.

On the World Wide Web, up-to-date information about IBM systems, optional devices, services, and support is available at http://www.ibm.com/supportportal/. IBM System x information is at http://www.ibm.com/systems/x/. IBM BladeCenter information is at http://www.ibm.com/systems/bladecenter/. IBM IntelliStation information is at http://www.ibm.com/systems/intellistation/.

How to send DSA data to IBM

Use the IBM Enhanced Customer Data Repository to send diagnostic data to IBM.

Before you send diagnostic data to IBM, read the terms of use at http://www.ibm.com/de/support/ecurep/terms.html.

You can use any of the following methods to send diagnostic data to IBM:

- Standard upload: http://www.ibm.com/de/support/ecurep/send_http.html
- Standard upload with the system serial number: http://www.ecurep.ibm.com/
- Secure upload: http://www.ibm.com/de/support/ecurep/ send_http.html#secure
- Secure upload with the system serial number: https://www.ecurep.ibm.com/

Creating a personalized support web page

You can create a personalized support web page by identifying IBM products that are of interest to you.

To create a personalized support web page, go to http://www.ibm.com/support/ mynotifications/. From this personalized page, you can subscribe to weekly email notifications about new technical documents, search for information and downloads, and access various administrative services.

Software service and support

Through IBM Support Line, you can get telephone assistance, for a fee, with usage, configuration, and software problems with your IBM products.

For information about which products are supported by Support Line in your country or region, see http://www.ibm.com/services/supline/products/.

For more information about Support Line and other IBM services, see http://www.ibm.com/services/ or see http://www.ibm.com/planetwide/ for support telephone numbers. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

Hardware service and support

You can receive hardware service through your IBM reseller or IBM Services.

To locate a reseller authorized by IBM to provide warranty service, go to http://www.ibm.com/partnerworld/ and click **Find Business Partners** on the right side of the page. For IBM support telephone numbers, see http://www.ibm.com/planetwide/. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

In the U.S. and Canada, hardware service and support is available 24 hours a day, 7 days a week. In the U.K., these services are available Monday through Friday, from 9 a.m. to 6 p.m.

IBM Taiwan product service

Use this information to contact IBM Taiwan product service.



IBM Taiwan product service contact information:

IBM Taiwan Corporation 3F, No 7, Song Ren Rd. Taipei, Taiwan Telephone: 0800-016-888

Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing IBM Corporation North Castle Drive Armonk, NY 10504-1785 U.S.A.

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product, and use of those websites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Trademarks

IBM, the IBM logo, and ibm.com are trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies.

A current list of IBM trademarks is available on the web at "Copyright and trademark information" at http://www.ibm.com/legal/copytrade.shtml.

Adobe and PostScript are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Cell Broadband Engine is a trademark of Sony Computer Entertainment, Inc., in the United States, other countries, or both and is used under license therefrom.

Intel, Intel Xeon, Itanium, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Java and all Java-based trademarks and logos are trademarks or registered trademarks of Oracle and/or its affiliates.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Important notes

Processor speed indicates the internal clock speed of the microprocessor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1024 bytes, MB stands for 1,048,576 bytes, and GB stands for 1,073,741,824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1,000,000 bytes, and GB stands for 1,000,000 bytes. Total user-accessible capacity can vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard disk drive bays with the largest currently supported drives that are available from IBM.

Maximum memory might require replacement of the standard memory with an optional memory module.

Each solid-state memory cell has an intrinsic, finite number of write cycles that the cell can incur. Therefore, a solid-state device has a maximum number of write cycles that it can be subjected to, expressed as "total bytes written" (TBW). A device that has exceeded this limit might fail to respond to system-generated commands or might be incapable of being written to. IBM is not responsible for replacement of a device that has exceeded its maximum guaranteed number of program/erase cycles, as documented in the Official Published Specifications for the device.

IBM makes no representation or warranties regarding non-IBM products and services that are ServerProven[®], including but not limited to the implied warranties of merchantability and fitness for a particular purpose. These products are offered and warranted solely by third parties.

IBM makes no representations or warranties with respect to non-IBM products. Support (if any) for the non-IBM products is provided by the third party, not IBM.

Some software might differ from its retail version (if available) and might not include user manuals or all program functionality.

Particulate contamination

Attention: Airborne particulates (including metal flakes or particles) and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the device that is described in this document.

Risks that are posed by the presence of excessive particulate levels or concentrations of harmful gases include damage that might cause the device to malfunction or cease functioning altogether. This specification sets forth limits for particulates and gases that are intended to avoid such damage. The limits must not be viewed or used as definitive limits, because numerous other factors, such as temperature or moisture content of the air, can influence the impact of particulates or environmental corrosives and gaseous contaminant transfer. In the absence of specific limits that are set forth in this document, you must implement practices that maintain particulate and gas levels that are consistent with the protection of human health and safety. If IBM determines that the levels of particulates or gases in your environment have caused damage to the device, IBM may condition provision of repair or replacement of devices or parts on implementation of appropriate remedial measures to mitigate such environmental contamination. Implementation of such remedial measures is a customer responsibility.

Contaminant	Limits
Particulate	• The room air must be continuously filtered with 40% atmospheric dust spot efficiency (MERV 9) according to ASHRAE Standard 52.2 ¹ .
	• Air that enters a data center must be filtered to 99.97% efficiency or greater, using high-efficiency particulate air (HEPA) filters that meet MIL-STD-282.
	• The deliquescent relative humidity of the particulate contamination must be more than 60% ² .
	• The room must be free of conductive contamination such as zinc whiskers.
Gaseous	 Copper: Class G1 as per ANSI/ISA 71.04-1985³ Silver: Corrosion rate of less than 300 Å in 30 days
1. ASHRAE 52	.2-2008 - Method of Testing General Ventilation Air-Cleaning Devices for

Table 170. Limits for particulates and gases

 ASHRAE 52.2-2008 - Method of Testing General Ventilation Air-Cleaning Devices for Removal Efficiency by Particle Size. Atlanta: American Society of Heating, Refrigerating and Air-Conditioning Engineers, Inc.

2. The deliquescent relative humidity of particulate contamination is the relative humidity at which the dust absorbs enough water to become wet and promote ionic conduction.

 ANSI/ISA-71.04-1985. Environmental conditions for process measurement and control systems: Airborne contaminants. Instrument Society of America, Research Triangle Park, North Carolina, U.S.A.

Documentation format

The publications for this product are in Adobe Portable Document Format (PDF) and should be compliant with accessibility standards. If you experience difficulties when you use the PDF files and want to request a web-based format or accessible PDF document for a publication, direct your mail to the following address:

Information Development IBM Corporation 205/A015 3039 E. Cornwallis Road P.O. Box 12195 Research Triangle Park, North Carolina 27709-2195 U.S.A.

In the request, be sure to include the publication part number and title.

When you send information to IBM, you grant IBM a nonexclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

Telecommunication regulatory statement

This product may not be certified in your country for connection by any means whatsoever to interfaces of public telecommunications networks. Further certification may be required by law prior to making any such connection. Contact an IBM representative or reseller for any questions.

Electronic emission notices

When you attach a monitor to the equipment, you must use the designated monitor cable and any interference suppression devices that are supplied with the monitor.

Federal Communications Commission (FCC) statement

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that might cause undesired operation.

Industry Canada Class A emission compliance statement

This Class A digital apparatus complies with Canadian ICES-003.

Avis de conformité à la réglementation d'Industrie Canada

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Australia and New Zealand Class A statement

Attention: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

European Union EMC Directive conformance statement

This product is in conformity with the protection requirements of EU Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a nonrecommended modification of the product, including the fitting of non-IBM option cards.

Attention: This is an EN 55022 Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Responsible manufacturer:

International Business Machines Corp. New Orchard Road Armonk, New York 10504 914-499-1900

European Community contact:

IBM Deutschland GmbH Technical Regulations, Department M372IBM-Allee 1, 71139 Ehningen, Germany Telephone: +49 7032 15 2941Email: lugi@de.ibm.com

Germany Class A statement

Deutschsprachiger EU Hinweis: Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2004/108/EG zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022 Klasse A ein. Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung der IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung der IBM gesteckt/eingebaut werden.

EN 55022 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden: "Warnung: Dieses ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funk-Störungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen zu ergreifen und dafür aufzukommen."

Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten

Dieses Produkt entspricht dem "Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG)". Dies ist die Umsetzung der EU-Richtlinie 2004/108/EG in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) (bzw. der EMC EG Richtlinie 2004/108/EG) für Geräte der Klasse A

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Einhaltung der EMV Vorschriften ist der Hersteller:

International Business Machines Corp. New Orchard Road Armonk, New York 10504 914-499-1900

Der verantwortliche Ansprechpartner des Herstellers in der EU ist:

IBM Deutschland GmbH Technical Regulations, Abteilung M372 IBM-Allee 1, 71139 Ehningen, Germany Telephone: +49 7032 15 2941 Email: lugi@de.ibm.com

Generelle Informationen:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 Klasse A.

Japan VCCI Class A statement

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用する と電波妨害を引き起こすことがあります。この場合には使用者が適切な対策 を講ずるよう要求されることがあります。 VCCI-A This is a Class A product based on the standard of the Voluntary Control Council for Interference (VCCI). If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.

Korea Communications Commission (KCC) statement

이 기기는 업무용(A급)으로 전자파적합기기로 서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목 적으로 합니다.

This is electromagnetic wave compatibility equipment for business (Type A). Sellers and users need to pay attention to it. This is for any areas other than home.

Russia Electromagnetic Interference (EMI) Class A statement

ВНИМАНИЕ! Настоящее изделие относится к классу А. В жилых помещениях оно может создавать радиопомехи, для снижения которых необходимы дополнительные меры

People's Republic of China Class A electronic emission statement



Taiwan Class A compliance statement

警告使用者: 這是甲類的資訊產品,在 居住的環境中使用時,可 能會造成射頻干擾,在這 種情況下,使用者會被要 求採取某些適當的對策。

Index

Special characters

! 168 ? 166

Α

accessibility features for this product 2 accessible documentation 496 account inactivity alert time set for management module 34 account inactivity disable time set for management module 35 account lockout period set for management module 36 account security commands 30 account security settings display for management module 30 enable complex password for management module user authentication 33 enable default administration password expiration for management module 34 enable password change at first login to management module 36 enable password required for management module 37 set management module account inactivity alert time 34 set management module account inactivity disable time 35 set management module account lockout period 36 set management module authentication logging timeout 32 set management module CLI inactivity timeout 33 set management module default to high 32 set management module default to legacy 31 set management module maximum LDAP sessions for user 36 set management module maximum number of login failures 35 set management module minimum number of different characters for password 34 set management module password expiration time 37 set management module password minimum change interval 37 set management module password reuse cycle 38 set management module user authentication method 33 set management module web interface inactivity timeout 38 accseccfg 30

accseccfg (continued) options alt 32 am 33 cp, on 33 ct 33 dc 34 de, on 34 high 32 ia 34 35 ici id 35 31 legacy lf 35 lp 36 mls 36 pc, on 36 pe 37 pi 37 pr, on 37 rc 38 wt 38 accseccfg command errors 423 accseccfg commands 30 example 38 accumulate timeout set for SOL 332 acknowledge alarms alarm ID 46 complete alarm key 46 generator ID 45 generator information 45 acknowledge call-home activity log entry management module 94 acoustic mode, disable 153 acoustic mode, enable 153 activate firmware I/O module 369, 373 switch 369, 373 activate I/O module SAS zone 415 activate network protocol settings I/O module 241 activate SAS zone I/O module 415 Active Directory group, delete 161 Active Directory group, set authority level 160 Active Directory group, set name 159 Active Directory groups, display (all) 159 Active Directory groups, display (specific) 159 add Call Home events management module 140, 141 add feature license management module 144 add firmware build ID list entry blade server 81 add SSH public key 394 add SSH public key (specific) 394

additional SSL certificate disable for standby management module 339 enable for standby management module 339 address IPv6 initial connection 15 link local 15 address prefix length set for blade server 190 set for channel 0 of management module 180 set for I/O module 198 advanced failover settings disable network interface for standby management module 40 display for management module 40 enable network interface for standby management module and allow IP swap during failover 40 enable network interface for standby management module and prevent IP swap during failover 41 advanced management module disable logical uplink failover 376 enable logical uplink failover 376 enable physical uplink failover 375 logical uplink failover delay 376 logical uplink failover IP address 376 logical uplink failover IPv6 IP address 377 network interface management commands 66 physical uplink failover delay 375 set logical link loss alert and failover policy 377 advfailover 40 options ip. noswap 41 ip. off 40 ip. swap 40 advfailover command 40 example 41 advfailover command errors 424 air filter set notification interval 42 view notification interval 42 air filter notification 42 airfilter example 42 management module 42 airfilter command 0, 1, 3, 6 months 42 notification interval 42 alarm acknowledge (alarm ID) 46 acknowledge (complete alarm key) 46 acknowledge (generator ID) 45 acknowledge (generator information) 45

alarm (continued) clear (alarm ID) 48 clear (complete alarm key) 48 clear (generator ID) 47 clear (generator information) 47 display (alarm ID) 44 display (all) 43 display (complete alarm key) 44 display (generator ID) 43 display (generator information) 44 display (power) 43 options c, a 48 c, g 47 c, k 48 c, o 47 p 43 q 43 q, a 44 q, g 43 q, k 44 q, o 44 r, a 46 r, g 45 r, k 46 r, o 45 s,1 49 set 49 alarm command 43 alarm command errors 425 alarm commands example 49 alarm panel command target 135 alarm panel module power off 272 power on 272 turn off 272 turn on 272 alert test 58 alert categories (enhanced legacy) disable 229 enable 229 alert notification method, set 57 alert recipient, create 54 alert recipient, delete 53 alert recipient, set email address 57 alert recipient, set hostname for alerts 58 alert recipient, set IP address for alerts 58 alert recipient, set name 55 alert recipient, set status 56 alert recipients, manage 53 alert state display all 229 alert type, filter 56 alert type, set 56 alertcfg 51 options dr 51 rl 51, 52 si 51 alertcfg command errors 426 alertcfg commands 51 example 52

alertentries 53 options 1 through 12 53 create (n, status, f, t, e, i) 54 del 53 e 57 f 56 i 58 n 55 status 56 t 57 test 58 alertentries command 53 alertentries command errors 426 alertentries commands example 59 alerts disable monitoring for all critical 229 disable monitoring for all informational 234 disable monitoring for all warning 232 disable monitoring for blade device critical 230 disable monitoring for blade device informational 235 disable monitoring for blade device warning 232 disable monitoring for chassis critical 231 disable monitoring for chassis informational 236 disable monitoring for chassis warning 233 disable monitoring for cooling device critical 231 disable monitoring for cooling device informational 238 disable monitoring for cooling device warning 234 disable monitoring for event log informational 237 disable monitoring for event log warning 233 disable monitoring for I/O module critical 230 disable monitoring for I/O module informational 235 disable monitoring for I/O module warning 232 disable monitoring for inventory change informational 236 disable monitoring for network change informational 237 disable monitoring for power module critical 231 disable monitoring for power module informational 238 disable monitoring for power module warning 234 disable monitoring for power state informational 236 disable monitoring for storage module critical 230 disable monitoring for storage module informational 235

alerts (continued) disable monitoring for storage module warning 233 disable monitoring for system management critical 231 disable monitoring for system management informational 236 disable monitoring for system management warning 233 disable monitoring for user activity informational 237 display all states 229 enable monitoring for all critical 229 enable monitoring for all informational 234 enable monitoring for all warning 232 enable monitoring for blade device critical 230 enable monitoring for blade device informational 235 enable monitoring for blade device warning 232 enable monitoring for chassis critical 231 enable monitoring for chassis informational 236 enable monitoring for chassis warning 233 enable monitoring for cooling device critical 231 enable monitoring for cooling device informational 238 enable monitoring for cooling device warning 234 enable monitoring for event log informational 237 enable monitoring for event log warning 233 enable monitoring for I/O module critical 230 enable monitoring for I/O module informational 235 enable monitoring for I/O module warning 232 enable monitoring for inventory change informational 236 enable monitoring for network change informational 237 enable monitoring for power module critical 231 enable monitoring for power module informational 238 enable monitoring for power module warning 234 enable monitoring for power state informational 236 enable monitoring for storage module critical 230 enable monitoring for storage module informational 235 enable monitoring for storage module warning 233 enable monitoring for system management critical 231 enable monitoring for system management informational 236

alerts (continued) enable monitoring for system management warning 233 enable monitoring for user activity informational 237 exclude service information with email alerts 51 include service information with email alerts 51 alerts, display 164 timestamp 164 algorithms, encryption 14 all information reload 204 assistance, getting 489 attributes, display for firmware 365 Australia Class A statement 497 authentication logging timeout set for management module 32 authentication method LDAP 217 authority, command 8 autoftp options desc 60 i 61 m 61 p 61 pw 61 u 61 autoftp command errors 427 autoftp commands 60 example 62 autoftp settings call-home 60, 61 automatic configuration setting display for management module 280 automatic power-on policy set for BladeCenter unit 275

В

battery backup unit command target 134 baud rate set for serial port of management module 253 bay data blade server 63 clear bay data 63 clear bay data for specific bay 64 display bay data 63 display bay data for specific bay 63 set bay data 64 set data definition to specific blade server 65 baydata 63 options b bay_num 63 b bay_num -clear 64 b bay_num -data "data_definition" 65 clear 63 data "data_definition" 64 baydata command errors 427 baydata commands 63 example 65

binding method LDAP 217 blade mezzanine command target 133 blade server 185, 186 add firmware build ID list entry 81 all blade servers 78 bay data 63 boot 72 boot (to console) 72 collect service data 301 command target 132 config command 111, 114 example 114 create firmware build ID list 80 cycle power 72, 273 delete all entries from firmware build ID list 84 delete entry from firmware build ID list 85 dhcpinfo commands 117 disable cKVM 185 disable DHCPv6 191 disable Ethernet channel 190 disable IPv6 190 disable IPv6 stateless auto-configuration 191 display all SRC records 124 display bay data 63 display boot mode 74 display boot sequence 75 display cKVM status 184 display Ethernet-over-USB setting 137 display firmware build IDs 80 display management network DHCP configuration 117 display name 111 display network configuration status 184 display power state 273 display service data 301 display specific SRC record 124 display temperature 357 display voltage 412 dump service data 301 enable cKVM 185 enable DHCPv6 configuration 191 enable dynamic power optimizer 155 enable dynamic power optimizer, extended 156 enable Ethernet channel 189 enable IPv6 190 enable IPv6 stateless auto-configuration 191 enable local power control 275 enable power capping 154 enable power management 154 enable power saver mode 155 enable Wake on LAN 274 export firmware build ID list 86 get service data 301 import firmware build ID list 85 power off 272, 273 power on 272, 273 power on (to console) 272, 273 reset 72, 288

blade server (continued) reset (clear NVRAM) 291 reset (enter SMS menu) 292 reset (run diagnostics with boot sequence) 291 reset (run diagnostics) 291 reset (to console) 72, 289 reset (with NMI) 290 set address prefix length 190 set as KVM owner 208 set as media tray owner 239 set boot mode 74 set boot sequence 76, 78 set Ethernet channel configuration method 188 set Ethernet channel gateway IP address (IPv4) 186 set Ethernet channel gateway/default route (IPv6) 187 set Ethernet channel hostname 189 set Ethernet channel subnet mask (IPv4) 187 set Ethernet channel VLAN ID 188 set Ethernet-over-USB setting 137 set I/O module for blade server management traffic 184 set IP address (IPv4) 185 set IP address (IPv6) 186 set name 111 set power capping 154 shutdown 273, 308 turn off 272, 273 turn on 272, 273 turn on (to console) 272, 273 update firmware build ID in firmware build ID list 83 update firmware build revision in firmware build ID list 84 update firmware type in firmware build ID list 83 update machine type in firmware build ID list 82 update manufacturer in firmware build ID list 82 blade server ISMP set IP address (IPv4) 191 blade server module display activity 228 display information 228 blade server power information display (overview) 149 blade server, display power trending 151, 152 blade servers disable multiple video sessions 192 enable multiple video sessions 192 BladeCenter Open Fabric Manager BladeCenter units 66 I/O modules 66 management module 66, 67, 68, 69, 70,71 network interface management commands 66 NIC allocation 66 BladeCenter S 150 display power management policies 251

BladeCenter T specific commands 29 BladeCenter unit command target 132 configuring 20 disable global cKVM 193 disable management channel auto-discovery 227 display management channel auto-discovery status 227 display network settings 192 display serial number 111 display type/model 111 display uuid 111 enable global cKVM 193 enable management channel auto-discovery 227 set automatic power-on policy 275 set VLAN ID 192 BladeCenter units clear list of discovered 286 display all discovered 285 display filtered by IP address 285 display filtered by name 286 display health for all discovered 285 blink location LED 169, 222 blower command target 134 blower power information display 149 blower temperature display 149 blower, display power trending 151, 152 BMC command target 133 bofm options l,i 66 l, i, d 67 1, i, d on 68 1, i, p off 70 l, i, p on 69 l, i, v 71 bofm command example 71 bofm command errors 428 bofm commands 66 boot 72 blade server 72 options c 72 p powercycle 72 p reset 72 boot (to console) blade server 72 boot command errors 429 boot commands 72 example 73 boot mode display for blade server 74 set for blade server 74 boot sequence display for blade server 75 set for all blade servers 78 set for blade server 76 bootmode 74 options p 74 bootmode command errors 429 bootmode commands 74

bootmode commands (continued) example 74 bootseq 75 cd 76 floppy 76 hd0 76 hd1 76 hd2 76 hd3 76 hd4 76 hyper 76 iscsi 76 iscsicrt 76 legacy 76 nodev 76 nw 76 options all 78 uefi 76 usbdisk 76 bootseq command errors 430 bootseq commands 75 example 79 buildidcfg 80 options ab 81 create 80 db 84,85 export 86 import 85 ub, ft 83 ub, id 83 ub, mfg 82 ub, mt 82 ub, rev 84 buildidcfg command errors 430 buildidcfg commands 80 example 86 built-in commands 27

С

call-home autoftp settings 60, 61 problem description 95 test call home 96 call-home activity log acknowledge call-home activity log entry for management module 94 display for management module 93 display FTP/TFTP server entries for management module 93 display IBM Support entries for management module 93 unacknowledge call-home activity log entry for management module 94 capture service information 124 certificate file (SSL CSR) download 344 import 345 upload 345 certificate file (SSL self-signed certificate) download 344 import 345 upload 345 change command environment 25, 131 change user password 387

chassis internal network command cin 97 chassis internal network configuration 97 chassis internal network status 102 chassis internal network status command 102 chconfig 87 options ca 89 cci 89 ce 89 89 cn co 89 cph 89 cs 89 cz 89 li 87 91 loc 91 ро ps 91 pw 91 sa 88 sc 89 u 91 chconfig command errors 431 chconfig commands 87 example 91 China Class A electronic emission statement 499 chlog 93 options ack 94 f 93 s 93 chlog command errors 432 chlog commands 93 example 94 chmanual options desc 95, 96 chmanual command errors 433 chmanual commands 95 example 96 cin 97 options entry_index -ip ip_address 99 entry_index clear 98 entry_index en 98 entry_index id 99 global en 97 id 100 vlan_id -ip ip_address 99 CIN turn all index entries on or off 98 cin all options clear 97 en state 98 cin command chassis internal network 97 cin command errors 433 cin commands example 100 cin configuration Specify VLAN ID 100 CIN configuration 98

CIN configuration entries 97 CIN configuration entry create 99 delete 98 disable 98 enable 98 Specify IP address 99 CIN configuration table display for management module 97 CIN index entry create 99 Specify IP address 99 CIN state set for enable or disable 97 CIN status table entries 102 cinstatus 102 cinstatus command 102 cinstatus commands example 102 cKVM disable for blade server 185 disable globally for BladeCenter unit 193 enable for blade server 185 enable globally for BladeCenter unit 193 cKVM status display for blade server 184 Class A electronic emission notice 496 clear options cnfg 103 clear alarms alarm ID 48 complete alarm key 48 generator ID 47 generator information 47 clear CIN configuration management module 97 clear command 103 clear command errors 435 clear commands example 104 clear event log management module 105 clear for management module 97 clear management module event log commands 105 example 105 clearlog 1 105 clearlog command errors 435 clearlog commands 105 example 105 CLI exit codes for SSH 20 CLI inactivity timeout set for management module 33 CLI key sequence set for SOL 334 CLI SSH server disable for management module 338 enable for management module 338 clock 106 options d 106 dst 109

clock (continued) options (continued) g 107 t 106 clock command errors 435 clock commands 106 example 110 clock settings display for management module 106 collect service data blade server 301 command health 163, 164 system physical configuration 225 command authority 8 command environment selecting 6 command history 168 command redirect 25, 131 command syntax 29 command target 25, 131 alarm panel 135 battery backup unit 134 blade mezzanine 133 blade server 132 BladeCenter unit 132 blower 134 BMC 133 disk drive 135 high-speed expansion card 133 I/O module 134 I/O-expansion card 133 integrated system management processor 133 management card 133 management module 132 media tray 134 memory 133 microprocessor 133 multiplexer expansion module 135 network clock module 135 power module 134 service processor 133 storage expansion unit 133 storage module 135 switch module 134 temporary 7 view 225 command target selection 6 command-line interface enable for management module 361 errors 419 guidelines 5 case sensitivity 6 command history 6 data types 6 delimiters 6 help 6 options 5 output format 6 strings 6 introduction 1 starting 14 using 5, 25 command-line session configuration display for management module 356 command-line timeout set for management module 356

commands accseccfg 30, 38 Active Directory, group authentication 159 advfailover 40, 41 airfilter 42 alarm 43, 49 alertcfg 51, 52 alertentries 53, 59 autoftp 60, 62 baydata 63, 65 bofm 66, 71 boot 72, 73 bootmode 74 bootseq 75, 79 buildidcfg 80, 86 built-in 27 chconfig 87, 91 chlog 93, 94 chmanual 95, 96 cin 100 cin command 97 cinstatus 102 cinstatus command 102 clear 103, 104 clear management module event log 105 clearlog 105 clock 106, 110 common 27 config 111, 114 configuration 27 console 115, 116 dhcpinfo 117, 118 discovery 28 display management module call-home events in events log 93 display management module event log 119, 123 displaylog 119, 123 displaysd 124, 125 dns 126, 129 environment 131, 136 ethoverusb 137 event log, clear for management module 105 event log, display for management module 93, 119, 123 eventinfo 138, 139 events 140, 141 examples account security 38 accseccfg 38 advfailover 41 alarm 49, 223 alertcfg 52 alertentries 59 autoftp 62 bavdata 65 blade server name 114 BladeCenter Open Fabric Management 71 bofm 71 boot 73 bootmode 74 bootseq 79 buildidcfg 86

commands (continued) examples (continued) chconfig 91 chlog 94 chmanual 96 cin 100 cinstatus 102 clear 104 clear management module event log 105 clearlog 105 clock 110 config 114 configure automated message settings 62 console 116 DHCP settings for management module 118 dhcpinfo 118 display automated message settings 62 display call-home owner 96 display KVM owner 209 display management module event log 123 display management module security 305 display media tray owner 240 display Service Advisor owner 91 display service information owner 303 displaylog 123 displaysd 125 DNS 129 env 136 environment 136 environment redirect 136 Ethernet network settings for management module 200 ethoverusb 137 eventinfo 139 events 141 exit 143 feature 146 files 147 fuelg 156 groups 162 health 164 help 166 history 168 I/O management 71 I/O module network protocol configuration 244 identify 170 ifconfig 200 info 205 iocomp 206 kvm 209 LDAP configuration for management module 219 ldapcfg 219 list 225 management module DHCP settings 118 management module DNS 129 management module Ethernet network settings 200

commands (continued) examples (continued) management module event log clear 105 management module event log display 123 management module LDAP configuration 219 management module name 114 management module network port configuration 270 management module restore configuration 282 management module save configuration 414 management module serial port settings 254 management module service 306 management module SLP configuration 309 management module SMTP settings 312 management module SNMP settings 328 management module SSH 338 management module telnet configuration 356 management module uplink failover 377 management module vlan 410 mcad 227 modactlog 228 monalerts 238 mt 240 name for blade server 114 name for management module 114 nat 244 network port configuration for management module 270 network protocol configuration for I/O module 244 ntp 247 ping 249 pmpolicy 252 portcfg 254 ports 270 power 277 rdoc 279 read 282 remotechassis 286 reset 292 restore configuration for management module 282 save configuration for management module 414 scale 300 sddump 302 sdemail 303 security 305 Serial Over LAN 335 serial port settings for management module 254 service 306 set call-home 96 set KVM owner 209

commands (continued) examples (continued) set management module security 305 set media tray owner 240 set Service Advisor 91 set service information 303 shutdown 308 slp 309 SLP configuration for management module 309 smtp 312 SMTP settings for management module 312 snmp 328 SNMP settings for management module 328 sol 335 SSH configuration for management module 338 sshcfg 338 sslcfg 348 syntax help 166 syslog 352 tcpcmdmode 355 telnetcfg 356 temps 357 trespass 359 uicfg 363 update 373 uplink 377 user account security 38 user interface configuration 363 users 400 vlan 410 vlan configuration for management module 410 volts 412 write 414 zonecfg 416 exit 143 feature 144, 146 files 147 fuelg 149, 156 group authentication, Active Directory 159 groups 159, 162 help 166 history 168 identify 169, 170 ifconfig 171, 200 info 203, 205 iocomp 206 kvm 208, 209 ldapcfg 210, 219 led 220, 223 LED 29 list 225 management module event log 28 management module failover 375, 377 mcad 227 memory 29 modactlog 228 monalerts 229, 238 monalertsleg 229 mt 239, 240

commands (continued) nat 241, 244 ntp 245, 247 ping 248, 249 pmpolicy 251, 252 portcfg 253, 254 ports 255, 270 power 272, 277 power control 29 power management 29 power management policy 251 rdoc 278, 279 read 280, 282 remacccfg 283 remotechassis 285, 286 reset 288, 292 reset command 29 restore configuration 29 save configuration 29 scale 293, 300 sddump 301, 302 sdemail 303 security 305 Serial Over LAN 330, 335 service 306 session command 29 shutdown 308 slp 309 smtp 311, 312 snmp 314, 328 SOL 330, 335 sshcfg 337, 338 sslcfg 339, 348 syslog 349, 352 system management command 29 tcpcmdmode 353, 355 telnet configuration 356 telnetcfg 356 temps 357 trespass 358, 359 uicfg 361, 363 update 365, 373 uplink 375, 377 user interface configuration 361, 363 users 379, 400 vlan 402, 410 volts 412 write 413, 414 zonecfg 415, 416 comment SSH public key 400 commit VLAN settings 402 commit timeout VLAN settings 402 common commands 27 common errors 421 communicating with IBM Systems Director 353 communication out-of-band 353 test I/O-module IP address 249 test IP address 248 test IP address (I/O-module) 249 communication rate set for serial port of management module 253

compatibility I/O module display details for blade server 206 display details for I/O module 206 display for all components 206 component and reloading information 203 component information display 203 config 111 options contact 112, 113, 114 loc 112 name 111 config command 111 example 114 config command errors 436 configuration disable automatic for management module 282 enable automatic for management module 281 save for management module (to chassis) 413 view for management module 225 view tree for system 225 configuration (encryption) save for management module (to file) 414 configuration (no encryption) save for management module (to file) 413 configuration commands 27 configuration from file (encryption) restore for management module 281 configuration from file (no encryption) restore for management module 280 configuration from midplane restore for management module 280 configuration information display for network card 184 configuration method set for channel 0 of management module 176 set for channel of blade server 188 configure LDAP command example 219 configure network ports command example 270 configure network protocols command example 244 configure SLP command example 309 confirm password LDAP distinguished name 218 connect to SSH public key 399 console 115 create override SOL session 115 create SOL session 115 non-persistent session 115 options 1 115 o 115 persistent console 115 console command 115 console command errors 437

console commands example 116 contact information Service Advisor 89 contact information, Service Advisor city 89 company 89 contact name 89 country 89 email address 89 phone number 89 postal code 89 state 89 street address 89 contact name display for management module 111 set for management module 112, 113, 114 contamination, particulate and gaseous 495 create VLAN entry 404 create alert recipient 54 create CIN configuration entry 99 create CIN index entry 99 create firmware build ID list blade server 80 create override SOL session 115 create partition scalable complex 296 create partition (automatically) scalable complex 294 create SOL session 115 persistent console 115 create stand-alone partition scalable complex 295 create stand-alone partition (automatically) scalable complex 294 create user 383 creating a personalized support web page 490 critical alerts disable monitoring for all 229 disable monitoring for blade device 230 disable monitoring for chassis 231 disable monitoring for cooling device 231 disable monitoring for I/O module 230 disable monitoring for power module 231 disable monitoring for storage module 230 disable monitoring for system management 231 enable monitoring for all 229 enable monitoring for blade device 230 enable monitoring for chassis 231 enable monitoring for cooling device 231 enable monitoring for I/O module 230 enable monitoring for power module 231

critical alerts (continued) enable monitoring for storage module 230 enable monitoring for system management 231 CSR generate for LDAP client 343 generate for management module web server 343 CSR (SSL) download certificate file 344 import certificate file 345 upload certificate file 345 custom support web page 490 cycle power blade server 72, 273 I/O module 273 switch module 273

DHCPv6

D

data encryption display management module setting 305 enable for management module 305 data rate set for channel 0 of management module 177 set for channel 1 of management module 182 date display for management module 106 set for management module 106 daylight-savings time mode set for management module 109 daylight-savings time setting display for management module 106 default IP address 15 delete VLAN entry 403, 404 delete Active Directory group 161 delete alert recipient 53 delete all entries from firmware build ID list blade server 84 delete all partitions scalable complex 296 delete CIN configuration 98 delete entry from firmware build ID list blade server 85 delete file management module 147 delete partition scalable complex 297 delete user 380 DHCP configuration display for I/O module 117 DHCP settings for management module commands example 118 dhcpinfo 117 options eth0 117 dhcpinfo command errors 438 dhcpinfo commands 117 example 118

disable for blade server 191 disable for I/O module 198 disable for management module 180 enable for blade server 191 enable for I/O module 198 enable for management module 180 disable additional SSL certificate for standby management module 339 blade server Ethernet channel VLAN ID 189 BladeCenter unit VLAN ID 192 CLI SSH server for management module 338 enhanced legacy alert categories 229 logging of login events from same IP address 35 monitoring for all critical alerts 229 monitoring for all informational alerts 234 monitoring for all warning alerts 232 monitoring for blade device critical alerts 230 monitoring for blade device informational alerts 235 monitoring for blade device warning alerts 232 monitoring for chassis critical alerts 231 monitoring for chassis informational alerts 236 monitoring for chassis warning alerts 233 monitoring for cooling device critical alerts 231 monitoring for cooling device informational alerts 238 monitoring for cooling device warning alerts 234 monitoring for event log informational alerts 237 monitoring for event log warning alerts 233 monitoring for I/O module critical alerts 230 monitoring for I/O module informational alerts 235 monitoring for I/O module warning alerts 232 monitoring for inventory change informational alerts 236 monitoring for network change informational alerts 237 monitoring for power module critical alerts 231 monitoring for power module informational alerts 238 monitoring for power module warning alerts 234 monitoring for power state informational alerts 236 monitoring for storage module critical alerts 230 monitoring for storage module informational alerts 235

disable (continued) monitoring for storage module warning alerts 233 monitoring for system management critical alerts 231 monitoring for system management informational alerts 236 monitoring for system management warning alerts 233 monitoring for user activity informational alerts 237 secure TCP command mode 354 Service Advisor 88 SMASH SSH server for management module 338 SSL for LDAP client 340 SSL for management module web server 339 syslog event log transmission for collector 1 349 syslog event log transmission for collector 2 350 TCP command mode 353 disable automatic configuration management module 282 disable CIN configuration entry 98 disable cKVM blade server 185 disable DHCPv6 blade server 191 I/O module 198 management module 180 disable Ethernet channel blade server 190 disable Ethernet channel 1 management module 184 disable global cKVM BladeCenter unit 193 disable IPv6 blade server 190 I/O module 197 management module 179 disable IPv6 stateless auto-configuration blade server 191 I/O module 198 management module 180 disable logical uplink failover advanced management module 376 management module (advanced) 376 disable management channel auto-discovery BladeCenter unit 227 disable multiple video sessions blade servers 192 disable NAT table I/O module 244 disable NEBS environment mode 153 disable network interface management module (standby) 40 disable power domain acoustic mode 153 disable SOL global 333 disable static IPv6 configuration I/O module 197 management module 179

disable technician debug management module 306 disable user 381 discovered BladeCenter units clear list 286 display all 285 display filtered by IP address 285 display filtered by name 286 display health for all 285 discovery commands 28 disk drive 135 display alert state 229 clock settings, management module 106 date, management module 106 daylight-savings time setting, management module 106 GMT offset, management module 106 management channel path information 204 power management policy all domains 251 BladeCenter S 251 specified power domain 251 remote presence access 283 TCP command-mode session status 353 TCP command-mode session timeout 353 time, management module 106 VLAN entry 404 VLAN settings 402 display (reset counter) event log management module 119 display active users 379 display activity blade server module 228 display advanced failover settings management module 40 display alarms alarm ID 44 all 43 complete alarm key 44 generator ID 43 generator information 44 power 43 display alert properties (all recipients) 53 display alert properties (single recipient) 53 display alerts 164 timestamp 164 display all Active Directory groups 159 display all BladeCenter units on network 285 display all event log entries management module 119 display all event log filters management module 119 display all information scalable complex 293 display all users 379 display automatic configuration setting management module 280

display blade server power information overview 149 display blade server SRC record (specific) 124 display blade server SRC records (all) 124 display blower power information 149 display blower temperature 149 display boot mode blade server 74 display call-home activity log management module 93 display call-home event management module event log entries 93 display CIN configuration table 97 display cKVM status blade server 184 display command-line session configuration management module 356 display component information 203 display configuration information network card 184 display contact name management module 111 display DHCP configuration I/O module 117 display DNS configuration management module 126 display DSA host key information management module 337 display entries of CIN status table 102 display Ethernet channel 0 configuration management module (primary) 171 management module (standby) 172 display Ethernet channel 0 DHCP configuration management module 117 display Ethernet channel 1 configuration management module (primary) 181 display Ethernet-over-USB setting blade server 137 display event description management module 138 display event log management module 119 display event log entries filtered by date management module 120 display event log entries filtered by severity level management module 120 display event log entries filtered by source management module 120, 121 display event user action management module 138, 139 display events list management module 140 display failover configuration management module 375 display features management module 144 display file list management module 147 display firmware attributes 365 display firmware build IDs blade server 80

display free space management module 140, 147 display FTP/TFTP server call-home activity log management module 93 display global remote alert settings management module 51 display health for BladeCenter units on network 285 display health status 163, 164 timestamp 164 display health status (tree) 163 display I/O module compatibility all components 206 display I/O module compatibility details blade server 206 I/O module 206 display I/O module power information 149 display I/O module SAS zone information 416 display I/O module SAS zone list 415 display IBM Support call-home activity log management module 93 display information blade server module 228 display IP addresses I/O module 248 display KVM owner 208 display LDAP settings management module 210 display LED state blower fault 220 external port link status 220 fanpack fault 220 fault 220 for blade server and all sub-components 221 for blade server front panel 220 safe-to-remove 220 display licenses management module 144 display location management module 111 display log entries with call-home events management module 119 display log entries with Event ID management module 119 display management channel auto-discovery status BladeCenter unit 227 display management module account security settings 30 display management module data encryption setting 305 display management module event log commands 119 example 123 display management module security 305 display management module status 124 display management network DHCP configuration blade server 117 display media tray owner 239 display media tray temperature 149

display name blade server 111 management module 111 display network configuration status blade server 184 display network port settings management module 255 switch 269 display network protocol settings I/O module 241 display network settings BladeCenter unit 192 I/O module 193 display node information scalable complex 293 display NTP configuration management module 245 display open ports management module 255 display partition information scalable complex 293 display POST status I/O module 276 switch module 276 display power domain information details 150 display power domain information overview 149 display power state blade server 273 I/O module 273 switch module 273 display power trending (blade server) 151, 152 display power trending (blower) 151, 152 display power trending (I/O module) 151, 152 display power trending (media tray) 152 display power trending (power domain) 151, 152 display power trending (system) 151, 152 display RSA host key information management module 337 display SAS zone information I/O module 416 display SAS zone list I/O module 415 display serial number BladeCenter unit 111 display serial port configuration management module 253 display Service Advisor 87 display service data blade server 301 display service data command 124 display service information 124 display service setting management module 306 display single user 380 display SLP settings management module 309 display SMTP server host name management module 311 display SMTP server IP address management module 311

display SNMP configuration management module 314 display specific Active Directory groups 159 display specific complex information scalable complex 293 display SSH public key 393 display SSH status management module 337 display state location LED 169 display state of -lse option management module 122 Display status of first five CIN entries 102 display syslog configuration management module 349 display telnet configuration management module 356 display temperature blade server 357 management module 357 media trav 357 display trespass feature status management module 358 display type/model BladeCenter unit 111 display uplink configuration management module 375 display user interface settings management module 361 display uuid BladeCenter unit 111 display various LED states LED states 220 display voltage blade server 412 management module 412 displaylog 119 display log entries with call-home events 119 display log entries with Event ID 119 display state of -lse option 122 filter log entries by call-home events flag 122 options -lse 122 a 119 c 119 ch 122 date 120 e 119 f 119 filters 119 i 122 i, l 122 1 122 1. i 122 lse 122 sev 120 src 120, 121 displaylog command errors 438 displaylog commands 119 example 123 displaysd 124 options i 124

displaysd (continued) options (continued) i, save 124 mmstat 124 save 124 save, i 124 src 124 displaysd command errors 439 displaysd commands 124 example 125 distinguished name LDAP client 218 distinguished name password LDAP client 218 distinguished name password (confirm) LDAP client 218 dns 126 options -ddns 126 i1 127 i2 127 i3 127 i61 128 i62 128 i63 128 on 126 p 129 DNS enable for management module 126 dns command errors 440 dns commands 126 example 129 DNS configuration display for management module 126 DNS first IPv4 IP address set for management module 127 DNS first IPv6 IP address set for management module 128 DNS second IPv4 IP address set for management module 127 DNS second IPv6 IP address set for management module 128 DNS server priority set for management module 129 DNS third IPv4 IP address set for management module 127 DNS third IPv6 IP address set for management module 128 documentation using 490 documentation format 496 Domain Catalog discovery set search domain 213 domain name set for channel 0 of management module 179 set for management module LDAP server 213 download 346, 347, 348 download certificate file SSL CSR 344 SSL self-signed certificate 344 download SSH public key 398 DSA host key information display for management module 337 DSA, sending data to IBM 490

dump service data blade server 301 duplex mode set for channel 0 of management module 177 set for channel 1 of management module 182 dynamic DNS enable for management module 126 dynamic power optimizer, enable for blade server 155 dynamic power optimizer, extended , enable for blade server 156

E

electronic emission Class A notice 496 Electronic emission notices 496 email alerts exclude service information 51 include service information 51 enable additional SSL certificate for standby management module 339 blade server Ethernet channel VLAN ID 189 BladeCenter unit VLAN ID 192 CLI SSH server for management module 338 enhanced legacy alert categories 229 monitoring for all critical alerts 229 monitoring for all informational alerts 234 monitoring for all warning alerts 232 monitoring for blade device critical alerts 230 monitoring for blade device informational alerts 235 monitoring for blade device warning alerts 232 monitoring for chassis critical alerts 231 monitoring for chassis informational alerts 236 monitoring for chassis warning alerts 233 monitoring for cooling device critical alerts 231 monitoring for cooling device informational alerts 238 monitoring for cooling device warning alerts 234 monitoring for event log informational alerts 237 monitoring for event log warning alerts 233 monitoring for I/O module critical alerts 230 monitoring for I/O module informational alerts 235 monitoring for I/O module warning alerts 232 monitoring for inventory change informational alerts 236 monitoring for logging of login events from same IP address 35

enable (continued) monitoring for network change informational alerts 237 monitoring for power module critical alerts 231 monitoring for power module informational alerts 238 monitoring for power module warning alerts 234 monitoring for power state informational alerts 236 monitoring for storage module critical alerts 230 monitoring for storage module informational alerts 235 monitoring for storage module warning alerts 233 monitoring for system management critical alerts 231 monitoring for system management informational alerts 236 monitoring for system management warning alerts 233 monitoring for user activity informational alerts 237 secure TCP command mode 354 Service Advisor 88 SMASH SSH server for management module 338 SSL for LDAP client 340 SSL for management module web server 339 syslog event log transmission for collector 1 349 syslog event log transmission for collector 2 350 TCP command mode 354 enable automatic configuration management module 281 enable CIN configuration entry 98 enable cKVM blade server 185 enable command-line interface management module 361 enable complex password for management module user authentication 33 enable data encryption management module 305 enable default administration password expiration for management module 34 enable DHCPv6 blade server 191 I/O module 198 management module 180 enable DNS management module 126 enable dynamic DNS management module 126 enable dynamic power optimizer for blade server 155 enable dynamic power optimizer, extended, for blade server 156 enable Ethernet channel blade server 189 enable Ethernet channel 1 management module 183

enable external management I/O module 196 enable external ports I/O module 196 enable fast POST I/O module 275, 276 enable FTP management module 261 enable global cKVM BladeCenter unit 193 enable HTTPS port management module 262 enable IPv6 blade server 190 I/O module 197 management module 179 enable IPv6 stateless auto-configuration blade server 191 I/O module 198 management module 180 enable local KVM switching globally 208 enable local media tray switching globally 239 enable local power control blade server 275 globally 274 enable logical uplink failover advanced management module 376 management module (advanced) 376 enable management channel auto-discovery BladeCenter unit 227 enable monitoring of event log state management module 122 enable multiple video sessions blade servers 192 enable NAT table I/O module 244 enable NEBS environment mode 153 enable network interface and allow IP swap management module (standby) 40 enable network interface and prevent IP swap management module (standby) 41 enable NTP management module 245, 262 enable password change at first login to management module 36 enable password required for management module 37 enable physical uplink failover advanced management module 375 management module (advanced) 375 enable port switch 269 enable power capping for blade server 154 enable power domain acoustic mode 153 enable power management for blade server 154, 155 enable power saver mode for blade server 155 enable protected mode I/O module 197

enable RDE management module 263 enable RDOCE management module 263 enable remote media tray switching globally 240 enable secure SMASH over SSH management module 264 enable secure TCP command mode management module 266, 362 enable security management module 305 enable SLP management module 263 enable SMASH over Telnet management module 264 enable SNMP agent management module (SNMPv1) 314 management module (SNMPv3) 314 enable SNMP traps management module 265, 314 enable SNMPv1 management module 361 enable SNMPv1 agent management module 264 enable SNMPv3 management module 361 enable SNMPv3 agent management module 265 enable SOL global 332 enable SSH port management module 265 enable static IPv6 configuration I/O module 197 management module 179 enable TCP command mode management module 266, 362 enable technician debug 306 management module enable Telnet port management module 267 enable TFTP management module 267 enable trespass feature management module 358 enable user 381 enable V3 authentication for NTP management module 246 enable Wake on LAN blade server 274 globally 274 enable web interface management module 363 encryption algorithms 14 end session 143 ending an SOL session 23, 115 enhanced legacy alert categories disable 229 enable 229 entries of the CIN status table display for management module 102 env 132, 133 options bbu 134 be 133 blade 132

env (continued) options (continued) blower 134 ckvm 133 сри 133 disk 135 exp 133 hsec 133 133 mgmtcrd mt 134 mux 135 ncc 135 power 134 sb 133 sp 133 storage 135 switch 134 system (management module) 132 tap 135 env command errors 440 env commands example 136 environment alarm panel 135 blade mezzanine 133 blade server 132 BladeCenter unit 132 blower 134 BMC 133 disk drive 135 high-speed expansion card 133 I/O module 134 I/O-expansion card 133 integrated system management processor 133 management card 133 management module 132 media tray 134 memory 133 microprocessor 133 multiplexer expansion module 135 network clock module 135 power module 134 service processor 133 storage expansion unit 133 storage module 135 switch module 134 environment commands 131 example 136 errors accseccfg command 423 advfailover command 424 alarm command 425 alertcfg command 426 alertentries command 426 autoftp command 427 baydata command 427 bofm command 428 boot command 429 bootmode command 429 bootseq command 430 buildidcfg command 430 chconfig command 431 chlog command 432 chmanual command 433 cin command 433

errors (continued) clear command 435 clearlog command 435 clock command 435 command-line interface 419 common 421 config command 436 console command 437 dhcpinfo command 438 displaylog command 438 displaysd command 439 dns command 440 env command 440 ethoverusb command 440 eventinfo command 441 events command 441 exit command 442 feature command 442 files command 444 fuelg command 445 groups command 448 health command 448 help command 449 history command 449 identify command 449 ifconfig command 450 info command 454 iocomp command 455 kvm command 455 ldapcfg command 455 led command 456 list command 457 mcad command 457 modactlog command 457 monalerts command 457 monalertsleg command 458 mt command 458 nat command 458 ntp command 459 ping command 459 pmpolicy command 460 portcfg command 460 ports command 460 power command 462 rdoc command 462 read command 463 remacccfg command 464 remotechassis command 464 reset command 465 scale command 465 sddump command 466 sdemail command 467 security command 467 service command 467 shutdown command 468 slp command 468 smtp command 468 snmp command 469 sol command 470 sshcfg command 471 sslcfg command 472 syslog command 474 tcpcmdmode command 475 telnetcfg command 475 temps command 476 thres command 476 trespass command 476

errors (continued) uicfg command 477 update command 478 uplink command 480 users command 481 vlan command 485 volts command 486 write command 486 zonecfg command 487 Ethernet configuring remote connection 21 Ethernet channel disable for blade server 190 enable for blade server 189 Ethernet channel 0 address prefix length set for management module 180 Ethernet channel 0 configuration display for management module (primary) 171 display for management module (standby) 172 Ethernet channel 0 configuration method set for management module 176 Ethernet channel 0 data rate set for management module 177 Ethernet channel 0 DHCP configuration display for management module 117 Ethernet channel 0 domain name set for management module 179 Ethernet channel 0 duplex mode set for management module 177 Ethernet channel 0 gateway IP address (IPv4) set for management module 174 Ethernet channel 0 gateway/default route (IPv6) set for management module 174 Ethernet channel 0 hostname set for management module 175 set for standby management module 176 Ethernet channel 0 MAC address set for management module 178 set for standby management module 178 Ethernet channel 0 MTU set for management module 177 Ethernet channel 0 static IP address (IPv4)set for management module 173 set for standby management module 173 Ethernet channel 0 static IP address (IPv6) set for management module 173 set for standby management module 174 Ethernet channel 0 subnet mask (IPv4) set for management module 175 Ethernet channel 1 disable for management module 184 enable for management module 183 Ethernet channel 1 configuration display for management module (primary) 181 Ethernet channel 1 data rate set for management module 182

Ethernet channel 1 duplex mode set for management module 182 Ethernet channel 1 gateway IP address (IPv4)set for management module 181 Ethernet channel 1 MAC address set for management module 183 Ethernet channel 1 MTU set for management module 183 Ethernet channel 1 static IP address (IPv4) set for management module 181 Ethernet channel 1 subnet mask (IPv4) set for management module 182 Ethernet channel configuration method set for blade server 188 Ethernet channel gateway IP address (IPv4)set for blade server 186 Ethernet channel gateway/default route (IPv6)set for blade server 187 Ethernet channel hostname set for blade server 189 Ethernet channel static IP address (IPv4) set for blade server 185 Ethernet channel static IP address (IPv6) set for blade server 186 Ethernet channel subnet mask (IPv4) set for blade server 187 Ethernet channel VLAN ID set for blade server 188 Ethernet network settings for management module commands example 200 Ethernet-over-USB setting display for blade server 137 set for blade server 137 ethoverusb 137 options s 137 ethoverusb command errors 440 ethoverusb commands 137 example 137 European Union EMC Directive conformance statement 497 event description display 138 event log clear for management module 105 display (reset counter) for management module 119 display all entries for management module 119 display all filters for management module 119 display entries for management module, filtered by date 120 display entries for management module, filtered by severity level 120 display entries for management module, filtered by source 120, 121 display for management module 119 enable monitoring of state 122 save to TFTP server 122

event log, clear for management module commands 105 event log, display for call-home event management module entries 93 event log, display for management module commands 119 event user action display 138, 139 eventinfo 138, 139 eventinfo command errors 441 eventinfo commands 138 example 139 events 140 options -add 140 -rm 141 events command errors 441 events commands 140 example 141 exit 143 exit codes (CLI) Secure Shell server 20 exit command 143 exit command errors 442 exit commands example 143 export datacenter feature licenses management module 145 export firmware build ID list blade server 86 external management enable for I/O module 196 external ports enable for I/O module 196

F

failover configuration display for management module 375 fast POST enable for I/O module 275, 276 FCC Class A notice 496 feature 144 options -add 144 -apply 145 -remove 144 -retrieve 145 feature command errors 442 feature commands 144 example 146 feature license add for management module 144 remove from management module 144 feature licenses export for datacenter 145 import from datacenter 145 features display for management module 144 files 147 options d 147 files command errors 444 files commands 147 example 147 filter alert type 56

filter log entries by call-home events flag management module 122 firmware display attributes 365 update 366, 370 I/O module 367, 368, 369, 371, 372, 373 switch 367, 368, 369, 371, 372, 373 verbose 368, 372 update (verbose) 367, 370 firmware build ID update in firmware build ID list 83 firmware build ID list add entry for blade server 81 create for blade server 80 delete all entries 84 delete entry 85 export for blade server 86 import for blade server 85 update firmware build ID for blade server 83 update firmware build revision for blade server 84 update firmware type for blade server 83 update machine type for blade server 82 update manufacturer for blade server 82 firmware build IDs display for blade server 80 firmware build revision update in firmware build ID list 84 firmware requirements 2 firmware type update in firmware build ID list 83 firmware update 365 flash location LED 169, 222 forest name set for Global Catalog discovery 213 set for management module LDAP server 213 FTP enable for management module 261 FTP data port number set for management module 256 FTP port number set for management module 256 FTP timeout set for management module 268 fuelg 149, 150 options am 153 dps 155 e 153 fpop 156 int 152 pcap 154 pm 151 pme 154, 155 pt 151, 152 tt 152 fuelg command errors 445 fuelg commands 149 example 156

G

gaseous contamination 495 gateway IP address (IPv4) set for channel 0 of management module 174 set for channel 1 of management module 181 set for channel of blade server 186 set for I/O module 194, 199 gateway IP address (IPv6) set for I/O module 195 gateway/default route (IPv6) set for channel 0 of management module 174 set for channel of blade server 187 generate CSR (LDAP client) 343 CSR (management module web server) 343 self-signed certificate (LDAP client) 341 self-signed certificate (management module web server) 341 generate host key management module 337 generate syslog test message management module 352 generate test alert 58 Germany Class A statement 497 get service data blade server 301 getting help 490 global enable local KVM switching 208 enable local media trav switching 239 enable local power control 274 enable remote media tray switching 240 enable Wake on LAN 274 Global Catalog discovery set forest name 213 global disable SOL 333 global enable SOL 332 GMT offset display for management module 106 set for management module 107 group filter LDAP 211 group LDAP authentication, management module 159 group search attribute LDAP 211 groups 159 options a 160 161 clear n 159 groups command 159 groups command errors 448 groups commands example 162 guidelines case sensitivity 6 command history 6

guidelines (continued) data types 6 delimiters 6 help 6 options 5 output format 6 overview of 5 strings 6

Η

hardware requirements 2 hardware service and support telephone numbers 491 health 163 display for all BladeCenter units on network 285 display status 163 display status (tree) 163 display status and alerts 164 display status and alerts with timestamp 164 options f 164 1 163 t 164 health command 163, 164 example 164 health command errors 448 help 25, 166 getting 489 help command 166 help command errors 449 help commands example 166 help, sending diagnostic data to IBM 490 help, World Wide Web 490 high-speed expansion card command target 133 history 168 history command 168 history command errors 449 history commands example 168 host kev generate for management module 337 host name set for blade server 189 set for channel 0 of management module 175 set for channel 0 of standby management module 176 HTTP port number set for management module 257 HTTP proxy setup Service Advisor 91 HTTPS port enable for management module 262 HTTPS port number set for management module 257

I/O module activate network protocol settings 241 activate SAS zone 415 BladeCenter Open Fabric Manager 66 bofm 66, 67, 68, 69, 70, 71 bofm commands 66 command target 134 cycle power 273 dhcpinfo commands 117 disable DHCPv6 198 disable IPv6 197 disable IPv6 stateless auto-configuration 198 disable NAT table 244 disable static IPv6 configuration 197 display DHCP configuration 117 display IP addresses 248 display network protocol settings 241 display network settings 193 display POST status 276 display power state 273 display SAS zone information 416 display SAS zone list 415 enable DHCPv6 configuration 198 enable external management 196 enable external ports 196 enable fast POST 275, 276 enable IPv6 197 enable IPv6 stateless auto-configuration 198 enable NAT table 244 enable protected mode 197 enable static IPv6 configuration 197 I/O management commands 66 keep new IP address configuration after reset 195 nat command 241, 244 example 244 power off 272 power on 272, 273 reset 288 reset (extended diagnostics) 290 reset (full diagnostics) 290 reset (standard diagnostics) 289 reset configuration 103 reset network protocol settings 241 revert to old IP address configuration after reset 195 set address prefix length 198 set gateway IP address (IPv4) 194 set gateway IP address (IPv6) 195 set IP address (IPv4) 194 set IP address (IPv6) 194 set NAT external port number 243 set NAT internal port number 243 set NAT protocol ID 242 set NAT protocol name 242 set RAID IP address (IPv4) 199 set subnet mask (IPv4) 196 turn off 272 turn on 273 I/O module compatibility display details for blade server 206

I/O module compatibility (continued) display details for I/O module 206 display for all components 206 I/O module for blade server management traffic set for blade server 184 I/O module power information display 149 I/O module, display power trending 151, 152 I/O-expansion card command target 133 I/O-module IP address ping 249 test communication 249 IBM Systems Director communication 353 IBM Taiwan product service 491 identify 169 options s 169 s. d 169 identify command 169 identify command errors 449 identify commands example 170 ifconfig 184, 192, 193 options ckvm 185 ckvm, enabled 193 dhcp6 198 em, enabled 196 ep, enabled 196 eth0 171 eth0, c 176 eth0, d 177 eth0, dhcp6 180 eth0, dn 179 eth0, g 174 eth0, g6 174 eth0, i 173 eth0, i6 173 eth0, ipv6 179 eth0, ipv6static 179 eth0, 1 178 eth0, m 177 eth0, n 175 eth0, o 172 eth0, o, i 173 eth0, o, i6 174 eth0, o, l 178 eth0, o, n 176 eth0, p6 180 eth0, r 177 eth0, s 175 eth0, sa6 180 eth1 181 eth1, d 182 eth1, down 184 eth1, g 181 eth1, i 181 eth1, iom 184 eth1, l 183 eth1, m 183 eth1, r 182 eth1, s 182 eth1, up 183

ifconfig (continued) options (continued) ethx 184 ethx, c 188 ethx, dhcp6 191 ethx, down 190 ethx, g 186 ethx, g6 187 ethx, i 185 ethx, i6 186 ethx, ipv6 190 ethx, n 189 ethx, p6 190 ethx, s 187 ethx, sa6 191 ethx, up 189 ethx, v 188 ethx, ve 189 g 194, 199 g6 195 i 191, 194, 199 i6 194 ipv6 197 ipv6static 197 ir 199 maxv 192 p6 198 pip 195 pm, enabled 197 s 196, 200 sa6 198 v 192 ve 192 ifconfig command errors 450 ifconfig commands 171 example 200 import 346, 347, 348 import certificate file SSL CSR 345 SSL self-signed certificate 345 import datacenter feature licenses management module 145 import firmware build ID list blade server 85 important notices 494 Industry Canada Class A emission compliance statement 497 info 203 options path 204 reload, all 204 reload, fw 204 reload, hw 204 reload, mac 204 reload, wwn 204 info command 203 info command errors 454 info commands example 205 information display for specific scalable complex 293 information (all) display for scalable complex 293 information about components and reloading components 203 information center 490

information display, blade server power (overview) 149 information display, blower power 149 information display, component 203 information display, I/O module power 149 information display, power domain (detailed) 150 information display, power domain (overview) 149 information LED turn off 221 information reload, all 204 information reload, firmware 204 information reload, hardware 204 information reload, MAC addresses 204 information reload, WWN 204 informational alerts disable monitoring for all 234 disable monitoring for blade device 235 disable monitoring for chassis 236 disable monitoring for cooling device 238 disable monitoring for event log 237 disable monitoring for I/O module 235 disable monitoring for inventory change 236 disable monitoring for network change 237 disable monitoring for power module 238 disable monitoring for power state 236 disable monitoring for storage module 235 disable monitoring for system management 236 disable monitoring for user activity 237 enable monitoring for all 234 enable monitoring for blade device 235 236 enable monitoring for chassis enable monitoring for cooling device 238 enable monitoring for event log 237 enable monitoring for I/O module 235 enable monitoring for inventory change 236 enable monitoring for network change 237 enable monitoring for power module 238 enable monitoring for power state 236 enable monitoring for storage module 235 enable monitoring for system management 236 enable monitoring for user activity 237 integrated system management processor command target 133 iocomp 206

iocomp command errors 455 iocomp commands 206 example 206 IP address CIN configuration entry 99 CIN index entry 99 display BladeCenter units on network filtered by 285 ping 248 test communication 248 IP address (I/O-module) ping 249 test communication 249 IP address (IPv4) set for blade server 185 set for blade server ISMP 191 set for I/O module 194 set for management module 173 set for standby management module 173 IP address (IPv6) set for blade server 186 set for I/O module 194 set for management module 173 set for standby management module 174 IP address configuration keep new after reset 195 revert to old after reset 195 IP address, default 15 IP addresses display for I/O module 248 IPv6 disable for blade server 190 disable for I/O module 197 disable for management module 179 enable for blade server 190 enable for I/O module 197 enable for management module 179 IPv6 configuration (static) disable for I/O module 197 disable for management module 179 enable for I/O module 197 enable for management module 179 IPv6 stateless auto-configuration disable for blade server 191 disable for I/O module 198 disable for management module 180 enable for blade server 191 enable for I/O module 198 enable for management module 180 ISMP reset 288

J

Japan VCCI Class A statement 498 Japan Voluntary Control Council for Interference Class A statement 498 JS20 blade server commands reset (clear NVRAM) 291 reset (run diagnostics with boot sequence) 291 reset (run diagnostics) 291 reset (with NMI) 290 JSxx blade server commands reset (enter SMS menu) 292

Κ

keep new IP address configuration after reset I/O module 195 Korea Communications Commission statement 499 kvm 208 options b 208 local 208 KVM display owner 208 set owner 208 kvm command errors 455 kvm commands 208 example 209 KVM port set state for management module 262

LDAP client generate CSR 343 generate self-signed certificate 341 LDAP client distinguished name set for management module 218 LDAP client distinguished name password set for management module 218 LDAP client distinguished name password (confirm) set for management module 218 LDAP group filter set for management module 211 LDAP group search attribute set for management module 211 LDAP login permission attribute set for management module 212 LDAP name set for management module 212 LDAP root distinguished name set for management module 216 LDAP security version set for management module 210 LDAP server (first) host name set for management module 214 LDAP server (first) IP address set for management module 214 LDAP server (first) port number set for management module 215 LDAP server (fourth) host name set for management module 215 LDAP server (fourth) IP address set for management module 215 LDAP server (fourth) port number set for management module 216 LDAP server (second) host name set for management module 214 LDAP server (second) IP address set for management module 214 LDAP server (second) port number set for management module 215 LDAP server (third) host name set for management module 214

LDAP server (third) IP address set for management module 214 LDAP server (third) port number set for management module 216 LDAP server authentication method set for management module 217 LDAP server binding method set for management module 217 LDAP server discovery method set for management module 213 LDAP server domain name set for management module 213 LDAP server forest name set for management module 213 LDAP settings display for management module 210 LDAP UID search attribute set for management module 217 ldapcfg 210 options aom 217 bm 217 cd 218 cp 218 dn 213 fn 213 gf 211 gsa 211 i1 214 214 i2 i3 214 i4 215 lpa 212 p 218 p1 215 p2 215 p3 216 p4 216 rd 216 server 213 t 212 usa 217 v 210 ldapcfg command 210 example 219 ldapcfg command errors 455 led 220 options e 220 info 220 info off 221 1 220, 221 loc 220, 222 loc, d 223 r 220 LED (information) turn off 221 LED (location), control 169 led command 220 led command errors 456 led commands example 223 LED commands 29 LED state display (blade server front panel) 220

LED state (continued) display (external port link status) 220 display (fault) 220 display (for blade server and all sub-components) 221 display (safe-to-remove) 220 display (state for blower fault LED) 220 display (state for fanpack fault LED) 220 display various LED states 220 licenses display for management module 144 light location LED 169, 222 time period 223 light location LED (BladeCenter unit) time period 169 link local address 15 list 225 options 1 225 list command example 225 list command errors 457 local KVM switching enable globally 208 local media tray switching enable globally 239 local power control enable for blade server 275 enable globally 274 location display for management module 111 set for management module 112 location LED blink 169, 222 display state 169 flash 169, 222 light 169, 222 time period 223 light (BladeCenter unit) time period 169 turn off 169, 222 location LED control 169 logging disable for logging of login events from same IP address 35 enable for logging of login events from same IP address 35 logical link loss alert and failover policy set for advanced management module 377 set for management module (advanced) 377 login permission attribute LDAP 212

Μ

MAC address set for channel 0 of management module 178 set for channel 0 of standby management module 178 set for channel 1 of management module 183 machine type update in firmware build ID list 82 manage alert recipients 53 management card command target 133 management channel auto-discovery disable for BladeCenter unit 227 enable for BladeCenter unit 227 management channel auto-discovery status display for BladeCenter unit 227 management channel path information display 204 management module account security commands 30, 66 accseccfg 30 accseccfg commands 30, 38 acknowledge call-home activity log entry 94 add Call Home events 140, 141 add feature license 144 add SSH public key 394 add SSH public key (specific) 394 advfailover command 40, 41 example 41 airfilter 42 autoftp commands 60, 62 bay data 63 bofm 66, 67, 68, 69, 70, 71 bofm commands 66, 71 cabling 12 change user password 387 chconfig commands 87, 91 chmanual commands 95, 96 cin commands 97 cinstatus commands 102 clear CIN configuration entries 97 clear event log 105 clear event log commands example 105 command target 132 command-line session configuration 356 command-line timeout 356 comment SSH public key 400 config command 111, 114 example 114 configuring 21 connect to SSH public key 399 create alert recipient 54 create user 383 default IP address 15 delete Active Directory group 161 delete alert recipient 53 delete CIN configuration 98 delete file 147 delete user 380 DHCP settings commands example 118 dhcpinfo commands 117, 118 direct connection 13 disable automatic configuration 282 disable CIN configuration entry 98 disable CLI SSH server 338 disable DHCPv6 180 disable Ethernet channel 1 184 disable IPv6 179

management module (continued) disable IPv6 stateless auto-configuration 180 disable network interface for standby 40 disable SMASH SSH server 338 disable static IPv6 configuration 179 disable technician debug 306 disable user 381 display (reset counter) event log 119 display account security settings 30 display active users 379 display advanced failover settings 40 display alert properties (all recipients) 53 display alert properties (single recipient) 53 display all Active Directory groups 159 display all event log entries 119 display all event log filters 119 display all users 379 display automatic configuration setting 280 display call-home activity log 93 display CIN configuration table 97 display clock settings 106 display contact name 111 display date 106 display daylight-savings time setting 106 display DNS configuration 126 display DSA host key information 337 display entries of CIN status table 102 display Ethernet channel 0 DHCP configuration 117 display event description 138 display event log 119 display event log commands example 123 display event log entries filtered by date 120 display event log entries filtered by severity level 120 display event log entries filtered by source 120, 121 display event user action 138, 139 display events list 140 display features 144 display file list 147 display free space 140, 147 display FTP/TFTP server call-home activity log 93 display global remote alert settings 51 display GMT offset 106 display IBM Support call-home activity log 93 display LDAP settings 210 display licenses 144 display location 111 display log entries with call-home events 119 display log entries with Event ID 119 display name 111

management module (continued) display network port settings 255 display NTP configuration 245 display open ports 255 display RSA host key information 337 display serial port configuration 253 display service setting 306 display single user 380 display SLP settings 309 display SMTP server host name 311 display SMTP server IP address 311 display SNMP configuration 314 display specific Active Directory groups 159 display SSH public key 393 display SSH status 337 display state of -lse option 122 display status 124 Display status of first five CIN entries 102 display syslog configuration 349 display temperature 357 display time 106 display trespass feature status 358 display user interface settings 361 display voltage 412 display volume information 278 dns commands 126, 129 example 129 download SSH public key 398 enable automatic configuration 281 enable CIN configuration entry 98 enable CLI SSH server 338 enable command-line interface 361 enable complex password 33 enable data encryption 305 enable default administration password expiration 34 enable DHCPv6 configuration 180 enable DNS 126 enable dynamic DNS 126 enable Ethernet channel 1 183 enable FTP 261 enable HTTPS port 262 enable IPv6 179 enable IPv6 stateless auto-configuration 180 enable monitoring of event log state 122 enable network interface for standby and allow IP swap 40 enable network interface for standby and prevent IP swap 41 enable NTP 245, 262 enable password change at first login 36 enable password required 37 enable RDE 263 enable RDOCE 263 enable secure SMASH over SSH 264 enable secure TCP command mode 266, 362 enable security 305 enable SLP 263 enable SMASH over Telnet 264 enable SMASH SSH server 338

management module (continued) enable SNMP agent (SNMPv1) 314 enable SNMP agent (SNMPv3) 314 enable SNMP traps 265, 314 enable SNMPv1 361 enable SNMPv1 agent 264 enable SNMPv3 361 enable SNMPv3 agent 265 enable SSH port 265 enable static IPv6 configuration 179 enable TCP command mode 266, 362 enable technician debug 306 enable Telnet port 267 enable TFTP 267 enable trespass feature 358 enable user 381 enable V3 authentication for NTP 246 enable web interface 363 Ethernet network settings commands example 200 export datacenter feature licenses 145 failover configuration 375 filter alert type 56 filter log entries by call-home events flag 122 generate host key 337 generate syslog test message 352 IBM Systems Director communication 353 ifconfig commands 171, 200 import datacenter feature licenses 145 kvm commands 208, 209 ldapcfg command 210, 219 example 219 map image 278 mcad commands 227 mount volume 278 mt commands 239, 240 network connection 13 portcfg commands 253, 254 ports command 255, 270 example 270 read CIN status table entries 102 read command 280, 282 example 282 remacccfg command 283 remotechassis command 285, 286 example 286 remove feature license 144 remove SSH public key 395 replace SSH public key 397 reset (failover) 289 reset (force failover) 289 reset (primary) 288 reset (standby) 288 reset configuration (keep logs) 103 reset network port settings 256 restore configuration from file (encryption) 281 restore configuration from file (no encryption) 280 restore configuration from midplane 280 save configuration to chassis 413

management module (continued) save configuration to file (encryption) 414 save configuration to file (no encryption) 413 save event log to TFTP server 122 sdemail commands 303 security commands 30, 305 serial connection 14, 17 serial port settings commands example 254 service command example 306 service commands 306 set account inactivity alert time 34 set account inactivity disable time 35 set account lockout period 36 set account security default to high 32 set account security default to legacy 31 set Active Directory group authority level 160 set Active Directory group name 159 set alert notification method 57 set alert recipient email address 57 set alert recipient name 55 set alert recipient status 56 set alert type 56 set authentication logging timeout 32 set CIN state for global enable or disable 97 set CLI inactivity timeout 33 set contact name 112, 113, 114 set date 106 set daylight-savings time mode 109 set DNS first IPv4 IP address 127 set DNS first IPv6 IP address 128 set DNS second IPv4 IP address 127 set DNS second IPv6 IP address 128 set DNS server priority 129 set DNS third IPv4 IP address 127 set DNS third IPv6 IP address 128 set Ethernet channel 0 address prefix length 180 set Ethernet channel 0 configuration method 176 set Ethernet channel 0 data rate 177 set Ethernet channel 0 domain name 179 set Ethernet channel 0 duplex mode 177 set Ethernet channel 0 gateway IP address (IPv4) 174 set Ethernet channel 0 gateway/default route (IPv6) 174 set Ethernet channel 0 hostname 175 set Ethernet channel 0 MAC address 178 set Ethernet channel 0 MTU 177 set Ethernet channel 0 static IP address (IPv4) 173 set Ethernet channel 0 static IP address (IPv6) 173 set Ethernet channel 0 subnet mask (IPv4) 175 set Ethernet channel 1 data rate 182

management module (continued) set Ethernet channel 1 duplex mode 182 set Ethernet channel 1 gateway IP address (IPv4) 181 set Ethernet channel 1 MAC address 183 set Ethernet channel 1 MTU 183 set Ethernet channel 1 static IP address (IPv4) 181 set Ethernet channel 1 subnet mask (IPv4) 182 set first LDAP server host name 214 set first LDAP server IP address 214 set first LDAP server port number 215 set fourth LDAP server host name 215 set fourth LDAP server IP address 215 set fourth LDAP server port number 216 set FTP data port number 256 set FTP port number 256 set FTP timeout 268 set GMT offset 107 set hostname for alerts 58 set HTTP port number 257 set HTTPS port number 257 set IP address (IPv4) 173 set IP address (IPv6) 173 set IP address for alerts 58 set LDAP client distinguished name 218 set LDAP client distinguished name password 218 set LDAP client distinguished name password (confirm) 218 set LDAP group filter 211 set LDAP group search attribute 211 set LDAP login permission attribute 212 set LDAP name 212 set LDAP root distinguished name 216 set LDAP security version 210 set LDAP server binding method 217 set LDAP server discovery method 213 set LDAP server domain name 213 set LDAP server for authentication only 217 set LDAP server forest name 213 set LDAP UID search attribute 217 set location 112 set maximum LDAP sessions for user 36 set maximum number of login failures 35 set maximum number of simultaneous sessions for user 390 set minimum number of different characters for password 34 set name 111 set NTP server hostname 245 set NTP server IP address 245 set NTP server key 246

management module (continued) set NTP update frequency 246 set password expiration time 37 set password minimum change interval 37 set password reuse cycle 38 set privacy password (SNMPv3) 392 set Remote Presence port number 257 set second LDAP server host name 214 set second LDAP server IP address 214 set second LDAP server port number 215 set secure TCP command mode port number 260 set serial port baud rate 253 set serial port communication rate 253 set serial port parity 253 set serial port stop bits 254 set server host name 311 set server IP address 311 set SLP address type 309 set SLP multicast address 309 set SLP port number 258 set SMASH Telnet port number 258 set SMTP e-mail server domain name 312 set SNMP agent port number 259 set SNMP community 1 first host name 316 set SNMP community 1 first host name - get 318 set SNMP community 1 first host name to set 317 set SNMP community 1 IP address (first host) 316 set SNMP community 1 IP address (first host) to get 318 set SNMP community 1 IP address (first host) to set 317 set SNMP community 1 IP address (second host) 319 set SNMP community 1 IP address (third host) 320 set SNMP community 1 name 315 set SNMP community 1 second host name 319 set SNMP community 1 third host name 320 set SNMP community 1 view type (SNMPv3) 320 set SNMP community 2 first host name 321 set SNMP community 2 IP address (first host) 321 set SNMP community 2 IP address (second host) 322 set SNMP community 2 IP address (third host) 323 set SNMP community 2 name 321 set SNMP community 2 second host name 322 set SNMP community 2 third host name 323

management module (continued) set SNMP community 2 view type (SNMPv3) 323 set SNMP community 3 first host name 324 set SNMP community 3 IP address (first host) 324 set SNMP community 3 IP address (second host) 325 set SNMP community 3 IP address (third host) 326 set SNMP community 3 name 324 set SNMP community 3 second host name 325 set SNMP community 3 third host name 326 set SNMP community 3 view type (SNMPv3) 326 set SNMP contact name 327 set SNMP location 328 set SNMP traps port number 259 set SSH port number 260 set state for KVM port 262 set syslog event log collector 1 IP address 350 set syslog event log collector 1 port number 351 set syslog event log collector 2 IP address 350 set syslog event log collector 2 port number 351 set syslog filter level 349 set TCP command mode port number 260 set TCP command-mode timeout 268 set Telnet port number 261 set Telnet port timeout 268 set TFTP port number 261 set third LDAP server host name 214 set third LDAP server IP address 214 set third LDAP server port number 216 set time 106 set trespass feature message 358 set trespass feature to default 359 set tsyslog event log collector 1 host name 350 set tsyslog event log collector 2 host name 350 set user access type (SNMPv3) 392 set user authentication method 33 set user authentication protocol (SNMPv3) 391 set user authority level 388 set user context name (SNMPv3) 390 set user hostname (SNMPv3 traps) 393 set user IP address (SNMPv3 traps) 393 set user name 385 set user password 386 set user privacy protocol (SNMPv3) 391 set web interface inactivity timeout 38 slp command 309 example 309

management module (continued) smtp commands 311, 312 SMTP settings commands example 312 snmp commands 314, 328 SNMP settings commands example 328 SSH connection 18 sshcfg command 337, 338 example 338 SSL certificate status 339 SSL status 339 synchronize with NTP server 247 telnet configuration 356 telnet timeout 356 terminate user session 379 trespass command 358, 359 example 359 turn secure TCP command mode on or off 267, 363 turn TCP command mode on or off 266, 362 unacknowledge call-home activity log entry 94 unlock user 382 unmount volume 278 uplink configuration 375 upload SSH public key 396 view configuration 225 view power management policy 252 vlan command 402, 410 example 410 write command 413, 414 example 414 management module (advanced) disable logical uplink failover 376 enable logical uplink failover 376 enable physical uplink failover 375 logical uplink failover delay 376 logical uplink failover IP address 376 logical uplink failover IPv6 IP address 377 physical uplink failover delay 375 set logical link loss alert and failover policy 377 management module (primary) display Ethernet channel 0 configuration 171 display Ethernet channel 1 configuration 181 reset 288 management module (standby) display Ethernet channel 0 configuration 172 reset 288 set Ethernet channel 0 hostname 176 set Ethernet channel 0 MAC address 178 set Ethernet channel 0 static IP address (IPv4) 173 set Ethernet channel 0 static IP address (IPv6) 174 set IP address (IPv4) 173 set IP address (IPv6) 174 management module air filter command 42

management module event log commands 28 management module failover commands 375 management module telnet configuration commands example 356 management module uplink failover commands example 377 management module web server generate CSR 343 generate self-signed certificate 341 management module, group LDAP authentication 159 management module, user accounts 379 management network DHCP configuration display for blade server 117 management-module firmware 2 manufacturer update in firmware build ID list 82 map image advanced management module volume 278 maximum LDAP sessions for user set for management module 36 maximum number of login failures set for management module 35 mcad 227 options e 227 mcad command errors 457 mcad commands 227 example 227 media trav command target 134 display owner 239 display temperature 357 set owner 239 media tray temperature display 149 media tray, display power trending 152 memory command target 133 memory commands 29 microprocessor command target 133 minimum number of different characters for password set for management module 34 modactlog 228 modactlog command errors 457 modactlog commands 228 example 228 module (blade server) display activity 228 display information 228 monalerts 229 options ca 229 cb 230 ccd 231 ccsm 231 ciom 230, 233, 235 cpm 231 ec 229 ia 234

monalerts (continued) options (continued) ib 235 icd 238 icsm 236 iel 237 iinv 236 iiom 235 inc 237 ipm 238 ipon 236 iua 237 wa 232 wb 232 wcd 234 wcsm 233 wel 233 wiom 232 wpm 234 monalerts command errors 457 monalerts commands 229 example 238 monalertsleg command errors 458 monalertsleg commands 229 monitoring disable for all critical alerts 229 disable for all informational alerts 234 disable for all warning alerts 232 disable for blade device critical alerts 230 disable for blade device informational alerts 235 disable for blade device warning alerts 232 disable for chassis critical alerts 231 disable for chassis informational alerts 236 disable for chassis warning alerts 233 disable for cooling device critical alerts 231 disable for cooling device informational alerts 238 disable for cooling device warning alerts 234 disable for event log informational alerts 237 disable for event log warning alerts 233 disable for I/O module critical alerts 230 disable for I/O module informational alerts 235 disable for I/O module warning alerts 232 disable for inventory change informational alerts 236 disable for network change informational alerts 237 disable for power module critical alerts 231 disable for power module informational alerts 238 disable for power module warning alerts 234 disable for power state informational alerts 236

monitoring (continued) disable for storage module critical alerts 230 disable for storage module informational alerts 235 disable for storage module warning alerts 233 disable for system management critical alerts 231 disable for system management informational alerts 236 disable for system management warning alerts 233 disable for user activity informational alerts 237 enable for all critical alerts 229 enable for all informational alerts 234 enable for all warning alerts 232 enable for blade device critical alerts 230 enable for blade device informational alerts 235 enable for blade device warning alerts 232 enable for chassis critical alerts 231 enable for chassis informational alerts 236 enable for chassis warning alerts 233 enable for cooling device critical alerts 231 enable for cooling device informational alerts 238 enable for cooling device warning alerts 234 enable for event log informational alerts 237 enable for event log warning alerts 233 enable for I/O module critical alerts 230 enable for I/O module informational alerts 235 enable for I/O module warning alerts 232 enable for inventory change informational alerts 236 enable for network change informational alerts 237 enable for power module critical alerts 231 enable for power module informational alerts 238 enable for power module warning alerts 234 enable for power state informational alerts 236 enable for storage module critical alerts 230 enable for storage module informational alerts 235 enable for storage module warning alerts 233 enable for system management critical alerts 231 enable for system management informational alerts 236

monitoring (continued) enable for system management warning alerts 233 enable for user activity informational alerts 237 mount volume advanced management module 278 239 mt options b 239 local 239 remote 240 mt command errors 458 mt commands 239 example 240 MTU set for channel 0 of management module 177 set for channel 1 of management module 183 multiple video sessions disable for blade servers 192 enable for blade servers 192 multiplexer expansion module command target 135 reset (failover) 289

Ν

name display BladeCenter units on network filtered by 286 display for blade server 111 display for management module 111 set for blade server 111 set for management module 111 name (contact) set for management module 112, 113, 114 nat 241 options activate 241 en 244 243 ep 243 ip pi 242 242 pn reset 241 nat command 241 example 244 nat command errors 458 NAT external port number set for I/O module 243 NAT internal port number set for I/O module 243 NAT protocol ID set for I/O module 242 NAT protocol name set for I/O module 242 NAT table disable for I/O module 244 enable for I/O module 244 NEBS, disable 153 network card display configuration information 184

network clock module command target 135 power off $2\overline{72}$ power on 272 turn off 272 turn on 272 network configuration status display for blade server 184 network interface disable for standby management module 40 enable for standby management module and allow IP swap during failover 40 enable for standby management module and prevent IP swap during failover 41 network port settings display for management module 255 display for switch 269 reset for management module 256 network protocol settings activate for I/O module 241 display for I/O module 241 reset for I/O module 241 network settings display for BladeCenter unit 192 display for I/O module 193 New Zealand Class A statement 497 node information display for scalable complex 293 notes, important 494 notices 493 electronic emission 496 FCC, Class A 496 notification method, set for alerts 57 ntp 245 options en, enabled 245 f 246 i 245 synch 247 v3 246 v3en, enabled 246 NTP enable for management module 245, 262 ntp command 245 example 247 ntp command errors 459 NTP configuration display for management module 245 NTP server synchronize management module clock 247 NTP server hostname set for management module 245 NTP server IP address set for management module 245 NTP server key set for management module 246 NTP update frequency set for management module 246

0

online documentation 1

open ports display for management module 255 options a 102 f 102 out-of-band communication, IBM Systems Director 353 override persistent command environment 7

Ρ

parity set for serial port of management module 253 particulate contamination 495 partition create for scalable complex 296 delete all from scalable complex 296 delete from scalable complex 297 power cycle in scalable complex 299 power off in scalable complex 299 power on in scalable complex 298 partition (automatic) create for scalable complex 294 partition information display for scalable complex 293 partition mode set to partition for scalable complex 298 set to stand alone for scalable complex 297 password change for user 387 LDAP distinguished name 218 password (confirm) LDAP distinguished name 218 password expiration time set for management module 37 password minimum change interval set for management module 37 password reuse cycle set for management module 38 path information display for management channel 204 People's Republic of China Class A electronic emission statement 499 persistent command environment override 7 persistent command target 6 ping I/O-module IP address 249 IP address 248 IP address (I/O-module) 249 r 248, 249 ping command errors 459 ping commands 248 example 249 pmpolicy 251 options pd 251 pdx 251 view for management module 252 pmpolicy command example 252 pmpolicy command errors 460

polling interval, set for power trending 152 portcfg options com1 253 com1, b 253 com1, p 253 com1, s 254 portcfg command errors 460 portcfg commands 253 example 254 ports 255 options -kvme, state 262 ftpdp 256 ftpe, on 261 ftpp 256 ftpt 268 httpp 257 httpse, on 262 httpsp 257 ntpe, on 262 open 255 rde, on 263 rdoce, on 263 reset 256 rpp 257 slpe, on 263 slpp 258 smashse, on 264 smashte, on 264 smashtp 258 snmplae, on 264 snmp3ae, on 265 snmpap 259 snmpte, on 265 snmptp 259 sshe, on 265 sshp 260 stcme, on 266 stcme, port mode 267 stcmp 260 tcme, on 266 tcme, port mode 266 tcmp 260 tcmt 268 telnete, on 267 telnetp 261 telnett 268 tftpe, on 267 tftpp 261 switch 269, 270 ports (open) display for management module 255 ports command 255 example 270 ports command errors 460 POST status display for I/O module 276 display for switch module 276 power options ap 275 cycle 273 cycle, c 273 fp 275, 276 local 274, 275

power (continued) options (continued) off 272 on 272 on, c 272 softoff 273 state 273 state, post 276 wol 274 power capping, enable for blade server 154 power capping, set for blade server 154 power command errors 462 power commands 272 example 277 power control commands 29 power cycle partition scalable complex 299 power domain disable acoustic mode 153 disable NEBS environment mode 153 enable acoustic mode 153 enable NEBS environment mode 153 power domain information display (detailed) 150 power domain information display (overview) 149 power domain redundancy loss policy, set 151 power domain, display power trending 151, 152 power management commands 29 power management policy display all 251 BladeCenter S policies 251 specified power domain policies 251 set for specified power domain 251 power management, enable for blade server 154, 155 power module command target 134 power off alarm panel module 272 blade server 272, 273 I/O module 272 network clock module 272 switch module 272, 273 power off partition scalable complex 299 power on alarm panel module 272 blade server 272, 273 I/O module 272, 273 network clock module 272 switch module 272, 273 power on (to console) blade server 272, 273 power on partition scalable complex 298 power polling interval, set 152 power saver mode, enable for blade server 155 power state display for blade server 273

power state (continued) display for I/O module 273 display for switch module 273 power trending, display (blade server) 151, 152 power trending, display (blower) 151, 152 power trending, display (I/O module) 151, 152 power trending, display (power domain) 151, 152 power trending, display (system) 151, 152 primary management module 7 problem description call-home 95 email 303 service information 303 product service, IBM Taiwan 491 protected mode enable for I/O module 197

R

RAID controller set gateway IP address (IPv4) 199 set subnet mask (IPv4) 200 RAID IP address (IPv4) set for I/O module 199 RDF enable for management module 263 rdoc 278 options map 278 mount 278 unmount 278 rdoc command errors 462 rdoc commands 278 example 279 RDOCE enable for management module 263 read 280 options config 280 config, auto, off 282 config, auto, on 281 config, 1, i 280 config, l, i, p 281 read CIN configuration status table entries 102 read CIN status table entries for management module 102 read command 280 example 282 read command errors 463 redirect command 25, 131 redundancy loss policy, power domain (set) 151 reload all information 204 reload firmware information 204 reload hardware information 204 reload MAC address information 204 reload MAC addresses information 204 reload WNN information 204 remacccfg 283 mode 283 slto 284

remacccfg (continued) srrto 284 srto 284 sto 283 remacccfg command 283 remacccfg command errors 464 remote alert set retry interval 51 set retry limit 52 remote media tray switching enable globally 240 remote presence access display 283 set 405 remote presence disconnection mode set 283 Remote Presence port number set for management module 257 remotechassis 285 options clear 286 health 285 ip 285 name 286 remotechassis command 285 example 286 remotechassis command errors 464 remove 346, 347, 348 remove feature license management module 144 remove SSH public key 395 replace SSH public key 397 required, firmware 2 required, hardware 2 reset 288 blade server 72, 288 I/O module 288 ISMP 288 management module (primary) 288 management module (standby) 288 options c 289 clr 291 ddg 291 dg 291 exd 290 f 289 force 289 full 290 sft 290 sms 292 standby 288 std 289 service processor 288 switch module 288 reset (clear NVRAM) blade server 291 reset (enter SMS menu) blade server 292 reset (extended diagnostics) I/O module 290 switch module 290 reset (failover) management module 289 multiplexer expansion module 289 reset (force failover) management module 289

reset (full diagnostics) I/O module 290 switch module 290 reset (run diagnostics with boot sequence) blade server 291 reset (run diagnostics) blade server 291 reset (standard diagnostics) I/O module 289 switch module 289 reset (to console) blade server 72, 289 reset (with NMI) blade server 290 reset blase server key sequence set for SOL 335 reset command 29 reset command errors 465 reset commands 288 example 292 reset configuration I/O module 103 switch module 103 reset configuration (keep logs) management module 103 reset default configuration 103 reset network port settings management module 256 reset network protocol settings I/O module 241 responding to thermal events 153 restore configuration management module (from file with encryption) 281 management module (from file with no encryption) 280 management module (from midplane) 280 restore configuration commands 29 restore management module configuration command example 282 retry count set for SOL 331 retry interval set for remote alerts 51 set for SOL 330 retry limit set for remote alerts 52 retry number set for remote alerts 51 revert to old IP address configuration after reset I/O module 195 RSA host key information display for management module 337 Russia Class A electromagnetic interference statement 499 Russia Electromagnetic Interference (EMI) Class A statement 499

S

SAS system set gateway IP address (IPv4) 199 set subnet mask (IPv4) 200 SAS zone activate for I/O module 415 SAS zone information display for I/O module 416 SAS zone list display for I/O module 415 save configuration commands 29 save configuration to chassis management module 413 save configuration to file (encryption) management module 414 save configuration to file (no encryption) management module 413 save event log to TFTP server management module 122 save management module configuration command example 414 save service information save to TFTP server 124 scalable complex create partition 296 create partition (automatically) 294 create stand-alone partition 295 create stand-alone partition (automatically) 294 delete all partitions 296 delete partition 297 display all information 293 display node information 293 display partition information 293 display specific complex information 293 power cycle partition 299 power off partition 299 power on partition 298 set partition mode to partition 298 set partition mode to stand alone 297 scale 293 options auto 294 compid 293 compid, partition 293 create 295, 296 cycle 299 delete 296, 297 mode 297, 298 node 293 off 299 on 298 scale command errors 465 scale commands 293 example 300 sddump options coll 301 init 301 sddump command errors 466 sddump commands 301 example 302 sdemail options subj 303 to 303 sdemail command errors 467 sdemail commands 303

search domain set for Domain Catalog discovery 213 secure command-line interface 14 Secure Shell connection clients 14 secure shell server disabling 19 Secure Shell server exit codes (CLI) 20 using 18 secure SMASH enabling 19 secure SMASH over SSH enable for management module 264 secure TCP command mode disable 354 enable 354 enable for management module 266, 362 set number of sessions 354 turn secure TCP command mode on or off for the management module 267, 363 secure TCP command mode port number set for management module 260 security 14, 305 display management module account settings 30 display management module setting 305 enable complex password for management module user authentication 33 enable default administration password expiration for management module 34 enable for management module 305 enable password change at first login to management module 36 enable password required for management module 37 options e 305 set management module account default to high 32 set management module account default to legacy 31 set management module account inactivity alert time 34 set management module account inactivity disable time 35 set management module account lockout period 36 set management module authentication logging timeout 32 set management module CLI inactivity timeout 33 set management module maximum LDAP sessions for user 36 set management module maximum number of login failures 35 set management module minimum number of different characters for password 34 set management module password expiration time 37

example 303

security (continued) set management module password minimum change interval 37 set management module password reuse cycle 38 set management module user authentication method 33 set management module web interface inactivity timeout 38 security command errors 467 security commands 305 account security 30 example 305 selecting command environment 6 selecting command target 6 self-signed certificate generate for LDAP client 341 generate for management module web server 341 self-signed certificate (SSL) download certificate file 344 import certificate file 345 upload certificate file 345 send threshold set for SOL 331 sending diagnostic data to IBM 490 Serial Over LAN 22 Serial Over LAN commands 330 example 335 serial port baud rate set for management module 253 serial port communication rate set for management module 253 serial port configuration display for management module 253 serial port parity set for management module 253 serial port settings for management module commands example 254 serial port stop bits set for management module 254 server host name set for management module 311 server IP address set for management module 311 service 306 options disable 306 enable 306 Service Advisor contact information 89 disable 88 display owner 87 enable 88 HTTP proxy setup 91 service and support before you call 489 hardware 491 software 491 service command example 306 service command errors 467 service commands 306 service data collect for blade server 301 display command 124

service data (continued) display for blade server 301 dump from blade server 301 get for blade server 301 service information capture 124 display 124 email 303 exclude from email alerts 51 include with email alerts problem description 303 save to TFTP server 124 service processor command target 133 reset 288 service setting display for management module 306 session command 29 session lost timeout interval set 284 session request retry timeout interval set 284 session request timeout interval set 284 session timeout interval 283 set set date, management module 106 daylight-savings time mode, management module 109 GMT offset, management module 107 power management policy specified power domain 251 remote presence access 405 remote presence disconnection mode 283 session lost timeout interval 284 session request retry timeout interval 284 session request timeout interval 284 session timeout interval 283 sol access 406 TCP command-mode session timeout 353 time, management module 106 VLAN configuration 407 VLAN entry name 407 VLAN gateway 409 VLAN ID 405 VLAN IP address 408 VLAN subnet 408 VLAN subnet mask 410 VLAN subnet route 409 VLAN tagging 406 set accumulate timeout SOL 332 set Active Directory group authority level 160 set Active Directory group name 159 set address prefix length blade server 190 I/O module 198 set alarm 49 set alert notification method 57 set alert recipient email address 57 set alert recipient name 55

set alert recipient status 56 set alert type 56 set automatic power-on policy BladeCenter unit 275 set boot mode blade server 74 set CIN state for disable management module 97 set CIN state for enable management module 97 set CLI key sequence SOL 334 set command-line timeout management module 356 set contact name management module 112, 113, 114 set DNS first IPv4 IP address management module 127 set DNS first IPv6 IP address management module 128 set DNS second IPv4 IP address management module 127 set DNS second IPv6 IP address management module 128 set DNS server priority management module 129 set DNS third IPv4 IP address management module 127 set DNS third IPv6 IP address management module 128 set Ethernet channel 0 address prefix length management module 180 set Ethernet channel 0 configuration method management module 176 set Ethernet channel 0 data rate management module 177 set Ethernet channel 0 domain name management module 179 set Ethernet channel 0 duplex mode management module 177 set Ethernet channel 0 gateway IP address (IPv4) management module 174 set Ethernet channel 0 gateway/default route (IPv6) management module 174 set Ethernet channel 0 hostname management module 175 standby management module 176 set Ethernet channel 0 MAC address management module 178 standby management module 178 set Ethernet channel 0 MTU management module 177 set Ethernet channel 0 static IP address (IPv4) management module 173 standby management module 173 set Ethernet channel 0 static IP address (IPv6) management module 173 standby management module 174 set Ethernet channel 0 subnet mask (IPv4) management module 175

set Ethernet channel 1 data rate management module 182 set Ethernet channel 1 duplex mode management module 182 set Ethernet channel 1 gateway IP address (IPv4) management module 181 set Ethernet channel 1 MAC address management module 183 set Ethernet channel 1 MTU management module 183 set Ethernet channel 1 static IP address (IPv4) management module 181 set Ethernet channel 1 subnet mask (IPv4) management module 182 set Ethernet channel configuration method blade server 188 set Ethernet channel gateway IP address (IPv4) blade server 186 set Ethernet channel gateway/default route (IPv6) blade server 187 set Ethernet channel hostname blade server 189 set Ethernet channel static IP address (IPv4) blade server 185 set Ethernet channel static IP address (IPv6) blade server 186 set Ethernet channel subnet mask (IPv4) blade server 187 set Ethernet channel VLAN ID blade server 188 set Ethernet-over-USB setting blade server 137 set first LDAP server host name management module 214 set first LDAP server IP address management module 214 set first LDAP server port number management module 215 set fourth LDAP server host name management module 215 set fourth LDAP server IP address management module 215 set fourth LDAP server port number management module 216 set FTP data port number management module 256 set FTP port number management module 256 set FTP timeout management module 268 set gateway IP address (IPv4) I/O module 194 RAID controller 199 SAS system 199 set gateway IP address (IPv6) I/O module 195 set hostname for alerts 58 set HTTP port number management module 257

set HTTPS port number management module 257 set I/O module for blade server management traffic blade server 184 set IP address (IPv4) blade server 185 blade server ISMP 191 I/O module 194 management module 173 standby management module 173 set IP address (IPv6) blade server 186 I/O module 194 management module 173 standby management module 174 set IP address for alerts 58 set KVM owner 208 set LDAP client distinguished name management module 218 set LDAP client distinguished name password management module 218 set LDAP client distinguished name password (confirm) management module 218 set LDAP group filter management module 211 set LDAP group search attribute management module 211 set LDAP login permission attribute management module 212 set LDAP name management module 212 set LDAP security version management module 210 set LDAP server binding method management module 217 set LDAP server discovery method management module 213 set LDAP server domain name management module 213 set LDAP server for authentication only management module 217 set LDAP server forest name management module 213 set LDAP server root distinguished name management module 216 set LDAP UID search attribute management module 217 set location management module 112 set logical link loss alert and failover policy advanced management module 377 management module (advanced) 377 set logical uplink failover delay advanced management module 376 management module (advanced) 376 set logical uplink failover IP address advanced management module 376 management module (advanced) 376 set logical uplink failover IPv6 IP address advanced management module 377 management module (advanced) 377 set management module account inactivity alert time 34

set management module account inactivity disable time 35 set management module account lockout period 36 set management module account security default high 32 legacy 31 set management module authentication logging timeout 32 set management module CLI inactivity timeout 33 set management module maximum LDAP sessions for user 36 set management module maximum number of login failures 35 set management module minimum number of different characters for password 34 set management module password expiration time 37 set management module password minimum change interval 37 set management module password reuse cycle 38 set management module user authentication method 33 set management module web interface inactivity timeout 38 set maximum number of simultaneous sessions for user 390 set media tray owner 239 set name blade server 111 management module 111 set NAT external port number I/O module 243 set NAT internal port number I/O module 243 set NAT protocol ID I/O module 242 set NAT protocol name I/O module 242 set NTP server hostname management module 245 set NTP server IP address management module 245 set NTP server key management module 246 set NTP update frequency management module 246 set number of sessions secure TCP command mode 354 TCP command mode 354 set partition mode to partition scalable complex 298 set partition mode to stand alone scalable complex 297 set physical uplink failover delay advanced management module 375 management module (advanced) 375 set port speed switch 270 set power capping for blade server 154 set power domain redundancy loss policy 151 set power polling interval 152

set privacy password (SNMPv3) 392 set Remote Presence port number management module 257 set reset blase server key sequence SOL 335 set retry count SOL 331 set retry interval 51 SOL 330 set retry limit remote alerts 52 set retry number 51 remote alerts 51 set SAS controller IP address (IPv4) I/O module 199 set second LDAP server host name management module 214 set second LDAP server IP address management module 214 set second LDAP server port number management module 215 set secure TCP command mode port number management module 260 set send threshold SOL 331 set serial port baud rate management module 253 set serial port communication rate management module 253 set serial port parity management module 253 set serial port stop bits management module 254 set server host name management module 311 set server IP address management module 311 set SLP address type management module 309 set SLP multicast address management module 309 set SLP port number management module 258 set SMASH Telnet port number management module 258 set SMTP e-mail server domain name management module 312 set SNMP agent port number management module 259 set SNMP community 1 first host name management module 316 set SNMP community 1 first host name -get management module 318 set SNMP community 1 first host name to set management module 317 set SNMP community 1 IP address (first host) management module 316 set SNMP community 1 IP address (first host) to get management module 318 set SNMP community 1 IP address (first host) to set management module 317

set SNMP community 1 IP address (second host) management module 319 set SNMP community 1 IP address (third host) management module 320 set SNMP community 1 name management module 315 set SNMP community 1 second host name management module 319 set SNMP community 1 third host name management module 320 set SNMP community 1 view type (SNMPv3) management module 320 set SNMP community 2 first host name management module 321 set SNMP community 2 IP address (first host) management module 321 set SNMP community 2 IP address (second host) management module 322 set SNMP community 2 IP address (third host) management module 323 set SNMP community 2 name management module 321 set SNMP community 2 second host name management module 322 set SNMP community 2 third host name management module 323 set SNMP community 2 view type (SNMPv3) management module 323 set SNMP community 3 first host name management module 324 set SNMP community 3 IP address (first host) management module 324 set SNMP community 3 IP address (second host) management module 325 set SNMP community 3 IP address (third host) management module 326 set SNMP community 3 name management module 324 set SNMP community 3 second host name management module 325 set SNMP community 3 third host name management module 326 set SNMP community 3 view type (SNMPv3) management module 326 set SNMP contact name management module 327 set SNMP location management module 328 set SNMP traps port number management module 259 set SSH port number management module 260

set state for KVM port management module 262 set static IP address (IPv4) blade server ISMP 191 set subnet mask (IPv4) I/O module 196 RAID controller 200 SAS system 200 set syslog event log collector 1 host name management module 350 set syslog event log collector 1 IP address management module 350 set syslog event log collector 1 port number management module 351 set syslog event log collector 2 host name management module 350 set syslog event log collector 2 IP address management module 350 set syslog event log collector 2 port number management module 351 set syslog filter level management module 349 set TCP command mode port number management module 260 set TCP command-mode timeout management module 268 set Telnet port number management module 261 set Telnet port timeout management module 268 set telnet timeout management module 356 set TFTP port number management module 261 set third LDAP server host name management module 214 set third LDAP server IP address management module 214 set third LDAP server port number management module 216 set trespass feature message management module 358 set trespass feature to default management module 359 set user access type (SNMPv3) 392 set user authentication protocol (SNMPv3) 391 set user authority level 388 set user context name (SNMPv3) 390 set user hostname (SNMPv3 traps) 393 set user IP address (SNMPv3 traps) 393 set user name 385 set user password 386 set user privacy protocol (SNMPv3) 391 set VLAN ID BladeCenter unit 192 shutdown blade server 273, 308 options f 308 shutdown command errors 468 shutdown commands 308 example 308 simultaneous sessions

set maximum number for user 390

slp 309 options i 309 t 309 SLP enable for management module 263 SLP address type set for management module 309 slp command 309 example 309 slp command errors 468 SLP multicast address set for management module 309 SLP port number set for management module 258 SLP settings display for management module 309 SMASH (secure) over SSH enable for management module 264 SMASH CLP enabling 19 SMASH over Telnet enable for management module 264 SMASH SSH server disable for management module 338 enable for management module 338 SMASH Telnet port number set for management module 258 smtp 311 options d 312 s 311 smtp command errors 468 smtp commands 311 example 312 SMTP e-mail server domain name set for management module 312 SMTP server host name display for management module 311 SMTP server IP address display for management module 311 SMTP settings for management module commands example 312 snmp 314 options -ca1 get -c1i1 0.0.0.0 318 -ca1 set -c1i1 0.0.0.0 317 a, on 314 a3, on 314 c1 315 c1i1 316 c1i2 319 c1i3 320 c2 321 c2i1 321 c2i2 322 c2i3 323 c3 324 c3i1 324 c3i2 325 c3i3 326 320 ca1 ca2 323 ca3 326 cn 327 1 328

snmp (continued) options (continued) t, on 314 SNMP agent enable for management module (SNMPv1) SNMPv1 314 enable for management module (SNMPv3) SNMPv3 314 SNMP agent port number set for management module 259 snmp command errors 469 snmp commands 314 example 328 SNMP community 1 first host name set for management module 316 set to get for management module 318 SNMP community 1 first host name to set set for management module 317 SNMP community 1 IP address (first host) set for management module 316 SNMP community 1 IP address (first host) to get set to get for management module 318 SNMP community 1 IP address (first host) to set set for management module 317 SNMP community 1 IP address (second host) set for management module 319 SNMP community 1 IP address (third host) set for management module 320 SNMP community 1 name set for management module 315 SNMP community 1 second host name set for management module 319 SNMP community 1 third host name set for management module 320 SNMP community 1 view type set for management module (SNMPv3) 320 SNMP community 2 first host name set for management module 321 SNMP community 2 IP address (first host) set for management module 321 SNMP community 2 IP address (second host) set for management module 322 SNMP community 2 IP address (third host) set for management module 323 SNMP community 2 name set for management module 321 SNMP community 2 second host name set for management module 322 SNMP community 2 third host name set for management module 323 SNMP community 2 view type set for management module (SNMPv3) 323

SNMP community 3 first host name set for management module 324 SNMP community 3 IP address (first host) set for management module 324 SNMP community 3 IP address (second host) set for management module 325 SNMP community 3 IP address (third host) set for management module 326 SNMP community 3 name set for management module 324 SNMP community 3 second host name set for management module 325 SNMP community 3 third host name set for management module 326 SNMP community 3 view type set for management module (SNMPv3) 326 SNMP configuration display for management module 314 SNMP contact name set for management module 327 SNMP location set for management module 328 SNMP settings for management module commands example 328 SNMP traps disable for management module 314 enable for management module 265, 314 SNMP traps port number set for management module 259 SNMPv1 enable for management module 361 SNMPv1 agent enable for management module 264 SNMPv3 community 1 view type 320 community 2 view type 323 community 3 view type 326 enable for management module 361 privacy password 392 trap receiver IP address or hostname 393 user access type 392 user authentication protocol 391 user context name 390 user privacy protocol 391 SNMPv3 agent enable for management module 265 software service and support telephone numbers 491 sol 330 options c 331 e 334 i 330 r 335 s 331 332, 333 status t 332 SOL 22, 23, 115 global disable 333 global enable 332

SOL (continued) set accumulate timeout 332 set CLI key sequence 334 set reset blase server key sequence 335 set retry count 331 set retry interval 330 set send threshold 331 status 330 sol access set 406 sol command errors 470 sol commands example 335 SOL commands 330 SOL session ending 23, 115 starting 22 Specify IP address CIN configuration entry 99 Specify VLAN ID CIN configuration 100 SRC record display specific for blade server 124 SRC records display all for blade server 124 SSH disabling 19 SSH clients 14 SSH connection 18 SSH port enable for management module 265 SSH port number set for management module 260 SSH public key add 394 SSH public key add (specific) 394 SSH public key comment 400 SSH public key connection 399 SSH public key display 393 SSH public key download 398 SSH public key remove 395 SSH public key replace 397 SSH public key upload 396 SSH status display for management module 337 sshcfg 337 options cstatus 338 hk, dsa 337 hk, gen 337 hk, rsa 337 sstatus 338 sshcfg command 337 example 338 sshcfg command errors 471 SSL disable for LDAP client 340 enable for LDAP client 340 SSL certificate (additional) disable for standby management module 339 enable for standby management module 339 SSL certificate status management module 339 SSL CSR download certificate file 344

SSL CSR (continued) import certificate file 345 upload certificate file 345 SSL for LDAP client disable 340 enable 340 SSL for management module web server disable 339 enable 339 SSL for web server disable for management module 339 enable for management module 339 SSL self-signed certificate download certificate file 344 import certificate file 345 upload certificate file 345 SSL status management module 339 SSL trusted certificate 1 346 download 346 import 346 remove 346 upload 346 SSL trusted certificate 2 347 download 347 import 347 remove 347 upload 347 SSL trusted certificate 3 348 download 348 import 348 remove 348 upload 348 sslcfg 339 options ac 339 c 341, 343 cert 341 cl 341, 343 client 340 cp 341, 343 cpwd 343 csr 343 dnld 344 dq 341, 343 341, 343 ea gn 341, 343 hn 341, 343 i 344, 345, 346, 347, 348 in 341, 343 1 344, 345, 346, 347, 348 on 341, 343 ou 341, 343 s 341.343 server 339 sp 341, 343 tc1 346 tc2 347 tc3 348 un 343 upld 345 sslcfg command errors 472 sslcfg commands 339 example 348 stand-alone partition create for scalable complex 295

stand-alone partition (automatic) create for scalable complex 294 standby management module disable additional SSL certificate 339 enable additional SSL certificate 339 set Ethernet channel 0 hostname 176 set Ethernet channel 0 MAC address 178 set Ethernet channel 0 static IP address (IPv4) 173 set Ethernet channel 0 static IP address (IPv6) 174 set IP address (IPv4) 173 set IP address (IPv6) 174 standby management modules 7 starting a session using SSH 18 starting a session using Telnet 16 starting an SOL session 22 starting command-line interface 14 state VLAN 403 static IP address (IPv4) set for blade server ISMP 191 set for channel 0 of management module 173 set for channel 0 of standby management module 173 set for channel 1 of management module 181 set for channel of blade server 185 static IP address (IPv6) set for channel 0 of management module 173 set for channel 0 of standby management module 174 set for channel of blade server 186 static IPv6 configuration disable for I/O module 197 disable for management module 179 enable for I/O module 197 enable for management module 179 status display for management module 124 SOL 330 stop bits set for serial port of management module 254 storage expansion unit command target 133 storage module command target 135 subnet mask (IPv4) set for channel 0 of management module 175 set for channel 1 of management module 182 set for channel of blade server 187 set for I/O module 196 set for RAID controller 200 set for SAS system 200 support web page, custom 490 switch display network port settings 269 enable port 269 set port speed 270 switch module command target 134

switch module (continued) cycle power 273 display POST status 276 display power state 273 power off 272, 273 power on 272, 273 reset 288 290 reset (extended diagnostics) reset (full diagnostics) 290 reset (standard diagnostics) 289 reset configuration 103 turn off 272, 273 turn on 272, 273 synchronize clock with NTP server management module 247 syntax help 166 syntax help commands example 166 syslog 349 options coll1 349 coll2 350 i1 350 i2 350 p1 351 351 p2 sev 349 test 352 syslog command errors 474 syslog commands 349 example 352 syslog configuration display for management module 349 syslog event log collector 1 host name set for management module 350 syslog event log collector 1 IP address set for management module 350 syslog event log collector 1 port number set for management module 351 syslog event log collector 2 host name set for management module 350 syslog event log collector 2 IP address set for management module 350 syslog event log collector 2 port number set for management module 351 syslog event log transmission for collector disable 349 disable for management module 349 enable 349 enable for management module 349 syslog event log transmission for collector 2 disable 350 disable for management module 350 enable 350 enable for management module 350 syslog filter level set for management module 349 syslog test message generate for management module 352 system view configuration tree 225 system management command 29 system physical configuration command 225

system power management policy command 251 system, display power trending 151, 152

Т

Taiwan Class A compliance statement 499 target 25, 131 TCP command mode disable 353 enable 354 enable for management module 266, 362 set number of sessions 354 turn TCP command mode on or off for the management module 266, 362 TCP command mode port number set for management module 260 TCP command-mode session status display 353 TCP command-mode session timeout display 353 set 353 TCP command-mode timeout set for management module 268 tcpcmdmode 353 options status, 0 353, 354 status, 1 to 20 354 t 353 tcpcmdmode command errors 475 tcpcmdmode commands 353 example 355 technician debug disable for management module 306 enable for management module 306 Telco environment 153 telecommunication regulatory statement 496 telnet configuration display for management module 356 telnet configuration commands 356 Telnet connection 14, 16 Telnet port enable for management module 267 Telnet port number set for management module 261 Telnet port timeout set for management module 268 telnet timeout set for management module 356 telnetcfg 356 options t 356 telnetcfg command errors 475 telnetcfg commands 356 example 356 temperature display for blade server 357 display for management module 357 display for media tray 357 temperature display, blower 149 temperature display, media tray 149 temporary command target 7

temps command errors 476 temps commands 357 example 357 terminate 379 terminate session 143 terminate user session management module 379 test alert generate 58 test call home call-home 96 test communication I/O-module IP address 249 IP address 248 IP address (I/O-module) 249 TFTP enable for management module 267 TFTP port number set for management module 261 thermal event response 153 thermal trending, display (blower) 152 thermal trending, display (media trav) 152 thres command errors 476 time display for management module 106 set for management module 106 trademarks 493 trespass 358 options 358 tw twd 359 twe 358 trespass command 358 example 359 trespass command errors 476 trespass feature enable for management module 358 trespass feature default set for management module 359 trespass feature message set for management module 358 trespass feature status display for management module 358 trusted certificate 1 (SSL) download 346 import 346 remove 346 upload 346 trusted certificate 2 (SSL) download 347 import 347 remove 347 upload 347 trusted certificate 3 (SSL) download 348 import 348 remove 348 upload 348 turn all CIN index entries on or off 98 turn off alarm panel module 272 blade server 272, 273 I/O module 272 network clock module 272 switch module 272, 273

temps 357

turn off LED information 221 turn off location LED 169, 222 turn on alarm panel module 272 blade server 272, 273 I/O module 272, 273 network clock module 272 switch module 272, 273 turn on (to console) blade server 272, 273 turn secure TCP command mode on or off management module 267, 363 turn TCP command mode on or off management module 266, 362

U

uicfg 361 options cli, enabled 361 snmp, enabled 361 stcm, enabled 362 stcm, port mode 363 tcm, enabled 362 tcm, port mode 362 web, enabled 363 uicfg command errors 477 uicfg commands 361 example 363 unacknowledge call-home activity log entrv management module 94 United States electronic emission Class A notice 496 United States FCC Class A notice 496 unlock user 382 unmount volume advanced management module 278 update options a 365 activate 368 i, 1 370 i, l, img 371, 372 i, l, img, activate 372, 373 i, n 370 u 366 u, img 367, 368 u, img, activate 369 u, r 366 u, v 367 update command 365 update command errors 478 update commands example 373 update firmware 365, 366, 370 I/O module 367, 368, 369, 371, 372, 373 switch 367, 368, 369, 371, 372, 373 verbose 368, 372 update firmware (verbose) 367, 370 update firmware build ID in firmware build ID list blade server 83

update firmware build revision in firmware build ID list blade server 84 update firmware type in firmware build ID list blade server 83 update machine type in firmware build ID list blade server 82 update manufacturer in firmware build ID list blade server 82 uplink 375 options alert 377 dls 376 dps 375 el, enabled 376 ep, enabled 375 ip 376 ip6 377 uplink command errors 480 uplink commands 375 example 377 uplink configuration display for management module 375 uplink failover (logical) disable for advanced management module 376 disable for management module (advanced) 376 enable for advanced management module 376 enable for management module (advanced) 376 uplink failover (physical) enable for advanced management module 375 enable for management module (advanced) 375 uplink failover delay (logical) set for advanced management module 376 set for management module (advanced) 376 uplink failover delay (physical) set for advanced management module 375 set for management module (advanced) 375 uplink failover IP address (logical) set for advanced management module 376 set for management module (advanced) 376 uplink failover IPv6 IP address (logical) set for advanced management module 377 set for management module (advanced) 377 upload 346, 347, 348 upload certificate file SSL CSR 345 SSL self-signed certificate 345 upload SSH public key 396 user authentication method enable complex password 33

user authentication method (continued) set for management module 33 user interface configuration 361 example 363 user interface settings display for management module 361 user session 379 users 379 options 1 through 12 380 a 388 ap 391 at 392 clear 380 cn 390 create (n, p, a, cn, ap, pp, ppw, at, i) 383 curr 379 disable 381 enable 381 i 393 ms 390 n 385 op 387 p 386 pk, add 394 pk, af 399 pk, cm 400 pk, dnld 398 pk, e 393 pk, remove 395 pk, upld 396, 397 pp 391 ppw 392 ts 379 unlock 382 users command 379 users command errors 481 users commands example 400 users, change password 387 users, create 383 users, delete 380 users, disable 381 users, display (active) 379 users, display (all) 379 users, display (single) 380 users, enable 381 users, management module 379 users, set access type (SNMPv3) 392 users, set authentication protocol (SNMPv3) 391 users, set authority level 388 users, set context name (SNMPv3) 390 users, set hostname (SNMPv3 traps) 393 users, set IP address (SNMPv3 traps) 393 users, set maximum number of simultaneous sessions 390 users, set name 385 users, set password 386 users, set privacy password (SNMPv3) 392 users, set privacy protocol (SNMPv3) 391 users, unlock 382

using Secure Shell server 18 using the command-line interface 5

V

V3 authentication for NTP enable for management module 246 view command target 225 vlan 402 c 407 commit 402 cto 402 delete 403, 404 g 409 i 408 n 407 405 rp 408 s smx 410 sol 406 srx 409 state 403 tag 406 vi 404 vid 405 VLAN state 403 vlan command 402 example 410 vlan command errors 485 VLAN configuration set 407 VLAN entry create 404 delete 403, 404 display 404 VLAN entry name set 407 VLAN gateway set 409 VLAN ID CIN configuration 100 disable for blade server Ethernet channel 189 disable for BladeCenter unit 192 enable for blade server Ethernet channel 189 enable for BladeCenter unit 192 set 405 set for BladeCenter unit 192 set for channel of blade server 188 VLAN IP address set 408 VLAN settings commit 402 commit timeout 402 display 402 VLAN subnet set 408 VLAN subnet mask set 410 VLAN subnet route set 409 VLAN tagging set 406

voltage display for blade server 412 display for management module 412 volts 412 volts command errors 486 volts commands 412 example 412 volume information display for management module 278 zonecfg commands 415

example 416

W

Wake on LAN enable for blade server 274 enable globally 274 warning alerts disable monitoring for all 232 disable monitoring for blade device 232 disable monitoring for chassis 233 disable monitoring for cooling device 234 disable monitoring for event log 233 disable monitoring for I/O module 232 disable monitoring for power module 234 disable monitoring for storage module 233 disable monitoring for system management 233 enable monitoring for all 232 enable monitoring for blade device 232 enable monitoring for chassis 233 enable monitoring for cooling device 234 enable monitoring for event log 233 enable monitoring for I/O module 232 enable monitoring for power module 234 enable monitoring for storage module 233 enable monitoring for system management 233 web interface enable for management module 363 web interface inactivity timeout set for management module 38 WNN information reload 204 write options config 413 config, l,i 413, 414 write command 413 example 414 write command errors 486

Ζ

zonecfg 415 options activate 415 view 416 zonecfg command errors 487
IBW ®

Part Number: 00V9902

Printed in USA

(1P) P/N: 00V9902

