

IBM BladeCenter

Management Module

BladeCenter T Management Module

Advanced Management Module

BladeCenter T Advanced Management Module



User's Guide

IBM BladeCenter

Management Module

BladeCenter T Management Module

Advanced Management Module

BladeCenter T Advanced Management Module



User's Guide

Note: Before using this information and the product it supports, read the general information in Appendix A, "Getting help and technical assistance," on page 111 and Appendix B, "Notices," on page 113.

Ninth Edition (December 2006)

This edition applies to version 1.25 of management-module firmware and to all subsequent releases and modifications until otherwise indicated in new editions.

© Copyright International Business Machines Corporation 2006. All rights reserved.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Chapter 1. The BladeCenter management module	1
Related documentation	2
Notices and statements in this document	3
 Chapter 2. Using the management-module Web interface	 5
Connecting to the management module	5
Management-module connection overview	5
Hardware requirements	6
Software requirements	6
Cabling the management module	7
Networked connection	7
Direct connection	7
Connecting to the management module for the first time	7
Starting the management-module Web interface	8
Configuring the management module	10
Configuring the management module for remote access	11
Configuring the management-module Ethernet ports	11
Using the Configuration Wizard (advanced management module only)	13
Communicating with the IBM Director software	13
Configuring advanced features	14
Network and security configuration	14
Configuring SNMP	14
Configuring SMTP	17
Configuring LDAP	18
Secure Web server and secure LDAP	34
Configuring the secure shell server	45
Configuring Wake on LAN	47
Verifying the Wake on LAN configuration	48
Linux-specific configuration	48
Using the configuration file	48
Backing up your management-module configuration	49
Restoring and modifying your management-module configuration	50
Using the remote disk feature	52
Mounting a disk drive or disk image	53
Unmounting a disk drive or disk image	53
Configuring an I/O module	54
 Chapter 3. Management-module Web interface overview	 57
Web interface pages and user roles	57
Management-module Web interface options	62
Monitors	62
System Status	62
Event Log	68
LEDs	69
Fuel Gauge	71
Hardware VPD	74
Firmware VPD	75
Blade Tasks	76
Power/Restart	76
On Demand	77
Remote Control	78
Firmware Update	82
Configuration	83

Serial Over LAN	86
I/O Module Tasks	87
Admin/Power/Restart.	87
Configuration	88
Firmware Update	90
MM Control	91
General Settings	91
Login Profiles	92
Alerts	96
Serial Port (advanced management module only)	96
Port Assignments	97
Network Interfaces	99
Network Protocols	101
Security	102
Configuration File (all management modules except advanced management module)	103
Configuration Mgmt (advanced management module only)	104
Firmware Update	104
Restore Defaults (management modules other than the advanced management module)	105
Configuration Wizard (advanced management module only)	106
Restart MM.	107
Service Tools (advanced management module only).	107
Settings	107
Service Data	108
AMM Status	108
Appendix A. Getting help and technical assistance	111
Before you call	111
Using the documentation	111
Getting help and information from the World Wide Web	111
Software service and support	112
Hardware service and support	112
IBM Taiwan product service	112
Appendix B. Notices	113
Trademarks.	114
Important notes	114
Index	117

Chapter 1. The BladeCenter management module

This *Management Module User's Guide* contains information about configuring the management module and managing components that are installed in an IBM® BladeCenter® unit. Although all types of management module have similar function, their physical attributes might vary. See the *Installation Guide* for your management module for information about management-module controls and indicators, installation, cabling, and configuration.

All IBM BladeCenter unit types are referred to throughout this document as the BladeCenter unit. All management-module types are referred to throughout this document as the management module. Unless otherwise noted, all commands can be run on all management-module and BladeCenter unit types.

The management module provides system-management functions and keyboard/video/mouse (KVM) multiplexing for all of the blade servers in the BladeCenter unit that support KVM. It controls the external keyboard, mouse, and video connections, for use by a local console, and a 10/100 Mbps Ethernet remote management connection.

Each BladeCenter unit comes with at least one management module. Some BladeCenter units support installation of a second, standby management module. Only one of the management modules in a BladeCenter unit can be active, and it functions as the primary management module. If a standby management module is installed, it remains inactive until it is switched to act as primary, either manually or automatically, if the primary management module fails.

If two management modules are installed in a BladeCenter unit, they must be of the same type: the advanced management module is not compatible for installation in the same BladeCenter unit with other management module types. Both management modules must always have the same level of firmware and the same IP address, and the firmware must support redundant management-module function, to enable changeover of control from the primary (active) management module to the standby management module. The latest level of management-module firmware is available at <http://www.ibm.com/bladecenter/>.

Note: After failover, you might not be able to establish a network connection to the management module for 5 minutes.

The service processor in the management module communicates with the service processor in each blade server to support features such as blade server power-on requests, error and event reporting, KVM requests, and requests to use the BladeCenter shared media tray (removable-media drives and USB ports).

You configure BladeCenter components by using the management module, setting information such as IP addresses. The management module communicates with all components in the BladeCenter unit, detecting their presence or absence, reporting their status, and sending alerts for error conditions when required.

Note: The sample screens that appear in this document might differ slightly from the screens that your system displays. Screen content varies according to the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

Related documentation

In addition to this *User's Guide*, the following documentation might be on the *Documentation* CD that comes with your BladeCenter management module, in Portable Document Format (PDF). Depending on your BladeCenter product, additional documents might also be included on the *Documentation* CD. The most recent versions of all BladeCenter documentation are at <http://www.ibm.com/bladecenter/>.

- *Safety Information*

This document contains translated caution and danger statements. Each caution and danger statement that appears in the documentation has a number that you can use to locate the corresponding statement in your language in the *Safety Information* document.

- *Management Module Installation Guide*

Each management module has a customized *Installation Guide* that contains instructions for installing the management module in a BladeCenter unit and creating the initial configuration. This document also contains safety and warranty information specific to the management module.

- *BladeCenter Management Module Command-Line Interface Reference Guide*

This document explains how to use the management-module command-line interface to directly access BladeCenter management functions as an alternative to using the Web-based user interface. The command-line interface also provides access to the text-console command prompt on each blade server through a Serial over LAN (SOL) connection.

- *IBM SMASH Installation and User's Guide*

This document provides an overview of the SMASH command-line protocol (CLP) standard, its history, features, and components and its relation to the IBM SMASH product. It also provides a detailed overview of SMASH Proxy and SMASH Embedded including configuration, functionality, accessibility, features, and components.

- *IBM BladeCenter Serial over LAN Setup Guide*

This document explains how to update and configure BladeCenter components for Serial over LAN (SOL) operation. The SOL connection provides access to the text-console command prompt on each blade server and enables the blade servers to be managed from a remote location.

In addition to the documentation in this library, be sure to review the *IBM BladeCenter Planning and Installation Guide* for your BladeCenter unit for information to help you prepare for system installation and configuration. This document is available at <http://www.ibm.com/bladecenter/>.

Notices and statements in this document

The caution and danger statements that appear in this document are also in the multilingual *Safety Information* document, which is on the IBM *BladeCenter Documentation* CD. Each statement is numbered for reference to the corresponding statement in the *Safety Information* document.

The following notices and statements are used in this document:

- **Note:** These notices provide important tips, guidance, or advice.
- **Important:** These notices provide information or advice that might help you avoid inconvenient or problem situations.
- **Attention:** These notices indicate possible damage to programs, devices, or data. An attention notice is placed just before the instruction or situation in which damage could occur.
- **Caution:** These statements indicate situations that can be potentially hazardous to you. A caution statement is placed just before the description of a potentially hazardous procedure step or situation.
- **Danger:** These statements indicate situations that can be potentially lethal or extremely hazardous to you. A danger statement is placed just before the description of a potentially lethal or extremely hazardous procedure step or situation.

Chapter 2. Using the management-module Web interface

This section provides instructions for using the management-module Web interface. It has the following information:

- “Connecting to the management module”
- “Starting the management-module Web interface” on page 8
- “Configuring the management module” on page 10
- “Communicating with the IBM Director software” on page 13
- “Configuring advanced features” on page 14
- “Configuring an I/O module” on page 54

See Chapter 3, “Management-module Web interface overview,” on page 57 for a detailed description of the structure and content of the management-module Web interface. Many Web interface functions can also be performed through the management-module command-line interface (CLI). See the *BladeCenter Management Module Command-Line Interface Reference Guide* for information and instructions.

Connecting to the management module

A remote console connection to the management module is required to configure and manage operation of the BladeCenter unit. All management-module types support connection through the remote management and console (Ethernet) connector. The advanced management module also supports CLI-only connection through the serial management port.

You can manage the BladeCenter unit and blade servers that support KVM by using the graphical user interface that is provided by the management-module Web interface or by using the command-line interface that you access through Telnet, a Secure Shell (SSH) server, or the serial port (advanced management module only). All management connections to blade servers that do not support KVM are made through the management-module command-line interface.

You can perform initial configuration of the management module after you connect it to your network; however, because of some requirements that are imposed by the default management-module settings, it might be easier to perform these setup operations using a temporary connection. The following information is in this section:

- “Management-module connection overview”
- “Cabling the management module” on page 7
- “Connecting to the management module for the first time” on page 7

After the initial cabling and configuration, connect to the management module as described in “Starting the management-module Web interface” on page 8.

Management-module connection overview

You can access the management-module Web interface through a network or through a computer that is connected directly to the management module. To connect a remote console to the management-module Web interface, you need the following equipment and information:

- A computer with Internet browser capability. To facilitate connections at multiple locations, you can use a notebook computer.

- The management-module MAC address (listed on the label on the management module).
- For a networked connection to the management module, the following equipment:
 - A standard Ethernet cable
 - A local Ethernet network port (facility connection)
- For direct connection of a computer to the management module remote management and console (Ethernet) connector, an Ethernet crossover cable. The advanced management module can use either a standard Ethernet cable or an Ethernet crossover cable to make this connection.

Connections through the advanced management-module serial port can access only the management-module command-line interface (CLI). For information about accessing the management-module CLI, see the *BladeCenter Management Module Command-Line Interface Reference Guide*.

Hardware requirements

To use the Remote Control feature that provides KVM access to a blade server, the client system must have, at minimum, the following performance level:

- Microprocessor - Intel® Pentium® III or later, operating at 700 MHz or faster (or equivalent)
- Memory - 256 MB RAM
- Video - 16MB RADEON 7500 ATI Mobility video chipset or equivalent (AGP 4X with 16 MB of video memory)

The following table lists the only blade server specified video resolution and refresh rate combinations, for KVM equipped blade servers, that are supported for all system configurations. Unless noted otherwise, these settings apply to all management-module types.

Resolution	Refresh rate
640 x 480	60 Hz
640 x 480	72 Hz
640 x 480	75 Hz
640 x 480	85 Hz
800 x 600	60 Hz
800 x 600	72 Hz
800 x 600	75 Hz
800 x 600	85 Hz
1024 x 768	60 Hz
1024 x 768 (advanced management module only)	70 Hz
1024 x 768	75 Hz

Software requirements

The management module supports the following Web browsers for remote (client) access. The client Web browser that you use must be Java™-enabled, must support JavaScript™ version 1.2 or later, and must have the Java Virtual Machine (JVM) Plug-in between version 1.4.2_08 and version 1.5. The JVM Plug-in is available at <http://www.java.com/>.

- Microsoft® Internet Explorer 5.5 or later (with latest Service Pack installed)

- Mozilla Firefox version 1.07 or later

The following server operating systems have USB support, which is required for the Remote Control feature:

- Microsoft Windows Server 2003
- Microsoft Windows 2000 with Service Pack 4 or later
- Red Hat Linux® version 7.3
- SUSE Linux version 8.0
- Novell NetWare 6.5

To use the Remote Control feature on an advanced management module, the client system must also have the Sun JRE between version 1.4.2_08 and version 1.5.

The management-module Web interface does not support the double-byte character set (DBCS) languages.

Cabling the management module

The following sections describe how to cable the management module to configure the BladeCenter unit by using the management-module Web interface. See the *Installation Guide* for your management module for specific cabling instructions. See the *BladeCenter Management Module Command-Line Interface Reference Guide* for information about connecting a remote console to the management module and using the management-module CLI to configure the BladeCenter unit.

After you cable the management module for initial configuration, see “Connecting to the management module for the first time.” See the *Installation Guide* for your management module for specific cabling information.

Networked connection

Connect one end of a Category 5 or higher Ethernet cable to the remote management and console (Ethernet) connector on the management module. Connect the other end of the Ethernet cable to the facility network.

Direct connection

Connect one end of a Category 5 or higher Ethernet cable (advanced management module only) or a Category 5 or higher Ethernet crossover cable (management module and advanced management module) to the remote management and console (Ethernet) connector on the management module. Connect the other end of the cable to the Ethernet connector on the client computer.

Note: The advanced management module can perform an automatic media dependent interface (MDI) crossover, eliminating the need for crossover cables or cross-wired (MDIX) ports. You might need to use a crossover cable to connect to the advanced management module if the network interface card in the client computer is very old.

Connecting to the management module for the first time

The following sections describe how to connect a remote console to the management module to perform initial configuration of the BladeCenter unit. The management module has the following default network settings:

- IP address: 192.168.70.125
- Subnet: 255.255.255.0
- User ID: USERID (all capital letters)

- Password: PASSWORD (note the number zero, not the letter O, in PASSWORD)

By default, the management module is configured to respond to DHCP first before using its static IP address.

The client computer that you connect to the management module must be configured to operate on the same subnet as the BladeCenter management module. The IP address of the management module must also be in the same local domain as the client computer. To connect to the management module for the first time, you must change the Internet protocol properties on the client computer.

After you connect the Ethernet cable from the management module to the client computer, complete the following steps:

1. Make sure that the subnet of the client computer is set to the same value as the default management module subnet (255.255.255.0).
2. Open a Web browser on the client computer, and direct it to the default management-module IP address (192.168.70.125).
3. Enter the default user name, USERID, and the default password, PASSWORD, to start the remote session.
4. Follow the instructions on the screen. Be sure to set the timeout value that you want for your Web session.

After you connect to the management module for the first time, perform the initial configuration of the BladeCenter unit (see “Configuring the management module” on page 10).

Starting the management-module Web interface

To start the management-module Web interface, complete the following steps:

1. Open a Web browser. In the address or URL field, type the IP address or host name defined for the management-module remote connection (see the *Installation Guide* for your management module for details).

The Enter Network Password page opens.

2. Type your user name and password. If you are logging in to the management module for the first time, you can obtain your user name and password from your system administrator. All login attempts are documented in the event log.

Note: The initial factory-defined user ID and password for the management module are as follows:

- User ID: USERID (all capital letters)
 - Password: PASSWORD (note the zero, not O, in PASSWORD)
3. Follow the instructions on the screen. Be sure to set the timeout value that you want for your Web session.

The BladeCenter management-module Web-interface page opens. The content of this and all other Web-interface pages varies according to the type of BladeCenter unit that you are using and the firmware versions and options that are installed. See Chapter 3, “Management-module Web interface overview,” on page 57 for detailed information about the management-module Web interface.

IBM BladeCenter Management Module

Bay 1: SN#01
User: USER1

System Status Summary

System is operating normally. All monitored parameters are OK.

The following links can be used to view the status of different components.

[Blade Servers](#)
[I/O Modules](#)
[Management Modules](#)
[Power Modules](#)
[Blowers](#)
[Front Panel](#)

Blade Servers

Click the icon in the Status column to view detailed information about each blade server.

Bay	Status	Name	Pwr	Owner**		Network		WOL*	Local Control			BEM*
				KVM	MT*	Onboard	Card		Pwr	KVM	MT*	
1	●	SN#J1RNE34911N	On	X	X	Eth	--- --- ---	On	X	X	X	
2	●	SN#ZJ1WLW47T16N	On			Eth	--- --- ---	On	X	X	X	
3	●	SN#ZJ1WS447L14E	Off			Eth	Eth --- ---	On	X	X	X	
4	●	McCarran	Off			Eth	--- --- ---	On	X	X	X	
5												
6		No blade present										
7		No blade present										
8		No blade present										
9		No blade present										
10		No blade present										
11		No blade present										

The top of the management-module Web-interface page shows the type of management module that you are logged in to. The following illustrations show the management-module types for a management module and advanced management module.

IBM BladeCenter Management Module

Bay 1: SN#01
User: USER1

System Status Summary

IBM BladeCenter Advanced Management Module

Bay 1: SN#01
User: USER1

System Status Summary

The upper-left corner of the management-module Web-interface page shows the login ID of the current user and the location and identity of the active (primary) management module. In the preceding examples, the login ID is USER1, and the primary management module is identified as SN#01 and is installed in management-module bay 1.

Configuring the management module

You configure only the primary (active) management module. The standby management module, if present, receives the configuration and status information automatically from the primary management module when necessary. The configuration information in this chapter applies to the primary management module, which might be the only management module in the BladeCenter unit.

If the management module that you installed is a replacement for the only management module in the BladeCenter unit and you saved the configuration file before you replaced the management module, you can apply the saved configuration file to the replacement management module by using the management-module Web interface. See “Restoring and modifying your management-module configuration” on page 50 for information about applying a saved configuration file.

The BladeCenter unit automatically detects the modules and blade servers that are installed and stores the vital product data (VPD). When the BladeCenter unit is started, the management module automatically configures the remote management port of the management module so that you can configure and manage BladeCenter components. You configure and manage BladeCenter components remotely by using the management-module Web interface or the management-module command-line interface (CLI).

Note: There are two ways to configure the I/O modules: through the management-module Web interface or through an external I/O-module port that is enabled through the management module, using a Telnet interface or a Web browser. See the documentation that comes with each I/O module for information.

For the active management module to communicate with network resources and with the I/O modules in the BladeCenter unit, you must configure the IP addresses for the following internal and external ports:

- The external Ethernet (remote management) port (Ethernet 0) of the management module (see the information that begins on page 99 for information). The initial automatic management-module configuration enables the network-management station to connect to the management module to configure the port completely and to configure the rest of the BladeCenter unit.
- The internal Ethernet port (Ethernet 1) on the management module for communication with the I/O modules (see the information that begins on page 99 for information). Internal Ethernet ports for the advanced management module cannot be manually configured.
- The management port on each I/O module which provides for communication with the management module. You configure this port by configuring the IP address for the I/O module (see the information that begins on page 88 for information).

Note: Some types of I/O modules, such as the pass-thru module, have no management port.

See the documentation that comes with each I/O module to determine what else you must configure in the I/O module.

To communicate with the blade servers for functions such as deploying an operating system or application program over a network, you must also configure at least one external (in-band) port on an Ethernet switch module in I/O-module bay 1 or 2.

Note: If a pass-thru module (instead of an Ethernet I/O module) is installed in I/O-module bay 1 or 2, you must configure the network switch that the pass-thru module is connected to; see the documentation that comes with the network switch for instructions.

Configuring the management module for remote access

After you connect the active management module to the network, the Ethernet port connection is configured in one of the following ways:

- If you have an accessible, active, and configured dynamic host configuration protocol (DHCP) server on the network, IP address, gateway address, subnet mask, and DNS server IP address are set automatically. The host name is set to the management-module MAC address by default, and the domain server cannot change it.
- If the DHCP server does not respond within 3 minutes after the port is connected, the management module uses the factory-defined static IP address and default subnet address.

Important: You cannot connect to the management module using the factory-defined static IP address and default subnet address until after this 3-minute period passes.

Either of these actions enables the Ethernet connection on the active management module.

Make sure that the client computer is on the same subnet as the management module; then, use your Web browser to connect to the management module (see “Starting the management-module Web interface” on page 8 for more information). In the browser **Address** field, specify the IP address that the management module is using:

- If the IP address was assigned through a DHCP server, get the IP address from your network administrator.
- The factory-defined static IP address is 192.168.70.125, the default subnet address is 255.255.255.0, and the default host name is MMxxxxxxxxxxxx, where xxxxxxxxxxxx is the burned-in medium access control (MAC) address. The MAC address is on a label on the management module, below the IP reset button.

Note: If the IP configuration is assigned by the DHCP server, the network administrator can use the MAC address of the management-module network interface to find out what IP address and host name are assigned.

Configuring the management-module Ethernet ports

To configure the management-module internal and external Ethernet ports, complete the following steps:

1. Under **MM Control** in the navigation pane, click **Network Interfaces**.
2. Configure the two Ethernet interfaces: external (remote management and console), and internal (communication with the I/O modules).

Note: For I/O-module communication with a remote management station, such as a management server that is running IBM Director server, through the management-module external Ethernet port, the I/O-module internal network interface and the management-module internal and external interfaces must be on the same subnet.

- **External Network Interface (eth0)** - This is the interface for the remote management and console port.
 - **Interface** - Select **Enabled** (the default) to use the Ethernet connection. (For the advanced management module, this field is for information only and cannot be changed.)
 - **DHCP** - Select one of the following choices:
 - **Enabled - Obtain IP config. from DHCP server**
 - **Disabled - Use static IP configuration**
 - **Try DHCP server. If it fails, use static IP config.** (the default).
 - **Hostname** - (Optional) This is the IP host name that you want to use for the management module (maximum of 63 characters and following host-naming standards).
 - **Static IP configuration** - You have to configure this information only if DHCP is disabled.
 - **IP address** - The IP address for the management module. The IP address must contain four integers from 0 through 255, separated by periods, with no spaces or consecutive periods. The default setting is 192.168.70.125.
 - **Subnet mask** - Four integers from 0 through 255, separated by periods, with no spaces. The default setting is 255.255.255.0
 - **Gateway address** - The IP address for your network gateway router. The gateway address must contain four integers from 0 through 255, separated by periods, with no spaces. This address must be accessible from the IP address and subnet mask.
 - **Internal Network Interface (eth1)** (all management modules except the advanced management module) - This interface communicates with the I/O modules.
 - Specify the IP address to use for this interface. The subnet mask must be the same as the subnet mask in the external network interface (eth0).
 - View the data rate, duplex mode, maximum transmission unit (MTU), locally-administered MAC address, and burned-in MAC address for this interface. You can configure the locally administered MAC address; the other fields are read-only.
3. Configure the internal Ethernet management port on each I/O module in the BladeCenter unit.

Note: Some types of I/O modules, such as a pass-thru module, have no management port.

- a. Under **I/O Module Tasks** in the navigation pane, click **Configuration**.
- b. Click **Bay 1**.
- c. In the **New Static IP address** fields, specify the IP configuration to use for this interface. The subnet mask must be the same as the subnet mask in the internal network interface (eth1).
- d. Click **Advanced Configuration**.
- e. In the **Advanced Setup** section, enable external management over all ports.
- f. Under **I/O Module Tasks** in the navigation pane, click **Admin/Power/Restart**.
- g. In the **I/O Module Advanced Setup** section, select I/O module 1; then, enable the external ports. (External ports have a default value of Disabled.)

Note: The initial user ID and password for the I/O module firmware are as follows:

- User ID: USERID (all capital letters)
- Password: PASSW0RD (note the zero, not O, in PASSW0RD)

Repeat step 3 for each I/O module in the BladeCenter unit.

To communicate with the blade servers for functions such as deploying an operating system or application program, you also must configure at least one external (in-band) port on an Ethernet I/O module.

Using the Configuration Wizard (advanced management module only)

The configuration wizard starts automatically when you access the Web interface of a new advanced management module for the first time. The configuration wizard also starts automatically the first time that you access the Web interface of an advanced management module that has been reset to its factory default settings.

To configure an advanced management module using the configuration wizard, click **Configuration Wizard** under **MM Control** in the navigation pane. You must be assigned the Supervisor role (command authority) to use the configuration wizard.

The first wizard pane lists all of the information that you need to know before using the wizard to configure the management module. After gathering this information, enter it into the wizard panes to complete a basic configuration of the management module. If you are importing a saved management module configuration or restoring one that is saved to the backplane of the BladeCenter unit, these options appear in the **Import Configuration** pane of the configuration wizard. Imported or restored configurations do not require any additional information entry.

You must restart the management module for the configuration changes to take effect. Click **Reboot Now** in the **Completion** pane of the configuration wizard to restart the management module; or, click **Reboot Later** to exit the wizard, saving your configuration changes without putting them in effect.

Communicating with the IBM Director software

The IBM Director program is a systems-management product that comes with some BladeCenter units. The IBM Director software communicates with the BladeCenter unit through the Ethernet port on the active management module.

See http://www.ibm.com/servers/eserver/xseries/systems_management/xseries_sm/dwnl.html for the version of IBM Director software that you can use to manage redundant management modules.

For you to configure the remote alert recipients for IBM Director over LAN, the remote alert recipient must be an IBM Director-enabled server.

To communicate with the BladeCenter unit, the IBM Director software needs a managed object (in the Group Contents pane of the IBM Director Management Console main window) that represents the BladeCenter unit. If the BladeCenter management-module IP address is known, the network administrator can create an IBM Director managed object for the unit. If the IP address is not known, the IBM Director software can automatically discover the BladeCenter unit (out-of-band, using the Ethernet port on the BladeCenter management module) and create a managed object for the unit.

For the IBM Director software to discover the BladeCenter unit, your network must initially provide connectivity from the IBM Director server to the BladeCenter management-module Ethernet port. To establish connectivity, the management module attempts to use DHCP to acquire its initial IP address for the Ethernet port. If the DHCP request fails, the management module uses the static IP address that is assigned to it. Therefore, the DHCP server (if it is used) must be on the management LAN for your BladeCenter unit.

Notes:

1. All management modules are preconfigured with the same static IP address. You can use the management-module Web interface to assign a new static IP address for each BladeCenter unit. If DHCP is not used and you do not assign a new static IP address for each BladeCenter unit before you attempt to communicate with the IBM Director software, only one BladeCenter unit at a time can be added onto the network for discovery. Adding multiple units to the network without a unique IP address assignment for each BladeCenter unit results in IP address conflicts.
2. For I/O-module communication with a remote management station, such as a management server that is running the IBM Director server, through the management-module external Ethernet port, the I/O-module internal network interface and the management-module internal and external interfaces must be on the same subnet.

Configuring advanced features

The following sections provide instructions for performing some of the functions that the management-module Web interface supports. Detailed descriptions of the management-module Web interface are in Chapter 3, “Management-module Web interface overview,” on page 57.

- “Network and security configuration”
- “Configuring Wake on LAN” on page 47
- “Using the configuration file” on page 48
- “Using the remote disk feature” on page 52

Network and security configuration

The following sections describe how to configure management-module networking and security parameters for the following protocols:

- SNMP and DNS (see “Configuring SNMP”)
- SMTP (see “Configuring SMTP” on page 17)
- SSL and LDAP (see “Configuring LDAP” on page 18)
- SSH (see “Configuring the secure shell server” on page 45)

Configuring SNMP

You can query the SNMP agent to collect the sysgroup information and to send configured SNMP alerts to the configured host names or IP addresses.

Note: If you plan to configure Simple Network Management Protocol (SNMP) traps on the management module, you must install and compile the management information base (MIB) on your SNMP manager. The MIB supports SNMP traps. The MIB is included in the management-module firmware update package that you downloaded from <http://www.ibm.com/bladecenter/>.

To configure SNMP, complete the following steps:

1. Log in to the management module on which you want to configure SNMP. For more information, see “Starting the management-module Web interface” on page 8
2. In the navigation pane, click **MM Control → General Settings**. In the management-module information page that opens, specify the following information:
 - **Name** - The name that you want to use to identify the management module. The name will be included with e-mail and SNMP alert notifications to identify the source of the alert. If more than one management module is installed in a BladeCenter unit, each management module can be given a unique name.
 - **Contact** - The name and phone number of the person to contact if there is a problem with the BladeCenter unit.
 - **Location** - Sufficient detail to quickly locate the BladeCenter unit for maintenance or other purposes.
3. Scroll to the bottom of the page and click **Save**.
4. In the navigation pane, click **MM Control → Network Protocols**; then, click the **Simple Network Management Protocol (SNMP)** link. A page similar to the one in the following illustration is displayed.

Simple Network Management Protocol (SNMP) ?

SNMPv1 agent	Enabled
SNMPv3 agent	Enabled
SNMP traps	Enabled

SNMPv1 Communities		
Community Name	Access Type	Host Name or IP Address
public	Get	1. 0.0.0.0 2. 3.
private	Set	1. 0.0.0.0 2. 3.
	Get	1. 2. 3.

SNMPv3 Users

If you enabled the SNMPv3 agent, you must configure SNMPv3 settings for active login profiles in order for the interaction between the SNMPv3 manager and SNMPv3 agent to work properly. You can configure these settings at the bottom of the individual login profile pages which can be reached via the [Login Profiles](#) page. Click the link for the login profile to configure, scroll to the bottom of the page and then click the “Configure SNMPv3 User” link.

5. Select **Enabled** in the applicable SNMP agent fields and in the **SNMP traps** field to forward alerts to SNMP communities and users on your network. For you to enable an SNMP agent, the following criteria must be met:
 - System contacts must be specified on the General Settings page.
 - The system location must be specified on the General Settings page.
 - For SNMPv1, at least one community name must be specified, with an access type set for each community name:
 - **Get** - All hosts in the community can query MIB objects and receive traps.

- **Set** - All hosts in the community can query and set MIB objects and receive traps.
- **Trap** - All hosts in the community can receive traps.
- At least one valid IP address or host name (if DNS is enabled) must be specified for each community.
- For SNMPv3, each SNMPv3 user must be configured.

Note: Alert recipients whose notification method is SNMP will not receive alerts unless both the SNMP agent and the SNMP traps are enabled.

6. If you are enabling the SNMPv1 agent, complete the following steps to set up a community that defines the administrative relationship between SNMP agents and SNMP managers; otherwise, continue with step 7. You must define at least one SNMPv1 community. Each community definition consists of the following parameters:

- Community name
- Host name or IP address

If either of these parameters is not correct, SNMP management access is not granted.

Note: If an error message window opens, make the necessary adjustments to the fields that are listed in the error window. Then, scroll to the bottom of the page and click **Save** to save the corrected information. You must configure at least one community to enable this SNMP agent.

- a. In the **Community Name** field, enter a name or authentication string to specify the community.
 - b. Select the **Access Type** for the community.
 - c. In the corresponding **Host Name** or **IP Address** field, enter the host name or IP address of each community manager.
7. Complete one of the following, based on DNS server availability:
 - If a DNS server is not available on your network, scroll to the bottom of the page and click **Save**.
 - If a DNS server is available on your network, scroll to the **Domain Name System (DNS)** section. A page similar to the one in the following illustration is displayed.

Domain Name System (DNS) ?

DNS	<input type="text" value="Enabled"/>
DNS server IP address 1	<input type="text" value="9.37.0.5"/>
DNS server IP address 2	<input type="text" value="9.37.0.6"/>
DNS server IP address 3	<input type="text" value="0.0.0.0"/>

8. If a DNS server (or servers) is available on your network, select **Enabled** in the **DNS** field. The **DNS** field specifies whether you use a DNS server on your network to translate host names into IP addresses.
9. (Optional) If you enabled DNS, in the **DNS server IP address** fields, specify the IP addresses of up to three DNS servers on your network. Each IP address must contain four integers from 0 through 255, separated by periods.
10. Scroll to the bottom of the page and click **Save**.

11. If you are enabling the SNMPv3 agent, complete the following steps to configure the SNMPv3 profile for each SNMPv3 user; otherwise, continue with step 12.
 - a. Click the **Login Profiles** link in the Simple Network Management Protocol (SNMP) section or, in the navigation pane, click **MM Control → Login Profiles**.
 - b. Select the user that is to be configured; then, click the **Configure SNMPv3 User** link at the bottom of the Login Profile page. A page similar to the one in the following illustration is displayed.

SNMPv3 User Profile 1

Context name:

Authentication protocol:

Privacy protocol:

Privacy password:

Confirm privacy password:

Access type:

Hostname/IP address for traps:

- c. Specify the SNMPv3 configuration information for this user; then, click **Save**.
 - d. Repeat step 11b and step 11c for each SNMPv3 user.
12. In the navigation pane, click **MM Control → Restart MM**; then, restart the management module to activate the changes.

Configuring SMTP

To specify the IP address or host name of the Simple Mail Transfer Protocol (SMTP) server, complete the following steps.

Note: If you plan to set up an SMTP server for e-mail alert notifications, make sure that the name in the **Name** field in the **MM Information** section of the **MM Control → General Settings** page is valid as part of an e-mail address (for example, there are no spaces).

1. Log in to the management module on which you want to configure SMTP. For more information, see “Starting the management-module Web interface” on page 8.
2. In the navigation pane, click **MM Control → Network Protocols**, and scroll down to the **Simple Mail Transfer Protocol (SMTP)** section.

Simple Mail Transfer Protocol (SMTP)

SMTP server host name or IP address:

3. In the **SMTP server host name or IP address** field, type the host name of the SMTP server. Use this field to specify the IP address or, if DNS is enabled and configured, the host name of the SMTP server.
4. Scroll to the bottom of the page and click **Save**.

Configuring LDAP

Using a Lightweight Directory Access Protocol (LDAP) server, a management module can authenticate a user by querying or searching an LDAP directory on an LDAP server, instead of going through its local user database. Then, all LDAP clients (BladeCenter management modules or server Remote Supervisor Adapters) can remotely authenticate any user access through a central LDAP server. This requires LDAP client support on the management module. You can also assign authority levels according to information that is found on the LDAP server.

You can also use LDAP to assign users and management modules to groups and perform group authentication, in addition to the normal user (password check) authentication. For example, a management module can be associated with one or more groups, and a user would pass only group authentication if the user belongs to at least one group that is associated with the management module.

Note: For management modules other than the advanced management modules, LDAP configuration is done in several sections of the **Network Protocols** page. For advanced management modules, all LDAP configuration is done in the **Lightweight Directory Access Protocol (LDAP) Client** section of the **Network Protocols** page.

Setting up a client to use the LDAP server: To set up a client to use the LDAP server, complete the following steps:

1. Log in to the management module on which you want to set up the client. For more information, see “Starting the management-module Web interface” on page 8.
2. In the navigation pane, click **MM Control → Network Protocols**. Scroll down to the **Lightweight Directory Access Protocol (LDAP) Client** section. For management modules other than the advanced management module, a page similar to the one in the following illustration is displayed.

Lightweight Directory Access Protocol (LDAP) Client ?

☐ Use DNS to Find LDAP Servers

Domain Source:

Search Domain:

Service Name:

☒ Use Pre-Configured LDAP Servers

	LDAP Server Host Name or IP Address	Port
1.	<input type="text"/>	<input type="text"/>
2.	<input type="text"/>	<input type="text"/>
3.	<input type="text"/>	<input type="text"/>

Miscellaneous Parameters

Root DN:

Group Filter:


Binding Method:

[Set DN and password only if Binding Method used is w/ Configured Credentials](#)

[Set attribute names for LDAP client search algorithm](#)

For the advanced management module, a page similar to the one in the following illustration is displayed.

Note: The following illustration shows the fields displayed for the default LDAP configuration. Different fields are displayed on this page based on the settings of the **Binding Method** and **Enhanced role-based security for Active Directory users** fields.

Lightweight Directory Access Protocol (LDAP) Client 

☐ Use DNS to Find LDAP Servers

Domain Source

Search Domain

Service Name

☒ Use Pre-Configured LDAP Servers

	LDAP Server Host Name or IP Address	Port
1.	<input type="text"/>	<input type="text"/>
2.	<input type="text"/>	<input type="text"/>
3.	<input type="text"/>	<input type="text"/>

Miscellaneous Parameters

Root DN	<input type="text"/>
UID search attribute	<input type="text"/>
Binding method	<input type="text" value="w/ Configured Credentials"/>
Client DN	<input type="text"/>
Password	<input type="password"/>
Confirm password	<input type="password"/>
Enhanced role-based security for Active Directory users	<input type="text" value="Disabled"/>
Group filter	<input type="text" value="BladeCenter"/>
Group Search Attribute	<input type="text"/>
Login Permission Attribute	<input type="text"/>

3. Configure the LDAP client, using the following information:

- a. Select **Use DNS to find LDAP Servers** or **Use Pre-Configured LDAP Servers** (default).

The management module contains a Version 2.0 LDAP Client that you can configure to provide user authentication through one or more LDAP servers. The LDAP servers that are used for authentication can be discovered dynamically or manually preconfigured.

- b. If you are using DNS to find LDAP servers, configure the following settings; then, go to step 3d on page 20. When discovering LDAP servers dynamically, the mechanisms that are described by RFC2782 are applied to find the servers through a process called DNS SRV.

Domain Source

The DNS SRV request that is sent to the DNS server must specify a domain name. The LDAP client determines where to get this domain name according to the option that is selected:

Extract search domain from login id. The LDAP client uses the domain name in the login ID. For example, if the login ID is joesmith@mycompany.com, the domain name is mycompany.com. If the domain name cannot be extracted from the login ID, the DNS SRV process fails, causing a user authentication failure.

Use only configured search domain below. The LDAP client uses the domain name that is set in the **Search Domain** field.

Try login id first, then configured value. The LDAP client first attempts to extract the domain name from the login ID. If this succeeds, this domain name is used in the DNS SRV request. If there is no domain name in the login ID, the LDAP client uses the domain name that is set in the **Search Domain** field as the domain name in the DNS SRV request. If neither of these items is configured, user authentication fails.

Search Domain

This optional parameter is used only when a configured search domain is being used as a domain source. This parameter might be used as the domain name in the DNS SRV request, depending on how the Domain Source parameter is configured.

Service Name

A DNS SRV request that is sent to a DNS server must also specify a service name. If this field is not set, the DNS SRV request uses a default value of ldap. Each DNS SRV request must also specify a protocol name: this value is set to tcp and is not configurable.

- c. If you are using preconfigured LDAP servers, configure the **LDAP Server Host Name or IP Address** fields; then, go to step 3d.

The port number for each server is optional. If the field is left blank, the default value of 389 is used for nonsecured LDAP connections. For secured connections, the default is 636. You must configure at least one LDAP server.

- d. Configure the following items for all LDAP server types:

Root DN

This is the distinguished name for the root entry of the directory tree on the LDAP server (for example, dn=companyABC,dn=com).

Binding Method

For initial binds to the LDAP server during user authentication, select one of the following options:

Anonymous authentication. A bind attempt is made without a client distinguished name or password. If the bind is successful, a search will be requested to find an entry on the LDAP server for the user who is attempting to log in. If an entry is found, a second attempt to bind is attempted, this time with the distinguished name and password of the user. If this succeeds, the user has passed the user authentication phase. Group authentication is then attempted, if it is enabled.

w/ Configured Credentials. A bind attempt is made, using the configured client domain name and password. If the initial bind is successful, a search is performed to find an entry on the LDAP server that belongs to the user who is logging in. If necessary, a second attempt to bind is attempted, this time with the domain name that is retrieved from the user LDAP record and the password that was entered during the login process. If this fails, the user is denied access. When using a binding method of configured credentials, you must configure the credentials as described in “Configuring the LDAP client authentication” on page 22.

w/ Login Credentials. A bind attempt is made, using the credentials that were supplied during the login process. If the initial bind is successful, a search is performed to find an entry on the LDAP server that belongs to the user who is logging in.

Group Filter

(For management modules other than the advanced management module) This parameter is used for group authentication. It specifies the set of groups to which the management module belongs. If this field is left blank, group authentication is disabled. Otherwise, group authentication is performed against this filter. The specified filter can be a specific group name (for example, IBMWest), a wildcard with a prefix (for example, IBM*), or a wildcard (specified as *). If a specific name is used, the management module belongs only to that group. If a prefix filter is used (for example, IBM*), the management module belongs to any group whose first three letters are IBM. If a wildcard filter (*) is used, the management module belongs to all groups. The default filter is IBM*.

Group authentication is performed after user authentication (where a user ID and password are verified). Group authentication refers to the process of verifying that a user is a member of at least one group that is associated with the management module. For example, if the group filter is set to IBM* and the user belongs to two groups (for example, Engineering and IBMWest), group authentication passes because the user belongs to a group (IBMWest) that matches the filter IBM*. If the groups to which the user belongs do not match the filter, group authentication fails, and the user is not allowed to access the management module. Note that if the group filter is *, group authentication will automatically succeed because any group to which the user belongs will match this wildcard. You must also configure additional authentication attributes as described in “Configuring the LDAP search attributes” on page 23.

Enhanced role-based security for Active Directory users

(For advanced management modules only) The setting of the **Enhanced role-based security for Active Directory users** field determines how users are authenticated on Active Directory servers:

- **Enabled:** Activates version 2 of the advanced management module role-based security (RBS) model. In version 2, a new RBS model is used for Active Directory servers that requires the use of a snap-in utility that runs on any Microsoft Windows platform. The snap-in utility configures roles on an Active Directory server and associates users, groups, and advanced management modules to those roles. Each role identifies the permissions given to users and groups associated with that role, and identifies the targets, such as advanced management modules, to which these roles are attached.

If enhanced role-based security is enabled, specify a target name for the advanced management module needs to be specified in the **AMM Target Name** field:

The free-formatted name configured in the **AMM Target Name** field is the target name for an advanced management module. A target name can be associated with one or more roles on the Active Directory server through the Role Based Security (RBS) Snap-In by creating targets with specific names and associating them to roles. If a name is configured in this field, you can define specific roles for users and advanced management modules (targets) that are members of the same role. When a user logs in to the advanced management module, and is authenticated using Active Directory, the roles

for that user are retrieved from the directory. The permissions assigned to the user are extracted from the roles specified for the advanced management module target and from the targets that match any advanced management module.

Multiple advanced management modules can share the same target name. This method can be used to group multiple advanced management modules together and assign them to the same roles using a single managed target identified by a single target name. The advanced management modules can also be managed independently by giving them unique names.

- **Disabled:** Activates version 1 of the advanced management module RBS model. In version 1, bitstrings were used to associate permissions to users and groups in an LDAP-enabled server environment. Version 1 supported Active Directory, Novell eDirectory, and OpenLDAP-based servers. When enhanced role-based security for Active Directory users is disabled, you must configure authentication attributes as described in “Configuring the LDAP search attributes” on page 23.

If you are not using Active Directory, then you should not enable version 2 of the advanced management module RBS model. Before enabling version 2, you should already have roles configured on the Active Directory server. The version 1 bitstring model cannot be automatically converted to the version 2 model; this is why you must configure users and groups before enabling version 2. Once enabled, the change takes effect immediately.

Depending on the LDAP configuration that you have set, click the options to set the domain names and passwords that are used for client authentication and the LDAP client search attributes. Each of these options is described in the following sections.

Configuring the LDAP client authentication: If the binding method is set to configured credentials, configure LDAP client authentication by completing the following steps:

1. In the navigation pane, click **MM Control → Network Protocols**.
2. Scroll down to the **Lightweight Directory Access Protocol (LDAP) Client** section.
 - For advanced management modules, the **Client DN** and **Password** are set in the **Miscellaneous Parameters** area of the **Lightweight Directory Access Protocol (LDAP) Client** section (see the illustration on page 19). The **Client DN** and **Password** fields will display only when the binding method is set for configured credentials.
 - For management modules other than advanced management modules, click **Set DN and password only if Binding Method is Client Authentication**. A page similar to the one in the following illustration is displayed.

3. Perform the initial bind to the LDAP server during user authentication with anonymous authentication, client-based authentication, or user principal name. To use client-based authentication, in the **Client DN** field, type a client distinguished name. Type a password in the **Password** field or leave it blank; then, confirm it.

Configuring the LDAP search attributes: For management modules other than the advanced management module and for advanced management modules where enhanced role-based security for Active Directory users is disabled, configure the LDAP search attributes by completing the following steps:

1. In the navigation pane, click **MM Control → Network Protocols**.
2. Scroll down to the **Lightweight Directory Access Protocol (LDAP) Client** section.
 - For advanced management modules, the **UID Search Attribute**, **Group Filter**, **Group Search Attribute**, and **Login Permission Attribute** are set in the **Miscellaneous Parameters** area of the **Lightweight Directory Access Protocol (LDAP) Client** section (see the illustration on page 19). The **Group Filter**, **Group Search Attribute**, and **Login Permission Attribute** fields will display only when enhanced role-based security for Active Directory users is disabled.
 - For management modules other than advanced management modules, click **Set attribute names for LDAP based client search algorithm**. A page similar to the one in the following illustration is displayed.

3. To configure the search attributes, use the following information:

UID Search Attribute

When the selected binding method is anonymous authentication or client authentication, the initial bind to the LDAP server is followed by a search request that is directed at retrieving specific information about the user, including the distinguished name, login permissions, and group ownerships of the user. To retrieve this information, the search request must specify the attribute name that is used to represent user IDs on that server. Specifically, this name is used as a search filter against the login ID that is entered by the user. This attribute name is configured

here. If this field is left blank, a default of UID is used during user authentication. For example, on Active Directory servers, the attribute name that is used for user IDs is often sAMAccountName.

When the selected binding method is user principal name or strict user principal name, the **UID Search Attribute** field defaults automatically to userPrincipalName during user authentication, if the user ID that is entered has the form *userid@somedomain*.

Group Filter

(For advanced management modules only) The **Group Filter** field is used for group authentication. It specifies the groups that the advanced management module belongs to. If the **Group Filter** field is left blank, group authentication is disabled. If enabled, group authentication is performed after user authentication. Specifically, an attempt is made to match at least one group in the list to a group that the user belongs to. If there is no match, the user fails authentication and is denied access. If there is at least one match, then group authentication passes. All comparisons made during authentication are case sensitive.

The group filter is limited to 511 characters and can contain multiple group names. The colon ":" character is used to delimit group names. Leading spaces and trailing spaces are ignored; all other spaces are treated as part of the group name. The asterisk "*" wildcard character is not treated as a wildcard, the wildcard concept being removed for security reasons. A group name can be specified as a full domain name or using only the company name portion. For example, a group with a domain name equal to cn=adminGroup,dc=mycompany,dc=com can be specified using the actual domain name or by using adminGroup.

Group Search Attribute

When the group filter name is configured, the list of groups to which a user belongs must be retrieved from the LDAP server. This is required to perform group authentication. To retrieve this list, the search filter that is sent to the server must specify the attribute name that is associated with groups. This field specifies this attribute name.

If this field is left blank, the attribute name in the filter defaults to memberOf.

Login Permission Attribute

When a user is successfully authenticated through an LDAP server, the login permissions for the user must be retrieved. To retrieve these permissions, the search filter that is sent to the server must specify the attribute name that is associated with login permissions. This field specifies this attribute name.

The login permission attributes are different for the advanced management module and management modules other than the advanced management module. Each set of attributes is described in one of the following sections:

- Login permission attributes for advanced management modules on page 25
- Login permission attributes for management modules other than advanced management modules on page 29

Login permission attributes for advanced management modules

This field must not be left blank, otherwise, it will be impossible to retrieve the user permissions. Without verified permissions, the login attempt will fail. This is different from earlier releases, where access was granted with default read-only permissions assigned to the user whose permissions could not be verified.

The attribute value returned by the LDAP server is searched for the keyword string "IBMRBSPermissions=". This keyword must be immediately followed by a bit string entered as 64 consecutive 0's or 1's. Each bit represents a particular set of functions. The bits are numbered according to their position. The leftmost bit is bit position 0, and the rightmost bit is bit position 11. A value of 1 at a particular position enables that particular function. A value of 0 disables that function. The string "IBMRBSPermissions=010000000000" is a valid example.

Note that the "IBMRBSPermissions=" keyword is used in order to allow it to be placed anywhere in the attribute field. This allows the LDAP administrator to reuse an existing attribute, thus preventing an extension to the LDAP schema. Furthermore, this allows the attribute to be used for its original purpose. The keyword string can be added anywhere. The attribute used should allow for a free-formatted string.

The permission bits are interpreted as follows:

- Deny Always (bit position 0): if this bit is set, a user will always fail authentication. This function can be used to block a particular user or users associated with a particular group.
- Supervisor Access (bit position 1): if this bit is set, a user is given administrator privileges, which lets the user view any page, allows changes to any field, and permits all actions provided by the interface. When this bit is set, the other bits that define specific function access do not have to be set individually.
- Read Only Access (bit position 2): if this bit is set, a user has read-only access, and cannot perform any maintenance procedures (for example, restart, remote actions, and firmware updates), and nothing can be modified (using the save, clear, or restore functions). Note that read-only and all other bits are mutually exclusive, with bit position 2 having the lowest precedence. That is, if any other bit is set, this bit will be ignored.
- Networking & Security (bit position 3): if this bit is set, a user can modify the settings in the **Security**, **Network Protocols**, and **Network Interface** panels for **MM Control**. If this bit is set, the user can also modify the IP configuration parameters for I/O modules under the **I/O Module Tasks → Management** panel.
- User Account Management (bit position 4): if this bit is set, a user can add, modify, and delete users and change the Global Login Settings in the **Login Profiles** panel.

- Blade Server Remote Console Access (bit position 5): if this bit is set, a user can access a remote blade server video console with keyboard and mouse control.
- Blade Server Remote Console and Virtual Media Access (bit position 6): if this bit is set, a user can access a remote blade server video console with keyboard and mouse control, and can also access the virtual media features for that remote blade server.
- Blade Server and I/O Module Power/Restart Access (bit position 7): if this bit is set, a user can access the power on and restart functions for the blade servers and the I/O modules. These functions are available in the **Blade Tasks** → **Power/Restart** panel and the **I/O Module Tasks** → **Power/Restart** panel.
- Basic Configuration (bit position 8): if this bit is set, a user can modify basic configuration parameters for the management module and blade servers. In particular, the user can modify parameters in the **General Settings** and **Alerts** panels of **MM Control**, and the **Configuration** panel of the **Blade Tasks**.
- Ability to Clear Event Logs (bit position 9): if this bit is set, a user can clear the event logs. All users can view the event logs, but this permission is required to clear the event logs.
- Advanced Adapter Configuration (bit position 10): if this bit is set, a user has no restrictions when configuring the management module, blade servers, I/O modules, and VPD. In addition, the user has administrative access, meaning that this user can also perform the following advanced functions: firmware upgrades on management module or blade servers, restore management module factory defaults, modify and restore the management module configuration from a configuration file, and restart or reset the management module.
- Version Number (bit positions 11 through 15): A version number of 00000 indicates that the user permissions scheme set using bit positions 0 through 10 will be used. A version number of 00001 indicates that the role-based user permissions scheme using bit positions 16 through 55 will be used. Any other version number will use the user permissions scheme set using bit positions 0 through 10.
- Deny Always Role (bit position 16): if this bit is set, a user will always fail authentication. This function can be used to block a particular user or users associated with a particular group.
- Supervisor Role (bit position 17): if this bit is set, a user has no restrictions. User has read/write access to all panels and fields for all devices. When this bit is set, there is no need to set any other authority levels listed below.
- Operator Role (bit position 18): if this bit is set, the user has read-only access. This user can not perform any maintenance procedures (for example, restart, remote actions, firmware updates) and is unable to modify any settings (using the save, clear, or restore functions). Note that

read-only and all other bits are mutually exclusive, with read-only having the lowest precedence. That is, if any other bit is set, this bit 18 is ignored.

- Chassis Operator Role (bit position 19): if this bit is set, the user has the ability to browse status and properties of chassis components (management module, blowers, midplane, power modules, media tray) and the ability to backup the management module configuration.
- Chassis User Account Management Role (bit position 20): if this bit is set, the user can add, modify, and delete users in the **MM Control → Login Profiles** panel. Changing the global login settings requires the Chassis Configuration role.
- Chassis Log Account Management Role (bit position 21): if this bit is set, the user can clear the event logs or change the log policy settings. All users can view the event logs, but this role is required to clear the logs or to change the log policy settings (the field at the top of the event log page).
- Chassis Configuration Role (bit position 22): if this bit is set, the user has the ability to modify and save any chassis configuration parameter (except user profiles and event log settings). For example, general management module settings, management module port assignments, management module network interfaces, management module network protocols, management module security. This user also has the ability to change the SOL configuration under the SOL configuration web panel, the ability to change the global login settings. In addition, this user can restore management module factory defaults configuration, if they also has Chassis Administration permissions.
- Chassis Administration Role (bit position 23): if this bit is set, the user has the ability to perform management module firmware updates, modify the state of the chassis LEDs, and restart the management module. restore management module factory defaults configuration if the user also has Chassis Configuration permissions.
- Blade Operator Role (bit position 24): if this bit is set, the user has the ability to read blade information but not to modify it.
- Blade Remote Presence Role (bit position 25): if this bit is set, the user has the ability to access the Remote Control web panel and the functions provided on the panel: remote console (KVM) and remote disk. In addition, this user can issue the command-line interface (CLI) console command to start an SOL session to a blade.
- Blade Configuration Role (bit position 26): if this bit is set, the user has the ability to modify and save any blade server configuration parameter (except parameters in the SOL configuration web panel). For example, blade server names, blade server policy settings, and the ability to disable or enable SOL for individual blade servers under Serial Over LAN status web panel.
- Blade Administration Role (bit position 27): if this bit is set, the user has the ability to power on or off and restart blade

servers, activate standby blade servers, do firmware updates, or modify the state of blade server LEDs.

- Switch Operator Role (bit position 28): if this bit is set, the user has the ability to browse the status and properties of I/O modules and the ability to ping I/O modules.
- Switch Configuration Role (bit position 29): if this bit is set, the user has the ability to configure the I/O module IP address, enable or disable external management over all ports, and preserve new IP configuration on all resets. The user also has the ability to restore factory defaults, and to launch a Telnet or web session to an I/O module, if the user also has Switch Administration permissions.
- Switch Administration Role (bit position 30): if this bit is set, the user has the ability to power on or off and restart I/O modules with various diagnostic levels, update passthru I/O module firmware, enable or disable Fast POST, and enable or disable external ports. The user also has the ability to restore factory defaults, and to launch a Telnet or web session to an I/O module, if the user also has Switch Configuration permissions.
- Blade 1 Scope (bit position 31): if this bit is set, the user will have access to the blade in slot 1.
- Blade 2 Scope (bit position 32): if this bit is set, the user will have access to the blade in slot 2.
- Blade 3 Scope (bit position 33): if this bit is set, the user will have access to the blade in slot 3.
- Blade 4 Scope (bit position 34): if this bit is set, the user will have access to the blade in slot 4.
- Blade 5 Scope (bit position 35): if this bit is set, the user will have access to the blade in slot 5.
- Blade 6 Scope (bit position 36): if this bit is set, the user will have access to the blade in slot 6.
- Blade 7 Scope (bit position 37): if this bit is set, the user will have access to the blade in slot 7.
- Blade 8 Scope (bit position 38): if this bit is set, the user will have access to the blade in slot 8.
- Blade 9 Scope (bit position 39): if this bit is set, the user will have access to the blade in slot 9.
- Blade 10 Scope (bit position 40): if this bit is set, the user will have access to the blade in slot 10.
- Blade 11 Scope (bit position 41): if this bit is set, the user will have access to the blade in slot 11.
- Blade 12 Scope (bit position 42): if this bit is set, the user will have access to the blade in slot 12.
- Blade 13 Scope (bit position 43): if this bit is set, the user will have access to the blade in slot 13.
- Blade 14 Scope (bit position 44): if this bit is set, the user will have access to the blade in slot 14.
- Chassis Scope (bit position 45): if this bit is set, the user will have access to the chassis and management module.

- I/O Module 1 Scope (bit position 46): if this bit is set, the user will have access to I/O module 1.
- I/O Module 2 Scope (bit position 47): if this bit is set, the user will have access to I/O module 2.
- I/O Module 3 Scope (bit position 48): if this bit is set, the user will have access to I/O module 3.
- I/O Module 4 Scope (bit position 49): if this bit is set, the user will have access to I/O module 4.
- I/O Module 5 Scope (bit position 50): if this bit is set, the user will have access to I/O module 5.
- I/O Module 6 Scope (bit position 51): if this bit is set, the user will have access to I/O module 6.
- I/O Module 7 Scope (bit position 52): if this bit is set, the user will have access to I/O module 7.
- I/O Module 8 Scope (bit position 53): if this bit is set, the user will have access to I/O module 8.
- I/O Module 9 Scope (bit position 54): if this bit is set, the user will have access to I/O module 9.
- I/O Module 10 Scope (bit position 55): if this bit is set, the user will have access to I/O module 10.
- Reserved (bit position 56 through 63): reserved for future use.

If none of the bits are set, the default is set to deny always (read-only) for the user.

Note that priority is given to login permissions retrieved directly from the user record. If the user does not have the login permission attribute in their record, an attempt will be made to retrieve the permissions from the groups that the user belongs to; this is done as part of the group authentication phase. The user will be assigned the inclusive OR of all the bits for all of the groups. Again, the Deny Always bit will only be set if all the other bits are zero. Also note that if the Deny Always bit is set for any of the groups, the user will be refused access. The Deny Always bit always has precedence over every other bit.

Important: If you give a user the ability to modify basic, networking, or security related adapter configuration parameters, you should consider giving this same user the ability to restart the management module. If the user is unable to reset the management module, changes that they make which require a restart will not take effect.

Login permission attributes for management modules other than advanced management modules

If the **Login Permission Attribute** field is left blank, the user is assigned a default of read-only permissions, assuming that user and group authentication passes. When successfully retrieved, the attribute value that is returned by the LDAP server is interpreted according to the following information:

- The field supports user roles for both the command authorities that are used in earlier versions of

management-module firmware and the role-based user permissions for the latest version of management-module firmware. Bit positions 11 through 16 determine which type of role is used. See “Web interface pages and user roles” on page 57 for information about the commands available for each user role.

- The attribute value must be a bit string that is entered as consecutive zeros or ones, with each bit representing a particular set of functions (for example, 010000000000 or 0000110010000). The bits are numbered according to their positions. The leftmost bit is bit position 0, and the rightmost bit is bit position 50. A value of 1 at a particular position enables the corresponding function. A value of 0 disables that function. The LDAP attribute string is copied into a local string that is 64 characters long. If fewer than 64 characters are specified, the local string is padded with zeros. If the string is longer than 64 characters, extra characters are not copied.
- The following functions are associated with the 50 bit positions:
 - User authorities (for scripting on management modules other than the advanced management module) (bit positions 0 through 10):
 - Deny Always (bit position 0): If this bit is set, a user will always fail authentication. This function can be used to block a particular user or users who are associated with a particular group.
 - Supervisor Access (bit position 1): If this bit is set, a user is given administrator privileges. The user has read and write access to every function. When this bit is set, other bits that define specific function access do not have to be set individually.
 - Read Only Access (bit position 2): If this bit is set, a user has read-only access and cannot perform any maintenance procedures (for example, restart, remote actions, and firmware updates), and nothing can be modified (using the save, clear, or restore functions). Note that read-only and all other bits are mutually exclusive, with bit position 2 having the lowest precedence. That is, if any other bit is set, this bit is ignored.
 - Networking and Security (bit position 3): If this bit is set, a user can modify the settings in the Security, Network Protocols, and Network Interface pages for MM Control. If this bit is set, a user can also modify the settings in the Management page for I/O Module Tasks.
 - User Account Management (bit position 4): If this bit is set, a user can add, modify, and delete users and change the Global Login Settings in the Login Profiles page.
 - Blade server Remote Console Access (bit position 5): If this bit is set, a user can access the remote server console.

- Blade server Remote Console and Virtual Media Access (bit position 6): If this bit is set, a user can access the remote server console and the virtual media functions for the remote server.
- Blade and I/O Module Power/Restart Access (bit position 7): If this bit is set, a user can access the power-on and restart functions for the blade servers and I/O modules.
- Basic Configuration (management module, I/O Modules, Blades) (bit position 8): If this bit is set, a user can modify the General Settings and Alerts pages for MM Control and the Configuration page for Blade Tasks.
- Ability to Clear Event Logs (bit position 9): If this bit is set, a user can clear the event logs. Everyone can look at the event logs, but this permission is required to clear the logs.
- Advanced Configuration (management module, I/O Modules, Blades) (bit position 10): If this bit is set, a user has no restrictions when configuring the management module, blade servers, I/O modules, and VPD. The user can also perform firmware upgrades on the management module or blade servers, restore the management module to its factory default settings, modify and restore the management-module configuration from a configuration file, and restart or reset the management module.
- Permission version (bit positions 11 through 15): These bits specify which type of user roles, user authorities, or role-based user permissions is being used. If these bits are set to 00001, the role-based user permissions, using bits 16 through 30, are used. If these bits are set to 00000 or any other value, the user authorities, using bits 0 through 10, are used.
- Role-based user permissions (non-scripting use on all management-module types) (bit positions 16 through 30):
 - Deny Always (bit position 16): If this bit is set, a user will always fail authentication. This function can be used to block a particular user or users who are associated with a particular group.
 - Supervisor (bit position 17): If this bit is set, a user is given administrator privileges. The user has read and write access to every function. When this bit is set, other bits that define specific function access do not have to be set individually.
 - Operator (bit position 18): If this bit is set, a user can view all information. User access to information is limited by the permission scope that is specified in bits 31 through 49.
 - Chassis Operator (bit position 19): If this bit is set, a user can view information about the common BladeCenter unit components.
 - Chassis User Account Management (bit position 20): If this bit is set, a user can add, modify, and delete user

login profiles. Changing the Global Login Settings requires Chassis Configuration permission.

- Chassis Log Management (bit position 21): If this bit is set, a user can clear the event logs or change the log policy settings. All users can look at the event logs, but this permission is required to clear the logs or change the log policy settings at the top of the event-log page.
- Chassis Configuration (bit position 22): If this bit is set, a user can perform management and setup operations for the common BladeCenter unit components and features. User access to information is limited by the permission scope that is specified in bit 45.
- Chassis Administration (bit position 23): If this bit is set, a user can manage operation of the common BladeCenter unit components and features. User access to information is limited by the permission scope that is specified in bit 45.
- Blade Operator (bit position 24): If this bit is set, a user can view information about the blade servers. User access to blade servers is limited by the permission scope that is specified in bits 31 through 44.
- Blade Remote Presence (bit position 25): If this bit is set, a user can access the remote server console and the virtual media functions for the remote server. User access to blade servers is limited by the permission scope that is specified in bits 31 through 44.
- Blade Configuration (bit position 26): If this bit is set, a user can perform management and setup operations for the blade servers. User access to blade servers is limited by the permission scope that is specified in bits 31 through 44.
- Blade Administration (bit position 27): If this bit is set, a user can manage operation of the blade servers. User access to blade servers is limited by the permission scope that is specified in bits 31 through 44.
- Switch Operator (bit position 28): If this bit is set, a user can view information about the I/O modules. User access to I/O modules is limited by the permission scope that is specified in bits 46 through 55.
- Switch Module Configuration (bit position 29): If this bit is set, a user can perform management and setup operations for the I/O modules. User access to I/O modules is limited by the permission scope that is specified in bits 46 through 55.
- Switch Module Administration (bit position 30): If this bit is set, a user can manage operation of the I/O modules. User access to I/O modules is limited by the permission scope that is specified in bits 46 through 55.
- Permission scope (for role-based user permissions) (bit positions 31 through 55):
 - Blade 1 (bit position 31): If this bit is set, a user can access information about the blade server that is addressed in blade bay 1.

- Blade 2 (bit position 32): If this bit is set, a user can access information about the blade server that is addressed in blade bay 2.
- Blade 3 (bit position 33): If this bit is set, a user can access information about the blade server that is addressed in blade bay 3.
- Blade 4 (bit position 34): If this bit is set, a user can access information about the blade server that is addressed in blade bay 4.
- Blade 5 (bit position 35): If this bit is set, a user can access information about the blade server that is addressed in blade bay 5.
- Blade 6 (bit position 36): If this bit is set, a user can access information about the blade server that is addressed in blade bay 6.
- Blade 7 (bit position 37): If this bit is set, a user can access information about the blade server that is addressed in blade bay 7.
- Blade 8 (bit position 38): If this bit is set, a user can access information about the blade server that is addressed in blade bay 8.
- Blade 9 (bit position 39): If this bit is set, a user can access information about the blade server that is addressed in blade bay 9.
- Blade 10 (bit position 40): If this bit is set, a user can access information about the blade server that is addressed in blade bay 10.
- Blade 11 (bit position 41): If this bit is set, a user can access information about the blade server that is addressed in blade bay 11.
- Blade 12 (bit position 42): If this bit is set, a user can access information about the blade server that is addressed in blade bay 12.
- Blade 13 (bit position 43): If this bit is set, a user can access information about the blade server that is addressed in blade bay 13.
- Blade 14 (bit position 44): If this bit is set, a user can access information about the blade server that is addressed in blade bay 14.
- Chassis (bit position 45): If this bit is set, a user can access information about the common BladeCenter unit components.
- I/O Module 1 (bit position 46): If this bit is set, a user can access information about the I/O module in I/O module bay 1.
- I/O Module 2 (bit position 47): If this bit is set, a user can access information about the I/O module in I/O module bay 2.
- I/O Module 3 (bit position 48): If this bit is set, a user can access information about the I/O module in I/O module bay 3.

- I/O Module 4 (bit position 49): If this bit is set, a user can access information about the I/O module in I/O module bay 4.
- I/O Module 5 (bit position 50): If this bit is set, a user can access information about the I/O module in I/O module bay 5.
- I/O Module 6 (bit position 51): If this bit is set, a user can access information about the I/O module in I/O module bay 6.
- I/O Module 7 (bit position 52): If this bit is set, a user can access information about the I/O module in I/O module bay 7.
- I/O Module 8 (bit position 53): If this bit is set, a user can access information about the I/O module in I/O module bay 8.
- I/O Module 9 (bit position 54): If this bit is set, a user can access information about the I/O module in I/O module bay 9.
- I/O Module 10 (bit position 55): If this bit is set, a user can access information about the I/O module in I/O module bay 10.
- Reserved (bit positions 56 through 63): These bits are reserved for future use.
- If none of the bits are set, the default is read-only for the user.
- Priority is given to login permissions that are retrieved directly from the user record. If the user record does not have the login permission attribute, an attempt will be made to retrieve the permissions from the groups to which the user belongs. This is done as part of the group authentication phase. The user will be assigned the inclusive OR of all the bits for all of the groups. The Browser Only bit is set only if all the other bits are set to zero. If the Deny Always bit is set for any of the groups, the user will be refused access. The Deny Always bit always has precedence over every other bit.

Secure Web server and secure LDAP

Secure Sockets Layer (SSL) is a security protocol that provides communication privacy. SSL enables applications to communicate in a way that is designed to prevent eavesdropping, tampering, and message forgery.

You can configure the management module to use SSL support for two types of connections: secure Web server (HTTPS) and secure LDAP connection (LDAPS). The management module takes on the role of SSL client or SSL server, depending on the type of connection. The following table shows that the management module acts as an SSL server for secure Web server connections. The management module acts as an SSL client for secure LDAP connections.

Table 1. Management-module SSL connection support

Connection type	SSL client	SSL server
Secure Web server (HTTPS)	Web browser of the user (for example, Microsoft Internet Explorer)	Management-module Web server

Table 1. Management-module SSL connection support (continued)

Connection type	SSL client	SSL server
Secure LDAP connection (LDAPS)	Management-module LDAP client	An LDAP server

You can view or change the Secure Sockets Layer (SSL) settings from the **MM Control → Security** page. You can enable or disable SSL and manage the certificates that are required for SSL.

Configuring security: Use the general procedure in this section to configure security for the management-module Web server and to configure security for the connection between the management module and an LDAP server. If you are not familiar with the use of SSL certificates, read the information in “SSL certificate overview.”

The content of the Security Web page is context-sensitive. The selections that are available on the page change when certificates or certificate-signing requests are generated, when certificates are imported or removed, and when SSL is enabled or disabled for the client or the server.

Perform the following general tasks to configure the security for the management module:

1. Configure the SSL server certificates for the secure Web server:
 - a. Disable the SSL server. Use the **SSL Server Configuration for Web Server** section on the **MM Control → Security** page.
 - b. Generate or import a certificate. Use the **SSL Server Certificate Management** section on the **MM Control → Security** page. (See “SSL server certificate management” on page 36.)
 - c. Enable the SSL server. Use the **SSL Server Configuration for Web Server** section on the **MM Control → Security** page. (See “Enabling SSL for the secure Web server” on page 43.)
2. Configure the SSL client certificates for secure LDAP connections:
 - a. Disable the SSL client. Use the **SSL Client Configuration for LDAP Client** section on the **MM Control → Security** page.
 - b. Generate or import a certificate. Use the **SSL Client Certificate Management** section on the **MM Control → Security** page. (See “SSL client certificate management” on page 43.)
 - c. Import one or more trusted certificates. Use the **SSL Client Trusted Certificate Management** section on the **MM Control → Security** page. (See “SSL client trusted certificate management” on page 43.)
 - d. Enable the SSL client. Use the **SSL Client Configuration for LDAP Client** section on the **MM Control → Security** page. (See “Enabling SSL for the LDAP client” on page 45.)
3. Restart the management module for SSL server configuration changes to take effect. For more information, see “Restart MM” on page 107.

Note: Changes to the SSL client configuration take effect immediately and do not require a restart of the management module.

SSL certificate overview: You can use SSL with either a self-signed certificate or with a certificate that is signed by a certificate authority. Using a self-signed

certificate is the simplest method for using SSL, but it does create a small security risk. The risk arises because the SSL client has no way of validating the identity of the SSL server for the first connection that is attempted between the client and server. It is possible that a third party could impersonate the server and intercept data that moves between the management module and the Web browser. If, at the time of the initial connection between the browser and the management module, the self-signed certificate is imported into the certificate store of the browser, all future communications will be secure for that browser (assuming that the initial connection was not compromised by an attack).

For more complete security, you can use a certificate that is signed by a certificate authority. To obtain a signed certificate, use the SSL Certificate Management page to generate a certificate-signing request. You must then send the certificate-signing request to a certificate authority and make arrangements to procure a certificate. When the certificate is received, it is then imported into the management module through the **Import a Signed Certificate** link, and you can enable SSL.

The function of the certificate authority is to verify the identity of the management module. A certificate contains digital signatures for the certificate authority and the management module. If a well-known certificate authority issues the certificate or if the certificate of the certificate authority has already been imported into the Web browser, the browser is able to validate the certificate and positively identify the management-module Web server.

The management module requires a certificate for the secure Web server and one for the secure LDAP client. Also, the secure LDAP client requires one or more trusted certificates. The trusted certificate is used by the secure LDAP client to positively identify the LDAP server. The trusted certificate is the certificate of the certificate authority that signed the certificate of the LDAP server. If the LDAP server uses self-signed certificates, the trusted certificate can be the certificate of the LDAP server itself. Additional trusted certificates can be imported if more than one LDAP server is used in your configuration.

SSL server certificate management: The SSL server requires that a valid certificate and corresponding private encryption key be installed before SSL is enabled. Two methods are available for generating the private key and required certificate: using a self-signed certificate and using a certificate that is signed by a certificate authority. If you want to use a self-signed certificate for the SSL server, see “Generating a self-signed certificate” on page 37. If you want to use a certificate-authority-signed certificate for the SSL server, see “Generating a certificate signing request” on page 38.

Generating a self-signed certificate: To generate a new private encryption key and self-signed certificate, complete the following steps:

1. In the navigation plane, click **MM Control** → **Security**. A page similar to the one in the following illustration is displayed.

The screenshot shows a web interface with two main sections. The first section is titled "SSL Server Configuration for Web Server" with a help icon. It contains a dropdown menu for "SSL Server" set to "Disabled" and a "Save" button. The second section is titled "SSL Server Certificate Management" with a help icon. It displays the status "No certificate or certificate signing request (CSR) has been generated." and two links: "Generate a New Key and a Self-signed Certificate" and "Generate a New Key and a Certificate Signing Request (CSR)". The third section is titled "SSL Client Configuration for LDAP Client" with a help icon. It contains a dropdown menu for "SSL Client" set to "Disabled" and a "Save" button. The fourth section is titled "SSL Client Certificate Management" with a help icon. It displays the status "No certificate or certificate signing request (CSR) has been generated." and two links: "Generate a New Key and a Self-signed Certificate" and "Generate a New Key and a Certificate Signing Request (CSR)".

2. In the **SSL Server Configuration for Web Server** section, make sure that the SSL server is disabled. If it is not disabled, select **Disabled** in the **SSL Server** field and then click **Save**.
3. In the **SSL Server Certificate Management** section, select **Generate a New Key and a Self-signed Certificate**. A page similar to the one in the following illustration is displayed.

The screenshot shows a form titled "SSL Server Self-signed Certificate" with a help icon. It is divided into two sections: "Certificate Data" and "Optional Certificate Data". The "Certificate Data" section includes five required fields: "Country (2 letter code)", "State or Province", "City or Locality", "Organization Name", and "MM Host Name". The "Optional Certificate Data" section includes seven optional fields: "Contact Person", "Email Address", "Organizational Unit", "Surname", "Given Name", "Initials", and "DN Qualifier".

4. Type the information in the required fields and any optional fields that apply to your configuration. For a description of the fields, see "Required certificate data"

on page 39. After you finish typing the information, click **Generate Certificate**. Your new encryption keys and certificate are generated. This process might take several minutes.

A page similar to the one in the following illustration is displayed. It shows that a self-signed certificate is installed.

SSL Server Certificate Management

SSL server certificate status: A self-signed certificate is installed.

[Generate a New Key and a Self-signed Certificate](#)

[Generate a New Key and a Certificate Signing Request \(CSR\)](#)

[Import a Signed Certificate](#)

[Download Certificate](#)

Generating a certificate signing request: To generate a new private encryption key and certificate-signing request, complete the following steps:

1. In the navigation pane, click **MM Control → Security**.
2. In the **SSL Server Configuration for Web Server** section, make sure that the SSL server is disabled. If it is not disabled, select **Disabled** in the **SSL Server** field and then click **Save**.
3. In the **SSL Server Certificate Management** section, select **Generate a New Key and a Certificate Signing Request**. A page similar to the one in the following illustration is displayed.

SSL Certificate Signing Request (CSR)

Certificate Request Data

Country (2 letter code)	<input type="text"/>
State or Province	<input type="text"/>
City or Locality	<input type="text"/>
Organization Name	<input type="text"/>
MM Host Name	<input type="text"/>

Optional Certificate Data

Contact Person	<input type="text"/>
Email Address	<input type="text"/>
Organizational Unit	<input type="text"/>
Surname	<input type="text"/>
Given Name	<input type="text"/>
Initials	<input type="text"/>
DN Qualifier	<input type="text"/>

CSR Attributes and Extension Attributes

Challenge Password	<input type="text"/>
Unstructured Name	<input type="text"/>

Generate CSR

4. Type the information in the required fields and any optional fields that apply to your configuration. The fields are the same as for a self-signed certificate, with some additional fields.

The following sections describe each of the common fields.

Required certificate data

The following user-input fields are required for generating a self-signed certificate or a certificate-signing request:

Country

Use this field to indicate the country in which the management module is located. This field must contain the 2-character country code.

State or Province

Use this field to indicate the state or province in which the management module is located. This field can contain a maximum of 30 characters.

City or Locality

Use this field to indicate the city or locality in which the management module is located. This field can contain a maximum of 50 characters.

Organization Name

Use this field to indicate the company or organization that owns the management module. When this information is used to generate a certificate-signing request, the issuing certificate authority can verify that the organization that is requesting the certificate is legally entitled to claim ownership of the given company or organization name. This field can contain a maximum of 60 characters.

MM Host Name

Use this field to indicate the management-module host name that appears in the browser Web address field.

Make sure that the value that you typed in the **MM host name** field exactly matches the host name as it is known by the Web browser. The browser compares the host name in the resolved Web address to the name that appears in the certificate. To prevent certificate warnings from the browser, the value that is used in this field must match the host name that is used by the browser to connect to the management module. For example, if the Web address in the address field is `http://mm11.xyz.com/private/main.ssi`, the value that is used for the **MM Host Name** field must be `mm11.xyz.com`. If the Web address is `http://mm11/private/main.ssi`, the value that is used must be `mm11`. If the Web address is `http://192.168.70.2/private/main.ssi`, the value that is used must be `192.168.70.2`.

This certificate attribute is generally referred to as the common name.

This field can contain a maximum of 60 characters.

Optional certificate data

The following user-input fields are optional for generating a self-signed certificate or a certificate-signing request:

Contact Person

Use this field to indicate the name of a contact person who is responsible for the management module. This field can contain a maximum of 60 characters.

Email Address

Use this field to indicate the e-mail address of a contact person who is responsible for the management module. This field can contain a maximum of 60 characters.

Organizational Unit

Use this field to indicate the unit within the company or organization that owns the management module. This field can contain a maximum of 60 characters.

Surname

Use this field for additional information, such as the surname of a person who is responsible for the management module. This field can contain a maximum of 60 characters.

Given Name

Use this field for additional information, such as the given name of a person who is responsible for the management module. This field can contain a maximum of 60 characters.

Initials

Use this field for additional information, such as the initials of a person who is responsible for the management module. This field can contain a maximum of 20 characters.

DN Qualifier

Use this field for additional information, such as a distinguished name qualifier for the management module. This field can contain a maximum of 60 characters.

Years Valid

This field is present for only an SSL server; it is not shown for an SSL client.

Certificate-signing request attributes

The following fields are optional unless they are required by your selected certificate authority:

Challenge Password

Use this field to assign a password to the certificate-signing request. This field can contain a maximum of 30 characters.

Unstructured Name

Use this field for additional information, such as an unstructured name that is assigned to the management module. This field can contain a maximum of 60 characters.

5. After you complete the information, click **Generate CSR**. The new encryption keys and certificate are generated. This process might take several minutes. A page similar to the one in the following illustration is displayed when the process is completed.

Download CSR

Certificate Signing Request (CSR) is ready for downloading.

To get the CSR, click "Download CSR". You can then send it to a CA for signing.

Download CSR

6. Click **Download CSR** and then click **Save** to save the file to your computer. The file that is produced when you create a certificate-signing request is in DER format. If your certificate authority expects the data in some other format, such as PEM, you can convert the file by using a tool such as OpenSSL (<http://www.openssl.org>). If the certificate authority asks you to copy the contents of the certificate-signing request file into a Web page, PEM format is usually expected.

The command for converting a certificate-signing request from DER to PEM format through OpenSSL is similar to the following command:

```
openssl req -in csr.der -inform DER -out csr.pem -outform PEM
```

7. Send the certificate signing request to your certificate authority. When the certificate authority returns your signed certificate, you might have to convert the certificate to DER format. (If you received the certificate as text in an e-mail or a Web page, it is probably in PEM format.) You can change the format by using a tool that is provided by your certificate authority or by using a tool such as OpenSSL (<http://www.openssl.org>). The command for converting a certificate from PEM to DER format is similar to the following command:

```
openssl x509 -in cert.pem -inform PEM -out cert.der -outform DER
```

Go to step 8 after the signed certificate is returned from the certificate authority.

8. In the navigation pane, click **MM Control → Security**. Scroll to the **SSL Server Certificate Management** section, which looks similar to the page in the following illustration.

SSL Server Certificate Management [?]

SSL server certificate status: A self-signed certificate is installed and a CSR has been generated.

[Generate a New Key and a Self-signed Certificate](#)

[Generate a New Key and a Certificate Signing Request \(CSR\)](#)

[Import a Signed Certificate](#)

[Download Certificate](#)

[Download CSR](#)

9. Select **Import a Signed Certificate**. A page similar to the one in the following illustration is displayed.

Import a Signed SSL Certificate [?]

To import a certificate in DER format, select the file and click "Import Certificate".

10. Click **Browse**.
11. Click the certificate file that you want and then click **Open**. The file name (including the full path) is displayed in the field next to the **Browse** button.
12. Click **Import Server Certificate** to begin the process. A progress indicator is displayed as the file is transferred to storage on the management module. Continue displaying this page until the transfer is completed.

Enabling SSL for the secure Web server:

Note: To enable SSL, you must have a valid SSL certificate installed.

To enable the secure Web server, complete the following steps:

1. In the navigation pane, click **MM Control → Security**. The page that is displayed is similar to the one in the following illustration and shows that a valid SSL server certificate is installed. If the SSL server certificate status does not show that a valid SSL certificate is installed, go to “SSL server certificate management” on page 36.

SSL Server Certificate Management ?

SSL server certificate status: A CA-signed certificate is installed.

[Generate a New Key and a Self-signed Certificate](#)

[Generate a New Key and a Certificate Signing Request \(CSR\)](#)

[Import a Signed Certificate](#)

[Download Certificate](#)

[Download CSR](#)

2. Scroll to the SSL Server Configuration for Web Server section and select **Enabled** in the **SSL Server** field and then click **Save**. The selected value takes effect the next time the management module is restarted.

SSL client certificate management: The SSL client requires that a valid certificate and corresponding private encryption key be installed before SSL is enabled. Two methods are available for generating the private key and required certificate: using a self-signed certificate and using a certificate that is signed by a certificate authority.

The procedure for generating the private encryption key and certificate for the SSL client is the same as the procedure for the SSL server, except that you use the **SSL Client Certificate Management** section of the Security Web page instead of the **SSL Server Certificate Management** section. If you want to use a self-signed certificate for the SSL client, see “Generating a self-signed certificate” on page 37. If you want to use a certificate-authority-signed certificate for the SSL client, see “Generating a certificate signing request” on page 38.

SSL client trusted certificate management: The secure SSL client (LDAP client) uses trusted certificates to positively identify the LDAP server. A trusted certificate can be the certificate of the certificate authority that signed the certificate of the LDAP server, or it can be the actual certificate of the LDAP server. At least one certificate must be imported to the management module before the SSL client is enabled. You can import up to three trusted certificates.

To import a trusted certificate, complete the following steps:

1. In the navigation pane, select **MM Control → Security**.
2. In the SSL Client Configuration for LDAP Client section, make sure that the SSL client is disabled. If it is not disabled, select **Disabled** in the **SSL Client** field and then click **Save**.

3. Scroll to the **SSL Client Trusted Certificate Management** section. A page similar to the one in the following illustration is displayed.

SSL Client Trusted Certificate Management ?

Trusted CA Certificate 1

Trusted CA Certificate 2

Trusted CA Certificate 3

4. Click **Import** next to one of the **Trusted CA Certificate 1** fields. A page similar to the one in the following illustration is displayed.

Import a Trusted CA Certificate ?

To import a certificate in DER format, select the file and click "Import Certificate".

5. Click **Browse**.
6. Select the certificate file that you want and click **Open**. The file name (including the full path) is displayed in the box next to the **Browse** button.
7. To begin the import process, click **Import Certificate**. A progress indicator is displayed as the file is transferred to storage on the management module. Continue displaying this page until the transfer is completed.

The SSL Client Trusted Certificate Management section of the **MM Control** → **Security** page now looks similar to the one in the following illustration.

SSL Client Trusted Certificate Management ?

Trusted CA Certificate 1

Trusted CA Certificate 2

Trusted CA Certificate 3


The **Remove** button is now available for the Trusted CA Certificate 1 option. If you want to remove a trusted certificate, click the corresponding **Remove** button.

You can import other trusted certificates by using the Trusted CA Certificate 2 and the Trusted CA Certificate 3 **Import** buttons.


Enabling SSL for the LDAP client: Use the SSL Client Configuration for LDAP Client section of the Security page to enable or disable SSL for the LDAP Client. To enable SSL, you must install a valid SSL client certificate and at least one trusted certificate.

To enable SSL for the client, complete the following steps:

1. In the navigation pane, click **MM Control → Security**. A page similar to the one in the following illustration is displayed.

SSL Client Configuration for LDAP Client 


SSL Client Disabled Save

SSL Server Certificate Management 

SSL server certificate status: A CA-signed certificate is installed.

[Generate a New Key and a Self-signed Certificate](#)

[Generate a New Key and a Certificate Signing Request \(CSR\)](#)

SSL Client Trusted Certificate Management 

Trusted CA Certificate 1 Import Remove

Trusted CA Certificate 2 Import

Trusted CA Certificate 3 Import

The **MM Control → Security** page shows an installed SSL client certificate and Trusted CA Certificate 1.

2. On the **SSL Client Configuration for LDAP Client** page, select **Enabled** in the **SSL Client** field.
3. Click **Save**. The selected value takes effect immediately.

Configuring the secure shell server

The Secure Shell (SSH) feature provides secure access to the command-line interface and the Serial over LAN (text console) redirect features of the management module.

Secure Shell users are authenticated by exchanging user ID and password. The password and user ID are sent after the encryption channel is established. The user ID and password pair can be one of the 12 locally stored user IDs and passwords, or they can be stored on an LDAP server. Public key authentication is not supported.

Generating a Secure Shell server key: A Secure Shell server key is used to authenticate the identity of the Secure Shell server to the client. Secure Shell must be disabled before you create a new Secure Shell server private key. You must create a server key before you enable the Secure Shell server.

When you request a new server key, both an RSA key and a DSA key are created to allow access to the management module from either an SSH version 1.5 or an SSH version 2 client. For security, the Secure Shell server private key is not backed up during a configuration save and restore operation.

The following SSH clients are available. Although some SSH clients have been tested, support or nonsupport of any particular SSH client is not implied.

- The SSH clients that are distributed with operating systems such as Linux, AIX®, and UNIX® (see your operating-system documentation for information). The SSH client of Red Hat Linux 7.3 was used to test the command-line interface.
- The SSH client of cygwin (see <http://www.cygwin.com> for information).

The following table shows the types of encryption algorithms that are supported by the SSH version 1.5 and version 2.0.

Algorithm	SSH version 1.5 clients	SSH version 2.0 clients
Public key exchange	SSH 1-key exchange algorithm	Diffie-Hellman-group 1-sha-1
Host key type	RSA (1024-bit)	DSA (1024-bit)
Bulk cipher algorithms	3-des	3-des-cbc or blowfish-cbc
MAC algorithms	32-bit crc	Hmac-sha1

To create a new Secure Shell server key, complete the following steps:

1. In the navigation pane, click **MM Control → Security**.
2. Scroll to the **Secure Shell (SSH) Server** section and make sure that the Secure Shell server is disabled. If it is not disabled, select **Disabled** in the **SSH Server** field and then click **Save**.
3. Scroll to the **SSH Server Key Management** section. A page similar to the one in the following illustration is displayed.



4. Click **Generate SSH Server Private Key**. A progress page is displayed. Wait for the operation to finish. This step might take several minutes to be completed.

Enabling the Secure Shell server: From the Security page, you can enable or disable the Secure Shell server. The selection that you make takes effect only after the management module is restarted. The value that is displayed on the screen (Enabled or Disabled) is the last selected value and is the value that is used when the management module is restarted.

Notes:

1. You can enable the Secure Shell server only if a valid Secure Shell server private key is installed.
2. For the advanced management module, the Secure Shell server can also be enabled or disabled using SNMP or the management-module command-line interface. See the *BladeCenter Management Module Command-Line Interface Reference Guide* for more information.

To enable the Secure Shell server, complete the following steps:

1. In the navigation pane, click **Security**.

2. Scroll to the **Secure Shell (SSH) Server** section. A page similar to the one in the following illustration is displayed.

Secure Shell (SSH) Server 

SSH Server

Disabled

SSH version

All SSH versions

All SSH versions

SSHv2 only

3. Click **Enabled** in the **SSH Server** field.
4. In the navigation pane, click **Restart ASM** to restart the management module.

Using the Secure Shell server: If you are using the Secure Shell client that is included in Red Hat Linux version 7.3, to start a Secure Shell session to a management module with network address 192.168.70.2, type a command similar to the following example:

```
ssh -x -l USERID 192.168.70.2
```

where -x indicates no X Window System forwarding and -l indicates that the session is to use the user ID USERID.

Configuring Wake on LAN

To configure the Wake on LAN[®] feature in the BladeCenter unit, complete the following steps:

1. Write down the MAC address of the integrated Ethernet controllers in each blade server. You can find this information in one of the following ways. The MAC addresses are needed to configure a remote system to start the blade servers through the Wake on LAN feature: the remote system issues the Wake on LAN command (a Magic Packet frame) by sending it to a MAC address.
 - Blade server MAC addresses are part of the VPD that the management module maintains for each installed blade server. (Go to **Monitors → Hardware VPD** in the management-module Web interface, and then scroll to the **BladeCenter Server MAC Addresses** section.)
 - The MAC address is listed on the bar code label that is on the bottom of each blade server enclosure. Each blade server might also have a loose label that has the MAC addresses printed on it.
 - For some blade server types, you can read the MAC address by using the blade server Configuration/Setup Utility program (**Devices and I/O Ports → System MAC Addresses**)
2. Make sure that the Wake on LAN feature is enabled in the BladeCenter management module (**Blade Tasks → Power/Restart** and **Blade Tasks → Configuration** in the management-module Web interface).
3. Make sure that the external ports of the Ethernet switch modules or pass-thru modules in I/O-module bays 1 and 2 are enabled (**I/O Module Tasks → Admin/Power/Restart → I/O Module Advanced Setup** in the

management-module Web interface). If the external ports are not enabled, blade servers in the BladeCenter unit will not be able to communicate with the external network.

Verifying the Wake on LAN configuration

To verify that the Wake on LAN feature was correctly configured and is functioning, complete the following steps:

1. Start the blade server operating system.
2. Attempt to ping the remote computer that will issue the Wake on LAN command (the Magic Packet frame). A successful ping verifies network connectivity.
3. Make sure that the blade server is the current owner of the keyboard, video, and mouse (KVM).
4. Shut down the blade server, insert a DOS startable diskette into a USB attached diskette drive, and then restart the blade server.
5. When the A:\ prompt appears, turn off the blade server by using the power-control button.
6. Issue the Wake on LAN command (the Magic Packet frame) from the remote computer.

If the Wake on LAN feature was correctly configured and is functioning, the single blade server wakes up. This is a good procedure to determine whether there is a single blade or BladeCenter configuration problem or a device-driver problem within the operating system.

Linux-specific configuration

To configure the Wake on LAN feature for Red Hat or SUSE Linux, complete the following steps:

1. Type the following command:

```
insmod bcm5700.o enable_wol=1,1
```

The `enable_wol=1,1` parameter instructs the device driver to enable the Wake on LAN feature for both Broadcom controllers in a single blade server. Because there are two Broadcom controllers, you must issue a 1 for each of them.
2. Recompile the device driver for your Linux image. For example, a device driver that was compiled in Red Hat Linux is not guaranteed to function for SUSE Linux. See the documentation that comes with your operating system for information about compiling device drivers.

For you to compile the Broadcom device drivers in Red Hat Linux, a default installation is not sufficient because all files that are required for a successful compilation are not included. A custom installation of Red Hat Linux, in which the packages for software and kernel development are selected, includes the files that are required for successful compilation of the device drivers.

Using the configuration file

Procedures for backing up and restoring the management-module configuration are in the following sections.

Note: If you cannot communicate with a replacement management module through the Web interface, the IP address might be different from the IP address of the management module that you removed. Use the IP reset button to set the management module to the factory default IP addresses; then, access the management module by using the factory IP address (see the *Installation Guide* for your management module for the factory IP addresses and instructions for using the IP reset button) and configure the management module or load the saved configuration file.

Backing up your management-module configuration

All management-module types allow you to save your management-module configuration to a file. The advanced management module also allows you to save the management-module configuration to the backplane of the BladeCenter unit.

The management module and advanced management module have different backup procedures. They are described in the following sections.

You can download a copy of your current management-module configuration to the client computer that is running the management-module Web interface. Use this backup copy to restore your management-module configuration if it is accidentally changed or damaged. Use it as a base that you can modify to configure multiple management modules with similar configurations.

Backing up a management module configuration: To back up your current configuration, complete the following steps:

1. Log in to the management module for which you want to back up the current configuration. For more information, see “Starting the management-module Web interface” on page 8.
2. In the navigation pane, click **MM Control → Configuration File**.
3. In the **Backup MM Configuration** section, click **View the current configuration summary**.

Note: The security settings on the Security page are not backed up.

4. Verify the settings and then click **Close**.
5. To back up the configuration, click **Backup**.
6. Type a name for the backup, select the location where the file will be saved, and then click **Save**.
 - In Mozilla Firefox, click **Save to Disk**, and then click **OK**.
 - In Microsoft Internet Explorer, select **Save this file to disk**, and then click **OK**.

Backing up an advanced management module configuration: To back up your current configuration, complete the following steps:

1. Log in to the management module for which you want to back up the current configuration. For more information, see “Starting the management-module Web interface” on page 8.
2. In the navigation pane, click **MM Control → Configuration Mgmt**.
3. Select the type of backup that you want to perform:
 - **Backup Configuration to File**
 - **Save Configuration to Chassis**
4. If you are saving the configuration to the chassis, click **Save**.
5. If you are backing up the configuration to a file, click **view the current configuration summary** in the **Backup Configuration to File** section and complete the following steps.

Note: The security settings on the Security page are not backed up.

- a. Verify the settings and then click **Close**.
- b. To back up the configuration, click **Backup**.
- c. Type a name for the backup, select the location where the file will be saved, and then click **Save**.

- In Mozilla Firefox, click **Save to Disk**, and then click **OK**.
- In Microsoft Internet Explorer, select **Save this file to disk**, and then click **OK**.

Restoring and modifying your management-module configuration

You can restore a default or saved configuration in full, or you can modify key fields in the saved configuration before restoring the configuration to your management module. Modifying the configuration file before you restore it helps you set up multiple management modules with similar configurations. You can quickly specify parameters that require unique values, such as names and IP addresses, without having to enter common, shared information. The advanced management module also allows you to restore a configuration that was previously saved to the backplane of the BladeCenter unit.

The management module and advanced management module have different restore procedures. They are described in the following sections.

Restoring a management module configuration: To restore or modify your current configuration, complete the following steps:

1. Log in to the management module for which you want to restore the configuration. For more information, see “Starting the management-module Web interface” on page 8.

2. Determine the type of restoration that you want to perform:

- **Restore Defaults**
- **Restore Configuration from File**

3. If you are restoring the default configuration, click **MM Control → Restore Defaults** in the navigation pane; then click **Restore Defaults**.

After the restore process is complete, go to step 5

4. If you are restoring the configuration from a file, click **MM Control → Configuration File** in the navigation pane; then, complete the following steps:
 - a. In the **Restore MM Configuration** section, click **Browse**.
 - b. Click the configuration file that you want; then, click **Open**. The file (including the full path) appears in the box next to **Browse**.
 - c. If you do not want to make changes to the configuration file, click **Restore**. A new window opens with the management-module configuration information. Verify that this is the configuration that you want to restore. If it is not the correct configuration, click **Cancel**.

If you want to make changes to the configuration file before you restore it, click **Modify and Restore** to open an editable configuration summary window. Initially, only the fields that allow changes appear. To change between this view and the complete configuration summary view, click the **Toggle View** button at the top or bottom of the window.

Note: When you click **Restore** or **Modify and Restore**, an alert window might open if the configuration file that you are attempting to restore was created by a management module with older firmware (and, therefore, less functionality). This alert message includes a list of system-management functions that you must configure after the restoration is complete. Some functions require configurations on more than one window.

- d. To proceed with restoring this file to the management module, click **Restore Configuration**. A progress indicator appears as the firmware on the management module is updated. A confirmation window opens to indicate whether the update was successful.

Note: The security settings on the Security page are not restored with the restore operation. To modify security settings, see “Secure Web server and secure LDAP” on page 34.

5. After you receive a confirmation that the restore process is complete, in the navigation pane, click **MM Control → Restart MM**; then, click **Restart**.
6. Click **OK** to confirm that you want to restart the management module.
7. Click **OK** to close the browser window.
8. To log in to the management module again, start the browser, and follow your login process.

Restoring an advanced management module configuration: To restore or modify your current configuration, complete the following steps. You can restore an advanced management module configuration only if it was previously saved to the chassis or external media, as described in “Backing up an advanced management module configuration” on page 49.

1. Log in to the management module for which you want to restore the configuration. For more information, see “Starting the management-module Web interface” on page 8.
2. In the navigation pane, click **MM Control → Configuration Mgmt**.
3. Select the type of restoration that you want to perform:

- **Restore Defaults**
- **Restore Configuration from File**
- **Restore Configuration from Chassis**

4. If you are restoring the default configuration, click one of the following:
 - **Restore Defaults** to restore the management module to factory settings
 - **Restore Defaults Preserve Logs** to restore the management module to factory settings while retaining the content of the management module Event Log

A progress indicator appears as the firmware on the management module is updated. A confirmation window opens to indicate whether the update was successful. After the restore process is complete, go to step 7

5. If you are restoring the configuration from a file, click **Browse** in the **Restore Configuration from File** section and complete the following steps:
 - a. Click the configuration file that you want; then, click **Open**. The file (including the full path) appears in the box next to **Browse**.
 - b. If you do not want to make changes to the configuration file, click **Restore**. A new window opens with the management-module configuration information. Verify that this is the configuration that you want to restore. If it is not the correct configuration, click **Cancel**.

If you want to make changes to the configuration file before you restore it, click **Modify and Restore** to open an editable configuration summary window. Initially, only the fields that allow changes appear. To change between this view and the complete configuration summary view, click the **Toggle View** button at the top or bottom of the window.

Note: When you click **Restore** or **Modify and Restore**, an alert window might open if the configuration file that you are attempting to restore

was created by a management module with older firmware (and, therefore, less functionality). This alert message includes a list of system-management functions that you must configure after the restoration is complete. Some functions require configurations on more than one window.

- c. To proceed with restoring this file to the management module, click **Restore Configuration**. A progress indicator appears as the firmware on the management module is updated. A confirmation window opens to indicate whether the update was successful.

Note: The security settings on the Security page are not restored with the restore operation. To modify security settings, see “Secure Web server and secure LDAP” on page 34.

A progress indicator appears as the firmware on the management module is updated. A confirmation window opens to indicate whether the update was successful. After the restore process is complete, go to step 7

6. If you are restoring the configuration from the chassis, click **Restore**; then, click **OK**.

A progress indicator appears as the firmware on the management module is updated. A confirmation window opens to indicate whether the update was successful.

7. After you receive a confirmation that the restore process is complete, in the navigation pane, click **MM Control → Restart MM**; then, click **Restart**.
8. Click **OK** to confirm that you want to restart the management module.
9. Click **OK** to close the browser window.
10. To log in to the management module again, start the browser, and follow your login process.

Using the remote disk feature

From the Remote Control window (see “Remote Control” on page 78), you can assign, or mount, a optical drive or diskette drive that is on the remote client computer to a blade server. By using this window, you can also specify a disk image or CD (ISO) image on the remote client computer for the blade server to use.

You can use the remote disk for functions such as updating blade server firmware, installing new software on the blade server, and installing or updating the operating system on the blade server. After you assign the remote disk, use the remote console function to access it. The remote disk appears as a USB drive on the blade server.

Your operating system must have USB support for you to use the remote disk feature. The following operating systems provide USB support:

- Microsoft Windows® Server 2003
- Microsoft Windows 2000 with Service Pack 4 or later
- Red Hat Linux version 7.3
- SUSE Linux version 8.0
- Novell NetWare 6.5

In addition, the client (remote) system must have Microsoft Windows 2000 or later and must have the Java 1.4.1 or later Plug-in installed. The client system must also have an Intel Pentium III or later microprocessor operating at 700 MHz or faster (or an equivalent microprocessor).

Mounting a disk drive or disk image

To mount a disk drive or disk image on a remote client computer to a blade server, complete the following steps:

1. Start the management-module Web interface (see “Starting the management-module Web interface” on page 8).
2. In the navigation pane, click **Blade Tasks** → **Remote Control**.
3. In the **Start Remote Control** section, click **Start Remote Control**.
4. For the advanced management module, select the blade server that will have control of the media tray in the **Remote Disk** section.
5. In the **Remote Disk** section, select the hard disk drives or images to make available for mounting from the left side of the remote disk drive selector; then, click >> to finalize the selection and move them to the right side of the remote disk drive selector. To deselect items, select them in the right side of the remote disk drive selector and then click <<.

When you select a diskette drive or an image file and move it to the right side of the drive selector, you are given the option to save the disk image in the management-module random access memory (RAM). This enables the disk image to remain mounted on the blade server so that you can access the disk image later, even if the Web interface session is terminated. Mounted drives that are not saved to the management module will be unmounted when the remote-control window is closed.

A maximum of one diskette drive or drive image can be stored on the management module. The size of the drive or image contents must be 1.44 MB or less.

Important: For management modules other than the advanced management module, the disk image is lost when the management module is restarted or when the management-module firmware is updated. To use the mounted disk, use the remote console function. The mounted disk appears as a USB disk drive that is attached to the server.

6. Click **Write Protect** to prevent data from being written to the mounted drives.
7. In the right side of the remote disk drive selector, select one or more drives or images to mount; then, click **Mount Drive**.

The mounted drive or disk image functions as a USB device that is connected to the blade server. To refresh the list of available drives on the remote client computer, click **Refresh List**.

Unmounting a disk drive or disk image

When you have finished using a drive or disk image, complete the following steps to close and unmount it:

1. Complete any procedures that are required by your operating system to close and unmount a remote disk or image. See the documentation for your operating system for information and instructions.

For the Microsoft Windows operating system, complete one of the following procedures to close and unmount a drive or drive image:

- If there is an unplug or eject hardware icon in the Windows taskbar, complete the following steps:
 - a. Double-click the unplug or eject hardware icon.
 - b. Select **USB Mass Storage Device** and click **Stop**.
 - c. Click **Close**.

- If there is no unplug or eject hardware icon in the Windows taskbar, complete the following steps:
 - a. In the Microsoft Windows Control Panel, click **Add/Remove Hardware**; then, click **Next**.
 - b. Select **Uninstall/Unplug a device**; then, click **Next**.
 - c. Click **Unplug/Eject a device**; then, click **Next**.
- 2. In the **Remote Disk** section of the Remote Control window of the management-module Web interface, click **Unmount Drive**.

Configuring an I/O module

Note: The I/O-module configuration panes vary by I/O-module type. Each pane displays only those settings that apply to the I/O module that is installed; therefore, some steps in the following procedure might not apply to your I/O module.

Most I/O-module configuration is performed using the management interface provided by each I/O module. Before you can access this management environment using a Web browser, some I/O modules must have their communications parameters set up using either the management-module web Interface or the management module command-line interface.

This section has general instructions for configuring I/O module communications parameters using the management-module web Interface. See the *Installation Guide* for your I/O module for specific configuration information. Instructions for configuring the I/O module using the management module command-line interface are in the *BladeCenter Management Module Command-Line Interface Reference Guide*.

To configure the I/O module for external communication using the management-module web Interface, complete the following steps:

1. Log on to the management module as described in “Connecting to the management module” on page 5. The management-module window opens.
2. From the **I/O Module Tasks** menu, click **Management**.
3. In the **I/O Module Management** section, click the bay number that corresponds to the location of the I/O module that you are configuring. The applicable bay number appears at the bottom of the window, followed by other related I/O-module information, including the IP address. The I/O-module information is divided into two sections: Current IP Configuration and New Static IP Configuration.
4. In the **IP address** field in the **New Static IP Configuration** section, type the new IP address of the I/O module; then, click **Save**.

You can set up the IP address for the Gigabit Ethernet switch module in either of two ways:

- Use the default IP address
- Obtain a valid, unique IP address from your system administrator

Note: The IP address for the I/O module must be on the same subnet as the management module. The management module does not check for invalid IP addresses.

5. Click **Advanced Management** and make sure that the following switch-module features are enabled:

- External ports
- External management over all ports
- Preserve new IP configuration on all resets

The default setting is **Disabled** for these features. If these features are not already enabled, change the setting to **Enabled**; then, click **Save**.

Note: See the *Installation and User's Guide* for your BladeCenter unit for additional information about enabling external management over all ports.

6. For I/O modules that support Network Address Translation (NAT) table, click **Network Protocol Configuration**.

The first column of the NAT table contains links that you can use to configure the protocol values. The maximum number of protocols is ten. Five protocols are predefined; for example, the first protocol will always be hypertext transfer protocol (HTTP), and the second protocol will always be Telnet.

You can activate or modify the Network Protocol settings on this page of the management-module interface by clicking one of the following buttons:

- To activate all of the values in the NAT table, click the **Activate** button.
- To immediately reset all of the values in the NAT table to their defaults, click the **Reset to defaults** button.

You can now start a Web-interface session, a Telnet session, or a Secure Shell (SSH) session to the I/O module to perform additional configuration. See the documentation for your I/O module for information.

Chapter 3. Management-module Web interface overview

This section describes the structure and content of the management-module Web interface for all management-module types. It has the following information:

- Features of the management-module Web interface that can be accessed by users, according to their assigned roles or authority levels (see “Web interface pages and user roles”)
- Descriptions of the management-module Web interface pages (see “Management-module Web interface options” on page 62)

See Chapter 2, “Using the management-module Web interface,” on page 5 for information about using the management-module Web interface to perform selected functions.

The Web-based user interface communicates with the management and configuration program that is part of the firmware that comes with the management module. You can use this program to perform the following tasks:

- Defining the login IDs and passwords.
- Selecting recipients for alert notification of specific events.
- Monitoring the status of the BladeCenter unit, blade servers, and other BladeCenter components.
- Controlling the BladeCenter unit, blade servers, and other BladeCenter components.
- Accessing the I/O modules to configure them.
- Changing the startup sequence in a blade server.
- Setting the date and time.
- Using a remote console for the blade servers.
- Changing ownership of the keyboard, video, and mouse.
- Changing ownership of the removable-media drives and USB ports. (The removable-media drives in the BladeCenter unit are viewed as USB devices by the blade server operating system.)
- Activating On Demand blade servers.
- Setting the active color of the critical (CRT) and major (MJR) alarm LEDs (for BladeCenter T unit only)

You also can use the management-module Web interface, SNMP, SMASH, and the management-module command-line interface to view some of the blade server configuration settings. See the information in this chapter and the documentation for the management method that you are using for more information.

Web interface pages and user roles

Some fields and selections in the management-module Web interface pages can be changed or executed only by users who are assigned roles with the required level of authority for those pages. Users with the Supervisor role (command authority) for a page can change information and execute all tasks in the page. Viewing information does not require any special command authority; however, users can be assigned restricted read-only access to specific devices in the BladeCenter unit, as follows:

- Users with the Operator role can view all information.

- Users with the Chassis Operator custom role can view information about the common BladeCenter unit components.
- Users with Blade Operator custom role can view information about the blade servers.
- Users with I/O Module (Switch) Operator custom role can view information about the I/O modules.

Table 2 lists the management-module Web interface pages and the roles (command authority levels) that are required to change information in these pages. The pages and roles that are listed in this table applies only to changing the information in a page or executing a task specified in a page: viewing the information in a page does not require any special role or command authority. In the table, each row indicates the valid user roles (command authorities) that allow a user to change the information or execute a task in that page. For example, in Table 2 executing tasks in the **Blade Tasks → Power/Restart** page is available to users with the Supervisor role or to users with the Blade Administration role.

Important: Make sure that the role set for each user is correct after updating management-module firmware, as these definitions might change between firmware versions.

Table 2. User role relationships

Page		Role required to change information or execute tasks										
		Supervisor	Chassis User Account Management	Blade Server Remote Presence	Chassis Operator	Chassis Administration	Blade Administration	I/O Module Administration	Chassis Log Administration	Chassis Configuration	Blade Configuration	I/O Module Configuration
Monitors	System Status	•	•	•	•	•	•	•	•	•	•	•
	Event Log (view)	•	•	•	•	•	•	•	•	•	•	•
	Event Log (clear or set log policy)	•							•			
	LEDs	•	•	•		•	•	•	•	•	•	•
	Fuel Gauge	•	•	•		•	•	•	•	•	•	•
	Hardware VPD	•	•	•		•	•	•	•	•	•	•
	Firmware VPD	•	•	•		•	•	•	•	•	•	•

Table 2. User role relationships (continued)

		Role required to change information or execute tasks										
		Supervisor	Chassis User Account Management	Blade Server Remote Presence	Chassis Operator	Chassis Administration	Blade Administration	I/O Module Administration	Chassis Log Administration	Chassis Configuration	Blade Configuration	I/O Module Configuration
Blade Tasks	Power/Restart	•					•					
	On Demand	•					•					
	Remote Control (remote console)	•		•								
	Remote Control (virtual media) (management modules other than the advanced management module)	•		•								
	Firmware Update	•					•					
	Configuration	•									•	
	Serial over LAN	•								•	•	
I/O Module Tasks	Admin/Power/Restart	•						•				
	Configuration (see Note 1)	•										•
	Firmware Update	•						•				

Table 2. User role relationships (continued)

Page		Role required to change information or execute tasks										
		Supervisor	Chassis User Account Management	Blade Server Remote Presence	Chassis Operator	Chassis Administration	Blade Administration	I/O Module Administration	Chassis Log Administration	Chassis Configuration	Blade Configuration	I/O Module Configuration
MM Control	General Settings	•								•		
	Login Profiles	•	•									
	Global Login Settings	•								•		
	Alerts (see Note 2)	•								•		
	Serial Port	•								•		
	Port Assignments	•								•		
	Network Interfaces	•								•		
	Network Protocols	•								•		
	Security	•								•		
	Configuration File (backup) (does not apply to advanced management module)	•			•							
	Configuration File (restore) (does not apply to advanced management module)	•										
	Configuration Mgmt (backup configuration to file) (advanced management module only)	•	•		•	•			•	•		
	Configuration Mgmt (save configuration to chassis)(advanced management module only)	•										
	Configuration Mgmt (restore) (advanced management module only)	•										
MM Control	Firmware Update	•				•						
	Restore Defaults (see Note 3)	•				◇				◇		
	Configuration Wizard (advanced management module only)	•										
	Restart MM	•				•						

Table 2. User role relationships (continued)

		Role required to change information or execute tasks										
		Supervisor	Chassis User Account Management	Blade Server Remote Presence	Chassis Operator	Chassis Administration	Blade Administration	I/O Module Administration	Chassis Log Administration	Chassis Configuration	Blade Configuration	I/O Module Configuration
Service Tools	Settings	•								•		
	Service Data	•										
	AMM Status (view only)											

Notes:

1. To send ping requests to an I/O module (**Advanced Management** link in **I/O Module Tasks → Configuration** page), the I/O Module Administration, I/O Module Configuration, or I/O Module Operator role is required.
2. For the BladeCenter T Management Module, the Supervisor or Chassis Administration role is required to reset filter detection under **MM Control → Alerts**.
3. For the **MM Control → Restore Defaults** page, both the Chassis Administration and Chassis Configuration roles are required.

Management-module Web interface options

Run the management and configuration program from the management-module Web interface to select the BladeCenter settings that you want to view or change.


The navigation pane (on the left side of the management-module Web interface window) contains navigational links that you use to manage your BladeCenter unit and check the status of the components (modules and blade servers). The links that are in the navigation pane are described in the following sections.

Online help is provided for the management-module Web interface. Click the help (?) icon next to a section or choice to display additional information about that item. For the advanced management module, Web interface screens are date and time stamped each time they are refreshed.

Monitors

Select the choices in the **Monitors** section to view the status, settings, and other information about components in your BladeCenter unit type.


System Status



Select **System Status** to view the overall system status, a list of outstanding events that require immediate attention, and the overall status of each of the blade servers and other components in the BladeCenter unit.

BladeCenter T alarm management:

System Status Summary

 One or more monitored parameters are abnormal.

Critical Alarms

Alarm Description	Action
Power Supply 4 DC Good Fault	<input type="button" value="ACK"/> <input type="button" value="CLEAR"/>

Major Alarms

Alarm Description	Action
Insufficient chassis power to support redundancy	<input type="button" value="ACK"/> <input type="button" value="CLEAR"/>

Minor Alarms

Alarm Description	Action
power will be cycled at 2AM - sysadmin	<input type="button" value="ACK"/> <input type="button" value="CLEAR"/>

Acknowledged Alarms

Alarm Description	Action
filter will need changing during next service	<input type="button" value="CLEAR"/>

The following links can be used to view the status of different components.

[Blade Servers](#)
[I/O Modules](#)

For the BladeCenter T unit, the System Status Summary displays active alarm conditions that are grouped by alarm type (critical, major, or minor). Critical, major, and minor alarms light the LED associated with their alarm level on the BladeCenter T unit. Acknowledging an alarm moves it from the critical, major, or minor active list to the acknowledged list and turns off its LED. Clearing an alarm removes it from all alarm lists and turns off its LED. Acknowledging or clearing an alarm only turns off its LED when there are no other alarms of the same level that are active to keep the LED turned on.

There are two action buttons, **ACK** and **CLEAR**, next to each alarm description in the list of active alarms. Click **ACK** to turn off the LED associated with an alarm and move the alarm to the acknowledged list. Click **CLEAR** to turn off the LED associated with the alarm and remove the alarm from all alarm lists. After an alarm has been moved to the acknowledged list, it can be removed from all alarm lists by clicking **CLEAR** action button that is to the right of the acknowledged alarm description.

BladeCenter unit detailed component status: The System Status pane provides the following detailed status information for BladeCenter components.

The following illustration shows a Blade Servers status pane for management modules other than the advanced management module.

Blade Servers ?

Click the icon in the Status column to view detailed information about each blade server.

Bay	Status	Name	Pwr	Owner**		Network		WOL*	Local Control			BEM*
				KVM	MT*	Onboard	Card		Pwr	KVM	MT*	
1		SN#K10V7363140	Off			Eth	--- ---	On	X	X	X	
2		SN#K10V7364105	Off			Eth	--- ---	On	X	X	X	
3		Blade 04	Off			Eth	--- ---	On	X	X	X	
4												
5		No blade present										
6		SN#K10UJ353166	Off	X	X	Eth	--- ---	On	X	X	X	
7		No blade present										
8		No blade present										

* MT = Media Tray (CD/USB) , WOL = Wake on LAN , BEM = Blade Expansion Module ,
BSE = Blade Storage Expansion , BPE = Blade PCI Expansion
** You can change the KVM and Media Tray ownership on the Remote Control panel (under Blade Tasks).

The following illustration shows a Blade Servers status pane for the advanced management module.

Blade Servers ?

Click the icon in the Status column to view detailed information about each blade server.

Bay	Status	Name	Pwr	Owner**		Connectivity/Expansion Cards		WOL*	Local Control			BEM*
				KVM	MT*	Legacy	HS*		Pwr	KVM	MT*	
1		No blade present										
2		JS21-Mau(SIT)	Off					On	X	X	X	
3		No blade present										
4		No blade present										
5		SN#YK30A0642036	Off					On	X	X	X	
6												
7		No blade present										
8		No blade present										
9		No blade present										
10		No blade present										
11		No blade present										
12		No blade present										
13		No blade present										
14		No blade present										

* MT = Media Tray (CD/ USB) , WOL = Wake on LAN , BEM = Blade Expansion Module , HS = High Speed
BSE = Blade Storage Expansion , PEU = Blade PCI I/O Expansion
** You can change the KVM and Media Tray ownership on the Remote Control panel (under Blade Tasks).


When you click **Blade Servers**, the following information is displayed:

- **Bay** - The lowest-number bay that the blade server occupies.
- **Status** - An icon that indicates good, warning, or bad status for the blade server. Click the icon for more detailed status information.
- **Name** - The name of the blade server.
- **Pwr** - The power state (on or off) of the blade server.
- **Owner** - An indication of whether the blade server is the current owner of the following BladeCenter resources:
 - **KVM** - Keyboard, video, and mouse
 - **MT** - The media tray containing the removable-media drives and USB ports

- **Network** (management modules other than the advanced management modules) - An indication of which network interfaces are on the blade server (Onboard) and the I/O expansion options (Card). For example, an Onboard status of Eth indicates that the blade server has integrated Ethernet controllers on the system board and a Card status of Fibre indicates that the blade server has a Fibre Channel I/O expansion option installed.
- **Connectivity/Expansion Cards** (advanced management modules only) - The Legacy column lists the types of I/O expansion cards installed in the blade server. The possible values are Eth (Ethernet), Ser (serial), Opt (optical), Fib (fibre), IB (Infiniband), CFFe (PCIe Combo Form Factor), iSC (iSCSI), and NVR (NVRAM). If multiple expansion cards are installed, they are listed in order starting with slot 1. The HS column lists the type of high-speed I/O-expansion cards installed in the blade server.
- **WOL** - An indication of whether the Wake on LAN feature is currently enabled for the blade server. The Wake on LAN feature is enabled by default in blade server BIOS and cannot be disabled. The BladeCenter management module provides a single point of control for the Wake on LAN feature, enabling the settings to be controlled for either the entire BladeCenter unit or a single blade server. Wake on LAN settings that are made in the management module override the settings in the blade server BIOS. See “Power/Restart” on page 76 for information.
- **Local Control** - An indication of whether the following options are enabled:
 - Local power control
 - Local keyboard, video, and mouse switching
 - Local removable-media drive and USB port switching
- **BEM** - An indication of whether an expansion unit, such as the SCSI expansion unit or PCI I/O Expansion Unit, occupies the blade bay.
- **SCOD** - (This information does not apply to all BladeCenter unit types and displays only when on-demand blade servers are installed in the BladeCenter unit.) An indication of whether the blade server is an On Demand blade server with a Standby status. You cannot turn on an On Demand blade server until you activate it (**Blade Tasks** → **On Demand**), which changes the status from Standby to Active.

Note: You must contact IBM within 14 calendar days after you activate an On Demand blade server. See your *Agreement for Standby Capacity on Demand* for additional information.

I/O Modules ?

Bay	Status	Type*	MAC Address	IP Address	Pwr	POST Status
1		Ethernet SM	00:05:5D:89:A3:A0	192.168.70.127	On	POST results available: FF: Module completed POST
2			No module present			
3			No module present			
4			No module present			

* SM = Switch Module, CM = Concentrator Module, PM = Pass-thru Module


When you click **I/O Modules**, the following information is displayed. The number of I/O module bays varies by BladeCenter unit type.

- **Bay** - The number of the bay that the I/O module occupies.
- **Status** - An icon that indicates good, warning, or bad status for the I/O module.
- **Type** - The type of I/O module in the bay, such as an Ethernet I/O module, Fibre Channel I/O module, or pass-thru module.


- **MAC Address** - The medium access control (MAC) address of the I/O module.

Note: Some types of I/O modules, such as a pass-thru module, have no MAC address nor IP address.

- **IP Address** - The IP address of the I/O module.
- **Pwr** - The power state (on or off) of the I/O module.
- **POST Status** - Text information about the status of the I/O module.


Management Modules 



Click the icon in the Status column for details about the primary management module.

Bay	Status	IP Address (external n/w interface)	Primary
1		192.168.70.125	X
2		No MM present	

When you click **Management Module**, the following information is displayed:

- **Bay** - The number of the bay that the management module occupies.
- **Status** - An icon that indicates good, warning, or critical status for the management module. Click the status icon for more detailed status information, such as self-test results, power-supply voltage levels, the inside temperature of the BladeCenter unit, and a list of users that are currently logged in to the BladeCenter unit. For the advanced management module, the detailed status will also display a list of users that are logged into the management module along with their access information.
- **IP Address** - The IP address of the remote management and console connection (external Ethernet port) on the management module.
- **Primary** - An indication of which management module is the primary, or active, management module.




Power Modules 

Bay	Status	Details
1		Power module status OK
2		Power module status OK
3		No power module
4		No power module

When you click **Power Modules**, the following information is displayed:

- **Bay** - The number of the bay that the power module occupies.
- **Status** - An icon that indicates good, warning, or critical status for the power module.
- **Details** - Text information about the status of the power module.

Fan-packs

Bay	Status	Fan Count	Average Speed (% of max)	Average Speed (RPM)	Controller State
1		3	51%	1400	Operational
2		3	----	----	Flashing
3			No fan-pack		
4		3	51%	1400	Operational

When you click **Fan-packs** (advanced management module installed in a BladeCenter H unit only), the following information is displayed:

- **Bay** - The number of the power module bay that the fan-pack occupies.
- **Status** - An icon that indicates good, warning, or critical status for the fan-pack.
- **Fan Count** - An number that indicates the number of fans in the fan-pack that are operational.
- **Average Speed (% of max)** - The current speed of the fan-pack, as a percentage of the maximum revolutions per minute (rpm). The fan-pack speed varies with the thermal load. An entry of 0ffline indicates that the fan-pack is not functioning.
- **Average Speed (RPM)** - The current speed of the fan-pack in RPMs. The fan-pack speed varies with the thermal load.
- **Controller State** - Indicates status of the fan-pack speed controller: operational, flashing (firmware is updating), not present, or communication error.

Blowers

Bay	Status	Speed (% of max)	Speed (RPM)	Controller State
1		51%	1400	Operational
2		----	----	Flashing

When you click **Blowers**, the following information is displayed:

- **Bay** - The number of the bay that the blower module occupies.
- **Status** - An icon that indicates good, warning, or critical status for the blower module.
- **Speed (% of max)** - The current speed of the blower module, as a percentage of the maximum revolutions per minute (rpm). The blower speed varies with the thermal load. An entry of 0ffline indicates that the blower is not functioning.
- **Speed (RPM)** (advanced management module installed in a BladeCenter H unit only) - The current speed of the blower module in RPMs. The blower speed varies with the thermal load.
- **Controller State** (advanced management module installed in a BladeCenter H unit only) - Indicates status of the blower speed controller: operational, flashing (firmware is updating), not present, or communication error.


Front Panel

Temp (°C)	Warning	Warning Reset
24.00	39.00	30.00

When you click **Front panel** the following information is displayed (front-panel temperature status is not available for all BladeCenter unit types):

- **Temp (C°)** - The ambient temperature of the front panel, as indicated by the front-panel temperature sensor.
- **Warning** - If the ambient temperature of the front panel reaches the warning threshold, a temperature warning event occurs that is entered in the event log.
- **Warning Reset** - If the ambient temperature of the front panel exceeds the warning threshold and then drops below the warning reset threshold, the temperature warning event is cleared. An indication that the temperature warning is cleared is entered in the event log.
- **Hysteresis** (advanced management module installed in a BladeCenter T unit only) - Indicates the difference between the warning and the warning reset temperature thresholds.

Event Log

Event Log 

☒ Monitor log state events

Severity	Source	Date
<div><div>E</div><div>W</div><div>I</div></div>	Error Warning Info	BLADE_02 BLADE_05 SERVPROC

Filter

Disable Filter

Note: Hold down Ctrl to select more than one option.
Hold down Shift to select a range of options.

Filters: None

Index	Sev	Source	Date/Time	Text
1	E	BLADE_02	06/23/03, 06:16:06	(IBM 867821X SN1) Hard Drive 2 Fault
2	E	BLADE_05	06/23/03, 06:15:08	(SN#J1RNE34911N) POSTBIOS: 162 Configuration Change Has Occurred
3	E	BLADE_05	06/23/03, 06:15:08	(SN#J1RNE34911N) POSTBIOS: 1762 Configuration Change Has Occurred
4	I	SERVPROC	06/23/03, 06:14:10	User USERID attempting to restart blade in bay 2.
5	I	SERVPROC	06/23/03, 06:13:55	User USERID attempting to restart blade in bay 5.
6	I	SERVPROC	06/23/03, 06:13:41	System log cleared.
End of Log.				

Clear Log

Save Log as Text File

Select **Event Log** to view entries that are currently stored in the management-module event log. This log includes entries for events that are detected by the blade servers. The log displays the most recent entries first. Information about all remote access attempts is recorded in the event log, and the management module sends out the applicable alerts if it is configured to do so.

The event log is of fixed capacity. On the BladeCenter unit, when the log is 75 percent full, the BladeCenter Information LEDs are lit. On the BladeCenter T unit, when the log is 75% full, the BladeCenter T MNR (minor alarm) LED is lit. On the BladeCenter unit, when the log is full, new entries overwrite the oldest entries, and the BladeCenter Error LEDs are lit. On the BladeCenter T unit, when the log is full,

new entries overwrite the oldest entries, and the BladeCenter T MJR (major alarm) LED is lit. If you do not want the management module to monitor the state of the event log, clear the **Monitor log state events** check box at the top of the event log page.

You can sort and filter entries in the event log. See the event log help for more information.

LEDs

BladeCenter unit LEDs:

The screenshot shows a web interface for configuring LEDs. It is divided into two main sections: 'Front and Rear Panel LEDs' and 'Blade Server LEDs'.

Front and Rear Panel LEDs

LED	Status	Action
System error		
Information		Off
Temperature		
Location		On Off Blink

Blade Server LEDs

Bay	Name	Pwr*	Error	Information	KVM	MT	Location
1	No blade present						
2	IBM 867821X SN1	On			Off		
3							
4	No blade present						
5	SNWJ1RNE34911N	On			Off		
6	No blade present						
7	No blade present						
8	No blade present						
9	No blade present						
10	No blade present						
11	No blade present						


Select **LEDs** to view the state of the BladeCenter system LED panel and blade server control panel LEDs. You also can use this choice to turn off the information LED and turn on, turn off, or blink the location LED on the BladeCenter unit and the blade servers.





The following information is displayed:


- **Front Panel LEDs** - The state of the following LEDs on the BladeCenter system LED panel. You can change the state of the information and location LEDs.
 - System error
 - Information
 - Over temperature
 - Location
- **Blade Server LEDs** - The state of the following LEDs on the blade server control panel. You can change the state of the information and location LEDs.
 - Power
 - Error
 - Information
 - Keyboard, video, and monitor select
 - Media (optical drive, diskette drive, USB port) select
 - Location
- **I/O-Module LEDs** - The state of the LEDs on some I/O-modules.


- **Fan-pack LEDs** (advanced management module installed in a BladeCenter H unit only) - The state of the Error LED on each power module fan-pack.
- **Blower LEDs** (advanced management module installed in a BladeCenter H unit only) - The state of the Error LED on each blower.

BladeCenter T unit LEDs:


Front and Rear Panel LEDs 

LED	Status	Action
Critical Alarm		Color of Critical and Major LEDs <input type="radio"/> Red <input checked="" type="radio"/> Amber
Major Alarm		
Minor Alarm		
Location		<input type="button" value="On"/> <input type="button" value="Off"/> <input type="button" value="Blink"/>
Light LEDs for Most Severe Alarm Only or for All Alarm Levels <input type="radio"/> Most Severe Alarm Only <input checked="" type="radio"/> All Alarms		

Set Alarm Panel LEDs 

Alarm Panel Severity: 

Alarm Description:

Blade Server LEDs 

Bay Name	State	Error	Information	KVM	MT	Location

Select **LEDs** to view the state of the BladeCenter T system-status panel and blade server control panel LEDs. You can also use this choice to turn on, turn off, or flash the location LED on the BladeCenter T unit and the blade servers, and control how the LEDs respond to alarms.

The following information is displayed:

- **Front and Rear Panel LEDs** - Controls and displays the state of the following LEDs on the BladeCenter T system LED panel:
 - Critical Alarm (CRT LED)
 - Major Alarm (MJR LED)
 - Minor Alarm (MNR LED)
 - Location

You can change the state of the location LED and select the active LED color (red or amber) for the critical and major alarm LEDs. This color selection is applied to the LEDs on the front and rear of the BladeCenter T unit and to the LED indications that are shown on this page. You can also specify whether the management module lights LEDs for all alarm levels that occur (critical, major, or minor) or whether it lights only the LED that corresponds to the most severe alarm level that occurs. Amber is the default color for the critical and major alarm LEDs. The management module is also set to light the LEDs for all alarm levels that occur (critical, major, or minor), by default.

- **Set Alarm Panel LEDs** - You can control the status of the LEDs on the front and rear of the BladeCenter T unit using the alarms database of the management module. Alarms can be added to the alarms database to provide user-defined control. To add an alarm, you must select the alarm severity that specifies which LED the alarm controls and enter a non-blank alarm description; then, click SET. After an alarm is added to the database, you can manage the alarm and its

associated LED from the System Status pane using the ACK and CLEAR buttons (see “System Status” on page 62 for information).

- **Blade Server LEDs** - The state of the following LEDs on the blade server control panel. You can change the state of the information and location LEDs.
 - Power
 - Error
 - Information
 - Keyboard, video, and monitor select
 - Media (optical drive and USB port) select
 - Location
- **I/O-Module LEDs** - The state of the LEDs on some I/O-modules.

Fuel Gauge

Select **Fuel Gauge** to view the power information, based on projected power consumption, for each power domain of the BladeCenter unit. Click the **Power management policy settings** link to go to the section of the **Blade Tasks** → **Configuration** page where you configure power management for the BladeCenter unit (see “Configuration” on page 83 for information).

BladeCenter Power Summary

	Power Domain 1	Power Domain 2
Status	● Power domain status is good.	● Power domain status is good.
Power Modules	Bay 1: 2000W Bay 2: 2000W	Bay 3: 1800W Bay 4: 1800W
Power Management Policy	Non-redundant	Non-redundant
Total Power [†]	2000W	1800W
Power in Use	390W	0W

BladeCenter Power Planning

	Power Domain 1	Power Domain 2
Total Power [†]	2000W	1800W
- Allocated Power (Max)	390W	0W
= Remaining Power	1610W	1800W

[†] **Note:** Actual total power limit may vary from power module label.

Use the following links to jump to different sections.

[Power Domain 1 details](#)

[Power Domain 2 details](#)

[Power management policy settings](#)

Refresh

There are two power domains in the BladeCenter unit. Click **Power Domain 1 details** or **Power Domain 2 details** for the list of BladeCenter components in each power domain (see page 73 for information). The power-management policy settings determine how the BladeCenter unit reacts in each power domain to a power source failure or power module failure. The combination of the BladeCenter

configuration, power-management policy settings, and available power might cause blade servers to reduce their power level (throttle) or not turn on.

The following power status information is displayed in the **BladeCenter Power Summary** and **BladeCenter Power Planning** sections:

- **Status** - This field contains a color-coded icon that indicates status of the power-domains and a short status description that lists any outstanding issues related to power consumption or redundancy in each power domain.
- **Power Modules** - This field lists the power modules installed in each power domain and their rated capacity in Watts.
- **Power-Management Policy** - This field displays the power-management policy set for each power domain, defining how the power domain will react to conditions that could result in a loss of redundancy. This setting is configured on the **Blade Tasks → Configuration** page (see “Configuration” on page 83 for information)
- **Power in Use** - This field displays the current power being used in each power domain, in Watts.
- **Total Power** - This field displays the amount of power available in each power domain, in Watts. Total power is calculated by the management module based on the rated capacities of the power modules installed in a power domain and the power-management policy that has been set for this power domain.
- **Allocated Power (Max)** - This field displays the total amount of power, in Watts, that is reserved for use by the components that are installed in a power domain. This value might include power for components that are not currently installed in the BladeCenter unit, such as the I/O Modules. Power is reserved for these components because the management module pre-allocates power for some components that are normally required for BladeCenter unit operation. The reserved-power total might also include power for components that are installed in BladeCenter unit, are in a standby state, and are not turned on. These components are included in the total so that the amount of spare (unallocated) power in the power domain can be accurately calculated.
- **Remaining Power** - This field displays the amount of unallocated (spare) power in a power domain, in Watts. This value is used by the management module when deciding if a newly installed module should turn on. The remaining power value is calculated based on the total power and the amount of reserved power for each power domain.

Detailed power information:

Power Domain 1

Bay(s)	Status	Module	State	Allocated Power			CPU Duty Cycles
				Currently	Max	Min	
Chassis Components							
		Midplane	On	10W	10W	10W	n/a
		Media Tray	On	10W	10W	10W	n/a
Blowers							
1		Blower 1	On	120W	120W	120W	n/a
2		Blower 2	On	120W	120W	120W	n/a
Management Modules							
1		WMN189277931	On	25W	25W	25W	n/a
2		Backup MM (not present)		15W	15W	15W	n/a
I/O Modules							
1		Ethernet SM	On	45W	45W	45W	n/a
2		Ethernet SM	On	45W	45W	45W	n/a
Blade Servers							
1		SN#J1RNE77931M	Standby	30W	202W	138W	(0% ,0%)
2		SN#J1RNE34912M	On	150W	150W	150W	n/a
4		SN#J1RNE18927M	Standby	40W	150W	150W	n/a
DOMAIN TOTALS				Currently	Max	Min	
Power Allocation				610W	892W	828W	



† This blade may throttle if redundancy is lost in this power domain.

* Cannot communicate with the blade. The power values for this blade are assumed.

Refresh

The detailed power status information for each monitored BladeCenter component is displayed in the **Power Domain details** sections of the Fuel Gauge page. The BladeCenter components that are part of each power domain are grouped by type. The status information for power domain 1 is shown. There is a separate status section for each power domain in your BladeCenter unit type.

The following information is displayed for each component that is installed in a power domain:

- **Bay** - This field displays the bays, if applicable, that a BladeCenter component occupies. It also indicates if a blade server is able to reduce its power consumption (throttle) if power redundancy is lost.
- **Status** - This field displays an icon that indicates power-management events that are outstanding for the component. The  icon indicates that a blade server will not be able to turn on because there is not enough remaining power in the power domain to support it. The  icon indicates that a blade server is currently reducing its power consumption (power throttling) to maintain redundant power in a power domain.
- **Module** - This field displays the component description.
- **State** - This field displays the power state of the module (On or Standby).
- **Currently Allocated Power** - This field displays the amount of power, in Watts, that is allocated to this module.
- **Maximum Allocated Power** - This field displays the maximum amount of power, in Watts, that a component requires.
- **Minimum Allocated Power** - This field displays the minimum amount of power, in Watts, that a blade server requires when it is operating at its minimum power level (fully throttled).

- **CPU Duty Cycles** - This field only applies to blade servers. It displays the duty cycle for each microprocessor installed in a blade server, as a percentage of full operation. The duty cycles for each microprocessor are separated by commas. An n/a is displayed for blade servers that do not report their CPU duty cycles. A duty cycle is a ratio of actual processing time used as a percentage of total processor time available.
- **DOMAIN TOTALS** - These fields list the total power allocated for all components installed in the power domain.

Hardware VPD

BladeCenter System VPD

Type / Model	87301XZ
Serial no.	23A0001
UUID	A7FB FB81 DB12 11D6 8D71 C8D6 4BF2 ED0C

[Edit BladeCenter System VPD](#)

BladeCenter Hardware VPD

Move your mouse pointer over a module name to see a description for that module in the status bar of your browser.

Bay(s)	Module Name	Manuf. ID	Machine Type/Model	Machine Serial No.	Hardware Revision	Manuf. Date	Part Number	FRU Number	FRU Serial No.
Chassis and Media Tray									
	Chassis	IBM	87301XZ	----	2	4603	90P3678	90P3696	3471CHT0
1	Media Tray	----	n/a	n/a	0	----	----	----	----
Blade Servers									
3-4	Blade 04	Intel	883931X	23A0119	----	----	----	90P0978	----
	Daughter Card	Unable to read VPD.							
	Daughter Card	Unable to read VPD.							
5	SN#<10V7363140	SLRM	867841X	KPHT239	8	2303	73P9120	73P9121	K10V736
6	SN#<10UJ353166	SLRM	867841X	KPHT163	8	1803	71P8790	59P6610	K10UJ35
8	SN#<10V7364105	SLRM	867841X	KPHT213	8	2303	73P9120	73P9121	K10V736

Select **Hardware VPD** to view the hardware vital product data (VPD) for the BladeCenter unit. When the BladeCenter unit is started, the management module collects the vital product data and stores it in nonvolatile memory. The management module then modifies the stored VPD as components are added to or removed from the BladeCenter unit. The hardware VPD that is collected and stored varies by BladeCenter unit type. Click **Module Activity Log** to view the log of modules that have been installed in or removed from the BladeCenter unit. The **WWN/GUID of Blades and Expansion Cards** section of the Hardware VPD page displays the World Wide Name (WWN) or Globally Unique Identifier (GUID) assigned to the blade servers and expansion cards. The **BladeCenter Server MAC Addresses** section at the bottom of the Hardware VPD page displays the MAC addresses of the integrated Ethernet controllers in each blade server.

Firmware VPD

Blade Server Firmware VPD

Bay(s)	Name	Firmware Type	Build ID	Released	Revision
1	SN#J1RNE34911N	BIOS	BSE105AUS	06/23/2003	1.00
		Diagnostics	BSYT06AUS	05/01/2003	1.00
		Blade sys. mgmt. proc.	BR8T17A	n/a	17
2	SN#ZJ1WLW47T16N	BIOS	BWE105AUS	08/06/2004	1.00
		Diagnostics	BWYT01AUS	06/11/2004	1.00
		Blade sys. mgmt. proc.	BWBT02A	n/a	0

To reread firmware VPD for a blade, select the blade, and click "Reload VPD".
This process may take a while.

Target

I/O Module Firmware VPD

Bay	Type	Firmware Type	Build ID	Released	Revision
1	Ethernet SM	Boot ROM	BRESMB4G	02/21/2003	05
		Main Application 1	BRESMR4G	12/19/2003	81
2	Ethernet SM	Boot ROM	BRESMB4G	01/29/2003	04
		Main Application 1	BRESMR4G	10/16/2003	72

Management Module Firmware VPD

Bay	Name	Firmware Type	Build ID	File Name	Released	Revision
1	4P3MM	Main application	BRET72A	CNETMNUS.PKT	08-13-04	16
		Boot ROM	BRBR72A	CNETBRUS.PKT	08-13-04	16
		Remote control	BRRG72A	CNETRGUS.PKT	08-13-04	16
2	Redundant MM	Main application	RRFT72A	CNFTMNUS.PKT	08-13-04	16


Select **Firmware VPD** to view the vital product data (VPD) for the firmware in all blade servers, I/O modules, and management modules in the BladeCenter unit. The firmware VPD that is collected and stored varies by BladeCenter unit type. For an advanced management module that is installed in a BladeCenter H, you can also view the VPD for blower and fan-pack firmware. The firmware VPD identifies the firmware type and provides version information such as a build ID, release date, and revision number. The VPD information varies by BladeCenter component type; for example, the VPD for the management-module firmware might also include the file name of the firmware components. (After you select **Firmware VPD**, it takes up to 30 seconds to refresh and display information.)

Click **Reload VPD** to refresh the firmware VPD information for a selected blade server or for all blade servers installed in the BladeCenter unit.

Blade Tasks

Select the choices in the **Blade Tasks** section to view and change the settings or configurations of blade servers in the BladeCenter unit.

Power/Restart

Blade Power / Restart 

Click the checkboxes in the first column to select one or more blade servers; then, click one of the links below the table to perform the desired action.

<input type="checkbox"/>	Bay	Name	Pwr	Local Pwr Control	Wake on LAN	Console Redirect	SCOD [†]
<input type="checkbox"/>	1	SN#K10V7363140	Off	Enabled	On		
<input type="checkbox"/>	2	SN#K10V7364105	Off	Enabled	On		
<input type="checkbox"/>	3	Blade 04	Off	Enabled	On		
	4						
	5	SN#K10WE39F17P	Off	Enabled	On		X
<input type="checkbox"/>	6	SN#K10UJ353166	Off	Enabled	On		
	7	No blade present					
	8	No blade present					

[†] SCOD = Standby Capacity on Demand

[Power On Blade](#)
[Power Off Blade](#)
[Restart Blade](#)
[Enable Local Power Control](#)
[Disable Local Power Control](#)
[Enable Wake on LAN](#)
[Disable Wake on LAN](#)
[Restart Blade System Mgmt Processor](#)

Select **Power/Restart** to perform the following actions on any blade server in the BladeCenter unit.

Notes:

1. You cannot perform these actions on an On Demand blade server with a Standby status (indicated by an X in the SCOD column). To activate an On Demand blade server, see the instructions in “On Demand” on page 77.
 2. The SCOD column displays only when on-demand blade servers are installed in the BladeCenter unit.
- Turn on or turn off the selected blade server (set the power state on or off).
 - Enable or disable local power control. When local power control is enabled, a local user can turn on or turn off the blade server by pressing the power-control button on the blade server.
 - Enable or disable the Wake on LAN feature.
 - Restart the blade server or the service processor in the blade server.
 - See which blade servers are currently under the control of a remote console (indicated by an X in the Console Redirect column).

Select the blade servers on which you want to perform an action; then, click the applicable link below the table for the action that you want to perform.

The following actions will not display unless an IBM BladeCenter JS20 Type 8842 blade server is installed in the BladeCenter unit. These actions will operate as described below for the BladeCenter JS20 Type 8842 blade server. When these actions are applied to other blade server types, they will perform a standard restart of the blade server.

- Restart the selected blade server with non-maskable interrupt (NMI).

- Restart the selected blade server and clear all settings stored in non-volatile memory (NVRAM).
- Restart the selected blade server and run diagnostics.
- Restart the selected blade server and run diagnostics using the default boot sequence configured for the blade server.

On Demand

On Demand Blade Activation

Click the checkboxes in the first column to select one or more On Demand blade servers that have a Standby status; then, click the 'Activate Standby Blade Servers' link below to activate the selected blade servers.

Note: You must contact IBM within 14 calendar days after you activate an On Demand blade server. See your Agreement for Standby Capacity on Demand for additional information.

Activating an On Demand blade server restarts the Blade System Management Processor on the blade server. It will take a few minutes for the status of the activated blade server to change from Standby to Active.

Select	Bay	Name	On Demand
	1	SN#K10V7363140	N/A
	2	SN#K10V7364105	N/A
	3	Blade 04	N/A
	4		
<input checked="" type="checkbox"/>	5	SN#K10WE39F17P	Standby
	6	SN#K10UJ353166	N/A
	7	No blade present	
	8	No blade present	

[Activate Standby Blade Servers](#)

Note: The OnDemand page displays only when there are on-demand blade servers installed in the BladeCenter unit.

Select **On Demand** to activate an On Demand blade server with Standby status. You must activate an On Demand blade server with Standby status before you can turn it on. When you activate an On Demand blade server, its status changes from Standby to Active, making the blade server available for use.

Select the check boxes in the Select column for one or more On Demand blade servers that have a Standby status; then, click the **Activate Standby Blade Servers** link to activate the selected blade servers. Blade servers with an On Demand status of N/A are not On Demand blade servers.

Note: You must contact IBM within 14 calendar days after you activate an On Demand blade server. See your *Agreement for Standby Capacity on Demand* for additional information.

Remote Control

The management module and advanced management module have different remote control panes.

The following illustration shows the Remote Control pane for management modules other than the advanced management module.

Remote Control Status

KVM owner:	Blade5 - SN#U1RNE34911N since 11/15/2003 09:24:11
Media tray owner:	Blade2 - IBM 867821X SN1 since 11/10/2003 10:12:57
Console redirect:	No session in progress.

Refresh

Start Remote Control

To disable the buttons located on the blade servers for KVM and media tray switching, check the boxes below and click "Save". Click "Start Remote Control" to control a blade server remotely. A new window will appear that provides access to the Remote Console and Remote Disk functionality. On this window, you will have full keyboard and mouse control of the blade server which currently owns the KVM. You will also be able to change KVM and media tray ownership.

Note: An Internet connection is required to download the Java Runtime Environment (JRE) if the Java 1.4 Plug-in is not already installed.

☐ Disable local KVM switching
☐ Disable local media tray switching

Save Start Remote Control

The following illustration shows the Remote Control pane for the advanced management module.

Remote Control Status

Firmware status: Active

KVM owner:	Blade4 - HS20-Mongoose since 11/13/2006 20:04:53
Media tray owner:	Blade4 - HS20-Mongoose since 11/13/2006 20:04:52
Console redirect:	No session in progress.

Refresh

Start Remote Control

Click "Start Remote Control" to control a blade server remotely. A new window will appear that provides access to the Remote Console and Remote Disk functionality. On this window, you will have full keyboard and mouse control of the blade server which currently owns the KVM. You will also be able to change KVM and media tray ownership.

Note: An Internet connection is required to download the Java Runtime Environment (JRE) if the Java 1.4.2 Plug-in is not already installed. For best results, use Sun JRE 1.4.2_08 or higher.

Start Remote Control

Remote Control Settings


☒ Enable local KVM switching
☒ Enable local media tray switching

Save


Select the **Remote Control** choice to perform the following tasks:

- For the advanced management module, the **Firmware status** is one of the following:
 - **Active** - indicates that the management module remote control application is communicating.
 - **Unable to access remote control firmware** - indicates that the management module cannot use remote control.
- View and change the current owners of the keyboard, monitor, and mouse (KVM), and of the removable-media drives and USB ports (media tray). See the *Installation and User's Guide* for your blade server type for more information about KVM and media tray switching.
- View the details of any currently active remote control session (user ID, client IP address, start time).
- Enable or disable local switching of the KVM and of the media tray for all blade servers until they are explicitly enabled again. This prevents a local user from switching the console display to a different blade server while you are performing remote control tasks. The media tray will be used by one blade server at a time..
- Redirect a blade server console to the remote console.

The following illustration shows a remote control session for management modules other than the advanced management module.



The following illustration shows a remote control session for the advanced management module.



Note: To properly run the Java Remote Control applet, go to the Microsoft Windows **Start** menu and select **Java Control Panel**. Select the **Cache** tab and make sure that **Enable Caching** is not selected. Use a version of the Sun JRE that is between version 1.4.2_08 and version 1.5.x.

On the remote console, you can perform the following tasks:

- Change the owner of the KVM and of the media tray to the blade server that you need to view. See the *Installation and User's Guide* for your blade server type for more information about KVM and media tray switching.
- Select and access the disk drives in the media tray.
- Mount a disk drive or disk image, from the computer that is acting as the remote console, onto a blade server. The mounted disk drive or disk image will appear as a USB device that is attached to the blade server. See “Using the remote disk feature” on page 52 for information and instructions.
- Access files at any available network location.
- View the current blade server display.
- Control the blade server as if you were at the local console, including restarting the blade server and viewing the POST process, with full keyboard and mouse control.

Remote console keyboard support includes all keys. Icons are provided for keys that might have a special meaning to the blade server. For example, to transmit Ctrl+Alt+Del to the blade server, you must click the **Ctrl** icon and then press the Alt and Del keys on the keyboard.

For the advanced management module, remote console video controls include:

- The **Refresh** icon updates the remote console display.
- The **Paint** icon updates the remote console display to show exactly what is displayed by the blade server, cleaning up display artifacts.
- The **Calibrate** icon runs a video calibration sequence that optimizes remote video session performance. A session should be calibrated when the colors displayed are significantly different than expected.
- **Preferences** allow you to set remote control session preferences and create custom key buttons that represent common key combinations.

Instead of clicking **Preferences**, you can press ALT+1 on the remote console to set the session preferences or press ALT+2 on the remote console to set common key combinations.

Up to four remote-control sessions are allowed at a time. If four remote-control sessions are already active, you must end one of the current sessions to start a new one.


The timeout value for a remote-control session is the same as the timeout value that you set for the management-module Web interface session when you logged in.

When you redirect a blade server Linux X Window System session console to the remote console, the ability of the remote console applet to accurately track the location of the mouse cursor depends on the configuration of the X Window System. To configure the X Window System for accurate mouse tracking, complete the following procedure. Type the commands through the remote console or at the keyboard attached to the BladeCenter unit. Note that these changes require root privileges.

1. Enter the following commands:
 - `init 3` (switch to text mode if necessary)
 - `rmmmod mousedev` (unload the mouse device driver)

2. Add the following statement to `.xinitrc` in the user's home directory:
`xset m 1 1` (turn off mouse acceleration)
3. Add the following statement to `/etc/modules.conf`:
`options mousedev xres=x yres=y` (notify the mouse device driver of the video resolution) where `x` and `y` specify the video resolution
4. Enter the following commands:
`insmod mousedev` (reload the mouse device driver)
`init 5` (return to GUI mode if necessary)

Firmware Update



The screenshot shows a web interface titled "Update Blade Firmware" with a help icon. Below the title is a instruction: "To update a firmware component, select a target blade and a firmware file, and click 'Update'". There are two input fields: "Target" with a dropdown menu showing "Blade1 - SN#229X7P J1NN" and "Firmware file" with a text box and a "Browse..." button. An "Update" button is located at the bottom right of the form.

Select **Firmware Update** to update the service processor firmware on a blade server. Select the target blade server and the firmware file to use for the update; then, click **Update**. You can obtain the firmware files from <http://www.ibm.com/bladecenter/>.

Configuration

The following illustration shows blade server configuration settings for management modules other than the advanced management module.

Blade Server Configuration

Use the following links to jump down to different sections on this page.

[Blade Information](#)

[Blade Policy Settings](#)

[Boot Sequence](#)

Blade Information

Bay	Name
1	SN#K10V73621EB
2	
3	Blade 04
4	
5	SN#K10V7363140
6	SN#K10UJ353166
7	<i>No blade present</i>
8	SN#K10V7364105

The following illustration shows blade server configuration settings for the advanced management module.

Blade Server Configuration ²

Use the following links to jump down to different sections on this page:

[Blade Information](#)
[Blade Policy Settings](#)
[Power Management Policy Settings](#)
[Management Network Configuration](#)
[Boot Sequence](#)

Blade Information ²

Bay	Name
1	SN#ZK11VM5CB13W
2	JS21-Maui(SIT)
3	No blade present
4	No blade present
5	
6	SN#YK3DA0642036
7	
8	No blade present
9	No blade present
10	No blade present
11	No blade present
12	No blade present
13	No blade present
14	No blade present

Save

Blade Policy Settings ²

These settings apply to all blade bays (including the empty bays).

Local power control ☐ Enabled

Select the **Configuration** choice to perform the following tasks:

- Define a name for a blade server.
- Enable or disable the following items on all blade servers in the BladeCenter unit:
 - Local power, KVM, and media tray control
 - Power management settings
 - The VLAN ID and BSMP IP address range used by SOL (advanced management module only)
 - The Wake on LAN feature
- Configure how each BladeCenter power domain responds if power demand in the domain is greater than the redundant power-module capacity. If this condition occurs, a single power module in the domain will not be able to meet the power needs of the domain should its companion power module fail. You select a domain power-management policy that is enforced if demand exceeds capacity when initial power is applied to the BladeCenter unit or when a blade server is installed in the BladeCenter unit. The power requirements for each component are analyzed when they initially request power. The following power-management policy options are supported:
 - **Redundant with potential performance impact**
For this policy, blade servers are turned on only if the power limit calculated for the power domain, based on the selected power management policy, is not exceeded. If power module redundancy is lost, the blade servers in the power domain with microprocessors that are capable of throttling will throttle down until the power in use is less than or equal to the power available from the remaining power module. Blade servers will power up in a throttled state in some configurations. After power redundancy is restored, the blade server microprocessors will return to their un-throttled performance levels. This option only affects the BladeCenter components that support power throttling.

- **Redundant without performance impact**

For this policy, new components installed in the power domain are turned on only if they can operate at their maximum power level if power redundancy in the domain is lost.

- **Non-redundant** (default setting)

For this policy, blade servers are turned on, only if the power limit calculated for the power domain, based on the selected power management policy, is not exceeded. If power module redundancy is lost, then the blade servers in the power domain with microprocessors that are capable of throttling will attempt to throttle down until the power in use is less than or equal to the power available from the remaining power module. After power redundancy is restored, the blade server microprocessors will return to their un-throttled performance levels. If blade servers are not able to reduce their power needs, power in the domain might be lost.

- Determine how the management module responds if it detects a over-temperature condition (thermal event) on a blade server. The following acoustic mode (quiet mode) options are supported in response to thermal events:
 - Disabled (default) - increases the blower speeds to provide additional cooling.
 - Enabled - reduce blade server power consumption (throttle blade servers) to stay within acoustic noise limits (quiet mode). This option only affects the BladeCenter components that support power throttling.
- View or define the startup (boot) sequence for one or more blade servers. The startup sequence prioritizes the following boot-record sources for a blade server. Boot sequence choices for your BladeCenter unit type might include:
 - Hard disk drives (0 through 3). The selection of hard disk drives depends on the hard disk drives that are installed in your blade server.
 - CD-ROM (optical drive).
 - Diskette drive (some BladeCenter unit types)
 - Network - PXE. Selecting Network - PXE attempts a PXE/DHCP network startup the next time the blade server is turned on or restarted.

Note: To use the optical drive or diskette drive (some BladeCenter unit types) as a boot-record source for a blade server, the blade server must have been designated as the owner of the optical drive, diskette drive (if supported for your BladeCenter unit type), and USB port. You set ownership either by pressing the CD/diskette/USB select button on the blade server or through the **Remote Control** choice described in “Remote Control” on page 78.

Serial Over LAN

Serial Over LAN (SOL)

Use the following links to jump down to different sections on this page.

- [Serial Over LAN Status](#)
- [Serial Over LAN Configuration](#)

Serial Over LAN Status

Click the checkboxes in the first column to select one or more blade servers; then, click one of the links below the table to enable or disable SOL on the selected blades.

Note: You have to enable the global "Serial over LAN" flag below in the Configuration section before enabling SOL on individual blade servers.

<input type="checkbox"/>	Bay	Name	SOL	SOL Session	BSMP IP Address
<input type="checkbox"/>	1	Blade does not support SOL	n/a	n/a	n/a
<input type="checkbox"/>	2	SN#ZJ1WS447L14E	Enabled	Not ready	10.10.10.81
<input type="checkbox"/>	3	SN#WS1ZJ147L47S	Enabled	Not ready	10.10.10.82
<input type="checkbox"/>	4	SN#ZJ1WS477L74V	Enabled	Not ready	10.10.10.83
	5	No blade present			
	6	Blade does not support SOL	n/a	n/a	n/a
	7	No blade present			
	8	No blade present			
	9	No blade present			
	10	No blade present			
	11	No blade present			

Select **Serial Over LAN** to monitor the SOL status for each blade server and to enable or disable SOL for each blade server, and globally for the BladeCenter unit. Enabling or disabling SOL globally does not affect the SOL session status for each blade server; SOL must be enabled both globally for the BladeCenter unit and individually for each blade server where you plan to start an SOL session. SOL is enabled globally and on the blade servers by default.

Note: For some BladeCenter unit types, the Serial Over LAN Status table also displays information about on-demand blade servers, if any are installed in the BladeCenter unit.

Serial Over LAN Configuration

Serial over LAN

SOL VLAN ID

BSMP IP address range

Transport Parameters

Accumulate timeout msec

Send threshold bytes

Retry count

Retry interval msec

User Defined Keystroke Sequences

'Enter CLI' key sequence

'Reset blade' key sequence

Save

Select this choice also to view and change the global Serial over LAN (SOL) settings that are used by all blade servers in the BladeCenter unit and to enable or disable SOL globally for the BladeCenter unit.

Note: For the advanced management module, the **SOL VLAN ID** and the **BSMP IP address range** are set in the **Blade Tasks → Configuration** page (see “Configuration” on page 88 for information).

Start and run SOL sessions using the management-module command-line interface. See the *BladeCenter Management Module Command-Line Interface Reference Guide* for information and instructions.

I/O Module Tasks

Select the choices in the **I/O Module Tasks** section to view and change the settings or configuration on network-interface I/O modules in the BladeCenter unit.

Note: Some choices do not apply to, and are not available for, some types of I/O modules such as pass-thru modules.

Admin/Power/Restart

The following illustration shows I/O module power and restart settings for management modules other than the advanced management module.

I/O Module Power/Restart

Select one or more module(s) using the checkboxes in the first column and then click on one of the links below the table to perform the desired action.

<input type="checkbox"/>	Bay	Type	MAC Address	IP Address	Pwr	POST Status
<input type="checkbox"/>	1	Ethernet SM	00:05:5D:89:A3:A0	10.90.90.94	On	POST results not complete: A0
	2		No module			
	3		No module			
	4		No module			

[Power On Module\(s\)](#)
[Power Off Module\(s\)](#)
[Restart Module\(s\) and Run Standard Diagnostics](#)
[Restart Module\(s\) and Run Extended Diagnostics](#)
[Restart Module\(s\) and Run Full Diagnostics](#)

The following illustration shows I/O module power and restart settings for the advanced management module.

I/O Module Power/Restart

Select one or more module(s) using the checkboxes in the first column and then click on one of the links below the table to perform the desired action.

<input type="checkbox"/>	Bay	Type	MAC Address	IP Address	Pwr	POST Status	WWN/GUID Type	WWN/GUID
<input type="checkbox"/>	1	Ethernet SM	00:05:5D:71:85:D8	192.168.70.127	On	POST results available: FF: Module completed POST successfully	n/a	n/a
	2		No module					
	3		No module					
	4		No module					
	5		No module					
	6		No module					
	7		No module					
	8		No module					
	9		No module					
	10		No module					

[Power On Module\(s\)](#)
[Power Off Module\(s\)](#)
[Restart Module\(s\) and Run Standard Diagnostics](#)
[Restart Module\(s\) and Run Extended Diagnostics](#)
[Restart Module\(s\) and Run Full Diagnostics](#)

Select **Admin/Power/Restart** to display the power status of the I/O modules and to perform the following actions:

- Turn on or turn off an I/O module
- Reset an I/O module

I/O Module Advanced Setup

Select a module

Fast POST

External ports

For each I/O module, enable or disable the following features:

- Fast POST
- External ports

Configuration

Note: The content of I/O-module configuration panes varies by I/O-module type. Each pane displays only those settings that apply to the I/O module that is installed.

I/O Module Configuration

Use the following links to jump down to different sections on this page.

[Bay 1](#)
[Bay 2](#)
[Bay 3](#)
[Bay 4](#)
[Bay 5](#)
[Bay 6](#)
[Bay 7](#)
[Bay 8](#)
[Bay 9](#)
[Bay 10](#)

Select **Configuration** to view or change the IP configuration of the I/O modules. Links that lead to the configuration section for each I/O module are at the top of the pane.

Bay 1 (Ethernet SM)* ?

Current IP Configuration

Configuration method: Static
IP address: 192.168.70.127
Subnet mask: 255.255.255.0
Gateway address: 0.0.0.0

New Static IP Configuration

Status: Enabled

To change the IP configuration for this I/O module, fill in the following fields and click "Save". This will save and enable the new IP configuration.

IP address
Subnet mask
Gateway address

[Advanced Configuration](#)

Save

Bay 2 (Server Conn M)* ?

Current IP Configuration

Configuration method: Port forwarding
IP address: 9.42.204.68: [:port>](#)
Subnet mask: 255.255.255.192
Gateway address: 9.42.204.65

[Advanced Configuration](#)

[Network Protocol Configuration](#)

When you use the management-module Web interface to update an I/O-module configuration, the management-module firmware writes its settings for the I/O module only to the management-module NVRAM; it does not write its settings for the I/O module to the I/O-module NVRAM.

If the I/O module restarts when the management module is not able to apply the IP address that it has in NVRAM for the I/O module, the I/O module uses whatever IP address that it has in its own NVRAM. If the two IP addresses are not the same, you might not be able to manage the I/O module anymore. The management module cannot apply the I/O module IP address from its NVRAM under any of the following conditions:

- The management module is restarting.
- The management module has failed.
- The management module has been removed from the BladeCenter unit.

You must use the Telnet interface to log in to the I/O module, change the IP address to match the one that you assigned through the management module, and then save the I/O module settings in the Telnet session (**Basic Setup → Save Changes**).

For I/O-module communication with a remote management station, through the management-module external Ethernet port, the I/O module internal network interface and the management-module internal and external interfaces must be on the same subnet.

Select **Advanced Configuration** to enable external management, ping an I/O module, configure other advanced I/O module settings, return an I/O module to the default configuration, and start the configuration and management firmware that might be in an I/O module.

Note: The initial factory-defined user ID and password for the I/O module firmware are as follows:

- User ID: USERID (all capital letters)
- Password: PASSW0RD (note the zero, not O, in PASSW0RD)

Network Protocol Settings

To configure a protocol, click a link in the "Protocol Name" column.

	Protocol Name	Protocol ID	External Port	Internal Port	Enabled
1.	HTTP	TCP	2080	80	Yes
2.	TELNET	TCP	2023	23	Yes
3.	HTTPS	TCP	2443	443	Yes
4.	SSH	TCP	2022	22	Yes
5.	SNMP	UDP	2161	161	Yes
6.	~not used~				
7.	~not used~				
8.	~not used~				
9.	~not used~				
10.	~not used~				

Activate

Reset to Defaults

Select **Network Protocol Configuration** to set the network protocol configuration for an I/O module that supports a Network Address Translation (NAT) table. You must click **Activate** for changes to take effect.

See the *Installation and User's Guide* for your BladeCenter unit type and "Configuring an I/O module" on page 54 for more information about basic I/O-module configuration. See the documentation that comes with the I/O module for details about the configuration and management firmware for the I/O module. Documentation for some I/O modules is on the IBM *Documentation* CD for your BladeCenter unit type.

Firmware Update

Update I/O Module Firmware

To update a firmware component, select a target module and a firmware file, and click "Update".

Target

None of the I/O modules support flashing over this interface

Firmware file

Browse...

Update

Note: Firmware update is only available for some I/O-module types.

Select **Firmware Update** to update the firmware in a I/O module. Select the target I/O module and the firmware file to use for the update; then, click **Update**. You can obtain the firmware files from <http://www.ibm.com/bladecenter/>.

MM Control

Select the choices in the **MM Control** section to view and change the settings or configuration on the management module that you are logged in to (the primary management module) through the management-module Web interface session. If your BladeCenter unit has redundant management modules, the configuration settings of the primary management module are automatically transferred to the second management module. This transfer can take up to 45 minutes.

Management-module configuration includes the following items:

- The name of the management module
- Up to 12 login profiles for logging in to the management module
- Ports used by the management module
- How alerts are handled
- Communication settings for the advanced management-module serial port
- The management-module Ethernet connections for remote console and for communicating with the I/O modules
- Settings for the SNMP, DNS, SMTP, and LDAP protocols
- Settings for secure socket layer (SSL) and Secure Shell (SSH) security

This also includes performing the following tasks:

- Backing up and restoring the management-module configuration
- Updating the management-module firmware
- Restoring the default configuration
- Restarting the management module
- Switching from the primary management module that is currently active to the standby management module (for BladeCenter units that support redundant management modules)

Note: For BladeCenter units with a standby management module installed, control automatically switches to the standby management module when the primary management module fails.

General Settings

The screenshot displays the 'MM Control' web interface. At the top right, there is a link 'View Configuration Summary'. Below this, the 'MM Information' section is visible, featuring a question mark icon. It contains three input fields: 'Name' with the value 'SN#01', 'Contact' with the value 'No Contact Configured', and 'Location' with the value 'No Location Configured'. Below this is the 'MM Date and Time' section, also with a question mark icon. It shows 'Date (mm/dd/yyyy): 02/26/2004' and 'Time (hh:mm:ss): 11:32:33'. A link 'Set MM Date and Time' is present below these fields. At the bottom right of the form, there is a 'Save' button.

Select **General Settings** to view or change the following settings:

- The name of the management module
- The name of the contact person who is responsible for the management module

- The physical location of the management module
- The real-time clock settings in the management module, including network time protocol (NTP) settings for the advanced management module

Some of the General Settings are used during SNMP and SMTP configuration. See “Configuring SNMP” on page 14 and “Configuring SMTP” on page 17 for additional information.

Login Profiles

[View Configuration Summary](#)

Management Module Login Configuration [?]

Use the following links to jump down to different sections on this page.

[Login Profiles](#)
[Global Login Settings](#)

Login Profiles [?]

To configure a login profile, click a link in the "Login ID" column.

Login ID	Access
1. USERID	Supervisor
2. ned	Operator
3. dan	Custom
4. ~ not used ~	
5. ~ not used ~	
6. ~ not used ~	
7. ~ not used ~	
8. ~ not used ~	
9. ~ not used ~	
10. ~ not used ~	
11. ~ not used ~	
12. ~ not used ~	

Select **Login Profiles** to configure up to 12 login profiles for logging in to the management module; and to specify the following global login settings:

- User authentication method (local, LDAP, or both)
- Lockout period after five unsuccessful login attempts
- For the advanced management module, you can also set the default session timeout interval for the Web interface and the session timeout interval for the command-line interface

The following illustration shows the global login settings for management modules other than the advanced management module.

Global Login Settings [?]

These settings apply to all login profiles.

User authentication method

Lockout period after 5 login failures minutes

The following illustration shows the global login settings for the advanced management module.

Global Login Settings ⓘ

These settings apply to all login profiles.

User authentication method	Local only
Lockout period after 5 login failures	2 minutes
Web inactivity session timeout	User picks timeout
CLI inactivity session timeout	10000 seconds

Save

For each user profile, specify the following values:

- Login ID
- Password (requires confirmation)
- Role or Authority Level (default is Operator or Read-Only)
Defines the command areas that a user can access, based on their Access Scope. Roles or authority levels might vary based on the type of BladeCenter unit that you are using and the management-module firmware version that is installed.
- Access Scope
Defines where the role or user authority defined for a user is valid.

Important: Roles or command authority definitions might change between firmware versions. Make sure that the role or command authority level set for each user is correct after updating management-module firmware.

[View Configuration Summary](#)

Login Profile 12

Login ID	user3
Password	
Confirm password	

Role

- ☐ Supervisor (requires Scope selection)
- ☐ Operator (readonly, all scopes)
- ☒ Custom (requires Roles and Scopes)

Unassigned roles

Chassis operator
Chassis user account management
Chassis log administration
Chassis configuration
Chassis administration
Blade operator
Blade configuration
Blade administration
Switch operator
Switch configuration
Switch administration

Assigned roles

Blade remote presence

Access Scope

Unassigned

Component	Status
Chassis	Good
Blade 1	Good
Blade 2	Good
Blade 3	Good
Blade 5	Good
Blade 9	Good
Blade 10	Good
Blade 11	Good
Blade 12	Good
Blade 14	Good
Switch 1	Warning
Switch 2	Warning
Switch 3	Warning
Switch 4	Warning

Assigned

Blade 4
Blade 6
Blade 7
Blade 8

Blade 13

Configure SNMPv3 User

Reset to Defaults

Cancel

Save

The following illustration shows user profile settings for older versions of management-module firmware.

The screenshot displays a web interface for configuring a user profile. At the top right, there is a link labeled "View Configuration Summary". Below this, the section "Login Profile 1" is shown with a help icon. It contains three input fields: "Login ID" with the text "USERID", "Password", and "Confirm password". Underneath, the "Authority Level" section has three radio button options: "Supervisor" (which is selected), "Read-Only", and "Custom". The "Custom" option is expanded, showing a list of checkboxes for various permissions: "User Account Management", "Blade Server Remote Console Access", "Blade Server Remote Console and Virtual Media Access", "Blade and I/O Module Power/Restart Access", "Ability to Clear Event Logs", "Basic Configuration (MM, I/O Modules, Blades)", "Networking & Security Configuration", and "Advanced Configuration (MM, I/O Modules, Blades)". At the bottom left, there is a link labeled "Configure SNMPv3 User".

Several user roles (authority levels) are available, each giving a user write and execute access to different areas of management-module and BladeCenter component function. Users with operator authority are read-only and can access management-module functions for viewing only. Multiple roles can be assigned to each user using the Custom role and users with the Supervisor role have write and execute access to all functions within their assigned Access Scope.

Attention: If you change the default login profile on the management module, be sure to keep a record of your login ID and password in a safe place. If you forget the management-module login ID and password, you will need to call for service.

Click **Configure SNMPv3 User** to perform additional user configuration required for SNMPv3 (see "Configuring SNMP" on page 14 for instructions). Click **View Configuration Summary** to display the configuration settings for all BladeCenter users and components.

Alerts

Management Module Alerts Configuration ?

Use the following links to jump down to different sections on this page.

[Remote Alert Recipients](#)
[Global Remote Alert Settings](#)
[Monitored Alerts](#)

Remote Alert Recipients ?

To configure a remote alert recipient, click a link in the "Name" column.

Name	Notification Method	Status
1. Administrator	SNMP over LAN	Receives all alerts
2. Mail Admin	E-mail over LAN	Disabled
3. ~ not used ~		
4. ~ not used ~		
5. ~ not used ~		
6. ~ not used ~		
7. ~ not used ~		
8. ~ not used ~		
9. ~ not used ~		
10. ~ not used ~		
11. ~ not used ~		
12. ~ not used ~		

Generate Test Alert

Select **Alerts** to specify which events (from lists of critical, warning, and system alerts) are monitored, which event notifications are sent to whom, how event notifications are sent (SNMP, e-mail, or IBM Director), whether to include the event log with the notification, and other alert parameters.

Note: The IBM Director program is a system-management product that comes with the BladeCenter unit. To configure the remote alert recipients for IBM Director over LAN, the remote alert recipient must be an IBM Director-enabled server.

Serial Port (advanced management module only)

[View Configuration Summary](#)

Serial Port ?

Baud rate

57600

Parity

NONE

Stop bits

1

Save

Select **Serial Port** to configure communications settings for the advanced management-module serial port. You can configure the serial port settings for baud rate, error checking parity, and the number of stop bits. Connections made using the advanced management-module serial port can only access the management-module command-line interface (CLI) and the Serial over LAN (SOL) feature. See the *BladeCenter Management Module Command-Line Interface Reference Guide* for information about using the serial port.

Click **View Configuration Summary** to display the configuration settings for all BladeCenter users and components.

Port Assignments

The following illustration shows port assignment settings for management modules other than the advanced management module.

[View Configuration Summary](#)

Port Assignments [?]

Currently, the following ports are open on this MM:

23, 6090, 5900, 1044, 1045, 80, 427, 161

You can change the port number for the following services/protocols. You have to restart the MM for the new settings to take effect. Note that you cannot configure a port to a number that is already in use.

HTTP	<input type="text" value="80"/>
HTTPS	<input type="text" value="443"/>
Telnet	<input type="text" value="23"/>
SSH	<input type="text" value="22"/>
SNMP Agent	<input type="text" value="161"/>
SNMP Traps	<input type="text" value="162"/>

The following illustration shows port assignment settings for the advanced management module.

[View Configuration Summary](#)

Port Assignments [?]

Currently, the following ports are open on this MM:

TCP: 6090, 80, 1044, 1045, 23, 443, 3900

UDP: 32768, 32769, 32770, 161, 427

You can change the port number for the following services/protocols. You have to restart the MM for the new settings to take effect. Note that you cannot configure a port to a number that is already in use.

HTTP	<input type="text" value="80"/>
HTTPS	<input type="text" value="443"/>
Telnet	<input type="text" value="23"/>
SSH	<input type="text" value="22"/>
SNMP Agent	<input type="text" value="161"/>
SNMP Traps	<input type="text" value="162"/>
FTP	<input type="text" value="21"/>
FTP Data	<input type="text" value="20"/>
TFTP	<input type="text" value="69"/>
Remote Disk	<input type="text" value="1044"/>
Remote Disk-On-Card	<input type="text" value="1045"/>
Remote KVM	<input type="text" value="3900"/>
SMASH CLP	<input type="text" value="50023"/>
Secure SMASH CLP	<input type="text" value="50022"/>

Select **Port Assignments** to configure some of the ports that are used by the management module. Management-module ports that can be configured on the Port Assignments page are listed in Table 3 on page 98.

Table 3. User-configurable management-module ports

Port name	Default port number	Description
HTTP	80	Port used for Web server HTTP connection using UDP
HTTPS	443	Port used for SSL connection using TCP
Telnet	23	Port used for the Telnet command-line interface connection
SSH	22	Port used for the Secure Shell (SSH) command-line interface connection
SNMP Agent	161	Port used for SNMP get/set commands using UDP
SNMP Traps	162	Port used for SNMP traps using UDP
FTP (advanced management module only)	21	Port used for the listen port of the management-module FTP server.
FTP Data (advanced management module only)	20	Port used for the data port of the management-module FTP server.
TFTP (advanced management module only)	69	Port used for the management-module TFTP server.
Remote Disk (advanced management module only)	1044	Port used for the management-module remote disk server.
Remote Disk-On-Card (advanced management module only)	1045	Port used for the management-module remote disk-on-card server.
Remote KVM (advanced management module only)	3900	Port used for the management-module remote KVM server.
SMASH command-line processor (advanced management module only)	50023	Port used for the management-module SMASH command-line protocol over Telnet.
Secure SMASH command-line processor (advanced management module only)	50022	Port used for the management-module secure SMASH command-line protocol over SSH.

Other ports that are used by the management module are listed in Table 4. These ports are fixed and cannot be modified.

Table 4. Fixed management-module ports

Port number (fixed)	Description
25	Port used for TCP e-mail alerts
53	Port used for the UDP Domain Name Server (DNS) resolver
68	Port used for DHCP client connection using UDP
427	Port used for the UDP Service Location Protocol (SLP) connection
1044	Port used for remote disk function (management modules other than the advanced management module)
1045	Port used for persistent remote disk-on-card (management modules other than the advanced management module)
5900	Port used for remote control (management modules other than the advanced management module)
6090	Port used for IBM Director commands using TCP/IP
13991	Port used for IBM Director alerts using UDP

Click **View Configuration Summary** to display the configuration settings for all BladeCenter users and components.

Network Interfaces

[View Configuration Summary](#)

Management Module Network Interfaces ?

Use the following links to jump down to different sections on this page.

[External Network Interface \(eth0\)](#)
[Internal Network Interface \(eth1\)](#)
[TCP Log](#)

External Network Interface (eth0) ?

Interface: Enabled
 DHCP Disabled - Use static IP configuration

*** Currently the static IP configuration is active for this interface.
 *** This static configuration is shown below.

Hostname

Static IP Configuration

IP address
 Subnet mask
 Gateway address

[Advanced Ethernet Setup](#) [IP Configuration Assigned by DHCP Server](#)

Select **Network Interfaces** to configure the management-module Ethernet interfaces and view the TCP log (the TCP log is not available for the advanced management module). For the advanced management module, you can configure only the external Ethernet interface used to communicate with the remote management and console. For all other management-module types, you can configure both the external Ethernet interface and the internal Ethernet interface used for communication with the I/O modules. The internal Ethernet interface for the advanced management module has no user-configurable settings.

For I/O-module communication with a remote management station, through the management-module external Ethernet port, the I/O module internal network interface and the management-module internal and external interfaces must be on the same subnet.

- When you click **External Network Interface (eth0)**, information about the interface for the remote management and console port is displayed:

Note: If your BladeCenter unit supports redundant management modules and you plan to use this feature with both management modules set to use the same external IP address, disable DHCP and configure and use a static IP address. (The IP configuration information will be transferred to the standby management module automatically when needed.)

- **Interface** - The status (Enabled or Disabled) of the Ethernet connection. The default is Enabled. (For the advanced management module, this field is for information only and cannot be changed.)
- **DHCP** - Select one of the following choices:
 - **Enabled - Obtain IP config. from DHCP server**
 - **Disabled - Use static IP configuration**
 - **Try DHCP server. If it fails, use static IP config.** (the default).
- **Hostname** - (Optional) This is the IP host name that you want to use for the management module (maximum of 63 characters and following host-naming standards).
- **Static IP configuration** - You must configure this information only if DHCP is disabled.
 - **IP address** - The IP address for the management module must contain four integers from 0 through 255, separated by periods, with no spaces or consecutive periods. The default setting is 192.168.70.125.
 - **Subnet mask** - The subnet mask must contain four integers from 0 to 255, separated by periods, with no spaces. The default setting is 255.255.255.0
 - **Gateway address** - The IP address for your network gateway router must contain four integers from 0 through 255, separated by periods, with no spaces. This address must be accessible from the IP address and subnet mask that were specified above.
- Click the **Advanced Ethernet Setup** link to view and configure the data rate, duplex mode, maximum transmission unit (MTU), and locally-administered MAC address for this interface. The burned-in MAC address field for the external interface is read-only.

For management modules other than the advanced management module, you can enable or disable the management-module physical uplink failover feature using the **Failover network uplink loss** field. For the advanced management module, you can enable or disable the management-module physical or logical uplink failover features using the **Failover on loss of physical network link** and **Failover on loss of logical network link** fields. If the external network interface of the primary management module fails, the uplink failover features force a failover to the standby management module, if one is installed, after the specified network failover delay. For the advanced management module, you can also specify the IP address that the management module uses to check the status of its logical network link.

- When you click **Internal Network Interface (eth1)** (this selection is not available for the advanced management module), information about the interface that communicates with the I/O modules, such as an Ethernet I/O module or the Fibre Channel I/O module, is displayed. Use it to perform the following tasks:
 - Specify the IP address to use for this interface. The internal network interface (eth1) and the external network interface (eth0) must be on the same subnet.
 - Click the **Advanced Ethernet Setup** link to view the data rate, duplex mode, maximum transmission unit (MTU), locally-administered MAC address, and burned-in MAC address for this interface. You can configure the locally-administered MAC address; the other fields are read-only.
- Click **TCP log** (the TCP log is not available for the advanced management module) to view entries that are currently stored in the management-module TCP log. This log contains error and warning messages that are generated by the TCP/IP code that is running on the management module; it might be used by a service representative for advanced troubleshooting. The log displays the most recent entries first.

You can sort and filter entries in the event log.

Click **View Configuration Summary** to display the configuration settings for all BladeCenter users and components.

Network Protocols

[View Configuration Summary](#)

Management Module Network Protocols

Use the following links to jump down to different sections on this page.

[Simple Network Management Protocol \(SNMP\)](#)
[Domain Name System \(DNS\)](#)
[Simple Mail Transfer Protocol \(SMTP\)](#)
[Lightweight Directory Access Protocol \(LDAP\)](#)
[Telnet Protocol](#)
[TCP Command Mode Protocol](#)
[Service Location Protocol \(SLP\)](#)
[File Transfer Protocol \(FTP\)](#)
[Trivial File Transfer Protocol \(TFTP\)](#)
[SMASH Command Line Protocol \(CLP\)](#)

Simple Network Management Protocol (SNMP)

SNMPv1 agent	<input type="button" value="Enabled"/>
SNMPv3 agent	<input type="button" value="Enabled"/>
SNMP traps	<input type="button" value="Enabled"/>

SNMPv1 Communities		
Community Name	Access Type	Host Name or IP Address
public	<input type="button" value="Get"/>	1. 0.0.0.0
		2.
		3.
private	<input type="button" value="Get"/>	1. 0.0.0.0

Select **Network Protocols** to view or change the settings for the SNMP, DNS, SMTP, LDAP, and SLP protocols. You can also enable or disable and set the timeout intervals for the Telnet and TCP interfaces. For the advanced management module, you can also configure the FTP, TFTP, and SMASH protocol settings.

Note: For the advanced management module, the Telnet interface and SMASH command-line processor can also be enabled or disabled using SNMP and management-module command-line interface. See the *BladeCenter Management Module Command-Line Interface Reference Guide* or the *IBM SMASH Installation and User's Guide* for more information.

Click **View Configuration Summary** to display the configuration settings for all BladeCenter users and components.

Some of the network protocol settings are used during SNMP, SMTP, and LDAP configuration. See “Configuring SNMP” on page 14, “Configuring SMTP” on page 17, and “Configuring LDAP” on page 18 for additional information.

Security

SSL Server Configuration for Web Server ?

SSL Server

SSL Server Certificate Management ?

SSL server certificate status: No certificate or certificate signing request (CSR) has been generated.

[Generate a New Key and a Self-signed Certificate](#)

[Generate a New Key and a Certificate Signing Request \(CSR\)](#)

SSL Client Configuration for LDAP Client ?

SSL Client

SSL Client Certificate Management ?

SSL client certificate status: No certificate or certificate signing request (CSR) has been generated.

[Generate a New Key and a Self-signed Certificate](#)

[Generate a New Key and a Certificate Signing Request \(CSR\)](#)

Select **Security** to view or change the secure socket layer (SSL) settings for the Web server and LDAP client, and view or change the Secure Shell (SSH) server settings. You can enable or disable (the default) SSL, and choose between self-signed certificates and certificates that are provided by a certificate authority (CA). You can also enable or disable (the default) SSH, select the SSH version to use (advanced management module only), and generate and manage the SSH server key.

Note: For the advanced management module, SSH can also be enabled or disabled using SNMP and management-module command-line interface. See the *BladeCenter Management Module Command-Line Interface Reference Guide* for more information.

The following illustration shows the secure shell configuration pane for management modules other than the advanced management module.

Secure Shell (SSH) Server ?

SSH Server

SSH Server Key Management ?

SSH server key status: SSH Server key is not installed.

The following illustration shows the secure shell configuration pane for the advanced management module.

Secure Shell (SSH) Server ?

SSH Server
SSH version

SSH Server Key Management ?

SSH server key status: SSH Server key is not installed.

Some of the security settings are used during SSL, LDAP, and SSH configuration. See “Secure Web server and secure LDAP” on page 34 and “Configuring the secure shell server” on page 45 for additional information.

Configuration File (all management modules except advanced management module)

Backup MM Configuration ?

To backup the configuration, click "Backup." You can [view the current configuration summary](#) before backing it up.

Restore MM Configuration ?

To restore the MM configuration, select a file and click "Restore." To modify the configuration and then restore it, select a file and click "Modify & Restore."

Select configuration file to restore

Select **Configuration File** to back up or restore the management-module configuration file. See “Using the configuration file” on page 48 for instructions.

Configuration Mgmt (advanced management module only)

Configuration Management ?

Use the following links to jump down to different sections on this page.

[Restore Defaults](#)
[Backup Configuration to File](#)
[Restore Configuration from File](#)
[Save Configuration to Chassis](#)
[Restore Configuration from Chassis](#)

Restore Defaults ?

This action will cause all configuration settings to be set to factory defaults. **You will lose the static IP configuration of the MM external network interface. You will need to reconfigure it to restore connectivity.** Clearing of the configuration will be followed by a restart of the MM. Press the "Restore Defaults" or the "Restore Defaults Preserve Logs" button if you want to proceed.

Restore Defaults

Restore Defaults Preserve Logs

Backup Configuration to File ?

To backup the configuration by saving it to a file, click "Backup." You can [view the current configuration summary](#) before backing it up.

Backup

Restore Configuration from File ?

To restore the configuration from a file, select a file and click "Restore." To modify the configuration and then restore it, select a file and click "Modify & Restore."

Select configuration file to restore

Browse...

Restore

Modify and Restore

Save Configuration to Chassis ?

This action will cause the configuration settings to be saved from AMM to the BladeCenter chassis. To save the configuration settings to the BladeCenter chassis with default format, click "Save".

Save

Select **Configuration Mgmt** to back up or restore the management-module configuration. The advanced management module provides several backup and restoration options. When restoring defaults, you can choose to save or discard the management module event log. See "Using the configuration file" on page 48 for instructions.

Firmware Update

Update MM Firmware ?

To update a firmware component on the MM, select a firmware file and click "Update". If there is a redundant MM installed, the firmware on the redundant MM will be automatically updated to the same level.

Browse...

Note: To ensure proper operation of the management module, make sure you update all MM firmware components to the same level.

Update

Select **Firmware Update** to update the management-module firmware; if a standby management module is installed, the firmware update will automatically be applied to both management modules. Click **Browse** to locate the firmware file that you want; then, click **Update**.

Management-module firmware is in several separate files that are installed independently; you must install all of the firmware update files. You can obtain the firmware files from <http://www.ibm.com/bladecenter/>.

Important: Make sure that the role or command authority level set for each user is correct after updating management-module firmware, as these definitions might change between firmware versions.

If a standby management module is installed in a BladeCenter unit that previously had only one management module installed, the firmware in the new management module is updated to the firmware version that is present in the primary (already installed) management module. This update takes place when the standby management module is installed. It does not matter if the new management module contains a later firmware version: the firmware version of the primary management module takes precedence. It can take up to 45 minutes to update the firmware in the standby management module and transfer the management-module configuration.

Restore Defaults (management modules other than the advanced management module)

Restore Defaults

This action will cause all MM settings to be set to factory defaults.

You will lose your TCP/IP connection as a result. You will need to reconfigure the external network interface to restore connectivity.

Clearing of the MM configuration will be followed by a restart of the MM. Press "Restore Defaults" button if you want to proceed.

Restore Defaults

Select **Restore Defaults** to restore the factory default configuration of the management module.

Configuration Wizard (advanced management module only)

Welcome to the Advanced Management Module Configuration Wizard

This wizard will step you through the task of configuring the Advanced Management Module (AMM) and I/O Modules for your BladeCenter.

If you do not wish to use this wizard, press "Exit" and you will return to the Advanced Management Module web user interface (UI).

Before you begin you will need to know:

- A pool of static IP addresses (up to 11) to assign to the Advanced Management Module and the I/O Modules
- Contact information for AMM administrator
- A new Login ID and Password for the default login profile
- Relevant IP addresses for DNS and SNMP agents and clients

Please insert all I/O Modules you would like to configure at this time.

You may print out a list of these prerequisites: [Print Prerequisites](#)

Note: Unless otherwise noted, configuration settings are applied immediately. It is recommended that you restart your AMM to ensure all settings are applied.

☐ Run this wizard on the next login.

< Back Next > Exit

Select **Configuration Wizard** to begin guided set up of an advanced management module. When the advanced management module configuration is in the default state (unconfigured) and a user connects to it using the management-module Web interface, the configuration wizard opens automatically. The user can choose to bypass the wizard and can return to it at any later time, even if the management module is configured, to make changes.

The configuration wizard repackages the information in the other advanced management module panes into a structured flow that facilitates the configuration process. See "Using the Configuration Wizard (advanced management module only)" on page 13 for information about using the configuration wizard.

Restart MM

Restart MM

This action will be followed by a restart of the MM. All existing network connections will be temporarily lost as a result. You will need to open a new browser and relogin to get back in to the user interface. Click "Restart" if you want to continue and restart the MM.

Restart

Switch Over to Redundant MM

This action will cause a restart of this MM, followed by a switch over to the redundant MM in bay 2. All existing network connections will be temporarily lost as a result. You will need to open a new browser and relogin to get back in to the user interface. You will also need to move the video, mouse, and keyboard cables to the redundant MM. Click "Switch Over" if you want to continue and switch over to the redundant MM.

Note: If you have DHCP enabled on the primary MM's external network interface, and the IP address is assigned by the DHCP server, after the switch over to the redundant MM, the DHCP server will assign a different IP address to the redundant MM. If you want to be able to access both MMs at the same static IP address, you need to disable DHCP. Static IP configuration is the recommended setting in this environment.

Switch Over

Select **Restart MM** to restart (reset) the management module. If a second management module is present, you can also select this choice to switch control to the standby management module.

Service Tools (advanced management module only)

For the advanced management module, select the choices in the **Service Tools** section to access information that might assist a technician servicing the BladeCenter unit.

Settings

Debug ?

☒ Enable debugging by service personnel

Save

In the **Debug** section, you can allow or restrict service access to the BladeCenter unit.

Service Data

Service Data

The support team will use the service data provided by this page.

Save Service Data

```
Service.txt
Time: 09/03/2005 19:47:22
UUID: Not Available
MAC Address 00:11:25:C3:05:E0

System Health: Critical
System Status Summary
One or more monitored parameters are abnormal.
Critical Events
    Multiple blower failures
    Blower 1 Fault
    Blower 2 Fault
Warnings and System Events
    Front panel temperature sensor is unavailable. Cooling capacity will be set to maximum.

BladeCenter Chassis (Midplane):
    Unable to read VPD
    LEDs:
        Error: off
        Information: off
        Temperature: off
        Location: off

There is no media tray installed.
```

In the **Service Data** section, you can view a summary of information that might be useful when servicing the BladeCenter unit. Click **Save Service Data** to save this information to a file on the client computer named `sdc.tgz`, for use by service personnel.

AMM Status

AMM Status

The following MMs are present in the chassis.

	MM Bay 1	MM Bay 2
Role	Not installed	Primary
Name		SN#BM
MAC Address		00:11:25:C3:08:6A
UUID		0000 0000 0000 0000 0000 0000 0000 0000

Use the following links to jump down to different sections on this page.

- [MM Connectivity Status](#)
- [MM Built-in Self Test \(BIST\) Results](#)

In the **AMM Status** section, you can view advanced management module information and the status of connections between the management modules and other BladeCenter components. Click **MM Connectivity Status** to view the status of management-module connections. Click **MM Built-in Self Test (BIST) Results** to view the results of management-module self tests.

MM Connectivity Status

Module	MM Bay 1 (Empty)	MM Bay 2 (Primary)
Last Update	n/a	07/13/2006 11:16
Blade 1		Communicating
Blade 2		Communicating
Blade 3		Not Installed
Blade 4		Not Installed
Blade 5 - 7		Communicating
Blade 8		Not Installed
Blade 9		Not Installed
Blade 10		Not Installed
Blade 11		Not Installed
Blade 12		Not Installed
Blade 13		Not Installed
Blade 14		Not Installed
I/O Module 1		Communicating
I/O Module 2		Not Installed
I/O Module 3		Not Installed
I/O Module 4		Not Installed

The **MM Connectivity Status** section displays the status of connections between the management modules and other BladeCenter components. The status of connections with the primary management module is periodically updated. If a standby management module is installed, its connection status shows the data that was collected the last time this management module was the primary management module; if the management module never acted as primary, no status data will be available for it. The **Last Update** field shows when the status information for each management module was collected.

MM BIST Results

Function	MM Bay 1 (Empty)	MM Bay 2 (Primary)
Last Update	n/a	07/13/2006 11:17
Blade Management Bus 1		Passed
Blade Management Bus 2		Passed
Real-time Clock		Passed
Local Management Bus		Passed
Primary File System		Passed
Backup File System		Passed
Boot Loader		Passed
Ethernet Port (eth0)		Passed
External Management Bus		Passed
Internal Ethernet Switch		Passed
Video Capture		Passed
USB Keyboard/Mouse Emulation		Passed
USB Mass Storage Emulation		Passed
USB Keyboard/Mouse Firmware		Passed
USB Mass Storage Firmware		Passed
Primary Core		Passed
Backup Core		Passed
Internal I/O Expander		Passed
Remote Control Firmware		Passed

The **MM Built-in Self Test (BIST) Results** section displays BIST results for the management modules. The test results for both the primary and standby management modules are kept updated. The **Last Update** field shows when the test results for each management module were collected.

Appendix A. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about IBM products, you will find a wide variety of sources available from IBM to assist you. This appendix contains information about where to go for additional information about IBM and IBM products, what to do if you experience a problem with your BladeCenter® product or optional device, and whom to call for service, if it is necessary.

Before you call

Before you call, make sure that you have taken these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Use the troubleshooting information in your system documentation, and use the diagnostic tools that come with your system. Information about diagnostic tools is in the *Hardware Maintenance Manual and Troubleshooting Guide* or *Problem Determination and Service Guide* on the IBM Documentation CD that comes with your system.
- Go to <http://www.ibm.com/servers/eserver/support/bladecenter/> to check for information to help you solve the problem.

You can solve many problems without outside assistance by following the troubleshooting procedures that IBM provides in the online help or in the documentation that is provided with your IBM product. The documentation that comes with BladeCenter systems also describes the diagnostic tests that you can perform. Most BladeCenter systems, operating systems, and programs come with documentation that contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the software.

Using the documentation

Information about your IBM BladeCenter system and preinstalled software, if any, or optional device is available in the documentation that comes with the product. That documentation can include printed documents, online documents, readme files, and help files. See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates. To access these pages, go to <http://www.ibm.com/servers/eserver/support/bladecenter/> and follow the instructions. Also, some documents are available through the IBM Publications Center at <http://www.ibm.com/shop/publications/order/>.

Getting help and information from the World Wide Web

On the World Wide Web, the IBM Web site has up-to-date information about IBM BladeCenter systems, optional devices, services, and support at <http://www.ibm.com/servers/eserver/support/bladecenter/>.

Software service and support

Through IBM Support Line, you can get telephone assistance, for a fee, with usage, configuration, and software problems with BladeCenter products. For information about which products are supported by Support Line in your country or region, see <http://www.ibm.com/services/sl/products/>.

For more information about Support Line and other IBM services, see <http://www.ibm.com/services/>, or see <http://www.ibm.com/planetwide/> for support telephone numbers. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

Hardware service and support

You can receive hardware service through IBM Services or through your IBM reseller, if your reseller is authorized by IBM to provide warranty service. See <http://www.ibm.com/planetwide/> for support telephone numbers, or in the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

In the U.S. and Canada, hardware service and support is available 24 hours a day, 7 days a week. In the U.K., these services are available Monday through Friday, from 9 a.m. to 6 p.m.

IBM Taiwan product service

台灣IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路7號3樓
電話：0800-016-888

IBM Taiwan product service contact information:
IBM Taiwan Corporation
3F, No 7, Song Ren Rd.
Taipei, Taiwan
Telephone: 0800-016-888

Appendix B. Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A.*

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product, and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Trademarks

The following terms are trademarks of International Business Machines Corporation in the United States, other countries, or both:

Active Memory	IBM	TechConnect
Active PCI	IBM (logo)	Tivoli
Active PCI-X	IntelliStation	Tivoli Enterprise
AIX	NetBAY	Update Connector
Alert on LAN	Netfinity	Wake on LAN
BladeCenter	Predictive Failure Analysis	XA-32
Chipkill	ServeRAID	XA-64
e-business logo	ServerGuide	X-Architecture
@server	ServerProven	XpandOnDemand
FlashCopy	System x	xSeries
i5/OS		

Intel, Intel Xeon, Itanium, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Java and all Java-based trademarks and logos are trademarks of Sun Microsystems, Inc. in the United States, other countries, or both.

Adaptec and HostRAID are trademarks of Adaptec, Inc., in the United States, other countries, or both.

Linux is a trademark of Linus Torvalds in the United States, other countries, or both.

Red Hat, the Red Hat "Shadow Man" logo, and all Red Hat-based trademarks and logos are trademarks or registered trademarks of Red Hat, Inc., in the United States and other countries.

Other company, product, or service names may be trademarks or service marks of others.

Important notes

Processor speeds indicate the internal clock speed of the microprocessor; other factors also affect application performance.

CD drive speeds list the variable read rate. Actual speeds vary and are often less than the maximum possible.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for approximately 1000 bytes, MB stands for approximately 1 000 000 bytes, and GB stands for approximately 1 000 000 000 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1 000 000 bytes, and GB stands for 1 000 000 000 bytes. Total user-accessible capacity may vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard disk drive bays with the largest currently supported drives available from IBM.

Maximum memory may require replacement of the standard memory with an optional memory module.

IBM makes no representation or warranties regarding non-IBM products and services that are ServerProven[®], including but not limited to the implied warranties of merchantability and fitness for a particular purpose. These products are offered and warranted solely by third parties.

IBM makes no representations or warranties with respect to non-IBM products. Support (if any) for the non-IBM products is provided by the third party, not IBM.

Some software may differ from its retail version (if available), and may not include user manuals or all program functionality.

Index

A

- acoustic mode 85
- alarm management 63
- algorithms, encryption 46
- AMM status, view 108
- assistance, getting 111
- authentication, LDAP 92
- authority, user 57

B

- blade server
 - firmware update 82
- blade server, Globally Unique Identifier 74
- blade server, GUID 74
- blade server, World Wide Name 74
- blade server, WWN 74
- BladeCenter unit
 - configuring 10

C

- configuration file
 - restoring 48
 - saving 48
- configuration wizard 106
- Configuration/Setup Utility program 5
- configure
 - I/O module 54
- configuring
 - DNS 16
 - LDAP 18
 - LDAP client authentication 22
 - LDAP search attributes 23
 - secure shell server 45
 - SMTP 17
 - SNMP 14
 - Wake on LAN 47
 - Wake on LAN (Linux) 48
- current users 66

D

- date stamp 62
- default IP address 7
- difficulty communicating with replacement module 48
- disable Telnet 101
- DNS 101
- DNS, configuring 16

E

- enable service technician access 107, 108
- encryption algorithms 46
- error log.
 - See event log

- Ethernet
 - configuring remote connection 11
- Ethernet failover 100
- event log 68
- event log in alerts 96
- event log, viewing 68
- expansion card, Globally Unique Identifier 74
- expansion card, GUID 74
- expansion card, World Wide Name 74
- expansion card, WWN 74

F

- failover, Ethernet 100
- failover, uplink 100
- firmware update
 - blade server 82
 - I/O module 90
 - management module 104
- FTP 101
- fuel gauge 71

G

- getting help 111
- Globally Unique Identifier 74
- GUID 74

H

- help 62
- help, getting 111

I

- I/O module
 - firmware update 90
- IP address, default 7
- IP reset button 48
- IP session, set for I/O module 54

L

- LDAP 101
 - configuring client authentication 22
 - configuring search attributes 23
 - overview 18
 - setting up client 18
- LDAP authentication 92
- LEDs
 - set color 70
- logged in users 66

M

- MAC address, blade server 74

- management module
 - configuration wizard 106
 - default IP address 7
 - firmware update 104
 - redundant
 - manual changeover 107
 - users logged in 66
- management-module Web interface
 - starting 8
- managing alarms 63
- managing power 71, 84
- mounting remote drive or image 52

N

- network protocols
 - configuring DNS 16
 - configuring LDAP 18
 - configuring SMTP 17
 - configuring SNMP 14
 - configuring SSL 34
- notes, important 114
- notices 113

P

- port assignments 97
- ports 97
 - serial 96
- power management 71, 84
- protocols
 - DNS 16
 - SMTP 17
 - SNMP 14
 - SSL 34

Q

- quiet mode 85

R

- redundant power loss 84
- remote console 79
- remote control 79
- remote disk 52, 81
- replacement module, difficulty communicating with 48
- restoring configuration file 48

S

- saving configuration file 48
- Secure Shell connection clients 46
- secure shell server
 - enabling 46
 - generating private key 45
 - overview 45
- secure Web server and secure LDAP
 - configuring security 35
 - enabling SSL for LDAP client 45

- secure Web server and secure LDAP (*continued*)
 - enabling SSL for secure Web server 43
 - overview 34
 - SSL certificate overview 35
 - SSL client certificate management 43
 - SSL client trusted certificate management 43
 - SSL server certificate management 36
- security 101, 102
- security, configuring 35
- serial over LAN 86
- serial port 96
- service technician
 - enable access 107, 108
- setting up LDAP client 18
- SMASH 101
- SMTP 101
- SMTP, configuring 17
- SNMP 101
- SNMP, configuring 14
- SOL 86
- SSH 102
- SSH clients 46
- SSL certificate overview 35
- SSL client certificate management 43
- SSL client trusted certificate management 43
- SSL security protocol 34
- SSL server certificate management 36
- SSL, enabling
 - for LDAP client 45
 - for secure Web server 43
- SSL,LDAP 102

T

- TCP 101
- TCP log 101
- TCP log, viewing 101
- Telnet, disable 101
- TFTP 101
- thermal event response 85
- time stamp 62
- trademarks 114

U

- uplink failover 100
- use authority 57
- users, logged in 66
- utility, Configuration/Setup 5

V

- view AMM status 108

W

- Wake on LAN
 - configuration 47
 - Linux configuration 48
 - verify configuration 48

Web browsers, supported 6
Web site
 BladeCenter Planning and Installation Guide 2
World Wide Name 74
WWN 74



Part Number: 42C4886

Printed in USA

(1P) P/N: 42C4886

