



87691VX VXA320 Tape Autoloader User's Guide

Important: Review the maintenance information in Chapter 5, "Using the media," on page 29 and Chapter 6, "Maintaining the 87691VX Tape Autoloader," on page 39, because periodic maintenance is not covered by the IBM warranty. Repairs or exchanges resulting from improper maintenance or use of unsupported media might result in billable service charges.



87691 VX VXA320 Tape Autoloader User's Guide

Note

Before using this information and the product it supports, read the information in Appendix C, "IBM Statement of Limited Warranty Z125-4753-09 08/2006," on page 75 and Appendix B, "Notices," on page 67.

Second Edition (June, 2008)

© Copyright International Business Machines Corporation 2008. All rights reserved.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Safety	v
-------------------------	----------

About this document	ix
--------------------------------------	-----------

Chapter 1. General information 1

Front components	2
Status LED	2
Operator controls	2
Rear components	3
Specifications	3
Tape drive environment and use	4
Tape handling and storage	4
Environmental issues	4
Tape drive cleaning	5
Firmware updates	5

Chapter 2. Mounting the 87691VX Tape Autoloader in a rack 7

Removing the shipping key	7
Assembling the rails	9
Attaching the rails to the rack	11
Attaching the 87691VX Tape Autoloader to the rails	13

Chapter 3. Installing and setting up the 87691VX Tape Autoloader 15

Step 1. Performing a parts inventory	15
Step 2. Checking the electrical outlets	16
Step 3. Determining the SCSI address	16
Step 4. Setting the SCSI address	17
Step 5. Connecting the SCSI bus cable	17
Step 6. Installing the SCSI bus terminator	18
Step 7. Connecting the power cables	19
Step 8. Installing a backup application	19

Chapter 4. Using the 87691VX Tape Autoloader 21

Using the operator panel	21
Using the 87691VX Tape Autoloader menus	22
Overview of the main menus	23
Setting password protection	24
Setting the operating mode	26
Using the 87691VX Tape Autoloader Ethernet connection	27
Connecting the 87691VX Tape Autoloader to an Ethernet network	27
Setting the Ethernet configuration options	27

Chapter 5. Using the media 29

Types of tape cartridges	29
Guidelines for using tape cartridges	30
Erasing a tape cartridge	30
Storage and shipping tape cartridges	30
Operating in harsh environments	32

Setting the write-protect switch	32
Placing the cartridge labels	33
Importing and exporting cartridges in the autoloader	33
Importing tape cartridges	33
Exporting tape cartridges	34
Loading and unloading cartridges in the tape drive	35
Loading tape cartridges	35
Unloading tape cartridges	35
Cleaning the tape drive	36
Cleaning the drive by using the Clean Drive option	36
Cleaning the drive by loading a cleaning cartridge	37

Chapter 6. Maintaining the 87691VX Tape Autoloader 39

Using the repair identification (RID) tag	39
Handling static-sensitive devices	39
Removing tape cartridges manually	40
Resetting the autoloader	41
Updating firmware and creating diagnostic logs using FTP	41
Updating the firmware	41
Creating diagnostic logs	42
Solving problems	42
Troubleshooting hints	43
Maintenance analysis procedures	44
CRU list	48
Removal and replacement procedures	48
Replacing the autoloader tape drive	48
Replacing the autoloader	51
Manually Removing a Tape Cartridge	53

Chapter 7. Using the Remote Management utility 55

Setting configuration options	57
Changing the library configuration	58
Changing the Ethernet configuration	59
Changing the Web access password	59
Viewing statistics	60
Running diagnostics	60

Appendix A. Error messages 63

Appendix B. Notices 67

Trademarks	67
Important notes	68
Product recycling and disposal	69
Battery return program	70
Electronic emission notices	71
Federal Communications Commission (FCC) statement	71
Industry Canada Class A emission compliance statement	72

Avis de conformité à la réglementation d'Industrie Canada	72
Australia and New Zealand Class A statement	72
United Kingdom telecommunications safety requirement	72
European Union EMC Directive conformance statement	72
Taiwanese Class A warning statement	73
Chinese Class A warning statement	73
Japanese Voluntary Control Council for Interference (VCCI) statement	73

Korean Class A warning statement	73
--	----

**Appendix C. IBM Statement of Limited
Warranty Z125-4753-09 08/2006 75**

Part 1 - General Terms.	75
Part 2 - Country-unique Terms	79
Part 3 - Warranty Information	89

Index 93

Safety

Before installing this product, read the Safety Information.

مج، يجب قراءة دات السلامة

Antes de instalar este produto, leia as Informações de Segurança.

在安装本产品之前，请仔细阅读 **Safety Information**
(安全信息)。

Prije instalacije ovog produkta obavezno pročitajte Sigurnosne Upute.

Před instalací tohoto produktu si přečtěte příručku bezpečnostních instrukcí.

Læs sikkerhedsforskrifterne, før du installerer dette produkt.

Ennen kuin asennat tämän tuotteen, lue turvaohjeet kohdasta Safety Information.

Avant d'installer ce produit, lisez les consignes de sécurité.

Vor der Installation dieses Produkts die Sicherheitshinweise lesen.

Πριν εγκαταστήσετε το προϊόν αυτό, διαβάστε τις πληροφορίες ασφάλειας
(safety information).

לפני שתתקינו מוצר זה, קראו את הוראות הבטיחות.

A termék telepítése előtt olvassa el a Biztonsági előírásokat!

Prima di installare questo prodotto, leggere le Informazioni sulla Sicurezza.

製品の設置の前に、安全情報をお読みください。

본 제품을 설치하기 전에 안전 정보를 읽으십시오.

Пред да се инсталира овој продукт, прочитајте информацијата за безбедност.

Lees voordat u dit product installeert eerst de veiligheidsvoorschriften.

Les sikkerhetsinformasjonen (Safety Information) før du installerer dette produktet.

Przed zainstalowaniem tego produktu, należy zapoznać się
z książką "Informacje dotyczące bezpieczeństwa" (Safety Information).

Antes de instalar este produto, leia as Informações sobre Segurança.

Перед установкой продукта прочтите инструкции по
технике безопасности.

Pred inštaláciou tohto zariadenia si prečítajte Bezpečnostné predpisy.

Pred namestitvijo tega proizvoda preberite Varnostne informacije.

Antes de instalar este producto lea la información de seguridad.

Läs säkerhetsinformationen innan du installerar den här produkten.

安裝本產品之前，請先閱讀「安全資訊」。

Statement 1:



DANGER

Electrical current from power, telephone, and communication cables is hazardous.

To avoid a shock hazard:

- Do not connect or disconnect any cables or perform installation, maintenance, or reconfiguration of this product during an electrical storm.
- Connect all power cords to a properly wired and grounded electrical outlet.
- Connect to properly wired outlets any equipment that will be attached to this product.
- When possible, use one hand only to connect or disconnect signal cables.
- Never turn on any equipment when there is evidence of fire, water, or structural damage.
- Disconnect the attached power cords, telecommunications systems, networks, and modems before you open the device covers, unless instructed otherwise in the installation and configuration procedures.
- Connect and disconnect cables as described in the following table when installing, moving, or opening covers on this product or attached devices.

To Connect:

1. Turn everything OFF.
2. First, attach all cables to devices.
3. Attach signal cables to connectors.
4. Attach power cords to outlet.
5. Turn device ON.

To Disconnect:

1. Turn everything OFF.
2. First, remove power cords from outlet.
3. Remove signal cables from connectors.
4. Remove all cables from devices.

Statement 14:



CAUTION:

Hazardous voltage, current, and energy levels might be present. Only a qualified service technician is authorized to remove the covers where the following label is attached.



Statement 15:



CAUTION:

Make sure that the rack is secured properly to avoid tipping when the server unit is extended.

Statement 23:



CAUTION:

Do not place any object weighing more than 50 kg (110 lb) on top of rack-mounted devices.



>50 kg (110 lb)

About this document

This document describes how to install and use the 87691VX Tape Autoloader. It contains the following chapters:

Chapter 1, “General information,” on page 1 describes the operator controls, LEDs, connector locations, and hardware specifications of the 87691VX Tape Autoloader.

Chapter 2, “Mounting the 87691VX Tape Autoloader in a rack,” on page 7 describes how to install the 87691VX Tape Autoloader in a rack.

Chapter 3, “Installing and setting up the 87691VX Tape Autoloader,” on page 15 describes how to install the 87691VX Tape Autoloader.

Chapter 4, “Using the 87691VX Tape Autoloader,” on page 21 describes the operator controls and how to use them

Chapter 5, “Using the media,” on page 29 describes the media to use in the 87691VX Tape Autoloader.

Chapter 6, “Maintaining the 87691VX Tape Autoloader,” on page 39 provides the maintenance procedures for the 87691VX Tape Autoloader.

Chapter 7, “Using the Remote Management utility” provides information about Remote Management utility.

Appendix A, “Error messages” provides information about autoloader error messages.

Store this document with your system documents.

Chapter 1. General information

The 87691VX Tape Autoloader is a SCSI external storage device that can be connected to a server that uses a low voltage differential (LVD) interface. It provides storage for up to 10 data cartridges. Each data cartridge is capable of storing up to 160 GB of native data, or 320 GB of compressed data, on a 230-meter tape using VXA technology.

See Appendix C, "IBM Statement of Limited Warranty Z125-4753-09 08/2006," on page 75 for the warranty terms. If a tape drive stops functioning due to a component failure during the tape drive warranty or maintenance time, IBM will replace the tape drive unit. IBM will replace any defective tape drive under the terms and conditions of the IBM® warranty or service agreement. It is our objective to work with you to identify the cause of any tape drive problems and provide a solution. The 87691VX Tape Autoloader is a Customer Replaceable Unit (CRU).

A **Tape Backup Units Compatibility** matrix is on the IBM Web site. To view the matrix of servers that support the autoloader and other tape backup units, complete the following steps:

1. Go to <http://www.ibm.com/systems/support/>.
2. Under the **IBM Systems support** menu, click **System x**.
3. Under the **System x** menu, click **HW/SW Compatibility**.
4. Under **Compatibility Information by Server or Product Type**, click **System x Servers**.
5. Under **Compatibility Info by Product Type**, click **Tape backup units**. The **Tape Backup Units Compatibility** matrix is displayed at the bottom of the Web page.

Figure 1 shows the front view of the 87691VX Tape Autoloader.




Figure 1. Front view of the 87691VX Tape Autoloader

Note: The illustrations in this document might differ slightly from your hardware.

Front components

Figure 2 shows the front view of the 87691VX Tape Autoloader.




Figure 2. Front view of the 87691VX Tape Autoloader

Status LED

The 87691VX Tape Autoloader has a status LED (see Figure 2), which is located to the right of the operator panel buttons. This LED is lit during normal autoloader activity and flashing when a fault condition occurs.

Operator controls

The 87691VX Tape Autoloader has a five-button operator panel and an LCD screen (see Figure 2) that you can use to monitor the autoloader operations, control tape cartridge movement, and select configuration options. The operator panel is also used to control the insertion and removal of tape cartridges through the access door. See “Using the operator panel” on page 21 for more information about the operator panel.

Use the two emergency access holes to open the access door and remove tape cartridges in the event of a power failure. See “Removing tape cartridges manually” on page 40 for information about this procedure.

Rear components

Figure 3 shows the components on the rear of the 87691VX Tape Autoloader.




Figure 3. Rear view of the 87691VX Tape Autoloader

Specifications

This section provides the specification for the autoloader.

Table 1. Specifications for the 87691VX Tape Autoloader

Physical specifications		
Width	447 mm (17.6 in.)	
Depth	686 mm (27.0 in.)	
Height	43.6 mm (1.718 in.)	
Weight	10.3 kg (22.8 lb.)	
Power specifications		
kVA (typical)	0.06 at 120 V ac	
V ac	100 to 125 V ac, or 200 to 240 V ac	
Hertz	50 to 60 Hz	
Btu maximum (watts)	77 Btu/hr (23 watts at 240 V ac)	
Power factor	0.4 to 0.6	
Other specifications		
Maximum altitude	2135 m (7000 ft)	
Recommended environment		
Environmental factor	Operating	Non-operating
Temperature	16 to 32°C (60 to 90°F)	10 to 43°C (50 to 110°F)
Relative humidity (noncondensing)	20 to 80%	20 to 80%
Maximum wet bulb	23°C (73°F)	27°C (80°F)
Note: The operating limits are also applicable to media. For media storage and shipping limits, see “Storage and shipping tape cartridges” on page 30.		

Tape drive environment and use

Tape drives require specific maintenance and environmental conditions to operate well. Using high-quality, data-grade media, handling and storing this media correctly, operating the tape device in a clean environment, and keeping the tape drive clean can help you to avoid problems.

Tape handling and storage

Most tapes are supplied in sealed cartridges so that the tapes will remain in a clean environment. Opening the cartridge allows dirt and airborne particles to enter. The cartridge should be opened only by the tape drive.

The tape is held under correct tension inside the cartridge. If the cartridge is dropped, this tension is relaxed. Inserting a dropped cartridge into a tape device can cause incorrect loading and jamming, which can ruin the tape and can cause physical damage if the cartridge is not removed correctly.

Store tapes in their protective containers and store them on end. The storage area must be clean, dry, at normal room temperature, and away from magnetic fields.

Environmental issues

Tape devices are designed to operate in a clean environment. Problem factors are dirt, dust, fibers and airborne particles. Airborne particles are the most difficult to address. When a tape is installed in the tape device, the clearance between the heads and the tape is measured in microns. Particles can damage the tape or the head if they come in contact with either. You are responsible for providing a clean operating environment for the tape drive and system.

Tape drive cleaning

No matter how clean the environment is, debris might build up on the heads of any tape drive. Every time a tape moves, some of the media surface comes off onto the heads. Over time, this builds up and causes errors in reading and writing. You are responsible for cleaning the tape drive in accordance with the cleaning procedure in “Cleaning the tape drive” on page 36.

Firmware updates

IBM occasionally releases firmware updates for tape drives and autoloaders. To download firmware updates from the IBM Web site, complete the following steps:

1. Go to <http://www.ibm.com/systems/support/>.
2. Under **Select a product or service type**, select **Hardware upgrades**.
3. Under **Product family**, select **Tape autoloader**.
4. Under **Type**, select **Tape Autoloader VXA-320**.
5. Click **Go**.
6. Under **Available downloads and drivers**, click the link for the applicable firmware file. The firmware download Web page will open.
7. Click the file link for the firmware update to download the file.
8. Save the firmware file to the same directory location of your Windows FTP utility.

Installing firmware updates is your responsibility.

Chapter 2. Mounting the 87691VX Tape Autoloader in a rack

The 87691VX Tape Autoloader is designed to be installed in a rack, using 1 U of rack space. Rack-mounting hardware is included with the autoloader.

Note: Racks are measured in vertical increments of 4.45 cm (1.75 inches) each. Each increment is call a “U”. A 1-U-high device is 1.75 inches tall.

To install the autoloader in a rack, you need the following tools:

- #1 Phillips screwdriver
- #2 Phillips screwdriver
- 8 mm wrench
- Tape measure

Before you start the installation, read the entire installation procedure.

Removing the shipping key

The robotic cartridge loader inside the autoloader is secured with a small metal shipping key to keep the loader from moving during shipping. Before you operate the autoloader, you must remove this shipping key. To remove the shipping key, complete the following steps:

- ___ 1. Remove the adhesive label that secures the shipping key to the autoloader.





Figure 4. Removing the shipping label

- ___ 2. Lift the shipping key up and out of the autoloader.



Shipping Key

Figure 5. Removing the shipping key

Assembling the rails

To assemble the rails, complete the following steps:

1. Using a tape measure, measure the distance from the outside of the front mounting holes of your rack to the outside of the back mounting holes. Record this measurement.
2. Locate the front and back rails for the left side. Position the rails as shown in Figure 6, with the front rail on top of the back rail. Spread the rails to the distance that you measured in 1.
3. Using a #2 Phillips screwdriver, attach the rails together with two M5 screws (the larger silver screws from the kit), as shown in Figure 6. Leave the screws loose so that you can adjust the reach of the rails, if necessary.




Figure 6. Assembling the left side rail

4. Assemble the rails for the right side in the same way (see Figure 7 on page 10).




Figure 7. Assembling the right side rail

Attaching the rails to the rack

To attach the rails to the rack, complete the following steps:

1. Position the left-side set of rails in the rack so that the front flange is inside the front screw holes in the rack (see Figure 8).




Figure 8. Attaching the left side rail to the front of the rack

2. Insert two M5 screws (the black screws from the kit) through the front flange of the rail (see Figure 8). Attach a nut to each screw. If your rack has square mounting holes or the holes are much larger than the screws that are provided in the kit, use a washer with the nut. Finger-tighten the nut.
3. Adjust the reach of the rails as necessary to position the back flange of the rail outside of the screw holes at the back of the rack (see Figure 9).



Figure 9. Attaching the left side rail to the back of the rack

4. From the back of the rack, insert an M5 screw (the silver screws from the kit) through the back flange of the rail (see Figure 9). Attach a nut to the screw. If your rack has square mounting holes or the holes are much larger than the screws that are provided in the kit, use a washer with the nut. Finger-tighten the nut.

Note: Before you tighten the screws further, make sure that the horizontal shelf that is created by the rails is level.

5. Using a #2 Phillips screwdriver and an 8 mm wrench, tighten the screws that secure the rails to the front and back of the rack.
6. Using a #2 Phillips screwdriver, tighten the two screws holding the set of rails together.
7. Repeat step 1 on page 11 through step 6 for the right-side rails.

Attaching the 87691VX Tape Autoloader to the rails

Statement 15:



CAUTION:

Make sure that the rack is secured properly to avoid tipping when the server unit is extended.

Statement 23:



CAUTION:

Do not place any object weighing more than 50 kg (110 lb) on top of rack-mounted devices.



>50 kg (110 lb)

To attach the autoloader to the rails, complete the following steps:

1. From the front of the rack, place the autoloader onto the shelf that is created by the rails (see Figure 10).



Figure 10. Placing the autoloader on the rails

2. Slide the autoloader all the way back until it makes contact with the small flanges near the back of the rails. The front edge of each shelf piece slides under the metal tabs at the bottom front edge of the autoloader.
3. From the back of the rack, attach the autoloader to the rails by inserting an M3 screw into each of the small flanges (see Figure 11 on page 14). Tighten the

screws, using a #1 Phillips screwdriver.



Figure 11. Attaching the autoloader to the rails

Note: For information about connecting cables and attaching the 87691VX Tape Autoloader to a host system, see Chapter 3, “Installing and setting up the 87691VX Tape Autoloader,” on page 15.

Chapter 3. Installing and setting up the 87691VX Tape Autoloader

This chapter provides step-by-step instructions for installing and setting up the 87691VX Tape Autoloader. If you need assistance with the installation, contact IBM service.

Before you install the 87691VX Tape Autoloader, let it acclimate to the operating environment for as long as it has been away from the environment or for 24 hours, whichever is less.

Because the autoloader is a low-voltage differential (LVD) device, all other devices on the SCSI bus should also be LVD. These devices include the controller cards, cables, terminators, and any other devices on the bus. Do not mix LVD and high voltage differential (HVD) devices on the same bus.

Attention: The 87691VX Tape Autoloader is a precision device that requires reasonable care in handling to prevent data loss or permanent damage to the device. Avoid bumping or dropping the 87691VX Tape Autoloader.

To install the 87691VX Tape Autoloader, complete the following steps:

Step 1. Performing a parts inventory

Make sure that you received the following items:

1. Power cable
2. The *87691VX Tape Autoloader User's Guide* (this document)
3. SCSI bus cable
4. Terminator
5. Cleaning cartridge
6. Package of sample bar code labels
7. Rack mounting hardware

Step 2. Checking the electrical outlets

Make sure that the electrical outlets are properly grounded.

Attention: Electrical current from power, telephone, and communication cables is hazardous. See "Safety" on page v for more information.

Step 3. Determining the SCSI address

The SCSI address identifies the device to the bus and the system. Be careful not to set two devices to the same SCSI address because this will cause errors. The selected address sets the priority of the device on the bus. Tape drives are usually slow devices, compared to hard disk drives, so a tape drives should be set to a high priority to ensure that it gets access to the bus in a timely manner.

The host system has 16 available SCSI address settings. From highest to lowest, the SCSI bus priority is as follows: Highest 7 6 5 4 3 2 1 0 15 14 13 12 11 10 9 8 Lowest.

Before you install the 87691VX Tape Autoloader, make sure that its SCSI address is not being used by another device. The 87691VX Tape Autoloader is a wide (16 bit) SCSI device and uses SCSI addresses from 0 through 15 (usually, address 7 is reserved for the SCSI I/O controller).

Note: The 87691VX Tape Autoloader is supported only on an LVD SCSI bus.

To determine an unused SCSI address, you need the following information:

- The name and the port number of the host system SCSI I/O controller that you want to connect the autoloader to
- The SCSI address of that SCSI I/O controller
- The SCSI addresses of other devices that are connected to that SCSI I/O controller

Step 4. Setting the SCSI address

The SCSI address is a unique address that identifies the 87691VX Tape Autoloader and drive to your system. The autoloader and the drive that is installed in it each must have its own unique SCSI address. The 87691VX Tape Autoloader is shipped with the autoloader SCSI address set to 0 and the drive address set to 5. If you want to change these settings, use the operator panel and display screen on the front of the device (see Figure 2 on page 2).

To set the autoloader SCSI ID, complete the following steps:

1. On the operator panel, press the Down a Level button to access the main menus.
2. Press the Next Choice button to scroll through the menus until the **Change a Configuration** menu is displayed.
3. Press the Down a Level button once, and then press the Next Choice button until the **Change Library ID** screen is displayed.
4. Press the Down a Level button to set the autoloader SCSI ID.
5. Press the Next Choice or Previous Choice button to scroll through the available values. When the SCSI address that you want to use is shown, press the Select button to select the value. A confirmation screen is displayed.
6. Press the Select button to set the SCSI ID to the selected value or press the Up a Level button to cancel the change. The library SCSI inquiry string is IBM 87691VX.

To set the drive SCSI ID, complete the following steps:

1. On the operator panel, press the Down a Level button to access the main menus
2. Press the Next Choice button to scroll through the menus until the **Change a Configuration** menu is displayed.
3. Press the Down a Level button once, and then press the **Next Choice** button until the Change Drive ID screen is displayed.
4. Press the Down a Level button to set the drive SCSI ID. Set the device at the highest available address. Do not select a SCSI address that is already in use.
5. Press the Next Choice or Previous Choice button to scroll through the available values. When the SCSI address that you want to use is displayed, press the Select button to select the value. A confirmation screen is displayed.
6. Press the Select button to set the SCSI ID to the selected value or press the Up a Level button to cancel the change. The tape drive SCSI inquiry string is IBM VXA-3.

Step 5. Connecting the SCSI bus cable

To connect the SCSI bus cable, complete the following steps:

1. Before you attach the cable, ensure that no connector pins are bent.
2. On the rear of the 87691VX Tape Autoloader (see Figure 12 on page 18), attach the device connector end of the SCSI bus cable to one of the SCSI connectors. Make sure that the connector is fully engaged.

Attention: Electrical current from power, telephone, and communication cables is hazardous. See “Safety” on page v for more information.

3. Secure the cable to the 87691VX Tape Autoloader using the thumbscrews on the cable (finger-tighten them only).
4. Connect the other end of the SCSI bus cable as follows:
 - If the 87691VX Tape Autoloader is the only device that is attached to the system, connect the cable to the host system (see Figure 12).
 - If the 87691VX Tape Autoloader is part of a multiple-device configuration, connect the cable to the next device.

Step 6. Installing the SCSI bus terminator

A terminator must be installed on the last device in the configuration.

Note: Before you attach the terminator, make sure that no pins on the connector are bent or damaged.

Attention: Electrical current from power, telephone, and communication cables is hazardous. See “Safety” on page v for more information.

To install the SCSI terminator, align it with the unused SCSI connector on the 87691VX Tape Autoloader and push in until the terminator is seated. Secure the terminator with the thumbscrews on the terminator (finger-tighten them only).

- If the 87691VX Tape Autoloader (see Figure 12) is the only SCSI device that is attached to the host system, install the terminator on one of the dual connectors.




Figure 12. Example of attaching one SCSI device to the system unit

- If more than one device is attached to the host system, move the terminator to the last device on the bus.




Figure 13. Example of attaching multiple SCSI devices to the system unit

Notes:

1. The terminator and the SCSI bus cable can be connected to either the top or the bottom SCSI connector on the 87691VX Tape Autoloader.

2. When the 87691VX Tape Autoloader is the last device on the bus that is attached to a host system, use the terminator that comes with the 87691VX Tape Autoloader.
3. Use only one external terminator to terminate the SCSI bus. You do not have to use the terminator that comes with the 87691VX Tape Autoloader if an IBM-approved terminator has been previously installed.

Step 7. Connecting the power cables

To connect the power cables, complete the following steps:

1. Connect the 87691VX Tape Autoloader power cable to an electrical outlet.

Attention:

- a. Connect the 87691VX Tape Autoloader power cable directly to an electrical outlet to ensure proper grounding. Using extension cords or power strips to supply power to the 87691VX Tape Autoloader does not ensure proper grounding.
- b. Electrical current from power, telephone, and communication cables is hazardous. See “Safety” on page v for more information.
2. Connect the power cables for all external devices and the system unit to electrical outlets.
3. Turn on the power to all of the external devices, except the 87691VX Tape Autoloader.
4. Review the information in “Status LED” on page 2.
5. Turn on the power to the system unit.
6. While you observe the LCD screen, turn on the power to the 87691VX Tape Autoloader and watch for the messages that the power-on procedure has been completed successfully.

Step 8. Installing a backup application

If you are using a separate backup application, install it now using the instructions that came with the application. If you are using the native Windows® backup applet, you must download the device driver from the IBM Web site. To download the device driver, complete the following steps:

1. Go to <http://www.ibm.com/systems/support/>.
2. Under **Select a product or service type**, select **Hardware upgrades**.
3. Under **Product family**, select **Tape autoloader**.
4. Under **Type**, select **Tape Autoloader VXA-320**.
5. Click **Go**.
6. Under **Available downloads and drivers**, click the link for the index of tape files.
7. Scroll down to the **87691VX Tape Autoloader** and click the file link for the Windows device driver.

Chapter 4. Using the 87691VX Tape Autoloader

This chapter describes the operator controls on the 87691VX Tape Autoloader and how to use them.

Using the operator panel

Use the five-button operator panel to navigate through the configuration, operation, and information menus. The 87691VX Tape Autoloader menus are organized in a tree structure (see Figure 15 on page 23) that consists of four main menus with submenus and selections. Use the operator panel buttons to move up and down between menu levels, view choices within menus, and make selections.

Figure 14 shows the operator panel buttons on the 87691VX Tape Autoloader.




Figure 14. Operator panel buttons on the 87691VX Tape Autoloader

Button	Function
Next Choice (right arrow)	Press the Next Choice button to move forward through the selections in a menu. Note: If you are entering a password, press the Next Choice button to move forward through the available values at a character position. Press and hold the button to move rapidly through the available values.
Previous Choice (left arrow)	Press the Previous Choice button to move backward through the selections in a menu. Note: If you are entering a password, press the Previous Choice button to move backward through the available values at a character position. Press and hold the button to move rapidly through the available values.

Up a Level (up arrow)	Press the Up a Level button to return to the previous level of menus. At the top level of menus, pressing the Up a Level button returns to the Home screen. Note: If you are entering a password, press the Up a Level button to move backward through the character positions of the password.
Down a Level (down arrow)	Press the Down a Level button to move down into a lower level of a menu. For example, if the LCD screen is displaying one of the main menus, press this button to view the submenu for that menu. Note: If you are entering a password, press the Down a Level button to move forward through the character positions of the password.
Select	Press the Select button to cause an operation displayed on the LCD screen to take effect. For example, if you are changing a SCSI ID, pressing the Select button causes the new value you have entered to take effect. As confirmation, after you press the Select button, the original LCD screen displays the new value.

Using the 87691VX Tape Autoloader menus

During normal operation, the Home screen displays the operating status of the autoloader and tape drive. If the autoloader has no current error condition, the status of the tape drive is displayed.

If a menu is displayed on the LCD screen and you want to view the Home screen, press the Up a Level button until the Home screen is displayed.

Figure 15 on page 23 shows the menus and submenus that can be used to control the 87691VX Tape Autoloader. The menu tree shows the basic structure of the options. Many of the submenus have several options within them.




Figure 15. Menus on the 87691VX Tape Autoloader

Overview of the main menus

Below the Home screen are four main menus. Press the Down a Level button on the operator panel to display the main menus. Then, use the Next Choice or Previous Choice buttons to scroll through the main menus. Press the Down a Level button to display submenus within a main menu option.

The following main menus are available.

Menu	Description
Select a Command	Use this option to issue commands for basic autoloader operations, including inserting and removing cartridges, loading and unloading cartridges from the tape drive, and cleaning the tape drive.

Menu	Description
View a Status	Use this option to view an event log for the autoloader, sensor readings, individual cartridge cell statistics, bar code label information, cartridge inventory, firmware versions, and serial numbers for the autoloader and tape drive.
Change a Configuration	Use this option to view and change the SCSI IDs, operating mode, emulation mode, autoclean settings, and Ethernet settings. Also use this option to set up a password to restrict access to the operator panel menus.
Run a Diagnostic	Use this option to run demonstrations, perform diagnostic tests, and reset the autoloader.

Setting password protection

You can set up a password for accessing operator panel menus. When you have set a password, access to the following operator panel functions is password-protected:

- Changing configuration settings
- Importing and exporting cartridges
- Loading and unloading the tape drive
- Cleaning the tape drive
- Running demos
- Resetting the autoloader

A password can be up to six characters in length and is not case sensitive.

When password protection is in effect, you must enter the password before you can use the operator panel menus. Each time you return to the Home screen and press the Up a Level button an additional time (or wait 2 minutes), password protection is reactivated; you must enter the password again to access the menus.

Attention: If you set a password, record it in a secure location. The operator panel functions cannot be used without the password.

Setting an operator panel password

To set a password for the operator panel, complete the following steps:

1. On the operator panel, press the Down a Level button to display the main menus.
2. Press the Next Choice button to scroll through the menus until the **Change a Configuration** menu is displayed.
3. Press the Down a Level button once and then press the Next Choice button until the **Change Password Entry?** screen is displayed.
4. Press the Down a Level button. The **Select Password Protection** screen is displayed.
5. Press the Next Choice button until ON is displayed.
6. Press the Select button. The **Select New Password** screen is displayed.
7. Press the Next or Previous Choice button to scroll through the available characters for each position. Press the Down a Level or Up a Level button to change character positions. When you have entered the password, press the Select button. The message Set Password Now? is displayed.

Note: You can enter a password of up to six characters, including blanks. The password is not case-sensitive.

8. Press the Select button to accept the password (or press the Up a Level button to cancel setting the password).
9. Press the Up a Level button until the Home screen is displayed. Press the Up a Level button again or wait 2 minutes without pressing any buttons for the password to take effect.

Note: If you want to continue using menus after you have set a password, do not press the Up a Level button an additional time after the Home screen is displayed. The password will not take effect until you have pressed the Up a Level button an additional time at the Home screen or you have pressed no buttons for 2 minutes.

Accessing password-protected operator panel menus

If you want to have access to the operator menus when the password protection is in effect, complete the following steps:

1. On the operator panel, press the Select, Next Choice, Previous Choice, or Down a Level button. The password entry screen is displayed.
2. Enter the password. Press the Next Choice or Previous Choice button to scroll through the available characters for each position. Press the Down a Level or Up a Level button to change character positions. When you have entered the password, press the Select button. You can now access the menus.
3. After you have finished using the menus, press the Up a Level button until the Home screen is displayed. Then, press the Up a Level button again or wait 2 minutes without pressing any buttons for password protection to be reactivated.

Note: You can try to enter the password 5 times. On the sixth attempt, the autoloader displays an encrypted version of the password. Contact IBM service to have the password decrypted.

Turning off the operator panel password

To turn off password protection for the operator panel, complete the following steps:

1. On the operator panel, press the Select, Next, Previous, or Down a Level button. The password entry screen is displayed.
2. Enter the password. Press the Next Choice or Previous Choice button to scroll through the available characters for each position. Press the Down a Level or Up a Level button to change character positions. When you have entered the password, press the Select button. You can now access the menus.
3. Press the Next Choice button to scroll through the menus until the **Change a Configuration** screen is displayed.
4. Press the Down a Level button once.
5. Press the Next Choice button until the **Change Password Entry?** screen is displayed.
6. Press the Select button. The **Select Password Protection** screen is displayed.
7. Press the Next Choice button until OFF is displayed.
8. Press the Select button. The message Set Password Protection Off? is displayed.
9. Press the Select button to turn off the password protection (or the Up a Level button to cancel the operation).

10. Press the Up a Level button until the Home screen is displayed.

Setting the operating mode

The autoloader can operate in either random or sequential mode. In random mode, the tape cartridges are moved into the tape drive according to the commands of a control program. In sequential mode, the tape cartridges are used in sequential order. The default mode that the autoloader comes configured to use is random mode.

Sequential mode can be configured to use the Restart option and Loop option.

Table 2. Sequential mode options

Option	Description
Restart	The Reset option determines what the autoloader will do after it is reset or the power is turned off and then on. To have the autoloader start at the beginning of the cartridge sequence, select ON. To have the autoloader start with the cartridge that was being used before the power interruption occurred, select OFF.
Loop	The reset option will determine what the autoloader does after it has used the last tape cartridge in the sequence. To have the autoloader start using the first cartridge again, select ON. To have the autoloader wait for operator intervention, select OFF. Operator intervention typically means removing the cartridges and inserting new cartridges.

Changing from Random mode to Sequential mode

To change the autoloader from Random to Sequential mode, complete the following steps:

1. On the Home screen, press the Down a Level button to access the main menus.
2. Press the Next Choice button to scroll through the menus until the **Change a Configuration** menu is displayed.
3. Press the Down a Level button once.
4. Press the Next Choice button until the **Change Op. Mode? Now Random** screen is displayed.
5. Press the Select button. The **Select Op. Mode Random Mode** screen is displayed.
6. Press the Next Choice button or Previous Choice button to change from Random mode to Sequential mode.
7. Press the Select button. The message **Set Op.Mode to Sequential Now?** is displayed.
8. Press the Select button. The **Restart at First Address: NO** screen is displayed.
9. Press the Next Choice button or Previous Choice button to change from YES to NO.
10. Press the Select button. The **Loop When Done Set Looping Off** screen is displayed.
11. Press the Next Choice button or Previous Choice button to change from OFF to ON.
12. Press the Select button. The message **Set Op. Mode to SEQUENTIAL Now?** is displayed.
13. Press the Select button.
14. Press the Up a Level button until the Home screen is displayed.

Changing from Sequential mode to Random mode

To change the autoloader from Sequential mode to Random mode, complete the following steps:

1. On the Home screen, press the Down a Level button to access the main menus.
2. Press the Next Choice button to scroll through the menus until the **Change a Configuration** menu is displayed.
3. Press the Down a Level button once.
4. Press the Next Choice button until the **Change Op. Mode? Now Sequential** screen is displayed.
5. Press the Select button. The **Select Op. Mode Sequential Mode** screen is displayed.
6. Press the Next Choice button or Previous Choice button to change from Sequential to Random mode.
7. Press the Select button. The message Set Op.Mode to Random Now? is displayed.
8. Press the Select button.
9. Press the Up a Level button until the Home screen is displayed.

Using the 87691VX Tape Autoloader Ethernet connection

You can connect the 87691VX Tape Autoloader to an Ethernet network to remotely monitor operations through the remote management utility. You can also create diagnostic listings and upgrade autoloader firmware.

Connecting the 87691VX Tape Autoloader to an Ethernet network

To connect the autoloader to an Ethernet network using an Ethernet cable, complete the following steps:

1. Insert one end of the cable into the 87691VX Tape Autoloader Ethernet connector until you hear it snap into place. The Ethernet connector is on the back of the autoloader (see Figure 3 on page 3).
2. Connect the other end of the cable to the network or directly to the server you will use to run the 87691VX Tape Autoloader remote management utility or to upload firmware.

Setting the Ethernet configuration options

You can use the 87691VX Tape Autoloader Ethernet interface to remotely monitor operations, upgrade firmware, and create diagnostic listings. Configuring the 87691VX Tape Autoloader Ethernet interface typically involves specifying the autoloader IP address, subnet mask, and gateway address. The IP address is used to route information from the autoloader to the server. You can choose between dynamic (server-assigned) or static (user-assigned) addressing for the IP address. If you select dynamic addressing, you can view the current server-assigned IP address through the **Status** menu. The subnet mask is used to route information to designated devices within the network. The gateway address is used to route information outside the subnet.

The autoloader also includes an FTP interface that you can use to transfer firmware files or create diagnostic listings. You can set up an FTP user name and password for this interface or use the autoloader defaults. You can view and change the FTP settings only through the autoloader remote management utility.

If you plan to use the Ethernet interface, you must obtain an Ethernet cable. Use a shielded Category 5 (10/100BaseT connection) data-grade cable or similar Category 5 cable that is compliant with EIA/TIA 568. The 87691VX Tape Autoloader Ethernet port connector is a pin-through-hole RJ-45 shielded connector. All Ethernet cables that are used with the autoloader must be properly shielded.

Setting the Ethernet addresses

To set Ethernet addresses, complete the following steps:

1. On the operator panel, press the Down a Level button to display the main menus.
2. Press the Next Choice button to scroll through the menus until the **Change a Configuration** menu is displayed.
3. Press the Down a Level button once and then press the Next Choice button until the **Change IP Address?** screen is displayed.
4. Press the Down a Level button. Select DHCP is displayed.
5. Specify that the IP address is to be server-assigned, or enter a specific IP address.
 - To specify that the address is to be server-assigned, complete the following steps:
 - a. Press the Next Choice or Previous Choice button to toggle to ON, and press the Select button. The message Set DHCP to ON Now? is displayed.
 - b. Press the select button to confirm.
 - To enter a specific IP address, complete the following steps:
 - a. Press the Next Choice or Previous Choice button to toggle to OFF, and press the Select button. The message Set IP Address is displayed.
 - b. Press the Next Choice or Previous Choice button to scroll through the available characters for each position. Press the Down a Level or Up a Level button to change character positions. When the IP address that you want has been entered, press the Select button. The message Set Subnet Address is displayed.
 - c. Press the Next Choice or Previous Choice button to scroll through the available characters for each position. Press the Down a Level or Up a Level button to change character positions. When the Subnet address that you want has been entered, press the Select button. The message Set Gateway Address is displayed.
 - d. Press the Next Choice or Previous Choice button to scroll through the available characters for each position. Press the Down a Level or Up a Level button to change character positions. When the Gateway address that you want has been entered, press the Select button. The message Set DHCP Off and New IP Address Now? is displayed.
 - e. Press the select button to confirm.
6. Press the Up a Level button until the Home screen is displayed.

Chapter 5. Using the media

The 87691VX Tape Autoloader uses data cartridges with VXA technology for saving and restoring system data. It only supports VXA X tape cartridges. If any other cartridge is inserted in the drive, it will be ejected.

Types of tape cartridges

The 87691VX Tape Autoloader supports the following media cartridges.

Data cartridge Use VXA data cartridges to save or restore programs or data.

Cleaning cartridge

Use a specially labeled cleaning cartridge to clean the 87691VX Tape Autoloader. For instructions for cleaning the 87691VX Tape Autoloader, see “Cleaning the tape drive” on page 36.

Attention: Use of other than IBM-supported VXA cleaning cartridges can damage your 87691VX Tape Autoloader and might void your warranty.

To view a list of supported tape media, complete the following steps:

1. Go to <http://www.ibm.com/systems/support/>.
2. Under **Select a product or service type**, select **Hardware upgrades**.
3. Under **Product family**, select **Tape autoloader**.
4. Under **Type**, select **Tape Autoloader VXA-320**.
5. Click **Go**.
6. Click the **Documentation** tab.
7. Under **Product usage**, click on the **Recommended tape drive media list**.

Guidelines for using tape cartridges

The following guidelines will help to protect your data and prolong the life of your tape cartridges and the 87691VX Tape Autoloader:

- Use only IBM-recommended tape cartridges.
- Remove the tape cartridge from the drive when the drive is not in use.
- Back up and then discard any tape cartridge that repeatedly produces error messages. (The error information is in the system error log.)
- On the tape cartridge, do not open the door that covers the tape. The door protects the tape from dirt, dust, and damage.
- Do not touch the tape. Any substance that is transferred to the tape by touching could cause loss of data.
- To avoid problems with loading and unloading, use only one label on a cartridge. Multiple or poorly placed labels can obstruct the drive load mechanism.
- Do not use poor-quality tape cartridges. They can cause excessive read or write errors, and might damage the tape drive.
- Discard any tape cartridges that are dropped, because the impact might damage the tape internally.
- Make sure that the environment is kept clean and constant. Do not operate the autoloader in a dusty environment, and always maintain a constant environment.

Attention:

1. Use only the recommended cleaning cartridge to clean the tape drive. Use of other than recommended cleaning cartridges can damage your drive and might void the warranty.
 2. Operating the autoloader outside of the recommended environment can result in possible loss of data or failure of the drive.
- Printers and copiers can produce paper and toner dust. Locate the autoloader away from these items. High-traffic areas near hallways and doors can also produce excess dust and dirt.
 - Record all important information on the tape label. Include information such as the model and number of the system or tape drive, the date, the density, any error statistics, and a log number. The operating environment and compression mode should also be noted.

Erasing a tape cartridge

Most bulk eraser devices do not have the capability to erase a tape cartridge. To properly erase a VXA tape cartridge with a bulk eraser device, the erasure coercivity rating must be a minimum of 4000 Oersted.

Storage and shipping tape cartridges

Before using a tape cartridge, let it acclimate to the operating environment by placing the cartridge in the operating environment for as long as it has been away from the environment or for 24 hours, whichever is less. (To determine the appropriate operating environment, see “Specifications” on page 3.)

Acclimation is necessary for any data cartridge that is exposed to a different humidity environment or to temperature changes of 11°C (20°F) or more.

Retrieve archived data on a tape unit that is clean and fully operational. Try to make the recovery environment the same as the operating environment. Let the tapes acclimate to the environment of the tape unit for at least 24 hours.

The recommended environment for storage and shipment of VXA data cartridges is shown in Table 3.

Table 3. Recommended environment for VXA data cartridges

Environmental factor	Storage	Shipping
Temperature	5°C to 32°C (41° to 90°F)	–40 to 52°C (–40 to 125°F)
Relative humidity (noncondensing)	20 to 60%	5 to 80%
Maximum wet bulb	26°C (79°F)	26°C (79°F)

Tape drives record data using densities that are similar to those of hard disk drives. Because most computer systems are not in a dust-free, climate-controlled environment, you must use special care when dealing with tape cartridges and tape drives.

Use the following guidelines for storing tape cartridges:

- Keep temperature and humidity constant at a level that is comfortable for you.
- Store tape cartridges in their protective cases. The storage case helps prevent damage from dust and physical misuse. When the tape cartridges are not in use or being stored, they should be in their storage cases and stood on edge in a designated storage location. Do not stack cartridges on the flat side or stack other items on top of the tape cartridges. Handle your tape cartridges with care to reduce archival problems.
- Keep tape cartridge protective cases closed except when you insert or remove a cartridge. Contamination can build up and be transferred to the tape cartridge if the protective case is left open.
- Exercise stored tapes at least once every 12 months. Run the tape from Beginning of Data (BOD) to End of Data (EOD) and back to BOD at normal operating speeds. Tapes that are stored in a warmer environment should be exercised more frequently.
- Sunlight can damage the tape and the cartridge shell. Store tape cartridges out of the direct sunlight

Operating in harsh environments

Do not use as an archival tape any tape that has been used outside of the operating ranges that are specified in Table 1 on page 3 for an extended period of time. The magnetic and physical strength of the tape will have deteriorated as a result of its exposure to the environment. Do not store important data on such a tape; transfer the data to a newer tape for reliable archiving.

Attention: Do not operate the 87691VX Tape Autoloader in a poor air-quality environment. If your environment contains an excessive amount of particulates, contact your IBM service representative for more information.

Setting the write-protect switch

The position of the write-protect switch on the VXA tape cartridge determines when you can write to the tape (see Figure 16).

- When the switch is set to the left, data can be written to and read from the tape.
- When the switch is set to the right, data can only be read.




Figure 16. Setting the Write-protect switch

Placing the cartridge labels

Use care when you place the cartridge label on a VXA tape cartridge. Use the following guidelines for tape cartridge labels:

- Use only labels that are provided with the cartridge and place them only in the designated locations.
- IBM VXA tape cartridges come with labels adhered to them. Do not adhere a label on top of an existing label. Poorly placed or multiple labels can clog the drive mechanism.
- Place the larger label on the end of the cartridge in the designated area.
- Place the smaller label on the top of the cartridge in the designated area.

Attention: Use only IBM-supported tape cartridges and labels.




Figure 17. Placing the Tape Cartridge Labels

Importing and exporting cartridges in the autoloader

Use the operator panel and menus to import and export (load and unload) tape cartridges in the 87691VX Tape Autoloader. See “Using the operator panel” on page 21 for information about using the operator panel.

Note: To avoid problems with loading and unloading, use only one label in each label location on a cartridge. Multiple or poorly placed labels can obstruct the drive load mechanism.

Importing tape cartridges

To import cartridges, complete the following steps:

1. On the Home screen, press the Down a Level button to access the main menus.
2. Press the **Next** button to scroll through the menus until the *Choose a Command* menu is displayed.
3. Press the Down a Level button once.
4. Press the Next Choice button until the **Import Cartridge** screen is displayed.
5. Press the Select button to display the cell selection display.

6. Press the Next Choice or Previous Choice button to scroll through the available cartridge cells. When the cell number in which you want to install the cartridge is displayed, press the Select button. The autoloader positions the selected cell and the cartridge access door will open.
7. Position the cartridge with the VXA logo up and the side with the bar code label and write-protect switch towards the cartridge access door.




Figure 18. Inserting a tape cartridge

8. Slide the cartridge fully through the access door until it snaps into place in the cartridge cell.
9. Press the Select button. The cartridge access door closes. The autoloader checks for the presence of a cartridge in the specified cell and makes sure that the cartridge is seated correctly. The cell selection screen displays the next available cell number.
10. Continue importing cartridges in the same manner until you have filled as many cells as you want.

Note: If you plan to store a cleaning cartridge in the autoloader, you must store it in cell 10.

11. After you have finished importing cartridges, the autoloader automatically scans the affected cartridge cells to update its cartridge inventory. Press the Up a Level button to return to the **Choose a Command** menu.

Exporting tape cartridges

To remove (export) tape cartridges from the autoloader, complete the following steps:

1. On the Home screen, press the Down a Level button to access the main menus.
2. Press the Next Choice button to scroll through the menus until the **Choose a Command** menu is displayed.
3. Press the Down a Level button once.
4. Press the Next Choice button until the **Export Cartridge** screen is displayed.
5. Press the Select button to display the cell selection screen.
6. Press the Next Choice or Previous Choice button to scroll through the available cartridge cells. When the cell number from which you want to remove the cartridge is displayed, press the Select button. The autoloader positions the selected cell, and the cartridge access door opens.
7. Remove the tape cartridge.

8. Press the Select button. The cartridge access door closes. The autoloader checks for the presence of a cartridge in the specified cell. The cell selection screen displays the next available cell number.
9. Continue exporting cartridges in the same manner until you have removed as many cartridges as you want.
10. After you have finished exporting cartridges, the autoloader automatically scans the affected cartridge cells to update its cartridge inventory. Press the Up a Level button to return to the **Choose a Command** menu.

Loading and unloading cartridges in the tape drive

Use the following instructions to load and unload tape cartridges from the autoloader tape drive.

Note: To avoid problems with loading and unloading, use only one label in each label position on a cartridge. Multiple or poorly placed labels can obstruct the drive load mechanism.

Loading tape cartridges

To load cartridges, complete the following steps:

1. On the Home screen, press the Down a Level button to access the main menus.
2. Press the Next Choice button to scroll through the menus until the **Choose a Command** menu is displayed.
3. Press the Down a Level button once.
4. Press the Next Choice button until the **Load Drive** screen is displayed.
5. Press the Select button to display the cell selection screen.
6. Press the Next Choice or Previous Choice button to scroll through the available cartridge cells. When the cell number from which you want to load the cartridge is displayed, press the Select button. The autoloader positions the selected cell and the cartridge is loaded into the drive. A series of status messages is displayed as the operation proceeds. The **Choose a Command** menu is displayed when the operation is complete.

Unloading tape cartridges

To remove tape cartridges from the autoloader tape drive, complete the following steps:

1. On the Home screen, press the Down a Level button to access the main menus.
2. Press the Next Choice button to scroll through the menus until the **Choose a Command** menu is displayed.
3. Press the Down a Level button once.
4. Press the Next Choice button until the **Unload Cartridge** screen is displayed.
5. Press the Select button to display the cell selection screen.
6. Press the Next Choice or Previous Choice button to scroll through the available cartridge cells. When the cell number into which you want to store the cartridge removed from the drive is displayed, press the Select button. The autoloader positions the selected cell and the drive will unload the cartridge into the cell. A series of status messages is displayed as the operation proceeds. The **Choose a Command** menu is displayed when the operation is complete.

Cleaning the tape drive

Regular cleaning helps maintain optimal performance of the tape drive and maximizes the life of your VXA tape cartridges. The tape drive monitors its cleaning needs internally and notifies the autoloader when it requires cleaning (after approximately every 75 hours of tape motion). The tape drive can also notify your software application when it requires cleaning if your application supports this feature.

You can clean the tape drive in any of the following ways:

- **Use the Autoclean function.** Set up automatic tape drive cleaning when you configure the autoloader, and store a cleaning cartridge in the autoloader. When the tape drive notifies the autoloader that it requires cleaning, the autoloader loads the cleaning cartridge into the tape drive, waits until the cleaning is finished, unloads the cleaning cartridge, returns it to its cell, and resumes normal operation. Enable the autoclean function by using the **Change Autoclean** menu under the **Change Configuration** main menu.
- **Use the Clean Drive option from the operator panel.** Use the **Clean Drive** option and a cleaning cartridge that is stored in the autoloader to clean the tape drive when the autoloader or software notifies you to do so. When you select the **Clean Drive** option, the autoloader loads the cleaning cartridge into the tape drive, waits until the cleaning is finished, unloads the cleaning cartridge, returns it to its cell, and resumes normal operation. For instruction for using this method, see “Cleaning the drive by using the Clean Drive option.”
- **Insert a cleaning cartridge through the Cartridge Access Door.** Use the **Import Cartridge and Load Drive** options to insert a cleaning cartridge and load it into the tape drive when the autoloader or software notifies you to do so. After the cleaning is finished, use the **Unload Cartridge** and **Export Cartridge** options to remove the cleaning cartridge. For instruction for using this method, see “Cleaning the drive by loading a cleaning cartridge” on page 37.

Note: If you are using all 10 cells in the autoloader for data cartridges, you will need to remove a data cartridge to make room for the cleaning cartridge.

Clean the tape drive whenever the autoloader displays the Clean Drive message on the Home screen or whenever your application software notifies you. (Not all software applications display cleaning requirements.)

Cleaning the drive by using the Clean Drive option

Make sure that the following tasks have been completed before you use the **Clean Drive** option:

- Install a cleaning cartridge in cell 10.
- Activate the cleaning cartridge cell, which designates cell 10 as the storage location for the cleaning cartridge.
- Disable the Autoclean function.

To clean the tape drive, complete the following steps:

1. On the Home screen, press the Down a Level button to access the main menus.
2. Press the Next Choice button to scroll through the menus until the **Choose a Command** menu is displayed.
3. Press the Down a Level button once.
4. Press the Next Choice button until the **Clean Drive?** screen is displayed.

5. Press the Select button. The confirmation message Start Cleaning Drive Now? is displayed.

Note: If cell 10 is empty, you are prompted to insert a cleaning cartridge. Follow the instructions to insert a cleaning cartridge. If you have not activated cell 10, an error message is displayed. Activate the cleaning cell and begin the cleaning process again.

6. Press the Select button to begin the cleaning process. When the cleaning operation is completed, the drive ejects the cleaning cartridge, and it is stored in cell 10.
7. Confirm that the cleaning was completed successfully by looking at the operator screen. If there is no message, the cleaning was successful. If the cleaning was not successful, a message that explains the failure is displayed. You might be prompted to insert a new cleaning cartridge.

Attention: Cleaning cartridges can be used for only 20 cleaning procedures. If you attempt to use a depleted cleaning cartridge, the drive detects the error and immediately ejects the cartridge. Do not attempt to rewind the cartridge and reuse it. This can cause debris to be deposited back onto the drive heads, causing damage and errors.

Cleaning the drive by loading a cleaning cartridge

Complete the following steps if you do not want to store a cleaning cartridge in the 87691VX Tape Autoloader.

Note: Before you insert a cleaning cartridge through the cartridge access door, make sure that you have disabled the Autoclean function.

1. If data cartridges are in all 10 cells, use the **Export Cartridge** option to remove a cartridge from the autoloader (see “Exporting tape cartridges” on page 34). Before you press a button to close the door, insert the cleaning cartridge. Then, press the Select button.

Note: If you do not have to export a cartridge to make room for the cleaning cartridge, use the **Import Cartridge** option to insert the cleaning cartridge into the autoloader (see “Importing tape cartridges” on page 33.)

2. On the Home screen, press the Down a Level button to access the main menus.
3. Press the Next Choice button to scroll through the menus until the **Choose a Command** menu is displayed.
4. Press the Down a Level button once.
5. Press the Next Choice button until the **Load Drive** screen is displayed.
6. Press the Select button to display the cell selection screen.
7. Press the Next Choice or Previous Choice button to scroll through the available cartridge cells. When the cell number that contains the cleaning cartridge is displayed, press the Select button. The autoloader positions the selected cell and the cleaning cartridge is loaded into the drive. The tape drive automatically performs the cleaning and ejects the cartridge when the cleaning operation is completed. Confirm that the cleaning completed successfully by looking at the operator screen. If there is no message, the cleaning operation was successful. If the cleaning was not successful, a message that explains the failure is displayed. You might be prompted to insert a new cleaning cartridge.
8. Use the **Unload Drive** option to return the cleaning cartridge to its cell.

9. Use the **Export Cartridge** option to remove the cleaning cartridge from the autoloader. Before you press a button to close the door, insert the data cartridge that you removed previously (if applicable). Then, press the Select button.

Chapter 6. Maintaining the 87691VX Tape Autoloader

This chapter describes autoloader maintenance tasks that you can perform on-site without the aid of a service technician. It also describes troubleshooting procedures to help you solve autoloader problems without service assistance.

Using the repair identification (RID) tag

An RID tag maintains the original serial number record of your 87691VX Tape Autoloader and is used by IBM to entitle the device to future warranty service. If the autoloader is replaced, you must retain the serial number of the original device to use the warranty.

To retain the serial number, complete the following steps:

1. Locate the RID tag that is included in the autoloader CRU package.
2. Read the instructions for the RID tag.
3. Copy the serial number from the original 87691VX Tape Autoloader onto the RID tag.
4. Attach the RID tag to the replacement 87691VX Tape Autoloader in an appropriate location.

Handling static-sensitive devices

Attention: Static electricity can damage the tape drive and other electronic devices. To avoid damage, keep static-sensitive devices in their static-protective packages until you are ready to install them.

To reduce the possibility of damage from electrostatic discharge, observe the following precautions:

- Limit your movement. Movement can cause static electricity to build up around you.
- The use of a grounding system is recommended. For example, wear an electrostatic-discharge wrist strap, if one is available.
- Handle the device carefully, holding it by its edges or its frame.
- Do not touch solder joints, pins, or exposed circuitry.
- Do not leave the device where others can handle and damage it.
- Remove the device from its package and install it directly into the autoloader without setting down the device. If it is necessary to set down the device, put it back into its static-protective package. Do not place the device on the autoloader cover or on a metal surface.
- Take additional care when handling devices during cold weather. Heating reduces indoor humidity and increases static electricity.

Removing tape cartridges manually

If you have to remove cartridges from the autoloader when power is unavailable, either due to a general power failure or a failure of the autoloader power supply, you can operate the cartridge access door manually. The autoloader has a small hole in the front bezel that provides access to a gear shaft attached to the cartridge access door. Using a small Phillips screwdriver, you can turn the gear shaft to open the cartridge access door.

If a cartridge is loaded in the tape drive when power to the autoloader fails and must remove that cartridge, you must remove the tape drive from the autoloader.

Attention: Electrical current from power, telephone, and communication cables is hazardous. See “Safety” on page v for more information.

For security, you can block access to the gear shaft from the hole in the front of the faceplate. A screw that is accessible from the hole in the top of the faceplate (see Figure 19) can be lowered in front of the gear shaft. To lower this screw, use a small Phillips screwdriver to turn the screw clockwise until it blocks access to the gear shaft.

To remove cartridges from the autoloader without power, complete the following steps:

1. Carefully insert a small Phillips screwdriver into the top access hole (see Figure 19) on the top front of the autoloader. Unscrew the security blocking screw.
2. Carefully insert a small Phillips screwdriver into the bottom access hole (see Figure 19) on the front of the autoloader. Make sure that the screwdriver engages the head of the gear shaft.




Figure 19. Access hole locations

3. Turn the gear shaft counterclockwise to open the cartridge access door.
4. When the door is fully open, you can remove cartridges by hand from the autoloader. To move cartridge cells into position in front of the door, gently rotate the cartridge carousel with your fingers.

Reach inside the door and gently rotate the carousel toward the left or right to access tapes in the remaining cells. If the carousel binds or will not move freely, a cartridge might be incorrectly seated in one of the cells. An incorrectly seated cartridge can be resolved only by a service call or a replacement unit.

5. When you are finished removing cartridges from the autoloader, close the cartridge access door by turning the gear shaft clockwise.

Resetting the autoloader

If the autoloader is not operating correctly, you might have to reset it. To reset the autoloader, complete the following steps

1. On the Home screen, press the Down a Level button to access the main menus.
2. Press the Next Choice button to scroll through the menus until the **Perform a Diagnostic** menu is displayed.
3. Press the Down a Level button once.
4. Press the Next Choice button until the **Reset library?** screen is displayed.
5. Press the Select button. The confirmation message Reset the LIBRARY Now? is displayed.
6. Press the Select button to begin the library reset process. The autoloader resets and performs a cartridge inventory. When the process is complete, the Home screen is displayed.

Updating firmware and creating diagnostic logs using FTP

You can use the optional autoloader Ethernet connection and the file transfer protocol (FTP) utility to upgrade the autoloader firmware. You must have the following hardware and software to use this utility:

- A Category 5 (100BaseT connection) data-grade cable
- Software that supports the FTP utility (RFC 959)
- A host system or network connection that uses a pin-through-hole RJ-45 shielded Ethernet connector

Updating the firmware

Before you update the firmware, make sure that the Ethernet cable is connected to the autoloader and that the autoloader Ethernet interface is configured. See Chapter 4, “Connecting the 87691VX Tape Autoloader to an Ethernet network” on page 27 for more information. You must also save the firmware binary file to the directory that contains your FTP utility. The file is available from two sources:

- From the IBM Web site. To download the file, complete the following steps:
 1. Go to <http://www.ibm.com/systems/support/>.
 2. Under **Select a product or service type**, select **Hardware upgrades**.
 3. Under **Product family**, select **Tape autoloader**.
 4. Under **Type**, select **Tape Autoloader VXA-320**.
 5. Click **Go**.
 6. Under **Available downloads and drivers**, click the link for the latest firmware update.
 7. Click the file link for the firmware update to download the file.
 8. Save the binary file to the directory that contains your FTP utility.
- From the IBM *Documentation* CD. Copy the binary file from the Firmware folder on the CD to the directory that contains your FTP utility.

To update the firmware, open the command-line interface and complete the following steps:

1. At the command prompt, type the following command and press Enter:
ftp
2. At the ftp> prompt, type the following command and press Enter:
open

3. At the To prompt, type the IP address (in the format `xxx.xxx.xxx.xxx`) and press Enter.
4. At the User (`xxx.xxx.xxx.xxx:(none)`) prompt, type the following user name and press Enter:
anonymous
5. At the Password required for anonymous prompt, type the following password in uppercase letters and press Enter:
IBM
6. At the User logged in prompt, type the following command and press Enter:
proceed
7. At the ftp> prompt, type the following command and press Enter:
bin
8. At the ftp> prompt, type the following command and press Enter:
ls

The Autoloader firmware file name and the Ethernet module firmware file name are displayed.

9. At the ftp> prompt, type the following command and press Enter:
put `xxxxxx.bin`

where `xxxxxx` is the firmware file name.

Note: The firmware update takes several minutes. When it is complete, the following message is displayed in the command-line interface window:

transfer complete

10. At the ftp> prompt, type the following command and press Enter:
close
11. At the ftp> prompt, type the following command and press Enter:
bye

You can now close the command-line interface window.

Creating diagnostic logs

To create a diagnostic log, complete the following steps:

1. Make sure that the Ethernet cable is connected to the autoloader and that the autoloader is configured. See Chapter 3, “Installing and setting up the 87691VX Tape Autoloader,” on page 15 for more information.
2. From the host system, start the FTP utility.
3. Log on to FTP. The default user name is anonymous, and the default password is IBM. The user name and password are case-sensitive.
4. Make sure that the FTP file transfer type is set to binary.
5. Type `get libdump.bin` and press Enter.

Solving problems

This section provides information for solving problems that might occur when you are installing and operating the autoloader. “Troubleshooting hints” on page 43 provides a list of potential problems and solutions. “Maintenance analysis procedures” on page 44 provides detailed troubleshooting information.

Troubleshooting hints

This section provides a list of problems and suggested solutions. If the information in this section does not solve your problem, see “Maintenance analysis procedures” on page 44.

Installation problems

If the autoloader and application software are not communicating after installation, check the following possible causes:

Power

Make sure that the autoloader power cord is inserted correctly, and that the power switch is on. Make sure that the host computer system is turned on.

SCSI IDs (SCSI autoloader)

Make sure that the SCSI IDs that you selected for the autoloader and tape drive are not the same as the IDs that are used by any other devices on the SCSI bus, including the SCSI adapter.

SCSI connections (SCSI autoloader)

Make sure that you have securely connected the SCSI cables and terminator to the SCSI connectors on the back of the autoloader. Make sure that the SCSI connections to the host computer and other devices on the bus are also secure.

LVD SCSI devices (SCSI autoloader)

Because the autoloader is a low-voltage differential (LVD) device, all other devices on the SCSI bus should also be LVD. These devices include the controller cards, cables, terminators, and any other devices on the bus. Do not mix LVD and high voltage differential (HVD) devices on the same bus.

SCSI cable lengths (SCSI autoloader)

Make sure that the cabling for the SCSI bus that is attached to the autoloader does not exceed the maximum length restriction.

Termination (SCSI autoloader)

Make sure that the SCSI bus is correctly terminated. If another device previously terminated the SCSI bus and is no longer at the physical end of the bus, be sure to remove the terminator from that device.

Compatibility

Make sure that the autoloader and tape drive are compatible with the SCSI adapter and application software that you plan to use.

Host adapter installation

Make sure that your host adapter is correctly installed. See the documentation that came with your adapter for installation and troubleshooting instructions. Pay special attention to instructions for setting various jumpers and switches on the adapter. Make sure that the adapter is correctly seated.

Software installation

Make sure that the application software is installed correctly. (See your software documentation.) Pay special attention to instructions that describe how to configure the software for use with the autoloader and tape drive.

Control mode

Make sure that the control mode is set correctly. Use SCSI mode (the default) with an application that controls the autoloader. Use Sequential mode only if you do not plan to use autoloader software. In Sequential

mode, the autoloader automatically processes cartridges in sequential order without direction from an application.

Autoloader operation problems

If the autoloader has been working correctly, but is now malfunctioning, check the following:

Control mode

If you are using application software to control the autoloader, make sure that the control mode is set to SCSI. Use Sequential mode only if you are not using autoloader software.

Hardware operation

Use the options in the **Diagnostics** menu to check specific autoloader functions.

Firmware level

Make sure that the autoloader and tape drive contain the latest versions of firmware.

Tape drive problems

If the application software and autoloader have been working correctly, but are now having problems reading and writing data, check the following possible causes:

Write-protect switch

If you are writing data, make sure that the cartridge is write-enabled.

Cartridge type

Use the correct cartridges for your tape drive. See Chapter 5, “Using the media,” on page 29 for information about selecting cartridges.

Cartridge age

If the cartridge has been in use for a long time or if it has been used frequently, try using a new cartridge.

Cleaning

Clean the tape drive as described in “Cleaning the tape drive” on page 36.

Maintenance analysis procedures

This section provides step-by-step procedures for isolating problems with the 87691VX Tape Autoloader.

Purpose of the MAPs

Use the maintenance analysis procedures (MAPs) to check the following items:

Power cable	SCSI address	Tape drive
Power supply	SCSI bus (signal) cable	Fan
Terminator	Configuration	Drive head

If a problem is detected, the procedure isolates the problem to the customer replaceable unit (CRU), either the taped drive or the autoloader. For instructions for removing and replacing a CRU, see “Removal and replacement procedures” on page 48.

Step 1: Power and fan

To determine whether the power and the fan are operating correctly, complete the following steps:

Attention: Electrical current from power, telephone, and communication cables is hazardous. See "Safety" on page v for more information.

1. Make sure that the 87691VX Tape Autoloader power cable is connected to an electrical outlet.
2. Make sure that the LCD screen is on and there is air flow from the fan at the rear of the unit.

Is the LCD screen on and is there airflow from the fan?

NO While watching for the LED screen to turn on, turn the power switch off and back on again. Repeat this procedure several times. If the status LED fails to come on or if there is no airflow from the fan, call IBM service.

YES Go to Step 3: Cooling fan.

Step 2: Power cable

This step determines whether the power cable is functional.

Make sure that all of the conductors in the power cable have continuity and that there are no short circuits.

Does the power cable have continuity and are there no short circuits?

NO Replace the power cable.

YES Call IBM service.

Step 3: Cooling fan

If the fan is not operating correctly, the autoloader might be overheating. To check the cooling fan, complete the following steps:

1. Press the power switch to turn off the power.
2. Press the power switch to turn on the power.
3. Observe the cooling fan, which is mounted to the back of the internal chassis. Make sure that the airflow is not impeded and that the fan operates correctly, providing good airflow.

Does the LCD screen turn on and stay on, and is there airflow from the fan?

NO The cooling fan is faulty. Replace the autoloader unit.

YES Go to Step 4: Tape drive.

Step 4: Tape drive

To determine whether the tape drive is the problem, complete the following steps:

1. Press the power switch to turn off the power.
2. Press the power switch to turn on the power.
3. Listen to and observe the installed tape drive. Make sure that it is functioning and not emitting abnormal noises.

Does the drive power-on appear to operate normally?

NO Turn off the 87691VX Tape Autoloader and then replace the drive. See "Replacing the autoloader tape drive" on page 48.

Note: If a cartridge is still in the drive that you are replacing, you can remove it manually. See "Removing tape cartridges manually" on page 40.

YES Go to Step 5: SCSI address.

Step 5: SCSI address

Make sure that the SCSI address setting is correct.

Is the SCSI address set correctly?

NO Set the SCSI address to the correct address and then go to Step 6: External SCSI cable connection. To set the SCSI address, see the instructions in "Step 4. Setting the SCSI address" on page 17.

Note: Turn the power to the 87691VX Tape Autoloader off and then back on again to ensure the SCSI address setting is recognized.

YES Go to Step 6: External SCSI cable connection.

Step 6: External SCSI cable connection

Make sure that the SCSI bus cable is correctly connected to the system unit and to the 87691VX Tape Autoloader.

Is the SCSI bus cable correctly connected to the system unit and to the 87691VX Tape Autoloader?

NO Connect the SCSI bus cable into the system unit and to the 87691VX Tape Autoloader, then go to Step 7: Terminator connection.

YES Go to Step 7: Terminator connection.

Step 7: Terminator connection

Make sure that the terminator is correctly connected to the last device on the SCSI bus.

Is the terminator correctly connected to the last device on the SCSI bus?

NO Connect the terminator to the last device on the SCSI bus, and then go to Step 8: Configuration.

YES Go to Step 8: Configuration.

Step 8: Configuration

Verify that the 87691VX Tape Autoloader has been correctly configured to the host system. For more information, see Chapter 3, "Installing and setting up the 87691VX Tape Autoloader," on page 15.

Is the 87691VX Tape Autoloader correctly configured to the host system?

NO Correct the configuration.

YES Go to Step 9: Diagnostics.

Step 9: Diagnostics

This step runs the diagnostics to determine the problem. Run the diagnostics on the 87691VX Tape Autoloader from the command prompt by entering : diag at the host system command prompt. For additional information about running diagnostics, see your system documentation.

Do all of the diagnostics routines pass?

NO Replace the CRU isolated by the diagnostics and identified by the service request number.

Note: If the tape drive is the CRU that was isolated by the diagnostics, check that the cable on the back of the tape drive is connected correctly. If the drive has recently been replaced because of a similar problem, contact IBM service.

YES If no problem was identified, the problem may be intermittent, related to the tape quality, or relating to the environment. If a CRU was replaced or changed and no more errors occur, the problem is fixed.

Step 10: Operation retry

Clean the tape drive (see "Cleaning the tape drive" on page 36). Then, attempt the failing operation again.

Does the 87691VX Tape Autoloader perform the failing operation correctly?

NO Replace the 87691VX Tape Autoloader.

YES Cleaning the 87691VX Tape Autoloader corrected the problem.

CRU list

This section lists the customer replaceable units (CRUs) that can be replaced.

Table 4.

CRU part number	Description	Tier
39M3640	Tape drive	Tier 1
40K2556	87691VX Tape Autoloader	Tier 1
01K6484	External SCSI cable	Tier 1
35I0145	External SCSI terminator	Tier 1
6952300	US power cord	Tier 1
36L8861	PDU power cord	Tier 1
42C3911	Rack mounting rails	Tier 1

Removal and replacement procedures

If you are instructed to return a device or component, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the autoloader tape drive

This section describes how to replace the autoloader tape drive.

Note: If your autoloader is installed in a rack, it is not necessary to remove the autoloader from the rack to replace the tape drive. It is also not necessary to disconnect the SCSI cable, terminator, or Ethernet cable from the back of the autoloader if they do not interfere with your access to the tape drive.

Removing a tape drive

To remove the tape drive, complete the following steps:

1. Make sure that the environment is free of conditions that could cause electrostatic discharge (ESD). If possible, use an antistatic mat and a grounded static protection wristband during installation. If a mat and wristband are not available, touch a known grounded surface, such as a metal computer chassis.
2. Turn off the autoloader and disconnect the power cord.

Attention: Electrical current from power, telephone, and communication cables is hazardous. See "Safety" on page v for more information.

3. Locate the tape drive cover plate at the back of the autoloader.
4. Using a #1 Phillips screwdriver, remove the two screws that secure the cover plate (see Figure 20 on page 49). Set the cover plate and screws aside.




Figure 20. Removing the tape drive cover plate

5. Disconnect the power cable, SCSI cable, and serial cable from the tape drive. Route the cables downward and away from the sides of the tape drive.




Figure 21. Disconnecting the tape drive cables

6. Pull on the tabs on the tape drive brackets and slide the tape drive out of the autoloader.




Figure 22. Removing the tape drive from the autoloader

7. Using a #1 Phillips screwdriver, remove the two screws from each of the brackets that are attached to the tape drive (see Figure 23 on page 50). Save the brackets and screws. You will attach the brackets to the new tape drive.




Figure 23. Removing the tape drive mounting brackets

Installing a tape drive

To install the tape drive, complete the following steps:

1. If your new tape drive has a bezel attached, remove the bezel before you install the tape drive in the autoloader:

To remove the bezel:

- a. Using a small flat-blade screwdriver, push the bezel side catch tabs on each side of the tape drive inward until they clear the metal tabs attached to the tape drive chassis.
 - b. With the bezel side catch tabs clear of the metal tabs that are on the tape drive chassis, rotate the bottom of the bezel out and up from the front of the drive.
 - c. Disengage the upper tabs from the top of the tape drive chassis and lift the bezel up and away from the drive.
2. Place the tape drive right side up (check the labels on the tape drive). Place the brackets you removed from the original tape drive on the new tape drive and attach them, using the two screws for each bracket.
 3. With the tape drive right side up, slide the tape drive into the autoloader until the bracket flanges rest against the flanges on the autoloader back panel.
 4. Connect the serial cable to the tape drive. The connector is keyed to ensure the correct orientation.

Note: Before you connect the SCSI cable in the following step, make sure that none of the pins on the SCSI cable are bent.

5. Connect the SCSI cable and power cable. The connectors are keyed to ensure the correct orientation.
6. Route the cables into the notch in each bracket, and make sure that the cables do not hang below the tape drive. Make sure that the serial cable is not pinched between the SCSI cable and the side of the notch.
7. Place the tape drive cover plate on the autoloader back panel. Make sure that the cables are not pinched by the cover plate. Insert and tighten the two screws.

Replacing the autoloader

This section describes how to replace the autoloader.

Removing the autoloader

To remove the tape drive, complete the following steps:

1. Make sure that the environment is free of conditions that could cause electrostatic discharge (ESD). If possible, use an antistatic mat and a grounded static protection wristband during installation. If a mat and wristband are not available, touch a known grounded surface, such as a metal computer chassis.

Attention: Electrical current from power, telephone, and communication cables is hazardous. See “Safety” on page v for more information.

2. Turn off the autoloader and disconnect the power cord.
3. Disconnect the SCSI cable, SCSI terminator, and Ethernet cable from the back of the autoloader.
4. Remove the autoloader from the rack.
5. Locate the tape drive cover plate at the back of the autoloader.
6. Using a #1 Phillips screwdriver, remove the two screws securing the cover plate (see Figure 24). Set the cover plate and screws aside.




Figure 24. Removing the tape drive cover plate

7. Disconnect the power cable, SCSI cable, and serial cable from the tape drive. Route the cables downward and away from the sides of the tape drive.




Figure 25. Disconnecting the tape drive cables

8. Pull on the tabs on the tape drive brackets and slide the tape drive out of the autoloader.




Figure 26. Removing the tape drive from the autoloader

Installing the autoloader

To install the autoloader, complete the following steps:

1. With the tape drive right side up, slide the tape drive into the autoloader until the bracket flanges rest against the flanges on the autoloader back panel.
2. Install the autoloader in the rack.
3. Connect the serial cable to the tape drive. The connector is keyed to ensure the correct orientation.

Note: Before you connect the SCSI cable in the following step, make sure that none of the pins on the SCSI cable are bent.

4. Connect the SCSI cable and power cable to the tape drive. The connectors are keyed to ensure the correct orientation.
5. Route the cables into the notch in each bracket, and make sure that the cables do not hang below the tape drive. Make sure that the serial cable is not pinched between the SCSI cable and the side of the notch.
6. Place the tape drive cover plate on the autoloader back panel. Make sure that the cables are not pinched by the cover plate. Insert and tighten the two screws.
7. Connect the SCSI cable, SCSI terminator, Ethernet cable, and power cable to the autoloader.

Manually Removing a Tape Cartridge

This section provides information about manually removing a tape cartridge.

Attention: This procedure might damage your tape cartridge, the 87691VX Tape Autoloader, or both. Use this procedure only after you have attempted the following tasks:

- Eject the cartridge by performing the cartridge unload procedure using the operator panel and display screen menus.
 - Turn the power to the 87691VX Tape Autoloader off and on again to clear potential hang conditions.
 - If available, issue the Unload SCSI command from your system command menu.
 - Disconnect the 87691VX Tape Autoloader from the system, and turn the power to the 87691VX Tape Autoloader on and off again several times.
1. Remove the drive from the 87691VX Tape Autoloader (see “Replacing the autoloader tape drive” on page 48).




Figure 27. Removing the top cover from the drive

2. To remove the top cover of the drive mechanism, complete the following steps:
 - a. Use a small screwdriver to press the top tabs (see Figure 27) on each side of the drive.
 - b. Slide the cover approximately 5 mm to the rear, and then lift off the cover.
3. Locate the large thumb wheel that is located below the right side of the data cartridge.
4. Gently rotate the thumb wheel (see Figure 28 on page 54) counterclockwise to remove slack from the tape by winding the media onto the take-up reel.
5. Insert a Phillips head screwdriver in the load motor access hole (see Figure 28 on page 54). Rotate the load motor clockwise to unwind the tape path. Unwind the mechanism until tape slack appears.




Figure 28. Turning the load motor to release the cartridge

6. Gently rotate the thumb wheel again to remove the slack from the tape by winding the media onto the take-up reel.
7. Repeat steps 5 on page 53 and 6 until all of the tape media is wound onto the cartridge take-up wheel.
8. When the tape is completely rewound into the cartridge, turn the load motor clockwise until the tape cartridge is lifted out of the drive mechanism and ejected.
9. Remove the tape cartridge and attach the top cover.

Chapter 7. Using the Remote Management utility

You can use the Remote Management utility to perform the following tasks:

- View information about the autoloader
- Configure the autoloader and Ethernet connection (see “Setting configuration options” on page 57)
- View autoloader statistics (see “Viewing statistics” on page 60)
- Run diagnostics (see “Running diagnostics” on page 60)

To access the Remote Management Utility, complete the following steps:

1. Make sure that the autoloader is connected to an Ethernet network, and that it is correctly configured.
2. Make sure that the autoloader is turned on.
3. Open a Web browser and enter the IP address of the autoloader in the following format: `http://IPADDRESS`. The Remote Management Utility home page is displayed.

The Remote Management Utility home page displays information in the following sections:

- Library information
- Library status (see Table 6)
- Tape drive status (see Table 7 on page 56)
- Inventory information (see Table 8 on page 56)

Note: The term *library* is synonymous with the term autoloader.

Table 5 provides a description of the information that is provided in the library information section.

Table 5. Library information

Information	Description
Vendor	Indicates the vendor identification value of the autoloader and tape drive.
Product	Indicates the product identification value of the autoloader and tape drive.
Serial number	Indicates the serial number of the autoloader of the autoloader and tape drive.
Firmware revision	Indicates the firmware level of the autoloader and tape drive.
SCSI ID	Indicates the SCSI ID of the autoloader and tape drive.

Table 6 provides a description of the information that is provided in the Library Status information section.

Table 6. Library status information

Information	Description
Robot control mode	Indicates the current operating mode of the autoloader. (random or sequential)

Table 6. Library status information (continued)

Information	Description
Door open sensor	Indicates the current reading of the door open sensor of the cartridge access door: <ul style="list-style-type: none"> • 1: Door completely open • 0: Door not completely open
Door closed sensor	Indicates the current reading of the door closed sensor of the cartridge access door. <ul style="list-style-type: none"> • 1: Door completely closed • 0: Door not completely closed
Library temperature	Indicates whether the internal temperature of the autoloader is within the normal operating temperature range.
Front door status	Indicates whether the front door is locked by an application.
Language	Indicates the current language that is being used on the LCD screen.
Auto clean	Indicates whether the automatic cleaning function is on or off.
Clean tape installed	Indicates whether a cleaning tape is installed in cell 10.
LCD	Indicates the current message that is displayed on the LCD screen.
Motion	Indicates whether the autoloader is in motion.

Table 7 provides a description of the information that is provided in the Tape Drive Status section.

Table 7. Tape drive status information

Information	Description
Index	Indicates the element index of the tape drive. Element indexes identify locations within the autoloader that can accept cartridges.
Status	Indicates whether tape motion is occurring. Possible values are active and inactive.

The inventory section provides an inventory of tape cartridges that tracks where tape cartridges are located in the autoloader. An inventory is performed each time one of the following events occurs

- The autoloader is turned on.
- A tape cartridge is inserted into the autoloader
- A tape cartridge is removed from the autoloader
- A tape cartridge is loaded in the tape drive
- A tape cartridge is unloaded from the tape drive

Table 8 provides a description of the information that is provided by the Inventory section.

Table 8. Inventory information

Information	Description
Index	Index specifies the element index number of the following autoloader components. Autoloader components that can accept tape cartridges are called elements. The following element index information is provided: <ul style="list-style-type: none"> • The slot index number. Possible values are 1 - 10. • The tape drive index number. This value is always 82. • The robot element index. This value is always 86.

Table 8. Inventory information (continued)

Information	Description
What	Indicates the type of element. Possible values are slot, tape drive, or robot.
P (present)	Indicates whether the element is present. <ul style="list-style-type: none"> • 1: Present • 0: Not present
O (occupied)	Indicates whether the element contains a tape cartridge: <ul style="list-style-type: none"> • 1: Contains a tape cartridge • 0: Does not contain a cartridge
V (valid)	Indicates whether the information is considered valid or not valid: <ul style="list-style-type: none"> • 1: The information is valid. • 0: The information is not valid. <p>Note: The information is considered not valid for the time after the autoloader has been turned on until it has completed an initial tape cartridge inventory.</p>
A (accessible)	Indicates whether the element is accessible: <ul style="list-style-type: none"> • 1: The element is accessible. • 0: The element is not accessible. <p>Notes:</p> <ol style="list-style-type: none"> 1. The value for the cartridge cell element is always 1. 2. For the tape drive the value 1 means that the tape drive is either empty or a cartridge has been ejected. The value 0 means that a tape cartridge is loaded in the tape drive.
R (reserved)	Indicates whether the element is reserved by a host system: <ul style="list-style-type: none"> • 1: The element is reserved. • 0: The element is not reserved.
Label valid	Indicates whether the bar code label information is considered valid or not valid: <ul style="list-style-type: none"> • 1: The information is valid. • 0: The information is not valid. <p>Note: The information is considered questionable if the autoloader had a problem reading the label.</p>
Label	If the element contains a tape cartridge, the field provides the bar code label information for the tape cartridge.

Setting configuration options

Configuration options can be set using either the operator panel or the Remote Management Utility. For information about using the operator panel to set configuration options, see Chapter 4, “Using the 87691VX Tape Autoloader,” on page 21.

You can use the Configuration page to perform the following tasks:

- Change the library configuration
- Change the Ethernet configuration
- Change the Web access password

To specify or change a configuration value, specify or change the value and click **Update**.

To access the Configuration page, click **Configuration**. To return to the Status page, click **Status**.

The Configuration page displays information in the following sections:

- Change Library Configuration
- Change Ethernet Configuration (see Table 10 on page 59)
- Change Web Access Password (see “Changing the Web access password” on page 59)

Changing the library configuration

Table 9 provides a description of the information that can be viewed and changed in the library configuration section.

Table 9. Library configuration information

Information	Description
Library SCSI ID	Indicates the SCSI ID of the library. Specify a value that meets the needs of your installation.
Drive SCSI ID	Indicates the SCSI ID of the tape drive. Specify a value that meets the needs of your installation.
New Control Mode	Indicates the control mode of the autoloader: <ul style="list-style-type: none"> • SCSI: This option cannot be selected. • LCD: This option cannot be selected. • Sequential: Indicates that you want the autoloader to process the cartridges sequentially without input from a control program. Sequential mode has the following sub-options: <ul style="list-style-type: none"> – Random: Indicates that you want the autoloader to randomly select tapes under the control of your autoloader control program. – Sequential: Indicates that you want the autoloader to use the tapes sequentially.
<ul style="list-style-type: none"> • New Front Panel Access Password • Confirm New Access Password • Current® Access Password 	Access to the operator panel functions can be controlled with a password. Use these fields to specify, change, or cancel the operator panel password: <ul style="list-style-type: none"> • To create a new password, type the new password in the New Front Panel Access Password and Confirm New Access Password field. • To change a password, type the new password in the New Front Panel Access Password and Confirm New Access Password, and type the current password in the Current Access password field. • To cancel a password, type the current password in the Current Access Password field.
Emulation Mode	Specify an emulation mode if your autoloader control program has not been certified. Select one of the following emulation modes: <ul style="list-style-type: none"> • Exabyte AutoPak 1x10 autoloader • EZ17 autoloader • 210 library
Language	Indicates that language that is displayed on the LCD screen. The default language is English.
<ul style="list-style-type: none"> • Fixed Cleaning Spot Enabled • Autoclean On 	Indicates whether you want to use the autoclean mode. To use the autoclean mode, select both the Fixed Cleaning Spot Enabled and the Autoclean On fields.

Table 9. Library configuration information (continued)

Information	Description
Cleanings Remaining	Indicates the number of time the cleaning cartridge can be used. Discard the cleaning cartridge when 0 is displayed.

Changing the Ethernet configuration

Table 10 provides a description of the information that can be viewed and changed in the Ethernet configuration section.

Table 10. Ethernet configuration information

Information	Description
IP Address	Indicates the IP address if static addressing is being used. If DHCP is be used, 0 is specified.
Subnet Mask	Indicates the subnet mask if static addressing is being used. If DHCP is be used, 0 is specified.
Gateway	Indicates the gateway address if static addressing is being used. If DHCP is be used, 0 is specified.
DHCP Assigned Address	Indicates the DHCP-assigned IP address if DHCP Is being used. If static addressing is used, 0 is specified.
FTP User Name	Indicates the FTP user name. The default value is anonymous.
FTP User Password	Indicates the FTP user password. The default value is Exabyte. The password is case sensitive.
E-Mail Server Address	Indicates the e-mail server address that you want to send E-mail alerts to.
E-Mail Server User Name	Indicates the e-mail user that you want to send e-mail alerts to.
E-mail Address	Indicates the e-mail address of the e-mail address that you want to send E-mail alerts to.
E-mail Server Sender	Indicates the text that you want displayed in the e-mail "From" field.
Web Access Password	If you have specified that a password must be used when changes are made to the configuration page, type the password in this field. See Table 11 on page 60 for more information.

Changing the Web access password

Web access passwords are used to control who can change the autoloader configuration values using the configuration page. Passwords can be from 1 to 6 characters and can contain spaces. The password is not case-sensitive.

Table 11 on page 60 provides a description of the information that is provided in the Web Access Password section.

Table 11. Web access password information

Information	Description
Current Web Access Password	Specify the current Web access password if you want to change the existing Web access password. To cancel a password, specify only the current Web access password. Do not specify the New Web Access Password or the Confirm New Web Access Password.
New Web Access Password	Specify a new password if you want to create an initial password or change the existing Web access password.
Confirm New Web Access Password	Specify the new password to confirm that you want to create an initial password or change the existing password.

Viewing statistics

The Statistics page provides statistical information about the autoloader. To access the Statistics page, click **Statistics**.

Table 12 provides a description of the information that can be specified in the Statistics section.

Table 12. Statistics information

Information	Description
Move Count	Indicates the number of moves the autoloader has made. A <i>move</i> is when a tape cartridge is either removed from a tape cartridge cell and placed in the tape drive, or removed from the tape drive and placed in the tape cartridge cell.
Pick Retry Counts	Indicates the number of times the tape cartridge loader has tried removing a tape cartridge from either a tape cartridge cell or the tape drive.
Put Retry Counts	Indicates the number of times the tape cartridge loader has tried to place a tape cartridge in either a tape cartridge cell or the tape drive.
Scan Count	Indicates the number of times the bar code scanner has scanned a bar code label.
Scan Retry Count	Indicates the number of times the bar code scanner has tried to scan a bar code.
Scan Fail Count	Indicates the number of times the bar code scanner has failed to scan a bar code.
Drive Load Count	Indicates the number of time the tape cartridge loader has placed a tape cartridge in the tape drive.
Drive Reload Count	Indicates the number of time the tape cartridge loader has tried to place a tape cartridge in the tape drive.

Running diagnostics

You can run diagnostics to determine the state of the autoloader. The diagnostics rotate the tape carousel to each tape cartridge position. If a tape is installed, the tape is placed in the tape drive and then removed. When the diagnostics are complete, the Diagnostics Results page is displayed.

To run the diagnostics, complete the following steps:

1. Click **Diagnostics**. The Library Diagnostics window opens.
2. Click **Run Test**.

Appendix A. Error messages

This section provides information about error messages on the LCD screen. The following information is provided for each message:

- The error message
- A description of the problem that caused the error message
- The corrective action for the error message

Some corrective actions advise you to reset power or turn the autoloader off and then on. Read the following information to avoid problems:

- To avoid disrupting communication between the host system and other devices on the communication bus, make sure that there is no activity on the communication bus before you turn off the autoloader.
- Unload the tape from the tape drive before you turn off the autoloader. If you turn off the autoloader with a tape loaded in the tape drive, the tape drive might have to perform a format recovery process that can take 2 - 3 hours.

Table 13 provides an alphabetical list of the error messages. If the corrective action does not resolve the problem, contact IBM service.

Table 13.

Message	Description	Corrective action
BOOTBLOCK	An error occurred while firmware was being uploaded to the autoloader.	Verify that you loaded the correct firmware. Do not load firmware from one model of autoloader or library into another autoloader. Reset the autoloader and reload the firmware. See "Resetting the autoloader" on page 41 for more information.
CELL MISLOADED MUST REMOVE TAPE (followed by: REMOVE TAPE AND PRESS ANY KEY)	The autoloader displays this message after it has exported a cartridge and you have not removed it from the autoloader.	Remove the exported cartridge and press any key to continue.
CELL MISLOADED REINSERT TAPE	A tape was inserted through the cartridge access port in the wrong orientation.	Position the cartridge as shown in Figure 18 on page 34.
CHOICE REJECTED DRIVE IS FULL	A command was issued from the operator panel to load a cartridge into the tape drive when the tape drive already contained a cartridge.	Wait until the current cartridge is unloaded by the application, or use the operator panel to unload it from the tape drive. See "Loading and unloading cartridges in the tape drive" on page 35 for more information.

Table 13. (continued)

Message	Description	Corrective action
COMMAND FAILED CHECK SHIP LOCK	The cartridge loader could not move. This might be caused by the shipping key.	Remove the shipping key. See “Removing the shipping key” on page 7 for more information.
COMMAND REJECTED CAROUSEL FULL	A command was issued from the operator panel to insert a cartridge into the autoloader when all of the cartridge cells were already full.	Export a cartridge from the autoloader to make room for a new cartridge. See “Importing and exporting cartridges in the autoloader” on page 33 for more information.
COMMAND REJECTED EMPTY CAROUSEL	A command was issued from the operator panel to either load a tape cartridge into the tape drive or remove a tape cartridge from the autoloader when there were no tape cartridges in the cartridge carousel.	Wait until the cartridge is ejected from the tape drive, or use the operator panel to import cartridges into the autoloader. See “Loading and unloading cartridges in the tape drive” on page 35 for more information.
CONFIGURATION LOCKED BY HOST	The application is currently controlling the autoloader (a SCSI command is active) or the Remote Management utility is controlling the autoloader.	Wait for the command from the application to complete.
DEMO ILLEGAL IN SEQUENTIAL MODE	The autoloader displays this message when you attempt to run the demo from the Selftest menu while the autoloader is set to Sequential mode.	Change the autoloader from sequential mode to random mode and continue your operation.
DEVICE NOT READY	The autoloader is not ready to perform the requested operation because it is performing diagnostics or a power-on self-test (POST).	Wait until the autoloader has finished, then retry the operation.
DRIVE CMD ERROR	The tape drive received an invalid command.	Turn the autoloader off and then on to reset the tape drive.
DRIVE LOAD FAIL	The cartridge could not be loaded into the tape drive because of a mechanical problem or because of a broken tape	Export the tape from the autoloader and verify that it is in good condition. Retry the operation. See “Importing and exporting cartridges in the autoloader” on page 33 for more information.
DRIVE TIMEOUT	The tape drive took too long to load or unload a tape, or the tape drive is not responding.	Turn the autoloader off and on to reset the tape drive.

Table 13. (continued)

Message	Description	Corrective action
DRV UNLOAD FAIL	The cartridge could not be unloaded from the tape drive because of a mechanical problem.	Power the autoloader off and on to reset the tape drive. Retry the operation.
HARDWARE ERROR	An operation could not be completed because of a mechanical problem.	Reset the autoloader and retry the operation. See "Resetting the autoloader" on page 41 for more information.
H/W INOPERABLE	An operation could not be completed because of a mechanical problem.	Reset the autoloader and retry the operation. See "Resetting the autoloader" on page 41 for more information.
IN ENET MODE	The autoloader is executing a command issued from the Remote Management utility when a command is issued from the operator panel.	Wait until the autoloader has finished its current operation, then retry the operation.
IN SECURITY MODE CHOICE REJECTED	Autoloader security has been set from the application.	Disable autoloader security from the application.
INSERT A NEW CLEANING CART	The cleaning cartridge has reached the end of its useful life.	Insert a new cleaning cartridge and press any key to continue the operation.
LIBRARY IS BUSY	The autoloader is executing a command issued from the application when a command is issued from the operator panel.	Wait until the autoloader has finished its current operation, then retry the requested operation.
LIBRARY IS EMPTY NO BAR CODES	The autoloader displays this message when it is in the cell information menu and there are no cartridges loaded in the autoloader.	No recovery action is needed. Load a data cartridge to perform a write and read or tape drive cleaning operation.
MEDIA REMOVAL IS LOCKED BY HOST	Media removal from the autoloader has been prevented by the application.	Turn off media removal prevention from the application.
OVER TEMPERATURE	The temperature limit of the tape drive has been exceeded, and the cartridge has been ejected from the tape drive.	Wait until the autoloader has cooled. Unload the cartridge to a cell and reload it into the tape drive. Check the room temperature. The ambient temperature must be no more than 40°C (104°F).
POST FAILED	The autoloader encountered an error during its power-on self-test.	Reset the autoloader. See "Resetting the autoloader" on page 41 for more information.

Table 13. (continued)

Message	Description	Corrective action
POST ILLEGAL IN SEQUENTIAL MODE	The autoloader displays this message if you attempt to run the power-on self-test from the Selftest menu while the autoloader is in sequential mode.	Change the autoloader from sequential mode to random mode and continue your operation.
REMOVE TAPE AND PRESS ANY KEY	This message is displayed after the CELL MISLOADED MUST REMOVE TAPE message.	Remove the tape cartridge and press any key to continue.
SEQUENTIAL MODE	An application tried to issue commands to the autoloader while it was in Sequential mode.	Set the autoloader to Random mode.
SERVO ERROR	There is a problem with the autoloader carousel.	Reset the autoloader (see page 79) and retry the operation. See "Resetting the autoloader" on page 41 for more information.
SERVO TIMEOUT	There is a problem with the autoloader carousel.	Reset the autoloader (see page 79) and retry the operation. See "Resetting the autoloader" on page 41 for more information.
SYSTEM ERROR	There is a problem with the autoloader.	Reset the autoloader and retry the operation. See "Resetting the autoloader" on page 41 for more information.
SYSTEM TIMEOUT	An autoloader operation took too long.	Reset the autoloader and retry the operation. See "Resetting the autoloader" on page 41 for more information.
WAIT FOR COMMAND TO COMPLETE	The autoloader is executing a command issued from the application or the Remote Management utility when a command is issued from the operator panel.	Wait until the autoloader has finished its current operation, then retry the operation.

Appendix B. Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A.*

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product, and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Trademarks

IBM, the IBM logo, and ibm.com are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. If these and other IBM trademarked terms are marked on their first occurrence in this information with a trademark symbol ([®] or [™]), these symbols indicate U.S. registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common

law trademarks in other countries. A current list of IBM trademarks is available on the Web at "Copyright and trademark information" at <http://www.ibm.com/legal/copytrade.shtml>.

Adobe and PostScript are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Cell Broadband Engine is a trademark of Sony Computer Entertainment, Inc., in the United States, other countries, or both and is used under license therefrom.

Intel, Intel Xeon, Itanium, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Java and all Java-based trademarks are trademarks of Sun Microsystems, Inc., in the United States, other countries, or both.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Other company, product, or service names may be trademarks or service marks of others.

Important notes

Processor speed indicates the internal clock speed of the microprocessor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1024 bytes, MB stands for 1 048 576 bytes, and GB stands for 1 073 741 824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1 000 000 bytes, and GB stands for 1 000 000 000 bytes. Total user-accessible capacity can vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard disk drive bays with the largest currently supported drives that are available from IBM.

Maximum memory might require replacement of the standard memory with an optional memory module.

IBM makes no representation or warranties regarding non-IBM products and services that are ServerProven[®], including but not limited to the implied warranties of merchantability and fitness for a particular purpose. These products are offered and warranted solely by third parties.


IBM makes no representations or warranties with respect to non-IBM products. Support (if any) for the non-IBM products is provided by the third party, not IBM.

Some software might differ from its retail version (if available) and might not include user manuals or all program functionality.

Product recycling and disposal

This unit must be recycled or discarded according to applicable local and national regulations. IBM encourages owners of information technology (IT) equipment to responsibly recycle their equipment when it is no longer needed. IBM offers a variety of product return programs and services in several countries to assist equipment owners in recycling their IT products. Information on IBM product recycling offerings can be found on IBM's Internet site at <http://www.ibm.com/ibm/environment/products/index.shtml>.

Esta unidad debe reciclarse o desecharse de acuerdo con lo establecido en la normativa nacional o local aplicable. IBM recomienda a los propietarios de equipos de tecnología de la información (TI) que reciclen responsablemente sus equipos cuando éstos ya no les sean útiles. IBM dispone de una serie de programas y servicios de devolución de productos en varios países, a fin de ayudar a los propietarios de equipos a reciclar sus productos de TI. Se puede encontrar información sobre las ofertas de reciclado de productos de IBM en el sitio web de IBM <http://www.ibm.com/ibm/environment/products/index.shtml>.



Notice: This mark applies only to countries within the European Union (EU) and Norway.

This appliance is labeled in accordance with European Directive 2002/96/EC concerning waste electrical and electronic equipment (WEEE). The Directive determines the framework for the return and recycling of used appliances as applicable throughout the European Union. This label is applied to various products to indicate that the product is not to be thrown away, but rather reclaimed upon end of life per this Directive.

注意: このマークは EU 諸国およびノルウェーにおいてのみ適用されます。

この機器には、EU 諸国に対する廃電気電子機器指令 2002/96/EC(WEEE) のラベルが貼られています。この指令は、EU 諸国に適用する使用済み機器の回収とリサイクルの骨子を定めています。このラベルは、使用済みになった時に指令に従って適正な処理をする必要があることを知らせるために種々の製品に貼られています。

Remarque : Cette marque s'applique uniquement aux pays de l'Union Européenne et à la Norvège.

L'étiquette du système respecte la Directive européenne 2002/96/EC en matière de Déchets des Equipements Electriques et Electroniques (DEEE), qui détermine les dispositions de retour et de recyclage applicables aux systèmes utilisés à travers

l'Union européenne. Conformément à la directive, ladite étiquette précise que le produit sur lequel elle est apposée ne doit pas être jeté mais être récupéré en fin de vie.

In accordance with the European WEEE Directive, electrical and electronic equipment (EEE) is to be collected separately and to be reused, recycled, or recovered at end of life. Users of EEE with the WEEE marking per Annex IV of the WEEE Directive, as shown above, must not dispose of end of life EEE as unsorted municipal waste, but use the collection framework available to customers for the return, recycling, and recovery of WEEE. Customer participation is important to minimize any potential effects of EEE on the environment and human health due to the potential presence of hazardous substances in EEE. For proper collection and treatment, contact your local IBM representative.

Battery return program


This product may contain a sealed lead acid, nickel cadmium, nickel metal hydride, lithium, or lithium ion battery. Consult your user manual or service manual for specific battery information. The battery must be recycled or disposed of properly. Recycling facilities may not be available in your area. For information on disposal of batteries outside the United States, go to <http://www.ibm.com/ibm/environment/products/index.shtml> or contact your local waste disposal facility.

In the United States, IBM has established a return process for reuse, recycling, or proper disposal of used IBM sealed lead acid, nickel cadmium, nickel metal hydride, and battery packs from IBM equipment. For information on proper disposal of these batteries, contact IBM at 1-800-426-4333. Have the IBM part number listed on the battery available prior to your call.

For Taiwan: Please recycle batteries.



For the European Union:



Notice: This mark applies only to countries within the European Union (EU).

Batteries or packaging for batteries are labeled in accordance with European Directive 2006/66/EC concerning batteries and accumulators and waste batteries and accumulators. The Directive determines the framework for the return and

recycling of used batteries and accumulators as applicable throughout the European Union. This label is applied to various batteries to indicate that the battery is not to be thrown away, but rather reclaimed upon end of life per this Directive.

Les batteries ou emballages pour batteries sont étiquetés conformément aux directives européennes 2006/66/EC, norme relative aux batteries et accumulateurs en usage et aux batteries et accumulateurs usés. Les directives déterminent la marche à suivre en vigueur dans l'Union Européenne pour le retour et le recyclage des batteries et accumulateurs usés. Cette étiquette est appliquée sur diverses batteries pour indiquer que la batterie ne doit pas être mise au rebut mais plutôt récupérée en fin de cycle de vie selon cette norme.

バッテリーあるいはバッテリー用のパッケージには、EU 諸国に対する廃電気電子機器指令 2006/66/EC のラベルが貼られています。この指令は、バッテリーと蓄電池、および廃棄バッテリーと蓄電池に関するものです。この指令は、使用済みバッテリーと蓄電池の回収とリサイクルの骨子を定めているもので、EU 諸国にわたって適用されます。このラベルは、使用済みになったときに指令に従って適正な処理をする必要があることを知らせるために種々のバッテリーに貼られています。

In accordance with the European Directive 2006/66/EC, batteries and accumulators are labeled to indicate that they are to be collected separately and recycled at end of life. The label on the battery may also include a chemical symbol for the metal concerned in the battery (Pb for lead, Hg for mercury, and Cd for cadmium). Users of batteries and accumulators must not dispose of batteries and accumulators as unsorted municipal waste, but use the collection framework available to customers for the return, recycling, and treatment of batteries and accumulators. Customer participation is important to minimize any potential effects of batteries and accumulators on the environment and human health due to the potential presence of hazardous substances. For proper collection and treatment, contact your local IBM representative.

This notice is provided in accordance with Royal Decree 106/2008 of Spain: The retail price of batteries, accumulators, and power cells includes the cost of the environmental management of their waste.

For California:

Perchlorate material – special handling may apply. See <http://www.dtsc.ca.gov/hazardouswaste/perchlorate/>.

The foregoing notice is provided in accordance with California Code of Regulations Title 22, Division 4.5 Chapter 33. Best Management Practices for Perchlorate Materials. This product/part may include a lithium manganese dioxide battery which contains a perchlorate substance.

Electronic emission notices

Federal Communications Commission (FCC) statement

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio

communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Industry Canada Class A emission compliance statement

This Class A digital apparatus complies with Canadian ICES-003.

Avis de conformité à la réglementation d'Industrie Canada

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Australia and New Zealand Class A statement

Attention: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

United Kingdom telecommunications safety requirement

Notice to Customers

This apparatus is approved under approval number NS/G/1234/J/100003 for indirect connection to public telecommunication systems in the United Kingdom.

European Union EMC Directive conformance statement

This product is in conformity with the protection requirements of EU Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a nonrecommended modification of the product, including the fitting of non-IBM option cards.

This product has been tested and found to comply with the limits for Class A Information Technology Equipment according to CISPR 22/European Standard EN 55022. The limits for Class A equipment were derived for commercial and industrial environments to provide reasonable protection against interference with licensed communication equipment.

Attention: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

European Community contact:

IBM Technical Regulations

Pascalstr. 100, Stuttgart, Germany 70569

Telephone: 0049 (0)711 785 1176
Fax: 0049 (0)711 785 1283
E-mail: tjahn@de.ibm.com

Taiwanese Class A warning statement

警告使用者：
這是甲類的資訊產品，在
居住的環境中使用時，可
能會造成射頻干擾，在這
種情況下，使用者會被要
求採取某些適當的對策。

Chinese Class A warning statement

聲 明
此為 A 級產品。在生活環境中，
該產品可能會造成無線電干擾。
在這種情況下，可能需要用戶對其
干擾採取切实可行的措施。

Japanese Voluntary Control Council for Interference (VCCI) statement

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に
基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を
引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求
されることがあります。

Korean Class A warning statement

이기기는 업무용으로 전자파 적합등록을 받은 기기
이오니, 판매자 또는 사용자는 이점을 주의하시기
바라며, 만약 잘못 구입하셨을 때에는 구입한 곳에
서 비업무용으로 교환하시기 바랍니다.

Appendix C. IBM Statement of Limited Warranty Z125-4753-09 08/2006

Part 1 - General Terms

This Statement of Limited Warranty includes Part 1 - General Terms, Part 2 - Country-unique Terms, and Part 3 - Warranty Information. The terms of Part 2 replace or modify those of Part 1.

The warranties provided by IBM in this Statement of Limited Warranty apply only to Machines you purchase for your use, and not for resale. The term "Machine" means an IBM machine, its features, conversions, upgrades, elements, or accessories, or any combination of them. The term "Machine" does not include any software programs, whether pre-loaded with the Machine, installed subsequently or otherwise. **NOTHING IN THIS STATEMENT OF LIMITED WARRANTY AFFECTS ANY STATUTORY RIGHTS OF CONSUMERS THAT CANNOT BE WAIVED OR LIMITED BY CONTRACT.**

This Statement of Limited Warranty is available, in multiple languages, at the following IBM Internet website: http://www.ibm.com/servers/support/machine_warranties/.

What this Warranty Covers

IBM warrants that each Machine is free from defects in materials and workmanship and conforms to its Specifications. "Specifications" is information specific to a Machine in a document entitled "Official Published Specifications" which is available upon request.

During the warranty period, IBM provides repair and exchange service for the Machine under the type of warranty service IBM designates for the Machine. The warranty period for the Machine is a fixed period starting on its original Date of Installation. The date on your purchase invoice or sales receipt is the Date of Installation unless IBM or your reseller informs you otherwise. The warranty period, type of warranty, and service level that apply to your Machine are designated in Part 3.

Many features, conversions, or upgrades involve the removal of parts and their return to IBM. An IBM part that replaces a removed part will assume the warranty service status of the removed part. An IBM part that is added to a Machine without replacing a previously-installed part is subject to warranty effective on its Date of Installation. Unless IBM specifies otherwise, the warranty period, type of warranty, and service level of such part is the same as the Machine on which it is installed.

Unless IBM specifies otherwise, these warranties apply only in the country or region in which you purchased the Machine.

THESE WARRANTIES ARE YOUR EXCLUSIVE WARRANTIES AND REPLACE ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME STATES OR JURISDICTIONS DO NOT ALLOW THE

EXCLUSION OF EXPRESS OR IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU. IN THAT EVENT, SUCH WARRANTIES ARE LIMITED IN DURATION TO THE WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD. SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

What this Warranty Does not Cover

This warranty does not cover the following:

1. failure or damage resulting from misuse (including but not limited to use of any Machine capacity or capability, other than that authorized by IBM in writing), accident, modification, unsuitable physical or operating environment, or improper maintenance by you;
2. failure caused by a product for which IBM is not responsible;
3. any non-IBM Products, including those provided with, or installed on, an IBM Machine at your request;
4. accessories, supply items and consumables (e.g. batteries and printer cartridges), and structural parts (e.g. frames and covers);
5. service of Machine alterations; and
6. service of a Machine on which you are using capacity or capability, other than that authorized by IBM in writing.

The warranty is voided by removal or alteration of identification labels on the Machine or its parts.

IBM does not warrant uninterrupted or error-free operation of a Machine.

Any technical or other support provided for a Machine under warranty, such as assistance with "how-to" questions and those regarding Machine set-up and installation, is provided **WITHOUT WARRANTIES OF ANY KIND**.

How to Obtain Warranty Service

If the Machine does not function as warranted during the warranty period, contact IBM or your reseller to obtain warranty service. Contact information for IBM is provided in Part 3. If you do not register the Machine with IBM, you may be required to present proof of purchase as evidence of your entitlement to warranty service.

What IBM Will Do to Correct Problems

IBM will attempt to diagnose and resolve your problem over the telephone or electronically by access to an IBM Internet website. Certain Machines contain remote support capabilities for direct problem reporting, remote problem determination and resolution with IBM. When you contact IBM for service, you must follow the problem determination and resolution procedures that IBM specifies. Following problem determination, if IBM determines on-site service is required, a service technician will be scheduled for service at your location.

You are responsible for downloading or obtaining from IBM, and installing designated Machine Code (microcode, basic input/output system code (called "BIOS"), utility programs, device drivers, and diagnostics delivered with an IBM

Machine) and other software updates in a timely manner from an IBM Internet website or from other electronic media, and following the instructions that IBM provides. You may request IBM to install Machine Code changes, however, you may be charged for that service.

Some parts of IBM Machines are designated as Customer Replaceable Units ("CRUs"). If your problem can be resolved with a CRU (e.g., keyboard, memory, hard disk drive), IBM will ship the CRU to you for you to install.

If the Machine does not function as warranted during the warranty period and your problem cannot be resolved over the telephone or electronically, through your application of Machine Code or software updates, or with a CRU, IBM or its subcontractor or a reseller that has been approved by IBM to provide warranty service, will either, at its discretion, 1) repair it to make it function as warranted, or 2) replace it with one that is at least functionally equivalent. If IBM or its subcontractor or the reseller is unable to do either, you may return the Machine to your place of purchase and your money will be refunded.

IBM or its subcontractor or the reseller will also manage and install selected engineering changes that apply to the Machine.

Exchange of a Machine or Part

When the warranty service involves the exchange of a Machine or part, the item IBM or its subcontractor or the reseller replaces becomes IBM's property and the replacement becomes yours. You represent that all removed items are genuine and unaltered. The replacement may not be new, but will be in good working order and at least functionally equivalent to the item replaced. The replacement assumes the warranty service status of the replaced item.

Your Additional Responsibilities

You agree:

1. before IBM or its subcontractor or the reseller exchanges a Machine or part, to remove all features, parts, options, alterations, and attachments not under warranty service and ensure that the Machine is free of any legal obligations or restrictions that prevent its exchange;
2. to obtain authorization from the owner to have IBM or its subcontractor or the reseller service a Machine that you do not own;
3. where applicable, before service is provided:
 - a. follow the service request procedures that IBM or its subcontractor or its reseller provides;
 - b. backup and secure all programs, data, and funds contained in the Machine; and
 - c. inform IBM or its subcontractor or the reseller of changes in the Machine's location;
4. to provide IBM or its subcontractor or the reseller with sufficient and safe access to your facilities to permit IBM to fulfill its obligations;
5. to allow IBM or its subcontractor or the reseller to install mandatory engineering changes, such as those required for safety;
6. when the type of warranty service requires that you deliver a failing Machine to IBM, you agree to ship it suitably packaged, as IBM specifies, to a location IBM designates. After the Machine has been repaired or exchanged, IBM will return the repaired Machine or provide a replacement Machine to you at its expense, unless IBM specifies otherwise. IBM is responsible for loss of, or

- damage to, your Machine only while it is 1) in IBM's possession or 2) in transit in those cases where IBM is responsible for the transportation charges; and
7. to securely erase from any Machine you return to IBM for any reason all programs not provided by IBM with the Machine, and data, including without limitation the following: 1) information about identified or identifiable individuals or legal entities ("Personal Data") and 2) your confidential or proprietary information and other data. If removing or deleting Personal Data is not possible, you agree to transform such information (e.g., by making it anonymous or encrypting it) so that it no longer qualifies as Personal Data under applicable law. You also agree to remove all funds from Machines returned to IBM. IBM is not responsible for any funds, programs not provided by IBM with the Machine, or data contained in a Machine that you return to IBM. You acknowledge that, to perform its responsibilities under this Statement of Limited Warranty, IBM may ship all or part of the Machine or its software to other IBM or third party locations around the world, and you authorize IBM to do so.

Limitation of Liability

Circumstances may arise where, because of a default on IBM's part or other liability, you are entitled to recover damages from IBM. In each such instance, regardless of the basis on which you are entitled to claim damages from IBM (including fundamental breach, negligence, misrepresentation, or other contract or tort claim), except for any liability that cannot be waived or limited by applicable laws, IBM is liable for no more than:

1. damages for bodily injury (including death) and damage to real property and tangible personal property; and
2. the amount of any other actual direct damages, up to the charges (if recurring, 12 months' charges apply) for the Machine that is subject of the claim. For purposes of this item, the term "Machine" includes Machine Code and Licensed Internal Code ("LIC").

This limit also applies to IBM's suppliers, subcontractors, and resellers. It is the maximum for which IBM and its suppliers, subcontractors and resellers are collectively responsible.

UNDER NO CIRCUMSTANCES IS IBM OR ITS SUPPLIERS, SUBCONTRACTORS, OR RESELLERS LIABLE FOR ANY OF THE FOLLOWING EVEN IF INFORMED OF THEIR POSSIBILITY: 1) THIRD PARTY CLAIMS AGAINST YOU FOR DAMAGES (OTHER THAN THOSE UNDER THE FIRST ITEM LISTED ABOVE); 2) LOSS OF, OR DAMAGE TO, DATA; 3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES; OR 4) LOST PROFITS, BUSINESS REVENUE, GOODWILL OR ANTICIPATED SAVINGS. SOME STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

Governing Law

Both you and IBM consent to the application of the laws of the country in which you acquired the Machine to govern, interpret, and enforce all of your and IBM's rights, duties, and obligations arising from, or relating in any manner to, the subject matter of this Statement of Limited Warranty, without regard to conflict of law principles.

THESE WARRANTIES GIVE YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE OR JURISDICTION TO JURISDICTION.

Jurisdiction

All of our rights, duties, and obligations are subject to the courts of the country in which you acquired the Machine.

Part 2 - Country-unique Terms

AMERICAS

Jurisdiction: *The following sentence is added to this section as it applies to countries in bold print below:*

Any litigation arising from this Statement of Limited Warranty will be settled exclusively by 1) in **Argentina**; the Ordinary Commercial Court of the city of Buenos Aires; 2) in **Bolivia**; the courts of the city of La Paz; 3) in **Brazil**; court of Rio de Janeiro, RJ; 4) in **Chile**; the Civil Courts of Justice of Santiago; 5) in **Colombia**; the Judges of the Republic of Colombia; 6) in **Ecuador**; the civil judges of Quito for executory or summary proceedings (as applicable); 7) in **Mexico**; the courts located in Mexico City, Federal District; 8) in **Paraguay**; the courts of the city of Asuncion; 9) in **Peru**; the judges and tribunals of the judicial district of Lima, Cercado; 10) in **Uruguay**; the courts of the city of Montevideo; 11) in **Venezuela**; the courts of the metropolitan area of the city of Caracas.

BRAZIL

Exchange of a Machine or Part: *Delete the last sentence:*

The replacement assumes the warranty service status of the replaced item.

CANADA

What this Warranty Covers: *The following replaces the 2nd paragraph to this section:*

During the warranty period, IBM provides repair and exchange service for the Machine under the type of warranty service IBM designates for the Machine. The warranty period for the Machine is a fixed period starting on its original Date of Installation. The date on your purchase invoice or sales receipt is the Date of Installation unless IBM informs you otherwise. The warranty period, type of warranty, and service level that apply to your Machine are designated in Part 3.

Limitation of Liability: *The following replaces item 1 and item 2 of this section:*

1. damages for bodily injury (including death) or physical harm to real property and tangible personal property caused by IBM's negligence; and
2. the amount of any other actual direct damages, up to the greater of \$100,000.00 or the charges (if recurring, 12 months' charges apply) for the Machine that is subject of the claim. For purposes of this item, the term "Machine" includes Machine Code and Licensed Internal Code ("LIC").

Governing Law: *The following replaces "laws of the country in which you acquired the Machine" in the first sentence:*

laws in the Province of Ontario.

PERU

Limitation of Liability: *The following is added at the end of this section:*

In accordance with Article 1328 of the Peruvian Civil Code the limitations and exclusions specified in this section will not apply to damages caused by IBM's willful misconduct ("dolo") or gross negligence ("culpa inexcusable").

UNITED STATES

Governing Law: *The following replaces "laws of the country in which you acquired the Machine" in the first sentence:*

laws of the State of New York

ASIA PACIFIC

AUSTRALIA

What this Warranty Covers: *The following paragraph is added to this section:*

The warranties specified in this Section are in addition to any rights you may have under the Trade Practices Act 1974 or other similar legislation and are only limited to the extent permitted by the applicable legislation.

Limitation of Liability: *The following is added to this section:*

Where IBM is in breach of a condition or warranty implied by the Trade Practices Act 1974 or other similar legislation, IBM's liability is limited to the repair or replacement of the goods or the supply of equivalent goods. Where that condition or warranty relates to right to sell, quiet possession or clear title, or the goods are of a kind ordinarily acquired for personal, domestic or household use or consumption, then none of the limitations in this paragraph apply.

Governing Law: *The following replaces "laws of the country in which you acquired the Machine" in the first sentence:*

laws of the State or Territory

CAMBODIA AND LAOS

Governing Law: *The following replaces "laws of the country in which you acquired the Machine" in the first sentence:*

laws of the State of New York, United States of America

CAMBODIA, INDONESIA, AND LAOS

Arbitration: *The following is added under this heading:*

Disputes arising out of or in connection with this Statement of Limited Warranty shall be finally settled by arbitration which shall be held in Singapore in accordance with the Arbitration Rules of Singapore International Arbitration Center

("SIAC Rules") then in effect. The arbitration award shall be final and binding for the parties without appeal and shall be in writing and set forth the findings of fact and the conclusions of law.

The number of arbitrators shall be three, with each side to the dispute being entitled to appoint one arbitrator. The two arbitrators appointed by the parties shall appoint a third arbitrator who shall act as chairman of the proceedings. Vacancies in the post of chairman shall be filled by the president of the SIAC. Other vacancies shall be filled by the respective nominating party. Proceedings shall continue from the stage they were at when the vacancy occurred.

If one of the parties refuses or otherwise fails to appoint an arbitrator within 30 days of the date the other party appoints its, the first appointed arbitrator shall be the sole arbitrator, provided that the arbitrator was validly and properly appointed.

All proceedings shall be conducted, including all documents presented in such proceedings, in the English language. The English language version of this Statement of Limited Warranty prevails over any other language version.

HONG KONG S.A.R.

As applies to transactions initiated and performed in Hong Kong S.A.R., phrases throughout this Agreement containing the word "country" (for example, "country of purchase" and "country of Installation") are replaced with "Hong Kong S.A.R."

INDIA

Limitation of Liability: *The following replaces items 1 and 2 of this section:*

1. liability for bodily injury (including death) or damage to real property and tangible personal property will be limited to that caused by IBM's negligence; and
2. as to any other actual damage arising in any situation involving nonperformance by IBM pursuant to, or in any way related to the subject of this Statement of Limited Warranty, the charge paid by you for the individual Machine that is the subject of the claim. For purposes of this item, the term "Machine" includes Machine Code and Licensed Internal Code ("LIC").

Arbitration: *The following is added under this heading:*

Disputes arising out of or in connection with this Statement of Limited Warranty shall be finally settled by arbitration which shall be held in Bangalore, India in accordance with the laws of India then in effect. The arbitration award shall be final and binding for the parties without appeal and shall be in writing and set forth the findings of fact and the conclusions of law.

The number of arbitrators shall be three, with each side to the dispute being entitled to appoint one arbitrator. The two arbitrators appointed by the parties shall appoint a third arbitrator who shall act as chairman of the proceedings. Vacancies in the post of chairman shall be filled by the president of the Bar Council of India. Other vacancies shall be filled by the respective nominating party. Proceedings shall continue from the stage they were at when the vacancy occurred.

If one of the parties refuses or otherwise fails to appoint an arbitrator within 30 days of the date the other party appoints its, the first appointed arbitrator shall be the sole arbitrator, provided that the arbitrator was validly and properly appointed.

All proceedings shall be conducted, including all documents presented in such proceedings, in the English language. The English language version of this Statement of Limited Warranty prevails over any other language version.

JAPAN

Governing Law: *The following sentence is added to this section:*

Any doubts concerning this Statement of Limited Warranty will be initially resolved between us in good faith and in accordance with the principle of mutual trust.

MACAU S.A.R.

As applies to transactions initiated and performed in Macau S.A.R., phrases throughout this Agreement containing the word “country” (for example, “country of purchase” and “country of Installation”) are replaced with “Macau S.A.R.”

MALAYSIA

Limitation of Liability: *The word “SPECIAL” in item 3 of the fifth paragraph is deleted.*

NEW ZEALAND

What this Warranty Covers: *The following paragraph is added to this section:*

The warranties specified in this section are in addition to any rights you may have under the Consumer Guarantees Act 1993 or other legislation which cannot be excluded or limited. The Consumer Guarantees Act 1993 will not apply in respect of any goods which IBM provides, if you require the goods for the purposes of a business as defined in that Act.

Limitation of Liability: *The following is added to this section:*

Where Machines are not acquired for the purposes of a business as defined in the Consumer Guarantees Act 1993, the limitations in this Section are subject to the limitations in that Act.

PEOPLE’S REPUBLIC OF CHINA (PRC)

Governing Law: *The following replaces “laws of the country in which you acquired the Machine” in the first sentence:*

laws of the State of New York, United States of America (except when local law requires otherwise).

PHILIPPINES

Limitation of Liability: *Item 3 in the fifth paragraph is replaced by the following:*

SPECIAL (INCLUDING NOMINAL AND EXEMPLARY DAMAGES), MORAL, INCIDENTAL, OR INDIRECT DAMAGES FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES; OR

Arbitration: *The following is added under this heading:*

Disputes arising out of or in connection with this Statement of Limited Warranty shall be finally settled by arbitration which shall be held in Metro Manila, Philippines in accordance with the laws of the Philippines then in effect. The arbitration award shall be final and binding for the parties without appeal and shall be in writing and set forth the findings of fact and the conclusions of law.

The number of arbitrators shall be three, with each side to the dispute being entitled to appoint one arbitrator. The two arbitrators appointed by the parties shall appoint a third arbitrator who shall act as chairman of the proceedings. Vacancies in the post of chairman shall be filled by the president of the Philippine Dispute Resolution Center, Inc. Other vacancies shall be filled by the respective nominating party. Proceedings shall continue from the stage they were at when the vacancy occurred.

If one of the parties refuses or otherwise fails to appoint an arbitrator within 30 days of the date the other party appoints its, the first appointed arbitrator shall be the sole arbitrator, provided that the arbitrator was validly and properly appointed.

All proceedings shall be conducted, including all documents presented in such proceedings, in the English language. The English language version of this Statement of Limited Warranty prevails over any other language version.

SINGAPORE

Limitation of Liability: *The words “SPECIAL” and “ECONOMIC” in item 3 in the fifth paragraph are deleted.*

EUROPE, MIDDLE EAST, AFRICA (EMEA)

THE FOLLOWING TERMS APPLY TO ALL EMEA COUNTRIES:

The terms of this Statement of Limited Warranty apply to Machines purchased from IBM or an IBM reseller.

How to Obtain Warranty Service:

*Add the following paragraph in **Western Europe** (Andorra, Austria, Belgium, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Liechtenstein, Lithuania, Luxembourg, Malta, Monaco, Netherlands, Norway, Poland, Portugal, San Marino, Slovakia, Slovenia, Spain, Sweden, Switzerland, United Kingdom, Vatican State, and any country subsequently added to the European Union, as from the date of accession):*

The warranty for Machines acquired in Western Europe shall be valid and applicable in all Western Europe countries provided the Machines have been announced and made available in such countries.

If you purchase a Machine in one of the Western European countries, as defined above, you may obtain warranty service for that Machine in any of those countries

from either (1) an IBM reseller approved to perform warranty service or (2) from IBM, provided the Machine has been announced and made available by IBM in the country in which you wish to obtain service.

If you purchase a Machine in a Middle East or African country, you may obtain warranty service for that Machine from the IBM entity within the country of purchase, if that IBM entity provides warranty service in that country, or from an IBM reseller, approved by IBM to perform warranty service on that Machine in that country. Warranty service in Africa is available within 50 kilometers of an IBM approved service provider. You are responsible for transportation costs for Machines located outside 50 kilometers of an IBM approved service provider.

Governing Law: *The phrase “the laws of the country in which you acquired the Machine” is replaced by:*

1) “the laws of Austria” in **Albania, Armenia, Azerbaijan, Belarus, Bosnia-Herzegovina, Bulgaria, Croatia, Georgia, Hungary, Kazakhstan, Kyrgyzstan, FYR Macedonia, Moldova, Montenegro, Poland, Romania, Russia, Serbia, Slovakia, Slovenia, Tajikistan, Turkmenistan, Ukraine, and Uzbekistan;** 2) “the laws of France” in **Algeria, Benin, Burkina Faso, Cameroon, Central African Republic, Chad, Comoros, Congo Republic, Djibouti, Democratic Republic of Congo, Equatorial Guinea, French Guiana, French Polynesia, Gabon, Gambia, Guinea, Guinea-Bissau, Ivory Coast, Lebanon, Libya, Madagascar, Mali, Mauritania, Mauritius, Mayotte, Morocco, New Caledonia, Niger, Reunion, Senegal, Seychelles, Togo, Tunisia, Vanuatu, and Wallis & Futuna;** 3) “the laws of Finland” in **Estonia, Latvia, and Lithuania;** 4) “the laws of England” in **Angola, Bahrain, Botswana, Burundi, Egypt, Eritrea, Ethiopia, Ghana, Jordan, Kenya, Kuwait, Liberia, Malawi, Malta, Mozambique, Nigeria, Oman, Pakistan, Qatar, Rwanda, Sao Tome, Saudi Arabia, Sierra Leone, Somalia, Tanzania, Uganda, United Arab Emirates, the United Kingdom, West Bank/Gaza, Yemen, Zambia, and Zimbabwe;** and 5) “the laws of South Africa” in **South Africa, Namibia, Lesotho and Swaziland.**

Jurisdiction: *The following exceptions are added to this section:*

1) **In Austria** the choice of jurisdiction for all disputes arising out of this Statement of Limited Warranty and relating thereto, including its existence, will be the competent court of law in Vienna, Austria (Inner-City); 2) **in Angola, Bahrain, Botswana, Burundi, Egypt, Eritrea, Ethiopia, Ghana, Jordan, Kenya, Kuwait, Liberia, Malawi, Malta, Mozambique, Nigeria, Oman, Pakistan, Qatar, Rwanda, Sao Tome, Saudi Arabia, Sierra Leone, Somalia, Tanzania, Uganda, United Arab Emirates, United Kingdom, West Bank/Gaza, Yemen, Zambia, and Zimbabwe** all disputes arising out of this Statement of Limited Warranty or related to its execution, including summary proceedings, will be submitted to the exclusive jurisdiction of the English courts; 3) **in Belgium and Luxembourg**, all disputes arising out of this Statement of Limited Warranty or related to its interpretation or its execution, the law, and the courts of the capital city, of the country of your registered office and/or commercial site location only are competent; 4) **in France, Algeria, Benin, Burkina Faso, Cameroon, Central African Republic, Chad, Comoros, Congo Republic, Djibouti, Democratic Republic of Congo, Equatorial Guinea, French Guiana, French Polynesia, Gabon, Gambia, Guinea, Guinea-Bissau, Ivory Coast, Lebanon, Libya, Madagascar, Mali, Mauritania, Mauritius, Mayotte, Morocco, New Caledonia, Niger, Reunion, Senegal, Seychelles, Togo, Tunisia, Vanuatu, and Wallis & Futuna** all disputes arising out of this Statement of Limited Warranty or related to its violation or execution, including summary proceedings, will be settled exclusively by the Commercial

Court of Paris; 5) **in South Africa, Namibia, Lesotho and Swaziland**, both of us agree to submit all disputes relating to this Statement of Limited Warranty to the jurisdiction of the High Court in Johannesburg; 6) **in Turkey** all disputes arising out of or in connection with this Statement of Limited Warranty shall be resolved by the Istanbul Central (Sultanahmet) Courts and Execution Directorates of Istanbul, the Republic of Turkey; 7) in each of the following specified countries, any legal claim arising out of this Statement of Limited Warranty will be brought before, and settled exclusively by, the competent court of a) Athens for **Greece**, b) Tel Aviv-Jaffa for **Israel**, c) Milan for **Italy**, d) Lisbon for **Portugal**, and e) Madrid for **Spain**; and 8) **in the United Kingdom**, both of us agree to submit all disputes relating to this Statement of Limited Warranty to the jurisdiction of the English courts.

Arbitration: *The following is added under this heading:*

In Albania, Armenia, Azerbaijan, Belarus, Bosnia-Herzegovina, Bulgaria, Croatia, Georgia, Hungary, Kazakhstan, Kyrgyzstan, Libya, FYR Macedonia, Moldova, Montenegro, Poland, Romania, Russia, Serbia, Slovakia, Slovenia, Tajikistan, Turkmenistan, Ukraine, and Uzbekistan all disputes arising out of this Statement of Limited Warranty or related to its violation, termination or nullity will be finally settled under the Rules of Arbitration and Conciliation of the International Arbitral Center of the Federal Economic Chamber in Vienna (Vienna Rules) by three arbitrators appointed in accordance with these rules. The arbitration will be held in Vienna, Austria, and the official language of the proceedings will be English. The decision of the arbitrators will be final and binding upon both parties. Therefore, pursuant to paragraph 598 (2) of the Austrian Code of Civil Procedure, the parties expressly waive the application of paragraph 595 (1) figure 7 of the Code. IBM may, however, institute proceedings in a competent court in the country of installation.

In Estonia, Latvia and Lithuania all disputes arising in connection with this Statement of Limited Warranty will be finally settled in arbitration that will be held in Helsinki, Finland in accordance with the arbitration laws of Finland then in effect. Each party will appoint one arbitrator. The arbitrators will then jointly appoint the chairman. If arbitrators cannot agree on the chairman, then the Central Chamber of Commerce in Helsinki will appoint the chairman.

EUROPEAN UNION (EU)

THE FOLLOWING TERMS APPLY TO ALL EU COUNTRIES:

The warranty for Machines acquired in EU countries is valid and applicable in all EU countries provided the Machines have been announced and made available in such countries.

DENMARK, FINLAND, GREECE, ITALY, NETHERLANDS, NORWAY, PORTUGAL, SPAIN, SWEDEN AND SWITZERLAND

Limitation of Liability: *The following replaces the terms of this section in its entirety:*

Except as otherwise provided by mandatory law:

1. IBM's liability for any damages and losses that may arise as a consequence of the fulfillment of its obligations under or in connection with this Statement of Limited Warranty or due to any other cause related to this Statement of Limited Warranty is limited to the compensation of only those damages and losses proved and actually arising as an immediate and direct consequence of

the non-fulfillment of such obligations (if IBM is at fault) or of such cause, for a maximum amount equal to the charges you paid for the Machine. For purposes of this item, the term "Machine" includes Machine Code and Licensed Internal Code ("LIC").

The above limitation shall not apply to damages for bodily injuries (including death) and damages to real property and tangible personal property for which IBM is legally liable.

2. **UNDER NO CIRCUMSTANCES IS IBM, OR ITS SUPPLIERS, SUBCONTRACTORS, OR RESELLERS LIABLE FOR ANY OF THE FOLLOWING, EVEN IF INFORMED OF THEIR POSSIBILITY: 1) LOSS OF, OR DAMAGE TO, DATA; 2) INCIDENTAL OR INDIRECT DAMAGES, OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES; 3) LOST PROFITS, EVEN IF THEY ARISE AS AN IMMEDIATE CONSEQUENCE OF THE EVENT THAT GENERATED THE DAMAGES; OR 4) LOSS OF BUSINESS, REVENUE, GOODWILL, OR ANTICIPATED SAVINGS.**

FRANCE AND BELGIUM

Limitation of Liability: *The following replaces the terms of this section in its entirety:*

Except as otherwise provided by mandatory law:

1. IBM's liability for any damages and losses that may arise as a consequence of the fulfillment of its obligations under or in connection with this Statement of Limited Warranty is limited to the compensation of only those damages and losses proved and actually arising as an immediate and direct consequence of the non-fulfillment of such obligations (if IBM is at fault), for a maximum amount equal to the charges you paid for the Machine that has caused the damages. For purposes of this item, the term "Machine" includes Machine Code and Licensed Internal Code ("LIC").

The above limitation shall not apply to damages for bodily injuries (including death) and damages to real property and tangible personal property for which IBM is legally liable.

2. **UNDER NO CIRCUMSTANCES IS IBM, OR ITS SUPPLIERS, SUBCONTRACTORS, OR RESELLERS LIABLE FOR ANY OF THE FOLLOWING, EVEN IF INFORMED OF THEIR POSSIBILITY: 1) LOSS OF, OR DAMAGE TO, DATA; 2) INCIDENTAL OR INDIRECT DAMAGES, OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES; 3) LOST PROFITS, EVEN IF THEY ARISE AS AN IMMEDIATE CONSEQUENCE OF THE EVENT THAT GENERATED THE DAMAGES; OR 4) LOSS OF BUSINESS, REVENUE, GOODWILL, OR ANTICIPATED SAVINGS.**

THE FOLLOWING TERMS APPLY TO THE COUNTRY SPECIFIED:

AUSTRIA AND GERMANY

What this Warranty Covers: *The following replaces the first sentence of the first paragraph of this section:*

The warranty for an IBM Machine covers the functionality of the Machine for its normal use and the Machine's conformity to its Specifications.

The following paragraphs are added to this section:

The minimum warranty period for Machines is twelve months. In case IBM or your reseller is unable to repair an IBM Machine, you can alternatively ask for a

price reduction as far as justified by the reduced value of the unrepaired Machine or ask for a cancellation of the respective agreement for such Machine and get your money refunded.

The second paragraph does not apply.

What IBM Will Do to Correct Problems: *The following is added to this section:*

During the warranty period, transportation for delivery of the failing Machine to IBM will be at IBM's expense.

Limitation of Liability: *The following paragraph is added to this section:*

The limitations and exclusions specified in the Statement of Limited Warranty will not apply to damages caused by IBM with fraud or gross negligence and for express warranty.

The following sentence is added to the end of item 2:

IBM's liability under this item is limited to the violation of essential contractual terms in cases of ordinary negligence.

IRELAND

What this Warranty Covers: *The following is added to this section:*

Except as expressly provided in these terms and conditions or Section 12 of the Sale of Goods Act 1893 as amended by the Sale of Goods and Supply of Services Act, 1980 ("the 1980 Act"), all conditions or warranties (express or implied, statutory or otherwise) are hereby excluded including, without limitation, any warranties implied by the Sale of Goods Act 1893 as amended by the 1980 Act (including, for the avoidance of doubt, section 39 of the 1980 Act).

Limitation of Liability: *The following replaces the terms of this section in its entirety:*

For the purposes of this section, a "Default" means any act, statement, omission, or negligence on the part of IBM in connection with, or in relation to, the subject matter of this Statement of Limited Warranty in respect of which IBM is legally liable to you, whether in contract or tort. A number of Defaults which together result in, or contribute to, substantially the same loss or damage will be treated as one Default occurring on the date of occurrence of the last such Default.

Circumstances may arise where, because of a Default, you are entitled to recover damages from IBM.

This section sets out the extent of IBM's liability and your sole remedy.

1. IBM will accept unlimited liability for death or personal injury caused by the negligence of IBM.
2. Subject always to the **Items for Which IBM is Not Liable** below, IBM will accept unlimited liability for physical damage to your tangible property resulting from the negligence of IBM.
3. Except as provided in items 1 and 2 above, IBM's entire liability for actual damages for any one Default will not in any event exceed the greater of 1) EUR 125,000, or 2) 125% of the amount you paid for the Machine directly relating to the Default.

Items for Which IBM is Not Liable

Save with respect to any liability referred to in item 1 above, under no circumstances is IBM, its suppliers or resellers liable for any of the following, even if IBM or they were informed of the possibility of such losses:

1. loss of, or damage to, data;
2. special, indirect, or consequential loss; or
3. loss of profits, business, revenue, goodwill, or anticipated savings.

SOUTH AFRICA, NAMIBIA, BOTSWANA, LESOTHO AND SWAZILAND

Limitation of Liability: *The following is added to this section:*

IBM's entire liability to you for actual damages arising in all situations involving nonperformance by IBM in respect of the subject matter of this Statement of Warranty will be limited to the charge paid by you for the individual Machine that is the subject of your claim from IBM.

SWITZERLAND

Your Additional Responsibilities: *The following sentence is added to this section:*

Personal Data also includes information about you as a legal entity.

TURKEY

What this Warranty Covers: *The following is added to this section:*

The minimum warranty period for Machines is 2 years.

UNITED KINGDOM

Limitation of Liability: *The following replaces the terms of this section in its entirety:*

For the purposes of this section, a "Default" means any act, statement, omission, or negligence on the part of IBM in connection with, or in relation to, the subject matter of this Statement of Limited Warranty in respect of which IBM is legally liable to you, whether in contract or tort. A number of Defaults which together result in, or contribute to, substantially the same loss or damage will be treated as one Default.

Circumstances may arise where, because of a Default, you are entitled to recover damages from IBM.

This section sets out the extent of IBM's liability and your sole remedy.

1. IBM will accept unlimited liability for:
 - a. death or personal injury caused by the negligence of IBM; and
 - b. any breach of its obligations implied by Section 12 of the Sale of Goods Act 1979 or Section 2 of the Supply of Goods and Services Act 1982, or any statutory modification or re-enactment of either such Section.
2. IBM will accept unlimited liability, subject always to the **Items for Which IBM is Not Liable** below, for physical damage to your tangible property resulting from the negligence of IBM.
3. IBM's entire liability for actual damages for any one Default will not in any event, except as provided in items 1 and 2 above, exceed the greater of 1)

Pounds Sterling 75,000, or 2) 125% of the total purchase price payable or the charges for the Machine directly relating to the Default.

These limits also apply to IBM's suppliers and resellers. They state the maximum for which IBM and such suppliers and resellers are collectively responsible.

Items for Which IBM is Not Liable

Save with respect to any liability referred to in item 1 above, under no circumstances is IBM or any of its suppliers or resellers liable for any of the following, even if IBM or they were informed of the possibility of such losses:

1. loss of, or damage to, data;
2. special, indirect, or consequential loss;
3. loss of profits, business, revenue, goodwill, or anticipated savings; or
4. third party claims against you for damages.

Part 3 - Warranty Information

87691VX Tape Autoloader

Country or Region of Purchase	Warranty Period	Type of Warranty Service*	Service Level*
Worldwide	3 years	1	Not applicable
* See "Types of Warranty Service" and "Service Levels" for explanations of warranty-service types and service levels.			

Scheduling of a warranty service will depend upon the following: 1) the time your request for service is received, 2) Machine technology, and 3) availability of parts. Contact your local IBM representative or the subcontractor or reseller performing services on behalf of IBM for country and location specific information.

Types of Warranty Service

1. Customer Replaceable Unit ("CRU") Service

IBM provides replacement CRUs to you for you to install. CRU information and replacement instructions are shipped with your Machine and are available from IBM at any time on your request. CRUs are designated as being either Tier 1 or a Tier 2 CRU. Installation of Tier 1 CRUs is your responsibility. If IBM installs a Tier 1 CRU at your request, you will be charged for the installation. You may install a Tier 2 CRU yourself or request IBM to install it, at no additional charge, under the type of warranty service designated for your Machine. IBM specifies in the materials shipped with a replacement CRU whether a defective CRU must be returned to IBM. When return is required, 1) return instructions and a container are shipped with the replacement CRU, and 2) you may be charged for the replacement CRU if IBM does not receive the defective CRU within 15 days of your receipt of the replacement.

2. On-site Service

IBM or your reseller will either repair or exchange the failing Machine at your location and verify its operation. You must provide suitable working area to allow disassembly and reassembly of the IBM Machine. The area must be clean, well lit and suitable for the purpose. For some Machines, certain repairs may require sending the Machine to an IBM service center.

3. Courier or Depot Service

You will disconnect the failing Machine for collection arranged by IBM. IBM will provide you with a shipping container for you to return your Machine to a designated service center. A courier will pick up your Machine and deliver it to the designated service center. Following its repair or exchange, IBM will arrange the return delivery of the Machine to your location. You are responsible for its installation and verification.

4. Customer Carry-In or Mail-In Service

You will deliver or mail as IBM specifies (prepaid unless IBM specifies otherwise) the failing Machine suitably packaged to a location IBM designates. After IBM has repaired or exchanged the Machine, IBM will make it available for your collection or, for Mail-in Service, IBM will return it to you at IBM's expense, unless IBM specifies otherwise. You are responsible for the subsequent installation of the Machine and verification of its operation.

5. CRU and On-site Service*

This type of Warranty Service is a combination of Type 1 and Type 2 (see above).

6. CRU and Courier or Depot Service*

This type of Warranty Service is a combination of Type 1 and Type 3 (see above).

7. CRU and Customer Carry-In or Mail-In Service*

This type of Warranty Service is a combination of Type 1 and Type 4 (see above).

8. Machine Exchange Service

IBM will initiate shipment of a replacement Machine to your location. You are responsible for its installation and verification of its operation. You must pack the failing Machine into the shipping container that contained the replacement Machine and return the failing Machine to IBM. Transportation charges, both ways, are paid by IBM. You may be charged for the replacement Machine if IBM does not receive the failing Machine within 15 days of your receipt of the replacement Machine.

(*) When a 5, 6, or 7 type of warranty service is listed, IBM will determine which type of warranty service is appropriate for the repair.

Service Levels

Service levels specified below are response-time objectives only and are not guarantees. The specified service level may not be available in all worldwide locations. Charges may apply outside IBM's normal service area. Certain Machines with a Same Day On-site response-time objective may require the installation and use of remote connectivity tools and equipment for direct problem reporting, remote problem determination and resolution.

1. Next Business Day (NBD), 9X5

After we receive your call, following problem determination, if IBM determines on-site service is required, a service technician will be scheduled to arrive at your location on the next business day. Service will be provided from 8:00 a.m. to 5:00 p.m. in your local time zone, Monday through Friday, excluding holidays.

2. Same Business Day (SBD), 9X5

After we receive your call, following problem determination, if IBM determines on-site service is required, a service technician will be scheduled to arrive at your location within four hours. Service will be provided from 8:00 a.m. to 5:00

p.m. in your local time zone, Monday through Friday, excluding local IBM holidays. If after 1:00 p.m. it is determined that on-site service is required, a service technician will be scheduled to arrive the morning of the following business day.

3. Same Day (SD), 24X7

After we receive your call, following problem determination, if IBM determines on-site service is required, a service technician will be scheduled to arrive at your location within four hours. This type of service will be provided 24 hours a day, every day, including holidays.

IBM Contact Information

For IBM in Canada or the United States, call 1-800-IBM-SERV (or 1-800-426-7378). For IBM in the European Union (EU), Asia Pacific, and Latin America countries, contact IBM in that country or visit the following IBM Internet website:
http://www.ibm.com/servers/support/machine_warranties/.

Index

A

- address
 - Ethernet 28
- autoclean option 36
- autoloader
 - change Ethernet configuration 59
 - components 2
 - configuration 58
 - data storage capacity 1
 - description 1
 - environmental air quality requirement 32
 - front components 2
 - installation problems 43
 - installing and setting up 15
 - mounting in rack 7
 - operation problems 44
 - power specifications 3
 - rear components 3
 - removal and replacement 51
 - removing the shipping key 7
 - repair identification tag 39
 - replace tape drive 48
 - resetting 41
 - statistics 60
 - supported servers 1

B

- backup application 19
- battery return program 70

C

- cable
 - power 19
 - SCSI 17
- cartridge
 - cleaning 29
 - tape 29
- Class A electronic emission notice 71
- cleaning cartridge 29
- cleaning tape drive
 - autoclean option 36
 - clean drive option 36
 - general information 36
 - loading a cleaning cartridge 37
- command menu 23
- configuration
 - autoloader 58
 - Ethernet 59
 - Ethernet connection 27
- controls, operator 2
- country unique terms 79
- courier or depot service 90
- CRU list 48
- customer carry-in service 90
- customer replaceable unit (CRU) service 89

D

- depot or courier service 90
- diagnostic log 42
- diagnostic menu 23
- diagnostics, running 60

E

- electronic emission Class A notice 71
- environmental specifications 3
- erase tape cartridge 30
- error messages 63
- Ethernet configuration options 59
- Ethernet connection
 - configuration options 27
 - setting address 28
 - setting up 27
 - uses for 27
- exchange of a machine or part 77
- exporting tape cartridge into autoloader 34

F

- fan problem 44
- FCC Class A notice 71
- firmware, updating 41
- front components 2

G

- general terms, warranty 75
- governing law 78

I

- importance of 5
- importing tape cartridge from autoloader 33
- install autoloader 15
- installation problems 43, 44
- inventory tape cartridge 56

J

- jurisdiction 79

L

- labeling tape cartridges 33
- law, governing 78
- LED, status 2
- liability, limitation of 78
- library information 55
- library status 55
- limitation of liability 78
- loading tape cartridge from autoloader 33

- loading tape cartridge into tape drive 35
- log 42

M

- machine exchange service 90
- machine or part, exchange of 77
- mail-in service 90
- main menu description 23
- MAPs
 - power and fan 44
 - purpose of 44
 - tape drive 46
- menus
 - description 22
 - submenus 22
- messages 63

N

- next business day service level 90
- notes, important 68
- notices 67
 - electronic emission 71
 - FCC, Class A 71

O

- obtaining warranty service 76
- on-site service 89
- operating mode
 - change to random 27
 - change to sequential 26
 - setting 26
- operator controls 2
- operator panel 2
 - error messages 63
 - password protecting 24
 - setting password 24
 - turning off password 25
 - using 21
 - using password 25

P

- panel, operator 2
- parts list 48
- password
 - changing web access 59
 - operator panel 24
 - setting operator panel 24
 - turning off 25
 - using 26
 - using operator panel 25
- power cable 19
- power specifications 3
- product recycling and disposal 69

R

- rack installation 7
- random mode, changing to sequential mode 26
- rear components 3
- recycling and disposal, product 69
- remote management utility
 - autoloader statistics 60
 - description 55
 - diagnostics 60
 - library information 55
 - library status 55
 - password 59
 - setting configuration options 58
 - setting Ethernet configuration 59
- tape cartridge inventory
 - information 56
- tape drive status 56
- removal and replacement
 - autoloader 51
 - tape drive 48
- removing tape cartridge manually 40
- repair identification tag 39
- reset autoloader 41

S

- same business day service level 91
- same day service level 91
- SCSI address
 - determining 16
 - setting 17
- SCSI cable 17, 21
- SCSI terminator 18
- sequential mode, changing to random mode 27
- servers supported 1
- service
 - courier or depot 90
 - CRU and on-site 90
 - customer carry-in or mail-in 90
 - customer replaceable unit (CRU) 89
 - machine exchange 90
 - on-site 89
- service level
 - next business day 90
 - same business day 91
 - same day 91
- ship tape cartridge 30
- shipping key removal 7
- specifications 3
- static-sensitive devices 39
- status
 - autoloader 55
 - tape drive 56
- status LED 2
- status menu 23
- store tape cartridge 30
- storing tape cartridges 4

T

- tape cartridge
 - inventory 56
 - manually remove 53

- tape cartridges
 - erasing 30
 - exporting into autoloader 34
 - guidelines for use 30
 - importing into autoloader 33
 - in harsh environments 32
 - loading into tape drive 35
 - manually remove from autoloader 40
 - placing labels 33
 - retrieving data from 30
 - setting write-protect switch 32
 - storage 4
 - storing and shipping 30
 - types 29
 - unloading from tape drive 35
- tape drive
 - cleaning 5
 - autoclean option 36
 - clean drive option 36
 - general information 36
 - loading a cleaning cartridge 37
 - environment 4
 - loading cartridges 35
 - manually remove tape cartridge 53
 - problem with 46
 - removal and replacement 48
 - solving problems 44
 - status 56
 - unloading cartridges 35
- terminator installation 18
- terms, country unique 79
- trademarks 68
- troubleshooting
 - diagnostics 60
 - error messages 63
 - fan problem 44
 - installation problems 43
 - operation problems 44
 - tape drive 46
 - tape drive problems 44
- type of warranty 89

U

- unique terms, country 79
- United States electronic emission Class A notice 71
- United States FCC Class A notice 71
- unloading tape cartridge from tape drive 35
- unloading tape cartridge into autoloader 34
- updating firmware 41

W

- warranty
 - general terms 75
 - service, obtaining 76
 - type 89
- Web access password 59
- web site
 - machine warranty 91
- write-protect switch 32



Part Number: 44R5294

Printed in USA

(1P) P/N: 44R5294

