

Removing the cross braces

Locate the rack near its installation site; then, complete the following steps to remove the cross braces:

1. Remove the side covers.
2. Open the rear door.
3. Remove the four screws and two nut plates.
(The nut plates are located on hinge side only)
4. Remove the cross braces.
5. Store the braces for future use. If you need to move the rack, you must reinstall the braces.

