

Blade Service Information





Microprocessor / Memory Option



NOTES:

- Use microprocessors with same cache size and type, same clock speed, and identical internal and external clock frequencies.
- Remove the microprocessor heat sink filler. Then, remove the microprocessor socket cover, if present, and lift the release lever before installing the microprocessor.
- ATTENTION: Do not touch exposed pins of the microprocessor socket. Remove the grease shield from the bottom of the heat sink before installing. Do not touch thermal grease. If thermal grease becomes contaminated, call for service.
- Tighten captive screws, alternating between screws until tight.
 Refer to your *Installation and User's Guide* for additional information.

Memory Installation Order:


For single microprocessor, install DIMMs in the following order.

DIMM Šlots: 1 & 4, 5 & 8, 2 & 3, 6 & 7

For dual microprocessors, install DIMMs in the following order. DIMM Slots: 1 & 4, 9 & 12, 5 & 8, 13 & 16, 2 & 3, 10 & 11, 6 & 7, 14 & 15

NOTES:

- DIMMs must be installed in pairs.
- DIMMs must match size, speed, and technology within pairs. Use only registered (buffered) ECC VLP DDR3 DIMMs.
- Refer to your Installation and User's Guide for advance memory information including mirroring.
- In scaled systems, DIMMs should be balanced between blades for optimal performance.



- 1 Microprocessor 1 Error LED
- 2 Control Panel Connector
- 3 Scaling Error LED 4 Scalability Card Connector
- 5 Power Sharing Connector
- 6 Expansion Card LED
- 7 I/O Expansion Connector 8 I/O Expansion Connector
- 9 Switch Block 10 IMM Backup Jumper
- 11 Expansion Connector LED
- 12 Blade Expansion Connector
- 13 Expansion Connector LED 14 DIMM 1-16 Error LEDs
- 15 Battery Error LED
- 16 3V Lithium Battery
- 17 Hypervisor Connector
- 18 Microprocessor 2 Error LED 19 Scalability Indicators

Light Path Diagnostics



3 ! NMI -

4 Mismatch


- Press power button on front panel to activate light path when blade is removed from the chassis
- MT button lights when light path is activated if the capacitor is charged.
- Look for LEDs through the front bezel for possible CPU errors when light path is activated.


Check light path on blade below for errors.

- Reboot blade server. If error still exists, you may need to replace system board.
- Check event log for additional information.

Reboot blade server.

If error still exists, you may need to replace system board. Check microprocessors to ensure they are compatible.





MANUFACTURING NOTES

- Refer to label print part number 68Y7909 for manufacturing and
- Ink colors to match PMS 2718C and PMS Black C.

