

iPECS

User Manual

ES-5048XG Managed 48-port 10GE Switch

ES-5048XG MANAGED 48-PORT 10GE SWITCH

*Layer 2 Managed Switch
with 48 10GBASE SFP+ Slots,
One Power Supply Unit
and one Fan Tray Module*

ABOUT THIS GUIDE

iPECS ES-5048XG

PURPOSE This guide gives specific information on how to operate and use the management functions of the switch.

AUDIENCE The guide is intended for use by network administrators who are responsible for operating and maintaining network equipment; consequently, it assumes a basic working knowledge of general switch functions, the Internet Protocol (IP), and Simple Network Management Protocol (SNMP).

CONVENTIONS The following conventions are used throughout this guide to show information:



NOTE: Emphasizes important information or calls your attention to related features or instructions.



CAUTION: Alerts you to a potential hazard that could cause loss of data, or damage the system or equipment.



WARNING: Alerts you to a potential hazard that could cause personal injury.

NOTICE OF CHANGES LG-Ericsson reserves the right to change specifications at any time without notice.

RELATED PUBLICATIONS The following publication details the hardware features of the switch, including the physical and performance-related characteristics, and how to install the switch:

The Installation Guide

Also, as part of the switch's software, there is an online web-based help that describes all management related features.

REVISION HISTORY This section summarizes the changes in each revision of this guide.

APRIL 2011 REVISION

This is the first version of this guide. This guide is valid for software release v2.0.0.24.

TABLE OF CONTENTS

iPECS ES-5048XG

ABOUT THIS GUIDE	3
TABLE OF CONTENTS	5
1 PREFACE	23
CLI Command Modes	23
User EXEC Mode	23
Privileged EXEC Mode	24
Global Configuration Mode	24
Interface Configuration Modes	24
Starting the CLI	25
CLI Command Conventions	26
Entering Commands	26
Terminal Command Buffer	27
Negating the Effect of Commands	27
Command Completion	27
Keyboard Shortcuts	28
2 USER INTERFACE COMMANDS	29
enable	29
disable	29
login	30
configure	30
exit (Configuration)	31
exit (EXEC)	31
end	31
help	32
history	32
history size	33
terminal history	34
terminal history size	34
terminal datadump	35
debug-mode	36

show history	36
show privilege	37
do	37
banner exec	38
banner login	39
banner motd	40
exec-banner	42
login-banner	42
motd-banner	43
show banner	43
3 SYSTEM MANAGEMENT COMMANDS	45
ping	45
tracert	47
telnet	50
resume	52
hostname	53
reload	53
service cpu-utilization	54
show cpu utilization	54
clear cpu counters	55
service cpu-counters	55
show cpu counters	56
show users	56
show sessions	57
show system	58
show version	58
system resources routing	59
show system resources routings	59
show system tcam utilization	60
show system defaults	60
show tech-support	63
show system id	64
4 CLOCK COMMANDS	65
clock set	65
clock source	65
clock timezone	66

clock summer-time	67
sntp authentication-key	68
sntp authenticate	69
sntp trusted-key	70
sntp client poll timer	70
sntp broadcast client enable	71
sntp anycast client enable	71
sntp client enable	72
sntp client enable (Interface)	73
sntp unicast client enable	73
sntp unicast client poll	74
sntp server	74
sntp port	76
show clock	77
show sntp configuration	78
show sntp status	78
5 CONFIGURATION AND IMAGE FILE COMMANDS	80
copy	80
delete	83
dir	84
more	84
rename	85
boot system	86
show running-config	87
show startup-config	87
show bootvar	88
6 AUTO-UPDATE AND AUTO-CONFIGURATION	89
boot host auto-config	89
show boot	89
ip dhcp tftp-server ip addr	91
ip dhcp tftp-server file	92
show ip dhcp tftp-server	92
7 MANAGEMENT ACL COMMANDS	93
management access-list	93
permit (Management)	94

deny (Management)	95
management access-class	96
show management access-list	96
show management access-class	97
8 NETWORK MANAGEMENT PROTOCOL (SNMP) COMMANDS	98
snmp-server	98
snmp-server community	98
snmp-server view	100
snmp-server group	101
snmp-server user	103
snmp-server filter	104
snmp-server host	105
snmp-server engineID local	107
snmp-server enable traps	108
snmp-server trap authentication	109
snmp-server contact	109
snmp-server location	110
snmp-server set	110
show snmp	111
show snmp engineID	112
show snmp views	112
show snmp groups	113
show snmp filters	114
show snmp users	114
9 RSA AND CERTIFICATE COMMANDS	116
crypto key generate dsa	116
crypto key generate rsa	116
show crypto key mypubkey	117
crypto certificate generate	118
crypto certificate request	119
crypto certificate import	120
crypto certificate export pkcs12	121
crypto certificate import pkcs12	122
show crypto certificate mycertificate	123
10 WEB SERVER COMMANDS	125

ip http server	125
ip http port	125
ip http timeout-policy	126
ip http secure-server	127
ip http secure-port	127
ip https certificate	128
show ip http	128
show ip https	129
11 TELNET, SECURE SHELL (SSH), AND SECURE LOGIN (SLOGIN) COMMANDS	130
ip telnet server	130
ip ssh port	130
ip ssh server	131
ip ssh pubkey-auth	131
crypto key pubkey-chain ssh	132
user-key	133
key-string	133
show ip ssh	135
show crypto key pubkey-chain ssh	135
12 LINE COMMANDS	137
line	137
speed	137
autobaud	138
exec-timeout	139
show line	139
13 AAA COMMANDS	141
aaa authentication login	141
aaa authentication enable	142
login authentication	144
enable authentication	144
ip http authentication	145
show authentication methods	146
password	147
enable password	147
username	148
show user accounts	148

aaa accounting login	149
aaa accounting dot1x	150
show accounting	152
passwords strength minimum character-classes	152
passwords strength max-limit repeated-characters	153
14 RADIUS COMMANDS	154
radius-server host	154
radius-server key	156
radius-server retransmit	157
radius-server source-ip	157
radius-server source-ipv6	158
radius-server timeout	159
radius-server deadtime	159
show radius-servers	160
15 TACACS+ COMMANDS	161
tacacs-server host	161
tacacs-server key	162
tacacs-server timeout	163
tacacs-server source-ip	163
show tacacs	164
16 SYSLOG COMMANDS	166
logging on	166
Logging host	166
logging console	168
logging buffered	168
clear logging	169
logging file	169
clear logging file	170
aaa logging	170
file-system logging	171
management logging	171
show logging	172
show logging file	173
show syslog-servers	174
17 REMOTE NETWORK MONITORING (RMON) COMMANDS	175

show rmon statistics	175
rmon collection stats	176
show rmon collection stats	177
show rmon history	178
rmon alarm	180
show rmon alarm-table	182
show rmon alarm	182
rmon event	184
show rmon events	185
show rmon log	185
rmon table-size	186
18 802.1X COMMANDS	188
aaa authentication dot1x	188
dot1x system-auth-control	189
dot1x port-control	189
dot1x reauthentication	190
dot1x timeout reauth-period	191
dot1x re-authenticate	191
dot1x timeout quiet-period	192
dot1x timeout tx-period	193
dot1x max-req	193
dot1x timeout supp-timeout	194
dot1x timeout server-timeout	195
show dot1x	196
show dot1x users	198
show dot1x statistics	199
dot1x auth-not-req	200
dot1x host-mode	200
dot1x violation-mode	201
dot1x guest-vlan	202
dot1x guest-vlan timeout	203
dot1x guest-vlan enable	204
dot1x mac-authentication	204
dot1x radius-attributes vlan	205
show dot1x advanced	206
19 ETHERNET CONFIGURATION COMMANDS	207

interface	207
interface range	207
shutdown	207
description	208
speed	209
flowcontrol	209
port jumbo-frame	210
clear counters	210
set interface active	211
errdisable recovery cause	212
errdisable recovery interval	213
show interfaces configuration	213
show interfaces status	214
show interfaces advertise	214
show interfaces description	215
show interfaces counters	216
show port jumbo-frame	217
show errdisable recovery	218
show errdisable interfaces	218
storm-control broadcast enable	219
storm-control broadcast level kbps	220
storm-control include-multicast	220
show storm-control	221
20 PHY DIAGNOSTICS COMMANDS	222
show fiber-ports optical-transceiver	222
21 PORT CHANNEL COMMANDS	224
channel-group	224
port-channel load-balance	225
show interfaces port-channel	225
22 ADDRESS TABLE COMMANDS	227
bridge multicast filtering	227
bridge multicast mode	227
bridge multicast address	229
bridge multicast forbidden address	230
bridge multicast forbidden ip-address	231

bridge multicast source group	232
bridge multicast forbidden source group	233
bridge multicast ipv6 mode	234
bridge multicast ipv6 forbidden ip-address	235
bridge multicast ipv6 source group	236
bridge multicast ipv6 forbidden source group	237
bridge multicast unregistered	238
bridge multicast forward-all	239
bridge multicast forbidden forward-all	240
mac address-table static	241
clear mac address-table	242
mac address-table aging-time	242
port security	243
port security mode	243
port security max	244
port security routed secure-address	245
show mac address-table	245
show mac address-table count	246
show bridge multicast mode	247
show bridge multicast address-table	247
show bridge multicast address-table static	250
show bridge multicast filtering	252
show bridge multicast unregistered	252
show ports security	253
show ports security addresses	254
23 PORT MONITOR COMMANDS	255
port monitor	255
show ports monitor	257
port monitor mode	257
24 sFLOW COMMANDS	259
sflow receiver	259
sflow flow-sampling	260
sflow counters-sampling	260
clear sflow statistics	261
show sflow configuration	261
show sflow statistics	262

25 LINK LAYER DISCOVERY PROTOCOL (LLDP) COMMANDS	263
lldp run	263
lldp transmit	263
lldp receive	264
lldp timer	265
lldp hold-multiplier	265
lldp reinit	266
lldp tx-delay	266
lldp optional-tlv	267
lldp management-address	268
lldp notifications	269
lldp notifications interval	269
lldp optional-tlv 802.1	270
lldp med enable	271
lldp med notifications topology-change	271
lldp med fast-start repeat-count	272
lldp med network-policy (global)	272
lldp med network-policy (interface)	273
clear lldp table	274
lldp med location	274
show lldp configuration	275
show lldp med configuration	277
show lldp local tlvs-overloading	278
show lldp local	278
show lldp neighbors	280
show lldp statistics	283
26 SPANNING-TREE COMMANDS	285
spanning-tree	285
spanning-tree mode	285
spanning-tree forward-time	286
spanning-tree hello-time	287
spanning-tree max-age	288
spanning-tree priority	288
spanning-tree disable	289
spanning-tree cost	290
spanning-tree port-priority	290

spanning-tree portfast	291
spanning-tree link-type	292
spanning-tree pathcost method	292
spanning-tree bpdu (Global)	293
spanning-tree bpdu (Interface)	294
spanning-tree guard root	295
spanning-tree bpduguard	296
clear spanning-tree detected-protocols	296
spanning-tree mst priority	297
spanning-tree mst max-hops	298
spanning-tree mst port-priority	298
spanning-tree mst cost	299
spanning-tree mst configuration	300
instance (MST)	300
name (MST)	301
revision (MST)	301
show (MST)	302
exit (MST)	303
abort (MST)	303
show spanning-tree	303
show spanning-tree bpdu	312
spanning-tree loopback-guard	313
27 VIRTUAL LOCAL AREA NETWORK (VLAN) COMMANDS	315
vlan database	315
vlan	315
interface vlan	316
interface range vlan	316
name	317
switchport protected-port	318
switchport community	318
show interfaces protected-ports	319
switchport	319
switchport mode	320
switchport access vlan	321
switchport trunk allowed vlan	321
switchport trunk native vlan	322

switchport general allowed vlan	323
switchport general pvid	324
switchport general ingress-filtering disable	324
switchport general acceptable-frame-type	325
map protocol protocols-group	326
switchport general map protocols-group vlan	327
map mac macs-group	327
switchport general map macs-group vlan	328
map subnet subnets-group	329
switchport general map subnets-group vlan	329
show vlan	330
show vlan protocols-groups	331
show vlan macs-groups	331
show vlan subnets-groups	332
show interfaces switchport	332
28 VIRTUAL LOCAL AREA NETWORK (VLAN) NON-ISCLI COMMANDS	335
switchport forbidden default-vlan	335
switchport forbidden vlan	335
switchport default-vlan tagged	336
show interfaces switchport	337
29 IGMP SNOOPING COMMANDS	340
ip igmp snooping (Global)	340
ip igmp snooping vlan	340
ip igmp snooping mrouter	341
ip igmp snooping mrouter interface	342
ip igmp snooping forbidden mrouter interface	342
ip igmp snooping static	343
ip igmp snooping querier	344
ip igmp snooping querier address	345
ip igmp snooping querier version	345
ip igmp robustness	346
ip igmp query-interval	346
ip igmp query-max-response-time	347
ip igmp last-member-query-count	348
ip igmp last-member-query-interval	348
ip igmp snooping vlan immediate-leave	349

show ip igmp snooping mrouter	349
show ip igmp snooping interface	350
show ip igmp snooping groups	351
30 IPv6 MLD Snooping Commands	352
ipv6 mld snooping (Global)	352
ipv6 mld snooping vlan	352
ipv6 mld robustness	353
ipv6 mld snooping mrouter	353
ipv6 mld snooping mrouter interface	354
ipv6 mld snooping forbidden mrouter interface	355
ipv6 mld snooping static	356
ipv6 mld query-interval	356
ipv6 mld query-max-response-time	357
ipv6 mld last-member-query-count	358
ipv6 mld last-member-query-interval	358
ipv6 mld snooping vlan immediate-leave	359
show ipv6 mld snooping mrouter	359
show ipv6 mld snooping interface	360
show ipv6 mld snooping groups	360
31 Link Aggregation Control Protocol (LACP) Commands	363
lacp system-priority	363
lacp port-priority	363
lacp timeout	364
show lacp	364
show lacp port-channel	366
32 GARP VLAN Registration Protocol (GVRP) Commands	367
gvrp enable (Global)	367
gvrp enable (Interface)	367
garp timer	368
gvrp vlan-creation-forbid	369
gvrp registration-forbid	370
clear gvrp statistics	370
show gvrp configuration	371
show gvrp statistics	371
show gvrp error-statistics	372

33 DHCP SNOOPING AND ARP INSPECTION COMMANDS	374
ip dhcp snooping	374
ip dhcp snooping vlan	374
ip dhcp snooping trust	375
ip dhcp snooping information option allowed-untrusted	376
ip dhcp snooping verify	376
ip dhcp snooping database	377
ip dhcp snooping database update-freq	377
ip dhcp snooping binding	378
clear ip dhcp snooping database	379
show ip dhcp snooping	379
show ip dhcp snooping binding	380
ip source-guard	381
ip arp inspection	382
ip arp inspection vlan	382
ip arp inspection trust	383
ip arp inspection validate	384
ip arp inspection list create	384
ip mac	385
ip arp inspection list assign	386
ip arp inspection logging interval	386
show ip arp inspection	387
show ip arp inspection list	387
show ip arp inspection statistics	388
clear ip arp inspection statistics	388
ip dhcp information option	389
show ip dhcp information option	389
34 IP ADDRESSING COMMANDS	391
ip address	391
ip address dhcp	392
renew dhcp	393
ip default-gateway	394
show ip interface	395
arp	395
arp timeout (Global)	396
arp timeout	397

clear arp-cache	397
show arp	398
show arp configuration	398
ip helper-address	399
show ip helper-address	400
ip domain lookup	401
ip domain name	401
ip name-server	402
ip host	403
clear host	404
clear host dhcp	404
show hosts	405
35 IPv6 ADDRESSING COMMANDS	407
ipv6 enable	407
ipv6 address autoconfig	408
ipv6 icmp error-interval	408
show ipv6 icmp error-interval	409
ipv6 address	410
ipv6 address link-local	411
ipv6 unreachable	412
ipv6 default-gateway	412
show ipv6 interface	413
show IPv6 route	414
ipv6 nd dad attempts	415
ipv6 host	416
ipv6 neighbor	417
ipv6 set mtu	418
ipv6 mld version	419
ipv6 mld join-group	419
show ipv6 neighbors	420
clear ipv6 neighbors	421
36 IP ROUTING PROTOCOL-INDEPENDENT COMMANDS	423
ip route	423
ip routing	424
show ip route	424

37 TUNNEL COMMANDS	426
interface tunnel	426
tunnel mode ipv6ip	426
tunnel isatap router	427
tunnel source	428
tunnel isatap query-interval	429
tunnel isatap solicitation-interval	429
tunnel isatap robustness	430
show ipv6 tunnel	431
38 ACL COMMANDS	432
ip access-list extended	432
permit (IP)	432
deny (IP)	435
ipv6 access-list	437
permit (IPv6)	438
deny (IPv6)	440
mac access-list	442
permit (MAC)	443
service-acl	444
show access-lists	445
show interfaces access-lists	446
clear access-lists counters	446
show interfaces access-lists counters	446
39 QUALITY OF SERVICE (QoS) COMMANDS	448
qos	448
qos advanced-mode trust	449
show qos	449
class-map	450
show class-map	451
match	452
policy-map	452
class	453
show policy-map	454
trust	455
set	456
police	457

service-policy	458
qos aggregate-policer	459
show qos aggregate-policer	460
police aggregate	460
wrr-queue cos-map	461
wrr-queue bandwidth	462
priority-queue out num-of-queues	463
traffic-shape	464
traffic-shape queue	464
rate-limit (Ethernet)	465
rate-limit (VLAN)	466
qos wrr-queue wrtd	467
show qos interface	467
wrr-queue	469
qos wrr-queue threshold	470
qos map policed-dscp	471
qos map dscp-queue	471
qos map dscp-dp	472
qos trust (Global)	473
qos trust (Interface)	474
qos cos	474
qos dscp-mutation	475
qos map dscp-mutation	475
show qos map	476
clear qos statistics	478
qos statistics policer	478
qos statistics aggregate-policer	479
qos statistics queues	479
show qos statistics	480
40 DATA CENTER ETHERNET COMMANDS	483
dce priority-flow-control enable (Global)	483
dce priority-flow-control priority enable	483
dce priority-flow-control enable (interface)	484
show dce priority-flow-control	484
dce qcn enable (global)	485
dce qcn priority enable	486

dce qcn cnm priority	487
dce qcn cp enable	487
dce qcn cp set-point	488
dce qcn cp feedback-weight	488
dce qcn cp min-sample-base	489
show dce qcn	489
dce dcbx enable	491
dce dcbx advertise priority-groups	491
dce dcbx advertise priority-flow-control	492
dce dcbx advertise application-protocol	492
dce application-protocol enable	493
dce application-protocol map	493
show dce dcbx	494
wrr-queue bandwidth (ETS)	496
show dce ets	497
dce cut-through enable (global)	498
dce cut-through enable (interface)	498
dce cut-through priority enable	499
dce cut-through untagged enable	499
dce cut-through packet-length	500
show dce cut-through	501
dce fip-snooping enable (Global)	501
dce fip-snooping enable (Interface)	502
dce fip-snooping fcf-address-filtering enable	503
dce fip-snooping fcf-address-filtering list	503
dce fip-snooping tunnel	504
clear dce fip-snooping tunnel	504
show dce fip-snooping configuration	505
show dce fip-snooping tunnels	505

This User Manual describes how to use the CLI and a list of the CLI commands and their arguments.

The CLI commands described in this document are organized according to feature groups in separate sections.

This section describes how to use the CLI. It contains the following topics:

- ◆ [CLI Command Modes](#)
- ◆ [Starting the CLI](#)
- ◆ [CLI Command Conventions](#)
- ◆ [Entering Commands](#)

CLI COMMAND MODES

To configure devices, the CLI is divided into various command modes. Each command mode has its own set of specific commands. Entering a question mark "?" at the console prompt displays a list of commands available for that particular command mode.

A specific command, which varies from mode to mode, is used to navigate from one mode to another. The standard order to access the modes is as follows: *User EXEC* mode, *Privileged EXEC* mode, *Global Configuration* mode, and *Interface Configuration* modes.

When starting a session, the initial mode for non-privileged users is the User EXEC mode. Only a limited subset of commands is available in the User EXEC mode. This level is reserved for tasks that do not change the configuration.

Privileged users enter the Privileged EXEC mode directly using a password. This mode provides access to the device Configuration modes.

The modes are described below.

USER EXEC MODE After logging into the device, the user is automatically in *User EXEC* command mode unless the user is defined as a privileged user. In general, the *User EXEC* commands enable the user to perform basic tests, and display system information.

The user-level prompt consists of the device "host name" followed by the angle bracket (>).

```
console>
```

The default host name is "console" unless it has been changed using the **hostname** command in the *Global Configuration* mode.

PRIVILEGED EXEC MODE

Privileged access is password-protected to prevent unauthorized use, because many of the privileged commands set operating system parameters: The password is not displayed on the screen and is case sensitive.

Privileged users enter directly into the *Privileged EXEC* mode.

Use **disable** to return to the *User EXEC* mode.

GLOBAL CONFIGURATION MODE

Global Configuration mode commands apply to features that affect the system as a whole, rather than just a specific interface.

To enter the *Global Configuration* mode, enter **configure** in the Privileged EXEC mode, and press <Enter>.

The *Global Configuration* mode prompt is displayed.

```
console(config)#
```

Use **exit**, **end** or **ctrl/z** to return to the Privileged EXEC mode.

INTERFACE CONFIGURATION MODES

Commands in the following modes perform specific interface operations:

- ◆ **Line Interface** — Contains commands to configure the management connections. These include commands such as line speed, timeout settings, etc. The *Global Configuration* mode command **line** is used to enter the *Line Configuration command* mode.

- ◆ **VLAN Database** — Contains commands to create a VLAN as a whole. The Global Configuration mode command **vlan database** is used to enter the *VLAN Database Interface Configuration* mode.
- ◆ **Management Access List** — Contains commands to define management access-lists. The *Global Configuration* mode command management access-list is used to enter the *Management Access List Configuration* mode.
- ◆ **Port Channel** — Contains commands to configure port-channels, for example, assigning ports to a VLAN or port-channel. The *Global Configuration* mode command interface **port-channel** is used to enter the *Port Channel Interface Configuration* mode.
- ◆ **SSH Public Key-Chain** — Contains commands to manually specify other device SSH public keys. The *Global Configuration* mode command crypto key pubkey-chain **ssh** is used to enter the *SSH Public Key-chain Configuration* mode.
- ◆ **Interface** — Contains commands that configure the interface. The *Global Configuration* mode command **interface** is used to enter the *Interface Configuration* mode.

STARTING THE CLI

The switch can be managed over a direct connection to the switch console port, or via a Telnet connection. The switch is managed by entering command keywords and parameters at the prompt. Using the switch CLI commands is similar to entering commands on a UNIX system.

If access is via a Telnet connection, ensure the device has an IP address defined, corresponding management access is granted, and the workstation used to access the device is connected to the device prior to using CLI commands.

ACCESSING THE CLI FROM THE CONSOLE LINE

1. Start the device and wait until the startup procedure is complete. The User Exec mode is entered, and the prompt "console>" is displayed.
2. Configure the device and enter the necessary commands to complete the required tasks.
3. When finished, exit the session with the **quit** or **exit** command.

ACCESSING THE CLI FROM TELNET

1. Enter **telnet** and the IP address of the device. A User Name prompt is displayed.
2. Enter the User Name and Password. You are in the Privileged Exec mode.

3. Configure the device and enter the necessary commands to complete the required tasks.
4. When finished, exit the session with the quit or exit command.

When another user is required to log onto the system, the **login** command is entered in the Privileged EXEC command mode,. This effectively logs off the current user and logs on the new user.

CLI COMMAND CONVENTIONS

The following table describes the command syntax conventions.

Table 1: CLI Conventions

Conventions	Description
[]	In a command line, square brackets indicates an optional entry.
{ }	In a command line, curly brackets indicate a selection of compulsory parameters separated by the character. One option must be selected. For example: flowcontrol {auto on off} means that for the flowcontrol command either auto , on or off must be selected.
<i>Italic font</i>	Indicates a parameter.
<Enter>	Any individual key on the keyboard. For example click <Enter>.
Ctrl+F4	Any combination keys pressed simultaneously on the keyboard.
Screen Display	Indicates system messages and prompts appearing on the console.
all	When a parameter is required to define a range of ports or parameters and all is an option, the default for the command is all when no parameters are defined. For example, the command interface range port-channel has the option of either entering a range of channels, or selecting all . When the command is entered without a parameter, it automatically defaults to all .

ENTERING COMMANDS

A CLI command is a series of keywords and arguments. Keywords identify a command, and arguments specify configuration parameters. For example, in the command "**show interfaces status gi1/0/5**" **show**, **interfaces** and **status** are keywords, **gi** is an argument that specifies the interface type, and **1/0/5** is an argument that specifies the port.

To enter commands that require parameters, enter the required parameters after the command keyword. For example, to set a password for the administrator, enter:

```
console(config)# username admin password smith
```

Help information can be displayed in the following ways:

- ◆ **Keyword Lookup** — The character ? is entered in place of a command. A list of all valid commands and corresponding help messages are displayed.
- ◆ **Partial Keyword Lookup** — A command is incomplete and the character ? is entered in place of a parameter. The matched parameters for this command are displayed.

The following describes features that assist in using the CLI:

TERMINAL COMMAND BUFFER

Every time a command is entered in the CLI, it is recorded on an internally managed Command History buffer. Commands stored in the buffer are maintained on a First In First Out (FIFO) basis. These commands can be recalled, reviewed, modified, and reissued. This buffer is not preserved across device resets. The keys that can be used to access the history buffer are described in [Table 2](#).

By default, the history buffer system is enabled, but it can be disabled at any time. For information about the command syntax to enable or disable the history buffer, see the **history** command.

There is a standard default number of commands that are stored in the buffer. The standard number of 10 commands can be increased to 256. By configuring 0, the effect is the same as disabling the history buffer system. For information about the command syntax for configuring the command history buffer, see the **history size** command.

To display the history buffer, see **show history** command.

NEGATING THE EFFECT OF COMMANDS

For many configuration commands, the prefix keyword "no" can be entered to cancel the effect of a command or reset the configuration to the default value. This guide describes the negation effect for all applicable commands.

COMMAND COMPLETION

If the command entered is incomplete, invalid, or has missing or invalid parameters, an appropriate error message is displayed.

To complete an incomplete command, press the <Tab> button. If the characters already entered are not enough for the system to identify a single matching command, press "?" to display the available commands matching the characters already entered.

Incorrect or incomplete commands are automatically re-entered next to the cursor. If a parameter must be added, the parameter can be added to the basic command already displayed next to the cursor. The following

example indicates that the command interface requires a missing parameter.

```
(config)#interface
%missing mandatory parameter
(config)#interface
```

KEYBOARD SHORTCUTS

The CLI has a range of keyboard shortcuts to assist in entering the CLI commands.

The following table describes these shortcuts:

Table 2: Keyboard Keys

Keyboard Key	Description
Up-arrow key	Recalls commands from the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Down-arrow key	Returns the most recent commands from the history buffer after recalling commands with the up arrow key. Repeating the key sequence will recall successively more recent commands.
Ctrl+A	Moves the cursor to the beginning of the command line.
Ctrl+E	Moves the cursor to the end of the command line.
Ctrl+Z / End	Returns back to the Privileged EXEC mode from any mode.
Backspace key	Moves the cursor back one space.
Up-arrow key	Recalls commands from the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.

enable The **enable** EXEC mode command enters the Privileged EXEC mode.

SYNTAX

enable [*privilege-level*]

PARAMETERS

privilege-level—Specifies the privilege level at which to enter the system.
(Range: 1–15)

DEFAULT CONFIGURATION

The default privilege level is 15.

COMMAND MODE

EXEC mode

EXAMPLE

The following example enters the Privileged EXEC mode.

```
Console> enable
enter password:
Console#
```

disable The **disable** Privileged EXEC mode command leaves the Privileged EXEC mode and returns to the User EXEC mode.

SYNTAX

disable [*privilege-level*]

PARAMETERS

privilege-level—Specifies the privilege level at which to enter the system.
(Range: 1–15)

DEFAULT CONFIGURATION

The default privilege level is 1.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example returns to the User EXEC mode.

```
Console# disable  
Console>
```

login The **login** EXEC mode command changes a user's login.

SYNTAX

login

COMMAND MODE

EXEC mode

EXAMPLE

The following example enters Privileged EXEC mode and logs in with username 'admin'.

```
Console> login  
User Name:admin  
Password:*****  
Console#
```

configure The **configure** Privileged EXEC mode command enters the Global Configuration mode.

SYNTAX

configure [*terminal*]

PARAMETERS

terminal—Enter the Global Configuration mode with or without the keyword terminal.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example enters Global Configuration mode.

```
Console# configure  
Console(config)#
```

exit (Configuration) The **exit** command exits any configuration mode to the next highest mode in the CLI mode hierarchy.

SYNTAX

exit

COMMAND MODE

All commands in configuration modes.

EXAMPLES

The following examples change the configuration mode from Interface Configuration mode to Privileged EXEC mode.

```
Console(config-if)# exit
Console(config)# exit
Console#
```

```
Router(config-if)# exit
Router(config)# exit
Router#
```

exit (EXEC) The **exit** EXEC mode command closes an active terminal session by logging off the device.

SYNTAX

exit

COMMAND MODE

EXEC mode

EXAMPLE

The following examples close an active terminal session.

```
Console> exit

Router> exit
```

end The **end** command ends the current configuration session and returns to the Privileged EXEC mode.

SYNTAX

end

COMMAND MODE

All configuration modes

EXAMPLE

The following examples end the Global Configuration mode session and return to the Privileged EXEC mode.

```
Console(config)# end
Console#
```

```
Router(config-if)# end
Router#
```

help The **help** command displays a brief description of the Help system.

SYNTAX

help

COMMAND MODE

All command modes

EXAMPLE

The following example describes the Help system.

```
Console# help
Help may be requested at any point in a command by entering a question mark
'?' . If nothing matches the currently entered incomplete command, the help
list is empty. This indicates that there is no command matching the input as
it currently appears. If the request is within a command, press the
Backspace key and erase the entered characters to a point where the request
results in a match.
Help is provided when:
1. There is a valid command and a help request is made for entering a
parameter or argument (e.g. 'show ?'). All possible parameters or arguments
for the entered command are then displayed.
2. An abbreviated argument is entered and a help request is made for arguments
matching the input (e.g. 'show pr?').
```

history The **history** Line Configuration mode command enables the command history function. Use the **no** form of this command to disable the command history function.

SYNTAX

history

no history

DEFAULT CONFIGURATION

The history command is enabled.

COMMAND MODE

Line Configuration mode

USER GUIDELINES

This command enables the command history function for a specified line. Use the **terminal history** EXEC mode command to enable or disable the command history function for the current terminal session.

EXAMPLE

The following example enables the command history function for Telnet.

```
Console(config)# line telnet
Console(config-line)# history
```

history size The **history size** Line Configuration mode command changes the command history buffer size for a particular line. Use the **no** form of this command to reset the command history buffer size to the default value.

SYNTAX

history size *number-of-commands*

no history size

PARAMETERS

number-of-commands—Specifies the number of commands the system records in its history buffer. (Range: 0–256)

DEFAULT CONFIGURATION

The default command history buffer size is 10 commands.

COMMAND MODE

Line Configuration mode

USER GUIDELINES

This command configures the command history buffer size for a particular line. Use the **terminal history size** EXEC mode command to configure the command history buffer size for the current terminal session.

The allocated command history buffer is per terminal user, and is taken from a shared buffer. If there is not enough space available in the shared buffer, the command history buffer size () cannot be increased above the default size.

EXAMPLE

The following example changes the command history buffer size to 100 entries for a particular line

```
Console(config)# line telnet
Console(config-line)# history size 100
```

terminal history The **terminal history** EXEC mode command enables the command history function for the current terminal session. Use the **no** form of this command to disable the command history function.

SYNTAX

terminal history

terminal no history

DEFAULT CONFIGURATION

The default configuration for all terminal sessions is defined by the **history** Line Configuration mode command.

COMMAND MODE

EXEC mode

USER GUIDELINES

The command enables the command history for the current session. The default is determined by the **history** Line Configuration mode command.

EXAMPLE

The following example disables the command history function for the current terminal session.

```
Console> terminal no history
```

terminal history size The **terminal history size** EXEC mode command changes the command history buffer size for the current terminal session. Use the **no** form of this command to reset the command history buffer size to the default value.

SYNTAX

terminal history size *number-of-commands*

terminal no history size

PARAMETERS

number-of-commands—Specifies the number of commands the system maintains in its history buffer. (Range: 10–256)

DEFAULT CONFIGURATION

The default configuration for all terminal sessions is defined by the **history size** Line Configuration mode command.

COMMAND MODE

EXEC mode

USER GUIDELINES

The **terminal history size** EXEC command changes the command history buffer size for the current terminal session. Use the **history** Line Configuration mode command to change the default command history buffer size.

The maximum number of commands in all buffers is 256.

EXAMPLE

The following example sets the command history buffer size to 20 commands for the current terminal session.

```
Console> terminal history size 20
```

terminal datadump The **terminal datadump** EXEC mode command enables dumping all the output of a show command without prompting. Use the **no** form of this command to disable dumping.

SYNTAX

terminal datadump
terminal no datadump

DEFAULT CONFIGURATION

Dumping is disabled.

COMMAND MODE

EXEC mode

USER GUIDELINES

By default, a **More** prompt is displayed when the output contains more lines than can be displayed on the screen. Pressing the **Enter** key displays the next line; pressing the **Spacebar** displays the next screen of output. The **terminal datadump** command enables dumping all output immediately after entering the show command.

This command is relevant only for the current session.

EXAMPLE

The following example dumps all output immediately after entering a show command.

```
Console> terminal datadump
```

debug-mode The **debug-mode** Privileged EXEC mode command mode switches to debug mode.

SYNTAX

debug-mode

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example enters Debug mode.

```
Console# debug-mode
```

show history The **show history** EXEC mode command lists commands entered in the current session.

SYNTAX

show history

COMMAND MODE

EXEC mode

USER GUIDELINES

The buffer includes executed and unexecuted commands.

Commands are listed from the first to the most recent command.

The buffer remains unchanged when entering into and returning from configuration modes.

EXAMPLE

The following example displays all the commands entered while in the current Privileged EXEC mode.

```
Console# show version
SW version 3.131 (date 23-Jul-2005 time 17:34:19)
HW version 1.0.0
```

```

Console# show clock
15:29:03 Jun 17 2005
Console# show history
show version
show clock
show history
3 commands were logged (buffer size is 10)

```

show privilege The **show privilege** EXEC mode command displays the current privilege level.

SYNTAX

show privilege

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the current privilege level for the Privileged EXEC mode.

```

Console# show privilege
Current privilege level is 15

```

do The **do** command executes an EXEC-level command from Global Configuration mode or any configuration submode.

SYNTAX

do *command*

PARAMETERS

command—Specifies the EXEC-level command to execute.

COMMAND MODE

All configuration modes

EXAMPLE

The following example executes the **show vlan** Privileged EXEC mode command from Global Configuration mode.

EXAMPLE

```

Console (Config)# do show vlan

```

Vlan	Name	Ports	Type	Authorization
1	1	te1-39, Po1, Po2, Po3, Po4, Po5, Po6, Po7, Po8	other	Required
2	2	te1	dynamicGvrp	Required

```

10 v0010 tel permanent Not Required
11 V0011 tel,te13 permanent Required
20 20 tel permanent Required
30 30 tel,te13 permanent Required
31 31 tel permanent Required
91 91 tel,te40 permanent Required
4093 guest-vlan tel,te13 permanent Guest
console(config)#s

```

banner exec Use the **banner exec** command to specify and enable a message to be displayed when an EXEC process is created (The user has successfully logged in), use the banner exec command in Global Configuration mode. Use the **no** form of this command to delete the existing EXEC banner.

SYNTAX

banner exec *d message-text d*

no banner exec

PARAMETERS

- ◆ **d**—Delimiting character of your choice—a pound sign (**#**), for example. You cannot use the delimiting character in the banner message.
- ◆ **message-text**—The message must start in a new line. You can enter multi-line messages. You can include tokens in the form of **\$(token)** in the message text. Tokens are replaced with the corresponding configuration variable. Tokens are described in the User Guidelines. The message can contain up to 2000 characters (after every 510 characters, you must press <Enter> to continue).

DEFAULT CONFIGURATION

Disabled (no EXEC banner is displayed).

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

When a user connects to a device, the message-of-the-day (MOTD) banner appears first, followed by the login banner and prompts. After the user logs in to the device, the EXEC banner is displayed.

Use tokens in the form of **\$(token)** in the message text to customize the banner. The tokens are described in the table below:

Token	Information displayed in the banner
\$(hostname)	Displays the host name for the device.
\$(domain)	Displays the domain name for the device.

\$(bold)	Indicates that the next text is a bold text. Using this token again indicates the end of the bold text.
\$(inverse)	Indicates that the next text is an inverse text. Using this token again indicates the end of the inverse text.
\$(contact)	Displays the system contact string.
\$(location)	Displays the system location string.
\$(mac-address)	Displays the base MAC address of the device.

Use the `no exec-banner` line configuration command to disable the EXEC banner on a particular line or lines.

EXAMPLE

The following example sets an EXEC banner that uses tokens. The percent sign (%) is used as a delimiting character. Note that the **\$(token)** syntax is replaced by the corresponding configuration variable.

```
Device(config)# banner exec %
Enter TEXT message. End with the character '%'.
$(bold)Session activated.$(bold) Enter commands at the prompt.
%
When a user logs on to the system, the following output is displayed:
Session activated. Enter commands at the prompt.
```

banner login Use the **banner login** command in Global Configuration mode to specify and enable a message to be displayed before the username and password login prompts. Use the **no** form of this command to delete the existing Login banner.

SYNTAX

```
banner login d message-text d
no banner login
```

PARAMETERS

- ◆ **Delimiting character of your choice**—A pound sign (#), for example. You cannot use the delimiting character in the banner message.
- ◆ **message-text**—Message text. The message must start on a new line. You can enter multi-line messages. You can include tokens in the form of **\$(token)** in the message text. Tokens are replaced with the corresponding configuration variable. Tokens are described in the User Guidelines. The message can contain up to 2000 characters (after every 510 characters, you must press <Enter> to continue).

DEFAULT CONFIGURATION

Disabled (no Login banner is displayed).

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

When a user connects to a device, the message-of-the-day (MOTD) banner appears first, followed by the login banner and prompts. After the user logs in to the device, the EXEC banner is displayed.

Use tokens in the form of **\$(token)** in the message text to customize the banner. The tokens are described in the table below:

Token	Information displayed in the banner
\$(hostname)	Displays the host name for the device.
\$(domain)	Displays the domain name for the device.
\$(bold)	Indicates that the next text is a bold text. Using this token again indicates the end of the bold text.
\$(inverse)	Indicates that the next text is an inverse text. Using this token again indicates the end of the inverse text.
\$(contact)	Displays the system contact string.
\$(location)	Displays the system location string.
\$(mac-address)	Displays the base MAC address of the device.

Use the **no login-banner** line configuration command to disable the Login banner on a particular line or lines.

EXAMPLE

The following example sets a Login banner that uses tokens. The percent sign (%) is used as a delimiting character. Note that the **\$(token)** syntax is replaced by the corresponding configuration variable.

```
Device(config)# banner login %
Enter TEXT message. End with the character '%'.
You have entered $(hostname).$(domain)
%
When the login banner is executed, the user will see the following banner:
You have entered host123.ourdomain.com
```

banner motd Use the **banner motd** command in Global Configuration mode to specify and enable a message-of-the-day banner. Use the **no** form of this command to delete the existing MOTD banner.

SYNTAX

banner motd *d message-text d*
no banner motd

PARAMETERS

- ◆ **d**—Delimiting character of your choice—a pound sign (#), for example. You cannot use the delimiting character in the banner message.

- ◆ **message-text**—The message must start on a new line. You can enter multi-line messages. You can include tokens in the form of **\$(token)** in the message text. Tokens are replaced with the corresponding configuration variable. Tokens are described in the User Guidelines. The message can contain up to 2000 characters (after every 510 characters, you must press <Enter> to continue).

DEFAULT CONFIGURATION

Disabled (no MOTD banner is displayed).

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

When a user connects to a device, the message-of-the-day (MOTD) banner appears first, followed by the login banner and prompts. After the user logs in to the device, the EXEC banner is displayed.

Use tokens in the form of **\$(token)** in the message text to customize the banner. The tokens are described in the table below:

Token	Information displayed in the banner
\$(hostname)	Displays the host name for the device.
\$(domain)	Displays the domain name for the device.
\$(bold)	Indicates that the next text is a bold text. Using this token again indicates the end of the bold text.
\$(inverse)	Indicates that the next text is an inverse text. Using this token again indicates the end of the inverse text.
\$(contact)	Displays the system contact string.
\$(location)	Displays the system location string.
\$(mac-address)	Displays the base MAC address of the device.

Use the **no motd-banner** line configuration command to disable the MOTD banner on a particular line or lines.

EXAMPLE

The following example sets an MOTD banner that uses tokens. The percent sign (%) is used as a delimiting character. Note that the **\$(token)** syntax is replaced by the corresponding configuration variable.

```
Device(config)# banner motd %
Enter TEXT message. End with the character '%'.
$(bold)Upgrade$(bold) to all devices begins at March 12
%
When the login banner is executed, the user will see the following banner:
Upgrade to all devices begins at March 12
```

exec-banner Use the **exec-banner** command in Line Configuration mode to enable the display of exec banners. Use the **no** form of this command to disable the display of exec banners.

SYNTAX

exec-banner
no exec-banner

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Disabled

COMMAND MODE

Line Configuration mode

EXAMPLE

```
console# configure
console(config)# line console
console(config-line)# exec-banner
console(config-line)# exit
console(config)# line telnet
console(config-line)# exec-banner
console(config-line)# exit
console(config)# line ssh
console(config-line)# exec-banner
```

login-banner Use the **login-banner** command in Line Configuration mode to enable the display of login banners. Use the **no** form of this command to disable the display of login banners.

SYNTAX

login-banner
no login-banner

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Enabled

COMMAND MODE

Line Configuration mode

EXAMPLE

```
console# configure
console(config)# line console
console(config-line)# login-banner
console(config-line)# exit
console(config)# line telnet
console(config-line)# login-banner
console(config-line)# exit
console(config)# line ssh
console(config-line)# login-banner
```

motd-banner Use the **motd-banner** command in Line Configuration mode to enable the display of message-of-the-day banners. Use the **no** form of this command to disable the display of MOTD banners.

SYNTAX

motd-banner

no motd-banner

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Enabled

COMMAND MODE

Line Configuration mode

EXAMPLE

```
console# configure
console(config)# line console
console(config-line)# motd-banner
console(config-line)# exit
console(config)# line telnet
console(config-line)# motd-banner
console(config-line)# exit
console(config)# line ssh
console(config-line)# motd-banner
```

show banner Use the **show banner** command in EXEC mode to display the configuration of banners.

SYNTAX

show banner motd

show banner login

show banner exec

PARAMETERS

This command has no arguments or keywords.

COMMAND MODE

EXEC mode

EXAMPLES

```
Device> show banner motd
Banner: MOTD
Line SSH: Enabled
Line Telnet: Enabled
Line Console: Enabled
10000 giga ports switch

console#
console# show banner login
-----
Banner: Login
Line SSH: Enabled
Line Telnet: Enabled
Line Console: Enabled

console#
console# show banner exec
```

```
Banner: EXEC
Line SSH: Enabled
Line Telnet: Enabled
Line Console: Enabled
dsadsa

console#
```

ping Use the **ping** command to send ICMP echo request packets to another node on the network.

SYNTAX

```
ping [ip] {ipv4-address | hostname} [size packet_size] [count  
packet_count] [timeout time_out]
```

```
ping ipv6 {ipv6-address | hostname} [size packet_size] [count  
packet_count] [timeout time_out]
```

PARAMETERS

- ◆ **ip**—Use IPv4 to check the network connectivity.
- ◆ **ipv6**—Use IPv6 to check the network connectivity.
- ◆ **ipv4-address**—IPv4 address to ping.
- ◆ **ipv6-address**—Unicast or multicast IPv6 address to ping. When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. Refer to the User Guidelines for the interface name syntax.
- ◆ **hostname**—Hostname to ping (160 characters. Maximum label size: 63.)
- ◆ **packet_size**—Number of bytes in the packet not including the VLAN tag. The default is 64 bytes. (IPv4: 64-1518, IPv6: 68-1518)
- ◆ **packet_count**—Number of packets to send, from 1 to 65535 packets. The default is 4 packets. If 0 is entered, it pings until stopped (0-65535).
- ◆ **time-out**—Timeout in milliseconds to wait for each reply, from 50 to 65535 milliseconds. The default is 2000 milliseconds (50-65535).

COMMAND MODE

EXEC mode

USER GUIDELINES

Press **Esc** to stop pinging. Following are sample results of the ping command:

- ◆ **Destination does not respond**—If the host does not respond, a “no answer from host” appears within 10 seconds.

- ◆ **Destination unreachable**—The gateway for this destination indicates that the destination is unreachable.
- ◆ **Network or host unreachable**—The switch found no corresponding entry in the route table.

The format of an **IPv6Z** address is: *<ipv6-link-local-address>%<interface-name>*

- ◆ **interface-name** = *vlan<integer> | ch<integer> | isatap<integer> | <physical-port-name> | 0*
- ◆ **integer** = *<decimal-number> | <integer><decimal-number>*
- ◆ **decimal-number** = *0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9*
- ◆ **physical-port-name** = Designated port number, for example te1

When using the ping **ipv6** command to check network connectivity of a directly attached host using its link local address, the egress interface may be specified in the **IPv6Z** format. If the egress interface is not specified, the default interface is selected. Specifying interface zone=0 is equivalent to not defining an egress interface.

When using the ping **ipv6** command with MC address, the information displayed is taken from all received echo responses.

EXAMPLES

```

Console> ping ip 10.1.1.1
Pinging 10.1.1.1 with 64 bytes of data:

64 bytes from 10.1.1.1: icmp_seq=0. time=11 ms
64 bytes from 10.1.1.1: icmp_seq=1. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=2. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=3. time=7 ms

----10.1.1.1 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 7/8/11

Console> ping ip yahoo.com
Pinging yahoo.com [66.218.71.198] with 64 bytes of data:

64 bytes from 10.1.1.1: icmp_seq=0. time=11 ms
64 bytes from 10.1.1.1: icmp_seq=1. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=2. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=3. time=7 ms

----10.1.1.1 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 7/8/11

Console> ping ip oob/176.16.1.1
Pinging oob/176.16.1.1 with 64 bytes of data:

64 bytes from oob/176.16.1.1: icmp_seq=0. time=5 ms
64 bytes from oob/176.16.1.1: icmp_seq=1. time=5 ms
64 bytes from oob/176.16.1.1: icmp_seq=2. time=5 ms
64 bytes from oob/176.16.1.1: icmp_seq=3. time=5 ms

```

```

----10.1.1.1 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 5/5/5

console> ping ipv6 3003::11
Pinging 3003::11 with 64 bytes of data:

64 bytes from 3003::11: icmp_seq=1. time=0 ms
64 bytes from 3003::11: icmp_seq=2. time=50 ms
64 bytes from 3003::11: icmp_seq=3. time=0 ms
64 bytes from 3003::11: icmp_seq=4. time=0 ms

---3003::11 PING Statistics---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 0/12/50

console> ping ipv6 FF02::1
Pinging FF02::1 with 64 bytes of data:

64 bytes from 3003::11: icmp_seq=1. time=0 ms
64 bytes from 3003::33: icmp_seq=1. time=70 ms
64 bytes from 3003::11: icmp_seq=2. time=0 ms
64 bytes from 3003::55: icmp_seq=1. time=1050 ms
64 bytes from 3003::33: icmp_seq=2. time=70 ms
64 bytes from 3003::55: icmp_seq=2. time=1050 ms
64 bytes from 3003::11: icmp_seq=3. time=0 ms
64 bytes from 3003::33: icmp_seq=3. time=70 ms
64 bytes from 3003::11: icmp_seq=4. time=0 ms
64 bytes from 3003::55: icmp_seq=3. time=1050 ms
64 bytes from 3003::33: icmp_seq=4. time=70 ms
64 bytes from 3003::55: icmp_seq=4. time=1050 ms

---- FF02::1 PING Statistics----
4 packets transmitted, 12 packets received

```

traceroute To discover (?) the routes that packets will take when traveling to their destination, use the **traceroute** EXEC command.

SYNTAX

traceroute ip {*ipv4-address* | *hostname*} [*size packet_size*] [*ttl max-ttl*] [*count packet_count*] [*timeout time_out*] [*source ip-address*] [*tos tos*]

traceroute ipv6 {*ipv6-address* | *hostname*} [*size packet_size*] [*ttl max-ttl*] [*count packet_count*] [*timeout time_out*] [*source ip-address*] [*tos tos*]

PARAMETERS

- ◆ **ip**—Use IPv4 to discover the route.
- ◆ **ipv6**—Use IPv6 to discover the route.
- ◆ **ipv4-address**—IPv4 address of the destination host. (Range: Valid IP address)
- ◆ **ipv6-address**—IPv6 address of the destination host.

- ◆ **hostname**—Hostname of the destination host. (Range: 1–160 characters. Maximum label size: 63.)
- ◆ **packet_size**—Number of bytes in the packet not including the VLAN tag. The default is 64 bytes. (IPv4:64-1518, IPv6: 68-1518)
- ◆ **ttl max-ttl**—The largest TTL value that can be used. The default is 30. The **traceroute** command terminates when the destination is reached or when this value is reached. (Range: 1–255)
- ◆ **count packet_count**—The number of probes to be sent at each TTL level. The default count is 3. (Range: 1–10)
- ◆ **timeout time_out**—The number of seconds to wait for a response to a probe packet. The default is 3 seconds. (Range: 1–60)
- ◆ **source ip-address**—One of the interface addresses of the device to use as a source address for the probes. The device will normally pick what it feels is the best source address to use. (Range: Valid IP address)
- ◆ **tos tos**—The Type-Of-Service byte in the IP Header of the packet.(Range: 0–255)

COMMAND MODE

EXEC mode

USER GUIDELINES

The traceroute command works by taking advantage of the error messages generated by routers when a datagram exceeds its time-to-live (TTL) value.

The traceroute command starts by sending probe datagrams with a TTL value of one. This causes the first router to discard the probe datagram and send back an error message. The traceroute command sends several probes at each TTL level and displays the round-trip time for each.

The traceroute command sends out one probe at a time. Each outgoing packet can result in one or two error messages. A "time exceeded" error message indicates that an intermediate router has seen and discarded the probe. A "destination unreachable" error message indicates that the destination node has received the probe and discarded it because it could not deliver the packet. If the timer goes off before a response comes in, the traceroute command prints an asterisk (*).

The traceroute command terminates when the destination responds, when the maximum TTL is exceeded, or when the user interrupts the trace with Esc.

The traceroute command is not relevant to IPv6 link local addresses.

EXAMPLE

```

Router> traceroute ip umaxpl.physics.lsa.umich.edu
Type Esc to abort.
Tracing the route to umaxpl.physics.lsa.umich.edu (141.211.101.64)
 0  i2-gateway.stanford.edu (192.68.191.83)  0 msec 0 msec 0 msec
 1  STAN.POS.calren2.NET (171.64.1.213)  0 msec 0 msec 0 msec
 2  SUNV--STAN.POS.calren2.net (198.32.249.73)  1 msec 1 msec 1 msec
 3  Abilene--QSV.POS.calren2.net (198.32.249.162)  1 msec 1 msec 1 msec
 4  kscying-snvang.abilene.ucaid.edu (198.32.8.103)  33 msec 35 msec 35 msec
 5  iplsng-kscying.abilene.ucaid.edu (198.32.8.80)  47 msec 45 msec 45 msec
 6  so-0-2-0x1.aa1.mich.net (192.122.183.9)  56 msec 53 msec 54 msec
 7  atm1-0x24.michnet8.mich.net (198.108.23.82)  56 msec 56 msec 57 msec
 8  * * *
 9  A-ARB3-LSA-NG.C-SEB.umnet.umich.edu (141.211.5.22)  58 msec 58 msec 58 msec
10  umaxpl.physics.lsa.umich.edu (141.211.101.64)  62 msec 63 msec 63 msec
Trace completed

```

The following table describes the significant fields shown in the display:

Field	Description
1	Indicates the sequence number of the router in the path to the host.
i2-gateway.stanford.edu	Host name of this router.
192.68.191.83	IP address of this router.
1 msec 1 msec 1 msec	Round-trip time for each of the probes that are sent.

The following are characters that can appear in the traceroute command output:

Field	Description
*	The probe timed out.
?	Unknown packet type.
A	Administratively unreachable. Usually, this output indicates that an access list is blocking traffic.
F	Fragmentation required and DF is set.
H	Host unreachable.
N	Network unreachable.
P	Protocol unreachable.
Q	Source quench.
R	Fragment reassembly time exceeded
S	Source route failed.
U	Port unreachable.

telnet The **telnet** EXEC mode command enables logging on to a host that supports Telnet.

SYNTAX

```
telnet {ip-address | hostname} [port] [keyword ...]
```

PARAMETERS

- ◆ **ip-address**—Specifies the destination host IP address.
- ◆ **hostname**—Specifies the destination host name. (Length: 1-160 characters. Maximum label length: 63 characters.)
- ◆ **port**—Specifies the decimal TCP port number or one of the keywords listed in the Ports table in the User Guidelines.
- ◆ **keyword**—Specifies the one or more keywords listed in the Keywords table in the User Guidelines.

DEFAULT CONFIGURATION

The default port is the Telnet port (23) on the host.

By default, Telnet is enabled.

COMMAND MODE

EXEC mode

USER GUIDELINES

Telnet software supports special Telnet commands in the form of Telnet sequences that map generic terminal control functions to operating system-specific functions. To enter a Telnet sequence, press the escape sequence keys (Ctrl-shift-6) followed by a Telnet command character.

Special Telnet Sequences

Telnet Sequence	Purpose
Ctrl-shift-6-b	Break
Ctrl-shift-6-c	Interrupt Process (IP)
Ctrl-shift-6-h	Erase Character (EC)
Ctrl-shift-6-o	Abort Output (AO)
Ctrl-shift-6-t	Are You There? (AYT)
Ctrl-shift-6-u	Erase Line (EL)

At any time during an active Telnet session, available Telnet commands can be listed by pressing the Ctrl-shift-6-? keys at the system prompt.

A sample of this list follows. Note that the Ctrl-shift-6 sequence appears as ^^ on the screen.

```

Console> `Ctrl-shift-6` ?
[Special telnet escape help]
^^ B sends telnet BREAK
^^ C sends telnet IP
^^ H sends telnet EC
^^ O sends telnet AO
^^ T sends telnet AYT
^^ U sends telnet EL
Ctrl-shift-6 x suspends the session (return to system command prompt)

```

Several concurrent Telnet sessions can be opened, enabling switching between the sessions. To open a subsequent session, the current connection has to be suspended by pressing the escape sequence keys (Ctrl-shift-6) and x to return to the system command prompt. Then open a new connection with the telnet EXEC mode command.

This command lists concurrent Telnet connections to remote hosts that were opened by the current Telnet session to the local device. It does not list Telnet connections to remote hosts that were opened by other Telnet sessions.

Keywords Table

Options	Description
/echo	Enables local echo.
/quiet	Prevents onscreen display of all messages from the software.
/source-interface	Specifies the source interface.
/stream	Turns on stream processing, which enables a raw TCP stream with no Telnet control sequences. A stream connection does not process Telnet options and can be appropriate for connections to ports running UNIX-to-UNIX Copy Program (UUCP) and other non-Telnet protocols.
Ctrl-shift-6 x	Returns to the System Command Prompt.

Ports Table

Keyword	Description	Port Number
BGP	Border Gateway Protocol	179
chargen	Character generator	19
cmd	Remote commands	514
daytime	Daytime	13
discard	Discard	9
domain	Domain Name Service	53
echo	Echo	7
exec	Exec	512
finger	Finger	79

Ports Table

Keyword	Description	Port Number
ftp	File Transfer Protocol	21
ftp-data	FTP data connections	20
gopher	Gopher	70
hostname	NIC hostname server	101
ident	Ident Protocol	113
irc	Internet Relay Chat	194
klogin	Kerberos login	543
kshell	Kerberos shell	544
login	Login	513
lpd	Printer service	515
nntp	Network News Transport Protocol	119
pim-auto-rp	PIM Auto-RP	496
pop2	Post Office Protocol v2	109
pop3	Post Office Protocol v3	110
smtp	Simple Mail Transport Protocol	25
sunrpc	Sun Remote Procedure Call	111
syslog	Syslog	514
tacacs	TAC Access Control System	49
talk	Talk	517
telnet	Telnet	23
time	Time	37
uucp	Unix-to-Unix Copy Program	540
whois	Nickname	43
www	World Wide Web	80

EXAMPLE

The following example displays logging in to IP address 176.213.10.50 via Telnet.

```
Console> telnet 176.213.10.50
Esc U sends telnet EL
```

resume The **resume** EXEC mode command enables switching to another open Telnet session.

SYNTAX

resume [*connection*]

PARAMETERS

connection—Specifies the connection number. (Range: 1-4 connections.)

DEFAULT CONFIGURATION

The default connection number is that of the most recent connection.

COMMAND MODE

EXEC mode

EXAMPLE

The following command switches to open Telnet session number 1.

```
Console> resume 1
```

hostname The **hostname** Global Configuration mode command specifies or modifies the device host name. Use the **no** form of the command to remove the existing host name.

SYNTAX

hostname *name*

no hostname

PARAMETERS

Name—specifies The Device Host Name. (Length: 1-160 Characters. Maximum label length: 63 characters.)

DEFAULT CONFIGURATION

No host name is defined.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example specifies the device host name as 'enterprise'.

```
Console(config)# hostname enterprise
enterprise(config)#
```

reload The **reload** Privileged EXEC mode command reloads the operating system.

SYNTAX

reload

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example reloads the operating system.

```
Console# reload
This command will reset the whole system and disconnect your current session.
Do you want to continue? (y/n) [n]
```

**service cpu-
utilization**The **service cpu-utilization** Global Configuration mode command enables measuring CPU utilization. Use the **no** form of this command to restore the default configuration.**SYNTAX****service cpu-utilization****no service cpu-utilization****DEFAULT CONFIGURATION**

Measuring CPU utilization is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINESUse the **show cpu utilization** Privileged EXEC command to view information on CPU utilization.**EXAMPLE**

The following example enables measuring CPU utilization.

```
Console(config)# service cpu-utilization
```

show cpu utilizationThe **show cpu utilization** Privileged EXEC mode command displays information about CPU utilization.**SYNTAX****show cpu utilization****COMMAND MODE**

Privileged EXEC mode

USER GUIDELINES

Use the **service cpu-utilization** Global Configuration mode command to enable measuring CPU utilization.

EXAMPLE

The following example displays CPU utilization information.

```
Console# show cpu utilization
CPU utilization service is on.
CPU utilization
-----
five seconds: 5%; one minute: 3%; five minutes: 3%
```

clear cpu counters The **clear cpu counters** EXEC mode command clears traffic counters to and from the CPU.

SYNTAX

clear cpu counters

COMMAND MODE

EXEC mode

EXAMPLE

The following example clears the CPU traffic counters.

```
Console# clear cpu counters
```

service cpu-counters The **service cpu-counters** Global Configuration mode command enables traffic counting to and from the CPU. To disable counting, use the **no** form of this command.

SYNTAX

service cpu-counters

no service cpu-counters

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use the **show cpu counters** command to display the CPU traffic counters.

EXAMPLE

The following example enables counting CPU traffic.

```
Console(config)# service cpu-counters
```

show cpu counters The **show cpu counters** EXEC mode command displays traffic counter information to and from the CPU.

SYNTAX

show cpu counters

COMMAND MODE

EXEC mode

USER GUIDELINES

Use the **service cpu-counters** command to enable traffic counting to and from the CPU.

EXAMPLE

The following example displays the CPU traffic counters.

```
Console# show cpu counters

CPU counters are active.

In Octets: 987891
In Unicast Packets: 3589
In Multicast Packets: 29
In Broadcast Packets: 8

Out Octets: 972181
Out Unicast Packets: 3322
Out Multicast Packets: 22
Out Broadcast Packets: 8
```

show users The **show users** EXEC mode command displays information about the active users.

SYNTAX

show users

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays information about the active users.

```

Console# show users

Username      Protocol      Location
-----
Bob           -             -
John          Serial        172.16.0.1
Robert        SSH           172.16.0.8
Betty         HTTP          172.16.1.7
Sam           Telnet        172.16.1.6

```

show sessions The **show sessions** EXEC mode command displays open Telnet sessions.

SYNTAX

show sessions

COMMAND MODE

EXEC mode

USER GUIDELINES

The command displays Telnet sessions to remote hosts opened by the current Telnet session to the local device. It does not display Telnet sessions to remote hosts opened by other Telnet sessions to the local device.

EXAMPLE

The following example displays open Telnet sessions.

```

Console# show sessions

Connection    Host          Address      Port      Byte
-----
1             Remote router 172.16.1.1   23        89
2             172.16.1.2    172.16.1.2   23        8

```

The following table describes significant fields shown above.

Field	Description
Connection	The connection number.
Host	The remote host to which the device is connected through a Telnet session.
Address	The remote host IP address.
Port	The Telnet TCP port number.
Byte	The number of unread bytes for the user to see on the connection.

show system The **show system** EXEC mode command displays system information.

SYNTAX

show system

PARAMETERS

There are no parameters for this command.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the system information.

```

console# show system
System Description:          Standalone Managed L3 10G Switch with
                             48 SFP+ slots
System Up Time (days, hour:min:sec):    00,02:21:59
System Contact:
System Name:
System Location:
System MAC Address:          00:08:f2:66:66:66
System Object ID:           1.3.6.1.4.1.259.10.1.14

Main Power Supply Status:      OK
Fan 1 Status:                  OK

```

Unit	Temperature (Celsius)	Status
1	37	OK

show version The **show version** EXEC mode command displays system version information.

SYNTAX

show version

PARAMETERS

There are no parameters for this command.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays system version information.

```

console > show version
SW version    2.0.0.24 ( date 10-Jan-2011 time 11:57:59 )
Boot version  0.0.2.1 ( date 09-Jan-2011 time 11:47:11 )

```

```
HW version    00.00.01
```

system resources routing

The **system resources routing** Global Configuration mode command configures the routing table maximum size. Use the **no** form of this command to return to the default size.

SYNTAX

system resources routing *routes hosts interfaces*

no system resources routing

PARAMETERS

- ◆ **routes**—Specifies the maximum number of remote networks in the routing table.
- ◆ **hosts**—Specifies the maximum number of directly attached hosts.
- ◆ **interfaces**—Specifies the maximum number of IP interfaces.

DEFAULT CONFIGURATION

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The settings are effective after reboot.

EXAMPLE

The following example configures the routing table maximum size.

```
Console# system resources routing 20 23 5
```

show system resources routings

The **show system resources routings** EXEC mode command displays system routing resources information.

SYNTAX

show system resources routings

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the system routing resources information.

```
Console> show system resources routings
```

Parameters	Current value	After reboot Value
-----	-----	-----
Hosts:	100	100
Routes:	32	32
IP Interfaces:	32	32

show system tcam utilization The **show system tcam utilization** EXEC mode command displays the Ternary Content Addressable Memory (TCAM) utilization.

SYNTAX

show system tcam utilization

PARAMETERS

There are no parameters for this command.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays TCAM utilization information.

```
Console> show system tcam utilization
```

```
TCAM utilization: 58%
```

show system defaults Use the **show system defaults** command to display system defaults.

SYNTAX

show system defaults [*section*]

PARAMETERS

section—Show information for specific session only. Available values are: management, 802.1x, port, fdb, port-mirroring, spanning-tree, vlan, voice-vlan, ip-addressing, network-security and qos-acl.

COMMAND MODE

EXEC mode

EXAMPLES

```
console# show system defaults
System Mode: Router
Maximum units in stack: 8
# Management defaults
Telnet: Enabled (Maximum 4 sessions, shared with SSH)
SSH: Enabled (Maximum 4 sessions, shared with Telnet)
```

```

HTTP: Enabled, port 80 (Maximum 27 sessions)
HTTPS: Disabled
SNMP: Enabled.
    User: first
SNMP version: V3
SNMP Local Engine ID: 0000000001
SNMP Notifications: Enabled
SNMP Authentication Notifications: Enabled
Console: Enabled.
Cryptographic keys are not generated
HTTPS certificate is not generated
Management ACL: No ACL is defined
AAA Telnet authentication login: Local user data base
AAA HTTP authentication login: Local data base
AAA HTTPS authentication login: Local data base
Radius accounting: Disabled
Radius: No server is defined
Tacacs: No server is defined
Syslog: No server is defined
Logging: Enabled
Logging to console: Informational messages
Logging to internal buffer: Informational messages
Logging to file: Error messages
Logging to remote server: Informational messages
Maximum no. of syslog messages: 200
SNTP: supported
SNTP Port No.: 123
SNTP Interface: Enabled
IP Domain Naming System: Enabled
DHCP Server: Enabled
DHCP Auto Configuration: Enabled
DHCP Option 67: Enabled
DHCP Option 82: Disabled

# IPv6 defaults

# 802.1x defaults
802.1X is disabled
Mode: Multiple host
Guest VLAN: Not defined

# Interface defaults in present unit
48 GE regular
2 10G fiberOptics
PoE: Enabled
POE mode: Port Limit
Duplex: Full
Negotiation: Enabled
Flow control: Off
Mdix mode: auto
LAGs: No LAG is defined
Storm control: Disabled
Storm control mode: unknown unicast, broadcast, multicast
Port security: Disabled
LLDP: Enabled
LLDPDU Handling: Filtering
Jumbo frames: Disabled
Port-Channel Load Balancing: Layer 2

# Bridging defaults
Maximum 16K entries
Aging time: 5 minutes
iSCSI: Enabled
iSCSI cos: 5, with no remark

```

```

# Multicast defaults
Multicast filtering: Disabled
IGMP snooping: Disabled
IGMP Querier: Disabled
Multicast TV Vlan Interface: disabled

# Port monitoring defaults
Port monitor is not defined
Maximum source port: 4
Maximum destination ports for mirroring: 2

# Spanning tree defaults
Spanning tree is Enabled
Spanning tree mode is Classic
Spanning tree interface: Enabled
Port fast: Disabled
BPDU handling: Filtering
BPDU Guard: Disabled

# Vlan defaults
Maximum Vlans: 4094
Default VLAN: Enabled
Default VLAN id: 1
GVRP: Disabled
Port mode: undefined
PVID: 1
VLAN membership: 1

# Voice vlan defaults
Voice VLAN: Disabled
Cos: 6 with no remark
OUI table:
00:E0:BB      3COM
00:03:6B      Cisco
00:E0:75      Veritel
00:D0:1E      Pingtel
00:01:E3      Simens
00:60:B9      NEC/Philips
00:0F:E2      Huawei-3COM
00:09:6E      Avaya

# Network security defaults
DHCP snooping: Disabled
ARP inspection: Disabled
ARP inspection Validation: Disabled

# DOS attacks

# IP addressing defaults
No IP interface is defined

# QoS and ACLs defaults
QoS mode is basic
QoS Basic Trust Mode: CoS
QoS Advanced Trust Mode: CoS-DSCP
Queue default mapping:
cos  qid:
0     2
1     1
2     1
3     3
4     4
5     5
6     6

```

7 7

show tech-support Use the **show tech-support** command to display system and configuration information you can provide to the Technical Assistance Center when reporting a problem.

SYNTAX

show tech-support [*config*] [*memory*]

PARAMETERS

Memory—Displays memory and processor state data.

Config—Displays switch configuration within the CLI commands supported on the device.

DEFAULT CONFIGURATION

By default, this command displays the output for technical-support-related show commands. Use keywords to specify the type of information to be displayed. If you do not specify any parameters, the system displays all configuration and memory data.

COMMAND TYPES

Switch command.

COMMAND MODE

EXEC mode

USER GUIDELINES



CAUTION: Avoid running multiple **show tech-support** commands on a switch or multiple switches on the network segment. Doing so may cause starvation of some time sensitive protocols, like STP.

The show tech-support command may timeout if the configuration file output takes longer to display than the configured session timeout time. If this happens, enter a set logout timeout value of **0** to disable automatic disconnection of idle sessions or enter a longer timeout value.

The show tech-support command output is continuous, it does not display one screen at a time. To interrupt the output, press Esc.

If you specify the **config** keyword, the show tech-support command displays a list of the commands supported on the device.

If user specifies the **memory** keyword, the show tech-support command displays the output:

flash info (dir if existed, or flash mapping)

show bootvar**buffers info** (like print os buff)**memory info** (like print os mem)**proc info** (like print os tasks)

versions of software components

show cpu utilization

show system id The **show system id** EXEC mode command displays the system identity information.

SYNTAX**show system id****PARAMETERS**

There are no parameters for this command.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the system identity information.

```
Console> show system id
Serial number : AC5210000024
```


clock set The **clock set** Privileged EXEC mode command manually sets the system clock.

SYNTAX

clock set *hh:mm:ss* {[*day month*] | [*month day*]} *year*

Parameters

- ◆ **hh:mm:ss**—Specifies the current time in hours (military format), minutes, and seconds. (Range: hh: 0-23, mm: 0-59, ss: 0-59)
- ◆ **day**—Specifies the current day of the month. (Range: 1-31)
- ◆ **month**—Specifies the current month using the first three letters of the month name. (Range: Jan-Dec)
- ◆ **year**—Specifies the current year. (Range: 2000–2037)

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

The user should enter the local clock time and date.

EXAMPLE

The following example sets the system time to 13:32:00 on March 7th, 2005.

```
Console# clock set 13:32:00 7 Mar 2005
```

clock source The **clock source** Global Configuration mode command configures an external time source for the system clock. Use the **no** form of this command to disable the external time source.

SYNTAX

clock source {**sntp**}
no clock source

PARAMETERS

sntp—Specifies that an SNTP server is the external clock source.

DEFAULT CONFIGURATION

There is no external clock source.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures an SNTP server as an external time source for the system clock.

```
Console(config)# clock source sntp
```

clock timezone Use the **clock timezone** Global Configuration command to set the time zone for display purposes. Use the **no** form of this command to set the time to Coordinated Universal Time (UTC) or Greenwich Mean Time (GMT), which is the same.

SYNTAX

clock timezone *zone hours-offset [minutes-offset]*

no clock timezone

PARAMETERS

- ◆ **zone**—The acronym of the time zone. (Range: Up to 4 characters)
- ◆ **hours-offset**—Hours difference from UTC. (Range: (-12)–(+13))
- ◆ **minutes-offset**—Minutes difference from UTC. (Range: 0–59)

DEFAULT CONFIGURATION

Offset is **0**.

Acronym is empty.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The system internally keeps time in UTC, so this command is used only for display purposes and when the time is manually set.

EXAMPLE

```
console(config)# clock timezone abc +2 minutes 32
```

clock summer-time Use one of the formats of the **clock summer-time** Global Configuration command to configure the system to automatically switch to summer time (daylight saving time). Use the **no** form of this command to configure the software not to automatically switch to summer time.

SYNTAX

clock summer-time *zone recurring {usa | eu | {week day month hh:mm week day month hh:mm}} [offset]*

clock summer-time *zone date date month year hh:mm date month year hh:mm [offset]*

clock summer-time *zone date month date year hh:mm month date year hh:mm [offset]*

no clock summer-time

PARAMETERS

- ◆ **zone**—The acronym of the time zone to be displayed when summer time is in effect. (Range: Up to 4 characters)
- ◆ **recurring**—Indicates that summer time should start and end on the corresponding specified days every year.
- ◆ **date**—Indicates that summer time should start on the first specific date listed in the command and end on the second specific date in the command.
- ◆ **usa**—The summer time rules are the United States rules.
- ◆ **eu**—The summer time rules are the European Union rules.
- ◆ **week**—Week of the month. Can be 1–4, first, last.
- ◆ **day**—Day of the week (first three letters by name, such as Sun). (characters)
- ◆ **date**—Date of the month. (Range: 1–31)
- ◆ **month**—Month (first three letters by name, such as Feb). (characters)
- ◆ **year**—year (no abbreviation). (Range: 2000–2097)
- ◆ **hh:mm**—Time (military format) in hours and minutes. (Range: hh:mmhh: 0-23, mm: 0-59)
- ◆ **offset**—Number of minutes to add during summer time (default is 60). (Range: 1440)

DEFAULT CONFIGURATION

Summer time is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

In both the date and recurring forms of the command, the first part of the command specifies when summer time begins, and the second part specifies when it ends. All times are relative to the local time zone. The start time is relative to standard time. The end time is relative to summer time. If the starting month is chronologically after the ending month, the system assumes that you are in the southern hemisphere.

USA rule for daylight saving time:

- ◆ From 2007:
 - Start: Second Sunday in March
 - End: First Sunday in November
 - Time: 2 am local time
- ◆ Before 2007:
 - Start: First Sunday in April
 - End: Last Sunday in October
 - Time: 2 am local time

EXAMPLE

```
console(config)# clock summer-time abc date apr 1 2010 09:00 aug 2 2010 09:00

EU rule for daylight saving time:
Start: Last Sunday in March
End: Last Sunday in October
Time: 1.00 am (01:00) Greenwich Mean Time (GMT)
```

sntp authentication-key The **sntp authentication-key** Global Configuration mode command defines an authentication key for Simple Network Time Protocol (SNTP). Use the **no** form of this command to remove the authentication key for SNTP.

SYNTAX

sntp authentication-key *key-number* **md5** *key-value*
no sntp authentication-key *key-number*

PARAMETERS

- ◆ **key-number**—Specifies the key number. (Range: 1–4294967295)
- ◆ **key-value**—Specifies the key value. (Length: 1–8 characters)

DEFAULT CONFIGURATION

No authentication key is defined.

COMMAND MODE

Global Configuration mode

EXAMPLES

The following example defines the authentication key for SNTP.

```
Console(config)# sntp authentication-key 8 md5 ClkKey
```

```
Device(config)# sntp authentication-key 8 md5 ClkKey
Device(config)# sntp trusted-key 8
Device(config)# sntp authenticate
```

sntp authenticate The **sntp authenticate** Global Configuration mode command enables authentication for received Simple Network Time Protocol (SNTP) traffic from servers. Use the **no** form of this command to disable the feature.

SYNTAX

sntp authenticate

no sntp authenticate

DEFAULT CONFIGURATION

Authentication is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The command is relevant for both unicast and broadcast.

EXAMPLES

The following example enables authentication for received SNTP traffic.

```
Console(config)# sntp authenticate
```

```
Device(config)# sntp authentication-key 8 md5 ClkKey
Device(config)# sntp trusted-key 8
Device(config)# sntp authenticate
```

sntp trusted-key The **sntp trusted-key** Global Configuration mode command authenticates the system identity with which Simple Network Time Protocol (SNTP) synchronizes. Use the **no** form of this command to disable system identity authentication.

SYNTAX

sntp trusted-key *key-number*
no sntp trusted-key *key-number*

PARAMETERS

key-number—Specifies the key number of the authentication key to be trusted. (Range: 1–4294967295)

DEFAULT CONFIGURATION

No keys are trusted.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The command is relevant for both received unicast and broadcast.

EXAMPLES

The following example authenticates key 8.

```
Console(config)# sntp trusted-key 8
```

```
Device(config)# sntp authentication-key 8 md5 ClkKey
Device(config)# sntp trusted-key 8
Device(config)# sntp authenticate
```

sntp client poll timer The **sntp client poll timer** Global Configuration mode command sets the polling time for the Simple Network Time Protocol (SNTP) client. Use the **no** form of this command to restore the default configuration.

SYNTAX

sntp client poll timer *seconds*
no sntp client poll timer

PARAMETERS

seconds—Specifies the polling interval in seconds. (Range: 60–86400)

DEFAULT CONFIGURATION

The default polling interval is 1024 seconds.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example sets the polling time for the SNTP client to 120 seconds.

```
Console(config)# sntp client poll timer 120
```

sntp broadcast client enable

The **sntp broadcast client enable** Global Configuration mode command enables Simple Network Time Protocol (SNTP) broadcast clients. Use the **no** form of this command to disable SNTP broadcast clients.

SYNTAX

sntp broadcast client enable

no sntp broadcast client enable

DEFAULT CONFIGURATION

The SNTP broadcast client is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use the **sntp client enable** Interface Configuration mode command to enable the SNTP client on a specific interface.

EXAMPLE

The following example enables the SNTP broadcast clients.

```
Console(config)# sntp broadcast client enable
```

sntp anycast client enable

The **sntp anycast client enable** Global Configuration mode command enables the SNTP anycast client. Use the **no** form of this command to disable the SNTP anycast client.

SYNTAX

sntp anycast client enable

no sntp anycast client enable

DEFAULT CONFIGURATION

The SNTP anycast client is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The polling time is configured with the **sntp client poll timer** Global Configuration mode command.

Use the **sntp client enable** Interface Configuration mode command to enable the SNTP client on a specific interface.

EXAMPLE

The following example enables SNTP anycast clients.

```
Console(config)# sntp anycast client enable
```

sntp client enable The **sntp client enable** Global Configuration mode command enables the Simple Network Time Protocol (SNTP) broadcast and anycast client on an interface. Use the **no** form of this command to disable the SNTP client.

SYNTAX

sntp client enable *{interface-id}*

no sntp client enable *{interface-id}*

PARAMETERS

interface-id—Specifies an interface ID, which can be one of the following types: Ethernet port, Port-channel or VLAN.

DEFAULT CONFIGURATION

The SNTP client is disabled on an interface.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The **sntp broadcast client enable** Global Configuration mode command globally enables broadcast clients.

The **sntp anycast client enable** Global Configuration mode command globally enables anycast clients.

EXAMPLE

The following example enables the SNTP broadcast and anycast client on tengigabitethernet port te3

```
Console(config)# sntp client enable tengigabitethernet 0/3
```


sntp client enable (Interface) To enable the Simple Network Time Protocol (SNTP) broadcast and anycast client on an interface, use the **sntp client enable** Interface Configuration command. Use the **no** form of this command to disable the SNTP client.

The **sntp client enable** Interface Configuration (Ethernet, Port-channel, VLAN) mode command enables the Simple Network Time Protocol (SNTP) broadcast and anycast client on an interface. Use the **no** form of this command to disable the SNTP client.

SYNTAX

sntp client enable
no sntp client enable

DEFAULT CONFIGURATION

The SNTP client is disabled on an interface.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel, VLAN) mode

USER GUIDELINES

The **sntp broadcast client enable** Global Configuration mode command globally enables broadcast clients.

The **sntp anycast client enable** Global Configuration mode command globally enables anycast clients.

EXAMPLE

The following example enables the SNTP broadcast and anycast client on an interface.

```
Console(config-if)# sntp client enable
```

sntp unicast client enable The **sntp unicast client enable** Global Configuration mode command enables the device to use Simple Network Time Protocol (SNTP) predefined unicast clients. Use the **no** form of this command to disable the SNTP unicast clients.

SYNTAX

sntp unicast client enable
no sntp unicast client enable

DEFAULT CONFIGURATION

The SNTP unicast client is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use the **sntp server** Global Configuration mode command to define SNTP servers.

EXAMPLE

The following example enables the device to use Simple Network Time Protocol (SNTP) unicast clients.

```
Console(config)# sntp unicast client enable
```

sntp unicast client poll

The **sntp unicast client poll** Global Configuration mode command enables polling for the Simple Network Time Protocol (SNTP) predefined unicast clients. Use the **no** form of this command to disable the polling for the SNTP client.

SYNTAX

sntp unicast client poll
no sntp unicast client poll

DEFAULT CONFIGURATION

Polling is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Polling time is configured with the **sntp client poll timer** Global Configuration mode command.

EXAMPLE

The following example enables polling for SNTP predefined unicast clients.

```
Console(config)# sntp unicast client poll
```

sntp server

The **sntp server** Global Configuration mode command configures the device to use the Simple Network Time Protocol (SNTP) to request and accept Network Time Protocol (NTP) traffic from a specified server. Use the **no** form of this command to remove a server from the list of SNTP servers.

SYNTAX

sntp server {*ipv4-address* | *ipv6-address* | *ipv6z-address* |
hostname} [*poll*] [*key keyid*]

no sntp server {*ipv4-address* | *ipv6-address* | *ipv6z-address* | *hostname*}

PARAMETERS

- ◆ **ipv4-address**—Specifies the server IPv4 address.
- ◆ **ipv6-address**—Specifies the server IPv6 address. A Link Local address (IPv6Z address) can be defined.
- ◆ **pv6z-address**—Specifies the IPv6Z address to ping. The IPv6Z address format is: *ipv6-link-local-address*%*{interface-name}*. The subparameters are:
 - **interface-name**—Specifies the outgoing interface name. The interface name has the format: *vlan {integer}* | *ch {integer}* | *isatap {integer}* | *{physical-port-name}*. The subparameter integer has the format: *{decimal-digit}* | *{integer}{decimal-digit}*. (Range for the decimal-digit: 0–9)
- ◆ **hostname**—Specifies the server hostname. Only translation to IPv4 addresses is supported. (Length: 1–158 characters. Maximum label length: 63 characters)
- ◆ **poll**—Enables polling.
- ◆ **key keyid**—Specifies the Authentication key to use when sending packets to this peer. (Range:1–4294967295)

DEFAULT CONFIGURATION

No servers are defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Up to 8 SNTP servers can be defined.

The **sntp unicast client enable** Global Configuration mode command enables predefined unicast clients.

The **sntp unicast client poll** Global Configuration mode command globally enables polling.

Polling time is configured with the **sntp client poll timer** Global Configuration mode command.

The format of an IPv6Z address is: *<ipv6-link-local-address>%<interface-name>*.

interface-name = *vlan<integer>* | *ch<integer>* | *isatap<integer>* | *<physical-port-name>* | *0*

integer = *<decimal-number>* | *<integer><decimal-number>*

decimal-number = 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9

physical-port-name = Designated port number, for example:te16.

If the egress interface is not specified, the default interface is selected. Specifying interface zone=0 is equal to not defining an egress interface.

EXAMPLE

The following example configures the device to accept SNTP traffic from the server on 192.1.1.1.

```
Console(config)# sntp server 192.1.1.1
```

sntp port The **sntp port** Global Configuration mode command specifies a Simple Network Time Protocol (SNTP) User Datagram Protocol (UDP) port. Use the **no** form of this command to use the SNTP server default port.

SYNTAX

sntp port *port-number*

no sntp port

PARAMETERS

port-number—Specifies the UDP port number used by an SNTP server. (Range 1–65535)

DEFAULT CONFIGURATION

The default port number is 123.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example specifies that port 321 of the SNTP server is the UDP port.

```
Console(config)# sntp port 321
```

show clock The **show clock** EXEC mode command displays the time and date from the system clock.

SYNTAX

show clock [*detail*]

PARAMETERS

detail—Displays the TimeZone and SummerTime configuration.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the system time and date.

```

Console> show clock
15:29:03 PDT(UTC-7) Jun 17 2002
Time source is SNTP

Console> show clock detail
15:29:03 PDT(UTC-7) Jun 17 2002
Time source is SNTP

Time zone:
Acronym is PST
Offset is UTC-8

Summertime:
Acronym is PDT
Recurring every year.
Begins at first Sunday of April at 2:00.
Ends at last Sunday of October at 2:00.
Offset is 60 minutes.

DHCP timezone: Disabled

```

```

Device> show clock detail
15:29:03 PDT(UTC-7) Jun 17 2002
Time source is SNTP

Timezone (DHCP):
Acronym is PST
Offset is UTC-8

Timezone (static):
Acronym is PST
Offset is UTC-8

Summertime (Static):
Acronym is PDT
Recurring every year.
Begins at first Sunday of April at 2:00.
Ends at last Sunday of October at 2:00.
Offset is 60 minutes.

DHCP timezone: Enabled

```

show sntp configuration The **show sntp configuration** Privileged EXEC mode command displays the Simple Network Time Protocol (SNTP) configuration on the device.

SYNTAX

show sntp configuration

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the device's current SNTP configuration.

```
console# show sntp configuration
SNTP port : 123 .
Polling interval: 1024 seconds.
No MD5 authentication keys.
Authentication is not required for synchronization.
No trusted keys.

Unicast Clients: Enabled
Unicast Clients Polling: Enabled

-----
Server          Polling  Encryption Key
-----
1.1.1.121       Disabled Disabled

Broadcast Clients: disabled
Anycast Clients: disabled
No Broadcast Interfaces.
console#
```

show sntp status The **show sntp status** Privileged EXEC mode command displays the Simple Network Time Protocol (SNTP) servers status.

SYNTAX

show sntp status

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the SNTP servers status.

```
Console# show sntp status
```

```
Clock is synchronized, stratum 4, reference is 176.1.1.8, unicast
Reference time is AFE2525E.70597B34 (00:10:22.438 PDT Jul 5 1993)
```

Unicast servers:

Server	Status	Last response	Offset [mSec]	Delay [mSec]
-----	-----	-----	-----	-----
176.1.1.8	Up	19:58:22.289 PDT Feb 19 2005	7.33	117.79
176.1.8.179	Unknown	12:17:17.987 PDT Feb 19 2005	8.98	189.19

Anycast server:

Server	Interface	Status	Last response	Offset [mSec]	Delay [mSec]
-----	-----	-----	-----	-----	-----
176.1.11.8	VLAN 118	Up	9:53:21.789 PDT Feb 19 2005	7.19	119.89

Broadcast:

Server	Interface	Last response
-----	-----	-----
176.9.1.1	VLAN 119	19:17:59.792 PDT Feb 19 2002

EXAMPLE

```
Device# show sntp status
```

```
Clock is synchronized, stratum 4, reference is 176.1.1.8, unicast
Reference time is AFE2525E.70597B34 (00:10:22.438 PDT Jul 5 1993)
```

Unicast servers:

Server	Status	Last response	Offset [mSec]	Delay [mSec]
-----	-----	-----	-----	-----
176.1.1.8	Up	19:58:22.289 PDT Feb 19 2002	7.33	117.79
176.1.8.179	Unknown	12:17:17.987 PDT Feb 19 2002	8.98	189.19

Broadcast:

Server	Interface	Last response
-----	-----	-----
176.9.1.1	VLAN 119	19:17:59.792 PDT Feb 19 2002

CONFIGURATION AND IMAGE FILE COMMANDS

iPECS ES-5048XG

copy The **copy** Privileged EXEC mode command copies files from a source to a destination.

SYNTAX

copy *source-url destination-url [snmp]*

PARAMETERS

- ◆ **source-url**—Specifies the source file location URL or source file reserved keyword to be copied. (Length: 1–160 characters)
- ◆ **destination-url**—Specifies the destination file URL or destination file reserved keyword. (Length: 1–160 characters)
- ◆ **snmp**—Specifies that the destination/source file is in SNMP format. Used only when copying from/to startup-config.

The following table displays URL options.

Keyword	Source or Destination
flash://	Source or destination URL for flash memory. This is the default URL. If a URL is specified without a prefix.
running-config	Currently running configuration file.
startup-config	Startup configuration file.
image	Image file. If specified as the source file, it is the active image file. If specified as the destination file, it is the non-active image file.
boot	Boot file.
tftp://	Source or destination URL for a TFTP network server. The syntax for this alias is <i>tftp://host/[directory]/filename</i> . The host can be either an IP address or a host name.
xmodem:	Source for the file from a serial connection that uses the Xmodem protocol.
null:	Null destination for copies or files. A remote file can be copied to null to determine its size.
backup-config	Backup configuration file.
unit://member/ backup-config	Backup configuration file.
WORD<1-128>	Specify URL prefixes.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

The location of a file system dictates the format of the source or destination URL.

The entire copying process may take several minutes and differs from protocol to protocol and from network to network.

If the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. The format of an IPv6Z address is: `{ipv6-link-local-address}%{interface-name}`. The subparameters are:

- ◆ **ipv6-link-local-address**—Specifies the IPv6 Link Local address.
- ◆ **interface-name**—Specifies the outgoing interface name. The interface name has the format: `vlan{integer} | ch{integer} | isatap{integer} | {physical-port-name}`. The subparameter *integer* has the format: `{decimal-digit} | {integer}{decimal-digit}`. *decimal-digit* has the range 0–9

If the egress interface is not specified, the default interface is selected. Specifying **interface zone=0** is equal to not defining an egress interface.

Understanding Invalid Combinations of Source and Destination

Some invalid combinations of source and destination exist. Specifically, if one of the following conditions exists:

- ◆ The source file and destination file are the same file.
- ◆ **xmodem:** is the destination file. The source file can be copied to **image**, **boot** and **null:** only.
- ◆ **tftp://** is the source file and destination file on the same copy.
- ◆ ***.prv** files cannot be copied.

The following table describes the copy characters:

Character	Description
!	For network transfers, indicates that the copy process is taking place. Each exclamation point indicates successful transfer of ten packets (512 bytes each).
.	For network transfers, indicates that the copy process timed out. Generally, several periods in a row means that the copy process may fail.s

Copying an Image File from a Server to Flash Memory

Use the **copy source-url image** command to copy an image file from a server to flash memory.

Copying a Boot File from a Server to Flash Memory

Use the **copy source-url boot** command to copy a boot file from a server to flash memory.

Copying a Configuration File from a Server to the Running Configuration File

Use the **copy source-url running-config** command to load a configuration file from a network server to the running device configuration file. The commands in the loaded configuration file are added to those in the running configuration file as if the commands were typed in the command-line interface (CLI). The resulting configuration file is a combination of the previous running configuration and the loaded configuration files, with the loaded configuration file taking precedence.

Copying a Configuration File from a Server to the Startup Configuration

Use the **copy source-url startup-config** command to copy a configuration file from a network server to the device startup configuration file. The startup configuration file is replaced by the copied configuration file.

Storing the Running or Startup Configuration on a Server

Use the **copy running-config destination-url** command to copy the current configuration file to a network server using TFTP, .

Use the **copy startup-config destination-url** command to copy the startup configuration file to a network server.

Saving The Running Configuration To The Startup Configuration

Use the **copy running-config startup-config** command to copy the running configuration to the startup configuration file.

Backing Up the Running Configuration or Startup Configuration to a Backup Configuration file

Use the **copy running-config file** command to back up the running configuration to a backup configuration file.

Use the **copy startup-config file** command to back up the startup configuration to a backup configuration file.

Backing Up the Running Configuration or Startup Configuration to the Backup Configuration

Use the **copy running-config backup-config** command to back up the running configuration to the backup configuration file.

Use the **copy startup-config backup-config** command to back up the startup configuration to the backup configuration file.

EXAMPLES

The following example copies system image file1 from the TFTP server 172.16.101.101 to a non-active image file.

```

Console# copy tftp://172.16.101.101/file1 image

Accessing file 'file1' on 172.16.101.101...
Loading file1 from 172.16.101.101:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!! [OK]
Copy took 0:01:11 [hh:mm:ss]

```

Copying an Image from a Server to Flash Memory

The following example copies a system image named file1 from the TFTP server with an IP address of 172.16.101.101 to a non-active image file.

```

Router# copy tftp://172.16.101.101/file1 image

Accessing file 'file1' on 172.16.101.101...
Loading file1 from 172.16.101.101:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!! [OK]
Copy took 0:01:11 [hh:mm:ss]

```

delete The **delete** Privileged EXEC mode command deletes a file from a flash memory device.

SYNTAX

delete *url*

PARAMETERS

url—Specifies the location URL or reserved keyword of the file to be deleted. (Length: 1–160 characters)

The following table displays keywords and URL prefixes:

Keyword	Source or Destination
flash://	URL of the flash memory. This is the default URL if a URL is specified without a prefix.
startup-config	Startup configuration file.
WORD	Specify URL prefixes.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

***.sys, *.prv, image-1** and **image-2** files cannot be deleted.

EXAMPLE

The following example deletes the file called 'test' from the flash memory.

```
Console# delete flash:test
Delete flash:test? [confirm]
```

dir The **dir** Privileged EXEC mode command displays the list of files on a flash file system.

SYNTAX

dir

dir *[directory-path]*

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the list of files on a flash file system

```
Total size of flash: 33292288 bytes
Free size of flash: 20708893 bytes

console# dir
Directory of flash:

File Name      Permission  Size Data Size      Modified
-----
tmp            rw          524288      104      01-Jan-2010 05:35:04
image-1        rw          10485760    10485760 01-Jan-2010 06:10:23
image-2        rw          10485760    10485760 01-Jan-2010 05:43:54
dhcpsn.prv     --          262144      --       01-Jan-2010 05:25:07
sshkeys.prv    --          262144      --       04-Jan-2010 06:05:00
syslog1.sys    r-          524288      --       01-Jan-2010 05:57:00
syslog2.sys    r-          524288      --       01-Jan-2010 05:57:00
directry.prv   --          262144      --       01-Jan-2010 05:25:07
startup-config rw          786432      1081     01-Jan-2010 10:05:34

Total size of flash: 66322432 bytes
Free size of flash: 42205184 bytes

console#
```

more The **more** Privileged EXEC mode command displays a file.

SYNTAX

more *url*

PARAMETERS

url—Specifies the location URL or reserved keyword of the source file to be displayed. (Length: 1–160 characters).

The following table displays options for the URL parameter:

Keyword	Source or Destination
flash://	Source or destination URL for flash memory. If a URL is specified without a prefix, this is the default URL.
running-config	Current running configuration file.
startup-config	Startup configuration file.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

Files are displayed in ASCII format, except for the images, which are displayed in a hexadecimal format.

*.**prv** files cannot be displayed.

EXAMPLE

The following example displays the running configuration file contents.

```

console# more running-config
no spanning-tree
interface range te1-48
speed 1000
exit
no lldp run
line console
exec-timeout 0
exit

```

rename The **rename** Privileged EXEC mode command renames a file.

SYNTAX

rename *url new-url*

PARAMETERS

- ◆ **url**—Specifies the file location URL. (Length: 1–160 characters)
- ◆ **new-url**—Specifies the file's new URL. (Length: 1–160 characters)

The following table displays options for the URL parameter:

Keyword	Source or Destination
flash://	URL for flash memory. If a URL is specified without a prefix, this is the default URL.
WORD	Specify URL prefixes.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

*.**sys** and *.**prv** files cannot be renamed.

EXAMPLE

The following example renames the configuration file.

```
Console# rename configuration.bak m-config.bak
```

boot system The **boot system** Privileged EXEC mode command specifies the active system image file that is loaded by the device at startup.

SYNTAX

boot system { *image-1* | *image-2* }

PARAMETERS

- ◆ **image-1**—Specifies that image-1 is loaded as the system image during the next device startup.
- ◆ **image-2**—Specifies that image-2 is loaded as the system image during the next device startup.

DEFAULT CONFIGURATION

This command has no default configuration.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

Use the **show bootvar** command to determine which image is the active image.

EXAMPLE

The following example specifies that **image-1** is the active system image file loaded by the device at startup.

```
Console# boot system image-1
```

show running-config

The **show running-config** Privileged EXEC mode command displays the current running configuration file contents.

SYNTAX

show running-config

PARAMETERS

This command has no arguments or keywords.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the running configuration file contents.

```
Console# show running-config
no spanning-tree
interface range tel-48
speed 1000
exit
no lldp run
interface vlan 1
ip address 1.1.1.1 255.0.0.0
exit
line console
exec-timeout 0
exit
console#
```

show startup-config

The **show startup-config** Privileged EXEC mode command displays the startup configuration file contents.

SYNTAX

show startup-config

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the startup configuration file contents.

```

Console# show startup-config
no spanning-tree
interface range te1-48
speed 1000
exit
no lldp run
interface vlan 1
ip address 1.1.1.1 255.0.0.0
exit
line console
exec-timeout 0
exit
console#

```

show bootvar The **show bootvar** EXEC mode command displays the active system image file that is loaded by the device at startup.

SYNTAX

show bootvar

PARAMETERS

There are no parameters for this command.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the active system image file that is loaded by the device at startup.

```

Console# show bootvar

Image      filename      Version      Date              Status
-----
1          image-1        1.1.04       23-Jul-2010  17:34:19      Active
2          image-2        1.1.0.5      22-Jan-2010  19:22:32      Not active*

"": Designates that the image was selected for the next boot.

```


AUTO-UPDATE AND AUTO-CONFIGURATION

iPECS ES-5048XG

boot host auto-config Use the **boot host auto-config** Global Configuration mode command to enable the support of auto configuration via DHCP. Use the **no** form of this command to disable DHCP auto configuration.

SYNTAX

boot host auto-config

no boot host auto-config

PARAMETERS

This command has no arguments or key words.

COMMAND MODE

Global Configuration mode

DEFAULT CONFIGURATION

Enabled by default.

show boot Use the **show boot** Privilege EXEC mode command to show the status of the IP DHCP Auto Config process.

SYNTAX

show boot

PARAMETERS

This command has no keywords or arguments.

COMMAND MODE

Privilege EXEC mode

EXAMPLES

```
console# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: force

Auto Config State: Finished
TFTP Server IP address: 1.2.20.2
Configuration filename: /config/configfile1.cfg

Auto Update
```

```

-----
Image Download via DHCP: enabled

```

```

console# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default
Auto Config State: Opening <hostname>-config file

```

```

Auto Update
-----
Image Download via DHCP: enabled

```

```

console# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default
Auto Config State: Downloading configuration file

```

```

Auto Update
-----
Image Download via DHCP: enabled

```

```

console# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default
Auto Config State: Searching hostname in indirect configuration file

```

```

Auto Update
-----
Image Download via DHCP: enabled

```

```

console# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default
Auto Config State: Quit - failed all steps of finding existing configuration
file

```

```

Auto Update
-----
Image Download via DHCP: enabled

```

```

console# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default

```

```

Auto Update
-----
Image Download via DHCP: enabled
Auto Update State: Downloaded indirect image file

```

```

console# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default

Auto Update
-----
Image Download via DHCP: enabled
Auto Update State: Downloading image file

```

```

console# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default
Auto Config State: Finished
TFTP Server IP address: 1.2.20.2
Configuration filename: /config/configfile1.cfg

```

```

Auto Update
-----
Image Download via DHCP: enabled
Auto Update State: Downloading image file

```

ip dhcp tftp-server ip addr Use the **ip dhcp tftp-server ip addr** Global Configuration mode command to set the TFTP server's IP address, used by a switch when it has not been received from the DHCP server. Use the **no** form of this command to remove the address.

SYNTAX

```

ip dhcp tftp-server ip addr ip-addr
no ip dhcp tftp-server ip-addr

```

PARAMETERS

ip-addr IP—Address of TFTP server

DEFAULT CONFIGURATION

No IP address

COMMAND MODE

Global Configuration mode

ip dhcp tftp-server file Use the **ip dhcp tftp-server file** Global Configuration mode command to set the full file name on the TFTP server by a switch when it has not been received from the DHCP server. Use the **no** form of this command to remove the name.

SYNTAX

ip dhcp tftp-server file *file-path*
no ip dhcp tftp-server file

PARAMETERS

file-path—full file name on TFTP server

DEFAULT CONFIGURATION

No file name

COMMAND MODE

Global Configuration mode

show ip dhcp tftp-server Use the **show ip dhcp tftp-server** EXEC mode command to display information about the TFTP server.

SYNTAX

show ip dhcp tftp-server

COMMAND MODE

EXEC

EXAMPLE

```
console# show ip dhcp tftp server
tftp server address
active                               1.1.1.1 from sname
manual                               2.2.2.2
file path on tftp server
activeconf/conf-file from option 67
```

management access-list The **management access-list** Global Configuration mode command configures a management access list and enters the Management Access-List Configuration command mode. Use the **no** form of this command to delete an access list.

SYNTAX

management access-list *name*
no management access-list *name*

PARAMETERS

name—Specifies the access list name. (Length: 1–32 characters)

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use this command to configure a management access list. This command enters the Management Access-List Configuration mode, where the denied or permitted access conditions are defined with the **deny** and **permit** commands.

If no match criteria are defined, the default value is **deny**.

When re-entering the access-list context, the new rules are entered at the end of the access list.

Use the **management access-class** command to select the active access list.

The active management list cannot be updated or removed.

For IPv6 management traffic that is tunneled in IPv4 packets, the management ACL is applied first on the external IPv4 header (rules with service field are ignored), and then again on the inner IPv6 header.

EXAMPLE

The following example creates a management access list called **mlist**, configures management tengigabitethernet interfaces 0/1 and 0/9, and makes the new access list the active list.

```
Console(config)# management access-list mlist
Console(config-macl)# permit tel
Console(config-macl)# permit te9
```

```
Console(config-macl)# exit
Console(config)# management access-class mlist
```

The following example creates a management access list called 'mlist', configures all interfaces to be management interfaces except tengigabitethernet interfaces 0/1 and 0/9, and makes the new access list the active list.

```
Console(config)# management access-list mlist
Console(config-macl)# deny tengigabitethernet 0/1
Console(config-macl)# deny tengigabitethernet 0/9
Console(config-macl)# permit
Console(config-macl)# exit
Console(config)# management access-class mlist
```

permit (Management) The **permit Management** Access-List Configuration mode command sets conditions for the management access list.

SYNTAX

permit [*interface-id*] [*service service*]

permit ip-source {*ipv4-address* | *ipv6-address/ipv6-prefix-length*} [*mask {mask | prefix-length}*] [*interface-id*] [*service service*]

PARAMETERS

- ◆ **interface-id**:—Specify an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN
- ◆ **service service** — Specifies the service type. Possible values are: Telnet, SSH, HTTP, HTTPS and SNMP.
- ◆ **ipv4-address**— Specifies the source IPv4 address.
- ◆ **ipv6-address/ipv6-prefix-length**— Specifies the source IPv6 address and source IPv6 address prefix length. The prefix length must be preceded by a forward slash (/). The parameter is optional.
- ◆ **mask mask** — Specifies the source IPv4 address network mask. This parameter is relevant only to IPv4 addresses.
- ◆ **mask prefix-length** — Specifies the number of bits that comprise the source IPv4 address prefix. The prefix length must be preceded by a forward slash (/). This parameter is relevant only to IPv4 addresses. (Range: 0–32)

COMMAND MODE

Management Access-List Configuration mode

USER GUIDELINES

Rules with ethernet, VLAN, and port-channel parameters are valid only if an IP address is defined on the appropriate interface.

EXAMPLE

The following example permits all ports in the access list called **mlist**

```
Console(config)# management access-list mlist
Console(config-macl)# permit
```

deny (Management) The **deny** Management Access-List Configuration mode command sets conditions for the management access list.

SYNTAX

```
deny [interface-id] [service service]
deny ip-source {ipv4-address | ipv6-address/ipv6-prefix-length}
    [mask {mask | prefix-length}] [interface-id] [service service]
```

PARAMETERS

- ◆ **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN
- ◆ **service service**—Specifies the service type. Possible values are: Telnet, SSH, HTTP, HTTPS and SNMP.
- ◆ **ipv4-address**—Specifies the source IPv4 address.
- ◆ **ipv6-address/ipv6-prefix-length**—Specifies the source IPv6 address and source IPv6 address prefix length. The prefix length must be preceded by a forward slash (/). The parameter is optional.
- ◆ **mask mask**—Specifies the source IPv4 address network mask. The parameter is relevant only to IPv4 addresses.
- ◆ **mask prefix-length**—Specifies the number of bits that comprise the source IPv4 address prefix. The prefix length must be preceded by a forward slash (/). The parameter is relevant only to IPv4 addresses. (Range: 0–32)

COMMAND MODE

Management Access-List Configuration mode

USER GUIDELINES

Rules with ethernet, VLAN, and port-channel parameters are valid only if an IP address is defined on the appropriate interface.

EXAMPLE

The following example denies all ports in the access list called **mlist**.

```
Console(config)# management access-list mlist
Console(config-macl)# deny
```

**management
access-class**

The **management access-class** Global Configuration mode command restricts management connections by defining the active management access list. To disable management connection restrictions, use the **no** form of this command.

SYNTAX

management access-class {**console-only** | *name*}
no management access-class

PARAMETERS

- ◆ **console-only**—Specifies that the device can be managed only from the console.
- ◆ **name**—Specifies the access list name to be used. (Length: 1–32 characters)

DEFAULT CONFIGURATION

The default configuration is no management connection restrictions.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example defines an access list called **mlist** as the active management access list.

```
Console(config)# management access-class mlist
```

**show management
access-list**

The **show management access-list** Privileged EXEC mode command displays management access lists.

SYNTAX

show management access-list [*name*]

PARAMETERS

- name**—Specifies the name of a management access list to be displayed. (Length: 1–32 characters)

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the **mlist** management access list.

```
Console# show management access-list mlist
console-only
-----
deny
! (Note: all other access implicitly denied)
mlist
-----
permit tel
permit te9
! (Note: all other access implicitly denied)
console#
```

**show management
access-class**

The **show management access-class** Privileged EXEC mode command displays information about the active management access list.

SYNTAX**show management access-class****COMMAND MODE**

Privileged EXEC mode

EXAMPLE

The following example displays the active management access list information.

```
Console# show management access-class
Management access-class is enabled, using access list mlist
```

NETWORK MANAGEMENT PROTOCOL (SNMP) COMMANDS

iPECS ES-5048XG

snmp-server Use the **snmp-server server** Global Configuration mode command to enable the device to be configured by SNMP. Use the **no** form of this command to disable this function.

SYNTAX

snmp-server server
no snmp-server server

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Enabled

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# snmp-server server
```

snmp-server community Use the **snmp-server community** Global Configuration mode command to set up the community access string to permit access to the Simple Network Management Protocol command. Use the **no** form of this command to remove the specified community string.

SYNTAX

snmp-server community *string* [*view view-name*] [*ro* | *rw* | *su*]
 {*ipv4-address* | *ipv6-address*} [*mask* | *prefix-length*] [*type router* | *oob*]
no snmp-server community *string* [*ipv4-address* | *ipv6-address*]

PARAMETERS

- ◆ **string**—Community string that acts like a password and permits access to the SNMP protocol. (Range: 1–20 characters)
- ◆ **ro**—Specifies read-only access (default)
- ◆ **rw**—Specifies read-write access

- ◆ **su**—Specifies SNMP administrator access
- ◆ **view view-name**—Specifies the name of a view to be configured using the command **snmp-server view** (no specific order of the command configurations is imposed on the user). The view defines the objects available to the community. It is not relevant for **su**, which has access to the whole MIB. If unspecified, all the objects, except the community-table and SNMPv3 user and access tables, are available. (Range: 1–30 characters)
- ◆ **ipv4-address**—Management station IPv4 address. The default is all IP addresses.
- ◆ **ipv6-address**—Management station IPv4 address. The default is all IP addresses.
- ◆ **mask**—Specifies the mask of the IPv4 address. This is not a network mask, but rather a mask that defines which bits of the packet's source address are compared to the configured IP address. If unspecified, it defaults to 255.255.255.255. The command returns an error if the mask is specified without an IPv4 address.
- ◆ **prefix-length**—Specifies the number of bits that comprise the IPv4 address prefix. If unspecified, it defaults to 32. The command returns an error if the prefix-length is specified without an IPv4 address.
- ◆ **group-name**—Specifies the name of a group that should be configured using the command **snmp-server group** with v1 or v2 parameter (no specific order of the two command configurations is imposed on the user). The group defines the objects available to the community. (Range: 1–30 characters)
- ◆ **type router**—Specifies that SNMP requests for duplicate tables configure the router tables. This is the default.
- ◆ **type oob**—Specifies that SNMP requests for duplicate tables configure the oob tables.

DEFAULT

No community is defined

COMMAND MODE

Global Configuration mode

USER GUIDELINES

You can't specify view-name for su, which has access to the whole MIB.

You can use the view-name to restrict the access rights of a community string.

The logical key of the command is the pair (community, ip-address). If ip-address is omitted then the key is (community, All-Ips).

By specifying the view-name parameter, the software:

- ◆ Generates an internal security-name.
- ◆ Maps the internal security-name for SNMPv1 and SNMPv2 security models to an internal group-name.
- ◆ Maps the internal group-name for SNMPv1 and SNMPv2 security models to view-name (read-view and notify-view always, and for rw for write-view also),

You can use the group-name to restrict the access rights of a community string. By specifying the group-name parameter the software:

- ◆ Generates an internal security-name.
- ◆ Maps the internal security-name for SNMPv1 and SNMPv2 security models to the group-name.

The **snmp-server community-group** command and **snmp-server** user command for v1 and v2 are equivalent. You should use the **snmp-server community-group** command when you want to configure the ipv4-address| ipv6-address management addresses.

The Type keyword is used for a different purpose. Therefore, when defining an SNMP community, the administrator must indicate which tables are being configured. If Type is router, it means that the device's tables are being configured.

EXAMPLE

```
snmp-server community
=====
console(config)# snmp-server community abcd su 1.1.1.121 mask 255.0.0.0
console(config)# snmp-server community-group tom abcd 1.1.1.122 prefix 8
```

snmp-server view The **snmp-server view** Global Configuration mode command creates or updates a Simple Network Management Protocol (SNMP) server view entry. Use the **no** form of this command to remove an SNMP server view entry.

SYNTAX

```
snmp-server view view-name oid-tree {included | excluded}
no snmp-server view view-name [oid-tree]
```

PARAMETERS

- ◆ **view-name**—Specifies the label for the view record that is being created or updated. The name is used to reference the record. (Length: 1–30 characters)
- ◆ **oid-tree**—Specifies the ASN.1 subtree object identifier to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as 1.3.6.2.4, or a word, such as System.

Replace a single sub-identifier with the asterisk (*) wildcard to specify a subtree family; for example 1.3.*.4.

- ◆ **included**—Specifies that the view type is included.
- ◆ **excluded**—Specifies that the view type is excluded.

DEFAULT CONFIGURATION

Default and DefaultSuper are the default view names.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command can be entered multiple times for the same view record.

The command logical key is the pair (view-name, oid-tree).

The number of views is limited to 64.

Default and DefaultSuper views are reserved for internal software use and cannot be deleted or modified.

EXAMPLE

The following example creates a view that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interface group.

```
Console(config)# snmp-server view user-view system included
Console(config)# snmp-server view user-view system.7 excluded
Console(config)# snmp-server view user-view ifEntry.*.1 included
```

snmp-server group The **snmp-server group** Global Configuration mode command configures a new Simple Network Management Protocol (SNMP) group or a table that maps SNMP users to SNMP views. Use the **no** form of this command, remove a specified SNMP group.

SYNTAX

```
snmp-server group groupname {v1 | v2 | v3 {noauth | auth | priv}
[notify notifyview]} [read readview] [write writeview]

no snmp-server group groupname {v1 | v2 | v3 [noauth | auth |
priv]} [context name]
```

PARAMETERS

- ◆ **groupname**—Specifies the group name. (Length: 1–30 characters)
- ◆ **v1**—Specifies the SNMP Version 1 security model.
- ◆ **v2**—Specifies the SNMP Version 2 security model.

- ◆ **v3**—Specifies the SNMP Version 3 security model.
- ◆ **noauth**—Specifies no packet authentication. Applicable only to the SNMP Version 3 security model.
- ◆ **auth**—Specifies packet authentication without encryption. Applicable only to the SNMP Version 3 security model.
- ◆ **priv**—Specifies packet authentication with encryption. Applicable only to the SNMP Version 3 security model.
- ◆ **notify notifyview**—Specifies the view name that enables specifying an inform or a trap. Applicable only to the SNMP Version 3 security model. (Length: 1–30 characters)
- ◆ **read readview**—Specifies the view name that enables viewing only the agent contents. (Length: 1–30 characters)
- ◆ **write writeview**—Specifies the view name that enables entering data and configuring the agent contents. (Length: 1–30 characters)

DEFAULT CONFIGURATION

No group entry exists.

If **notifyview** is not specified, nothing is defined for the notify view.

If **readview** is not specified, all objects except for the community-table and SNMPv3 user and access tables are available.

If **writeview** is not specified, nothing is defined for the write view.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The command logical key is (**groupname, snmp-version, security-level**). For snmp-version v1/v2 the security-level is always **noauth**.

The **Router** context is translated to "" context in the MIB.

EXAMPLE

The following example attaches a group called user-group to SNMPv3 and assigns to the group the privacy security level and read access rights to a view called user-view.

```
Console(config)# snmp-server group user-group v3 priv read user-view
```

snmp-server user Use the **snmp-server user** Global Configuration mode command to configure a new SNMP Version 3 user. Use the **no** form of the command to remove a user.

SYNTAX

```
snmp-server user username groupname {v1 | v2c | [remote host]
v3 [encrypted] [auth {md5 | sha} auth-password]}
no snmp-server user username [remote host]
```

PARAMETERS

- ◆ **username**—The name of the user on the host that connects to the agent. (Range: Up to 20 characters)
- ◆ **groupname**—The name of the group to which the user belongs. The group should be configured using the command **snmp-server group** with v3 parameters (no specific order of the 2 command configurations is imposed on the user). (Range: Up to 30 characters)
- ◆ **remote host**—IP address of the remote SNMP host.
- ◆ **v1**—Specifies that v1 is to be used.
- ◆ **v2c**—Specifies that v2c is to be used.
- ◆ **v3**—Specifies that v3 is to be used.
- ◆ **encrypted**—Specifies whether the password appears in encrypted format.
- ◆ **auth**—Specifies which authentication level is to be used.
- ◆ **md5**—Specifies the HMAC-MD5-96 authentication level.
- ◆ **Sha**—Specifies the HMAC-SHA-96 authentication level.
- ◆ **auth-password**—Specifies the authentication password.

Parameters Range engineid-string 5 - 32 characters.

auth-passwordUp to 32 characters.

DEFAULT

No group entry exists.

COMMAND MODE

Global configuration

USER GUIDELINES

If **auth md5** or **auth sha** is specified, both authentication and privacy are enabled for the user.

When you enter a **show running-config** command, you do not see a line for this user. To see if this user has been added to the configuration, type the **show snmp user** command.

An SNMP EngineID should be defined in order to add users to the device.

Changing or removing the value of **snmpEngineID** deletes the SNMPv3 users' database.

The logical key of the command is Username.

Configuring a remote host is required in order to send informs to that host. A configured remote host is also able to manage the device (besides getting the informs)

To configure a remote user, specify the IP address for the remote SNMP agent of the device where the user resides. Also, before you configure remote users for a particular agent, configure the SNMP engine ID, using the **snmp-server engineID remote** command. The remote agent's SNMP engine ID is needed when computing the authentication and privacy digests from the password. If the remote engine ID is not configured first, the configuration command fails.

EXAMPLE

```
snmp-server user
=====
console(config)# snmp-server user tom acbd v1
console(config)# snmp-server user tom acbd v2c
console(config)# snmp-server engineid local default
The engine-id must be unique within your administrative domain.
Do you wish to continue? [Y/N]
y
The SNMPv3 database will be erased. Do you wish to continue? [Y/N]
y
console(config)# snmp-server user tom acbd v3
```

snmp-server filter The **snmp-server filter** Global Configuration mode command creates or updates a Simple Network Management Protocol (SNMP) server filter entry. Use the **no** form of this command to remove the specified SNMP server filter entry.

SYNTAX

```
snmp-server filter filter-name oid-tree {included | excluded}
no snmp-server filter filter-name [oid-tree]
```

PARAMETERS

- ◆ **filter-name**—Specifies the label for the filter record that is being updated or created. The name is used to reference the record. (Length: 1–30 characters)

- ◆ **oid-tree**—Specifies the ASN.1 subtree object identifier to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as 1.3.6.2.4, or a word, such as System. Replace a single sub-identifier with the asterisk (*) wildcard to specify a subtree family; for example, 1.3.*.4.
- ◆ **included**—Specifies that the filter type is included.
- ◆ **excluded**—Specifies that the filter type is excluded.

DEFAULT CONFIGURATION

No view entry exists.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command can be entered multiple times for the same filter record. If an object identifier is included in two or more lines, later lines take precedence. The command's logical key is the pair (filter-name, oid-tree).

EXAMPLE

The following example creates a filter that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interfaces group.

```
Console(config)# snmp-server filter filter-name system included
Console(config)# snmp-server filter filter-name system.7 excluded
Console(config)# snmp-server filter filter-name ifEntry.*.1 included
```

snmp-server host Use the **snmp-server host** Global Configuration mode command to specify the recipient of a Simple Network Management Protocol notification operation. Use the **no** form of this command to remove the specified host.

SYNTAX

snmp-server host { *ipv4-address* | *ipv6-address* | *hostname* } [*traps* | *informs*] [*version* {1 | 2c | 3} [*auth* | *noauth* | *priv*]] [*community-string*] [*udp-port port*] [*filter filtername*] [*timeout seconds*] [*retries retries*]

no snmp-server host { *ipv4-address* | *ipv6-address* | *hostname* } [*traps* | *informs*] [*version* {1 | 2c | 3}]

PARAMETERS

- ◆ **pv4-address**—IPv4 address of the host (the targeted recipient).
- ◆ **ipv6-address**—Pv6 address of the host (the targeted recipient). When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. Refer to the User Guidelines for the interface name syntax.

- ◆ **hostname**—Hostname of the host. (Range: 1–158 characters. Maximum label size: 63)
- ◆ **trap**—Sends SNMP traps to this host (default).
- ◆ **informs**—Sends SNMP informs to this host. Not applicable to SNMPv1.
- ◆ **1**—SNMPv1 traps are used.
- ◆ **2c**—SNMPv2 traps are used
- ◆ **3**—SNMPv2 traps are used
- ◆ **community-string**—Password-like community string sent with the notification operation. (Range: 1–20 characters)
- ◆ **noauth**—Specifies no authentication of a packet.
- ◆ **auth**—Specifies authentication of a packet without encrypting it.
- ◆ **priv**—Specifies authentication of a packet with encryption.
- ◆ **udp-port port**—UDP port of the host to use. The default is 162. (Range: 1–65535)
- ◆ **filter filename**—A string that is the name of the filter that defines the filter for this host. If unspecified, nothing is filtered. The filter should be defined using the command **snmp-server filter** (no specific order of the command configurations is imposed on the user). (Range: Up to 30 characters)
- ◆ **timeout seconds**—Number of seconds to wait for an acknowledgment before resending informs. The default is 15 seconds. The parameter is relevant only for informs. (Range: 1–300)
- ◆ **retries retries**—Maximum number of times to resend an inform request, when a response is not received for a generated message. The default is 3. The parameter is relevant only for informs. (Range: 0–255)

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The logical key of the command is the pair (ip-address/hostname, traps/informs, version).

When configuring snmp v1 or v2 notifications recipient the software would automatically generate a notification view for that recipient for all the MIB. (.For SNMPv3 the software doesn't automatically create a user nor a notify view. Use the commands **snmp-server user**, **snmp-server group** and **snmp-server view** in Global Configuration mode to create a user, a group or a notify group respectively.

The format of an IPv6Z address is: *<ipv6-link-local-address>%<interface-name>*

interface-name = *vlan<integer> | ch<integer> | isatap<integer> | <physical-port-name> | 0*

integer = *<decimal-number> | <integer><decimal-number>*

decimal-number = 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9

physical-port-name = Designated port number, for example 0/16

If the egress interface is not specified, the default interface is selected. Specifying interface zone=0 is equal to not defining an egress interface.

EXAMPLE

The following defines a host at the IP address displayed.

```
console(config)# snmp-server host 1.1.1.121 abc
```

snmp-server engineID local

The **snmp-server engineID local** Global Configuration mode command specifies the Simple Network Management Protocol (SNMP) engineID on the local device. Use the **no** form of this command to remove the configured engine ID.

SYNTAX

snmp-server engineID local {*engineid-string* | *default*}

no snmp-server engineID local

PARAMETERS

- ◆ **engineid-string**—Specifies a concatenated hexadecimal character string identifying the engine ID. Each byte in a hexadecimal character string is two hexadecimal digits. Bytes are separated by a period or colon. If an odd number of hexadecimal digits are entered, the system automatically prefixes the digit 0 to the string. (Length: 5–32 characters, 9–64 hexadecimal digits)
- ◆ **default**—Specifies that the engine ID is created automatically based on the device MAC address.

DEFAULT CONFIGURATION

The engine ID is not configured.

If SNMPv3 is enabled using this command, and the default is specified, the default engine ID is defined per standard as:

- ◆ First 4 octets: First bit = 1, the rest is IANA Enterprise number = 674.
- ◆ Fifth octet: Set to 3 to indicate the MAC address that follows.

- ◆ Last 6 octets: The device MAC address.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

To use SNMPv3, specify an engine ID for the device. Any ID can be specified or use a default string, which is generated using the device MAC address.

As the EngineID should be unique within an administrative domain, the following guidelines are recommended:

- ◆ For standalone devices, use the default keyword to configure the Engine ID.
- ◆ For stackable systems, configure an EngineID, and verify that it is unique within the administrative domain.

Changing or removing the value of **snmpEngineID** deletes the SNMPv3 users database.

The SNMP EngineID cannot be all 0x0 or all 0xF or 0x000000001

EXAMPLE

The following example enables SNMPv3 on the device and sets the device local engine ID to the default value.

```
Console(config)# snmp-server engineID local default
```

snmp-server enable traps Use the **snmp-server enable traps** Global Configuration mode command to enable the device to send SNMP traps. Use the **no** form of the command to disable SNMP traps.

SYNTAX

snmp-server enable traps

no snmp-server enable traps

DEFAULT CONFIGURATION

SNMP traps are enabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables SNMP traps.

```
Console(config)# snmp-server enable traps
```

snmp-server trap authentication

Use the **snmp-server trap authentication** Global Configuration mode command to enable the device to send SNMP traps when authentication fails. Use the **no** form of this command to disable SNMP failed authentication traps.

SYNTAX

snmp-server trap authentication

no snmp-server trap authentication

DEFAULT CONFIGURATION

SNMP failed authentication traps are enabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables SNMP failed authentication traps.

```
Console(config)# snmp-server trap authentication
```

snmp-server contact

Use the **snmp-server contact** Global Configuration mode command to configure the system contact (sysContact) string. Use the **no** form of the command to remove the system contact information.

SYNTAX

snmp-server contact *text*

no snmp-server contact

PARAMETERS

text—Specifies the string describing system contact information. (Length: 1–160 characters)

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures the system contact point called Technical_Support.

```
Console(config)# snmp-server contact Technical_Support
```

snmp-server location

Use the **snmp-server location** Global Configuration mode command to configure the system location string. Use the **no** form of this command to remove the location string.

SYNTAX

snmp-server location *text*
no snmp-server location

PARAMETERS

text—Specifies a string describing system location information. (Length: 1–160 characters)

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example defines the device location as New_York.

```
Console(config)# snmp-server location New_York
```

snmp-server set

Use the **snmp-server set** Global Configuration mode command to define the SNMP MIB value.

SYNTAX

snmp-server set *variable-name name value [name2 value2 ...]*

PARAMETERS

- ◆ **variable-name**—Specifies the SNMP MIB variable name, which must be a valid string.
- ◆ **name value**—Specifies a list of name and value pairs. Each name and value must be a valid string. In the case of scalar MIBs, there is only a single name-value pair. In the case of an entry in a table, there is at least one name-value pair, followed by one or more fields.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Although the CLI can set any required configuration, there might be a situation where an SNMP user sets a MIB variable that does not have an equivalent command. To generate configuration files that support those situations, use the **snmp-server set** command.

EXAMPLE

The following example configures the scalar MIB sysName with the value TechSupp.

```
Console(config)# snmp-server set sysName sysname TechSupp
```

show snmp Use the **show snmp** Privileged EXEC mode command to display the SNMP status.

SYNTAX

show snmp

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the SNMP communications status.

```
Console# show snmp
```

SNMP is enabled

Community-String	Community-Access	View name	IP Address	type
public	read only	user-view	All	Router
private	read write	Default	172.16.1.1/10	Router
private	su	DefaultSuper	172.16.1.1	Router

Community-string	Group name	IP address	type
public	user-group	All	Router

Traps are enabled.
Authentication trap is enabled.

Version 1,2 notifications

Target Address	Type	Community	Version	UDP Port	Filter name	TO Sec	Retries
192.122.173.42	Trap	public	2	162		15	3
192.122.173.42	Inform	public	2	162		15	3

Version 3 notifications

Target Address	Type	Username	Security Level	UDP Port	Filter name	TO Sec	Retries
-----	-----	-----	-----	----	-----	---	-----
192.122.173.42	Inform	Bob	Priv	162		15	3

System Contact: Robert
System Location: Marketing

The following table describes the significant fields shown in the display.

Field	Description
Community-string	The community access string permitting access to the SNMP protocol.
Community-access	The access type—read-only, read-write, super access.
IP Address	The management station IP Address.
Trap-Rec-Address	The targeted recipient.
Trap-Rec-Community	The statistics sent with the notification operation.
Version	The SNMP version (1 or 2) for the sent trap.

show snmp engineID Use the **show snmp engineID** Privileged EXEC mode command to display the local Simple Network Management Protocol (SNMP) engine ID.

SYNTAX

show snmp engineID

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the SNMP engine ID.

```

Console # show snmp engineID
Local SNMP engineID: 08009009020C0B099C075878
#Editor: If snmp-server engineID remote command is supported add the
following line
IP address                               Remote SNMP engineID
-----                               -
172.16.1.108009009020C0B099C075879

```

show snmp views Use the **show snmp views** Privileged EXEC mode command to display the configured SNMP views.

SYNTAX

show snmp views [*viewname*]

PARAMETERS

viewname—Specifies the view name. (Length: 1–30 characters)

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the configured SNMP views.

```

Console# show snmp views

Name                OID Tree                Type
-----
Default             iso                     Included
Default             snmpNotificationMIB    Excluded

```

show snmp groups Use the **show snmp groups** Privileged EXEC mode command to display the configured SNMP groups.

SYNTAX

show snmp groups [*groupname*]

PARAMETERS

groupname—Specifies the group name. (Length: 1–30 characters)

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the configured SNMP groups.

```

Console# show snmp groups

Name                Security                Views
                   Model    Level    Read    Write    Notify
-----
user-group          V3      priv    Default ""      ""
managers-group      V3      priv    Default Default ""

```

The following table describes significant fields shown above.

Field	Description
Name	Group name.
Security Model	SNMP model in use (v1, v2 or v3).
Security Level	Packet authentication with encryption. Applicable to SNMP v3 security only.

Field	Description	
Views	Read	View name enabling viewing the agent contents. If unspecified, all objects except the community-table and SNMPv3 user and access tables are available.
	Write	View name enabling data entry and managing the agent contents.
	Notify	View name enabling specifying an inform or a trap.

show snmp filters Use the **show snmp filters** Privileged EXEC mode command to display the configured SNMP filters.

SYNTAX

show snmp filters [*filtername*]

PARAMETERS

filtername—Specifies the filter name. (Length: 1–30 characters)

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the configured SNMP filters.

```

Console# show snmp filters

```

Name	OID Tree	Type
-----	-----	-----
user-filter	1.3.6.1.2.1.1	Included
user-filter	1.3.6.1.2.1.1.7	Excluded
user-filter	1.3.6.1.2.1.2.2.1.*.1	Included

show snmp users Use the **show snmp users** Privileged EXEC mode command to display the configured SNMP users.

SYNTAX

show snmp users [*username*]

PARAMETERS

username—Specifies the user name. (Length: 1–30 characters)

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the configured SNMP users.

```
Console# show snmp users
```

Name	Group name	Auth Method	Remote
-----	-----	-----	-----
John	user-group	md5	
John	user-group	md5	08009009020C0B099C075879

crypto key generate dsa The **crypto key generate dsa** Global Configuration mode command generates DSA key pairs.

SYNTAX

crypto key generate dsa

DEFAULT CONFIGURATION

DSA key pairs do not exist.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

DSA keys are generated in pairs - one public DSA key and one private DSA key.

If the device already has DSA keys, a warning is displayed with a prompt to replace the existing keys with new keys.

This command is not saved in the router configuration. However, the keys generated by this command are saved in the private configuration (which is never displayed to the user or backed up to another device).

EXAMPLE

The following example generates DSA key pairs.

```
Console(config)# crypto key generate dsa
```

crypto key generate rsa The **crypto key generate rsa** Global Configuration mode command generates RSA key pairs.

SYNTAX

crypto key generate rsa

DEFAULT CONFIGURATION

RSA key pairs do not exist.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

RSA keys are generated in pairs - one public RSA key and one private RSA key.

If the device already has RSA keys, a warning is displayed with a prompt to replace the existing keys with new keys.

This command is not saved in the router configuration; however, the keys generated by this command are saved in the private configuration (which is never displayed to the user or backed up to another device).

EXAMPLE

The following example generates RSA key pairs.

```
Console(config)# crypto key generate rsa
```

show crypto key mypubkey The **show crypto key mypubkey** Privileged EXEC mode command displays the device SSH public keys.

SYNTAX

show crypto key mypubkey [*rsa* | *dsa*]

PARAMETERS

- ◆ **rsa**—Displays the RSA key.
- ◆ **dsa**—Displays the DSA key.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the SSH public RSA keys on the device.

```
Console# show crypto key mypubkey rsa
RSA key data:
005C300D 06092A86 4886F70D 01010105 00034B00 30480241 00C5E23B 55D6AB22
04AEF1BA A54028A6 9ACC01C5 129D99E4 64CAB820 847EDAD9 DF0B4E4C 73A05DD2
BD62A8A9 FA603DD2 E2A8A6F8 98F76E28 D58AD221 B583D7A4 71020301 87685768
Fingerprint(Hex): 77:C7:19:85:98:19:27:96:C9:CC:83:C5:78:89:F8:86
Fingerprint(Bubble Babble): yteriuwt jgkljhglk yewiury hdskjfryt gfhkjglk
```

crypto certificate generate The **crypto certificate generate** Global Configuration mode command generates a self-signed certificate for HTTPS.

SYNTAX

```
crypto certificate number generate [key-generate [length]]
                        [passphrase string] [cn common-name] [ou organization-unit] [or
                        organization] [loc location] [st state] [cu country] [duration days]
```

PARAMETERS

- ◆ **number**—Specifies the certificate number. (Range: 1–2)
- ◆ **key-generate**—Regenerates SSL RSA key.
- ◆ **length**—Specifies the SSL's RSA key length. (Range: 512–2048)
- ◆ **passphrase string**—Specifies the passphrase used for exporting the certificate in PKCS12 file format. (Length: 8–96 characters)
- ◆ **cn common-name**—Specifies the fully qualified device URL or IP address. (Length: 1–64 characters)
- ◆ **ou organization-unit**—Specifies the organization-unit or department name. (Length: 1–64 characters)
- ◆ **or organization**—Specifies the organization name. (Length: 1–64 characters)
- ◆ **loc location**—Specifies the location or city name. (Length: 1–64 characters)
- ◆ **st state**—Specifies the state or province name. (Length: 1–64 characters)
- ◆ **cu country**—Specifies the country name. (Length: 2 characters)
- ◆ **duration days**—Specifies the number of days a certification is valid. (Range: 30–3650)

DEFAULT CONFIGURATION

The default certificate number is 1.

The default SSL's RSA key length is 1024.

If **passphrase string** is not specified, the certificate is not exportable.

If **cn common-name** is not specified, it defaults to the device's lowest static IPv6 address (when the certificate is generated), or to the device's lowest static IPv4 address if there is no static IPv6 address, or to 0.0.0.0 if there is no static IP address.

If **duration days** is not specified, it defaults to 365 days.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command is not saved in the router configuration. However, the certificate and keys generated by this command are saved in the private configuration (which is never displayed to the user or backed up to another device).

When exporting a RSA key pair to a PKCS#12 file, the RSA key pair is as secure as the passphrase. Keep the passphrase secure.

If the RSA key does not exist, you must use the parameter **key-generate**.

EXAMPLE

The following example generates a self-signed certificate for HTTPS.

```
Console# crypto certificate generate key-generate
```

crypto certificate request The **crypto certificate request** Privileged EXEC mode command generates and displays a certificate request for HTTPS.

SYNTAX

crypto certificate *number* **request** *common-name* [*ou organization-unit*] [*or organization*] [*loc location*] [*st state*] [*cu country*]

PARAMETERS

- ◆ **number**—Specifies the certificate number. (Range: 1–2)
- ◆ **common-name**—Specifies the device's fully qualified URL or IP address. (Length: 1–64 characters)
- ◆ **ou organization-unit**—Specifies the organization-unit or department name. (Length: 1–64 characters)
- ◆ **or organization**—Specifies the organization name. (Length: 1–64 characters)
- ◆ **loc location**—Specifies the location or city name. (Length: 1–64 characters)
- ◆ **st state**—Specifies the state or province name. (Length: 1–64 characters)
- ◆ **cu country**—Specifies the country name. (Length: 2 characters)

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

Use this command to export a certificate request to a Certification Authority. The certificate request is generated in Base64-encoded X.509 format.

Before generating a certificate request, first generate a self-signed certificate using the **crypto certificate generate** Global Configuration mode command to generate the keys. The certificate fields must be re-entered.

After receiving the certificate from the Certification Authority, use the **crypto certificate import** Global Configuration mode command to import the certificate into the device. This certificate replaces the self-signed certificate.

EXAMPLE

The following example displays the certificate request for HTTPS.

```

Console# crypto certificate 1 request
-----BEGIN CERTIFICATE REQUEST-----
MIwTCCASoCAQAwYjELMAkGA1UEBhMCUFACzAJBgNVBAGTAkNDMQswCQYDVQQH
EwRDEMMAoGA1UEChMDZGxkMQwwCgYDVQQLEwNkbGQxGQxGQzAJBgNVBAMTAmxkMRAw
DgKoZihvcNAQkBFgFsmIGfMA0GCSqGSIb3DQEBAQUAA4GNADCBiQKBgQC8ecwQ
HdML0831i0fh/F0MV/Kib6Sz5p+3nUUenbfHp/igVPmFM+1nbqTDekb2ymCu6K
aKvEbVLF9F2LmM7VPjDBb9bb4jnxkvwW/wzDLvW2rsy5NPmH1QV1+8Ubx3GyCm
/oW93BSOFwxwEsP58kf+sPYPy+/8wwmoNtDwIDAQABoB8wHQYJKoZIhvcNAQkH
MRDjEyMwgICCAgICAICAQIMA0GCSqGSIb3DQEBAUAA4GBAGb8UgIx7rB05m+2
m5ZZPhIw18ARSPXwhVdJexFjbnmvcacqjPG8pIiRV6LkxryGF2bVU3jKEipcZa
g+uNpyTkDt3ZVU72pjz/fa8TF0n3
-----END CERTIFICATE REQUEST-----

CN= router.gm.com
O= General Motors
C= US

```

crypto certificate import The **crypto certificate import** Global Configuration mode command imports a certificate signed by a Certification Authority for HTTPS.

SYNTAX

crypto certificate *number* import

PARAMETERS

number—Specifies the certificate number. (Range: 1–2)

COMMAND MODE

Global Configuration mode

USER GUIDELINES

To end the session, use a blank line.

The imported certificate must be based on a certificate request created by the **crypto certificate request** privileged EXEC command.

If the public key found in the certificate does not match the device's SSL RSA key, the command fails.

This command is not saved in the router configuration. However, the certificate imported by this command is saved in the private configuration (which is never displayed to the user or backed up to another device).

EXAMPLE

The following example imports a certificate signed by Certification Authority for HTTPS.

```
Console(config)# crypto certificate 1 import
-----BEGIN CERTIFICATE-----
dHmUgUm9vdCBDZxJ0aWZpZXIwXDANBgkqhkiG9w0BAQEFAANLADBIAkEAp4HS
nnH/xQSGA2ffkRBwU2XIxb7n8VPsTm1xyJ1t11a1GaqchfMqge0kmfhcoHSWr
yf1FpD0MWOTgDAwIDAQABo4IBojCCAZ4wEwYJKwYBBAGCNxQCBAYeBABDAEEw
CwR0PBAQDAgFGMA8GA1UdEwEB/wQFMAMBAf8wHQYDVIR0OBByEAF4MT9BRD47
ZvKBAEL9Ggp+6MIIBNgYDVIR0fBIIBLTCCASkgdKggc+ggcyGgclszGFwOi8v
L0VByb3h5JTlwU29mdHdhcmU1MjBSb290JTlwQ2VydGlmWVYLENOPXNlcnZl
-----END CERTIFICATE-----

Certificate imported successfully.
Issued to: router.gm.com
Issued by: www.verisign.com
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: DC789788 DC88A988 127897BC BB789788
```

crypto certificate export pkcs12 The **crypto certificate export pkcs12** Privileged EXEC mode command exports the certificate and the RSA keys within a PKCS12 file.

SYNTAX

crypto certificate *number* export pkcs12

PARAMETERS

number—Specifies the certificate number. (Range: 1–2)

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

The **crypto certificate export pkcs12** command creates a PKCS 12 file that contains the certificate and an RSA key pair.

The passphrase for the export is determined when the key is generated.

The certificate and key pair are exported in a standard PEM-format PKCS12 file. This format can be converted to and from the binary PFX file used by Windows and Linux by using the **openssl** command-line tool. See an open source OpenSSL user manual (man pkcs12) for more information.

EXAMPLE

The following example exports the certificate and the RSA keys within a PKCS12 file.

```

Console# crypto certificate 1 export pkcs12
Bag Attributes
localKeyID: 0C 75 81 77 5A 31 53 D1 FF 4E 26 BE 8D 4A FD 8B 22 9F 45 D4
subject=/C=us/ST= /L= /CN= /O= /OU=
issuer= /C=us/ST= /L= /CN= /O= /OU=
-----BEGIN CERTIFICATE-----
MIIBfDCCASYCAQAwDQYJKoZIhvcNAQEEBQAwSTELMAkGA1UEBhMCdXMxCjAIBgNV
BAGTASAxCjAIBGNVBAcTASAxCjAIBGNVBAMTASAxCjAIBGNVBAoTASAxCjAIBGNV
BAstASAwHhcNMDQwMjA3MTU1NDQ4WhcNMDUwMjA2MTU1NDQ4WjBJMQswCQYDVQQG
EwJ1czEKMAgGA1UECBMIDEKMAgGA1UEBxMBIDEKMAgGA1UEAxMBIDEKMAgGA1UE
ChMBIDEKMAgGA1UECxMBIDBcMA0GCSqGSIb3DQEBAQUAA0sAMEgCQCZXP/tk3e/
jrulfZw8qT2oS5ymrEIES/sRJE8uahTBJqKulVHqRYJR3VYa/03HSJ741w5MzPI
iuWZzrbbuXAxAgMBAAEwDQYJKoZIhvcNAQEEBQADQQBQ+GTLeN1p1kARxI4C1fTU
efig3ffZ/tjW5q1t1r5F6zNv/GuXWw7rGzmRyoMXDcYp1TaA4gAIFQCpFGqiSbAx
-----END CERTIFICATE-----
Bag Attributes
localKeyID: 0C 75 81 77 5A 31 53 D1 FF 4E 26 BE 8D 4A FD 8B 22 9F 45 D4
Key Attributes: <No Attributes>
-----BEGIN RSA PRIVATE KEY-----
Proc-Type: 4, ENCRYPTED
DEK-Info: DES-EDE3-CBC, 085DCBF3A41D2669
dac0m9jqEp1DM50sIDb8Jq1jxW/1P0kqSxuMhc25OdBE/1fPBg9VSvV1ARaYt16W
bX67UyJ8t7HHF3AowjcWzElQ5GJgSQ0VemsqsRQzjpCTb090rx+cNwVfIvjoedgQ
Mt15+fKIAcqsEfEgEGJNXQ4jEzsXAkWfQLFfgt4703IpkUn0AxrQzutJD0c28Uxp
raMVTVS1SkJIvaPuXJxdZ279tDMwZffILBfKCJGACT5V5/4WEqDkrF+uuF9/oxm2
5SVL8TvUmXB/3hX4UoaXtxAhuyOdhh1kyyZSpw9BPPR/8bc/wUYERh7+7JXLKHpd
ueeu3znfIX4dDeti8B3xYvvE8kGZjxFN1cC3zc3JsD0IVu1LkyiAa93P4LPEvAwG
Fw1LqmGiiqw9JM/tzc6kYkZxylFzCrSVf2exP+/tEvM=
-----END RSA PRIVATE KEY-----

```

crypto certificate import pkcs12 The **crypto certificate import pkcs12** Privileged EXEC mode command imports the certificate and the RSA keys within a PKCS12 file.

SYNTAX

crypto certificate *number* import pkcs12 *passphrase*

PARAMETERS

- ◆ **number**—Specifies the certificate number. (Range: 1–2)
- ◆ **passphrase**—Specifies the passphrase used to encrypt the PKCS12 file for export. (Length: 8–96 characters)

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

Use the passphrase that was exported by the **crypto certificate export pkcs12** command.

This passphrase is saved for later exports.

EXAMPLE

The following example imports the certificate and the RSA keys within a PKCS12 file.

```

Console# crypto certificate 1 import pkcs12 passphrase
Bag Attributes
localKeyID: 0C 75 81 77 5A 31 53 D1 FF 4E 26 BE 8D 4A FD 8B 22 9F 45 D4
subject=/C=us/ST= /L= /CN= /O= /OU=
issuer= /C=us/ST= /L= /CN= /O= /OU=
-----BEGIN CERTIFICATE-----
MIIBfDCCASYCAQAwDQYJKoZIhvcNAQEEBQAwSTELMAkGA1UEBhMCdXMxCjAIBgNV
BAGTASAxCjAIBGNVBACjAIBGNVBAMTASAxCjAIBGNVBACjAIBGNVBACjAIBGNV
BAsTASAwHhcNMDQwMjA3MTU1NDQ4WjcNMDUwMjA2MTU1NDQ4WjBjMQswCQYDVQQG
EwJ1czEKMAgGA1UECBMIDEKMAgGA1UEBxMBIDEKMAgGA1UEAxMBIDEKMAgGA1UE
ChMBIDEKMAgGA1UECxMBIDBcMA0GCsGGSIB3DQEBAQUAA0sAMEgCQCZXP/tk3e/
jrulfZw8qT2oS5ymrEIES/sRJE8uahTBjQKulVHqRYJR3VYa/03HSJ741w5MzPI
iuWZzrbbuXAxAgMBAAEwDQYJKoZIhvcNAQEEBQADQQBQ+GTLeN1p1kARxI4C1fTU
efig3ffZ/tjW5q1t1r5F6zNv/GuXWw7rGzmRyoMXDcYp1TaA4gAIFQCpFGqiSbAx
-----END CERTIFICATE-----
Bag Attributes
localKeyID: 0C 75 81 77 5A 31 53 D1 FF 4E 26 BE 8D 4A FD 8B 22 9F 45 D4
Key Attributes: <No Attributes>
-----BEGIN RSA PRIVATE KEY-----
Proc-Type: 4, ENCRYPTED
DEK-Info: DES-EDE3-CBC, 085DCBF3A41D2669
dac0m9jqEp1DM50sIDb8Jq1jxW/1P0kqSxuMhc25OdBE/1fPBg9VSvV1ARaYt16W
bX67UyJ8t7HHF3AowjcWzElQ5GJgSQ0VemsqsRQzjpCTb090rx+cNwVfIvjoedgQ
Mtl5+fKIAcqsFEGEGJNXQ4jEzsXakwQLFfgt4703IpkUn0AxrQzutJD0cC28Uxp
raMVTVS1SkJIvaPuXJxdZ279tDMwZffILBfKJGACT5V5/4WEqDkrF+uuF9/oxm2
5SVL8TvUmXB/3hX4UoaXtxAhuyOdhh1kyyZSpw9BPPR/8bc/wUYERh7+7JXLKHpd
ueeu3znfIX4dDeti8B3xYvvE8kGZjxFN1cC3zc3JsD0IVu1LkyiAa93P4LPEvAwG
Fw1LqmGiigw9JM/tzc6kYkZxylFzCrSVf2exP+/tEvM=
-----END RSA PRIVATE KEY-----

```

**show crypto
certificate
mycertificate**

The **show crypto certificate mycertificate** Privileged EXEC mode command displays the device SSL certificates.

SYNTAX

show crypto certificate mycertificate [*number*]

PARAMETERS

number—Specifies the certificate number. (Range: 1–2)

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays SSL certificate # 1 present on the device.

```

Console# show crypto certificate mycertificate 1
-----BEGIN CERTIFICATE-----
dHmUgUm9vdCBDZXJ0aWZpZXIwXjA1NDQ4WjBjMQswCQYDVQQGEwJ1czEKMAgGA1UECBMIDEKMAgGA1UEBxMBIDEKMAgGA1UEAxMBIDEKMAgGA1UEChMBIDEKMAgGA1UECxMBIDBcMA0GCsGGSIB3DQEBAQUAA0sAMEgCQCZXP/tk3e/
jrulfZw8qT2oS5ymrEIES/sRJE8uahTBjQKulVHqRYJR3VYa/03HSJ741w5MzPI
iuWZzrbbuXAxAgMBAAEwDQYJKoZIhvcNAQEEBQADQQBQ+GTLeN1p1kARxI4C1fTU
efig3ffZ/tjW5q1t1r5F6zNv/GuXWw7rGzmRyoMXDcYp1TaA4gAIFQCpFGqiSbAx
-----END CERTIFICATE-----

```

```
ZvKBAEL9Ggp+6MIIBNgYDVR0fBIIBLTCCASKwgdKggc+ggcyGgclsZGFwOi8v
L0VByb3h5JTlwU29mdHdhcmU1MjBSb290JTlwQ2VydGlmaWVyLENOPXNlcnZl
-----END CERTIFICATE-----
```

```
Issued by: www.verisign.com
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: DC789788 DC88A988 127897BC BB789788
```

ip http server The **ip http server** Global Configuration mode command enables configuring and monitoring the device from a web browser. Use the **no** form of this command to disable this function.

SYNTAX

ip http server
no ip http server

DEFAULT CONFIGURATION

HTTP server is enabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables configuring the device from a web browser.

```
Console(config)# ip http server
```

ip http port The **ip http port** Global Configuration mode command specifies the TCP port used by the web browser interface. Use the **no** form of this command to restore the default configuration.

SYNTAX

ip http port *port-number*
no ip http port

PARAMETERS

port-number**Port number**—For use by the HTTP server. (Range: 0–65534)

DEFAULT CONFIGURATION

The default port number is 80.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures the http port number as 100.

```
Console(config)# ip http port 100
```

ip http timeout-policy

Use the **ip http timeout-policy** Global Configuration mode command to set the interval for the system to wait for user input in http sessions before automatic logoff. Use the **no** form of this command to return to the default value.

SYNTAX

ip http timeout-policy *idle seconds*

no ip http timeout-policy

PARAMETERS

seconds—Specifies the maximum number of seconds that a connection is kept open if no data is received or response data cannot be sent out. (Range: 0–86400)

DEFAULT

600 seconds

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command also configures the timeout-policy for HTTPS.

To specify no timeout, enter the **ip http timeout-policy 0** command.

EXAMPLE

The following example configures the http port number as 100.

```
Console(config)# ip http timeout-policy 0
```

ip http secure-server Use the **ip http secure-server** Global Configuration mode command to enable the device to be configured securely from a browser, and to also enable the device to be monitored or have its configuration modified securely from a browser,. Use the **no** form of this command to disable this function.

SYNTAX

ip http secure-server
no ip http secure-server

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use the **crypto certificate generate** command to generate an HTTPS certificate.

EXAMPLE

```
console(config)# ip http secure-server
```

ip http secure-port To specify the TCP port to be used by the secure web browser interface, use the **ip http secure-port** Global Configuration mode command. To use the default port, use the **no** form of this command.

SYNTAX

ip http secure-port *port-number*
no ip http secure-port

PARAMETERS

port-number—Port number for use by the HTTPS server (Range: 0–65534)

DEFAULT

The default port number is 443.

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# ip http secure-port 1234
```

ip https certificate The **ip https certificate** Global Configuration mode command configures the active certificate for HTTPS. Use the **no** form of this command to restore the default configuration.

SYNTAX

ip https certificate *number*

no ip https certificate

PARAMETERS

number—Specifies the certificate number. (Range: 1–2)

DEFAULT CONFIGURATION

The default certificate number is 1.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use the **crypto certificate generate** command to generate a HTTPS certificate.

EXAMPLE

The following example configures the active certificate for HTTPS.

```
Console(config)# ip https certificate 2
```

show ip http The **show ip http** EXEC mode command displays the HTTP server configuration.

SYNTAX

show ip http

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the HTTP server configuration.

```
Console# show ip http
HTTP server enabled
Port: 80
Interactive timeout: 10 minutes
```

show ip https The **show ip https** Privileged EXEC mode command displays the HTTPS server configuration.

SYNTAX

show ip https

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the HTTPS server configuration.

```
Console# show ip https
HTTPS server enabled
Port: 443
Interactive timeout: Follows the HTTP interactive timeout (10 minutes)

Certificate 1 is active
Issued by: www.verisign.com
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: DC789788 DC88A988 127897BC BB789788

Certificate 2 is inactive
Issued by: self-signed
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: 1873B936 88DC3411 BC8932EF 782134BA
```

TELNET, SECURE SHELL (SSH), AND SECURE LOGIN (SLOGIN) COMMANDS

iPECS ES-5048XG

ip telnet server The **ip telnet server** Global Configuration mode command enables the device to be configured from a Telnet server. Use the **no** form of this command to disable the device configuration from a Telnet server.

SYNTAX

ip telnet server

no ip telnet server

DEFAULT CONFIGURATION

Device configuration from a Telnet server is enabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

To control the device configuration by SSH, use the **ip ssh server** Global Configuration mode command.

EXAMPLE

The following example enables the device to be configured from a Telnet server.

```
Console(config)# ip telnet server
```

ip ssh port The **ip ssh port** Global Configuration mode command specifies the port used by the SSH server. Use the **no** form of this command to restore the default configuration.

SYNTAX

ip ssh port *port-number*

no ip ssh port

PARAMETERS

port-number—Specifies the port number to be used by the SSH server. (Range: 1–65535)

DEFAULT CONFIGURATION

The default port number is 22.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example specifies that port number 8080 is used by the SSH server.

```
Console(config)# ip ssh port 8080
```

ip ssh server The **ip ssh server** Global Configuration mode command enables the device to be configured from an SSH server. Use the **no** form of this command to disable the device configuration from a SSH server,.

SYNTAX

ip ssh server

no ip ssh server

DEFAULT CONFIGURATION

Device configuration from an SSH server is enabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

If encryption keys are not generated, the SSH server is in standby until the keys are generated. To generate SSH server keys, use the **crypto key generate dsa** and **crypto key generate rsa** Global Configuration mode commands.

EXAMPLE

The following example enables configuring the device from a SSH server.

```
Console(config)# ip ssh server
```

ip ssh pubkey-auth The **ip ssh pubkey-auth** Global Configuration mode command enables public key authentication of incoming SSH sessions. Use the **no** form of this command to disable this function.

SYNTAX

ip ssh pubkey-auth

no ip ssh pubkey-auth

DEFAULT CONFIGURATION

Public Key authentication of incoming SSH sessions is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

AAA authentication is independent.

EXAMPLE

The following example enables public key authentication for incoming SSH sessions.

```
Console(config)# ip ssh pubkey-auth
```

crypto key pubkey-chain ssh

The **crypto key pubkey-chain ssh** Global Configuration mode command enters the SSH Public Key-chain Configuration mode. This mode is used to manually specify other device public keys such as SSH client public keys.

SYNTAX

crypto key pubkey-chain ssh

DEFAULT CONFIGURATION

Keys do not exist.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use this command when you want to manually specify SSH client's public keys.

EXAMPLE

The following example enters the SSH Public Key-chain Configuration mode and manually configures the RSA key pair for SSH public key-chain to 'bob'.

```
Console(config)# crypto key pubkey-chain ssh
Console(config-pubkey-chain)# user-key bob
Console(config-pubkey-key)# key-string rsa
AAAAB3NzaC1yc2EAAAADAQABAAQCVtNrWpWl
Al4kpqIw9GBRonZQZxjHKcQKL6rMlQ+
ZNXfZSkvHG+QusIZ/76ILmFT34v7u7ChFAE+
Vu4GRfpSwoQUvV35LqJJk67IOU/zfwO1lg
kTwml75QR9gHujS6KwGN2QWXgh3ub8gDjTSq
muSn/Wd05iDX2IExQWu08licg1k02LYciz
+Z4TrEU/9FJxwPiVQOjc+KBXuR0juNg5nFYsY
0ZCk0N/W9a/tnkmlshRE7Di7l+w3fNiOA
6w9o44t6+AINEICBCCA4YcF6zMzaTlwefWwX6f+
Rmt5nhhqdaTn/4oJfcel66DqVX1gWmN
```

```
zNR4DYDvSzg0lDnwCAC8Qh
```

```
Fingerprint: a4:16:46:23:5a:8d:1d:b5:37:59:eb:44:13:b9:33:e9
```

user-key The **user-key** SSH Public Key-string Configuration mode command specifies which SSH public key is manually configured. Use the **no** form of this command to remove an SSH public key.

SYNTAX

```
user-key username {rsa | dsa}
```

```
no user-key username
```

PARAMETERS

- ◆ **username**—Specifies the remote SSH client username. (Length: 1–48 characters)
- ◆ **rsa**—Specifies that the RSA key pair is manually configured.
- ◆ **dsa**—Specifies that the DSA key pair is manually configured.

DEFAULT CONFIGURATION

No SSH public keys exist.

COMMAND MODE

SSH Public Key-string Configuration mode

USER GUIDELINES

Follow this command with the **key-string** SSH Public Key-String Configuration mode command to specify the key.

Please note that after entering this command, the existing key is deleted even if no new key is defined by the **key-string** command

EXAMPLE

The following example enables manually configuring an SSH public key for SSH public key-chain **bob**.

```
Console(config)# crypto key pubkey-chain ssh
Console(config-pubkey-chain)# user-key bob rsa
Console(config-pubkey-key)# key-string row
AAAAB3NzaC1yc2EAAAADAQABAAQCVtNrWpWl
```

key-string The **key-string** SSH Public Key-string Configuration mode command manually specifies an SSH public key.

SYNTAX

```
key-string [row key-string]
```

PARAMETERS

- ◆ **row**—Specifies the SSH public key row by row.
- ◆ **key-string**—Specifies the key in UU-encoded DER format. UU-encoded DER format is the same format as in the `authorized_keys` file used by OpenSSH. (Length:0–160)

DEFAULT CONFIGURATION

Keys do not exist.

COMMAND MODE

SSH Public Key-string Configuration mode

USER GUIDELINES

Use the **key-string** SSH Public Key-string Configuration mode command without the **row** parameter to specify which SSH public key is to be interactively configured next. Enter a row with no characters to complete the command.

Use the **key-string row** SSH Public Key-string Configuration mode command to specify the SSH public key, row by row. Each row must begin with a **key-string row** command.

The UU-encoded DER format is the same format as in the `authorized_keys` file used by OpenSSH.

EXAMPLE

The following example enters public key strings for SSH public key client 'bob'.

```

Console(config)# crypto key pubkey-chain ssh
Console(config-pubkey-chain)# user-key bob rsa
Console(config-pubkey-key)# key-string
AAAAB3NzaC1yc2EAAAADAQABAAQCVtNrWpWl
Al4kpqIw9GBRonZQZxjHKcQKL6rMlQ+
ZNXfZSkvHG+QusIZ/76ILmFT34v7u7ChFAE+
Vu4GRfpSwoQUvV35LqJJk67IOU/zfw011g
kTwml75QR9gHujS6KwGN2QWXgh3ub8gDjTSq
muSn/Wd05iDX2IExQWu08licg1k02LYciz
+Z4TrEU/9FJxwPiVQOjc+KBXuR0juNg5nFYsY
0ZCk0N/W9a/tnkmlshRE7Di7l+w3fNiOA
6w9o44t6+AINEICBCCA4YcF6zMzaTlwefWwX6f+
Rmt5nhhqAtN/4oJfcel66DqVX1gWmN
zNR4DYDvSzg01DnwCAC8Qh

Fingerprint: a4:16:46:23:5a:8d:1d:b5:37:59:eb:44:13:b9:33:e9

Console(config)# crypto key pubkey-chain ssh
Console(config-pubkey-chain)# user-key bob rsa
Console(config-pubkey-key)# key-string row AAAAB3Nza
Console(config-pubkey-key)# key-string row C1yc2

```

show ip ssh The **show ip ssh** Privileged EXEC mode command displays the SSH server configuration.

SYNTAX

show ip ssh

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the SSH server configuration.

```

Console# show ip ssh

SSH server enabled. Port: 22
RSA key was generated.
DSA (DSS) key was generated.

SSH Public Key Authentication is enabled.

Active incoming sessions:

IP address      SSH username    Version    Cipher      Auth code
-----
172.16.0.1      John Brown      1.5        3DES        HMAC-SHA1

```

The following table describes the significant fields shown in the display.

Field	Description
IP address	The client address
SSH username	The user name
Version	The SSH version number
Cipher	The encryption type (3DES, Blowfish, RC4)
Auth Code	The authentication Code (HMAC-MD5, HMAC-SHA1)

show crypto key pubkey-chain ssh The **show crypto key pubkey-chain ssh** Privileged EXEC mode command displays SSH public keys stored on the device.

SYNTAX

show crypto key pubkey-chain ssh [*username username*]
 [*fingerprint {bubble-babble | hex}*]

PARAMETERS

- ◆ **username username**—Specifies the remote SSH client username. (Length: 1–48 characters)

- ◆ **fingerprint {bubble-babble | hex}**—Specifies the fingerprint display format. The possible values are:
 - **bubble-babble**—Specifies that the fingerprint is displayed in Bubble Babble format.
 - **hex**—Specifies that the fingerprint is displayed in hexadecimal format.

DEFAULT CONFIGURATION

The default fingerprint format is hexadecimal.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following examples display SSH public keys stored on the device.

```

Console# show crypto key pubkey-chain ssh

Username
-----
bob
john
Fingerprint
-----
9A:CC:01:C5:78:39:27:86:79:CC:23:C5:98:59:F1:86
98:F7:6E:28:F2:79:87:C8:18:F8:88:CC:F8:89:87:C8

Console# show crypto key pubkey-chain ssh username bob
Username: bob
Key: 005C300D 06092A86 4886F70D 01010105 00034B00 30480241 00C5E23B 55D6AB22
    04AEF1BA A54028A6 9ACC01C5 129D99E4
Fingerprint: 9A:CC:01:C5:78:39:27:86:79:CC:23:C5:98:59:F1:86

```


line The **line** Global Configuration mode command identifies a specific line for configuration and enters the Line Configuration command mode.

SYNTAX

line {*console* | *telnet* | *ssh*}

PARAMETERS

- ◆ **console**—Enters the console terminal line mode.
- ◆ **telnet**—Configures the device as a virtual terminal for remote console access (Telnet).
- ◆ **ssh**—Configures the device as a virtual terminal for secured remote console access (SSH).

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures the device as a virtual terminal for remote (Telnet) console access.

```
Console(config)# line telnet
Console(config-line)#
```

speed The **speed** Line Configuration mode command sets the line baud rate. Use the **no** form of this command to restore the default configuration.

SYNTAX

speed *bps*

no speed

PARAMETERS

bps—Specifies the baud rate in bits per second (bps). Possible values are 2400, 4800, 9600, 19200, 38400, 57600, and 115200.

DEFAULT CONFIGURATION

The default speed is 9600 bps.

COMMAND MODE

Line Configuration (console) mode

USER GUIDELINES

The configured speed is applied when Autobaud is disabled. This configuration applies to the current session only.

EXAMPLE

The following example configures the line baud rate as 9600 bits per second.

```
Console(config-line)# speed 9600
```

autobaud The **autobaud** Line Configuration mode command sets the line for automatic baud rate detection (autobaud). Use the **no** form of this command to disable automatic baud rate detection.

SYNTAX

autobaud

no autobaud

DEFAULT CONFIGURATION

Automatic baud rate detection is disabled.

COMMAND MODE

Line Configuration mode

USER GUIDELINES

To start communication using Autobaud, press the **Enter** key twice.

EXAMPLE

The following example enables autobaud.

```
Console(config)# line console  
Console(config-line)# autobaud
```

exec-timeout The **exec-timeout** Line Configuration mode command sets the session idle time interval, during which the system waits for user input before automatic logoff. Use the **no** form of this command to restore the default configuration.

SYNTAX

exec-timeout *minutes* [*seconds*]
no exec-timeout

PARAMETERS

- ◆ **minutes**—Specifies the number of minutes. (Range: 0-65535)
- ◆ **seconds**—Specifies the number of seconds. (Range: 0-59)

DEFAULT CONFIGURATION

The default idle time interval is 10 minutes.

COMMAND MODE

Line Configuration mode

USER GUIDELINES

To specify no timeout, enter the **exec-timeout** 0 0 command.

EXAMPLE

The following example sets the HTTP session idle time interval before automatic logoff to 20 minutes.

```
Console(config)# line console
Console(config-line)# exec-timeout 20
```

show line The **show line** EXEC mode command displays line parameters.

SYNTAX

show line [*console* | *telnet* | *ssh*]

PARAMETERS

- ◆ **console**—Displays the console configuration.
- ◆ **telnet**—Displays the Telnet configuration.
- ◆ **ssh**—Displays the SSH configuration.

DEFAULT CONFIGURATION

If the line is not specified, all line configuration parameters are displayed.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the line configuration.

```
Console> show line

Console configuration:

Interactive timeout: Disabled
History: 10
Baudrate: 9600
Databits: 8
Parity: none
Stopbits: 1

Telnet configuration:

Telnet is enabled.
Interactive timeout: 10 minutes 10 seconds
History: 10

SSH configuration:

SSH is enabled.
Interactive timeout: 10 minutes 10 seconds
History: 10
```

aaa authentication login The **aaa authentication login** Global Configuration mode command sets an authentication method applied during login. Use the **no** form of this command to restore the default authentication method.

SYNTAX

```
aaa authentication login {default | list-name} method [method2 ...]  
no aaa authentication login {default | list-name}
```

PARAMETERS

- ◆ **default**—Uses the listed authentication methods that follow this argument as the default method list when a user logs in.
- ◆ **list-name**—Specifies a name for a list of authentication methods activated when a user logs in. (Length: 1–12 characters)
- ◆ **method [method2 ...]**—Specifies a list of methods that the authentication algorithm tries, in the given sequence. The additional authentication methods are used only if the previous method returns an error, not if it fails. To ensure that the authentication succeeds even if all methods return an error, specify **none** as the final method in the command line. Select one or more methods from the following list:

Keyword	Description
enable	Uses the enable password for authentication.
line	Uses the line password for authentication.
local	Uses the local username database for authentication.
none	Uses no authentication.
radius	Uses the list of all RADIUS servers for authentication.
tacacs	Uses the list of all TACACS+ servers for authentication.

DEFAULT CONFIGURATION

The local user database is the default authentication method. This is the same as entering the command **aaa authentication login local**.

If an authentication method is not defined, console users can log in without any authentication verification.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The default and additional list names created with the **aaa authentication login** command are used with the **login authentication** command.

Create a list by entering the **aaa authentication login** list-name method command for a particular protocol, where list-name is any character string used to name) this list. The method argument identifies the list of methods that the authentication algorithm tries, in the given sequence.

The additional methods of authentication are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in the command line to ensure that the authentication succeeds even if all methods return an error.

EXAMPLE

The following example sets the authentication login methods.

```
Console (config)# aaa authentication login default radius local enable none
```

aaa authentication enable

The **aaa authentication enable** Global Configuration mode command sets an authentication method for accessing higher privilege levels. To restore the default authentication method, use the **no** form of this command.

SYNTAX

aaa authentication enable {default | list-name} method [method2 ...]

no aaa authentication enable {default | list-name}

PARAMETERS

- ◆ **default**—Uses the listed authentication methods that follow this argument as the default method list, when accessing higher privilege levels.
- ◆ **list-name** —Specifies a name for the list of authentication methods activated when a user accesses higher privilege levels. (Length: 1–12 characters)
- ◆ **method [method2 ...]**—Specifies a list of methods that the authentication algorithm tries, in the given sequence. The additional authentication methods are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in the command line to ensure that the authentication succeeds, even if all methods return an error. Select one or more methods from the following list:

Keyword	Description
enable	Uses the enable password for authentication.
line	Uses the line password for authentication.
none	Uses no authentication.
radius	Uses the list of all RADIUS servers for authentication. Uses username "\$enabx\$." where x is the privilege level.
tacacs	Uses the list of all TACACS servers for authentication. Uses username "\$enabx\$." where x is the privilege level.

DEFAULT CONFIGURATION

The **enable password** command is the default authentication login method. This is the same as entering the command **aaa authentication enable default enable**.

On a console, the enable password is used if a password exists. If no password is set, authentication still succeeds. This is the same as entering the command **aaa authentication enable default enable none**.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The default and additional list names created with the **aaa authentication enable** command are used with the **enable authentication** command.

All **aaa authentication enable default** requests sent by the device to a RADIUS or TACACS+ server include the username **\$enabx\$**, where **x** is the requested privilege level.

Create a list by entering the **aaa authentication enable** list-name method command where list-name is any character string used to name this list. The method argument identifies the list of methods that the authentication algorithm tries, in the given sequence.

The additional methods of authentication are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in the command line to ensure that the authentication succeeds even if all methods return an error.

EXAMPLE

The following example sets the enable password for authentication for accessing higher privilege levels.

```
Console(config)# aaa authentication enable default enable
```

login authentication The **login authentication** Line Configuration mode command specifies the login authentication method list for a remote Telnet or console session. Use the **no** form of this command to restore the default authentication method.

SYNTAX

login authentication {*default* | *list-name*}

no login authentication

PARAMETERS

- ◆ **default**—Uses the default list created with the **aaa authentication login** command.
- ◆ **list-name**—Uses the specified list created with the **aaa authentication login** command. (Length: 1–12 characters).

DEFAULT CONFIGURATION

The default is the **aaa authentication login** command default.

COMMAND MODE

Line Configuration mode

EXAMPLE

The following example specifies the login authentication method for a console session.

```
Console(config)# line console
Console(config-line)# login authentication default
```

enable authentication The **enable authentication** Line Configuration mode command specifies the authentication method for accessing a higher privilege level from a remote Telnet or console. Use the **no** form of this command to restore the default authentication method.

SYNTAX

enable authentication {*default* | *list-name*}

no enable authentication

PARAMETERS

- ◆ **default**—Uses the default list created with the **aaa authentication enable** command.
- ◆ **list-name**—Uses the specified list created with the **aaa authentication enable** command. (Length: 1–12 characters).

DEFAULT CONFIGURATION

The default is the **aaa authentication enable** command default.

COMMAND MODE

Line Configuration mode

EXAMPLE

The following example specifies the authentication method when accessing a higher privilege level from a console.

```
Console(config)# line console
Console(config-line)# enable authentication default
```

ip http authentication

The **ip http authentication** Global Configuration mode command specifies authentication methods for HTTP server access. Use the **no** form of this command to restore the default authentication method.

SYNTAX

ip http authentication aaa login-authentication *method1*
[*method2...*]

no ip http authentication aaa login-authentication

PARAMETERS

method [method2 ...]—Specifies a list of methods that the authentication algorithm tries, in the given sequence. The additional authentication methods are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in the command line to ensure that the authentication succeeds, even if all methods return an error. Select one or more methods from the following list:

Keyword	Description
local	Uses the local username database for authentication.
none	Uses no authentication.
radius	Uses the list of all RADIUS servers for authentication.
tacacs	Uses the list of all TACACS+ servers for authentication.

DEFAULT CONFIGURATION

The local user database is the default authentication login method. This is the same as entering the **ip http authentication local** command.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The command is relevant for HTTP and HTTPS server users.

The additional methods of authentication are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in

the command line to ensure that the authentication succeeds, even if all methods return an error.

EXAMPLE

The following example specifies the HTTP access authentication methods.

```
Console(config)# ip http authentication aaa login-authentication radius local
```

show authentication methods

The **show authentication methods** Privileged EXEC mode command displays information about the authentication methods.

SYNTAX

show authentication methods

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the authentication configuration.

```
Console# show authentication methods
```

```
Login Authentication Method Lists
```

```
-----
```

```
Default: Radius, Local, Line
```

```
Console_Login: Line, None
```

```
Enable Authentication Method Lists
```

```
-----
```

```
Default: Radius, Enable
```

```
Console_Enable: Enable, None
```

Line	Login Method List	Enable Method List
-----	-----	-----
Console	Console_Login	Console_Enable
Telnet	Default	Default
SSH	Default	Default

```
HTTP: Radius, local
```

```
HTTPS: Radius, local
```

```
Dot1x: Radius
```

password The **password** Line Configuration mode command specifies a password on a line, also known as access method, such as a console or Telnet. Use the **no** form of this command to return to the default password.

SYNTAX

password *password* [*encrypted*]
no password

PARAMETERS

- ◆ **password**—Specifies the password for this line. (Length: 0–159 characters)
- ◆ **encrypted**—Specifies that the password is encrypted and copied from another device configuration.

DEFAULT CONFIGURATION

No password is defined.

COMMAND MODE

Line Configuration mode

EXAMPLE

The following example specifies the password 'secret' on a console.

```
Console(config)# line console
Console(config-line)# password secret
```

enable password Use the **enable password** Global Configuration mode command to set a local password to control access to normal and privilege levels. Use the **no** form of this command to return to the default password.

SYNTAX

enable password [*level* *privilege-level*] { *password* | *encrypted-password* }
no enable password [*level* *level*]

PARAMETERS

- ◆ **level** *privilege-level*—Level for which the password applies. If not specified the level is 15. (Range: 1–15)
- ◆ **password**—Password for this level. (Range: 0–159 chars)
- ◆ **encrypted-password**—Encrypted password you enter, copied from another device configuration.

DEFAULT

Default for **level** is 15.

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# enable password level 15 let-me-in
```

username Use the **username** Global Configuration mode command to establish a username-based authentication system. Use the **no** form to remove a user name.

SYNTAX

username *name* { *nopassword* | **password** *password* | **privilege** *privilege-level* | **password encrypted** *encrypted-password* }

username *name*

no username *name*

PARAMETERS

- ◆ **name**—The name of the user. (Range: 1–20 characters)
- ◆ **nopassword**—No password is required for this user to log in.
- ◆ **password**—The authentication password for the user. (Range: 1–159)
- ◆ **password-encrypted**—Encrypted password you enter, copied from another device configuration.
- ◆ **privilege** *privilege-level* —Privilege level for which the password applies. If not specified the level is 15. (Range: 1–15)

DEFAULT

No user is defined.

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# username tom privilege 15 password 1234
```

show user accounts The **show user accounts** Privileged EXEC mode command displays information about the users local database.

SYNTAX

show user accounts

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays information about the users local database.

```
Console# show user accounts
```

```

Username      Privilege
-----
Bob           15
Robert        15
Smith         15
```

The following table describes the significant fields shown in the display:

Field	Description
Username	The user name.
Privilege	The user's privilege level.

aaa accounting login Use the **aaa accounting login** command in Global Configuration mode to enable accounting of device management sessions. Use the **no** form of this command to disable accounting.

SYNTAX

aaa accounting login *start-stop group radius*

no aaa accounting login *start-stop group radius*

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command enables the recording of device management sessions (Telnet, serial and WEB but not SNMP).

It records only users that were identified with a username (e.g. a user that was logged in with a line password is not recorded).

If accounting is activated, the device sends a “start”/“stop” messages to a Radius server when a user logs in / logs out respectively.

The device uses the configured priorities of the available Radius servers in order to select the Radius server.

The following table describes the supported Radius accounting Attributes Values, and when they are sent by the switch.

Name	Start	Stop	Description
User-Name (1)	Yes	Yes	User’s identity.
NAS-IP-Address (4)	Yes	Yes	The switch IP address that is used for the session with the Radius server.
Class (25)	Yes	Yes	Arbitrary value is included in all accounting packets for a specific session.
Called-Station-ID (30)	Yes	Yes	The switch IP address that is used for the management session.
Calling-Station-ID (31)	Yes	Yes	The user IP address.
Acct-Session-ID (44)	Yes	Yes	A unique accounting identifier.
Acct-Authentic (45)	Yes	Yes	Indicates how the supplicant was authenticated.
Acct-Session-Time (46)	No	Yes	Indicates how long the user was logged in.
Acct-Terminate-Cause (49)	No	Yes	Reports why the session was terminated.

EXAMPLE

```
console(config)# aaa accounting login start-stop group radius
```

aaa accounting dot1x To enable accounting of 802.1x sessions, use the **aaa accounting dot1x** Global Configuration mode command. Use the **no** form of this command to disable accounting.

SYNTAX

aaa accounting dot1x *start-stop group radius*

no aaa accounting dot1x *start-stop group radius*

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command enables the recording of 802.1x sessions.

If accounting is activated, the device sends a "start"/"stop" messages to a Radius server when a user logs in / logs out to the network, respectively.

The device uses the configured priorities of the available Radius servers in order to select the Radius server.

If a new replaces an old supplicant (even if the port state remains authorized), the software sends a "stop" message for the old supplicant and a "start" message for the new supplicant.

In multiple sessions mode (dot1x multiple-hosts authentication), the software sends "start"/"stop" messages for each authenticated supplicant.

In multiple hosts mode (dot1x multiple-hosts), the software sends "start"/"stop" messages only for the supplicant that has been authenticated.

The software does not send "start"/"stop" messages if the port is force-authorized.

The software does not send "start"/"stop" messages for hosts that are sending traffic on the guest VLAN or on the unauthenticated VLANs.

The following table describes the supported Radius accounting Attributes Values and when they are sent by the switch.

Name	Start	Stop	Description
User-Name (1)	Yes	Yes	Supplicant's identity.
NAS-IP-Address (4)	Yes	Yes	The switch IP address that is used for the session with the Radius server.
NAS-Port (5)	Yes	Yes	The switch port from where the supplicant has logged in.
Class (25)	Yes	Yes	Arbitrary value is included in all accounting packets for a specific session.
Called-Station-ID (30)	Yes	Yes	The switch MAC address.
Calling-Station-ID (31)	Yes	Yes	The supplicant MAC address.
Acct-Session-ID (44)	Yes	Yes	A unique accounting identifier.
Acct-Authentic (45)	Yes	Yes	Indicates how the supplicant was authenticated.
Acct-Session-Time (46)	No	Yes	Indicated how long the supplicant was logged in.
Acct-Terminate-Cause (49)	No	Yes	Reports why the session was terminated.
Nas-Port-Type (61)	Yes	Yes	Indicates the supplicant physical port type.

EXAMPLE

```
console(config)# aaa accounting dot1x start-stop group radius
```

show accounting The **show accounting** EXEC mode command displays information about the accounting status.

SYNTAX

show accounting

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays information about the accounting status.

```
Console# show accounting

Login: Radius
802.1x: Disabled
```

passwords strength minimum character-classes Use the **passwords strength minimum character-classes** Global Configuration mode command to configure the minimal classes required for passwords in the local database. Use the **no** form to remove the requirement.

SYNTAX

passwords strength minimum character-classes *number*
no passwords strength minimum character-classes

PARAMETERS

number—The minimal length required for passwords.(Range: 0–4)

DEFAULT

0

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The setting is relevant to local users' passwords, line passwords and enable passwords.

The software checks the minimum length requirement when you define a password in an unencrypted format.

The classes are: upper case letters, lower case letters, numbers and special characters.

EXAMPLE

```
Console# passwords strength minimum character-classes
```

passwords strength max-limit repeated- characters

Use the **passwords strength max-limit repeated-characters** Global Configuration mode command to configure the maximum number of characters in the new password that can be repeated consecutively. Use the **no** form to remove the requirement.

SYNTAX

passwords strength max-limit repeated-characters *number*
no passwords strength max-limit repeated-characters

PARAMETERS

number—The maximum number of characters in the new password that can be repeated consecutively. (Range: 1–16)

DEFAULT

1

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The setting is relevant to local users' passwords, line passwords and enable passwords. The software checks the maximum number of characters in the new password that can be repeated consecutively.

EXAMPLE

```
Console# passwords strength max-limit repeated-characters
```

radius-server host Use the **radius-server host** Global Configuration mode command to specify a RADIUS server host. Use the no form of the command to delete the specified RADIUS server host.

SYNTAX

```
radius-server host {ipv4-address | ipv6-address | ipv6z-address |
  hostname} [auth-port auth-port-number] [timeout timeout]
  [retransmit retries] [deadtime deadtime] [key key-string] [source
  {ipv4-address | ipv6-address}] [priority priority] [usage {login |
  802.1x | all}]
```

```
no radius-server host {ipv4-address | ipv6-address | hostname}
```

Parameters

- ◆ **ipv4-address**—Specifies the RADIUS server host IPv4 address.
- ◆ **ipv6-address**—Specifies the RADIUS server host IPv6 address.
- ◆ **ipv6z-address**—Specifies the RADIUS server host IPv6Z address. The IPv6Z address format is: **{ipv6-link-local-address}%{interface-name}**. The subparameters are:
 - **ipv6-link-local-address**—Specifies the IPv6 Link Local address.
 - **interface-name**—Specifies the outgoing interface name. The interface name has the format: **vlan{integer} | ch{integer} | isatap{integer} | {physical-port-name}**.
 - The subparameter **integer** has the format: **{decimal-digit} | {integer}{decimal-digit}**. **decimal-digit** has the range 0–9.
- ◆ **hostname**—Specifies the RADIUS server host name. Translation to IPv4 addresses only is supported. (Length: 1–158 characters. Maximum label length: 63 characters)
- ◆ **auth-port auth-port-number**—Specifies the port number for authentication requests. If the port number is set to 0, the host is not used for authentication. (Range: 0–65535)
- ◆ **timeout timeout**—Specifies the timeout value in seconds. (Range: 1–30)
- ◆ **retransmit retries**—Specifies the retransmit value. (Range: 1–10)

- ◆ **deadtime deadtime**—Specifies the length of time in minutes during which a RADIUS server is skipped over by transaction requests. (Range: 0–2000)
- ◆ **key key-string**—Specifies the authentication and encryption key for all RADIUS communications between the device and the RADIUS server. This key must match the encryption used on the RADIUS daemon. To specify an empty string, enter "". (Length: 0–128 characters)
- ◆ **source {ipv4-address | ipv6-address}**—Specifies the source IPv4 or IPv6 address to use for communication. 0.0.0.0 is interpreted as a request to use the IP address of the outgoing IP interface.
- ◆ **priority priority**—Specifies the order in which servers are used, where 0 has the highest priority. (Range: 0–65535)
- ◆ **usage {login | 802.1x | all}**—Specifies the RADIUS server usage type. The possible values are:
 - **login**—Specifies that the RADIUS server is used for user login parameters authentication.
 - **802.1x**—Specifies that the RADIUS server is used for 802.1x port authentication.
 - **all**—Specifies that the RADIUS server is used for user login parameters authentication and 802.1x port authentication.

DEFAULT CONFIGURATION

No RADIUS host is specified; the global **radius-server** command values are the default values.

The default authentication port number is 1812.

If **timeout** is not specified, the global value is used.

If **retransmit** is not specified, the global value is used.

If **key-string** is not specified, the global value is used.

If the **source** value is not specified, the global value is used.

The default usage type is **all**.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

To specify multiple hosts, multiple **radius-server host** commands can be used.

If no host-specific **timeout**, **retries**, **deadtime** or **key-string** values are specified, the global values apply to each RADIUS server host.

The **source** parameter address type must be the same as that of the **host** parameter.

EXAMPLE

The following example specifies a RADIUS server host with IP address 192.168.10.1, authentication request port number 20, and a 20-second timeout period.

```
Console(config)# radius-server host 192.168.10.1 auth-port 20 timeout 20
```

radius-server key Use the **radius-server key** Global Configuration mode command to set the authentication and encryption key for all RADIUS communications between the device and the RADIUS daemon. Use the **no** form of this command to restore the default configuration.

SYNTAX

radius-server key [*key-string*]
no radius-server key

PARAMETERS

key-string—Specifies the authentication and encryption key for all RADIUS communications between the device and the RADIUS server. This key must match the encryption used on the RADIUS daemon. (Range: 0–128 characters)

DEFAULT CONFIGURATION

The key-string is an empty string.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example defines the authentication and encryption key for all RADIUS communications between the device and the RADIUS daemon.

```
Console(config)# radius-server key enterprise-server
```

radius-server retransmit Use the **radius-server retransmit** Global Configuration mode command to specify the number of times the software searches the list of RADIUS server hosts. Use the no form of this command to restore the default configuration.

SYNTAX

radius-server retransmit *retries*

no radius-server retransmit

PARAMETERS

retries—Specifies the retransmit value. (Range: 1–10)

DEFAULT CONFIGURATION

The software searches the list of RADIUS server hosts 3 times.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures the number of times the software searches all RADIUS server hosts as 5.

```
console(config)# radius-server retransmit 5
```

radius-server source-ip Use the **radius-server source-ip** Global Configuration mode command to specify the source IP address used for communication with RADIUS servers. Use the no form of this command to restore the default configuration.

SYNTAX

radius-server source-ip *{source}*

no radius-server source-ip *{source}*

PARAMETERS

source—Specifies the source IP address.

DEFAULT CONFIGURATION

The source IP address is the IP address of the outgoing IP interface.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

If there is no available IP interface of the configured IP source address, an error message is issued when attempting to communicate with the IP address.

EXAMPLE

The following example configures the source IP address used for communication with all RADIUS servers to 10.1.1.1.

```
console(config)# radius-server source-ip 10.1.1.1
```

**radius-server
source-ipv6**

Use the **radius-server source-ipv6** Global Configuration mode command to specify the source IPv6 address used for communication with RADIUS servers. Use the no form of this command to restore the default configuration.

SYNTAX

radius-server source-ipv6 {source}

no radius-server source-ipv6 {source}

PARAMETERS

source—Specifies the source IPv6 address.

DEFAULT CONFIGURATION

The source IP address is the IP address of the outgoing IP interface.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

If there is no available IP interface of the configured IP source address, an error message is issued when attempting to communicate with the IP address.

EXAMPLE

The following example configures the source IP address used for communication with all RADIUS servers to 3ffe:1900:4545:3:200:f8ff:fe21:67cf.

```
console(config)# radius-server source-ipv6  
3ffe:1900:4545:3:200:f8ff:fe21:67cf
```

radius-server timeout Use the **radius-server timeout** Global Configuration mode command to set the time interval during which the device waits for a server host to reply. Use the **no** form of this command to restore the default configuration.

SYNTAX

radius-server timeout *timeout*

no radius-server timeout

PARAMETERS

timeout—Specifies the timeout value in seconds. (Range: 1–30)

DEFAULT CONFIGURATION

The default timeout value is 3 seconds.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example sets the timeout interval on all RADIUS servers to 5 seconds.

```
Console(config)# radius-server timeout 5
```

radius-server deadtime Use the **radius-server deadtime** Global Configuration mode command to configure the time interval during which unavailable RADIUS servers are skipped over by transaction requests. This improves RADIUS response time when servers are unavailable. Use the **no** form of this command to restore the default configuration.

SYNTAX

radius-server deadtime *deadtime*

no radius-server deadtime

PARAMETERS

deadtime—Specifies the time interval in minutes during which a RADIUS server is skipped over by transaction requests. (Range: 0–2000)

DEFAULT CONFIGURATION

The default deadtime interval is 0.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example sets all RADIUS server deadtimes to 10 minutes.

```
Console(config)# radius-server deadtime 10
```

show radius-servers Use the **show radius-servers** Privileged EXEC mode command to display the RADIUS server settings.

SYNTAX

show radius-servers

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays RADIUS server settings.

```
Console# show radius-servers
```

IP address	Port Auth	Port Acct	Time Out	Retrans mit	Dead time	Source IP	Priority	Usage
172.16.1.1	1812	1813	Global	Global	Global	Global	1	All
172.16.1.2	1812	1813	11	8	Global	Global	2	All

```
Global values
```

```
-----
Timeout: 3
Retransmit: 3
Deadtime: 0
Source IP: 172.16.8.1
```


tacacs-server host Use the **tacacs-server host** Global Configuration mode command to specify a TACACS+ host. Use the **no** form of this command to delete the specified TACACS+ host.

SYNTAX

```
tacacs-server host {ip-address | hostname} [single-connection]
[port port-number] [timeout timeout] [key key-string] [source
{source}] [priority priority]
```

```
no tacacs-server host {ip-address | hostname}
```

PARAMETERS

- ◆ **ip-address**—Specifies the TACACS+ server host IP address.
- ◆ **hostname**—Specifies the TACACS+ server host name. (Length: 1?158 characters. Maximum label length: 63 characters)
- ◆ **single-connection**—Specifies that a single open connection is maintained between the device and the daemon, instead of the device opening and closing a TCP connection to the daemon each time it communicates.
- ◆ **port port-number**—Specifies the server port number. If the port number is 0, the host is not used for authentication. (Range: 0–65535)
- ◆ **timeout timeout**—Specifies the timeout value in seconds. (Range: 1–30)
- ◆ **key key-string**—Specifies the authentication and encryption key for all TACACS+ communications between the device and the TACACS+ server. This key must match the encryption used on the TACACS+ daemon. To specify an empty string, enter "". (Length: 0?128 characters)
- ◆ **source {source}**—Specifies the source IP to use for the communication. 0.0.0.0 indicates a request to use the outgoing IP interface IP address.
- ◆ **priority priority**—Specifies the order in which the TACACS+ servers are used, where 0 is the highest priority. (Range: 0–65535)

DEFAULT CONFIGURATION

No TACACS+ host is specified.

The default **port-number** is 49.

If **timeout** is not specified, the global value is used.

If **key-string** is not specified, the global value is used.

If **source** is not specified, the global value is used.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Multiple **tacacs-server host** commands can be used to specify multiple hosts.

If no host-specific timeout, key, or source values are specified, the global values apply to each host. Example

The following example specifies a TACACS+ host.

```
Console(config)# tacacs-server host 172.16.1.1
```

tacacs-server key Use the **tacacs-server key** Global Configuration mode command to set the authentication encryption key used for all TACACS+ communications between the device and the TACACS+ daemon. Use the **no** form of this command to disable the key.

SYNTAX

tacacs-server key *key-string*

no tacacs-server key

PARAMETERS

key-string—Specifies the authentication and encryption key for all TACACS+ communications between the device and the TACACS+ server. This key must match the encryption used on the TACACS+ daemon. (Length: 0–128 characters)

DEFAULT CONFIGURATION

The default key is an empty string.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example sets Enterprise as the authentication encryption key for all TACACS+ servers.

```
Console(config)# tacacs-server key enterprise
```

**tacacs-server
timeout**

Use the **tacacs-server timeout** Global Configuration mode command to set the interval during which the device waits for a TACACS+ server to reply. Use the **no** form of this command to restore the default configuration.

SYNTAX

tacacs-server timeout *timeout*

no tacacs-server timeout

PARAMETERS

timeout—Specifies the timeout value in seconds. (Range: 1–30)

DEFAULT CONFIGURATION

The default timeout value is 5 seconds.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example sets the timeout value to 30 for all TACACS+ servers.

```
Console(config)# tacacs-server timeout 30
```

**tacacs-server
source-ip**

Use the **tacacs-server source-ip** Global Configuration mode command to configure the source IP address to be used for communication with TACACS+ servers. Use the **no** form of this command to restore the default configuration.

SYNTAX

tacacs-server source-ip *{source}*

no tacacs-server source-ip *{source}*

PARAMETERS

source—Specifies the source IP address. (Range: Valid IP address)

DEFAULT CONFIGURATION

The default source IP address is the outgoing IP interface address.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

If the configured IP source address has no available IP interface, an error message is issued when attempting to communicate with the IP address.

EXAMPLE

The following example specifies the source IP address for all TACACS+ servers.

```
Console(config)# tacacs-server source-ip 172.16.8.1
```

show tacacs Use the **show tacacs** Privileged EXEC mode command to display configuration and statistical information for a TACACS+ server.

SYNTAX

show tacacs [*ip-address*]

PARAMETERS

ip-address—Specifies the TACACS+ server name or IP address.

DEFAULT CONFIGURATION

If **ip-address** is not specified, information for all TACACS+ servers is displayed.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays configuration and statistical information for all TACACS+ servers.

```
Console# show tacacs
```

IP address	Status	Port	Single Connection	Time Out	Source IP	Priority
-----	-----	---	-----	-----	-----	-----
172.16.1.1	Connected	49	No	Global	Global	1

Global values

TimeOut: 3

Source IP: 172.16.8.1

logging on Use the **logging on** Global Configuration mode command to control error message logging. This command sends debug or error messages to a logging process, which logs messages asynchronously to designated locations for the process that generated the messages. Use the **no** form of this command to disable the logging process.

SYNTAX

logging on

no logging on

DEFAULT CONFIGURATION

Message logging is enabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The logging process controls the logging messages distribution at various destinations, such as the logging buffer, logging file or syslog server. Logging on and off at these destinations can be individually configured using the **logging buffered**, **logging file**, and **logging** Global Configuration mode commands. However, if the **logging on** command is disabled, no messages are sent to these destinations. Only the console receives messages.

EXAMPLE

The following example enables logging error messages.

```
Console(config)# logging on
```

Logging host Use the **logging host** global configuration command to log messages to a syslog server. Use the **no** form of this command to delete the syslog server with the specified address from the list of syslogs.

SYNTAX

logging host {*ipv4-address* | *ipv6-address* | *hostname*} [*port port*]
[*severity level*] [*facility facility*] [*description text*]

no logging host {*ipv4-address* | *ipv6-address* | *hostname*}

PARAMETERS

- ◆ **ipv4-address**—IPv4 address of the host to be used as a syslog server.
- ◆ **ipv6-address**—Pv6 address of the host to be used as a syslog server. When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. Refer to the User Guidelines for the interface name syntax.
- ◆ **hostname**—Hostname of the host to be used as a syslog server. Only translation to IPv4 addresses is supported. (Range: 1–158 characters. Maximum label size: 63)
- ◆ **port**—Port number for syslog messages. If unspecified, the port number defaults to 514. (Range: 1–65535)
- ◆ **level**—Limits the logging of messages to the syslog servers to a specified level: emergencies, alerts, critical, errors, warnings, notifications, informational, debugging.
- ◆ **facility**—The facility that is indicated in the message. It can be one of the following values: local0, local1 , local2 , local3 , local4 , local5 , local 6, local7. If unspecified, the port number defaults to local7.
- ◆ **text**—Description of the syslog server. (Range: Up to 64 characters)

DEFAULT

No messages are logged to a syslog server host.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

You can use multiple syslog servers.

The format of an IPv6Z address is: *<ipv6-link-local-address>%<interface-name>*

interface-name = *vlan<integer> | ch<integer> | isatap<integer> | <physical-port-name> | 0*

integer = *<decimal-number> | <integer><decimal-number>*

decimal-number = *0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9*

physical-port-name = Designated port number, for example 0/16.

If the egress interface is not specified, the default interface is selected. Specifying interface zone=0 is equal to not defining an egress interface.

EXAMPLES

```
console(config)# logging host 1.1.1.121
```

```
console(config)# logging host 3000::100
```

logging console Use the **logging console** Global Configuration mode command to limit messages logged to the console to messages with a specific severity level. Use the **no** form of this command to disable logging limiting to the console.

SYNTAX

logging console *level*

no logging console

PARAMETERS

level—Specifies the severity level of logged messages displayed on the console. The possible values are: emergencies, alerts, critical, errors, warnings, notifications, informational and debugging.

DEFAULT CONFIGURATION

The default severity level is informational.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example limits logging messages displayed on the console to messages with severity level errors.

```
Console(config)# logging console errors
```

logging buffered Use the **logging buffered** Global Configuration mode command to limit the syslog message display from an internal buffer to messages with a specific severity level, and to define the buffer size. Use the **no** form of this command to cancel using the buffer and returning the buffer size to default

SYNTAX

logging buffered [*buffer-size*] [*severity-level*]

no logging buffered

PARAMETERS

buffer-size—Specifies the maximum number of messages stored in the history table. (Range: 20–400)

severity-level—Specifies the severity level of messages logged in the buffer. The possible values are: emergencies, alerts, critical, errors, warnings, notifications, informational and debugging.

DEFAULT CONFIGURATION

The default severity level is informational.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

All the syslog messages are logged to the internal buffer. This command limits the messages displayed to the user.

EXAMPLE

The following example limits the syslog message display from an internal buffer to messages with severity level **debugging**.

```
Console(config)# logging buffered debugging
```

clear logging Use the **clear logging** Privileged EXEC mode command to clear messages from the internal logging buffer.

SYNTAX

clear logging

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example clears messages from the internal logging buffer.

```
Console# clear logging
Clear logging buffer [confirm]
```

logging file Use the **logging file** Global Configuration mode command to limit syslog messages sent to the logging file to messages with a specific severity level. Use the **no** form of this command to cancel using the buffer.

SYNTAX

logging file *level*

no logging file

PARAMETERS

level—Specifies the severity level of syslog messages sent to the logging file. The possible values are: emergencies, alerts, critical, errors, warnings, notifications, informational and debugging.

DEFAULT CONFIGURATION

The default severity level is errors.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example limits syslog messages sent to the logging file to messages with severity level alerts.

```
Console(config)# logging file alerts
```

clear logging file Use the **clear logging file** Privileged EXEC mode command to clear messages from the logging file.

SYNTAX

clear logging file

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example clears messages from the logging file.

```
Console# clear logging file
Clear Logging File [y/n]
```

aaa logging Use the **aaa logging** Global Configuration mode command to enable logging AAA login events. Use the **no** form of this command to disable logging AAA login events.

SYNTAX

aaa logging {login}
no aaa logging {login}

PARAMETERS

login—Enables logging messages related to successful AAA login events, unsuccessful AAA login events and other AAA login-related events.

DEFAULT CONFIGURATION

Logging of AAA login events is enabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command enables logging messages related to successful login events, unsuccessful login events and other login-related events. Other types of AAA events are not subject to this command.

EXAMPLE

The following example enables logging messages related to AAA login events.

```
Console(config)# aaa logging login
```

file-system logging Use the **file-system logging** Global Configuration mode command to enable the logging of file system events. Use the **no** form of this command to disable logging file system events.

SYNTAX

file-system logging {*copy* | *delete-rename*}

no file-system logging {*copy* | *delete-rename*}

PARAMETERS

- ◆ **copy**—Specifies logging messages related to file copy operations.
- ◆ **delete-rename**—Specifies logging messages related to file deletion and renaming operations.

DEFAULT CONFIGURATION

Logging file system events is enabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables logging messages related to file copy operations.

```
Console(config)# file-system logging copy
```

management logging Use the **management logging** Global Configuration mode command to enable logging Management Access List (ACL) deny events. Use the **no** form of this command to disable logging management access list events.

SYNTAX

management logging {*deny*}

no management logging {deny}**PARAMETERS**

deny—Enables logging messages related to management ACL deny actions.

DEFAULT CONFIGURATION

Logging management ACL deny events is enabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Other management ACL events are not subject to this command.

EXAMPLE

The following example enables logging messages related to management ACL deny actions.

```
Console(config)# management logging deny
```

show logging Use the **show logging** Privileged EXEC mode command to display the logging status and the syslog messages stored in the internal buffer.

SYNTAX**show logging****COMMAND MODE**

Privileged EXEC mode

EXAMPLE

The following example displays the logging status and the syslog messages stored in the internal buffer.

```
console# show logging
Logging is enabled.
Console Logging: Level info. Console Messages: 0 Dropped.
Buffer Logging: Level info. Buffer Messages: 61 Logged, 61 Displayed, 200 Max.
File Logging: Level error. File Messages: 898 Logged, 64 Dropped.
4 messages were not logged

Application filtering control
Application      Event              Status
-----
AAA              Login              Enabled
File system      Copy               Enabled
File system      Delete-Rename      Enabled
Management ACL   Deny              Enabled

Aggregation: Disabled.
```

```

Aggregation aging time: 300 Sec

01-Jan-2010 05:29:46 :%INIT-I-Startup: Warm Startup
01-Jan-2010 05:29:02 :%LINK-I-Up: Vlan 1
01-Jan-2010 05:29:02 :%LINK-I-Up: te48
01-Jan-2010 05:29:02 :%LINK-I-Up: te47
01-Jan-2010 05:29:00 :%LINK-W-Down: te48

```

show logging file Use the **show logging file** Privileged EXEC mode command to display the logging status and the syslog messages stored in the logging file.

SYNTAX

show logging file

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the logging status and the syslog messages stored in the logging file.

```

Logging is enabled.
Console Logging: Level info. Console Messages: 0 Dropped.
Buffer Logging: Level info. Buffer Messages: 61 Logged, 61 Displayed, 200 Max.
File Logging: Level error. File Messages: 898 Logged, 64 Dropped.
4 messages were not logged

Application filtering control
Application          Event                      Status
-----
AAA                  Login                      Enabled
File system          Copy                      Enabled
File system          Delete-Rename             Enabled
Management ACL       Deny                     Enabled

Aggregation: Disabled.
Aggregation aging time: 300 Sec

01-Jan-2010 05:57:00 :%SSHD-E-ERROR: SSH error: key_read: type mismatch:
encoding error

01-Jan-2010 05:56:36 :%SSHD-E-ERROR: SSH error: key_read: type mismatch:
encoding error

01-Jan-2010 05:55:37 :%SSHD-E-ERROR: SSH error: key_read: type mismatch:
encoding error

01-Jan-2010 05:55:03 :%SSHD-E-ERROR: SSH error: key_read: key_from_blob
bgEgGnt9
z6NHgZwKI5xKqF7cBtdl1xmFgSEWuDhho5UedydAjVkKS5XR2... failed

01-Jan-2010 05:55:03 :%SSHD-E-ERROR: SSH error: key_from_blob: invalid key
type.

```

```
01-Jan-2010 05:56:34 :%SSHD-E-ERROR: SSH error: bad sigbloblen 58 !=
SIGBLOB_LEN
console#
```

show syslog-servers Use the **show syslog-servers** Privileged EXEC mode command to display the syslog server settings.

SYNTAX

show syslog-servers

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the syslog server settings.

```
console# show syslog-servers

Device Configuration
-----

IP address      Port    Severity  Facility Description
-----
1.1.1.121       514     info      local7
3000::100       514     info      local7

console#
```

REMOTE NETWORK MONITORING (RMON) COMMANDS

iPECS ES-5048XG

show rmon statistics Use the **show rmon statistics** EXEC mode command to display RMON Ethernet statistics.

SYNTAX

show rmon statistics *{interface-id}*

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays RMON Ethernet statistics for tengigabitethernet port 0/1.

```
console# show rmon statistics tel
Port tel
Dropped: 0
Octets: 0
Broadcast: 0
CRC Align Errors: 0
Undersize Pkts: 0
Fragments: 0
64 Octets: 0
128 to 255 Octets: 1
512 to 1023 Octets: 0
Packets: 0
Multicast: 0
Collisions: 0
Oversize Pkts: 0
Jabbers: 0
65 to 127 Octets: 1
256 to 511 Octets: 1
1024 to max Octets: 0
```

The following table describes the significant fields displayed.

Field	Description
Dropped	The total number of events in which packets were dropped by the probe due to lack of resources. Note that this number is not necessarily the number of packets dropped. It is the number of times this condition was detected.
Octets	The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets).
Packets	The total number of packets (including bad packets, broadcast packets, and multicast packets) received.
Broadcast	The total number of good packets received and directed to the broadcast address. This does not include multicast packets.

Field	Description
Multicast	The total number of good packets received and directed to a multicast address. This number does not include packets directed to the broadcast address.
CRC Align Errors	The total number of packets received with a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but with either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Collisions	The best estimate of the total number of collisions on this Ethernet segment.
Undersize Pkts	The total number of packets received, less than 64 octets long (excluding framing bits, but including FCS octets) and otherwise well formed.
Oversize Pkts	The total number of packets received, longer than 1518 octets (excluding framing bits, but including FCS octets) and otherwise well formed.
Fragments	The total number of packets received, less than 64 octets in length (excluding framing bits but including FCS octets) and either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Jabbers	The total number of packets received, longer than 1518 octets (excluding framing bits, but including FCS octets), and either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
64 Octets	The total number of packets (including bad packets) received that are 64 octets in length (excluding framing bits but including FCS octets).
65 to 127 Octets	The total number of packets (including bad packets) received that are between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).
128 to 255 Octets	The total number of packets (including bad packets) received that are between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).
256 to 511 Octets	The total number of packets (including bad packets) received that are between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).
512 to 1023 Octets	The total number of packets (including bad packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).
1024 to max	The total number of packets (including bad packets) received that were between 1024 octets and the maximum frame size in length inclusive (excluding framing bits but including FCS octets).

rmon collection stats Use the **rmon collection stats** Interface Configuration mode command to enable Remote Monitoring (RMON) MIB history group of statistics on an interface. Use the **no** form of this command to remove a specified RMON history group of statistics.

SYNTAX

rmon collection stats *index* [*owner ownername*] [*buckets bucket-number*] [*interval seconds*]

no rmon collection stats *index*

PARAMETERS

- ◆ **index**—The requested group of statistics index.(Range: 1–65535)
- ◆ **owner ownername**—Records the name of the owner of the RMON group of statistics. If unspecified, the name is an empty string. (Range: Valid string)
- ◆ **buckets bucket-number**—A value associated with the number of buckets specified for the RMON collection history group of statistics. If unspecified, defaults to 50.(Range: 1–50)
- ◆ **interval seconds**—The number of seconds in each polling cycle. If unspecified, defaults to 1800 (Range: 1–3600).

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode. Cannot be configured for a range of interfaces (range context).

show rmon collection stats Use the **show rmon collection stats** EXEC mode command to display the requested RMON history group statistics.

SYNTAX

show rmon collection stats [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays all RMON history group statistics.

```

Console# show rmon collection stats

```

Index	Interface	Interval	Requested Samples	Granted Samples	Owner
-----	-----	-----	-----	-----	-----
1	te1	30	50	50	CLI
2	te1	1800	50	50	Manager

The following table describes the significant fields shown in the display.

Field	Description
Index	An index that uniquely identifies the entry.
Interface	The sampled Ethernet interface.

Field	Description
Interval	The interval in seconds between samples.
Requested Samples	The requested number of samples to be saved.
Granted Samples	The granted number of samples to be saved.
Owner	The entity that configured this entry.

show rmon history Use the **show rmon history** EXEC mode command to display RMON Ethernet history statistics.

SYNTAX

show rmon history *index {throughput | errors | other} [period seconds]*

PARAMETERS

- ◆ **index**—Specifies the set of samples to display. (Range: 1–65535)
- ◆ **throughput**—Displays throughput counters.
- ◆ **errors**—Displays error counters.
- ◆ **other**—Displays drop and collision counters.
- ◆ **period seconds**—Specifies the period of time in seconds to display. (Range: 1–2147483647)

COMMAND MODE

EXEC mode

EXAMPLE

The following examples display RMON Ethernet history statistics for index 1.

```

Console# show rmon history 1 throughput

Sample Set: 1                      Owner: CLI
Interface: tel                     Interval: 1800
Requested samples: 50              Granted samples: 50

Maximum table size: 500

Time          Octets      Packets    Broadcast  Multicast  Util
-----
Jan 18 2005   303595962   357568     3289       7287       19%
21:57:00      287696304   275686     2789       5878       20%
Jan 18 2005
21:57:30

```

```
Console# show rmon history 1 errors
```

```
Sample Set: 1          Owner: Me
Interface: tel         Interval: 1800
Requested samples: 50   Granted samples: 50
```

```
Maximum table size: 500 (800 after reset)
```

Time	CRC Align	Undersize	Oversize	Fragments	Jabbers
-----	-----	-----	-----	-----	-----
Jan 18 2005	1	1	0	49	0
21:57:00	1	1	0	27	0
Jan 18 2005					
21:57:30					

```
Console# show rmon history 1 other
```

```
Sample Set: 1          Owner: Me
Interface: tel         Interval: 1800
Requested samples: 50   Granted samples: 50
```

```
Maximum table size: 500
```

Time	Dropped	Collisions
-----	-----	-----
Jan 18 2005 21:57:00	3	0
Jan 18 2005 21:57:30	3	0

The following table describes significant fields shown in the display:

Field	Description
Time	Date and Time the entry is recorded.
Octets	The total number of octets of data (including those in bad packets and excluding framing bits but including FCS octets) received on the network.
Packets	The number of packets (including bad packets) received during this sampling interval.
Broadcast	The number of good packets received during this sampling interval that were directed to the broadcast address.
Multicast	The number of good packets received during this sampling interval that were directed to a multicast address. This number does not include packets addressed to the broadcast address.
Utilization	The best estimate of the mean physical layer network utilization on this interface during this sampling interval, in hundredths of a percent.
CRC Align	The number of packets received during this sampling interval that had a length (excluding framing bits but including FCS octets) between 64 and 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Undersize	The number of packets received during this sampling interval that were less than 64 octets long (excluding framing bits but including FCS octets) and were otherwise well formed.

Field	Description
Oversize	The number of packets received during this sampling interval that were longer than 1518 octets (excluding framing bits but including FCS octets) but were otherwise well formed.
Fragments	The total number of packets received during this sampling interval that were less than 64 octets in length (excluding framing bits but including FCS octets) and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error), or a bad FCS with a non-integral number of octets (Alignment Error). It is normal for etherHistoryFragments to increment because it counts both runts (which are normal occurrences due to collisions) and noise hits.
Jabbers	The number of packets received during this sampling interval that were longer than 1518 octets (excluding framing bits but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Dropped	The total number of events in which packets were dropped by the probe due to lack of resources during this sampling interval. This number is not necessarily the number of packets dropped, it is the number of times this condition has been detected.
Collisions	The best estimate of the total number of collisions on this Ethernet segment during this sampling interval.

rmon alarm Use the **rmon alarm** Global Configuration mode command to configure alarm conditions. Use the **no** form of this command to remove an alarm.

SYNTAX

```
rmon alarm index mib-object-id interval rthreshold fthreshold revent
fevent [type {absolute | delta}]
[startup {rising | rising-falling | falling}] [owner name]
no rmon alarm index
```

PARAMETERS

- ◆ **index**—Specifies the alarm index. (Range: 1–65535)
- ◆ **mib-object-id**—Specifies the object identifier of the variable to be sampled. (Valid OID)
- ◆ **interval**—Specifies the interval in seconds during which the data is sampled and compared with rising and falling thresholds. (Range: 1–4294967295)
- ◆ **rthreshold**—Specifies the rising threshold value. (Range: 0–4294967295)
- ◆ **fthreshold**—Specifies the falling threshold value. (Range: 0–4294967295)
- ◆ **revent**—Specifies the index of the event triggered when a rising threshold is crossed. (Range: 0–65535)
- ◆ **fevent**—Specifies the index of the event triggered when a falling threshold is crossed. (Range: 0–65535)

- ◆ **type {absolute | delta}**—Specifies the method used for sampling the selected variable and calculating the value to be compared against the thresholds. The possible values are:
 - **absolute**—Specifies that the selected variable value is compared directly with the thresholds at the end of the sampling interval.
 - **delta**—Specifies that the selected variable value of the last sample is subtracted from the current value, and the difference is compared with the thresholds.
- ◆ **startup {rising | rising-falling | falling}**—Specifies the alarm that may be sent when this entry becomes valid. The possible values are:
 - **rising**—Specifies that if the first sample (after this entry becomes valid) is greater than or equal to **rthreshold**, a single rising alarm is generated.
 - **rising-falling**—Specifies that if the first sample (after this entry becomes valid) is greater than or equal to **rthreshold**, a single rising alarm is generated. If the first sample (after this entry becomes valid) is less than or equal to **fthreshold**, a single falling alarm is generated.
 - **fallin** —Specifies that if the first sample (after this entry becomes valid) is less than or equal to **fthreshold**, a single falling alarm is generated.
- ◆ **owner name**—Specifies the name of the person who configured this alarm. (Valid string)

DEFAULT CONFIGURATION

The default method type is **absolute**.

The default startup direction is **rising-falling**.

If the owner **name** is not specified, it defaults to an empty string.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures an alarm with index 1000, MIB object ID, sampling interval 360000 seconds (100 hours), rising threshold value 1000000, falling threshold value 1000000, rising threshold event index 10, falling threshold event index 10, absolute method type and rising-falling alarm.

```
console(config)# rmon alarm 1000 1.3.6.1.2.1.2.2.1.10.1 360000 1000000
1000000 10 20
```

show rmon alarm-table Use the **show rmon alarm-table** EXEC mode command to display a summary of the alarms table.

SYNTAX

show rmon alarm-table

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the alarms table.

```
Console# show rmon alarm-table
```

Index	OID	Owner
----	-----	-----
1	1.3.6.1.2.1.2.2.1.10.1	CLI
2	1.3.6.1.2.1.2.2.1.10.1	Manager
3	1.3.6.1.2.1.2.2.1.10.9	CLI

The following table describes the significant fields shown in the display:

Field	Description
Index	An index that uniquely identifies the entry.
OID	Monitored variable OID.
Owner	The entity that configured this entry.

show rmon alarm Use the **show rmon alarm** EXEC mode command to display alarm configuration.

SYNTAX

show rmon alarm *number*

PARAMETERS

number—Specifies the alarm index. (Range: 1–65535)

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays RMON 1 alarms.

```

Console# show rmon alarm 1

Alarm 1
-----
OID: 1.3.6.1.2.1.2.2.1.10.1
Last sample Value: 878128
Interval: 30
Sample Type: delta
Startup Alarm: rising
Rising Threshold: 8700000
Falling Threshold: 78
Rising Event: 1
Falling Event: 1
Owner: CLI

```

The following table describes the significant fields shown in the display:

Field	Description
Alarm	Alarm index.
OID	Monitored variable OID.
Last Sample Value	The value of the statistic during the last sampling period. For example, if the sample type is delta , this value is the difference between the samples at the beginning and end of the period. If the sample type is absolute , this value is the sampled value at the end of the period.
Interval	The interval in seconds over which the data is sampled and compared with the rising and falling thresholds.
Sample Type	The method of sampling the variable and calculating the value compared against the thresholds. If the value is absolute , the variable value is compared directly with the thresholds at the end of the sampling interval. If the value is delta , the variable value at the last sample is subtracted from the current value, and the difference is compared with the thresholds.
Startup Alarm	The alarm that may be sent when this entry is first set. If the first sample is greater than or equal to the rising threshold, and startup alarm is equal to rising or rising-falling, then a single rising alarm is generated. If the first sample is less than or equal to the falling threshold, and startup alarm is equal falling or rising-falling, then a single falling alarm is generated.
Rising Threshold	The sampled statistic rising threshold. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval is less than this threshold, a single event is generated.
Falling Threshold	The sampled statistic falling threshold. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval is greater than this threshold, a single event is generated.
Rising Event	The event index used when a rising threshold is crossed.
Falling Event	The event index used when a falling threshold is crossed.
Owner	The entity that configured this entry.

rmon event Use the **rmon event** Global Configuration mode command to configure an event. Use the **no** form of this command to remove an event.

SYNTAX

```
rmon event index {none | log | trap | log-trap} [community text]
[description text] [owner name]
no rmon event index
```

PARAMETERS

- ◆ **index**—Specifies the event index. (Range: 1–65535)
- ◆ **none**—Specifies that no notification is generated by the device for this event.
- ◆ **log**—Specifies that a notification entry is generated in the log table by the device for this event.
- ◆ **trap**—Specifies that an SNMP trap is sent to one or more management stations by the device for this event.
- ◆ **log-trap**—Specifies that an entry is generated in the log table and an SNMP trap is sent to one or more management stations by the device for this event.
- ◆ **community text**—Specifies the SNMP community to which an SNMP trap is sent. (Octet string; length: 0–127 characters)
- ◆ **description text**—Specifies a comment describing this event. (Length: 0–127 characters)
- ◆ **owner name**—Specifies the name of the person who configured this event. (Valid string)

DEFAULT CONFIGURATION

If the owner name is not specified, it defaults to an empty string.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures an event identified as index 10, for which the device generates a notification in the log table.

```
Console(config)# rmon event 10 log
```


show rmon events Use the **show rmon events** EXEC mode command to display the RMON event table.

SYNTAX

show rmon events

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the RMON event table.

```

Console# show rmon events

```

Index	Description	Type	Community	Owner	Last time sent
-----	-----	-----	-----	-----	-----
1	Errors	Log		CLI	Jan18 2006 23:58:17
2	High Broadcast	Log-Trap	router	Manager	Jan18 2006 23:59:48

The following table describes significant fields shown in the display:

Field	Description
Index	A unique index that identifies this event.
Description	A comment describing this event.
Type	The type of notification that the device generates about this event. Can have the following values: none , log , trap , log-trap . In the case of log, an entry is made in the log table for each event. In the case of trap, an SNMP trap is sent to one or more management stations.
Community	If an SNMP trap is to be sent, it is sent to the SNMP community specified by this octet string.
Owner	The entity that configured this event.
Last time sent	The time this entry last generated an event. If this entry has not generated any events, this value is zero.

show rmon log Use the **show rmon log** EXEC mode command to display the RMON log table.

SYNTAX

show rmon log [*event*]

PARAMETERS

event—Specifies the event index. (Range: 0–65535)

COMMAND MODE

EXEC mode

EXAMPLE

The following examples display the RMON log table.

```

Console# show rmon log
Maximum table size: 500 (800 after reset)

Event          Description          Time
-----
1              MIB Var.:              Jan 18 2006 23:48:19
                1.3.6.1.2.1.2.2.1.10.53
                , Delta, Rising, Actual
                Val: 800, Thres.Set:
                100, Interval (sec):1

```

rmon table-size Use the **rmon table-size** Global Configuration mode command to configure the maximum size of RMON tables. Use the no form of this command to return to the default configuration.

SYNTAX

rmon table-size {*history entries* | *log entries*}

no rmon table-size {*history* | *log*}

PARAMETERS

- ◆ **history entries**—Specifies the maximum number of history table entries. (Range: 20–270)
- ◆ **log entries**—Specifies the maximum number of log table entries. (Range: 20–100)

DEFAULT CONFIGURATION

The default history table size is 270 entries.

The default log table size is 200 entries.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The configured table size takes effect after the device is rebooted.

EXAMPLE

The following example configures the maximum size of RMON history tables to 100 entries.

```
Console(config)# rmon table-size history 100
```

aaa authentication dot1x Use the **aaa authentication dot1x** Global Configuration mode command to specify one or more authentication, authorization, and accounting (AAA) methods for use on interfaces running IEEE 802.1x. Use the **no** form of this command to restore the default configuration.

SYNTAX

aaa authentication dot1x default *method* [*method2* ...]

no aaa authentication dot1x default

PARAMETERS

method [**method2** ...]—Specify at least one method from the following list:

Keyword	Description
radius	Uses the list of all RADIUS servers for authentication
none	Uses no authentication

DEFAULT CONFIGURATION

The default method is Radius.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Additional methods of authentication are used only if the previous method returns an error and not if the request for authentication is denied. Specify **none** as the final method in the command line to ensure that authentication succeeds even if all methods return an error.

EXAMPLE

The following example uses the **aaa authentication dot1x default** command with no authentication.

```
Console(config)# aaa authentication dot1x default none
```

dot1x system-auth-control Use the **dot1x system-auth-control** Global Configuration mode command to enable 802.1x globally. Use the **no** form of this command to restore the default configuration.

SYNTAX

dot1x system-auth-control
no dot1x system-auth-control

DEFAULT CONFIGURATION

All the ports are in FORCE_AUTHORIZED state.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables 802.1x globally.

```
Console(config)# dot1x system-auth-control
```

dot1x port-control Use the **dot1x port-control** Interface Configuration (Ethernet) mode command to enable manual control of the port authorization state. Use the **no** form of this command to restore the default configuration.

SYNTAX

dot1x port-control {*auto* | *force-authorized* | *force-unauthorized*}[*time-range time-range-name*]
no dot1x port-control

PARAMETERS

- ◆ **auto**—Enables 802.1x authentication on the interface and causes the port to transition to the authorized or unauthorized state based on the 802.1x authentication exchange between the device and the client.
- ◆ **force-authorized**—Disables 802.1x authentication on the interface and causes the port to transition to the authorized state without any authentication exchange required. The port resends and receives normal traffic without 802.1x-based client authentication.
- ◆ **force-unauthorized**—Denies all access through this interface by forcing the port to transition to the unauthorized state and ignoring all attempts by the client to authenticate. The device cannot provide authentication services to the client through the interface.
- ◆ **time-range-name**—Specifies a time range. When the Time Range is not in effect, the port state is Unauthorized. (Range: 1–32 characters)

DEFAULT CONFIGURATION

The port is in the force-authorized state.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

It is recommended to disable spanning tree or to enable spanning-tree PortFast mode on 802.1x edge ports (ports in **auto** state that are connected to end stations), in order to proceed to the forwarding state immediately after successful authentication.

EXAMPLE

The following example enables 802.1x authentication on tengigabitethernet port 0/15.

```
Console(config)# interface tengigabitethernet 0/15
Console(config-if)# dot1x port-control auto
```

**dot1x
reauthentication**

Use the **dot1x reauthentication** Interface Configuration mode command to enable periodic re-authentication of the client. Use the **no** form of this command to return to the default setting.

SYNTAX

dot1x reauthentication

no dot1x reauthentication

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Periodic re-authentication is disabled.

COMMAND MODE

Interface configuration (Ethernet)

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# dot1x reauthentication
```

dot1x timeout reauth-period Use the **dot1x timeout reauth-period** Interface Configuration mode command to set the number of seconds between re-authentication attempts. Use the **no** form of this command to return to the default setting.

SYNTAX

dot1x timeout reauth-period *seconds*

no dot1x timeout reauth-period

PARAMETERS

seconds—Number of seconds between re-authentication attempts. (Range: 30–4294967295)

DEFAULT

3600

COMMAND MODE

Interface Configuration (Ethernet) mode

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# dot1x timeout reauth-period 5000
```

dot1x re-authenticate The **dot1x re-authenticate** Privileged EXEC mode command manually initiates re-authentication of all 802.1x-enabled ports or the specified 802.1x-enabled port.

SYNTAX

dot1x re-authenticate [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following command manually initiates re-authentication of 802.1x-enabled tengigabitethernet port 0/15.

```
Console# dot1x re-authenticate tengigabitethernet 0/15
```

dot1x timeout quiet-period Use the **dot1x timeout quiet-period** Interface Configuration (Ethernet) mode command to set the time interval that the device remains in a quiet state following a failed authentication exchange (for example, the client provided an invalid password). Use the **no** form of this command to restore the default configuration.

SYNTAX

dot1x timeout quiet-period *seconds*
no dot1x timeout quiet-period

PARAMETERS

seconds—Specifies the time interval in seconds that the device remains in a quiet state following a failed authentication exchange with the client. (Range: 0–65535 seconds)

DEFAULT CONFIGURATION

The default quiet period is 60 seconds.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

During the quiet period, the device does not accept or initiate authentication requests.

The default value of this command should only be changed to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

To provide faster response time to the user, a smaller number than the default value should be entered.

EXAMPLE

The following example sets the time interval that the device remains in the quiet state following a failed authentication exchange to 3600 seconds.

```
Console(config)# interface tengigabitethernet 0/15
Console(config-if)# dot1x timeout quiet-period 3600
```


dot1x timeout tx-period Use the **dot1x timeout tx-period** Interface Configuration (Ethernet) mode command to set the time interval during which the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the client before resending the request. Use the **no** form of this command to restore the default configuration.

SYNTAX

dot1x timeout tx-period *seconds*
no dot1x timeout tx-period

PARAMETERS

seconds—Specifies the time interval in seconds during which the device waits for a response to an EAP-request/identity frame from the client before resending the request. (Range: 1–65535 seconds)

DEFAULT CONFIGURATION

The default timeout period is 30 seconds.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

The default value of this command should be changed only to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

EXAMPLE

The following command sets the time interval during which the device waits for a response to an EAP request/identity frame to 3600 seconds.

```
Console(config)# interface tengigabitethernet 0/15  
Console(config-if)# dot1x timeout tx-period 3600
```

dot1x max-req Use the **dot1x max-req** Interface Configuration mode command to set the maximum number of times that the device sends an Extensible Authentication Protocol (EAP) request/identity frame (assuming that no response is received) to the client before restarting the authentication process. Use the **no** form of this command to restore the default configuration.

SYNTAX

dot1x max-req *count*
no dot1x max-req

PARAMETERS

count—Specifies the maximum number of times that the device sends an EAP request/identity frame before restarting the authentication process. (Range: 1–10)

DEFAULT CONFIGURATION

The default maximum number of attempts is 2.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

The default value of this command should be changed only to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

EXAMPLE

The following example sets the maximum number of times that the device sends an EAP request/identity frame to 6

```
Console(config)# interface tengigabitethernet 0/15
Console(config-if)# dot1x max-req 6
```

dot1x timeout supp-timeout

Use the **dot1x timeout supp-timeout** Interface Configuration (Ethernet) mode command to set the time interval during which the device waits for a response to an Extensible Authentication Protocol (EAP) request frame from the client before resending the request. Use the **no** form of this command to restore the default configuration.

SYNTAX

dot1x timeout supp-timeout *seconds*
no dot1x timeout supp-timeout

PARAMETERS

seconds—Specifies the time interval in seconds during which the device waits for a response to an EAP request frame from the client before resending the request. (Range: 1–65535 seconds)

DEFAULT CONFIGURATION

The default timeout period is 30 seconds.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

The default value of this command should be changed only to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

EXAMPLE

The following example sets the time interval during which the device waits for a response to an EAP request frame from the client before resending the request to 3600 seconds.

```
Console(config)# interface tengigabitethernet 0/15
Console(config-if)# dot1x timeout supp-timeout 3600
```

**dot1x timeout
server-timeout**

Use the **dot1x timeout server-timeout** Interface Configuration (Ethernet) mode command to set the time interval during which the device waits for a response from the authentication server. Use the **no** form of this command to restore the default configuration.

SYNTAX

dot1x timeout server-timeout *seconds*

no dot1x timeout server-timeout

PARAMETERS

seconds—Specifies the time interval in seconds during which the device waits for a response from the authentication server. (Range: 1–65535 seconds)

DEFAULT CONFIGURATION

The default timeout period is 30 seconds.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

The actual timeout period can be determined by comparing the value specified by the **dot1x timeout server-timeout** command to the result of multiplying the number of retries specified by the **radius-server retransmit** command by the timeout period specified by the **radius-server timeout** command, and selecting the lower of the two values.

EXAMPLE

The following example sets the time interval between retransmission of packets to the authentication server to 3600 seconds.

```
Console(config)# interface tengigabitethernet 0/15
Console(config-if)# dot1x timeout server-timeout 3600
```

show dot1x Use the **show dot1x** Privileged EXEC mode command to display the 802.1x device or specified interface status.

SYNTAX

show dot1x [*interface interface-id*]

PARAMETERS

interface-id—Specify an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following examples display the status of 802.1x-enabled Ethernet ports.

```
Console# show dot1x
802.1x is enabled
```

Port	Admin Mode	Oper Mode	Reauth Control	Reauth Period	Username
----	-----	-----	-----	-----	-----
te1	Auto	Authorized	Ena	3600	Bob
te2	Auto	Authorized	Ena	3600	John
te3	Auto	Unauthorized	Ena	3600	Clark
te4	Force-auth	Authorized	Dis	3600	n/a
te5	Force-auth	Unauthorized	Dis	3600	n/a

* Port is down or not present.

```
Console# show dot1x interface te3
```

802.1x is enabled.

Port	Admin Mode	Oper Mode	Reauth Control	Reauth Period	Username
----	-----	-----	-----	-----	-----
te3	Auto	Unauthorized	Ena	3600	Clark

```
Time-range:                work-hours (Inactive now)
Quiet period:              60 Seconds
Tx period:                 30 Seconds
Max req:                   2
Supplicant timeout:        30 Seconds
```

```

Server timeout:                30 Seconds
Session Time (HH:MM:SS):      08:19:17
MAC Address:                   00:08:78:32:98:78
Authentication Method:         Remote
Termination Cause:             Supplicant logoff

```

Authenticator State Machine

```

State:                          HELD

```

Backend State Machine

```

State:                          IDLE
Authentication success:         9
Authentication fails:           1

```

The following table describes the significant fields shown in the display.

Field	Description
Port	The port number.
Admin mode	The port admin mode. Possible values: Force-auth, Force-unauth, Auto.
Oper mode	The port oper mode. Possible values: Authorized, Unauthorized or Down.
Reauth Control	Reauthentication control.
Reauth Period	Reauthentication period.
Username	The username representing the supplicant identity. This field shows the username if the port control is auto. If the port is Authorized, it displays the username of the current user. If the port is Unauthorized, it displays the last user authenticated successfully.
Quiet period	The number of seconds that the device remains in the quiet state following a failed authentication exchange (for example, the client provided an invalid password).
Tx period	The number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the client before resending the request.
Max req	The maximum number of times that the device sends an EAP request frame (assuming that no response is received) to the client before restarting the authentication process.
Supplicant timeout	The number of seconds that the device waits for a response to an EAP-request frame from the client before resending the request.
Server timeout	The number of seconds that the device waits for a response from the authentication server before resending the request.
Session Time	The amount of time (HH:MM:SS) that the user is logged in.
MAC address	The supplicant MAC address.
Authentication Method	The authentication method used to establish the session.
Termination Cause	The reason for the session termination.
State	The current value of the Authenticator PAE state machine and of the Backend state machine.

Field	Description
Authentication success	The number of times the state machine received a Success message from the Authentication Server.
Authentication fails	The number of times the state machine received a Failure message from the Authentication Server.

show dot1x users Use the **show dot1x users** Privileged EXEC mode command to display active 802.1x authenticated users for the device.

SYNTAX

show dot1x users [*username username*]

PARAMETERS

username—Specifies the supplicant username (Length: 1–160 characters)

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays 802.1x users.

```
Switch# show dot1x users
Port Username      Session      Auth      MAC      Address      VLAN  Filter
-----
te1 Bob      1d 03:08:58 Remote  0008.3b79.8787  3
te2 John     08:19:17    None    0008.3b89.3127  2    OK

Port Username      Session      Auth      MAC      Address      VLAN  Filter
-----
te1 Bob  1d 09:07:38 Remote  0008.3b79.8787  3    OK
te1 Bernie 03:08:58 Remote  0008.3b79.3232  9    OK
te2 John  08:19:17 Remote  0008.3b89.3127  2
te3 Paul  02:12:48 Remote  0008.3b89.8237  8    Warning

Switch# show dot1x users username Bob
Port Username      Session      Auth      MAC      Address      VLAN  Filter
-----
te1 Bob  1d 09:07:38 Remote  0008.3b79.8787  3    OK
Filter ID #1: Supplicant-IPv4
Filter ID #2: Supplicant-IPv6

Switch# show dot1x users username Bernie
Port Username      Session      Auth      MAC      Address      VLAN  Filter
-----
te1 Bernard 03:08:58 Remote  0008.3b79.3232  9    OK
Filter ID #1: Supplicant-IPv4
```

show dot1x statistics Use the **show dot1x statistics** Privileged EXEC mode command to display 802.1x statistics for the specified interface.

SYNTAX

show dot1x statistics interface *interface-id*

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays 802.1x statistics for tengigabitethernet port 0/1.

```
Console# show dot1x statistics interface tengigabitethernet 0/1

EapolFramesRx: 11
EapolFramesTx: 12
EapolStartFramesRx: 1
EapolLogoffFramesRx: 1
EapolRespIdFramesRx: 3
EapolRespFramesRx: 6
EapolReqIdFramesTx: 3
EapolReqFramesTx: 6
InvalidEapolFramesRx: 0
EapLengthErrorFramesRx: 0
LastEapolFrameVersion: 1
LastEapolFrameSource: 00:08:78:32:98:78
```

The following table describes the significant fields shown in the display:

Field	Description
EapolFramesRx	The number of valid EAPOL frames of any type that have been received by this Authenticator.
EapolFramesTx	The number of EAPOL frames of any type that have been transmitted by this Authenticator.
EapolStartFramesRx	The number of EAPOL Start frames that have been received by this Authenticator.
EapolLogoffFramesRx	The number of EAPOL Logoff frames that have been received by this Authenticator.
EapolRespIdFramesRx	The number of EAP Resp/Id frames that have been received by this Authenticator.
EapolRespFramesRx	The number of valid EAP Response frames (other than Resp/Id frames) that have been received by this Authenticator.
EapolReqIdFramesTx	The number of EAP Req/Id frames that have been transmitted by this Authenticator.
EapolReqFramesTx	The number of EAP Request frames (other than Req/Id frames) that have been transmitted by this Authenticator.

Field	Description
InvalidEapolFramesRx	The number of EAPOL frames that have been received by this Authenticator for which the frame type is not recognized.
EapLengthErrorFramesRx	The number of EAPOL frames that have been received by this Authenticator in which the Packet Body Length field is invalid.
LastEapolFrameVersion	The protocol version number carried in the most recently received EAPOL frame.
LastEapolFrameSource	The source MAC address carried in the most recently received EAPOL frame.

dot1x auth-not-req Use the **dot1x auth-not-req** Interface Configuration (VLAN) mode command to enable unauthorized devices access to the VLAN. Use the **no** form of this command to disable access to the VLAN.

SYNTAX

dot1x auth-not-req

no dot1x auth-not-req

DEFAULT CONFIGURATION

Access is enabled.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

An access port cannot be a member in an unauthenticated VLAN.

The native VLAN of a trunk port cannot be an unauthenticated VLAN.

For a general port, the PVID can be an unauthenticated VLAN (although only tagged packets are accepted in the unauthorized state).

EXAMPLE

The following example enables unauthorized devices access to VLAN 5.

```
Console(config)# interface vlan 5
Console(config-if)# dot1x auth-not-req
```

dot1x host-mode Use the **dot1x host-mode** Interface Configuration mode command to allow a single host (client) or multiple hosts on an IEEE 802.1x-authorized port. Use the **no** form of this command to return to the default setting.

SYNTAX

dot1x host-mode {*multi-host* | *single-host* | *multi-sessions*}

PARAMETERS

- ◆ **multi-host**—Enable multiple-hosts mode.
- ◆ **single-host**—Enable single-hosts mode.
- ◆ **multi-sessions**—Enable multiple-sessions mode.

DEFAULT

Default mode is multi-host.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

In multiple hosts mode only one of the attached hosts must be successfully authorized for all hosts to be granted network access. If the port becomes unauthorized, all attached clients are denied access to the network.

In multiple sessions mode each host must be successfully authorized in order to grant network access. Please note that packets are NOT encrypted, and after success full authentication filtering is based on the source MAC address only.

Port security on a port can't be enabled in single-host mode and in multiple-sessions mode.

It is recommended to enable reauthentication when working in multiple-sessions mode in order to detect User Logout for users that hadn't sent Logoff.

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# dot1x host-mode multi-host
console(config-if)# dot1x host-mode single-host
console(config-if)# dot1x host-mode multi-sessions
```

dot1x violation-mode

Use the **dot1x violation-mode** Interface Configuration (Ethernet) mode command to configure the action to be taken, when a station whose MAC address is not the supplicant MAC address, attempts to access the interface. Use the **no** form of this command to return to default.

SYNTAX

dot1x violation-mode {*restrict* | *protect* | *shutdown*}

no dot1x violation-mode

PARAMETERS

- ◆ **restrict**—Generates a trap when a station whose MAC address is not the supplicant MAC address, attempts to access the interface. The

minimum time between the traps is 1 second. Those frames are forwarded but their source address are not learned.

- ◆ **protect**—Discard frames with source addresses not the supplicant address.
- ◆ **shutdown**—Discard frames with source addresses not the supplicant address and shutdown the port

DEFAULT CONFIGURATION

Protect

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

The command is relevant for single-host mode.

The command is not relevant for multiple-hosts mode.

The command is relevant for multiple-sessions mode, but you should note that since PCs are sending traffic prior to successful 802.1X authentication, this command might not be useful in this mode.

BPDU message whose MAC address is not the supplicant MAC address wouldn't be discarded in the protect mode.

BPDU message whose MAC address is not the supplicant MAC address would cause a shutdown in the shutdown mode.

EXAMPLE

```
console(config)# interface tengigabitethernet tel
console(config-if)# dot1x violation-mode protect
```

dot1x guest-vlan Use the **dot1x guest-vlan** Interface Configuration (VLAN) mode command to define a guest VLAN. Use the **no** form of this command to restore the default configuration.

SYNTAX

dot1x guest-vlan
no dot1x guest-vlan

DEFAULT CONFIGURATION

No VLAN is defined as a guest VLAN.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

Use the **dot1x guest-vlan enable** Interface Configuration mode command to enable unauthorized users on an interface to access the guest VLAN.

If the guest VLAN is defined and enabled, the port automatically joins the guest VLAN when the port is unauthorized and leaves it when the port becomes authorized. To be able to join or leave the guest VLAN, the port should not be a static member of the guest VLAN.

EXAMPLE

The following example defines VLAN 2 as a guest VLAN.

```
Console# configure
Console(config)# interface vlan 2
Console(config-if)# dot1x guest-vlan
```

**dot1x guest-vlan
timeout**

Use the **dot1x guest-vlan timeout** Global Configuration mode command to set the time delay between enabling 802.1x (or port up) and adding a port to the guest VLAN. Use the **no** form of this command to restore the default configuration.

SYNTAX

dot1x guest-vlan timeout *timeout*
no dot1x guest-vlan timeout

PARAMETERS

timeout—Specifies the time delay in seconds between enabling 802.1x (or port up) and adding the port to the guest VLAN. (Range: 30–180)

DEFAULT CONFIGURATION

The guest VLAN is applied immediately.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command is relevant if the guest VLAN is enabled on the port. Configuring the timeout adds delay from enabling 802.1x (or port up) to the time the device adds the port to the guest VLAN.

EXAMPLE

The following example sets the delay between enabling 802.1x and adding a port to a guest VLAN to 60 seconds.

```
Console(config)# dot1x guest-vlan timeout 60
```

dot1x guest-vlan enable Use the **dot1x guest-vlan enable** Interface Configuration (Ethernet) mode command to enable unauthorized users on the interface access to the guest VLAN. Use the **no** form of this command to disable access.

SYNTAX

dot1x guest-vlan enable
no dot1x guest-vlan enable

DEFAULT CONFIGURATION

The default configuration is disabled.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

A device can have only one global guest VLAN. The guest VLAN is defined using the **dot1x guest-vlan** Interface Configuration mode command.

EXAMPLE

The following example enables unauthorized users on tengigabitethernet port 0/1 to access the guest VLAN.

```
Console(config)# interface tengigabitethernet 0/15
Console(config-if)# dot1x guest-vlan enable
```

dot1x mac-authentication Use the **dot1x mac-authentication** Interface Configuration (Ethernet) mode command to enable authentication based on the station's MAC address. Use the **no** form of this command to disable access.

SYNTAX

dot1x mac-authentication {mac-only | mac-and-802.1x}
no dot1x mac-authentication

PARAMETERS

- ◆ **mac-only**—Enables authentication based on the station's MAC address only. 802.1X frames are ignored.
- ◆ **mac-and-802.1x**—Enables 802.1X authentication and MAC address authentication on the interface.

DEFAULT CONFIGURATION

Authentication based on the station's MAC address is disabled.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

The guest VLAN must be enabled when MAC authentication is enabled.

Static MAC addresses cannot be authorized. Do not change an authenticated MAC address to a static address.

It is not recommended to delete authenticated MAC addresses.

Reauthentication must be enabled when working in this mode.

EXAMPLE

The following example enables authentication based on the station's MAC address on tengigabitethernet port 0/1.

```
Console(config)# interface tel  
Console(config-if)# dot1x mac-authentication mac-only
```

dot1x radius-attributes vlan

Use the **dot1x radius-attributes vlan** Interface Configuration mode command, to enable user-based VLAN assignment. Use the **no** form of this command to disable user-based VLAN assignment.

SYNTAX

dot1x radius-attributes vlan

no dot1x radius-attributes vlan

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Disabled

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

The configuration of this command is allowed only when the port is Forced Authorized.

Radius attributes are supported only in the multiple sessions mode (multiple hosts with authentication)

When Radius attributes are enabled and the Radius Accept message does not contain the supplicant's VLAN as an attribute, then the supplicant is rejected.

Packets to the supplicant are sent untagged.

After successful authentication the port remains member in the unauthenticated VLANs and in the Guest VLAN. Other static VLAN

configuration is not applied on the port. If the supplicant VLAN does not exist on the switch, the supplicant is rejected.

EXAMPLE

```
console(config)# interface tel
console(config-if)# dot1x radius-attributes vlan
```

show dot1x advanced Use the **show dot1x advanced** Privileged EXEC mode command to display 802.1x advanced features for the device or specified interface.

SYNTAX

show dot1x advanced [*interface-id*]

PARAMETERS

interface-id—Specify an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays 802.1x advanced features for the device.

```
console# show dot1x advanced
Guest VLAN: 3978
Unauthenticated VLANs: 91, 92
Interface Multiple Guest  MAC          VLAN          Legacy-  Policy
           Hosts      VLAN  Authentication  Assignment  supp Mode  Assignment
-----
tel1  Disabled Enabled MAC-and-802.1X  Enabled      Enable      Disabled
tel2  Enabled  Disabled Disabled      Enabled      Enable      Disabled

Switch# show dot1x advanced tengigabitethernet 0/1

Interface Multiple Guest  MAC          VLAN          Legacy-  Policy
           Hosts      VLAN  Authentication  Assignment  sup Mode  Assignment
-----
tel1  Disabled Enabled MAC-and-802.1X  Enabled      Enable
Legacy-Supp mode is disabled
Policy assignment resource err handling: Accept
Single host parameters
Violation action: Discard
Trap: Enabledx
Status: Single-host locked
Violations since last trap: 9
```

ETHERNET CONFIGURATION COMMANDS

iPECS ES-5048XG

interface Use the **interface** Global Configuration mode command to configure an interface and enter interface configuration mode.

SYNTAX

interface interface-id

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

interface range Use the **interface range** command to execute a command on multiple ports at the same time.

SYNTAX

interface range interface-id-list

PARAMETERS

interface-id-list—Specify list of interface IDs. The interface ID can be one of the following types: Ethernet port or Port-channel

USER GUIDELINES

Commands under the interface range context are executed independently on each interface in the range: If the command returns an error on one of the interfaces, it does not stop the execution of the command on other interfaces.

EXAMPLE

```
console(config)# interface range te1-20
```

shutdown Use the **shutdown** Interface Configuration (Ethernet, Port-channel) mode command to disable an interface. Use the **no** form of this command to restart a disabled interface.

SYNTAX

shutdown

no shutdown

DEFAULT CONFIGURATION

The interface is enabled.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

EXAMPLE

The following example disables tengigabitethernet port 0/5 operations.

```
Console(config)# interface te5
Console(config-if)# shutdown
Console(config-if)#
```

The following example restarts the disabled Ethernet port.

```
Console(config)# interface te5
Console(config-if)# no shutdown
Console(config-if)
```

description Use the **description** Interface Configuration (Ethernet, Port-channel) mode command to add a description to an interface. Use the **no** form of this command to remove the description.

SYNTAX

description *string*

no description

PARAMETERS

string—Specifies a comment or a description of the port to assist the user. (Length: 1–64 characters)

DEFAULT CONFIGURATION

The interface does not have a description.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

EXAMPLE

The following example adds the description 'SW#3' to tengigabitethernet port 0/5.

```
Console(config)# interface tengigabitethernet 0/5
Console(config-if)# description SW#3
```


speed Use the **speed** Interface Configuration (Ethernet, Port-channel) mode command to configure the speed of a given Ethernet interface when not using auto-negotiation. Use the **no** form of this command to restore the default configuration.

SYNTAX

speed {10 | 100 | 1000 | 10000}

no speed

PARAMETERS

- ◆ **10**—Forces 10 Mbps operation.
- ◆ **100**—Forces 100 Mbps operation.
- ◆ **1000**—Forces 1000 Mbps operation.
- ◆ **10000**—Forces 10000 Mbps operation.

DEFAULT CONFIGURATION

The port operates at its maximum speed capability.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

The **no speed** command in a Port-channel context returns each port in the Port-channel to its maximum capability.

EXAMPLE

The following example configures the speed of tengigabitethernet port 0/5 to 100 Mbps operation.

```
Console(config)# interface tengigabitethernet 0/5
Console(config-if)# speed 100
```

flowcontrol Use the **flowcontrol** Interface Configuration (Ethernet, Port-channel) mode command to configure the flow control on a given interface. Use the **no** form of this command to disable flow control.

SYNTAX

flowcontrol {auto | on | off}

no flowcontrol

PARAMETERS

- ◆ **aut**—Specifies auto-negotiation.
- ◆ **on**—Enables flow control.

◆ **off**—Disables flow control.

DEFAULT CONFIGURATION

Flow control is enabled.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

Use the **negotiation** command to enable **flow control auto**.

EXAMPLE

The following example enables flow control on port `te1`

```
Console(config)# interface tengigabitethernet 0/1
Console(config-if)# flowcontrol on
```

port jumbo-frame Use the **port jumbo-frame** Global Configuration mode command to enable jumbo frames on the device. Use the **no** form of this command to disable jumbo frames.

SYNTAX

port jumbo-frame

no port jumbo-frame

DEFAULT CONFIGURATION

Jumbo frames are disabled on the device.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command takes effect only after resetting the device.

EXAMPLE

The following example enables jumbo frames on the device.

```
Console(config)# port jumbo-frame
```

clear counters Use the **show interfaces counters** EXEC mode command to display traffic seen by all the physical interfaces or by a specific interface.

SYNTAX

show interfaces counters *[interface-id]* **[detailed]**

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

detailed—Displays information for non-present ports in addition to present ports.

COMMAND MODE

EXEC mode

EXAMPLE

The following example clears the statistics counters for tengigabitethernet port 0/5.

```
Console# clear counters tengigabitethernet 0/5.
```

set interface active Use the **set interface active** EXEC mode command to reactivate an interface that was shut down.

SYNTAX

set interface active { *interface-id* }

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

USER GUIDELINES

This command is used to activate interfaces that were configured to be active, but were shut down by the system.

EXAMPLE

The following example reactivates tengigabitethernet port 0/1.

```
Console# set interface active tengigabitethernet 0/1
```

errdisable recovery cause Use the **errdisable recovery cause** Global Configuration mode command to enable automatic re-activation of an interface after Err-Disable shutdown. Use the **no** form of this command to disable automatic re-activation.

SYNTAX

```
errdisable recovery cause {all | port-security | dot1x-src-address |
acl-deny |stp-bpdu-guard | stp-loopback-guard }
no errdisable recovery cause {all | port-security | dot1x-src-address
| acl-deny | stp-bpdu-guard | stp-loopback-guard }
```

PARAMETERS

all -Enables the error recovery mechanism for all the reasons

port-security - Enables the error recovery mechanism for the Port security Err-Disable state.

dot1x-src-address- Enables the error recovery mechanism for the 802.1x Err-Disable state.

acl-deny- Enables the error recovery mechanism for the ACL Deny Err-Disable state.

stp-bpdu-guard- Enables the error recovery mechanism for the STP BPDU Guard Err-Disable state.

stp-loopback-guard - Enables the error recovery mechanism for the STP Loopback Guard Err-Disable state.

DEFAULT CONFIGURATION

Automatic re-activation is disabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables automatic re-activation of an interface after Loopback Detection Err-Disable shutdown.

```
Console(config)# errdisable recovery cause loopback-detection
```

errdisable recovery interval Use the **errdisable recovery interval** Global Configuration mode command timeout interval to set the error recovery timeout interval. Use the **no** form of this command to return to the default configuration.

SYNTAX

errdisable recovery interval *seconds*

no errdisable recovery interval

PARAMETERS

seconds—Specifies the error recovery timeout interval in seconds. (Range: 30–86400)

DEFAULT CONFIGURATION

The default error recovery timeout interval is 300 seconds.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example sets the error recovery timeout interval to 10 minutes.

```
Console(config)# errdisable recovery interval 600
```

show interfaces configuration Use the **show interfaces configuration** EXEC mode command to display the configuration for all configured interfaces or for a specific interface.

SYNTAX

show interfaces configuration [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the configuration of all configured interfaces:

```
console# show interfaces configuration
```

Port	Type	Duplex	Speed	Neg	Flow control	Admin State	Back Pressure	Mdix Mode
te1	1G-Copper	Full	10000	Disabled	Off	Up	Disabled	Off

```

te2 1G-Copper Full 1000 Disabled Off Up Disabled Off
Ch      Type      Speed Neg      Flow      Admin
-----
Po1      Disabled Off      Up

```

show interfaces status Use the **show interfaces status** EXEC mode command to display the status of all configured interfaces or of a specific interface.

SYNTAX

show interfaces status [*interface-id*][**detailed**]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

detailed—Displays information for non-present ports in addition to present ports.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the status of all configured interfaces.

```

console# show interfaces status

Port      Type      Duplex Speed Neg      Flow Link  Back      Mdix
-----
te1 1G-Copper Full 1000 Disabled Off Up Disabled Off
te2 1G-Copper -- -- -- -- Down -- --

Ch      Type      Duplex Speed Neg      Flow Link
-----
Po1 1G Full 10000 Disabled Off Up

```

show interfaces advertise Use the **show interfaces advertise** EXEC mode command to display auto-negotiation advertisement information for all configured interfaces or for a specific interface.

SYNTAX

show interfaces advertise [*interface-id* |

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLES

The following examples display auto-negotiation information.

```
Console# show interfaces advertise
```

Port	Type	Neg	Operational Link Advertisement
te1	1G-Copper	Enable	1000f, 100f, 10f, 10h
te2	1G-Copper	Enable	1000f

```
Console# show interfaces advertise tengigabitethernet 0/1
```

```
Port:te1
```

```
Type: 1G-Copper
```

```
Link state: Up
```

```
Auto Negotiation: enabled
```

	10h	10f	100h	100f	1000f
Admin Local link Advertisement	yes	yes	yes	yes	yes
Oper Local link Advertisement	yes	yes	yes	yes	yes
Remote Local link Advertisement	no	no	yes	yes	yes
Priority Resolution	-	-	-	-	yes

```
Console# show interfaces advertise tengigabitethernet 0/1
```

```
Port: te1
```

```
Type: 1G-Copper
```

```
Link state: Up
```

```
Auto negotiation: disabled.
```

show interfaces description Use the **show interfaces description** EXEC mode command to display the description for all configured interfaces or for a specific interface.

SYNTAX

show interfaces description *[interface-id]*

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the description of all configured interfaces.

```
Console# show interfaces description
```

```
Port      Descriptions
-----
te1       -----
te1       Port that should be used for management only
te2
te1
te1
te2
```

```
Ch      Description
----
Po1     Output
```

show interfaces counters Use the **show interfaces counters** EXEC mode command to display traffic seen by all the physical interfaces or by a specific interface.

SYNTAX

show interfaces counters [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays traffic seen by all the physical interfaces.

```
console# show interfaces counters tengigabitethernet 0/
Port      InUcastPkts  InMcastPkts  InBcastPkts  InOctets
-----
te1       0            0            0            0
Port      OutUcastPkts  OutMcastPkts  OutBcastPkts  OutOctets
-----
te1       0            1            35           7051
Alignment Errors: 0
FCS Errors: 0
Single Collision Frames: 0
Multiple Collision Frames: 0
SQE Test Errors: 0
Deferred Transmissions: 0
Late Collisions: 0
Excessive Collisions: 0
Carrier Sense Errors: 0
Oversize Packets: 0
Internal MAC Rx Errors: 0
Symbol Errors: 0
```



```
Received Pause Frames: 0
Transmitted Pause Frames: 0
```

The following table describes the fields shown in the display.

Field	Description
InOctets	The number of received octets.
InUcastPkts	The number of received unicast packets.
InMcastPkts	The number of received multicast packets.
InBcastPkts	The number of received broadcast packets.
OutOctets	The number of transmitted octets.
OutUcastPkts	The number of transmitted unicast packets.
OutMcastPkts	The number of transmitted multicast packets.
OutBcastPkts	The number of transmitted broadcast packets.
FCS Errors	The number of frames received that are an integral number of octets in length but do not pass the FCS check.
Single Collision Frames	The number of frames that are involved in a single collision, and are subsequently transmitted successfully.
Multiple Collision Frames	The number of frames that are involved in more than one collision and are subsequently transmitted successfully.
SQE Test Errors	The number of times that the SQE TEST ERROR is received. The SQE TEST ERROR is set in accordance with the rules for verification of the SQE detection mechanism in the PLS Carrier Sense Function as described in IEEE Std. 802.3, 2000 Edition, section 7.2.4.6.
Deferred Transmissions	The number of frames for which the first transmission attempt is delayed because the medium is busy.
Late Collisions	The number of times that a collision is detected later than one slotTime into the transmission of a packet.
Excessive Collisions	The number of frames for which transmission fails due to excessive collisions.
Oversize Packets	The number of frames received that exceed the maximum permitted frame size.
Internal MAC Rx Errors	The number of frames for which reception fails due to an internal MAC sublayer receive error.
Received Pause Frames	The number of MAC Control frames received with an opcode indicating the PAUSE operation.
Transmitted Pause Frames	The number of MAC Control frames transmitted on this interface with an opcode indicating the PAUSE operation.

show port jumbo-frame Use the **show port jumbo-frame** EXEC mode command to display the configuration of jumbo frames.

SYNTAX

show port jumbo-frame

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the configuration of jumbo frames on the device.

```
Console# show port jumbo-frame

Jumbo frames are disabled
Jumbo frames will be enabled after reset
```

show errdisable recovery Use the **show errdisable recovery** EXEC mode command to display the Err-Disable configuration.

SYNTAX

show errdisable recovery

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the Err-Disable configuration.

```
console# show errdisable recovery
Timer interval: 300 Seconds

      Reason                Automatic Recovery
-----
port-security              Disable
dot1x-src-address          Disable
acl-deny                    Enable
stp-bpdu-guard             Disable
stp-loopback-guard         Disable
```

show errdisable interfaces Use the **show errdisable interfaces** EXEC mode command to display the Err-Disable state of all interfaces or of a specific interface.

SYNTAX

show errdisable interfaces [*interface-id*]

PARAMETERS

- ◆ **interface**—Interface number
- ◆ **Port-channel-number**—Port channel index.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the Err-Disable state of all interfaces.

```
console# show errdisable interfaces
Interface          Reason                      Automatic recovery
-----
te1                 port-security              No
te12 acl-deny       Yes
```

**storm-control
broadcast enable**

Use the **storm-control broadcast enable** Interface Configuration mode command to enable storm control. Use the **no** form of this command to disable storm control.

SYNTAX

storm-control broadcast enable
no storm-control broadcast enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Disabled

COMMAND MODE

Interface Configuration mode(Ethernet)

USER GUIDELINES

- ◆ Use the **storm-control broadcast level** Interface Configuration command to set the maximum rate.
- ◆ Use the **storm-control include-multicast** Interface Configuration command to also count multicast packets and optionally unknown unicast packets in the storm control calculation.
- ◆ Storm control and rate-limit (of unicast packets) cannot be enabled simultaneously on the same port.

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# storm-control broadcast enable
```

storm-control broadcast level kbps Use the **storm-control broadcast level** Interface Configuration mode command to configure the maximum rate of broadcast. Use the **no** form of this command to return to default.

SYNTAX

storm-control broadcast level kbps *kbps*
no storm-control broadcast level

PARAMETERS

kbps—Maximum number of kilo bits per second of broadcast traffic on a port. (Range 3K–10G)

DEFAULT CONFIGURATION

1000

COMMAND MODE

Interface Configuration mode (Ethernet)

USER GUIDELINES

Use the **storm-control broadcast enable** Interface Configuration command to enable storm control.

The calculated rate includes the 20 bytes of Ethernet framing overhead (preamble+SFD+IPG).

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# storm-control broadcast level kbps 12345
```

storm-control include-multicast Use the **storm-control include-multicast** Interface Configuration mode command to count multicast packets in the broadcast storm control. Use the **no** form of this command to disable counting of multicast packets in the broadcast storm control.

SYNTAX

storm-control include-multicast [*unknown-unicast*]
no storm-control include-multicast

PARAMETERS

This command has no arguments or keywords.

unknown-unicast—Specifies also the count of unknown unicast packets.

DEFAULT CONFIGURATION

Disabled

COMMAND MODE

Interface Configuration mode (Ethernet)

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# storm-control include-multicast
```

show storm-control Use the **show storm-control** EXEC mode command to display the configuration of storm control.

SYNTAX

show storm-control [*interface-id*]

PARAMETERS

interface-id—Specifies the interface.

COMMAND MODE

EXEC mode

EXAMPLE

```
console# show storm-control
Port   State   Rate [Kbits/Sec] Included
-----
tel1 Enabled 12345          Broadcast, Multicast,
                        Unknown unicast
tel2 Disabled 100000         Broadcast
```

USER GUIDELINES

Use the **storm-control broadcast enable** Interface Configuration command to enable storm control.

The calculated rate includes the 20 bytes of Ethernet framing overhead (preamble+SFD+IPG).

If the suppression level in percentage is translated (for the current port's speed) to a rate that is lower than the minimum rate, the minimum rate would be set.

EXAMPLE

```
console(config)# interface tel
console(config-if)# storm-control broadcast level kbps 12345
```

show fiber-ports optical-transceiver Use the **show fiber-ports optical-transceiver** EXEC mode command to display the optical transceiver diagnostics.

SYNTAX

show fiber-ports optical-transceiver [*interface interface-id*]
[*detailed*]

Parameters

- ◆ **interface-id**—Specifies an interface ID. The interface ID must be an Ethernet port.
- ◆ **detailed**—Displays detailed diagnostics.

COMMAND MODE

EXEC mode

EXAMPLE

The following examples display the optical transceiver diagnostics results.

```
console# show fiber-ports optical-transceiver
```

Port	Temp	Voltage	Current	Output Power	Input Power	LOS
te1	W	OK	OK	OK	OK	OK
te2	OK	OK	OK	E	OK	OK

Temp - Internally measured transceiver temperature
 Voltage - Internally measured supply voltage
 Current - Measured TX bias current
 Output Power - Measured TX output power in milliWatts
 Input Power - Measured RX received power in milliWatts
 LOS - Loss of signal
 N/A - Not Available, N/S - Not Supported,
 W - Warning, E - Error

```
console# show fiber-ports optical-transceiver detailed
```

Port	Temp [C]	Voltage [Volt]	Current [mA]	Output Power [mWatt]	Input Power [mWatt]	LOS
------	----------	----------------	--------------	----------------------	---------------------	-----

gi0/1	Copper					
gi0/26	Copper					
gi0/27	28	3.32	7.26	3.53	3.68	No
gi0/28	29	3.33	6.50	3.53	3.71	No

Temp - Internally measured transceiver temperature
 Voltage - Internally measured supply voltage
 Current - Measured TX bias current

Output Power - Measured TX output power in milliWatts
Input Power - Measured RX received power in milliWatts
LOS - Loss of signal
N/A - Not Available, N/S - Not Supported, W - Warning, E - Error

channel-group Use the **channel-group** Interface Configuration (Ethernet) mode command to associate a port with a port-channel. Use the **no** form of this command to remove a port from a port-channel.

SYNTAX

channel-group *port-channel mode {on | auto}*

no channel-group

PARAMETERS

- ◆ **port-channel**—Specifies the port channel number for the current port to join.
- ◆ **mode {on | auto}**—Specifies the mode of joining the port channel. The possible values are:
 - **on**—Forces the port to join a channel without an LACP operation.
 - **auto**—Forces the port to join a channel as a result of an LACP operation.

DEFAULT CONFIGURATION

The port is not assigned to a port-channel.

COMMAND MODE

Interface Configuration (Ethernet) mode

EXAMPLE

The following example forces port `te1` to join port-channel 1 without an LACP operation.

```
Console(config)# interface tengigabitethernet 0/1
Console(config-if)# channel-group 1 mode on
```


port-channel load-balance Use the **port-channel load-balance** Global Configuration mode command to configure the load balancing policy of the port channeling. Use the **no** form of this command to reset to default.

SYNTAX

port-channel load-balance {*src-dst-mac* | *src-dst-ip* | *src-dst-mac-ip* | }
no port-channel load-balance

PARAMETERS

- ◆ **src-dst-mac**—Port channel load balancing is based on the source and destination MAC address.
- ◆ **src-dst-ip**—Port channel load balancing is based on the source and destination IP address.
- ◆ **src-dst-mac-ip**—Port channel load balancing is based on the source and destination of MAC and IP addresses.

DEFAULT CONFIGURATION

src-dst-mac is the default option.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

In **src-dst-mac-ip-port** load balancing policy, fragmented packets might be reordered.

EXAMPLE

```
console#
console# configure
console(config)# port-channel load-balance src-dst-mac
console(config)# port-channel load-balance src-dst-ip
console(config)# port-channel load-balance src-dst-mac-ip
console(config)# port-channel load-balance src-dst-mac-ip-port
console(config)#
```

show interfaces port-channel Use the **show interfaces port-channel** EXEC mode command to display port-channel information for all port channels or for a specific port channel.

SYNTAX

show interfaces port-channel [*interface-id*]

PARAMETERS

interface-id—Specify an interface ID. The interface ID must be a Port Channel.

COMMAND MODE**EXEC mode****EXAMPLE**

The following example displays information on all port-channels.

```
console# show interfaces port-channel
Load balancing: src-dst-mac.
Gathering information...
Channel  Ports
-----  -----
Po1      Active: te1,Inactive: te2-3
Po2      Active: te25 Inactive: te24
Po3

console# show interfaces switchport te10
Gathering information...

Name: te10
Switchport: enable
Administrative Mode: access
Operational Mode: down
Access Mode VLAN: 1
Access Multicast TV VLAN: none
Trunking Native Mode VLAN: 1
Trunking VLANs Enabled: 1
                        2-4094 (Inactive)
General PVID: 1
General VLANs Enabled: none
General Egress Tagged VLANs Enabled: none
General Forbidden VLANs: none
General Ingress Filtering: enabled
General Acceptable Frame Type: all
General GVRP status: disabled
Customer Mode VLAN: none
Private-vlan promiscuous-association primary VLAN: none
Private-vlan promiscuous-association Secondary VLANs Enabled: none
Private-vlan host-association primary VLAN: none
Private-vlan host-association Secondary VLAN Enabled: none
DVA: disable
```

bridge multicast filtering Use the **bridge multicast filtering** Global Configuration mode command to enable the filtering of multicast addresses. Use the **no** form of this command to disable multicast address filtering.

SYNTAX

bridge multicast filtering
no bridge multicast filtering

DEFAULT CONFIGURATION

Multicast address filtering is disabled. All multicast addresses are flooded to all ports.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

If multicast devices exist on the VLAN, do not change the unregistered multicast addresses' states to drop on the device ports.

If multicast devices exist on the VLAN and IGMP-snooping is not enabled, the **bridge multicast forward-all** command should be used to enable forwarding all multicast packets to the multicast switches.

EXAMPLE

The following example enables bridge multicast filtering.

```
Console(config)# bridge multicast filtering
```

bridge multicast mode Use the **bridge multicast mode** Interface Configuration (VLAN) mode command to configure the multicast bridging mode. Use the **no** form of this command to return to the default configuration.

SYNTAX

bridge multicast mode {*mac-group* | *ip-group* | *ip-src-group*}
no bridge multicast mode

PARAMETERS

- ◆ **mac-group**—Specifies that multicast bridging is based on the packet's VLAN and MAC address.
- ◆ **ipv4-group**—Specifies that multicast bridging is based on the packet's VLAN and MAC address for non-IPv4 packets, and on the packet's VLAN and IPv4 destination address for IPv4 packets.
- ◆ **ipv4-src-group**—Specifies that multicast bridging is based on the packet's VLAN and MAC address for non-IPv4 packets, and on the packet's VLAN, IPv4 destination address and IPv4 source address for IPv4 packets.

DEFAULT CONFIGURATION

The default mode is mac-group.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

Use the mac-group mode when using a Network Management System that uses a MIB based on the multicast MAC address. Otherwise, it is recommended to use the ipv4-group or ipv4-src-group mode because there is no overlapping of IPv4 multicast addresses in these modes.

For each Forwarding Data Base (FDB) mode, use different CLI commands to configure static entries in the FDB, as described in the following table:

FDB mode		CLI commands
mac-group	bridge multicast address	bridge multicast forbidden address
ipv4-group	bridge multicast ip-address	bridge multicast forbidden ip-address
ipv4-src-group	bridge multicast source group	bridge multicast forbidden source group

The following table describes the actual data that is written to the Forwarding Data Base (FDB) as a function of the IGMP version that is used in the network:

FDB mode	IGMP version 2	IGMP version 3
mac-group	MAC group address	MAC group address
ipv4-group	IP group address	IP group address
ipv4-src-group	(*)	IP source and group addresses

(*) Note that (*,G) cannot be written to the FDB if the mode is **ipv4-src-group**. In that case, no new FDB entry is created, but the port is added to the static (S,G) entries (if they exist) that belong to the requested group. It is recommended to set the FDB mode to ipv4-group or mac-group for IGMP version 2.

If an application on the device requests (*,G), the operating FDB mode is changed to ipv4-group.

EXAMPLE

The following example configures the multicast bridging mode as ipv4-group on VLAN 2.

```
Console(config)# interface vlan 2
Console(config-if)# bridge multicast mode ipv4-group
```

bridge multicast address

Use the **bridge multicast address** Interface Configuration (VLAN) mode command to register a MAC-layer multicast address in the bridge table and statically add or remove ports to or from the group. Use the **no** form of this command to unregister the MAC address.

SYNTAX

```
bridge multicast address {mac-multicast-address} [[add | remove]
{ethernet interface-list | port-channel port-channel-list}]
no bridge multicast address {mac-multicast-address}
```

PARAMETERS

- ◆ **mac-multicast-address**—Specifies the group MAC multicast address.
- ◆ **add**—Adds ports to the group.
- ◆ **remove**—Removes ports from the group.
- ◆ **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- ◆ **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

DEFAULT CONFIGURATION

No multicast addresses are defined.

If **ethernet interface-list** or **port-channel port-channel-list** is specified without specifying **add** or **remove**, the default option is **add**.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

To register the group in the bridge database without adding or removing ports or port channels, specify the **mac-multicast-address** parameter only.

Static multicast addresses can be defined on static VLANs only.

You can execute the command before the VLAN is created.

EXAMPLE

The following example registers the MAC address to the bridge table:

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast address 01:00:5e:02:02:03
```

The following example registers the MAC address and adds ports statically.

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast address 01:00:5e:02:02:03 add te1-2
```

bridge multicast forbidden address

Use the **bridge multicast forbidden address** Interface Configuration (VLAN) mode command to forbid adding or removing a specific multicast address to or from specific ports. Use the **no** form of this command to restore the default configuration.

SYNTAX

```
bridge multicast forbidden address {mac-multicast-address} {add
| remove} {ethernet interface-list | port-channel port-channel-list}
no bridge multicast forbidden address {mac-multicast-address}
```

PARAMETERS

- ◆ **mac-multicast-address**—Specifies the group MAC multicast address.
- ◆ **add**—Forbids adding ports to the group.
- ◆ **remove**—Forbids removing ports from the group.
- ◆ **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- ◆ **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

DEFAULT CONFIGURATION

No forbidden addresses are defined.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

Before defining forbidden ports, the multicast group should be registered.

You can execute the command before the VLAN is created.

EXAMPLE

The following example forbids MAC address 0100.5e02.0203 on port 9 within VLAN 8.

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast address 0100.5e.02.0203
Console(config-if)# bridge multicast forbidden address 0100.5e02.0203 add te9
```

**bridge multicast
forbidden ip-
address**

Use the **bridge multicast forbidden ip-address** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IP multicast address to or from specific ports. Use the no form of this command to restore the default configuration.

SYNTAX

```
bridge multicast forbidden ip-address {ip-multicast-address} {add  
| remove} {ethernet interface-list | port-channel port-channel-list}  
no bridge multicast forbidden ip-address {ip-multicast-address}
```

PARAMETERS

- ◆ **ip-multicast-address**—Specifies the group IP multicast address.
- ◆ **add**—Forbids adding ports to the group.
- ◆ **remove**—Forbids removing ports from the group.
- ◆ **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- ◆ **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

DEFAULT CONFIGURATION

No forbidden addresses are defined.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

Before defining forbidden ports, the multicast group should be registered.

You can execute the command before the VLAN is created.

EXAMPLE

The following example registers IP address 239.2.2.2, and forbids the IP address on port `te9` within VLAN 8.

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast ip-address 239.2.2.2
Console(config-if)# bridge multicast forbidden ip-address 239.2.2.2 add te9
```

**bridge multicast
source group**

Use the **bridge multicast source group** Interface Configuration (VLAN) mode command to register a source IP address - multicast IP address pair to the bridge table, and statically add or remove ports to or from the source-group. Use the no form of this command to unregister the source-group-pair.

SYNTAX

bridge multicast source *ip-address* **group** *ip-multicast-address*
[[*add* | *remove*] { *ethernet interface-list* | *port-channel port-channel-list*}]

no bridge multicast source *ip-address* **group** *ip-multicast-address*

PARAMETERS

- ◆ **ip-address**—Specifies the source IP address.
- ◆ **ip-multicast-address**—Specifies the group IP multicast address.
- ◆ **add**—Adds ports to the group for the specific source IP address.
- ◆ **remove**—Removes ports from the group for the specific source IP address.
- ◆ **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- ◆ **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

DEFAULT CONFIGURATION

No multicast addresses are defined.

If **ethernet** *interface-list* or **port-channel** *port-channel-list* is specified without specifying **add** or **remove**, the default option is **add**.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

The following example registers a source IP address - multicast IP address pair to the bridge table:

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast source 239.2.2.2 group 239.2.2.2
```

bridge multicast forbidden source group

Use the **bridge multicast forbidden source group** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IP source address - multicast address pair to or from specific ports. Use the no form of this command to return to the default configuration.

SYNTAX

bridge multicast forbidden source *ip-address* **group** *ip-multicast-address* {*add* | *remove*} {*ethernet interface-list* | *port-channel port-channel-list*}

no bridge multicast forbidden source *ip-address* **group** *ip-multicast-address*

PARAMETERS

- ◆ **ip-address**—Specifies the source IP address.
- ◆ **ip-multicast-address**—Specifies the group IP multicast address.
- ◆ **add**—Forbids adding ports to the group for the specific source IP address.
- ◆ **remove**—Forbids removing ports from the group for the specific source IP address.
- ◆ **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- ◆ **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

DEFAULT CONFIGURATION

No forbidden addresses are defined.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

Before defining forbidden ports, the multicast group should be registered.

You can execute the command before the VLAN is created.

EXAMPLE

The following example registers a source IP address - multicast IP address pair to the bridge table, and forbids adding the pair to tengigabitethernet port te9 on VLAN 8:

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast source 13.16.1.1 group 239.2.2.2
Console(config-if)# bridge multicast forbidden source 13.16.1.1 group
239.2.2.2 add te9
```

**bridge multicast
ipv6 mode**

Use the **bridge multicast ipv6 mode** Interface Configuration (VLAN) mode command to configure the multicast bridging mode for ipv6 multicast packets. Use the no form of this command to return to the default configuration.

SYNTAX

bridge multicast ipv6 mode {*mac-group* | *ip-group* | *ip-src-group*}
no bridge multicast ipv6 mode

PARAMETERS

- ◆ **mac-group**—Specifies that multicast bridging is based on the packet's VLAN and MAC address.
- ◆ **ip-group**—Specifies that multicast bridging is based on the packet's VLAN and IPv6 destination address for IPv6 packets.
- ◆ **ip-src-group**—Specifies that multicast bridging is based on the packet's VLAN, IPv6 destination address and IPv6 source address for IPv6 packets.

DEFAULT CONFIGURATION

The default mode is mac-group.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

Use the **mac-group** mode when using a Network Management System that uses a MIB based on the multicast MAC address.

For each Forwarding Data Base (FDB) mode, use different CLI commands to configure static entries for IPv6 multicast addresses in the FDB, as described in the following table:

FDB mode	CLI commands	
mac-group	bridge multicast address	bridge multicast forbidden address

FDB mode	CLI commands	
ipv4-group	bridge multicast ipv6 ip-address	bridge multicast ipv6 forbidden ip-address
ipv4-src-group	bridge multicast ipv6 source group	bridge multicast ipv6 forbidden source group

The following table describes the actual data that is written to the Forwarding Data Base (FDB) as a function of the MLD version that is used in the network:

FDB mode	MLD version 1	MLD version 2
mac-group	MAC group address	MAC group address
ipv4-group	IP group address	IP group address
ipv4-src-group	(*)	IP source and group addresses

(*) Note that (*,G) cannot be written to the FDB if the mode is **ip-src-group**. In that case, no new FDB entry is created, but the port is added to the (S,G) entries (if they exist) that belong to the requested group. If an application on the device requests (*,G), the operating FDB mode is changed to **ip-group**.

- ◆ You can execute the command before the VLAN is created.

EXAMPLE

The following example configures the multicast bridging mode as **ip-group** on VLAN 2.

```
Console(config)# interface vlan 2
Console(config-if)# bridge multicast ipv6 mode ip-group
```

bridge multicast ipv6 forbidden ip- address

Use the **bridge multicast ipv6 forbidden ip-address** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IPv6 multicast address to or from specific ports. To restore the default configuration, use the **no** form of this command.

SYNTAX

bridge multicast ipv6 forbidden ip-address {*ipv6-multicast-address*} {*add* | *remove*} {*ethernet interface-list* | *port-channel port-channel-list*}

no bridge multicast ipv6 forbidden ip-address {*ipv6-multicast-address*}

PARAMETERS

- ◆ **ipv6-multicast-address**—Specifies the group IPv6 multicast address.
- ◆ **add**—Forbids adding ports to the group.

- ◆ **remove**—Forbids removing ports from the group.
- ◆ **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- ◆ **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

DEFAULT CONFIGURATION

No forbidden addresses are defined.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

Before defining forbidden ports, the multicast group should be registered.

You can execute the command before the VLAN is created.

EXAMPLE

The following example registers an IPv6 multicast address, and forbids the IPv6 address on port 9 within VLAN 8.

```
console(config)# interface vlan 8
Console(config-if)# bridge multicast ipv6 ip-address FE02:0:0:0:4:4:4
Console(config-if)# bridge multicast ipv6 forbidden ip-address
FE02:0:0:0:4:4:4 add te9
```

bridge multicast ipv6 source group

Use the **bridge multicast ipv6 source group** Interface Configuration (VLAN) mode command to register a source IPv6 address - multicast IPv6 address pair to the bridge table, and statically add or remove ports to or from the source-group. Use the **no** form of this command to unregister the source-group-pair.

SYNTAX

bridge multicast ipv6 source *ipv6-source-address* **group** *ipv6-multicast-address* *[[add | remove] { ethernet interface-list | port-channel port-channel-list}]*

no bridge multicast ipv6 source *ipv6-address* **group** *ipv6-multicast-address*

PARAMETERS

- ◆ **ipv6-source-address**—Specifies the source IPv6 address.
- ◆ **ipv6-multicast-address**—Specifies the group IPv6 multicast address.
- ◆ **add**—Adds ports to the group for the specific source IPv6 address.

- ◆ **remove**—Removes ports from the group for the specific source IPv6 address.
- ◆ **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- ◆ **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

DEFAULT CONFIGURATION

No multicast addresses are defined.

If **ethernet interface-list** or **port-channel port-channel-list** is specified without specifying **add** or **remove**, the default option is **add**.

You can execute the command before the VLAN is created.

COMMAND MODE

Interface Configuration (VLAN) mode

EXAMPLE

The following example registers a source IPv6 address - multicast IPv6 address pair to the bridge table:

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast source FE02:0:0:0:4:4:4 group
FE02:0:0:0:4:4:4
```

bridge multicast ipv6 forbidden source group

Use the **bridge multicast ipv6 forbidden source group** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IP source address - multicast address pair to or from specific ports. Use the **no** form of this command to return to the default configuration.

SYNTAX

bridge multicast ipv6 forbidden source *ipv6-source-address* **group**
ipv6-multicast-address {*add* | *remove*} {*interface-list* | *port-*
channel port-channel-list}

no bridge multicast ipv6 forbidden source *ipv6-address* **group**
ipv6-multicast-address

PARAMETERS

- ◆ **ipv6-source-address**—Specifies the source IPv6 address.
- ◆ **ipv6-multicast-address**—Specifies the group IPv6 multicast address.
- ◆ **add**—Forbids adding ports to the group for the specific source IPv6 address.

- ◆ **remove**—Forbids removing ports from the group for the specific source IPv6 address.
- ◆ **interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- ◆ **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

DEFAULT CONFIGURATION

No forbidden addresses are defined.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

Before defining forbidden ports, the multicast group should be registered.

You can execute the command before the VLAN is created.

EXAMPLE

The following example registers a source IPv6 address - multicast IPv6 address pair to the bridge table, and forbids adding the pair to tengigabitethernet 0/9 on VLAN 8:

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast source FE02:0:0:0:4:4:4 group
FE02:0:0:0:4:4:4
Console(config-if)# bridge multicast forbidden source FE02:0:0:0:4:4:4 group
FE02:0:0:0:4:4:4 add te9
```

bridge multicast unregistered

Use the **bridge multicast unregistered** Interface Configuration (Ethernet, Port-Channel) mode command to configure the forwarding state of unregistered multicast addresses. Use the **no** form of this command to restore the default configuration.

SYNTAX

```
bridge multicast unregistered {forwarding | filtering}
no bridge multicast unregistered
```

PARAMETERS

- ◆ **forwarding**—Forwards unregistered multicast packets.
- ◆ **filtering**—Filters unregistered multicast packets.

DEFAULT CONFIGURATION

Unregistered multicast addresses are forwarded.

COMMAND MODE

Interface Configuration (Ethernet, Port-Channel) mode

USER GUIDELINES

Do not enable unregistered multicast filtering on ports that are connected to routers, because the 224.0.0.x address range should not be filtered. Note that routers do not necessarily send IGMP reports for the 224.0.0.x range.

You can execute the command before the VLAN is created.

EXAMPLE

The following example specifies that unregistered multicast packets are filtered on tengigabitethernet port 0/1:

```
Console(config)# interface tel
Console(config-if)# bridge multicast unregistered filtering
```

**bridge multicast
forward-all**

Use the **bridge multicast forward-all** Interface Configuration (VLAN) mode command to enable forwarding all multicast packets for a range of ports or port channels. Use the **no** form of this command to restore the default configuration.

SYNTAX

bridge multicast forward-all {*add* | *remove*} {*ethernet interface-list* | *port-channel port-channel-list*}

no bridge multicast forward-all

PARAMETERS

- ◆ **add**—Forces forwarding of all multicast packets.
- ◆ **remove**—Does not force forwarding of all multicast packets.
- ◆ **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- ◆ **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

DEFAULT CONFIGURATION

Forwarding of all multicast packets is disabled.

COMMAND MODE

Interface Configuration (VLAN) mode

EXAMPLE

The following example enables all multicast packets on port te8 to be forwarded.

```
Console(config)# interface vlan 2
Console(config-if)# bridge multicast forward-all add te8
```

bridge multicast forbidden forward- all

Use the **bridge multicast forbidden forward-all** Interface Configuration (VLAN) mode command to forbid a port to dynamically join multicast groups. Use the no form of this command to restore the default configuration.

SYNTAX

bridge multicast forbidden forward-all {*add* | *remove*} {*ethernet interface-list* | *port-channel port-channel-list*}

no bridge multicast forbidden forward-all

PARAMETERS

- ◆ **add**—Forbids forwarding of all multicast packets.
- ◆ **remove**—Does not forbid forwarding of all multicast packets.
- ◆ **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- ◆ **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

DEFAULT CONFIGURATION

Ports are not forbidden to dynamically join multicast groups.

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

Use this command to forbid a port to dynamically join (by IGMP, for example) a multicast group.

The port can still be a multicast router port.

EXAMPLE

The following example forbids forwarding of all multicast packets to te1 within VLAN 2.

```
Console(config)# interface vlan 2
Console(config-if)# bridge multicast forbidden forward-all add ethernet te1
```

mac address-table static

Use the **mac address-table static** Global Configuration mode command to add MAC-layer station source address to the MAC address table. Use the **no** form of this command to delete the MAC address.

SYNTAX

mac address-table static *mac-address* *vlan* *vlan-id* *interface* *interface-id* [*permanent* | *delete-on-reset* | *delete-on-timeout* | *secure*]

no mac address-table static [*mac-address*] *vlan* *vlan-id*

PARAMETERS

mac-address—AC address (Range: Valid MAC address)

vlan-id—Specify the VLAN

interface-id—Specify an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel (Range: Valid Ethernet port, Valid Port-channel number)

permanent—The address can only be deleted by the **no bridge address** command.

delete-on-reset—The address is deleted after reset.

delete-on-timeout—The address is deleted after aged out.

secure—The address is deleted after the port changes mode to unlock learning (no port security command). Available only when the port is in learning locked mode.

DEFAULT CONFIGURATION

No static addresses are defined. The default mode for an added address is permanent.

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# mac address-table static 00:3f:bd:45:5a:b1 vlan 1 te1
```

clear mac address-table Use the **clear mac address-table** Privileged EXEC command to remove learned or secure entries from the forwarding database.

SYNTAX

clear mac address-table *dynamic [interface interface-id]*

clear mac address-table *secure interface interface-id*

PARAMETERS

interface interface-id—Delete all dynamic address on the specified interface. The interface ID can be one of the following types: Ethernet port or port-channel.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

```
console# clear mac address-table dynamic
```

mac address-table aging-time Use the **mac address-table aging-time** global configuration command to set the aging time of the address table. Use the **no** form of this command to restore the default.

SYNTAX

mac address-table aging-time *seconds*

no mac address-table aging-time

PARAMETERS

seconds—Time is number of seconds. (Range:10–300)

DEFAULT CONFIGURATION

300

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# mac address-table aging-time 600
```

port security Use the **port security** Interface Configuration (Ethernet, Port-channel) mode command to enable port security on an interface. Use the **no** form of this command to disable port security on an interface.

SYNTAX

```
port security [forward | discard | discard-shutdown] [trap seconds]  
no port security
```

PARAMETERS

- ◆ **forward**—Forwards packets with unlearned source addresses, but does not learn the address.
- ◆ **discard**—Discards packets with unlearned source addresses.
- ◆ **discard-shutdown**—Discards packets with unlearned source addresses and shuts down the port.
- ◆ **trap seconds**—Sends SNMP traps and specifies the minimum time interval in seconds between consecutive traps. (Range: 1–1000000)

DEFAULT CONFIGURATION

The feature is disabled

The default mode is discard.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

EXAMPLE

The following example forwards all packets to port te1 without learning addresses of packets from unknown sources and sends traps every 100 seconds if a packet with an unknown source address is received.

```
console(config)# tengigabitethernet 0/1  
Console(config-if)# port security forward trap 100
```

port security mode Use the **port security mode** Interface Configuration (Ethernet, port-channel) mode command configures the port security learning mode. Use the **no** form of this command to restore the default configuration.

SYNTAX

```
port security mode {lock | max-addresses }  
no port security mode
```

PARAMETERS

- ◆ **lock**—Saves the current dynamic MAC addresses associated with the port and disables learning, relearning and aging.

- ◆ **max-addresses**—Deletes the current dynamic MAC addresses associated with the port and learns up to the maximum number of addresses allowed on the port. Relearning and aging are enabled.

DEFAULT CONFIGURATION

The default port security mode is lock.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

EXAMPLE

The following example sets the port security mode to dynamic for tengigabitethernet interface 0/7.

```
Console(config)# interface tengigabitethernet 0/7
Console(config-if)# port security mode dynamic
```

port security max Use the **port security mode** Interface Configuration (Ethernet, Port-channel) mode command to configure the maximum number of addresses that can be learned on the port while the port is in port security max-addresses mode. Use the **no** form of this command to restore the default configuration.

SYNTAX

```
port security max {max-addr}
no port security max
```

PARAMETERS

max-addr—Specifies the maximum number of addresses that can be learned on the port. (Range: 0–128)

DEFAULT CONFIGURATION

This default maximum number of addresses is 1.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

This command is relevant in port security max-addresses mode only.

EXAMPLE

```
Console(config)# interface tengigabitethernet 0/1
Console(config-if)# port security max 20
```

port security routed secure-address Use the **port security routed secure-address** Interface Configuration (Ethernet, Port-channel) mode command to add a MAC-layer secure address to a routed port. Use the no form of this command to delete a MAC address from a routed port.

SYNTAX

port security routed secure-address *mac-address*
no port security routed secure-address [*mac-address*]

PARAMETERS

mac-address—Specifies the MAC address.

DEFAULT CONFIGURATION

No addresses are defined.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode. It cannot be configured for a range of interfaces (range context).

USER GUIDELINES

This command enables adding secure MAC addresses to a routed port in port security mode. The command is available when the port is a routed port and in port security mode. The address is deleted if the port exits the security mode or is not a routed port.

This command is required because the **bridge address** command cannot be executed on internal VLANs.

EXAMPLE

The following example adds the MAC-layer address 66:66:66:66:66:66 to tengigabitethernet port 0/1.

```
Console(config)# interface tengigabitethernet 0/1
Console(config-if)# port security routed secure-address 66:66:66:66:66:66
```

show mac address-table Use the **show mac address-table** EXEC command to view entries in the MAC address table.

SYNTAX

show mac address-table [*dynamic | static | secure*] [*vlan vlan*]
 [*interface interface-id*] [*address mac-address*]

PARAMETERS

- ◆ **dynamic**—Displays only dynamic MAC address table entries.
- ◆ **static**—Displays only static MAC address table entries.
- ◆ **secure**—Displays only secure MAC address table entries.

- ◆ **vlan**—Specifies VLAN, such as VLAN 1.
- ◆ **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.
- ◆ **mac-address**—MAC address.

DEFAULT

COMMAND MODE

EXEC mode

USER GUIDELINES

Internal usage VLANs (VLANs that are automatically allocated on routed ports) are presented in the VLAN column by a port number and not by a VLAN ID.

EXAMPLE

```
Console# show mac address-table
```

```
Aging time is 300 sec
```

VLAN	MAC Address	Port	Type
1	00:00:26:08:13:23	0	self
1	00:3f:bd:45:5a:b1	te1	static
1	00:a1:b0:69:63:f3	te24	dynamic
2	00:a1:b0:69:63:f3	te24	dynamic

```
Console# show mac address-table 00:3f:bd:45:5a:b1
```

```
Aging time is 300 sec
```

VLAN	MAC Address	Port	Type
1	00:3f:bd:45:5a:b1		static

show mac address-table count Use the **show mac address-table count** EXEC mode command to display the number of addresses present in the Forwarding Database.

SYNTAX

show mac address-table count [*vlan vlan* | *interface interface-id*]

PARAMETERS

- ◆ **vlan**—Specifies VLAN.
- ◆ **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

```

Console# show mac address-table count

Capacity: 8192
Free: 8083
Used: 109

Static addresses: 2
Secure addresses: 1
Dynamic addresses: 97
Internal addresses: 9

```

show bridge multicast mode Use the **show bridge multicast mode** EXEC mode command to display the multicast bridging mode for all VLANs or for a specific VLAN.

SYNTAX

show bridge multicast mode [*vlan vlan-id*]

PARAMETERS

vlan vlan-id—Specifies the VLAN ID.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the multicast bridging mode for all VLANs.

```

Console# show bridge multicast mode

VLAN      IPv4 Multicast mode      IPv6 Multicast mode
          Admin            Oper            Admin            Oper
----      -
1         MAC-GROUP          MAC-GROUP      MAC-GROUP          MAC-GROUP
11        IPv4-GROUP           IPv4-GROUP     IPv6-GROUP          IPv6-GROUP
12        IPv4-SRC-GROUP        IPv4-SRC-GROUP IPv6-SRC-GROUP      IPv6-SRC-GROUP

```

show bridge multicast address-table Use the **show bridge multicast address-table** EXEC mode command to display multicast MAC address or IP address table information.

SYNTAX

show bridge multicast address-table [*vlan vlan-id*] [*address {mac-multicast-address | ipv4-multicast-address | ipv6-multicast-address}*] [*format {ip | mac}*] [*source {ipv4-source-address | ipv6-source-address}*]

PARAMETERS

◆ **vlan vlan-id**—Specifies the VLAN ID.

- ◆ **address {mac-multicast-address | ipv4-multicast-address | ipv6-multicast-address}**—Specifies the multicast address. The possible values are:
 - ◆ **mac-multicast-address**—Specifies the MAC multicast address.
 - ◆ **ipv4-multicast-address**—Specifies the IPv4 multicast address.
 - ◆ **ipv6-multicast-address**—Specifies the IPv6 multicast address.
- ◆ **format {ip | mac}**—Specifies the multicast address format. The possible values are:
 - ◆ **ip**—Specifies that the multicast address is an IP address.
 - ◆ **mac**—Specifies that the multicast address is a MAC address.
- ◆ **source {ipv4-source-address | ipv6-source-address}**—Specifies the source address. The possible values are:
 - **ipv4-address**—Specifies the source IPv4 address.
 - **ipv6-address**—Specifies the source IPv6 address.

DEFAULT CONFIGURATION

If the format is not specified, it defaults to mac.

COMMAND MODE

EXEC mode

USER GUIDELINES

A MAC address can be displayed in IP format only if it is within the range 0100.5e00.0000 through 0100.5e7f.ffff.

Multicast Router ports (defined statically or discovered dynamically) are members in all MC groups.

Ports that were defined via **bridge multicast forbidden forward-all** command are displayed in all forbidden MC entries.

EXAMPLE

The following example displays bridge multicast address information.

```
Console# show bridge multicast address-table
```

```
Multicast address table for VLANs in MAC-GROUP bridging mode:
```

Vlan	MAC Address	Type	Ports
8	01:00:5e:02:02:03	Static	1-2

```
Forbidden ports for multicast addresses:
```


Vlan	MAC Address	Ports
8	01:00:5e:02:02:03	te9

Multicast address table for VLANs in IPv4-GROUP bridging mode:

Vlan	MAC Address	Type	Ports
1	224.0.0.251	Dynamic	te12

Forbidden ports for multicast addresses:

Vlan	MAC Address	Ports
1	232.5.6.5	
1	233.22.2.6	

Multicast address table for VLANs in IPv4-SRC-GROUP bridging mode:

Vlan	Group Address	Source address	Type	Ports
1	224.2.2.251	11.2.2.3	Dynamic	te11

Forbidden ports for multicast addresses:

Vlan	Group Address	Source Address	Ports
8	239.2.2.2	*	te9
8	239.2.2.2	1.1.1.11	te9

Multicast address table for VLANs in IPv6-GROUP bridging mode:

VLAN	IP/MAC Address	Type	Ports
8	ff02::4:4:4	Static	te1-2, te7, Po1

Forbidden ports for multicast addresses:

VLAN	IP/MAC Address	Ports
8	ff02::4:4:4	te9

Multicast address table for VLANs in IPv6-SRC-GROUP bridging mode:

Vlan	Group Address	Source address	Type	Ports
8	ff02::4:4:4	*	Static	te1-2, te7, Po1
8	ff02::4:4:4	fe80::200:7ff:fe00:200	Static	

Forbidden ports for multicast addresses:

Vlan	Group Address	Source address	Ports
8	ff02::4:4:4	*	te9
8	ff02::4:4:4	fe80::200:7ff:fe00:200	te9

show bridge multicast address-table static Use the **show bridge multicast address-table static** EXEC mode command to display the statically configured multicast addresses.

SYNTAX

show bridge multicast address-table static [*vlan vlan-id*] [*address mac-multicast-address | ipv4-multicast-address | ipv6-multicast-address*] [*source ipv4-source-address | ipv6-source-address*] [*all | mac | ip*]

PARAMETERS

- ◆ **vlan vlan-id**—Specifies the VLAN ID.
- ◆ **address {mac-multicast-address | ipv4-multicast-address | ipv6-multicast-address}**—Specifies the multicast address. The possible values are:
 - **mac-multicast-address**—Specifies the MAC multicast address.
 - **ipv4-multicast-address**—Specifies the IPv4 multicast address.
 - **ipv6-multicast-address**—Specifies the IPv6 multicast address.
- ◆ **source {ipv4-source-address | ipv6-source-address}**—Specifies the source address. The possible values are:
 - **ipv4-address**—Specifies the source IPv4 address.
 - **ipv6-address**—Specifies the source IPv6 address.

DEFAULT CONFIGURATION

When all/mac/ip is not specified, all entries (mac and ip) will be displayed.

COMMAND MODE

EXEC mode

USER GUIDELINES

A MAC address can be displayed in IP format only if it is within the range 0100.5e00.0000-- 0100.5e7f.ffff.

EXAMPLE

The following example displays the statically configured multicast addresses.

```
Console# show bridge multicast address-table static
```

```
MAC-GROUP table
```

Vlan	MAC Address	Ports
1	0100.9923.8787	te1, te2

Forbidden ports for multicast addresses:

Vlan	MAC Address	Ports
----	-----	-----

IPv4-GROUP Table

Vlan	IP Address	Ports
----	-----	-----
1	231.2.2.3	te1, te2
19	231.2.2.8	te1-8
19	231.2.2.8	te9-11

Forbidden ports for multicast addresses:

Vlan	IP Address	Ports
----	-----	-----
1	231.2.2.3	te8
19	231.2.2.8	te8

IPv4-SRC-GROUP Table:

Vlan	Group Address	Source address	Ports
----	-----	-----	-----

Forbidden ports for multicast addresses:

Vlan	Group Address	Source address	Ports
----	-----	-----	-----

IPv6-GROUP Table

Vlan	IP Address	Ports
----	-----	-----
191	FF12::8	te1-8

Forbidden ports for multicast addresses:

Vlan	IP Address	Ports
----	-----	-----
11	FF12::3	te8
191	FF12::8	te8

IPv6-SRC-GROUP Table:

Vlan	Group Address	Source address	Ports
----	-----	-----	-----
192	FF12::8	FE80::201:C9A9:FE40:8988	te1-8

Forbidden ports for multicast addresses:

Vlan	Group Address	Source address	Ports
----	-----	-----	-----
192	FF12::3	FE80::201:C9A9:FE40:8988	te8

show bridge multicast filtering Use the **show bridge multicast filtering** EXEC mode command to display the multicast filtering configuration.

SYNTAX

show bridge multicast filtering *vlan-id*

PARAMETERS

vlan-id—Specifies the VLAN ID. (Range: Valid VLAN)

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the multicast configuration for VLAN 1.

```

Console# show bridge multicast filtering 1

Filtering: Enabled

VLAN: 1

Port          Forward-All Static   Status
-----
te1           Forbidden         Filter
te2           Forward           Forward(s)
te3           -                 Forward(d)

```

show bridge multicast unregistered Use the **show bridge multicast unregistered** EXEC mode command to display the unregistered multicast filtering configuration.

SYNTAX

show bridge multicast unregistered [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the unregistered multicast configuration.

```
Console# show bridge multicast unregistered
```

Port	Unregistered
te1	Forward
te2	Filter
te3	Filter

show ports security Use the **show ports security** Privileged EXEC mode command to display the port-lock status.

SYNTAX

show ports security [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the port-lock status of all ports.

```
console# show ports security
```

Port	Status	Learning	Action	Max	Trap	Frequency
te1	Enabled	Max- Addresses	Discard	3	Enabled	100
te2	Disabled	Max- Addresses	-	28	-	-
te3	Enabled	Lock	Discard, Shutdown	8	Disabled	-

The following table describes the fields shown above.

Field	Description
Port	The port number.
Status	The port security status. The possible values are: Enabled or Disabled.
Mode	The port security mode.

Field	Description
Action	The action taken on violation.
Maximum	The maximum number of addresses that can be associated on this port in the Max-Addresses mode.
Trap	The status of SNMP traps. The possible values are: Enable or Disable.
Frequency	The minimum time interval between consecutive traps.

show ports security addresses Use the **show ports security addresses** Privileged EXEC mode command to display the current dynamic addresses in locked ports.

SYNTAX

show ports security addresses [*interface-id*

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays dynamic addresses in all currently locked ports.

```
Console# show ports security addresses
```

Port	Status	Learning	Current	Maximum
----	-----	-----	-----	-----
te1	Enabled	Max-addresses	2	3
te2	Disabled	Max-addresses	-	128
te3	Enabled	Lock	NA	NA

port monitor Use the **port monitor** Interface Configuration (Ethernet) mode command to start a port monitoring session. Use the **no** form of this command to stop a port monitoring session.

SYNTAX

port monitor *src-interface-id* [*rx* | *tx*]

no port monitor *src-interface-id*

port monitor *vlan* *vlan-id*

no port monitor *vlan* *vlan-id*

PARAMETERS

- ◆ **rx**—Monitors received packets only. If no option is specified, it monitors both rx and tx.
- ◆ **tx**—Monitors transmitted packets only. If no option is specified, it monitors both rx and tx.
- ◆ **vlan vlan-id**—VLAN number
- ◆ **src-interface-id**—Specifies an interface ID. The interface ID must be an Ethernet port.

DEFAULT CONFIGURATION

Monitors both received and transmitted packets.

COMMAND MODE

Interface Configuration (Ethernet) mode. It cannot be configured for a range of interfaces (range context).

USER GUIDELINES

This command enables port copy between Source Port (src-interface) to a Destination Port (The port in context).

The analyzer port for port ingress traffic mirroring should be the same port for all mirrored ports.

The analyzer port for port egress traffic mirroring should be the same port for all mirrored ports.

The analyzer port for VLAN mirroring should be the same for all the mirrored VLANs, and should be the same port as the analyzer port for port ingress mirroring traffic.

Following are restrictions apply for ports that are configured to be source ports:

- ◆ The port cannot be a destination port.

The following restrictions apply to ports that are configured to be monitor ports:

- ◆ The port can't be source port.
- ◆ The port isn't member in port-channel.
- ◆ IP interface is not configured on the port.
- ◆ GVRP is not enabled on the port.
- ◆ The port is not a member in any VLAN, except for the default VLAN (will be automatically removed from the default VLAN).
- ◆ L2 protocols are not active on the copy dest. Port: LLDP, LBD, STP, LACP.

The following restrictions apply to ports that are configured to be monitor ports:

- ◆ The port cannot be source port.
- ◆ The port is not a member in port-channel.



NOTE: In this mode some traffic duplication on the analyzer port may be observed. For example:

- Port 2 is being egress monitored by port 4.
- Port 2 & 4 are members in VLAN 3.
- Unknown Unicast packet sent to VLAN 3 will egress from port 4 twice, one instance as normal forward and another instance as mirrored from port 2.
- Moreover, if port 2 is an untagged member in VLAN 3 and port 4 is a tagged member then both instances will look different (one tagged and the other is not).

NOTE: When the port is configured to 802.1X auto mode it will forward any mirrored traffic regardless of the .1X state. However, it will operate as a normal network port (forward traffic) only after authorization is done.

NOTE: Mirrored traffic is exposed to STP state, i.e. if the port is in STP blocking, it will not egress any mirrored traffic.

EXAMPLE

The following example copies traffic for both directions (Tx and Rx) from the source port 2 to destination port 1.

```
Console(config)# interface te1
Console(config-if)# port monitor te2
```

show ports monitor Use the **show ports monitor** EXEC mode command to display the port monitoring status.

SYNTAX

show ports monitor

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the port monitoring status.

```
Console# show ports monitor
Port monitor mode: Monitor-only
Source port      Destination Port      Type      Status
-----
te8              te1                  RX, TX    Active
te2              te1                  RX, TX    Active
te18             te1                  Rx        Active
VLAN 9           te1                  N/A      Active
```

port monitor mode Use the **port monitor mode** Global Configuration mode command to define the monitoring mode. Use the **no** form of this command to return to default.

SYNTAX

port monitor mode {*monitor-only* | *network*}
no port monitor mode

PARAMETERS

- ◆ **monitor-only**—Specifies that the monitor port acts only as a monitor port. Other network traffic is discarded at ingress and egress.
- ◆ **network**—Specifies that the monitor port acts also as a network port.

DEFAULT CONFIGURATION

Product-specific

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Once the port monitor mode is defined, no changing between modes is allowed. Any mode change will have to first go through un-defining the monitor port.

EXAMPLE

```
console(config)# port monitor mode network
```

sflow receiver Use the **sflow receiver** Global Configuration mode command to define sFlow collector. Use the **no** form of this command to remove the definition of the collector.

SYNTAX

sflow receiver *index* {*ipv4-address* | *ipv6-address* | *hostname*} [*port* *port*] [*max-datagram-size bytes*]

no sflow receiver *index*

PARAMETERS

- ◆ **index**—The index of the receiver. (Range: 1–8)
- ◆ **ipv4-address**—Pv4 address of the host to be used as an sFlow Collector.
- ◆ **ipv6-address**—IPv6 address of the host to be used as an sFlow Collector. When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. Refer to the User Guidelines for the interface name syntax.
- ◆ **hostname**—Hostname of the host to be used as an sFlow Collector. Only translation to IPv4 addresses is supported.
- ◆ **port**—Port number for syslog messages. If unspecified, the port number defaults to 6343. The range is 1-65535.
- ◆ **bytes**—Specifies the maximum number of bytes that can be sent in a single sample datagram. If unspecified, it defaults to 1400.

DEFAULT

No receiver is defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

If the IP address of the sFlow receiver is set to 0.0.0.0, no sFlow datagrams are sent.

sflow flow-sampling Use the **sflow flow-sampling** Interface Configuration mode command to enable sFlow Flow sampling and configure the average sampling rate of a specific port. Use the **no** form of this command to disable Flow sampling.

SYNTAX

sflow flow-sampling *rate receiver-index [max-header-size bytes]*
no sflow flow-sampling

PARAMETERS

- ◆ **rate**—Specifies the average sampling rate (Range: 1, 1024–1073741823.)
- ◆ **receiver-index**—Index of the receiver/collector (Range: 1–8.)
- ◆ **bytes**—Specifies the maximum number of bytes that would be copied from the sampled packet. If unspecified, defaults to 128. (Range: 20–256.)

DEFAULT

Disabled

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

A new sampling rate configuration is not immediately loaded to the hardware. It will be loaded to the hardware only after the next packet is sampled (based on the current sampling rate).

sflow counters-sampling Use the **sflow counters-sampling** Interface Configuration mode command to enable sFlow Counters sampling and to configure the maximum interval of a specific port. Use the **no** form of this command to disable sFlow Counters sampling.

SYNTAX

sflow counters-sampling *interval receiver-index*
no sflow counters-sampling

PARAMETERS

- ◆ **interval**—Specifies the maximum number of seconds between successive samples of the interface counters. (Range: 1, 15–86400.)
- ◆ **receiver-index**—Index of the receiver/collector. (Range: 1–8.)

DEFAULT

Disabled

COMMAND MODE

Interface Configuration (Ethernet) mode

clear sflow statistics Use the **clear sFlow statistics** EXEC mode command to clear sFlow statistics.

SYNTAX**clear sflow statistics** [*interface-id*]**PARAMETERS**

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

EXEC mode

USER GUIDELINES

If no interface is specified by the user, the command clears all the sFlow statistics counters (including datagrams sent). If an interface is specified by the user, the command clears only the counter of the specific interface.

show sflow configuration Use the **show sflow configuration** EXEC mode command to display the sFlow configuration for ports that are enabled for Flow sampling or Counters sampling.

SYNTAX**show sflow configuration** [*interface-id*]**PARAMETERS**

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

EXEC mode

EXAMPLE

```
Console # show sflow configuration
```

```
Receivers
```

Index	IP Address	Port	Max Datagram Size
1	0.0.0.0	6343	1400
2	172.16.1.2	6343	1400
3	0.0.0.0	6343	1400
4	0.0.0.0	6343	1400
5	0.0.0.0	6343	1400
6	0.0.0.0	6343	1400
7	0.0.0.0	6343	1400
8	0.0.0.0	6343	1400

```
Interfaces
```

Inter-	Flow	Counters	Max Header Flow	Counters Collector
--------	------	----------	-----------------	--------------------

face	Sampling	Sampling	Size	Collector	Index	Index
-----	-----	-----	-----	-----	-----	-----
te1	1/2048	60 sec	128	1		1
te2	1/4096	Disabled	128	0		2

show sflow statistics Use the **show sflow statistics** EXEC mode command to display the sFlow statistics for ports that are enabled for Flow sampling or Counters sampling.

SYNTAX

show sflow statistics [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

EXEC mode

EXAMPLE

```

Console # show sflow statistics
Total sFlow datagrams sent to collectors: 100

Interface      Packets sampled      datagrams sent to collector
-----
1/1            30                   50
1/2            10                   10
1/3            0                    10
1/4            0                    0

```

LINK LAYER DISCOVERY PROTOCOL (LLDP) COMMANDS

iPECS ES-5048XG

lldp run Use the **lldp run** Global Configuration mode command to enable Link Layer Discovery Protocol (LLDP). To disable LLDP, use the **no** form of this command.

SYNTAX

lldp run
no lldp run

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Enabled

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# lldp run
```

lldp transmit Use the **lldp transmit** Interface Configuration mode command to enable transmitting Link Layer Discovery Protocol (LLDP) on an interface. Use the **no** form of this command to stop transmitting LLDP on an interface.

SYNTAX

lldp transmit
no lldp transmit

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Enabled

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

LLDP manages LAG ports individually. LLDP sends separate advertisements on each port in a LAG.

LLDP operation on a port is not dependent on the STP state of a port. I.e. LLDP frames are sent on blocked ports.

If a port is controlled by 802.1X, LLDP would operate only if the port is authorized.

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# lldp transmit
```

lldp receive Use the **lldp receive** Interface Configuration mode command to enable receiving Link Layer Discovery Protocol (LLDP) on an interface. Use the **no** form of this command to stop receiving LLDP on an interface.

SYNTAX

lldp receive

no lldp receive

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Enabled

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

LLDP manages LAG ports individually. LLDP data received through LAG ports is stored individually per port.

LLDP operation on a port is not dependent on the STP state of a port. I.e. LLDP frames are received on blocked ports.

If a port is controlled by 802.1X, LLDP would operate only if the port is authorized.

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# lldp receive
```


lldp timer Use the **lldp timer** Global Configuration mode command to specify how often the software sends Link Layer Discovery Protocol (LLDP) updates. Use the **no** form of this command to restore the default configuration.

SYNTAX

lldp timer *seconds*

no lldp timer

PARAMETERS

seconds—Specifies, in seconds, how often the software sends LLDP updates. (Range: 5?32768 seconds)

DEFAULT CONFIGURATION

The default update interval is 30 seconds.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example sets the interval for sending LLDP updates to 60 seconds.

```
Console(config)# lldp timer 60
```

lldp hold-multiplier Use the **lldp hold-multiplier** Global Configuration mode command to set the time interval during which the receiving device holds a Link Layer Discovery Protocol (LLDP) packet before discarding it. Use the **no** form of this command to restore the default configuration.

SYNTAX

lldp hold-multiplier *number*

no lldp hold-multiplier

PARAMETERS

number—Specifies the LLDP packet hold time interval as a multiple of the LLDP timer value. (Range: 2use the **no** form of this command10)

DEFAULT CONFIGURATION

The default LLDP hold multiplier is 4.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The actual Time-To-Live (TTL) value of LLDP frames is expressed by the following formula:

$$\text{TTL} = \min(65535, \text{LLDP-Timer} * \text{LLDP-HoldMultiplier})$$

For example, if the value of the LLDP timer is 30 seconds, and the value of the LLDP hold multiplier is 4, then the value 120 is encoded in the TTL field of the LLDP header.

EXAMPLE

The following example sets the LLDP packet hold time interval to 90 seconds.

```
Console(config)# lldp timer 30
Console(config)# lldp hold-multiplier 3
```

lldp reinit Use the **lldp reinit** Global Configuration mode command to specify the minimum time an LLDP port waits before reinitializing LLDP transmission. Use the **no** form of this command to revert to the default setting.

SYNTAX

lldp reinit seconds

no lldp reinit

PARAMETERS

seconds—Specifies the minimum time in seconds an LLDP port waits before reinitializing LLDP transmission.(Range: 1–10)

DEFAULT

2 seconds

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# lldp reinit 4
```

lldp tx-delay Use the **lldp tx-delay** Global Configuration mode command to set the delay between successive LLDP frame transmissions initiated by value/status changes in the LLDP local systems MIB. Use the **no** form of this command to restore the default configuration.

SYNTAX

lldp tx-delay seconds

no lldp tx-delay

PARAMETERS

seconds—Specifies the delay in seconds between successive LLDP frame transmissions initiated by value/status changes in the LLDP local systems MIB. (Range: 1?8192 seconds)

DEFAULT CONFIGURATION

The default LLDP frame transmission delay is 2 seconds.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

It is recommended that the tx-delay be less than 0.25 of the LLDP timer interval.

EXAMPLE

The following example sets the LLDP transmission delay to 10 seconds.

```
Console(config)# lldp tx-delay 10
```

lldp optional-tlv Use the **lldp optional-tlv** Interface Configuration (Ethernet) mode command to specify which optional TLVs from the basic set are transmitted. Use the **no** form of this command to restore the default configuration.

SYNTAX

lldp optional-tlv *tlv* [*tlv2* ... *tlv5*]

no lldp optional-tlv

PARAMETERS

tlv—Specifies TLV that should be included. Available optional TLVs are: port-desc, sys-name, sys-desc, sys-cap, 802.3-mac-phy, 802.3-lag, 802.3-max-frame-size.

DEFAULT CONFIGURATION

No optional TLV is transmitted.

COMMAND MODE

Interface Configuration (Ethernet) mode

EXAMPLE

The following example specifies that the port description TLV is transmitted on tengigabitethernet port 0/2.

```
Console(config)# interface tengigabitethernet 0/2
Console(config-if)# lldp optional-tlv port-desc
```

lldp management-address Use the **lldp management-address** Interface Configuration (Ethernet) mode command to specify the management address advertised from an interface. Use the **no** form of this command to stop advertising management address information.

SYNTAX

lldp management-address {*ip-address* | *none* | *automatic* [*interface-id*] }

no lldp management-address

PARAMETERS

- ◆ **ip-address**—Specifies the static management address to advertise.
- ◆ **none**—Specifies that no address is advertised.
- ◆ **automatic**—Specifies that the software would automatically choose a management address to advertise from all the IP addresses of the product. In case of multiple IP addresses the software chooses the lowest IP address among the dynamic IP addresses. If there are no dynamic addresses, the software chooses the lowest IP address among the static IP addresses.
- ◆ **automatic interface-id**—Specifies that the software automatically chooses a management address to advertise from the IP addresses that are configured (associated) for the interface ID. In case of multiple IP addresses, the software chooses the lowest IP address among the dynamic IP addresses of the interface. If there are no dynamic addresses, the software chooses the lowest IP address among the static IP addresses of the interface. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN. Note that if the port or port-channel are members in a VLAN that has an IP address, that address is not included because the address is associated with the VLAN.

DEFAULT CONFIGURATION

No IP address is advertised.

The default advertisement is **automatic**.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

Each port can advertise one IP address.

EXAMPLE

The following example sets the LLDP management address advertisement mode to **automatic** on tengigabitethernet port 0/2.

```
Console(config)# interface tengigabitethernet 0/2
Console(config)# lldp management-address automatic
```

Ildp notifications Use the **Ildp notifications** Interface Configuration (Ethernet) mode command to enable or disable sending Link Layer Discovery Protocol (LLDP) notifications on an interface. Use the **no** form of this command to restore the default configuration.

SYNTAX

Ildp notifications {*enable* | *disable*}

no Ildp notifications

PARAMETERS

- ◆ **enable**—Enables sending LLDP notifications.
- ◆ **disable**—Disables sending LLDP notifications.

DEFAULT CONFIGURATION

Sending LLDP notifications is disabled.

COMMAND MODE

Interface Configuration (Ethernet) mode

EXAMPLE

The following example enables sending LLDP notifications on tengigabitethernet port 0/5.

```
Console(config)# interface tengigabitethernet 0/5
Console(config)# lldp notifications 10
```

Ildp notifications interval Use the **Ildp notifications interval** Global Configuration mode command to configure the maximum transmission rate of LLDP notifications. Use the **no** form of this command to return to the default.

SYNTAX

Ildp notifications interval *seconds*

no Ildp notifications interval

PARAMETERS

seconds—The device should not send more than one notification in the indicated period. (Range: 5–3600)

DEFAULT

5 seconds

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# lldp notification interval 10
```

Ildp optional-tlv 802.1 Use the **lldp optional-tlv** Interface Configuration mode command to specify which optional TLVs from the basic set to transmit. Use the **no** form of this command revert to the default setting.

SYNTAX**lldp optional-tlv 802.1** *pvid***no lldp optional-tlv 802.1** *pvid***lldp optional-tlv 802.1 ppvid add** *ppvid***lldp optional-tlv 802.1 ppvid remove** *ppvid***lldp optional-tlv 802.1 vlan-name add** *vlan-id***lldp optional-tlv 802.1 vlan-name remove** *vlan-id***lldp optional-tlv 802.1 protocol add** {*stp* | *rstp* | *mstp* | *pause* | *802.1x* | *lacp* | *gvrp*}**lldp optional-tlv 802.1 protocol remove** {*stp* | *rstp* | *mstp* | *pause* | *802.1x* | *lacp* | *gvrp*}**PARAMETERS***pvid*—Advertises the PVID of the port.

- ◆ *ppvid*—Adds/removes PPVID for advertising. PPVID 0 can be used to advertise the PPVIDs capabilities of the interface.(Range: 0–4094)
- ◆ *vlan*—Adds/removse VLAN ID for advertising. (Range: 1–4094)

DEFAULT

No optional TLV is transmitted.

COMMAND MODE

Interface Configuration (Ethernet) mode

lldp med enable Use the **lldp med enable** Interface Configuration (Ethernet) mode command to enable Link Layer Discovery Protocol (LLDP) Media Endpoint Discovery (MED) on an interface. Use the **no** form of this command to disable LLDP MED on an interface.

SYNTAX

lldp med enable [*tlv ... tlv4*]

no lldp med enable

PARAMETERS

tlv—Specifies the TLV that should be included. Available TLVs are: network-policy, location, and poe-pse, inventory. The capabilities TLV is always included if LLDP-MED is enabled.

DEFAULT CONFIGURATION

LLDP MED is disabled.

COMMAND MODE

Interface Configuration (Ethernet) mode

EXAMPLE

The following example enables LLDP MED with the **location** TLV on tengigabitethernet port 0/3.

```
Console(config)# interface tengigabitethernet 0/3
Console(config)# lldp med enable location
```

lldp med notifications topology-change Use the **lldp med notifications topology-change** Interface Configuration (Ethernet) mode command to enable sending LLDP MED topology change notifications. Use the **no** form of this command to restore the default configuration.

SYNTAX

lldp med notifications topology-change {*enable* | *disable*}

no lldp med notifications topology-change

PARAMETERS

◆ **enable**—Enables sending LLDP MED topology change notifications.

◆ **disable**—Disables sending LLDP MED topology change notifications.

DEFAULT CONFIGURATION

Disable is the default.

COMMAND MODE

Interface Configuration (Ethernet) mode

EXAMPLE

The following example enables sending LLDP MED topology change notifications on tengigabitethernet port 0/2.

```
Console(config)# interface tengigabitethernet 0/2
Console(config)# lldp med notifications topology-change enable
```

lldp med fast-start repeat-count

Use the **lldp med fast-start repeat-count** Global Configuration mode command to configure the number of times the fast start LLDPDU is being sent during the activation of the fast start mechanism defined by LLDP-MED. Use the **no** form of this command return to default.

SYNTAX

lldp med fast-start repeat-count *number*

no lldp med fast-start repeat-count

PARAMETERS

number—Specifies the number of times the fast start LLDPDU is being sent during the activation of the fast start mechanism.

DEFAULT

3

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# lldp med fast-start repeat-count 4
```

lldp med network-policy (global)

Use the **lldp med network-policy** Global Configuration mode command to define LLDP MED network policy. Use the **no** form of this command to remove LLDP MED network policy.

SYNTAX

lldp med network-policy *number application [vlan id] [vlan-type {tagged | untagged}] [up priority] [dscp value]*

no lldp med network-policy *number*

PARAMETERS

- ◆ **number**—Network policy sequential number.
- ◆ **application**—The name or the number of the primary function of the application defined for this network policy. Available application names

are: voice, voice-signaling, guest-voice, guest-voice-signaling, softphone-voice, video-conferencing, streaming-video, video-signaling.

- ◆ **vlan id**—VLAN identifier for the application.
- ◆ **vlan-type**—Specifies if the application is using a Tagged or an Untagged VLAN.
- ◆ **up priority**—User Priority (Layer 2 priority) to be used for the specified application.
- ◆ **dscp value**—DSCP value to be used for the specified application.

DEFAULT

No Network policy is defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use the **lldp med network-policy** Interface Configuration command to attach a network policy to a port.

Up to 32 network policies can be defined.

EXAMPLE

```
console(config)# lldp med network-policy 1 voice-signaling vlan 1
```

lldp med network-policy (interface)

Use the **lldp med network-policy** Interface Configuration (Ethernet) mode command to attach or remove an LLDP MED network policy on an interface. Use the **no** form of this command to remove all the LLDP MED network policies from the interface.

SYNTAX

```
lldp med network-policy {add | remove} number
no lldp med network-policy number
```

PARAMETERS

- ◆ **number**—Specifies the network policy sequential number.
- ◆ **add**—Attaches the specified network policy to the interface.
- ◆ **remove**—Removes the specified network policy from the interface.

DEFAULT CONFIGURATION

No network policy is attached to the interface.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

For each port, only one network policy per application (voice, voice-signaling, etc.) can be defined.

EXAMPLE

The following example attaches LLDP MED network policy 1 to tengigabitethernet port 0/1.

```
Console(config)# interface tengigabitethernet 0/1
Console(config-if)# lldp med network-policy add 1
```

clear lldp table Use the **clear lldp table** command in Privileged EXEC mode to restart the LLDP RX state machine and clear the neighbors table.

SYNTAX

clear lldp table *[interface-id]*

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

```
console# clear lldp table tengigabitethernet 0/1
```

lldp med location Use the **lldp med location** Interface Configuration (Ethernet) mode command to configure the location information for the Link Layer Discovery Protocol (LLDP) Media Endpoint Discovery (MED) for an interface. Use the **no** form of this command to delete location information for an interface.

SYNTAX

lldp med location *{ {coordinate data} | {civic-address data} | {ecs-elin data} }*

no lldp med location *{coordinate | civic-address | ecs-elin}*

PARAMETERS

- ◆ **coordinate**—Specifies the location data as coordinates.
- ◆ **civic-address**—Specifies the location data as a civic address.

- ◆ **ecs-elin**—Specifies the location data as an Emergency Call Service Emergency Location Identification Number (ECS ELIN).
- ◆ **data**—Specifies the location data in the format defined in ANSI/TIA 1057: dotted hexadecimal data: Each byte in a hexadecimal character string is two hexadecimal digits. Bytes are separated by a period or colon. (Length: coordinate: 16 bytes. Civic-address: 6-160 bytes. Ecs-elin: 10-25 bytes)

DEFAULT CONFIGURATION

The location is not configured.

COMMAND MODE

Interface Configuration (Ethernet) mode

EXAMPLE

The following example configures the LLDP MED location information on tengigabitethernet port 0/2 as a civic address.

```
console(config)# interface te2
console(config-if)# lldp med location civic-address 616263646566
```

show lldp configuration

Use the **show lldp configuration** Privileged EXEC mode command to display the Link Layer Discovery Protocol (LLDP) configuration for all interfaces or for a specific interface.

SYNTAX

show lldp configuration [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example sets the LLDP re-initialization delay to 10 seconds.

```
Switch# show lldp configuration
State: Enabled
Timer: 30 Seconds
Hold multiplier: 4
Reinit delay: 2 Seconds
Tx delay: 2 Seconds
Notifications interval: 5 seconds

LLDP packets handling: Filtering

Port      State  Optional TLVs  Address  Notifications
```

```

-----
te1  RX,TX PD, SN, SD, SC      172.16.1.1    Disabled
te2  TX      PD, SN           172.16.1.1    Disabled
te3  RX,TX PD, SN, SD, SC      None          Disabled
te5  RX,TX D, SN, SD, SC       automatic     Disabled
te6  RX,TX PD, SN, SD, SC      auto vlan 1   Disabled
te7  RX,TX PD, SN, SD, SC      auto g1       Disabled
te8              RX,TX PD, SN, SD, SC      auto ch1     Disabled
Switch# show lldp configuration tel
State: Enabled
Timer: 30 Seconds
Hold multiplier: 4
Reinit delay: 2 Seconds
Tx delay: 2 Seconds
Notifications interval: 5 seconds
LLDP packets handling: Filtering

Port State      Optional TLVs      Address      Notifications
-----
tel  RX, TX      PD, SN, SD, SC      72.16.1.1    Disabled

802.3 optional TLVs: 802.3-mac-phy, 802.3-lag, 802.3-max-frame-size

802.1 optional TLVs
PVID: Enabled
PPVIDs: 0, 1, 92
VLANs: 1, 92
Protocols: 802.1x

```

The following table describes the significant fields shown in the display:

Field	Description
Timer	The time interval between LLDP updates.
Hold multiplier	The amount of time (as a multiple of the timer interval) that the receiving device holds a Link Layer Discovery Protocol (LLDP) packet before discarding it.
Reinit timer	The minimum time interval an LLDP port waits before re-initializing an LLDP transmission.
Tx delay	The delay between successive LLDP frame transmissions initiated by value/status changes in the LLDP local systems MIB.
Port	The port number.
State	The port's LLDP state.
Optional TLVs	Optional TLVs that are advertised. Possible values are: PD - Port description SN - System name SD - System description SC - System capabilities
Address	The management address that is advertised.
Notifications	Indicates whether LLDP notifications are enabled or disabled.

show lldp med configuration Use the **show lldp med configuration** Privileged EXEC mode command to display the Link Layer Discovery Protocol (LLDP) Media Endpoint Discovery (MED) configuration for all interfaces or for a specific interface.

SYNTAX

show lldp med configuration *[interface-id]*

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following examples display the LLDP MED configuration for all interfaces and for tengigabitethernet port 0/1.

EXAMPLE

The following examples display the LLDP MED configuration for all interfaces and for tengigabitethernet port 0/1.

```
console# show lldp med configuration
```

```
Fast Start Repeat Count: 4.
```

```
Network policy 1
```

```
-----
```

```
Application type: voiceSignaling
```

```
VLAN ID: 1 untagged
```

```
Layer 2 priority: 0
```

```
DSCP: 0
```

Port	Capabilities	Network policy	Location	Notifications	Inventory
te1	Yes	Yes	Yes	Enabled	Yes
te2	Yes	Yes	No	Enabled	No
te3	No	No	No	Enabled	No

```
console# show lldp med configuration tengigabitethernet 0/1
```

Port	Capabilities	Network policy	Location	Notifications	Inventory
te1	Yes	Yes	Yes	Enabled	Yes

```
Network policies:
```

```
Location:
```

```
Civic-address: 61:62:63:64:65:66
```

show lldp local tlvs-overloading Use the **show lldp local tlvs-overloading** EXEC mode command to display the status of TLVs overloading of the Link Layer Discovery Protocol (LLDP).

SYNTAX

show lldp local tlvs-overloading *[interface-id]*

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

EXEC mode

USER GUIDELINES

The command calculates the overloading status of the current LLDP configuration, and not for the last LLDP packet that was sent.

EXAMPLE

```
Switch# show lldp local tlvs-overloading
Ports with LLDP TLV overloading are: tel, te9
Switch# show lldp local tlvs-overloading
No LLDP TLV overloading.
Switch# show lldp local tlvs-overloading tel
TLVs Group          Bytes      Status
-----
Mandatory            31         Transmitted
LLDP-MED Capabilities  9         Transmitted
LLDP-MED Location    200        Transmitted
802.1 1360           Overloading

Total: 1600 bytes
Left: 100 bytes
```

show lldp local Use the **show lldp local** Privileged EXEC mode command to display the Link Layer Discovery Protocol (LLDP) information that is advertised from a specific port.

SYNTAX

show lldp local *interface-id*

PARAMETERS

Interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following examples display LLDP information that is advertised from tengigabitethernet ports 0/1 and 0/2.

```
Switch# show lldp local tel
Device ID: 0060.704C.73FF
Port ID: tel
Capabilities: Bridge
System Name: ts-7800-1
System description:
Port description:
Management address: 172.16.1.8
802.3 MAC/PHY Configuration/Status
Auto-negotiation support: Supported
Auto-negotiation status: Enabled
Auto-negotiation Advertised Capabilities: 100BASE-TX full duplex, 1000BASE-T
full duplex
Operational MAU type: 1000BaseTFD
802.3 Link Aggregation
Aggregation capability: Capable of being aggregated
Aggregation status: Not currently in aggregation
Aggregation port ID: 1
802.3 Maximum Frame Size: 1522

802.3 EEE
Local Tx: 30 usec
Local Rx: 25 usec
Remote Tx Echo: 30 usec
Remote Rx Echo: 25 usec

802.1 PVID: 1
802.1 PPVID: 2 supported, enabled
802.1 VLAN: 2 (VLAN2)
802.1 Protocol: 88 8E 01

LLDP-MED capabilities: Network Policy, Location Identification
LLDP-MED Device type: Network Connectivity
LLDP-MED Network policy
Application type: Voice
Flags: Tagged VLAN
VLAN ID: 2
Layer 2 priority: 0
DSCP: 0

LLDP-MED Power over Ethernet
Device Type: Power Sourcing Entity
Power source: Primary Power Source
Power priority: High
Power value: 9.6 Watts

LLDP-MED Location
Coordinates: 54:53:c1:f7:51:57:50:ba:5b:97:27:80:00:00:67:01

LLDP-MED Inventory
Hardware Revision: B1
Firmware Revision: A1
Software Revision: 3.8
Serial number: 7978399
Manufacturer name: Manufacturer
Model name: Model 1
Asset ID: Asset 123
```

```
Switch# show lldp local te2

LLDP is disabled.
```

show lldp neighbors Use the **show lldp neighbors** Privileged EXEC mode command to display information about neighboring devices discovered using Link Layer Discovery Protocol (LLDP). The information can be displayed for all interfaces or for a specific interface.

SYNTAX

show lldp neighbors *[interface-id]*

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

There are no guidelines for this command.

A TLV value that cannot be displayed as an ASCII string is displayed as an hexadecimal string.

EXAMPLE

The following examples display information about neighboring devices discovered using LLDP.

Location information, if it exists, is also displayed.

```
Switch# show lldp neighbors
```

Port	Device ID	Port ID	System Name	Capabilities	TTL
te1	00:00:00:11:11:11	te1	ts-7800-2	B	90
te1	00:00:00:11:11:11 D	te1	ts-7800-2	B	90
te2	00:00:26:08:13:24	te3	ts-7900-1	B, R	90
te3	00:00:26:08:13:24	te2	ts-7900-2	W	90

```
Switch# show lldp neighbors te1

Device ID: 00:00:00:11:11:11
Port ID: te
System Name: ts-7800-2
Capabilities: B
System description:
Port description:
Management address: 172.16.1.1
Time To Live: 90 seconds

802.3 MAC/PHY Configuration/Status
Auto-negotiation support: Supported.
Auto-negotiation status: Enabled.
```


Auto-negotiation Advertised Capabilities: 100BASE-TX full duplex, 1000BASE-T full duplex.

Operational MAU type: 1000BaseTFD

802.3 Power via MDI

MDI Power support Port Class: PD

PSE MDI Power Support: Not Supported

PSE MDI Power State: Not Enabled

PSE power pair control ability: Not supported.

PSE Power Pair: Signal

PSE Power class: 1

802.3 Link Aggregation

Aggregation capability: Capable of being aggregated

Aggregation status: Not currently in aggregation

Aggregation port ID: 1

802.3 Maximum Frame Size: 1522

802.3 EEE

Remote Tx: 25 usec

Remote Rx: 30 usec

Local Tx Echo: 30 usec

Local Rx Echo: 25 usec

802.1 PVID: 1

802.1 PPVID: 2 supported, enabled

802.1 VLAN: 2(VLAN2)

802.1 Protocol: 88 8E 01

LLDP-MED capabilities: Network Policy.

LLDP-MED Device type: Endpoint class 2.

LLDP-MED Network policy

Application type: Voice

Flags: Unknown policy

VLAN ID: 0

Layer 2 priority: 0

DSCP: 0

LLDP-MED Power over Ethernet

Device Type: Power Device

Power source: Primary power

Power priority: High

Power value: 9.6 Watts

LLDP-MED Inventory

Hardware revision: 2.1

Firmware revision: 2.3

Software revision: 2.7.1

Serial number: LM759846587

Manufacturer name: VP

Model name: TR12

Asset ID: 9

LLDP-MED Location

Coordinates: 54:53:c1:f7:51:57:50:ba:5b:97:27:80:00:00:67:01

The following table describes significant LLDP fields shown in the display:

Field	Description
Port	The port number.
Device ID	The neighbor device's configured ID (name) or MAC address.
Port ID	The neighbor device's port ID.
System name	The neighbor device's administratively assigned name.
Capabilities	The capabilities discovered on the neighbor device. Possible values are: B - Bridge R - Router W - WLAN Access Point T - Telephone D - DOCSIS cable device H - Host r - Repeater O - Other
System description	The neighbor device's system description.
Port description	The neighbor device's port description.
Management address	The neighbor device's management address.
Auto-negotiation support	The auto-negotiation support status on the port. (Supported or Not Supported)
Auto-negotiation status	The active status of auto-negotiation on the port. (Enabled or Disabled)
Auto-negotiation Advertised Capabilities	The port speed/duplex/flow-control capabilities advertised by the auto-negotiation.
Operational MAU type	The port MAU type.
LLDP MED	
Capabilities	The sender's LLDP-MED capabilities.
Device type	The device type. Indicates whether the sender is a Network Connectivity Device or Endpoint Device, and if an Endpoint, to which Endpoint Class it belongs.
LLDP MED - Network Policy	
Application type	The primary function of the application defined for this network policy.
Flags	Flags. The possible values are: Unknown policy: Policy is required by the device, but is currently unknown. Tagged VLAN: The specified application type is using a Tagged VLAN. Untagged VLAN: The specified application type is using an Untagged VLAN.
VLAN ID	The VLAN identifier for the application.
Layer 2 priority	The Layer 2 priority used for the specified application.
DSCP	The DSCP value used for the specified application.
LLDP MED - Power Over Ethernet	
Power type	The device power type. The possible values are: Power Sourcing Entity (PSE) or Power Device (PD).

Field	Description
Power Source	The power source utilized by a PSE or PD device. A PSE device advertises its power capability. The possible values are: Primary power source and Backup power source. A PD device advertises its power source. The possible values are: Primary power, Local power, Primary and Local power.
Power priority	The PD device priority. A PSE device advertises the power priority configured for the port. A PD device advertises the power priority configured for the device. The possible values are: Critical, High and Low.
Power value	The total power in watts required by a PD device from a PSE device, or the total power a PSE device is capable of sourcing over a maximum length cable based on its current configuration.
LLDP MED - Location	
Coordinates, Civic address, ECS ELIN.	The location information raw data.

show lldp statistics Use the **show lldp statistics** EXEC mode command to display the Link Layer Discovery Protocol (LLDP) statistics.

SYNTAX

show lldp statistics [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

EXEC mode

EXAMPLE

```
Switch# show lldp statistics
Contax(config-if)# do show lldp statistics
Tables Last Change Time: 14-Oct-2010 32:08:18
Tables Inserts: 26
Tables Deletes: 2
Tables Dropped: 0
Tables Ageouts: 1
```

	TX Frames		RX Frames		RX	TLVs
	RX Ageouts					
Port	Total	Total	Discarded	Errors	Discarded	Unrecognized
Total						
te1	730	850	0	0	0	0
	0					
te2	0	0	0	0	0	0
	0					
te3	730	0	0	0	0	0
	0					
te4	0	0	0	0	0	0
	0					
te5	0	0	0	0	0	0
	0					

te6	8	7	0	0	0	0
		1				
te/7	0	0	0	0	0	0
		0				
te8	0	0	0	0	0	0
		0				
te9	730	0	0	0	0	0
		0				
te10	0	0	0	0	0	0
		0				

spanning-tree Use the **spanning-tree** Global Configuration mode command to enable spanning-tree functionality. Use the **no** form of this command to disable the spanning-tree functionality.

SYNTAX

spanning-tree

no spanning-tree

DEFAULT CONFIGURATION

Spanning-tree is enabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables spanning-tree functionality.

```
Console(config)# spanning-tree
```

spanning-tree mode Use the **spanning-tree mode** Global Configuration mode command to configure the spanning-tree protocol currently running. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree mode {*stp* | *rstp* | *mst*}

no spanning-tree mode

PARAMETERS

- **stp**—Specifies that the Spanning Tree Protocol (STP) is enabled.
- **rstp**—Specifies that the Rapid Spanning Tree Protocol (RSTP) is enabled.
- **mst**—Specifies that the Multiple Spanning Tree Protocol (MSTP) is enabled.

DEFAULT CONFIGURATION

The default is RSTP.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

In RSTP mode, the device uses STP when the neighbor device uses STP.

In MSTP mode, the device uses RSTP when the neighbor device uses RSTP, and uses STP when the neighbor device uses STP.

EXAMPLE

The following example configures the spanning-tree protocol as RSTP.

```
console(config)# spanning-tree mode mstp
```

spanning-tree forward-time

Use the **spanning-tree forward-time** Global Configuration mode command to configure the spanning-tree bridge forward time, which is the amount of time a port remains in the listening and learning states before entering the forwarding state. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree forward-time *seconds*

no spanning-tree forward-time

PARAMETERS

seconds—Specifies the spanning-tree forward time in seconds. (Range: 4–30)

DEFAULT CONFIGURATION

The default forwarding time for the IEEE Spanning Tree Protocol (STP) is 15 seconds.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

When configuring the forwarding time, the following relationship should be maintained:

$$2 * (\text{Forward-Time} - 1) \geq \text{Max-Age}$$

EXAMPLE

The following example configures the spanning tree bridge forwarding time to 25 seconds.

```
Console(config)# spanning-tree forward-time 25
```

spanning-tree hello-time

Use the **spanning-tree hello-time** Global Configuration mode command to configure the spanning tree bridge Hello time, which is how often the device broadcasts Hello messages to other devices. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree hello-time *seconds*

no spanning-tree hello-time

PARAMETERS

seconds—Specifies the spanning-tree Hello time in seconds. (Range: 1–10)

DEFAULT CONFIGURATION

The default Hello time for IEEE Spanning Tree Protocol (STP) is 2 seconds.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

When configuring the Hello time, the following relationship should be maintained:

$$\text{Max-Age} \geq 2 * (\text{Hello-Time} + 1)$$

EXAMPLE

The following example configures the spanning-tree bridge hello time to 5 seconds.

```
Console(config)# spanning-tree hello-time 5
```

spanning-tree max-age Use the **spanning-tree max-age** Global Configuration mode command to configure the spanning-tree bridge maximum age. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree max-age *seconds*
no spanning-tree max-age

PARAMETERS

seconds—Specifies the spanning-tree bridge maximum age in seconds. (Range: 6–40)

DEFAULT CONFIGURATION

The default maximum age for IEEE Spanning Tree Protocol (STP) is 20 seconds.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

When configuring the maximum age, the following relationships should be maintained:

$$2 * (\text{Forward-Time} - 1) \geq \text{Max-Age}$$

$$\text{Max-Age} \geq 2 * (\text{Hello-Time} + 1)$$

EXAMPLE

The following example configures the spanning-tree bridge maximum age to 10 seconds.

```
Console(config)# spanning-tree max-age 10
```

spanning-tree priority Use the **spanning-tree priority** Global Configuration mode command to configure the device spanning-tree priority, which is used to determine which bridge is selected as the root bridge. Use the **no** form of this command to restore the default device spanning-tree priority.

SYNTAX

spanning-tree priority *priority*
no spanning-tree priority

PARAMETERS

priority—Specifies the bridge priority. (Range: 0–61440)

DEFAULT CONFIGURATION

The default bridge priority for IEEE Spanning Tree Protocol (STP) is 32768.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The priority value must be a multiple of 4096.

The switch with the lowest priority is the root of the spanning tree.

EXAMPLE

The following example configures the spanning-tree priority to 12288.

```
Console(config)# spanning-tree priority 12288
```

**spanning-tree
disable**

Use the **spanning-tree disable** Interface Configuration (Ethernet, port-channel) mode command to disable the spanning tree on a specific port. Use the **no** form of this command to enable the spanning tree on a port.

SYNTAX

spanning-tree disable

no spanning-tree disable

DEFAULT CONFIGURATION

Spanning tree is enabled on all ports.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

EXAMPLE

The following example disables the spanning tree on tengigabitethernet port 0/5

```
Console(config)# interface tengigabitethernet 0/5
Console(config-if)# spanning-tree disable
```

spanning-tree cost Use the **spanning-tree cost** Interface Configuration (Ethernet, port-channel) mode command to configure the spanning-tree path cost for a port. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree cost *cost*

no spanning-tree cost

PARAMETERS

cost—Specifies the port path cost. (Range: 1–200000000)

DEFAULT CONFIGURATION

Default path cost is determined by port speed and path cost method (long or short) as shown below:

Interface	Long	Short
Port-channel	20,000	4
Gigabit Ethernet (1000 Mbps)	20,000	4
Fast Ethernet (100 Mbps)	200,000	19
Ethernet (10 Mbps)	2,000,000	100

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

EXAMPLE

The following example configures the spanning-tree cost on tengigabitethernet port 0/15 to 35000.

```
Console(config)# interface tengigabitethernet 0/15
Console(config-if)# spanning-tree cost 35000
```

spanning-tree port-priority Use the **spanning-tree port-priority** Interface Configuration (Ethernet, port-channel) mode command to configure the port priority. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree port-priority *priority*

no spanning-tree port-priority

PARAMETERS

priority—Specifies the port priority. (Range: 0–240)

DEFAULT CONFIGURATION

The default port priority for IEEE Spanning Tree Protocol (STP) is 128.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

USER GUIDELINES

The priority value must be a multiple of 16.

EXAMPLE

The following example configures the spanning priority on tengigabitethernet port 0/15 to 96

```
Console(config)# interface tengigabitethernet 0/15
Console(config-if)# spanning-tree port-priority 96
```

spanning-tree portfast

Use the **spanning-tree portfast** Interface Configuration (Ethernet, port-channel) mode command to enable the PortFast mode. In PortFast mode, the interface is immediately put into the forwarding state upon linkup, without waiting for the standard forward time delay. Use the **no** form of this command to disable the PortFast mode.

SYNTAX

spanning-tree portfast [auto]

no spanning-tree portfast

PARAMETERS

auto—Specifies that the software waits for 3 seconds (with no BPDUs received on the interface) before putting the interface into the PortFast mode.

DEFAULT CONFIGURATION

PortFast mode is disabled.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

EXAMPLE

The following example enables the PortFast mode on tengigabitethernet port 0/15.

```
Console(config)# interface tengigabitethernet 0/15
Console(config-if)# spanning-tree portfast
```

spanning-tree link-type Use the **spanning-tree link-type** Interface Configuration (Ethernet, port-channel) mode command to override the default link-type setting determined by the port duplex mode, and enable Rapid Spanning Tree Protocol (RSTP) transitions to the forwarding state. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree link-type {*point-to-point* | *shared*}

no spanning-tree spanning-tree link-type

PARAMETERS

- ◆ **point-to-point**—Specifies that the port link type is point-to-point.
- ◆ **shared**—Specifies that the port link type is shared.

DEFAULT CONFIGURATION

The device derives the port link type from the duplex mode. A full-duplex port is considered a point-to-point link and a half-duplex port is considered a shared link.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

EXAMPLE

The following example enables shared spanning-tree on tengigabitethernet port 0/15.

```
Console(config)# interface tengigabitethernet 0/15
Console(config-if)# spanning-tree link-type shared
```

spanning-tree pathcost method Use the **spanning-tree pathcost method** Global Configuration mode command to set the default path cost method. Use the **no** form of this command to return to the default configuration.

SYNTAX

spanning-tree pathcost method {*long* | *short*}

no spanning-tree pathcost method

PARAMETERS

- ◆ **long**—Specifies that the default port path costs are within the range: 1–200,000,000.
- ◆ **short**—Specifies that the default port path costs are within the range: 1–65,535.

DEFAULT CONFIGURATION

Short path cost method.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command applies to all the spanning tree instances on the switch.

- ◆ If the short method is chosen, the switch use for the default cost values in the range 1 through 65,535.
- ◆ If the long method is chosen, the switch use for the default cost values in the range 1 through 200,000,000.

EXAMPLE

The following example sets the default path cost method to Long.

```
Console(config)# spanning-tree pathcost method long
```

**spanning-tree bpd
(Global)**

Use the **spanning-tree bpd** Global Configuration mode command to define BPDU handling when the spanning tree is disabled globally or on a single interface. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree bpd {*filtering* | *flooding* | *bridging*}
no spanning-tree bpd

PARAMETERS

- ◆ **filtering**—Specifies that BPDU packets are filtered when the spanning tree is disabled on an interface.
- ◆ **flooding**—Specifies that untagged BPDU packets are flooded unconditionally (without applying VLAN rules) to all ports with the spanning tree disabled and BPDU handling mode of flooding. Tagged BPDU packets are filtered.
- ◆ **bridging**—Specifies that BPDU packets, whether untagged or tagged, are flooded and are subject to ingress and egress VLAN rules when the spanning tree is disabled globally. This mode is not relevant if the spanning tree is disabled only on a group of ports.

DEFAULT CONFIGURATION

The default setting is **flooding**.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The **filtering** and **flooding** modes are relevant when the spanning tree is disabled globally or on a single interface.

The **bridging** mode is relevant only when the spanning tree is disabled globally.

The BPDU handling mode cannot be changed to **bridging** if the spanning tree is globally enabled.

The spanning tree cannot be globally enabled if the BPDU handling mode is **bridging**.

EXAMPLE

The following example defines the BPDU packet handling mode as **flooding** when the spanning tree is disabled on an interface.

```
Console(config)# spanning-tree bpdn flooding
```

spanning-tree bpdn (Interface)

Use the **spanning-tree bpdn** Interface Configuration (Ethernet, Port-channel) mode command to define BPDU handling when the spanning tree is disabled on a single interface. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree bpdn {*filtering* | *flooding*}

no spanning-tree bpdn

PARAMETERS

- ◆ **filtering**—Specifies that BPDU packets are filtered when the spanning tree is disabled on an interface.
- ◆ **flooding**—Specifies that untagged BPDU packets are flooded unconditionally (without applying VLAN rules) to ports with the spanning tree disabled and BPDU handling mode of flooding. Tagged BPDU packets are filtered.

DEFAULT CONFIGURATION

The **spanning-tree bpdn (Global)** command determines the default configuration.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

If the **spanning-tree bpdn (Global)** command is supported and the **bridging** mode is supported:

If the global BPDU handling mode is **bridging**, the operational BPDU handling mode is bridging for all the ports (The per-interface BPDU handling configuration is kept as a shadow configuration).

EXAMPLE

The following example defines the BPDU packet as **flooding** when the spanning tree is disabled on tengigabitethernet port 0/3.

```
Console(config)# interface tengigabitethernet 0/3
Console(config-if)# spanning-tree bpdu flooding
```

spanning-tree guard root use the **spanning-tree guard root** Interface Configuration (Ethernet, Port-channel) mode command to enable root guard on all spanning-tree instances on the interface. Root guard prevents the interface from becoming the root port of the device. Use the **no** form of this command to disable the root guard on the interface.

SYNTAX

spanning-tree guard root
no spanning-tree guard root

DEFAULT CONFIGURATION

Root guard is disabled.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

Root guard can be enabled when the device operates in STP, RSTP and MSTP modes.

When root guard is enabled, the port changes to the alternate state if the spanning-tree calculations select the port as the root port.

EXAMPLE

The following example prevents tengigabitethernet port 0/1 from being the root port of the device..

```
Console(config)# interface tengigabitethernet 0/1
Console(config-if)# spanning-tree guard root
```

spanning-tree bpduguard Use the **spanning-tree bpduguard** Interface Configuration (Ethernet, port-channel) mode command to shut down an interface when it receives a bridge protocol data unit (BPDU). Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree bpduguard {*enable* | *disable*}
no spanning-tree bpduguard

PARAMETERS

enable—Enables BPDU Guard.

disable—Disables BPDU Guard.

DEFAULT CONFIGURATION

BPDU Guard is disabled.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

The command can be enabled when the spanning tree is enabled (useful when the port is in the PortFast mode) or disabled.

EXAMPLE

The following example shuts down Ethernet port 0/5 when it receives a BPDU.

```
Console(config)# interface tengigabitethernet 0/5
Console(config-if)# spanning-tree bpduguard enable
```

clear spanning-tree detected-protocols Use the **clear spanning-tree detected-protocols** Privileged EXEC command to restart the protocol migration process (force the renegotiation with neighboring switches) on all interfaces or on the specified interface

SYNTAX

clear spanning-tree detected-protocols [*interface interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

This feature should be used only when working in RSTP or MSTP mode.

EXAMPLE

```
console# clear spanning-tree detected-protocols
```

spanning-tree mst priority Use the **spanning-tree mst priority** Global Configuration mode command to configure the device priority for the specified spanning-tree instance. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree mst *instance-id* *priority* *priority*

no spanning-tree mst *instance-id* *priority*

PARAMETERS

- ◆ **instance-id**—Specifies the spanning-tree instance ID. (Range:1–7)
- ◆ **priority**—Specifies the device priority for the specified spanning-tree instance. This setting affects the likelihood that the switch is selected as the root switch. A lower value increases the probability that the switch is selected as the root switch. (Range: 0–61440)

DEFAULT CONFIGURATION

The default bridge priority for IEEE Spanning Tree Protocol (STP) is 32768.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The priority value must be a multiple of 4096.

The switch with the lowest priority is the root of the spanning tree.

EXAMPLE

The following example configures the spanning tree priority of instance 1 to 4096.

```
Console(config)# spanning-tree mst 1 priority 4096
```

spanning-tree mst max-hops Use the **spanning-tree mst max-hops** Global Configuration mode command to configure the number of hops in an MST region before the BDP is discarded and the port information is aged out. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree mst max-hops *hop-count*
no spanning-tree mst max-hops

PARAMETERS

hop-count—Specifies the number of hops in an MST region before the BDP is discarded. (Range: 1–40)

DEFAULT CONFIGURATION

The default number of hops is 20.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures the maximum number of hops that a packet travels in an MST region before it is discarded to 10.

```
Console(config)# spanning-tree mst max-hops 10
```

spanning-tree mst port-priority Use the **spanning-tree mst port-priority** Interface Configuration (Ethernet, port-channel) mode command to configure the priority of a port. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree mst *instance-id* **port-priority** *priority*
no spanning-tree mst *instance-id* **port-priority**

PARAMETERS

- ◆ **instance-id**—Specifies the spanning tree instance ID. (Range: 1–15)
- ◆ **priority**—Specifies the port priority. (Range: 0–240 in multiples of 16)

DEFAULT CONFIGURATION

The default port priority for IEEE Spanning Tree Protocol (STP) is 128.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

USER GUIDELINES

The priority value must be a multiple of 16.

EXAMPLE

The following example configures the port priority of port te1 to 144.

```
Console(config)# interface tengigabitethernet 0/1
Console(config-if)# spanning-tree mst 1 port-priority 144
```

spanning-tree mst cost

Use the **spanning-tree mst cost** Interface Configuration (Ethernet, Port-channel) mode command to configure the path cost for multiple spanning-tree (MST) calculations. If a loop occurs, the spanning tree considers path cost when selecting an interface to put in the forwarding state. Use the **no** form of this command to restore the default configuration.

SYNTAX

spanning-tree mst *instance-id* **cost** *cost*

no spanning-tree mst *instance-id* **cost**

PARAMETERS

- ◆ **instance-id**—Specifies the spanning-tree instance ID. (Range: 1–15)
- ◆ **cost**—Specifies the port path cost. (Range: 1–200000000)

DEFAULT CONFIGURATION

Default path cost is determined by the port speed and path cost method (long or short) as shown below:

Interface	Long	Short
Port-channel	20,000	4
Gigabit Ethernet (1000 Mbps)	20,000	4
Fast Ethernet (100 Mbps)	200,000	19
Ethernet (10 Mbps)	2,000,000	100

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

EXAMPLE

The following example configures the MSTP instance 1 path cost for tengigabitethernet port 0/9 to 4.

```
Console(config)# interface tengigabitethernet 0/9
Console(config-if)# spanning-tree mst 1 cost 4
```

spanning-tree mst configuration Use the **spanning-tree mst configuration** Global Configuration mode command to enable configuring an MST region by entering the Multiple Spanning Tree (MST) mode.

SYNTAX

spanning-tree mst configuration

COMMAND MODE

Global Configuration mode

USER GUIDELINES

For two or more switches to be in the same MST region, they need to contain the same VLAN mapping, the same configuration revision number, and the same name.

EXAMPLE

The following example configures an MST region.

```
Console(config)# spanning-tree mst configuration
Console(config-mst)# instance 1 vlan 10-20
Console(config-mst)# name region1
Console(config-mst)# revision 1
```

instance (MST) Use **instance** MST Configuration mode command to map VLANs to an MST instance. Use the **no** form of this command to restore default mapping.

SYNTAX

instance *instance-id* **vlan** *vlan-range*
no instance *instance-id* **vlan** *vlan-range*

PARAMETERS

- ◆ **instance-id**—MST instance (Range: 1–15)
- ◆ **vlan-range**—The specified range of VLANs is added to the existing ones. To specify a range, use a hyphen. To specify a series, use a comma. (Range: 1–4094)

DEFAULT CONFIGURATION

All VLANs are mapped to the common and internal spanning tree (CIST) instance (instance 0).

COMMAND MODE

MST Configuration mode

USER GUIDELINES

All VLANs that are not explicitly mapped to an MST instance are mapped to the common and internal spanning tree (CIST) instance (instance 0) and cannot be unmapped from the CIST.

For two or more devices to be in the same MST region, they must have the same VLAN mapping, the same configuration revision number, and the same name.

EXAMPLE

The following example maps VLANs 10-20 to MST instance 1.

```
Console(config)# spanning-tree mst configuration  
Console(config-mst)# instance 1 vlan 10-20
```

name (MST) Use the **name** MST Configuration mode command to define the MST configuration name. Use the **no** form of this command to restore the default setting.

SYNTAX

name *string*

no name

PARAMETERS

string—Specifies the MST configuration name. (Length: 1–32 characters)

DEFAULT CONFIGURATION

The default name is the bridge address.

COMMAND MODE

MST Configuration mode

EXAMPLE

The following example defines the configuration name as Region1.

```
Console(config)# spanning-tree mst configuration  
Console(config-mst)# name region1
```

revision (MST) Use the **revision** MST Configuration mode command to define the MST configuration revision number. Use the **no** form of this command to restore the default configuration.

SYNTAX

revision *value*

no revision

PARAMETERS

value—Specifies the MST configuration revision number. (Range: 0–65535)

DEFAULT CONFIGURATION

The default configuration revision number is 0.

COMMAND MODE

MST Configuration mode

EXAMPLE

The following example sets the configuration revision to 1.

```
Console(config) # spanning-tree mst configuration
Console(config-mst) # revision 1
```

show (MST) Use the **show** MST Configuration mode command to displays the current or pending MST region configuration.

SYNTAX

show {*current* | *pending*}

PARAMETERS

- ◆ **current**—Displays the current MST region configuration.
- ◆ **pending**—Displays the pending MST region configuration.

COMMAND MODE

MST Configuration mode

EXAMPLE

The following example displays a pending MST region configuration.

```
Console(config-mst)# show pending

Pending MST configuration
Name: Region1
Revision: 1

Instance      Vlans Mapped      State
-----
0             1-9,21-4094      Enabled
1             10-20             Enabled
```

exit (MST) Use the **exit** MST Configuration mode command to exit the MST region Configuration mode and apply all configuration changes.

SYNTAX

exit

COMMAND MODE

MST Configuration mode

EXAMPLE

The following example exits the MST Configuration mode and saves changes.

```
Console(config)# spanning-tree mst configuration
Console(config-mst)# exit
Console(config)#
```

abort (MST) Use the **abort** MST Configuration mode command to exit the MST Configuration mode without applying the configuration changes.

SYNTAX

abort

COMMAND MODE

MST Configuration mode

EXAMPLE

The following example exits the MST Configuration mode without saving changes.

```
Console(config)# spanning-tree mst configuration
Console(config-mst)# abort
```

show spanning-tree Use the **show spanning-tree** Privileged EXEC mode command to display the spanning-tree configuration.

SYNTAX

show spanning-tree *[interface-id] [instance instance-id]*

show spanning-tree *[detail] [active | blockedports] [instance instance-id]*

show spanning-tree *mst-configuration*

PARAMETERS

- ◆ **instance instance-id**—Specifies the spanning tree instance ID. (Range: 0–15)
- ◆ **detail**—Displays detailed information.
- ◆ **active**—Displays active ports only.
- ◆ **blockedports**—Displays blocked ports only.
- ◆ **mst-configuration**—Displays the MST configuration identifier.
- ◆ **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following examples display spanning-tree information.

```

Console# show spanning-tree
Spanning tree enabled mode RSTP
Default port cost method: long
Loopback guard: Disabled

Root ID      Priority      32768
            Address      00:01:42:97:e0:00
            Path Cost    20000
            Root Port    te1
            Hello Time 2 sec           Max Age 20 sec   Forward Delay 15 sec

Bridge ID     Priority      36864
            Address      00:02:4b:29:7a:00
            Hello Time 2 sec           Max Age 20 sec   Forward Delay 15 sec

```


Interfaces

Name	State	Prio. Nbr	Cost	Sts	Role	PortFast	Type
te1	Enabled	128.1	20000	FWD	Root	No	P2p (RSTP)
te2	Enabled	128.2	20000	FWD	Desg	No	Shared (STP)
te3	Disabled	128.3	20000	-	-	-	-
te4	Enabled	128.4	20000	BLK	Altn	No	Shared (STP)
te5	Enabled	128.5	20000	DIS	-	-	-

Console# **show spanning-tree**

Spanning tree enabled mode RSTP
Default port cost method: long

Root ID Priority 36864
 Address 00:02:4b:29:7a:00

 This switch is the Root.

 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Interfaces

Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
te1	Enabled	-	20000	FWD	Desg	No	P2p (RSTP)
te2	Enabled	128.1	20000	FWD	Desg	No	Shared (STP)
te3	Disabled	128.2	20000	-	-	-	-
te4	Enabled	128.3	20000	FWD	Desg	No	Shared (STP)
te5	Enabled	128.4	20000	DIS	-	-	-
		128.5					

Console# **show spanning-tree**

Spanning tree disabled (BPDU filtering) mode RSTP
Default port cost method: long

Root ID Priority N/A
 Address N/A
 Path Cost N/A
 Root Port N/A
 Hello Time N/A Max Age N/A Forward Delay N/A

Bridge ID Priority 36864
 Address 00:02:4b:29:7a:00

 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Interfaces

Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
te1	Enabled	-	20000	-	-	-	-
te2	Enabled	128.1	20000	-	-	-	-
te3	Disabled	128.2	20000	-	-	-	-
te4	Enabled	128.3	20000	-	-	-	-
te5	Enabled	128.4	20000	-	-	-	-
		128.5					

Console# **show spanning-tree active**

Spanning tree enabled mode RSTP
Default port cost method: long

Root ID	Priority	32768
	Address	00:01:42:97:e0:00
	Path Cost	20000
	Root Port	te1
	Hello Time	2 sec
	Max Age	20 sec
	Forward Delay	15 sec

Bridge ID	Priority	36864
	Address	00:02:4b:29:7a:00
	Hello Time	2 sec
	Max Age	20 sec
	Forward Delay	15 sec

Interfaces

Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
te1	Enabled	-	20000	FWD	Root	No	P2p (RSTP)
te2	Enabled	128.1	20000	FWD	Desg	No	Shared (STP)
te4	Enabled	128.2	20000	BLK	Altn	No	Shared (STP)
		128.4					

Console# **show spanning-tree blockedports**

Spanning tree enabled mode RSTP
Default port cost method: long

Root ID	Priority	32768
	Address	00:01:42:97:e0:00
	Path Cost	20000
	Root Port	te1
	Hello Time	2 sec
	Max Age	20 sec
	Forward Delay	15 sec

Bridge ID	Priority	36864
	Address	00:02:4b:29:7a:00
	Hello Time	2 sec
	Max Age	20 sec
	Forward Delay	15 sec

Interfaces

Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
te4	Enabled	-	19	BLK	Altn	No	Shared (STP)
			128.4				

Console# **show spanning-tree detail**

Spanning tree enabled mode RSTP
Default port cost method: long

Root ID	Priority	32768
	Address	00:01:42:97:e0:00
	Path Cost	20000
	Root Port	te1
	Hello Time	2 sec
	Max Age	20 sec
	Forward Delay	15 sec

Bridge ID	Priority	36864
	Address	00:02:4b:29:7a:00
	Hello Time	2 sec
	Max Age	20 sec
	Forward Delay	15 sec

Number of topology changes 2 last change occurred 2d18h ago

Times: hold 1, topology change 35, notification 2
hello 2, max age 20, forward delay 15

Port 1 (te1) enabled	
State: Forwarding	Role: Root
Port id: 128.1	Port cost: 20000
Type: P2p (configured: auto) RSTP	Port Fast: No (configured:no)
Designated bridge Priority: 32768	Address: 00:01:42:97:e0:00
Designated port id: 128.25	Designated path cost: 0
Guard root: Disabled	BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Port 2 (te2) enabled	
State: Forwarding	Role: Designated
Port id: 128.2	Port cost: 20000
Type: Shared (configured: auto) STP	Port Fast: No (configured:no)
Designated bridge Priority: 32768	Address: 00:02:4b:29:7a:00
Designated port id: 128.2	Designated path cost: 20000
Guard root: Disabled	BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

Port 3 (te3) disabled	
State: N/A	Role: N/A
Port id: 128.3	Port cost: 20000
Type: N/A (configured: auto)	Port Fast: N/A (configured:no)
Designated bridge Priority: N/A	Address: N/A
Designated port id: N/A	Designated path cost: N/A
Guard root: Disabled	BPDU guard: Disabled

Number of transitions to forwarding state: N/A
BPDU: sent N/A, received N/A

```

Port 4 (te4) enabled
State: Blocking                               Role: Alternate
Port id: 128.4                               Port cost: 20000
Type: Shared (configured:auto) STP           Port Fast: No (configured:no)
Designated bridge Priority: 28672             Address: 00:30:94:41:62:c8
Designated port id: 128.25                   Designated path cost: 20000
Guard root: Disabled                         BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

```

```

Port 5 (te5) enabled
State: Disabled                               Role: N/A
Port id: 128.5                               Port cost: 20000
Type: N/A (configured: auto)                 Port Fast: N/A (configured:no)
Designated bridge Priority: N/A              Address: N/A
Designated port id: N/A                     Designated path cost: N/A
Guard root: Disabled                         BPDU guard: Disabled

Number of transitions to forwarding state: N/A
BPDU: sent N/A, received N/A

```

Console# **show spanning-tree ethernet** te1

```

Port 1 (te1) enabled
State: Forwarding                             Role: Root
Port id: 128.1                               Port cost: 20000
Type: P2p (configured: auto) RSTP           Port Fast: No (configured:no)
Designated bridge Priority: 32768            Address: 00:01:42:97:e0:00
Designated port id: 128.25                  Designated path cost: 0
Guard root: Disabled                         BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

```

Console# **show spanning-tree mst-configuration**

```

Name: Region1
Revision: 1

Instance      Vlans mapped      State
-----
0             1-9, 21-4094      Enabled
1             10-20              Enabled

```

Console# **show spanning-tree**

```

Spanning tree enabled mode MSTP
Default port cost method: long

```

```

##### MST 0 Vlans Mapped: 1-9

```

```

CST Root ID      Priority 32768
                  Address 00:01:42:97:e0:00
                  Path    20000
                  Cost     te1
                  Root
                  Port

                  Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

```

```

IST Master ID      Priority 32768
                   Address 00:02:4b:29:7a:00

                   This switch is the IST master.

                   Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

                   Max hops 20

```

Interfaces

Name	State	Prio.	Nbr	Cost	Sts	Role	PortFast	Type
te1	Enabled	128.1	20000	FWD	Root	No	--	
te2	Enabled	128.2	20000	FWD	Desg	No	P2p Bound (RSTP)	
te3	Enabled	128.3	20000	FWD	Desg	No	Shared Bound	
te4	Enabled	128.4	20000	FWD	Desg	No	(STP)	
							P2p	
							P2p	

```
##### MST 1 Vlans Mapped: 10-20
```

```

Root ID           Priority 24576
                   Address 00:02:4b:29:89:76
                   Path      20000
                   Cost       te4
                   Root       19
                   Port
                   Rem hops

```

```

Bridge ID         Priority 32768
                   Address 00:02:4b:29:7a:00

```

Interfaces

Name	State	Prio.	Nbr	Cost	Sts	Role	PortFast	Type
te1	Enabled	128.1	20000	FWD	Boun	No	--	
te2	Enabled	128.2	20000	FWD	Boun	No	P2p Bound (RSTP)	
te3	Enabled	128.3	20000	BLK	Altn	No	Shared Bound	
te4	Enabled	128.4	20000	FWD	Root	No	(STP)	
							P2p	
							P2p	

```
Console# show spanning-tree detail
```

```

Spanning tree enabled mode MSTP
Default port cost method: long

```

```
##### MST 0 Vlans Mapped: 1-9
```

```

CST Root ID       Priority 32768
                   Address 00:01:42:97:e0:00
                   Path      20000
                   Cost       te1
                   Root
                   Port

                   Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

```

```

IST Master ID      Priority 32768
                   Address 00:02:4b:29:7a:00

                   This switch is the IST master.

                   Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

                   Max hops 20
                   Number of topology changes 2 last change occurred 2d18h ago
                   Times: hold 1, topology change 35, notification 2
                   hello 2, max age 20, forward delay 15

```

```

Port 1 (te1) enabled
State: Forwarding                                Role: Root
Port id: 128.1                                   Port cost: 20000
Type: P2p (configured: auto) Boundary RSTP       Port Fast: No (configured:no)
Designated bridge Priority: 32768                Address: 00:01:42:97:e0:00
Designated port id: 128.25                       Designated path cost: 0
Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

```

```

Port 2 (te2) enabled
State: Forwarding                                Role: Designated
Port id: 128.2                                   Port cost: 20000
Type: Shared (configured: auto) Boundary STP     Port Fast: No (configured:no)
Designated bridge Priority: 32768                Address: 00:02:4b:29:7a:00
Designated port id: 128.2                       Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```

Port 3 (te3) enabled
State: Forwarding                                Role: Designated
Port id: 128.3                                   Port cost: 20000
Type: Shared (configured: auto) Internal         Port Fast: No (configured:no)
Designated bridge Priority: 32768                Address: 00:02:4b:29:7a:00
Designated port id: 128.3                       Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```

Port 4 (te4) enabled                                v
State: Forwarding
Port id: 128.4
Type: Shared (configured: auto) Internal
Designated bridge Priority: 32768
Designated port id: 128.2
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```

##### MST 1 Vlans Mapped: 10-20

```

```

Root ID      Priority 24576
              Address 00:02:4b:29:89:76
              Path     20000
              Cost      te4
              Root
              Port

              Rem hops 19

```

```

Bridge ID          Priority 32768
                   Address 00:02:4b:29:7a:00

                   Number of topology changes 2 last change occurred 1d9h ago

                   Times: hold 1, topology change 2, notification 2
                   hello 2, max age 20, forward delay 15

```

```

Port 1 (te1) enabled
State: Forwarding                                Role: Boundary
Port id: 128.1                                   Port cost: 20000
Type: P2p (configured: auto) Boundary RSTP       Port Fast: No (configured:no)
Designated bridge Priority: 32768                Address: 00:02:4b:29:7a:00
Designated port id: 128.1                        Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

```

```

Port 2 (te2) enabled
State: Forwarding                                Role: Designated
Port id: 128.2                                   Port cost: 20000
Type: Shared (configured: auto) Boundary STP     Port Fast: No (configured:no)
Designated bridge Priority: 32768                Address: 00:02:4b:29:7a:00
Designated port id: 128.2                        Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```

Port 3 (te3) disabled
State: Blocking                                  Role: Alternate
Port id: 128.3                                   Port cost: 20000
Type: Shared (configured: auto) Internal         Port Fast: No (configured:no)
Designated bridge Priority: 32768                Address: 00:02:4b:29:1a:19
Designated port id: 128.78                       Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```

Port 4 (te4) enabled
State: Forwarding                                Role: Designated
Port id: 128.4                                   Port cost: 20000
Type: Shared (configured: auto) Internal         Port Fast: No (configured:no)
Designated bridge Priority: 32768                Address: 00:02:4b:29:7a:00
Designated port id: 128.2                        Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```
Console# show spanning-tree
```

```
Spanning tree enabled mode MSTP
Default port cost method: long
```

```
##### MST 0 Vlans Mapped: 1-9
```

```

CST Root ID      Priority 32768
                  Address 00:01:42:97:e0:00
                  Path      20000
                  Cost       te1
                  Root
                  Port

                  Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

```

```

IST Master ID      Priority 32768
                   Address 00:02:4b:19:7a:00
                   Path    10000
                   Cost     19
                   Rem hops

Bridge ID          Priority 32768
                   Address 00:02:4b:29:7a:00

                   Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec
                   Max hops 20

Console# show spanning-tree

Spanning tree enabled mode MSTP
Default port cost method: long

##### MST 0 Vlans Mapped: 1-9

CST Root ID       Priority 32768
                   Address 00:01:42:97:e0:00

                   This switch is root for CST and IST master.

                   Root      te1
                   Port

                   Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec
                   Max hops 20

```

show spanning-tree bpd Use the **show spanning-tree bpd** EXEC mode command to display the BPDU handling when spanning-tree is disabled.

SYNTAX

show spanning-tree bpd *[interface-id]*

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following examples display spanning-tree information.


```
Console# show spanning-tree bpdu
```

```
Global: Flooding
```

Interface -----	Admin Mode -----	Oper Mode -----
te1	Global	Flooding
te2	Global	STP
te3	Flooding	STP

spanning-tree loopback-guard

Use the **spanning-tree loopback-guard global configuration** command to shut down any interface when it receives a loopback bridge protocol data unit (BPDU). Use the **no** form of this command to return the default setting.

SYNTAX

spanning-tree loopback-guard

no spanning-tree loopback-guard

COMMAND MODE

Global

USER GUIDELINES

This command is used with Spanning Tree configuration.

EXAMPLE

```
Switch (config)# spanning-tree loopback-guard
```


VIRTUAL LOCAL AREA NETWORK (VLAN) COMMANDS

iPECS ES-5048XG

vlan database Use the **vlan database** Global Configuration mode command to enter the VLAN Configuration mode.

SYNTAX

vlan database

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enters the VLAN database mode.

```
Console(config)# vlan database
Console(config-vlan)#
```

vlan Use the **vlan** VLAN Configuration mode command to create a VLAN. Use the **no** form of this command to restore the default configuration or delete a VLAN.

SYNTAX

vlan *vlan-range* [*name* *vlan-name*]

no vlan *vlan-range*

PARAMETERS

- ◆ **vlan-range**—Specifies a list of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.
- ◆ **name**—Specifies the VLAN name. The option is only valid in case where only one VLAN is configured by the command (Range: 1–32 characters)

COMMAND MODE

VLAN Configuration mode

EXAMPLE

The following example creates VLAN number 1972.

```
Console(config)# vlan database
Console(config-vlan)# vlan 1972
```

interface vlan Use the **interface vlan** Global Configuration mode command to enter the Interface Configuration (VLAN) mode and enable configuration of the specified VLAN ID.

SYNTAX

interface vlan *vlan-id*

PARAMETERS

vlan-id—Specifies an existing VLAN ID.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

If the VLAN does not exist (ghost VLAN), not all of the commands are available under the interface VLAN context.

The commands that are supported for VLANs that do not exist are:

- ◆ IGMP snooping control commands
- ◆ Bridge multicast configuration commands

EXAMPLE

The following example configures VLAN 1 with IP address 131.108.1.27 and subnet mask 255.255.255.0.

```
Console (config)# interface vlan 1
Console (config-if)# ip address 131.108.1.27 255.255.255.0
```

interface range vlan Use the **interface range vlan** Global Configuration mode command to enable configuring multiple VLANs simultaneously.

SYNTAX

interface range vlan *vlan-range*

PARAMETERS

vlan-range—Specifies a list of VLAN IDs. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Commands under the interface range context are executed independently on each interface in the range. If the command returns an error on one of

the interfaces, an error message is displayed and command execution continues on the other interfaces.

EXAMPLE

The following example groups VLANs 221 through 228 and 889 to receive the same command.

```
Console(config)# interface range vlan 221-228, vlan 889
Console(config-if)#
```

name Use the **name** Interface Configuration (VLAN) mode command to add a name to a VLAN. Use the **no** form of this command to remove the VLAN name.

SYNTAX

name *string*
no name

PARAMETERS

string—Specifies a unique name associated with this VLAN. (Length: 1–32 characters)

DEFAULT CONFIGURATION

No name is defined.

COMMAND MODE

Interface Configuration (VLAN) mode. It cannot be configured for a range of interfaces (range context).

USER GUIDELINES

The VLAN name must be unique.

EXAMPLE

The following example gives VLAN number 19 the name Marketing.

```
Console(config)# interface vlan 19
Console(config-if)# name Marketing
```

switchport protected-port Use the **switchport protected-port** Interface Configuration mode command to isolate unicast, multicast, and broadcast traffic at Layer 2 from other protected ports on the same switch. Use the **no** form of this command to disable protection on the port.

SYNTAX

switchport protected-port
no switchport protected-port

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Unprotected

COMMAND MODE

Interface configuration (Ethernet, port-channel)

USER GUIDELINES

Use this command to isolate unicast, multicast, and broadcast traffic at Layer 2 from other protected ports (that are not associated with the same community as the ingress interface) on the same switch. Please note that the packet is still subject to FDB decision and to all filtering rules. Use the **switchport community** Interface Configuration command to associate the interface with a community.

EXAMPLE

```
console(config)# interface tel  
console(config-if)# switchport protected-port
```

switchport community Use the **switchport community** Interface Configuration mode command to associate a protected port with a community. Use the **no** form of this command to return to default.

SYNTAX

switchport community *community*
no switchport community

PARAMETERS

community—Specifies the community number. (Range:1 - 30)

DEFAULT CONFIGURATION

The port is not associated with any community.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

USER GUIDELINES

The command is relevant only when the port is defined as a protected port. Use the **switchport protected-port** Interface Configuration command to define a port as a protected port.

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# switchport community 1
```

show interfaces protected-ports

Use the **show interfaces protected-ports** EXEC mode command to show protected ports configuration.

SYNTAX

show interfaces protected-ports [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

```
console# show interfaces protected-ports
```

Interface	State	Community
te1	Protected	1
te2	Protected	Isolated
te3	Unprotected	20
te4	Unprotected	Isolated



NOTE: The Community column for unprotected ports is relevant only when the port state is changed to Protected.

switchport

Use the **switchport** Interface Configuration mode command with no keywords to put an interface that is in Layer 3 mode into Layer 2 mode for Layer 2 configuration. Use the **no** form of this command to put an interface in Layer 3 mode.

SYNTAX

switchport

no switchport

DEFAULT CONFIGURATION

Layer 2 mode

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

switchport mode Use the **switchport mode** Interface Configuration (Ethernet, port-channel) mode command to configure the VLAN membership mode of a port. Use the **no** form of this command to restore the default configuration.

SYNTAX

switchport mode { *access* | *trunk* | *general* | *private-vlan*
 {*promiscuous* | *host*} | *customer* }

no switchport mode

PARAMETERS

- ◆ **access**—Specifies an untagged layer 2 VLAN port.
- ◆ **trunk**—Specifies a trunking layer 2 VLAN port.
- ◆ **general**—Specifies a full 802-1q supported VLAN port.
- ◆ **customer**—Specifies that the port is connected to customer equipment. Used when the switch is in a provider network.
- ◆ **private-vlan promiscuous**—Private-VLAN promiscuous port.
- ◆ **private-vlan host**—Private-VLAN host port.

DEFAULT CONFIGURATION**COMMAND MODE**

Interface Configuration (Ethernet, port-channel) mode

USER GUIDELINES

- ◆ When the port mode is changed, it receives the configuration corresponding to the mode.
- ◆ If the port mode is changed to access and the access VLAN does not exist, then the port will not belong to any VLAN.

EXAMPLE

The following example configures tengigabitethernet port 0/1 as an untagged layer 2 VLAN port.

```
Console(config)# interface tengigabitethernet 0/1
Console(config-if)# switchport mode access
```


switchport access vlan Use the **switchport access vlan** Interface Configuration (Ethernet, port-channel) mode command to configure the VLAN ID when the interface is in access mode. Use the **no** form of this command to restore the default configuration.

SYNTAX

switchport access vlan { *vlan-id* | *none* }

no switchport access vlan

PARAMETERS

vlan-id—Specifies the VLAN ID to which the port is configured.

none—Specifies the access port cannot belong to any VLAN.

DEFAULT CONFIGURATION

If the default VLAN is enabled, the VLAN ID is 1. Otherwise, it is not a member of any VLAN.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

USER GUIDELINES

The command automatically removes the port from the previous VLAN and adds it to the new VLAN.

EXAMPLE

The following example configures a VLAN ID of 23 to the untagged layer 2 VLAN tengigabitethernet port 0/1.

```
Console(config)# interface tengigabitethernet 0/1
Console(config-if)# switchport access vlan 23
```

switchport trunk allowed vlan Use the **switchport trunk allowed vlan** Interface Configuration mode command to set the trunk characteristics when the interface is in trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default.

SYNTAX

switchport trunk allowed vlan { *all* | *none* | *add vlan-list* | *remove vlan-list* | *except vlan-list* }

no switchport trunk allowed vlan

PARAMETERS

all—Specifies all VLANs from 1 to 4094. At any time, the port belongs to all VLANs existing at the time. (Range: 1–4094)

none—Specifies an empty VLAN list The port does not belong to any VLAN.

add vlan-list—List of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.

remove vlan-list—List of VLAN IDs to remove. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.

except vlan-list—List of VLAN IDs is calculated by inverting the defined list of VLANs (the calculated list will include all VLANs from interval 1..4094 except VLANs from the defined list).

DEFAULT CONFIGURATION

The Default VLAN is its Native VLAN and the port belongs to either all VLANs or only to the Default VLAN depending on a value of parameter Trunk Port Default Configuration.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

USER GUIDELINES

The RS port model behavior allows only the following options: Add and Remove.

Inside **except vlan-list** is saved as **add ~ vlan-list**, where **~ vlan-list** is a list of all VLANs from 1 to 4094 minus the VLANs from **vlan-list**. Command **show running/startup** always uses the latter format.

The port must be in trunk mode before the command can take effect.

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# switchport mode trunk
console(config-if)# switchport trunk allowed vlan all
```

switchport trunk native vlan Use the **switchport trunk native vlan** Interface Configuration (Ethernet, port-channel) mode command to define the native VLAN when the interface is in trunk mode. Use the **no** form of this command to restore the default configuration.

SYNTAX

switchport trunk native vlan { *vlan-id* | *none* }

no switchport trunk native vlan

PARAMETERS

- ◆ **vlan-id**—Specifies the native VLAN ID.
- ◆ **none**—Specifies the access port cannot belong to any VLAN.

DEFAULT CONFIGURATION

If the default VLAN is enabled, the VLAN ID is 1. Otherwise, the VLAN ID is 4095.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

USER GUIDELINES

The command adds the port as a member of the VLAN. If the port is already a member of the VLAN (not a native), it must first be removed from the VLAN.

EXAMPLE

The following example configures VLAN number 123 as the native VLAN when the port is in trunk mode.

```
Console# interface tel
Console(config-if)# switchport trunk native vlan 123
```

**switchport general
allowed vlan**

Use the **switchport general allowed vlan** Interface Configuration mode command to set the general characteristics when the interface is in general mode. Use the **no** form of this command to reset a general characteristic to the default.

SYNTAX

**switchport general allowed vlan {add | remove} vlan-list
[tagged|untagged]**

no switchport general allowed vlan

PARAMETERS

- ◆ **add vlan-list**—List of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs. (Range: 1–4094)
- ◆ **remove vlan-list**—List of VLAN IDs to remove. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.
- ◆ **tagged** - Specify that packets would be transmitted tagged for the configured VLANs
- ◆ **untagged** - Specify that packets would be transmitted untagged for the configured VLANs (this is the default)

DEFAULT CONFIGURATION

The port's PVID equals to the Default VLAN ID and belongs to the Default VLAN as untagged one.

COMMAND MODE

Interface Configuration mode

EXAMPLE

```
console(config-if)# interface tengigabitethernet 0/1
console(config-if)# switchport mode general
console(config-if)# switchport general allowed vlan add 2-3 tagged
```

switchport general pvid

Use the **switchport general pvid** Interface Configuration (Ethernet, Port-channel) mode command to configure the Port VLAN ID (PVID) when the interface is in general mode. Use the **no** form of this command to restore the default configuration.

SYNTAX

switchport general pvid *vlan-id*

no switchport general pvid

PARAMETERS

vlan-id—Specifies the Port VLAN ID (PVID).

DEFAULT CONFIGURATION

If the default VLAN is enabled, PVID is 1. Otherwise, PVID is =4095.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

EXAMPLE

The following example configures PVID 234 for tengigabitethernet port 0/2, when the interface is in general mode.

```
Console(config)# interface tengigabitethernet 0/2
Console(config-if)# switchport mode general
Console(config-if)# switchport general pvid 234
```

switchport general ingress-filtering disable

Use the **switchport general ingress-filtering disable** Interface Configuration (Ethernet, Port-channel) mode command to disable port ingress filtering. Use the **no** form of this command to restore the default configuration.

SYNTAX

switchport general ingress-filtering disable

no switchport general ingress-filtering disable

DEFAULT CONFIGURATION

Ingress filtering is enabled.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

EXAMPLE

The following example disables port ingress filtering on tengigabitethernet port 0/1.

```
Console(config)# interface tengigabitethernet 0/1
Console(config-if)# switchport mode general
Console(config-if)# switchport general ingress-filtering disable
```

switchport general acceptable-frame-type

Use the **switchport general acceptable-frame-type** Interface Configuration mode command to configure ingress filtering based on packet type tagged/untagged. Use the **no** form of this command to return to default.

SYNTAX

switchport general acceptable-frame-type {*tagged-only* | *untagged-only* | *all*}

no switchport general acceptable-frame-type

PARAMETERS

- ◆ **tagged-only**—Discard untagged packets and priority tagged packets.
- ◆ **untagged-only**—Discard VLAN tagged packets (not including Priority tagged packets)
- ◆ **all**—Do not discard packets based on whether the packet is VLAN tagged or not.

DEFAULT CONFIGURATION

All frame types are accepted at ingress.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

EXAMPLE

The following example configures tengigabitethernet port 0/3 to discard untagged frames at ingress.

```
Console(config)# interface tengigabitethernet 0/3
Console(config-if)# switchport mode general
Console(config-if)# switchport general acceptable-frame-type tagged-only
```

map protocol protocols-group Use the **map protocol protocols-group** VLAN Configuration mode command to map a protocol to a group of protocols. Use the **no** form of this command to delete a protocol from a group.

SYNTAX

map protocol *protocol* [*encapsulation*] **protocols-group** *group*
no map protocol *protocol* [*encapsulation*]

PARAMETERS

- ◆ **protocol**—Specifies a 16-bit protocol number or one of the reserved names listed in the User Guidelines. (Range: 0x0600–0xFFFF)
- ◆ **encapsulation**—Specifies one of the following values: Ethernet, rfc1042, llcOther. If no option is indicated, the default is Ethernet.
- ◆ **protocols-group group**—Specifies the group number of the group of protocols associated together. (Range: 1–2147483647)

DEFAULT CONFIGURATION

The default encapsulation is Ethernet.

COMMAND MODE

VLAN Configuration mode

USER GUIDELINES

The value 0x8100 is not valid as the protocol number for Ethernet encapsulation.

The following protocol names are reserved for Ethernet Encapsulation:

- ◆ ip
- ◆ arp
- ◆ ipv6
- ◆ ipx

EXAMPLE

The following example maps protocol ip to protocol group number 213.

```
Console(config)# vlan database
Console(config-vlan)# map protocol ip protocols-group 213
```

**switchport general
map protocols-
group vlan**

Use the **switchport general map protocols-group vlan** Interface Configuration (Ethernet, Port-channel) mode command to set a protocol-based classification rule. Use the no form of this command to delete a classification.

SYNTAX

switchport general map protocols-group *group* **vlan** *vlan-id*

no switchport general map protocols-group *group*

PARAMETERS

- ◆ **group**—Specifies the group number as defined in the **map protocol protocols-group** command. (Range: 1–65535)
- ◆ **vlan-id**—Defines the VLAN ID in the classifying rule.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

DEFAULT CONFIGURATION

No classification is defined.

USER GUIDELINES

The VLAN classification rule priorities are:

1. MAC-based VLAN (Best match among the rules)
2. Subnet-based VLAN (Best match among the rules)
3. Protocol-based VLAN
4. PVID

EXAMPLE

The following example sets a protocol-based classification rule.

```
Console(config-if)# switchport general map protocols-group 1 vlan 8
```

**map mac macs-
group**

Use the **map mac macs-group** VLAN Configuration mode command to map a MAC address or range of MAC addresses to a group of MAC addresses. Use the **no** form of this command to delete the map.

SYNTAX

map mac *mac-address* {*prefix-mask* | *host*} **macs-group** *group*

no map mac *mac-address* {*prefix-mask* | *host*}

PARAMETERS

- ◆ **mac-address**—Specifies the MAC address to be mapped to the group.
- ◆ **prefix-mask**—Specifies the number of ones in the mask.
- ◆ **host**—Specifies that the mask is comprised of all 1s.
- ◆ **group**—Specifies the group number. (Range: 1–2147483647)

COMMAND MODE

VLAN Configuration mode

EXAMPLE

The following example maps a MAC address to a group of MAC addresses.

```
Console(config)# vlan database
Console(config-vlan)# map mac 0011.1111.1111 8 macs-group 1
```

switchport general map macs-group vlan

Use the **switchport general map macs-group vlan** Interface Configuration (Ethernet, Port-channel) mode command to set a mac-based classification rule. Use the no form of this command to delete a classification rule.

SYNTAX

switchport general map macs-group group vlan vlan-id
no switchport general map macs-group group

PARAMETERS

- ◆ **group**—Specifies the group number. (Range: 1–2147483647)
- ◆ **vlan-id**—Defines the VLAN ID associated with the rule.

COMMAND MODE

Interface Configuration (Ethernet, port-channel) mode

USER GUIDELINES

MAC-based VLAN rules cannot contain overlapping ranges on the same interface.

The VLAN classification rule priorities are:

1. MAC-based VLAN (Best match among the rules).
2. Subnet-based VLAN (Best match among the rules).
3. Protocol-based VLAN.
4. PVID.

EXAMPLE

The following example sets a mac-based classification rule.

```
Console (config-if)# switchport general map mac-group 1 vlan 8
```

**map subnet
subnets-group**

Use the **map subnet subnets-group** VLAN Configuration mode command to map an IP subnet to a group of IP subnets. Use the **no** form of this command to delete the map.

SYNTAX

map subnet *ip-address prefix-mask* **subnets-group** *group*
no map subnet *ip-address prefix-mask*

PARAMETERS

- ◆ **ip-address**—Specifies the IP address prefix of the subnet to be mapped to the group.
- ◆ **prefix-mask**—Specifies the number of 1s in the mask.
- ◆ **group**—Specifies the group number. (Range: 1–2147483647)

COMMAND MODE

VLAN Configuration mode

EXAMPLE

The following example maps an IP subnet to a group of IP subnets.

```
Console (config-vlan)# map subnet 172.16.1.1 24 subnets-group 4
```

**switchport general
map subnets-group
vlan**

Use the **switchport general map subnets-group vlan** Interface Configuration (Ethernet, Port-channel) mode command to set a subnet-based classification rule. Use the **no** form of this command to delete a subnet-based classification rule.

SYNTAX

switchport general map subnets-group *group* **vlan** *vlan-id*
no switchport general map subnets-group *group*

PARAMETERS

- ◆ **group**—Specifies the group number. (Range: 1–2147483647)
- ◆ **vlan-id**—Defines the VLAN ID associated with the rule.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

The VLAN classification rule priorities are:

1. MAC-based VLAN (Best match among the rules)
2. Subnet-based VLAN (Best match among the rules)
3. Protocol-based VLAN
4. PVID

EXAMPLE

The following example sets a subnet-based classification rule.

```
Console (config-if)# switchport general map subnets-group 1 vlan 8
```

show vlan Use the **show vlan** Privileged EXEC mode command to display VLAN information for all VLANs or for a specific VLAN.

SYNTAX

show vlan [*tag vlan-id* | *name vlan-name*]

PARAMETERS

- ◆ **tag vlan-id**—Specifies a VLAN ID.
- ◆ **name vlan-name**—Specifies a VLAN name string. (Length: 1–32 characters)

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays information for all VLANs.

```
Console# show vlan
```

VLAN	Name	Ports	Type	Authorization
----	-----	-----	-----	-----
1	default	te1-2	Other	Required
10	VLAN0010	te3-4	dynamic	Required
11	VLAN0011	te1-2	static	Required
20	VLAN0020	te3-4	static	Required
21	VLAN0021		static	Required
30	VLAN0030		static	Required
31	VLAN0031		static	Required
91	VLAN0091	te1-2	static	Not Required
3978	Guest VLAN	te17	static	Guest

show vlan protocols-groups Use the **show vlan protocols-groups** EXEC mode command to display protocols-groups information.

SYNTAX

show vlan protocols-groups

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays protocols-groups information.

```
Console> show vlan protocols-groups
```

Protocol	Encapsulation	Group
-----	-----	-----
0x800 (IP)	Ethernet	1
0x806 (ARP)	Ethernet	1
0x86dd (IPv6)	Ethernet	2
0x8898	Ethernet	3

show vlan macs-groups Use the **show vlan macs-groups** EXEC mode command to display macs-groups information.

SYNTAX

show vlan macs-groups

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays macs-groups information.

```
console# show vlan macs-groups
```

Mac Address	Mask	Group Id
00:12:34:56:78:90	20	22
00:60:70:4c:73:ff	40	1

show vlan subnets-groups Use the **show vlan subnets-groups** EXEC mode command to display subnets-groups information.

SYNTAX

show vlan subnets-groups

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays subnets-groups information.

```
console# show vlan subnets-groups
```

Ip Subnet Address	Mask	Group Id
1.1.1.1	32	1
172.16.2.0	24	2

show interfaces switchport Use the **show interfaces switchport** Privileged EXEC command to display the administrative and operational status of all interfaces or a specific interface.

SYNTAX

show interfaces switchport *[interface-id]*

PARAMETERS

Interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

EXAMPLE

```
Protected: Enabled, Uplink is gi1/0/1
```

```
Classification rules:
```

Classification type	Group ID	VLAN ID
-----	-----	-----
Protocol	1	19
Protocol	1	20
Protocol	2	72
Subnet	1	15
MAC	6	11

VIRTUAL LOCAL AREA NETWORK (VLAN) NON-ISCLI COMMANDS

iPECS ES-5048XG

switchport forbidden default- vlan

Use the **switchport forbidden default-vlan** interface configuration command to forbid a port from being added to the default VLAN. Use the **no** form of this command to revert to default.

SYNTAX

switchport forbidden default-vlan
no switchport forbidden default-vlan

PARAMETERS

This command has no keywords or arguments.

DEFAULT CONFIGURATION

Membership in the Default VLAN is allowed.

COMMAND MODE

Interface and Interface range configuration (Ethernet, port-channel)

USER GUIDELINES

The command may be used only when the Default VLAN is supported. If the Default VLAN is supported, the command may be used at any time regardless of if the port belongs to the Default VLAN.

The 'no' command does not add the port to Default VLAN; it only defines an interface as permitted to be a member of the Default VLAN, and the port will be added only when conditions are met.

switchport forbidden vlan

The **switchport forbidden vlan** Interface Configuration (Ethernet, Port-channel) mode command forbids adding or removing specific VLANs to or from a port. To restore the default configuration, use the **no** form of this command.

SYNTAX

switchport forbidden vlan {add *vlan-list* | remove *vlan-list*}
no switchport forbidden vlan {add *vlan-list* | remove *vlan-list*}

PARAMETERS

- ◆ **add *vlan-list*** — Specifies a list of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs.

- ◆ **remove** *vlan-list* — Specifies a list of VLAN IDs to remove. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen designate a range of IDs.

DEFAULT CONFIGURATION

All VLANs are allowed.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

EXAMPLE

The following example forbids adding VLAN IDs 234 to 256 to Ethernet port 1/7.

```
Console(config)# interface ethernet 1/7
Console(config-if)# switchport mode trunk
Console(config-if)# switchport forbidden vlan add 234-256
```

switchport default-vlan tagged

Use the **switchport default-vlan tagged** interface configuration command to configure the port as a tagged port in the default VLAN as a tagged port. Use the **no** form of the command to return to default.

SYNTAX

switchport default-vlan tagged
no switchport default-vlan tagged

PARAMETERS

This command has no keywords or arguments.

DEFAULT CONFIGURATION

If the port is a member in the default VLAN, it is a member as an untagged port.

COMMAND MODE

Interface configuration (Ethernet, port-channel)

USER GUIDELINES

The command adds a port to the default VLAN as a tagged port.

The command is available only if the port mode is trunk or general.

When a trunk port is a member in the default VLAN as a tagged port then:

The native VLAN can't be the default VLAN

The default of the native VLAN is 4095



NOTE: If the native VLAN of a port is the default VLAN when the port is added to the default VLAN as a tagged, the native VLAN is set by the system to 4095.

When a general port is a member in the default VLAN as a tagged port then:

1. The PVID can be the default VLAN.
2. The default of the PVID is the default VLAN



NOTE: The PVID is not changed when the port is added to the default VLAN as a tagged.

If one of the following conditions exists when executing the “switchport default-vlan tagged” command, the port would be added (automatically by the system) to the default VLAN when the condition does not longer exist:

The port is a member in a LAG.

The port is 802.1X unauthorized.

An IP address is defined on the port.

The port is a destination port of port mirroring.

An IP address is defined on the default VLAN and the port is a PVE protected port.

The “no switchport default-vlan tagged” command removes the port from the default VLAN, and return the default VLAN mode to “untagged”.



NOTE: If the native VLAN of a trunk port is 4095 when the port is removed from the default VLAN (as a tagged), the native VLAN is set by the system to the default VLAN.

NOTE: The PVID of a general port is not changed when the port is removed from the default VLAN (as a tagged). If the PVID is the default VLAN, the port is added by the system to the default VLAN as an untagged.

show interfaces switchport

The **show interfaces switchport** EXEC mode command displays the switchport configuration for all interfaces or for a specific interface.

SYNTAX

show interfaces switchport { *interface-id* }

PARAMETERS

interface-id—Specify an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel

COMMAND MODE

EXEC mode

EXAMPLE

The following examples display the switchport configuration.

```

Console> show interfaces switchport ethernet 1/1
Port 1/1:
VLAN Membership mode: General

PVID: 1 (default)
Ingress Filtering: Enabled
Acceptable Frame Type: All
GVRP status: Enabled
Protected: Enabled, Uplink is 1/9.

Port 1/1 is member in:

```

	VLAN Name	Egress rule	Type
	1	default	untaggedSystem
	8	VLAN008	taggedDynamic
11		VLAN0011	taggedStatic
19		IPv6VLAN	untaggedStatic
72		VLAN0072	untaggedStatic

```

Forbidden VLANs:

```

	VLAN Name
	73 Out

```

Classification rules:
Classification type
-----
Protocol based VLANs
Protocol based VLANs

```

	Group	VLAN
		219
		372

```

Console> show interfaces switchport ethernet 1/2
Port 1/2:
VLAN Membership mode: General

Operating parameters:
PVID: 4095 (discard vlan)
Ingress Filtering: Enabled
Acceptable Frame Type: All
GVRP status: Enabled
Protected: Disabled

Port 1/1 is member in:

```

	VLAN Name	Egress rule	Type
91	IP Telephony	tagged	Static

```

Protected: Disabled

Port 1/2 is statically configured to:

```

	VLAN Name	Egress rule

```

8          VLAN0072untagged
91         IP Telephony    tagged

```

Forbidden VLANS:

```

          VLAN Name
-----
          73 Out

```

```
Console> show interfaces switchport ethernet 1/2
```

```
Port 1/2:
```

```
VLAN Membership mode: Access
```

```
Access VLAN: Dynamic
```

```
PVID: 9
```

```
Ingress Filtering: Enabled
```

```
Acceptable Frame Type: All
```

```
GVRP status: Enabled
```

```
VLAN Membership:
```

```

          VLAN NameEgress rule
          -----
8          VLAN0072untagged

```

ip igmp snooping (Global) Use the **ip igmp snooping** Global Configuration mode command to enable Internet Group Management Protocol (IGMP) snooping. Use the **no** form of this command to disable IGMP snooping.

SYNTAX

ip igmp snooping
no ip igmp snooping

DEFAULT CONFIGURATION

IGMP snooping is disabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables IGMP snooping.

```
Console(config)# ip igmp snooping
```

ip igmp snooping vlan Use the **ip igmp snooping vlan** Global Configuration mode command to enable Internet Group Management Protocol (IGMP) snooping on a specific VLAN. Use the **no** form of this command to disable IGMP snooping on a VLAN interface.

SYNTAX

ip igmp snooping vlan *vlan-id*
no ip igmp snooping vlan *vlan-id*

PARAMETERS

vlan-id—Specifies the VLAN.

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

USER GUIDELINES

IGMP snooping can be enabled only on static VLANs.

IGMPv1, IGMPv2 and IGMPv3 are supported.

To activate IGMP snooping, the **bridge multicast filtering** should be enabled.

The User Guidelines of the bridge multicast mode Interface VLAN Configuration command describes the configuration that is written into the FDB as a function of the FDB mode and the IGMP version that is used in the network.

EXAMPLE

```
console(config)# ip igmp snooping vlan 2
```

**ip igmp snooping
mrouter**

Use the **ip igmp snooping mrouter** Global Configuration mode command to enable automatic learning of multicast router ports. Use the **no** form of this command to remove the configuration.

SYNTAX

ip igmp snooping *vlan vlan-id* **mrouter** *learn pim-dvmrp*
no ip igmp snooping *vlan vlan-id* **mrouter** *learn pim-dvmrp*

PARAMETERS

vlan-id—Specifies the VLAN.

DEFAULT

Learning pim-dvmrp is enabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Multicast router ports are learned based on:

- ◆ Queries received on the port
- ◆ PIM/PIMv2 received on the port
- ◆ DVMRP received on the port
- ◆ MRDISC received on the port
- ◆ MOSPF received on the port

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# ip igmp snooping vlan 1 mrouter learn pim-dvmrp
```

**ip igmp snooping
mrouter interface**

Use the **ip igmp snooping mrouter interface** Global Configuration mode command to define a port that is connected to a multicast router port. Use the **no** form of this command to remove the configuration.

SYNTAX

ip igmp snooping *vlan vlan-id* **mrouter interface** *interface-list*
no ip igmp snooping *vlan vlan-id* **mrouter interface** *interface-list*

PARAMETERS

- ◆ **vlan-id**—Specifies the VLAN.
- ◆ **interface-list**—Specifies the list of interfaces. The interfaces can be one of the following types: Ethernet port or Port-channel.

DEFAULT

No ports defined

COMMAND MODE

Global Configuration mode

USER GUIDELINES

A port that is defined as a multicast router port receives all IGMP packets (reports and queries) as well as all multicast data.

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# ip igmp snooping vlan 1 mrouter interface tel
```

**ip igmp snooping
forbidden mrouter
interface**

Use the **ip igmp snooping forbidden mrouter interface** Global Configuration mode command to forbid a port from being defined as a multicast router port by static configuration or by automatic learning. Use the **no** form of this command to remove the configuration.

SYNTAX

ip igmp snooping *vlan vlan-id* **forbidden mrouter interface** *interface-list*
no ip igmp snooping *vlan vlan-id* **forbidden mrouter interface** *interface-list*

PARAMETERS

- ◆ **vlan-id**—Specifies the VLAN.
- ◆ **interface-list**—Specifies a list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

DEFAULT

No ports defined

COMMAND MODE

Global Configuration mode

USER GUIDELINES

A port that is a forbidden mrouter port cannot be a multicast router port (i.e. cannot be learned dynamically or assigned statically).

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# ip igmp snooping vlan 1 forbidden mrouter interface tel
```

ip igmp snooping static

Use the **ip igmp snooping static** Global Configuration mode command to register an IP-layer multicast address to the bridge table, and to add statically ports to the group. Use the **no** form of this command to remove ports specified as members of a static multicast group.

SYNTAX

ip igmp snooping *vlan* *vlan-id* **static** *ip-address* [*interface interface-list*]

no ip igmp snooping *vlan* *vlan-id* **static** *ip-address* [*interface interface-list*]

PARAMETER

- ◆ **vlan-id**—Specifies the VLAN.
- ◆ **ip-address**—Specifies the IP multicast address.
- ◆ **interface-list**—Specifies a list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

DEFAULT CONFIGURATION

No multicast addresses are defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Static multicast addresses can only be defined on static VLANs.

You can execute the command before the VLAN is created.

You can register an entry without specifying an interface.

Using the **no**. command without a port-list removes the entry.

EXAMPLE

```
console(config)# ip igmp snooping vlan 1 static 239.2.2.2 te
```

ip igmp snooping querier

Use the **ip igmp snooping querier** Global Configuration mode command to enable the Internet Group Management Protocol (IGMP) querier on a specific VLAN. Use the **no** form of this command to disable the IGMP querier on a VLAN interface.

SYNTAX

ip igmp snooping vlan *vlan-id* querier

no ip igmp snooping vlan *vlan-id* querier

PARAMETERS

vlan-id—Specifies the VLAN

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The IGMP snooping querier can be enabled on a VLAN only if IGMP snooping is enabled for that VLAN.

No more than one switch can be configured as an IGMP Querier for a VLAN.

When the IGMP snooping querier is enabled, it starts after a host-time-out/ 2 with no IGMP traffic detected from a multicast router.

The IGMP Snooping Querier disables itself if it detects IGMP traffic from a multicast router. It restarts automatically after host-time-out/2.

Following are the IGMP snooping querier parameters as a function of the IGMP snooping parameters:

- ◆ QueryMaxResponseTime: host-time-out/10.
- ◆ QueryInterval: host-time-out/ 3.

EXAMPLE

```
console(config)# ip igmp snooping vlan 1 querier
```

ip igmp snooping querier address

Use the **ip igmp snooping querier address** Global Configuration mode command to define the source IP address that the IGMP snooping querier would use. Use the **no** form of this command to return to default.

SYNTAX

ip igmp snooping *vlan vlan-id* **querier address** *ip-address*

no ip igmp snooping *vlan vlan-id* **querier address**

PARAMETERS

- ◆ **vlan-id**—Specifies the VLAN.
- ◆ **ip-address**—Source IP address.

DEFAULT

If an IP address is configured for the VLAN, it is used as the source address of the IGMP snooping querier.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

If an IP address is not configured by this command, and no IP address is configured for the querier's VLAN, the querier is disabled.

EXAMPLE

```
console(config)# ip igmp snooping vlan 1 querier address 1.2.3.4
```

ip igmp snooping querier version

Use the **ip igmp snooping querier version** Global Configuration mode command to configure the IGMP version of an IGMP querier on a specific VLAN. Use the **no** form of this command to return to default.

SYNTAX

ip igmp snooping *vlan vlan-id* **querier version** {2 | 3}

no ip igmp snooping *vlan vlan-id* **querier version**

PARAMETERS

- ◆ **vlan-id**—Specifies the VLAN.
- ◆ **2**—Specifies that the IGMP version would be IGMPv2.

- ◆ **3**—Specifies that the IGMP version would be IGMPv3.

DEFAULT
IGMPv2.

COMMAND MODE
Global Configuration mode

EXAMPLE

```
console(config)# ip igmp snooping vlan 1 querier version 3
```

ip igmp robustness Use the **ip igmp robustness** Interface Configuration mode command to change a value of the IGMP robustness variable. Use the **no** format of the command to return to default.

SYNTAX

ip igmp robustness *count*
no ip igmp robustness

PARAMETERS

count—The number of expected packet loss on a link. Parameter range. (Range: 1–7)

DEFAULT
2

COMMAND MODE
Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

```
console(config)# interface vlan 1
console(config-if)# ip igmp robustness 3
```

ip igmp query-interval Use the **ip igmp query-interval** Interface Configuration mode command to configure the Query interval. Use the **no** format of the command to return to default.

SYNTAX

ip igmp query-interval *seconds*
no ip igmp query-interval

PARAMETERS

seconds—Frequency, in seconds, at which IGMP query messages are sent on the interface. (Range: 30–18000)

DEFAULT

125

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ip igmp query-interval 300
```

ip igmp query-max-response-time

Use the **ip igmp query-max-response-time** Interface Configuration mode command to configure the Query Maximum Response time. Use the **no** format of the command to return to default.

SYNTAX

ip igmp query-max-response-time *seconds*
no ip igmp query-max-response-time

PARAMETERS

seconds—Maximum response time, in seconds, advertised in IGMP queries. (Range: 5–20)

DEFAULT

10

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ip igmp query-max-response-time 5
```

ip igmp last-member-query-count

Use the **ip igmp last-member-query-count** Interface Configuration mode command to configure the Last Member Query Counter. Use the **no** format of the command to return to default.

SYNTAX

ip igmp last-member-query-count *count*
no ip igmp last-member-query-count

PARAMETER

count—The number of times that group- or group-source-specific queries are sent upon receipt of a message indicating a leave. (Range: 1–7)

DEFAULT

A value of Robustness variable

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ip igmp last-member-query-count 3
```

ip igmp last-member-query-interval

Use the **ip igmp last-member-query-interval** Interface Configuration mode command to configure the Last Member Query interval. Use the **no** format of the command to return to default.

SYNTAX

ip igmp last-member-query-interval *milliseconds*
no ip igmp last-member-query-interval

PARAMETERS

milliseconds—Interval, in milliseconds, at which IGMP group-specific host query messages are sent on the interface. (Range: 100–25500)

DEFAULT

1000

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ip igmp last-member-query-interval 3000
```

**ip igmp snooping
vlan immediate-
leave**

Use the **ip igmp snooping vlan immediate-leave** Global Configuration mode command to enable the IGMP Snooping Immediate-Leave processing on a VLAN. Use the **no** format of the command to disable IGMP Snooping Immediate-Leave processing.

SYNTAX

ip igmp snooping vlan *vlan-id* immediate-leave
no ip igmp snooping vlan *vlan-id* immediate-leave

PARAMETERS

vlan-id—Specifies the VLAN ID value. (Range: 1–4094)

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# ip igmp snooping vlan 1 immediate-leave
```

**show ip igmp
snooping mrouter**

The **show ip igmp snooping mrouter** EXEC mode command displays information on dynamically learned multicast router interfaces for all VLANs or for a specific VLAN.

SYNTAX

show ip igmp snooping mrouter [*interface vlan-id*]

PARAMETERS

interface *vlan-id*—Specifies the VLAN ID.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays information on dynamically learned multicast router interfaces for VLAN 1000.

```
Console# show ip igmp snooping mrouter interface 1000
```

VLAN	Static	Dynamic	Forbidden
-----	-----	-----	-----
1000	te1	te2	te3-te23

show ip igmp snooping interface

The **show ip igmp snooping interface** EXEC mode command displays the IGMP snooping configuration for a specific VLAN.

SYNTAX

show ip igmp snooping interface *vlan-id*

PARAMETERS

vlan-id—Specifies the VLAN ID.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the IGMP snooping configuration for VLAN 1000.

```
Console # show ip igmp snooping interface 1000
IGMP Snooping is globally enabled
IGMP Snooping admin: Enabled
IGMP Snooping oper: Enabled
Routers IGMP version: 3
Groups that are in IGMP version 2 compatibility mode:
231.2.2.3, 231.2.2.3
Groups that are in IGMP version 1 compatibility mode:

IGMP snooping querier admin: Enabled
IGMP snooping querier oper: Enabled
IGMP snooping querier address admin:
IGMP snooping querier address oper: 172.16.1.1
IGMP snooping querier version admin: 3

IGMP snooping robustness: admin 2 oper 2
IGMP snooping query interval: admin 125 sec oper 125 sec
IGMP snooping query maximum response: admin 10 sec oper 10 sec
IGMP snooping last member query counter: admin 2 oper 2
IGMP snooping last member query interval: admin 1000 msec oper 500 msec
IGMP snooping last immediate leave: enable

Automatic learning of multicast router ports is enabled
```

show ip igmp snooping groups The **show ip igmp snooping groups** EXEC mode command displays the multicast groups learned by the IGMP snooping.

SYNTAX

show ip igmp snooping groups [*vlan vlan-id*] [*address ip-multicast-address*] [*source ip-address*]

PARAMETERS

vlan vlan-id—Specifies the VLAN ID.

address ip-multicast-address—Specifies the IP multicast address.

source ip-address—Specifies the IP source address.

COMMAND MODE

EXEC mode

USER GUIDELINES

To see the full multicast address table (including static addresses), use the **show bridge multicast address-table** command.

The Include list contains the ports which are in forwarding state for this group according to the snooping database. In general, the Exclude list contains the ports that have issued an explicit Exclude for that specific source in a multicast group. The Reporters That Are Forbidden Statically list contains the list of ports which have asked to receive a multicast flow but were defined as forbidden for that multicast group in multicast bridge.



NOTE: Under certain circumstances, the Exclude list may not contain accurate information. For example, in the case when two Exclude reports were received on the same port for the same group but for different sources, the port will not be in the Exclude list but rather in the Include list.

EXAMPLE

The following example shows the output for IGMP version 2.

```
Console# show ip igmp snooping groups
```

Vlan	IP Address	Querier	Ports
----	-----	-----	-----
1	231.2.2.2	Yes	te1
1	231.2.2.3	No	te2
19	231.2.2.4	Yes	te9

ipv6 mld snooping (Global) The **ipv6 mld snooping** Global Configuration mode command enables IPv6 Multicast Listener Discovery (MLD) snooping. To disable IPv6 MLD snooping, use the **no** form of this command.

SYNTAX

ipv6 mld snooping
no ipv6 mld snooping

DEFAULT CONFIGURATION

IPv6 MLD snooping is disabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables IPv6 MLD snooping.

```
Console(config)# ip ipv6 mld snooping
```

ipv6 mld snooping vlan Use the **ipv6 mld snooping vlan** Global Configuration mode command to enable MLD snooping on a specific VLAN. Use the **no** form of this command to disable MLD snooping on a VLAN interface.

SYNTAX

ipv6 mld snooping vlan *vlan-id*
no ipv6 mld snooping vlan *vlan-id*

PARAMETERS

vlan-id—Specifies the VLAN.

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

USER GUIDELINES

MLD snooping can only be enabled on static VLANs.

MLDv1 and MLDv2 are supported.

To activate MLD snooping, the Bridge Multicast Filtering command should be enabled.

The user guidelines of the bridge multicast IPv6 mode interface VLAN configuration command describe the configuration that can be written into the FDB as a function of the FDB mode, and the MLD version that is used in the network.

EXAMPLE

```
console(config)# ipv6 mld snooping vlan 2
```

ipv6 mld robustness Use the **ipv6 mld robustness** interface Configuration mode command to change a value of the IGMP robustness variable. Use the **no** format of the command to return to default.

SYNTAX

ipv6 mld robustness *count*

no ipv6 mld robustness

PARAMETERS

countThe number of expected packet losses on a link. (Range: 1–7)

DEFAULT

2

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ipv6 mld robustness 3
```

ipv6 mld snooping mrouter Use the **ipv6 mld snooping mrouter** Global Configuration mode command to enable automatic learning of multicast router ports. Use the **no** form of this command to remove the configuration.

SYNTAX

ipv6 mld snooping *vlan vlan-id* **mrouter** *learn pim-dvmrp*

no ipv6 mld snooping *vlan vlan-id* **mrouter** *learn pim-dvmrp*

PARAMETERS

vlan-id—Specifies the VLAN.

DEFAULT

Learning **pim-dvmrp** is enabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Multicast router ports can be configured statically with the **bridge multicast forward-all** command.

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# ipv6 mld snooping vlan 1 mrouter learn pim-dvmrp
```

ipv6 mld snooping mrouter interface

Use the **ipv6 mld snooping mrouter interface** Global Configuration mode command to define a port that is connected to a multicast router port. Use the **no** form of this command to remove the configuration.

SYNTAX

```
ipv6 mld snooping vlan vlan-id mrouter interface interface-list  
no ipv6 mld snooping vlan vlan-id mrouter interface interface-list
```

PARAMETERS

- ◆ **vlan-id**—Specifies the VLAN.
- ◆ **interface-list**—Specifies a list of interfaces. The interfaces can be from one of the following types: Ethernetport or Port-channel.

DEFAULT

No ports defined

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command may be used in conjunction with the **bridge multicast forward-all** command, which is used in older versions to statically configure a port as a multicast router.

A port that is defined as a multicast router port receives all MLD packets (reports and queries) as well as all multicast data.

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# ipv6 mld snooping vlan 1 mrouter interface tel
```

**ipv6 mld snooping
forbidden mrouter
interface**

Use the **ipv6 mld snooping forbidden mrouter interface** Global Configuration mode command to forbid a port from being defined as a multicast router port by static configuration or by automatic learning. Use the **no** form of this command to remove the configuration.

SYNTAX

ipv6 mld snooping *vlan vlan-id* **forbidden mrouter interface**
interface-list

no ipv6 mld snooping *vlan vlan-id* **forbidden mrouter interface**
interface-list

PARAMETERS

- ◆ **vlan-id**—Specifies the VLAN.
- ◆ **interface-list**—Specifies list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

DEFAULT

No forbidden ports by default

COMMAND MODE

Global Configuration mode

USER GUIDELINES

A port that is forbidden mrouter port cannot be a multicast router port (i.e. cannot be learned dynamically or assigned statically).

The command bridge **multicast forbidden forward-all** command was used in older versions to forbid dynamic learning of multicast router ports.

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# ipv6 mld snooping vlan 1 forbidden mrouter interface tel
```

ipv6 mld snooping static Use the **ipv6 mld snooping static** Global Configuration mode command to register a IPv6-layer multicast address to the bridge table, and to add statically ports to the group. Use the **no** form of this command to remove ports specified as members of a static multicast group.

SYNTAX

ipv6 mld snooping *vlan vlan-id* **static** *ipv6-address interface*
[interface-list]

no ipv6 mld snooping *vlan vlan-id* **static** *ipv6-address interface*
[interface-list]

PARAMETERS

- ◆ **vlan-id**—Specifies the VLAN.
- ◆ **ipv6-address**—Specifies the IP multicast address
- ◆ **interface-list**—Specifies list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

DEFAULT CONFIGURATION

No multicast addresses are defined.

COMMAND MODE

Global configuration mode

USER GUIDELINES

Static multicast addresses can only be defined on static VLANs.

You can execute the command before the VLAN is created.

You can register an entry without specifying an interface.

Using the **no** command without a port-list removes the entry.

EXAMPLE

```
console(config)# ipv6 mld snooping vlan 1 static 239.2.2.2 tel
```

ipv6 mld query-interval Use the **ipv6 mld query-interval** Interface Configuration mode command to configure the Query interval. Use the **no** format of the command to return to default.

SYNTAX

ipv6 mld query-interval *seconds*

ipv6 mld query-interval

PARAMETERS

seconds—Frequency, in seconds, at which MLD query messages are sent on the interface. (Range: 30–18000)

DEFAULT

125

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ipv6 mld query-interval 3000
```

ipv6 mld query-max-response-time

Use the **ipv6 mld query-max-response-time** Interface Configuration mode command to configure the Query Maximum Response time. Use the **no** format of the command to return to default.

SYNTAX

ipv6 mld query-max-response-time *seconds*

no ipv6 mld query-max-response-time

PARAMETER

seconds—Maximum response time, in seconds, advertised in MLD queries. (Range: 5–20)

DEFAULT

10

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ipv6 mld query-max-response-time 5
```

ipv6 mld last-member-query-count Use the **ipv6 mld last-member-query-count** Interface Configuration mode command to configure the Last Member Query Counter. Use the **no** format of the command to return to default.

SYNTAX

ipv6 mld last-member-query-count *count*
no ipv6 mld last-member-query-count

PARAMETERS

count—The number of times that group- or group-source-specific queries are sent upon receipt of message indicating a leave. (Range: 1–7)

DEFAULT

A value of Robustness variable

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ipv6 mld last-member-query-count 3
```

ipv6 mld last-member-query-interval Use the **ipv6 mld last-member-query-interval** interface configuration command to configure the Last Member Query Interval. Use the **no** format of the command to return to default.

SYNTAX

ipv6 mld last-member-query-interval *milliseconds*
no ipv6 mld last-member-query-interval

PARAMETER

milliseconds—Interval, in milliseconds, at which IGMP group-specific host query messages are sent on the interface. (Range: 100–64512).

DEFAULT

1000

COMMAND MODE

Interface Configuration (VLAN) mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ipv6 mld last-member-query-interval 2000
```

**ipv6 mld snooping
vlan immediate-
leave**

Use the **ipv6 mld snooping vlan immediate-leave** Global Configuration mode command to enable MLD Snooping Immediate-Leave processing on a VLAN. Use the **no** format of the command to return to disable MLD Snooping Immediate-Leave processing.

SYNTAX

ipv6 mld snooping vlan *vlan-id* **immediate-leave**
no ipv6 mld snooping vlan *vlan-id* **immediate-leave**

PARAMETERS

vlan-id—Specifies the VLAN ID value. (Range: 1–4094)

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

USER GUIDELINES

You can execute the command before the VLAN is created.

EXAMPLE

```
console(config)# ipv6 mld snooping vlan 1 immediate-leave
```

**show ipv6 mld
snooping mrouter**

The **show ipv6 mld snooping mrouter** EXEC mode command displays information on dynamically learned multicast router interfaces for all VLANs or for a specific VLAN.

SYNTAX

show ipv6 mld snooping mrouter [*interface vlan-id*]

PARAMETERS

interface vlan-id—Specifies the VLAN ID.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays information on dynamically learned multicast router interfaces for VLAN 1000

```
Console# show ipv6 mld snooping mrouter interface 1000
VLAN    Static    Dynamic    Forbidden
----    -
1000    te1         te2        te3-23
```

show ipv6 mld snooping interface

The **show ipv6 mld snooping interface** EXEC mode command displays the IPv6 MLD snooping configuration for a specific VLAN.

SYNTAX

show ipv6 mld snooping interface *vlan-id*

PARAMETERS

vlan-id—Specifies the VLAN ID.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the MLD snooping configuration for VLAN 1000.

```
Console# show ipv6 mld snooping interface 1000

MLD Snooping is globally enabled

MLD Snooping admin: Enabled
MLD snooping oper mode: Enabled
Routers MLD version: 2
Groups that are in MLD version 1 compatibility mode:
FF12::3, FF12::8

MLD snooping robustness:                admin 2  oper 2
MLD snooping query interval: admin 125 sec  oper 125 sec
MLD snooping query maximum response: admin 10 sec  oper 10 sec
MLD snooping last member query counter: admin 2  oper 2
MLD snooping last member query interval: admin 1000 msec  oper 600 msec
MLD snooping last immediate leave: enable
Automatic learning of multicast router ports is enabled
```

show ipv6 mld snooping groups

The **show ipv6 mld snooping groups** EXEC mode command displays the multicast groups learned by the MLD snooping.

SYNTAX

show ipv6 mld snooping groups [*vlan vlan-id*] [*address ipv6-multicast-address*] [*source ipv6-address*]

PARAMETERS

- ◆ **vlan vlan-id**—Specifies the VLAN ID.
- ◆ **address ipv6-multicast-address**—Specifies the IPv6 multicast address.
- ◆ **source ipv6-address**—Specifies the IPv6 source address.

COMMAND MODE

EXEC mode

USER GUIDELINES

To see the full multicast address table (including static addresses), use the **show bridge multicast address-table** command.

The Include list contains the ports which are in a forwarding state for this group according to the snooping database. In general, the Exclude list contains the ports which have issued an explicit Exclude for that specific source in a multicast group.

The Reporters That Are Forbidden Statically list contains the list of ports which have asked to receive a multicast flow but were defined as forbidden for that multicast group in a multicast bridge.



NOTE: Under certain circumstances, the Exclude list may not contain accurate information; for example, in the case when two Exclude reports were received on the same port for the same group but for different sources, the port will not be in the Exclude list but rather in the Include list.

EXAMPLE

The following example shows the output for IPv6 MLD version 2.

```
Console# show ipv6 mld snooping groups
```

Vlan	Group Address	Source Address	Include Ports	Exclude Ports	Compatibility Mode
1	FF12::3	FE80::201:C9FF:FE40:8001	te1		1
1	FF12::3	FE80::201:C9FF:FE40:8002	te2		1
19	FF12::8	FE80::201:C9FF:FE40:8003	te9		2
19	FF12::8	FE80::201:C9FF:FE40:8004	te1	te12	2
19	FF12::8	FE80::201:C9FF:FE40:8005	te0-11	te12	2

MLD Reporters that are forbidden statically:

Vlan	Group Address	Source address	Ports
1	FF12::3	FE80::201:C9FF:FE40:8001	te8
19	FF12::8	FE80::201:C9FF:FE40:8001	te8

LINK AGGREGATION CONTROL PROTOCOL (LACP) COMMANDS

iPECS ES-5048XG

lacp system-priority Use the **lacp system-priority** Global Configuration mode command to set the system priority. Use the **no** form of this command to restore the default configuration.

SYNTAX

lacp system-priority *value*
no lacp system-priority

PARAMETERS

value—Specifies the system priority value. (Range: 1–65535)

DEFAULT CONFIGURATION

The default system priority is 1.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example sets the system priority to 120.

```
Console(config)# lacp system-priority 120
```

lacp port-priority Use the **lacp port-priority** Interface Configuration (Ethernet) mode command to set the physical port priority. Use the **no** form of this command to restore the default configuration.

SYNTAX

lacp port-priority *value*
no lacp port-priority

PARAMETERS

value—Specifies the port priority. (Range: 1–65535) Use the **no** form of this command to restore the default configuration.

DEFAULT CONFIGURATION

The default port priority is 1.

COMMAND MODE

Interface Configuration (Ethernet) mode

EXAMPLE

The following example sets the priority of tengigabitethernet port 0/6.

```
console(config)# interface te6
console(config-if)# lacp port-priority 247
```

lacp timeout Use the **lacp timeout** Interface Configuration (Ethernet) mode command to assign an administrative LACP timeout to an interface. Use the **no** form of this command to restore the default configuration.

SYNTAX**lacp timeout** {*long* | *short*}**no lacp timeout****PARAMETERS**

- ◆ **long**—Specifies the long timeout value.
- ◆ **short**—Specifies the short timeout value.

DEFAULT CONFIGURATION

The default port timeout value is Long.

COMMAND MODE

Interface Configuration (Ethernet) mode

EXAMPLE

The following example assigns a long administrative LACP timeout to tengigabitethernet port 0/6.

```
Console(config)# interface tengigabitethernet 0/6
Console(config-if)# lacp timeout long
```

show lacp Use the **show lacp** EXEC mode command to display LACP information for all Ethernet ports or for a specific Ethernet port.

SYNTAX**show lacp** *interface-id* [*parameters* | *statistics* | *protocol-state*]**PARAMETERS**

- ◆ **parameters**—Displays parameters only.
- ◆ **statistics**—Displays statistics only.

- ◆ **protocol-state**—Displays protocol state only.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays LACP information for tengigabitethernet port 0/1.

```
Console> show lacp ethernet tel
```

Port tel LACP parameters:

Actor

```

system priority:          1
system mac addr:         00:00:12:34:56:78
port Admin key:          30
port Oper key:           30
port Oper number:        21
port Admin priority:     1
port Oper priority:      1
port Admin timeout:      LONG
port Oper timeout:       LONG
LACP Activity:           ACTIVE
Aggregation:             AGGREGATABLE
synchronization:        FALSE
collecting:              FALSE
distributing:            FALSE
expired:                 FALSE

```

Partner

```

system priority:          0
system mac addr:         00:00:00:00:00:00
port Admin key:          0
port Oper key:           0
port Oper number:        0
port Admin priority:     0
port Oper priority:      0
port Admin timeout:      LONG
port Oper timeout:       LONG
LACP Activity:           PASSIVE
Aggregation:             AGGREGATABLE
synchronization:        FALSE
collecting:              FALSE
distributing:            FALSE
expired:                 FALSE

```

Port tel LACP Statistics:

```

LACP PDUs sent:          2
LACP PDUs received:      2

```

Port tel LACP Protocol State:

LACP State Machines:

```

Receive FSM:             Port Disabled State
Mux FSM:                 Detached State

```

Control Variables:

```

BEGIN:                                FALSE
LACP_Enabled:                        TRUE
Ready_N:                            FALSE
Selected:                            UNSELECTED
Port_moved:                          FALSE
NNT:                                  FALSE
Port_enabled:                        FALSE

Timer counters:

    periodic tx timer:                0
    current while timer:              0
    wait while timer:                 0

```

show lacp port-channel Use the **show lacp port-channel** EXEC mode command to display LACP information for a port-channel.

SYNTAX

show lacp port-channel [*port_channel_number*]

PARAMETERS

port_channel_number—Specifies the port-channel number.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays LACP information about port-channel 1.

```

Console> show lacp port-channel 1

Port-Channel 1:Port Type 1000 Ethernet

Actor

    System                1
    Priority:              000285:0E1C00
    MAC Address:          29
    Admin Key:             29
    Oper Key:

Partner

    System                0
    Priority:              00:00:00:00:00:00
    MAC Address:          14
    Oper Key:

```

GARP VLAN REGISTRATION PROTOCOL (GVRP) COMMANDS

iPECS ES-5048XG

gvrp enable (Global) Use the **gvrp enable** Global Configuration mode command to enable the Generic Attribute Registration Protocol (GARP) VLAN Registration Protocol (GVRP) globally. Use the **no** form of this command to disable GVRP on the device.

SYNTAX

gvrp enable
no gvrp enable

DEFAULT CONFIGURATION

GVRP is globally disabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables GVRP globally on the device.

```
Console(config)# gvrp enable
```

gvrp enable (Interface) Use the **gvrp enable** Interface Configuration (Ethernet, Port-channel) mode command to enable GVRP on an interface. Use the **no** form of this command to disable GVRP on an interface.

SYNTAX

gvrp enable
no gvrp enable

DEFAULT CONFIGURATION

GVRP is disabled on all interfaces.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

An access port does not dynamically join a VLAN because it is always a member of one VLAN only. Membership in an untagged VLAN is propagated

in the same way as in a tagged VLAN. That is, the PVID must be manually defined as the untagged VLAN VID.

EXAMPLE

The following example enables GVRP on tengigabitethernet port 0/6.

```
Console(config)# interface tengigabitethernet 0/6
Console(config-if)# gvrp enable
```

garp timer Use the **garp timer** Interface Configuration (Ethernet, port channel) mode command to adjust the values of the join, leave and leaveall timers of GARP applications, such as GVRP. Use the **no** form of this command to restore the default configuration.

SYNTAX

garp timer {*join* | *leave* | *leaveall*} *timer-value*
no garp timer

PARAMETERS

- ◆ **join** | **leave** | **leaveall**—Specifies the type of timer for which the timer value is specified. The possible values are:
 - **join**—Specifies the GARP join timer. The GARP join timer value specifies the time interval between the two join messages sent by the GARP application.
 - **leave**—Specifies the GARP leave timer. The GARP leave timer value specifies the time interval for a GARP application to wait for a join message after receiving a leave message for a GARP attribute, before it de-registers the GARP attribute.
 - **leaveall**—Specifies the GARP leaveall timer. The GARP leaveall timer value specifies the time interval between leaveall messages for a GARP entity, which prompt other GARP entities to re-reregister all attribute information on this entity.
- ◆ **timer-value**—Specifies the timer value in milliseconds in multiples of 10. (Range: 10–2147483640)

DEFAULT CONFIGURATION

The following are the default timer values:

- ◆ **Join timer**—200 milliseconds
- ◆ **Leave timer**—600 milliseconds
- ◆ **Leaveall timer**—10000 milliseconds

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

The **timer-value** value must be a multiple of 10.

The following relationship must be maintained between the timers:

- ◆ The leave time must be greater than or equal to three times the join time.
- ◆ The leave-all time must be greater than the leave time.

Set the same GARP timer values on all Layer 2-connected devices to ensure proper operation of the GARP application.

EXAMPLE

The following example sets the leave timer for tengigabitethernet port 0/6 to 900 milliseconds.

```
Console(config)# interface tengigabitethernet 0/6
Console(config-if)# garp timer leave 900
```

gvrp vlan-creation-forbid

Use the **gvrp vlan-creation-forbid** Interface Configuration (Ethernet, Port-channel) mode command to disable dynamic VLAN creation or modification. Use the **no** form of this command to enable dynamic VLAN creation or modification.

SYNTAX

gvrp vlan-creation-forbid
no gvrp vlan-creation-forbid

DEFAULT CONFIGURATION

Dynamic VLAN creation or modification is enabled.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

EXAMPLE

The following example disables dynamic VLAN creation on tengigabitethernet port 0/3.

```
Console(config)# interface tengigabitethernet 0/3
Console(config-if)# gvrp vlan-creation-forbid
```

gvrp registration-forbid Use the **gvrp registration-forbid** Interface Configuration (Ethernet, Port-channel) mode command to deregister all dynamic VLANs on a port and prevent VLAN creation or registration on the port. Use the **no** form of this command to allow dynamic registration of VLANs on a port.

SYNTAX

gvrp registration-forbid
no gvrp registration-forbid

DEFAULT CONFIGURATION

Dynamic registration of VLANs on the port is allowed.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

EXAMPLE

The following example forbids dynamic registration of VLANs on tengigabitethernet port 0/2.

```
Console(config)# interface tengigabitethernet 0/2  
Console(config-if)# gvrp registration-forbid
```

clear gvrp statistics Use the **clear gvrp statistics** Privileged EXEC mode command to clear GVRP statistical information for all interfaces or for a specific interface.

SYNTAX

clear gvrp statistics [*interface-id*]

PARAMETERS

Interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example clears all GVRP statistical information on tengigabitethernet port 0/5.

```
Console# clear gvrp statistics ethernet 5
```

show gvrp configuration Use the **show gvrp configuration** EXEC mode command to display GVRP configuration information, including timer values, whether GVRP and dynamic VLAN creation are enabled, and which ports are running GVRP.

SYNTAX

show gvrp configuration [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays GVRP configuration information.

```
console# show gvrp configuration
```

```
GVRP Feature is currently Enabled on the device.
Maximum VLANs: 4094
```

Port(s)	GVRP-Status	Regist- ration	Dynamic VLAN Creation	Timers(ms) Join	Leave Leave All
te1	Enabled	Forbidden	Disabled	200	600 10000
te2	Enabled	Normal	Enabled	400	1200 20000

show gvrp statistics Use the **show gvrp statistics** EXEC mode command to display GVRP statistics for all interfaces or for a specific interface.

SYNTAX

show gvrp statistics [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays GVRP statistical information.

```
Console# show gvrp statistics
```

```
GVRP statistics:
```

```
-----
```

```
Legend:
```

```

rJE : Join Empty Received      rJIn: Join In Received
rEmp: Empty Received          rLIn: Leave In Received
rLE : Leave Empty Received    rLA : Leave All Received
sJE : Join Empty Sent         sJIn: Join In Sent
sEmp: Empty Sent              sLIn: Leave In Sent
sLE : Leave Empty Sent        sLA : Leave All Sent

```

Port	rJE	rJIn	rEmp	rLIn	rLE	rLA	sJE	sJIn	sEmp	sLIn	sLE	sLA
----	----	----	----	----	----	----	----	----	----	----	----	----
1	0	0	0	0	0	0	0	0	0	0	0	0
2	0	0	0	0	0	0	0	0	0	0	0	0
3	0	0	0	0	0	0	0	0	0	0	0	0
4	0	0	0	0	0	0	0	0	0	0	0	0
5	0	0	0	0	0	0	0	0	0	0	0	0
6	0	0	0	0	0	0	0	0	0	0	0	0
7	0	0	0	0	0	0	0	0	0	0	0	0
8	0	0	0	0	0	0	0	0	0	0	0	0

show gvrp error-statistics Use the **show gvrp error-statistics** EXEC mode command to display GVRP error statistics for all interfaces or for a specific interface.

SYNTAX

```
show gvrp error-statistics [interface-id]
```

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays GVRP error statistics.

```
console# show gvrp error-statistics
```

```
GVRP Error Statistics:
```

```
-----
```

```
Legend:
```

```

INVPROT : Invalid Protocol Id
INVATYP : Invalid Attribute Type  INVALEN : Invalid Attribute Length
INVAVAL : Invalid Attribute Value INVEVENT: Invalid Event

```

Port	INVPROT	INVATYP	INVAVAL	INVALEN	INVEVENT
te1	0	0	0	0	0
te2	0	0	0	0	0
te3	0	0	0	0	0
te4	0	0	0	0	0
te5	0	0	0	0	0
te6	0	0	0	0	0
te0/7	0	0	0	0	0
te0/8	0	0	0	0	0

DHCP SNOOPING AND ARP INSPECTION COMMANDS

iPECS ES-5048XG

ip dhcp snooping Use the **ip dhcp snooping** Global Configuration mode command to enable Dynamic Host Configuration Protocol (DHCP) Snooping globally. Use the **no** form of this command to restore the default configuration.

SYNTAX

ip dhcp snooping

no ip dhcp snooping

DEFAULT CONFIGURATION

DHCP snooping is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

For any DHCP Snooping configuration to take effect, DHCP Snooping must be enabled globally. DHCP Snooping on a VLAN is not active until DHCP Snooping on a VLAN is enabled by using the **ip dhcp snooping vlan** Global Configuration mode command.

EXAMPLE

The following example enables DHCP Snooping on the device.

```
Console(config)# ip dhcp snooping
```

ip dhcp snooping vlan Use the **ip dhcp snooping vlan** Global Configuration mode command to enable DHCP Snooping on a VLAN. Use the **no** form of this command to disable DHCP Snooping on a VLAN.

SYNTAX

ip dhcp snooping vlan *vlan-id*

no ip dhcp snooping *vlan-id*

PARAMETERS

vlan-id—Specifies the VLAN ID.

DEFAULT CONFIGURATION

DHCP Snooping on a VLAN is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

DHCP Snooping must be enabled globally before enabling DHCP Snooping on a VLAN.

EXAMPLE

The following example enables DHCP Snooping on VLAN 21.

```
Console(config)# ip dhcp snooping vlan 21
```

ip dhcp snooping trust

Use the **ip dhcp snooping trust** Interface Configuration (Ethernet, Port-channel) mode command to configure a port as trusted for DHCP snooping purposes. Use the **no** form of this command to restore the default configuration.

SYNTAX

ip dhcp snooping trust

no ip dhcp snooping trust

DEFAULT CONFIGURATION

The interface is untrusted.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

Configure as trusted the ports that are connected to a DHCP server or to other switches or routers. Configure the ports that are connected to DHCP clients as untrusted.

EXAMPLE

The following example configures tengigabitethernet port 0/5 as trusted for DHCP Snooping.

```
Console(config)# interface tengigabitethernet 0/5
Console(config-if)# ip dhcp snooping trust
```

**ip dhcp snooping
information option
allowed-untrusted**

Use the **ip dhcp snooping information option allowed-untrusted** Global Configuration mode command to allow a device to accept DHCP packets with option-82 information from an untrusted port. Use the **no** form of this command to drop these packets from an untrusted port.

SYNTAX

ip dhcp snooping information option allowed-untrusted
no ip dhcp snooping information option allowed-untrusted

DEFAULT CONFIGURATION

DHCP packets with option-82 information from an untrusted port are discarded.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example allows a device to accept DHCP packets with option-82 information from an untrusted port.

```
Console(config)# ip dhcp snooping information option allowed-untrusted
```

**ip dhcp snooping
verify**

Use the **ip dhcp snooping verify** Global Configuration mode command to configure a device to verify that the source MAC address in a DHCP packet received on an untrusted port matches the client hardware address. Use the **no** form of this command to disable MAC address verification in a DHCP packet received on an untrusted port.

SYNTAX

ip dhcp snooping verify
no ip dhcp snooping verify

DEFAULT CONFIGURATION

The switch verifies that the source MAC address in a DHCP packet received on an untrusted port matches the client hardware address in the packet.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures a device to verify that the source MAC address in a DHCP packet received on an untrusted port matches the client hardware address.

```
Console(config)# ip dhcp snooping verify
```

ip dhcp snooping database

Use the **ip dhcp snooping database** Global Configuration mode command to enable the DHCP Snooping binding database file. Use the **no** form of this command to delete the DHCP Snooping binding database file.

SYNTAX

ip dhcp snooping database

no ip dhcp snooping database

DEFAULT CONFIGURATION

The DHCP Snooping binding database file is not defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The DHCP Snooping binding database file resides on Flash.

To ensure that the lease time in the database is accurate, the Simple Network Time Protocol (SNTP) must be enabled and configured.

The device writes binding changes to the binding database file only if the device system clock is synchronized with SNTP.

EXAMPLE

The following example enables the DHCP Snooping binding database file.

```
Console(config)# ip dhcp snooping database
```

ip dhcp snooping database update-freq

Use the **ip dhcp snooping database update-freq** Global Configuration mode command to set the update frequency of the DHCP Snooping binding database file. Use the **no** form of this command to restore the default configuration.

SYNTAX

ip dhcp snooping database update-freq *seconds*

no ip dhcp snooping database update-freq

PARAMETERS

seconds—Specifies the update frequency in seconds. (Range: 600–86400)

DEFAULT CONFIGURATION

The default update frequency value is 1200 seconds.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example sets the DHCP Snooping binding database file update frequency to 1 hour.

```
Console(config)# ip dhcp snooping database update-freq 3600
```

ip dhcp snooping binding

Use the **ip dhcp snooping binding** Privileged EXEC mode command to configure the DHCP Snooping binding database and add binding entries to the database. Use the **no** form of this command to delete entries from the binding database.

SYNTAX

```
ip dhcp snooping binding mac-address vlan-id ip-address interface-id expiry {seconds | infinite}  
no ip dhcp snooping binding mac-address vlan-id
```

PARAMETERS

- ◆ **mac-address**— Specifies a MAC address.
- ◆ **vlan-id**—Specifies a VLAN number.
- ◆ **ip-address**—Specifies an IP address.
- ◆ **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- ◆ **expiry seconds**—Specifies the time interval, in seconds, after which the binding entry is no longer valid. (Range: 10–4294967295)
- ◆ **expiry infinite**—Specifies infinite lease time.

DEFAULT CONFIGURATION

No static binding exists.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

After entering this command, an entry is added to the DHCP Snooping database. If the DHCP Snooping binding file exists, the entry is also added to that file.

The entry is displayed in the show commands as a DHCP Snooping entry.

The user cannot delete dynamic temporary entries for which the IP address is 0.0.0.0.

EXAMPLE

The following example adds a binding entry to the DHCP Snooping binding database.

```
Console# ip dhcp snooping binding 0060.704C.73FF 23 176.10.1.1 ethernet 5
        expiry 900
```

**clear ip dhcp
snooping database**

Use the **clear ip dhcp snooping database** Privileged EXEC mode command to clear the DHCP Snooping binding database.

SYNTAX

clear ip dhcp snooping database

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example clears the DHCP Snooping binding database.

```
Console# clear ip dhcp snooping database
```

**show ip dhcp
snooping**

Use the **show ip dhcp snooping** EXEC mode command to display the DHCP snooping configuration for all interfaces or for a specific interface.

SYNTAX

show ip dhcp snooping [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the DHCP snooping configuration.

```
console# show ip dhcp snooping
DHCP snooping is Enabled
DHCP snooping is configured on following VLANs: 21
DHCP snooping database is Enabled
Relay agent Information option 82 is Enabled
Option 82 on untrusted port is allowed
Verification of hwaddr field is Enabled
DHCP snooping file update frequency is configured to: 6666 seconds

  Interface      Trusted
  -----
te1              Yes
te2              Yes
```

show ip dhcp snooping binding

Use the **show ip dhcp snooping binding** User EXEC mode command to display the DHCP Snooping binding database and configuration information for all interfaces or for a specific interface.

SYNTAX

show ip dhcp snooping binding [*mac-address mac-address*] [*ip-address ip-address*] [*vlan vlan-id*] [*interface-id*]

PARAMETERS

- ◆ **mac-address mac-address**—Specifies a MAC address.
- ◆ **ip-address ip-address**—Specifies an IP address.
- ◆ **vlan vlan-id**—Specifies a VLAN ID.
- ◆ **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

User EXEC mode

EXAMPLE

The following examples displays the DHCP snooping binding database and configuration information for all interfaces on a device.

```
Console# show ip dhcp snooping binding
```

```
Update frequency: 1200
```

```
Total number of binding: 2
```

Mac Address	IP Address	Lease (sec)	Type	VLAN	Interface
0060.704C.73FF	10.1.8.1	-----	snooping	3	21
0060.704C.7BC1	10.1.8.2	7983	snooping	3	22
		92332	(s)		

ip source-guard Use the **ip source-guard** Interface Configuration (Ethernet, Port-channel) mode command to enable IP Source Guard on an interface. Use the **no** form of this command to disable IP Source Guard on an interface.

SYNTAX

ip source-guard

no ip source-guard

DEFAULT CONFIGURATION

IP source guard is disabled.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

IP Source Guard must be enabled globally before enabling IP Source Guard on an interface.

IP Source Guard is active only on DHCP snooping untrusted interfaces, and if at least one of the interface VLANs are DHCP snooping enabled.

EXAMPLE

The following example enables IP Source Guard on tengigabitethernet port 0/5.

```
Console(config)# interface tengigabitethernet 0/5
Console(config-if)# ip source-guard
```

ip arp inspection Use the **ip arp inspection** Global Configuration mode command globally to enable Address Resolution Protocol (ARP) inspection. Use the **no** form of this command to disable ARP inspection.

SYNTAX

ip arp inspection
no ip arp inspection

DEFAULT CONFIGURATION

ARP inspection is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Note that if a port is configured as an untrusted port, then it should also be configured as an untrusted port for DHCP Snooping, or the IP-address-MAC-address binding for this port should be configured statically. Otherwise, hosts that are attached to this port cannot respond to ARPs.

EXAMPLE

The following example enables ARP inspection on the device.

```
Console(config)# ip arp inspection
```

ip arp inspection vlan Use the **ip arp inspection vlan** Global Configuration mode command to enable ARP inspection on a VLAN, based on the DHCP Snooping database. Use the **no** form of this command to disable ARP inspection on a VLAN.

SYNTAX

ip arp inspection vlan *vlan-id*
no ip arp inspection vlan *vlan-id*

PARAMETERS

vlan-id—Specifies the VLAN ID.

DEFAULT CONFIGURATION

DHCP Snooping based ARP inspection on a VLAN is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command enables ARP inspection on a VLAN based on the DHCP snooping database. Use the **ip arp inspection list assign** Global Configuration mode command to enable static ARP inspection.

EXAMPLE

The following example enables DHCP Snooping based ARP inspection on VLAN 23.

```
Console(config)# ip arp inspection vlan 23
```

ip arp inspection trust

Use the **ip arp inspection trust** Interface Configuration (Ethernet, Port-channel) mode command to configure an interface trust state that determines if incoming Address Resolution Protocol (ARP) packets are inspected. Use the **no** form of this command to restore the default configuration.

SYNTAX

ip arp inspection trust
no ip arp inspection trust

DEFAULT CONFIGURATION

The interface is untrusted.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

The device does not check ARP packets that are received on the trusted interface; it only forwards the packets.

For untrusted interfaces, the device intercepts all ARP requests and responses. It verifies that the intercepted packets have valid IP-to-MAC address bindings before updating the local cache and before forwarding the packet to the appropriate destination. The device drops invalid packets and logs them in the log buffer according to the logging configuration specified with the **ip arp inspection log-buffer vlan** Global Configuration mode command.

EXAMPLE

The following example configures tengigabitethernet port 0/3 as a trusted interface.

```
Console(config)# interface tengigabitethernet 0/3  
Console(config-if)# ip arp inspection trust
```

ip arp inspection validate Use the **ip arp inspection validate** Global Configuration mode command to perform specific checks for dynamic Address Resolution Protocol (ARP) inspection. Use the **no** form of this command to restore the default configuration.

SYNTAX

ip arp inspection validate
no ip arp inspection validate

DEFAULT CONFIGURATION

ARP inspection validation is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The following checks are performed:

- ◆ **Source MAC address:** Compares the source MAC address in the Ethernet header against the sender MAC address in the ARP body. This check is performed on both ARP requests and responses.
- ◆ **Destination MAC address:** Compares the destination MAC address in the Ethernet header against the target MAC address in the ARP body. This check is performed for ARP responses.
- ◆ **IP addresses:** Compares the ARP body for invalid and unexpected IP addresses. Addresses include 0.0.0.0, 255.255.255.255, and all IP multicast addresses.

EXAMPLE

The following example executes ARP inspection validation.

```
Console(config)# ip arp inspection validate
```

ip arp inspection list create Use the **ip arp inspection list create** Global Configuration mode command to create a static ARP binding list and enters the ARP list configuration mode. Use the **no** form of this command to delete the list.

SYNTAX

ip arp inspection list create *name*
no ip arp inspection list create *name*

PARAMETERS

name—Specifies the static ARP binding list name. (Length: 1–32 characters)

DEFAULT CONFIGURATION

No static ARP binding list exists.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use the **ip arp inspection list assign** command to assign the list to a VLAN.

EXAMPLE

The following example creates the static ARP binding list 'servers' and enters the ARP list configuration mode.

```
Console(config)# ip arp inspection list create servers
Console(config-ARP-list)#
```

ip mac Use the **ip mac** ARP-list Configuration mode command to create a static ARP binding. Use the **no** form of this command to delete a static ARP binding.

SYNTAX

```
ip ip-address mac mac-address
no ip ip-address mac mac-address
```

PARAMETERS

- ◆ **ip-address**—Specifies the IP address to be entered to the list.
- ◆ **mac-address**—Specifies the MAC address associated with the IP address.

DEFAULT CONFIGURATION

No static ARP binding is defined.

COMMAND MODE

ARP-list Configuration mode

EXAMPLE

The following example creates a static ARP binding.

```
Console(config)# ip arp inspection list create servers
Console(config-ARP-list)# ip 172.16.1.1 mac 0060.704C.7321
Console(config-ARP-list)# ip 172.16.1.2 mac 0060.704C.7322
```

ip arp inspection list assign Use the **ip arp inspection list assign** Global Configuration mode command to assign a static ARP binding list to a VLAN. Use the **no** form of this command to delete the assignment.

SYNTAX

ip arp inspection list assign *vlan-id name*
no ip arp inspection list assign *vlan*

PARAMETERS

- ◆ **vlan-id**—Specifies the VLAN ID.
- ◆ **name**—Specifies the static ARP binding list name.

DEFAULT CONFIGURATION

No static ARP binding list assignment exists.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example assigns the static ARP binding list Servers to VLAN 37.

```
Console(config)# ip arp inspection list assign 37 servers
```

ip arp inspection logging interval Use the **ip arp inspection logging interval** Global Configuration mode command to set the minimum time interval between successive ARP SYSLOG messages. Use the **no** form of this command to restore the default configuration.

SYNTAX

ip arp inspection logging interval {*seconds* | *infinite*}
no ip arp inspection logging interval

PARAMETERS

- ◆ **seconds**—Specifies the minimum time interval between successive ARP SYSLOG messages. A 0 value means that a system message is immediately generated. (Range: 0–86400)
- ◆ **infinite**—Specifies that SYSLOG messages are not generated.

DEFAULT CONFIGURATION

The default minimum ARP SYSLOG message logging time interval is 5 seconds.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example sets the minimum ARP SYSLOG message logging time interval to 60 seconds.

```
Console(config)# ip arp inspection logging interval 60
```

show ip arp inspection

Use the **show ip arp inspection** EXEC mode command to display the ARP inspection configuration for all interfaces or for a specific interface.

SYNTAX

show ip arp inspection [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the ARP inspection configuration.

```
console# show ip arp inspection
IP ARP inspection is Enabled
IP ARP inspection is configured on following VLANs: 1
Verification of packet header is Enabled
IP ARP inspection logging interval is: 222 seconds

Interface      Trusted
-----
te1             Yes
te2             Yes
```

show ip arp inspection list

Use the **show ip arp inspection list** Privileged EXEC mode command to display the static ARP binding list.

SYNTAX

show ip arp inspection list

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the static ARP binding list.

```
Console# show ip arp inspection list
```

```
List name: servers
```

```
Assigned to VLANs: 1,2
```

IP	ARP
-----	-----
172.16.1.1	0060.704C.7322
172.16.1.2	0060.704C.7322

show ip arp inspection statistics

Use the **show ip arp inspection statistics** EXEC command to display Statistics For The Following Types Of Packets That Have Been Processed By This Feature: Forwarded, Dropped, IP/MAC Validation Failure.

SYNTAX

show ip arp inspection statistics *[vlan vlan-id]*

PARAMETERS

vlan-id—Specifies VLAN ID.

COMMAND MODE

EXEC mode

USER GUIDELINES

To clear ARP Inspection counters use the **clear ip arp inspection statistics** CLI command. Counters values are kept when disabling the ARP Inspection feature.

EXAMPLE

```
console# show ip arp inspection statistics
```

Vlan	Forwarded Packets	Dropped Packets	IP/MAC Failures
----	-----	-----	-----
2	1500	100	80

clear ip arp inspection statistics

Use the **clear ip arp inspection statistics** Privileged EXEC mode command to clear statistics ARP Inspection statistics globally.

SYNTAX

clear ip arp inspection statistics *[vlan vlan-id]*

PARAMETERS

vlan-id—Specifies VLAN ID

COMMAND MODE

Privileged EXEC mode

EXAMPLE

```
console# clear ip arp inspection statistics
```

ip dhcp information option

Use the **ip dhcp information option** Global Configuration command to enable DHCP option-82 data insertion. Use the **no** form of this command to disable DHCP option-82 data insertion.

SYNTAX

ip dhcp information option

no ip dhcp information option

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

DHCP option-82 data insertion is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

DHCP option 82 would be enabled only if DHCP snooping or DHCP relay are enabled.

EXAMPLE

```
console(config)# ip dhcp information option
```

show ip dhcp information option

The **show ip dhcp information option** EXEC mode command displays the DHCP Option 82 configuration.

SYNTAX

show ip dhcp information option

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the DHCP Option 82 configuration.

```
console# show ip dhcp information option
Relay agent Information option is Enabled
```

ip address Use the **ip address** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to define an IP address for an interface. Use the **no** form of this command to remove an IP address definition.

SYNTAX

If the product is a switch router.

ip address *ip-address* {*mask* | *prefix-length*}

no ip address [*ip-address*]

If the product is a switch only.

ip address *ip-address* {*mask* | *prefix-length*} [**default-gateway** *ip-address*]

no ip address [*ip-address*]

If the product is switch only and supports a single IP address:

ip address *ip-address* {*mask* | *prefix-length*} [**default-gateway** *ip-address*]

no ip address

PARAMETERS

- ◆ **ip-address**—Specifies the IP address.
- ◆ **mask**—Specifies the network mask of the IP address.
- ◆ **prefix-length**—Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 8–30)
- ◆ **default-gateway ip-address**—Specifies the default gateway IP address.

DEFAULT CONFIGURATION

No IP address is defined for interfaces.

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

USER GUIDELINES

Defining a static IP address on an interface implicitly removes the DHCP client configuration on the interface.

If the product supports multiple IP addresses:

The product supports up to x IP addresses. The IP addresses should be from different IP subnets. When adding an IP address from a subnet that already exists in the list, the new IP address replaces the existing IP address from that subnet.

If the product is switch only and supports a single IP address.

If the IP address configured in global context then it would be bound to the currently defined management interface. If the management interface is Default VLAN and the VID of the default VLAN is changed then when new setting is applied, the IP address will be automatically redefined on the new Default VLAN.

If the IP address is configured in Interface context then the IP address is bound to the interface in context.

If a static IP address is already defined, the user must do **no IP address** in the relevant interface context before changing the IP address.

If a dynamic IP address is already defined, the user must do **no ip address** in the relevant interface context before configuring another dynamic IP address.

The Interface context could be a port, LAG or VLAN, depending on support that is defined for the product.

EXAMPLE

The following example configures VLAN 1 with IP address 131.108.1.27 and subnet mask 255.255.255.0.

```
Console(config)# interface vlan 1
Console(config-if)# ip address 131.108.1.27 255.255.255.0
```

ip address dhcp Use the **ip address dhcp** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to acquire an IP address for an Ethernet interface from the Dynamic Host Configuration Protocol (DHCP) server. Use the **no** form of this command to release an acquired IP address.

SYNTAX

ip address dhcp
no ip address dhcp

PARAMETERS

No parameters

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

USER GUIDELINES

The **ip address dhcp** command allows any interface to dynamically learn its IP address by using the DHCP protocol.

DHCP client configuration on an interface implicitly removes the static IP address configuration on the interface.

If the device is configured to obtain its IP address from a DHCP server, it sends a DHCPDISCOVER message to provide information about itself to the DHCP server on the network.

If the **ip address dhcp** command is used with or without the optional keyword, the DHCP option 12 field (host name option) is included in the DISCOVER message. By default, the host name specified in the option 12 field is the globally configured device host name.

The **no ip address dhcp** command releases any IP address that was acquired, and sends a DHCPRELEASE message.

EXAMPLE

The following example acquires an IP address for tengigabitethernet port 0/16 from DHCP.

```
Console(config)# interface tengigabitethernet 0/16
Console(config-if)# ip address dhcp
```

renew dhcp Use the **renew dhcp** Privileged EXEC mode command to renew an IP address that was acquired from a DHCP server for a specific interface.

SYNTAX

renew dhcp { *interface-id* } [**force-autoconfig**]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

force-autoconfig - In the case the DHCP server holds a DHCP option 67 record for the assigned IP address, the file would overwrite the existing device configuration

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

Note that this command does not enable DHCP on an interface. If DHCP is not enabled on the requested interface, the command returns an error message.

If DHCP is enabled on the interface and an IP address was already acquired, the command tries to renew that IP address.

If DHCP is enabled on the interface and an IP address has not yet been acquired, the command initiates a DHCP request.

EXAMPLE

The following example renews an IP address that was acquired from a DHCP server for VLAN 19.

```
Console# renew dhcp vlan 19
```

ip default-gateway The **ip default-gateway** Global Configuration mode command defines a default gateway (device). Use the **no** form of this command to restore the default configuration.

SYNTAX

ip default-gateway *ip-address*
no ip default-gateway

PARAMETERS

ip-address—Specifies the default gateway IP address.

COMMAND MODE

Global Configuration mode

DEFAULT CONFIGURATION

No default gateway is defined.

EXAMPLE

The following example defines default gateway 192.168.1.1.

```
Console(config)# ip default-gateway 192.168.1.1
```

show ip interface Use the **show ip interface** EXEC mode command to display the usability status of configured IP interfaces.

SYNTAX

show ip interface [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the configured IP interfaces and their types.

The information on the default gateway is not shown when the device is in router mode

```
console# show ip interface
```

Gateway IP Address	Activity status	Type
1.1.1.254	Inactive	static

IP Address	I/F	Type	Status
1.1.1.1/8	vlan 1	Static	Valid
2.2.2.2/24	tel	Static	Valid

arp Use the **arp** Global Configuration mode command to add a permanent entry to the Address Resolution Protocol (ARP) cache. Use the **no** form of this command to remove an entry from the ARP cache.

SYNTAX

arp *ip-address mac-address [interface-id]*

no arp *ip-address*

PARAMETERS

- ◆ **ip-address**—IP address or IP alias to map to the specified MAC address.
- ◆ **mac-address**—MAC address to map to the specified IP address or IP alias.

- ◆ **interface-id**—interface ID. Can be Ethernet port, Port-channel or VLAN.

COMMAND MODE

Global Configuration mode

DEFAULT CONFIGURATION

No permanent entry is defined.

USER GUIDELINES

The software uses ARP cache entries to translate 32-bit IP addresses into 48-bit hardware (MAC) addresses. Because most hosts support dynamic address resolution, static ARP cache entries generally do not need to be specified.

Example

The following example adds IP address 198.133.219.232 and MAC address 00:00:0c:40:0f:bc to the ARP table.

```
Console(config)# arp 198.133.219.232 00:00:0c:40:0f:bc ethernet 6
```

arp timeout (Global) Use the **arp timeout** Global Configuration mode command to set the time interval during which an entry remains in the ARP cache. Use the **no** form of this command to restore the default configuration.

SYNTAX

arp timeout *seconds*

no arp timeout

PARAMETERS

seconds—Specifies the time interval (in seconds) during which an entry remains in the ARP cache.
(Range: 1–40000000)

DEFAULT CONFIGURATION

The default ARP timeout is 60000 seconds in Router mode, and 300 seconds in Switch mode.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures the ARP timeout to 12000 seconds.

```
Console(config)# arp timeout 12000
```

arp timeout Use the **arp timeout** inTeface Configuration command to configure how long an entry remains in the ARP cache for specific interface. Use the **no** form of this command restore the default value.

SYNTAX

arp timeout *seconds*

no arp timeout

PARAMETERS

seconds—Time (in seconds) that an entry remains in the ARP cache. It is recommended not to set it to less than 3600. (Range: 1–40000000)

DEFAULT

Defined by the **arp timeout** Global Configuration command

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

USER GUIDELINES

This configuration can be applied only if at least one IP address defined on specific interface.

EXAMPLE

```
Console (config)# interface vlan 1
Console(config-if)# arp timeout 12000
```

clear arp-cache Use the **clear arp-cache** Privileged EXEC mode command to delete all dynamic entries from the ARP cache.

SYNTAX

clear arp-cache

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example deletes all dynamic entries from the ARP cache.

```
Console# clear arp-cache
```

show arp Use the **show arp** Privileged EXEC mode command to display entries in the ARP table.

SYNTAX

```
show arp [ip-address ip-address] [mac-address mac-address]
           [interface-id]
```

PARAMETERS

- ◆ **ip-address ip-address**—Specifies the IP address.
- ◆ **mac-address mac-address**—Specifies the MAC address.
- ◆ **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

Since the associated interface of a MAC address can be aged out from the FDB table, the Interface field can be empty.

If an ARP entry is associated with an IP interface that is defined on a port or port-channel, the VLAN field is empty.

EXAMPLE

The following example displays entries in the ARP table.

```
Console# show arp

ARP timeout: 80000 Seconds

VLAN      Interface  IP Address  HW Address  Status
-----
VLAN 1    1          10.7.1.102  00:10:B5:04:DB:4B  Dynamic
VLAN 1    2          10.7.1.135  00:50:22:00:2A:A4  Static
```

show arp configuration Use the **show arp configuration** privileged EXEC command to display the global and interface configuration of the ARP protocol.

SYNTAX

```
show arp configuration
```

PARAMETERS

This command has no arguments or key words.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

```

Console# show arp configuration

Global configuration:
ARP timeout:      80000 Seconds
ARP Proxy: enabled

Interface configuration:
g2:
ARP timeout:60000 Seconds
VLAN 1:
ARP Proxy: disabled
ARP timeout:      70000 Seconds
VLAN 2:
ARP Proxy: enabled
ARP timeout:80000 Second (Global)

```

ip helper-address Use the **ip helper-address** Global Configuration mode command to enable the forwarding of User Datagram Protocol (UDP) broadcast packets received on an interface to a specific (helper) address. Use the **no** form of this command to disable the forwarding of broadcast packets to a specific (helper) address.

SYNTAX

ip helper-address {*ip-interface* | *all*} *address* [*udp-port-list*]
no ip helper-address {*ip-interface* | *all*} *address*

PARAMETERS

- ◆ **ip-interface**—Specifies the IP interface.
- ◆ **all**—Specifies all IP interfaces.
- ◆ **address**—Specifies the destination broadcast or host address to which to forward UDP broadcast packets. A value of 0.0.0.0 specifies that UDP broadcast packets are not forwarded to any host.
- ◆ **udp-port-list**—Specifies the destination UDP port number to which to forward broadcast packets. (Range: 1–65535)

DEFAULT CONFIGURATION

Forwarding of User Datagram Protocol (UDP) broadcast packets received on an interface to a specific (helper) address is disabled.

If **udp-port-list** is not specified, packets for the default services are forwarded to the helper address.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The **ip helper-address** command forwards specific UDP broadcast packets from one interface to another.

Many helper addresses may be defined. However, the total number of address-port pairs is limited to 128 for the device.

The setting of a helper address for a specific interface has precedence over the setting of a helper address for all the interfaces.

Forwarding of BOOTP/DHCP (ports 67, 68) cannot be enabled with this command. Use the DHCP relay commands to relay BOOTP/DHCP packets.

The **ip helper-address** command specifies a UDP port number to which UDP broadcast packets with that destination port number are forwarded. By default, if no UDP port number is specified, the device forwards UDP broadcast packets for the following six services:

- ◆ IEN-116 Name Service (port 42)
- ◆ DNS (port 53)
- ◆ NetBIOS Name Server (port 137)
- ◆ NetBIOS Datagram Server (port 138)
- ◆ TACACS Server (port 49)
- ◆ Time Service (port 37)

EXAMPLE

The following example enables the forwarding of User Datagram Protocol (UDP) broadcasts received on all interfaces to specific UDP ports of a destination IP address.

```
Console (config)# ip helper-address all 172.16.9.9 49 53
```

show ip helper-address Use the **show ip helper-address** Privileged EXEC mode command to display the IP helper addresses configuration on the system.

SYNTAX

show ip helper-address

PARAMETERS

This command has no arguments or key words.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example displays the IP helper addresses configuration on the system.

```
Console# show ip helper-address
```

Interface	Helper Address	Udp ports
192.168.1.1	172.16.8.8	37, 42, 49, 53, 137, 138
192.168.2.1	172.16.9.9	37, 49

ip domain lookup Use the **ip domain lookup** Global Configuration mode command to enable the IP Domain Name System (DNS)-based host name-to-address translation. Use the **no** form of this command to disable DNS-based host name-to-address translation.

SYNTAX

ip domain lookup

no ip domain lookup

DEFAULT CONFIGURATION

IP Domain Name System (DNS)-based host name-to-address translation is enabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables IP Domain Name System (DNS)-based host name-to-address translation.

```
Console(config)# ip domain lookup
```

ip domain name Use the **ip domain name** Global Configuration mode command to define a default domain name used by the software to complete unqualified host names (names without a dotted-decimal domain name). Use the **no** form of this command to remove the default domain name.

SYNTAX

ip domain name *name*

no ip domain name

PARAMETERS

name—Specifies the default domain name used to complete unqualified host names. Do not include the initial period that separates an unqualified name from the domain name. (Length: 1–158 characters. Maximum label length: 63 characters)

DEFAULT CONFIGURATION

A default domain name is not defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Domain names and host names are restricted to the ASCII letters A through Z (case-insensitive), the digits 0 through 9, the underscore and the hyphen. A period (.) is used to separate labels.

The maximum size of a label is 63 characters. The maximum name size is 158 bytes.

EXAMPLE

The following example defines the default domain name as 'www.website.com'.

```
Console(config)# ip domain name www.website.com
```

ip name-server Use the **ip name-server** Global Configuration mode command to define the available name servers. Use the **no** form of this command to remove a name server.

SYNTAX

```
ip name-server { server1-ipv4-address | server1-ipv6-address }  
[server-address2 ... server-address8]
```

```
no ip name-server [server-address ... server-address8]
```

PARAMETERS

server-address—IP addresses of the name server. Up to 8 servers can be defined in one command or by using multiple commands. The IP address can be IPv4 address or IPv6 address. When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. Refer to the User Guidelines for the interface name syntax.

DEFAULT CONFIGURATION

No name server IP addresses are defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The preference of the servers is determined by the order in which they were entered.

Up to 8 servers can be defined using one command or using multiple commands.

The format of an **IPv6Z address** is: <ipv6-link-local-address>%<interface-name>

interface-name = vlan<integer> | ch<integer> | isatap<integer> | <physical-port-name> | 0

integer = <decimal-number> | <integer><decimal-number>

decimal-number = 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9

physical-port-name= Designated port number, for example 0/16.

If the egress interface is not specified, the default interface is selected. Specifying interface zone=0 is equal to not defining an egress interface.

EXAMPLE

The following example defines the available name server.

```
Console(config)# ip name-server 176.16.1.18
```

ip host Use the **ip host** Global Configuration mode command to define the static host name-to-address mapping in the host cache. Use the **no** form of this command to remove the static host name-to-address mapping.

SYNTAX

ip host *name address [address2 address3 address4]*

no ip host *name*

PARAMETERS

- ◆ **name**—Specifies the host name. (Length: 1–158 characters. Maximum label length: 63 characters)
- ◆ **address**—Specifies the associated IP address. Up to 4 addresses can be defined.

DEFAULT CONFIGURATION

No host is defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Host names are restricted to the ASCII letters A through Z (case-insensitive), the digits 0 through 9, the underscore and the hyphen. A period (.) is used to separate labels.

EXAMPLE

The following example defines a static host name-to-address mapping in the host cache.

```
Console(config)# ip host accounting.website.com 176.10.23.1
```

clear host Use the **clear host** Privileged EXEC mode command to delete entries from the host name-to-address cache.

SYNTAX

clear host {*name* | *}

PARAMETERS

- ◆ **name**—Specifies the host entry to remove. (Length: 1–158 characters. Maximum label length: 63 characters)
- ◆ ***** —Removes all entries.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

The following example deletes all entries from the host name-to-address cache.

```
Console# clear host *
```

clear host dhcp Use the **clear host dhcp** Privileged EXEC mode command to delete entries from the host name-to-address mapping received from Dynamic Host Configuration Protocol (DHCP).

SYNTAX

clear host dhcp {*name* | *}

PARAMETERS

- ◆ **name** —Specifies the host entry to remove. (Length: 1–158 characters. Maximum label length: 63 characters)

- ◆ *—Removes all entries.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

This command deletes the host name-to-address mapping temporarily until the next refresh of the IP addresses.

EXAMPLE

The following example deletes all entries from the host name-to-address mapping received from DHCP.

```
Console# clear host dhcp *
```

show hosts Use the **show hosts** EXEC mode command to display the default domain name, the list of name server hosts, the static and the cached list of host names and addresses.

SYNTAX

show hosts [*name*]

PARAMETERS

name—Specifies the host name. (Length: 1–158 characters. Maximum label length: 63 characters)

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays host information.

```
Console> show hosts
```

```
System name: Device
Default domain is gm.com, sales.gm.com, usa.sales.gm.com(DHCP)
Name/address lookup is enabled
Name servers (Preference order): 176.16.1.18 176.16.1.19

Configured host name-to-address mapping:

Host                               Addresses
-----
accounting.gm.com                  176.16.8.8 176.16.8.9 (DHCP)
                                   2002:0:130F::0A0:1504:0BB4
```

Host	Total	Elapsed	Type	Addresses
-----	-----	-----	----	-----
www.stanford.edu	72	3	IP	171.64.14.203

ipv6 enable Use the **ipv6 enable** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to enable the IPv6 addressing mode on an interface. Use the **no** form of this command to disable the IPv6 addressing mode on an interface.

SYNTAX

ipv6 enable [*no-autoconfig*]

no ipv6 enable

PARAMETERS

no-autoconfig—EnableS processing of IPv6 on an interface without stateless address autoconfiguration procedure

DEFAULT CONFIGURATION

IPv6 addressing is disabled.

Unless you are using the no-autoconfig parameter, when the interface is enabled stateless address autoconfiguration procedure is enabled.

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

USER GUIDELINES

The **ipv6 enable** command automatically configures an IPv6 link-local unicast address on the interface, while also enabling the interface for IPv6 processing. The **no ipv6 enable** command removes the entire IPv6 interface configuration.

To enable stateless address autoconfiguration on an enabled IPv6 interface, use the IPv6 address autoconfig command.

EXAMPLE

The following example enables VLAN 1 for the IPv6 addressing mode.

```
Console(config)# interface vlan 1
Console(config-if)# ipv6 enable
```

ipv6 address autoconfig Use the **ipv6 address autoconfig** Interface Configuration mode command to enable automatic configuration of IPv6 addresses, using stateless autoconfiguration on an interface. Addresses are configured depending on the prefixes received in Router Advertisement messages. Use the **no** form of this command to disable address autoconfiguration on the interface.

SYNTAX

ipv6 address *autoconfig*
no ipv6 address *autoconfig*

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Address autoconfiguration is enabled on the interface, no addresses are assigned by default.

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode.

USER GUIDELINES

When **address autoconfig** is enabled, router solicitation ND procedure is initiated to discover a router and assign IP addresses to the interface, based on the advertised on-link prefixes.

When disabling address autoconfig, automatically generated addresses that are assigned to the interface are removed.

The default state of the address autoconfig is enabled. Use the **enable ipv6 no-autoconfig** command to enable an IPv6 interface without address autoconfig.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ipv6 address autoconfig
```

ipv6 icmp error-interval Use the **ipv6 icmp error-interval** Global Configuration mode command to configure the rate limit interval and bucket size parameters for IPv6 Internet Control Message Protocol (ICMP) error messages. Use the **no** form of this command to return the interval to its default setting.

SYNTAX

ipv6 icmp error-interval *milliseconds [bucketsize]*
no ipv6 icmp error-interval

PARAMETERS

- ◆ **milliseconds**—The time interval between tokens being placed in the bucket. Each token represents a single ICMP error message. The acceptable range is from 0–2147483647 with a default of 100 milliseconds. Setting milliseconds to 0 disables rate limiting. (Range: 0– 2147483647)
- ◆ **bucketsize**—(Optional) The maximum number of tokens stored in the bucket. The acceptable range is from 1–200 with a default of 10 tokens.

DEFAULT CONFIGURATION

The default interval is 100ms and the default bucketsize is 10 i.e. 100 ICMP error messages per second

COMMAND MODE

Global Configuration mode

USER GUIDELINES

To set the average ICMP error rate limit, calculate the interval with the following formula:

Average Packets Per Second = (1/ interval) * bucket size

EXAMPLE

```
console(config)# ipv6 icmp error-interval 123 45
```

show ipv6 icmp error-interval Use the **show ipv6 error-interval** command in the EXEC mode to display the IPv6 ICMP error interval.

SYNTAX

show ipv6 icmp error-interval

COMMAND MODE

EXEC mode

EXAMPLE

```
Console> show ipv6 icmp error-interval
Rate limit interval: 100 ms
Bucket size: 10 tokens
```

ipv6 address Use the **ipv6 address** Interface Configuration mode command to configure an IPv6 address for an interface. Use the **no** form of this command To remove the address from the interface.

SYNTAX

ipv6 address *ipv6-address/prefix-length* [*eui-64*] [*anycast*]
no ipv6 address [*ipv6-address/prefix-length*] [*eui-64*]

PARAMETERS

- ◆ **ipv6-address**—Specifies the IPv6 network assigned to the interface. This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.
- ◆ **prefix-length**—Specifies the length of the IPv6 prefix. A decimal value that indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark (/) must precede the decimal.
- ◆ **eui-64**—(Optional) Builds an interface ID in the low order 64 bits of the IPv6 address based on the interface MAC address.
- ◆ **anycast**—(Optional) Indicates that this address is an anycast address.
- ◆ **prefix-length**—3–128 (64 when the **eui-64** parameter is used).

DEFAULT CONFIGURATION

No IP address is defined for the interface.

COMMAND MODE

Interface configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

USER GUIDELINES

If the value specified for the /prefix-length argument is greater than 64 bits, the prefix bits have precedence over the interface ID.

Using the no IPv6 address command without arguments removes all manually configured IPv6 addresses from an interface, including link local manually configured addresses.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ipv6 address 3000::123/64 eui-64 anycast
```

ipv6 address link-local Use the **ipv6 address link-local** command to configure an IPv6 link-local address for an interface. Use the **no** form of this command to return to the default link local address on the interface.

SYNTAX

```
ipv6 address ipv6-address/prefix-length link-local
no ipv6 address [ipv6-address/prefix-length link-local]
```

PARAMETERS

- ◆ **ipv6-address**—Specifies the IPv6 network assigned to the interface. This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.
- ◆ **prefix-length**—Specifies the length of the IPv6 prefix. A decimal value indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark (/) must precede the decimal. Only 64-bit length is supported, according to IPv6 over Ethernet's well-known practice

DEFAULT CONFIGURATION

IPv6 is enabled on the interface, link local address of the interface is FE80::EUI64 (interface MAC address).

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

USER GUIDELINES

Using the **no ipv6 link-local address** command removes the manually configured link local IPv6 address from an interface. Multiple IPv6 addresses can be configured per interface, but only one link-local address. When the **no ipv6 link-local address** command is used, the interface is reconfigured with the standard link local address (the same IPv6 link-local address that is set automatically when the **enable ipv6** command is used). The system automatically generates a link-local address for an interface when IPv6 processing is enabled on the interface. To manually specify a link-local address to be used by an interface, use the **ipv6 link-local address** command. The system supports only 64 bits prefix length for link-local addresses.

EXAMPLE

```
console(config)# interface vlan 1
console(config-if)# ipv6 address fe80::123/64 link-local
```

ipv6 unreachable Use the **ipv6 unreachable** Interface Configuration mode command to enable the generation of Internet Control Message Protocol for IPv6 (ICMPv6) unreachable messages for any packets arriving on a specified interface. Use the **no** form of this command To prevent the generation of unreachable messages.

SYNTAX

ipv6 unreachable
no ipv6 unreachable

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

ICMP unreachable messages are sent by default.

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode.

USER GUIDELINES

When ICMP unreachable messages are enabled, when receiving a packet addressed to one of the interface's IP address with TCP/UDP port not assigned, the device sends ICMP unreachable messages. Use the **no ipv6 unreachable** command to disable sending ICMP unreachable messages on the interface.

EXAMPLE

```
console(config)# interface tel  
console(config-if)# ipv6 unreachable
```

ipv6 default-gateway Use the **ipv6 default-gateway** Global Configuration mode command to define an IPv6 default gateway. Use the **no** form of this command To remove the default gateway.

SYNTAX

ipv6 default-gateway *ipv6-address*
no ipv6 default-gateway

PARAMETERS

ipv6-address—Specifies the IPv6 address of the next hop that can be used to reach that network. When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. Refer to the user guidelines for the interface name syntax.

DEFAULT CONFIGURATION

No default gateway is defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The format of an IPv6Z address is: <ipv6-link-local-address>%<interface-name>

interface-name = vlan<integer> | ch<integer> | <physical-port-name> | 0

integer = <decimal-number> | <integer><decimal-number>

decimal-number = 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9

physical-port-name = Designated port number, for example 0/16.

Configuring a new default GW without deleting the previous configured information overwrites the previous configuration. A configured default GW has a higher precedence over automatically advertised (via router advertisement message). Precedence takes effect once the configured default GW is reachable. Reachability state is not verified automatically by the neighbor discovery protocol. Router reachability can be confirmed by either receiving Router Advertisement message containing router's MAC address or manually configured by user using the IPv6 neighbor CLI command. Another option to force reachability confirmation is to ping the router link-local address (this will initiate the neighbor discovery process).

If the egress interface is not specified, the default interface is selected. Specifying interface zone=0 is equal to not defining an egress interface.

EXAMPLE

```
console(config)# ipv6 default-gateway fe80::abcd
```

show ipv6 interface Use the **show ipv6 interface** EXEC command mode to display the usability status of interfaces configured for IPv6.

SYNTAX

show ipv6 interface [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

DEFAULT CONFIGURATION

Displays all IPv6 interfaces.

COMMAND MODE

EXEC mode

USER GUIDELINES

Use the **show ipv6 neighbors** command in the privileged EXEC mode to display IPv6 neighbor discovery cache information.

EXAMPLE

```

Console# show ipv6 interface
Interface      IP addresses      Type
-----
VLAN 1         4004::55/64 [ANY]  manual
VLAN 1         fe80::200:b0ff:fe00:0  linklayer
VLAN 1         ff02::1           linklayer
VLAN 1         ff02::77          manual
VLAN 1         ff02::1:ff00:0     manual
VLAN 1         ff02::1:ff00:1     manual
VLAN 1         ff02::1:ff00:55    manual

Default Gateway IP address  Type      Interface  State
-----
fe80::77                    Static    VLAN 1     unreachable
fe80::200:cff:fe4a:dfa8     Dynamic  VLAN 1     stale

Console# show ipv6 interface Vlan 15
IPv6 is disabled

Console# show ipv6 interface Vlan 1
Number of ND DAD attempts: 1
MTU size: 1500
Stateless Address Autoconfiguration state: enabled
ICMP unreachable message state: enabled
MLD version: 2

IP addresses      Type      DAD State
-----
4004::55/64 [ANY]  manual    Active
fe80::200:b0ff:fe00:0  linklayer Active
ff02::1           linklayer -----
ff02::77          manual    -----
ff02::1:ff00:0     manual    -----
ff02::1:ff00:1     manual    -----
ff02::1:ff00:55    manual    -----

```

show IPv6 route Use the **show ipv6 route** command to display the current state of the IPv6 routing table.

SYNTAX

show ipv6 route

COMMAND MODE

EXEC mode

EXAMPLE

```

Console> show ipv6 route
Codes: L - Local, S - Static, I - ICMP, ND - Router Advertisement
The number in the brackets is the metric.

```

```

S  ::/0 via fe80::77 [0] VLAN 1 Lifetime Infinite
ND ::/0 via fe80::200:cff:fe4a:dfa8 [0] VLAN 1 Lifetime 1784 sec
L  2001::/64 is directly connected, g2 Lifetime Infinite
L  2002:1:1:1::/64 is directly connected, VLAN 1 Lifetime 2147467 sec
L  3001::/64 is directly connected, VLAN 1 Lifetime Infinite
L  4004::/64 is directly connected, VLAN 1 Lifetime Infinite
L  6001::/64 is directly connected, g2 Lifetime Infinite

```

ipv6 nd dad attempts Use the **ipv6 nd dad attempts** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to configure the number of consecutive neighbor solicitation messages that are sent on an interface while Duplicate Address Detection (DAD) is performed on the unicast IPv6 addresses of the interface. Use the **no** form of this command to restore the number of messages to the default value.

SYNTAX

ipv6 nd dad attempts *attempts*

PARAMETERS

attempts—Specifies the number of neighbor solicitation messages. A value of 0 disables DAD processing on the specified interface. A value of 1 configures a single transmission without follow-up transmissions. (Range: 0–600)

DEFAULT CONFIGURATION

Duplicate Address Detection on unicast IPv6 addresses with the sending of one neighbor solicitation message is enabled.

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

USER GUIDELINES

Duplicate Address Detection (DAD) verifies the uniqueness of new unicast IPv6 addresses before the addresses are assigned to interfaces (the new addresses remain in a tentative state while DAD is performed). DAD uses neighbor solicitation messages to verify the uniqueness of unicast IPv6 addresses.

An interface returning to the administrative Up state restarts DAD for all of the unicast IPv6 addresses on the interface. While DAD is performed on the Link Local address of an interface, the state of the other IPv6 addresses is still set to TENTATIVE. When DAD is completed on the Link Local address, DAD is performed on the remaining IPv6 addresses.

When DAD identifies a duplicate address, the address state is set to DUPLICATE and the address is not used. If the duplicate address is the Link Local address of the interface, the processing of IPv6 packets is disabled on the interface and an error message is displayed.

All configuration commands associated with the duplicate address remain as configured while the address state is set to DUPLICATE.

If the Link Local address for an interface changes, DAD is performed on the new Link Local address and all of the other IPv6 address associated with the interface are regenerated (DAD is performed only on the new Link Local address).

Configuring a value of 0 with the **ipv6 nd dad attempts** Interface Configuration mode command disables duplicate address detection processing on the specified interface. A value of 1 configures a single transmission without follow-up transmissions. The default is 1 message.

Until the DAD process is completed, an IPv6 address is in the tentative state and cannot be used for data transfer. It is recommended to limit the configured value.

EXAMPLE

The following example configures the number of consecutive neighbor solicitation messages sent during DAD processing to 2 on tengigabitethernet port 0/9.

```
Console (config)# interface tengigabitethernet 0/9
Console (config-if)# ipv6 nd dad attempts 2
```

ipv6 host Use the **ipv6 host** Global Configuration mode command to define a static host name-to-address mapping in the host name cache. Use the **no** form of this command to remove the host name-to-address mapping.

SYNTAX

```
ipv6 host name ipv6-address1 [ipv6-address2...ipv6-address4]
no ipv6 host name
```

PARAMETERS

nameName of the host. (Range: 1–158 characters)

- ◆ **ipv6-address1**—Associated IPv6 address. This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons. When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. Refer to the user guidelines for the interface name syntax.
- ◆ **ipv6-address2-4**—(Optional) Additional IPv6 addresses that may be associated with the host's name

DEFAULT CONFIGURATION

No host is defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The format of an IPv6Z address is: <ipv6-link-local-address>%<interface-name>

interface-name = vlan<integer> | ch<integer> | isatap<integer> | <physical-port-name>

integer = <decimal-number> | <integer><decimal-number>

decimal-number = 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9

physical-port-name = Designated port number, for example 0/16.

EXAMPLE

```
console(config)# ipv6 host server 3000::a31b
```

ipv6 neighbor Use the **ipv6 neighbor** command to configure a static entry in the IPv6 neighbor discovery cache. Use the **no** form of this command to remove a static IPv6 entry from the IPv6 neighbor discovery cache.

SYNTAX

ipv6 neighbor *ipv6_addr interface-id hw_addr*

no ipv6 neighbor *ipv6_addr interface-id*

PARAMETERS

- ◆ **Ipv6_addr**—Specifies the Pv6 address to map to the specified MAC address.
- ◆ **interface-id**—Specifies the interface that is associated with the IPv6 address
- ◆ **hw_addr**—Specifies the MAC address to map to the specified IPv6 address.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The **IPv6 neighbor** command is similar to the **ARP** (global) command.

If an entry for the specified IPv6 address already exists in the neighbor discovery cache—learned through the IPv6 neighbor discovery process—the entry is automatically converted to a static entry.

A new static neighbor entry with a global address can be configured only if a manually configured subnet already exists in the device.

Use the show **IPv6 neighbors** command to view static entries in the IPv6 neighbor discovery cache.

EXAMPLE

```
console(config)# ipv6 neighbor 3000::a31b vlan 1 001b.3f9c.84ea
```

ipv6 set mtu Use the **ipv6 mtu** Interface Configuration mode command to set the maximum transmission unit (MTU) size of IPv6 packets sent on an interface. Use the default parameter to restore the default MTU size.

SYNTAX

ipv6 set mtu { *interface-id* } { *bytes* | *default* }

PARAMETERS

- ◆ **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- ◆ **bytes**—Specifies the MTU in bytes.
- ◆ **default**—Sets the default MTU size 1500 bytes. Minimum is 1280 bytes

DEFAULT CONFIGURATION

1500 bytes

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

This command is intended for debugging and testing purposes and should be used only by technical support personnel.

EXAMPLE

```
console# ipv6 set mtu tel default
```

ipv6 mld version Use the **ipv6 mld version** Interface Configuration mode command to change the version of the Multicast Listener Discovery Protocol (MLD). Use the **no** form of this command to change to the default version.

SYNTAX

ipv6 mld version {1 | 2}
no ipv6 mld version

PARAMETERS

1—Specifies MLD version 1.

2—Specifies MLD version 2.

DEFAULT CONFIGURATION

MLD version 1.

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode

```
console(config)# interface vlan 1  
console(config-if)# ipv6 mld version 2
```

ipv6 mld join-group Use the **ipv6 mld join-group** Interface Configuration mode command to configure Multicast Listener Discovery (MLD) reporting for a specified group. Use the **no** form of this command to cancel reporting and leave the group.

SYNTAX

ipv6 mld join-group *group-address*
no ipv6 mld join-group *group-address*

PARAMETERS

group-address—Specifies the IPv6 address of the multicast group.

DEFAULT CONFIGURATION

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode

USER GUIDELINES

The **ipv6 mld join-group** command configures MLD reporting for a specified group. The packets that are addressed to a specified group address will be passed up to the client process in the device.

EXAMPLE

The following example configures MLD reporting for specific groups:

```
console(config)# interface vlan 1
console(config-if)# ipv6 mld join-group ff02::10
```

show ipv6 neighbors Use the **show ipv6 neighbors** Privileged EXEC mode command to display IPv6 neighbor discovery cache information.

SYNTAX

show ipv6 neighbors *{static | dynamic}[ipv6-address ipv6-address]
[mac-address mac-address] [interface-id]*

PARAMETERS

- ◆ **static**—Shows static neighbor discovery cash entries.
- ◆ **dynamic**—Shows dynamic neighbor discovery cash entries.
- ◆ **ipv6-address**—Shows the neighbor discovery cache information entry of a specific IPv6 address.
- ◆ **mac-address**—Shows the neighbor discovery cache information entry of a specific MAC address.
- ◆ **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

Since the associated interface of a MAC address can be aged out from the FDB table, the Interface field can be empty.

When an ARP entry is associated with an IP interface that is defined on a port or port-channel, the VLAN field is empty.

The possible neighbor cash states are:

- ◆ **INCMP (Incomplete)**—Address resolution is being performed on the entry. Specifically, a Neighbor Solicitation has been sent to the solicited-node multicast address of the target, but the corresponding Neighbor Advertisement has not yet been received.
- ◆ **REACH (Reachable)**—Positive confirmation was received within the last ReachableTime milliseconds that the forward path to the neighbor was functioning properly. While REACHABLE, no special action takes place as packets are sent.

- ◆ STALE—More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly. While stale, no action takes place until a packet is sent.
- ◆ DELAY—More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly, and a packet was sent within the last DELAY_FIRST_PROBE_TIME seconds. If no reachability confirmation is received within DELAY_FIRST_PROBE_TIME seconds of entering the DELAY state, send a Neighbor Solicitation and change the state to PROBE.
- ◆ PROBE—A reachability confirmation is actively sought by retransmitting Neighbor Solicitations every RetransTimer milliseconds until a reachability confirmation is received.

EXAMPLE

```
Console# show ipv6 neighbors dynamic
```

Interface	IPv6 address	HW address	State	Router
VLAN 1	fe80::200:cff:fe4a:dfa8	00:00:0c:4a:df:a8	stale	yes
VLAN 1	fe80::2d0:b7ff:fea1:264d	00:d0:b7:a1:26:4d	stale	no

clear ipv6 neighbors Use the **clear ipv6 neighbors** Privileged EXEC mode command to delete all entries in the IPv6 neighbor discovery cache, except for static entries.

SYNTAX

clear ipv6 neighbors

PARAMETERS

This command has no keywords or arguments.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

```
console# clear ipv6 neighbors
```


IP ROUTING PROTOCOL- INDEPENDENT COMMANDS

iPECS ES-5048XG

ip route Use the **ip route** Global Configuration mode command to configure static routes. Use the **no** form of this command to remove static routes.

SYNTAX

ip route *prefix* {*mask* | *prefix-length*} *ip-address* [*metric distance*]
[*reject-route*]

no ip route *prefix* {*mask* | *prefix-length*} [*ip-address*]

PARAMETERS

- ◆ **prefix**—Specifies the IP address that is the IP route prefix for the destination IP.
- ◆ **mask**—Specifies the network subnet mask of the IP address prefix.
- ◆ **prefix-length**—Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 0–32)
- ◆ **ip-address**—Specifies the IP address or IP alias of the next hop that can be used to reach the network.
- ◆ **metric distance**—Specifies an administrative distance. (Range: 1–255)
- ◆ **reject-route**—Stops routing to the destination network via all gateways.

DEFAULT CONFIGURATION

The default administrative distance is 1.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example configures a static route with prefix 172.16.0.0, prefix length 16, and gateway 131.16.1.1.

```
Console(config)# ip route 172.16.0.0 /16 131.16.1.1
```

ip routing Use the **ip routing** Global Configuration mode command to enable IPv4 Routing. Use the **no** format of the command to disable IPv4 Routing.

SYNTAX

ip routing
no ip routing

DEFAULT CONFIGURATION

Enabled by default.

COMMAND MODE

Global Configuration mode

DEFAULT CONFIGURATION

No routing is defined

show ip route Use the **show ip route** EXEC mode command to display the current routing table state.

SYNTAX

show ip route [*connected* | *static* | {*address address* [*mask* | *prefix-length*] [*longer-prefixes*]}]

PARAMETERS

- ◆ **connected**—Displays connected routing entries only.
- ◆ **static**—Displays static routing entries only.
- ◆ **address address**—Specifies the address for which routing information is displayed.
- ◆ **mask**—Specifies the network subnet mask of the IP address.
- ◆ **prefix-length**—Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 1–32)
- ◆ **longer-prefixes**—Specifies that the **address** and **mask** pair becomes a prefix and any routes that match that prefix are displayed.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the current routing table state.

```
Console> show ip route
console# show ip route
Maximum Parallel Paths: 1 (1 after reset)
```



```

IP Forwarding:                enabled

Codes: C - connected, S - static, D - DHCP

S 0.0.0.0/0                    [1/1] via 10.5.234.254 119:9:27   vlan 1
C 10.5.234.0/24                is directly connected           vlan 1
Console> show ip route address 172.1.1.0 255.255.255.0

Codes: C - connected, S - static, E - OSPF external, * - candidate default

S 172.1.1.0/24 [5/3] via 10.0.2.1, 17:12:19, Ethernet1

Console> show ip route address 172.1.1.0 255.255.255.0 longer-prefixes
Codes: C - connected, S - static, E - OSPF external

S 172.1.1.0/24 [5/3] via 10.0.2.1, 17:12:19, Ethernet1
S 172.1.1.1/32 [5/3] via 10.0.3.1, 19:51:18, Ethernet1

```

The following table describes the significant fields shown in the display:

Field	Description
O	The protocol that derived the route.
10.8.1.0/24	The remote network address.
[30/2000]	The first number in the brackets is the administrative distance of the information source; the second number is the metric for the route.
via 10.0.1.2	The address of the next router to the remote network.
00:39:08	The last time the route was updated, in hours:minutes:seconds.
Ethernet 1	The interface through which the specified network can be reached.

interface tunnel Use the **interface tunnel** Global Configuration mode command to enter the Interface Configuration (Tunnel) mode.

SYNTAX

interface tunnel *number*

PARAMETERS

number—Specifies the tunnel index.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enters the Interface Configuration (Tunnel) mode.

```
Console(config)# interface tunnel 1
Console(config-tunnel)#
```

tunnel mode ipv6ip Use the **tunnel mode ipv6ip** Interface Configuration (Tunnel) mode command to configure an IPv6 transition-mechanism global support mode. Use the **no** form of this command to remove an IPv6 transition mechanism.

SYNTAX

tunnel mode ipv6ip *{isatap}*
no tunnel mode *ipv6ip*

PARAMETERS

isatap—Enables an automatic IPv6 over IPv4 Intra-Site Automatic Tunnel Addressing Protocol (ISATAP) tunnel.

DEFAULT CONFIGURATION

The IPv6 transition-mechanism global support mode is disabled.

COMMAND MODE

Interface Configuration (Tunnel) mode

USER GUIDELINES

The system can be enabled to ISATAP tunnel. When enabled, an automatic tunnel interface is created on each interface that is assigned an IPv4 address.

Note that on a specific interface (for example, port or VLAN), both native IPV6 and transition-mechanisms can coexist. The host implementation chooses the egress interface according to the scope of the destination IP address (such as ISATAP or native IPv6).

EXAMPLE

The following example configures an IPv6 transition mechanism global support mode.

```
Console(config)# interface tunnel 1
Console(config-tunnel)# tunnel mode ipv6ip isatap
```

tunnel isatap router Use the **tunnel isatap router** Interface Configuration (Tunnel) mode command to configure a global string that represents a specific automatic tunnel router domain name. Use the **no** form of this command to remove the string associated with the router domain name and restore the default configuration.

SYNTAX

tunnel isatap router *router-name*
no tunnel isatap router

PARAMETERS

router-name—Specifies the router's domain name.

DEFAULT CONFIGURATION

The automatic tunnel router's default domain name is ISATAP.

COMMAND MODE

Interface Configuration (Tunnel) mode

USER GUIDELINES

The **ipv6 tunnel routers-dns** command determines the string that the host uses for automatic tunnel router lookup in the IPv4 DNS procedure. By default, the string ISATAP is used for the corresponding automatic tunnel types.

Only one string can represent the automatic tunnel router name per tunnel. Using this command, therefore, overwrites the existing entry.

EXAMPLE

The following example configures the global string ISATAP2 as the automatic tunnel router domain name.

```
Console(config)# tunnel 1
Console(config-tunnel)# tunnel isatap router ISATAP2
```

tunnel source Use the **tunnel source** Interface Configuration (Tunnel) mode command to set the local (source) IPv4 address of a tunnel interface. The **no** form deletes the tunnel local address.

SYNTAX

tunnel source { *auto* | *ipv4-address* }
no tunnel source

PARAMETERS

- ◆ **auto**—The system minimum IPv4 address is used as the source address for packets sent on the tunnel interface. If the IPv4 address is changed, then the local address of the tunnel interface is changed too.
- ◆ **ip4-address**—Specifies the IPv4 address to use as the source address for packets sent on the tunnel interface. The local address of the tunnel interface is not changed when the IPv4 address is moved to another interface (only if StackTable is changed).

DEFAULT

No source address is defined.

COMMAND MODE

Interface Configuration (Tunnel) mode

USER GUIDELINES

The configured source IPv4 address is used for forming the tunnel interface identifier. The interface identifier is set to the 8 least significant bytes of the SIP field of the encapsulated IPv6 tunneled packets.

EXAMPLE

```
console(config)# interface tunnel 1
console(config-tunnel)# tunnel source auto
```

tunnel isatap query-interval Use the **tunnel isatap query-interval** Global Configuration mode command to set the time interval between Domain Name System (DNS) queries (before the ISATAP router IP address is known) for the automatic tunnel router domain name. Use the **no** form of this command to restore the default configuration.

SYNTAX

tunnel isatap query-interval *seconds*
no tunnel isatap query-interval

PARAMETERS

seconds—Specifies the time interval in seconds between DNS queries. (Range: 10–3600)

DEFAULT CONFIGURATION

The default time interval between DNS queries is 10 seconds.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command determines the time interval between DNS queries before the ISATAP router IP address is known. If the IP address is known, the robustness level that is set by the **tunnel isatap robustness** Global Configuration mode command determines the refresh rate.

EXAMPLE

The following example sets the time interval between DNS queries to 30 seconds.

```
Console(config)# tunnel isatap query-interval 30
```

tunnel isatap solicitation-interval Use the **tunnel isatap solicitation-interval** Global Configuration mode command to set the time interval between ISATAP router solicitation messages. Use the **no** form of this command to restore the default configuration.

SYNTAX

tunnel isatap solicitation-interval *seconds*
no tunnel isatap solicitation-interval

PARAMETERS

seconds—Specifies the time interval in seconds between ISATAP router solicitation messages. (Range: 10–3600)

DEFAULT CONFIGURATION

The default time interval between ISATAP router solicitation messages is 10 seconds.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command determines the interval between router solicitation messages when there is no active ISATAP router. If there is an active ISATAP router, the robustness level set by the **tunnel isatap robustness** Global Configuration mode command determines the refresh rate.

EXAMPLE

The following example sets the time interval between ISATAP router solicitation messages to 30 seconds.

```
Console(config)# tunnel isatap solicitation-interval 30
```

**tunnel isatap
robustness**

Use the **tunnel isatap robustness** Global Configuration mode command to configure the number of DNS query/router solicitation refresh messages that the device sends. Use the **no** form of this command to restore the default configuration.

SYNTAX

tunnel isatap robustness *number*

no tunnel isatap robustness

PARAMETERS

number—Specifies the number of DNS query/router solicitation refresh messages that the device sends. (Range: 1–20)

DEFAULT CONFIGURATION

The default number of DNS query/router solicitation refresh messages that the device sends is 3.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The DNS query interval (after the ISATAP router IP address is known) is the Time-To-Live (TTL) that is received from the DNS, divided by (Robustness + 1).

The router solicitation interval (when there is an active ISATAP router) is the minimum-router-lifetime that is received from the ISATAP router, divided by (Robustness + 1).

EXAMPLE

The following example sets the number of DNS query/router solicitation refresh messages that the device sends to 5.

```
Console(config)# tunnel isatap robustness 5
```

show ipv6 tunnel Use the **show ipv6 tunnel** EXEC mode command to display information on the ISATAP tunnel.

SYNTAX

show ipv6 tunnel

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays information on the ISATAP tunnel.

```
Console> show ipv6 tunnel
Tunnel 1
-----

Tunnel status                : DOWN
Tunnel protocol              : NONE
Tunnel Local address type    : auto
Tunnel Local Ipv4 address    : 0.0.0.0
Router DNS name              : ISATAP
Router IPv4 address          : 0.0.0.0
DNS Query interval           : 300 seconds
Min DNS Query interval       : 0 seconds
Router Solicitation interval : 10 seconds
Min Router Solicitation interval : 0 seconds
Robustness                   : 2
```

ip access-list extended Use the **ip access-list** global configuration mode command to define an IPv4 access list and to place the device in IPv4 access list configuration mode. Use the **no** form of this command to remove the access list.

SYNTAX

ip access-list extended *access-list-name*
no ip access-list extended *access-list-name*

PARAMETERS

- ◆ **access-list-name**—Name of the IPv4 access list.
- ◆ **access-list-name**—0–32 characters. (Use "" for empty string)

DEFAULT

No IPv4 access list is defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

IPv4 ACL is defined by a unique name. IPv4 ACL, IPv6 ACL, MAC ACL or Policy Map cannot have the same name.

EXAMPLE

```
console(config)# ip access-list extended server
```

permit (IP) Use the **permit** IP Access-list Configuration mode command to set permit conditions for IPv4 access list.

SYNTAX

permit *protocol* {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [*dscp number* | *precedence number*] [*time-range time-range-name*]
permit *icmp* {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [*any* | *icmp-type*] [*any* | *icmp-code*] [*dscp number* | *precedence number*] [*time-range time-range-name*]

permit igmp {any | source source-wildcard} {any | destination destination-wildcard} [igmp-type] [dscp number | precedence number] [time-range time-range-name]

permit tcp {any | source source-wildcard} {any|source-port/port-range}{any | destination destination-wildcard} {any|destination-port/port-range } [dscp number | precedence number] [match-all list-of-flags] [time-range time-range-name]

permit udp {any | source source-wildcard} {any|source-port/port-range} {any | destination destination-wildcard} {any|destination-port/port-range } [dscp number | precedence number] [match-all time-range-name] [time-range time-range-name]

PARAMETERS

- ◆ **protocol**—The name or the number of an IP protocol. Available protocol names icmp, igmp, ip, tcp, egp, igp, udp, hmp, rdp, idpr, ipv6, ipv6:rout, ipv6:frag, idrp, rsvp, gre, esp, ah, ipv6:icmp, eigrp, ospf, ipinip, pim, l2tp, isis. To match any protocol use the ip keyword.(Range: 0–255)
- ◆ **source**—Source IP address of the packet.
- ◆ **source-wildcard**—Wildcard bits to be applied to the source IP address. Use ones in the bit position that you want to be ignored.
- ◆ **destination**—Destination IP address of the packet.
- ◆ **destination-wildcard**—Wildcard bits to be applied to the destination IP address. Use ones in the bit position that you want to be ignored.
- ◆ **dscp number**—Specifies the DSCP value.
- ◆ **precedence number**—Specifies the IP precedence value.
- ◆ **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: echo-reply, destination-unreachable, source-quench, redirect, alternate-host-address, echo-request, router-advertisement, router-solicitation, time-exceeded, parameter-problem, timestamp, timestamp-reply, information-request, information-reply, address-mask-request, address-mask-reply, traceroute, datagram-conversion-error, mobile-host-redirect, mobile-registration-request, mobile-registration-reply, domain-name-request, domain-name-reply, skip, photuris. (Range: 0–255)
- ◆ **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- ◆ **igmp-type**—IGMP packets can be filtered by IGMP message type. Enter a number or one of the following values: host-query, host-report, dvmrp, pim, cisco-trace, host-report-v2, host-leave-v2, host-report-v3. (Range: 0–255)

- ◆ **destination-port**—Specifies the UDP/TCP destination port. You can enter range of ports by using hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), on500-isakmp (4500), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs-ds (49), talk (517), tftp (69), time (37), who (513), xdmcp (177).(Range: 0–65535).
- ◆ **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- ◆ **match-all list-of-flags**—List of TCP flags that should occur. If a flag should be set, it is prefixed by "+". If a flag should be unset, it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.
- ◆ **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)

DEFAULT

No IPv4 access list is defined.

COMMAND MODE

IP Access-list Configuration mode

USER GUIDELINES

You enter IP-access list configuration mode by using the IP Access-list Global Configuration command.

After an access control entry (ACE) is added to an access control list, an implied deny any any condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

The number of TCP/UDP ranges that can be defined in ACLs is limited. You can define up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for source port in ACE it would be not be counted again if it is also used for source port in another ACE. If a range of ports is used for destination port in ACE it would be not be counted again if it is also used for destination port in another ACE.

If a range of ports is used for source port it would be counted again if it is also used for destination port.

EXAMPLE

```
console(config)# ip access-list extended server
console(config-ip-al)# permit ip 1.1.1.0 0.0.0.255 1.1.2.0 0.0.0.0
```

deny (IP) Use the **deny** IP Access-list Configuration mode command to set deny conditions for IPv4 access list.

SYNTAX

deny *protocol* {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [*dscp number* | *precedence number*] [*time-range time-range-name*] [*disable-port* | *log-input*]

deny *icmp* {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} {*any|icmp-type*} {*any|icmp-code*} [*dscp number* | *precedence number*] [*time-range time-range-name*] [*disable-port* | *log-input*]

deny *igmp* {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [*igmp-type*] [*dscp number* | *precedence number*] [*time-range time-range-name*] [*disable-port* | *log-input*]

deny *tcp* {*any* | *source source-wildcard*} {*any|source-port/port-range*} {*any* | *destination destination-wildcard*} {*any|destination-port/port-range*} [*dscp number* | *precedence number*] [*match-all list-of-flags*] [*time-range time-range-name*] [*disable-port* | *log-input*]

deny *udp* {*any* | *source source-wildcard*} {*any|source-port/port-range*} {*any* | *destination destination-wildcard*} {*any|destination-port/port-range*} [*dscp number* | *precedence number*] [*match-all time-range-name*] [*time-range time-range-name*] [*disable-port* | *log-input*]

PARAMETERS

- ◆ **protocol**—The name or the number of an IP protocol. Available protocol names: icmp, igmp, ip, tcp, egp, igp, udp, hmp, rdp, idpr, ipv6, ipv6:rout, ipv6:frag, idrp, rsvp, gre, esp, ah, ipv6:icmp, eigrp, ospf, ipinip, pim, l2tp, isis. To match any protocol use the Ip keyword. (Range: 0–255)
- ◆ **source**—Source IP address of the packet.
- ◆ **source-wildcard**—Wildcard bits to be applied to the source IP address. Use 1s in the bit position that you want to be ignored.
- ◆ **destination**—Destination IP address of the packet.
- ◆ **destination-wildcard**—Wildcard bits to be applied to the destination IP address. Use 1s in the bit position that you want to be ignored.
- ◆ **dscp number**—Specifies the DSCP value.
- ◆ **precedence number**—Specifies the IP precedence value.

- ◆ **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: echo-reply, destination-unreachable, source-quench, redirect, alternate-host-address, echo-request, router-advertisement, router-solicitation, time-exceeded, parameter-problem, timestamp, timestamp-reply, information-request, information-reply, address-mask-request, address-mask-reply, traceroute, datagram-conversion-error, mobile-host-redirect, mobile-registration-request, mobile-registration-reply, domain-name-request, domain-name-reply, skip, photuris. (Range: 0–255)
- ◆ **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- ◆ **igmp-type**—IGMP packets can be filtered by IGMP message type. Enter a number or one of the following values: host-query, host-report, dvmrp, pim, cisco-trace, host-report-v2, host-leave-v2, host-report-v3. (Range: 0–255)
- ◆ **destination-port**—Specifies the UDP/TCP destination port. You can enter range of ports by using hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), non500-isakmp (4500), ntp (123), rip (520), snmp 161), snmptrap (162), sunrpc (111), syslog (514), tacacs-ds (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535)
- ◆ **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- ◆ **match-all list-of-flags**—List of TCP flags that should occur. If a flag should be set it is prefixed by "+". If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.
- ◆ **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)
- ◆ **disable-port**—The Ethernet interface is disabled if the condition is matched.
- ◆ **log-input**—Specifies sending an informational syslog message about the packet that matches the entry. Because forwarding is done in hardware and logging is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might

not be able to match the hardware processing rate, and not all packets will be logged.

DEFAULT

No IPv4 access list is defined.

COMMAND MODE

IP Access-list Configuration mode

USER GUIDELINES

You enter IP-access list configuration mode by using the IP Access-list Global Configuration command.

After an access control entry (ACE) is added to an access control list, an implied deny any any condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

The number of TCP/UDP ranges that can be defined in ACLs is limited. You can define up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for source port in ACE it would be not be counted again if it is also used for source port in another ACE. If a range of ports is used for destination port in ACE it would be not be counted again if it is also used for destination port in another ACE.

If a range of ports is used for source port, it would be counted again if it is also used for destination port.

EXAMPLE

```
console(config)# ip access-list extended server
console(config-ip-al)# deny ip 1.1.1.0 0.0.0.255 1.1.2.0 0.0.0.0
```

ipv6 access-list Use the **ipv6 access-list** global configuration mode command to define an IPv6 access list and to place the device in IPv6 access list configuration mode. Use the **no** form of this command to remove the access list.

SYNTAX

```
ipv6 access-list [access-list-name]
no ipv6 access-list [access-list-name]
```

PARAMETERS

- ◆ **access-list-name**—Name of the IPv6 access list.
- ◆ **access-list-name**—0–32 characters (use "" for empty string)

DEFAULT

No IPv6 access list is defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

IPv6 ACL is defined by a unique name. IPv4 ACL, IPv6 ACL, MAC ACL or Policy Map cannot have the same name.

Every IPv6 ACL has implicit permit icmp any any nd-ns any, permit icmp any any nd-na any, and deny ipv6 any any statements as its last match conditions. (The former two match conditions allow for ICMPv6 neighbor discovery.)

The IPv6 neighbor discovery process makes use of the IPv6 network layer service, therefore, by default, IPv6 ACLs implicitly allow IPv6 neighbor discovery packets to be sent and received on an interface. In IPv4, the Address Resolution Protocol (ARP), which is equivalent to the IPv6 neighbor discovery process, makes use of a separate data link layer protocol; therefore, by default, IPv4 ACLs implicitly allow ARP packets to be sent and received on an interface.

EXAMPLE

```
Switch (config)# ipv6 access-list acl1
Switch(config-ipv6-acl)# permit tcp 2001:0DB8:0300:0201::/64 any any 80
```

permit (IPv6) Use the **permit** command in IPv6 Access-list Configuration mode to set permit conditions for IPv6 access list.

SYNTAX

permit *protocol* {*any* | {*source-prefix/length* } {*any* | *destination-prefix/length* } [*dscp number* | *precedence number*] [*time-range time-range-name*]

permit *icmp* {*any* | {*source-prefix/length* } {*any* | *destination-prefix/length* } {*any*|*icmp-type*} {*any*|*icmp-code*} [*dscp number* | *precedence number*] [*time-range time-range-name*]

permit *tcp* {*any* | {*source-prefix/length* } {*any* | *source-port/port-range* } } {*any* | *destination-prefix/length* } {*any*| *destination-port/port-range*} [*dscp number* | *precedence number*] [*match-all list-of-flags*] [*time-range time-range-name*]

permit *udp* {*any* | {*source-prefix/length* } } {*any* | *source-port/port-range* } } {*any* | *destination-prefix/length* } {*any*| *destination-port/port-range*} [*dscp number* | *precedence number*] [*time-range time-range-name*]

PARAMETERS

- ◆ **protocol**—The name or the number of an IP protocol. Available protocol names are: icmp (58), tcp (6) and udp (17). To match any protocol, use the ipv6 keyword. (Range: 0–255)

- ◆ **source-prefix/length**—The source IPv6 network or class of networks about which to set permit conditions. This argument must be in the form documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- ◆ **destination-prefix/length**—The destination IPv6 network or class of networks about which to set permit conditions. This argument must be in the form documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- ◆ **dscp number**—Specifies the DSCP value. (Range: 0–63)
- ◆ **precedence number**—Specifies the IP precedence value.
- ◆ **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: destination-unreachable (1), packet-too-big (2), time-exceeded (3), parameter-problem (4), echo-request (128), echo-reply (129), mld-query (130), mld-report (131), mldv2-report (143), mld-done (132), router-solicitation (133), router-advertisement (134), nd-ns (135), nd-na (136). (Range: 0–255)
- ◆ **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- ◆ **destination-port**—Specifies the UDP/TCP destination port. You can enter a range of ports by using a hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), non500-isakmp (4500), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535)
- ◆ **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- ◆ **match-all list-of-flag**—List of TCP flags that should occur. If a flag should be set it is prefixed by "+". If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.
- ◆ **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)

DEFAULT

No IPv6 access list is defined.

COMMAND MODE

IPv6 Access-list Configuration mode

USER GUIDELINES

The number of TCP/UDP ranges that can be defined in ACLs is limited. You can define up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for a source port in ACE it would be not be counted again if it is also used for a source port in another ACE. If a range of ports is used for destination port in ACE it would be not be counted again if it is also used for destination port in another ACE.

If a range of ports is used for source port it would be counted again if it is also used for destination port.

EXAMPLE

```
console(config)# ipv6 access-list server
console(config-ipv6-acl)# permit tcp 3001::2/64 any any 80
```

deny (IPv6) Use the **deny** command in IPv6 access list configuration mode to set permit conditions for IPv6 access list.

SYNTAX

deny *protocol* {*any* | {*source-prefix/length* } {*any* | *destination- prefix/length* } [*dscp number* | *precedence number*] [*time-range time-range-name*] [*disable-port* | *log-input*]

deny *icmp* {*any* | {*source-prefix/length* } {*any* | *destination- prefix/length* } {*any|icmp-type*} {*any|icmp-code*} [*dscp number* | *precedence number*] [*time-range time-range-name*] [*disable-port* | *log-input*]

deny *tcp* {*any* | {*source-prefix/length* } {*any* | *source-port/port-range* } } {*any* | *destination- prefix/length* } {*any* | *destination-port/port-range*} [*dscp number* | *precedence number*] [*match-all list-of-flags*] [*time-range time-range-name*] [*disable-port* | *log-input*]

deny *udp* {*any* | {*source-prefix/length* } } {*any* | *source-port/port-range* } } {*any* | *destination- prefix/length* } {*any* | *destination-port/port-range*} [*dscp number* | *precedence number*] [*time-range time-range-name*] [*disable-port* | *log-input*]

PARAMETERS

- ◆ **protocol**—The name or the number of an IP protocol. Available protocol names are: icmp (58), tcp (6) and udp (17). To match any protocol use the ipv6 keyword. (Range: 0–255)
- ◆ **source-prefix/length**—The source IPv6 network or class of networks about which to set permit conditions. This argument must be in the

form documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.

- ◆ **destination-prefix/length**—The destination IPv6 network or class of networks about which to set permit conditions. This argument must be in the form documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- ◆ **dscp number**—Specifies the DSCP value. (Range: 0–63)
- ◆ **precedence number**—Specifies the IP precedence value.
- ◆ **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: destination-unreachable (1), packet-too-big (2), time-exceeded (3), parameter-problem (4), echo-request (128), echo-reply (129), mld-query (130), mld-report (131), mldv2-report (143), mld-done (132), router-solicitation (133), router-advertisement (134), nd-ns (135), nd-na (136). (Range: 0–255)
- ◆ **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- ◆ **destination-port**—Specifies the UDP/TCP destination port. You can enter a range of ports by using a hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), non500-isakmp (4500), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535)
- ◆ **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- ◆ **match-all list-of-flags**—List of TCP flags that should occur. If a flag should be set it is prefixed by "+". If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.
- ◆ **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)
- ◆ **disable-port**—The Ethernet interface would be disabled if the condition is matched.

- ◆ **log-input**—Specifies to send an informational syslog message about the packet that matches the entry. Because forwarding is done in hardware and logging is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might not be able to match the hardware processing rate, and not all packets will be logged.

DEFAULT

No IPv6 access list is defined.

COMMAND MODE

IPv6 Access-list Configuration mode

USER GUIDELINES

The number of TCP/UDP ranges that can be defined in ACLs is limited. You can define up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for source port in ACE it would be not be counted again if it is also used for source port in another ACE. If a range of ports is used for a destination port in ACE it would be not be counted again if it is also used for a destination port in another ACE.

If a range of ports is used for source port it would be counted again if it is also used for destination port.

EXAMPLE

```
console(config)# ipv6 access-list server
console(config-ipv6-al)# deny tcp 3001::2/64 any any 80
```

mac access-list Use the **mac access-list** Global Configuration mode command to define a Layer 2 access list and to place the device in MAC access list configuration mode. Use the **no** form of this command to remove the access list.

SYNTAX

mac access-list extended *access-list-name*
no mac access-list extended *access-list-name*

PARAMETERS

access-list-name—Specifies the name of the MAC access list. (Range: access-list-name0–32 characters - use "" for empty string)

DEFAULT

No MAC access list is defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

MAC ACL is defined by a unique name. IPv4 ACL, IPv6 ACL, MAC ACL or Policy Map cannot have the same name.

EXAMPLE

```
console(config)# mac access-list extended server1
```

permit (MAC) Use the **permit** command in MAC Access List Configuration mode to set permit conditions for an MAC access list,.

SYNTAX

permit {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [*eth-type 0*| *aarp* | *amber* | *dec-spanning* | *decnet-iv* | *diagnostic* | *dsm* | *etype-6000*] [*vlan vlan-id*] [*cos cos cos-wildcard*] [*time-range time-range-name*]

PARAMETERS

- ◆ **source**—Source MAC address of the packet.
- ◆ **source-wildcard**—Wildcard bits to be applied to the source MAC address. Use 1s in the bit position that you want to be ignored.
- ◆ **destination**—Destination MAC address of the packet.
- ◆ **destination-wildcard**—Wildcard bits to be applied to the destination MAC address. Use 1s in the bit position that you want to be ignored.
- ◆ **eth-type**—The Ethernet type in hexadecimal format of the packet.
- ◆ **vlan-id**—The VLAN ID of the packet. (Range: 1–4094)
- ◆ **cos**—The Class of Service of the packet. (Range: 0–7)
- ◆ **cos-wildcard**—Wildcard bits to be applied to the CoS.
- ◆ **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)

DEFAULT

No MAC access list is defined.

COMMAND MODE

MAC Access-list Configuration mode

USER GUIDELINES

You enter MAC-access list configuration mode by using the MAC Access-list Global Configuration command.

After an access control entry (ACE) is added to an access control list, an implied deny-any-any condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

EXAMPLE

```
console(config)# mac access-list extended server1
console(config-mac-acl)# permit 00:00:00:00:00:01 00:00:00:00:00:ff any
```

service-acl use the **service-acl** command in interface configuration mode to control access to an interface. Use the **no** form of this command to remove the access control.

SYNTAX

```
service-acl input acl-name1 [acl-name2]
no service-acl input
```

PARAMETERS

acl-name—Specifies an ACL to apply to the interface. See the usage guidelines. (Range: acl-name0–32 characters. Use "" for empty string)

DEFAULT

No ACL is assigned.

COMMAND MODE

Interface Configuration (Ethernet, Port-Channel) mode.

Interface Configuration (Ethernet, VLAN, Port-Channel) mode.

USER GUIDELINES

IPv4 ACL and IPv6 ACL can be bound together to an interface.

MAC ACL cannot be bound on an interface with IPv4 ACL or IPv6 ACL.

Two ACLs of the same type can't be added to a port.

An ACL can't be added to a port that is already bounded to an ACL, without first removing the current ACL and binding the two ACLs together.

EXAMPLE

```
console(config)# mac access-list extended server
console(config-mac-acl)# permit 00:00:00:00:00:01 00:00:00:00:00:ff any
console(config-mac-acl)# exit
console(config)# interface tengigabitethernet 0/1
console(config-if)# service-acl input server
```

show access-lists Use the **show access-lists** Privileged EXEC mode command to display access control lists (ACLs) configured on the switch.

SYNTAX

```
show access-lists [name | access-list-number]
show access-lists time-range-active [name]
```

PARAMETERS

- ◆ **name**—Specifies the name of the ACL.
- ◆ **access-list-number**—Specifies the number of the IP standard ACL list.
- ◆ **time-range-active**—Shows only the Access Control Entries (ACEs) that their time-range is currently active (including those that are not associated with time-range).

COMMAND MODE

Privileged EXEC mode

EXAMPLE

```
Switch# show access-lists
Router# show access-lists

Standard IP access list 1
deny any
Standard IP access list 2
deny 192.168.0.0, wildcard bits 0.0.0.255
permit any
Standard IP access list 3
deny 0.0.0.0
deny 192.168.0.1, wildcard bits 0.0.0.255
permit any
Standard IP access list 4
permit 0.0.0.0
permit 192.168.0.2, wildcard bits 0.0.0.255

Extended IP access list ACL1
permit 234 172.30.40.1 0.0.0.0 any
permit 234 172.30.8.8 0.0.0.0 any

Extended IP access list ACL2
permit 234 172.30.19.1 0.0.0.255 any time-range weekdays
permit 234 172.30.23.8 0.0.0.255 any time-range weekends

Switch# show access-lists time-range-active
Extended IP access list ACL1
permit 234 172.30.40.1 0.0.0.0 any
permit 234 172.30.8.8 0.0.0.0 any

Extended IP access list ACL2
permit 234 172.30.19.1 0.0.0.255 any time-range weekdays

Switch# show access-lists
```

show interfaces access-lists Use the **show interfaces access-lists** Privileged EXEC mode command to display access lists applied on interfaces.

SYNTAX

show interfaces access-lists [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

```
Console# show interfaces access-lists
Interface      Input ACL
-----
te1            ACL1
te2            ACL3
te3            blockcdp, blockvtp
```

clear access-lists counters Use The **Clear Access-lists Counters** Privileged EXEC mode command to clear access-lists counters.

SYNTAX

clear access-lists counters [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

Privileged EXEC mode

EXAMPLE

```
console# clear access-lists counters tengigabitethernet 0/1
```

show interfaces access-lists counters Use the **show interfaces access-lists counters** Privileged EXEC mode command to display Access List counters.

SYNTAX

show interfaces access-lists counters [*ethernet interface* | *port-channel port-channel-number*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

COMMAND MODE

Privileged EXEC mode

USER GUIDELINES

The counter of deny ACE hits counts only ACEs with the log-input keyword.

Because forwarding is done in hardware and counting is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might not be able to match the hardware processing rate, and not all packets are counted.

EXAMPLE

```
console# show interfaces access-lists counters
```

Interface	deny ACE hits
-----	-----
te1	79
te2	9
te3	0

```
Number of hits that were counted in global counter (due to lack of resources)  
=19
```

QUALITY OF SERVICE (QoS) COMMANDS

iPECS ES-5048XG

qos Use the **qos** Global Configuration mode command to enable Quality of Service (QoS) on the device. Use the **no** form of this command to disable QoS on the device.

SYNTAX

qos [*basic* | *advanced* [*ports-not-trusted* | *ports-trusted*]]
no qos

PARAMETERS

- ◆ **basic**—QoS basic mode. If no option is specified, the QoS mode defaults to the basic mode.
- ◆ **advanced**—Specifies the QoS advanced mode, which enables the full range of QoS configuration.

ports-not-trusted—Relevant for advanced mode only. Indicates that packets not classified by Policy map rules to a QoS action are mapped to egress queue 0. This is the default setting in advanced mode.

ports-trusted—Relevant for advanced mode only. Indicates that packets not classified by Policy map rules to a QoS action are mapped to an egress queue based on the packet's fields. Use the **qos advanced-mode trust global** configuration command to specify the trust mode.

DEFAULT CONFIGURATION

If the **qos** command is entered without any parameters, the QoS **basic** mode is enabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables the QoS basic mode on the device.

```
Console(config)# qos basic
```


qos advanced-mode trust Use the **qos advanced-mode trust** global configuration command to configure the trust mode when the default action is trust in advanced mode. Use the **no** form of this command to return to default.

SYNTAX

qos advanced-mode trust {*cos* | *dscp* | *cos-dscp*}
no qos advanced-mode trust

PARAMETERS

cos—Classifies ingress packets with the packet CoS values. For untagged packets, the port default CoS is used.

dscp—Classifies ingress packets with the packet DSCP values.

cos-dscp—Classifies ingress packets with the packet DSCP values for IP packets. For other packet types, use the packet CoS values.

DEFAULT CONFIGURATION

cos-dscp

COMMAND MODE

Global configuration

USER GUIDELINES

The configuration is relevant for advanced mode in the following cases:

- ◆ ports-not-trusted mode: For packets that are classified to the QoS action trust.
- ◆ ports-trusted mode: For packets that are not classified by to any QoS action or classified to the QoS action trust.

EXAMPLE

```
qos advanced-mode trust cos-dscp
```

show qos Use the **show qos** EXEC mode command to display the Quality of Service (QoS) mode for the device. The trust mode is displayed for the QoS basic mode.

SYNTAX

show qos

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Disabled Command Mode

COMMAND MODE

EXEC mode

USER GUIDELINES

Trust mode is displayed if QoS is enabled in basic mode.

EXAMPLE

The following example displays QoS attributes when QoS is enabled in basic mode on the device and the advanced mode is supported.

```
Console> show qos
Qos: basic
Basic trust: dscp
```

```
console>show qos
Qos: Disabled
```

```
console>show qos
Qos: Basic mode
Basic trust: dscp
```

```
console>show qos
Qos: Advanced mode
Advanced mode ports state: Trusted
Advanced mode trust type: cos
```

The following example displays QoS attributes when QoS is enabled in basic mode on the device and the advanced mode is not supported.

```
Console> show qos
Qos: disable
Trust: dscp
```

class-map Use the **class-map** Global Configuration mode command to create or modify a class map and enters the Class-map Configuration mode. Use the **no** form of this command to delete a class map.

SYNTAX

class-map *class-map-name* [*match-all* | *match-any*]

no class-map *class-map-name*

PARAMETERS

◆ **class-map-name**—Specifies the class map name.

- ◆ **match-all**—Performs a logical AND of all the matching statements under this class map. All match criteria in this class map must be matched.
- ◆ **match-any**—Performs a logical OR of all the matching statements under this class map. One or more match criteria in this class map must be matched.

DEFAULT CONFIGURATION

If neither **match-all** nor **match-any** is specified, the **match-all** parameter is selected by default.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The **class-map** Global Configuration mode command specifies the name of the class map for which class-map match criteria are to be created or modified and enters class-map configuration mode. In this mode, up to two match commands can be entered to configure the match criteria for this class. When using two match commands, each has to point to a different type of ACL (one IP and one MAC). The classification is by first match, therefore, the order is important. The **class-map** command and its subcommands are used to define packet classification, marking, and aggregate policing as part of a globally named service policy applied on a per-interface basis. If there is more than one match statement in a match-all class map and if there is a repetitive classification field in the participating ACLs, an error message is generated.

After entering the Quality of Service (QoS) Class-map Configuration mode, the following configuration commands are available:

exit: Exits the QoS Class-map Configuration mode.

match: Configures classification criteria.

no: Removes a match statement from a class map.

EXAMPLE

The following example creates a class map called Class1 and configures it to check that packets match all classification criteria in the class map match statement.

```
Console(config)# class-map class1 match-all
Console(config-cmap)#
```

show class-map The **show class-map** EXEC mode command displays all class maps.

SYNTAX

show class-map [*class-map-name*]

PARAMETERS

class-map-name—Specifies the name of the class map to be displayed.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the class map for Class1.

```
Console> show class-map class1

Class Map match-any class1 (id4)
Match Ip dscp 11 21
```

match Use the **match** Class-map Configuration mode command to define the match criteria for classifying traffic. Use the **no** form of this command to delete the match criteria.

SYNTAX

match access-group *acl-name*
no match access-group *acl-name*

PARAMETERS

acl-name—Specifies the MAC or IP Access Control List (ACL) name.

DEFAULT CONFIGURATION

No match criterion is supported.

COMMAND MODE

Class-map Configuration mode.

EXAMPLE

The following example defines the match criterion for classifying traffic as an access group called Enterprise in a class map called Class1.

```
Console(config)# class-map class1
Console(config-cmap)# match access-group enterprise
```

policy-map Use the **policy-map** Global Configuration mode command to creates a policy map and enter the Policy-map Configuration mode. Use the **no** form of this command to delete a policy map.

SYNTAX

policy-map *policy-map-name*
no policy-map *policy-map-name*

PARAMETERS

policy-map-name—Specifies the policy map name.

DEFAULT CONFIGURATION

The default behavior of the policy map is to set the DSCP value to 0 if the packet is an IP packet, and to set the CoS value to 0 if the packet is tagged.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use the **policy-map** Global Configuration mode command to specify the name of the policy map to be created, added to, or modified before configuring policies for classes whose match criteria are defined in a class map.

Entering the **policy-map** Global Configuration mode command also enables configuring or modifying the class policies for that policy map. Class policies in a policy map can be configured only if the classes have match criteria defined for them. Use the **class-map** Global Configuration mode and **match** Class-map Configuration mode commands to configure the match criteria for a class.

The match criteria is for a class. Only one policy map per interface per direction is supported. The same policy map can be applied to multiple interfaces and directions.

EXAMPLE

The following example creates a policy map called Policy1 and enters the Policy-map Configuration mode.

```
Console(config)# policy-map policy1
Console(config-pmap)#
```

class The **class** Policy-map Configuration mode command defines a traffic classification and enters the Policy-map Class Configuration mode. Use the **no** form of this command to detach a class map from the policy map.

SYNTAX

```
class class-map-name [access-group acl-name]
no class class-map-name
```

PARAMETERS

◆ **class-map-name**—Specifies the name of an existing class map. If the class map does not exist, a new class map is created under the specified name.

- ◆ **acl-name**—Specifies the name of an IP or MAC Access Control List (ACL).

DEFAULT CONFIGURATION

No class map is defined for the policy map.

COMMAND MODE

Policy-map Configuration mode

USER GUIDELINES

Use the **policy-map** Global Configuration mode command to identify the policy map and to enter the Policy-map Configuration mode before using the **class** command. After specifying a policy map, a policy for new classes can be configured or a policy for any existing classes in that policy map can be modified.

Use the **service-policy** Interface Configuration (Ethernet, Port-channel) mode command to attach a policy map to an interface. Use an existing class map to attach classification criteria to the specified policy map and use the **access-group** parameter to modify the classification criteria of the class map.

If this command is used to create a new class map, the name of an IP or MAC ACL must also be specified with the **access-group** parameter.

EXAMPLE

The following example defines a traffic classification called Class1 with an access-group called Enterprise. The class is in a policy map called policy1.

```
Console(config)# policy-map policy1
Console(config-pmap)# class class1 access-group enterprise
```

show policy-map Use the **show policy-map** EXEC mode command to display all policy maps or a specific policy map.

SYNTAX

show policy-map [*policy-map-name*]

PARAMETERS

policy-map-name—Specifies the policy map name.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays all policy maps.

```

Console> show policy-map
Policy Map policy1
class class1
set Ip dscp 7
Policy Map policy2
class class 2
police 96000 4800 exceed-action drop
class class3
police 124000 96000 exceed-action policed-dscp-transmit

```

trust Use the **trust** Policy-map Class Configuration mode command to configure the trust state, which selects the value that QoS uses as the source of the internal DSCP value. Use the **no** form of this command to return to the default trust state.

SYNTAX

trust *cos-dscp*

no trust

PARAMETERS

cos-dscp—Specifies that if the packet is IP, then QoS acts as for **dscp**; otherwise QoS acts as for **cos**.

DEFAULT CONFIGURATION

The default state is untrusted.

If the **trust** command is specified with no parameters, the default mode is **dscp**.

COMMAND MODE

Policy-map Class Configuration mode

USER GUIDELINES

Use this command to distinguish the Quality of Service (QoS) trust behavior for certain traffic from others. For example, incoming traffic with certain DSCP values can be trusted. A class map can be configured to match and trust the DSCP values in the incoming traffic.

Trust values set with this command supersede trust values set on specific interfaces with the **qos trust** Interface Configuration mode command.

The **trust** command and the **set** Policy-map Class Configuration mode command are mutually exclusive within the same policy map.

Policy maps that contain **set** or **trust** Policy-map Class Configuration mode commands cannot be attached, or that have Access Control List (ACL)

classification to an egress interface by using the **service-policy** Interface Configuration mode command.

If specifying **trust cos**, QoS maps a packet to a queue, the received or default port CoS value, and the CoS-to-queue map.

If specifying **trust dscp**, QoS maps the packet using the DSCP value from the ingress packet.

If specifying **tcp-udp-port**, QoS maps the packet to a queue using the TCP\UDP port value from the ingress packet and the tcp-udp-port-to-queue map.

EXAMPLE

The following example creates an ACL, places it into a class map, places the class map into a policy map and configures the trust state using the DSCP value in the ingress packet.

```
console(config)# mac access-list extended m1
console(config-mac-acl)# permit any any
console(config-mac-acl)# exit
console(config)# class-map c1
console(config-cmap)# match access-group m1
console(config-cmap)# exit
console(config)# policy-map p1
console(config-pmap)# class c1
console(config-pmap-c)# trust cos-dscp
```

set Use the **set** Policy-map Class Configuration mode command to set new values in the IP packet.

SYNTAX

set {*dscp new-dscp* | *queue queue-id* | *cos new-cos*}

no set

PARAMETERS

- ◆ **dscp new-dscp**—Specifies the new DSCP value for the classified traffic. (Range: 0–63)
- ◆ **queue queue-id**—Specifies the explicit queue id to set the egress queue.
- ◆ **cos new-cos**—Specifies the new User priority to be marked in the packet. (Range: 0–7)

COMMAND MODE

Policy-map Class Configuration mode

USER GUIDELINES

This command and the **trust** Policy-map Class Configuration mode command are mutually exclusive within the same policy map.

Policy maps that contain **set** or **trust** Policy-map Class Configuration mode commands or that have ACL classifications cannot be attached to an egress interface using the Service-policy Interface Configuration mode command.

To return to the Policy-map Configuration mode, use the **exit** command. To return to the Privileged EXEC mode, use the **end** command.

EXAMPLE

The following example creates an ACL, places it into a class map, places the class map into a policy map and sets the DSCP value in the packet to 56 for classes in policy map called p1.

```
console(config)# mac access-list extended m1
console(config-mac-acl)# permit any any
console(config-mac-acl)# exit
console(config)# class-map c1
console(config-cmap)# match access-group m1
console(config-cmap)# exit
console(config)# policy-map p1
console(config-pmap)# class c1
Console(config-pmap-c)# set dscp 56
```

police Use the **police** Policy-map Class Configuration mode command to define the policer for classified traffic. Use the **no** form of this command to remove a policer.

SYNTAX

police *committed-rate-kbps committed-burst-byte [exceed-action {drop | policed-dscp-transmit}]*

no police

PARAMETERS

- ◆ **committed-rate-kbps**—Specifies the average traffic rate (CIR) in kbits per second (bps). (Range: 3–12582912)
- ◆ **committed-burst-byte**—Specifies the normal burst size (CBS) in bytes. (Range: 3000–19173960)
- ◆ **exceed-action {drop | policed-dscp-transmit}**—Specifies the action taken when the rate is exceeded. The possible values are:
 - **drop**—Drops the packet.
 - **policed-dscp-transmit**—Remarks the packet DSCP, according to the policed-DSCP map as configured by the **qos map policed-dscp** Global Configuration mode command.

COMMAND MODE

Policy-map Class Configuration mode

USER GUIDELINES

Policing uses a token bucket algorithm. CIR represents the speed with which the token is removed from the bucket. CBS represents the depth of the bucket.

EXAMPLE

The following example defines a policer for classified traffic. When the traffic rate exceeds 124,000 kbps or the normal burst size exceeds 9600 bytes, the packet is dropped. The class is called Class1 and is in a policy map called Policy1.

```
Console(config)# policy-map policy1
Console(config-pmap)# class class1
Console(config-pmap-c)# police 124000 9600 exceed-action drop
```

service-policy Use the **service-policy** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to apply a policy map to the input of a particular interface. Use the **no** form of this command to detach a policy map from an interface.

SYNTAX

service-policy input *policy-map-name*

no service-policy input

PARAMETERS

policy-map-name—Specifies the policy map name to apply to the input interface. (Length: 1–32 characters)

COMMAND MODE

Interface Configuration (Ethernet, VLAN, Port-channel) mode

USER GUIDELINES

Only one policy map per interface per direction is supported.

EXAMPLE

The following example attaches a policy map called Policy1 to the input interface.

```
Console(config-if)# service-policy input policy1
```

qos aggregate-policer Use the **qos aggregate-policer** Global Configuration mode command to define the policer parameters that can be applied to multiple traffic classes. Use the **no** form of this command to remove an existing aggregate policer.

SYNTAX

```
qos aggregate-policer aggregate-policer-name committed-rate-kbps
excess-burst-byte [exceed-action {drop | policed-dscp-transmit}]
```

```
no qos aggregate-policer aggregate-policer-name
```

PARAMETERS

- ◆ **aggregate-policer-name**—Specifies the aggregate policer name.
- ◆ **committed-rate-kbps**—Specifies the average traffic rate (CIR) in kbits per second (kbps). (Range: 3–57982058)
- ◆ **excess-burst-byte**—Specifies the normal burst size (CBS) in bytes. (Range: 3000–19173960)
- ◆ **exceed-action {drop | policed-dscp-transmit}**—Specifies the action taken when the rate is exceeded. The possible values are:
 - **drop**—Drops the packet.
 - **policed-dscp-transmit**—Remarks the packet DSCP.

DEFAULT CONFIGURATION

No aggregate policer is defined.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Define an aggregate policer if the policer is shared with multiple classes.

Policers in one port cannot be shared with other policers in another device. Traffic from two different ports can be aggregated for policing purposes.

An aggregate policer can be applied to multiple classes in the same policy map. An aggregate policer cannot be applied across multiple policy maps.

An aggregate policer cannot be deleted if it is being used in a policy map. The **no police aggregate** Policy-map Class Configuration mode command must first be used to delete the aggregate policer from all policy maps before using the **no mls qos aggregate-policer** command.

Policing uses a token bucket algorithm. CIR represents the speed with which the token is removed from the bucket. CBS represents the depth of the bucket.

EXAMPLE

The following example defines the parameters of a policer called Policer1 that can be applied to multiple classes in the same policy map. When the

average traffic rate exceeds 124,000 kbps or the normal burst size exceeds 9600 bytes, the packet is dropped.

```
Console(config)# qos aggregate-policer policer1 124000 9600 exceed-action drop
```

show qos aggregate-policer Use the **show qos aggregate-policer** EXEC mode command to display the aggregate policer parameter.

SYNTAX

show qos aggregate-policer [*aggregate-policer-name*]

PARAMETERS

aggregate-policer-name—Specifies the aggregate policer name.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the parameters of the aggregate policer called Policer1.

```
Console> show qos aggregate-policer policer1
aggregate-policer policer1 96000 4800 exceed-action drop
not used by any policy map
```

police aggregate Use the **police aggregate** Policy-map Class Configuration mode command to apply an aggregate policer to multiple classes within the same policy map. Use the **no** form of this command to remove an existing aggregate policer from a policy map.

SYNTAX

police aggregate *aggregate-policer-name*
no police aggregate *aggregate-policer-name*

PARAMETERS

aggregate-policer-name—Specifies the aggregate policer name.

COMMAND MODE

Policy-map Class Configuration mode

USER GUIDELINES

An aggregate policer can be applied to multiple classes in the same policy map. An aggregate policer cannot be applied across multiple policy maps or interfaces.

Use the **exit** command to return to the Policy-map Configuration mode.
Use the **end** command to return to the Privileged EXEC mode.

EXAMPLE

The following example applies the aggregate policer called Policer1 to a class called Class1 in a policy map called Policy1.

```
Console(config)# policy-map policy1
Console(config-pmap)# class class1
Console(config-pmap-c)# police aggregate policer1
```

wrr-queue cos-map Use the **wrr-queue cos-map** Global Configuration mode command maps Class of Service (CoS) values to a specific egress queue. Use the **no** form of this command to restore the default configuration.

SYNTAX

wrr-queue cos-map *queue-id* *cos0 ... cos7*
no wrr-queue cos-map [*queue-id*]

PARAMETERS

- ◆ **queue-id**—Specifies the queue number to which the CoS values are mapped.
- ◆ **cos0 ... cos7**—Specifies up to 7 CoS values to map to the specified queue number. (Range: 1–7)

DEFAULT CONFIGURATION

The default CoS value mapping to 8 queues is as follows:

CoS value 0 is mapped to queue 3.
CoS value 1 is mapped to queue 1.
CoS value 2 is mapped to queue 2.
CoS value 3 is mapped to queue 4.
CoS value 4 is mapped to queue 5.
CoS value 5 is mapped to queue 6.
CoS value 6 is mapped to queue 7.
CoS value 7 is mapped to queue 8.

The default CoS value mapping to 3 queues is as follows:

CoS value 0 is mapped to queue 2.
CoS value 1 is mapped to queue 1.
CoS value 2 is mapped to queue 1.
CoS value 3 is mapped to queue 2.

CoS value 4 is mapped to queue 2.
 CoS value 5 is mapped to queue 3.
 CoS value 6 is mapped to queue 3.
 CoS value 7 is mapped to queue 3.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Use this command to distribute traffic to different queues, where each queue is configured with different weighted round robin (WRR) and Weighted Random Early Detection (WRED) parameters.

The expedite queues are enabled using the **priority-queue out** Interface Configuration mode commands

EXAMPLE

The following example maps CoS value 4 to queue 2.

```
Console(config)# wrr-queue cos-map 2 7
```

wrr-queue bandwidth

Use the **wrr-queue bandwidth** global Configuration command to assign Weighted Round Robin (WRR) weights to egress queues. The weight ratio determines the frequency at which the packet scheduler removes packets from each queue. Use the **no** form of this command to restore the default configuration.

SYNTAX

wrr-queue bandwidth *weight1 weight2 ... weight_n*
no wrr-queue bandwidth

PARAMETERS

weight1 weight2 ... weight_n—Specifies the ratio of the bandwidth assigned by the WRR packet scheduler to the packet queues. Separate values by a space. (Range: 0–255)

DEFAULT CONFIGURATION

wrr is disabled by default. The default wrr weight is '1' for all queues.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The ratio for each queue is defined as the queue weight divided by the sum of all queue weights (the normalized weight). This sets the bandwidth allocation of each queue.

A weight of 0 indicates that no bandwidth is allocated for the same queue, and the shared bandwidth is divided among the remaining queues. It is not recommended to set the weight of a queue to a 0 as it might stop transmission of control-protocols packets generated by the device.

All eight queues participate in the WRR, excluding the expedite queues, in which case the corresponding weight is ignored (not used in the ratio calculation). The expedite queue is a priority queue; it is serviced until empty before the other queues are serviced. The expedite queues are enabled by using the **priority-queue out** Interface Configuration mode command.

EXAMPLE

The following 7 WRR queues.

```
Console(config)# wrr-queue bandwidth 6 6 6 6 6 6 6
```

priority-queue out num-of-queues Use the **priority-queue out num-of-queues** Global Configuration mode command to configure the number of expedite queues. Use the **no** form of this command to restore the default configuration.

SYNTAX

priority-queue out num-of-queues *number-of-queues*
no priority-queue out num-of-queues

PARAMETERS

number-of-queues—Specifies the number of expedite queues. Expedite queues have higher indexes. (Range: 0–8). If number-of-queues = 0, all queues are assured forwarding. If number-of-queues = 8, all queues are expedited.

DEFAULT CONFIGURATION

All queues are expedite queues.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

While configuring the **priority-queue num-of-queues** command, the weighted round robin (WRR) weight ratios are affected because there are fewer queues participating in WRR. This indicates that the corresponding weight in the **wrr-queue bandwidth** Interface Configuration mode command is ignored (not used in the ratio calculation).

EXAMPLE

The following example configures the number of expedite queues as 2.

```
Console(config)# priority-queue out num-of-queues 2
```

traffic-shape Use the **traffic-shape** Interface Configuration (Ethernet, Port-channel) mode command to configure the egress port shaper. Use the **no** form of this command to disable the shaper.

SYNTAX

traffic-shape *committed-rate* [*committed-burst*]

no traffic-shape

PARAMETERS

- ◆ **committed-rate**—Specifies the average traffic rate (CIR) in kbits per second (kbps). (Range: FE, GE: 64kbps–maximum port speed; 10GE: 64Kbps–maximum port speed)
- ◆ **committed-burst**—Specifies the excess burst size (CBS) in bytes. (Range: 4KB –16MB)

DEFAULT CONFIGURATION

The shaper is disabled.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

EXAMPLE

The following example sets a shaper on tengigabitethernet port 0/5 on queue 1 when the average traffic rate exceeds 124000 kbps or the normal burst size exceeds 9600 bytes.

```
Console(config)# interface te5
Console(config-if)# traffic-shape 1 124000 9600
```

traffic-shape queue Use the **traffic-shape queue** Interface Configuration (Ethernet, Port-channel) mode command to configure the egress queue shaper. Use the **no** form of this command to disable the shaper.

SYNTAX

traffic-shape queue *queue-id* *committed-rate* [*committed-burst*]

no traffic-shape queue *queue-id*

PARAMETERS

- ◆ **queue-id**—Specifies the queue number to which the shaper is assigned.
- ◆ **committed-rate**—Specifies the average traffic rate (CIR) in kbits per second (kbps). (Range: 64 kbps–maximum port speed)
- ◆ **committed-burst**—Specifies the excess burst size (CBS) in bytes. (Range: 4 KB - 16 MB)

DEFAULT CONFIGURATION

The shaper is disabled.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

EXAMPLE

The following example sets a shaper on tengigabitethernet port 0/5 when the average traffic rate exceeds 124000 kbps or the normal burst size exceeds 9600 bytes.

```
Console(config)# interface te5
Console(config-if)# traffic-shape 124000 9600
```

rate-limit (Ethernet) Use the **rate-limit** Interface Configuration (Ethernet) mode command to limit the incoming traffic rate on a port. Use the **no** form of this command to disable the rate limit.

SYNTAX

rate-limit *committed-rate-kbps [burst committed-burst-byte]*
no rate-limit

PARAMETERS

- ◆ **rate**—Specifies the maximum number of kilobits per second of ingress traffic on a port. The range is 3–10000000.
- ◆ **burst bytes**—The burst size in bytes (3000–19173960). If unspecified, defaults to 128K.

DEFAULT CONFIGURATION

Rate limiting is disabled.

COMMAND MODE

Interface Configuration (Ethernet) mode

USER GUIDELINES

- ◆ Storm control and rate-limit (of unicast packets) can't be enabled simultaneously on the same port.

EXAMPLE

The following example limits the incoming traffic rate on tengigabitethernet port 0/5 to 150,000 kbps.

```
Console(config)# interface te5  
Console(config-if)# rate-limit 150000
```

rate-limit (VLAN) Use the **rate-limit** (VLAN) Global Configuration mode command to limit the incoming traffic rate for a VLAN. Use the **no** form of this command to disable the rate limit.

SYNTAX

rate-limit *vlan-id committed-rate committed-burst*
no rate-limit vlan

PARAMETERS

- ◆ **vlan-id**—Specifies the VLAN ID.
- ◆ **committed-rate**—Specifies the average traffic rate (CIR) in kbits per second (kbps). (Range: 3–8000000)
- ◆ **committed-burst**—Specifies the maximum burst size (CBS) in bytes. (Range: 3000–19173960)

DEFAULT CONFIGURATION

Rate limiting is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

Traffic policing in a policy map takes precedence over VLAN rate limiting. If a packet is subject to traffic policing in a policy map and is associated with a VLAN that is rate limited, the packet is counted only in the traffic policing of the policy map.

EXAMPLE

The following example limits the rate on VLAN 11 to 150000 kbps or the normal burst size to 9600 bytes.

```
Console(config)# rate-limit 11 150000 9600
```

qos wrr-queue wrtd Use the **qos wrr-queue wrtd** Global Configuration mode command to enable Weighted Random Tail Drop (WRTD). Use the **no** form of this command to disable WRTD.

SYNTAX

qos wrr-queue wrtd
no qos wrr-queue wrtd

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

USER GUIDELINES

The command is effective after reset.

show qos interface Use the **show qos interface** EXEC mode command to display Quality of Service (QoS) information on the interface.

SYNTAX

show qos interface [*buffers* | *queueing* | *policers* | *shapers* | *rate-limit*] [*interface-id*]

PARAMETERS

- ◆ **buffers**—Displays the buffer settings for the interface's queues. For GE ports, displays the queue depth for each of the 8 queues. For FE ports, displays the minimum reserved setting.
- ◆ **queueing**—Displays the queue's strategy (WRR or EF), the weight for WRR queues, the CoS to queue map and the EF priority.
- ◆ **policers**—Displays all the policers configured for this interface, their settings, and the number of policers currently unused.
- ◆ **shapers**—Displays the shaper of the specified interface and the shaper for the queue on the specified interface.
- ◆ **rate-limit**—Displays the rate-limit configuration.
- ◆ **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, or Port-channel.

DEFAULT CONFIGURATION

There is no default configuration for this command.

COMMAND MODE

EXEC mode

USER GUIDELINES

The **policers** option is relevant for a VLAN interface only.

If no parameter is specified with the **show qos interface** command, the port QoS mode (DSCP trusted, CoS trusted, untrusted, and so on), default CoS value, DSCP-to-DSCP- map (if any) attached to the port, and policy map (if any) attached to the interface are displayed. If a specific interface is not specified, the information for all interfaces is displayed.

EXAMPLE

This is an example of the output from the **show qos interface buffers** command for 8 queues.

```

Console> show qos interface buffers tel
tel
Notify Q depth:
buffers gi2/0/1
Ethernet gi2/0/1

qid  thresh0  thresh1  thresh2
1    100      100      80
2    100      100      80
3    100      100      80
4    100      100      80
5    100      100      80
6    100      100      80
7    100      100      80
8    100      100      80

```

This is an example of the output from the **show qos interface shapers** command for 8 queues.

```

Console> show qos interface shapers tel
tengigabitethernet 0/1
Port shaper: enable
Committed rate: 192000 bps
Committed burst: 9600 bytes

```

QID	Status	Target Committed Rate [bps]	Target Committed Burst [bytes]
1	Enable	100000	17000
2	Disable	N/A	N/A
3	Enable	200000	19000
4	Disable	N/A	N/A
5	Disable	N/A	N/A
6	Disable	N/A	N/A
7	Enable	178000	8000
8	Enable	23000	1000

This is an example of the output from the **show qos interface policer** command.

```

Console> show qos interface policer tel
Ethernet tel
Class map: A
Policer type: aggregate
Committed rate: 192000 bps
Committed burst: 9600 bytes
Exceed-action: policed-dscp-transmit

Class map: B
Policer type: single
Committed rate: 192000 bps
Committed burst: 9600 bytes
Exceed-action: drop

Class map: C
Policer type: none
Committed rate: N/A
Committed burst: N/A
Exceed-action: N/A

```

This is an example of the output from the **show qos interface rate-limit** command.

```

Console> show qos interface rate-limit tel

```

Port	rate-limit [kbps]	Burst [KBytes]
-----	-----	-----
tel	1000	512K

wrr-queue Use the **wrr-queue** Global Configuration mode command to enable the tail-drop mechanism on an egress queue. Use the **no** form of this command to disable the tail-drop mechanism on an egress queue.

SYNTAX

```

wrr-queue tail-drop
no wrr-queue

```

PARAMETERS

tail-drop— Specifies the tail-drop mechanism.

DEFAULT CONFIGURATION

The tail-drop mechanism on an egress queue is disabled.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command can only be used if Advanced mode is enabled.

EXAMPLE

The following example enables the tail-drop mechanism on an egress queue.

```
Console(config)# wrr-queue tail-drop
```

qos wrr-queue threshold

Use the **qos wrr-queue threshold** Global Configuration mode command to assign queue thresholds globally. Use the **no** form of this command to restore the default configuration.

SYNTAX

qos wrr-queue threshold *tengigabitethernet* *queue-id* *threshold-percentage*

no qos wrr-queue threshold *tengigabitethernet* *queue-id*

PARAMETERS

- ◆ **queue-id**—Specifies the queue number to which the tail-drop threshold is assigned.
- ◆ **threshold-percentage**—Specifies the queue threshold percentage value.

DEFAULT CONFIGURATION

The default threshold is 80 percent.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

If the threshold is exceeded, packets with the corresponding DP are dropped until the threshold is no longer exceeded.

EXAMPLE

The following example assigns a threshold of 80 percent to WRR queue 1.

```
Console(config)# qos wrr-queue threshold tengigabitethernet 1 80
```

qos map policed-dscp Use the **qos map policed-dscp** Global Configuration mode command to configure the policed-DSCP map for remarking purposes. Use the **no** form of this command to restore the default configuration.

SYNTAX

```
qos map policed-dscp dscp-list to dscp-mark-down
no qos map policed-dscp [dscp-list]
```

PARAMETERS

- ◆ **dscp- list**—Specifies up to 8 DSCP values, separated by spaces. (Range: 0–63)
- ◆ **dscp-mark-down**—Specifies the DSCP value to mark down. (Range: 0–63)

DEFAULT CONFIGURATION

The default map is the Null map, which means that each incoming DSCP value is mapped to the same DSCP value.

COMMAND MODE

Global Configuration mode.

EXAMPLE

The following example marks incoming DSCP value 3 as DSCP value 43 on the policed-DSCP map.

```
Console(config)# qos map policed-dscp 3 to 43
Reserved DSCP. DSCP 3 was not configured.
```

qos map dscp-queue Use the **qos map dscp-queue** Global Configuration mode command to configure the DSCP to CoS map. Use the **no** form of this command to restore the default configuration.

SYNTAX

```
qos map dscp-queue dscp-list to queue-id
no qos map dscp-queue [dscp-list]
```

PARAMETERS

- ◆ **dscp-list**—Specifies up to 8 DSCP values, separated by spaces. (Range: 0– 63)
- ◆ **queue-id**—Specifies the queue number to which the DSCP values are mapped.

DEFAULT CONFIGURATION

The default map for 8 queues is as follows.

DSCP value	0-7	8-15	16-23	24-31	32-39	40-47	48-56	57-63
Queue-ID	1	2	3	4	5	6	7	8

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example maps DSCP values 33, 40 and 41 to queue 1.

```
Console(config)# qos map dscp-queue 33 40 41 to 1
```

qos map dscp-dp Use the **qos map dscp-dp** Global Configuration mode command to map the DSCP to Drop Precedence. Use the **no** form of this command to restore the default configuration.

SYNTAX

qos map dscp-dp *dscp-list* to *dp*

no qos map dscp-dp [*dscp-list*]

PARAMETERS

- ◆ **dscp-list**—Specifies up to 8 DSCP values, with values separated by a space. (Range: 0–63)
- ◆ **dp**—Specifies the Drop Precedence value to which the DSCP values are mapped. (values: 0,2) where 2 is the highest Drop Precedence)

DEFAULT CONFIGURATION

All the DSCPs are mapped to Drop Precedence 0.

COMMAND MODE

Global Configuration mode.

EXAMPLE

The following example maps DSCP values 25, 27 and 29 to Drop Precedence 2.

```
Console(config)# qos map dscp-dp 25 27 29 to 2
```


qos trust (Global) Use the **qos trust** Global Configuration mode command to configure the system to the basic mode and trust state. Use the **no** form of this command to return to the default configuration.

SYNTAX

qos trust {*cos* | *dscp*}

no qos trust

PARAMETERS

- ◆ **cos**— Specifies that ingress packets are classified with packet CoS values. Untagged packets are classified with the default port CoS value.
- ◆ **dscp**— Specifies that ingress packets are classified with packet DSCP values.

DEFAULT CONFIGURATION

CoS is the default trust mode.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

This command can be used only in QoS basic mode.

Packets entering a quality of service (QoS) domain are classified at the edge of the QoS domain. When the packets are classified at the edge, the switch port within the QoS domain can be configured to one of the trusted states because there is no need to classify the packets at every switch within the domain.

Use this command to specify whether the port is trusted and which fields of the packet to use to classify traffic.

When the system is configured with trust DSCP, the traffic is mapped to the queue by the DSCP-queue map.

When the system is configured with trust CoS, the traffic is mapped to the queue by the CoS-queue map.

EXAMPLE

The following example configures the system to the DSCP trust state.

```
Console(config)# qos trust dscp
```

qos trust (Interface) Use the **qos trust** Interface Configuration (Ethernet, Port-channel) mode command to enable each port trust state while the system is in the basic QoS mode. Use the **no** form of this command to disable the trust state on each port.

SYNTAX

qos trust
no qos trust

DEFAULT CONFIGURATION

Each port is enabled while the system is in basic mode.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

EXAMPLE

The following example configures tengigabitethernet port 0/15 to the default trust state.

```
Console(config)# interface te15  
Console(config-if)# qos trust
```

qos cos Use the **qos cos** Interface Configuration (Ethernet, Port-channel) mode command to define the default CoS value of a port. Use the **no** form of this command to restore the default configuration.

SYNTAX

qos cos *default-cos*
no qos cos

PARAMETERS

default-cos—Specifies the default CoS value of the port. If the port is trusted and the packet is untagged, then the default CoS value become the CoS value. (Range: 0–7)

DEFAULT CONFIGURATION

The default CoS value of a port is 0.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

USER GUIDELINES

Use the default CoS value to assign a CoS value to all untagged packets entering the port. Use the **qos cos override** command to assign this default CoS value to tagged packets.

EXAMPLE

The following example defines the port `te15` default CoS value as 3 .

```
Console(config)# interface te15
Console(config-if)# qos cos 3
```

qos dscp-mutation Use the **qos dscp-mutation** Global Configuration mode command to apply the DSCP Mutation map to system DSCP trusted ports. Use the **no** form of this command to restore the trusted port with no DSCP mutation.

SYNTAX

qos dscp-mutation

no qos dscp-mutation

COMMAND MODE

Global Configuration mode.

USER GUIDELINES

Apply the DSCP-to-DSCP-mutation map to a port at the boundary of a Quality of Service (QoS) administrative domain. If two QoS domains have different DSCP definitions, use the DSCP-to-DSCP-mutation map to translate a set of DSCP values to match the definition of another domain. Apply the map to ingress and to DSCP-trusted ports only. Applying this map to a port causes IP packets to be rewritten with newly mapped DSCP values at the ingress ports. If applying the DSCP mutation map to an untrusted port, to class of service (CoS), or to an IP-precedence trusted port, the command has no immediate effect until the port becomes DSCP-trusted.

EXAMPLE

The following example applies the DSCP Mutation map to system DSCP trusted ports.

```
Console(config)# qos dscp-mutation
```

qos map dscp-mutation Use the **qos map dscp-mutation** Global Configuration mode command to configure the DSCP to DSCP Mutation table. Use the **no** form of this command to restore the default configuration.

SYNTAX

qos map dscp-mutation *in-dscp* to *out-dscp*

no qos map dscp-mutation [*in-dscp*]

PARAMETERS

- ◆ **in-dscp**—Specifies up to 8 DSCP values to map, separated by spaces. (Range: 0–63)
- ◆ **out-dscp**—Specifies up to 8 DSCP mapped values, separated by spaces. (Range: 0–63)

DEFAULT CONFIGURATION

The default map is the Null map, which means that each incoming DSCP value is mapped to the same DSCP value.

COMMAND MODE

Global Configuration mode.

USER GUIDELINES

This is the only map that is not globally configured. It is possible to have several maps and assign each one to a different port.

EXAMPLE

The following example changes DSCP values 1, 2, 4, 5 and 6 to DSCP Mutation Map value 63.

```
Console(config)# qos map dscp-mutation 1 2 4 5 6 to 63
```

show qos map Use the **show qos map** EXEC mode command to display the QoS mapping information.

SYNTAX

show qos map [dscp-queue | dscp-dp | policed-dscp | dscp-mutation]

PARAMETERS

- ◆ **dscp-queue**—Displays the DSCP to queue map.
- ◆ **dscp-dp**—Displays the DSCP to Drop Precedence map.
- ◆ **policed-dscp**—Displays the DSCP to DSCP remark table.
- ◆ **dscp-mutation**—Displays the DSCP-DSCP mutation table.

COMMAND MODE

EXEC mode

EXAMPLE

The following example displays the QoS mapping information.

```
Console> show qos map
```

Dscp-queue map:

d1	:	d2	0	1	2	3	4	5	6	7	8	9
--	--	--	--	--	--	--	--	--	--	--	--	--
0	:		01	01	01	01	01	01	01	01	02	02
1	:		02	02	02	02	02	02	03	03	03	03
2	:		03	03	03	03	04	04	04	04	04	04
3	:		04	04	05	05	05	05	05	05	05	05
4	:		06	06	06	06	06	06	06	06	07	07
5	:		07	07	07	07	07	07	08	08	08	08
6	:		08	08	08	08						

The following table appears:

Dscp-DP map:

d1	:	d2	0	1	2	3	4	5	6	7	8	9
--	--	--	--	--	--	--	--	--	--	--	--	--
0	:	00	00	00	00	00	00	00	00	00	00	00
1	:	00	00	00	00	00	00	00	00	00	00	00
2	:	00	00	00	00	00	00	00	00	00	00	00
3	:	00	00	00	00	00	00	00	00	00	00	00
4	:	00	00	00	00	00	00	00	00	00	00	00
5	:	00	00	00	00	00	00	00	00	00	00	00
6	:	00	00	00	00							

The following table appears:

Policed-dscp map:

d1	:	d2	0	1	2	3	4	5	6	7	8	9
--	--	--	--	--	--	--	--	--	--	--	--	--
0	:		00	01	02	03	04	05	06	07	08	09
1	:		10	11	12	13	14	15	16	17	18	19
2	:		20	21	22	23	24	25	26	27	28	29
3	:		30	31	32	33	34	35	36	37	38	39
4	:		40	41	42	43	44	45	46	47	48	49
5	:		50	51	52	53	54	55	56	57	58	59
6	:		60	61	62	63						

The following table appears:

Dscp-dscp mutation map:												
d1	:	d2	0	1	2	3	4	5	6	7	8	9
--	--	--	--	--	--	--	--	--	--	--	--	--
0	:		00	01	02	03	04	05	06	07	08	09
1	:		10	11	12	13	14	15	16	17	18	19
2	:		20	21	22	23	24	25	26	27	28	29
3	:		30	31	32	33	34	35	36	37	38	39
4	:		40	41	42	43	44	45	46	47	48	49
5	:		50	51	52	53	54	55	56	57	58	59
6	:		60	61	62	63						

clear qos statistics Use the **clear qos statistics** EXEC mode command to clear the QoS statistics counters.

SYNTAX

clear qos statistics

COMMAND MODE

EXEC mode

EXAMPLE

The following example clears the QoS statistics counters.

```
Console# clear qos statistics
```

qos statistics policer Use the **qos statistics policer** Interface Configuration (Ethernet, Port-channel) mode command to enable counting in-profile and out-of-profile. Use the **no** form of this command to disable counting.

SYNTAX

qos statistics policer *policy-map-name class-map-name*

no qos statistics policer *policy-map-name class-map-name*

PARAMETERS

◆ **policy-map-name**—Specifies the policy map name.

◆ **class-map-name**—Specifies the class map name.

DEFAULT CONFIGURATION

Counting in-profile and out-of-profile is disabled.

COMMAND MODE

Interface Configuration (Ethernet, Port-channel) mode

EXAMPLE

The following example enables counting in-profile and out-of-profile on the interface.

```
Console(config-if)# qos statistics policer policy1 class1
```

**qos statistics
aggregate-policer**

Use the **qos statistics aggregate-policer** Global Configuration mode command to enable counting in-profile and out-of-profile. Use the **no** form of this command to disable counting.

SYNTAX

qos statistics aggregate-policer *aggregate-policer-name*
no qos statistics aggregate-policer *aggregate-policer-name*

PARAMETERS

aggregate-policer-name—Specifies the aggregate policer name.

DEFAULT CONFIGURATION

Counting in-profile and out-of-profile is disabled.

COMMAND MODE

Global Configuration mode

EXAMPLE

The following example enables counting in-profile and out-of-profile on the interface.

```
Console(config)# qos statistics aggregate-policer policer1
```

**qos statistics
queues**

Use the **qos statistics queues** Global Configuration mode command to enable QoS statistics for output queues. Use the **no** form of this command to disable QoS statistics for output queues.

SYNTAX

qos statistics queues set {*queue* | **all**} {*dp* | **all**} {*interface* | **all**}
no qos statistics queues set

PARAMETERS

◆ **set**—Specifies the counter set number.

- ◆ **interface**—Specifies the Ethernet port.
- ◆ **queue**—Specifies the output queue number.
- ◆ **dp**—Specifies the drop precedence. The available values are: **high**, **low**.

DEFAULT CONFIGURATION

Set 1: All interfaces, all queues, high DP.

Set 2: All interfaces, all queues, low DP.

COMMAND MODE

Global Configuration mode

USER GUIDELINES

There are no user guidelines for this command.

EXAMPLE

The following example enables QoS statistics for output queues for counter set 1.

```
Console(config)# qos statistics queues 1 all all all
```

show qos statistics Use the **show qos statistics** EXEC mode command to display Quality of Service statistical information.

SYNTAX

show qos statistics

COMMAND MODE

EXEC mode

USER GUIDELINES

Up to 16 sets of counters can be enabled for policers. The counters can be enabled in the creation of the policers.

Use the **qos statistics queues** Global Configuration mode command to enable QoS statistics for output queues.

EXAMPLE

The following example displays Quality of Service statistical information.

```
Console# show qos statistics
```

```
Policers
```

```
-----
```

Interface	Policy map	Class Map	In-profile bytes	Out-of-profile bytes
-----	-----	-----	-----	-----
te1	Policy1	Class1	7564575	5433
te1	Policy1	Class2	8759	52
te2	Policy1	Class1	746587458	3214
te2	Policy1	Class2	5326	23

```
Aggregate Policers
```

```
-----
```

Name	In-profile bytes	Out-of-profile bytes
-----	-----	-----
Policer1	7985687	121322

```
Output Queues
```

```
-----
```

Interface	Queue	DP	Total packets	%TD packets
-----	-----	--	-----	-----
te1	2	High	799921	1.2%
te2	All	High	5387326	0.2%

dce priority-flow-control enable
(Global)

Use the **dce priority-flow-control enable** global configuration command to globally enable the Priority Flow Control feature. Use the **no** form of this command to disable Priority Flow Control.

SYNTAX

dce priority-flow-control enable
no dce priority-flow-control enable

DEFAULT CONFIGURATION

Disabled.

COMMAND MODE

Global Configuration mode.

USER GUIDELINES

When priority-flow-control (PFC) is disabled on the switch, all interfaces use IEEE 802.3x flow control.

EXAMPLE

```
console(config)# dce priority-flow-control enable
```

dce priority-flow-control priority enable

Use the **dce priority-flow-control priority enable** global configuration command to enable priority flow control for a priority. Use the **no** form of this command to disable priority flow control.

SYNTAX

dce priority-flow-control priority *priority* enable
no dce priority-flow-control priority *priority* enable

PARAMETERS

priority—802.1Q Priority, range 0–7

COMMAND MODE

Global configuration mode

DEFAULT CONFIGURATION

Disabled

USER GUIDELINES

Priority-Flow-Control can be enabled for a priority, only if that priority is mapped (by the priority2queue mapping table) to a dedicated queue (I.e. no other priority is mapped to that queue). If Priority-Flow-Control Priority is enabled for a priority, then that priority cannot be mapped to a queue that is already shared by other priorities.

EXAMPLE

```
console(config)# dce priority-flow-control priority 7 enable
```

dce priority-flow-control enable (interface)

Use the **dce priority-flow-control enable** interface configuration command to enable the Priority Flow Control feature for an interface. Use the **no** form of this command to disable Priority Flow Control.

SYNTAX

dce priority-flow-control enable
no dce priority-flow-control enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Disabled Command Mode

Interface configuration (Etherment) mode

USER GUIDELINES

Use the **dce priority-flow-control enable** global configuration command to globally enable PFC.

Use the **dce priority-flow-control priority enable** global configuration command to determine on which priorities to enable PFC.

EXAMPLE

```
console(config-if)# dce priority-flow-control enable
```

show dce priority-flow-control

To display the information on Priority Flow Control, use the **show dce priority-flow-control** command in EXEC mode.

SYNTAX

show dce priority-flow-control [*interface-id*]

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC

EXAMPLE

```
console# show dce priority-flow-control
```

PFC is globally enabled

Priority	PFC Admin	PFC Oper
0	Disabled	Disabled
1	Disabled	Disabled
2	Disabled	Disabled
3	Disabled	Disabled
4	Disabled	Disabled
5	Disabled	Disabled
6	Disabled	Disabled
7	Enabled	Enabled

Interface	PFC Admin	PFC Oper
te0/1	Enabled	Disabled
te0/2	Disabled	Disabled
te0/3	Disabled	Disabled
te0/4	Disabled	Disabled
te0/5	Disabled	Disabled
.		
.		
.		
te0/47	Disabled	Disabled
te0/48	Disabled	Disabled

dce qcn enable (global) Use the **dce qcn enable** global configuration command to enable Quantized Congestion Notification (QCN) feature. Use the **no** form of this command to disable QCN.

SYNTAX

dce qcn enable

no dce qcn enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Disabled

COMMAND MODE

Global configuration

USER GUIDELINES

Enable the QCN feature to throttle traffic at the edge of the network when there is congestion.

EXAMPLE

```
console(config)# dce qcn enable
```

**dce qcn priority
enable**

Use the **dce qcn priority** enable global configuration command to enable Quantized Congestion Notification (QCN) for a priority. Use the **no** form of this command to disable QCN for a priority.

SYNTAX

dce qcn priority *priority* **enable**

no dce qcn priority *priority* **enable**

PARAMETERS

priority—802.1Q Priority, range 0–7

DEFAULT CONFIGURATION

Disabled

COMMAND MODE

Global configuration

USER GUIDELINES

QCN can be enabled up to 7 priorities.

QCN can't be enabled for a priority that is mapped to Queue 0.

QCN Operating state is enabled for a priority only if that priority is mapped (by the priority2queue mapping function) to a queue that is not associated with non-QCN priorities. i.e. non-QCN priorities are not mapped to that queue.



NOTE: Multiple QCN priorities can be mapped to the same queue.

EXAMPLE

```
console(config)# dce qcn priority 7 enable
```

dce qcn cnm priority Use the **dce qcn cnm priority** global configuration command to configure the priority to use for all Congestion Notification Messages (CNMs) transmitted by the device. Use the no form of this command to return to default.

SYNTAX

dce qcn cnm priority *priority*
no dce qcn cnm priority

PARAMETERS

priority—802.1Q Priority, range 0–7

DEFAULT CONFIGURATION

6

COMMAND MODE

Global configuration

EXAMPLE

```
console(config)# dce qcn cnm priority 7
```

dce qcn cp enable Use the **dce qcn cp enable** interface configuration command to enable Congestion Point (CP) creation for an interface. Use the no form of this command to disable CP creation for an interface.

SYNTAX

dce qcn cp enable
no dce qcn cp enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Enabled Command mode

COMMAND MODE

Interface configuration (Ethernet)

USER GUIDELINES

If CP creation is enabled for an interface, the system automatically creates a Congestion Point (CP) for a queue of that interface if at least QCN priority (Oper state) is mapped to that queue.

EXAMPLE

```
console(config-if)# dce qcn cp enable
```

dce qcn cp set-point Use the **dce qcn cp set-point** global configuration command to configure the QCN set-point of an egress queue. Use the **no** form of this command to return to default.

SYNTAX

dce qcn cp set-point *bytes*

no dce qcn cp set-point

PARAMETERS

bytes—Specifies the set point in bytes. The value should be a multiple of 512

Range 512–4294966784

DEFAULT CONFIGURATION

Product-specific, should be 20% of the queue size

COMMAND MODE

Global configuration

EXAMPLE

```
console(config)# dce qcn cp set-point 1024
```

dce qcn cp feedback-weight Use the **dce qcn cp feedback-weight** global configuration command configures the Feedback Weight of a QCN egress queue. Use the **no** form of this command to return to default.

SYNTAX

dce qcn cp feedback-weight [-]*number*

no dce qcn cp feedback-weight

PARAMETERS

[-]*number*—Specifies the Feedback Weight. The weight cpW is equal to two to the power of this object. Thus, if this number contains a -1, cpW = 1/2.

Range -8–7

DEFAULT CONFIGURATION

The number is 1->cpW=2

COMMAND MODE

Global configuration

EXAMPLE

```
console(config)# dce qcn cp feedback-weight -7
```

dce qcn cp min-sample-base

Use the **dce qcn cp min-sample-base** global configuration command to configure the minimum number of bytes to enqueue in a QCN egress queue between transmissions of Congestion Notification Messages. Use the **no** form of this command to return to default.

SYNTAX

dce qcn cp min-sample-base *bytes*

no dce qcn cp min-sample-base

PARAMETERS

bytes—Specifies the minimal sample base in bytes. the value should be a multiple of 16.

Range 10000–4294967280

DEFAULT CONFIGURATION

150000

COMMAND MODE

Global configuration

EXAMPLE

```
console(config)# dce qcn cp min-sample-base 20000
```

show dce qcn

To display the information on the Quantized Congestion Notification (QCN) feature, use the **show dce qcn** command in EXEC mode.

SYNTAX

show dce qcn [*interface-id*]

PARAMETERS

[*interface-id*]*—*Specifies an interface ID. The interface ID must be an Ethernet port.

DEFAULT CONFIGURATION

EXEC

COMMAND MODE

Interface configuration (Ethernet)

USER GUIDELINES

LLDP should be enabled for rx and tx in order that DCBX would be active.

EXAMPLE

```
console# show dce qcn
```

```
QCN is Enabled
CNM priority: 7
```

Priority	QCN Admin	Queue	QCN Oper
0	Disabled	3	Disabled
1	Disabled	1	Disabled
2	Disabled	2	Disabled
3	Disabled	4	Disabled
4	Disabled	5	Disabled
5	Disabled	6	Disabled
6	Disabled	7	Disabled
7	Enabled	8	Enabled

Congestion Points

```
cpW = 1/128
min-sample-base = 20000
```

Set-Point for an egress queues: 1024

Interface	CP status
te0/1	Enabled
te0/2	Disabled
te0/3	Disabled
te0/4	Disabled
te0/5	Disabled
.	
.	
.	
te0/47	Disabled
te0/48	Disabled

dce dcbx enable To enable the DCB Capability Exchange Protocol (DCBX) on an interface, use the **dce dcbx enable** command in interface configuration mode. To disable DCBX on an interface, use the **no** form of this command.

SYNTAX

dce dcbx enable
no dce dcbx enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Enabled

COMMAND MODE

Interface configuration (Ethernet)

USER GUIDELINES

LLDP should be enabled for rx and tx in order that DCBX would be active.

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1  
console(config-if)# dce dcbx enable
```

dce dcbx advertise priority-groups To advertise the DCBX priority-groups TLV on an interface, use the **dce dcbx advertise priority-groups** command in interface configuration mode. To disable the advertisement on the interface, use the **no** form of this command.

SYNTAX

dce dcbx advertise priority-groups
no dce dcbx advertise priority-groups

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Enabled

COMMAND MODE

Interface configuration (Ethernet)

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# dce dcbx advertise priority-groups
```

**dce dcbx advertise
priority-flow-control**

To advertise the DCBX priority-flow-control TLV on an interface, use the **dce dcbx advertise priority-flow-control** command in interface configuration mode. To disable the advertisement on the interface, use the **no** form of this command.

SYNTAX

dce dcbx advertise priority-flow-control
no dce dcbx advertise priority-flow-control

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Enabled

COMMAND MODE

Interface configuration (Ethernet)

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# dce dcbx advertise priority-flow-control
```

**dce dcbx advertise
application-protocol**

To advertise the DCBX application and protocol mapping TLV on an interface, use the **dce dcbx advertise application-protocol** command in interface configuration mode. To disable the advertisement on the interface, use the **no** form of this command.

SYNTAX

dce dcbx advertise application-protocol
no dce dcbx advertise application-protocol

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Enabled

COMMAND MODE

Interface configuration (Ethernet)

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# dce dcbx advertise application-protocol
```

dce application-protocol enable

Use the **dce application-protocol enable global configuration** to enable application to priority mapping. Use the **no** form of this command to disable the mapping.

SYNTAX

dce application-protocol enable

no dce application-protocol enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Disabled

COMMAND MODE

Interface configuration (Ethernet)

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# dce application-protocol enable
```

dce application-protocol map

Use the **dce application-protocol map** global configuration command to map applications to priorities. Use the **no** form of this command to delete mapping.

SYNTAX

dce application-protocol map {etype *number* | port *number*} to *priority1* [*priority2* ... *priority8*]

no dce application-protocol map {etype *number* | port *number*}

PARAMETERS

etype *number*—Ethernet type

port *number*}—TCP/UDP Port number

priority—802.1Q Priority

Range ***priority*** 0–7

DEFAULT CONFIGURATION

No mapping is defined.

COMMAND MODE

Global configuration

EXAMPLE

```
console(config)# dce application-protocol map port 21 to priority 6
```

show dce dcbx To display the DCB Capability Exchange (DCBX) information for specific interface, use the **show dce dcbx** command in privileged EXEC mode.

SYNTAX

show dce dcbx ethernet *interface-id*

PARAMETERS

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

COMMAND MODE

Privileged EXEC

DEFAULT CONFIGURATION**COMMAND MODE**

Privileged EXEC

USER GUIDELINES**EXAMPLE**

```
console# show dce dcbx tengigabitethernet 0/1
```

```
DCBX state is enabled.
```

```
DCBX control TLV
```

```
Max version 1
Oper Version 1
```

```
Priorities Groups TLV
```

```
Max Version: 2
Oper Version: 2
```

Field	Local	Remote
Advertisement	Enabled	Disabled
Enable	Enabled	Disabled
Willing	false	false

Error	Yes	No
Num of TCs	7	0

Priority to priority-groups mapping

Priority	Priority Group	
	Local	Remote
0	15	0
1	15	0
2	15	0
3	15	0
4	15	0
5	15	0
6	15	0
7	15	0

Priority-groups BW allocation

Priority Group	BW Allocation	
	Local	Remote
0	12	0
1	12	0
2	12	0
3	12	0
4	13	0
5	13	0
6	13	0
7	13	0

Priority flow control TLV

Max Version: 2
Oper Version: 2

Field	Local	Remote
Advertisement	Enabled	Disabled
Enable	Enabled	Disabled
Willing	false	false
Error	Yes	No
Num of TCs	8	0

Priority	Flow Control	
	Local	Remote
0	Disabled	Disabled
1	Disabled	Disabled
2	Disabled	Disabled
3	Disabled	Disabled
4	Disabled	Disabled
5	Disabled	Disabled
6	Disabled	Disabled
7	Enabled	Disabled

Application TLV

Max Version: 2
Oper Version: 2

Field	Local	Remote
Advertisement	Enabled	Disabled
Enable	Enabled	Disabled
Willing	false	false
Error	Yes	No

Application to priority mapping

Application	Priority	
	Local	Remote
Port 21	6	

console#

wrr-queue bandwidth (ETS) Use the **wrr-queue bandwidth** global configuration command to allocate bandwidth to queues. Use the **no** form of this command to return to default.

SYNTAX

wrr-queue bandwidth *percentage1* [*percentage 2 .. percentage8*]

no wrr-queue bandwidth

PARAMETERS

percentage 2 .. percentage8—The BW in percentage allocated to queues. Percentage1 specifies the bandwidth for Queue 1, percentage2 specifies the bandwidth for Queue 2 and so on. The sum should be 100. Unspecified percentage defaults to 0.

Range *percentage 0–100*

DEFAULT CONFIGURATION

Percentage5 .. percentage8= 13

Percentage1 .. percentage4= 12

COMMAND MODE

Global configuration

EXAMPLE

```
console(config)# wrr-queue bandwidth 30 20 10 10 10 10 5 5
```

show dce ets To display the information on the Enhanced Transmission Selection (ETS) feature, use the **show dce ets** command in EXEC mode.

SYNTAX

show dce ets

PARAMETERS

This command has no arguments or keywords.

COMMAND MODE

Privileged EXEC

EXAMPLE

```
console# show dce ets
Priority assignment table
```

Priority	Queue
0	3
1	1
2	2
3	4
4	5
5	6
6	7
7	8

Transmission Selection Algorithm

Queue	Transmission Selection Algorithm
1	SP
2	SP
3	SP
4	SP
5	SP
6	SP
7	SP
8	SP

BW allocation

Queue	Bandwidth
1	30%
2	20%
3	10%
4	10%
5	10%
6	10%
7	5%
8	5%

```
console#
```

dce cut-through enable (global) Use the **dce cut-through enable** global configuration command to enable cut-through. Use the **no** form of this command to disable cut-through.

SYNTAX

dce cut-through enable
no dce cut-through enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Disabled

COMMAND MODE

Global configuration

USER GUIDELINES

The configuration must be applied only after reboot.

EXAMPLE

```
console(config)# dce cut-through enable  
This setting will take effect only after copying running configuration to  
startup configuration and resetting the device  
console(config)#
```

dce cut-through enable (interface) Use the **dce cut-through enable** interface configuration command to enable cut-through for an interface. Use the **no** form of this command to disable cut-through for the interface.

SYNTAX

dce cut-through enable
no dce cut-through enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Disabled

COMMAND MODE

Interface configuration (Ethernet)

USER GUIDELINES

The oper state of Cut Through for the interface can be enabled only for 10G ports. Packets are be subject to Cut Through if Cut Through is enabled (oper state) for the ingress interface and for the packet's priority (with the **dce cut-through priority enable** global configuration command). For untagged packets, Cut Through should be enabled for untagged packets for the ingress interface (with the **dce cut-through untagged enable** interface configuration command).

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# dce cut-through enable
```

**dce cut-through
priority enable**

Use the **dce cut-through priority enable** global configuration command to enable cut-through for a priority. Use the **no** form of this command to disable cut-through for the priority.

SYNTAX

dce cut-through priority *priority* enable
no dce cut-through priority *priority* enable

PARAMETERS

priority—802.1Q Priority

Range *priority* 0–7

DEFAULT CONFIGURATION

Disabled

COMMAND MODE

Global configuration

USER GUIDELINES**EXAMPLE**

```
console(config)# dce cut-through priority 7 enable
```

**dce cut-through
untagged enable**

Use the **dce cut-through untagged enable** interface configuration command to enable cut-through for untagged packets for an interface. Use the **no** form of this command to disable cut-through for untagged packets.

SYNTAX

dce cut-through untagged enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT CONFIGURATION

Disabled

COMMAND MODE

Interface configuration (Ethernet)

EXAMPLE

```
console(config)# interface tengigabitethernet 0/1
console(config-if)# dce cut-through untagged enable
```

**dce cut-through
packet-length**

Use the **dce cut-through packet-length** global configuration command to configure the default packet length that is assigned to a packet in the Cut-Through mode. Use the **no** form of this command to return to default.

SYNTAX

dce cut-through packet-length *bytes*

no dce cut-through packet-length

PARAMETERS

bytes—Specifies the default packet length in bytes.

bytes range 257–16383

DEFAULT CONFIGURATION

1522

COMMAND MODE

Global configuration

USER GUIDELINES

In the current version, the command only affects the buffer allocation mechanism. The buffer management counts the number of buffers for each packet that is allocated per packet in the size configured by this command.

A new value for this parameter is applied only after reboot.

EXAMPLE

```
console(config)# dce cut-through packet-length 1024
This setting will take effect only after copying running configuration to
startup configuration and resetting the device
console(config)#
```

show dce cut-through To display the information on cut-through, use the **show dce cut-through** command in EXEC mode.

SYNTAX

show dce cut-through [*interface-id*]

PARAMETERS

[*interface-id*]*—*Specifies an interface ID. The interface ID must be an Ethernet port.

DEFAULT CONFIGURATION

COMMAND MODE

EXEC

EXAMPLE

```
console# show dce cut-through

Cut Through is disabled (Would be enabled after reset)

Default packet length: 1522 (Would be 1024 after reboot)

Priority 0: Disabled
Priority 1: Disabled
Priority 2: Disabled
Priority 3: Disabled
Priority 4: Disabled
Priority 5: Disabled
Priority 6: Disabled
Priority 7: Enabled

Interface Admin    Oper    Untagged
-----
te0/1      Disabled Disabled Enabled
te0/2      Disabled Disabled Disabled
te0/3      Disabled Disabled Disabled
te0/4      Disabled Disabled Disabled
.
.
.
te0/47     Disabled Disabled Disabled
te0/48     Disabled Disabled Disabled
```

dce fip-snooping enable (Global) To enable FIP snooping for the device, use the **dce fip-snooping enable** command in the Global Configuration mode. To disable FIP snooping for the device, use the no form of this command.

SYNTAX

dce fip-snooping enable

no dce fip-snooping enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# dce fip-snooping enable
```

**dce fip-snooping
enable (Interface)**

To enable FIP snooping for an interface, use the **dce fip-snooping enable** command in interface Configuration mode. To disable FIP snooping for the interface, use the no form of this command.

SYNTAX

```
dce fip-snooping enable {enode | fcf | non-fcoe }  
no dce fip-snooping enable
```

PARAMETERS

enode—Specify that the port is connected to FCoE node.

fcf—Specify that the port is connected to Fiber Channel Forwarder and or Enodes.

non-fcoe—Specify that the port is not connected to FCoE node of Forwarder.

DEFAULT

Disabled

COMMAND MODE

Interface configuration mode (Ethernet, Port-channel)

USER GUIDELINES

If the administrator knows that a port is connected only to Enodes, then the port type should be enode; Otherwise some of the Enode rules would not be applied.

Example

```
console(config-if)# dce fip-snooping enable enode
```

**dce fip-snooping
fcf-address-filtering
enable**

To enable filtering of packets based on configured list of MAC addresses of FCFs, use the **dce fip-snooping fcf-address-filtering enable** command in global configuration mode. To disable filtering, use the no form of this command.

SYNTAX

dce fip-snooping fcf-address-filtering enable
no dce fip-snooping fcf-address-filtering enable

PARAMETERS

This command has no arguments or keywords.

DEFAULT

Disabled

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# dce fip-snooping fcf-address-filtering enable
```

**dce fip-snooping
fcf-address-filtering
list**

To add a MAC address to the FCF MAC addresses list, use the **dce fip-snooping fcf-address-filtering list** command in global configuration mode. To remove an address, use the no form of this command.

SYNTAX

dce fip-snooping fcf-address-filtering list *mac-address*
no dce fip-snooping fcf-address-filtering list [*mac-address*]

PARAMETERS

mac-address—Specify a MAC address to add to the list

DEFAULT

The list is empty

COMMAND MODE

Global Configuration mode

EXAMPLE

```
console(config)# dce fip-snooping fcf-address-filtering list 0010.0D48.37FF
```

dce fip-snooping tunnel To add a static tunnel to an interface for FIP snooping, use the **dce fip-snooping tunnel** command in Interface Configuration mode. To remove a tunnel, use the no form of this command.

SYNTAX

dce fip-snooping tunnel *source-mac-address destination-mac-address*

no dce fip-snooping tunnel *source-mac-address destination-mac-address*

PARAMETERS

source-mac-address—Specify the source MAC address

destination-mac-address—Specify the destination MAC address

DEFAULT

No tunnels are configured

COMMAND MODE

Interface configuration mode (Ethernet, Port-channel)

EXAMPLE

```
console(config)# dce fip-snooping tunnel 0010.0D48.37FF 0010.0D48.38FF
```

clear dce fip-snooping tunnel To clear dynamic tunnels of FIP snooping, use the **clear dce fip-snooping tunnel** command in Privileged EXEC mode.

SYNTAX

clear dce fip-snooping tunnel { *interface-id* | *} { *source-mac-address* | *} { *destination-mac-address* | *}

clear dce fip-snooping tunnel all

PARAMETERS

interface-id—Specify an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel

source-mac-address—Specify the source MAC address

destination-mac-address—Specify the destination MAC address

all—Clear all tunnels

COMMAND MODE

Privileged EXEC mode

EXAMPLE

```
console# clear dce fip-snooping tunnel te1 0010.0D48.87FF 0010.0D48.88FF
```

show dce fip-snooping configuration

To display the FIP snooping configuration, use the **show dce fip-snooping configuration** command in EXEC mode

SYNTAX

show dce fip-snooping configuration [*interface-id*]

PARAMETERS

interface-id—Specify an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel

COMMAND MODE

EXEC mode

EXAMPLE

```
console> show dce fip-snooping configuration
```

```
FIP snooping is enabled
FCF MAC address filtering is enabled
FCF MAC addresses list: 0060.704C.73FF, 0060.708C.73FF
```

Interface	Snooping	Port type
te1	Enabled	FCF
te2	Enabled	Enode
te3	Enabled	Non-FCOE
te4	Disabled	

show dce fip-snooping tunnels

To display the FIP snooping tunnels, use the **show dce fip-snooping tunnels** command in EXEC mode.

SYNTAX

show dce fip-snooping tunnels [*dynamic|static*] [*interface interface-id*]

PARAMETERS

dynamic—Displays only dynamic tunnels

static—Displays only static tunnels

interface-id—Specify an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel

COMMAND MODE

EXEC mode

EXAMPLE

```
console> show dce fip-snooping tunnels
```

Static tunnels:

Interface	Source Address	Destination Address
-----	-----	-----
te1	0060.704C.1238	0060.704C.73FF

Dynamic tunnels:

Interface	Source Address	Destination Address	S_ID
-----	-----	-----	-----
te1	0060.704C.1238	0060.704C.73FF	0.0.1
te1	0060.704C.1239	0060.704C.73FF	0.0.2

