

IBM



Advanced Settings Utility, v9.30 User's Guide

Version 9.30

IBM



Advanced Settings Utility, v9.30 User's Guide

Version 9.30

Note

Before using this information and the product it supports, read the information in "Notices" on page 131.

Edition Notice

This edition applies to version 9.30 of IBM Advanced Settings Utility and to all subsequent releases and modifications until otherwise indicated in new editions.

Seventeenth Edition (December 2012)

Copyright International Business Machines Corporation 2004, 2012.

US Government Users Restricted Rights -- Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

© **Copyright IBM Corporation 2012.**

US Government Users Restricted Rights -- Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Tables	v
---------------	----------

Chapter 1. Using the Advanced Settings

Utility	1
----------------	----------

Limitations	1
Supported firmware	1
Operating system support	3
WinPE support	4
Windows Server 2008 support	6
IPMI device driver support for Windows	7
Installing the Microsoft IPMI device driver	8
Verifying the installation	8
IPMI device driver support for Linux	9
Obtaining the ASU and patch files	9
Downloading the Advanced Settings Utility	9
Using ASU patch files	10
Extracting the ASU files for Windows	11
Extracting the ASU files for Linux	12
Using the ASU commands	12
Using the ASU to configure the Remote Supervisor	
Adapters settings	13
Setting up communication with the ASU	13
Configuring the Ethernet settings on a Remote Supervisor Adapter II	13
Configuring IMM-based servers using ASU	15
Connectivity	16
Enabling and disabling the LAN over USB interface	17
Settings syntax	18
Instances of settings	19
Using the Remote Disk Command Line Interface	20
Using the ASU to configure settings for VMware ESXi/vSphere Hypervisor	21
Supported settings	22
Notes	26
Command example	26
Known limitations	26

Chapter 2. Using the command-line

interface	29
------------------	-----------

Command syntax	29
Command configuration applications	29
Configuring the IMM LAN over USB interface	30
Feature on Demand configuration	32
FoD key management on different devices	34
Getting the key from the IBM web site	36
Chassis Management Module configuration	37
List CMM settings	39
List CMM settings in a tree-like format	40
Display help information for CMM setting	41
Show CMM setting	42
Set CMM setting	42
Show possible values for CMM setting	43
Show default value for CMM setting	44
Load default value for CMM setting	44

Delete CMM setting	45
Import local file to CMM	46
Export file from CMM	46
Reboot CMM	47
Reset CMM to default	48
Enumerate attached CMM	49
IMM application configuration	49
Check the host OS power status	50
Power on the host OS	51
Power off the host OS	51
Clear the system event log	52
Show the system event log	53
Clear the IMM event log	53
Show the IMM event log	54
Clear the IMM event log and system event log	55
Classes of settings	55
Setting interdependencies support on an IMM2-based system	57
Command modifiers	59
Command connectivity options	60
Command general options	61
ASU log file	66
Return codes	66
ASU return codes	66
RDCLI return codes	67
Baseboard management controller startup sequence (boot order) settings	68
Boot order settings for IMM-based servers	69
Configuring iSCSI	71
IPv6 related settings in IMM	72
Managing certificates for IMM-based systems	73
Signing a certificate sign request using certificate authority	73
Revoking a certificate	73
Supported commands for IMM-based certificate management	73
Disabling the corresponding server	74
Remote Disk Command Line Interface	77

Chapter 3. Using the commands

Batch command	79
Comparedefault command	81
Createuuid command	83
Delete command	84
Deletecert command	85
Dump command	86
Encrypt command	87
Export command	88
Generate command	89
Help command	94
Import command	95
Loaddefault command	97
Patchadd command	100
Patchextract command	101
Patchlist command	101

Patchremove command	102
Readraw command	103
Rebootbmc command	103
Rebootimm command	104
Rebootrsa command	105
Replicate command	106
Resetsa command	107
Restore command	108
Save command	109
Set command	112
Setenc command	114
Show command	115
Showdefault command	117
Showgroups command	118
Showlocation command	119
Showvalues command	121
Version command	125

Writeraw command	125
Nodes command	126

Appendix. Getting help and technical assistance. 129

Using the documentation	129
Getting help and information from the World Wide Web	130
Software service and support	130
Hardware service and support	130
Product services - Taiwan	130

Notices 131

Trademarks	131
Important notes	132

Tables

1.	Connection options for ESXi/vSphere Hypervisor image	26	30.	Options	47
2.	IMM LAN over USB configuration application commands	31	31.	Connection options	47
3.	Supported devices and interfaces	32	32.	Options	48
4.	Commands.	33	33.	Connection options	48
5.	Options	33	34.	Options	49
6.	Command options parameters	36	35.	Connection options	49
7.	Available switch device codes	36	36.	Commands.	50
8.	Commands.	37	37.	Command options	50
9.	Options	38	38.	Connection options	50
10.	Connection options	38	39.	Options	50
11.	Options	40	40.	Connection options	50
12.	Options	40	41.	Options	51
13.	Options	41	42.	Connection options	51
14.	Options	42	43.	Options	52
15.	Connection options	42	44.	Connection options	52
16.	Options	43	45.	Options	52
17.	Connection options	43	46.	Connection options	52
18.	Options	43	47.	Options	53
19.	Connection options	43	48.	Connection options	53
20.	Options	44	49.	Options	54
21.	Connection options	44	50.	Connection options	54
22.	Options	45	51.	Options	54
23.	Connection options	45	52.	Connection options	54
24.	Options	45	53.	Options	55
25.	Connection options	45	54.	Connection options	55
26.	Options	46	55.	Command modifiers	59
27.	Connection options	46	56.	Command connectivity options	61
28.	Options	47	57.	ASU return codes	66
29.	Connection options	47	58.	RDCLI return codes.	67
			59.	Supported ASU commands	73
			60.	Explanation of XML.	91

Chapter 1. Using the Advanced Settings Utility

Use the IBM® Advanced Settings Utility (ASU) to modify firmware settings from the command line on multiple operating-system platforms.

You can perform the following tasks using the utility:

- Modify selected basic input/output system (BIOS) CMOS settings without restarting the system to access F1 settings
- Modify selected baseboard management controller setup settings
- Modify selected Remote Supervisor Adapter and Remote Supervisor Adapter II setup settings
- Modify selected settings in the integrated management module IMM-based servers for the IMM firmware and IBM System x® Server firmware. The IMM replaces the Remote Supervisor Adapter and baseboard management controller functions on IMM-based servers. IBM System x Server Firmware is the IBM implementation of Unified Extensible Firmware Interface (UEFI). The UEFI replaces the basic input/output system (BIOS) and defines a standard interface among the operating system, platform firmware, and external devices.
- Modify a limited number of VPD settings on IMM-based servers
- Modify iSCSI boot settings. To modify iSCSI settings with the ASU, you must first manually configure the values using the server Setup utility settings on IMM-based servers. For more information, see iSCSI configuration.
- Remote connectivity to support setting all the listed firmware types settings on IMM-based servers. Remote connection support requires accessing the IMM external port over a LAN.

The ASU supports scripting environments because it is a command-line utility. It also offers easier scripting through its batch-processing mode.

For a list of the ASU commands and their descriptions, see Chapter 3, “Using the commands,” on page 79..

Limitations

For IMM-based servers, consider the limitations in this topic.

Some settings might require that you restart the IMM before the settings become effective or so that the values that are set through ASU can display in the IMM web interface.

For IMM-based servers, ASU supports the commands to generate, import, or export security certificates. The IMM version must be at least yuoo78m or later so that ASU can manage security certificates.

Supported firmware

This topic lists the firmware types and settings that are supported by the Advanced Settings Utility.

Throughout this document, the term *Remote Supervisor Adapter II* refers to both the IBM Remote Supervisor Adapter II and the IBM Remote Supervisor Adapter II SlimLine, unless otherwise noted.

The ASU supports the following firmware types:

- BIOS firmware
- Remote Supervisor Adapter firmware
- Remote Supervisor Adapter II firmware
- Baseboard management controller firmware
- IBM System x Server firmware
- IMM firmware
- UEFI firmware
- Original Design Manufacturer integrated baseboard management controller firmware
- Original Design Manufacturer Remote Supervisor Adapter firmware

Note: The PC-DOS version of the ASU supports BIOS settings only.

Supported settings

For the firmware types, the following settings are supported:

- Banked CMOS at 70h/71h (NS317)
- CMOS at 70h/71h and 72h/73h (NS417)
- CMOS at 72h/73h (AMD 8111)
- CMOS through baseboard management controller
- Serial EEPROM settings
- The following Remote Supervisor Adapter and Remote Supervisor Adapter II commands:
 - 8-bit values
 - 16-bit values
 - IP address values (32 bits)
 - Strings
 - Keystroke sequences
 - Certificate
 - Port
- The following baseboard management controller commands:
 - 8-bit values
 - 8-bit value within a block
 - IP address values (32 bits)
 - MAC address values (48 bits)
 - Strings
- Single and multi-node systems

The ASU retrieves and modifies user settings from the supported firmware types through its command-line interface. The ASU does not update any of the firmware code.

Operating system support

The following operating systems (32-bit and 64-bit) support the ASU.

- Microsoft Windows 2000, Windows XP, Windows Server 2003, Windows Server 2003 R2, Windows Server 2008, Windows Server 2008 R2, Windows Vista™, and Windows Small Business Server 2011, Windows 2012.

Note: For the Windows operating system, you must have administrator privileges. For more information about using the ASU on the Windows operating system, see the readme file that is extracted when you extract the ASU package.

- Microsoft WinPE 1.6, Microsoft WinPE 2.0, and Microsoft WinPE 2.1
- Red Hat® Linux® version 4, Red Hat Linux version 5, Red Hat Linux version 7, Red Hat Linux version 8, and Red Hat Linux version 9 (see the note that follows this list)
- Red Hat Enterprise Linux AS 2.1
- Red Hat Enterprise Linux version 3 (see the note that follows this list)
- Red Hat Enterprise Linux version 4 (see the note that follows this list)
- Red Hat Enterprise Linux version 5 with Xen added (see the note that follows this list)
- Red Hat Enterprise Linux version 6 with Xen added (see the note that follows this list)
- SUSE Linux version 7, SUSE Linux version 8, and SUSE Linux version 9
- SUSE Linux Enterprise Server 8, SUSE Linux Enterprise Server 9, SUSE Linux Enterprise Server 10, and SUSE Linux Enterprise Server 10 with Xen added, SUSE Linux Enterprise Server 11, SUSE Linux Enterprise Server 11 SP1.
- VMware ESX Server 3.x, VMware ESX Server 3.5, VMware ESX Server 4.0 and VMware Infrastructure 3
- VMware ESXi 4.x, VMware vSphere Hypervisor 5.0

Note: For Red Hat Enterprise Linux version 3, Red Hat Linux version 9, and other Linux distributions that do not install the compatibility libstdc++ library, the following message might be displayed:

```
./asu: error while loading shared libraries:
libstdc++-libc6.1-1.so.2: cannot open shared object file:
No such file or directory.
```

If this message is displayed, install the compat-libstdc++*.rpm that is included on the distribution media.

For Linux operating systems, you must have the “lsusb” utility installed as a prerequisite. You can find the installation package of this utility in the corresponding Linux distribution media.

For BIOS-based servers, run the ASU on the system that contains the settings that you want to view and change. When the ASU configures the settings, it interacts with the physical hardware. On operating systems that require root or administrator access to interact with the physical hardware, you must run the ASU from an account that has root or administrator access. (Windows and Linux require root and administrator access.)

The Remote Supervisor Adapter device drivers and Remote Supervisor Adapter II USB daemon are used to view and change Remote Supervisor Adapter or Remote

Supervisor Adapter II settings. If there is no Remote Supervisor Adapter or Remote Supervisor Adapter II device driver for an operating system (such as PC-DOS), the ASU does not support changing Remote Supervisor Adapter or Remote Supervisor Adapter II settings for that operating system.

For baseboard management controller settings, an Intelligent Platform Management Interface (IPMI) device driver is required. A corresponding IBM IPMI mapping layer might also be required. The ASU supports interfacing with different versions of the IPMI device driver (OSA, MSI, Microsoft IPMI Driver, and OpenIPMI). For Microsoft Windows-based implementations, see IPMI device driver support for Windows. For Linux-based implementations, see IPMI device driver support for Linux.

Notes

- You cannot use the ASU to configure Remote Supervisor Adapter II settings from Red Hat Enterprise Linux AS 2.1 because there is no Remote Supervisor Adapter II device driver for the Red Hat Enterprise Linux AS 2.1 operating system.
- You cannot use the ASU to configure Remote Supervisor Adapter or Remote Supervisor Adapter II settings from PC-DOS because there is no Remote Supervisor Adapter or Remote Supervisor Adapter II device driver for PC-DOS.
- You can view or change settings on a local server only.
- You cannot use the ASU to configure baseboard management controller settings from PC-DOS because there is no baseboard management controller device driver for PC-DOS.
- The PC-DOS version of the ASU does not support a multi-node-capable server when it is configured as multi-node.
- The PC-DOS version of the ASU does not support a server in which the BIOS settings are stored in the baseboard management controller (for example, an IBM System x3950 M2 server).
- You cannot unpack the Windows ASU packages on a server or workstation that is running a 64-bit version of WinPE. You can unpack the Windows ASU packages on a server or workstation that is running any of the other Windows operating systems that support the ASU. (For a list of operating systems that support the ASU, see Operating-system support.)

Note: For the latest information about IBM servers, workstations, and the operating systems that are supported, see *Compatibility for hardware, applications, and middleware*.

WinPE support

Windows Preinstallation Environment (WinPE) requires some special considerations for the Advanced Settings Utility (ASU) to function correctly. These considerations are different for WinPE 1.6 or earlier and WinPE 2.0 (the version that is based on the Windows Vista operating system) or later.

WinPE 1.6 or earlier

ASU is not supported on WinPE 1.6 for IMM-based servers.

WinPE 1.6 or earlier (the WinPE versions that are based on Windows XP and Windows Server 2003) do not have temporary file storage, which affects how you extract the device driver from the ASU executable file.

The WinPE 1.6 or earlier versions also cannot recognize new USB devices after startup, which affects the behavior of the Remote Supervisor Adapter II **Reset** and **Restart** commands.

Device driver extraction for read-only media

Windows operating-system support of the ASU requires the loading of a helper device driver. This device driver is embedded in the ASU executable file and, under normal circumstances, is extracted automatically at runtime to either a temporary directory or, if no "TEMP" environment variable is defined, the directory that contains the executable file, if it does not already exist. The device driver is then automatically loaded and used by the ASU. In the case of WinPE, where no writeable temporary directory is defined, there must be an alternative way to load the device driver.

If the ASU is unable to extract the device driver to a temporary directory, it attempts to load the device driver from the directory where the executable file is located. If the device driver exists, it is loaded, and execution continues. If the ASU does not find the device driver and cannot extract it for loading, an error message is displayed, and execution is stopped.

If you are running the ASU from nonwriteable media (such as a CD), the device driver must exist on the media. You can manually extract it from the ASU executable file (and then copy it onto the nonwriteable media) by running the following command from a writeable media that contains the ASU:

ASU extractdriver (32-bit Windows version)

ASU64 extractdriver (64-bit Windows version)

The device driver is extracted as wflash.sys into the directory that contains the executable file. Then, you can copy the device driver (together with the ASU executable file) to nonwriteable media such as a bootable WinPE CD.

Remote Supervisor Adapter II reset and restart problem with WinPE

WinPE versions that are earlier than WinPE 2.0 recognize devices that are available only at startup time and later. This causes a problem when you issue a resetsra or rebootsra command to the Remote Supervisor Adapter II using the ASU because it removes the Remote Supervisor Adapter II from the bus. This prevents further communication with the device before a subsequent server restart.

If the version of WinPE is earlier than 2.0, an information message is displayed indicating that the server must be restarted before you can run another ASU command for the Remote Supervisor Adapter II.

WinPE 2.0 or later

The standard WinPE 2.0 (based on the Windows Vista operating system) image is missing two packages that the ASU requires for operation. For instructions for adding optional WinPE packages to the image that you create, see the documentation that comes with the Windows Automated Installation Kit.

To run the ASU, you must add the following packages:

- WinPE-MDAC-Package

- WinPE -WMI-Package

WinPE 2.0 has an integrated Microsoft IPMI device driver, and the ASU 2.3.0 or later has an embedded mapping layer that supports that driver. Therefore, no user-installed IPMI driver or mapping layer is required. For more information about the IPMI device-driver support in WinPE 2.0, see IPMI device driver support for Windows.

Windows Server 2008 support

The Microsoft Windows Server 2008 operating system supports ASU version 2.3.0 or later.

Windows Server 2008 has an integrated Microsoft IPMI device driver, and the ASU 2.3.0 or later has an embedded mapping layer that supports that driver. Therefore, no user-installed IPMI driver or mapping layer is required. For more information about the IPMI device-driver support in Windows Server 2008, see IPMI device driver support for Windows.

Supported systems

The ASU supports the servers, blade servers, and computers that are listed in the following lists.

- IBM System x3100 M4 Type 2582
- IBM System x3200 M2 Type 4367, 4368
- IBM System x3200 M3 Type 7327, 7328
- IBM System x3250 M2 Type 4190, 4191, 4194, 7650
- IBM System x3250 M3 Type 4251, 4252, 4261
- IBM System x3250 M4 Type 2583
- IBM System x3300 M4 Type 7382
- IBM System x3400 Type 7973, 7974
- IBM System x3400 Type 7975, 7976
- IBM System x3400 M2 Type 7836, 7837
- IBM System x3400 M3 Type 7378, 7379
- IBM System x3500 Type 7977
- IBM System x3550 Type 7978, 1913
- IBM System x3500 M2 Type 7839
- IBM System x3500 M3 Type 7380
- IBM System x3530 M4 Type 7160
- IBM System x3550 M2 Type 7946, 4198
- IBM System x3550 M3 Type 7944, 4254
- IBM System x3500 M4 Type 7383/*
- IBM System x3550 M4 Type 7914/*
- IBM System x3620 M3 Type 7376
- IBM System x3630 M3 Type 7377
- IBM System x3630 M4 Type 7158
- IBM System x3650 Type 7979, 1914
- IBM System x3650 M2 Type 7947, 4199
- IBM System x3650 M3 Type 7945, 4255, 5454
- IBM System x3650 M4 Type 7915/*

- IBM System x3690 X5 Type 7148, 7149
- IBM System x3690 X5 Type 7192, 7147
- IBM System x3750 M4 Type 8722,8733
- IBM System x3755 M3 Type 7164
- IBM System x3850 M2 / x3950 M2 Type 7141, 7144
- IBM System x3850 M2 / x3950 M2 Type 7233, 7234
- IBM System x3850 X5 / x3950 X5 Type 7145, 7146
- IBM System x3850 X5 / x3950 X5 Type 7143, 7191
- IBM System x iDataPlex® dx320 Type 6388
- IBM System x iDataPlex dx360 M2 Type 7321, 6380, 7323
- IBM System x iDataPlex dx360 M3 Type 6391
- IBM System x iDataPlex dx360 M4 Type 7912, 7913, 7918, 7919
- IBM BladeCenter® HS12 Type 8014, 8028, 1916
- IBM BladeCenter HS21 Type 8853, 1885
- IBM BladeCenter HS21 XM Type 7995, 1915
- IBM BladeCenter HS22 Type 7870, 1936, 7809, 1910
- IBM BladeCenter HS22V Type 7871, 1949
- IBM BladeCenter HS23 Type 7875, 1929
- IBM BladeCenter HS23E Type 8038, 8039
- IBM BladeCenter LS21/LS41 Type 7971, 7972
- IBM BladeCenter LS22/LS42 Type 7901, 7902
- IBM BladeCenter HX5 Type 7872, 1909
- IBM BladeCenter HX5 Type 7873, 1910
- IBM Flex System™ x440 Compute Node Type 7917
- IBM Flex System x220 Compute Node Type 7906,2585
- IBM Flex System x240 Compute Node Type 8737,8738,7863
- IBM Smart Analytics System Type 7949

For the latest list of supported systems, see Support for IBM Systems.

IPMI device driver support for Windows

This section explains the Intelligent Platform Management Interface (IPMI) device driver support for Windows.

Microsoft Windows supports the OSA and MSI IPMI device drivers. If you are using Windows Server 2003 R2, Windows Server 2008, or Windows PE 2.0 or later, you do not have to install an external (OSA or MSI) IPMI device driver. Microsoft integrates the IPMI device driver with the operating system. The ASU supports these operating systems starting with ASU 2.3.0. To support the integrated device driver, a new IBM mapping layer is required. This new mapping layer comes embedded in the ASU 2.3.0 or later.

If you want to use the Microsoft IPMI device driver and you have previously installed the IBM mapping layer, you must remove the mapping layer. This mapping layer was required to support the OSA and MSI IPMI device drivers. The ASU embedded mapping layer conflicts with the externally installed and previously required IBM mapping layer.

The Microsoft IPMI device driver is automatically installed with Windows Server 2008 and Windows PE 2.0 or later. However, it is not installed by default with Microsoft Windows Server 2003 R2. For instructions on installing the Microsoft IPMI device driver on Microsoft Windows Server 2003 R2, see “Installing the Microsoft IPMI device driver.”

Installing the Microsoft IPMI device driver

The Microsoft IPMI device driver is not installed by default on Microsoft Windows Server 2003 R2.

About this task

To install the Microsoft IPMI device driver on Windows Server 2003 R2, complete the following steps:

Procedure

1. Click **Start > Control Panel > Add/Remove Programs**.
2. Click **Add/Remove Windows Components**.
3. From the component list, select **Management and Monitoring Tools**, and then click **Details**.
4. Select **Hardware Management**.
5. Click **Next**. The installation wizard opens and guides you through the installation. The Windows Server 2003 R2 installation disk is required.

What to do next

You can verify that the installation was successful. For instructions, see “Verifying the installation.”

Verifying the installation

This topic describes how to verify that the Microsoft IPMI device driver installed correctly.

Procedure

1. Click **Start > Control Panel > System**.
2. Select the Hardware tab.
3. Click **Device Manager**.
4. Click **View > Show Hidden Devices**.
5. Expand **System devices**. If the Microsoft IPMI device driver is installed correctly, a device named Microsoft Generic IPMI Compliant Device is displayed under **System devices**. For a multi-node configuration, a device named Microsoft Generic IPMI Compliant Device is created for each node.

Results

For an IBM System x3950 M2 server (multi-node configuration), the Microsoft IPMI device driver is the only supported IPMI driver.

IPMI device driver support for Linux

To access baseboard management controller settings, use either the OSA or MSI device driver and its corresponding IBM IPMI mapping layer. You can also use the OpenIPMI device driver that comes in many Linux distributions.

Notes

1. The default version of OpenIPMI that is in Red Hat Enterprise Linux 3 Update 6 and Red Hat Enterprise Linux 3 Update 7 has a timing issue; therefore, it is not supported by the ASU. In this case, the OSA IPMI mapping layer is required.
2. For an IBM System x3950 M2 server (multi-node configuration), the OpenIPMI device driver is the only supported IPMI driver.

Obtaining the ASU and patch files

The ASU, patch files, and device drivers that you need are available from the IBM Support web site. Patch files are not required for IMM-based servers.

Download the following files:

- ASU package. The package contains the ASU tool and the additional files that are required for IMM-based servers. The additional files for IMM-based servers are required for configuring and activating the IMM LAN over USB interface.
- (For BIOS-based servers only) BIOS patch file for the server. (To determine if an external BIOS code patch is required, see Supported systems.)
- (For BIOS-based servers only) Remote Supervisor Adapter device drivers or Remote Supervisor Adapter II USB daemon (if you want to use the ASU to configure Remote Supervisor Adapter or Remote Supervisor Adapter II settings).
- (For BIOS-based servers only) Baseboard management controller device drivers and, if required, mapping layer (if you want to use the ASU to configure baseboard management controller settings).

Downloading the Advanced Settings Utility

Use this topic to help you locate and download the required ASU files.

About this task

Changes are made periodically to the IBM web site. Procedures for locating firmware and documentation might vary slightly from what is described in this topic.

Procedure

1. To download the IBM Advanced Settings Utility, go to the IBM Support Portal or complete the following steps:
 - a. Go to the Support for IBM systems page.
 - b. In the navigation pane, click **Systems Management software**.
 - c. Under Popular links, click **Tools and utilities**.
 - d. Under Configuration, click **Advanced Settings Utility**.
2. For BIOS-based servers only, download the BIOS definition file:
 - a. On the Support page for the server, select **Software and device drivers**.
 - b. On the Software and device drivers page, click **BIOS**.

- c. Select **BIOS definition file for use with IBM Advanced Setting Utility**. The BIOS definition file must match the BIOS level that the server is running.
 - d. Select the ASU BIOS definition .exe file.
 - e. Follow the instructions that guide you through the download process.
3. For BIOS-based servers only, return to the software and device drivers page to install the device-driver software for the Remote Supervisor Adapter II and baseboard management controller.
4. If required, download the IPMI device driver using the following steps. The IPMI device driver is not required in Windows 2003 R2, Windows 2008, and Linux operating systems that support OpenIPMI. For more information, see IPMI device driver support for Windows or IPMI device driver support for Linux.
 - a. On the Software and device drivers page, click **OSA IPMI**, and then select the applicable device-driver file.
 - b. Read the .txt file and follow the instructions that guide you through the download process.
5. After you have downloaded the OSA IPMI device driver file:
 - a. Select the applicable mapping layer for OSA IPMI file.
 - b. Read the .txt file, and follow the instructions that guide you through the download process.
6. (For BIOS-based servers only.) On the "Software and device drivers" page:
 - a. Click **Remote Supervisor Adapter II**.
 - b. Select the applicable RSA II daemon.
 - c. Read the .txt file, and follow the instructions that guide you through the download process.

Using ASU patch files

ASU configuration information is contained in a patch. This topic explains how to use ASU patch files. Patch files are not required for IMM-based servers.

The ASU requires configuration information for the baseboard management controller, BIOS, and Remote Supervisor Adapter II before you can perform ASU operations that are targeted to the selected device. This configuration information is contained in a patch. There are separate patches for the baseboard management controller, BIOS, and Remote Supervisor Adapter II.

The ASU now contains the baseboard management controller and Remote Supervisor Adapter II patches. Depending on the server model and BIOS level, a BIOS code patch might be required. For a list of servers that require a BIOS patch file, see Supported systems. For the systems that do not require a BIOS patch file, the BIOS patch is embedded in the BIOS ROM. If the BIOS patch is required, you must download the BIOS patch (definition file) from the IBM web site and add it to the ASU (only if you are required to perform an ASU command by using the BIOS settings).

To determine whether the BIOS patch is already available for the ASU, enter the ASU **patchlist** command to display the current available patches. If the ASU determines that a BIOS patch file is embedded in the BIOS, it displays the BIOS patch files that are available.

Example of ASU output when the **patchlist** command is issued with the BIOS patch not listed:

```
Patch 1: <XX[00->99] (BMC)>
Patch 2: <XX[00->99] (RSA)>
```

Example of ASU output when the **patchlist** command is issued with the BIOS patch listed:

```
Patch 1: <XX[00->99] (BMC)>
Patch 2: <XX[00->99] (RSA)>
Patch 3: <D0[14->14] (BIOS)>
```

If the BIOS patch is not listed, you must add the patch before you can change or view BIOS settings. You can either add or remove a patch from the ASU.

The following illustration shows how patches are added and removed in the ASU binary code. For each BIOS code and firmware type, the internal locations of the settings vary. A patch informs the ASU where the settings are located for a single BIOS code version.

If a BIOS patch is needed and is not listed when you use the **patchlist** command, download the selected BIOS definition file (patch file) from the IBM web site and perform a patch add using the ASU.

When you run the ASU, it automatically scans the patches that are available and determines if the applicable patch exists for the setting that you want. If an applicable patch exists, the ASU applies the setting. If the patch does not exist, the ASU displays an error.

A patch that is added remains until you run the **patchremove** command on that patch.

Notes

1. You cannot remove the BIOS patches that are embedded in the BIOS ROM by running the **patchremove** command.
2. Only one patch is supported for any major version of BIOS. For example, if there are BIOS versions 19A and 19B, only one patch is supported for both.

Extracting the ASU files for Windows

This topic contains instructions for extracting the ASU files on a Windows operating system.

About this task

You must run the ASU commands from the directory in which the ASU files are located.

Procedure

1. Change directories to the directory that contains the downloaded ASU files.
2. Choose one of the following methods to extract the ASU files:
 - Using Windows, double-click *filename.exe*, where *filename* is the file name for the Advanced Settings Utility for Windows that you downloaded.
The files are automatically extracted to the same directory.
 - Using a command prompt, type *filename.exe*, where *filename* is the file name for the Advanced Settings Utility for Windows that you downloaded.

What to do next

The ASU requires additional files for IMM-based servers. These files are required to automatically configure and activate the LAN over a USB interface. The ASU uses the LAN over USB interface as a connectivity option. For more information about connectivity options, see Command connectivity options.

Extracting the ASU files for Linux

This topic contains instructions for extracting the ASU files on a Linux operating system.

About this task

You must type the ASU commands from the directory in which the ASU files are located.

Procedure

1. Open an xterm or other terminal window.
2. Change directories to the directory that contains the downloaded ASU files.
3. From a shell command prompt, type one of the following commands and press **Enter**.
 - If the .tgz file for ASU was downloaded:
Enter `tar -zxvf filename.tgz` where *filename* is the file name of the Advanced Settings Utility for Linux that you downloaded.
The files are extracted to the same directory.
 - If the .rpm file for ASU was downloaded:
Enter `rpm -Uvh filename.rpm` where *filename* is the file name of the Advanced Settings Utility for Linux that you downloaded.
The files are extracted to the `/opt/ibm/toolscenter/asu` directory.

What to do next

The ASU requires additional files for IMM-based servers. These files are required to automatically configure and activate the LAN over a USB interface. The ASU uses the LAN over USB interface as a connectivity option. For more information about connectivity options, see Command connectivity options.

Using the ASU commands

The ASU uses the `asu` or `asu64` command. This topic lists some example ASU commands.

- To see all of the ASU command modes and options, type the following command:
`asu` (for a 64-bit operating system, type `asu64`)
- To change a value, type the following command:
`asu set setting value`
- To show the current value, type the following command:
`asu show setting`
- To show all possible values, type the following command:
`asu showvalues setting`
- To add a patch, type the following command:

```
asu patchadd filename.def
```

where *filename* is the file name of the definition file.

Explanation of variables

- In the commands, *setting* is the name of a setting that you want to view or change, and *value* is the value that you are placing on the setting.
- If *value* contains spaces, enclose the value string in quotation marks ("").
- If you are using a Linux operating system, you must add either a period (.) to the path environment variable or type ./ before each ASU command. For example, type ./asu or, for a 64-bit operating system, type ./asu64.

Using the ASU to configure the Remote Supervisor Adapters settings

Use the ASU to directly configure a Remote Supervisor Adapter or Remote Supervisor Adapter II.

Be sure to install the Remote Supervisor Adapter device drivers or Remote Supervisor Adapter II USB daemon before you use the ASU. To install the device drivers, see the IBM Remote Supervisor Adapter II Installation Instructions for Microsoft Windows Users or IBM Remote Supervisor Adapter II Installation Instructions for Linux Users, which are available at Support for IBM Systems.

Setting up communication with the ASU

Before you can use the ASU to modify Remote Supervisor Adapter or Remote Supervisor Adapter II settings, you must configure the operating-system setting so that the ASU can communicate correctly with the Remote Supervisor Adapter or Remote Supervisor Adapter II.

About this task

Use the Configuration/Setup Utility program that is part of the system BIOS code to configure the operating-system setting. To configure the operating-system setting by using the Configuration/Setup Utility program, complete the following steps:

Procedure

1. Turn on the system.
2. When the prompt **Press F1 for Configuration/Setup** is displayed, press **F1**.
3. On the Configuration/Setup Utility main menu, select **Advanced Setup**, and then select **RSA Settings**.
4. Select **Other OS** for a Windows operating system, or select **Linux OS** as the operating-system USB selection.
5. Select **Save the Values and Reboot RSA**, and then press **Enter**. Wait until the message RSA Settings saved is displayed.
6. Exit the Configuration/Setup Utility program and complete the startup of the operating system.

Configuring the Ethernet settings on a Remote Supervisor Adapter II

The Remote Supervisor Adapter II requires configuration to enable remote access to the adapter through the adapter Ethernet and serial connectors.

For detailed information about using the Remote Supervisor Adapter II Web interface for remote access, see the IBM Remote Supervisor Adapter II User's Guide.

You can use the ASU to configure the Remote Supervisor Adapter II Ethernet settings.

Note: If you have an accessible, active, and configured Dynamic Host Configuration Protocol (DHCP) server on your network, the host name, IP address, gateway address, and subnet mask are set automatically. You can use the Configuration/Setup Utility program that is part of the server BIOS to select DHCP server settings. For more information, see the IBM Remote Supervisor Adapter II Installation Instructions for Microsoft Windows Users or IBM Remote Supervisor Adapter II Installation Instructions for Linux Users, which is available at <http://www.ibm.com/systems/support/>.

You can also configure the DHCP setting by using the ASU. To use the ASU, continue with the following procedure.

If you have an enabled DHCP server and you want to configure the serial connector, go to .

Configuring Ethernet settings without DHCP server

If you do not have a DHCP server on your network, use this topic to help you configure Ethernet settings.

About this task

If you are using Linux, be sure to type ./ before asu.

Procedure

1. If you have not already, extract the ASU files. For more information, see Extracting the ASU files for Windows or Extracting the ASU files for Linux.
2. At the command prompt, change to the directory that contains the ASU files.
3. If you have not already done so, add the Remote Supervisor Adapter/Remote Supervisor Adapter II ASU patch. For more information, see Patchadd command and Patchlist command. Note: This step is not required if you are using ASU version 2.0 or later.
4. To view a list of all settings and their assigned values, type the command `asu show all` and press **Enter**.
5. From the following list, select the items that you want to set.
 - To enable the network interface on the Remote Supervisor Adapter II, type the following command and press **Enter**:
`asu set RSA_Network1 Enabled`
 - To set the IP address, type the following command and press **Enter**:
`asu set RSA_HostIPAddress1 192.169.70.140`
 - To set the subnet mask, type the following command and press **Enter**:
`asu set RSA_HostIPSubnet1 255.255.255.0.`
 - To set the gateway IP address, type the following command and press **Enter**:
`asu set RSA_GatewayIPAddress1 192.168.70.1`
 - To enable DHCP, type the following command and press **Enter**:
`asu set RSA_DHCP1 Enabled`

- To set the data-transfer rate, type the following command and press **Enter**:
`asu set RSA_LANDataRate1 "10M Ethernet"`
 - To set duplex mode, type the following command and press **Enter**:
`asu set RSA_Duplex1 Full`
6. Restart the system by entering `asu rebootrsa` and pressing **Enter**.

Configuring serial connection on RSA

Use the ASU to configure the Remote Supervisor Adapter II serial connection.

About this task

The serial connector connects to a modem for dial-out support only. To configure the Remote Supervisor Adapter II serial connection for access to a modem, complete the following steps.

If you are using a Linux operating system, be sure to type `./` before `asu`.

Procedure

1. If you have not already, extract the ASU files. For more information, see [Extracting the ASU files for Windows](#) or [Extracting the ASU files for Linux](#).
2. At the command prompt, change directories to the directory that contains the ASU files.
3. To view a list of all of the settings and assigned values, enter the `asu show all` command and press **Enter**:
4. From the following list, select the items that you want to set.
 - To change the modem baud rate, type the following command and press **Enter**:
`asu set RSA_ModemBaudRate1 value`
 where *value* is a number from 2400 through 57600 in increments of 2400 (for example, 2400, 4800, 7200, 9600, ..., 57600). The default is 57600.

Note: Make sure that the baud rate matches the baud rate of the device that you are connecting to the serial connector on the Remote Supervisor Adapter II.

 - To change the modem parity, type the following command and press **Enter**:
`asu set RSA_ModemParity1 value`
 where *value* is None, Odd, Even, Mark, or Space. The default is None.
 - To change modem stop bits, type the following command and press **Enter**:
`asu set RSA_ModemStopBits1 value`
 where *value* is either 1 or 2. The default is 1.
5. Restart the system by typing `asu rebootrsa` and pressing **Enter**.

Configuring IMM-based servers using ASU

Use the Advanced Settings Utility to configuring settings on IMM-based servers.

The ASU uses the same set of commands and syntax that are used by previous versions of the ASU tool. Some commands are enhanced to manage and display groups of settings. New classes are used as filters if you display the supported settings by using the `show set` of commands.

To use all of the new functions in the ASU 3.01, the IMM firmware level must be version 1.05 or later.

ASU can support certificate management of IMM-based servers. To use this function, the IMM firmware level must be yuoo71a or later.

For IMM-based servers, after you use the ASU to change settings, you must reset the IMM before you flash new firmware. If you do not reset the IMM, the changes you made to the settings might be lost. To reset the IMM, run the `asu rebootimm` command.

The following sections describe the functions that are available to support IMM-based servers with the ASU.

Connectivity

For IMM-based servers, all firmware settings are configured through the IMM.

The ASU can connect to the IMM locally (in-band) through the Keyboard Controller Style (KCS) interface or through the LAN over USB interface. The ASU can also connect remotely over the LAN.

The IMM comes with a LAN over USB interface that can be configured and activated on the running operating system. After you install and configure the corresponding information file, the ASU can be connected to the IMM. The local LAN over USB connection requires authentication. A new set of connectivity parameters are required when the ASU is connected over the LAN.

If the LAN over USB interface was disabled before executing a ASU command, ASU configures and activates it for ASU connection. After executing the command, ASU disables the interface. If the interface was enabled before, it remains enabled without changes so that ASU can keep the LAN over USB interface the same status as before and after the ASU command.

The local connection over the KCS interface does not require authentication and follows the online connecting model and command structure of BIOS-based servers, where no connectivity parameters are required. If you do not specify connectivity parameters, the ASU attempts to connect to the IMM by using the default LAN settings on the LAN over USB interface. If the ASU is unable to connect to the IMM over the LAN, it automatically connects over the KCS interface, provided that the correct IPMI device drivers or mapping layers are installed. For more information about the KCS interface, see the Intelligent Platform Management Interface Specification.

In the following example, the ASU attempts to connect through the LAN over USB interface. If the LAN over USB interface connection has failed, the ASU attempts to connect through the KCS interface.

asu show

You can request that the ASU connect locally, exclusively using the KCS interface, which avoids the automated connection over the LAN over USB interface (and the fallback to the KCS interface). If you use the `--kcs` option, the ASU communicates through the KCS interface only.

In the following example, the ASU attempts to connect through the KCS interface only, without the need for authentication parameters.

asu show --kcs

You can also request that the ASU connect locally, exclusively using the LAN over USB interface, by specifying the `--host` connectivity option. The ASU does not attempt to fall back to use the KCS interface when this option is specified.

In the following example, the ASU attempts to connect through the LAN over USB interface only by using the default user ID and password account.

asu show --host 169.254.95.118

When the ASU runs any command on an IMM-based server, it attempts to connect and automatically configure the LAN over USB interface if it detects that this interface is not configured. The ASU provides a level of automatic and default settings. You can specify to skip the automatic configuration process if you have manually configured the IMM LAN over USB interface by using different settings than those used by the ASU application default settings.

Use the `--noimmlancfg` option to skip the automatic configuration process if you have manually configured the interface. For example, to show the IMM list of settings and avoid using the automatic configuration process when you attempt to connect through the LAN over USB interface, type the following command:

```
asu show IMM --noimmlancfg
```

If the ASU is connecting remotely to the IMM over the LAN, there is no requirement for the remote operating system of the targeted IMM to be online. The ASU can connect to the IMM remotely when the server is connected to power or is using standby power. Both IPv4 and IPv6 are supported remotely by ASU. Before running ASU, be sure that the IMM net configuration is correct.

To connect remotely, the `--host` option is a required. The following example indicates the minimum required parameter when the ASU connects remotely through the LAN to the IMM external port.

```
asu show --host target_IMM_external_IP_address
```

Enabling and disabling the LAN over USB interface

Use the ASU to enable or disable the IMM LAN over USB interface by using the `IMM.LanOverUsb` setting.

When you enable or disable this setting, you must use the KCS interface because the LAN over USB interface is removed during the set command process. This prevents the ASU set command from terminating correctly. You must use the `--kcs` connectivity option to make sure that the asu command is completed correctly and relates status.

```
asu set IMM.LanOverUsb Disabled --kcs
```

To connect remotely to an IMM from a Windows client to display all available settings, type the following command. The IMM external IP address is 9.5.51.37.

```
asu show all --host 9.5.51.37 --user testid --password test
```

To connect locally to an IMM from a Windows operating system to display all available settings, type the following command. The ASU connects to the IMM through the LAN over USB interface.

```
asu show all --user testid --password test
```

To connect locally to an IMM from a Windows operating system to display all available settings, type the following command. The ASU attempts to connect over the LAN over USB interface by using the default IMM authentication credentials. If the default settings do not match, the ASU attempts to use the KCS interface, provided that the IPMI device drivers and mapping layers are installed.

```
asu show all
```

To connect locally forcing the ASU to use the KCS interface and avoid using the LAN over USB interface, type the following command:

```
asu show --kcs
```

For more information about connectivity parameters and usage, see Command connectivity options.

Settings syntax

All settings in IMM-based servers are configured through the IMM and the settings are classified into groups of settings.

The term group is used in this document to refer to how the settings for a specific subsystem are grouped together.

The following groups of settings or firmware settings are supported:

- UEFI - UEFI (BIOS) settings
- BootOrder - Boot-order configuration in UEFI
- iSCSI - iSCSI supported settings (Boot-over-iSCSI settings)
- SYSTEM_PROD_DATA - User-configurable VPD settings

There is a new setting syntax to use for identifying the corresponding group of settings. The setting name is preceded by the corresponding group name:

```
group_name.setting_name
```

To set the external IP address in the IMM, type the following command:

```
asu set IMM.HostIPAddress 9.5.51.37
```

where *IMM.HostIPAddress* is the IMM setting that is used to configure the IMM external IP address. The setting is part of the IMM group.

There are settings that include an additional index, which is referred to in this document as an instance. The index is used to identify and set different instances of the same setting when these are available.

To set the first instance of a number or login ID, type the following command:

```
asu set IMM.LoginId.1 testid
```

where *IMM.LoginId.1* is the IMM setting that is used to configure the first instance of a login account.

Instances of settings

This topic explains instances of settings on IMM-based servers.

The ASU is extending the support of instances in several different ways. Commands have been created or modified to provide more information about instances and ways to create and delete them. Instances are denoted by adding a dot, followed by the instance number to the end of the setting name. For example, if the setting name is "IMM.LoginId," instance number 1 of the setting is "IMM.LoginId.1".

Note: There is an exception to the naming convention for single instances. Single instances do not have the dot followed by an instance number. The setting instead appears like a non-instance setting. Single instance settings are denoted in the output of the `showvalues` command by having a maximum number of instances of `:single.` For example, the setting `iSCSI.initiatorName` is a "single instance." The dot followed by an instance number is not used. If the single instance exists, the setting `iSCSI.initiatorName` is displayed in the `show` command output. If it does not exist, the setting is not displayed in the `show` command output.

Instance settings are now defined to have a minimum and maximum number of allowed instances. To determine which settings can have instances and the minimum and maximum number of instances allowed, use the `showvalues` command with the new `--instances` parameter. The output of this command is detailed in `Showvalues` command.

Creating and deleting instances

This topic explains how to create and delete instances using the Advanced Settings Utility.

Use the `set` command to create an instance. If the instance does not already exist, and the instance number is between 1 and the maximum number of allowed instances, the instance is automatically created and set to the value specified in the `set` command.

Use the `delete` command to delete an instance. This command deletes the instance if deleting the instance does not cause the number of instances for the setting to go below the minimum number of allowed instances for the setting.

Note: There are restrictions for creating and deleting instances of settings that are part of a record. For more information about the restrictions, see `Record management`.

Record management

This topic explains how instances can be part of a record and how to manage instances in a record.

Record management is a new feature in the ASU. Settings that have instances can be part of a record. A record is basically a group of settings that have dependencies on each other. For example, a user ID and a password are dependent on each other. A user ID must have a password and a password must have a user ID. Therefore, they are grouped in the same record.

Each record has a setting that is defined as the "record key." It represents the primary setting for the record.

All settings in a record are created or deleted as a group. To create an instance of a record, you must first perform a "set" on the key setting of the record. This automatically causes an instance to be created and set to its default value for all other settings in the record. For examples of creating an instance of a setting, see the Set command.

To delete an instance of a record, the delete command is performed on the "record key" setting. This automatically deletes all other instances for the settings in the record. For examples of deleting an instance of a setting, see the Delete command.

Determining if a setting is part of a record

To determine if a setting is part of a record, use the showvalues command with the **--instances** parameter. Settings that are part of a record are marked with the text "recordKey" (if the setting is the record key) or "recordKey=key_name" (if the setting is part of a record but is not the key), where *key_name* is the name of the setting that is the record key. Examples of the showvalues output for settings that are part of a record are shown in Showvalues command.

Creating an instance of a record

All settings in a record are created or deleted as a group. To create an instance of a record, you must first perform a "set" on the key setting of the record. This automatically causes an instance to be created and set to its default value for all other settings in the record. For examples of creating an instance of a setting, see the Set command.

Deleting an instance of a record

To delete an instance of a record, the delete command is performed on the "record key" setting. This automatically deletes all other instances for the settings in the record. For examples of deleting an instance of a setting, see the Delete command.

Using the Remote Disk Command Line Interface

Use the Remote Disk Command Line Interface (RDCLI) to mount an image to a remote IMM-based server.

RDCLI is available in an ASU release package. Use it to mount an ISO, DVD, or CD to a remote IMM-based system so that it can be accessed like a local hardware device.

Considerations

Note the following points before using the RDCLI:

- To use the RDCLI mount image to connect to a remote IMM-based system, the system must be installed with the remote present key and function enabled.
- RDCLI does not work if there is a session started with the remote present function through the IMM web user interface.
- RDCLI is supported only in rack IMM-based servers. RDCLI does not support IMM-based blade servers.

Supported operating systems

The RDCLI supports the following operating systems:

- SUSE Linux Enterprise Server 10 (32 / 64 bit)
- SUSE Linux Enterprise Server 11 (32 / 64 bit)
- Red Hat Enterprise Linux version 4 (32 / 64 bit)
- Red Hat Enterprise Linux version 5 (32 / 64 bit)

Package

RDCLI contents:

`rdmount --` Performs authentication and spawns new file server processes that allow access to the virtual disk. It can also query the existing file server processes.

`rdumount --` Binary to unmount an ISO, DVD, or CD from a remote IMM-based server

These 2 binaries are packaged under the `rdcli32` and `rdcli64` directory within ASU Linux distribution.

Supported command line parameters

`-s <address or hostname>` = The address or hostname of the remote SP

`-d <path>` = The image or local optical drive directory path

`-l <login>` = Authorized login user to SP.

`-p <password>` = Password of the authorized login user.

`-w <port>` = Authentication port used to communicate to SP

Using the ASU to configure settings for VMware ESXi/vSphere Hypervisor

This topic describes how to use the ASU to configure settings for VMware ESXi/vSphere Hypervisor with IBM customization in IMM-based servers.

The VMware ESXi/vSphere Hypervisor supports the ASU. Because the ESXi image has no console and individual tools cannot run directly on this operating system, ASU configures the ESXi/vSphere Hypervisor image based on the CIM stack. ASU only supports IMMv1 or IMM2 systems that have the CIM stack. Make sure that the CIM server is available on the operating system before running the ASU command.

ESXi with IBM customization must synchronize the schema from IMM after the operating system starts or after the IMM firmware update. The update takes approximately 15 minutes. Do not run ASU until the schema synchronization is finished.

Using the command-line interface

Enter the following command:

```
asu command <setting_name> <connection_options>
```

Supported commands

For the ESXi/vSphere Hypervisor OS, ASU only supports three basic commands for configuration.

show: get the current setting value

set: modify the current setting value

showvalues: get the values the setting support

Note: The <setting_name> is the setting that refers to IMM, uEFI, and BootOrder. But a group name such as IMM, uEFI, or all is not supported.

Supported settings

This topic describes the supported settings for VMware ESXi/vSphere Hypervisor with IBM customization in IMM-based servers.

ASU supports three kinds of settings for VMware ESXi/vSphere Hypervisor: BootOrder settings, IMM settings, and uEFI settings.

BootOrder settings

BootOrder.BootOrder

BootOrder.WolBootOrder

IMM settings

IMM.ShutdownAndPowerOff

IMM.PowerOnServer

IMM.ShutdownAndRestart

IMM.LoginId.1

IMM.AuthorityLevel.1

IMM.Password.1

IMM.UserAccountManagementPriv.1

IMM.RemoteConsolePriv.1

IMM.RemoteConsoleDiskPriv.1

IMM.RemotePowerPriv.1

IMM.ClearEventLogPriv.1

IMM.BasicAdapterConfigPriv.1
IMM.AdapterConfigNetworkSecurityPriv.1
IMM.AdvancedAdapterConfigPriv.1
IMM.SNMPv3_AuthenticationProtocol.1
IMM.SNMPv3_PrivacyProtocol.1
IMM.SNMPv3_PrivacyPassword.1
IMM.SNMPv3_AccessType.1
IMM.SNMPv3_TrapHostname.1
IMM.User_Authentication_Method
IMM.LockoutPeriod
IMM.WebTimeout
IMM.AccountSecurity
IMM.LoginPassword
IMM.RemoteAlertRecipient_Status.1
IMM.RemoteAlertRecipient_Name.1
IMM.RemoteAlertRecipient_Email.1
IMM.RemoteAlertRecipient_IncludeEventLog.1
IMM.RetryLimit
IMM.EntriesDelay
IMM.RetryDelay
IMM.SerialRedirectionCLIMode1
IMM.SerialBaudRate
IMM.CIMOverHTTPPort
IMM.CIMOverHTTPSPort
IMM.HTTPPort
IMM.SSLPort
IMM.TelnetPort
IMM.SSHPort

IMM.SNMP_AgentPort

IMM.SNMP_TrapPort

IMM.SNMPTraps

IMM.Community_Name.1

IMM.SSL_Server_Enable

IMM.CIMXMLOverHTTPS_Enable

IMM.SSL_Client_Enable

IMM.SSH_Enable

uEFI settings in an IMMv1 system

This topic lists the uEFI settings that you can use for an IMMv1 system.

uEFI.TurboModeEnable

uEFI.ProcessorEistEnable

uEFI.ProcessorCcxEnable

uEFI.PackageCState

uEFI.ProcessorC1eEnable

uEFI.ProcessorHyperThreading

uEFI.ProcessorVmxEnable

uEFI.DdrSpeed

uEFI.MemoryChannelMode

uEFI.SpareErrorThreshold

uEFI.SocketInterleave

uEFI.PatrolScrub

uEFI.DemandScrub

uEFI.IdeMode

uEFI.VideoSelect

uEFI.RomOrder

uEFI.OnboardDeviceEnable.1

uEFI.LegacyRomExecution.1

uEFI.PCIeGenSelection.1

uEFI.SerialCOMPort1
uEFI.RemoteConsoleRedirection
uEFI.SerialPortSharing
uEFI.SerialPortAccessMode
uEFI.SPRedirection
uEFI.LegacyOptionRomPort
uEFI.Com1BaudRate
uEFI.Com1DataBits uEFI.Com1Parity
uEFI.Com1StopBits
uEFI.Com1TextEmul
uEFI.Com1ActiveAfterBoot
uEFI.Com1FlowControl
uEFI.EnergyManager
uEFI.PerformanceStates
uEFI.WatchdogTimerUefi
uEFI.WatchdogTimerUefiValue
uEFI.RebootOnNMI
uEFI.ForceLegacyVideo
uEFI.Rehook19
uEFI.ThunkSupport
uEFI.EnableLegacyPxe
uEFI.Usb20_1

uEFI settings in an IMM2 system

This topic provides information about the uEFI settings that you can use on an IMM2 system.

In the IMM2 system, ASU supports uEFI group for VMware ESXi/v Sphere Hypervisor with IBM customization. To get the list, use the following ASU command:

```
asu.exe showvalues uefi --host <OS_ip> --user root --password <OS_password> --vmware-esxi
```

You can also get the list using the command `asu show uefi <connection_options>` in a Windows or Linux operating system of your current IMM2 system.

Notes

1. The settings listed above are all supported through the ESXi CIM stack. However, some IMMv1 or IMM2 systems might not have all of the settings above. Some settings might not be supported by different systems.
2. ASU ESXi support is limited:
 - Only three commands are supported. Other ASU commands like **showdefault**, **loaddefault**, and **showgroups** are still not supported.
 - ASU only supports a uEFI group on IMM2-based systems; no other groups or subgroups are supported.
 - There is no support for setting attributes. Some settings have dependency or are read-only, but ASU ESXi support cannot check it. If you try to modify read-only settings, some might fail and some might set successfully, but cannot take effect on IMM/uEFI systems.
3. Some of the above settings have instance IDs; for example IMM.LoginId.1, where 1 is a positive integer instance ID. Generally, the instance ID "1" is the default, and you can configure it.

Table 1. Connection options for ESXi/vSphere Hypervisor image

Parameter	Required	Description
--host <OS ip>	Yes	ESXi/vSphere Hypervisor image IP address. Both IPv4 and IPv6 are supported.
--user root	Yes	ESXi/vSphere Hypervisor image user, need root here
--password <OS_password>	Yes	Password for root user
--vmware-esxi [http]	--vmware-esxi is required, while [http] is optional	If [http] is not specified, ASU uses https to connect to the ESXi/vSphere Hypervisor image.
--port <port>	Optional	The connection port; the default port for https is 5989.

Command example

```
asu.exe show <setting_name> --host <OS_ip> --user root --password <OS_password> --vmware-esxi
asu.exe set <setting_name> <setting_value> --host <OS_ip> --user root --password <OS_password> --vmware-esxi
asu.exe showvalues <setting_name> --host <OS_ip> --user root --password <OS_password> --vmware-esxi
```

Known limitations

This topic lists all of the known limitations.

1. RDCLI only supports ISO/CDROM/DVDROM as the mount source.
2. RDCLI does not support non-IMM systems.
3. Limitations on system settings (x3755 M3 type 7164):
 - Settings are read-only:
 - BMC_User02LAN_Priv
 - BMC_User02Serial_Priv
 - BMC_User02Name
 - BMC_NetworkMACAddress
 - Settings are dependent on other settings:
 - BMC_NetworkIPAddress

- BMC_NetworkIPSubnetMask

These two settings can be set only after BMC_NetworkIPAddrSource is set to "Static Address."

- Settings need proper value:

- BMC_NetworkIPDefaultGateway
- BMC_NetworkIPBackupGateway

Value of these settings must follow the same pattern as BMC_NetworkIPAddress and BMC_NetworkIPSubnetMask

- After configuration, you must wait one second for settings to take effective.
 - BMC_NetworkIPAddress
 - BMC_NetworkIPSubnetMask
 - BMC_NetworkIPDefaultGateway

- BMC_NetworkIPAddrSource only supports DHCP/Static Address/Other

4. ASU certificate management does not support system list below:

x3755 M3 Type 7164

5. ASU does not support the **loaddefault** value for the boot order on IMM-based systems. The **loaddefault** command does not change the boot order to the default value.
6. ASU does not check if the value to set is NULL or a valid one when set IMM.RemoteAlertRecipient_Email.1 on ESXi.
7. In Flex system, there are two types of user accounts due to security design: CMM user (LDAP user) and IMM2 user (local user). CMM users are available for Web, CLI, and CIM interfaces. IMM2 users are available for IPMI and SNMPv3 interfaces. Generally, ASU needs a IMM2 user to work on IMM, but it needs a CMM user in FoD key management if **--device CMM** or **--interface CIM** is specified.
8. On ESXi, ASU successfully sets uEFI.LegacyRomExecution, but this does not take effect after uEFI synchronization when the operating system is rebooted.
9. On an OEM IMM2 system, some of uEFI settings, which are dependent on other settings, can be set by ASU. However, this does not take effect after uEFI synchronization when the operating system is rebooted.
10. On the Windows operating system, if you have uninstalled the NDIS Network driver, then use the ASU command **asu immcfg-detect driver** to detect the driver status. The NDIS Network driver will be installed automatically, and the detect result would be the driver that is installed already.
11. After ASU sets some IMM network settings, which might lead to an IMM IP address change or ASU connection close, ASU might fail to get set result.

Chapter 2. Using the command-line interface

This section describes how to use the Advanced Settings Utility (ASU) command-line interface.

Command syntax

Before using the command-line interface, read the following guidelines.

- Each command has the following format:
`asu [application] [command [command_modifier] | [class]]
[options] [connect_options]`
- Each command starts with `asu` or `asu64`.
- The optional configuration application can be either of the following options (see Command configuration applications):
 - `savestat`
 - `immcfg`
 - `fodcfg`
 - `cmmcfg`
 - `immapp`
- `command` is one of the commands that is listed in the Command reference.
- `command_modifier` is one or more options that apply only to a certain command. These are considered command modifiers or extensions. Each command modifier must be preceded by a double hyphen (`--`). (See Command modifiers.)
- `class` is a filter that acts on a listing of settings (settings display filters). A class is not considered a modifier or option. Classes are also used to operate a command upon a group or class of settings. A class does not require the double hyphen (`--`) as part of the syntax. For more information about a class, see Classes of settings.
- `option` is one or more general options that globally apply to the operation. Each option requires the preceding double hyphen (`--`) as part of its syntax. (See Command general options.)
- `connect_option` is one or more parameters that are related to the ASU connection to the IMM. Connect options are defined as options. Each requires the double hyphen (`--`) as part of its syntax. (See Command connectivity options.)
- Brackets (`[]`) indicate that an application, option, or class is optional. Brackets are not part of the command that you type.

Command configuration applications

This topic explains the additional configuration applications integrated by the ASU.

The following applications are included in the ASU:

- `savestat`
- `immcfg`
- `fodcfg`
- `cmmcfg`
- `immapp`

The following sections describe each of the applications and outline the command syntax and structure.

Savestat

The savestat application is used by the scripting toolkit to save and restore the state information about the system. This function is supported for both IMM-based servers and some BIOS-based servers. The use cases for these are identical, other than the following differences:

- A file called savestat.def is used for BIOS-based servers. It is supplied in the scripting toolkit run environment.
- Using savestat on IMM-based servers might require additional connectivity parameters because the data is in the IMM on the server.

savestat write data example:

```
asu savestat write datafile
```

This command uses the contents of the datafile file to update the persistent storage contents.

savestat read data example:

```
asu savestat read datafile
```

This command reads the contents of the persistent storage and writes the results to the datafile file. The file is created if it does not already exist. If the file already exists, it is overwritten.

Configuring the IMM LAN over USB interface

This topic describes how to install and configure the LAN over USB interface that is used to communicate with the IMM.

The ASU provides the ability to install and configure the LAN over USB interface that is used to communicate with the IMM as an add-on configuration application called immcfg. The command syntax is:

```
asu immcfg [application_commands]
```

The supported commands and the operating systems for which these are available are listed in Table 1.

The additional files that are required to perform these commands are included with the ASU package. The following required files must be in the directory from which the ASU is run.

Windows:

```
ibm_rndis_server_os.inf  
device.cat
```

Linux:

```
cdc_interface.sh
```

Table 2. IMM LAN over USB configuration application commands

Configuration application command	Description	Operating system support	Command syntax to set the command
setip	Sets the operating system IP address for the LAN over USB interface	Windows only	asu immcfg --setip
detectdevice	Detects whether the IMM LAN over USB interface is activated	Windows only	asu immcfg --detectdevice
installdriver	Installs the IMM LAN over USB device driver	Windows only	asu immcfg --installdriver [--inf inf_path/name]
detectdriver	Detects whether the device driver for the IMM LAN over USB interface is installed in the operating system	Windows only	asu immcfg --detectdriver
autocfgdhcp	Automatically detects the presence of the IMM LAN/USB device, installs the required device driver, and delegates to IMM to assign IP address to the OS USB-LAN interface.	Windows Linux VMware	asu immcfg --autocfgdhcp
autocfgstatic	Auto configures the IMM LAN/USB device using all default settings. Default settings include: Packaged INF/CAT and .SH files Default IP addresses: 169.254.95.120 for the OS IP Address. Note: Assumes 169.254.95.118 as the IMM IP address. For multinode, the primary node is always assigned 169.254.95.120, the secondary node is 169.254.96.120, and all other must follow this pattern.	Windows Linux VMware	asu immcfg --autocfgstatic

Table 2. IMM LAN over USB configuration application commands (continued)

Configuration application command	Description	Operating system support	Command syntax to set the command
disable-imm-lan	Takes down the IMM USB LAN. 1) For Windows it disables the LAN interface with Windows API, unsets IP(SetupDiChangeState). 2) for Linux/VMware, it calls the ifdown and unset IP, removes the configuration file in the Linux cdc_interface.sh.	Windows Linux VMware	asu immcfg --disable-imm-lan Note: This case is for inband only. This parameter is also available when you try to operate a normal ASU command like: asu show all --disable-imm-lan It also disables the LAN interface after the command is done.

Note: On Windows platform, automatically install LAN over USB device driver or install driver by ibm_rndis_server_os.inf, which only supports these operating systems: Windows XP SP2, Windows XP x64, Windows Server 2003 SP1, and Windows Vista.

Feature on Demand configuration

This topic describes Feature on Demand configuration (fodcfg) management which is supported by ASU.

Fodcfg is used to acquire, install, uninstall, report, and export activation keys from the key repository. Fodcfg supports the hardware devices as key repositories:

- IMM2 based systems including, System x Server
- CMM
- IOM (I/O Module) switches

For different devices, fodcfg supports three different interfaces: IPMI, CIM, and SNMP. Below is a matrix for supported devices and interfaces. The check means that the device supports the interface. IPMI interface here means IPMI through LAN or LAN-over-USB. KCS is the IPMI interface using local keyboard controller style.

Table 3. Supported devices and interfaces

	IPMI	KCS	CIM	SNMP
IMM	√	√	√	
CMM			√	
Switch				√

Command syntax

asu fodcfg <command> [options] [command options] [device&interface] [connection options]

Commands

Table 4. Commands

Command	Description
acquirekey	Acquire and download the activation key from the IBM web site.
installkey	Install activation keys from the user-specified location to the key repository.
uninstallkey	Uninstall activation keys from the device.
reportkey	Inventory information of a specified key repository.
exportkey	Export activation keys from a specific key store.

Table 5. Options

Option	Description
--help	Display this help in the console window and exit. This command is the same as running with no parameters.
--disable-imm-lan	Disable the USB LAN interface on an IMM system.
[command options]:	
Acquirekey command	
-m <MT/DC>	For the system/option feature, specify the system machine type (MT) here. For the IOM switch, specify device code (DC).
-u <unique id>	Unique identifier information
-d <dir>	Download the key file to <dir> location.
-r	Install the downloaded activation key.
--ibmid <userid:pwd>	IBM ID credential for the interactive IBM web site
--auth <code>	IBM authorization code
Installkey command:	A single activation key file. Fodcfg installs a single activation key file
-f <keyfilename dir>	
Uninstallkey command:	Activation key ID returned from the report command. If keyid is "all," uninstall all keys.
--keyid <keyid>	
Note: Some devices must follow rules to install and uninstall activation keys; "--keyid all" might not work correctly. Uninstall the (Upgrade 2) key first, and then (Upgrade 1). See device documents for the key management operation rules.	
Reportkey command:	
None	
Exportkey command:	Activation key ID returned from the report command. If keyid is "all", export all keys.
--keyid <keyid>	
-d <dir>	Download the key file to <dir> location. The default value is the current folder.
[device&interface]:	
Support device: IMM, CMM, Switch.	
--device <device>	
--interface <interface>	Support interface: ipmi, kcs, cim, snmp.

Table 5. Options (continued)

Option	Description
Note: If a device is specified, the default interface value is all supported interfaces by the device. If an interface is specified, the default device value is the device that supports this interface. If neither are specified, the default device is IMM.	
[connection options]:	
--host <IP>	Remote key repository. The default is the local IMM device.
--user <userid>	Key repository credential user name
--password <password>	Password of the key repository
--cimhttp	Use http for the cim interface.
--port <port>	Port for the cim interface. The default is 5989.
--tftp <IP:port>	Tftp server for the snmp interface
--sftp <IP:port>	Sftp server for the snmp interface
--ftpid <user:password>	Ftp credential ID for snmp interface
--community <community>	Community for snmpv1v2. The default is public
--authproto <MD5/SHA>	Authorization protocol for snmpv3. The default is no auth.
--privproto <DES/AES>	Privacy protocol for snmpv3. The default is No privacy.
--privpasswd <password>	Privacy password. The default is None.

Command sample

```
asu.exe fodcfg installkey -f .\ibm_fod_7870abcdefg_anyos.key --host 10.10.10.1
```

Using the address 10.10.10.1, install the activation key
ibm_fod_7870abcdefg_anyos.key on the default device IMM.

```
asu.exe fodcfg uninstallkey --keyid b2e61a48881917af --host 10.10.10.1  
--user USERID --password PASSWORD --device cmm --interface cim
```

Using the address 10.10.10.1 through the cim interface, uninstall the activation key
b2e61a48881917af in CMM.

```
asu.exe fodcfg uninstallkey --device switch --keyid all --user abc  
--password abc123 --authproto MD5 --tftp 9.125.90.179:69 --host 9.125.90.190
```

Using the address 9.125.90.190 through the snmp interface, uninstall all the
activation keys in the switch.

Note: The ASU fodcfg application needs an extra TFTP/SFTP server to run on switches using the snmp interface. Make sure that you have both write and read access for the TFTP/SFTP server. The ASU fodcfg application supports both snmp v1v2 and snmp v3. Make sure that the switch is properly configured and that you have the authority to perform operations on the switch.

FoD key management on different devices

This topic explains how to manage Feature on Demand keys installed on different devices.

IMM2-based systems including System x Server

Multiple interfaces are supported for the IMM-based system. If no interface (`--interface`) is specified, ASU tries to use CIM. If no interface (`--interface`) is specified and the CIM fails, try to run the IPMI interface. It runs the KCS interface. However, if `--host`, `--user`, or `--password` is specified, ASU does not try the KCS interface.

ASU supports FoD key management in-band when `--host` is not specified. First, ASU tries to get the IP address for the LAN-over-USB. The default values for `--user` and `--password` are `USERID` and `PASSWORD`, respectively. ASU defaults to KCS if LAN-over-USB fails.

ASU supports work on the CIM interface by connecting with HTTP and HTTPS. By default, ASU tries to connect with HTTPS, and the default port is 5989. You can specify `--cimhttp` to try the connection with HTTP, and then also specify `--port 5988`, which is the port for HTTP. Before running ASU, configure the IMM correctly.

CMM

Only the CIM interface is supported on CMM; no in-band methods are available. You must enter `--host` for CMM management. The default values for `--user` and `--password` are `USERID` and `PASSWORD`, respectively.

ASU supports both HTTP and HTTPS. You can use the CIM interface on a CMM device the same as on an IMM device. Before running ASU, make sure that the CMM CIM interface is configured correctly.

IOM switches

The IOM switch is designed to use SNMP for FoD activation key management, and needs additional TFTP/SFTP server for key file transactions. You must prepare TFTP/SFTP before running the ASU command for FoD management on the IOM switch. In the command line, `--tftp <IP:port>` is for TFTP, while `--sftp <IP:port>` and `--ftpid <user:password>` are for SFTP. Make sure that you have both read and write access for TFTP/SFTP. You do not need to do operations on TFTP/SFTP server directory; ASU automatically uploads and downloads keys and files.

ASU supports both SNMPv1v2 and SNMPv3. You do not need to specify `--user` and `--password` for SNMPv1v2. However, if `--user` and `--password` are specified, ASU tries to run SNMPv3 with the `snmp` user and authorization password first, then defaults to SNMPv1v2 if SNMPv3. `--privproto` and `--privpasswd` are for SNMPv3 privacy encryption. Before running ASU, make sure that the configuration on the IOM switch for the SNMP interface is correct.

Note: ASU supports both SNMPv1v2 and SNMPv3. To use the correct one, make sure that both the interface and the IOM switch are supported.

The current ASU FoD operation on switches is only support on IPv4. IPv6 will be supported in a future release.

Getting the key from the IBM web site

This topic explains how to generate and download activation keys from the IBM web site using the ASU command line utility without logging onto the web site.

On the IBM web site, enter information in the **Command options** field.

Table 6. Command options parameters

Parameter	Required	Description
--ibmid <userid:pwd>	Yes	The IBM ID credential for the interactive IBM web site.
-u <unique id>	Yes	Unique identifier information.
-m <MT/DC>	Yes	The machine type/device code. For the system/option feature, specify the system machine type (MT). For the IOM switch, specify the device code (DC).
--auth <code>	Optional	The IBM authorization code. If no authcode is provided, ASU gets the key without generating it.
-d <dir>	Optional	Download the key file to <dir> location. The default value is the current folder.
-r	Optional	Install the downloaded activation key.

Values “-u” and “-m” specify the system information. Value “-u” is a unique identifier and “-m” is the system server type or switch device code. To get the keys that are installed on the IMM/CMM, enter the server type “-m.” For the switch keys, enter the device code. The available switch device codes are shown below.

When no authorization code is entered, ASU downloads the keys for that system directly. If “--auth” is specified, ASU tries to generate and then download the keys for that system using the authorization code.

You can specify “-r” using the **acquirekey** command to generate and download keys and install them automatically. If “-r” is not specified, ASU gets the key and puts it in the local folder without installing it. To install the key automatically, you must specify both [device&interface] and [connection options].

Table 7. Available switch device codes

Feature description	Install on system	Device code	Unique ID format
IBM Flex System Fabric EN4093 10Gb Scalable Switch (Upgrade 1)	IBM Flex System Enterprise Chassis[8721]	FCA1EL	IBM Switch Serial Number(12 characters)
	IBM Flex System Enterprise Chassis[7893]	FC3597	

Table 7. Available switch device codes (continued)

Feature description	Install on system	Device code	Unique ID format
IBM Flex System Fabric EN4093 10Gb Scalable Switch (Upgrade 2)	IBM Flex System Enterprise Chassis[8721]	FCA1EM	IBM Switch Serial Number(12 characters)
	IBM Flex System Enterprise Chassis[7893]	FC3597	
IBM Flex System EN2092 1Gb Ethernet Scalable Switch (Upgrade 1)	IBM Flex System Enterprise Chassis[7893]	FC3599	IBM Switch Serial Number(12 characters)
	IBM Flex System Enterprise Chassis[8721]	FCA1QW	
IBM Flex System EN2092 1Gb Ethernet Scalable Switch (10Gb Uplinks)	IBM Flex System Enterprise Chassis[8721]	FCA1EN	IBM Switch Serial Number(12 characters)
	IBM Flex System Enterprise Chassis[7893]	FC3594	
IBM Flex System IB6131 Infiniband Switch (FDR Upgrade)	IBM Flex System Enterprise Chassis[8721]	FCA1QX	Switch Serial Number(19 characters)

Chassis Management Module configuration

This topic describes Chassis Management Module (CMM) configuration management that is supported by ASU.

CMM is the management module for the Flex System chassis. ASU supports CMM configuration in ASU version 9.30 or later.

Command syntax

asu cmmcfg <command>[setting name] [setting options] [options] [connection options]

Commands

Table 8. Commands

Command	Description
list	Show all subsettings of the specified setting, and the support operation commands for each setting in list view. If the setting name is not specified, show all the setting names and the support commands for each setting name.
showtree	Show all subsettings of the specified setting, and the support operation commands for each setting in tree view. If the setting name is not specified, show all the setting names and the support commands for each setting name.
help	Display detail information about the specify setting.
show	Show the value of the specified setting.
set	Set the value for the specified setting.
showvalues	Show all the possible values for the specified setting.

Table 8. Commands (continued)

Command	Description
showdefault	Show the default value for the specified setting.
loaddefault	Load default values for the specified setting.
delete	Delete the specified setting.
import	Import local file to CMM.
export	Export file from CMM to local.
reboot	Restart the CMM.
reset	Reset the CMM to defaults and reboot.
enum	Enumerate all attached CMM.
Note: List, showtree and help commands are used to display supported setting information. You can run them to get all the settings' format and description, so every setting supports these three commands. These commands are not operation commands for CMM, so you do not need to connect to CMM while running them. Connection options are also not required.	

<setting name>

Setting name is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

Table 9. Options

Option	Description
--help	Display this help in the console window and exit.

Table 10. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

CMM settings and commands supported

```

CMM<xx>:[Reboot,Reset]
CMM<xx>.Account:[Show]
CMM<xx>.Account.@<UserID>:[Delete]
CMM<xx>.Account.@<UserID>.Password:[Set,ShowValues]
CMM<xx>.Configuration:[Export,Import,ShowValues]
CMM<xx>.Firmware:[Show]
CMM<xx>.Network
CMM<xx>.Network.HostName:[Set,Show,ShowValues]
CMM<xx>.Network.DomainName:[Set,Show,ShowValues]
CMM<xx>.Network.DNS
CMM<xx>.Network.DNS.DDNS:[Set,Show,ShowValues]
CMM<xx>.Network.DNS.State:[Set,Show,ShowValues]
CMM<xx>.Network.DNS.IPv4Address:[Set,Show,ShowValues]
CMM<xx>.Network.DNS.IPv6Address:[Set,Show,ShowValues]
CMM<xx>.Network.DNS.IPv6Preferred:[Set,Show,ShowValues]
CMM<xx>.Network.IPv4:[Show]
CMM<xx>.Network.IPv4.StaticAddress:[Set,Show,ShowValues]
CMM<xx>.Network.IPv4.StaticSubnetMask:[Set,Show,ShowValues]
CMM<xx>.Network.IPv4.StaticDefaultGateway:[Set,Show,ShowValues]
CMM<xx>.Network.IPv4.AssignAddressMethod:[Set,Show,ShowValues,ShowDefault,LoadDefault]
  
```

```

CMM<xx>.Network.IPv6:[Show]
CMM<xx>.Network.IPv6.State:[Show,ShowValues]
CMM<xx>.Network.IPv6.Auto:[Set,Show,ShowValues]
CMM<xx>.Network.IPv6.DHCP:[Set,Show,ShowValues]
CMM<xx>.Network.IPv6.Static:[Set,Show,ShowValues]
CMM<xx>.Network.IPv6.StaticAddress:[Set,Show,ShowValues]
CMM<xx>.Network.IPv6.StaticDefaultGateway:[Set,Show,ShowValues]
CMM<xx>.Network.IPv6.StaticSubnetPrefixLength:[Set,Show,ShowValues]
CMM<xx>.Network.Ethernet:[Show]
CMM<xx>.Security
CMM<xx>.Security.Policy:[Set,Show,ShowValues]
CMM<xx>.Security.LdapClient:[Set,Show,ShowValues]
CMM<xx>.Security.SshServer:[Show,ShowValues]
CMM<xx>.Security.LdapTrustedCert:[Show,Delete,Import,Export,ShowValues]
CMM<xx>.Chassis:[Show]
CMM<xx>.Chassis.Name:[Set,Show,ShowValues]
CMM<xx>.Chassis.Room:[Set,Show,ShowValues]
CMM<xx>.Chassis.Rack:[Set,Show,ShowValues]
CMM<xx>.Chassis.Location:[Set,Show,ShowValues]
CMM<xx>.Chassis.UnitHeight:[Show,ShowValues]
CMM<xx>.Chassis.LowestRackUnit:[Set,Show,ShowValues]
CMM<xx>.Properties
CMM<xx>.Properties.General
CMM<xx>.Properties.General.ModuleName:[Show,ShowValues]
CMM<xx>.Properties.DateTime
CMM<xx>.Properties.DateTime.AutoDST:[Set,Show,ShowValues]
CMM<xx>.Properties.DateTime.SyncMethod:[Set,Show,ShowValues,ShowDefault,LoadDefault]
CMM<xx>.Properties.DateTime.Date:[Set,Show,ShowValues]
CMM<xx>.Properties.DateTime.Time:[Set,Show,ShowValues]
CMM<xx>.Properties.DateTime.SyncFrequency:[Set,Show,ShowValues]
CMM<xx>.Properties.DateTime.NTPServer:[Set,Show,ShowValues]
CMM<xx>.Properties.DateTime.NTPv3Auth:[Set,Show,ShowValues]
CMM<xx>.Properties.DateTime.NTPv3KeyIndex:[Set,Show,ShowValues]
CMM<xx>.Properties.DateTime.NTPv3KeyData:[Set,Show,ShowValues]
CMM<xx>.Properties.DateTime.GMTOffset:[Set,Show,ShowValues,ShowDefault,LoadDefault]

```

Note: The setting name is composed by node name separated by a comma. You do not need to type the <> tag in node name, and the value between it is user-inputted, which means number from 0 to 9 or userid like USERID. The count of char x represents the numbers required for input. For example: cmm01.account.@user.password. All the settings support these three commands: list, showtree and help.

List CMM settings

You use ASU to list all sub settings of the specified CMM setting and the support operation commands for each setting. If the setting name is not specified, list all the setting names and support commands for each setting name.

List command is not an operation command. You do not need to connect CMM to run it. All the settings are supported by this command.

Command syntax

```
asu cmmcfg list [setting name] [options]
```

Command

```
<setting name>
```

Setting name is an option parameter for the list command. It is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

Table 11. Options

Option	Description
--help	Display this help in the console window and exit.

Command example

```
C:\asu>asu.exe cmmcfg list cmm01 --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Discription:
    Setting name is composed by node name below separated by '.'
Example:
    cmm01.account.@user.password
    cmm01.network.dns.ipv4address1
Using 'enum' command to show all attached cmm.
    The <> tag in node name doesn't need to be typed, and the value between it
    needs user input which means number form '0' to '9' or userid like 'USERID'.
    The count of char 'x' stand for how many numbers need to input.
*****
CMM<xx>:[Reboot,Reset]
CMM<xx>.Account:[Show]
CMM<xx>.Account.@UserID:[Delete]
CMM<xx>.Account.@UserID.Password:[Set,ShowValues]
CMM<xx>.Configuration:[Export,Import,ShowValues]
CMM<xx>.Firmware:[Show]
CMM<xx>.Network
CMM<xx>.Network.HostName:[Set,Show,ShowValues]
CMM<xx>.Network.DomainName:[Set,Show,ShowValues]
CMM<xx>.Network.DNS
CMM<xx>.Network.DNS.DDNS:[Set,Show,ShowValues]
CMM<xx>.Network.DNS.State:[Set,Show,ShowValues]
CMM<xx>.Network.DNS.IPv4Address<x>:[Set,Show,ShowValues]
.....
Command executed successfully
```

List CMM settings in a tree-like format

You use ASU to list all sub settings of the specified CMM setting and the support operation commands for each setting in a tree-like format. If the setting name is not specified, list all the setting names and support commands for each setting name.

Showtree command is not an operation command. You do not need to connect CMM to run it. All the settings are supported by this command.

Command syntax

```
asu cmmcfg showtree [setting name] [options]
```

Command

```
<setting name>
```

Setting name is an option parameter for the list comment. It is in the format of xx.xx.xx, which can be shown by list or showtree command.

Table 12. Options

Option	Description
--help	Display this help in the console window and exit.

Command example

```
C:\asu>asu.exe cmmcfg showtree cmm01 --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Discription:
    Setting name is composed by node name below separated by '.'
Example:
    cmm01.account.@user.password
    cmm01.network.dns.ipv4address1
Using 'enum' command to show all attached cmm.
    The <> tag in node name doesn't need to be typed, and the value between it
    needs user input which means number form '0' to '9' or userid like 'USERID'.
    The count of char 'x' stand for how many numbers need to input.
*****
|-CMM<xx>: [Reboot,Reset]
    |-Account: [Show]
        |-@<UserID>: [Delete]
            |-Password: [Set,ShowValues]
        |-Configuration: [Export,Import,ShowValues]
        |-Firmware: [Show]
        |-Network
            |-HostName: [Set,Show,ShowValues]
            |-DomainName: [Set,Show,ShowValues]
            |-DNS
                |-DDNS: [Set,Show,ShowValues]
                |-State: [Set,Show,ShowValues]
                |-IPv4Address<x>: [Set,Show,ShowValues]
                |-IPv6Address<x>: [Set,Show,ShowValues]
                |-IPv6Preferred: [Set,Show,ShowValues]
            |-IPv4: [Show]
                |-StaticAddress: [Set,Show,ShowValues]
        .....
Command executed successfully.
```

Display help information for CMM setting

You can use ASU to display detail information about the specific CMM setting.

The Help command is not an operation command. You do not need to connect CMM to run it. All the settings are supported by this command.

Command syntax

```
asu cmmcfg help <setting name> [options]
```

Command

```
<setting name>
```

Setting name is in the format of xx.xx.xx, which can be shown by list or showtree command.

Table 13. Options

Option	Description
--help	Display this help in the console window and exit.

Command example

```
C:\asu>asu.exe cmmcfg help cmm01
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Description:
```

This setting name is used to config the CMM.
Supported commands for this setting name:

help	Display this help message
list	Show all subsettings of the specified setting name in list view
showtree	Show all subsettings of this setting group in tree view
enum	Enumerate all attached CMM
reboot	Reboot the CMM
reset	Reset the CMM to defaults and reboot

Show CMM setting

You can use ASU to show the current value for the specified CMM setting.

Command syntax

```
asu cmmcfg show <setting name> [options] [connection options]
```

Command

<setting name>

Setting name is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

Table 14. Options

Option	Description
--help	Display this help in the console window and exit.

Table 15. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg show cmm01.network.ipv4.staticaddress --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
cmm01.network.ipv4.staticaddress=9.1115.252.27
```

Set CMM setting

You can use ASU to apply a value to a CMM setting.

Command syntax

```
asu cmmcfg set <setting name> <value> [options] [connection options]
```

Command

<setting name>

Setting name is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

<value>

Specify the value to set.

Table 16. Options

Option	Description
--help	Display this help in the console window and exit.

Table 17. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg set cmm01.network.ipv4.staticaddress 9.115.252.27 --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
cmm01.network.ipv4.staticaddress=9.115.252.27
This setting will take effect after the CMM restart.
```

Show possible values for CMM setting

You can use ASU to show the possible values for the specified CMM setting.

Command syntax

```
asu cmmcfg showvalues <setting name> [options] [connection options]
```

Command

<setting name>

Setting name is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

Table 18. Options

Option	Description
--help	Display this help in the console window and exit.

Table 19. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg showvalues cmm01.Network.DNS.State --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
cmm01.Network.DNS.State=Enabled=Disabled
```

Show default value for CMM setting

You can use ASU to show the default value for the specified CMM setting.

Command syntax

```
asu cmmcfg showdefault <setting name> [options] [connection options]
```

Command

<setting name>

Setting name is in the format of xx.xx.xx, which can be shown by list or showtree command.

Table 20. Options

Option	Description
--help	Display this help in the console window and exit.

Table 21. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	Key repository credential user name. The default is USERID.
--password <password>	CMM user name to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg showdefault cmm01.Network.Ipv4.AssignAddressMethod --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
cmm01.Network.Ipv4.AssignAddressMethod=DHCP Then Static
```

Load default value for CMM setting

You can use ASU to load the default value for the specified CMM setting.

Command syntax

```
asu cmmcfg loaddefault <setting name> [options] [connection options]
```

Command

<setting name>

Setting name is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

Table 22. Options

Option	Description
--help	Display this help in the console window and exit.

Table 23. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg loaddefault cmm01.Network.Ipv4.AssignAddressMethod--host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
cmm01.Network.Ipv4.AssignAddressMethod=DHCP Then Static
```

Delete CMM setting

You can use ASU to delete a specified CMM setting.

Command syntax

```
asu cmmcfg delete <setting name> [options] [connection options]
```

Command

<setting name>

Setting name is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

Table 24. Options

Option	Description
--help	Display this help in the console window and exit.

Table 25. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg delete cmm01.Account.@ASUTEST --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
cmm01.Account.@ASUTEST is deleted.
Command executed successfully.
```

Import local file to CMM

You can use ASU to import a local file to CMM.

Command syntax

asu cmmcfg import <setting name> [options] [connection options]

Command

<setting name>

Setting name is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

Table 26. Options

Option	Description
--help	Display this help in the console window and exit.

Table 27. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg import
cmm01.configuration sftp://user:password@9.115.234.91:63/cfgabc.txt@Passw0rd
--host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-2012 All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
Started to import configuration file from
sftp://user:password@9.115.234.91:63/cfgabc.txt@Passw0rd
Still running 0.....
Still running 1.....
Still running 2.....
Still running 3.....
Finished to import configuration file to
sftp:// user: password@9.115.234.91:63/cfgabc.txt@Passw0rd
```

Export file from CMM

You can use ASU to export a file from CMM to your local system.

Command syntax

asu cmmcfg export <setting name> [options] [connection options]

Command

<setting name>

Setting name is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

Table 28. Options

Option	Description
--help	Display this help in the console window and exit.

Table 29. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg export cmm01.configuration
sftp://user:password@9.115.234.91:63/cfgabc.txt@Passw0rd --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-2012 All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
Started to export configuration file to
sftp://user:password@9.115.234.91:63/cfgabc.txt@Passw0rd
Still running 0.....
Still running 1.....
Still running 2.....
Finished to export configuration file to
sftp://user:password@9.115.234.91:63/cfgabc.txt@Passw0rd
```

Reboot CMM

You can use ASU to reboot the CMM.

Command syntax

```
asu cmmcfg reboot <setting name> [options] [connection options]
```

Command

<setting name>

Setting name is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

Table 30. Options

Option	Description
--help	Display this help in the console window and exit.

Table 31. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg reboot cmm01 --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
Issuing reboot command to CMM.
Checking if the CMM has reboot yet. (attempt 0)
CMM has started the reboot.
Disconnect from CMM
Wait for about x mins to let the CMM complete reboots.
Checking if CMM CIM interface is ready. (attempt 0)
Connected to CMM at IP address 10.10.10.1
Reboot completed successfully.
```

Reset CMM to default

You can use ASU to reset the CMM to default and reboot.

Command syntax

```
asu cmmcfg reset <setting name> [options] [connection options]
```

Command

<setting name>

Setting name is in the format of CMM<0x>.xx.xx, which can be shown by list or showtree command.

Table 32. Options

Option	Description
--help	Display this help in the console window and exit.

Table 33. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg reset cm01 --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
Issuing reset command to CMM.
Checking if the CMM has reset yet. (attempt 0)
CMM has started the reset.
Disconnect from CMM
Wait for about x mins to let the CMM complete reset.
Checking if CMM CIM interface is ready. (attempt 0)
Connected to CMM at IP address 10.10.10.1
Reset completed successfully.
```


Enumerate attached CMM

You can use ASU to enumerate all attached CMMs.

Command syntax

```
asu cmmcfg enum [options] [connection options]
```

Command

Table 34. Options

Option	Description
--help	Display this help in the console window and exit.

Table 35. Connection options

Connection option	Description
--host <ip>	Address of the CMM server to operate on.
--user <userid>	CMM user name to authenticate. The default is USERID.
--password <password>	CMM password to authenticate. The default is PASSWORD.
--port <port>	Port for the CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe cmmcfg enum --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20xx All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
CMM[1]=cmm01
Name=SN#Y030BG16802L
Role=Primary
```

Note: The enumerate command also describes which CMM is primary and which one is secondary.

IMM application configuration

This topic describes IMM application configuration (immapp) that is supported by ASU.

Immapp is the application for IMM configuration, which is supported by ASU version 9.30 or later. It is used to power on, power off, and reboot the operating system (OS). You can also use immapp to report the OS status and show and clear the OS event log and IMM log.

Note: Immapp only supports IMM based systems. For CIM interface, both http and https are supported.

Command syntax

```
asu immapp <command> [options] [command options] [connection options]
```

Commands

Table 36. Commands

Command	Description
powerstate	Display the current Host OS power state of the server.
poweron	Power on the server Host OS.
poweroff	Power off the server Host OS.
reboot	Reboot the server Host OS.
clearsel	Clear the system event log.
showsel	Display the system event log.
clearimmlog	Clear the IMM event log.
showimmlog	Display the IMM event log.
clearalllog	Clear the IMM event log and system event log.

Table 37. Command options

Option	Description
--help	Display help information for commands and exit without executing command.

Table 38. Connection options

Connection option	Description
--host <ip>	Address of the IMM server to operate on.
--user <userid>	IMM user name to authenticate. The default is USERID.
--password <password>	IMM password to authenticate. The default is PASSWORD.
--kcs	Force to use IPMI over KCS local interface.
--cimhttp	Use http for CIM interface. The default is https.
--port <port>	Port for the IMM interface. The default is 5989.

Check the host OS power status

You can use the ASU command line to display the power state of the remote system host OS.

Command syntax

```
asu immapp powerstate [command options] [connection options]
```

Command

Table 39. Options

Option	Description
--help	Display help information for commands and exit without executing command.

Table 40. Connection options

Connection option	Description
--host <ip>	Address of the IMM server to operate on.
--user <userid>	IMM user name to authenticate. The default is USERID.

Table 40. Connection options (continued)

Connection option	Description
--password <password>	IMM password to authenticate. The default is PASSWORD.
--kcs	Force to use IPMI over KCS local interface.

Command example

```
C:\asu>asu.exe immapp powerstate --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-2012 All Rights Reserved
Connected to IMM at IP address 10.10.10.1
Server Power is currently On!
```

Power on the host OS

You can use the ASU command line to power on the remote system host OS.

Command syntax

```
asu immapp poweronos [command options] [connection options]
```

Command

Table 41. Options

Option	Description
--help	Display help information for commands and exit without executing command.

Table 42. Connection options

Connection option	Description
--host <ip>	Address of the IMM server to operate on.
--user <userid>	IMM user name to authenticate. The default is USERID.
--password <password>	IMM password to authenticate. The default is PASSWORD.
--kcs	Force to use IPMI over KCS local interface.

Command example

```
C:\asu>asu.exe immapp poweronos --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20nn All Rights Reserved
Connected to IMM at IP address:10.10.10.1
Server is powered on.
```

Power off the host OS

You can use the ASU command line to power off the remote system host OS.

Command syntax

```
asu immapp poweroffos [command options] [connection options]
```

Command

Table 43. Options

Option	Description
--help	Display help information for commands and exit without executing command.

Table 44. Connection options

Connection option	Description
--host <ip>	Address of the IMM server to operate on.
--user <userid>	IMM user name to authenticate. The default is USERID.
--password <password>	IMM password to authenticate. The default is PASSWORD.
--kcs	Force to use IPMI over KCS local interface.

Command example

```
C:\asu>asu.exe immapp poweroffos --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20nn All Rights Reserved
Connected to IMM at IP address:10.10.10.1
Server is powered off.
```

Clear the system event log

You can use the ASU command line to clear the remote system IMM system event log.

Command syntax

```
asu immapp clearsel [command options] [connection options]
```

Command

Table 45. Options

Option	Description
--help	Display help information for commands and exit without executing command.

Table 46. Connection options

Connection option	Description
--host <ip>	Address of the IMM server to operate on.
--user <userid>	IMM user name to authenticate. The default is USERID.
--password <password>	IMM password to authenticate. The default is PASSWORD.
--kcs	Force to use IPMI over KCS local interface.

Command example

```
C:\asu>asu.exe immapp clearsel --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20nn All Rights Reserved
Connected to IMM at IP address:10.10.10.1
Successfully clear the system event log.
```

Show the system event log

You can use the ASU command line to show the remote system IMM system event log.

Command syntax

asu immapp showsel [command options] [connection options]

Command

Table 47. Options

Option	Description
--help	Display help information for commands and exit without executing command.

Table 48. Connection options

Connection option	Description
--host <ip>	Address of the IMM server to operate on.
--user <userid>	IMM user name to authenticate. The default is USERID.
--password <password>	IMM password to authenticate. The default is PASSWORD.
--kcs	Force to use IPMI over KCS local interface.

Command example

```
C:\asu>asu.exe immapp showsel --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20nn All Rights Reserved
Connected to IMM at IP address:10.10.10.1
SEL Information
Version      : 1.5 (v1.5, v2 compliant)
Entries      : 512
Free Space   : 0 bytes
Percent Used : 100%
Last Add Time : 02/26/2002 08:58:55
Last Del Time : 02/19/2002 03:43:34
Overflow     : true
Supported Cmds : 'Reserve'
  1 | 07/03/2012 | 09:38:35 | Event Logging Disabled #0xb6 | Log area reset/cleared | Asserted
  2 | 07/03/2012 | 09:39:54 | System Firmware Progress #0xb4 | System boot initiated | Asserted
  3 | 07/04/2012 | 07:00:27 | Power Unit #0x01 | Power off/down | Asserted
  4 | 07/04/2012 | 07:01:25 | Power Unit #0x01 | Power off/down | Deasserted
  5 | 07/04/2012 | 07:01:25 | System Firmware Progress #0xb4 | Unspecified | Asserted
  6 | 07/04/2012 | 07:03:21 | System Firmware Progress #0xb4 | System boot initiated | Asserted
  7 | 07/04/2012 | 07:24:06 | Power Unit #0x01 | Power off/down | Asserted
  8 | 07/04/2012 | 07:35:48 | Power Unit #0x01 | Power off/down | Deasserted
  9 | 07/04/2012 | 07:35:59 | System Firmware Progress #0xb4 | Unspecified | Asserted
 10 | 07/04/2012 | 07:38:06 | System Firmware Progress #0xb4 | System boot initiated | Asserted
```

Clear the IMM event log

You can use the ASU command line to clear the remote IMM event log.

Command syntax

asu immapp clearimmlog [command options] [connection options]

Command

Table 49. Options

Option	Description
--help	Display help information for commands and exit without executing command.

Table 50. Connection options

Connection option	Description
--host <ip>	Address of the IMM server to operate on.
--user <userid>	IMM user name to authenticate. The default is USERID.
--password <password>	IMM password to authenticate. The default is PASSWORD.
--cimhttp	Use http for CIM interface. The default is https.
--port <port>	Port for CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe immapp clearimmlog --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20nn All Rights Reserved
Connected to CIMOM at IP address:10.10.10.1 on Port:5989
Successfully clear the IMM log.
```

Show the IMM event log

You can use the ASU command line to display the remote IMM event log.

Command syntax

asu immapp showimmlog [command options] [connection options]

Command

Table 51. Options

Option	Description
--help	Display help information for commands and exit without executing command.

Table 52. Connection options

Connection option	Description
--host <ip>	Address of the IMM server to operate on.
--user <userid>	IMM user name to authenticate. The default is USERID.
--password <password>	IMM password to authenticate. The default is PASSWORD.
--cimhttp	Use http for CIM interface. The default is https.
--port <port>	Port for CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe immapp showimmlog --host 10.10.10.1 --port 5988
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-2012 All Rights Reserved
Connected to CIMOM at IP address: 10.10.10.1 on Port:5988
0 | Severity:2 | Message:The Chassis Event Log on system SN#2329269 cleared by user USERID
1 | Severity:2 | Message:The ComponentActivity Log on system SN#2329269 cleared by user USERID
2 | Severity:2 | Message:Remote Login Successful. Login ID: USERID from Web at IP address 9.123.236.180
3 | Severity:2 | Message:Remote Login Successful. Login ID: USERID from Web at IP address 9.125.90.77
4 | Severity:2 | Message:Remote Login Successful. Login ID: USERID from Web at IP address 9.125.90.77
5 | Severity:2 | Message:Remote Login Successful. Login ID: USERID from Web at IP address 9.111.30.227
6 | Severity:2 | Message:Remote Login Successful. Login ID: USERID from Web at IP address 9.111.30.227
7 | Severity:2 | Message:Management Controller SN# 2329269 reset was initiated by user USERID
8 | Severity:2 | Message:LAN: Ethernet[eth1] interface is now active
9 | Severity:2 | Message:ENET[sp-ethernetport] IP-Cfg:HstName=IMM-00215E5E118D, IP@=9.125.90.89, NetMsk=255.255.255.0, GW@=9.125.90.1
10 | Severity:2 | Message:ENET[sp-ethernetport] IPv6-LinkLocal:HstName=IMM-00215E5E118D, IP@=fe80::221:5eff:fe5e:118d, Pref=64
11 | Severity:2 | Message:Remote Login Successful. Login ID: USERID from Web at IP address 9.111.30.227
12 | Severity:2 | Message:"Host Power" has been turned off
13 | Severity:2 | Message:"Host Power" has been turned on
```

Clear the IMM event log and system event log

You can use the ASU command line to clear the remote IMM event log and system log.

Command syntax

```
asu immapp clearalllog [command options] [connection options]
```

Command

Table 53. Options

Option	Description
--help	Display help information for commands and exit without executing command.

Table 54. Connection options

Connection option	Description
--host <ip>	Address of the IMM server to operate on.
--user <userid>	IMM user name to authenticate. The default is USERID.
--password <password>	IMM password to authenticate. The default is PASSWORD.
--cimhttp	Use http for CIM interface. The default is https.
--port <port>	Port for CIM interface. The default is 5989.

Command example

```
C:\asu>asu.exe immapp clearalllog --host 10.10.10.1
IBM Advanced Settings Utility version 9.30.79M
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-20nn All Rights Reserved
Connected to IMM at IP address:10.10.10.1
Successfully clear the system event log.
Connected to CIMOM at IP address: 10.10.10.1 on Port:5989
Successfully clear the IMM log.
```

Classes of settings

This topic explains classes and how they are used in the Advanced Settings Utility.

For commands that support operating on multiple settings, classes are used to indicate groups of settings. The commands that support classes are comparedefault, help, loaddefault, show, showdefault, showlocation, and showvalues.

Classes

The ASU classes of settings are described in the following list:

all

This class includes all settings that are listed in the ASU for the Remote Supervisor Adapter or Remote Supervisor Adapter II, baseboard management controller, and BIOS.

authentication

This class includes all settings that are classified as authentication settings, which includes passwords, user IDs, and authority-related settings.

The **save** and **restore** commands do not save or restore this class of settings.

You can list the user IDs and authority-related settings using the **show** command.

You cannot list the password settings using the show command. To list the password settings, use the **showvalues** command.

Example:

List the settings defined as authentication, including the password settings. Password settings are normally not displayed when you use the show command. To display the available password, use the showvalues command with the password class:

```
asu showvalues authentication
```

backupctl

This class lists all settings that are not restored when you run the restore command. An additional flag is required for these settings to be included during a restore operation. For more information, see the Restore command.

Class filter for the show, showvalues, showdefault, and showlocation commands.

To list the settings that are not restored if saved, type the following command:

```
asu show backupctl
```

bios

This class includes all settings that match the installed BIOS code level.

bmc

This class includes all settings that are identified as baseboard management controller settings.

change

This class includes all settings that are not in the reboot class that can be changed safely and changed back before the system is restarted.

critical

This class includes all settings that you cannot change safely before a restart but that must be tested.

group

This class includes all settings that belong to the specified group. To view the supported groups, use the **showgroups** command.

Settings in BIOS-based servers and IMM-based servers are cataloged in classes or groups. If specified, the class is used as a filter for the command that is displaying or operating on the settings.

Class filter for the **show**, **showvalues**, **showdefault**, **showlocation**, **save**, **restore**, and **replicate** commands.

Examples:

To list the settings that are part of the IMM group (IMM-based servers):

```
asu show IMM
```

To list the settings that are part of the BIOS group (BIOS-based servers):

```
asu show bios
```

nochange

This class includes all changeable settings that are not in the reboot and change classes.

noreplicate

This class lists all settings that are not replicated when you run the replicate command. These settings are usually unique to each system.

Class filter for the **show**, **showvalues**, **showdefault**, and **showlocation** commands.

Example:

To list the settings that are not replicated:

```
asu show noreplicate
```

password

This class lists all settings that are classified as password settings.

Password setting values are not displayed with a **show** command.

This class filter can be used with the following commands to list the settings classified as password: **showvalues**, **showdefault**, and **showlocation** (BIOS-based servers only) commands.

Example:

List the settings that are defined as password settings. Password settings are normally not displayed when you use the **show** command. To display the available password, use the **showvalues** command with the password class:

```
asu showvalues password
```

rsa

This class includes all settings that are identified as Remote Supervisor Adapter and Remote Supervisor Adapter II settings.

readonly

This class includes all settings that are **read-only** (for example, settings that you cannot change).

reboot

This class includes all settings that can be changed safely before a restart. If changing a setting does not preclude starting from the hard disk drive on the next startup, the setting is in this class.

writeonly

This class includes all settings that are **write-only** (for example, settings that you can change but that cannot be read, such as passwords).

Setting interdependencies support on an IMM2-based system

Settings are now interdependencies that are supported on IMM2-based systems.

When you run the **show** and **set** commands, some settings are hidden or read-only because they are dependent on other settings. The dependency information is shown using the **showvalues** command.

Example:

Setting “BootModes.OptimizedBoot” is hidden (suppressed) if the value of the setting “BootModes.SystemBootMode” is Legacy Only. If the value of the setting “BootModes.SystemBootMode” changes, the value is displayed. The dependency information is described in this **showvalues** command:

```
D:\asu>asu showvalues BootModes.OptimizedBoot --host 9.119.41.101
IBM Advanced Settings Utility version 9.00.76N
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-2012 All Rights Reserved
Connected to IMM at IP address 9.119.41.101
BootModes.OptimizedBoot=Disable<Enable>
This setting is hidden if the result of the following expression is true: " BootModes.SystemBootMode == Legacy Only "
```

Refer to the ASU User's Guide for the settings marked as (*).

After modifying the setting “BootModes.SystemBootMode” to “Legacy Only,” you cannot display or set it. The output of the **show** command might look like this one:

```
D:\asu>asu show BootModes.OptimizedBoot --host 9.119.41.101
IBM Advanced Settings Utility version 9.00.76N
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-2012 All Rights Reserved
Connected to IMM at IP address 9.119.41.101
This setting cannot be shown because it is hidden!
```

The setting “SystemRecovery.POSTWatchdogTimerValue” is read-only if the setting “SystemRecovery.POSTWatchdogTimer” is “disabled.” The dependency information is:

```
D:\asu>asu showvalues SystemRecovery.POSTWatchdogTimerValue --host 9.119.41.101
IBM Advanced Settings Utility version 9.00.76N
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-2012 All Rights Reserved
Connected to IMM at IP address 9.119.41.101
SystemRecovery.POSTWatchdogTimerValue= numeric min=5 max=20 step=1 default=5
```

This setting is read-only if the result of the following expression is set to true:

```
SystemRecovery.POSTWatchdogTimer == Disable "
```

Refer to the ASU User's Guide for the settings marked as (*).

If you try to modify the value, the following output is displayed:

```
D:\asu>asu set SystemRecovery.POSTWatchdogTimerValue 7 --host 9.119.41.101
IBM Advanced Settings Utility version 9.00.76N
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-2012 All Rights Reserved
Connected to IMM at IP address 9.119.41.101
This setting cannot be set because it is read-only!
```

Setting groups and setting values also have internal independencies. You cannot display or change them because they are hidden. When you use the **showvalues** command, some settings are marked with an asterisk. Asterisks mean that the settings are not only dependent on other internal settings, but also depend on the system environment. You can modify these settings using the uEFI F1 menu. The sample output can be described as below:

```
D:\asu>asu showvalues Power.PowerPerformanceBias --host 9.125.90.191
IBM Advanced Settings Utility version 9.00.76N
Licensed Materials - Property of IBM
(C) Copyright IBM Corp. 2007-2012 All Rights Reserved
Connected to IMM at IP address 9.125.90.191
(*)Power.PowerPerformanceBias=<Platform Controlled>=0S Controlled
```

Refer to the ASU User's Guide for the settings marked as (*).

Note: Only the **show** and **set** commands support setting interdependencies. Use the **showvalues** command to see the values of the dependency information. Other commands like **save**, **replicate**, **restore**, and **batch** ignore the dependencies restriction.

Command modifiers

This topic describes the command modifiers and the commands to which they apply.

Purpose

Command modifiers are optional. Use command modifiers to modify the default operation of specific commands.

Table 55. Command modifiers

Command modifier	Description	SyntaxLAN-over-USB
--group	Optional command modifier for the show , showdefault , showvalues , showlocation , and save commands. When used with a supporting command, it is used to specify the name of a group section. The group_name is obtained by running the showgroups command.	asu show [--group group_name] asu save [--group group_name] Obtain the group_name by running the following showgroups command: asu showgroups
--setlist	Optional command modifier for the show , showdefault , showvalues , showlocation , and save commands. When used with a supporting command, it is used to specify a list of settings on which the command operates.	asu show [--setlist name1 name2 nameN] asu save [--setlist name1 name 2 nameN]
--exbackupctl	Optional command modifier for the save command. Use this command modifier during a save command to exclude saving the backup control settings in a file. The default in a save command is to include all backupctl settings. To review the backupctl settings, use the asu show backupctl command. This command is mutually exclusive to the inbackupctl command modifier.	asu save file_name [--exbackupctl]

Table 55. Command modifiers (continued)

Command modifier	Description	Syntax LAN-over-USB
--incbackupctl	<p>Optional command modifier for the restore command.</p> <p>Use this command modifier during a restore command to include the backup control settings.</p> <p>The backupctl settings are not restored by default. To review the backupctl settings, use the asu show backupctl command.</p> <p>This command is mutually exclusive to the exbackupctl command modifier.</p>	asu save file_name [--incbackupctl]
--instances	<p>Optional command modifier for the showvalues command.</p> <p>Use this command modifier during a showvalues command to show the names of settings that can have instances.</p> <p>This command is mutually exclusive to the group command modifier.</p>	asu showvalues [--instances]
--help	<p>Optional command modifier for all commands and applications.</p> <p>Use this command modifier to show the help text for an ASU command or application.</p>	asu command application --help

Command connectivity options

This topic describes the command connectivity options, which are a set of parameters that relate to the ASU connection on the IMM.

The connectivity options might be required when you connect the ASU to a local IMM. When you attempt to connect the ASU to a local IMM and none of the connectivity parameters are specified, the ASU attempts to connect to the IMM by using the default LAN over USB interface settings. The default settings include user ID, password, and host. The values for these settings are defined by the IMM hardware. If none of these settings are specified on a local connection and the default LAN over USB interface settings fail, the ASU attempts to connect over the KCS interface. The KCS interface does not require any of these parameters.

To connect the ASU remotely to the IMM, the host parameter is required. The user and password parameters are optional. If these parameters are not specified, the default settings are used.

Any local or remote LAN over USB connection requires authentication. The default authentication parameters are the default user ID and password that comes configured with each IMM. For the default authentication settings, see the documentation that comes with the server or optional devices.

Table 56. Command connectivity options

Connectivity option	Description	Syntax
host	Specifies the host name or IP address of the IMM to which the ASU should connect.	asu cmd [command_modifier] options --host host_name ip asu cmd [command_modifier] options --host=host_name ip
user	Specifies the user name to use when you are authenticating with the IMM.	asu cmd [command_modifier] options --user user_id asu cmd [command_modifier] options --user=user_id
password	Specifies the password to use when you are authenticating with the IMM.	asu cmd [command_modifier] options --password password asu cmd [command_modifier] options --password=password
password-file	Specifies the name of a file that contains the password to use when you are authenticating with the IMM.	asu cmd [command_modifier] options --password-file file_name asu cmd [command_modifier] options --password-file=file_name
kcs	Specifies to send commands by using the KCS IPMI interface only. This option requires the IPMI device driver. For more information, see IPMI device driver support for Windows or IPMI device driver support for Linux. This option does not require authentication.	asu cmd [command_modifier] options --kcs

Command general options

This section describes the available command general options.

Bypass command option

Note: The bypass command option is not available for IMM-based servers.

If you try to run the **patchadd** command on a system on which a BIOS CMOS patch file is already installed in the BIOS ROM and the definition file that you use has the same BIOS code level as the system, an error message is generated and the

ASU is not modified. Also, if you issue the patchremove command and select the BIOS CMOS patch, an error message is generated, and the ASU does not remove this patch.

To add and use a BIOS CMOS definition patch file on a system in which the BIOS ROM has a BIOS CMOS patch with the same BIOS code level, use the bypass option (--bypass) at the end of the asu command.

```
asu patchadd GG16A.def --bypass
asu patchlist --bypass
asu show all --bypass
```

When you run the asu command with the bypass option, the ASU ignores the BIOS CMOS patch information in BIOS ROM.

dumplogfile command option

Use the dumplogfile option to redirect all output that is produced by the ASU to a log file.

Using the dumplogfile command

The **dumplogfile** option is inserted at the end of any ASU command.

The **dumplogfile** option complements in function and is mutually exclusive with the silent option. When the **dumplogfile** option is specified, the ASU runs in silent mode. All output that is produced by the ASU, whether informational or error logging, is redirected to a predefined log file. For Linux, the log file is /asulog/asuout.log. For Windows, the log file is c:\asulog\asuout.log, where c is the system drive as defined in Windows.

Output

The dumplogfile option does not produce any additional output or filter any output that is normally produced by the ASU. It is a simple redirect to the predefined file.

Every time the ASU runs, the predefined file is initialized. All content from a previous ASU run is lost. There are no appends to the existing file from a previous run.

The predefined log file has no maximum file size. If, during an ASU run, the file reaches the file system available space, any additional output is lost.

Examples

The following examples show the asu command with the dumplogfile option.

Command	Description
asu show all dumplogfile	This ASU command shows the current value for all settings and redirects the output to a predefined log file.
asu set CMOS_CRTRequired Disabled dumplogfile	This ASU command sets the value, and all output is redirected to the predefined log file.

-nx node option

The `-nx` option supports multi-node systems. In a multi-node system, there are multiple BIOS CMOS settings, Remote Supervisor Adapter settings, and baseboard management controller settings for legacy system; and multiple uEFI settings, and IMM settings for IMM-based system. The ASU enables you to access any node settings by adding the `-nx` parameter to the command (where `x` is the selected node).

Before you use the `-nx` option with a multi-node system that is running a Windows operating system, see IPMI device driver support for Windows. If the multi-node system is running a Linux operating system, see IPMI device driver support for Linux.

Syntax

If the optional `-nx` parameter is specified, the ASU performs the operation for node `x`, where `x` is the selected node in a multi-node system and is a number from 1 through 8. If the `-nx` parameter is not specified, the operation is performed on the primary node (node 1). The `-nx` option must be at the end of the command. If the `--bypass` option is also specified, the `--bypass` option must follow the node option. See the following examples.

```
asu show all -n3
```

This command shows the current value for all settings for node 3.

```
asu set CMOSCRTRRequired Disabled
```

This command sets the CMOS setting to disabled for node 1.

```
asu rebootrsa -n1
```

This command restarts the Remote Supervisor Adapter node 1, which is the primary node.

```
asu patchadd GG16A.def -nx 2 --bypass
```

This command forces adding a patch to node 2.

When you run the `asu` command with the `--bypass` option, the ASU ignores the BIOS CMOS patch information in BIOS ROM.

showsptraffic command option

Note: The `showsptraffic` command option is not available for IMM-based servers.

Use the **showsptraffic** command option (`--showsptraffic`) to show raw traffic to and from the service processor (SP). Use this option for debugging.

Usage

The `showsptraffic` option is inserted anywhere in any `asu` command. Any communication with the service processor is shown.

Output

When the `showsptraffic` option is specified on the command line, the following lines are interspersed with normal output:

```
SP Sent: <byte 1> <byte 2> ... <byte n>
SP Recv: <byte 1> <byte 2> ... <byte n>
```

Or

```
SP6 Sent: <byte 1> <byte 2> ... <byte n>
SP6 Recv: <byte 1> <byte 2> ... <byte n>
```

Examples

The `showsptraffic` option and corresponding output are shown in the following example.

Command line:

```
asu show RSA_SSL_Server_Enable --showsptraffic
```

Output:

```
SP Sent: 02 06 00 00 00 00 04 09 05 01 01 01
SP Recv: 04 06 01 00 00 00 04 09 05 01 01 00
RSA_SSL_Server_Enable=Disabled
```

Command line:

```
asu set RSA_SSH_Enable Enabled --showsptraffic
```

Output:

```
SP Sent: 00 06 01 00 00 00 04 09 05 01 04 01 01
SP Recv: 04 06 00 00 00 00 04 09 05 01 04 01
SP Sent: 02 06 00 00 00 00 04 09 05 01 04 01
SP Recv: 04 06 01 00 00 00 04 09 05 01 04 01 01
RSA_SSH_Enable=Enabled
```

silent command option

Use the silent command option to suppress all output.

Usage

The silent option is inserted at the end of any ASU command. Any output that is produced by the ASU as either informational or error logging to screen is suppressed. To determine whether the command was successful, see the command return code.

Output

If the ASU command is successful, the return code is zero (0). If the ASU command is not successful, the return code is a positive number greater than zero (0). For information about the return codes, see Return codes.

Examples

In the following command example, the ASU sets the value, and no output is produced to the screen or to a file.

```
asu set CMOS_CRTRequired Disabled --silent
```


--help command option

Use the --help command option to show command-line help.

Usage

The --help option can be used to give a full description of an ASU application (for example, savestat, immcfg or fodcfg) or ASU command (for example, batch, set, or loaddefault).

Output

The output is a full description of the ASU application or command, including available options and the description of those options. Running `asu --help` displays details about the --help command option.

Examples

In the following command example, the ASU displays the full description of the `asu show` command.

Command line:

```
asu show --help
```

Output

Description:

If <setting> is specified, current value is only shown for setting. Show the current value for one or all settings. If "--group all" is specified, current values are shown for all settings. If "--group <group>" is specified then only values are shown for settings in that group. If "--setlist <setting1>...<settingN>" is specified, the list of settings from <setting1> to <settingN> are specified.

Syntax:

```
show [<setting>][<cmdmod>] [<options>] [<connect_opts>]
```

where

<cmd_mod>

Note: Use the command "asu showgroups" to find variable classes available.

--setlist <name 1>...<name n> - Operate commands on list of settings.

--group <variableclass> - Operate commands on the group of setting options.

--silent - Silent execution. Use return code to retrieve status.

--dumptofile - Silent execution and output to asuout.log file.

-n<node> - Node number node in a multinode system

-v - Verbose <connect_opts>

Note: These connectivity options apply to IMM-based servers only:

--host <ip> - Address of the IMM to operate on.

--user <user> - User name used to authenticate to the IMM

--password <pwd> - Password used to authenticate to the IMM

--password-file <fn> - File containing password to authenticate with IMM

ASU log file

This section explains the ASU log file mechanism.

ASU generates a new log file into the log file directory every time ASU is executed.

On the Windows platform, the ASU log file directory is in IBM_Support under system drive device. On the Linux platform, the ASU log file directory is /var/log/IBM_Support/

The ASU log file is named with the running time as asu_%runningtime%.log. Running time is formatted as %Year%% Month%%Day%%Hour%%Minute %%Second%% Microsecond%% Timezone%.

asu_20120827161042.593000+480.log

Return codes

This section lists and explains the return codes for both ASU and RDCLI.

ASU return codes

ASU groups failure return codes into different categories. This topic explains the ASU return codes and categories.

When the ASU completes a request successfully, it returns a zero (0) return code. If a failure is detected, the ASU return code is a positive number greater than zero.

The ASU groups the failure return codes into different categories. Failure return codes are used as a signal that a failure is detected. However, these return codes do not indicate a specific failure. For detailed error isolation, see the return code explanation that is displayed on the screen with the specific error condition.

The different categories of errors are described in the following table, including brief descriptions of the possible types of failure.

Table 57. ASU return codes

Return code value	Description	Explanation
0	Successful command	The ASU command has been completed successfully.
5	Input error	The input that was provided to the ASU has an error. This might be a user-input error or an error with the provided definition file.

Table 57. ASU return codes (continued)

Return code value	Description	Explanation
10	Software error	An error occurred when you tried to use specific software.
15	Hardware error	An error occurred when the ASU tried to communicate with or find specific hardware.
20	Data error	An error occurred in the data that the ASU reads or sets.
25	Program error	An error occurred in the ASU program execution flow.
30	Invalid or missing patch detected	An ASU patch is missing or an ASU patch does not match the required level.
35	The command is not supported.	
40	Invalid value input error	The input value that is provided to the ASU has a syntax error.
45	Batch command error	One or more of the commands that were specified in the batch file has failed.
80	32-bit version running on 64-bit operating system	The ASU application is a 32-bit version, and you are attempting to run it on a 64-bit operating system.

RDCLI return codes

This topic lists and describes the RDCLI return codes.

Table 58. RDCLI return codes

Return code value	Description	Explanation
0	Success	The ASU command has been completed successfully.
1	Parameter is lacking	The input parameters provided to the RDCLI are not enough for RDCLI.
2	Could not allocate memory	The operating system failed to allocate enough memory for RDCLI to run.
6	Unknown option	The input parameters provided to RDCLI have unknown options.
7	Unknown option character	The input parameters contain some unknown characters.
10	No target path specified	The input parameters do not provide the file path that you wanted to mount onto the IMM.
13	Error from ending the previous RDCLI process	Failed to end an existing RDCLI process on the current local machine.
14	Error from system call	Error occurred when invoking an operation system call.
22	Invalid token	Invalid token ended the process.

Table 58. RDCLI return codes (continued)

Return code value	Description	Explanation
34	You failed to authenticate. Check your login information, IMM setting, and firewall status.	You did not pass authentication because your information is incorrect , or you entered the wrong IMM configuration or an improper firewall status. Check that they are all correct.
37	Socket error, socket connection fail	Socket connection error occurred.
38	Could not reach the Service Processor IMM authentication site-check, hostname/IP/ports/the installation, of IMM remote disk key	Some unknown errors occurred during the authentication process. Check all configuration and input.
44	Indicate a target IMM by hostname or IP address.	Provide a target IMM hostname or IP address when issuing the RDCLI command.
59	You failed to mount remote disk. Check to see if others have already used the remote disk, and unmount their disk before mounting yours.	You did not mount the local file onto IMM remote disk because the disk is occupied by another user.
60	The remote disk session stopped.	The connect session between the local computer and IMM are broken.
62	Specify a port argument to connect to the IMM Virtual Disk port.	Provide a correct port number to connect to IMM if you do want to not use the default port number.
63	No virtual drives found. Try again later.	No virtual drive on IMM is currently available.
64	Local drive to remote drive attach failed.	Failed to map the local file to the IMM remote disk.
65	Could not open target file	Failed to open the local file that you want to mount.
66	Lack remote key. Install the key to activate the remote disk function.	You did not install the remote presence key on IMM. You must install the key now.
67	There is already a link on that machine, so unmount first.	There is already a session mounting file on the same IMM as the local machine. Unmount the previous session before you issue a new RDCLI command.

Baseboard management controller startup sequence (boot order) settings

This topic describes the startup sequence settings for the baseboard management controller.

Note: The baseboard management controller startup sequence setting is not available for IMM-based servers.

If the startup sequence (boot order) settings for your IBM System x Server are contained in the baseboard management controller and not in the BIOS CMOS memory, you must use the baseboard management controller settings when you use the asu commands (such as the set and show command).

To determine whether the startup sequence settings for your System x Server are contained in the baseboard management controller, use the ASU patchextract command. The patchextract command syntax is:

```
asu patchextract patch_number patch_filename
```

where

the *patch_number* is the patch number for the BIOS code and *patch_filename* is the generated extracted BIOS definition file.

Command line

asu patchlist - to determine which patch is the BIOS patch.

Output

```
Patch 1: <XX[00->99] <BMC>
Patch 2: <XX[00->99] <RSA>
Patch 3: <DY[14->14] <BIOS>
```

Command line

asu patchextract 3 bios.def - bios.def contains the bios definitions.

Output

```
Extracted patch 3: <DY[14->14] <BIOS>> to bios.def
```

Open the bios.def file and review the contents. If any of the settings start with BMCSetting (for example, BMCSetting BMC_PrimaryBootDevice2, "Second Primary Boot Device", critical,.....), the server startup sequence settings are contained in the baseboard management controller, and you must use the BMCSetting when you access the server startup sequence settings.

Note: Before you can access the baseboard management controller settings, the baseboard management controller device driver must be installed. For information about obtaining the device driver, see Obtaining the ASU and patch files.

Boot order settings for IMM-based servers

The boot order settings on IMM-based servers are a special group of settings. This topic describes those settings.

The boot order sequence is stored in the IMM and used by the server firmware during the startup process.

The following examples illustrate how to view the current settings and to set the boot order sequence. Each example shows a different connectivity option to illustrate the different method of connectivity.

To determine the current boot order sequence, start by listing the settings that belong to the special boot-order group. The special group or class is currently defined as BootOrder.

To list the boot order settings using a local connection to an IMM:

```
asu show BootOrder
```

A sample output of the command:

```
BootOrder.BootOrder=CD/DVD Rom=Floppy Disk=Hard Disk  
0=Network=Hard Disk 1=Hard Disk 2=Hard Disk 3
```

The setting that contains the boot order is called BootOrder.BootOrder. This output represents an ordered list. The syntax of an ordered list is:

```
value1=value2=valueN
```

The values that are separated by the equal sign (=) represent each of the items in the list. Therefore, this is the list of devices in the boot order.

The listed values are those devices that are currently set in the boot order. Additional devices might be available to be included in the boot order. To learn about all the available devices, use the showvalues command.

To list the devices that are available to be set by using the remote connection to an IMM and the default authentication for the BootOrder.BootOrder setting, type the following command:

```
asu showvalues BootOrder.BootOrder --host 9.5.51.207
```

A sample output for this command:

```
BootOrder.BootOrder==CD/DVD Rom=Floppy Disk=Hard Disk  
0=Network=Hard Disk 1=Hard Disk 2=Hard Disk 3=Hard Disk  
4=USB Storage=Diagnostics=iSCSI=iSCSI Critical=Legacy  
Only=Embedded Hypervisor
```

The list of devices is much larger than what is shown in the previous example. Note the double equal sign (==) sign nomenclature. The double equal sign represents the values in an ordered list. You can select any of these values to build a new ordered list.

After all the possible values are known, you can build a new ordered list of values by using the set command.

To build a new boot order sequence by using the set command on a local IMM through the LAN over USB connection:

```
asu set BootOrder.BootOrder "Network=Hard Disk 1=USB  
Storage=Diagnostics=iSCSI=iSCSI Critical=Legacy  
Only=Embedded Hypervisor" --user testuser --password  
testpwd
```

Each of the devices in the list in the specified order constitutes the new boot order sequence.

A sample output for this command:

```
BootOrder.BootOrder=Network=Hard Disk 1=USB  
Storage=Diagnostics=iSCSI=iSCSI Critical=Legacy  
Only=Embedded Hypervisor --user testuser --password  
testpwd
```

Configuring iSCSI

The ASU supports setting iSCSI boot parameters. This section describes how to configure iSCSI settings.

The ASU is designed to configure iSCSI settings, which do not initially exist. This section describes the detailed steps for creating and configuring the iSCSI settings.

Before you configure iSCSI boot parameters, read the following general information:

- The iSCSI settings are grouped into a record. The record key for the record is the iSCSI.AttemptName setting. Each record represents an attempt. The term "attempt" is equivalent to the term "instance" that is defined for other settings.
- More than one attempt can be defined. In the examples in this section, all the settings that end with ".1" belong to the "first" attempt. The iSCSI.AttemptName.1 setting defines the name of the attempt group of settings.
- If more than one attempt is defined, the same setting names that define the attempt group are used, but each attempt contains a different instance number sequence.
- The iSCSI settings can now be created using the ASU **set** command on an instance of the iSCSI.AttemptName setting that does not already exist.
- The iSCSI settings can now be deleted using the ASU **delete** command on an instance of the iSCSI.AttemptName setting. This command deletes all iSCSI settings for that instance because iSCSI instance settings are grouped as a record.
- The iSCSI.InitiatorName parameter is the only one defined as a global iSCSI setting to all attempts and does not require an instance index. This setting does not require the attempt index that all the other settings require. The initiator name is always defined as iSCSI.InitiatorName.
- The iSCSI parameters are defined in the iSCSI group of settings. To list the available iSCSI settings, type the following command:

```
asu show iscsi
```

Single attempt group

The following example shows the list of settings if a single attempt group is defined. All setting names with the same instance ".1" belong to the same attempt group:

```
iSCSI.InitiatorName  
  
iSCSI.MacAddress.1  
iSCSI.AttemptName.1  
iSCSI.IscsiMode.1  
iSCSI.ConnectRetryCount.1  
iSCSI.ConnectTimeout.1  
iSCSI.InitiatorInfoFromDhcp.1  
iSCSI.LocalIp.1  
iSCSI.SubnetMask.1  
iSCSI.Gateway.1  
iSCSI.TargetInfoFromDhcp.1  
iSCSI.TargetName.1  
iSCSI.TargetIp.1  
iSCSI.TargetPort.1  
iSCSI.BootLun.1  
iSCSI.CHAPType.1  
iSCSI.CHAPName.1  
iSCSI.CHAPSecret.1
```

```
iSCSI.ReverseCHAPName.1  
iSCSI.ReverseCHAPSecret.1  
  
iSCSI.MacAddress.2
```

Two attempt groups

The following example shows the list of settings if two attempts are defined:

```
iSCSI.InitiatorName  
  
iSCSI.MacAddress.1  
iSCSI.AttemptName.1  
iSCSI.IscsiMode.1  
iSCSI.ConnectRetryCount.1  
iSCSI.ConnectTimeout.1  
iSCSI.InitiatorInfoFromDhcp.1  
iSCSI.LocalIp.1  
iSCSI.SubnetMask.1  
iSCSI.Gateway.1  
iSCSI.TargetInfoFromDhcp.1  
iSCSI.TargetName.1  
iSCSI.TargetIp.1  
iSCSI.TargetPort.1  
iSCSI.BootLun.1  
iSCSI.CHAPType.1  
iSCSI.CHAPName.1  
iSCSI.CHAPSecret.1  
iSCSI.ReverseCHAPName.1  
iSCSI.ReverseCHAPSecret.1  
  
iSCSI.MacAddress.2  
iSCSI.AttemptName.2  
iSCSI.IscsiMode.2  
iSCSI.ConnectRetryCount.2  
iSCSI.ConnectTimeout.2  
iSCSI.InitiatorInfoFromDhcp.2  
iSCSI.LocalIp.2  
iSCSI.SubnetMask.2  
iSCSI.Gateway.2  
iSCSI.TargetInfoFromDhcp.2  
iSCSI.TargetName.2  
iSCSI.TargetIp.2  
iSCSI.TargetPort.2  
iSCSI.BootLun.2  
iSCSI.CHAPType.2  
iSCSI.CHAPName.2  
iSCSI.CHAPSecret.2  
iSCSI.ReverseCHAPName.2  
iSCSI.ReverseCHAPSecret.2
```

IPv6 related settings in IMM

To be consistent with the web user interface, ASU requires that you enter a prefix for the IPv6 address.

The following is an example:

```
IMM.IPv6HostIPAddressWithPrefix1= 2002:325b:1000::097D:5AF5/64
```

where 64 is the address prefix for an IPv6 address.

You must enter '/' in the setting string as a prefix between the address and prefix.

Managing certificates for IMM-based systems

ASU can manage either the CA (Certificate Authority) or CSR (Certificate Sign Request) file on an IMM-based system. This section explains how to set up certificates for both Linux and Windows.

Signing a certificate sign request using certificate authority

About this task

As an example, this topic uses `asu_csr.der` as your certificate sign request file.

Procedure

1. Export the certificate sign request file using the **asu export** command.
2. Convert the certificate sign request format from DER to PEM.
3. Enter the command, `openssl req -in asu_csr.der -inform DER -out asu_csr.pem -outform PEM`.
4. Sign the certificate sign request using the certificate authority just set up.
5. Enter the command, `openssl ca -policy policy_anything -out asu_cert.pem -infile asu_csr.pem`.
6. Convert the certificate format from PEM to DER. The certificate sign request file is ready to import.
7. Import the certificate sign request file using the **asu import** command.
8. Enter the command, `openssl x509 -in asu_cert.pem -inform PEM -out asu_cert.der -outform DER`. You receive the signed certificate "asu_cert.der" for your certificate sign request file "asu_csr.der."

Revoking a certificate

This topic provides the command that you enter to revoke a signed certificate.

You cannot sign the same certificate sign request twice. You must revoke it before signing it again. Use the following command to revoke a certificate signed by this certificate authority.

```
openssl ca -revoke cert.pem
```

Supported commands for IMM-based certificate management

This topic lists all supported ASU commands for certification management.

Table 59. Supported ASU commands

Settings\command	generate	import	export	deletecert
SSL_HTTPS_SERVER_CERT	Y	Y	Y	N/A
SSL_HTTPS_SERVER_CSR	Y	N/A	Y	N/A
SSL_SERVER_DIRECTOR_CERT	Y	Y	Y	N/A
SSL_SERVER_DIRECTOR_CSR	Y	N/A	Y	N/A
SSL_LDAP_CLIENT_CERT	Y	Y	Y	N/A
SSL_LDAP_CLIENT_CSR	Y	N/A	Y	N/A
SSL_CLIENT_TRUSTED_CERT1	N/A	Y	Y	Y
SSL_CLIENT_TRUSTED_CERT2	N/A	Y	Y	Y
SSL_CLIENT_TRUSTED_CERT3	N/A	Y	Y	Y

Table 59. Supported ASU commands (continued)

Settings\command	generate	import	export	deletecert
SSH_SERVER_KEY	Y	N/A	N/A	N/A

Note: You can also view the supported commands for certificate settings by running the Showvalues command. On a command line, enter the following information:

```
asu showvalues IMM.SSL_HTTPS_SERVER_CERT
```

The following output is displayed:

```
IMM.SSL_HTTPS_SERVER_CERT=*generate=import=export
```

Disabling the corresponding server

Before you can manage a certificate on IMM, use this topic to help you disable the HTTPS server, the IBM Systems Director, and the SSL Client Configuration for the LDAP client.

Procedure

- Before using HTTPS Server Certificate Management, disable the HTTPS server:
 - On a command line, check to see if the IMM HTTPS server configuration for the web server is disabled by entering the `asu show IMM.SSL_Server_Enable` command. The following output is displayed: `IMM.SSL_Server_Enable=Disabled`.
 - If the server is enabled, disable the IMM HTTPS server configuration for the web server using the `asu set IMM.SSL_Server_Enable Disabled` command. The following output is displayed: `IMM.SSL_Server_Enable=Disabled`.
 - Restart the IMM to enable the change (enable or disable) by entering the `asu rebootimm` command.
- Before using IBM Systems Director over HTTPS Certificate Management, disable the director over the HTTPS server:
 - On a command line, enter the `asu show IMM.CIMXMLOverHTTPS_Enable` command to see if the IBM Systems Director Over HTTPS is disabled. The following output is displayed: `IMM.CIMXMLOverHTTPS_Enable=Disabled`.
 - If the server is enabled, disable IBM Systems Director Over HTTPS using the `asu set IMM.CIMXMLOverHTTPS_Enable Disabled` command. The following output is displayed: `IMM.CIMXMLOverHTTPS_Enable=Disabled`.
 - Restart the IMM to enable the change (enable or disable) by entering the `asu rebootimm` command.
- Before using SSL Client Certificate Management, disable the SSL Client Configuration for the LDAP client:
 - On a command line, check to see if the SSL Client Configuration for LDAP client is disabled by entering the `asu show IMM.SSL_Client_Enable` command. The following output is displayed: `IMM.IMM.SSL_Client_Enable=Disabled`.
 - If the server is enabled, disable the IMM SSL Client Configuration for LDAP using the `asu set IMM.SSL_Client_Enable Disabled` command. The following output is displayed: `IMM.SSL_Client_Enable=Disabled`.

Sample commands using ASU to manage certificates

This topic provides sample commands and responses used and received when managing certificates using ASU.

Getting the current status of the certificate setting

Use the `asu show` command to view the status of a particular certificate.

At the command line, if you enter:

```
asu show IMM.SSL_HTTPS_SERVER_CERT
```

The output is:

```
IMM.SSL_HTTPS_SERVER_CERT=Private Key and CA-signed cert installed, Private Key stored, CSR available for download.
```

Getting the available command for the setting

Get supported commands for the related certificate setting by running the `asu showvalues` command, or see the command supported table as a reference.

At the command line, if you enter:

```
asu showvalues IMM.SSL_HTTPS_SERVER_CSR
```

The output is:

```
IMM.SSL_HTTPS_SERVER_CSR=*generate=export
```

You can tell from the output that commands `generate` and `export` are supported for the setting, `IMM.SSL_HTTPS_SERVER_CSR`.

Generating a Certificate Sign Request (CSR)

Use the following command to generate a CSR.

At the command line, if you enter:

```
asu generate IMM.SSL_HTTPS_SERVER_CSR asu.xml
```

The output is:

```
Certificate was generated successfully!
```

An xml file, like `asu.xml` in this command line, is required in the `generate` command for all settings that support "generate," except `SSH_SERVER_KEY`. For instructions on creating this xml, refer to "Generate command."

A certificate sign request must be signed by an independent certificate authority to be a certificate.

Generating a self-signed certificate

You can also use ASU to generate a self-signed certificate, which is one that is already signed.

At the command line, if you enter:

```
asu generate IMM.SSL_HTTPS_SERVER_CERT asu.xml
```

The output is:

```
Certificate was generated successfully!
```

Exporting a certificate sign request

At the command line, if you enter:

```
asu export IMM.SSL_HTTPS_SERVER_CSR asu_csr.der
```

The output is:

Certificate was exported successfully!

The asu_csr.der file is saved in the current directory.

You can export a certificate or a certificate sign request. If a certificate sign request is signed by an independent certificate authority, it is a CA-signed certificate.

Importing a certificate

After you export a certificate, you can get the certificate sign request file "asu_csr.der." You must sign it using an independent certificate authority. You can only import the CA-signed certificate, which is different than a self_signed one, into HTTPS Server Certificate Management and IBM Systems Director over HTTPS Certificate Management.

The following two settings for SSL Client Certificate Management only permit CA-signed certificates to be imported:

- SSL_LDAP_CLIENT_CERT
- SSL_LDAP_CLIENT_CSR

The following three settings allow both self-signed and CA-signed certificates to be imported:

- SSL_CLIENT_TRUSTED_CERT1
- SSL_CLIENT_TRUSTED_CERT2
- SSL_CLIENT_TRUSTED_CERT3

For settings SSL_CLIENT_TRUSTED_CERT1, SSL_CLIENT_TRUSTED_CERT2, and SSL_CLIENT_TRUSTED_CERT3, if the certificate already exists, you must delete it before importing the certificate.

The certificate to be imported should be in DER form. To set up your own independent certificate authority and sign your certificate sign request file, see "Using the OpenSSL to set up a certificate authority and sign a certificate sign request."

On a command line, if you enter:

```
asu import IMM.SSL_HTTPS_SERVER_CERT asu_cert.der
```

The output is:

Certificate was imported successfully!

Note: "asu_cert.der" is a CA-signed certificate after asu_csr.der is signed using your own certificate authority.

Deleting a certificate

In SSL Client Certificate Management, only three settings support the "deletecert" command:

- SSL_CLIENT_TRUSTED_CERT1
- SSL_CLIENT_TRUSTED_CERT2
- SSL_CLIENT_TRUSTED_CERT3

On a command line, if you enter:

```
asu deletecert IMM.SSL_CLIENT_TRUSTED_CERT1
```

The output is:

```
Certificate was deleted successfully!
```

Remote Disk Command Line Interface

This topic describes the Remote Disk Command Line Interface (RDCLI) and provides examples on how to use it.

The RDCLI is designed to mount an ISO/DVD/CD to a remote IMM-based server. Before you invoke RDCLI, make sure that:

- The remote IMM has been connected to your network environment.
- There is no other remote session open through RDCLI or the IMM web interface.
- The remote key is installed on the server and the remote function is enabled.

To mount a cdrom/iso to a remote IMM:

```
rdmount -s 192.168.1.12 -d /dev/cdrom -l USERID -p PASSWORD
rdmount -s 192.168.1.12 -d /home/install.iso -l USERID -p PASSWORD
rdmount -s 192.168.1.12 -d /dev/cdrom -l USERID -p PASSWORD -w 90
```

If a remote IMM has an IPv6 address:

```
rdmount -s 2002:325b:1000::097D:5AF5 -d /dev/cdrom -l USERID -p PASSWORD
rdmount -s 2002:325b:1000::097D:5AF5 -d /home/install.iso -l USERID -p PASSWORD
rdmount -s 2002:325b:1000::097D:5AF5 -d /dev/cdrom -l USERID -p PASSWORD -w 90
```

"2002:325b:1000::097D:5AF5" is an IPv6 address of IMM.

If the mount is successful, a message displays that the mount operation completed without error. Otherwise, a message states that the mount operation failed and provides details about the failure.

"-w 90" means that you can switch the authentication port to 90, the default port number is 80.

Query the existing mount sessions between the client operating system and the remote server:

```
rdmount -q
```

If it succeeds, it list all available "tokens" on this client operating system in the format list below:

```
"Token 507: drive path /home/install.iso, mounted to SP 192.168.0.1, by user USERID"
```

If it fails, an error message prints with the reason for the failure.

Unmount an ISO/DVD/CD that is already mounted to the remote system. For example, the remote mount session has the token 507: `rdumount 507`.

If the action was successful, a message displays saying that the present remote session has ended. If the action failed, an error message and reason for the failure prints.

Chapter 3. Using the commands

This section describes the Advanced Settings Utility (ASU) commands.

The following commands are explained in this reference:

Batch command

Use the batch command to queue ASU operations without any knowledge of the scripting capabilities of the operating system on which the ASU is running.

Syntax

The syntax of the batch command is

```
asu batch batch_filename [-nx] [connect_options]
```

where

batch_filename is the name of a file that contains a list of ASU commands.

Notes

1. If the optional -nx parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. x can be a number from 1 through 8. If the -nx parameter is not specified, the operation is performed on the primary node (node 1).
2. Do not specify the -nx optional parameter in the batch file for any of the batched commands.
3. The connect options are defined for only IMM-based servers. The --host ip_address connect option is required if you connect remotely to the IMM. The --user user_id and --password password connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The --user user_id and --password password connect options are not required if you are using the local KCS interface.
4. All consecutive "set" commands in a batch file are set synchronously, and the inconsecutive "set" command parts are set one-by-one. If an error happens in one "set" command, all consecutive "set" commands also work, and the commands above the error are set successfully. However the ones below the error stop working.

Output

When you use the batch command on a batch file, the output that is sent to stdout and stderr is the collective output of all the commands in the batch file. The output of each command in the batch file is preceded by the command itself, surrounded by brackets ([]).

```
[command 1]  
output of command 1  
[command 2]  
output of command 2
```

•

-
-

```
[command n]  
output of command n
```

The batch command and corresponding output are shown in the following examples.

Example 1

Batch file:

```
set IMM.PowerRestorePolicy "Always on"  
set IMM.PowerOnAtSpecifiedTime_Hour 05  
set IMM.PowerOnAtSpecifiedTime_Minute 00  
set IMM.PowerOnAtSpecifiedTime_Second 00  
set IMM.ShutdownAndPowerOff_WeekDay Sunday  
set IMM.HTTPPort 81  
set IMM.SSLPort 441  
set IMM.TelnetPort 21  
set SYSTEM_PROD_DATA.SysEncloseAssetTag "Server Tag"  
set iSCSI.InitiatorName "iqn.2009-01.com.ibm:InitiatorName"  
set uEFI.Com1BaudRate 9600
```

Output:

```
[set IMM.PowerRestorePolicy "Always on"]  
IMM.PowerRestorePolicy=Always on  
[set IMM.PowerOnAtSpecifiedTime_Hour 05]  
IMM.PowerOnAtSpecifiedTime_Hour=05  
[set IMM.PowerOnAtSpecifiedTime_Minute 00]  
IMM.PowerOnAtSpecifiedTime_Minute=00  
[set IMM.PowerOnAtSpecifiedTime_Second 00]  
IMM.PowerOnAtSpecifiedTime_Second=00  
[set IMM.ShutdownAndPowerOff_WeekDay Sunday]  
IMM.ShutdownAndPowerOff_WeekDay=Sunday  
[set IMM.HTTPPort 81]  
IMM.HTTPPort=81  
[set IMM.SSLPort 441]  
IMM.SSLPort=441  
[set IMM.TelnetPort 21]  
IMM.TelnetPort=21  
[set SYSTEM_PROD_DATA.SysEncloseAssetTag "Server Tag"]  
SYSTEM_PROD_DATA.SysEncloseAssetTag=Server Tag  
[set iSCSI.InitiatorName "iqn.2009-01.com.ibm:InitiatorName"]  
iSCSI.InitiatorName=iqn.2009-01.com.ibm:InitiatorName  
[set uEFI.Com1BaudRate 9600]  
uEFI.Com1BaudRate=9600
```

Example 2

Batch file:

```
show CMOS_PrimaryBootDevice1  
show CMOS_PrimaryBootDevice2  
show CMOS_PrimaryBootDevice3  
show CMOS_PrimaryBootDevice4
```

Output:

```
[show CMOS_PrimaryBootDevice1]  
CMOS_PrimaryBootDevice1=CD ROM  
[show CMOS_PrimaryBootDevice2]  
CMOS_PrimaryBootDevice2=Diskette Drive 0
```



```
[show CMOS_PrimaryBootDevice3]
CMOS_PrimaryBootDevice3=Hard Disk 0
[show CMOS_PrimaryBootDevice4]
CMOS_PrimaryBootDevice4=Network
```

Example 3

Batch file:

```
set CMOS_PrimaryBootDevice1 "Network"
set CMOS_PrimaryBootDevice2 "Hard Disk 0"
set CMOS_PrimaryBootDevice3 "Diskette Drive 0"
set CMOS_PrimaryBootDevice4 "CD ROM"
```

Output:

```
[set CMOS_PrimaryBootDevice1 "Network"]
CMOS_PrimaryBootDevice1=Network
[set CMOS_PrimaryBootDevice2 "Hard Disk 0"]
CMOS_PrimaryBootDevice2=Hard Disk 0
[set CMOS_PrimaryBootDevice3 "Diskette Drive 0"]
CMOS_PrimaryBootDevice3=Diskette Drive 0
[set CMOS_PrimaryBootDevice4]
CMOS_PrimaryBootDevice4=CD ROM
{set CMOS_PrimaryBootDevice1}
CMOS_PrimaryBootDevice1=CD ROM
[show CMOS_PrimaryBootDevice2]
CMOS_PrimaryBootDevice2=Diskette Drive 0
[show CMOS_PrimaryBootDevice3]
CMOS_PrimaryBootDevice3=Hard Disk 0
[show CMOS_PrimaryBootDevice4]
CMOS_PrimaryBootDevice4=Network
```

Comparedefault command

Use the comparedefault command to compare current values to default values for one or more settings.

Syntax

The syntax of the **batch** command is

```
asu comparedefault [setting | class] [-v] [-nx] [connect_options]
```

where

where *setting* is the name of an ASU setting and *class* is the name of an ASU class of settings.

Notes

1. If the optional -v parameter is specified, the output is verbose.
2. If the optional -nx parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. x can be a number from 1 through 8. If the -nx parameter is not specified, the operation is performed on the primary node (node 1).
3. The connect options are defined for only IMM-based servers. The --host ip_address connect option is required if you connect remotely to the IMM. The --user user_id and --password password connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The --user user_id and --password password connect options are not required if you are using the local KCS interface.

Output

The output of the **comparedefault** command shows the current and default values for one or all settings. Without the -v parameter:

```
<setting 1>=<current value 1><<default value1>>
<setting 2>=<current value 2><<default value2>>
.
.
•<setting n>=<current value n><<default valuen>>
```

With the -v parameter:

```
<setting 1>: <setting 1 description> = <current value 1>,
<default value 1> (default)
<setting 2>: <setting 2 description> = <current value 2>,
<default value 2> (default)
.
.
.
<setting n>: <setting n description> = <current value n>,
<default value n> (default)
```

The **comparedefault** command and corresponding output are shown in the following examples.

Example 1

Command line:

```
asu comparedefault uefi.com1baudrate
```

Output:

```
uEFI.Com1BaudRate=115200<115200>
```

Example 2

Command line:

```
asu comparedefault CMOS_PrimaryBootDevice1
```

Output:

```
CMOS_PrimaryBootDevice1=Network<CD ROM>
```

Example 3

Command line:

```
asu comparedefault CMOS_PrimaryBootDevice2 -v
```

Output:

```
CMOS_PrimaryBootDevice2: Second Startup Device = Network, CD
ROM (default)
```

Example 4

Command line:

```
asu comparedefault bios
```

Output:

```
CMOS_DisketteA=1.44 MB 3.5"<1.44 MB 3.5">
CMOS_CRTRequired=Disabled<Enabled>

•
•
•
CMOS_OSUSBControl=Other OS<Other OS>
```

Createuuid command

Use the **createuuid** command to generate and set the Universally Unique Identifier (UUID). This command is for IMM-based servers only.

Syntax

Note: When you set the UUID, the command requires the setting name. You can use the **asu show** command to identify the setting.

The syntax of the **createuuid** command is:

```
asu createuuid UUID_setting_name [connect_options]
```

Notes

1. The *UUID_setting_name* is usually defined as `SYSTEM_PROD_DATA.SysInfoUUID`.
2. To view the actual setting name, which can vary from server to server, use the **show** command to list the setting name that belongs to the `SYSTEM_PROD_DATA` group. To view the available groups, use the **showgroups** command.
3. The connect options are defined for only IMM-based servers. The `--host ip_address` connect option is required if you connect remotely to the IMM. The `--user user_id` and `--password password` connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The `--user user_id` and `--password password` connect options are not required if you are using the local KCS interface.

Output

To see the value that is set by the **createuuid** command, use the **show** command.

```
asu show SYSTEM_PROD_DATA.SysInfoUUID
```

The output of the **show** command is the new randomly generated UUID.

```
SYSTEM_PROD_DATA.SysInfoUUID=801a3b663e82b60104af001a64e50c94
```

The **createuuid** command and corresponding output are shown in the following examples.

Command line:

```
asu createuuid SYSTEM_PROD_DATA.SysInfoUUID
```

Output:

The command does not produce output. To see the generated UUID, use the **show** command.

```
asu show SYSTEM_PROD_DATA.SysInfoUUID
SYSTEM_PROD_DATA.SysInfoUUID=801a3b663e82b60104af001a64e50c94
```

Delete command

Use the **delete** command to delete an instance of a setting. This command is for IMM-based servers only.

Syntax

Note: Using this command to delete the instance of a setting that is a record key results in all other settings with the same instance number to be deleted.

The syntax of the **delete** command is

```
asu delete setting_instance [-nx] [connect_options]
```

where

setting_instance is the name of an instance of a setting to delete. Use the command **asu show all** to show a list of available setting instances.

Use the **asu showvalues** setting command to show a list of all values that are available for the setting.

Limitations

Settings can have a minimum number of allowed instances. The delete command does not allow you to delete an instance if doing so causes the number of instances to drop below the minimum number of allowed instances. To determine the minimum number of instances allowed, use the command:

```
asu showvalues --instances
```

The output for each setting that can have instances will be displayed, along with the minimum and maximum number of allowed instances.

Also, deleting instances that are part of a record is allowed for only the record key setting. To determine whether or not a setting is part of a record, use the command:

```
asu showvalues --instances
```

The output for each setting that can have instances will be displayed, along with the record information. See the **asu showvalues** command for details about the record information.

Notes

1. Values that contain spaces must be enclosed in quotation marks ("). If a value contains quotation marks, add a backslash (\) before each quotation mark in the value.
2. If the optional -nx parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the -nx parameter is not specified, the operation is performed on the primary node (node 1).
3. The connect options are defined for only IMM-based servers. The --host ip_address connect option is required if you connect remotely to the IMM. The --user user_id and --password password connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The --user user_id and --password password connect options are not required if you are using the local KCS interface.

Output

The **delete** command and corresponding output are shown in the following examples.

Deleting an instance that exists

Command line:

```
asu delete IMM.Community_Name.1
```

Output:

```
Deleting IMM.Community_Name.1
Waiting for command completion status
Command completed successfully
```

Deleting an instance that does not exist

Command line:

```
asu delete IMM.Community_Name.3
```

Output:

```
Could not find setting IMM.Community_Name.3
```

Deleting an instance that causes the number of instances to drop below the minimum allowed number of instances

Command line:

```
asu delete IMM.MacAddress.1
```

Output:

```
The setting IMM.MacAddress.1 cannot be deleted. Too few instances.
```

Deleting an instance that is in a record but is not the record key

Command line:

```
asu delete iSCSI.ConnectTimeout.1
```

Output:

```
The setting iSCSI.ConnectTimeout.1 is part of a record and cannot be
deleted. To delete the entire instance of the record you must
delete the record's key setting, iSCSI.AttemptName.1.
```

Deletecert command

Use the **deletecert** command to delete a certificate on IMM. This command is for IMM-based servers only.

Syntax

Note: Only Client Trusted Certificate setting is supported for this command. See "Supported commands for IMM-based certificate management" to learn more about supported commands of settings.

The syntax of the **deletecert** command is

```
asu deletecert setting_[-nx] [connect_options]
```

Notes

1. If the optional `-nx` parameter is specified, the ASU performs the operation for node `x`, where `x` is the selected node in a multi-node system. `x` can be a number from 1 through 8. If the `-nx` parameter is not specified, the operation is performed on the primary node (node 1).
2. The connect options are defined for only IMM-based servers. The `--host ip_address` connect option is required if you connect remotely to the IMM. The `--user user_id` and `--password password` connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The `--user user_id` and `--password password` connect options are not required if you are using the local KCS interface.

Deleting SSL Client Trusted Certificate 1

The delete command and corresponding output are shown in the following examples.

Command line:

```
asu deletecert IMM.SSL_CLIENT_TRUSTED_CERT1
```

Output:

```
Certificate was deleted successfully!
```

Dump command

Use the **dump** command to see the raw contents of CMOS memory. This command is for BIOS-based servers only.

Syntax

The syntax of the **dump** command is

```
asu dump [-nx]
```

Note: If the optional `-nx` parameter is specified, the ASU performs the operation for node `x`, where `x` is the selected node in a multi-node system. `x` can be a number from 1 through 8. If the `-nx` parameter is not specified, the operation is performed on the primary node (node 1).

Output

The output of the **dump** command is a table that contains the current raw hexadecimal contents of CMOS memory. The CMOS memory setting area is preceded by `<` and followed by `>`. CMOS memory locations that are outside the CMOS memory setting area are denoted by `*`. The ASU uses information from the CMOS memory map to determine how to access the second bank of CMOS memory. It also uses CMOS memory limit information from the map to determine the CMOS memory setting area.

The **dump** command and corresponding output are shown in the following example.

Command line:

```
asu dump
```

Output:

```

0 1 2 3 4 5 6 7 8 9 A B C D E F
00: 38*00*14*00*10*00*01*07*07*03*26*02*50*80<00 00
10: 40 00 00 7e 01 80 02 ff ff 00 00 f2 00 86 c0 c8
20: 60 00 00 00 00 00 00 00 00 00 02 27 50 07 18
30: ff ff 20 05 0d 06 00 00 c0 00 f0 ff 00 ca 00 00
40: 00 00 00 00 00 00 00 00 00 00 00 20 52 00 00 60
50: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
60: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 24
70: 10 42 08 21 00 00 81 4a 2a 00 2e 28 00 30 00 00
80: 00 00 ff 01 00>00*00*00*00*00*00*00*00*00*00
90: 00*00*00*00*00*00*00*00*00*00*00*00*00*00*00
a0: 00*00*00*00*00*00*00*00*00*00*00*00*00*00*00
b0: 00*00*00*00*00*00*00*00*00*00*00*00*00*00*00
c0: 00*00*00*00*00*00*00*00*00*00*00*00*00*00*00
d0: 00*00*00*00*00*00*00*00*00*00*00*00*00*00*00
e0: 00*00*00*00*00*00*00*00*00*00*00*00*00*00*00
f0: 00*00*00*32*08*9c*00*62*90*5c*cd*ff*4f*5f*ba*9f

```

Encrypt command

Use the **encrypt** command to encrypt a setting value.

Syntax

The value that you encrypt can be any valid string. If the value contains spaces, it must be enclosed in double-quotes (") so that you can use the encrypted value in the **setenc** command.

The syntax of the **encrypt** command is

```
asu encrypt <value>
```

where

value is the valid value of an ASU setting.

Output

The output of the **encrypt** command shows the encrypted string of data that you enter. For example, if you enter "value," the output is s56RrL6.

The **encrypt** command and corresponding output are shown in the following examples.

Command line:

```
asu encrypt "something to input"
```

Output:

```
pzMRbH7QfvsPWGtRWacRmL7T
```

Command line:

```
asu encrypt something_to_input
```

Output:

```
pzMRbH7QfvsPWGtRWacRmL7T
```

Export command

Use the **export** command to export a selected certificate or certificate sign request (CSR) file.

Syntax

This **export** command is only for the Remote Supervisor Adapter and Remote Supervisor Adapter II and IMM. Specially, out-of-band mode of the command is supported only for IMM. This command fails if the certificate or certificate sign request is not available in the Remote Supervisor Adapter, Remote Supervisor Adapter II, or IMM.

The **export** command generates a binary file that is saved in the current directory.

Note: To learn more about supported commands of settings for IMM-based servers, see "Supported commands for IMM-based certificate management."

The syntax of the **export** is

```
asu export setting certificate_binary_file [-nx] [connect_options]
```

where

setting is the name of a valid ASU setting and *certificate_binary_file* is the name of a file that is generated with the valid certificate information that is provided by the Remote Supervisor Adapter, Remote Supervisor Adapter II, or IMM. To learn more about supported command of settings, see "Supported commands for IMM-based certificate management."

Notes

1. If the optional -nx parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the -nx parameter is not specified, the operation is performed on the primary node (node 1).
2. The connect options are defined for IMM-based servers only. The --host ip_address connect option is required if you connect remotely to the IMM. The --user user_id and --password password connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The --user user_id and --password password connect options are not required if you are using the local KCS interface.

Output

The output of the **export** command is a binary file and a message that indicates that the Remote Supervisor Adapter, Remote Supervisor Adapter II, or IMM completed the command successfully.

The export command and corresponding output are shown in the following example.

Exporting a certificate from RSA

Command line:

```
asu export RSA_SSL_Client_PrivateKey_Export asu.cert
```


Output:

```
Certificate was exported to the file successfully!  
( asu.cert file is saved in the current directory)
```

Exporting a certificate sign request file from IMM

The IMM external IP address is 9.5.51.37.

Command line:

```
asu export IMM.SSL_HTTPS_SERVER_CSR asu.cert --host 9.5.51.37
```

Output:

```
Certificate was exported successfully!  
( asu.cert file in saved in the current directory)
```

Generate command

Use the **generate** command to generate a private key and public key pair with a self-signed certificate or a certificate sign request.

The **generate** command is targeted to only the Remote Supervisor Adapter, Remote Supervisor Adapter II, or IMM. Specially, out-of-band mode of the command is supported for IMM only. The generate command generates a private key and public key pair with a self-signed certificate or certificate sign request (CSR). The generation can take a few seconds to complete, depending on the state of the Remote Supervisor Adapter, Remote Supervisor Adapter II, or IMM.

The **generate** command requires an Extensible Markup Language (XML) file that contains the certificate information that you want in the directory from which the ASU is running. When you extract the ASU files, a template file (template.xml) is extracted. This file provides an XML file with the correct syntax. Modify this XML file with the information you need to generate the selected certificate.

To learn more about supported commands of settings for IMM-based servers, see "Supported commands for IMM-based certificate management."

Note: The XML file supports the self-signed certificate request and the certificate sign request (CSR). The start and end tag for the self-signed certificate is `new_key_and_self_signed_cert_info`. The start and end tag for a certificate sign request is `new_key_and_cert_sign_req_info`.

Template.xml

```
<?xml version="1.0" encoding="utf-8"?>  
<asu version="2.1">  
  <new_key_and_self_signed_cert_info>  
    <item type="Required">  
      <vectorID>0001</vectorID>  
      <name>countryName</name>  
      <value minlen="2" maxlen="2">xx</value>  
    </item>  
    <item type="Required">  
      <vectorID>0001</vectorID>  
      <name>stateOrProvinceName</name>  
      <value minlen="1" maxlen="30">xx</value>  
    </item>  
    <item type="Required">  
      <vectorID>0001</vectorID>  
      <name>localityName</name>
```

```

    <value minlen="1" maxlen="50">xx</value>
  </item>
  <item type="Required">
    <vectorID>0001</vectorID>
    <name>organizationName</name>
    <value minlen="1" maxlen="60">xx</value>
  </item>
  <item type="Required">
    <vectorID>0001</vectorID>
    <name>commonName</name>
    <value minlen="1" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>Name</name>
    <value minlen="1" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>emailAddress</name>
    <value minlen="1" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>validityPeriod</name>
    <value minlen="0" maxlen="2">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>organizationalUnitName</name>
    <value minlen="0" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>Surname</name>
    <value minlen="0" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>givenName</name>
    <value minlen="0" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>Initials</name>
    <value minlen="0" maxlen="20">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>dnQualifier</name>
    <value minlen="0" maxlen="60">xx</value>
  </item>
</new_key_and_self_signed_cert_info>
<new_key_and_cert_sign_req_info>
  <item type="Required">
    <vectorID>0001</vectorID>
    <name>countryName</name>
    <value minlen="2" maxlen="2">xx</value>
  </item>
  <item type="Required">
    <vectorID>0001</vectorID>
    <name>stateOrProvinceName</name>
    <value minlen="1" maxlen="30">xx</value>
  </item>
  <item type="Required">
    <vectorID>0001</vectorID>
    <name>localityName</name>

```

```

    <value minlen="1" maxlen="50">xx</value>
  </item>
  <item type="Required">
    <vectorID>0001</vectorID>
    <name>organizationName</name>
    <value minlen="1" maxlen="60">xx</value>
  </item>
  <item type="Required">
    <vectorID>0001</vectorID>
    <name>commonName</name>
    <value minlen="1" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>Name</name>
    <value minlen="1" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>emailAddress</name>
    <value minlen="1" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>organizationalUnitName</name>
    <value minlen="0" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>Surname</name>
    <value minlen="0" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>givenName</name>
    <value minlen="0" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>Initials</name>
    <value minlen="0" maxlen="20">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0001</vectorID>
    <name>dnQualifier</name>
    <value minlen="0" maxlen="60">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0002</vectorID>
    <name>challengePassword</name>
    <value minlen="6" maxlen="30">xx</value>
  </item>
  <item type="Optional">
    <vectorID>0002</vectorID>
    <name>unstructuredName</name>
    <value minlen="1" maxlen="60">xx</value>
  </item>
</new_key_and_cert_sign_req_info>
</asu>

```

Table 60. Explanation of XML

Item	Description
Country name	The two-letter ISO abbreviation for your country

Table 60. Explanation of XML (continued)

Item	Description
State or Province name	The state or province where your organization is located. Do not abbreviate.
Locality name	The city where your organization is located
Organization name	The exact legal name of your organization. Do not abbreviate.
Common name	A fully qualified domain name that resolves to the SSL VPN device. For example, to secure the URL https://ssl.yourdomain.com, the common name of the certificate sign request should be ssl.yourdomain.com.
Name	Optional field for entering a contact name
Email address	Optional field for entering a contact email address
Organization unit name	Optional field for the name of the unit in your organization
Surname	Optional field for entering the surname of a contact person
givenName	Optional field for entering the given name of a contact name
Initials	Optional field for entering the initials of a contact name
dnQualifier	Optional field for entering the domain name qualifier
Challenge password	Optional attribute. If you specify a challenge password in the certificate sign request, you must know the challenge password if you want to revoke the certificate later.
unstructuredName	Optional field for entering the unstructured name for a contact

Notes

1. **xx** is a user input field. The minimum length for each vector (item) is identified by **minlen=**, and the maximum length is identified by **maxlen=**. For example, for the vector named **stateOrProvinceName**, the **minlen** is 1, the **maxlen** is 30, and a valid **xx** value is Vermont.
2. Items that are identified as "Required" have to be updated with user data. Items that are identified as "Optional" do not have to be updated. If the optional items are not updated, remove them from the XML file.
3. The ASU requires that you provide the XML file with the correct data for the **generate** command to run correctly.

Syntax

The syntax of the **generate** command is

```
asu generate setting xml_file [-nx] [connect_options]
```

where

setting is the name of a valid Remote Supervisor Adapter, Remote Supervisor Adapter II, or IMM setting and *xml_file* is the name of an XML file that contains valid information.

When generating a SSH key in IMM, the syntax of the **generate** command is

```
asu generate setting [-nx] [connect_options]
```

because the *xml_file* is not required for generating an SSH key.

Notes®

1. If the optional **-nx** parameter is specified, the ASU performs the operation for node *x*, where *x* is the selected node in a multi-node system. Node *x* can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).
2. The connect options are defined for IMM-based servers only. The **--host ip_address** connect option is required if you connect remotely to the IMM. The **--user user_id** and **--password password** connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The **--user user_id** and **--password password** connect options are not required if you are using the local KCS interface.

Output

The output of the **generate** command is a message that indicates that the Remote Supervisor Adapter, Remote Supervisor Adapter II, or IMM has completed the command successfully.

The **generate** command for a self-signed certificate and corresponding output are shown in the following example.

Command

Command line:

```
asu generate RSA_Generate_SSL_Client_Certificate asu.xml
```

Output:

```
Certificate was generated successfully!
```

Command line:

```
asu generate IMM.SSL_HTTPS_SERVER_CERT asu.xml
```

Output:

```
Certificate was generated successfully!
```

The **generate** command for a certificate sign request certificate and corresponding output are shown in the following example:

Command line:

```
asu generate IMM.SSL_HTTPS_SERVER_CSR asu.xml
```

Output:

```
Certificate was generated successfully!
```

The **generate** command for SSH Key and corresponding output are shown in the following example:

Command line:

```
asu generate IMM.SSH_SERVER_KEY
```

Output:

```
Certificate was generated successfully!
```

Help command

Use the **help** command to view help for one or more settings. For BIOS settings, the help from this command is the same help that you access when you press F1 during startup.

Syntax

The syntax of the **help** command is
`asu help [setting | class] [connect_options]`

where

setting is the name of an ASU setting and *class* is the name of an ASU class of settings.

Note: The connect options are defined for IMM-based servers only. The `--host ip_address` connect option is required if you connect remotely to the IMM. The `--user user_id` and `--password password` connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The `--user user_id` and `--password password` connect options are not required if you are using the local KCS interface.

Output

The output of the **help** command shows the help text for one or more settings. The name and description of the setting are followed by the help title and the help text.

```
<setting 1>: <setting description 1>
<help title 1>
-----
<help text 1>
<setting 2>: <setting description 2>
<help title 2>
-----
<help text 2>

•
•
•
<setting n>: <setting description n>
<help title n>
-----
<help text n>
```

The **help** command and corresponding output are shown in the following examples.

Command line:

```
BootOrder.BootOrder: Boot Order
Help for Boot Order
-----
```

Output:

Specify, from the list of bootable devices, the desired order in which to search for bootable media. One or more items from the list may be specified.

Command line:

```
asu help CMOS_PrimaryBootDevice3
```

Output:

```
CMOS_PrimaryBootDevice3: Third Startup Device
```

```
Help for Startup Device
```

```
-----  
The system uses a startup sequence to determine which device  
will be the startup device. The startup device is the  
diskette drive, hard disk, or network adapter which will be used  
to load the operating system. This field specifies the third  
device for which a system start will be attempted. If the  
start from this device fails, the system will attempt to  
start from the fourth startup device.
```

Command line:

```
asu help bios
```

Output:

```
CMOS_DisketteA: Diskette Drive A
```

```
Help for Diskette Drive
```

```
-----  
If you change or add a diskette drive, you might need to  
use this option to set the correct type.
```

```
CMOS_CRTRequired: Displayless Operation
```

```
Help for Displayless Operation
```

```
-----  
This option suppresses the error messages that  
normally occur when no video device is present.
```

-
-
-

```
CMOS_OSUSBControl: OS USB Selection
```

```
Operating System USB Support
```

```
-----  
Choose which operating system you will be using  
for RSA II USB support.
```

Import command

Use the **command** to import a certificate into the Remote Supervisor Adapter, Remote Supervisor Adapter II, or IMM.

Syntax

The import command is targeted to a Remote Supervisor Adapter , Remote Supervisor Adapter II or IMM. Use the command to import a certificate into the Remote Supervisor Adapter or Remote Supervisor Adapter II command or IMM. Specially, out-of-band mode of the command is supported only for IMM. The import command requires a binary certificate file that is in the same directory from which the ASU is running.

You are only allowed to import the CA-signed certificate (it differs from self-signed) into section HTTPS Server Certificate Management and IBM Systems Director over HTTPS Certificate Management.

For section SSL Client Certificate Management, the first two settings
SSL_LDAP_CLIENT_CERT, SSL_LDAP_CLIENT_CSR,

also only permit CA-signed certificate to be imported. But for the other three settings

- SSL_CLIENT_TRUSTED_CERT1
- SSL_CLIENT_TRUSTED_CERT2
- SSL_CLIENT_TRUSTED_CERT3

both self-signed and CA-signed are allowed to be imported.

The certificate to be imported should be in DER form. If you want to set up your own independent certificate authority, and sign your certificate sign request file, see Using the OpenSSL to set up a certificate authority and Sign a certificate sign request.

Note: See Supported commands for IMM-based certificate management to learn more about supported commands of settings for IMM-based server. For settings:

SSL_CLIENT_TRUSTED_CERT1
SSL_CLIENT_TRUSTED_CERT2
SSL_CLIENT_TRUSTED_CERT3

If the certificate already exists, you must delete it before import the certificate.

The syntax of the **import** command is

```
asu import setting certificate_binary_file [-nx] [connect_options]
```

where

setting is the name of an ASU setting and *certificate_binary_file* is the name of a file that is generated with the valid certificate information.

Notes

1. If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).
2. The connect options are defined for IMM-based servers only. The **--host ip_address** connect option is required if you connect remotely to the IMM. The **--user user_id** and **--password password** connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The **--user user_id** and **--password password** connect options are not required if you are using the local KCS interface.

Output

The output of the **import** command is a message that indicates that the Remote Supervisor Adapter, Remote Supervisor Adapter II, or IMM has completed the command successfully.

You are only allowed to import the signed certificate in DER form. See Using the OpenSSL to set up a certificate authority and sign a certificate sign request to learn about how to set up your own CA.

The **import** command and corresponding output are shown in the following examples.

Command line:

```
asu import RSA_Import_Trusted_Certificate_1 asu.cert
```

Output:

```
Certificate was imported successfully!
```

Command line:

```
asu import IMM.SSL_HTTPS_SERVER_CERT asu.cert
```

Output:

```
Certificate was imported successfully!
```

Loaddefault command

Use the **loaddefault** command to load default values for one or more settings.

Limitations

- Not all settings in the definition or configuration file have assigned default values.
- The **loaddefault** command sets the default settings only for the settings that have defined default values in the configuration file.
- On BIOS-based servers, the **loaddefault** command should not be viewed or used as a general restore factory defaults command.
- On IMM-based servers, when the **loaddefault** command is run remotely (using the `--host` connectivity option) the authentication and password class settings are not applied.
- On IMM-based servers that are running the ASU 3.00, the **loaddefault** command is not functionally equivalent to the "Restore Defaults" function that is defined in the IMM web interface. You have to use the IMM web interface or the server Setup utility settings to restore the IMM settings to the factory defaults.
- On IMM-based servers that are running the ASU 3.01 or later (and have the required IMM firmware that is described in Using the ASU to configure settings in IMM-based servers), the **loaddefault** command is now functionally equivalent to the "Restore Defaults" function that is defined in the IMM web interface. Settings from other groups are still not the equivalent of the 'restore factory defaults' function that is available through the server Setup utility (F1 Setup).

Note: For the ASU 3.01, some instances are deleted when you run the **loaddefault** command. To determine which instances are deleted, use the **showdefault** command. Instances that have a default value of "remove" are deleted.

The following example shows using the **showdefault** command on a setting that has a default action of remove and then performing the **loaddefault** command on the setting.

Command line:

```
asu showdefault IMM.LoginId.7
```

Output:

IMM.LoginId.7=<remove>

Command line:

```
asu loaddefault IMM.LoginId.7
```

Output:

Could not find setting IMM.LoginId.7

Syntax

The syntax of the **loaddefault** command is

```
asu loaddefault [setting | class] [-v] [-nx] [connect_options]
```

where

setting is the name of an ASU setting and *class* is the name of an ASU class of settings.

Notes

1. If the optional **-v** parameter is specified, the output is verbose.
2. If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).
3. The connect options are defined for IMM-based servers only. The **--host ip_address** connect option is required if you connect remotely to the IMM. The **--user user_id** and **--password password** connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The **--user user_id** and **--password password** connect options are not required if you are using the local KCS interface.

Output

The output of the **loaddefault** command is displayed if a setting is changed to the default value. If a setting is already set to the default value, no output is displayed. If a setting is not already set to the default value, the value is changed, and the output is shown as the output of the set command.

Note: Starting with the ASU 3.01, there are exceptions on IMM-based servers. Performing the loaddefault command on a group of settings (for example, IMM, UEFI, SYSTEM_PROD_DATA, BOOT_ORDER, and all) can trigger a reset to factory defaults. If the group is being reset to factory defaults, the setting names and their new values are not displayed. Instead, the ASU displays the message Issuing reset of IMM.

Without the **-v** parameter:

```
<setting 1>=<default value 1>  
<setting 2>=<default value 2>
```

```
•  
•  
•
```

```
<setting n>=<default value n>
```

With the **-v** parameter:

```
<setting 1>: <setting 1 description> = <default value 1>  
<setting 2>: <setting 2 description> = <default value 2>
```

-
-
-

```
<setting n>: <setting n description> = <default value n>
```

The **loaddefault** command and corresponding output are shown in the following examples.

Command line:

```
asu loaddefault uEFI.Com1BaudRate
```

Output:

```
uEFI.Com1BaudRate=115200
```

Command line:

```
asu loaddefault CMOS_CRTRequired
```

Output:

```
CMOS_CRTRequired=Enabled
```

Command line:

```
asu loaddefault CMOS_KbdRequired -v
```

Output:

```
CMOS_KbdRequired: Keyboardless Operation = Enabled
```

Command line:

```
asu loaddefault bios
```

Output:

```
CMOS_DisketteA=1.44 MB 3.5"  
CMOS_CRTRequired= Enabled  
CMOS_WakeOnLAN=Enabled
```

Command line (IMM-based servers with ASU 3.01 or later):

```
asu loaddefault IMM
```

Output:

```
Issuing reset of IMM  
The IMM has started the reset. Waiting for the reset to complete.  
Connected to IMM at IP address 169.254.95.118  
Reset completed successfully
```

Command line (IMM-based servers with ASU 3.01 or later):

```
asu loaddefault all
```

Output:

```
Connected to IMM at IP address 9.5.107.158  
SYSTEM_PROD_DATA.SysInfoProdName=  
SYSTEM_PROD_DATA.SysInfoProdIdentifier=  
SYSTEM_PROD_DATA.SysInfoSerialNum=  
SYSTEM_PROD_DATA.SysInfoUUID=  
SYSTEM_PROD_DATA.SysEncloseAssetTag=  
uEFI.TurboModeEnable=Disable
```

```
uEFI.OperatingMode=Custom Mode
.
.
.
Issuing reset of IMM
The IMM has started the reset. Waiting for the reset to complete.
Connected to IMM at IP address 169.254.95.118
Reset completed successfully
```

Patchadd command

Use the **patchadd** command to add support for a particular firmware setting to the ASU. This command is for BIOS-based servers only.

Depending on the system from which you are running this command, a BIOS patchadd might not occur because the BIOS patch is already contained in the BIOS ROM.

Syntax

The syntax of the patchadd command is

```
asu patchadd patch_filename
```

where

patch_filename is the name of a patch file. For a description of the patch file format, see Using ASU patches.

Output

The output of the **patchadd** command shows the success or failure of adding a patch. If the patch succeeded, a message is shown indicating that a new patch was written to the executable file, and information about the patch is provided. If the patch failed, a message is shown indicating why the patch failed.

If the patch command is successful, the output looks similar to this example:

```
Wrote new patch <<patch identification>> to <executable>
Wrote patch footer to <executable>
```

If the patch command is not successful (duplicate), the output looks similar to this example:

```
<<patch identification>> already patched.
Wrote patch footer to <executable>
```

The **patchadd** command and corresponding output are shown in the following examples.

Successful patch

Command line:

```
asu patchadd T2C125A.def
```

Output:

```
Wrote new patch <T2[25->25] (BIOS)> to ./asu
Wrote patch footer to ./asu
```

System BIOS already has a patch

Command line:

```
asu patchadd T2C125A.def
```

Output:

```
BIOS def file already defined in BIOS ROM!
```

Patchextract command

Use the **patchextract** command to extract a patch from the ASU to a patch file. This command is for BIOS-based servers only.

You can patch the extracted patch file to another version of the ASU using the **patchadd** command.

Syntax

The syntax of the **patchextract** command is

```
asu patchextract patch_number patch_filename
```

where

patch_number is the patch number to extract and *patch_filename* is the name of the patch file that is extracted.

To show the patch number for each patch, use the **patchlist** command.

Output

The output of the **patchextract** command shows the success or failure of the extraction operation. If the extraction is successful, a message is displayed indicating which patch was extracted and the name of the file to which it was extracted.

```
Extracted patch <patch number>: <<patch identification>> to <patch filename>
```

The **patchextract** command and corresponding output are shown in the following example.

Command line:

```
asu patchextract 1 T2.def
```

Output:

```
Extracted patch 1: <T2[25->25] (BIOS)> to T2.def
```

Patchlist command

Use the **patchlist** command to display the patches that are applied to the ASU. This command is for BIOS-based servers only.

Syntax

The syntax of the **patchlist** command is

```
asu patchlist
```

Output

The output of the **patchlist** command is a list of patches. Each patch has a patch number and patch identification.

Patch <patch number 1>: <<patch identification 1>>

Patch <patch number 2>: <<patch identification 2>>

•
•
•

Patch <patch number n>: <<patch identification n>>

The **patchlist** command and corresponding output are shown in the following example.

Command line:

```
asu patchlist
```

Output:

```
Patch 1: <T2[25->25] (BIOS)>
```

```
Patch 2: <GE[00->99] (RSA)>
```

```
Patch 3: <GE[46->46] (BIOS)>
```

Patchremove command

Use the **patchremove** command to remove a patch from the ASU. This command is for BIOS-based servers only.

Depending on the system from which you are running the **patchremove** command, the BIOS patch might not be removed because the patch is contained in the BIOS ROM.

Syntax

The syntax of the **patchremove** command is

```
asu patchremove patch_number
```

where

patch_number is the patch number to extract. Use the **patchlist** command to show the patch number for each patch.

Output

The output of the **patchremove** command shows the success or failure of the removal operation. If the removal is successful, messages are displayed that indicate the removal of a patch and the copying of every other patch to the temporary executable file.

```
Copied patch <<patch identification>> to <temporary executable>
```

```
Removing patch <<patch identification>> from <executable>
```

The **patchremove** command and corresponding output are shown in the following examples.

Command line:

```
asu patchremove 2
```

Output:

```
Copied patch <T2[25->25] (BIOS)> to smep2tmp-9yFP0a
Removing patch <GE[00->99] (RSA)> from ./asu
```

The **patchremove** command is attempting to remove a BIOS patch that is in BIOS ROM and the corresponding output are shown in the following example.

Command line:

```
asu patchremove 3
```

Output:

```
Cannot remove patch in BIOS ROM, patch <T2[25->25]. (BIOS)> is not removed.
```

Readraw command

Use the **readraw** command to read raw CMOS data and save it in a file to use on other systems by using the **writeraw** command. This command is for BIOS-based servers only.

Syntax

The syntax of the **readraw** command is

```
asu readraw filename [-nx]
```

where

filename is the name of a file to which the raw CMOS data is saved.

Note: If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).

Output

The output of the **readraw** command is a message that indicates that the raw read is completed.

Command line:

```
asu readraw CMOSraw.dat
```

Output:

```
Raw CMOS read from CMOS, written to CMOSraw.dat
```

Rebootbmc command

Use the **rebootbmc** command to restart the baseboard management controller. This command is for BIOS-based servers only.

This command is useful because you must restart the system after you make changes to baseboard management controller settings.

Syntax

The syntax of the **rebootbmc** command is

```
asu rebootbmc [-nx]
```

Note: If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).

Output

The output of the **rebootbmc** command is a message that indicates that the restart of the baseboard management controller is completed.

The **rebootbmc** command and corresponding output are shown in the following example.

Command line:

```
asu rebootbmc
```

Output:

```
Rebooting BMC...done
```

Rebootimm command

Use the **rebootimm** command to restart the integrated management module (IMM). This command is for IMM-based servers only.

This command is useful because you must restart the IMM after making changes to IMM settings. This command takes approximately four minutes to complete.

Syntax

The syntax of the **rebootimm** command is

```
asu rebootimm [-nx] [connect_options] [-a]
```

Note: If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).

Notes

1. If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).
2. The connect options are defined for IMM-based servers only. The **--host ip_address** connect option is required if you connect remotely to the IMM. The **--user user_id** and **--password password** connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The **--user user_id** and **--password password** connect options are not required if you are using the local KCS interface.

3. If the option **-a** parameter is specified, ASU restarts all nodes in the same partition. ASU does not support restarting multiple partitions.

Output

The output of the **rebootimm** command is a message that indicates that the restart of the IMM is completed.

The **rebootimm** command and corresponding output are shown in the following example.

Command line:

```
asu rebootimm
```

Output:

```
Connected to IMM at IP address 169.254.95.118
Issuing reset command to IMM.
The IMM has started the reset. Waiting for the reset to complete.
Connected to IMM at IP address 169.254.95.118
Reset completed successfully.
```

Rebootrsa command

Use the **rebootrsa** command to restart the Remote Supervisor Adapter or Remote Supervisor Adapter II. This command is for BIOS-based servers only.

This command is useful because you must restart a Remote Supervisor Adapter or Remote Supervisor Adapter II after you make changes to the Remote Supervisor Adapter settings. This command takes approximately 30 seconds to complete.

Syntax

The syntax of the **rebootrsa** command is

```
asu rebootrsa [-nx]
```

Note: If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).

Output

The output of the **rebootrsa** command is a message that indicates that the restart of the Remote Supervisor Adapter is completed.

The **rebootrsa** command and corresponding output are shown in the following example.

Command line:

```
asu rebootrsa
```

Output:

```
Rebooting RSA/RSA2...done
```

Replicate command

Use the **replicate** command to replicate all settings in the input update configuration file.

On IMM-based servers, the replicate command skips the settings that are defined as "noreplicate." To see the settings that are defined as "noreplicate," use the **show** command and specify the noreplicate class.

Syntax

The syntax of the **replicate** command is

```
asu replicate file_name [connect_options]
```

where

file_name is the name of the file that was created by a previous **asu save** command or by redirecting the output of a previous **asu show** command to a file.

Note: The connect options are defined for IMM-based servers only. The --host ip_address connect option is required if you connect remotely to the IMM. The --user user_id and --password password connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The --user user_id and --password password connect options are not required if you are using the local KCS interface.

Output

The output of the **replicate** command is a list of output from set commands.

```
<setting 1>=<value 1>  
<setting 2>=<value 2>
```

```
•  
•  
•
```

```
<setting n>=<value n>
```

The **replicate** command and corresponding output are shown in the following examples.

Command line (IMM-based servers):

```
asu replicate rep.data
```

rep.data file (Show or save output file):

```
uEFI.Com1BaudRate=115200  
uEFI.Com1DataBits=8  
uEFI.Com1Parity=None  
uEFI.Com1StopBits=1  
uEFI.Com1TextEmul=VT100  
uEFI.Com1ActiveAfterBoot=Enable  
uEFI.Com1FlowControl=Disable
```

Output:

```
uEFI.Com1BaudRate=115200  
uEFI.Com1DataBits=8  
uEFI.Com1Parity=None
```

```
uEFI.Com1StopBits=1
uEFI.Com1TextEmul=VT100
uEFI.Com1ActiveAfterBoot=Enable
uEFI.Com1FlowControl=Disable
```

Command line (BIOS-based servers):

```
asu replicate rep.data
```

rep.data file (Show output file):

```
CMOS_CRTRequired=Enabled
CMOS_KbdRequired=Enabled
```

-
-
-

```
CMOS_OSUSBControl=Other OS
```

Output:

```
CMOS_CRTRequired=Enabled
CMOS_KbdRequired=Enabled
```

-
-
-

```
CMOS_OSUSBControl=Other OS
```

Note: The output is identical to the show output file that is used as input to the **replicate** command.

Resetrsa command

Use the **resetrsa** command to reset the Remote Supervisor Adapter or Remote Supervisor Adapter II to the default settings and then restart it. This command is for BIOS-based servers only.

This command takes approximately 30 seconds to complete.

Syntax

The syntax of the **resetrsa** command is

```
asu resetrsa [-nx]
```

Note: If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).

Output

The output of the **resetrsa** command is a message that indicates that the restart of the Remote Supervisor Adapter is completed.

The **resetrsa** command and corresponding output are shown in the following example.

Command line:

```
asu resetrsa
```

Output:
Rebooting RSA/RSA2...done

Restore command

Use the **restore** command to restore all settings that are defined in the update configuration file on the server.

On IMM-based servers, the backup control settings are not restored by default. To restore the backup control settings on an IMM-based server, you must specify the **-incbackupctl** modifier (see the specific syntax in Table 2).

Limitations

Settings that are defined in the password and authentication class are not restored during a restore operation. To list the settings that belong to the password or authentication class, use the following command:

```
asu showvalues authentication
```

To list only the password class settings, use the following command:

```
asu showvalues password
```

During a restore operation, the ASU does not delete settings that might exist on the target server that is being restored and that are not included in the restore file.

The **restore** command restores the values that are defined in the restore file for those settings that exist in the target system. Therefore, the restore operation should be viewed as restoring values and not as a system settings restore command.

Syntax

The syntax of the **restore** command is

```
asu restore file_name [--incbackupctl ] [-nx] [connect_options]
```

where

file_name is the name of the file that was created by a previous **asu save** command or by redirecting the output of a previous **asu show** command to a file.

Notes

1. The optional **-incbackupctl** parameter is used on a restore operation to specify if the settings defined by the backupctl class are to be included. To list the backupctl class, use the **show** command and specify the backupctl class.
2. The connect options are defined for IMM-based servers only. The **--host ip_address** connect option is required if you connect remotely to the IMM. The **--user user_id** and **--password password** connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The **--user user_id** and **--password password** connect options are not required if you are using the local KCS interface.

Output

Each setting and the restored value are displayed.

```
<setting 1>=<value 1>  
<setting 2>=<value 2>
```

-
-
-

```
<setting n>=<value n>
```

The **restore** command and corresponding output are shown in the following example.

Command line (IMM-based servers):

```
asu restore rep.data
```

rep.data file (Show or save output file):

```
uEFI.Com1BaudRate=115200  
uEFI.Com1DataBits=8  
uEFI.Com1Parity=None  
uEFI.Com1StopBits=1  
uEFI.Com1TextEmul=VT100  
uEFI.Com1ActiveAfterBoot=Enable  
uEFI.Com1FlowControl=Disable
```

Output:

```
uEFI.Com1BaudRate=115200  
uEFI.Com1DataBits=8  
uEFI.Com1Parity=None  
uEFI.Com1StopBits=1  
uEFI.Com1TextEmul=VT100  
uEFI.Com1ActiveAfterBoot=Enable  
uEFI.Com1FlowControl=Disable
```

Command line (BIOS-based servers):

```
asu restore rep.data
```

rep.data file (Show or save output file):

```
CMOS_CRTRequired=Enabled  
CMOS_KbdRequired=Enabled
```

-
-
-

```
CMOS_OSUSBControl=Other OS
```

Output:

```
CMOS_CRTRequired=Enabled  
CMOS_KbdRequired=Enabled
```

-
-
-

```
CMOS_OSUSBControl=Other OS
```

Note: The output is identical to the save or show output file that is used as input in the **restore** command.

Save command

Use the **save** command to save all settings to a file.

By default, backup control settings (settings in the class backupctl) are saved unless an optional modifier is specified. The supported modifiers include `--group`, `--setlist`, and `--excbbackupctl` (see the specific syntax in Table 2).

Limitations

Settings that are defined in the password class or authentication settings (user IDs) class settings are not saved during a save operation. To list the settings that belong to the password class, type the following command:

```
asu showvalues password
```

Syntax

The syntax of the **save** command is

```
asu save file_name [--group group_name | --setlist set_name1..set_nameN]
[--excbbackupctl] [-nx] [connect_options]
```

where

file_name is the name of the file to which the saved settings are written.

Notes

1. If the optional **--group** parameter is specified, only settings that belong to the specified group are saved.
2. If the optional **--setlist** parameter is specified, only settings that belong to the specified list of settings are saved.
3. If the optional **--excbbackupctl** parameter is specified, backup control settings (settings in the class backupctl) are not saved.
4. If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).
5. The connect options are defined for IMM-based servers only. The `--host ip_address` connect option is required if you connect remotely to the IMM. The `--user user_id` and `--password password` connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The `--user user_id` and `--password password` connect options are not required if you are using the local KCS interface.

Output

The output of the save command is a message that indicates that the settings are saved to the file name that is specified in the command.

The **save** command and corresponding output are shown in the following examples.

Command line to save all settings:

```
asu save save.txt
```

Output:

```
Settings saved to save.txt
```

save.txt file (Save output file):

```
CMOS_CRTRequired=Enabled
CMOS_KbdRequired=Enabled
```

-
-
-

```
BMC_CRTRequired=Enabled
BMC_KbdRequired=Enabled
```

-
-
-

Command line to save all BIOS settings:

```
asu save save.txt --group bios
```

Output:

```
Settings saved to save.txt
```

save.txt file (Save output file):

```
CMOS_CRTRequired=Enabled
CMOS_KbdRequired=Enabled
```

-
-
-

Command line to save all IMM settings:

```
asu save save.txt --group IMM
```

Output:

```
Settings saved to save.txt
```

save.txt file (Save output file):

```
IMM.PowerRestorePolicy=Last state
IMM.PowerOnAtSpecifiedTime_Year=0
```

-
-
-

Command line to save only the IMM.LockoutPeriod and UEFI.rehook19 settings:

```
asu save save.txt --setlist IMM.LockoutPeriod uEFI.rehook19
```

Output:

```
Settings saved to save.txt
```

save.txt file (Save output file):

```
IMM.LockoutPeriod=2
uEFI.rehook19=CMOS_KbdRequired=Enabled
```

Command line to save all settings except those in the backupctl class:

```
asu save save.txt --excbackupctl
```

Output:

```
Settings saved to save.txt
```

save.txt file (Save output file):

```
uEFI.TurboModeEnable=Enable
uEFI.ProcessorEistEnable=Enable
```

-
-
-

Command line to save all BIOS settings from node 2:

```
asu save save.txt --group bios -n2
```

Output:

Settings saved to save.txt

save.txt file (Save output file):

```
CMOS_CRTRequired=Enabled
CMOS_KbdRequired=Enabled
```

-
-
-

Set command

Use the **set** command to change the value of a setting or to list a setting.

The **set** command also creates an instance if the instance number does not exist, and if the instance value is less than or equal to the maximum allowed instances for the setting. For more information about instances, see [Instances of settings](#).

Syntax

The syntax of the **set** command is either

```
asu set setting value [-v] [-nx] [connect_options]
```

where

setting is the name of a setting to change.

Use the command **asu show all** to show a list of available settings; *value* is the exact value string to set for the setting.

For settings with a single value, the **asu showvalues** command output is *setting_name=value*.

OR

```
asu set setting value1=value2=valueN [-v] [-nx] [connect_options]
```

where

setting is the name of a setting to change that can accept a list of values.

Use the **asu showvalues** setting command to show a list of all values that are available for the setting.

For settings that allow a list of values, the **asu showvalues** command output syntax is *setting_name==value1=value2=valueN*. The double equal sign (==) shows that the setting can accept single or multiple values in an ordered list.

Notes

1. Values that contain spaces must be enclosed in quotation marks ("). If a value contains quotation marks, add a backslash (\) before each quotation mark in the value.
2. If the optional **-v** parameter is specified, the output is verbose.
3. If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).
4. The connect options are defined for IMM-based servers only. The **--host ip_address** connect option is required if you connect remotely to the IMM. The **--user user_id** and **--password password** connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The **--user user_id** and **--password password** connect options are not required if you are using the local KCS interface.

Output

The output of the **set** command when the **-v** parameter is not specified is the setting name and the new value. When the **-v** parameter is specified, the description of the setting is also shown.

The setting with a single value without the **-v** parameter:

```
<setting>=<new value>
```

Setting with a single value with the **-v** parameter:

```
<setting>: <setting description> = <new value>
```

Setting with multiple values without the **-v** parameter:

```
<setting>=<new value1>=<new value2>=<new valueN>
```

Setting with multiple values with the **-v** parameter:

```
<setting>: <setting description>=<new value1>=<new value2>=<new valueN>
```

The **set** command and corresponding output are shown in the following examples.

Command line:

```
asu set CMOS_CRTRRequired Disabled
```

Output:

```
CMOS_CRTRRequired=Disabled
```

Command line:

```
asu set CMOS_DisketteA "1.44 MB 3.5\\""
```

Output:

```
CMOS_DisketteA=1.44 MB 3.5"
```

Command line:

```
asu set RSAIP_HostIPAddress1 192.168.0.100
```

Output:

```
RSAIP_HostIPAddress1=192.168.0.100
```

Command line:

```
asu set RSAStrng_LoginId2 rsauser
```

Output:

```
RSAStrng_LoginId2=rsauser
```

Command line to set the boot order to be CD/DVD ROM, then diskette, and then Hard Disk 0:

```
asu set BootOrder.BootOrder "CD/DVD Rom=Floppy Disk=Hard Disk 0"
```

Output:

```
BootOrder.BootOrder=CD/DVD Rom=Floppy Disk=Hard Disk 0
```

Create a new record instance and set the record key setting

Command line:

```
asu set iSCSI.AttemptName.2 "MyAttempt2Name"
```

Output:

```
iSCSI.AttemptName.2=MyAttempt2Name
```

Note: All other settings in this record (for example, iSCSI.LocalIp.2 and iSCSI.SubnetMask.2) are set to default values.

To set the other settings for this instance in this record:

Command line:

```
asu set iSCSI.LocalIp.2 "9.5.107.170"
```

Output:

```
iSCSI.LocalIp.2=9.5.107.170
```

The output is followed by this command line:

```
asu set iSCSI.SubnetMask.2 "255.255.255.0"
```

Output:

```
iSCSI.SubnetMask.2="255.255.255.0"
```

Setenc command

Use the **setenc** command to change the value of a setting or to list a setting.

You can apply an *<encrypted value>* to a setting. The encrypted value is a value returned by the **encrypt** command. If *<encrypted value>* contains spaces, it must be enclosed in double-quotes ("").

Syntax

The syntax of the **setenc** command is either

```
asu setenc setting <encrypted value>
```

where

setting is the name of a setting to change.

Use the command **asu show all** to show a list of available settings; *value* is the exact encrypted value string to set for setting.

For settings with a single value, the **asu showvalues** command output is *setting_name=<encrypted value>*.

OR

```
asu set setting value1=value2=valueN [-v] [-nx] [connect_options]
```

where

setting is the name of a setting to change that can accept a list of values.

Use the **asu showvalues** setting command to show a list of all values that are available for the setting.

Output

The output of the **setenc** command when the **-v** parameter is not specified is the setting name and the new value. When the **-v** parameter is specified, the description of the setting is also shown.

The setting with a single value without the **-v** parameter:

```
<setting>=<new value>
```

Setting with a single value with the **-v** parameter:

```
<setting>: <setting description> = <new value>
```

Setting with multiple values without the **-v** parameter:

```
<setting>=<new value1>=<new value2>=<new valueN>
```

Setting with multiple values with the **-v** parameter:

```
<setting>: <setting description>=<new value1>=<new value2>=<new valueN>
```

The **setenc** command and corresponding output are shown in the following examples.

Command line:

```
asu setenc CMOS_CRTRRequired 5vMOYnMPa1
The "5vMOYnMPa1" equals "Enable" encrypted by command encrypt.
```

Output:

```
CMOS_CRTRRequired=Disabled
```

Show command

Use the **show** command to see the current value of one or more settings.

Syntax

The syntax of the **show** command is either

```
asu show [all | --group group_name | setting_name |
--setlist name1..nameN | class] [-v] [-nx] [connect_options]
```

If no setting command modifier or class setting is specified, all settings and their current values are displayed.

Notes

1. If the optional **all** parameter is specified, all settings are displayed.
2. If the optional **--group** *group_name* is specified, only settings in the group *group_name* are displayed.
3. If the optional **--setlist** *name1..nameN* is specified, only the settings that are specified in *name1..nameN* are displayed.
4. If the optional class setting is specified, only settings that belong to the specific class are displayed.
5. If the optional **-v** parameter is specified, the output is verbose.
6. If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).
7. The connect options are defined for IMM-based servers only. The **--host** *ip_address* connect option is required if you connect remotely to the IMM. The **--user** *user_id* and **--password** *password* connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The **--user** *user_id* and **--password** *password* connect options are not required if you are using the local KCS interface.

Output

If the **-v** parameter is not specified, the setting and the current value are displayed.
If the **-v** parameter is specified, the description of the setting is displayed as well as an indicator that the value is the default value.

The setting without the **-v** parameter:

<setting>=<current value>

Setting with the **-v** parameter:

<setting>: <setting description> = <current value> [(default)]

Command line:

```
asu show RSAIP_HostIPAddress1
```

Output:

```
RSAIP_HostIPAddress1=192.168.0.100
```

Command line:

```
asu show CMOS_WakeOnLAN -v
```

Output:

```
CMOS_WakeOnLAN: Wake On Lan = Enabled (default)
```

Command line:

```
asu show bios
```

Output:

```
CMOS_DisketteA=1.44 MB 3.5"
CMOS_CRTRequired=Disabled
```

```
•
•
•
```

```
CMOS_OSUSBControl=Other OS
```

Showdefault command

Use the **showdefault** command to show the default value for one or more settings.

Syntax

The syntax of the **showdefault** command is either

```
asu showdefault [all | --group group_name | setting_name |
--setlist name1..nameN | class] [-v] [-nx] [connect_options]
```

If no setting command modifier or class setting is specified, all settings and their current values are displayed.

Notes

1. If the optional **all** parameter is specified, all settings are displayed.
2. If the optional **--group group_name** is specified, only settings in the group *group_name* are displayed.
3. If the optional **--setlist name1..nameN** is specified, only the settings that are specified in *name1..nameN* are displayed.
4. If the optional class setting is specified, only settings that belong to the specific class are displayed.
5. If the optional **-v** parameter is specified, the output is verbose.
6. If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).
7. The connect options are defined for IMM-based servers only. The **--host ip_address** connect option is required if you connect remotely to the IMM. The **--user user_id** and **--password password** connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The **--user user_id** and **--password password** connect options are not required if you are using the local KCS interface.

Output

If the **-v** parameter is not specified, the setting and the default value are displayed. If the **-v** parameter is specified, the description of the setting is also displayed.

The setting without the **-v** parameter:

```
setting=default value
```

Setting with the **-v** parameter:

```
setting: setting description = default value
```

For instance settings, the default state can be that the instance does not exist. If this is the case, the default value that is displayed by the **showdefault** command is

"delete." This response indicates that all instances of the setting are deleted if the **loaddefault** command is performed on the setting. For more information about instances, see Instances of settings.

The **showdefault** command and corresponding output are shown in the following examples.

Command line:

```
asu showdefault CMOS_WakeOnLAN -v
```

Output:

```
CMOS_WakeOnLAN: Wake On Lan = Enabled
```

Command line:

```
asu showdefault bios
```

Output:

```
CMOS_DisketteA=1.44 MB 3.5"  
CMOS_CRTRequired=Disabled
```

-
-
-

```
CMOS_OSUSBControl=Other OS
```

Command line:

```
asu showdefault iSCSI.AttemptName.1
```

Output:

```
iSCSI.AttemptName.1=<remove>
```

Showgroups command

Use the **showgroups** command to list the setting groups that are available on the server.

The settings are organized into groups. All uEFI settings belong to the uEFI group, and all BIOS settings belong to the BIOS group. The listed groups can be used as a class of commands that support the class modifier, or they can be used with the **--group *group*** option on commands that support this option.

Syntax

The syntax of the **showgroups** command is

```
asu showgroups [-nx] [connect_options]
```

Notes

1. If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).
2. The connect options are defined for IMM-based servers only. The **--host *ip_address*** connect option is required if you connect remotely to the IMM. The **--user *user_id*** and **--password *password*** connect options are required only if the default user ID and password settings are changed in the IMM for either a

local or remote LAN connection. The `--user user_id` and `--password password` connect options are not required if you are using the local KCS interface.

Output

The setting groups that are available on the server are displayed.

The **showgroups** command and corresponding output are shown in the following examples.

Command line:

```
asu showgroups
```

Output on an IMM-based server:

```
IMM
SYSTEM_PROD_DATA
uEFI
BootOrder
```

Output on a BIOS-based server:

```
bios
bmc
rsa
```

Showlocation command

Use the **showlocation** command to show the location of one or more settings. This command is for BIOS-based servers only.

This command shows where the actual data for the setting is stored.

Syntax

The syntax of the **showlocation** command is

```
asu showlocation [all | --group group_name | setting_name |  
--setlist name1..nameN | class] [-v] [-nx] [connect_options]
```

If no setting command modifier or class setting is specified, all settings and their current values are displayed.

Notes

1. If the optional **all** parameter is specified, all settings are displayed.
2. If the optional `--group group_name` is specified, only settings in the group *group_name* are displayed.
3. If the optional `--setlist name1..nameN` is specified, only the settings that are specified in *name1..nameN* are displayed.
4. If the optional *class* setting is specified, only settings that belong to the specific class are displayed.
5. If the optional **-v** parameter is specified, the output is verbose.
6. If the optional **-nx** parameter is specified, the ASU performs the operation for node *x*, where *x* is the selected node in a multi-node system. Node *x* can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).

7. The connect options are defined for IMM-based servers only. The `--host ip_address` connect option is required if you connect remotely to the IMM. The `--user user_id` and `--password password` connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The `--user user_id` and `--password password` connect options are not required if you are using the local KCS interface.

Output

If the `-v` parameter is not specified, the setting and its location are displayed. If the `-v` parameter is specified, the description of the setting is also displayed.

Without the `-v` parameter:

```
<setting>=<location>[<extra location info>]
```

```
if <location> is CMOS, <extra location info> is of the form
    <byte offset>,"<bit offset>","<number of bits>
if <location> is SP, <extra location info> is of the form
    <SP dot byte 1>".<SP dot byte 2>"," ... ".<SP dot byte n>
if <location> is SP6, <extra location info> is of the form
    "><write command info> "><read command info> and <write command info>
    and <read command info> are of the form
    <read command byte>["@<data offset>]
    (".<command data>)*["|<request data length>]
```

With the `-v` parameter:

```
<setting>: <setting description> {
    <location>[<extra location info>]
}
```

```
if <location> is CMOS, <extra location info> is of the form
    <byte offset>,"<bit offset>","<number of bits>
if <location> is SP, <extra location info> is of the form
    <SP dot byte 1>".<SP dot byte 2>". ... ".<SP dot byte n>
if <location> is SP6, <extra location info> is of the form
    "><write command info> "><read command info> and <write command info>
    and <read command info> are of the form
    <read command byte>["@<data offset>]
    (".<command data>)*["|<request data length>]
```

The **showlocation** command and corresponding output are shown in the following examples.

Command line:

```
asu showlocation CMOS_SerialA
```

Output:

```
CMOS_SerialA=CMOS[70,00,03]
```

Command line:

```
asu showlocation CMOS_SerialA -v
```

Output:

```
CMOS_SerialA: Serial Port A {
    CMOS[70,00,03]
}
```

Command line:

```
asu showlocation RSA_Network1
```


Output:

```
RSA_Network1=SP[04.09.01.01.02]
```

Command line:

```
asu showlocation RSA_Network1 -v
```

Output:

```
RSA_Network1: Network Interface 1 {  
    SP[04.09.01.01.02]  
}
```

Showvalues command

Use the **showvalues** command to list all possible values for one or more settings.

This command is useful for finding the value parameter that is used for the set command. Now, the **showvalues** command also describes the setting interdependencies information.

Syntax

The syntax of the **showvalues** command is

```
asu showdefault [all | --group group_name | setting_name |  
--setlist name1..nameN | class] [-v] [-nx] [connect_options]
```

```
asu showvalues [all | --group group_name | setting_name | --setlist name1..nameN |  
--instances | class] [-v | -t] [-nx] [connect_options]
```

Notes

1. If the optional **all** parameter is specified, all settings are displayed.
2. If the optional **--group group_name** is specified, only settings in the group *group_name* are displayed.
3. If the optional **--setlist name1..nameN** is specified, only the settings that are specified in *name1..nameN* are displayed.
4. If the optional *class* setting is specified, only settings that belong to the specific class are displayed.
5. If the optional **-v** parameter is specified, the output is verbose.
6. If the optional **-t** parameter is used, the output includes the raw values.
7. If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).
8. The connect options are defined for IMM-based servers only. The **--host ip_address** connect option is required if you connect remotely to the IMM. The **--user user_id** and **--password password** connect options are required only if the default user ID and password settings are changed in the IMM for either a local or remote LAN connection. The **--user user_id** and **--password password** connect options are not required if you are using the local KCS interface.
9. If the optional **--instances** parameter is specified, only settings that can have instances are displayed. The minimum and maximum number of instances allowed for the settings is also displayed. For more information about instances, see Instances of settings.

Output

If the **-v** parameter is not specified, the setting and its value are displayed. If the **-v** parameter is specified, the description of the setting is also displayed.

If the setting is an enumerated type:

-v and -t not specified:

```
<setting>=<value 1>=<value 2>=...=<value n>
```

-v specified:

```
<setting>: <setting description> {
    <value 1>
    <value 2>
    .
    .
    .
    <value n>
}
```

-t specified:

```
<setting>=<value 1>[<raw 1>]=<value 2>[<raw 2>]=...=<value n>[<raw n>]
```

If the setting is a string type:

-v not specified:

```
<setting>=char[<length>]
```

<length> is the max length string that can be entered.
If <length> is omitted, there is no maximum.

-v specified:

```
<setting>: <setting description> {
    char[<length>]
}
```

<length> is the max length string that can be entered.
If <length> is omitted, there is no maximum.

If the setting is an IP address type:

-v not specified:

```
<setting>= x.x.x.x where (0 <= x <= 255)
```

-v specified:

```
<setting>: <setting description> {
    A string formatted x.x.x.x, where x is an integer from 0 to 255
}
```

If the setting is a MAC address type:

-v not specified:

```
<setting>= x:x:x:x where (0 <= x <= FF)
```

-v specified:

```
<setting>: <setting description> {
    A string formatted x:x:x:x, where x is a hex integer from 0 to FF
}
```

If the setting is a keystroke sequence type:

-v not specified:

```
<setting>=(c)* where c in [0x01-0xFF, 'ESC', ^A-^Z, ^[-^_, ' ' '~']
```

-v specified:

```
<setting>: <setting description> {
    A space-separated sequence of characters where each of the characters is:
    0x01-0xFF, 'ESC', ^A-^Z, ^[-^_, ' ', '!', '#', '$', '%', '&',
    '(', ')', '*', '+', ',', '-', '.', '/', '0'-'9', ':', ';', '<',
    '=', '>', '?', '@', A'-'Z', '[', '\', ']', '^', '_', 'a'-'z',
    '{', '|', '}', or '~'
```

If the **--instances** parameter is specified, the output for a setting that is not part of a record is:

```

-v not specified:
    <setting>= numeric type=dec min=0 max=65535 default=3260 [min=0, max=256]
    The output for the setting indicates that it can have anywhere from
    0 to 256 instances. This is indicated by '[min=0, max=256]'
-v specified:
<setting>: T <setting description> {
    numeric data
    numeric type = dec
    minimum value = 0
    maximum value = 65535
    default value = 3260
    min instances = 0
    max instances = 256
}

```

The verbose output for the setting also indicates that it can have anywhere from 0 to 256 instances. In this case this is indicated by 'min instances = 0' and 'max instances = 256'.

If the **--instances** parameter is specified, the output for settings that are part of a record is:

```

-v not specified:
setting1=char[] default="" [min=0, max=12] recordKey
setting2=char[] default="" [min=0, max=12] recordKey="setting1"
setting3=char[] default="" [min=0, max=12] recordKey="setting1"

```

The output for all of the settings indicate that they can have anywhere from 0 to 12 instances. Setting1 is the recordKey, and setting2 and setting3 are part of a record,

where

setting1 is the key setting.

For more information about records, see Record management.

```

-v specified:
<setting1>: <setting1 description> {
    char[]
    default =
    min instances = 0
    max instances = 12
    Record Key
}
<setting2>: <setting2 description> {
    char[]
    maximum characters = 16
    pattern = ^(.{4,16})?
    default =
    Record Key = <setting1>
}
<setting3>: <setting3 description> {
    char[]
    maximum characters = 16
    pattern = ^(.{4,16})?
    default =
    Record Key = <setting1>
}

```

The verbose output for setting1 also indicates that it can have anywhere from 0 to 256 instances. In this case, it is indicated by 'min instances = 0' and 'max instances = 256'. Setting1 is the recordKey and setting2 and setting3 are part of the same record as setting1,

where

setting1 is the key setting.

For more information about records, see Record management.

If the setting is a certificate related setting:

-v not specified:

```
<setting>=<generate>=<import>=...=<export>
```

-v specified:

```
<setting>:<setting long name> {  
    generate  
    import  
    export  
}
```

"generate, import, export" are methods supported by this certificate setting.

If the setting has interdependency information:

Setting 1 has clear dependency:

```
<setting 1>=<value 11>=<value 12>=...=<value 1n>
```

This setting is hidden if the result of the following expression is true:

```
" <setting 2>== <value 20> "
```

Refer to the ASU User's Guide for the settings which is marked as(*).

Setting 1 depends on both internal settings and system environment:

```
(*)<setting 1>=<value 11>=<value 12>=...=<value 1n>
```

See the ASU User's Guide for the settings marked as(*).

The **showvalues** command and corresponding output are shown in the following examples.

Command line:

```
asu showvalues CMOS_SerialA
```

Output:

```
CMOS_SerialA=PnP=Auto-configure=<Port 3F8, IRQ 4>=Port 2F8,  
IRQ 3=Port 3E8, IRQ 4=Port 2E8, IRQ 3=Disabled
```

Command line:

```
asu showvalues CMOS_SerialA -v
```

Output:

```
CMOS_SerialA: Serial Port A {  
PnP  
Auto-configure  
Port 3F8, IRQ 4 (default)  
Port 2F8, IRQ 3  
Port 3E8, IRQ 4  
Port 2E8, IRQ 3  
Disabled  
}
```

Command line:

```
asu showvalues CMOS_SerialA -t
```

Output:

```
CMOS_SerialA=PnP=Auto-configure=<Port 3F8, IRQ 4>=Port 2F8,  
IRQ 3=Port 3E8, IRQ 4=Port 2E8, IRQ 3=Disabled
```

Command line:

```
asu showvalues --instances
```

Output:

```
IMM.LoginId=char[] maxchars=16 pattern=^(.{4,16})? default=<remove>  
[min=0, max=12] recordKey  
IMM.Password=char[] default="" [min=0, max=12] recordKey="IMM.LoginId"  
IMM.AuthorityLevel=<Supervisor>=ReadOnly=Custom [min=0, max=12]  
recordKey="IMM.LoginId"
```

Command line:

```
asu showvalues IMM.SSL_HTTPS_SERVER_CERT
```

Output:

```
IMM.SSL_HTTPS_SERVER_CERT=*generate=import=export
```

Version command

Use the **version** command to show the version and build date of the ASU.

The version number uses the following standard format: *w.xy.zzz*

where

w is the major revision number (this value changes if there are major new features in the release), *x* is the minor revision number (this value changes if there are only minor new features in the release), *y* is the sub-minor revision number (this value changes if there are only fixes in the release), and *zzz* is the build number.

Syntax

The syntax of the **version** command is

```
asu version
```

Output

The output of the **version** command shows the current version and build date of the ASU.

The **version** command and corresponding output are shown in the following example.

Command line:

```
asu version
```

Output:

```
Advanced Settings Utility 3.00.65A Mar 12 2009
```

Writeraw command

Use the **writeraw** command to read and write CMOS data that is saved in a file through the readraw command. This command is for BIOS-based servers only.

Syntax

The syntax of the **writeraw** command is

```
asu writeraw filename [-nx]
```

where

filename is the name of a file in which the raw CMOS data is to be read.

Note: If the optional **-nx** parameter is specified, the ASU performs the operation for node x, where x is the selected node in a multi-node system. Node x can be a number from 1 through 8. If the **-nx** parameter is not specified, the operation is performed on the primary node (node 1).

Output

The output of the **writeraw** command is a file that is generated in the directory where the ASU is running and a message that indicates that the raw write operation is completed.

The **writeraw** command and corresponding output are shown in the following example.

Command line:

```
asu writeraw CMOSraw.dat
```

Output:

```
Raw CMOS read from CMOSraw.dat, written to CMOS  
CMOSraw.dat file generated
```

Nodes command

Use the **nodes** command to detect the available nodes in current system. This command is for IMM and legacy servers.

Syntax

The syntax of the **nodes** command is

```
asu nodes
```

Note: You can use it on a multinode system or a single node system. On a single node system, 1 is always reported.

Output

The output of the **nodes** command is a string with a number of nodes currently available on the system.

The **nodes** command and corresponding output are shown in the following example.

Command line:

```
asu nodes
```

Output:

System Nodes: 2

Appendix. Getting help and technical assistance

This section contains information about where to go for additional information about IBM and IBM products, what to do if you experience a problem with your system, and whom to call for service, if it is necessary.

If you need help, service, or technical assistance or just want more information about IBM products, you will find a wide variety of sources available from IBM to assist you.

Before you call

The syntax of the **nodes** command is

Before you call, make sure that you have taken these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Use the troubleshooting information in your system documentation, and use the diagnostic tools that come with your system. Information about diagnostic tools is in the Problem Determination and Service Guide on the IBM Documentation CD that comes with your system.
- Go to the IBM support website at <http://www.ibm.com/systems/support/> to check for technical information, hints, tips, and new device drivers or to submit a request for information.

You can solve many problems without outside assistance by following the troubleshooting procedures that IBM provides in the online help or in the documentation that is provided with your IBM product. The documentation that comes with IBM systems also describes the diagnostic tests that you can perform. Most systems, operating systems, and programs come with documentation that contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

Using the documentation

Information about your IBM system and preinstalled software, if any, or optional device is available in the documentation that comes with the product.

The documentation can include printed documents, online documents, readme files, and help files. See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates.

To access these pages, go to Support for IBM Systems and follow the instructions. Also, some documents are available through the IBM Publications Center at <http://www.ibm.com/shop/publications/order/>.

Getting help and information from the World Wide Web

On the World Wide Web, the IBM web site has up-to-date information about IBM systems, optional devices, services, and support.

The address for IBM System x[®] and xSeries[®] information is <http://www.ibm.com/systems/x/>. The address for IBM BladeCenter[®] information is <http://www.ibm.com/systems/bladecenter/>. The address for IBM IntelliStation[®] information is <http://www.ibm.com/intellistation/>. You can find service information for IBM systems and optional devices at <http://www.ibm.com/systems/support/>.

To access these pages, go to Support for IBM Systems and follow the instructions. Also, some documents are available through the IBM Publications Center at <http://www.ibm.com/shop/publications/order/>.

Software service and support

Through IBM Support Line, you can get telephone assistance, for a fee, with usage, configuration, and software problems with System x and xSeries[®] servers, BladeCenter products, IntelliStation[®] workstations, and appliances.

For information about which products are supported by Support Line in your country or region, see the Supported Product List.

For more information about Support Line and other IBM services, see IT Services, or see the Directory of worldwide contacts for support telephone numbers. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

Hardware service and support

You can receive hardware service through your IBM reseller or IBM Services.

To locate a reseller authorized by IBM to provide warranty service, go to PartnerWorld[®] and click **Find Business Partners** on the side of the page. For IBM support telephone numbers, see the Directory of worldwide contacts.

In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378). In the U.S. and Canada, hardware service and support is available 24 hours a day, 7 days a week. In the U.K., these services are available Monday through Friday, from 9 a.m. to 6 p.m.

Product services - Taiwan

This topic explains how to get product service in Taiwan.

For IBM Taiwan product service contact information:

IBM Taiwan Corporation

3F, No 7, Song Ren Rd.

Taipei, Taiwan

Telephone: 0800-016-888

Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing

North Castle Drive

Armonk, NY 10504-1785

U.S.A.

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product, and use of those websites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Trademarks

IBM, the IBM logo, and ibm.com[®] are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. If these and other IBM trademarked terms are marked on their first occurrence in this information with a trademark symbol ([®] or [™]), these symbols

indicate U.S. registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common law trademarks in other countries. A current list of IBM trademarks is available on the web at "Copyright and trademark information" at <http://www.ibm.com/legal/copytrade.shtml>.

Adobe and PostScript are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Cell Broadband Engine is a trademark of Sony Computer Entertainment, Inc., in the United States, other countries, or both and is used under license therefrom.

Intel, Intel Xeon, Itanium, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Java[™] and all Java-based trademarks are trademarks of Sun Microsystems, Inc., in the United States, other countries, or both.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Other company, product, or service names may be trademarks or service marks of others.

Important notes

Processor speed indicates the internal clock speed of the microprocessor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1024 bytes, MB stands for 1 048 576 bytes, and GB stands for 1 073 741 824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1 000 000 bytes, and GB stands for 1 000 000 000 bytes. Total user-accessible capacity can vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard disk drive bays with the largest currently supported drives that are available from IBM.

Maximum memory might require replacement of the standard memory with an optional memory module.

IBM makes no representation or warranties regarding non-IBM products and services that are ServerProven[®], including but not limited to the implied warranties of merchantability and fitness for a particular purpose. These products are offered and warranted solely by third parties.

IBM makes no representations or warranties with respect to non-IBM products. Support (if any) for the non-IBM products is provided by the third party, not IBM.

Some software might differ from its retail version (if available) and might not include user manuals or all program functionality.

Readers' Comments — We'd Like to Hear from You

IBM
Advanced Settings Utility, v9.30
User's Guide
Version 9.30

We appreciate your comments about this publication. Please comment on specific errors or omissions, accuracy, organization, subject matter, or completeness of this book. The comments you send should pertain to only the information in this manual or product and the way in which the information is presented.

For technical questions and information about products and prices, please contact your IBM branch office, your IBM business partner, or your authorized remarketer.

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute your comments in any way it believes appropriate without incurring any obligation to you. IBM or any other organizations will only use the personal information that you supply to contact you about the issues that you state on this form.

Comments:

Thank you for your support.

Send your comments to the address on the reverse side of this form.

If you would like a response from IBM, please fill in the following information:

Name

Address

Company or Organization

Phone No.

Email address



Cut or Fold
Along Line

Fold and Tape

Please do not staple

Fold and Tape



NO POSTAGE
NECESSARY
IF MAILED IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 40 ARMONK, NEW YORK

POSTAGE WILL BE PAID BY ADDRESSEE

International
Business Machines Corporation
PO Box 12195
Research Triangle Park
NC
U.S.A. 27709-9990



Fold and Tape

Please do not staple

Fold and Tape

Cut or Fold
Along Line



Printed in USA