

BladeCenter



Serial over LAN Setup Guide

BladeCenter



Serial over LAN Setup Guide

Note: Before using this information and the product it supports, read the general information in Appendix A, "Getting help and technical assistance," on page 51 and Appendix B, "Notices," on page 53.

Twelfth Edition (November 2009)

© Copyright International Business Machines Corporation 2009.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Chapter 1. Introduction	1
Hardware and firmware requirements	2
Hardware requirements	2
Firmware requirements	3
Checking firmware versions	4
Starting the BladeCenter management-module Web interface	5
Chapter 2. General configuration	7
Configuring the global SOL settings for the BladeCenter unit	7
Configuring the management module	9
Installing and configuring SSH for SOL	11
Enabling SOL for blade servers	12
Updating and configuring the blade server BIOS	13
Chapter 3. Operating system configuration	15
Linux configuration	15
Red Hat Enterprise Linux ES 2.1 configuration	15
SUSE SLES 8.0 configuration	19
Installing the Ethernet controller device driver for Linux operating systems	21
Microsoft Windows 2003 Standard Edition configuration	22
Chapter 4. Special component requirements	25
Configuring the BladeCenter HS22 Type 7870 blade server	25
Configuring the BladeCenter HS20 Type 8832 and HS20 Type 8843 blade servers	27
HS20 Type 8832 SOL jumper placement	28
Updating the integrated systems management processor firmware	28
Updating the Broadcom Ethernet controller firmware	29
Configuring the BladeCenter HS40 Type 8839 blade server	29
Updating the Baseboard Management Controller firmware	29
Updating and configuring the BIOS	30
Configuring the BladeCenter JS20 Type 8842 blade server	30
Updating the open firmware (BIOS)	31
Updating the integrated systems management processor firmware	31
Updating the Broadcom Ethernet controller firmware	32

Configuring the IBM 4-Port Gb Ethernet Switch Module for BladeCenter	32
Configuring the Nortel Networks Layer 2-7 GbE Switch Module for IBM BladeCenter	33
Configuring the Cisco Systems Intelligent Gigabit Ethernet Switch Module for the IBM BladeCenter	34
Connecting an Intelligent Copper Pass-thru Module	36

Chapter 5. Using SOL	37
Starting an SOL session	37
Starting a command-line Telnet connection	38
Establishing a serial connection	38
Starting a command-line Secure Shell (SSH) connection	39
Starting an SOL session from the command-line interface	39
Ending an SOL session	40
Monitoring SOL session status	41
Restarting a blade server through SOL	43
Mounting and unmounting media for Linux operating systems	44

Chapter 6. Troubleshooting SOL.	45
Management module indicates that blade server does not support SOL	45
Blade server shows SOL status of Not Ready	46
SOL session opens and drops	47
Trouble entering SOL commands or receiving double prompts	48
Garbage characters in an SOL session.	48

Appendix A. Getting help and technical assistance	51
Before you call	51
Using the documentation	51
Getting help and information from the World Wide Web	52
Software service and support	52
Hardware service and support	52
IBM Taiwan product service	52

Appendix B. Notices	53
Trademarks	53
Important notes	53

Index	55
------------------------	-----------

Chapter 1. Introduction

Serial over LAN (SOL) provides a means to manage servers remotely by using a command-line interface (CLI) over a Telnet or Secure Shell (SSH) connection. SOL is required to manage servers that do not have keyboard/video/mouse (KVM) support, such as the JS20 Type 8842 blade server.

SOL provides console redirection for both BIOS and the blade server operating system. The SOL feature redirects server serial-connection data over a LAN without the need for special cabling. The SOL connection enables blade servers to be managed from any remote location with network access. The advantages of SOL include:

- Remote administration without keyboard, video, or mouse (headless servers)
- Reduced cabling and no need for a serial concentrator
- Standard Telnet interface that eliminates the need for special client software

The IBM® BladeCenter® management module command-line interfaces provide access to the text-console command prompt on each blade server through a SOL connection, enabling the blade servers to be managed from a remote location. This document explains how to update and configure BladeCenter components for SOL operation using the BladeCenter management-module Web interface. You can also perform many configuration procedures using the management-module command-line interface or the simple network management protocol (SNMP). See the *BladeCenter Management Module Command-Line Interface Reference Guide* for information about the management-module command-line interface and instructions about how to use it. All BladeCenter unit types, including the BladeCenter T unit, are referred to throughout this document as the BladeCenter unit. Unless stated otherwise, all descriptions and instructions in this document apply to all BladeCenter unit configurations.

In the BladeCenter environment, the integrated system management processor (ISMP) and network interface controller (NIC) on each blade server routes the serial data from the blade server serial communications port to the network infrastructure of the BladeCenter unit, including an Ethernet-compatible I/O module that supports SOL communication. BladeCenter components are configured for SOL operation through the BladeCenter management module. The management module also acts as a proxy in the network infrastructure to couple a client running a Telnet session with the management module to an SOL session running on a blade server, enabling the Telnet client to interact with the serial port of the blade server over the network. Because all SOL traffic is controlled by and routed through the management module, administrators can segregate the management traffic for the BladeCenter unit from the data traffic of the blade servers.

To start an SOL connection with a blade server, you must first start a Telnet command-line interface session with the management module. When this Telnet command-line interface session is running, you can start a remote-console SOL session with any blade server in the BladeCenter unit that is set up and enabled for SOL operation. You can establish up to 20 separate Web interface, Telnet, serial (advanced management module only), or SSH sessions with a BladeCenter management module. For a BladeCenter unit, this enables you to have 14 simultaneous SOL sessions active (one for each of up to 14 blade servers) with 6 additional command-line interface sessions available for BladeCenter unit

management. For a BladeCenter T unit, this enables you to have 8 simultaneous SOL sessions active (one for each of up to 8 blade servers) with 12 additional command-line interface sessions available for BladeCenter unit management. If security is a concern, you can use Secure Shell (SSH) sessions, or connections made through the serial management port that is available on the advanced management module, to establish secure Telnet command-line interface sessions with the BladeCenter management module before starting an SOL console redirect session with a blade server.

The most recent versions of all BladeCenter documentation is available at <http://www.ibm.com/support/>.

Hardware and firmware requirements

The BladeCenter unit must be correctly configured before you can use the command-line interface and SOL. This section describes the hardware and software that are required for the command-line interface and SOL.

Hardware requirements

All BladeCenter components, except for the BladeCenter HS20 Type 8678 blade server, are SOL capable. All blade servers must be configured to enable SOL operation. Some of the older BladeCenter components require additional configuration to support SOL operation.

To use the SOL feature, the following hardware is required:

- An SOL-capable blade server.
The BladeCenter HS20 Type 8678 blade server does not support SOL operation. You can use the console command to control a blade server through SOL only on blade server types that support SOL functionality that have the required firmware levels (see Table 1 on page 3).
- An Ethernet I/O module installed in I/O-module bay 1. For systems using management channel auto discovery (MCAD), SOL can use I/O modules installed in other I/O-module bays (see the *BladeCenter Advanced Management Module User's Guide* for additional information about MCAD).

The following blade servers have specific requirements for SOL operation:

- For the BladeCenter HS20 Type 8832 and Type 8843 blade servers, and LS20 Type 8850 blade server:
 - SOL uses the first network interface, Ethernet 1 (eth1 or Planar Ethernet 1), of the blade server to communicate. When this network interface attempts to boot through PXE or DHCP, the network interface is reset, causing the current SOL session to be dropped and have a new status of Not Ready. If you require booting through PXE or DHCP, use the second network interface, Ethernet 2 (eth2 or Planar Ethernet 2), of the blade server and install an Ethernet I/O module in I/O-module bay 1.
 - For the BladeCenter HS20 Type 8832 blade server, jumper J28 must be installed in the correct position. See “HS20 Type 8832 SOL jumper placement” on page 28 for information.
- For the BladeCenter JS20 Type 8842 blade server, SOL uses the first network interface, Ethernet 1 (eth1 or Planar Ethernet 1), of the blade server to communicate. When this network interface attempts to use BOOTP, the network interface is reset, causing the current SOL session to be dropped and have a new

status of Not Ready. If you require BOOTP, use the second network interface, Ethernet 2 (eth2 or Planar Ethernet 2), of the blade server and install an Ethernet I/O module in I/O-module bay 1.

Firmware requirements

Make sure that you are using the latest versions of device drivers, firmware, and BIOS for your blade server, management module, and other BladeCenter components. Go to <http://www.ibm.com/support/> for the latest information about upgrading the device drivers, firmware, and BIOS for BladeCenter components. The latest instructions are in the documentation that comes with the updates.

The firmware level of most BladeCenter components supports SOL operation. Some of the older BladeCenter components must have their firmware upgraded to support SOL operation. The following table lists the firmware levels that are required for older BladeCenter components to support SOL operation. If a component is not listed in the table, all firmware levels for that component support SOL operation.

Table 1. Firmware levels required for SOL for older BladeCenter components

Component		Firmware level
BladeCenter Management Module		1.08 or later
BladeCenter HS20 Type 8678 blade server		No SOL support
BladeCenter HS20 Type 8832 blade server	BladeCenter HS20 Type 8832 blade server BIOS	1.03 or later
	BladeCenter HS20 Type 8832 blade server diagnostics	1.02 or later
	BladeCenter HS20 Type 8832 blade server ISMP	1.03 or later
	BladeCenter HS20 Type 8832 blade server Broadcom Ethernet Controller Boot ROM	3.21 or later
	BladeCenter HS20 Type 8832 blade server Broadcom Ethernet Controller Firmware	2.2 or later
	BladeCenter HS20 Type 8832 blade server Broadcom Ethernet Controller Diagnostic Utility	1.06 or later
	BladeCenter HS20 Type 8832 blade server Broadcom Ethernet Controller Linux [®] Device Driver	7.1.22 or later
IBM 4-Port Gb Ethernet Switch Module for BladeCenter		1.04 or later
Nortel Networks Layer 2-7 GbE Switch Module for IBM BladeCenter (4-port switch)		See the IBM Support Web site ¹
Note 1: Go to http://www.ibm.com/support/ for the latest information about firmware levels that support SOL.		

Checking firmware versions

About this task

Complete the following steps to view the firmware levels that are installed in the BladeCenter components:

1. Start the BladeCenter management-module Web interface (see “Starting the BladeCenter management-module Web interface” on page 5).
2. In the navigation pane, click **Monitors** → **Firmware VPD**.

Results

The Firmware VPD choice identifies the firmware type, build ID, release date, and revision number for the firmware that is installed in each blade server, I/O module, and management module in the BladeCenter unit. The vital product data (VPD) for the firmware in the management modules also includes the file name of the firmware components. (Selecting the Firmware VPD choice takes up to 30 seconds to refresh and display information.)

Important: To avoid problems and to maintain proper system performance, always make sure that the blade server firmware code, service processor code, and diagnostic firmware code levels are consistent for all blade servers within the BladeCenter unit.

Compare the installed firmware version to the information in Table 1 on page 3 and to the firmware information at <http://www.ibm.com/support/>. If the firmware version installed is at or above the version listed in Table 1 on page 3, your BladeCenter component has the firmware code needed to use the SOL feature. If installed firmware versions do not meet at least the minimum requirements, download the latest firmware code from <http://www.ibm.com/support/> and install it following the firmware update instructions in Chapter 4, “Special component requirements,” on page 25.

Starting the BladeCenter management-module Web interface

About this task


Note: The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

The management-module Web interface is used to perform SOL configuration. The management-module Web interface supports only configuration and monitoring of the command-line interface and SOL and cannot be used to start command-line interface or SOL sessions.

Complete the following steps to start the BladeCenter management-module Web interface:

1. Open a Web browser. In the address or URL field, type the IP address or host name that is assigned for the management-module remote connection.
The Enter Network Password window opens.
2. Type your user name and password. If you are logging in to the management module for the first time, you can obtain your user name and password from your system administrator. All login attempts are documented in the event log.
The initial user ID and password for the management module are:
 - User ID: USERID (all capital letters)
 - Password: PASSWORD (note the zero, not O, in PASSWORD)
3. Follow the instructions on the screen. Be sure to set the timeout value that you want for your Web session.

The BladeCenter management-module Web interface window opens.



Chapter 2. General configuration

Note: The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

This section provides instructions for configuring the BladeCenter unit to operate using SOL. You must perform the following procedures:

- Make sure that all BladeCenter components and firmware meet the minimum SOL requirements (see “Hardware and firmware requirements” on page 2).
- Configure the BladeCenter unit for SOL operation (see “Configuring the global SOL settings for the BladeCenter unit”).
- Configure the management module for SOL operation (see “Configuring the management module” on page 9).
- If required, configure BladeCenter components for SOL operation (see Chapter 4, “Special component requirements,” on page 25).
- Update and configure BladeCenter BIOS for SOL operation (see “Updating and configuring the blade server BIOS” on page 13).
- Configure the operating system that is installed on each blade server to enable SOL (see Chapter 3, “Operating system configuration,” on page 15).
- If secure SOL sessions over a network are required, install and configure SSH for SOL (see “Installing and configuring SSH for SOL” on page 11).
- Enable the blade servers for SOL operation (see “Enabling SOL for blade servers” on page 12).

Perform the SOL configuration that is shared by all BladeCenter components using the management-module Web interface. The management-module Web interface supports only configuration and monitoring of the command-line interface and SOL and cannot be used to start command-line interface or SOL sessions.

You can also perform some SOL configuration using the management-module command-line interface or the Simple Network Management Protocol (SNMP). See the *BladeCenter Management Module Command-Line Interface Reference Guide* for information about the management-module command-line interface and instructions for using it.

Configuring the global SOL settings for the BladeCenter unit

About this task

Complete the following steps to configure the global SOL settings for the BladeCenter unit:

1. Start the BladeCenter management-module Web interface (see “Starting the BladeCenter management-module Web interface” on page 5).
2. In the navigation pane, click **Blade Tasks** → **Serial Over LAN**. In the management-module information page that opens make sure that the settings match the following default values or are set to the values that are required by your network configuration. Unless otherwise noted, the default

management-module SOL settings provide the best overall SOL performance. (For advanced management modules, click the **Serial Over LAN configuration** link to access the SOL settings.)

Results

The following illustration shows SOL settings for management modules other than an advanced management module.

Serial Over LAN Configuration ⓘ

Serial over LAN

SOL VLAN ID

BSMP IP address range

Transport Parameters

Accumulate timeout msec

Send threshold bytes

Retry count

Retry interval msec

User Defined Keystroke Sequences

'Enter CLI' key sequence

'Reset blade' key sequence

The following illustration shows SOL settings for an advanced management module.

Serial Over LAN Configuration ⓘ

The two readonly fields below can be configured on the [Blade Configuration](#) page.

Serial over LAN

SOL VLAN ID: 4095

Transport Parameters

Accumulate timeout msec

Send threshold bytes

Retry count

Retry interval msec

User Defined Keystroke Sequences

'Enter CLI' key sequence

'Reset blade' key sequence

Note: For the advanced management module, the **SOL VLAN ID** and the **BSMP IP address range** are set on the **Blade Tasks → Configuration** page (see the *Advanced Management Module User's Guide* for information).

The SOL settings and recommended values are:

- **Serial Over Lan: Enabled**

Use this field to enable or disable SOL globally for the BladeCenter unit. If SOL is enabled globally and if SOL is enabled for a blade server, an SOL session can

be established with that blade server. If SOL is disabled globally, no SOL sessions can be established with any blade servers in the BladeCenter unit.

- **SOL VLAN ID** (management modules other than the advanced management module)
 - For all switch modules other than the Cisco Systems Intelligent Gigabit Ethernet Switch Module for the IBM BladeCenter, the SOL VLAN ID must be set to 4095 (default value).
 - For the Cisco Systems Intelligent Gigabit Ethernet Switch Module for the IBM BladeCenter the SOL VLAN ID is set as follows:
 - For Cisco IOS releases earlier than 12.1(22)EA6a, the SOL VLAN ID can be set to any value between 3 and 1001: it *cannot* be set to the default value of 4095.
 - For Cisco IOS release 12.1(22)EA6a and later, the SOL VLAN ID is set to a default value of 4095. If desired, you can still set your own defined VLAN ID.

Note: If your blade server has a Broadcom Ethernet controller and you want to use an SOL VLAN ID of 4095 for the Cisco Systems Intelligent Gigabit Ethernet Switch Module, upgrade to the latest versions of blade server Broadcom Ethernet Controller firmware (minimum level supported is 1.20.14).

If you set the SOL VLAN ID to a custom value, write it down for later use during the configuration process.

- **BSMP IP Address Range: $x.x.x.x$** (management modules other than the advanced management module)

This is a mandatory field where $x.x.x.x$ is the base IP address for blade servers that is used for internal communication inside the BladeCenter unit. The IP address that SOL uses to communicate with the blade system management processor (BSMP) of each blade server is based on the IP address that is set in this field. For example, if the value that you enter is 10.1.1.1, the blade server in blade bay 1 will have IP address 10.1.1.1, the blade server in blade bay 2 will have IP address 10.1.1.2, and so on.
- **Accumulate timeout: 25** (default value is 5 for management modules other than the advanced management module and 150 for the advanced management module)
- **Send threshold: 250**
- **Retry count: 3**
- **Retry interval: 2500** (default value is 250)

Do not attempt to enable or disable SOL on any of the blade servers that are listed in the **Serial Over LAN Status** section.

Configuring the management module

About this task

Before you configure the management module for SOL operation, review the following information:

- Make sure that the management-module external network interface (eth0) configuration is valid for your production network. This configuration can be obtained from a DHCP server or set statically.

- For management module types other than the advanced management module, the management-module internal network interface (eth1) and the Ethernet I/O module configuration can be different from that of the management-module external network interface (eth0); however, the management-module internal network interface (eth1) and the Ethernet I/O module configuration must be in the same subnet. The management-module internal interface (eth1) is exposed to the external network through the management module, so it must not conflict with any other addresses on your production network. If you use a configuration for the Ethernet I/O module that is not valid for your production network, you will not be able to update the firmware or manage your Ethernet I/O module through a Web interface.
- Telnet sessions with the BladeCenter management module do not have a timeout value set by default. If no timeout value is set, Telnet sessions will remain active indefinitely. See the *BladeCenter Management Module Command-Line Interface Reference Guide* for information about configuring the Telnet session timeout value for the management module.
- The SOL blade system management processor (BSMP) address range can include any valid IP addresses that do not conflict with any of the IP addresses of the blade servers. The BSMP address range is used for internal communication between the blade server and the I/O module and is not exposed to the external network.

Complete the following steps to update the management-module firmware and configure the management module to enable SOL:

1. Start the BladeCenter management-module Web interface (see “Starting the BladeCenter management-module Web interface” on page 5).
2. Complete the following steps to update the BladeCenter management module firmware:
 - a. Download the latest management-module firmware from <http://www.ibm.com/support/>.
 - b. Update the management-module firmware, following the instructions that come with the update file that you downloaded.
3. Start the BladeCenter management-module Web interface (see “Starting the BladeCenter management-module Web interface” on page 5).
4. Complete the following steps to enable SOL for the management module:
 - a. For management module types other than the advanced management module, complete the following steps to configure the internal network interface (eth1) settings:
 - 1) In the navigation pane, click **MM Control** → **Network Interfaces**.
 - 2) Scroll to the **Internal Ethernet Interface (eth1)** section.
 - 3) Make sure that **Interface** is set to **Enabled**.
 - 4) Set the **Static IP Configuration** fields to the values that are required for your physical network. The values must be in the following formats:
 - **IP address:** *x.x.x.x*
 - **Subnet mask:** *x.x.x.x*
 - **Gateway address:** *x.x.x.x*

The static IP configuration values specify valid IP addresses of the form *x.x.x.x*, where each *x* is a number from 0 to 255.
 - 5) Click **Save**; then, click **OK** or **Yes** to confirm. Do not restart the management module.

- b. Complete the following steps to configure the Ethernet I/O module network settings:

Note: If you are using management channel auto discovery (MCAD), replace references to I/O-module bay 1 in the following procedure with the I/O module bay number that is actually being used (see the *BladeCenter Advanced Management Module User's Guide* for additional information about MCAD).

- 1) In the navigation pane, click **I/O Module Tasks** → **Configuration**.
 - 2) Scroll to the **Bay 1 (Ethernet SM)*** section.
 - 3) Set the values in the **New Static IP Configuration** fields, if they are not already correct as listed in the **Current IP Configuration** section. The values must be in the following formats:
 - **IP address:** *x.x.x.x*
 - **Subnet mask:** *x.x.x.x*
 - **Gateway address:** *x.x.x.x*The static IP configuration values specify valid IP addresses of the form *x.x.x.x*, where each *x* is a number from 0 to 255.
 - 4) If you changed any values, click **Save**.
5. Complete the following steps to restart the management module. Restarting the management module ends the current BladeCenter management-module Web interface session.
 - a. In the navigation pane, click **MM Control** → **Restart MM**.
 - b. Click **Restart**.
 - c. Click **OK** to confirm.
 - d. Click **Yes** to restart the management module and end the session.

Installing and configuring SSH for SOL

About this task

Complete the following steps to install and configure Secure Shell Server (SSH) for SOL:

1. Start the BladeCenter management-module Web interface (see “Starting the BladeCenter management-module Web interface” on page 5).
2. If you have not previously installed a security key file, complete the following steps. Otherwise, go to step 3.
 - a. In the navigation pane, click **MM Control** → **Security**.
 - b. Download the latest version of the SSH security key file from <http://www.ibm.com/support/>. Navigate to the **Install SSL/SSH** section and click **BladeCenter firmware update**.
 - c. Click **Browse** and select the file that was downloaded in step 2b.
 - d. Click **Install SSL/SSH**.
 - e. Scroll to the **Install SSL/SSH** section and click **Configure and enable**.
3. Complete the following steps to generate the SSH Server Private Key:
 - a. In the navigation pane, click **MM Control** → **Security**.
 - b. Scroll to the **SSH Server Key Management** section and click **Generate SSH Server Private Key**.
 - c. Click **OK** to confirm.
4. Complete the following steps to enable SSH:

- a. Scroll to the **Secure Shell (SSH) Server** section.
 - b. Select **Enabled** for the **SSH Server** option; then, click **Save**.
 - c. Click **OK** to confirm.
5. Complete the following steps to restart the management module. Restarting the management module ends the current BladeCenter management-module Web interface session.
 - a. In the navigation pane, click **MM Control** → **Restart MM**.
 - b. Click **Restart**.
 - c. Click **OK** to confirm.
 - d. Click **Yes** to restart the management module and end the session.

Results

You can now use an SSH client to start a secure Telnet session with the management module and secure SOL sessions with the blade servers.

Enabling SOL for blade servers

About this task

SOL must be enabled both globally for the BladeCenter unit (see “Configuring the global SOL settings for the BladeCenter unit” on page 7) and individually for each blade server where you plan to start an SOL session.

Note: Make sure that console redirection is enabled for your blade server, with port 2 (COM 2) specified as the remote console port. Remote console configuration information for the HS20 Type 8832, HS20 Type 8843, and HS40 Type 8839 blade servers is in Chapter 4, “Special component requirements,” on page 25. See the *Installation and User’s Guide* for your blade server for information about configuring blade server BIOS settings such as console redirection.

Complete the following steps to enable SOL for a blade server:

1. Start the BladeCenter management-module Web interface (see “Starting the BladeCenter management-module Web interface” on page 5).
2. Complete the following steps to enable SOL on the blade servers:
 - a. In the navigation pane, click **Blade Tasks** → **Serial Over LAN**; then, scroll to the **Serial Over LAN Status** section.
 - b. Select each blade server that will have SOL enabled; then, click or select **Enable Serial Over LAN**. (For advanced management modules, you will also need to click **Perform Action**.) Selecting the check box at the top of the status table selects all blade servers. The **SOL** column of the table will show a status of Enabled for each of the blade servers that was selected. The **SOL Session** column of the table indicates a status of Not Ready for each of the blade servers that was selected.
 - c. To disable SOL for a blade server, select each blade server that will have SOL disabled; then, click or select **Disable Serial Over LAN**. (For advanced management modules, you will also need to click **Perform Action**.) Selecting the check box at the top of the status table selects all blade servers. The **SOL** column of the table will show a status of Disabled for each of the blade servers that was selected.

Note: The blade server SOL status periodically updates itself automatically; however, you can refresh the window for an immediate display of updated status.

3. Complete the following steps to power-on or restart the blade servers on which SOL was enabled:
 - a. In the navigation pane, click **Blade Tasks** → **Power/Restart**.
 - b. Select each blade server on which SOL was enabled; then, click either **Power On Blade** or **Restart Blade**, depending on the current status of the blade servers.
 - c. Click **OK** twice to confirm.
4. Complete the following steps to check the SOL status of the blade servers (see “Monitoring SOL session status” on page 41 for more information):
 - a. In the navigation pane, click **Blade Tasks** → **Serial Over LAN**; then, scroll to the **Serial Over LAN Status** section.
 - b. Make sure that the **SOL Session** column of the table shows a status of Ready. For the BladeCenter HS20 Type 8832 blade server, if the SOL Session column does not show a status of Ready, make sure that the J28 jumper on the blade server is in the correct position. See “HS20 Type 8832 SOL jumper placement” on page 28 for information.

Updating and configuring the blade server BIOS

About this task

Note: If you update the blade server BIOS using UpdateXpress, the blade server will maintain any BIOS settings that might have been set previously using the Configuration/Setup Utility program; the blade server will *not* revert to the BIOS default settings when you use UpdateXpress.

Complete the following steps to update and configure the blade server BIOS to enable SOL. Some blade servers have special BIOS update and configuration requirements that are in Chapter 4, “Special component requirements,” on page 25.

1. Complete the following steps to update the blade server BIOS:
 - a. Download the latest version of BIOS for your blade server type from <http://www.ibm.com/support/>.
 - b. Update the blade server BIOS, following the instructions that come with the update file that you downloaded.
2. Complete the following steps to configure the blade server BIOS settings:
 - a. Restart the blade server and press F1 when prompted to start the Configuration/Setup Utility program.
 - b. Select **Devices and I/O Ports**; then, make sure that the values are set as follows:
 - **Serial Port A:** Auto-configure
 - **Serial Port B:** Auto-configure
 - c. Select **Remote Console Redirection**; then, make sure that the values are set as follows:
 - **Remote Console Active:** Enabled
 - **Remote Console COM Port:** COM 2
 - **Remote Console Baud Rate:** 19200
 - **Remote Console Data Bits:** 8
 - **Remote Console Parity:** None

- **Remote Console Stop Bits:** 1
 - **Remote Console Text Emulation:** ANSI
 - **Remote Console Keyboard Emulation:** ANSI
 - **Remote Console Active After Boot:** Enabled
 - **Remote Console Flow Control:** Hardware
- d. Press Esc twice to exit the **Remote Console Redirection** and **Devices and I/O Ports** sections of the Configuration/Setup Utility program.
- Note:** For older blade servers, do not use Planar Ethernet 1 for PXE/DHCP or BOOTP booting or installation. See “Hardware and firmware requirements” on page 2 for information.
- e. If your blade server does not support PXE/BOOTP booting or installation and SOL on Planar Ethernet 1 at the same time, select **Start Options**; then, set the following values:
- **Planar Ethernet PXE/DHCP to Planar Ethernet 2**
 - **Run PXE only on selected Planar NIC to Enabled**
- f. Press Esc to exit the **Start Options** section of the Configuration/Setup Utility program.
- g. Select **Save Settings**; then, press Enter.
- h. Press Enter to confirm.
- i. Select **Exit Setup**; then, press Enter.
- j. Make sure that **Yes, exit the Setup Utility** is selected; then, press Enter.

Chapter 3. Operating system configuration

This section provides instructions for configuring your operating system for SOL operation, including any required installation of device drivers. It includes the following instructions:

- “Linux configuration”
 - “Red Hat Enterprise Linux ES 2.1 configuration”
 - “SUSE SLES 8.0 configuration” on page 19
 - “Installing the Ethernet controller device driver for Linux operating systems” on page 21
- “Microsoft Windows 2003 Standard Edition configuration” on page 22

Linux configuration

Complete one of the following procedures to enable SOL sessions for your Linux operating system. You must be logged in as a root user to perform these procedures. For SOL operation, you must also configure the Linux operating system to expose the Linux initialization (booting) process. This enables users to log in to the Linux console using an SOL session and directs Linux output to the serial console. See the documentation for your specific Linux operating-system type for information and instructions.

Note: You do not have to configure the Linux operating system when using a BladeCenter JS20 Type 8842 blade server; however, you still must install the Ethernet controller device drivers (see “Installing the Ethernet controller device driver for Linux operating systems” on page 21).

Red Hat Enterprise Linux ES 2.1 configuration

Note: This procedure is based on a default installation of Red Hat Enterprise Linux ES 2.1. The file names, structures, and commands might be different for other versions of Red Hat Linux.

Complete the following steps to configure the general Linux parameters for SOL operation when using the Red Hat Enterprise Linux ES 2.1 operating system.

Note: Hardware flow control prevents character loss during communication over a serial connection. You must enable it when using a Linux operating system.

1. Add the following line to the end of the # Run gettys in standard runlevels section of the /etc/inittab file. This enables hardware flow control and enables users to log in through the SOL console.

```
7:2345:respawn:/sbin/agetty -h ttyS1 19200 vt102
```

2. Add the following line at the bottom of the /etc/securetty file to enable a user to log in as the root user through the SOL console:

```
ttyS1
```

LILO configuration

About this task

If you are using LILO, complete the following steps:

1. Complete the following steps to modify the `/etc/lilo.conf` file:
 - a. Add the following text to the end of the first `default=linux` line:
`-Monitor`
 - b. Comment out the `map=/boot/map` line by adding a `#` at the beginning of this line.
 - c. Comment out the `message=/boot/message` line by adding a `#` at the beginning of this line.
 - d. Add the following line before the first `image=...` line:
`# This will allow you to only Monitor the OS boot via SOL`
 - e. Add the following text to the end of the first `label=linux` line:
`-Monitor`
 - f. Add the following line to the first `image=...` section. This enables SOL.
`append="console=ttyS1,19200n8 console=tty1"`
 - g. Add the following lines between the two `image=...` sections:
`# This will allow you to Interact with the OS boot via SOL`
`image=/boot/vmlinuz-2.4.9-e.12smp`
`label=linux-Interact`
`initrd=/boot/initrd-2.4.9-e.12smp.img`
`read-only`
`root=/dev/hda6`
`append="console=tty1 console=ttyS1,19200n8 "`

The following samples show examples of the original content of the `/etc/lilo.conf` file and the content of this file after modification.

Original `/etc/lilo.conf` contents

```
prompt
timeout=50
default=linux
boot=/dev/hda
map=/boot/map
install=/boot/boot.b
message=/boot/message
linear
image=/boot/vmlinuz-2.4.9-e.12smp
    label=linux
    initrd=/boot/initrd-2.4.9-e.12smp.img
    read-only
    root=/dev/hda6
image=/boot/vmlinuz-2.4.9-e.12
    label=linux-up
    initrd=/boot/initrd-2.4.9-e.12.img
    read-only
    root=/dev/hda6
```

Modified /etc/lilo.conf contents

```
prompt
timeout=50
default=linux-Monitor
boot=/dev/hda
#map=/boot/map
install=/boot/boot.b
#message=/boot/message
linear
# This will allow you to only Monitor the OS boot via S0L
image=/boot/vmlinuz-2.4.9-e.12smp
    label=linux-Monitor
    initrd=/boot/initrd-2.4.9-e.12smp.img
    read-only
    root=/dev/hda6
    append="console=ttyS1,19200n8 console=tty1"
# This will allow you to Interact with the OS boot via S0L
image=/boot/vmlinuz-2.4.9-e.12smp
    label=linux-Interact
    initrd=/boot/initrd-2.4.9-e.12smp.img
    read-only
    root=/dev/hda6
    append="console=tty1 console=ttyS1,19200n8 "
image=/boot/vmlinuz-2.4.9-e.12
    label=linux-up
    initrd=/boot/initrd-2.4.9-e.12.img
    read-only
    root=/dev/hda6
```

2. Type `lilo` and then press Enter to store and activate the LILO configuration.

Results

When the Linux operating system starts, a LILO boot: prompt is displayed instead of the graphical user interface. Pressing Tab while at this prompt will install all of the boot options that are listed. To load the operating system in interactive mode, type `linux-Interact` and then press Enter.

GRUB configuration

About this task

If you are using GRUB, complete the following steps to modify the `/boot/grub/grub.conf` file:

1. Comment out the `splashimage=...` line by adding a `#` at the beginning of this line.
2. Add the following line before the first `title=...` line:
`# This will allow you to only Monitor the OS boot via S0L`
3. Append the following text to the first `title=...` line:
`S0L Monitor`

4. Append the following text to the kernel/... line of the first title=... section:

```
console=ttyS1,19200 console=tty1
```
5. Add the following lines between the two title=... sections:

```
# This will allow you to Interact with the OS boot via SOL
title Red Hat Linux (2.4.9-e.12smp) SOL Interactive
    root (hd0,0)
    kernel /vmlinuz-2.4.9-e.12smp ro root=/dev/hda6 console=tty1
console=ttyS1,19200
    initrd /initrd-2.4.9-e.12smp.img
```

Results

Note: The entry beginning with kernel /vmlinuz... is shown with a line break after console=tty1. In your file, the entire entry must all be on one line.

The following samples show examples of the original content of the /boot/grub/grub.conf file and the content of this file after modification.

Original /boot/grub/grub.conf contents
<pre>#grub.conf generated by anaconda # # Note that you do not have to rerun grub after making changes to this file # NOTICE: You have a /boot partition. This means that # all kernel and initrd paths are relative to /boot/, eg. # root (hd0,0) # kernel /vmlinuz-version ro root=/dev/hda6 # initrd /initrd-version.img #boot=/dev/hda default=0 timeout=10 splashimage=(hd0,0)/grub/splash.xpm.gz title Red Hat Enterprise Linux ES (2.4.9-e.12smp) root (hd0,0) kernel /vmlinuz-2.4.9-e.12smp ro root=/dev/hda6 initrd /initrd-2.4.9-e.12smp.img title Red Hat Enterprise Linux ES-up (2.4.9-e.12) root (hd0,0) kernel /vmlinuz-2.4.9-e.12 ro root=/dev/hda6 initrd /initrd-2.4.9-e.12.img</pre>

Modified /boot/grub/grub.conf contents

```
#grub.conf generated by anaconda
#
# Note that you do not have to rerun grub after making changes to this file
# NOTICE: You have a /boot partition. This means that
#         all kernel and initrd paths are relative to /boot/, eg.
#         root (hd0,0)
#         kernel /vmlinuz-version ro root=/dev/hda6
#         initrd /initrd-version.img
#boot=/dev/hda
default=0
timeout=10
# splashimage=(hd0,0)/grub/splash.xpm.gz
# This will allow you to only Monitor the OS boot via SOL
title Red Hat Enterprise Linux ES (2.4.9-e.12smp) SOL Monitor
    root (hd0,0)
    kernel /vmlinuz-2.4.9-e.12smp ro root=/dev/hda6 console=ttyS1,19200 console=tty1
    initrd /initrd-2.4.9-e.12smp.img
# This will allow you to Interact with the OS boot via SOL
title Red Hat Linux (2.4.9-e.12smp) SOL Interactive
    root (hd0,0)
    kernel /vmlinuz-2.4.9-e.12smp ro root=/dev/hda6 console=tty1 console=ttyS1,19200
    initrd /initrd-2.4.9-e.12smp.img
title Red Hat Enterprise Linux ES-up (2.4.9-e.12)
    root (hd0,0)
    kernel /vmlinuz-2.4.9-e.12 ro root=/dev/hda6
    initrd /initrd-2.4.9-e.12.img
```

You must reboot the Linux operating system after completing these procedures for the changes to take effect and to enable SOL. You must also install device drivers for your Ethernet controller (see “Installing the Ethernet controller device driver for Linux operating systems” on page 21).

SUSE SLES 8.0 configuration

About this task

Note: This procedure is based on a default installation of SUSE SLES 8.0. The file names, structures, and commands might be different for other versions of SUSE Linux.

Complete the following steps to configure the general Linux parameters for SOL operation when using the SUSE SLES 8.0 operating system.

Note: Hardware flow control prevents character loss during communication over a serial connection. You must enable it when using a Linux operating system.

1. Add the following line to the end of the # `getty-programs` for the normal `runlevels` section of the `/etc/inittab` file. This enables hardware flow control and enables users to log in through the SOL console.

```
7:2345:respawn:/sbin/agetty -h ttyS1 19200 vt102
```

2. Add the following line after the tty6 line at the bottom of the /etc/securetty file to enable a user to log in as the root user through the SOL console:
ttyS1
3. Complete the following steps to modify the /boot/grub/menu.lst file:
 - a. Comment out the gfxmenu... line by adding a # at the beginning of the line.
 - b. Add the following line before the first title... line:
This will allow you to only Monitor the OS boot via SOL
 - c. Add the following text to the end of the first title... line:
SOL Monitor
 - d. Add the following text to the end of the kernel... line of the first title... section:
console=ttyS1,19200 console=tty1
 - e. Add the following lines between the first two title... sections:
This will allow you to Interact with the OS boot via SOL
title linux SOL Interactive
kernel (hd0,1)/boot/vmlinuz root=/dev/hda2 acpi=oldboot vga=791
console=tty1 console=ttyS1,19200
initrd (hd0,1)/boot/initrd

Results

Note: The entry beginning with kernel (hd0,1) is shown with a line break after vga=791. In your file, the entire entry must all be on one line.

The following samples show the original content of the /boot/grub/menu.lst file and the content of this file after modification.

Original /boot/grub/menu.lst contents	Notes
<pre> gfxmanu (hd0,1)/boot/message color white/blue black/light-gray default 0 timeout 8 title linux kernel (hd0,1)/boot/vmlinuz root=/dev/hda2 acpi=oldboot vga=791 initrd (hd0,1)/boot/initrd title floppy root chainloader +1 title failsafe kernel (hd0,1)/boot/vmlinuz.shipped root=/dev/hda2 ide=nodma apm=off vga=normal nosmp disablepic maxcpus=0 3 initrd (hd0,1)/boot/initrd.shipped </pre>	1
<p>Note 1: The entry beginning with kernel (hd0,1) is shown with a line break after nosmp. In your file, the entire entry must all be on one line.</p>	

Modified /boot/grub/menu.lst contents	Notes
<pre>#gfxmanu (hd0,1)/boot/message color white/blue black/light-gray default 0 timeout 8 # This will allow you to only Monitor the OS boot via SOL title linux SOL Monitor kernel (hd0,1)/boot/vmlinuz root=/dev/hda2 acpi=oldboot vga=791 console=ttyS1,19200 console=tty1 initrd (hd0,1)/boot/initrd # This will allow you to Interact with the OS boot via SOL title linux SOL Interactive kernel (hd0,1)/boot/vmlinuz root=/dev/hda2 acpi=oldboot vga=791 console=tty1 console=ttyS1,19200 initrd (hd0,1)/boot/initrd title floppy root chainloader +1 title failsafe kernel (hd0,1)/boot/vmlinuz.shipped root=/dev/hda2 ide=nodma apm=off vga=normal nosmp disableapic maxcpus=0 3 initrd (hd0,1)/boot/initrd.shipped</pre>	<p>1</p>
<p>Note 1: The entry beginning with kernel (hd0,1) is shown with a line break after nosmp. In your file, the entire entry must all be on one line.</p>	

You must reboot the Linux operating system after completing these procedures for the changes to take effect and to enable SOL. You must also install device drivers for your Ethernet controller (see “Installing the Ethernet controller device driver for Linux operating systems”).

Installing the Ethernet controller device driver for Linux operating systems

About this task

If you are using a Linux operating system, complete the following steps to install the device driver for your Ethernet controller. Before performing these steps, make sure that you are logged in as a root user, that the development tools packages have already been installed, and that the kernel source package or cross-compile utilities have already been installed.

1. Obtain the latest version of the Ethernet controller device-driver source package for your blade server type from <http://www.ibm.com/support/>.
2. Update the blade server Ethernet controller device drivers, following the instructions that come with the device-driver source package that you downloaded.
3. Configure the network interfaces for the Linux operating system. See the documentation for your operating system for information and instructions.

Microsoft Windows 2003 Standard Edition configuration

About this task

Note: This procedure is based on a default installation of the Microsoft® Windows® 2003 operating system.

Complete the following steps to configure the Windows 2003 operating system for SOL operation. You must be logged in as a user with administrator access to perform this procedure.

1. Complete the following steps to determine which boot entry ID to modify:
 - a. Type `bootcfg` at a Windows command prompt; then press Enter to display the current boot options for your system.
 - b. In the **Boot Entries** section, locate the **Boot entry ID** for the section with an OS friendly name of Windows Server 2003, Standard. Write down the **Boot entry ID** that appears above this line for use in the next step.
2. To enable the Microsoft Windows Emergency Management System (EMS), at a Windows command prompt, type `bootcfg /EMS ON /PORT COM2 /BAUD 19200 /ID boot_id` where *boot_id* is the boot entry ID from step 1b; then, press Enter.
3. Complete the following steps to verify that the EMS console is redirected to the COM2 serial port:
 - a. Type `bootcfg` at a Windows command prompt; then, press Enter to display the current boot options for your system.
 - b. Verify the following changes to the `bootcfg` settings:
 - In the **Boot Loader Settings** section, make sure that **redirect** is set to **COM2** and that **redirectbaudrate** is set to **19200**.
 - In the **Boot Entries** section, make sure that the OS Load Options: line has `/redirect` appended to the end of it.

Results

The following samples show examples of the original `bootcfg` program output and the output after modification.

Original bootcfg program output
<pre>Boot Loader Settings ----- timeout: 30 default: multi(0)disk(0)rdisk(0)partition(1)\WINDOWS Boot Entries ----- Boot entry ID: 1 OS Friendly Name: Windows Server 2003, Standard Path: multi(0)disk(0)rdisk(0)partition(1)\WINDOWS OS Load Options: /fastdetect</pre>

Modified bootcfg program output

```
Boot Loader Settings
-----
timeout: 30
default: multi(0)disk(0)rdisk(0)partition(1)\WINDOWS
redirect: COM2
redirectbaudrate: 19200
Boot Entries
-----
Boot entry ID: 1
OS Friendly Name: Windows Server 2003, Standard
Path: multi(0)disk(0)rdisk(0)partition(1)\WINDOWS
OS Load Options: /fastdetect /redirect
```

You must reboot the Windows 2003 operating system after completing this procedure for the changes to take effect and to enable SOL.

Note: For SOL to operate, you might need to uninstall the COM2 device from the Windows device manager. See the documentation that comes with your operating system for instructions.

Chapter 4. Special component requirements

Most BladeCenter components are pre-configured for SOL operation. Some BladeCenter components must be configured to support SOL operation. This section provides instructions for configuring BladeCenter components for SOL operation. It also provides information that is needed when connecting certain components for SOL operation. Use this information in addition to the information in Chapter 2, “General configuration,” on page 7 and Chapter 3, “Operating system configuration,” on page 15. This section is divided into the following subsections:

Special blade server configuration requirements:

- “Configuring the BladeCenter HS22 Type 7870 blade server”
- “Configuring the BladeCenter HS20 Type 8832 and HS20 Type 8843 blade servers” on page 27
- “Configuring the BladeCenter HS40 Type 8839 blade server” on page 29
- “Configuring the BladeCenter JS20 Type 8842 blade server” on page 30

Special I/O-module configuration and connection requirements:

- “Configuring the IBM 4-Port Gb Ethernet Switch Module for BladeCenter” on page 32
- “Configuring the Nortel Networks Layer 2-7 GbE Switch Module for IBM BladeCenter” on page 33
- “Configuring the Cisco Systems Intelligent Gigabit Ethernet Switch Module for the IBM BladeCenter” on page 34
- “Connecting an Intelligent Copper Pass-thru Module” on page 36


Configuring the BladeCenter HS22 Type 7870 blade server

About this task


Complete the following steps to configure the HS22 Type 7870 blade server for SOL operation. See the *IBM BladeCenter HS22 Type 7870 Installation and User's Guide* for additional information relating to these steps.

1. Obtain the latest versions of HS22 Type 7870 blade server firmware from <http://www.ibm.com/support/>.
2. Update the HS22 Type 7870 blade server firmware, following the instructions that come with the update file that you downloaded. The HS22 Type 7870 blade server has multiple firmware images. Make sure that you restart the blade server after updating each firmware image.
3. Make sure that you have configured the BladeCenter unit and the operating system for SOL operation, following the instructions in Chapter 2, “General configuration,” on page 7 and Chapter 3, “Operating system configuration,” on page 15.
4. Restart the blade server and immediately give the blade server control of the BladeCenter unit shared keyboard, video, and mouse ports.
 - If you are managing the blade server by using the BladeCenter system console, press the KVM select button on the blade server.

- If you are managing the blade server from a remote location, see the *IBM BladeCenter Management Module User's Guide* or *IBM BladeCenter Management Module Command-Line Interface Reference Guide* for information and instructions.
5. When the prompt Press <F1> Setup is displayed, press F1. If you have set an administrator password, you must type the administrator password to access the full Setup-utility menu. If you do not type the administrator password, a limited Setup-utility menu is available.
 6. Select **System Settings** and then press Enter.
 7. Select **Devices and I/O Ports** and then press Enter.
 8. Select **Console Redirection Settings** and then press Enter.
 9. From the Console Redirection Settings menu:
 - a. If you are using a serial breakout cable with a BladeCenter H unit or a BladeCenter S unit, set **COM Port 1** to **Enable**; otherwise, set it to **Disable**.



- b. Set **COM Port 2** to **Enable**.
- c. Set **Remote Console** to **Enable**.
- d. Set **Legacy Option ROM Display** to **COM Port 2**.
- e. Set the following **COM2 Settings**:



- 1) Make sure that the **Baud Rate** is set to **115200**.

Note: The settings for **Data Bits**, **Parity**, and **Stop Bits** are static and cannot be changed.

- 2) Set **Terminal Emulation** to ANSI (default) or VT100, depending on your system configuration.
 - 3) Set **Active After Boot** to **Enable**.
 - 4) Set **Flow Control** to **Hardware**.
10. Press Esc four times; then, press Y, when prompted, to save settings and restart the blade server.



What to do next

After the blade server has restarted, you can establish an SOL session to it using the advanced management module CLI. See “Starting an SOL session” on page 37 for information and instructions.

Configuring the BladeCenter HS20 Type 8832 and HS20 Type 8843 blade servers

About this task

Note: If an SOL session for the BladeCenter HS20 Type 8832 or Type 8843 blade server displays only a flashing cursor in a blank screen, this indicates an interruption in the flow of serial data. Press Ctrl+q to resume serial data flow.


The following sections describe the SOL configuration that is required for the BladeCenter HS20 Type 8832 and Type 8843 blade servers. You must perform the following procedures:

- “HS20 Type 8832 SOL jumper placement” on page 28 (Type 8832 blade server only)
- “Updating and configuring the blade server BIOS” on page 13
- “Updating the integrated systems management processor firmware” on page 28
- “Updating the Broadcom Ethernet controller firmware” on page 29
- “Installing the Ethernet controller device driver for Linux operating systems” on page 21

HS20 Type 8832 SOL jumper placement

About this task

For SOL operation with the HS20 Type 8832 blade server, jumper J28 on the blade server must be installed on pins 2 and 3. This is the default jumper position that directs SOL data to I/O-module bay 1 in the BladeCenter unit.



Updating the integrated systems management processor firmware

About this task

Note: Make sure that the blade server BIOS is upgraded and configured before you update the integrated systems management processor firmware (see “Updating and configuring the blade server BIOS” on page 13).

Complete the following procedure to update the BladeCenter HS20 Type 8832 or Type 8843 blade server integrated systems management processor (ISMP) firmware. No configuration is required for the BladeCenter HS20 Type 8832 or Type 8843 blade server ISMP to enable SOL.

Attention: Do not change the BladeCenter media tray owner by pressing the button on the front of the blade server or through the BladeCenter management-module Web interface while the ISMP firmware update is in progress. This will interrupt the update procedure and might damage the blade server.

Complete the following steps to update the BladeCenter HS20 Type 8832 or Type 8843 blade server ISMP firmware:

1. Download the latest version of ISMP firmware for your blade server type from <http://www.ibm.com/support/>.
2. Update the blade server ISMP firmware, following the instructions that come with the update file that you downloaded. To update the blade server ISMP firmware click **Blade Tasks** → **Firmware Update** in the BladeCenter management-module Web interface or use an update diskette.

Updating the Broadcom Ethernet controller firmware

About this task

The Broadcom Ethernet controller on the BladeCenter HS20 Type 8832 and Type 8843 blade servers has the following requirements for SOL operation:

- An SOL capable Ethernet I/O module must be installed in I/O module bay 1 of the BladeCenter unit (see “Hardware and firmware requirements” on page 2).
- For the BladeCenter HS20 Type 8832 blade server, the SOL jumper J28 must be placed on pins 2 and 3. This is the default jumper position. See “HS20 Type 8832 SOL jumper placement” on page 28.

Complete the following steps to update the BladeCenter HS20 Type 8832 or Type 8843 blade server Broadcom Ethernet controller firmware. You do not have to configure the Broadcom Ethernet Controllers to enable SOL.

1. Download the latest version of Broadcom Ethernet controller firmware for your blade server type from <http://www.ibm.com/support/>.
2. Update the blade server Broadcom Ethernet controller firmware, following the instructions that come with the update file that you downloaded. To update the blade server Broadcom Ethernet controller firmware, use an update diskette or use the Broadcom Ethernet controller diagnostic utility, depending on the operating system that is installed on your blade server.

Configuring the BladeCenter HS40 Type 8839 blade server

The following sections describe the SOL configuration that is required for the BladeCenter HS40 Type 8839 blade server. You must perform the following procedures:

- “Updating the Baseboard Management Controller firmware”
- “Updating and configuring the BIOS” on page 30
- “Installing the Ethernet controller device driver for Linux operating systems” on page 21

Updating the Baseboard Management Controller firmware

About this task

No configuration is required for the BladeCenter HS40 Type 8839 blade server BMC to enable SOL.

Complete the following steps to update the BladeCenter HS40 Type 8839 blade server BMC firmware:

1. Download the latest version of BladeCenter HS40 Type 8839 blade server BMC firmware from <http://www.ibm.com/support/>.
2. Update the blade server BMC firmware, following the instructions that come with the update images that you downloaded. To update the blade server BMC firmware, use an update diskette.

Updating and configuring the BIOS

About this task

Important: The BladeCenter HS40 Type 8839 blade server BMC firmware must be updated before you update the BIOS firmware.

Complete the following steps to update and configure the BladeCenter HS40 Type 8839 blade server BIOS to enable SOL:

1. Complete the following steps to update the BladeCenter HS40 Type 8839 blade server BIOS:
 - a. Download the latest version of BladeCenter HS40 Type 8839 blade server BIOS from <http://www.ibm.com/support/>.
 - b. Update the blade server BIOS, following the instructions that come with the update images that you downloaded.
2. Complete the following steps to configure the BladeCenter HS40 Type 8839 blade server BIOS settings:
 - a. Restart the blade server and press F1 when prompted to start the Configuration/Setup Utility program.
 - b. Select **Devices and I/O Ports**; then, make sure that the **Serial Ports** value is set to **Enabled**
 - c. Select **Remote Console Redirection**; then, make sure that the values are set as follows:

Note: For newer versions of HS40 Type 8839 BIOS, the BIOS Redirection Port is set to a fixed value of Serial 2 and cannot be changed.

 - **BIOS Redirection Port:** Serial 2
 - **Baud Rate:** 19.2K
 - **Flow Control:** CTS/RTS
 - **Terminal Type:** VT100+
 - d. Press Esc twice to exit the **Remote Console Redirection** and **Devices and I/O Ports** sections of the Configuration/Setup Utility program.
 - e. Press F10.
 - f. Make sure that **OK** is selected; then, press Enter.
3. Remove the blade server from the BladeCenter unit and then reinstall it. See the *Installation and User's Guide* for your blade server for instructions.

Configuring the BladeCenter JS20 Type 8842 blade server

No manual configuration of the BladeCenter JS20 Type 8842 blade server open firmware (BIOS) or ISMP is required. This blade server automatically configures itself when you install it in the BladeCenter unit and is automatically reconfigured after you install new software or hardware. The BladeCenter JS20 Type 8842 blade server has built-in support for the SOL feature. You must install the Broadcom Ethernet controller device driver after you install the blade server operating system.

You must use the SOL feature to initially install and configure the operating system in the BladeCenter JS20 Type 8842 blade server. After the operating system has been completely installed and configured, you can use either Telnet or SSH sessions to communicate directly with the blade server operating system.

Note: The Broadcom Ethernet controller on the BladeCenter JS20 Type 8842 blade server might be unable to communicate for a few seconds while the blade server is restarting. If this occurs, the current SOL session will be terminated; however, the SOL session can be established again after the blade server restarts.

The following sections describe how to set up SOL for the BladeCenter JS20 Type 8842 blade server. You must perform the following procedures:

- “Updating the open firmware (BIOS)”
- “Updating the integrated systems management processor firmware”
- “Updating the Broadcom Ethernet controller firmware” on page 32
- “Installing the Ethernet controller device driver for Linux operating systems” on page 21

Updating the open firmware (BIOS)

About this task

Notes:

1. The Linux operating system must be installed and configured before updating BIOS.
2. You must be logged in as a root user to perform these procedures.
3. If an SOL session is in progress, it will be terminated when the BladeCenter JS20 Type 8842 blade server open firmware is updated. The SOL session can be established again after the firmware update is complete.

Complete the following steps to update the BladeCenter JS20 Type 8842 blade server open firmware. You do not have to configure the blade server open firmware to enable SOL.

1. Download the latest version of BladeCenter JS20 Type 8842 blade server open firmware from <http://www.ibm.com/support/>.
2. Update the blade server open firmware, following the instructions that come with the update file that you downloaded.

Updating the integrated systems management processor firmware

About this task

Attention: Do not change the BladeCenter media tray owner by pressing the button on the front of the blade server or through the BladeCenter management-module Web interface while the integrated systems management processor (ISMP) firmware update is in progress. This will interrupt the update procedure and might damage the BladeCenter JS20 Type 8842 blade server.

Important: You must update the open firmware (BIOS) on the BladeCenter JS20 Type 8842 blade server before you update the ISMP firmware.

Complete the following steps to update the BladeCenter JS20 Type 8842 blade server ISMP firmware. You do not have to configure the ISMP to enable SOL.

1. Download the latest version of BladeCenter JS20 Type 8842 blade server ISMP firmware from <http://www.ibm.com/support/>.

2. Update the blade server ISMP firmware, following the instructions that come with the update file that you downloaded. To update the blade server ISMP firmware, click **Blade Tasks** → **Firmware Update** in the BladeCenter management-module Web interface.

Updating the Broadcom Ethernet controller firmware

About this task

Notes:

1. The Linux operating system must be installed and configured before updating the Broadcom Ethernet controller firmware.
2. You must be logged in as a root user to perform these procedures.

The Broadcom Ethernet controller on the BladeCenter JS20 Type 8842 blade server has the following requirements for SOL operation:

- An SOL capable Ethernet I/O module must be installed in I/O module bay 1 of the BladeCenter unit (see “Hardware and firmware requirements” on page 2).
- You must not have any other Broadcom Ethernet Controller devices, such as the BladeCenter Gigabit Ethernet Expansion Card, activated.
- The latest Broadcom Ethernet controller network device driver must be installed and both Ethernet interfaces (eth0 and eth1) must be configured before you use the Broadcom Ethernet controller diagnostic utility.

Complete the following steps to update the BladeCenter JS20 Type 8842 blade server Broadcom Ethernet controller firmware. You do not have to configure the Broadcom Ethernet controllers to enable SOL.

1. Download the latest version of BladeCenter JS20 Type 8842 blade server Broadcom Ethernet controller firmware from <http://www.ibm.com/support/>.
2. Update the blade server Broadcom Ethernet controller firmware, following the instructions that come with the update file that you downloaded.

Results

After installing the Broadcom Ethernet controller firmware, you must restart the blade server before you can use the SOL feature.

Configuring the IBM 4-Port Gb Ethernet Switch Module for BladeCenter

About this task

Complete the following steps to update the firmware of the IBM 4-Port Gb Ethernet Switch Module for BladeCenter. No configuration is required for the IBM 4-Port Gb Ethernet Switch Module for BladeCenter to enable SOL.

Note:

1. You will not be able to perform this procedure if the values for the network configuration of the IBM 4-Port Gb Ethernet Switch Module for BladeCenter are not within the same subnet as the BladeCenter management-module network interfaces (eth0 and eth1). See “Configuring the management module” on page 9 for information.
2. If you are using management channel auto discovery (MCAD), replace references to I/O-module bay 1 in the following procedure with the I/O

module bay number that is actually being used (see the *BladeCenter Advanced Management Module User's Guide* for additional information about MCAD).

1. Obtain the latest version of IBM 4-Port Gb Ethernet Switch Module for BladeCenter firmware from <http://www.ibm.com/support/>.
2. Start the BladeCenter management-module Web interface (see “Starting the BladeCenter management-module Web interface” on page 5).
3. In the navigation pane, click **I/O Module Tasks → Configuration**.
4. Scroll to the **Current IP Configuration** section and make sure that it contains values that are within the same subnet as the BladeCenter management-module network interfaces (eth0 and eth1). If the values are not in the same subnet, you must modify them before you continue. See “Configuring the management module” on page 9 for information.
5. Scroll to the **Bay 1 (Ethernet SM)*** section; then, click **Advanced Management**.
6. Scroll to the **Start Telnet/Web Session** section; then, click **Start Web Session**. This will start a new Web browser session and connect to the IBM 4-Port Gb Ethernet Switch Module for BladeCenter Web interface.
7. Log in to the IBM 4-Port Gb Ethernet Switch Module for BladeCenter Web interface.
8. Click **Maintenance**.
9. Click **Using Browser**.
10. Click **Upgrade Firmware/Configuration**.
11. Click **Browse**; then, select the firmware update file that you obtained in step 1.
12. Click **Start**; then, click **Yes** to confirm each time you are asked a question.
13. Close the Web browser.
14. Complete the following steps to restart the I/O module:
 - a. In the navigation pane, click **I/O Module Tasks → Admin/Power/Restart**.
 - b. Select your IBM 4-Port Gb Ethernet Switch Module for BladeCenter and click **Restart Module(s) and Run Standard Diagnostics**.
 - c. Click **OK** to confirm.

Configuring the Nortel Networks Layer 2-7 GbE Switch Module for IBM BladeCenter

About this task

Complete the following steps to update the firmware of the Nortel Networks Layer 2-7 GbE Switch Module for IBM BladeCenter. No configuration is required for the Nortel Networks Layer 2-7 GbE Switch Module for IBM BladeCenter to enable SOL.

Notes:

- You will not be able to perform this procedure if the values for the network configuration of the Nortel Networks Layer 2-7 GbE Switch Module for IBM BladeCenter are not within the same subnet as the BladeCenter management-module network interfaces (eth0 and eth1). See “Configuring the management module” on page 9 for information.
- These steps require that an accessible TFTP (Trivial FTP) server is present on your production network.

1. Obtain the latest version of Nortel Networks Layer 2-7 GbE Switch Module for IBM BladeCenter firmware from <http://www.ibm.com/support/>.
2. Update the Nortel Networks Layer 2-7 GbE Switch Module for IBM BladeCenter firmware, following the instructions that come with the update file that you downloaded. The Nortel Networks Layer 2-7 GbE Switch Module has multiple firmware images. These images must all be updated, in the correct order. Make sure that you restart the Nortel Networks Layer 2-7 GbE Switch Module after updating each firmware image.

Configuring the Cisco Systems Intelligent Gigabit Ethernet Switch Module for the IBM BladeCenter

About this task

Note: For Cisco IOS release 12.1(22)EA6a and later, the SOL VLAN ID is set to a default value of 4095. If you use the default SOL VLAN ID of 4095, no additional configuration of the Cisco Systems Intelligent Gigabit Ethernet Switch Module is required. You need to complete the following procedure if you set a custom SOL VLAN ID.

Complete the following steps to configure the Cisco Systems Intelligent Gigabit Ethernet Switch Module for the IBM BladeCenter. The Cisco Systems Intelligent Gigabit Ethernet Switch Module has built-in support for the SOL feature and does not require a firmware upgrade.

Note:

1. You will not be able to perform this procedure if the values for the network configuration of the Cisco Systems Intelligent Gigabit Ethernet Switch Module are not within the same subnet as the BladeCenter management-module network interfaces (eth0 and eth1). See “Configuring the management module” on page 9 for information.
2. If you are using management channel auto discovery (MCAD), replace references to I/O-module bay 1 in the following procedure with the I/O module bay number that is actually being used (see the *BladeCenter Advanced Management Module User’s Guide* for additional information about MCAD).
 1. Start the BladeCenter management-module Web interface (see “Starting the BladeCenter management-module Web interface” on page 5).
 2. In the navigation pane, click **I/O Module Tasks** → **Configuration**.
 3. Scroll to the **Current IP Configuration** section and make sure that it contains values that are within the same subnet as the BladeCenter management-module network interfaces (eth0 and eth1). If the values are not in the same subnet, you must modify them before you continue. See “Configuring the management module” on page 9 for information.
 4. Scroll to the **Bay 1 (Ethernet SM)*** section; then, click **Advanced Management**.
 5. Scroll to the **Start Telnet/Web Session** section; then, click **Start Telnet Session**. This will start a new Telnet session and connect to the Cisco Systems Intelligent Gigabit Ethernet Switch Module Telnet interface.
 6. Log in to the Cisco Systems Intelligent Gigabit Ethernet Switch Module Telnet interface.
 7. Complete the following steps to activate the VLAN ID for the Cisco Systems Intelligent Gigabit Ethernet Switch Module:
 - a. Type `en` and then press Enter.

- b. Type `config t` and then press Enter.
- c. Type `vlan vlan_id`, where *vlan_id* is the VLAN ID that was set for the management module (see “Configuring the global SOL settings for the BladeCenter unit” on page 7); then, press Enter.
- d. Type `state active` and then press Enter.
- e. Type `end` and then press Enter.
- f. Type `wri` and then press Enter.

Attention: To maintain system security, you must remove the SOL VLAN ID from the external ports of the Cisco Systems Intelligent Gigabit Ethernet Switch Module.

8. Complete the following steps to remove the SOL VLAN ID from the external ports of the Cisco Systems Intelligent Gigabit Ethernet Switch Module:
 - a. Type `config t` and then press Enter.
 - b. Type `int gi0/port_number`, where *port_number* is an external port number from 17 through 20 for the switch module; then, press Enter.
 - c. Type `switchport trunk allowed vlan remove vlan_id`, where *vlan_id* is the VLAN ID that was set in step 7c (4095, by default); then, press Enter.
 - d. Repeat step 8b and 8c for each external port number from 17 through 20.
 - e. Type `end` and then press Enter.
 - f. Type `wri` and then press Enter.

Note: For SOL operation with Cisco IOS releases earlier than 12.1(22)EA6a, the internal interfaces of the Cisco Ethernet Switch Module must be set to trunk mode. Trunk mode is the default configuration. If SOL sessions do not go into a Ready state and you are using Cisco IOS releases earlier than 12.1(22)EA6a, perform the procedure in step 9 to configure trunk mode.

9. Complete the following steps to configure the internal interfaces of the Cisco Systems Intelligent Gigabit Ethernet Switch Module for trunk mode:
 - a. Type `config t` and then press Enter.
 - b. Type `int gi0/port_number`, where *port_number* is an external port number from 1 through 14 for the switch module; then, press Enter.
 - c. Type `switchport mode trunk` and then, press Enter.
 - d. Repeat step 9b and 9c for each external port number from 1 through 14.
 - e. Type `exit` and then press Enter.
 - f. Type `int gi0/port_number`, where *port_number* is an external port number from 1 through 16 for the switch module; then, press Enter.
 - g. Type `sw trunk allow vlan add vlan_id`, where *vlan_id* is the VLAN ID that was set in step 7c; then, press Enter.
 - h. Repeat step 9f and 9g for each external port number from 1 through 16.
 - i. Type `end` and then press Enter.
 - j. Type `wri` and then press Enter.
10. Type `exit` and then press Enter to close the Cisco Systems Intelligent Gigabit Ethernet Switch Module Telnet interface session.
11. Close the window in which the Telnet session was running.

Connecting an Intelligent Copper Pass-thru Module

Before you begin

For SOL to function with an Intelligent Copper Pass-thru Module (ICPM), the external port corresponding to the blade server must have an Ethernet cable attached to it with a link to an upstream switch. For example, to support SOL for the blade server in bay 2, you must plug an Ethernet cable into RJ-45 port 2 of the ICPM and have this Ethernet cable connected to an upstream switch.

Chapter 5. Using SOL

The BladeCenter management module command-line interface provides a convenient method for entering commands that manage and monitor BladeCenter components. This section contains the following information about using the command-line interface:

- “Starting an SOL session”
- “Ending an SOL session” on page 40
- “Monitoring SOL session status” on page 41
- “Restarting a blade server through SOL” on page 43
- “Mounting and unmounting media for Linux operating systems” on page 44

See the documentation for your operating system for information about commands that you can enter through an SOL connection.

Starting an SOL session

Start an SOL session from a client computer through the management-module command-line interface by establishing a Telnet connection to the IP address of the management module, by setting up a session with the management module serial port (advanced management module only), or by establishing a Secure Shell (SSH) connection. You can establish up to 20 separate Web interface, Telnet, serial (advanced management module only), or SSH sessions with a BladeCenter management module. For a BladeCenter unit, this enables you to have 14 simultaneous SOL sessions active (one for each of up to 14 blade servers) with 6 additional command-line interface sessions available for BladeCenter unit management. For a BladeCenter T unit, this enables you to have 8 simultaneous SOL sessions active (one for each of up to 8 blade servers) with 12 additional command-line interface sessions available for BladeCenter unit management. See the *BladeCenter Management Module Command-Line Interface Reference Guide* for information about the management-module command-line interface.

This section provides the following instructions:

- “Starting a command-line Telnet connection” on page 38
- “Establishing a serial connection” on page 38
- “Starting a command-line Secure Shell (SSH) connection” on page 39
- “Starting an SOL session from the command-line interface” on page 39

Note: When using a Microsoft Windows client to make an SOL connection to a server running a Linux or Unix operating system, you might experience problems such as double command prompts or an inability to issue commands that execute correctly. If this happens, change the terminal emulation software being used on the Windows client to map the Enter key as a carriage return (hex 0x0D) instead of the carriage return and line feed combination. Linux and Unix operating systems require only a carriage return to terminate commands in the CLI.

Starting a command-line Telnet connection

About this task

Note: If there is no Telnet or SOL traffic within the timeout interval specified in the management module, the Telnet session and any SOL session associated with this Telnet session will terminate. See the *BladeCenter Management Module Command-Line Interface Reference Guide* for information about configuring the Telnet session timeout value.

To log on to the management module using Telnet, complete the following steps:

1. Open a command-line window on the network-management workstation, type `telnet 192.168.70.125`, and press Enter. The IP address 192.168.70.125 is the default IP address of the management module; if a new IP address has been assigned to the management module, use that one instead. You can also substitute a valid host name instead of using an IP address.

A command-prompt window opens.

2. At the login prompt, type the management-module user ID. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module Web access. The default management-module user name is USERID and the default password is PASSWORD (note the number zero, not the letter O, in PASSWORD).

A CLI command prompt is displayed. You can now enter commands for the management module.

Establishing a serial connection

About this task

After connecting a serial cable from the advanced management module to the client computer, complete the following steps:

1. Open a terminal session on the client computer, and make sure that the serial port settings for the client computer match the settings for the serial port on the advanced management module. The default advanced management-module serial port settings are as follows:
 - Baud rate: 57600
 - Parity: no parity
 - Stop bits: 1
2. At the login prompt, type the management-module user ID. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module Web access. The default management-module user name is USERID and the default password is PASSWORD (note the number zero, not the letter O, in PASSWORD).

Results

The CLI command prompt is displayed. You can now enter commands for the management module.

Starting a command-line Secure Shell (SSH) connection

About this task

To log on to the management module using SSH, complete the following steps:

1. Make sure that the SSH service on the network-management workstation is enabled. See your operating-system documentation for instructions.
2. Make sure that the SSH server on the BladeCenter management module is enabled. See the *BladeCenter Management Module User's Guide* for instructions.
3. Start a SSH session to the management module using the SSH client of your choice. For example, if you are using the cygwin client, open a command-line window on the network-management workstation, type `ssh -x 192.168.70.125`, and press Enter. The IP address 192.168.70.125 is the default IP address of the management module; if a new IP address has been assigned to the management module, use that one instead.

A command-prompt window opens.

4. Type the management-module user ID when prompted. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module Web access. The default management-module user name is USERID and the default password is PASSWORD (note the number zero, not the letter O, in PASSWORD).

A CLI command prompt is displayed. You can now enter commands for the management module.

Starting an SOL session from the command-line interface

About this task

After an SOL session is started, all commands are sent to the operating system on the blade server specified by the **console** command until the SOL session is ended, regardless of the persistent command target that was in effect before the SOL session. During an SOL session, no BladeCenter command-line interface commands are valid. If a blade server is restarted while an SOL session is in progress, the SOL session remains in progress while the blade server restarts. Restarting the management module will end all SOL sessions that are running.

The BladeCenter management module automatically stores the previous 8 KB (kilobytes) of serial data that was transmitted by each blade server even when SOL sessions are not active. When an SOL session is established, all of the previous serial data, up to 8 KB, is automatically displayed. If no previous data is available when the SOL session is started, the cursor will remain on the command line until new serial data is transmitted. If a management module fails, all Telnet and SOL sessions are terminated, and their caches are lost, even if failover to a redundant management module is successful.

See the *BladeCenter Management Module Command-Line Interface Reference Guide* for information about configuring a blade server for SOL using the management module command-line interface. See your operating-system documentation for information about commands that you can enter using an SOL command-line interface.

Note: Serial over LAN (SOL) must be enabled for both the BladeCenter unit and the blade server before you can start an SOL session with the blade server. See

Chapter 2, “General configuration,” on page 7 and Chapter 4, “Special component requirements,” on page 25 for information about enabling SOL.

After you start a Telnet or SSH session to the BladeCenter management module (see the *BladeCenter Management Module Command-Line Interface Reference Guide*), you can start an SOL session to any individual blade server that supports SOL using the **console** command. Because you can start up to 20 separate Web interface, Telnet, serial (advanced management module only), or SSH sessions to the BladeCenter management module, you can have up to 14 simultaneous SOL sessions with blade servers and 6 command-line interface sessions with other BladeCenter components active at the same time. available for BladeCenter unit management. For a BladeCenter T unit, you can have up to 8 simultaneous SOL sessions with blade servers and 12 command-line interface sessions with other BladeCenter T components active at the same time.

To start an SOL session from the command line, type the following command, indicating the target blade server:

```
console -T system:blade[x]
```

where *x* is the blade bay where the blade server assembly is installed. (A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies.)

For example, to start an SOL connection to the blade server in blade bay 5, type

```
console -T system:blade[5]
```

Note: If an SOL session displays only a flashing cursor in a blank screen, this indicates an interruption in the flow of serial data. Press Ctrl+q to resume serial data flow.

Ending an SOL session

About this task

To end an SOL session, press Esc followed by an open parenthesis (press Shift and 9 at the same time):

```
Esc (
```

When the SOL session ends, the command-line interface returns to the persistent command target that was in effect before the SOL session. If you want to end the Telnet or SSH command-line session, type `exit`.

Notes:

1. Exiting an SOL session does not stop the flow of serial data.
2. The keys pressed to end an SOL session and return to the management-module command line interface can be set to another user-defined keystroke sequence. See the *BladeCenter Management Module User's Guide* for information.

Monitoring SOL session status

About this task

Complete the following steps to monitor SOL session status:

1. Start the BladeCenter management-module Web interface (see “Starting the BladeCenter management-module Web interface” on page 5).
2. In the navigation pane, click **Blade Tasks** → **Serial Over LAN**; then, scroll to the **Serial Over LAN Status** section.

Results

The following illustration shows the SOL status page for management modules other than an advanced management module.

Serial Over LAN Status ⓘ

Click the checkboxes in the first column to select one or more blade servers; then, click one of the links below the table to enable or disable SOL on the selected blades.

Note: You have to enable the global "Serial over LAN" flag above before enabling SOL on individual blade servers.

<input type="checkbox"/>	Bay	Name	SOL	SOL Session	BSMP IP Address
	1	No blade present			
	2	Blade does not support SOL	n/a	n/a	n/a
	3				
	4	No blade present			
<input type="checkbox"/>	5	SN#J1RNE34911N	Disabled	Not ready	10.10.10.84
	6	No blade present			
	7	No blade present			
	8	No blade present			
	9	No blade present			
	10	No blade present			
	11	No blade present			
	12	No blade present			
	13	No blade present			
	14	No blade present			

[Disable Serial Over LAN](#)
[Enable Serial Over LAN](#)

For management modules other than the advanced management module, the SOL Session status for each blade server has three possible states:

Not Ready

This status indicates that no SOL session is available between the management module and the blade server. It might indicate that there was an SOL session setup failure that must be investigated.

Ready This status indicates that an SOL session is established between the management module and the blade server. This SOL session is available to connect to a Telnet session, if one is requested by the user.

Active This status indicates that there is an SOL session between the management module and the blade server and that this session is currently connected to a Telnet session.

The following illustration shows the SOL status page for an advanced management module.

Serial Over LAN Status 

Click the checkboxes in the first column to select one or more blades; then, click one of the links below the table to enable or disable SOL on the selected blades.

Note: You have to enable the global "Serial over LAN" flag below in the Configuration section before enabling SOL on individual blades.

<input type="checkbox"/>	Bay	Name	SOL Status
<input type="checkbox"/>	1	JS21-Mau(SIT)	
	2	No blade present	
<input type="checkbox"/>	3	Vista32 3D	
	4	No blade present	
	5	No blade present	
	6	No blade present	
	7	No blade present	
	8	No blade present	
	9	No blade present	
	10	No blade present	
	11	No blade present	
	12	No blade present	
	13	No blade present	
	14	No blade present	

Available actions

For advanced management modules, the SOL Session status for each blade server has five possible states:

Unknown 

This status indicates that the status of the SOL session is not known. It might indicate that the blade server is still being discovered.

Disabled 

This status indicates that SOL is disabled for the blade server.

No session 

This status indicates that no SOL session is available between the management module and the blade server. It might indicate that there was an SOL session setup failure that must be investigated.

Ready 

This status indicates that an SOL session is established between the management module and the blade server. This SOL session is available to connect to a Telnet session, if one is requested by the user.

Active 

This status indicates that there is an SOL session between the management module and the blade server and that this session is currently connected to a Telnet session.

For advanced management modules, click the **SOL Status** icon for a blade server to see a detailed summary of the condition for that blade server and recommended actions. You can also click the **SOL Status Summary** link to see the status summary information for all the blader servers managed by the advanced management module.

SOL Status Summary

Blade 8 - SN#YL11W8045045

Property	Value
SOL Enabled	Yes
Retry Interval (mSec)	250
Retry Count	7
Bytes Received	0
Bytes Sent	0
Destination IP Address	10.10.10.87
Destination MAC Address	00:1A:64:84:2F:1C
IOM Slot Number	1
Session Status	Not Ready
SOL Console User ID	
SOL Console log in from	
SOL Console log in start	
SOL Console log in stop	
Blade Power State	On
Recommended Action	Cannot connect to the baseboard management controller (BMC) on this blade server. Please refer to BMC user guide for troubleshooting information.

If an SOL session closes itself, or if the session indicates that it is active and is not responding, complete the following steps:

1. Disable SOL for the affected blade server (see “Enabling SOL for blade servers” on page 12).
2. Wait 60 seconds.
3. Re-enable SOL for the blade server (see “Enabling SOL for blade servers” on page 12).

Problems with SOL sessions can also be due to incorrect BladeCenter configuration, or installation of components or firmware that are not SOL compatible.

Restarting a blade server through SOL

About this task

You can restart a blade server during an SOL session by typing a specific key sequence. This makes it possible to restart the blade server without ending the SOL session so that you can use the restart command in the management-module command-line interface.

Type the following key sequence (Esc R Esc r Esc R) to restart a blade server during an SOL session:

1. Press Esc.
2. Type a capital R by pressing Shift and r at the same time.
3. Press Esc.
4. Press r.
5. Press Esc.
6. Type a capital R by pressing Shift and r at the same time.

Results

The blade server that is hosting this SOL session restarts, returning to the SOL session that is already in progress.

Note: The keys pressed to restart a blade server can be set to another user-defined keystroke sequence. See the *BladeCenter Management Module User's Guide* for information.

Mounting and unmounting media for Linux operating systems

About this task

The following sections describe how to mount and unmount media using the Linux operating system for each blade server type.

For BladeCenter units that do not have a diskette drive, you can mount only optical drive media.

Mounting and unmounting media using Linux

About this task

The following section describes how to mount and unmount media using a Linux operating system.

Note: These procedures are based on a default installation of Red Hat Enterprise Linux ES 2.1. The file names, structures, and commands might be different for other versions of Red Hat Linux or other types of Linux operating systems.

Complete the following steps if the medium to be mounted is a CD:

1. Make sure that the `/mnt/cdrom` directory exists on your server. If this directory does not exist, type `mkdir /mnt/cdrom` and then press Enter.
2. To mount the CD, type `mount /dev/scd0 -t iso9660 -o ro /mnt/cdrom` and then press Enter.

Results

Complete the following steps if the medium to be mounted is a diskette:

1. Make sure that the `/mnt/floppy` directory exists on your server. If this directory does not exist, type
`mkdir /mnt/floppy`

and then press Enter.

2. To mount the diskette, type
`mount /dev/sda -o auto /mnt/floppy`

and then press Enter.

Complete the following steps to unmount media:

1. Type `cd` and then press Enter.
2. Type one of the following commands:
 - If the medium to be unmounted is a CD, type
`umount /mnt/cdrom`

and then press Enter.
 - If the medium to be unmounted is a diskette, type
`umount /mnt/floppy`

and then press Enter.

Chapter 6. Troubleshooting SOL

This section contains some troubleshooting hints and tips to assist you in solving problems that you might be experiencing with Serial over LAN operation. Go to <http://www.ibm.com/systems/support/> for the latest information about solving problems with SOL. Information in this section relates to the following topics:

Note: If you are using management channel auto discovery (MCAD), replace references to I/O-module bay 1 in the following procedures with the I/O module bay number that is actually being used (see the *BladeCenter Advanced Management Module User's Guide* for additional information about MCAD).

- "Management module indicates that blade server does not support SOL"
- "Blade server shows SOL status of Not Ready" on page 46
- "SOL session opens and drops" on page 47
- "Trouble entering SOL commands or receiving double prompts" on page 48
- "Garbage characters in an SOL session" on page 48

Management module indicates that blade server does not support SOL

About this task

If the management module SOL configuration page indicates that a blade server does not support SOL, check the following items:

- Make sure that blade server type that you are using supports SOL. For example, the Type 8678 blade server does not support SOL and this is a normal message for this blade server type.
- The management module has not completed its communication sequence with each of the blade servers in the BladeCenter unit. This condition commonly occurs immediately after power has been applied to the BladeCenter unit or after an management module reset. Allow 5 minutes after power application or a management module reset to make sure that all blade servers have been scanned.
- Turn off the blade server, remove it from the BladeCenter unit, reinstall it, and turn it back on.
- Move the blade server to a different blade bay.
- Update the blade server service processor firmware (BMC or ISMP firmware). Latest firmware is available from <http://www.ibm.com/systems/support/>. Install the update by following the instructions that come with the update. See the *Management Module User's Guide* for additional information.
- Try a different management module. If the BladeCenter unit contains a standby management module, switch control to it and wait 5 minutes for the management module to fully establish communications with all blade servers.
- Update the management module firmware. Latest firmware is available from <http://www.ibm.com/systems/support/>. Install the update by following the instructions that come with the update. See the *Management Module User's Guide* for additional information.
- There might be a problem with the blade server system board.

Blade server shows SOL status of Not Ready

About this task

If a blade server with SOL enabled in the management module indicates an SOL status of Not Ready, check the following items:

- Make sure that an Ethernet switch module is installed in I/O-module bay 1. An Ethernet switch module needs to be installed in I/O module bay 1; pass-thru modules do not support SOL.
- Make sure that the SOL port assignment is set to blade server NIC 1, the default SOL port assignment that connects to the switch module in bay 1. The Type 8832 blade server provides a jumper to change the SOL port assignment. All blade servers except the HS40 and JS2x blade servers provide a setting in the network controller firmware to change the SOL port assignment. This setting can be changed only when flashing the NIC firmware on the blade server. If SOL traffic has been assigned to NIC 2, then the switch module in I/O-module bay 2 needs to be an Ethernet switch module and additional configuration of this switch module might be required. See Chapter 2, “General configuration,” on page 7, Chapter 3, “Operating system configuration,” on page 15, and Chapter 4, “Special component requirements,” on page 25 for more information.
- Make sure that SOL is properly set up in the blade server system firmware (BIOS). Only the JS2x family of blade servers do not require system firmware configuration to enable SOL. See “Updating and configuring the blade server BIOS” on page 13 and Chapter 4, “Special component requirements,” on page 25, for information about setting up blade server BIOS for SOL operation.

Note: A blade server might start slowly or become unresponsive if COM 1 is configured for SOL instead of COM 2.

- Make sure that the SOL IP address range (for the BSMP) is not already in use on the external network. The default SOL BSMP address range starts at 10.1.1.80 and ends at 10.1.1.93 for all 14 blades in the BladeCenter unit. If any blade servers or other external devices use this range of IP addresses for production traffic, an IP address conflict will occur and SOL traffic might be blocked. The SOL BSMP starting address can be changed using the management module Web interface and any IP address range can be used that is not being used for production traffic.
- If the blade server has an operating system loaded, verify that the Broadcom NIC drivers are loaded and up to date. A downlevel NIC driver loaded in Linux can cause SOL to go into the Not Ready state.
- Make sure that the blade server is powered up. Some blade servers need to be powered up for SOL to indicate a status of Ready. It can take up to 60 seconds after some blade servers are powered up for SOL to indicate that they are Ready.
- Make sure that the management module can communicate with the switch module in I/O-module bay 1. Verify communications by pinging the I/O module from the management module. See the *Management Module User's Guide* for additional information.
- Make sure that the Ethernet switch module in I/O-module bay 1 is configured for SOL operation. For most switch modules, the default configuration settings for the management module and the switch module are fine; however, if the switch module in I/O-module bay 1 is a Cisco Systems Intelligent Gigabit Ethernet Switch Module for the IBM BladeCenter, make sure that it has a firmware level of 12.1(22)EA6a or later. (This is the minimum firmware level that the switch module requires to support a management module default SOL VLAN of 4095.) If the Cisco Gigabit Ethernet Switch Module has a firmware

level older than 12.1(22)EA6a, then the SOL VLAN must be set to a value between 1 and 1001 and the Cisco switch needs to be configured for these setting (see “Configuring the Cisco Systems Intelligent Gigabit Ethernet Switch Module for the IBM BladeCenter” on page 34). If the BladeCenter I/O module internal ports are VLAN enabled (‘trunked’ in Cisco terms), then these ports must be configured to pass traffic from the SOL VLAN ID.

- Restart the blade server system management processor (see the *Management Module User’s Guide* or the *Management Module Command-line Interface Reference Guide* for instructions). Make sure that the blade server is turned on when restarting the management processor. After the restart is complete, check the blade server SOL status; if the status indicates Ready, then try to start an SOL session.
- Disable SOL for the blade server; then, re-enable it (see the *Management Module User’s Guide* or the *Management Module Command-line Interface Reference Guide* for instructions). Make sure that the blade server is turned on when disabling and re-enabling SOL. After the disable and re-enable is complete, check the blade server SOL status; if the status indicates Ready, then try to start an SOL session.
- Restart the management module (see the *Management Module User’s Guide* or the *Management Module Command-line Interface Reference Guide* for instructions). After the restart is complete, check the blade server SOL status; if the status indicates Ready, then try to start an SOL session.
- Restart the switch module in I/O-module bay 1 (see the *Management Module User’s Guide* or the *Management Module Command-line Interface Reference Guide* for instructions). After the restart is complete, check the blade server SOL status; if the status indicates Ready, then try to start an SOL session.
- Turn off the blade server, remove it from the BladeCenter unit, reinstall it, and turn it back on. After doing this, check the blade server SOL status; if the status indicates Ready, then try to start an SOL session.

SOL session opens and drops

About this task

If you can open an SOL session with a blade server but it will not remain open, check the following items:

- Make sure that the session timeout has not expired. The management module has a default timeout value of 120 seconds for command-line interface sessions. This value can be changed to never timeout using the command: `telnetcfg -T system:mm[x] -t 0` (where *x* is the primary management-module bay number). See the *Management Module Command-line Interface Reference Guide* for instructions.
- (For HS20 Type 8832, JS20 Type 8842, HS20 Type 8843, and LS20 Type 8850 blade servers only) SOL traffic shares blade server NIC port 1 with regular Ethernet traffic. Do not try to use SOL on a blade server while attempting to PXE boot it through NIC port 1. Traffic from a network install server running through blade server port 1 can block SOL traffic, which will cause the SOL session to hang.
- Make sure that the latest Broadcom Ethernet driver is installed on the blade server, especially for blade servers running a Linux operating system.
- Do not type on the keyboard while the blade server is rebooting or the operating system network drivers are loading; this action has been known to cause an SOL session to drop.

Trouble entering SOL commands or receiving double prompts

About this task

If you are having trouble entering commands in an SOL session or are receiving double prompts, check the following items:

- Check the keyboard Return key settings for your terminal emulation program. Make sure that only a line-feed character is sent whenever the Return key is pressed (Telnet works this way by default). The Putty terminal application has a configuration setting for the Return key under **Configuration → Connection → Telnet**.
- The service processor on older blade servers, including the Type 8832 and Type 8842 blade servers, might block SOL output to a blade server that is running Linux. If this happens, enter Ctrl+q in the SOL session to clear the keystroke buffer.
- Make sure that the operating system that is running on the blade server supports SOL. See Chapter 3, “Operating system configuration,” on page 15 for instructions.
- Make sure that the operating system that is running on the blade server is set up correctly for SOL console access (see Chapter 3, “Operating system configuration,” on page 15 for instructions). For example, you must enable the Windows Emergency Management System (EMS) for Windows Server 2003 and redirect it to the COM2 serial port.

Garbage characters in an SOL session

About this task

The default character encoding in Linux does not translate many of the characters sent over an SOL session, which might corrupt the BIOS screens display. If you are getting garbage characters while viewing or typing in an SOL session, check the following items:

- Make sure the serial port settings in your terminal emulation program match the settings specified in the blade server BIOS configuration. Also, make sure that Hardware Flow Control is enabled.
- Try setting the remote console text and keyboard emulation to VT100/220, instead of ANSI, in blade server BIOS. This might improve character display in SOL sessions. These settings are found in the blade server BIOS, under **Devices and I/O Ports → Remote Console Redirection**.
- To correct garbage or missing characters when using Gnome Terminal on a remote computer, complete the following steps:
 1. From the Gnome Terminal menu, select **Terminal → Set Character Encoding → Add or Remove**.
 2. From the list of available encodings that displays, select **Western IBM850**; then, click on the right-arrow button to add this encoding to the list of encodings shown in the menu and click **OK**.
 3. From the Gnome Terminal menu, select **Terminal → Set Character Encoding → Western (IBM850)**.

Using these settings for the Gnome Terminal should greatly reduce the amount of garbage or missing characters.

- Try a different terminal emulation program. Several programs are available, such as Telnet, Putty, or Hyperterm.

- Update the blade server service processor firmware (BMC or ISMP firmware). Latest firmware is available from <http://www.ibm.com/systems/support/>. Install the update by following the instructions that come with the update. See the *Management Module User's Guide* for additional information.
- Restart blade server system management processor (see the *Management Module User's Guide* or the *Management Module Command-line Interface Reference Guide* for instructions).
- Check the external link statistics for the switch module in I/O-module bay 1. Look for high packet loss or high packet error rates. See the *Management Module User's Guide* for additional information.
- Try to start an SOL session with another blade server in the BladeCenter unit. If you see garbage or missing characters with all blade server sessions, then suspect the management module.
- If the blade server supports local KVM, then switch the local command console to the blade server and type some characters. If you see the same garbage or missing character problem, then the problem is most likely with the management module.

Appendix A. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about IBM products, you will find a wide variety of sources available from IBM to assist you. This section contains information about where to go for additional information about IBM and IBM products, what to do if you experience a problem with your system, and whom to call for service, if it is necessary.

Before you call

Before you call, make sure that you have taken these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Use the troubleshooting information in your system documentation, and use the diagnostic tools that come with your system. Information about diagnostic tools is in the *Problem Determination and Service Guide* on the *IBM Documentation CD* that comes with your system.
- Go to the IBM support Web site at <http://www.ibm.com/systems/support/> to check for technical information, hints, tips, and new device drivers or to submit a request for information.

You can solve many problems without outside assistance by following the troubleshooting procedures that IBM provides in the online help or in the documentation that is provided with your IBM product. The documentation that comes with IBM systems also describes the diagnostic tests that you can perform. Most systems, operating systems, and programs come with documentation that contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

Using the documentation

Information about your IBM system and preinstalled software, if any, or optional device is available in the documentation that comes with the product. That documentation can include printed documents, online documents, readme files, and help files. See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates. To access these pages, go to <http://www.ibm.com/systems/support/> and follow the instructions. Also, some documents are available through the IBM Publications Center at <http://www.ibm.com/shop/publications/order/>.

Getting help and information from the World Wide Web

On the World Wide Web, the IBM Web site has up-to-date information about IBM systems, optional devices, services, and support. The address for IBM System x[®] and xSeries[®] information is <http://www.ibm.com/systems/x/>. The address for IBM BladeCenter information is <http://www.ibm.com/systems/bladecenter/>. The address for IBM IntelliStation[®] information is <http://www.ibm.com/intellistation/>.

You can find service information for IBM systems and optional devices at <http://www.ibm.com/systems/support/>.

Software service and support

Through IBM Support Line, you can get telephone assistance, for a fee, with usage, configuration, and software problems with System x and xSeries servers, BladeCenter products, IntelliStation workstations, and appliances. For information about which products are supported by Support Line in your country or region, see <http://www.ibm.com/services/sl/products/>.

For more information about Support Line and other IBM services, see <http://www.ibm.com/services/>, or see <http://www.ibm.com/planetwide/> for support telephone numbers. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

Hardware service and support

You can receive hardware service through your IBM reseller or IBM Services. To locate a reseller authorized by IBM to provide warranty service, go to <http://www.ibm.com/partnerworld/> and click **Find a Business Partner** on the right side of the page. For IBM support telephone numbers, see <http://www.ibm.com/planetwide/>. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

In the U.S. and Canada, hardware service and support is available 24 hours a day, 7 days a week. In the U.K., these services are available Monday through Friday, from 9 a.m. to 6 p.m.

IBM Taiwan product service

台灣 IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路 7 號 3 樓
電話：0800-016-888

IBM Taiwan product service contact information:

IBM Taiwan Corporation
3F, No 7, Song Ren Rd.
Taipei, Taiwan
Telephone: 0800-016-888

Appendix B. Notices

Trademarks

IBM, the IBM logo, and [ibm.com](http://www.ibm.com)[®] are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. If these and other IBM trademarked terms are marked on their first occurrence in this information with a trademark symbol ([®] or [™]), these symbols indicate U.S. registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common law trademarks in other countries. A current list of IBM trademarks is available on the Web at “Copyright and trademark information” at <http://www.ibm.com/legal/copytrade.shtml>.

Adobe[®] and PostScript[®] are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Cell Broadband Engine[™] is a trademark of Sony Computer Entertainment, Inc., in the United States, other countries, or both and is used under license therefrom.

Intel[®], Intel Xeon[®], Itanium[®], and Pentium[®] are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Java[™] and all Java-based trademarks are trademarks of Sun Microsystems, Inc., in the United States, other countries, or both.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, and Windows NT[®] are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX[®] is a registered trademark of The Open Group in the United States and other countries.

Other company, product, or service names may be trademarks or service marks of others.

Important notes

Processor speeds indicate the internal clock speed of the microprocessor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1024 bytes, MB stands for 1 048 576 bytes, and GB stands for 1 073 741 824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1 000 000 bytes, and GB stands for 1 000 000 000 bytes. Total user-accessible capacity can vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard disk drive bays with the largest currently supported drives available from IBM.

Maximum memory might require replacement of the standard memory with an optional memory module.

IBM makes no representation or warranties regarding non-IBM products and services that are ServerProven[®], including but not limited to the implied warranties of merchantability and fitness for a particular purpose. These products are offered and warranted solely by third parties.

IBM makes no representations or warranties with respect to non-IBM products. Support (if any) for the non-IBM products is provided by the third party, not IBM.

Some software might differ from its retail version (if available), and might not include user manuals or all program functionality.

Index

A

assistance, getting 51

B

blade server
 enable SOL 12
 Linux Ethernet driver 21
 remote console redirection settings 13
 restart through SOL 43
 SOL status 13
 update firmware (BIOS) 13
blade server HS20 Type 8832
 configure 27
 firmware update (Ethernet controller) 29
 firmware update (ISMP) 28
 jumper position 28
 Linux configuration 15
blade server HS20 Type 8843
 configure 27
 firmware update (Ethernet controller) 29
 firmware update (ISMP) 28
 Linux configuration 15
blade server HS22 Type 7870
 configure 25
blade server HS40 Type 8839
 configure 29
 firmware update (BMC) 29
 Linux configuration 15
 remote console redirection settings 30
 update firmware (BIOS) 30
blade server JS20 Type 8842
 configure 31
 firmware update (Ethernet controller) 32
 firmware update (ISMP) 31
 update firmware (BIOS) 31

C

checking firmware 4
Cisco Systems Intelligent Gigabit Ethernet Switch Module configuration 34
command-line interface starting 37
configuration
 special requirements 25
configure
 blade server HS20 Type 8832 27
 blade server HS20 Type 8843 27
 blade server HS22 Type 7870 25
 blade server HS40 Type 8839 29
 blade server JS20 Type 8842 31
 Cisco Systems Intelligent Gigabit Ethernet Switch Module 34
 global SOL settings 7, 41

configure (*continued*)
 GRUB 17
 IBM 4-port Gb Ethernet I/O 32
 LILO 16
 Linux (HS20 Type 8832 blade server) 15
 Linux (HS20 Type 8843 blade server) 15
 Linux (HS40 Type 8839 blade server) 15
 management module 9
 Microsoft Windows 2003 22
 Nortel Layer 2-7 GbE I/O 33
 Red Hat Enterprise Linux 15
 SSH 11
 SUSE Linux 19
connect
 ICPM 36
 Intelligent Copper Pass-thru Module 36

D

device driver
 blade server (Linux for Ethernet controller) 21
documentation, latest version 2

E

Emergency Management System (EMS)
 Microsoft Windows 2003 22
enable SOL for blade server 12
ending an SOL session 40

F

firmware
 checking version 4
firmware requirements 3
firmware update
 blade server (BIOS) 13
 blade server HS20 Type 8832 (Ethernet controller) 29
 blade server HS20 Type 8832 (ISMP) 28
 blade server HS20 Type 8843 (Ethernet controller) 29
 blade server HS20 Type 8843 (ISMP) 28
 blade server HS40 Type 8839 (BIOS) 30
 blade server HS40 Type 8839 (BMC) 29
 blade server JS20 Type 8842 (BIOS) 31
 blade server JS20 Type 8842 (Ethernet controller) 32
 blade server JS20 Type 8842 (ISMP) 31

firmware update (*continued*)
 management module 10
firmware versions 3

G

getting help 51
global SOL settings, configure 7, 41
GRUB configuration 17

H

hardware flow control 15, 19
hardware requirements 2
hardware service and support
 IBM reseller 52
 IBM Services 52
 telephone numbers 52
help, getting 51

I

IBM 4-port Gb Ethernet I/O configuration 32
IBM Support Line 52
ICPM connection 36
install, SSH 11
Intelligent Copper Pass-thru Module connection 36

J

jumper position
 blade server HS20 Type 8832 28

L

LILO configuration 16
Linux
 mounting media 44
 unmounting media 44
Linux configuration
 HS20 Type 8832 blade server 15
 HS20 Type 8843 blade server 15
 HS40 Type 8839 blade server 15
Linux driver
 blade server Ethernet controller 21

M

management module
 configuration 9
 configure SOL 10
 enable SOL 11
 firmware update 10
management-module firmware 3
management-module Web interface starting 5

- maximum number
 - SOL sessions 1, 2, 37
 - Telnet sessions 1, 37
- media
 - mount (Linux) 44
 - unmount (Linux) 44
- Microsoft Windows 2003
 - configuration 22
 - Emergency Management System (EMS) 22
- mount media, Linux 44

N

- Nortel Layer 2-7 GbE I/O
 - configuration 33
- notes, important 53

O

- online documentation 2

R

- Red Hat Enterprise Linux
 - configuration 15
- remote console redirection
 - blade server 13
 - blade server HS40 Type 8839 30
- required
 - firmware 3
 - hardware 2

S

- serial
 - connection 38
- Serial over LAN 1, 40
- software service and support 52
- SOL 1, 40
 - blade server restart 43
 - configure management module 10
 - enable blade server 12
 - enable for management module 11
 - starting
 - from command line 39
 - status of blade server 13
 - troubleshooting 45
 - using 37
- SOL session
 - ending 40
 - maximum allowed 1, 2, 37
 - starting 37, 40
- SOL settings, configure global 7, 41
- SSH
 - connection 39
 - install and configure 11
- starting
 - command-line interface 37
 - management-module Web interface 5
 - session using serial 38
 - session using SSH 39
 - session using Telnet 38
 - SOL from command line 39
 - SOL session 37, 40

- status, SOL for blade server 13
- support, web site 51
- SUSE Linux configuration 19

T

- telephone numbers
 - hardware service and support 52
- Telnet connection 38
- Telnet sessions, maximum allowed 1, 37
- trademarks 53
- troubleshooting
 - double prompts in SOL session 48
 - garbage characters in SOL session 48
 - missing characters in SOL session 48
 - no SOL support 45
 - SOL not ready 46
 - SOL sessions drop 47
 - trouble entering SOL commands 48
- troubleshooting SOL 45

U

- unmount media, Linux 44
- using SOL 37

W

- web site
 - publication ordering 51
 - support 51
 - support line, telephone numbers 52



Part Number: 44R5390

Printed in USA

(1P) P/N: 44R5390

