

IBM Spectrum Protect
Version 8.1.10

Single-Site Disk Solution Guide



Note:

Before you use this information and the product it supports, read the information in [“Notices” on page 111](#).

Edition notice

This edition applies to version 8, release 1, modification 10 of IBM Spectrum® Protect (product numbers 5725-W98, 5725-W99, 5725-X15), and to all subsequent releases and modifications until otherwise indicated in new editions.

© **Copyright International Business Machines Corporation 1993, 2020.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

About this publication.....	vii
Who should read this guide.....	vii
Publications	vii
What's new.....	ix
Part 1. Planning.....	1
Selecting a system size.....	2
System requirements for a single-site disk solution.....	2
Hardware requirements.....	2
Software requirements.....	4
Planning worksheets.....	5
Planning for storage.....	16
Planning the storage arrays.....	16
Planning for security.....	18
Planning for administrator roles.....	18
Planning for secure communications.....	18
Planning for storage of encrypted data.....	19
Planning firewall access.....	19
Part 2. Implementation.....	21
Setting up the system.....	21
Configuring the storage hardware.....	21
Installing the server operating system.....	22
Installing on AIX systems.....	22
Installing on Linux systems.....	24
Installing on Windows systems.....	28
Configuring multipath I/O.....	28
AIX systems.....	29
Linux systems.....	30
Windows systems.....	31
Creating the user ID for the server.....	31
Preparing file systems for the server.....	32
AIX systems.....	32
Linux systems.....	34
Windows systems.....	34
Installing the server and Operations Center.....	35
Installing on AIX and Linux systems.....	35
Installing prerequisite RPM files for the graphical wizard.....	36
Installing on Windows systems.....	37
Configuring the server and the Operations Center.....	37
Configuring the server instance.....	37
Installing the backup-archive client.....	39
Setting options for the server.....	39
Configuring secure communications with Transport Layer Security.....	40
Configuring the Operations Center.....	40
Securing communications between the Operations Center and the hub server.....	41
Registering the product license.....	43
Configuring data deduplication.....	44
Defining data retention rules for your business.....	44

Defining schedules for server maintenance activities.....	44
Defining client schedules.....	47
Installing and configuring backup-archive clients.....	47
Registering and assigning clients to schedules.....	47
Installing the client management service.....	48
Verifying that the client management service is installed correctly.....	48
Configuring the Operations Center to use the client management service.....	49
Completing the implementation.....	50
Part 3. Monitoring.....	51
Daily checklist.....	51
Periodic checklist.....	60
Verifying license compliance.....	66
Tracking system status by using email reports.....	68
Part 4. Managing.....	69
Managing the Operations Center.....	69
Adding and removing spoke servers.....	69
Adding a spoke server.....	69
Removing a spoke server.....	70
Starting and stopping the web server.....	70
Restarting the initial configuration wizard.....	71
Changing the hub server.....	72
Restoring the configuration to the preconfiguration state.....	72
Protecting applications, virtual machines, and systems.....	74
Adding clients.....	74
Selecting the client software and planning the installation.....	75
Specifying rules for backing up and archiving client data.....	76
Scheduling backup and archive operations.....	79
Registering clients.....	80
Installing and configuring clients.....	81
Managing client operations.....	85
Evaluating errors in client error logs.....	85
Stopping and restarting the client acceptor.....	86
Resetting passwords.....	87
Modifying the scope of a client backup.....	88
Managing client upgrades.....	88
Decommissioning a client node.....	89
Deactivating data to free storage space.....	92
Managing data storage.....	92
Auditing a storage pool container.....	92
Managing inventory capacity.....	93
Managing memory and processor usage.....	95
Tuning scheduled activities.....	95
Securing the server.....	96
Security concepts.....	96
Managing administrators.....	98
Changing password requirements.....	99
Securing the server on the system.....	101
Restricting user access to the server.....	101
Limiting access through port restrictions.....	101
Stopping and starting the server.....	102
Stopping the server.....	102
Starting the server for maintenance or reconfiguration tasks.....	103
Planning to upgrade the server.....	104
Preparing for an outage.....	105
Implementing a disaster recovery plan.....	106

Recovery drills.....	106
Recovering from system outages.....	106
Restoring the database.....	107
Appendix A. Accessibility.....	109
Notices.....	111
Glossary.....	115
Index.....	117

About this publication

This publication provides information about planning for, implementing, monitoring, and operating a data protection solution that uses IBM Spectrum Protect best practices.

Who should read this guide

This guide is intended for anyone who is registered as an administrator for IBM Spectrum Protect. A single administrator can manage IBM Spectrum Protect, or several people can share administrative responsibilities.

You should be familiar with the operating system on which the server resides and the communication protocols required for the client or server environment. You also need to understand the storage management practices of your organization, such as how you are currently backing up workstation files and how you are using storage devices.

Publications

The IBM Spectrum Protect product family includes IBM Spectrum Protect Plus, IBM Spectrum Protect for Virtual Environments, IBM Spectrum Protect for Databases, and several other storage management products from IBM®.

To view IBM product documentation, see [IBM Knowledge Center](#).

What's new in this release

This release of IBM Spectrum Protect introduces new features and updates.

For a list of new features and updates in this release, see the following topics:

- [What's new for Server components](#)
- [What's new for Client components](#)

New and changed information in this product documentation is indicated by a vertical bar (|) to the left of the change.

Part 1. Planning for a single-site disk data protection solution

Plan for a data protection implementation that includes a server at a single site that uses data deduplication.

Implementation options

You can configure the server for a single-site disk solution in the following ways:

Configure the server by using the Operations Center and administrative commands

This documentation provides steps to configure a range of storage systems and the server software for your solution. Configuration tasks are completed by using wizards and options in the Operations Center and IBM Spectrum Protect commands. For information about getting started, see the “Planning roadmap” on page 1.


Configure the server by using automated scripts

For detailed guidance on implementing a single-site disk solution with specific IBM Storwize® storage systems, and by using automated scripts to configure the server, see [IBM Spectrum Protect Blueprints](#).

The blueprint documentation does not include steps for installing and configuring the Operations Center, or setting up secure communications by using Transport Security Layer (TLS). An option for using Elastic Storage Server, based on IBM Spectrum Scale technology, is included.

Planning roadmap

Plan for the single-site disk solution by reviewing the architecture layout in the following figure and then completing the roadmap tasks that follow the diagram.



The following steps are required to plan for a single-site disk environment.

1. [Select your system size.](#)
2. [Meet system requirements for hardware and software.](#)

3. Record values for your system configuration in the [planning worksheets](#).
4. Plan for storage.
5. Plan for security.
 - a. Plan for administrator roles.
 - b. Plan for secure communications.
 - c. Plan for storage of encrypted data.
 - d. Plan for firewall access.

Selecting a system size

Select the size of the IBM Spectrum Protect server based on the amount of data that you manage and the systems to be protected.

About this task

You can use the information in the table to determine the size of the server that is required, based on the amount of data that you manage.

The following table describes the volume of data that a server manages. This amount includes all versions. The daily amount of data is how much new data you back up each day. Both the total managed data and daily amount of new data are measured as the size before any data reduction.

<i>Table 1. Determining the size of the server</i>		
Total managed data	Daily amount of new data to back up	Required server size
60 TB - 240 TB	Up to 10 TB per day	Small
360 TB - 1440 TB	10 - 30 TB per day	Medium
1000 TB - 4000 TB	30 - 100 TB per day	Large

The daily backup values in the table are based on test results with 128 MB sized objects, which are used by IBM Spectrum Protect for Virtual Environments. Workloads that consist of objects that are smaller than 128 KB might not be able to achieve these daily limits.

System requirements for a single-site disk solution

After you select the IBM Spectrum Protect solution that best fits your data protection requirements, review the system requirements to plan for implementation of the data protection solution.

Ensure that your system meets the hardware and software prerequisites for the size of server that you plan to use.

Related information

[IBM Spectrum Protect Supported Operating Systems](#)

Hardware requirements

Hardware requirements for your IBM Spectrum Protect solution are based on system size. Choose equivalent or better components than those items that are listed to ensure optimum performance for your environment.

For a definition of system sizes, see [“Selecting a system size” on page 2](#).

The following table includes minimum hardware requirements for the server and storage, based on the size of the server that you plan to build. If you are using local partitions (LPARs) or work partitions (WPARs), adjust the network requirements to take account of the partition sizes.

Use the information in the following table as a starting point. For the most up-to-date information about hardware requirements and specifications for the server and storage, see [IBM Spectrum Protect Blueprints](#).

Hardware component	Small system	Medium system	Large system
Server processor	<p>AIX 6 processor cores, 3.42 GHz or faster</p> <p>Linux Windows 16 processor cores, 1.7 GHz or faster</p>	<p>AIX 10 processor cores, 3.42 GHz or faster</p> <p>Linux Windows 20 processor cores, 2.2 GHz or faster</p>	<p>AIX 20 processor cores, 3.42 GHz</p> <p>Linux Windows 44 processor cores, 2.2 GHz or faster</p>
Server memory	64 GB RAM	128 GB RAM	256 GB RAM
Network	<ul style="list-style-type: none"> • 10 GB Ethernet (1 port) • 8 GB Fibre Channel adapter (2 ports) 	<ul style="list-style-type: none"> • 10 GB Ethernet (2 ports) • 8 GB Fibre Channel adapter (2 ports) 	<ul style="list-style-type: none"> • 10 GB Ethernet (4 ports) • 8 GB Fibre Channel adapter (4 ports)
Storage	<ul style="list-style-type: none"> • 1.45 TB SSD disks for the database, plus space for Operations Center records • 67 TB deduplicated directory-container storage pool 	<ul style="list-style-type: none"> • 2.53 TB SSD disks for the database, plus space for Operations Center records • 207.9 TB deduplicated directory-container storage pool 	<ul style="list-style-type: none"> • 6.54 TB SSD disks for the database, plus space for Operations Center records • 1049.67 TB deduplicated directory-container storage pool

Estimating database space requirements for the Operations Center

Hardware requirements for the Operations Center are included in the preceding table, except for the database and archive log space (inventory) that the Operations Center uses to hold records for managed clients.

If you do not plan to install the Operations Center on the same system as the server, you can estimate system requirements separately. To calculate system requirements for the Operations Center, see the system requirements calculator in [technote 1641684](#).

Managing the Operations Center on the server is a workload that requires extra space for database operations. The amount of space depends on the number of clients that are monitored on a server. Review the following guidelines to estimate how much space your server requires.

Database space

The Operations Center uses approximately 1.2 GB of database space for every 1000 clients that are monitored on a server. For example, consider a hub server with 2000 clients that also manages three spoke servers, each with 1500 clients. This configuration has a total of 6500 clients across the four servers and requires approximately 8.4 GB of database space. This value is calculated by rounding the 6500 clients up to the next closest 1000, which is 7000:

$$7 \times 1.2 \text{ GB} = 8.4 \text{ GB}$$

Archive log space

The Operations Center uses approximately 8 GB of archive log space every 24 hours, for every 1000 clients. In the example of 6500 clients across the hub server and the spoke servers, 56 GB of archive log space is used over a 24-hour period for the hub server.

For each spoke server in the example, the archive log space that is used over 24 hours is approximately 16 GB. These estimates are based on the default status collection interval of 5 minutes. If you reduce the collection interval from once every 5 minutes to once every 3 minutes, the space requirements increase. The following examples show the approximate increase in the log space requirement with a collection interval of once every 3 minutes:

- Hub server: 56 GB to approximately 94 GB
- Each spoke server: 16 GB to approximately 28 GB

Increase the archive log space so that you have sufficient space available to support the Operations Center, without affecting the existing server operations.

Software requirements

Documentation for the single-site disk IBM Spectrum Protect solution includes installation and configuration tasks for the following operating systems. You must meet the minimum software requirements that are listed.

For information about software requirements for IBM in tape device drivers, refer to the [IBM Tape Device Drivers Installation and User's Guide](#).

AIX systems

Type of software	Minimum software requirements
Operating system	IBM AIX® 7.1 For more information about operating system requirements, see AIX: Minimum system requirements for AIX systems .
Gunzip utility	The gunzip utility must be available on your system before you install or upgrade the IBM Spectrum Protect server. Ensure that the gunzip utility is installed and the path to it is set in the PATH environment variable.
File system type	JFS2 file systems AIX systems can cache a large amount of file system data, which can reduce memory that is required for server and IBM Db2® processes. To avoid paging with the AIX server, use the <code>ib1w</code> mount option for the JFS2 file system. Less memory is used for the file system cache and more is available for IBM Spectrum Protect. Do not use the file system mount options, Concurrent I/O (CIO), and Direct I/O (DIO), for file systems that contain the IBM Spectrum Protect database, logs, or storage pool volumes. These options can cause performance degradation of many server operations. IBM Spectrum Protect and Db2 can still use DIO where it is beneficial to do so, but IBM Spectrum Protect does not require the mount options to selectively take advantage of these techniques.
Other software	Korn Shell (ksh)

Linux systems

Type of software	Minimum software requirements
Operating system	Red Hat Enterprise Linux® 7 (x86_64)

Type of software	Minimum software requirements
Libraries	GNU C libraries, Version 2.3.3-98.38 or later that is installed on the IBM Spectrum Protect system. Red Hat Enterprise Linux Servers: <ul style="list-style-type: none"> • libaio • libstdc++.so.6 (32-bit and 64-bit packages are required) • numactl.x86_64
File system type	Format database-related file systems with ext3 or ext4. For storage pool-related file systems, use XFS.
Other software	Korn Shell (ksh)

Windows systems

Type of software	Minimum software requirements
Operating system	Microsoft Windows Server 2012 R2 (64-bit) or Windows Server 2016
File system type	NTFS
Other software	Windows 2012 R2 or Windows 2016 with .NET Framework 3.5 is installed and enabled. The following User Account Control policies must be disabled: <ul style="list-style-type: none"> • User Account Control: Admin Approval Mode for the Built-in Administrator account • User Account Control: Run all administrators in Admin Approval Mode

Related information

[Setting AIX network options](#)

Planning worksheets

Use the planning worksheets to record values that you use to set up your system and configure the IBM Spectrum Protect server. Use the best practice default values that are listed in the worksheets.

Each worksheet helps you prepare for different parts of the system configuration by using best practice values:

Server system preconfiguration

Use the preconfiguration worksheets to plan for the file systems and directories that you create when you configure file systems for IBM Spectrum Protect during system setup. All directories that you create for the server must be empty.

Server configuration

Use the configuration worksheets when you configure the server. Default values are suggested for most items, except where noted.

AIX

<i>Table 2. Worksheet for preconfiguration of an AIX server system</i>				
Item	Default value	Your value	Minimum directory size	Notes
TCP/IP port address for communications with the server	1500		Not applicable	Ensure that this port is available when you install and configure the operating system The port number can be a number in the range 1024 - 32767.
Directory for the server instance	/home/tsminst1/tsminst1		50 GB	If you change the value for the server instance directory from the default, also modify the Db2 instance owner value in Table 3 on page 8 .
Directory for server installation	/		Available space that is required for the directory: 5 GB	
Directory for server installation	/usr		Available space that is required for the directory: 5 GB	
Directory for server installation	/var		Available space that is required for the directory: 5 GB	
Directory for server installation	/tmp		Available space that is required for the directory: 5 GB	
Directory for server installation	/opt		Available space that is required for the directory: 10 GB	
Directory for the active log	/tsminst1/TSMalog		<ul style="list-style-type: none"> • Small and medium: 140 GB • Large: 300 GB 	When you create the active log during the initial configuration of the server, set the size to 128 GB.
Directory for the archive log	/tsminst1/TSMarchlog		<ul style="list-style-type: none"> • Small: 1 TB • Medium: 2 TB • Large: 4 TB 	

Table 2. Worksheet for preconfiguration of an AIX server system (continued)

Item	Default value	Your value	Minimum directory size	Notes
Directories for the database	/tsminst1/ TSMdbspace00 /tsminst1/ TSMdbspace01 /tsminst1/ TSMdbspace02 /tsminst1/ TSMdbspace03 ...		Minimum total space for all directories: <ul style="list-style-type: none"> • Small: At least 1 TB • Medium: At least 2 TB • Large: At least 4 TB 	Create a minimum number of file systems for the database, depending on the size of your system: <ul style="list-style-type: none"> • Small: At least 4 file systems • Medium: At least 4 file systems • Large: At least 8 file systems
Directories for storage	/tsminst1/TSMfile00 /tsminst1/TSMfile01 /tsminst1/TSMfile02 /tsminst1/TSMfile03 ...		Minimum total space for all directories: <ul style="list-style-type: none"> • Small: At least 38 TB • Medium: At least 180 TB • Large: At least 500 TB 	Create a minimum number of file systems for storage, depending on the size of your system: <ul style="list-style-type: none"> • Small: At least 2 file systems • Medium: At least 10 file systems • Large: At least 30 file systems

Table 2. Worksheet for preconfiguration of an AIX server system (continued)

Item	Default value	Your value	Minimum directory size	Notes
Directories for database backup	/tsminst1/TSMbkup00 /tsminst1/TSMbkup01 /tsminst1/TSMbkup02 /tsminst1/TSMbkup03		Minimum total space for all directories: <ul style="list-style-type: none"> • Small: At least 3 TB • Medium: At least 10 TB • Large: At least 16 TB 	Create a minimum number of file systems for backing up the database, depending on the size of your system: <ul style="list-style-type: none"> • Small: At least 2 file systems • Medium: At least 3 file systems • Large: At least 3 file systems The first database backup directory is also used for the archive log failover directory and a second copy of the volume history and device configuration files.

Table 3. Worksheet for IBM Spectrum Protect configuration

Item	Default value	Your value	Notes
Db2 instance owner	tsminst1		If you changed the value for the server instance directory in Table 2 on page 6 from the default, also modify the value for the Db2 instance owner.
Db2 instance owner password	passw0rd		Select a different value for the instance owner password than the default. Ensure that you record this value in a secure location.
Primary group for the Db2 instance owner	tsmsrvrs		
Server name	The default value for the server name is the system host name.		

Table 3. Worksheet for IBM Spectrum Protect configuration (continued)

Item	Default value	Your value	Notes
Server password	passw0rd		Select a different value for the server password than the default. Ensure that you record this value in a secure location.
Administrator ID: user ID for the server instance	admin		
Administrator ID password	passw0rd		Select a different value for the administrator password than the default. Ensure that you record this value in a secure location.
Schedule start time	22:00		The default schedule start time begins the client workload phase, which is predominantly the client backup and archive activities. During the client workload phase, server resources support client operations. Normally, these operations are completed during the nightly schedule window. Schedules for server maintenance operations are defined to begin 10 hours after the start of the client backup window.

Linux

Table 4. Worksheet for preconfiguration of a Linux server system

Item	Default value	Your value	Minimum directory size	Notes
TCP/IP port address for communications with the server	1500		Not applicable	Ensure that this port is available when you install and configure the operating system The port number can be a number in the range 1024 - 32767.

Table 4. Worksheet for preconfiguration of a Linux server system (continued)

Item	Default value	Your value	Minimum directory size	Notes
Directory for the server instance	/home/tsminst1/ tsminst1		25 GB	If you change the value for the server instance directory from the default, also modify the Db2 instance owner value in Table 5 on page 11.
Directory for the active log	/tsminst1/TSMalog		<ul style="list-style-type: none"> • Small and medium: 140 GB • Large: 300 GB 	
Directory for the archive log	/tsminst1/ TSMarchlog		<ul style="list-style-type: none"> • Small: 1 TB • Medium: 2 TB • Large: 4 TB 	
Directories for the database	/tsminst1/ TSMdbspace00 /tsminst1/ TSMdbspace01 /tsminst1/ TSMdbspace02 /tsminst1/ TSMdbspace03 ...		Minimum total space for all directories: <ul style="list-style-type: none"> • Small: At least 1 TB • Medium: At least 2 TB • Large: At least 4 TB 	Create a minimum number of file systems for the database, depending on the size of your system: <ul style="list-style-type: none"> • Small: At least 4 file systems • Medium: At least 4 file systems • Large: At least 8 file systems
Directories for storage	/tsminst1/TSMfile00 /tsminst1/TSMfile01 /tsminst1/TSMfile02 /tsminst1/TSMfile03 ...		Minimum total space for all directories: <ul style="list-style-type: none"> • Small: At least 38 TB • Medium: At least 180 TB • Large: At least 500 TB 	Create a minimum number of file systems for storage, depending on the size of your system: <ul style="list-style-type: none"> • Small: At least 2 file systems • Medium: At least 10 file systems • Large: At least 30 file systems

Table 4. Worksheet for preconfiguration of a Linux server system (continued)

Item	Default value	Your value	Minimum directory size	Notes
Directories for database backup	/tsminst1/TSMbkup00 /tsminst1/TSMbkup01 /tsminst1/TSMbkup02 /tsminst1/TSMbkup03		Minimum total space for all directories: <ul style="list-style-type: none"> • Small: At least 3 TB • Medium: At least 10 TB • Large: At least 16 TB 	<p>Create a minimum number of file systems for backing up the database, depending on the size of your system:</p> <ul style="list-style-type: none"> • Small: At least 2 file systems • Medium: At least 3 file systems • Large: At least 3 file systems <p>The first database backup directory is also used for the archive log failover directory and a second copy of the volume history and device configuration files.</p>

Table 5. Worksheet for IBM Spectrum Protect configuration

Item	Default value	Your value	Notes
Db2 instance owner	tsminst1		If you changed the value for the server instance directory in Table 4 on page 9 from the default, also modify the value for the Db2 instance owner.
Db2 instance owner password	passw0rd		Select a different value for the instance owner password than the default. Ensure that you record this value in a secure location.
Primary group for the Db2 instance owner	tsmsrvrs		
Server name	The default value for the server name is the system host name.		

Table 5. Worksheet for IBM Spectrum Protect configuration (continued)

Item	Default value	Your value	Notes
Server password	passw0rd		Select a different value for the server password than the default. Ensure that you record this value in a secure location.
Administrator ID: user ID for the server instance	admin		
Administrator ID password	passw0rd		Select a different value for the administrator password than the default. Ensure that you record this value in a secure location.
Schedule start time	22:00		The default schedule start time begins the client workload phase, which is predominantly the client backup and archive activities. During the client workload phase, server resources support client operations. Normally, these operations are completed during the nightly schedule window. Schedules for server maintenance operations are defined to begin 10 hours after the start of the client backup window.

Windows

Because many volumes are created for the server, configure the server by using the Windows feature of mapping disk volumes to directories rather than to drive letters.

For example, `C:\tsminst1\TSMdbpsace00` is a mount point to a volume with its own space. The volume is mapped to a directory under the C: drive, but does not take up space from the C: drive. The exception is the server instance directory, `C:\tsminst1`, which can be a mount point or a regular directory.

Table 6. Worksheet for preconfiguration of a Windows server system

Item	Default value	Your value	Minimum directory size	Notes
TCP/IP port address for communications with the server	1500		Not applicable	Ensure that this port is available when you install and configure the operating system The port number can be a number in the range 1024 - 32767.
Directory for the server instance	C:\tsminst1		25 GB	If you change the value for the server instance directory from the default, also modify the Db2 instance owner value in Table 7 on page 14 .
Directory for the active log	C:\tsminst1\TSMalog		<ul style="list-style-type: none"> • Small and medium: 140 GB • Large: 300 GB 	
Directory for the archive log	C:\tsminst1\TSMarch log		<ul style="list-style-type: none"> • Small: 1 TB • Medium: 2 TB • Large: 4 TB 	
Directories for the database	C:\tsminst1\TSMdbspace00 C:\tsminst1\TSMdbspace01 C:\tsminst1\TSMdbspace02 C:\tsminst1\TSMdbspace03 ...		Minimum total space for all directories: <ul style="list-style-type: none"> • Small: At least 1 TB • Medium: At least 2 TB • Large: At least 4 TB 	Create a minimum number of file systems for the database, depending on the size of your system: <ul style="list-style-type: none"> • Small: At least 4 file systems • Medium: At least 4 file systems • Large: At least 8 file systems

Table 6. Worksheet for preconfiguration of a Windows server system (continued)

Item	Default value	Your value	Minimum directory size	Notes
Directories for storage	C:\tsminst1\TSMfile00 C:\tsminst1\TSMfile01 C:\tsminst1\TSMfile02 C:\tsminst1\TSMfile03 ...		Minimum total space for all directories: <ul style="list-style-type: none"> • Small: At least 38 TB • Medium: At least 180 TB • Large: At least 500 TB 	Create a minimum number of file systems for storage, depending on the size of your system: <ul style="list-style-type: none"> • Small: At least 2 file systems • Medium: At least 10 file systems • Large: At least 30 file systems
Directories for database backup	C:\tsminst1\TSMbkup00 C:\tsminst1\TSMbkup01 C:\tsminst1\TSMbkup02 C:\tsminst1\TSMbkup03		Minimum total space for all directories: <ul style="list-style-type: none"> • Small: At least 3 TB • Medium: At least 10 TB • Large: At least 16 TB 	Create a minimum number of file systems for backing up the database, depending on the size of your system: <ul style="list-style-type: none"> • Small: At least 2 file systems • Medium: At least 3 file systems • Large: At least 3 file systems <p>The first database backup directory is also used for the archive log failover directory and a second copy of the volume history and device configuration files.</p>

Table 7. Worksheet for IBM Spectrum Protect configuration

Item	Default value	Your value	Notes
Db2 instance owner	tsminst1		If you changed the value for the server instance directory in Table 6 on page 13 from the default, also modify the value for the Db2 instance owner.

Table 7. Worksheet for IBM Spectrum Protect configuration (continued)

Item	Default value	Your value	Notes
Db2 instance owner password	pAssw0rd		Select a different value for the instance owner password than the default. Ensure that you record this value in a secure location.
Server name	The default value for the server name is the system host name.		
Server password	passw0rd		Select a different value for the server password than the default. Ensure that you record this value in a secure location.
Administrator ID: user ID for the server instance	admin		
Administrator ID password	passw0rd		Select a different value for the administrator password than the default. Ensure that you record this value in a secure location.
Schedule start time	22:00		<p>The default schedule start time begins the client workload phase, which is predominantly the client backup and archive activities. During the client workload phase, server resources support client operations. Normally, these operations are completed during the nightly schedule window.</p> <p>Schedules for server maintenance operations are defined to begin 10 hours after the start of the client backup window.</p>

Planning for storage

Choose the most effective storage technology for IBM Spectrum Protect components to ensure efficient server performance and operations.

Storage hardware devices have different capacity and performance characteristics, which determine how they can be used effectively with IBM Spectrum Protect. For general guidance on selecting the appropriate storage hardware and set up for your solution, review the following guidelines.

Database and active log

- Use a fast disk for the IBM Spectrum Protect database and active log, for example with the following characteristics:
 - High performance, 15k rpm disk with Fibre Channel or serial-attached SCSI (SAS) interface
 - Solid-state disk (SSD)
- Isolate the active log from the database unless you use SSD or flash hardware
- When you create arrays for the database, use RAID level 5

Storage pool

- You can use less expensive and slower disks for the storage pool
- The storage pool can share disks for the archive log and database backup storage
- Use RAID level 6 for storage pool arrays to add protection against double drive failures when you use large disk types

Related information

[Storage system requirements and reducing the risk of data corruption](#)

Planning the storage arrays

Prepare for disk storage configuration by planning for RAID arrays and volumes, according to the size of your IBM Spectrum Protect system.

You design storage arrays with size and performance characteristics that are suitable for one of the IBM Spectrum Protect server storage components, such as the server database or a storage pool. The storage planning activity must take account of drive type, RAID level, number of drives, the number of spare drives, and so on. In the solution configurations, storage groups contain internal-storage RAID arrays and consist of multiple physical disks that are presented as logical volumes to the system. When you configure the disk storage system, you create storage groups, or data storage pools, and then create storage arrays in the groups.

You create volumes, or LUNs, from the storage groups. The storage group defines which disks provide the storage that makes up the volume. When you create volumes, make them fully allocated. Faster disks types are used to hold the database volumes and active log volumes. Slower disk types can be used for the storage pool volumes, archive log, and database backup volumes. If you use a smaller disk storage pool to stage data, you might need to use faster disks to manage the daily workload performance for ingesting and migrating data.

Table 8 on page 16 and Table 9 on page 17 describe the layout requirements for storage groups and volume configuration.

<i>Table 8. Components of storage group configuration</i>	
Component	Details
Server storage requirement	How the storage is used by the server.
Disk type	Size and speed for the disk type that is used for the storage requirement.

Table 8. Components of storage group configuration (continued)

Component	Details
Disk quantity	Number of each disk type that is needed for the storage requirement.
Hot spare capacity	Number of disks that are reserved as spares to take over if disk failures occur.
RAID level	Level of RAID array that is used for logical storage. The RAID level defines the type of redundancy that is provided by the array, for example, 5 or 6.
RAID array quantity	Number of RAID arrays to be created.
DDMs per RAID array	How many disk drive modules (DDMs) are to be used in each of the RAID arrays.
Usable size per RAID array	Size that is available for data storage in each RAID array after accounting for space that is lost due to redundancy.
Total usable size	Total size that is available for data storage in the RAID arrays: Quantity x Usable size
Suggested storage group and array names	Preferred name to use for MDisks and MDisk groups.
Usage	Server component that uses part of the physical disk.

Table 9. Components of volume configuration

Component	Details
Server storage requirement	Requirement for which the physical disk is used.
Volume name	Unique name that is given to a specific volume.
Storage group	Name of the storage group from which the space is obtained to create the volume.
Size	Size of each volume.
Intended server mount point	Directory on the server system where the volume is mounted.
Quantity	Number of volumes to create for a specific requirement. Use the same naming standard for each volume that is created for the same requirement.
Usage	Server component that uses part of the physical disk.

Examples

Configuration examples for storage groups and volumes are available at the following link: [Examples of worksheets for planning storage arrays](#). The examples show how to plan the storage for different server sizes. In the example configurations, there is a one-to-one mapping between disks and storage groups. You can download the examples and edit the worksheets to plan the storage configuration for your server.

Planning for security

Plan to protect the security of systems in the IBM Spectrum Protect solution with access and authentication controls, and consider encrypting data and password transmission.

For guidelines about protecting your storage environment against ransomware attacks, and recovering your storage environment if an attack occurs, see [Protecting the storage environment against ransomware](#).

Planning for administrator roles

Define the authority levels that you want to assign to administrators who have access to the IBM Spectrum Protect solution.

You can assign one of the following levels of authority to administrators:

System

Administrators with system authority have the highest level of authority. Administrators with this level of authority can complete any task. They can manage all policy domains and storage pools, and grant authority to other administrators.

Policy

Administrators who have policy authority can manage all of the tasks that are related to policy management. This privilege can be unrestricted, or can be restricted to specific policy domains.

Storage

Administrators who have storage authority can allocate and control storage resources for the server.

Operator

Administrators who have operator authority can control the immediate operation of the server and the availability of storage media such as tape libraries and drives.

The scenarios in [Table 10 on page 18](#) provide examples about why you might want to assign varying levels of authority so that administrators can perform tasks:

Scenario	Type of administrator ID to set up
An administrator at a small company manages the server and is responsible for all server activities.	<ul style="list-style-type: none">• System authority: 1 administrator ID
An administrator for multiple servers also manages the overall system. Several other administrators manage their own storage pools.	<ul style="list-style-type: none">• System authority on all servers: 1 administrator ID for the overall system administrator• Storage authority for designated storage pools: 1 administrator ID for each of the other administrators
An administrator manages 2 servers. Another person helps with the administration tasks. Two assistants are responsible for helping to ensure that important systems are backed up. Each assistant is responsible for monitoring the scheduled backups on one of the IBM Spectrum Protect servers.	<ul style="list-style-type: none">• System authority on both servers: 2 administrator IDs• Operator authority: 2 administrator IDs for the assistants with access to the server that each person is responsible for

Planning for secure communications

Plan for protecting communications among the IBM Spectrum Protect solution components.

Determine the level of protection that is required for your data, based on regulations and business requirements under which your company operates.

If your business requires a high level of security for passwords and data transmission, plan on implementing secure communication with Transport Layer Security (TLS) or Secure Sockets Layer (SSL) protocols.

TLS and SSL provide secure communications between the server and client, but can affect system performance. To improve system performance, use TLS for authentication without encrypting object data. To specify whether the server uses TLS 1.2 for the entire session or only for authentication, see the **SSL** client option for client-to-server communication, and the **UPDATE SERVER=SSL** parameter for server-to-server communication. Beginning in V8.1.2, TLS is used for authentication by default. If you decide to use TLS to encrypt entire sessions, use the protocol only for sessions where it is necessary and add processor resources on the server to manage the increase in network traffic. You can also try other options. For example, some networking devices such as routers and switches provide the TLS or SSL function.

You can use TLS and SSL to protect some or all of the different possible communication paths, for example:

- Operations Center: browser to hub; hub to spoke
- Client to server
- Server to server: node replication

Related information

[Securing communications](#)

Planning for storage of encrypted data

Determine whether your company requires stored data to be encrypted, and choose the option that best suits your needs.

If your company requires the data in storage pools to be encrypted, then you have the option of using IBM Spectrum Protect encryption, or an external device such as tape for encryption.

If you choose IBM Spectrum Protect to encrypt the data, extra computing resources are required at the client that might affect the performance of backup and restore processes.

Related information

[Data encryption considerations for cloud-container storage pools in IBM Spectrum Protect](#)

Planning firewall access

Determine the firewalls that are set and the ports that must be open for the IBM Spectrum Protect solution to work.

Table 11 on page 19 describes the ports that are used by the server, client, and Operations Center.

<i>Table 11. Ports that are used by the server, client, and Operations Center</i>			
Item	Default	Direction	Description
Base port (TCP PORT)	1500	Outbound/ inbound	Each server instance requires a unique port. You can specify an alternative port number instead of using the default. The TCP PORT option listens for both TCP/IP and SSL-enabled sessions from the client. For administrative client traffic, you can use the TCPADMIN PORT and ADMINONCLIENT PORT options to set port values.
SSL-only port (SSLTCP PORT)	No default	Outbound/ inbound	This port is used if you want to restrict communication on the port to SSL-enabled sessions only. To support both SSL and non-SSL communications, use the TCP PORT or TCPADMIN PORT options.

Table 11. Ports that are used by the server, client, and Operations Center (continued)

Item	Default	Direction	Description
SMB	45	Inbound/ outbound	This port is used by configuration wizards that communicate by using native protocols with multiple hosts.
SSH	22	Inbound/ outbound	This port is used by configuration wizards that communicate by using native protocols with multiple hosts.
SMTP	25	Outbound	This port is used to send email alerts from the server.
NDMP	No default	Inbound/ outbound	<p>The server must be able to open an outbound NDMP control port connection to the NAS device. The outbound control port is the Low-Level Address in the data mover definition for the NAS device.</p> <p>During an NDMP filer-to-server restore, the server must be able to open an outbound NDMP data connection to the NAS device. The data connection port that is used during a restore can be configured on the NAS device.</p> <p>During NDMP filer-to-server backups, the NAS device must be able to open outbound data connections to the server and the server must be able to accept inbound NDMP data connections. You can use the server option NDMPPORTRANGE to restrict the set of ports available for use as NDMP data connections. You can configure a firewall for connections to these ports.</p>
Replication	No default	Outbound/ inbound	<p>The port and protocol for the outbound port for replication are set by the DEFINE SERVER command that is used to set up replication.</p> <p>The inbound ports for replication are the TCP ports and SSL ports that the source server names in the DEFINE SERVER command.</p>
Client schedule port	Client port: 1501	Outbound	The client listens on the port that is named and communicates the port number to the server. The server contacts the client if server prompted scheduling is used. You can specify an alternative port number in the client options file.
Long running sessions	KEEPALIVE setting: YES	Outbound	When the KEEPALIVE option is enabled, keepalive packets are sent during client-server sessions to prevent the firewall software from closing long-running, inactive connections.
Operations Center	HTTPS: 11090	Inbound	These ports are used for the Operations Center web browser. You can specify an alternative port number.
Client management service port	Client port: 9028	Inbound	The client management service port must be accessible from the Operations Center. Ensure that firewalls cannot prevent connections. The client management service uses the TCP port of the server for the client node for authentication by using an administrative session.

Part 2. Single-site disk implementation of a data protection solution

The single-site disk solution is configured at one site and uses data deduplication.

Implementation roadmap

The following steps are required to set up the IBM Spectrum Protect single-site disk environment.

1. Set up the system.
 - a. Configure the storage hardware and set up storage arrays for your environment size.
 - b. Install the server operating system.
 - c. Configure multipath I/O.
 - d. Create the user ID for the server instance.
 - e. Prepare file systems for IBM Spectrum Protect.
2. Install the server and Operations Center.
3. Configure the server and Operations Center.
 - a. Complete the initial configuration of the server.
 - b. Set server options.
 - c. Configure Secure Sockets Layer for the server and client.
 - d. Configure the Operations Center.
 - e. Register your IBM Spectrum Protect license.
 - f. Configure data deduplication.
 - g. Define data retention rules for your business.
 - h. Define server maintenance schedules.
 - i. Define client schedules.
4. Install and configure clients.
 - a. Register and assign clients to schedules.
 - b. Install and verify the client management service.
 - c. Configure the Operations Center to use the client management service.
5. Complete the implementation.

Setting up the system

To set up the system, you must first configure your disk storage hardware and the server system for IBM Spectrum Protect.

Configuring the storage hardware

To configure your storage hardware, review general guidance for disk systems and IBM Spectrum Protect.

Procedure

1. Provide a connection between the server and the storage devices by following these guidelines:
 - Use a switch or direct connection for Fibre Channel connections.

- Consider the number of ports that are connected and account for the amount of bandwidth that is needed.
 - Consider the number of ports on the server and the number of host ports on the disk system that are connected.
2. Verify that device drivers and firmware for the server system, adapters, and operating system are current and at the recommended levels.
 3. Configure storage arrays. Make sure that you planned properly to ensure optimal performance. See [“Planning for storage” on page 16](#) for more information.
 4. Ensure that the server system has access to disk volumes that are created. Complete the following steps:
 - a) If the system is connected to a Fibre Channel switch, zone the server to see the disks.
 - b) Map all of the volumes to tell the disk system that this specific server is allowed to see each disk.

Installing the server operating system

Install the operating system on the server system and ensure that IBM Spectrum Protect server requirements are met. Adjust operating system settings as directed.

Installing on AIX systems

Complete the following steps to install AIX on the server system.

Procedure

1. Install AIX Version 7.1, TL4, SP6, or later according to the manufacturer instructions.
2. Configure your TCP/IP settings according to the operating system installation instructions.
3. Open the `/etc/hosts` file and complete the following actions:

- Update the file to include the IP address and host name for the server. For example:

```
192.0.2.7 server.yourdomain.com server
```

- Verify that the file contains an entry for localhost with an address of 127.0.0.1. For example:

```
127.0.0.1 localhost
```

4. Enable AIX I/O completion ports by issuing the following command:

```
chdev -l iocp0 -P
```

Server performance can be affected by the Olson time zone definition.

5. To optimize performance, change your system time zone format from Olson to POSIX. Use the following command format to update the time zone setting:

```
chtz=local_timezone,date/time,date/time
```

For example, if you lived in Tucson, Arizona, where Mountain Standard Time is used, you would issue the following command to change to the POSIX format:

```
chtz MST7MDT,M3.2.0/2:00:00,M11.1.0/2:00:00
```

6. In the `.profile` file of the instance user, verify that the following environment variable is set:

```
export MALLOCOPTIONS=multiheap:16
```

In later versions of the IBM Spectrum Protect server, this value is set automatically when the server is started. If the instance user is not available, complete this step later, when the instance user becomes available.

7. Set the system to create full application core files. Issue the following command:

```
chdev -l sys0 -a fullcore=true -P
```

8. For communications with the server and Operations Center, make sure that the following ports are open on any firewalls that might exist:

- For communications with the server, open port 1500.
- For secure communications with the Operations Center, open port 11090 on the hub server.

If you are not using the default port values, make sure that the ports that you are using are open.

9. Enable TCP high-performance enhancements. Issue the following command:

```
no -p -o rfc1323=1
```

10. For optimal throughput and reliability, bond two 10 Gb Ethernet ports together for a medium system and four 10 Gb Ethernet ports for a large system. Use the System Management Interface Tool (SMIT) to bond the ports together by using Etherchannel.

The following settings were used during testing:

```

mode          8023ad          Enable automatic recovery after failover
auto_recovery yes             Adapter used when whole channel fails
backup_adapter NONE          Determines how outgoing adapter is chosen
hash_mode     src_dst_port    Determines interval value for IEEE
interval      long           802.3ad mode
mode          8023ad          EtherChannel mode of operation
netaddr       0              Address to ping
noloss_failover yes         Enable lossless failover after ping
failure
num_retries   3              Times to retry ping before failing
retry_time    1              Wait time (in seconds) between pings
use_alt_addr  no             Enable Alternate EtherChannel Address
use_jumbo_frame no          Enable Gigabit Ethernet Jumbo Frames

```

11. Verify that user process resource limits, also known as *ulimits*, are set according to guidelines in Table 12 on page 23. If ulimit values are not set correctly, you might experience server instability or a failure of the server to respond.

Table 12. User limits (ulimit) values			
User limit type	Setting	Value	Command to query value
Maximum size of core files created	core	Unlimited	ulimit -Hc
Maximum size of a data segment for a process	data	Unlimited	ulimit -Hd
Maximum file size	fsize	Unlimited	ulimit -Hf
Maximum number of open files	nofile	65536	ulimit -Hn
Maximum amount of processor time in seconds	cpu	Unlimited	ulimit -Ht
Maximum number of user processes	nproc	16384	ulimit -Hu

If you need to modify any user limit values, follow the instructions in the documentation for your operating system.

Installing on Linux systems

Complete the following steps to install Linux x86_64 on the server system.

Before you begin

The operating system will be installed on the internal hard disks. Configure the internal hard disks by using a hardware RAID 1 array. For example, if you are configuring a small system, the two 300 GB internal disks are mirrored in RAID 1 so that a single 300 GB disk appears available to the operating system installer.

Procedure

1. Install Red Hat Enterprise Linux Version 7.4 or later, according to the manufacturer instructions.

Obtain a bootable DVD that contains Red Hat Enterprise Linux Version 7.4 or later and start your system from this DVD. See the following guidance for installation options. If an item is not mentioned in the following list, leave the default selection.

- a) After you start the DVD, choose **Install or upgrade an existing system** from the menu.
- b) On the Welcome screen, select **Test this media & install Red Hat Enterprise Linux 7.4**.
- c) Select your language and keyboard preferences.
- d) Select your location to set the correct timezone.
- e) Select **Software Selection** and then on the next screen, select **Server with GUI**.
- f) From the installation summary page, click **Installation Destination** and verify the following items:
 - The local 300 GB disk is selected as the installation target.
 - Under Other Storage Options, **Automatically configure partitioning** is selected.

Click **Done**.

- g) Click **Begin Installation**.

After the installation starts, set the root password for your root user account.

After the installation is completed, restart the system and log in as the root user. Issue the **df** command to verify your basic partitioning.

For example, on a test system, the initial partitioning produced the following result:

```
[root@tvapp02]# df -h
Filesystem      Size  Used Avail Use% Mounted on
/dev/mapper/rhel-root  50G  3.0G  48G   6% /
devtmpfs        32G   0    32G   0% /dev
tmpfs           32G  92K   32G   1% /dev/shm
tmpfs           32G  8.8M   32G   1% /run
tmpfs           32G   0    32G   0% /sys/fs/cgroup
/dev/mapper/rhel-home 220G  37M  220G   1% /home
/dev/sda1       497M 124M  373M  25% /boot
```

2. Configure your TCP/IP settings according to the operating system installation instructions.

For optimal throughput and reliability, consider bonding multiple network ports together. Bond two ports for a medium system and four ports for a large system. This can be accomplished by creating a Link Aggregation Control Protocol (LACP) network connection, which aggregates several subordinate ports into a single logical connection. The preferred method is to use a bond mode of 802.3ad, **miimon** setting of 100, and a **xmit_hash_policy** setting of layer3+4.

Restriction: To use an LACP network connection, you must have a network switch that supports LACP.

For additional instructions about configuring bonded network connections with Red Hat Enterprise Linux Version 7, see [Create a Channel Bonding Interface](#).

3. Open the `/etc/hosts` file and complete the following actions:

- Update the file to include the IP address and host name for the server. For example:

```
192.0.2.7 server.yourdomain.com server
```

- Verify that the file contains an entry for localhost with an address of 127.0.0.1. For example:

```
127.0.0.1 localhost
```

4. Install components that are required for the server installation. Complete the following steps to create a Yellowdog Updater Modified (YUM) repository and install the prerequisite packages.

- a) Mount your Red Hat Enterprise Linux installation DVD to a system directory. For example, to mount it to the /mnt directory, issue the following command:

```
mount -t iso9660 -o ro /dev/cdrom /mnt
```

- b) Verify that the DVD mounted by issuing the **mount** command.
You should see output similar to the following example:

```
/dev/sr0 on /mnt type iso9660
```

- c) Change to the YUM repository directory by issuing the following command:

```
cd /etc/yum/repos.d
```

If the `repos.d` directory does not exist, create it.

- d) List directory contents:

```
ls rhel-source.repo
```

- e) Rename the original repo file by issuing the **mv** command.
For example:

```
mv rhel-source.repo rhel-source.repo.orig
```

- f) Create a new repo file by using a text editor.
For example, to use the vi editor, issue the following command:

```
vi rhel74_dvd.repo
```

- g) Add the following lines to the new repo file. The **baseurl** parameter specifies your directory mount point:

```
[rhel74_dvd]
name=DVD Redhat Enterprise Linux 7.4
baseurl=file:///mnt
enabled=1
gpgcheck=0
```

- h) Install the prerequisite package `ksh.x86_64`, by issuing the **yum** command.
For example:

```
yum install ksh.x86_64
```

5. When the software installation is complete, you can restore the original YUM repository values by completing the following steps:

- a) Unmount the Red Hat Enterprise Linux installation DVD by issuing the following command:

```
umount /mnt
```

- b) Change to the YUM repository directory by issuing the following command:

```
cd /etc/yum/repos.d
```

- c) Rename the repo file that you created:

```
mv rhel74_dvd.repo rhel74_dvd.repo.orig
```

d) Rename the original file to the original name:

```
mv rhel-source.repo.orig rhel-source.repo
```

6. Determine whether kernel parameter changes are required. Complete the following steps:

- a) Use the **sysctl -a** command to list the parameter values.
- b) Analyze the results by using the guidelines in [Table 13 on page 26](#) to determine whether any changes are required.
- c) If changes are required, set the parameters in the `/etc/sysctl.conf` file.
The file changes are applied when the system is started.

Tip: Automatically adjust kernel parameter settings and eliminate the need for manual updates to these settings. On Linux, the Db2 database software automatically adjusts interprocess communication (IPC) kernel parameter values to the preferred settings. For more information about kernel parameter settings, search for Linux kernel parameters in the [Version 11.5 product documentation](#).

Parameter	Description
kernel.shmni	The maximum number of segments.
kernel.shmmax	The maximum size of a shared memory segment (bytes). This parameter must be set before automatically starting the IBM Spectrum Protect server on system startup.
kernel.shmall	The maximum allocation of shared memory pages (pages).
kernel.sem There are four values for the kernel.sem parameter.	(SEMMSL) The maximum semaphores per array.
	(SEMMNS) The maximum semaphores per system.
	(SEMOPM) The maximum operations per semaphore call.
	(SEMMNI) The maximum number of arrays.
kernel.msgmni	The maximum number of system-wide message queues.
kernel.msgmax	The maximum size of messages (bytes).
kernel.msgmnb	The default maximum size of queue (bytes).
kernel.randomize_va_space	The kernel.randomize_va_space parameter configures the use of memory ASLR for the kernel. Enable ASLR for V7.1 and later servers. To learn more details about the Linux ASLR and Db2, see technote 1365583 .
vm.swappiness	The vm.swappiness parameter defines whether the kernel can swap application memory out of physical random access memory (RAM). For more information about kernel parameters, see the Db2 product information .

Table 13. Linux kernel parameter optimum settings (continued)

Parameter	Description
vm.overcommit_memory	The vm.overcommit_memory parameter influences how much virtual memory the kernel permits allocating. For more information about kernel parameters, see the Db2 product information .

7. Open firewall ports to communicate with the server. Complete the following steps:

a) Determine the zone that is used by the network interface. The zone is public, by default.

Issue the following command:

```
# firewall-cmd --get-active-zones
public
  interfaces: ens4f0
```

b) To use the default port address for communications with the server, open TCP/IP port 1500 in the Linux firewall.

Issue the following command:

```
firewall-cmd --zone=public --add-port=1500/tcp --permanent
```

If you want to use a value other than the default, you can specify a number in the range 1024 - 32767. If you open a port other than the default, you will need to specify that port when you run the configuration script.

c) If you plan to use this system as a hub, open port 11090, which is the default port for secure (https) communications.

Issue the following command:

```
firewall-cmd --zone=public --add-port=11090/tcp --permanent
```

d) Reload the firewall definitions for the changes to take effect.

Issue the following command:

```
firewall-cmd --reload
```

8. Verify that user process resource limits, also known as *ulimits*, are set according to guidelines in [Table 14 on page 27](#). If ulimit values are not set correctly, you might experience server instability or a failure of the server to respond.

Table 14. User limits (ulimit) values			
User limit type	Setting	Value	Command to query value
Maximum size of core files created	core	Unlimited	ulimit -Hc
Maximum size of a data segment for a process	data	Unlimited	ulimit -Hd
Maximum file size	fsize	Unlimited	ulimit -Hf
Maximum number of open files	nofile	65536	ulimit -Hn
Maximum amount of processor time in seconds	cpu	Unlimited	ulimit -Ht

<i>Table 14. User limits (ulimit) values (continued)</i>			
User limit type	Setting	Value	Command to query value
Maximum number of user processes	nproc	16384	ulimit -Hu

If you need to modify any user limit values, follow the instructions in the documentation for your operating system.

Installing on Windows systems

Install Microsoft Windows Server 2012 Standard Edition on the server system and prepare the system for installation and configuration of the IBM Spectrum Protect server.

Procedure

1. Install Windows Server 2016 Standard Edition, according to the manufacturer instructions.
2. Change the Windows account control policies by completing the following steps.
 - a) Open the Local Security Policy editor by running `secpol.msc`.
 - b) Click **Local Policies > Security Options** and ensure that the following User Account Control policies are disabled:
 - Admin Approval Mode for the Built-in Administrator account
 - Run all administrators in Admin Approval Mode
3. Configure your TCP/IP settings according to installation instructions for the operating system.
4. Apply Windows updates and enable optional features by completing the following steps:
 - a) Apply the latest Windows Server 2016 updates.
 - b) Install and enable the Windows 2012 R2 feature Microsoft .NET Framework 3.5 from the Windows Server Manager.
 - c) If required, update the FC and Ethernet HBA device drivers to newer levels.
 - d) Install the multipath I/O driver that is appropriate for the disk system that you are using.
5. Open the default TCP/IP port, 1500, for communications with the IBM Spectrum Protect server. For example, issue the following command:

```
netsh advfirewall firewall add rule name="Backup server port 1500"
dir=in action=allow protocol=TCP localport=1500
```

6. On the Operations Center hub server, open the default port for secure (https) communications with the Operations Center.

The port number is 11090.

For example, issue the following command:

```
netsh advfirewall firewall add rule name="Operations Center port 11090"
dir=in action=allow protocol=TCP localport=11090
```

Configuring multipath I/O

You can enable and configure multipathing for disk storage. Use the documentation that is provided with your hardware for detailed instructions.

AIX systems

Procedure

1. Determine the Fibre Channel port address that you must use for the host definition on the disk subsystem. Issue the **lscfg** command for every port.

- On small and medium systems, issue the following commands:

```
lscfg -vps -l fcs0 | grep "Network Address"  
lscfg -vps -l fcs1 | grep "Network Address"
```

- On large systems, issue the following commands:

```
lscfg -vps -l fcs0 | grep "Network Address"  
lscfg -vps -l fcs1 | grep "Network Address"  
lscfg -vps -l fcs2 | grep "Network Address"  
lscfg -vps -l fcs3 | grep "Network Address"
```

2. Ensure that the following AIX file sets are installed:

- devices.common.IBM.mpio.rte
- devices.fcp.disk.rte

3. Issue the **cfgmgr** command to have AIX rescan the hardware and discover available disks. For example:

```
cfgmgr
```

4. To list the available disks, issue the following command:

```
lsdev -Ccdisk
```

The output is similar to the following example:

```
hdisk0 Available 00-00-00 SAS Disk Drive  
hdisk1 Available 00-00-00 SAS Disk Drive  
hdisk2 Available 01-00-00 SAS Disk Drive  
hdisk3 Available 01-00-00 SAS Disk Drive  
hdisk4 Available 06-01-02 MPIO IBM 2076 FC Disk  
hdisk5 Available 07-01-02 MPIO IBM 2076 FC Disk  
...
```

5. Use the output from the **lsdev** command to identify and list device IDs for each disk device.

For example, a device ID could be `hdisk4`. Save the list of device IDs to use when you create file systems for the IBM Spectrum Protect server.

6. Correlate the SCSI device IDs to specific disk LUNs from the disk system by listing detailed information about all physical volumes in the system. Issue the following command:

```
lspv -u
```

On an IBM Storwize system, the following information is an example of what is shown for each device:

```
hdisk4 00f8cf083fd97327 None active  
33213600507630081010578000000000003004214503IBMfcp
```

In the example, `60050763008101057800000000000030` is the UID for the volume, as reported by the Storwize management interface.

To verify disk size in megabytes and compare the value with what is listed for the system, issue the following command:

```
bootinfo -s hdisk4
```

Linux systems

Procedure

1. Edit the `/etc/multipath.conf` file to enable multipathing for Linux hosts.

If the `multipath.conf` file does not exist, you can create it by issuing the following command:

```
mpathconf --enable
```

The following parameters were set in `multipath.conf` for testing on an IBM FlashSystem® storage system:

```
defaults {
    user_friendly_names no
}

devices {
    device {
        vendor "IBM "
        product "2145"
        path_grouping_policy group_by_prio
        user_friendly_names no
        path_selector "round-robin 0"
        prio "alua"
        path_checker "tur"
        failback "immediate"
        no_path_retry 5
        rr_weight uniform
        rr_min_io_rq "1"
        dev_loss_tmo 120
    }
}
```

2. Set the multipath option to start when the system is started.

Issue the following commands:

```
systemctl enable multipathd.service
systemctl start multipathd.service
```

3. To verify that disks are visible to the operating system and are managed by multipath, issue the following command:

```
multipath -l
```

4. Ensure that each device is listed and that it has as many paths as you expect. You can use size and device ID information to identify which disks are listed.

For example, the following output shows that a 2 TB disk has two path groups and four active paths. The 2 TB size confirms that the disk corresponds to a pool file system. Use part of the long device ID number (12, in this example) to search for the volume on the disk-system management interface.

```
[root@tapsrv01 code]# multipath -l
36005076802810c50980000000000012 dm-43 IBM,2145
size=2.0T features='1 queue_if_no_path' hwhandler='0' wp=rw
|+- policy='round-robin 0' prio=0 status=active
| |- 2:0:1:18 sdcw 70:64 active undef running
| `-- 4:0:0:18 sdgb 131:112 active undef running
`+- policy='round-robin 0' prio=0 status=enabled
| - 1:0:1:18 sdat 66:208 active undef running
| - 3:0:0:18 sddy 128:0 active undef running
```

- a) If needed, correct disk LUN host assignments and force a bus rescan.

For example:

```
echo "- - -" > /sys/class/scsi_host/host0/scan
echo "- - -" > /sys/class/scsi_host/host1/scan
echo "- - -" > /sys/class/scsi_host/host2/scan
```

You can also restart the system to rescan disk LUN host assignments.

- b) Confirm that disks are now available for multipath I/O by reissuing the **multipath -l** command.
5. Use the multipath output to identify and list device IDs for each disk device.
- For example, the device ID for your 2 TB disk is 36005076802810c509800000000000012.
- Save the list of device IDs to use in the next step.

Windows systems

Procedure

1. Ensure that the Multipath I/O feature is installed. If needed, install additional vendor-specific multipath drivers.
2. To verify that disks are visible to the operating system and are managed by multipath I/O, issue the following command:

```
c:\program files\IBM\SDDDSM\datapath.exe query device
```

3. Review the multipath output and ensure that each device is listed and that it has as many paths as you expect. You can use size and device serial information to identify which disks are listed.

For example, by using part of the long device serial number (34, in this example) you can search for the volume on the disk-system management interface. The 2 TB size confirms that the disk corresponds to a storage pool file system.

```
DEV#: 4 DEVICE NAME: Disk5 Part0 TYPE: 2145 POLICY: OPTIMIZED
SERIAL: 60050763008101057800000000000034 LUN SIZE: 2.0TB
=====
Path# Adapter/Hard Disk State Mode Select Errors
0 Scsi Port2 Bus0/Disk5 Part0 OPEN NORMAL 0 0
1 Scsi Port2 Bus0/Disk5 Part0 OPEN NORMAL 27176 0
2 Scsi Port3 Bus0/Disk5 Part0 OPEN NORMAL 28494 0
3 Scsi Port3 Bus0/Disk5 Part0 OPEN NORMAL 0 0
```

4. Create a list of disk device IDs by using the serial numbers that are returned from the multipath output in the previous step.

For example, the device ID for your 2 TB disk is 60050763008101057800000000000034

Save the list of device IDs to use in the next step.

5. To bring new disks online and clear the read-only attribute, run `diskpart.exe` with the following commands. Repeat for each of the disks:

```
diskpart
select Disk 1
online disk
attribute disk clear readonly
select Disk 2
online disk
attribute disk clear readonly
< ... >
select Disk 49
online disk
attribute disk clear readonly
exit
```

Creating the user ID for the server

Create the user ID that owns the IBM Spectrum Protect server instance. You specify this user ID when you create the server instance during initial configuration of the server.

About this task

You can specify only lowercase letters (a-z), numerals (0-9), and the underscore character (_) for the user ID. The user ID and group name must comply with the following rules:

- The length must be 8 characters or fewer.
- The user ID and group name cannot start with *ibm*, *sql*, *sys*, or a numeral.
- The user ID and group name cannot be *user*, *admin*, *guest*, *public*, *local*, or any SQL reserved word.

Procedure

1. Use operating system commands to create a user ID.

- **Linux | AIX** Create a group and user ID in the home directory of the user that owns the server instance.

For example, to create the user ID `tsminst1` in group `tsmsrvrs` with a password of `tsminst1`, issue the following commands from an administrative user ID:

```
AIX mkgroup id=1001 tsmsrvrs
mkuser id=1002 pgrp=tsmsrvrs home=/home/tsminst1 tsminst1
passwd tsminst1
```

```
Linux groupadd tsmsrvrs
useradd -d /home/tsminst1 -m -g tsmsrvrs -s /bin/bash tsminst1
passwd tsminst1
```

Log off, and then log in to your system. Change to the user account that you created. Use an interactive login program, such as `telnet`, so that you are prompted for the password and can change it if necessary.

- **Windows** Create a user ID and then add the new ID to the Administrators group. For example, to create the user ID `tsminst1`, issue the following command:

```
net user tsminst1 * /add
```

After you create and verify a password for the new user, add the user ID to the Administrators group by issuing the following commands:

```
net localgroup Administrators tsminst1 /add
net localgroup DB2ADMNS tsminst1 /add
```

2. Log off the new user ID.

Preparing file systems for the server

You must complete file system configuration for the disk storage to be used by the server.

AIX systems

You must create volume groups, logical volumes, and file systems for the server by using the AIX Logical Volume Manager.

Procedure

1. Increase the queue depth and maximum transfer size for all of the available *hdiskX* disks. Issue the following commands for each disk:

```
chdev -l hdisk4 -a max_transfer=0x100000
chdev -l hdisk4 -a queue_depth=32
chdev -l hdisk4 -a reserve_policy=no_reserve
chdev -l hdisk4 -a algorithm=round_robin
```

Do not run these commands for operating system internal disks, for example, *hdisk0*.

2. Create volume groups for the IBM Spectrum Protect database, active log, archive log, database backup, and storage pool. Issue the **mkvg** command, specifying the device IDs for corresponding disks that you previously identified.

For example, if the device names *hdisk4*, *hdisk5*, and *hdisk6* correspond to database disks, include them in the database volume group and so on.

System size: The following commands are based on the medium system configuration. For small and large systems, you must adjust the syntax as required.

```
mkvg -S -y tsmdb hdisk2 hdisk3 hdisk4
mkvg -S -y tsmactlog hdisk5
mkvg -S -y tsmarchlog hdisk6
mkvg -S -y tsmdbback hdisk7 hdisk8 hdisk9 hdisk10
mkvg -S -y tsmstgpool hdisk11 hdisk12 hdisk13 hdisk14 ... hdisk49
```

3. Determine the physical volume names and the number of free physical partitions to use when you create logical volumes. Issue the **lsvg** for each volume group that you created in the previous step.

For example:

```
lsvg -p tsmdb
```

The output is similar to the following. The *FREE PPs* column represents the free physical partitions:

```
tsmdb:
PV_NAME  PV STATE  TOTAL PPs  FREE PPs  FREE DISTRIBUTION
hdisk4   active    1631      1631      327..326..326..326..326
hdisk5   active    1631      1631      327..326..326..326..326
hdisk6   active    1631      1631      327..326..326..326..326
```

4. Create logical volumes in each volume group by using the **mklv** command. The volume size, volume group, and device names vary, depending on the size of your system and variations in your disk configuration.

For example, to create the volumes for the IBM Spectrum Protect database on a medium system, issue the following commands:

```
mklv -y tsmdb00 -t jfs2 -u 1 -x 1631 tsmdb 1631 hdisk2
mklv -y tsmdb01 -t jfs2 -u 1 -x 1631 tsmdb 1631 hdisk3
mklv -y tsmdb02 -t jfs2 -u 1 -x 1631 tsmdb 1631 hdisk4
```

5. Format file systems in each logical volume by using the **crfs** command.

For example, to format file systems for the database on a medium system, issue the following commands:

```
crfs -v jfs2 -d tsmdb00 -p rw -a logname=INLINE -a options=rbrw
-a agblksize=4096 -m /tsminst1/TSMdbspace00 -A yes
crfs -v jfs2 -d tsmdb01 -p rw -a logname=INLINE -a options=rbrw
-a agblksize=4096 -m /tsminst1/TSMdbspace01 -A yes
crfs -v jfs2 -d tsmdb02 -p rw -a logname=INLINE -a options=rbrw
-a agblksize=4096 -m /tsminst1/TSMdbspace02 -A yes
```

6. Mount all of the newly created file systems by issuing the following command:

```
mount -a
```

7. List all file systems by issuing the **df** command.

Verify that file systems are mounted at the correct LUN and correct mount point. Also, verify the available space.

The following example of command output shows that the amount of used space is typically 1%:

```
tapsrv07> df -g /tsminst1/*
Filesystem      GB blocks  Free    %Used  Iused  %Iused  Mounted on
/dev/tsmact00   195.12    194.59  1%      4      1%      /tsminst1/TSMalog
```

8. Verify that the user ID you created in [“Creating the user ID for the server”](#) on page 31 has read and write access to the directories for the server.

Linux systems

You must format ext4 or xfs file systems on each of the disk LUNs to be used by the IBM Spectrum Protect server.

Procedure

1. Using the list of device IDs that you generated previously, issue the **mkfs** command to create and format a file system for each storage LUN device. Specify the device ID in the command. See the following examples.

For the database, format ext4 file systems:

```
mkfs -t ext4 -T largefile -m 2 /dev/mapper/36005076802810c50980000000000012
```

For storage pool LUNs, format xfs file systems:

```
mkfs -t xfs /dev/mapper/3600507630081010578000000000002c3
```

You might issue the **mkfs** command as many as 50 times, depending on how many different devices you have.

2. Create mount point directories for file systems.

Issue the **mkdir** command for each directory that you must create. Use the directory values that you recorded in the planning worksheets.

For example, to create the server instance directory by using the default value, issue the following command:

```
mkdir /tsminst1
```

Repeat the **mkdir** command for each file system.

3. Add an entry in the `/etc/fstab` file for each file system so that file systems are mounted automatically when the server is started.

For example:

```
/dev/mapper/36005076802810c50980000000000012 /tsminst1/TSMdbspace00 ext4
defaults 0 0
```

4. Mount the file systems that you added to the `/etc/fstab` file by issuing the **mount -a** command.
5. List all file systems by issuing the **df** command.

Verify that file systems are mounted at the correct LUN and correct mount point. Also, verify the available space.

The following example on an IBM Storwize system shows that the amount of used space is typically 1%:

```
[root@tapsrv04 ~]# df -h /tsminst1/*
Filesystem                                Size  Used Avail Use% Mounted on
/dev/mapper/36005076300810105780000000000003 134G  188M 132G  1%  /tsminst1/
TSMalog
```

6. Verify that the user ID you created in [“Creating the user ID for the server” on page 31](#) has read and write access to the directories for the IBM Spectrum Protect server.

Windows systems

You must format New Technology File System (NTFS) file systems on each of the disk LUNs to be used by the IBM Spectrum Protect server.

Procedure

1. Create mount point directories for file systems.

Issue the **md** command for each directory that you must create. Use the directory values that you recorded in the planning worksheets. For example, to create the server instance directory by using the default value, issue the following command:

```
md c:\tsminst1
```

Repeat the **md** command for each file system.

2. Create a volume for every disk LUN that is mapped to a directory under the server instance directory by using the Windows volume manager.

Go to **Server Manager > File and Storage Services** and complete the following steps for each disk that corresponds to the LUN mapping that was created in the previous step:

- a) Bring the disk online.
- b) Initialize the disk to the GPT basic type, which is the default.
- c) Create a simple volume that occupies all of the space on the disk. Format the file system by using NTFS, and assign a label that matches the purpose of the volume, such as TSMfile00. Do not assign the new volume to a drive letter. Instead, map the volume to a directory under the instance directory, such as C:\tsminst1\TSMfile00.

Tip: Determine the volume label and directory mapping labels based on the size of the disk that is reported.

3. Verify that file systems are mounted at the correct LUN and correct mount point. List all file systems by issuing the **mountvol** command and then review the output.
For example:

```
\\?\Volume{8ffb9678-3216-474c-a021-20e420816a92}\  
C:\tsminst1\TSMdbspace00\
```

4. After the disk configuration is complete, restart the system.

What to do next

You can confirm the amount of free space for each volume by using Windows Explorer.

Installing the server and Operations Center

Use the IBM Installation Manager graphical wizard to install the components.

Installing on AIX and Linux systems

Install the IBM Spectrum Protect server and the Operations Center on the same system.

Before you begin

Verify that the operating system is set to the language that you require. By default, the language of the operating system is the language of the installation wizard.

Procedure

1. **AIX**
Verify that the required RPM files are installed on your system.
See “Installing prerequisite RPM files for the graphical wizard” on page 36 for details.
2. Before you download the installation package, verify that you have enough space to store the installation files when they are extracted from the product package.
For space requirements, see the download document at [technote 588093](#).
3. Go to [Passport Advantage®](#) and download the package file to an empty directory of your choice.

4. Ensure that executable permission is set for the package. If necessary, change the file permissions by issuing the following command:

```
chmod a+x package_name.bin
```

5. Extract the package by issuing the following command:

```
./package_name.bin
```

where *package_name* is the name of the downloaded file.

6. **AIX**

6. Ensure that the following command is enabled so that the wizards work properly:

```
lsuser
```

By default, the command is enabled.

7. Change to the directory where you placed the executable file.
8. Start the installation wizard by issuing the following command:

```
./install.sh
```

When you select the packages to install, choose both the server and Operations Center.

What to do next

- If errors occur during the installation process, the errors are recorded in log files that are stored in the IBM Installation Manager logs directory.

To view installation log files from the Installation Manager tool, click **File > View Log**. To collect these log files from the Installation Manager tool, click **Help > Export Data for Problem Analysis**.

- After you install the server and before you customize it for your use, go to the [IBM Spectrum Protect support site](#). Click **Support and downloads** and apply any applicable fixes.

Related information

[AIX: installing the server components](#)

[Linux: installing the server components](#)

AIX Installing prerequisite RPM files for the graphical wizard

RPM files are required for the IBM Installation Manager graphical wizard.

Procedure

1. Verify that the following files are installed on your system. If the files are not installed, go to Step 2.

```
atk-1.12.3-2.aix5.2.ppc.rpm          libpng-1.2.32-2.aix5.2.ppc.rpm
cairo-1.8.8-1.aix5.2.ppc.rpm        libtiff-3.8.2-1.aix5.2.ppc.rpm
expat-2.0.1-1.aix5.2.ppc.rpm        pango-1.14.5-4.aix5.2.ppc.rpm
fontconfig-2.4.2-1.aix5.2.ppc.rpm   pixman-0.12.0-3.aix5.2.ppc.rpm
freetype2-2.3.9-1.aix5.2.ppc.rpm    xcursor-1.1.7-3.aix5.2.ppc.rpm
gettext-0.10.40-6.aix5.1.ppc.rpm    xft-2.1.6-5.aix5.1.ppc.rpm
glib2-2.12.4-2.aix5.2.ppc.rpm       xrender-0.9.1-3.aix5.2.ppc.rpm
gtk2-2.10.6-4.aix5.2.ppc.rpm        zlib-1.2.3-3.aix5.1.ppc.rpm
libjpeg-6b-6.aix5.1.ppc.rpm
```

2. Ensure that there is at least 150 MB of free space in the /opt file system.
3. From the directory where the installation package file is extracted, go to the g_tk directory.
4. Download the RPM files to the current working directory from the [IBM AIX Toolbox for Linux Applications website](#) by issuing the following command:

```
download-prerequisites.sh
```

5. From the directory that contains the RPM files that you downloaded, install them by issuing the following command:

```
rpm -Uvh *.rpm
```

Installing on Windows systems

Install the IBM Spectrum Protect server and the Operations Center on the same system.

Before you begin

Make sure that the following prerequisites are met:

- Verify that the operating system is set to the language that you require. By default, the language of the operating system is the language of the installation wizard.
- Ensure that the user ID that you plan to use during the installation is a user with local Administrator authority.

Procedure

1. Before you download the installation package, verify that you have enough space to store the installation files when they are extracted from the product package.
For space requirements, see the download document at [technote 588095](#).
2. Go to [Passport Advantage](#) and download the package file to an empty directory of your choice.
3. Change to the directory where you placed the executable file.
4. Double-click the executable file to extract to the current directory.
5. In the directory where the installation files were extracted, start the installation wizard by double-clicking the `install.bat` file.

When you select the packages to install, choose both the server and Operations Center.

What to do next

- If errors occur during the installation process, the errors are recorded in log files that are stored in the IBM Installation Manager logs directory.

To view installation log files from the Installation Manager tool, click **File > View Log**. To collect these log files from the Installation Manager tool, click **Help > Export Data for Problem Analysis**.

- After you install the server and before you customize it for your use, go to the [IBM Spectrum Protect support site](#). Click **Support and downloads** and apply any applicable fixes.

Related information

[Windows: installing the server components](#)

Configuring the server and the Operations Center

After you install the components, complete the configuration for the IBM Spectrum Protect server and the Operations Center.

Configuring the server instance

Use the IBM Spectrum Protect server instance configuration wizard to complete the initial configuration of the server.

Before you begin

Ensure that the following requirements are met:

- The system where you installed IBM Spectrum Protect must have the X Window System client. You must also be running an X Window System server on your desktop.
- The system must have the Secure Shell (SSH) protocol enabled. Ensure that the port is set to the default value, 22, and that the port is not blocked by a firewall. You must enable password authentication in the `sshd_config` file in the `/etc/ssh/` directory. Also, ensure that the SSH daemon service has access rights to connect to the system by using the `localhost` value.
- You must be able to log in to IBM Spectrum Protect with the user ID that you created for the server instance, by using the SSH protocol. When you use the wizard, you must provide this user ID and password to access that system.
- If you changed any settings in the preceding steps, restart the server before you proceed with the configuration wizard.

Windows Verify that the remote registry service is started by completing the following steps:

1. Click **Start > Administrative Tools > Services**. In the **Services** window, select **Remote Registry**. If it is not started, click **Start**.
2. Ensure that port 137, 139, and 445 are not blocked by a firewall:
 - a. Click **Start > Control Panel > Windows Firewall**.
 - b. Select **Advanced Settings**.
 - c. Select **Inbound Rules**.
 - d. Select **New Rule**.
 - e. Create a port rule for TCP ports 137, 139, and 445 to allow connections for domain and private networks.
3. Configure the user account control by accessing the local security policy options and completing the following steps.
 - a. Click **Start > Administrative Tools > Local Security Policy**. Expand **Local Policies > Security Options**.
 - b. If not already enabled, enable the built-in administrator account by selecting **Accounts: Administrator account status > Enable > OK**.
 - c. If not already disabled, disable user account control for all Windows administrators by selecting **User Account Control: Run all administrators in Admin Approval Mode > Disable > OK**.
 - d. If not already disabled, disable the User Account Control for the built-in Administrator account by selecting **User Account Control: Admin Approval Mode for the Built-in Administrator Account > Disable > OK**.
4. If you changed any settings in the preceding steps, restart the server before you proceed with the configuration wizard.

About this task

The wizard can be stopped and restarted, but the server is not operational until the entire configuration process is complete.

Procedure

1. Start the local version of the wizard.
 - **Linux | AIX** Open the `dsmicfgx` program in the `/opt/tivoli/tsm/server/bin` directory. This wizard can be only run as a root user.
 - **Windows** Click **Start > All Programs > IBM Spectrum Protect > Configuration Wizard**.
2. Follow the instructions to complete the configuration.

Use the information that you recorded in “[Planning worksheets](#)” on page 5 during IBM Spectrum Protect system set up to specify directories and options in the wizard.

Linux | AIX On the **Server Information** window, set the server to start automatically by using the instance user ID when the system boots.

Windows By using the configuration wizard, the server is set to start automatically when rebooted.

Installing the backup-archive client

As a best practice, install the IBM Spectrum Protect backup-archive client on the server system so that the administrative command-line client and scheduler are available.

Procedure

- To install the backup-archive client, follow the installation instructions for your operating system.
 - [Install UNIX and Linux backup-archive clients](#)
 - [Installing the Windows client for the first time](#)

Setting options for the server

Review the server options file that is installed with the IBM Spectrum Protect server to verify that the correct values are set for your system.

Procedure

1. Go to the server instance directory and open the `dsmserv.opt` file.
2. Review the values in the following table and verify your server option settings, based on system size.

Server option	Small system value	Medium system value	Large system value
ACTIVELOGDIRECTORY	Directory path that was specified during configuration	Directory path that was specified during configuration	Directory path that was specified during configuration
ACTIVELOGSIZE	131072	131072	262144
ARCHLOGCOMPRESS	Yes	No	No
ARCHLOGDIRECTORY	Directory path that was specified during configuration	Directory path that was specified during configuration	Directory path that was specified during configuration
COMMMETHOD	TCPIP	TCPIP	TCPIP
COMMTIMEOUT	3600	3600	3600
DEDUPREQUIRESBACKUP	No	No	No
DEVCONFIG	devconf.dat	devconf.dat	devconf.dat
EXPINTERVAL	0	0	0
IDLETIMEOUT	60	60	60
MAXSESSIONS	250	500	1000
NUMOPENVOLSALLOWED	20	20	20
TCPADMINPORT	1500	1500	1500
TCPPORT	1500	1500	1500
VOLUMEHISTORY	volhist.dat	volhist.dat	volhist.dat

Update server option settings if necessary, to match the values in the table. To make updates, close the `dsmseiv.opt` file and use the **SETOPT** command from the administrative command-line interface to set the options.

For example, to update the `IDLETIMEOUT` option to 60, issue the following command:

```
setopt idletimeout 60
```

3. If any server option values must be updated, edit the `dsmseiv.opt` file by using the following guidelines:

- Remove the asterisk at the beginning of a line to enable an option.
- On each line, enter only one option and the specified value for the option.
- If an option occurs in multiple entries in the file, the server uses the last entry.

Save your changes and close the file. If you edit the `dsmseiv.opt` file directly, you must restart the server for the changes to take effect.

Related information

[Server options reference](#)

[SETOPT \(Set a server option for dynamic update\)](#)

Configuring secure communications with Transport Layer Security

To encrypt data and secure communications in your environment, Secure Sockets Layer (SSL) or Transport Layer Security (TLS) is enabled on the IBM Spectrum Protect server and backup-archive client. An SSL certificate is used to verify communication requests between the server and client.

About this task

As shown in the following figure, you can manually configure secure communications between the server and backup-archive client by setting options in the server and client options files, and then transferring the self-signed certificate that is generated on the server to the client. Alternatively, you can obtain and transfer a unique certificate that is signed by a certificate authority (CA).



For more information about configuring the server and clients for SSL or TLS communications, see [Configuring storage agents, servers, clients, and the Operations Center to connect to the server by using SSL](#).

Configuring the Operations Center

After you install the Operations Center, complete the following configuration steps to start managing your storage environment.

Before you begin

When you connect to the Operations Center for the first time, you must provide the following information:

- Connection information for the server that you want to designate as a hub server
- Login credentials for an administrator ID that is defined for that server

Procedure

1. Designate the hub server.

In a web browser, enter the following address:

```
https://hostname:secure_port/oc
```

where:

- *hostname* represents the name of the computer where the Operations Center is installed
- *secure_port* represents the port number that the Operations Center uses for HTTPS communication on that computer

For example, if your host name is `tsm.storage.mylocation.com` and you are using the default secure port for the Operations Center, which is 11090, the address is:

```
https://tsm.storage.mylocation.com:11090/oc
```

When you log in to the Operations Center for the first time, a wizard guides you through an initial configuration to set up a new administrator with system authority on the server.

2. Set up secure communications between the Operations Center and the hub server by configuring the Secure Sockets Layer (SSL) protocol.

Follow the instructions in [“Securing communications between the Operations Center and the hub server”](#) on page 41.

3. Optional: To receive a daily email report that summarizes system status, configure your email settings in the Operations Center.

Follow the instructions in [“Tracking system status by using email reports”](#) on page 68.

Securing communications between the Operations Center and the hub server

To secure communications between the Operations Center and the hub server, add the Transport Layer Security (TLS) certificate of the hub server to the truststore file of the Operations Center.

Before you begin

The truststore file of the Operations Center is a container for certificates that the Operations Center can access. It contains the certificate that the Operations Center uses for HTTPS communication with web browsers.

During the installation of the Operations Center, you create a password for the truststore file. To secure communication between the Operations Center and the hub server, you must use the same password to add the certificate of the hub server to the truststore file. If you do not remember this password, you can reset it.

The following figure illustrates the components for setting up SSL between the Operations Center and the hub server.



About this task

This procedure provides steps to implement secure communications by using self-signed certificates.

Procedure

To set up SSL communication by using self-signed certificates, complete the following steps.

1. Specify the `cert256.arm` certificate as the default certificate in the key database file of the hub server:

- a) Issue the following command from the hub server instance directory:

```
gsk8capicmd_64 -cert -setdefault -db cert.kdb -stashed  
-label "TSM Server SelfSigned SHA Key"
```

- b) Restart the hub server so that it can receive the changes to the key database file.
- c) Verify that the `cert256.arm` certificate is set as the default. Issue the following command:

```
gsk8capicmd_64 -cert -list -db cert.kdb -stashed
```

2. Stop the Operations Center web server.
3. Open the operating system command line on the system where the Operations Center is installed, and change to the following directory:

- **Linux** | **AIX** `installation_dir/ui/jre/bin`
- **Windows** `installation_dir\ui\jre\bin`

Where `installation_dir` represents the directory in which the Operations Center is installed.

4. Open the IBM Key Management window by issuing the following command:

```
ikeyman
```

5. Click **Key Database File > Open**.
6. Click **Browse**, and go to the following directory, where `installation_dir` represents the directory in which the Operations Center is installed:
 - **Linux** | **AIX** `installation_dir/ui/Liberty/usr/servers/guiServer`
 - **Windows** `installation_dir\ui\Liberty\usr\servers\guiServer`
7. In the `guiServer` directory, select the `gui-truststore.jks` file.
8. Click **Open**, and click **OK**.
9. Enter the password for the truststore file, and click **OK**.
10. In the Key database content area of the IBM Key Management window, click the arrow, and select **Signer Certificates** from the list. Click **Add**.
11. In the Open window, click **Browse**, and go to the hub server instance directory:

- **Linux** | **AIX** `/opt/tivoli/tsm/server/bin`
- **Windows** `c:\Program Files\Tivoli\TSM\server1`

The directory contains the `cert256.arm` certificate.

If you cannot access the hub server instance directory from the Open window, complete the following steps:

- a) Use FTP or another file-transfer method to copy the `cert256.arm` files from the hub server to the following directory on the computer where the Operations Center is installed:

- **Linux** | **AIX** `installation_dir/ui/Liberty/usr/servers/guiServer`
- **Windows** `installation_dir\ui\Liberty\usr\servers\guiServer`

- b) In the Open window, go to the `guiServer` directory.

12. Select the `cert256.arm` certificate as the SSL certificate.
13. Click **Open**, and click **OK**.
14. Enter a label for the certificate. For example, enter the name of the hub server.

15. Click **OK**. The SSL certificate of the hub server is added to the truststore file, and the label is displayed in the Key database content area of the IBM Key Management window.
16. Close the IBM Key Management window.
17. Start the Operations Center web server.

When you connect to the Operations Center for the first time, you are prompted to identify the IP address or network name of the hub server, and the port number for communicating with the hub server. If the ADMINONCLIENTPORT server option is enabled for the IBM Spectrum Protect server, enter the port number that is specified by the TCPADMINPORT server option. If the ADMINONCLIENTPORT server option is not enabled, enter the port number that is specified by the TCPPORT server option.

Related tasks

[Starting and stopping the web server](#)

The web server of the Operations Center runs as a service and starts automatically. You might have to stop and start the web server, for example, to make configuration changes.

Registering the product license

To register your license for the IBM Spectrum Protect product, use the **REGISTER LICENSE** command.

About this task

Licenses are stored in enrollment certificate files, which contain licensing information for the product. The enrollment certificate files are on the installation media, and are placed on the server during installation. When you register the product, the licenses are stored in a NODELOCK file within the current directory.

Procedure

Register a license by specifying the name of the enrollment certificate file that contains the license. To use the Operations Center command builder for this task, complete the following steps.

1. Open the Operations Center.
2. Open the Operations Center command builder by hovering over the settings icon  and clicking **Command Builder**.
3. Issue the **REGISTER LICENSE** command.

For example, to register a base IBM Spectrum Protect license, issue the following command:

```
register license file=tsmbasic.lic
```

What to do next

Save the installation media that contains your enrollment certificate files. You might need to register your license again if, for example, one of the following conditions occur:

- The server is moved to a different computer.
- The NODELOCK file is corrupted. The server stores license information in the NODELOCK file, which is in the directory from which the server is started.
- **Linux** If you change the processor chip that is associated with the server on which the server is installed.

Related information

[REGISTER LICENSE \(Register a new license\)](#)

Configuring data deduplication

Create a directory-container storage pool and at least one directory to use inline data deduplication.

Before you begin

Use the storage pool directory information that you recorded in [“Planning worksheets” on page 5](#) for this task.

Procedure

1. Open the Operations Center.
2. On the Operations Center menu bar, hover over **Storage**.
3. From the list that is displayed, click **Storage Pools**.
4. Click the **+Storage Pool** button.
5. Complete the steps in the **Add Storage Pool** wizard:
 - To use inline data deduplication, select a **Directory** storage pool under Container-based storage.
 - When you configure directories for the directory-container storage pool, specify the directory paths that you created for storage during system setup.
6. After you configure the new directory-container storage pool, click **Close & View Policies** to update a management class and start using the storage pool.

Defining data retention rules for your business

After you create a directory-container storage pool for data deduplication, update the default server policy to use the new storage pool. The **Add Storage Pool** wizard opens the **Services** page in the Operations Center to complete this task.

Procedure

1. On the **Services** page of the Operations Center, select the STANDARD domain and click **Details**.
2. On the **Summary** page for the policy domain, click the **Policy Sets** tab.

The **Policy Sets** page indicates the name of the active policy set and lists all of the management classes for that policy set.
3. Click the **Configure** toggle, and make the following changes:
 - Change the backup destination for the STANDARD management class to the directory-container storage pool.
 - Change the value for the Backups column to **No limit**.
 - Change the retention period. Set the Keep Extra Backups column to 30 days or more, depending on your business requirements.
4. Save your changes and click the **Configure** toggle again so that the policy set is no longer editable.
5. Activate the policy set by clicking **Activate**.

Defining schedules for server maintenance activities

Create schedules for each server maintenance operation by using the **DEFINE SCHEDULE** command in the Operations Center command builder.

About this task

Schedule server maintenance operations to run after client backup operations. You can control the timing of schedules by setting the start time in combination with the duration time for each operation.

The following example shows how you can schedule server maintenance operations in combination with the client backup schedule for a single-site disk solution.

Operation	Schedule
Client backup	Starts at 22:00.
Processing for database and disaster recovery files	<ul style="list-style-type: none"> The database backup operation starts at 11:00, or 13 hours after the beginning of the client backup operation. This process runs until completion. Device configuration information and volume history backup operations start at 17:00, or 6 hours after the start of the database backup operation. Volume history deletion starts at 20:00, or 9 hours after the start of the database backup operation.
Inventory expiration	Starts at 12:00, or 14 hours after the beginning of the client backup operation. This process runs until completion.

Procedure

After you configure the device class for the database backup operations, create schedules for database backup and other required maintenance operations by using the **DEFINE SCHEDULE** command. Depending on the size of your environment, you might need to adjust the start times for each schedule in the example.

1. Define a device class for the backup operations.

For example, use the **DEFINE DEVCLASS** command to create a device class that is named `DBBACK_FILEDEV`:

```
define devclass dback_filedev devtype=file
    directory=db_backup_directories
```

where `db_backup_directories` is a list of the directories that you created for the database backup.

Linux | AIX For example, if you have four directories for database backups, starting with `/tsminst1/TSMbkup00`, issue the following command:

```
define devclass dback_filedev devtype=file
    directory=/tsminst1/TSMbkup00,
    /tsminst1/TSMbkup01,/tsminst1/TSMbkup02,
    /tsminst1/TSMbkup03"
```

Windows For example, if you have four directories for database backups, starting with `C:\tsminst1\TSMbkup00`, issue the following command:

```
define devclass dback_filedev devtype=file
    directory="c:\tsminst1\TSMbkup00,
    c:\tsminst1\TSMbkup01,c:\tsminst1\TSMbkup02,
    c:\tsminst1\TSMbkup03"
```

2. Set the device class for automatic database backup operations. Use the **SET DBRECOVERY** command to specify the device class that you created in the preceding step.

For example, if the device class is `dback_filedev`, issue the following command:

```
set dbrecovery dback_filedev
```

3. Create schedules for the maintenance operations by using the **DEFINE SCHEDULE** command. See the following table for the required operations with examples of the commands.

Operation	Example command
Back up the database.	<p>Create a schedule to run the BACKUP DB command. If you are configuring a small system, set the COMPRESS parameter to YES.</p> <p>For example, on a small system, issue the following command to create a backup schedule that uses the new device class:</p> <pre data-bbox="609 346 1468 451">define schedule DBBACKUP type=admin cmd="backup db devclass=dbback_filedev type=full numstreams=3 wait=yes compress=yes" active=yes desc="Back up the database." startdate=today starttime=11:00:00 duration=45 durunits=minutes</pre>
Back up the device configuration information.	<p>Create a schedule to run the BACKUP DEVCONFIG command:</p> <pre data-bbox="609 569 1417 667">define schedule DEVCONFIGBKUP type=admin cmd="backup devconfig filenames=devconfig.dat" active=yes desc="Backup the device configuration file." startdate=today starttime=17:00:00 duration=45 durunits=minutes</pre>
Back up the volume history.	<p>Create a schedule to run the BACKUP VOLHISTORY command:</p> <pre data-bbox="609 789 1403 888">define schedule VOLHISTBKUP type=admin cmd="backup volhistory filenames=volhist.dat" active=yes desc="Back up the volume history." startdate=today starttime=17:00:00 duration=45 durunits=minutes</pre>
Remove older versions of database backups that are no longer required.	<p>Create a schedule to run the DELETE VOLHISTORY command:</p> <pre data-bbox="609 1010 1403 1108">define schedule DELVOLHIST type=admin cmd="delete volhistory type=dbb todate=today-6 totime=now" active=yes desc="Remove old database backups." startdate=today starttime=20:00:00 duration=45 durunits=minutes</pre>
Remove objects that exceed their allowed retention.	<p>Create a schedule to run the EXPIRE INVENTORY command.</p> <p>Set the RESOURCE parameter based on the system size that you are configuring:</p> <ul data-bbox="609 1268 878 1388" style="list-style-type: none"> • Small systems: 10 • Medium systems: 30 • Large systems: 40 <p>For example, on a medium-sized system, issue the following command to create a schedule that is named EXPINVENTORY:</p> <pre data-bbox="609 1493 1403 1612">define schedule EXPINVENTORY type=admin cmd="expire inventory wait=yes resource=30 duration=120" active=yes desc="Remove expired objects." startdate=today starttime=12:00:00 duration=45 durunits=minutes</pre>

What to do next

After you create schedules for the server maintenance tasks, you can view them in the Operations Center by completing the following steps:

1. On the Operations Center menu bar, hover over **Servers**.
2. Click **Maintenance**.

Related information

[DEFINE SCHEDULE \(Define a schedule for an administrative command\)](#)

Defining client schedules

Use the Operations Center to create schedules for client operations.

Procedure

1. On the Operations Center menu bar, hover over **Clients**.
2. Click **Schedules**.
3. Click **+Schedule**.
4. Complete the steps in the **Create Schedule** wizard.

Set client backup schedules to start at 22:00, based on the server maintenance activities that you scheduled in [“Defining schedules for server maintenance activities”](#) on page 44.

Installing and configuring backup-archive clients

Following the successful setup of your IBM Spectrum Protect server system, install and configure client software to begin backing up data.

Procedure

- To install the backup-archive client, follow the installation instructions for your operating system.
 - [Install UNIX and Linux backup-archive clients](#)
 - [Installing the Windows client for the first time](#)

What to do next

Register and assign your clients to schedules.

Registering and assigning clients to schedules

Add and register your clients through the Operations Center by using the **Add Client** wizard.

Before you begin

Determine whether the client requires an administrative user ID with client owner authority over the client node. To determine which clients require an administrative user ID, see [technote 7048963](#).

Restriction: For some types of clients, the client node name and the administrative user ID must match. You cannot authenticate those clients by using the Lightweight Directory Access Protocol authentication method that was introduced in V7.1.7. For details about this authentication method, sometimes referred to as integrated mode, see [Authenticating users by using an Active Directory database](#).

Procedure

To register a client, complete one of the following actions.

- If the client requires an administrative user ID, register the client by using the **REGISTER NODE** command and specify the **USERID** parameter:

```
register node node_name password userid=node_name
```

where *node_name* specifies the node name and *password* specifies the node password. For details, see [Register a node](#).

- If the client does not require an administrative user ID, register the client by using the Operations Center Add Client wizard. Complete the following steps:
 - a. On the Operations Center menu bar, click **Clients**.
 - b. In the Clients table, click **+Client**.

c. Complete the steps in the **Add Client** wizard:

- 1) Specify that redundant data can be eliminated on both the client and server. In the Client-side data deduplication area, select the **Enable** check box.
- 2) In the **Configuration** window, copy the **TCPSERVERADDRESS**, **TCPPORT**, **NODENAME**, and **DEDUPLICATION** option values.

Tip: Record the option values and keep them in a safe place. After you complete the client registration and install the software on the client node, use the values to configure the client.

- 3) Follow the instructions in the wizard to specify the policy domain, schedule, and option set.
- 4) Set how risks are displayed for the client by specifying the at-risk setting.
- 5) Click **Add Client**.

Installing the client management service

Install the client management service for backup-archive clients that run on Linux and Windows operating systems. The client management service collects diagnostic information about backup-archive clients and makes the information available to the Operations Center for basic monitoring capability.

Procedure

Install the client management service on the same computer as the backup-archive client by completing the following steps:

1. Download the installation package for the client management service from an IBM download site such as IBM Passport Advantage® or IBM Fix Central. Look for a file name that is similar to `<version>-IBM_Spectrum_Protect-CMS-operating_system.bin`.
2. Create a directory on the client system that you want to manage, and copy the installation package there.
3. Extract the contents of the installation package file.
4. Run the installation batch file from the directory where you extracted the installation and associated files. This is the directory that you created in step 2.
5. To install the client management service, follow the instructions in the IBM Installation Manager wizard.

If IBM Installation Manager is not already installed on the client system, you must select both IBM Installation Manager and IBM Spectrum Protect Client Management Services.

Related information

[Configuring the client management service for custom client installations](#)

Verifying that the client management service is installed correctly

Before you use the client management service to collect diagnostic information about a backup-archive client, you can verify that the client management service is correctly installed and configured.

Procedure

On the client system, at the command line, run the following commands to view the configuration of the client management service:

- On Linux client systems, issue the following command:

```
client_install_dir/cms/bin/CmsConfig.sh list
```

where `client_install_dir` is the directory where the backup-archive client is installed. For example, with the default client installation, issue the following command:

```
/opt/tivoli/tsm/cms/bin/CmsConfig.sh list
```

The output is similar to the following text:

Listing CMS configuration

```
server1.example.com:1500 NO_SSL HOSTNAME
Capabilities: [LOG_QUERY]
  Opt Path: /opt/tivoli/tsm/client/ba/bin/dsm.sys

  Log File: /opt/tivoli/tsm/client/ba/bin/dsmerror.log
            en_US MM/dd/yyyy HH:mm:ss Windows-1252

  Log File: /opt/tivoli/tsm/client/ba/bin/dsmsched.log
            en_US MM/dd/yyyy HH:mm:ss Windows-1252
```

- On Windows client systems, issue the following command:

```
client_install_dir\cms\bin\CmsConfig.bat list
```

where *client_install_dir* is the directory where the backup-archive client is installed. For example, with the default client installation, issue the following command:

```
C:\Program Files\Tivoli\TSM\cms\bin\CmsConfig.bat list
```

The output is similar to the following text:

Listing CMS configuration

```
server1.example.com:1500 NO_SSL HOSTNAME
Capabilities: [LOG_QUERY]
  Opt Path: C:\Program Files\Tivoli\TSM\baclient\dsm.opt

  Log File: C:\Program Files\Tivoli\TSM\baclient\dsmerror.log
            en_US MM/dd/yyyy HH:mm:ss Windows-1252

  Log File: C:\Program Files\Tivoli\TSM\baclient\dsm Sched.log
            en_US MM/dd/yyyy HH:mm:ss Windows-1252
```

If the client management service is correctly installed and configured, the output displays the location of the error log file.

The output text is extracted from the following configuration file:

- On Linux client systems:

```
client_install_dir/cms/Liberty/usr/servers/cmsServer/client-configuration.xml
```

- On Windows client systems:

```
client_install_dir\cms\Liberty\usr\servers\cmsServer\client-configuration.xml
```

If the output does not contain any entries, you must configure the `client-configuration.xml` file. For instructions to configure this file, see [Configuring the client management service for custom client installations](#). You can use the **CmsConfig verify** command to verify that a node definition is correctly created in the `client-configuration.xml` file.

Configuring the Operations Center to use the client management service

If you did not use the default configuration for the client management service, you must configure the Operations Center to access the client management service.

Before you begin

Ensure that the client management service is installed and started on the client system. Verify whether the default configuration is used. The default configuration is not used if either of the following conditions is met:

- The client management service does not use the default port number, 9028.
- The backup-archive client is not accessed by the same IP address as the client system where the backup-archive client is installed. For example, a different IP address might be used in the following situations:

- The computer system has two network cards. The backup-archive client is configured to communicate on one network, while the client management service communicates on the other network.
- The client system is configured with the Dynamic Host Configuration Protocol (DHCP). As a result, the client system is dynamically assigned an IP address, which is saved on the server during the previous backup-archive client operation. When the client system is restarted, the client system might be assigned a different IP address. To ensure that the Operations Center can always find the client system, you specify a fully qualified domain name.

Procedure

To configure the Operations Center to use the client management service, complete the following steps:

1. On the Clients page of the Operations Center, select the client.
2. Click **Details > Properties**.
3. In the Remote diagnostics URL field in the General section, specify the URL for the client management service on the client system.

The address must start with `https`. The following table shows examples of the remote diagnostics URL.

Type of URL	Example
With DNS host name and default port, 9028	<code>https://server.example.com</code>
With DNS host name and non-default port	<code>https://server.example.com:1599</code>
With IP address and non-default port	<code>https://192.0.2.0:1599</code>

4. Click **Save**.

What to do next

You can access client diagnostic information such as client log files from the **Diagnosis** tab in the Operations Center.

Completing the implementation

After the IBM Spectrum Protect solution is configured and running, test backup operations and set up monitoring to ensure that everything runs smoothly.

Procedure

1. Test backup operations to verify that your data is protected in the way that you expect.
 - a) On the **Clients** page of the Operations Center, select the clients that you want to back up, and click **Back Up**.
 - b) On the **Servers** page of the Operations Center, select the server for which you want to back up the database. Click **Back Up**, and follow the instructions in the **Back Up Database** window.
 - c) Verify that the backup operations completed successfully with no warning or error messages.

Tip: Alternatively, you can use the backup-archive client GUI to back up client data and you can backup the server database by issuing **BACKUP DB** command from an administrative command-line.
2. Set up monitoring for your solution by following the instructions in [Part 3, “Monitoring a single-site disk solution,”](#) on page 51.

Part 3. Monitoring a single-site disk solution

After you implement a single-site disk solution, monitor the solution for correct operation. By monitoring the solution daily and periodically, you can identify existing and potential issues. The information that you gather can be used to troubleshoot problems and optimize system performance.

About this task

The preferred way to monitor a solution is by using the Operations Center, which provides overall and detailed system status in a graphical user interface. In addition, you can configure the Operations Center to generate a daily email report that summarizes system status.

In some cases, you might want to use advanced monitoring tools to complete specific monitoring or troubleshooting tasks.

Tip: If you plan to diagnose issues with backup-archive clients on Linux or Windows operating systems, install IBM Spectrum Protect client management services on each computer where a backup-archive client is installed. In this way, you can ensure that the **Diagnose** button is available in the Operations Center for diagnosing issues with backup-archive clients. To install the client management service, follow the instructions in [Installing the client management service](#).

Procedure

1. Complete daily monitoring tasks. For instructions, see [Daily monitoring checklist](#).
2. Complete periodic monitoring tasks. For instructions, see [Periodic monitoring checklist](#).
3. To verify that your IBM Spectrum Protect solution complies with licensing requirements, follow the instructions in [Verify license compliance](#).
4. To set up Operations Center to generate email status reports, see [Tracking system status by using email reports](#)

What to do next

Resolve any issues that you detect. To resolve an issue by changing the configuration of your solution, follow the instructions in [Part 4, “Managing operations for a single-site disk solution,” on page 69](#). The following resources are also available:


- To resolve performance issues, see [Performance](#).
- To resolve other types of issues, see [Troubleshooting](#).

Daily monitoring checklist

To ensure that you are completing the daily monitoring tasks for your IBM Spectrum Protect solution, review the daily monitoring checklist.

Complete the daily monitoring tasks from the Operations Center **Overview** page. You can access the **Overview** page by opening the Operations Center and clicking **Overviews**.

The following figure shows the location for completing each task.



Tip: To run administrative commands for advanced monitoring tasks, use the Operations Center command builder. The command builder provides a type-ahead function to guide you as you enter commands. To open the command builder, go to the Operations Center **Overview** page. On the menu bar, hover over the settings icon  and click **Command Builder**.

The following table lists the daily monitoring tasks and provides instructions for completing each task.

Table 15. Daily monitoring tasks

Task	Basic procedures	Advanced procedures and troubleshooting information
<p>Watch for security notifications, which can indicate a ransomware attack.</p>	<p>If a potential ransomware attack is detected in the IBM Spectrum Protect environment, a security notification message is displayed in the foreground of the Operations Center. For more information, click the message to open the Security Notifications page.</p>	<p>On the Security Notifications page, you can take the following actions:</p> <ul style="list-style-type: none"> • View notification details by client. <p>Restriction: Notifications are available only for backup-archive clients and IBM Spectrum Protect for Virtual Environments clients.</p> <ul style="list-style-type: none"> • Acknowledge a security notification by selecting it and clicking Acknowledge. When you acknowledge a security notification, a check mark is added to the Acknowledged column of the Security Notifications page for the selected client. The standard by which a notification is acknowledged is determined by your organization. A check mark might mean that you investigated the issue and determined that it is a false positive. Or it might mean that a problem exists and is being resolved. • Assign a security notification to an administrator by selecting the security notification and clicking Assign. To view the assignment, the administrator must sign in to the Operations Center and click Overviews > Security. If you are not certain whether the administrator regularly monitors the Security Notifications page, notify the administrator about the assignment. • If the notification is a false positive, you can select the security notification and click Reset. The security notification is deleted. Historical data that is used for baseline comparisons with the most recent backup operation is deleted. A new baseline is calculated going forward. • Optionally, you can disable security notifications by using the SET SECURITYNOTIF command.

Table 15. Daily monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting information
<p>1 Determine whether clients are at risk of being unprotected due to failed or missed backup operations.</p>	<p>To verify whether clients are at risk, in the Clients area, look for an At risk notification. To view details, click the Clients area.</p> <p> Attention: If the At risk percentage is much greater than usual, it might indicate a ransomware attack. A ransomware attack can cause backup operations to fail, thus placing clients at risk. For example, if the percentage of clients at risk is normally between 5% and 10%, but the percentage increases to 40% or 50%, investigate the cause.</p> <p>If you installed the client management service on a backup-archive client, you can view and analyze the client error and schedule logs by completing the following steps:</p> <ol style="list-style-type: none"> 1. In the Clients table, select the client and click Details. 2. To diagnose an issue, click Diagnosis. 	<p>For clients that do not have the client management service installed, access the client system to review the client error logs.</p>
<p>2 Determine whether client-related or server-related errors require attention.</p>	<p>To determine the severity of any reported alerts, in the Alerts area, hover over the columns.</p>	<p>To view additional information about alerts, complete the following steps:</p> <ol style="list-style-type: none"> 1. Click the Alerts area. 2. In the Alerts table, select an alert. 3. In the Activity Log pane, review the messages. The pane displays related messages that were issued before and after the selected alert occurred.
<p>3 Determine whether servers that are managed by the Operations Center are available to provide data protection services to clients.</p>	<ol style="list-style-type: none"> 1. To verify whether servers are at risk, in the Servers area, look for an Unavailable notification. 2. To view additional information, click the Servers area. 3. Select a server in the Servers table and click Details. 	<p>Tip: If you detect an issue that is related to server properties, update the server properties:</p> <ol style="list-style-type: none"> 1. In the Servers table, select a server and click Details. 2. To update server properties, click Properties.

Table 15. Daily monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting information
<p>4 Determine whether sufficient space is available for the server inventory, which consists of the server database, active log, and archive log.</p>	<ol style="list-style-type: none"> Click the Servers area. In the Status column of the table, view the status of the server and resolve any issues: <ul style="list-style-type: none"> Normal  Sufficient space is available for the server database, active log, and archive log. Critical  Insufficient space is available for the server database, active log, or archive log. You must add space immediately, or the data protection services that are provided by the server will be interrupted. Warning  The server database, active log, or archive log is running out of space. If this condition persists, you must add space. Unavailable  Status cannot be obtained. Ensure that the server is running, and that there are no network issues. This status is also shown if the monitoring administrator ID is locked or otherwise unavailable on the server. This ID is named IBM-OC-hub_server_name. Unmonitored  Unmonitored servers are defined to the hub server, but are not configured for management by the Operations Center. To configure an unmonitored server, select the server, and click Monitor Spoke. 	<p>You can also look for related alerts on the Alerts page. For additional instructions about troubleshooting, see Resolving server problems.</p>

Table 15. Daily monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting information
<p>5 Verify server database backup operations.</p>	<p>To determine when a server was most recently backed up, complete the following steps:</p> <ol style="list-style-type: none"> 1. Click the Servers area. 2. In the Servers table, review the Last Database Backup column. 	<p>To obtain more detailed information about backup operations, complete the following steps:</p> <ol style="list-style-type: none"> 1. In the Servers table, select a row and click Details. 2. In the DB Backup area, hover over the check marks to review information about backup operations. <p>If a database was not backed up recently (for example, in the last 24 hours), you can start a backup operation:</p> <ol style="list-style-type: none"> 1. On the Operations Center Overview page, click the Servers area. 2. In the table, select a server and click Back Up. <p>To determine whether the server database is configured for automatic backup operations, complete the following steps:</p> <ol style="list-style-type: none"> 1. On the menu bar, hover over the settings icon  and click Command Builder. 2. Issue the QUERY DB command: <div data-bbox="959 1073 1474 1129" style="background-color: #f0f0f0; padding: 5px; border: 1px solid #ccc;"> <pre>query db f=d</pre> </div> 3. In the output, review the Full Device Class Name field. If a device class is specified, the server is configured for automatic database backups.
<p>6 Monitor other server maintenance tasks. Server maintenance tasks can include running administrative command schedules, maintenance scripts, and related commands.</p>	<p>To search for information about processes that failed because of server issues, complete the following steps:</p> <ol style="list-style-type: none"> 1. Click Servers > Maintenance. 2. To obtain the two-week history of a process, view the History column. 3. To obtain more information about a scheduled process, hover over the checkbox that is associated with the process. 	<p>For more information about monitoring processes and resolving issues, see the Operations Center online help.</p>

Table 15. Daily monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting information
<p>7 Verify that the amount of data that was recently sent to and from servers is within the expected range.</p>	<ul style="list-style-type: none"> To obtain an overview of activity in the last 24 hours, view the Activity area. To compare activity in the last 24 hours with activity in the previous 24 hours, review the figures in the Current® and Previous areas. 	<ul style="list-style-type: none"> If more data was sent to the server than you expected, determine which clients are backing up more data and investigate the cause. It is possible that client-side data deduplication is not working correctly. <p> Attention: If the amount of backed-up data is significantly larger than usual, it might indicate a ransomware attack. When ransomware encrypts data, the system perceives the data as being changed, and the changed data is backed up. Thus, backup volumes become larger. To determine which clients are affected, click the Applications, Virtual Machines, or Systems tab.</p> If less data was sent to the server than you expected, investigate whether client backup operations are proceeding on schedule.

Table 15. Daily monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting information
<p>8 Verify that storage pools are available to back up client data.</p>	<p>1. If problems are indicated in the Storage & Data Availability area, click Pools to view the details:</p> <ul style="list-style-type: none"> • If the Critical  status is displayed, insufficient space is available in the storage pool, or its access status is unavailable. <p> Attention: If the status is critical, investigate the cause:</p> <ul style="list-style-type: none"> – If the data deduplication rate for a storage pool drops significantly, it might indicate a ransomware attack. During a ransomware attack, data is encrypted and cannot be deduplicated. To verify the data deduplication rate, in the Storage Pools table, review the value in the % Savings column. – If a storage pool unexpectedly becomes 100% utilized, it might indicate a ransomware attack. To verify the utilization, review the value in the Capacity Used column. Hover over the values to see the percentages of used and free space. <ul style="list-style-type: none"> • If the Warning  status is displayed, the storage pool is running out of space, or its access status is read-only. <p>2. To view the used, free, and total space for your selected storage pool, hover over the entries in the Capacity Used column.</p>	<p>To view the storage-pool capacity that was used over the past two weeks, select a row in the Storage Pools table and click Details.</p>

Table 15. Daily monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting information
<p>9 Verify that storage devices are available for backup operations.</p>	<p>In the Storage & Data Availability area, in the Volumes section, under the capacity bars, review the status that is reported next to Devices. If a Critical  or Warning  status is displayed for any device, investigate the issue. To view details, click Devices.</p>	<p>Disk devices might have a critical or warning status for the following reasons:</p> <ul style="list-style-type: none"> • For DISK device classes, volumes might be offline or have a read-only access status. The Disk Storage column of the Disk Devices table shows the state of volumes. • For FILE device classes that are not shared, directories might be offline. Also, insufficient free space might be available for allocating scratch volumes. The Disk Storage column of the Disk Devices table shows the state of directories. • For FILE device classes that are shared, drives might be unavailable. A drive is disabled if it is offline, if it stopped responding to the server, or if its path is offline. Other columns of the Disk Devices table show the state of the drives and paths.
<p>10 Monitor retention sets.</p>	<p>To obtain the overall status of retention sets, view the Retention Sets area on the Operations Center Overview page:</p> <ul style="list-style-type: none"> • The Completed field specifies the number of retention sets that were created in the server database and are tracked in the server inventory. • The Expired field specifies the number of retention sets whose data is expired. • The Deleted field specifies the number of retention sets that were deleted. <p>To view or modify retention rules, click Services > Retention Rules.</p>	<p>For more information about retention sets, click the Retention Sets area to open the Retention Sets page. To view or modify retention set properties, double-click a retention set.</p> <p>For more detailed information, you can run related commands:</p> <ol style="list-style-type: none"> 1. On the Operations Center Overview page, hover over the settings icon  and click Command Builder. 2. To determine which retention set creation jobs are running, interrupted, or completed, run the QUERY JOB command. For instructions, see QUERY JOB (Query a retention set creation job). 3. To query retention rules, run the QUERY RETRULE command. For instructions, see QUERY RETRULE (Query a retention rule). 4. To query retention sets, run the QUERY RETSET command. For instructions, see QUERY RETSET (Query a retention set). 5. To query retention set contents, run the QUERY RETSETCONTENTS command. For instructions, see QUERY RETSETCONTENTS (Query the contents of a retention set).

Table 15. Daily monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting information
<p>11 Monitor storage rules.</p>	<p>To obtain the overall status of storage rule operations, view the Storage Rules Overview page.</p>	<p>The status summary shows the most recent processing results for storage rules. The number of storage rules in each of the following states is shown:</p> <ul style="list-style-type: none">  Normal The number of storage rules that ran without errors.  Warning The number of storage rules that completed processing, but did not move or copy all eligible data. Either some files were skipped, the rule's time limit was reached, or the process was canceled.  Failed The number of storage rules that did not complete processing. For example, the server might fail to process data because the target storage pool has insufficient space or because the server cannot access the storage pool.  Other states The number of storage rules in other states. The server on which the storage rule is defined might be unavailable to provide the data, or might be running an earlier version of IBM Spectrum Protect that does not support status. Status might not be applicable because the storage rule was not activated or not run. <p>Tip: An icon is displayed only if one or more storage rules are in the corresponding state. To view more detailed information about each storage rule, click Storage Rules to open the Storage Rules page.</p>

Periodic monitoring checklist

To help ensure that your IBM Spectrum Protect solution operates correctly, complete the tasks in the periodic monitoring checklist. Schedule periodic tasks frequently enough so that you can detect potential issues before they become problematic.

Tip: To run administrative commands for advanced monitoring tasks, use the Operations Center command builder. The command builder provides a type-ahead function to guide you as you enter commands. To open the command builder, go to the Operations Center **Overview** page. On the menu bar, hover over the settings icon  and click **Command Builder**.

Table 16. Periodic monitoring tasks

Task	Basic procedures	Advanced procedures and troubleshooting
<p>Monitor system performance.</p>	<p>Determine the length of time that is required for client backup operations:</p> <ol style="list-style-type: none"> 1. On the Operations Center Overview page, click Clients. Find the server that is associated with the client. 2. Click Servers. Select the server and click Details. 3. To view the duration of completed tasks in the last 24 hours, click Completed Tasks. 4. To view the duration of tasks that were completed more than 24 hours ago, use the QUERY ACTLOG command. Follow the instructions in QUERY ACTLOG (Query the activity log). 5. If the duration of client backup operations is increasing and the reasons are not clear, investigate the cause. <p>If you installed the client management service on a backup-archive client, you can diagnose performance issues for the backup-archive client by completing the following steps:</p> <ol style="list-style-type: none"> 1. On the Operations Center Overview page, click Clients. 2. Select a backup-archive client and click Details. 3. To retrieve client logs, click Diagnosis. 	<p>For instructions about reducing the time that it takes for the client to back up data to the server, see Resolving common client performance problems.</p> <p>Look for performance bottlenecks. For instructions, see Identifying performance bottlenecks.</p> <p>For information about identifying and resolving other performance issues, see Performance.</p>

Table 16. Periodic monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting
<p>Determine the disk savings that are provided by data deduplication.</p>	<ol style="list-style-type: none"> 1. On the Operations Center Overview page, click Pools. 2. Select a pool and click Quick Look. 3. In the Data Deduplication area, view the Space saved row. 	<p>For advanced monitoring, to obtain detailed statistics about the data-deduplication process for a specific directory-container storage pool or cloud-container storage pool, complete the following steps:</p> <ol style="list-style-type: none"> 1. On the Operations Center Overview page, hover over the settings icon  and click Command Builder. 2. Obtain a statistical report by issuing the GENERATE DEDUPSTATS command. Follow the instructions in GENERATE DEDUPSTATS (Generate data deduplication statistics for a directory-container storage pool). 3. View the statistical report by issuing the QUERY DEDUPSTATS command. Follow the instructions in QUERY DEDUPSTATS (Query data deduplication statistics).
<p>Verify that current backup files for device configuration and volume history information are saved.</p>	<p>Access your storage locations to ensure that the files are available. The preferred method is to save the backup files to two locations.</p> <p>To locate the volume history and device configuration files, complete the following steps:</p> <ol style="list-style-type: none"> 1. On the Operations Center Overview page, hover over the settings icon  and click Command Builder. 2. To locate the volume history and device configuration files, issue the following commands: <ul style="list-style-type: none"> <code>query option volhistory</code> <code>query option devconfig</code> 3. In the output, review the Option Setting column to find the file locations. <p>If a disaster occurs, both the volume history file and the device configuration file are required to restore the server database.</p>	

Table 16. Periodic monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting
<p>Determine whether sufficient space is available for the instance directory file system.</p>	<p>Verify that at least 20% of free space is available in the instance directory file system. Take the action that is appropriate for your operating system:</p> <ul style="list-style-type: none"> • AIX To view available space in the file system, on the operating system command line, issue the following command: <pre style="background-color: #f0f0f0; padding: 5px;">df -g instance_directory</pre> where <i>instance_directory</i> specifies the instance directory. • Linux To view available space in the file system, on the operating system command line, issue the following command: <pre style="background-color: #f0f0f0; padding: 5px;">df -h instance_directory</pre> where <i>instance_directory</i> specifies the instance directory. • Windows In the Windows Explorer program, right-click the file system and click Properties. View the capacity information. <p>The preferred location of the instance directory depends on the operating system where the server is installed:</p> <ul style="list-style-type: none"> • AIX Linux /home/tsminst1/tsminst1 • Windows C:\tsminst1 <p>Tip: If you completed a planning worksheet, the location of the instance directory is recorded in the worksheet.</p>	

Table 16. Periodic monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting
Identify unexpected client activity.	<p>To monitor client activity to determine whether data volumes exceed expected amounts, complete the following steps:</p> <ol style="list-style-type: none"> 1. On the Operations Center Overview page, click the Clients area. 2. To view activity over the past two weeks, double-click any client. 3. To view the number of bytes sent to the client, click the Properties tab. 4. In the Last Session area, view the Sent to client row. 	<p>When you double-click a client in the Clients table, the Activity over 2 Weeks area displays the amount of data that the client sent to the server each day.</p> <p>Periodically review the SQL activity summary table, which contains statistics about client sessions. To compare current activity with previous activity, use an SQL SELECT statement. If the level of activity is significantly different from previous activity, it might indicate a ransomware attack.</p> <p>Periodically review the activity log. Look for ANE messages that indicate how many files were backed up and inspected. Compare current data deduplication rates with previous rates. If an unusually high number of files were backed up, or the rate of data deduplication unexpectedly drops to 0, it might indicate a ransomware attack.</p>

Table 16. Periodic monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting
<p>Monitor storage pool growth over time.</p>	<ol style="list-style-type: none"> 1. On the Operations Center Overview page, click the Pools area. 2. To view the capacity that was used over the last two weeks, select a pool and click Details. 	<p>Tips:</p> <ul style="list-style-type: none"> • To specify the time period that must elapse before all deduplicated extents are removed from a directory-container storage pool or cloud-container storage pool after they are no longer referenced by the inventory, complete the following steps: <ol style="list-style-type: none"> 1. On the Storage Pools page of the Operations Center, select the storage pool. 2. Click Details > Properties. 3. Specify the duration in the Delay period for container reuse field. • To determine data deduplication performance for directory-container and cloud-container storage pools, use the GENERATE DEDUPSTATS command. • To view data deduplication statistics for a storage pool, complete the following steps: <ol style="list-style-type: none"> 1. On the Storage Pools page of the Operations Center, select the storage pool. 2. Click Details > Properties. <p>Alternatively, use the QUERY EXTENTUPDATES command to display information about updates to data extents in directory-container or cloud-container storage pools. The command output can help you determine which data extents are no longer referenced and which ones are eligible to be deleted from the system. In the output, monitor the number of data extents that are eligible to be deleted from the system. This metric has a direct correlation to the amount of free space that will be available within the container storage pool.</p> • To display the amount of physical space that is occupied by a file space after the removal of the data deduplication savings, use the select * from occupancy command. The command output includes the LOGICAL_MB value. LOGICAL_MB is the amount of space that is used by the file space.

Table 16. Periodic monitoring tasks (continued)

Task	Basic procedures	Advanced procedures and troubleshooting
<p>Evaluate the timing of client schedules. Ensure that the start and end times of client schedules meet your business needs.</p>	<p>On the Operations Center Overview page, click Clients > Schedules.</p> <p>In the Schedules table, the Start column displays the configured start time for the scheduled operation. To see when the most recent operation was started, hover over the clock icon.</p>	<p>Tip: You can receive a warning message if a client operation runs longer than expected. Complete the following steps:</p> <ol style="list-style-type: none"> 1. On the Operations Center Overview page, hover over Clients and click Schedules. 2. Select a schedule and click Details. 3. View the details of a schedule by clicking the blue arrow next to the row. 4. In the Run time alert field, specify the time when a warning message will be issued if the scheduled operation is not completed. 5. Click Save.
<p>Evaluate the timing of maintenance tasks. Ensure that the start and end times of maintenance tasks meet your business needs.</p>	<p>On the Operations Center Overview page, click Servers > Maintenance.</p> <p>In the Maintenance table, review the information in the Last Run Time column. To see when the last maintenance task was started, hover over the clock icon.</p>	<p>Tip: If a maintenance task is running too long, change the start time or the maximum run time. Complete the following steps:</p> <ol style="list-style-type: none"> 1. On the Operations Center Overview page, hover over the settings icon  and click Command Builder. 2. To change the start time or maximum run time for a task, issue the UPDATE SCHEDULE command. For instructions, see UPDATE SCHEDULE (Update a client schedule).

Related information

- [QUERY ACTLOG \(Query the activity log\)](#)
- [UPDATE STGPOOL \(Update a storage pool\)](#)
- [QUERY EXTENTUPDATES \(Query updated data extents\)](#)

Verifying license compliance

Verify that your IBM Spectrum Protect solution complies with the provisions of your licensing agreement. By verifying compliance regularly, you can track trends in data growth or processor value unit (PVU) usage. Use this information to plan for future license purchasing.

About this task

The method that you use to verify that your solution complies with license terms varies depending on the provisions of your IBM Spectrum Protect licensing agreement.

Front-end capacity licensing

The front-end model determines license requirements based on the amount of primary data that is reported as being backed up by clients. Clients include applications, virtual machines, and systems.

Back-end capacity licensing

The back-end model determines license requirements based on the terabytes of data that are stored in primary storage pools and repositories.

Tips:

- To ensure the accuracy of front-end and back-end capacity estimates, install the most recent version of the client software on each client node.
- The front-end and back-end capacity information in the Operations Center is for planning and estimation purposes.

PVU licensing

The PVU model is based on the use of PVUs by server devices.

Important: The PVU calculations that are provided by IBM Spectrum Protect are considered estimates and are not legally binding. The PVU licensing information that is reported by IBM Spectrum Protect is not considered an acceptable substitute for the IBM License Metric Tool. The IBM License Metric Tool is designed to reflect actual usage. For example, after you install the IBM Spectrum Protect backup-archive client, the tool counts the client only after first usage. For more information about the IBM License Metric Tool, see [IBM License Metric Tool](#).

If you have questions or concerns about licensing requirements, contact your IBM Spectrum Protect software provider.

Procedure

To monitor license compliance, complete the steps that correspond to the provisions of your licensing agreement.

Tip: The Operations Center provides an email report that summarizes front-end and back-end capacity usage. Reports can be sent automatically to one or more recipients regularly. To configure and manage email reports, click **Reports** on the Operations Center menu bar.

Option	Description
Front-end model	<p>a. On the Operations Center menu bar, hover over the settings icon  and click Licensing.</p> <p>The front-end capacity estimate is displayed on the Front-end Usage page.</p> <p>b. If a value is displayed in the Not Reporting column, click the number to identify clients that did not report capacity usage.</p> <p>c. To estimate capacity for clients that did not report capacity usage, go to the following download site, which provides measuring tools and instructions: https://public.dhe.ibm.com/storage/tivoli-storage-management/front_end_capacity_measurement_tools</p> <p>To measure front-end capacity by script, complete the instructions in the most recently available licensing guide.</p> <p>d. Add the Operations Center estimate and any estimates that you obtained by using a script.</p> <p>e. Verify that the estimated capacity complies with your licensing agreement.</p>
Back-end model	<p>Restriction: If the source and target replication servers do not use the same policy settings, you cannot use the Operations Center to monitor back-end capacity usage for replicated clients. For information about how to estimate capacity usage for these clients, see technote 1656476.</p> <p>a. On the Operations Center menu bar, hover over the settings icon  and click Licensing.</p> <p>b. Click the Back-end tab.</p> <p>c. Verify that the estimated amount of data complies with your licensing agreement.</p>

Option	Description
PVU model	For information about how to assess compliance with PVU licensing terms, see Assessing compliance with the PVU licensing model .

Tracking system status by using email reports

Set up the Operations Center to generate email reports that summarize system status. You can configure a mail server connection, change report settings, and optionally create custom reports.

Before you begin

Before you set up email reports, ensure that the following requirements are met:

- A Simple Mail Transfer Protocol (SMTP) host server is available to send and receive reports by email. The SMTP server must be configured as an open mail relay. You must also ensure that the IBM Spectrum Protect server that sends email messages has access to the SMTP server. If the Operations Center is installed on a separate computer, that computer does not require access to the SMTP server.
- To set up email reports, you must have system privilege for the server.
- To specify the recipients, you can enter one or more email addresses or administrator IDs. If you plan to enter an administrator ID, the ID must be registered on the hub server and must have an email address that is associated with it. To specify an email address for an administrator, use the **EMAILADDRESS** parameter of the **UPDATE ADMIN** command.

About this task

You can configure the Operations Center to send a general operations report, a license compliance report, and one or more custom reports. You create custom reports by selecting a template from a set of commonly used report templates or by entering SQL SELECT statements to query managed servers.

Procedure

To set up and manage email reports, complete the following steps:

1. On the Operations Center menu bar, click **Reports**.
2. If an email server connection is not yet configured, click **Configure Mail Server** and complete the fields.
After you configure the mail server, the general operations report and license compliance report are enabled.
3. To change report settings, select a report, click **Details**, and update the form.
4. Optional: To add a custom report, click **+ Report**, and complete the fields.

Tip: To immediately run and send a report, select the report and click **Send**.

Results

Enabled reports are sent according to the specified settings.

Related information

[UPDATE ADMIN \(Update an administrator\)](#)

Part 4. Managing operations for a single-site disk solution

Use this information to manage operations for a single-site disk solution with IBM Spectrum Protect that includes a server and uses data deduplication for a single location.

Managing the Operations Center

The Operations Center provides web and mobile access to status information about the IBM Spectrum Protect environment. You can use the Operations Center to monitor multiple servers and to complete some administrative tasks. The Operations Center also provides web access to the IBM Spectrum Protect command line.

Adding and removing spoke servers

In a multiple-server environment, you can connect the other servers, called *spoke servers*, to the hub server.

About this task

The spoke servers send alerts and status information to the hub server. The Operations Center shows you a consolidated view of alerts and status information for the hub server and any spoke servers.

Adding a spoke server

After you configure the hub server for the Operations Center, you can add one or more spoke servers to the hub server.

Before you begin

Communication between the spoke server and the hub server must be secured by using the Transport Layer Security (TLS) protocol. To secure communication, add the certificate of the spoke server to the truststore file of the hub server.

Procedure

1. In the Operations Center menu bar, click **Servers**.

The **Servers** page opens.

In the table on the **Servers** page, a server might have a status of "Unmonitored." This status means that although an administrator defined this server to the hub server by using the **DEFINE SERVER** command, the server is not yet configured as a spoke server.

2. Complete one of the following steps:

- Click the server to highlight it, and in the table menu bar, click **Monitor Spoke**.
- If the server that you want to add is not shown in the table, and secure SSL/TLS communication is not required, click **+ Spoke** in the table menu bar.

3. Provide the necessary information, and complete the steps in the spoke configuration wizard.

Tip: If the event-record retention period of the server is less than 14 days, the period is automatically reset to 14 days if you configure the server as a spoke server.

Removing a spoke server

You can remove a spoke server from the Operations Center.

About this task

You might need to remove a spoke server in the following situations, for example:

- You want to move the spoke server from one hub server to another hub server.
- You want to decommission the spoke server.

Procedure

To remove the spoke server from the group of servers that are managed by the hub server, complete the following steps:

1. From the IBM Spectrum Protect command line, issue the following command on the hub server:

```
QUERY MONITORSETTINGS
```

2. From the output of the command, copy the name that is in the **Monitored Group** field.
3. Issue the following command on the hub server, where *group_name* represents the name of the monitored group, and *member_name* represents the name of the spoke server:

```
DELETE GRPMEMBER group_name member_name
```

4. Optional: If you want to move the spoke server from one hub server to another hub server, do **not** complete this step. Otherwise, you can disable alerting and monitoring on the spoke server by issuing the following commands on the spoke server:

```
SET STATUSMONITOR OFF  
SET ALERTMONITOR OFF
```

5. Optional: If the spoke server definition is used for other purposes, such as enterprise configuration, command routing, storing virtual volumes, or library management, do **not** complete this step. Otherwise, you can delete the spoke server definition on the hub server by issuing the following command on the hub server:

```
DELETE SERVER spoke_server_name
```

Tip: If a server definition is deleted immediately after the server is removed from the monitored group, status information for the server can remain in the Operations Center indefinitely.

To avoid this issue, wait until the status collection interval passes before you delete the server definition. The status collection interval is shown on the Settings page of the Operations Center.

Starting and stopping the web server

The web server of the Operations Center runs as a service and starts automatically. You might have to stop and start the web server, for example, to make configuration changes.

Procedure

1. Stop the web server.

- **AIX** From the */installation_dir/ui/utils* directory, where *installation_dir* represents the directory where the Operations Center is installed, issue the following command:

```
./stopserver.sh
```

- **Linux** Issue the following command:

```
service opscenter.rc stop
```

- **Windows** From the **Services** window, stop the **IBM Spectrum Protect Operations Center** service.
2. Start the web server.
- **AIX** From the `/installation_dir/ui/Utils` directory, where `installation_dir` represents the directory where the Operations Center is installed, issue the following command:


```
./startserver.sh
```
 - **Linux** Issue the following commands:

Start the server:

```
service opscenter.rc start
```

Restart the server:

```
service opscenter.rc restart
```

Determine whether the server is running:

```
service opscenter.rc status
```
 - **Windows** From the **Services** window, start the **IBM Spectrum Protect Operations Center** service.

Restarting the initial configuration wizard

You might need to restart the initial configuration wizard of the Operations Center, for example, to make configuration changes.

Before you begin

To change the following settings, use the **Settings** page in the Operations Center rather than restarting the initial configuration wizard:

- The frequency at which status data is refreshed
- The duration that alerts remain active, inactive, or closed
- The conditions that indicate that clients are at risk

The Operations Center help includes more information about how to change these settings.

About this task

To restart the initial configuration wizard, you must delete a properties file that includes information about the hub server connection. However, any alerting, monitoring, at-risk, or multiserver settings that were configured for the hub server are not deleted. These settings are used as the default settings in the configuration wizard when the wizard restarts.

Procedure

1. Stop the Operations Center web server.
2. On the computer where the Operations Center is installed, go to the following directory, where `installation_dir` represents the directory in which the Operations Center is installed:
 - **AIX** | **Linux** `installation_dir/ui/Liberty/usr/servers/guiServer`
 - **Windows** `installation_dir\ui\Liberty\usr\servers\guiServer`

For example:

 - **AIX** | **Linux** `/opt/tivoli/tsm/ui/Liberty/usr/servers/guiServer`
 - **Windows** `c:\Program Files\Tivoli\TSM\ui\Liberty\usr\servers\guiServer`
3. In the `guiServer` directory, delete the `serverConnection.properties` file.

4. Start the Operations Center web server.
5. Open the Operations Center.
6. Use the configuration wizard to reconfigure the Operations Center.
Specify a new password for the monitoring administrator ID.
7. On any spoke servers that were previously connected to the hub server, update the password for the monitoring administrator ID by issuing the following command from the IBM Spectrum Protect command-line interface:

```
UPDATE ADMIN IBM-OC-hub_server_name new_password
```

Restriction: Do not change any other settings for this administrator ID. After you specify the initial password, this password is managed automatically by the Operations Center.

Changing the hub server

You can use the Operations Center to remove the hub server of IBM Spectrum Protect, and configure another hub server.

Procedure

1. Restart the initial configuration wizard of the Operations Center.
As part of this procedure, you delete the existing hub server connection.
2. Use the wizard to configure the Operations Center to connect to the new hub server.

Related tasks

[Restarting the initial configuration wizard](#)

You might need to restart the initial configuration wizard of the Operations Center, for example, to make configuration changes.

Restoring the configuration to the preconfiguration state

If certain problems occur, you might want to restore the Operations Center configuration to the preconfigured state where the IBM Spectrum Protect servers are not defined as hub or spoke servers.

Procedure

To restore the configuration, complete the following steps:

1. Stop the Operations Center web server.
2. Unconfigure the hub server by completing the following steps:
 - a) On the hub server, issue the following commands:

```
SET MONITORINGADMIN ""
SET MONITOREDSEVERGROUP ""
SET STATUSMONITOR OFF
SET ALERTMONITOR OFF
REMOVE ADMIN IBM-OC-hub_server_name
```

Tip: *IBM-OC-hub_server_name* represents the monitoring administrator ID that was automatically created when you initially configured the hub server.

- b) Reset the password for the hub server by issuing the following command on the hub server:

```
SET SERVERPASSWORD ""
```



Attention: Do not complete this step if the hub server is configured with other servers for other purposes, such as library sharing, exporting and importing of data, or node replication.

3. Unconfigure any spoke servers by completing the following steps:

- a) On the hub server, to determine whether any spoke servers remain as members of the server group, issue the following command:

```
QUERY SERVERGROUP IBM-OC-hub_server_name
```

Tip: *IBM-OC-*hub_server_name** represents the name of the monitored server group that was automatically created when you configured the first spoke server. This server group name is also the same as the monitoring administrator ID that was automatically created when you initially configured the hub server.

- b) On the hub server, to delete spoke servers from the server group, issue the following command for each spoke server:

```
DELETE GRPMEMBER IBM-OC-hub_server_name spoke_server_name
```

- c) After all spoke servers are deleted from the server group, issue the following commands on the hub server:

```
DELETE SERVERGROUP IBM-OC-hub_server_name  
SET MONITOREDSEVERGROUP ""
```

- d) On each spoke server, issue the following commands:

```
REMOVE ADMIN IBM-OC-hub_server_name  
SETOPT PUSHSTATUS NO  
SET ALERTMONITOR OFF  
SET STATUSMONITOR OFF
```

- e) On each spoke server, delete the definition of the hub server by issuing the following command:

```
DELETE SERVER hub_server_name
```



Attention: Do not complete this step if the definition is used for other purposes, such as library sharing, exporting and importing of data, or node replication.

- f) On the hub server, delete the definition of each spoke server by issuing the following command:

```
DELETE SERVER spoke_server_name
```



Attention: Do not complete this step if the server definition is used for other purposes, such as library sharing, exporting and importing of data, or node replication.

4. Restore the default settings on each server by issuing the following commands:

```
SET STATUSREFRESHINTERVAL 5  
SET ALERTUPDATEINTERVAL 10  
SET ALERTACTIVEDURATION 480  
SET ALERTINACTIVEDURATION 480  
SET ALERTCLOSEDDURATION 60  
SET STATUSATRISKINTERVAL TYPE=AP INTERVAL=24  
SET STATUSATRISKINTERVAL TYPE=VM INTERVAL=24  
SET STATUSATRISKINTERVAL TYPE=SY INTERVAL=24  
SET STATUSSKIPASFAILURE YES TYPE=ALL
```

5. Restart the initial configuration wizard of the Operations Center.

Related tasks

[Restarting the initial configuration wizard](#)

You might need to restart the initial configuration wizard of the Operations Center, for example, to make configuration changes.

[Starting and stopping the web server](#)

The web server of the Operations Center runs as a service and starts automatically. You might have to stop and start the web server, for example, to make configuration changes.

Protecting applications, virtual machines, and systems

The server protects data for clients, which can include applications, virtual machines, and systems. To start protecting client data, register the client node with the server and select a backup schedule to protect the client data.

Adding clients

After you implement a data protection solution with IBM Spectrum Protect, you can expand the solution by adding clients.

About this task

The procedure describes basic steps for adding a client. For more specific instructions about configuring clients, see the documentation for the product that you install on the client node. You can have the following types of client nodes:

Application client nodes

Application client nodes include email servers, databases, and other applications. For example, any of the following applications can be an application client node:

- IBM Spectrum Protect Snapshot
- IBM Spectrum Protect for Databases
- IBM Spectrum Protect for Enterprise Resource Planning
- IBM Spectrum Protect for Mail
- IBM Spectrum Protect for Virtual Environments

System client nodes

System client nodes include workstations, network-attached storage (NAS) file servers, and API clients.

Virtual machine client nodes

Virtual machine client nodes consist of an individual guest host within a hypervisor. Each virtual machine is represented as a file space.

Procedure

To add a client, complete the following steps:

1. Select the software to install on the client node and plan the installation. Follow the instructions in [“Selecting the client software and planning the installation”](#) on page 75.
2. Specify how to back up and archive client data. Follow the instructions in [“Specifying rules for backing up and archiving client data”](#) on page 76.
3. Specify when to back up and archive client data. Follow the instructions in [“Scheduling backup and archive operations”](#) on page 79.
4. To allow the client to connect to the server, register the client. Follow the instructions in [“Registering clients”](#) on page 80.
5. To start protecting a client node, install and configure the selected software on the client node. Follow the instructions in [“Installing and configuring clients”](#) on page 81.

Selecting the client software and planning the installation

Different types of data require different types of protection. Identify the type of data that you must protect and select the appropriate software.

About this task

The preferred practice is to install the backup-archive client on all client nodes so that you can configure and start the client acceptor on the client node. The client acceptor is designed to efficiently run scheduled operations.

The client acceptor runs schedules for the following products: the backup-archive client, IBM Spectrum Protect for Databases, IBM Spectrum Protect for Enterprise Resource Planning, IBM Spectrum Protect for Mail, and IBM Spectrum Protect for Virtual Environments. If you install a product for which the client acceptor does not run schedules, you must follow the configuration instructions in the product documentation to ensure that scheduled operations can occur.

Procedure

Based on your goal, select the products to install and review the installation instructions.

Tip: If you install the client software now, you must also complete the client configuration tasks that are described in [“Installing and configuring clients”](#) on page 81 before you can use the client.

Goal	Product and description	Installation instructions
Protect a file server or workstation	The backup-archive client backs up and archives files and directories from file servers and workstations to storage. You can also restore and retrieve backup versions and archived copies of files.	<ul style="list-style-type: none"> • Client environment requirements • Install UNIX and Linux backup-archive clients • Installing the Windows client for the first time
Protect applications with snapshot backup and restore capabilities	IBM Spectrum Protect Snapshot protects data with integrated, application-aware snapshot backup and restore capabilities. You can protect data that is stored by IBM Db2 database software and SAP, Oracle, Microsoft Exchange, and Microsoft SQL Server applications.	<ul style="list-style-type: none"> • Installing and upgrading IBM Spectrum Protect Snapshot for UNIX and Linux • Installing and upgrading IBM Spectrum Protect Snapshot for VMware • Installing and upgrading IBM Spectrum Protect Snapshot for Windows
Protect an email application on an IBM Domino® server	IBM Spectrum Protect for Mail: Data Protection for IBM Domino automates data protection so that backups are completed without shutting down IBM Domino servers.	<ul style="list-style-type: none"> • Installation of Data Protection for IBM Domino on a UNIX, AIX, or Linux system (V7.1.0) • Installation of Data Protection for IBM Domino on a Windows system (V7.1.0)
Protect an email application on a Microsoft Exchange server	IBM Spectrum Protect for Mail: Data Protection for Microsoft Exchange Server automates data protection so that backups are completed without shutting down Microsoft Exchange servers.	Installing, upgrading, and migrating
Protect a Db2 database	The application programming interface (API) of the backup-archive client can be used to back up Db2 data to the IBM Spectrum Protect server.	Installing the IBM Spectrum Protect backup-archive clients (UNIX, Linux, and Windows)
Protect an IBM Informix® database	The API of the backup-archive client can be used to back up Informix data to the IBM Spectrum Protect server.	Installing the IBM Spectrum Protect backup-archive clients (UNIX, Linux, and Windows)

Goal	Product and description	Installation instructions
Protect a Microsoft SQL database	IBM Spectrum Protect for Databases: Data Protection for Microsoft SQL Server protects Microsoft SQL data.	Installing Data Protection for SQL Server on Windows Server Core
Protect an Oracle database	IBM Spectrum Protect for Databases: Data Protection for Oracle protects Oracle data.	Data Protection for Oracle installation
Protect an SAP environment	IBM Spectrum Protect for Enterprise Resource Planning: Data Protection for SAP provides protection that is customized for SAP environments. The product is designed to improve the availability of SAP database servers and reduce administration workload.	<ul style="list-style-type: none"> • Installing Data Protection for SAP for Db2 • Installing Data Protection for SAP for Oracle
Protect a virtual machine	<p>IBM Spectrum Protect for Virtual Environments provides protection that is tailored for Microsoft Hyper-V and VMware virtual environments. You can use IBM Spectrum Protect for Virtual Environments to create incremental forever backups that are stored on a centralized server, create backup policies, and restore virtual machines or individual files.</p> <p>Alternatively, use the backup-archive client to back up and restore a full VMware or Microsoft Hyper-V virtual machine. You can also back up and restore files or directories from a VMware virtual machine.</p>	<ul style="list-style-type: none"> • Installing and upgrading Data Protection for Microsoft Hyper-V • Installing and upgrading • Installing the IBM Spectrum Protect backup-archive clients (UNIX, Linux, and Windows)

Tip: To use the client for space management, you can install IBM Spectrum Protect for Space Management or IBM Spectrum Protect HSM for Windows.

Specifying rules for backing up and archiving client data

Before you add a client, ensure that appropriate rules are specified for backup and archive operations for the client data. During the client registration process, you assign the client node to a policy domain, which has the rules that control how and when client data is stored.

Before you begin

Determine how to proceed:

- If you are familiar with the policies that are configured for your solution and you know that they do not require changes, continue with [“Scheduling backup and archive operations”](#) on page 79.
- If you are not familiar with the policies, follow the steps in this procedure.

About this task

Policies affect how much data is stored over time, and how long data is retained and available for clients to restore. To meet objectives for data protection, you can update the default policy and create your own policies. A policy includes the following rules:

- How and when files are backed up and archived to server storage.
- The number of copies of a file and the length of time copies are kept in server storage.

During the client registration process, you assign a client to a *policy domain*. The policy for a specific client is determined by the rules in the policy domain to which the client is assigned. In the policy domain, the rules that are in effect are in the active *policy set*.

When a client backs up or archives a file, the file is bound to a management class in the active policy set of the policy domain. A *management class* is the key set of rules for managing client data. The backup and archive operations on the client use the settings in the default management class of the policy domain unless you further customize policy. A policy can be customized by defining more management classes and assigning their use through client options.

Client options can be specified in a local, editable file on the client system and in a client option set on the server. The options in the client option set on the server can override or add to the options in the local client option file.

Procedure

1. Review the policies that are configured for your solution by following the instructions in [“Viewing policies”](#) on page 77.
2. If you need to make minor changes to meet data retention requirements, follow the instructions in [“Editing policies”](#) on page 78.
3. Optional: If you need to create policy domains or make extensive changes to policies to meet data retention requirements, see [Customizing policies](#).

Viewing policies

View policies to determine whether they must be edited to meet your requirements.

Procedure

1. To view the active policy set for a policy domain, complete the following steps:
 - a) On the **Services** page of the Operations Center, select a policy domain and click **Details**.
 - b) On the **Summary** page for the policy domain, click the **Policy Sets** tab.

Tip: To help ensure that you can recover data after a ransomware attack, apply the following guidelines:

 - Ensure that the value in the Backups column is a minimum of 2. The preferred value is 3, 4, or more.
 - Ensure that the value in the Keep Extra Backups column is a minimum of 14 days. The preferred value is 30 or more days.
 - Ensure that the value in the Keep Archives column is a minimum of 30 days.

If IBM Spectrum Protect for Space Management software is installed on the client, ensure that data is backed up before you migrate it. On the **DEFINE MGMTCLASS** or **UPDATE MGMTCLASS** command, specify **MIGREQUIRESBKUP=YES**. Then, follow the guidelines in the tip.
2. To view inactive policy sets for a policy domain, complete the following steps:
 - a) On the **Policy Sets** page, click the **Configure** toggle. You can now view and edit the policy sets that are inactive.
 - b) Scroll through the inactive policy sets by using the forward and back arrows. When you view an inactive policy set, the settings that differentiate the inactive policy set from the active policy set are highlighted.
 - c) Click the **Configure** toggle. The policy sets are no longer editable.

Editing policies

To change the rules that apply to a policy domain, edit the active policy set for the policy domain. You can also activate a different policy set for a domain.

Before you begin

Changes to policy can affect data retention. Ensure that you continue to back up data that is essential to your organization so that you can restore that data if a disaster occurs. Also, ensure that your system has sufficient storage space for planned backup operations.

About this task

You edit a policy set by changing one or more management classes within the policy set. If you edit the active policy set, the changes are not available to clients unless you reactivate the policy set. To make the edited policy set available to clients, activate the policy set.

Although you can define multiple policy sets for a policy domain, only one policy set can be active. When you activate a different policy set, it replaces the currently active policy set.

To learn about preferred practices for defining policies, see [Customizing policies](#).

Procedure

1. On the **Services** page of the Operations Center, select a policy domain and click **Details**.
2. On the **Summary** page for the policy domain, click the **Policy Sets** tab.

The **Policy Sets** page indicates the name of the active policy set and lists all of the management classes for that policy set.

3. Click the **Configure** toggle. The policy set is editable.
4. To edit a policy set that is not active, click the forward and back arrows to locate the policy set.
5. Edit the policy set by completing any of the following actions:

Option	Description
Add a management class	<ol style="list-style-type: none">a. In the Policy Sets table, click +Management Class.b. To specify the rules for backing up and archiving data, complete the fields in the Add Management Class window.c. To make the management class the default management class, select the Make default check box.d. Click Add.
Delete a management class	In the Management Class column, click - . Tip: To delete the default management class, you must first assign a different management class as the default.
Make a management class the default management class	In the Default column for the management class, click the radio button. Tip: The default management class manages client files when another management class is not assigned to, or appropriate for managing, a file. To ensure that clients can always back up and archive files, choose a default management class that contains rules for both backing up and archiving files.
Modify a management class	To change the properties of a management class, update the fields in the table.

6. Click **Save**.



Attention: When you activate a new policy set, data might be lost. Data that is protected under one policy set might not be protected under another policy set. Therefore, before you activate a

policy set, ensure that the differences between the previous policy set and the new policy set do not cause data to be lost.

7. Click **Activate**. A summary of the differences between the active policy set and the new policy set is displayed. Ensure that the changes in the new policy set are consistent with your data retention requirements by completing the following steps:
 - a) Review the differences between corresponding management classes in the two policy sets, and consider the consequences for client files. Client files that are bound to management classes in the active policy set will be bound to the management classes with the same names in the new policy set.
 - b) Identify management classes in the active policy set that do not have counterparts in the new policy set, and consider the consequences for client files. Client files that are bound to these management classes will be managed by the default management class in the new policy set.
 - c) If the changes to be implemented by the policy set are acceptable, select the **I understand that these updates can cause data loss** check box and click **Activate**.

Scheduling backup and archive operations

Before you register a new client with the server, ensure that a schedule is available to specify when backup and archive operations take place. During the registration process, you assign a schedule to the client.

Before you begin

Determine how to proceed:

- If you are familiar with the schedules that are configured for the solution and you know that they do not require modification, continue with [“Registering clients” on page 80](#).
- If you are not familiar with the schedules or the schedules require modification, follow the steps in this procedure.

About this task

Typically, backup operations for all clients must be completed daily. Schedule client and server workloads to achieve the best performance for your storage environment. To avoid the overlap of client and server operations, consider scheduling client backup and archive operations so that they run at night. If client and server operations overlap or are not given enough time and resources to be processed, you might experience decreased system performance, failed operations, and other issues.

Procedure

1. Review available schedules by hovering over **Clients** on the Operations Center menu bar. Click **Schedules**.
2. Optional: Modify or create a schedule by completing the following steps:

Option	Description
Modify a schedule	<ol style="list-style-type: none">a. In the Schedules view, select the schedule and click Details.b. On the Schedule Details page, view details by clicking the blue arrows at the beginning of the rows.c. Modify the settings in the schedule, and click Save.
Create a schedule	In the Schedules view, click +Schedule and complete the steps to create a schedule.

3. Optional: To configure schedule settings that are not visible in the Operations Center, use a server command. For example, you might want to schedule a client operation that backs up a specific directory and assigns it to a management class other than the default.

- a) On the **Overview** page of the Operations Center, hover over the settings icon  and click **Command Builder**.
- b) Issue the **DEFINE SCHEDULE** command to create a schedule or the **UPDATE SCHEDULE** command to modify a schedule. For more information about the commands, see [DEFINE SCHEDULE \(Define a client schedule\)](#) or [UPDATE SCHEDULE \(Update a client schedule\)](#).

Related information

[Tuning the schedule for daily operations](#)

Registering clients

Register a client to ensure that the client can connect to the server, and the server can protect client data.

Before you begin

Determine whether the client requires an administrative user ID with client owner authority over the client node. To determine which clients require an administrative user ID, see [technote 7048963](#).

Restriction: For some types of clients, the client node name and the administrative user ID must match. You cannot authenticate those clients by using the Lightweight Directory Access Protocol authentication method that was introduced in V7.1.7. For details about this authentication method, sometimes referred to as integrated mode, see [Authenticating users by using an Active Directory database](#).

Procedure

To register a client, complete one of the following actions.

- If the client requires an administrative user ID, register the client by using the **REGISTER NODE** command and specify the **USERID** parameter:

```
register node node_name password userid=node_name
```

where *node_name* specifies the node name and *password* specifies the node password. For details, see [Register a node](#).

- If the client does not require an administrative user ID, register the client by using the Operations Center Add Client wizard. Complete the following steps:
 - a. On the Operations Center menu bar, click **Clients**.
 - b. In the Clients table, click **+Client**.
 - c. Complete the steps in the **Add Client** wizard:
 - 1) Specify that redundant data can be eliminated on both the client and server. In the Client-side data deduplication area, select the **Enable** check box.
 - 2) In the **Configuration** window, copy the **TCPSERVERADDRESS**, **TCPPORT**, **NODENAME**, and **DEDUPLICATION** option values.

Tip: Record the option values and keep them in a safe place. After you complete the client registration and install the software on the client node, use the values to configure the client.
 - 3) Follow the instructions in the wizard to specify the policy domain, schedule, and option set.
 - 4) Set how risks are displayed for the client by specifying the at-risk setting.
 - 5) Click **Add Client**.

Related information

[Tcpserveraddress option](#)

[Tcpport option](#)

[Nodename option](#)

[Deduplication option](#)

Installing and configuring clients

To start protecting a client node, you must install and configure the selected software.

Procedure

If you already installed the software, start at step “2” on page 82.

1. Take one of the following actions:

- To install software on an application or client node, follow the instructions.

Software	Link to instructions
IBM Spectrum Protect backup-archive client	<ul style="list-style-type: none"> – Install UNIX and Linux backup-archive clients – Installing the Windows client for the first time <p>Tip: You can also update existing clients by using the Operations Center. For instructions, see Scheduling client updates.</p>
IBM Spectrum Protect for Databases	<ul style="list-style-type: none"> – Data Protection for Oracle installation – Installing Data Protection for SQL Server on Windows Server Core
IBM Spectrum Protect for Mail	<ul style="list-style-type: none"> – Installation of Data Protection for IBM Domino on a UNIX, AIX, or Linux system (V7.1.0) – Installation of Data Protection for IBM Domino on a Windows system (V7.1.0) – Installing, upgrading, and migrating
IBM Spectrum Protect Snapshot	<ul style="list-style-type: none"> – Installing and upgrading IBM Spectrum Protect Snapshot for UNIX and Linux – Installing and upgrading IBM Spectrum Protect Snapshot for VMware – Installing and upgrading IBM Spectrum Protect Snapshot for Windows
IBM Spectrum Protect for Enterprise Resource Planning	<ul style="list-style-type: none"> – Installing Data Protection for SAP for Db2 – Installing Data Protection for SAP for Oracle

- To install software on a virtual machine client node, follow the instructions for the selected backup type.

Backup type	Link to instructions
If you plan to create full VMware backups of virtual machines, install and configure the IBM Spectrum Protect backup-archive client.	<ul style="list-style-type: none"> – Install UNIX and Linux backup-archive clients – Installing the Windows client for the first time

Backup type	Link to instructions
If you plan to create incremental forever full backups of virtual machines, install and configure IBM Spectrum Protect for Virtual Environments and the backup-archive client on the same client node or on different client nodes.	<p data-bbox="686 195 1045 226">– Data protection for VMware</p> <p data-bbox="686 241 1446 336">Tip: You can obtain the software for IBM Spectrum Protect for Virtual Environments and the backup-archive client in the IBM Spectrum Protect for Virtual Environments installation package.</p>

2. To allow the client to connect to the server, add or update the values for the **TCPSEVERADDRESS**, **TCPPORT**, and **NODENAME** options in the client options file. Use the values that you recorded when you registered the client ([“Registering clients”](#) on page 80).
 - For clients that are installed on an AIX, Linux, or Mac OS X operating system, add the values to the client system-options file, `dsm.sys`.
 - For clients that are installed on a Windows operating system, add the values to the `dsm.opt` file.

By default, the options files are in the installation directory.

3. If you installed a backup-archive client on a Linux or Windows operating system, install the client management service on the client. Follow the instructions in [“Installing the client management service”](#) on page 48.
4. Configure the client to run scheduled operations. Follow the instructions in [“Configuring the client to run scheduled operations”](#) on page 82.
5. Optional: Configure communications through a firewall. Follow the instructions in [“Configuring client/server communications through a firewall”](#) on page 84.
6. Run a test backup to verify that data is protected as you planned.
For example, for a backup-archive client, complete the following steps:
 - a) On the **Clients** page of the Operations Center, select the client that you want to back up, and click **Back Up**.
 - b) Verify that the backup completes successfully and that there are no warning or error messages.
7. Monitor the results of the scheduled operations for the client in the Operations Center.

What to do next

If you need to change what is getting backed up from the client, follow the instructions in [“Modifying the scope of a client backup”](#) on page 88.

Configuring the client to run scheduled operations

You must configure and start a client scheduler on the client node. The client scheduler enables communication between the client and server so that scheduled operations can occur. For example, scheduled operations typically include backing up files from a client.

About this task

The preferred method is to install the backup-archive client on all client nodes so that you can configure and start the client acceptor on the client node. The client acceptor is designed to efficiently run scheduled operations. The client acceptor manages the client scheduler so that the scheduler runs only when required:

- When it is time to query the server about the next scheduled operation
- When it is time to start the next scheduled operation

By using the client acceptor, you can reduce the number of background processes on the client and help to avoid memory retention problems.

The client acceptor runs schedules for the following products: the backup-archive client, IBM Spectrum Protect for Databases, IBM Spectrum Protect for Enterprise Resource Planning, IBM Spectrum Protect for Mail, and IBM Spectrum Protect for Virtual Environments. If you installed a product for which the client acceptor does not run schedules, follow the configuration instructions in the product documentation to ensure that scheduled operations can occur.

If your business uses a third-party scheduling tool as standard practice, you can use that scheduling tool as an alternative to the client acceptor. Typically, third-party scheduling tools start client programs directly by using operating system commands. To configure a third-party scheduling tool, see the product documentation.

Procedure

To configure and start the client scheduler by using the client acceptor, follow the instructions for the operating system that is installed on the client node:

AIX and Oracle Solaris

- a. From the backup-archive client GUI, click **Edit > Client Preferences**.
- b. Click the **Web Client** tab.
- c. In the **Managed Services Options** field, click **Schedule**. If you also want the client acceptor to manage the web client, click the **Both** option.
- d. To ensure that the scheduler can start unattended, in the `dsm.sys` file, set the **passwordaccess** option to `generate`.
- e. To store the client node password, issue the following command and enter the client node password when prompted:

```
dsmc query sess
```

- f. Start the client acceptor by issuing the following command on the command line:

```
/usr/bin/dsmcad
```

- g. To enable the client acceptor to start automatically after a system restart, add the following entry to the system startup file (typically, `/etc/inittab`):

```
tsm::once:/usr/bin/dsmcad > /dev/null 2>&1 # Client Acceptor Daemon
```

Linux

- a. From the backup-archive client GUI, click **Edit > Client Preferences**.
- b. Click the **Web Client** tab.
- c. In the **Managed Services Options** field, click **Schedule**. If you also want the client acceptor to manage the web client, click the **Both** option.
- d. To ensure that the scheduler can start unattended, in the `dsm.sys` file, set the **passwordaccess** option to `generate`.
- e. To store the client node password, issue the following command and enter the client node password when prompted:

```
dsmc query sess
```

- f. Start the client acceptor by logging in with the root user ID and issuing the following command:

```
service dsmcad start
```

- g. To enable the client acceptor to start automatically after a system restart, add the service by issuing the following command at a shell prompt:

```
# chkconfig --add dsmcad
```

MAC OS X

- a. In the backup-archive client GUI, click **Edit > Client Preferences**.
- b. To ensure that the scheduler can start unattended, click **Authorization**, select **Password Generate**, and click **Apply**.
- c. To specify how services are managed, click **Web Client**, select **Schedule**, click **Apply**, and click **OK**.
- d. To ensure that the generated password is saved, restart the backup-archive client.
- e. Use the IBM Spectrum Protect Tools for Administrators application to start the client acceptor.

Windows

- a. In the backup-archive client GUI, click **Utilities > Setup Wizard > Help me configure the Client Scheduler**. Click **Next**.
- b. Read the information on the **Scheduler Wizard** page and click **Next**.
- c. On the **Scheduler Task** page, select **Install a new or additional scheduler** and click **Next**.
- d. On the **Scheduler Name and Location** page, specify a name for the client scheduler that you are adding. Then, select **Use the Client Acceptor daemon (CAD)** to manage the scheduler and click **Next**.
- e. Enter the name that you want to assign to this client acceptor. The default name is Client Acceptor. Click **Next**.
- f. Complete the configuration by stepping through the wizard.
- g. Update the client options file, `dsm.opt`, and set the **passwordaccess** option to generate.
- h. To store the client node password, issue the following command at the command prompt:

```
dsmc query sess
```

Enter the client node password when prompted.

- i. Start the client acceptor service from the **Services Control** page. For example, if you used the default name, start the Client Acceptor service. Do not start the scheduler service that you specified on the **Scheduler Name and Location** page. The scheduler service is started and stopped automatically by the client acceptor service as needed.

Configuring client/server communications through a firewall

If a client must communicate with a server through a firewall, you must enable client/server communications through the firewall.

Before you begin

If you used the Add Client wizard to register a client, find the option values in the client options file that you obtained during that process. You can use the values to specify ports.

About this task



Attention: Do not configure a firewall in a way that might cause termination of sessions that are in use by a server or storage agent. Termination of a valid session can cause unpredictable results. Processes and sessions might appear to stop due to input/output errors. To help exclude sessions from timeout restrictions, configure known ports for IBM Spectrum Protect components. Ensure that the **KEEPALIVE** server option remains set to the default value of YES. In this way, you can help to ensure that client/server communication is uninterrupted. For instructions about setting the **KEEPALIVE** server option, see [KEEPALIVE](#).

Procedure

Open the following ports to allow access through the firewall:

TCP/IP port for the backup-archive client, command-line administrative client, and the client scheduler

Specify the port by using the **tcpport** option in the client options file. The **tcpport** option in the client options file must match the **TCPPORT** option in the server options file. The default value is 1500. If you decide to use a value other than the default, specify a number in the range 1024 - 32767.

HTTP port to enable communication between the web client and remote workstations

Specify the port for the remote workstation by setting the **httpport** option in the client options file of the remote workstation. The default value is 1581.

TCP/IP ports for the remote workstation

The default value of 0 (zero) causes two free port numbers to be randomly assigned to the remote workstation. If you do not want the port numbers to be randomly assigned, specify values by setting the **webports** option in the client options file of the remote workstation.

TCP/IP port for administrative sessions

Specify the port on which the server waits for requests for administrative client sessions. The value of the client **tcpadminport** option must match the value of the **TCPADMINPORT** server option. In this way, you can secure administrative sessions within a private network.

Managing client operations

You can evaluate and resolve errors that are related to a backup-archive client by using the Operations Center, which provides suggestions for resolving errors. For errors on other types of clients, you must examine the error logs on the client and review the product documentation.

About this task

In some cases, you can resolve client errors by stopping and starting the client acceptor. If client nodes or administrator IDs are locked, you can resolve the issue by unlocking the client node or administrator ID, and then resetting the password.

For detailed instructions about identifying and resolving client errors, see [Resolving client problems](#).

Evaluating errors in client error logs

You can resolve client errors by obtaining suggestions from the Operations Center or by reviewing error logs on the client.

Before you begin

To resolve errors in a backup-archive client on a Linux or Windows operating system, ensure that the client management service is installed and started. For installation instructions, see [“Installing the client management service”](#) on page 48. For instructions about verifying the installation, see [“Verifying that the client management service is installed correctly”](#) on page 48.

Procedure

To diagnose and resolve client errors, take one of the following actions:

- If the client management service is installed on the client node, complete the following steps:
 - a) On the Operations Center Overview page, click **Clients** and select the client.
 - b) Click **Details**.
 - c) On the client Summary page, click the **Diagnosis** tab.
 - d) Review the retrieved log messages.

Tips:

- To show or hide the Client Logs pane, double-click the Client Logs bar.
- To resize the Client Logs pane, click and drag the Client Logs bar.

If suggestions are displayed on the Diagnosis page, select a suggestion. In the Client Logs pane, client log messages to which the suggestion relates are highlighted.

e) Use the suggestions to resolve the problems that are indicated by the error messages.

Tip: Suggestions are provided for only a subset of client messages.

- If the client management service is not installed on the client node, review the error logs for the installed client.

Stopping and restarting the client acceptor

If you change the configuration of your solution, you must restart the client acceptor on all client nodes where a backup-archive client is installed.

About this task

In some cases, you can resolve client scheduling problems by stopping and restarting the client acceptor. The client acceptor must be running to ensure that scheduled operations can occur on the client. For example, if you change the IP address or domain name of the server, you must restart the client acceptor.

Procedure

Follow the instructions for the operating system that is installed on the client node:

AIX and Oracle Solaris

- To stop the client acceptor, complete the following steps:
 - a. Determine the process ID for the client acceptor by issuing the following command on the command line:

```
ps -ef | grep dsmcad
```

Review the output. In the following sample output, 6764 is the process ID for the client acceptor:

```
root 6764 1 0 16:26:35 ? 0:00 /usr/bin/dsmcad
```

- b. Issue the following command on the command line:

```
kill -9 PID
```

where *PID* specifies the process ID for the client acceptor.

- To start the client acceptor, issue the following command on the command line:

```
/usr/bin/dsmcad
```

Linux

- To stop the client acceptor (and not restart it), issue the following command:

```
# service dsmcad stop
```

- To stop and restart the client acceptor, issue the following command:

```
# service dsmcad restart
```

MAC OS X

Click **Applications > Utilities > Terminal**.

- To stop the client acceptor, issue the following command:

```
/bin/launchctl unload -w com.ibm.tivoli.dsmcad
```

- To start the client acceptor, issue the following command:

```
/bin/launchctl load -w com.ibm.tivoli.dsmcad
```

Windows

- To stop the client acceptor service, complete the following steps:
 - a. Click **Start > Administrative Tools > Services**.
 - b. Double-click the client acceptor service.
 - c. Click **Stop** and **OK**.
- To restart the client acceptor service, complete the following steps:
 - a. Click **Start > Administrative Tools > Services**.
 - b. Double-click the client acceptor service.
 - c. Click **Start** and **OK**.

Related information

[Resolving client scheduling problems](#)

Resetting passwords

If a password for a client node or an administrator ID is lost or forgotten, you can reset the password. Multiple attempts to access the system with an incorrect password can cause a client node or administrator ID to be locked. You can take steps to resolve the issue.

Procedure

To resolve password issues, take one of the following actions:

- If a backup-archive client is installed on a client node, and the password is lost or forgotten, complete the following steps:

1. Generate a new password by issuing the **UPDATE NODE** command:

```
update node node_name new_password forcepwreset=yes
```

where *node_name* specifies the client node and *new_password* specifies the password that you assign.

2. Inform the client node owner about the changed password. When the owner of the client node logs in with the specified password, a new password is generated automatically. That password is unknown to users to enhance security.

Tip: The password is generated automatically if you previously set the **passwordaccess** option to generate in the client options file.

- If an administrator is locked out because of password issues, complete the following steps:

1. To provide the administrator with access to the server, issue the **UNLOCK ADMIN** command. For instructions, see [UNLOCK ADMIN \(Unlock an administrator\)](#).
2. Set a new password by using the **UPDATE ADMIN** command:

```
update admin admin_name new_password forcepwreset=yes
```

where *admin_name* specifies the name of the administrator and *new_password* specifies the password that you assign.

- If a client node is locked, complete the following steps:

1. Determine why the client node is locked and whether it must be unlocked. For example, if the client node is decommissioned, the client node is being removed from the production environment. You cannot reverse the decommission operation, and the client node remains locked. A client node also might be locked if the client data is the subject of a legal investigation.

2. If you must unlock a client node, use the **UNLOCK NODE** command. For instructions, see [UNLOCK NODE \(Unlock a client node\)](#).
3. Generate a new password by issuing the **UPDATE NODE** command:

```
update node node_name new_password forcepwreset=yes
```

where *node_name* specifies the name of the node and *new_password* specifies the password that you assign.

4. Inform the client node owner about the changed password. When the owner of the client node logs in with the specified password, a new password is generated automatically. That password is unknown to users to enhance security.

Tip: The password is generated automatically if you previously set the **passwordaccess** option to generate in the client options file.

Modifying the scope of a client backup

When you set up client backup operations, the preferred practice is to exclude objects that you do not require. For example, you typically want to exclude temporary files from a backup operation.

About this task

When you exclude unnecessary objects from backup operations, you get better control of the amount of storage space that is required for backup operations, and the cost of storage. Depending on your licensing package, you also might be able to limit licensing costs.

Procedure

How you modify the scope of backup operations depends on the product that is installed on the client node:

- For a backup-archive client, you can create an include-exclude list to include or exclude a file, groups of files, or directories from backup operations. To create an include-exclude list, follow the instructions in [Creating an include-exclude list](#).

To ensure consistent use of an include-exclude list for all clients of one type, you can create a client option set on the server that contains the required options. Then, you assign the client option set to each of the clients of the same type. For details, see [Controlling client operations through client option sets](#).

- For a backup-archive client, you can specify the objects to include in an incremental backup operation by using the **domain** option. Follow the instructions in [Domain option](#).
- For other products, to define which objects are included in and excluded from backup operations, follow the instructions in the product documentation.

Managing client upgrades

When a fix pack or interim fix becomes available for a client, you can upgrade the client to take advantage of product improvements. Servers and clients can be upgraded at different times and can be at different levels with some restrictions.

Before you begin

1. Review the client/server compatibility requirements in [IBM Spectrum Protect Server-Client Compatibility and Upgrade Considerations](#) . If your solution includes servers or clients at a level that is earlier than V7.1, review the guidelines to ensure that client backup and archive operations are not disrupted.
2. Verify system requirements for the client in [IBM Spectrum Protect Supported Operating Systems](#).
3. If the solution includes storage agents or library clients, review the information about storage-agent and library-client compatibility with servers that are configured as library managers. See [Storage-agent and library-client compatibility with an IBM Spectrum Protect server](#) .

If you plan to upgrade a library manager and a library client, you must upgrade the library manager first.

Procedure

To upgrade the software, complete the instructions that are listed in the following table.

Software	Link to instructions
IBM Spectrum Protect backup-archive client	<ul style="list-style-type: none"> • Scheduling client updates
IBM Spectrum Protect Snapshot	<ul style="list-style-type: none"> • Installing and upgrading IBM Spectrum Protect Snapshot for UNIX and Linux • Installing and upgrading IBM Spectrum Protect Snapshot for VMware • Installing and upgrading IBM Spectrum Protect Snapshot for Windows
IBM Spectrum Protect for Databases	<ul style="list-style-type: none"> • Upgrading Data Protection for SQL Server • Data Protection for Oracle installation • Installing, upgrading, and migrating
IBM Spectrum Protect for Enterprise Resource Planning	<ul style="list-style-type: none"> • Upgrading • Upgrading
IBM Spectrum Protect for Mail	<ul style="list-style-type: none"> • Installation of Data Protection for IBM Domino on a UNIX, AIX, or Linux system (V7.1.0) • Installation of Data Protection for IBM Domino on a Windows system (V7.1.0) • Installing, upgrading, and migrating
IBM Spectrum Protect for Virtual Environments	<ul style="list-style-type: none"> • Installing and upgrading • Installing and upgrading Data Protection for Microsoft Hyper-V

Decommissioning a client node

If a client node is no longer required, you can start a process to remove it from the production environment. For example, if a workstation was backing up data to the IBM Spectrum Protect server, but the workstation is no longer used, you can decommission the workstation.

About this task

When you start the decommission process, the server locks the client node to prevent it from accessing the server. Files that belong to the client node are gradually deleted, and then the client node is deleted. You can decommission the following types of client nodes:

Application client nodes

Application client nodes include email servers, databases, and other applications. For example, any of the following applications can be an application client node:

- IBM Spectrum Protect Snapshot
- IBM Spectrum Protect for Databases
- IBM Spectrum Protect for Enterprise Resource Planning
- IBM Spectrum Protect for Mail
- IBM Spectrum Protect for Virtual Environments

System client nodes

System client nodes include workstations, network-attached storage (NAS) file servers, and API clients.

Virtual machine client nodes

Virtual machine client nodes consist of an individual guest host within a hypervisor. Each virtual machine is represented as a file space.

Restriction: You cannot decommission an object client node.

The simplest method for decommissioning a client node is to use the Operations Center. The decommission process runs in the background. If the client is configured to replicate client data, the Operations Center automatically removes the client from replication on the source and target replication servers before it decommissions the client.

Tip: Alternatively, you can decommission a client node by issuing the **DECOMMISSION NODE** or **DECOMMISSION VM** command. You might want to use this method in the following cases:

- To schedule the decommission process for the future or to run a series of commands by using a script, specify the decommission process to run in the background.
- To monitor the decommission process for debugging purposes, specify the decommission process to run in the foreground. If you run the process in the foreground, you must wait for the process to be completed before you continue with other tasks.

Procedure

Take one of the following actions:

- To decommission a client in the background by using the Operations Center, complete the following steps:
 - a) On the Operations Center **Overview** page, click **Clients** and select the client.
 - b) Click **More > Decommission**.
- To decommission a client node by using an administrative command, take one of the following actions:
 - To decommission an application or system client node in the background, issue the **DECOMMISSION NODE** command. For example, if the client node is named AUSTIN, issue the following command:

```
decommission node austin
```

- To decommission an application or system client node in the foreground, issue the **DECOMMISSION NODE** command and specify the `wait=yes` parameter. For example, if the client node is named AUSTIN, issue the following command:

```
decommission node austin wait=yes
```

- To decommission a virtual machine in the background, issue the **DECOMMISSION VM** command. For example, if the virtual machine is named AUSTIN, the file space is 7, and the file space name is specified by the file space ID, issue the following command:

```
decommission vm austin 7 nametype=fsid
```

If the virtual machine name includes one or more spaces, enclose the name in double quotation marks. For example:

```
decommission vm "austin 2" 7 nametype=fsid
```

- To decommission a virtual machine in the foreground, issue the **DECOMMISSION VM** command and specify the `wait=yes` parameter. For example, issue the following command:

```
decommission vm austin 7 nametype=fsid wait=yes
```

If the virtual machine name includes one or more spaces, enclose the name in double quotation marks. For example:

```
decommission vm "austin 2" 7 nametype=fsid wait=yes
```

What to do next

Watch for error messages, which might be displayed in the user interface or in the command output, immediately after you run the process.

You can verify that the client node is decommissioned:

1. On the Operations Center **Overview** page, click **Clients**.
2. In the Clients table, in the At risk column, review the state:
 - A DECOMMISSIONED state specifies that the node is decommissioned.
 - A null value specifies that the node is not decommissioned.
 - A PENDING state specifies that the node is being decommissioned, or the decommission process failed.

Tip: If you want to determine the status of a pending decommission process, issue the following command:

```
query process
```

3. Review the command output:

- If status is provided for the decommission process, the process is in progress. For example:

```
query process
```

Process Number	Process Description	Process Status
3	DECOMMISSION NODE	Number of backup objects deactivated for node NODE1: 8 objects deactivated.

- If no status is provided for the decommission process, and you did not receive an error message, the process is incomplete. A process can be incomplete if files that are associated with the node are not yet deactivated. After the files are deactivated, run the decommission process again.
- If no status is provided for the decommission process, and you receive an error message, the process failed. Run the decommission process again.

Tip: To reset the status of a node or virtual machine that was previously decommissioned, use the following administrative commands:

- To reset the status of a node that was previously decommissioned from the production environment by using the **DECOMMISSION NODE** command, use the **RECOMMISSION NODE** command.
- To reset the status of a virtual machine file space that was previously decommissioned from the production environment by using the **DECOMMISSION VM** command, use the **RECOMMISSION VM** command.

Related information

[DECOMMISSION NODE \(Decommission a client node\)](#)

[DECOMMISSION VM \(Decommission a virtual machine\)](#)

Deactivating data to free storage space

In some cases, you can deactivate data that is stored on the IBM Spectrum Protect server. When you run the deactivation process, any backup data that was stored before the specified date and time is deactivated and will be deleted as it expires. In this way, you can free space on the server.

About this task

Some application clients always save data to the server as active backup data. Because active backup data is not managed by inventory expiration policies, the data is not deleted automatically, and uses server storage space indefinitely. To free the storage space that is used by obsolete data, you can deactivate the data.

When you run the deactivation process, all active backup data that was stored before the specified date becomes inactive. The data is deleted as it expires and cannot be restored. The deactivation feature applies only to application clients that protect Oracle databases.

Procedure

1. From the Operations Center Overview page, click **Clients**.
2. In the Clients table, select one or more clients and click **More > Clean Up**.

Command-line method: Deactivate data by using the **DEACTIVATE DATA** command.

Related information

[DEACTIVATE DATA \(Deactivate data for a client node\)](#)

Managing data storage

Manage your data for efficiency and add supported devices and media to the server to store client data.

Related information

[Storage pool types](#)

Auditing a storage pool container

Audit a storage pool container to check for inconsistencies between database information and a container in a storage pool.

About this task

You audit a storage pool container in the following situations:

- When you issue the **QUERY DAMAGED** command and a problem is detected
- When the server displays messages about damaged data extents
- Your hardware reports an issue and error messages that are associated with the storage pool container are displayed

Procedure

1. To audit a storage pool container, issue the **AUDIT CONTAINER** command.
For example, issue the following command to audit a container, 000000000000076c.dcf:

```
audit container c:\tsm-storage\07\000000000000076c.dcf
```

2. Review the output from the ANR4891I message for information about any damaged data extents.

What to do next

If you detect problems with the storage pool container, you can restore data based on your configuration. Issue the **AUDIT CONTAINER** command and specify the container name.

Related information

[AUDIT CONTAINER \(Verify the consistency of database information for a directory-container storage pool\)](#)

[QUERY DAMAGED \(Query damaged data in a directory-container or cloud-container storage pool\)](#)

Managing inventory capacity

Manage the capacity of the database, active log, and archive logs to ensure that the inventory is sized for the tasks, based on the status of the logs.

Before you begin

The active and archive logs have the following characteristics:

- The active log can be a maximum size of 512 GB. For more information about sizing the active log for your system, see [Planning the storage arrays](#).
- The archive log size is limited to the size of the file system that it is installed on. The archive log size is not maintained at a predefined size like the active log. Archive log files are automatically deleted after they are no longer needed.

As a best practice, you can optionally create an archive failover log to store archive log files when the archive log directory is full.

Check the Operations Center to determine the component of the inventory that is full. Ensure that you stop the server before you increase the size of one of the inventory components.

Procedure

- To increase the size of the database, complete the following steps:
 - Create one or more directories for the database on separate drives or file systems.
 - Issue the **EXTEND DBSPACE** command to add the directory or directories to the database. The directories must be accessible to the instance user ID of the database manager. By default, data is redistributed across all database directories and space is reclaimed.

Tips:

- The time that is needed to complete redistribution of data and reclaiming of space is variable, depending on the size of your database. Make sure that you plan adequately.
- Ensure that the directories that you specify are the same size as existing directories to ensure a consistent degree of parallelism for database operations. If one or more directories for the database are smaller than the others, they reduce the potential for optimized parallel prefetching and distribution of the database.
- Halt and restart the server to fully use the new directories.
- Reorganize the database if necessary. Index and table reorganization for the server database can help to avoid unexpected database growth and performance issues. For more information about reorganizing the database, see [Resolving and preventing issues related to database growth and degraded performance in Tivoli Storage Manager V7.1.1.200 and later servers](#).
- To decrease the size of the database for V7.1 servers and later, issue the following IBM Db2 commands from the server instance directory:

Restriction: The commands can increase I/O activity, and might affect server performance. To minimize performance problems, wait until one command is completed before you issue the next command. The Db2 commands can be issued when the server is running.

```
db2 connect to tsmbd1
db2 set schema tsmbd1
db2 ALTER TABLESPACE USERSPACE1 REDUCE MAX
db2 ALTER TABLESPACE IDXSPACE1 REDUCE MAX
db2 ALTER TABLESPACE LARGEIDXSPACE1 REDUCE MAX
db2 ALTER TABLESPACE LARGESPACE1 REDUCE MAX
db2 ALTER TABLESPACE REPLTBLSPACE1 REDUCE MAX
db2 ALTER TABLESPACE REPLIDXSPACE1 REDUCE MAX
db2 ALTER TABLESPACE ARCHOBJDATASPACE REDUCE MAX
db2 ALTER TABLESPACE ARCHOBJIDXSPACE REDUCE MAX
db2 ALTER TABLESPACE BACKOBJDATASPACE REDUCE MAX
db2 ALTER TABLESPACE BACKOBJIDXSPACE REDUCE MAX
db2 ALTER TABLESPACE BFABFDATASPACE REDUCE MAX
db2 ALTER TABLESPACE BFABFIDXSPACE REDUCE MAX
db2 ALTER TABLESPACE BFBFEXTDATASPACE REDUCE MAX
db2 ALTER TABLESPACE BFBFEXTIDXSPACE REDUCE MAX
db2 ALTER TABLESPACE DEDUPTBLSPACE1 REDUCE MAX
db2 ALTER TABLESPACE DEDUPIIDXSPACE1 REDUCE MAX
db2 ALTER TABLESPACE DEDUPTBLSPACE2 REDUCE MAX
db2 ALTER TABLESPACE DEDUPIIDXSPACE2 REDUCE MAX
db2 ALTER TABLESPACE DEDUPTBLSPACE3 REDUCE MAX
db2 ALTER TABLESPACE DEDUPIIDXSPACE3 REDUCE MAX
db2 ALTER TABLESPACE DEDUPTBLSPACE4 REDUCE MAX
db2 ALTER TABLESPACE DEDUPIIDXSPACE4 REDUCE MAX
db2 ALTER TABLESPACE DEDUPTBLSPACE5 REDUCE MAX
db2 ALTER TABLESPACE DEDUPIIDXSPACE5 REDUCE MAX
```

- To increase or decrease the size of the active log, complete the following steps:
 - a) Ensure that the location for the active log has enough space for the increased log size. If a log mirror exists, its location must also have enough space for the increased log size.
 - b) Halt the server.
 - c) In the `dsmserv.opt` file, update the **ACTIVELOGSIZE** option to the new size of the active log, in megabytes.

The size of an active log file is based on the value of the **ACTIVELOGSIZE** option. Guidelines for space requirements are in the following table:

<i>Table 17. How to estimate volume and file space requirements</i>	
ACTIVELOGSize option value	Reserve this much free space in the active log directory, in addition to the ACTIVELOGSize space
16 GB - 128 GB	5120 MB
129 GB - 256 GB	10240 MB
257 GB - 512 GB	20480 MB

To change the active log to its maximum size of 512 GB, enter the following server option:

```
activelogsize 524288
```

- d) If you plan to use a new active log directory, update the directory name that is specified in the **ACTIVELOGDIRECTORY** server option. The new directory must be empty and must be accessible to the user ID of the database manager.
 - e) Restart the server.
- Compress the archive logs to reduce the amount of space that is required for storage. Enable dynamic compression of the archive log by issuing the following command:

```
setopt archlogcompress yes
```

Restriction: Use caution when you enable the **ARCHLOGCOMPRESS** server option on systems with sustained high volume usage and heavy workloads. Enabling this option in this system environment can cause delays in archiving log files from the active log file system to the archive log file system. This delay can cause the active log file system to run out of space. Be sure to monitor the available space in the active log file system after archive log compression is enabled. If the active log directory file system usage nears out of space conditions, the **ARCHLOGCOMPRESS** server option must be disabled. You can use the **SETOPT** command to disable archive log compression immediately without halting the server.

Related information

[ACTIVELOGSIZE server option](#)

[EXTEND DBSPACE \(Increase space for the database\)](#)

[SETOPT \(Set a server option for dynamic update\)](#)

Managing memory and processor usage

Ensure that you manage memory requirements and processor usage to ensure that the server can complete data processes such as backup and data deduplication. Consider the impact on performance when you complete certain processes.

Before you begin

- Ensure that your configuration uses the required hardware and software. For more information, see [IBM Spectrum Protect Supported Operating Systems](#).
- For more information about managing resources such as the database and recovery log, see [Planning the storage arrays](#).
- Add more system memory to determine whether there is a performance improvement. Monitor memory usage regularly to determine whether more memory is required.

Procedure

1. Release memory from the file system cache where possible.
2. To manage the system memory that is used by each server on a system, use the **DBMEMPERCENT** server option. Limit the percentage of system memory that can be used by the database manager of each server. If all servers are equally important, use the same value for each server. If one server is a production server and other servers are test servers, set the value for the production server to a higher value than the test servers.
3. Set the user data limit and private memory for the database to ensure that private memory is not exhausted. Exhausting private memory can result in errors, less than optimal performance, and instability.

Tuning scheduled activities

Schedule maintenance tasks daily to ensure that your solution operates correctly. By tuning your solution, you maximize server resources and effectively use different functions available within your solution.

Procedure

1. Monitor system performance regularly to ensure that backup and maintenance tasks are completing successfully. For more information about monitoring, see [Part 3, “Monitoring a single-site disk solution,” on page 51](#).
2. If the monitoring information shows that the server workload increased, you might need to review the planning information. Review whether the capacity of the system is adequate in the following cases:
 - The number of clients increases
 - The amount of data that is being backed up increases
 - The amount of time that is available for backups changes

3. Determine whether your solution has performance issues.
Review the client schedules to check whether tasks are completing within the scheduled time frame:
 - a. On the **Clients** page of the Operations Center, select the client.
 - b. Click **Details**.
 - c. From the client **Summary** page, review the **Backed up** and **Replicated** activity to identify any risks.
Adjust the time and frequency of client backup operations, if necessary.
4. Schedule enough time for the following maintenance tasks to complete successfully within a 24-hour period:
 - a. Back up the database
 - b. Run expiration to remove client backups and archive file copies from server storage.

Related information

[Deduplicating data \(V7.1.1\)](#)

[Performance](#)

Securing the IBM Spectrum Protect server

Secure the IBM Spectrum Protect server and data by controlling access to servers and client nodes, encrypting data, and maintaining secure access levels and passwords.

Security concepts

You can protect IBM Spectrum Protect from security risks by using communication protocols, securing passwords, and providing different access levels for administrators.

Transport Layer Security

You can use the Secure Sockets Layer (SSL) or the Transport Layer Security (TLS) protocol to provide transport layer security for a secure connection between servers, clients, and storage agents. If you send data between the server, client, and storage agent, use SSL or TLS to encrypt the data.

Tip: Any IBM Spectrum Protect documentation that indicates "SSL" or to "select SSL" applies to TLS.

SSL is provided by the Global Security Kit (GSKit) that is installed with the IBM Spectrum Protect server that the server, client, and storage agent use.

Restriction: Do not use the SSL or TLS protocols for communications with an IBM Db2 database instance that is used by any IBM Spectrum Protect servers.

Each server, client, or storage agent that enables SSL must use a trusted self-signed certificate or obtain a unique certificate that is signed by a certificate authority (CA). You can use your own certificates or purchase certificates from a CA. Either certificate must be installed and added to the key database on the IBM Spectrum Protect server, client, or storage agent. The certificate is verified by the SSL client or server that requests or initiates the SSL communication. Some CA certificates are preinstalled in the key databases, by default.

SSL is set up independently on the IBM Spectrum Protect server, client, and storage agent.

Authority levels

With each IBM Spectrum Protect server, different administrative authority levels are available that determine the tasks that an administrator can complete.

After registration, an administrator must be granted authority by being assigned one or more administrative authority levels. An administrator with system authority can complete any task with the

server and assign authority levels to other administrators by using the **GRANT AUTHORITY** command. Administrators with policy, storage, or operator authority can complete subsets of tasks.

An administrator can register other administrator IDs, grant levels of authority to them, rename IDs, remove IDs, and lock and unlock them from the server.

An administrator can control access to specific client nodes for root user IDs and non-root user IDs. By default, a non-root user ID cannot back up data on the node. Use the **UPDATE NODE** command to change the node settings to enable backup.

Passwords

By default, the server automatically uses password authentication. With password authentication, all users must enter a password when they access the server.

Use Lightweight Directory Access Protocol (LDAP) to apply stricter requirements for passwords. For more information, see [Managing passwords and log on procedures \(V7.1.1\)](#).

<i>Table 18. Password authentication characteristics</i>	
Characteristic	More information
Case-sensitivity	Not case-sensitive.
Default password expiration	90 days. The expiration period begins when an administrator ID or client node is first registered to the server. If the password is not changed within this period, the password must be changed the next time that the user accesses the server.
Invalid password attempts	You can set a limit on consecutive invalid password attempts for all client nodes. When the limit is exceeded, the server locks the node.
Default password length	8 characters. The administrator can specify a minimum length. Beginning with Version 8.1.4, the default minimum length for server passwords changed from 0 to 8 characters.

Session security

Session security is the level of security that is used for communication among IBM Spectrum Protect client nodes, administrative clients, and servers and is set by using the **SESSIONSECURITY** parameter.

The **SESSIONSECURITY** parameter can be set to one of the following values:

- The **STRICT** value enforces the highest level of security for communication between IBM Spectrum Protect servers, nodes, and administrators.
- The **TRANSITIONAL** value specifies that the existing communication protocol is used while you update your IBM Spectrum Protect software to V8.1.2 or later. This is the default. When **SESSIONSECURITY=TRANSITIONAL**, stricter security settings are automatically enforced as higher versions of the TLS protocol are used and as the software is updated to V8.1.2 or later. After a node, administrator, or server meets the requirements for the **STRICT** value, session security is automatically updated to the **STRICT** value, and the entity can no longer authenticate by using a previous version of the client or earlier TLS protocols.

Note: You are not required to update backup-archive clients to V8.1.2 or later before you upgrade servers. After you upgrade a server to V8.1.2 or later, nodes and administrators that are using earlier versions of the software will continue to communicate with the server by using the **TRANSITIONAL**

value until the entity meets the requirements for the STRICT value. Similarly, you can upgrade backup-archive clients to V8.1.2 or later before you upgrade your IBM Spectrum Protect servers, but you are not required to upgrade servers first. Communication between servers and clients is not interrupted.

For more information about the **SESSIONSECURITY** parameter values, see the following commands.

<i>Table 19. Commands used to set the SESSIONSECURITY parameter</i>	
Entity	Command
Client nodes	<ul style="list-style-type: none"> • REGISTER NODE • UPDATE NODE
Administrators	<ul style="list-style-type: none"> • REGISTER ADMIN • UPDATE ADMIN
Servers	<ul style="list-style-type: none"> • DEFINE SERVER • UPDATE SERVER

Administrators that authenticate by using the **DSMADMC** command, **DSMC** command, or dsm program cannot authenticate by using an earlier version after authenticating by using V8.1.2 or later. To resolve authentication issues for administrators, see the following tips:

Tips:

- Ensure that all IBM Spectrum Protect software that the administrator account uses to log on is upgraded to V8.1.2 or later. If an administrator account logs on from multiple systems, ensure that the server's certificate is installed on each system.
- After an administrator successfully authenticates with the server by using V8.1.2 or later software or V7.1.8 or later software, the administrator can no longer authenticate with that server using client or server versions earlier than V8.1.2 or V7.1.8. An administrator command can be issued from any system.
- If necessary, create a separate administrator account to use only with clients and servers that are using V8.1.1 or earlier software.

Enforce the highest level of security for communication with the IBM Spectrum Protect server by ensuring that all nodes, administrators, and servers use STRICT session security. You can use the **SELECT** command to determine which servers, nodes, and administrators are using TRANSITIONAL session security and should be updated to use STRICT session security.

Related information

[Securing communications](#)

Managing administrators

An administrator who has system authority can complete any task with the IBM Spectrum Protect server, including assigning authority levels to other administrators. To complete some tasks, you must be granted authority by being assigned one or more authority levels.

Procedure

Complete the following tasks to modify administrator settings.

Task	Procedure
Add an administrator.	<p>To add an administrator, ADMIN1, with system authority and specify a password, complete the following steps:</p> <ol style="list-style-type: none"> Register the administrator and specify Pa\$#\$twO as the password by issuing the following command: <pre data-bbox="899 415 1300 447">register admin admin1 Pa\$#\$twO</pre> Grant system authority to the administrator by issuing the following command: <pre data-bbox="899 562 1386 594">grant authority admin1 classes=system</pre>
Change administrative authority.	<p>Change the authority level for an administrator, ADMIN1.</p> <ul style="list-style-type: none"> Grant system authority to the administrator by issuing the following command: <pre data-bbox="899 800 1370 831">grant authority admin1 classes=system</pre> Revoke system authority for the administrator by issuing the following command: <pre data-bbox="899 936 1386 968">revoke authority admin1 classes=system</pre>
Remove administrators.	<p>Remove an administrator, ADMIN1, from accessing the IBM Spectrum Protect server by issuing the following command:</p> <pre data-bbox="899 1129 1117 1161">remove admin admin1</pre>
Temporarily prevent access to the server.	<p>Lock or unlock an administrator by using the LOCK ADMIN or UNLOCK ADMIN command.</p>

Changing password requirements

You can change the minimum password limit, password length, password expiration, and enable or disable authentication for IBM Spectrum Protect.

About this task

By enforcing password authentication and managing password restrictions, you protect your data and your servers from potential security risks.

Procedure

Complete the following tasks to change password requirements for IBM Spectrum Protect servers.

Table 20. Authentication tasks for IBM Spectrum Protect servers

Task	Procedure
Set a limit for invalid password attempts.	<p>a. On the Servers page in the Operations Center, select the server.</p> <p>b. Click Details, and then click the Properties tab.</p> <p>c. Set the number of invalid attempts in the Invalid sign-on attempt limit field.</p> <p>The default value at installation is 0.</p>
Set a minimum length for passwords.	<p>a. On the Servers page in the Operations Center, select the server.</p> <p>b. Click Details and then click the Properties tab.</p> <p>c. Set the number of characters in the Minimum password length field.</p>
Set the expiration period for passwords.	<p>a. On the Servers page in the Operations Center, select the server.</p> <p>b. Click Details and then click the Properties tab.</p> <p>c. Set the number of days in the Password common expiration field.</p>
Disable password authentication.	<p>By default, the server automatically uses password authentication. With password authentication, all users must enter a password to access the server.</p> <p>You can disable password authentication only for passwords that authenticate with the server (LOCAL). By disabling password authentication, you increase the security risk for the server.</p>
Set a default authentication method.	<p>Issue the SET DEFAULTAUTHENTICATION command. For example, to use the server as the default authentication method, issue the following command:</p> <pre data-bbox="873 1339 1468 1388">set defaultauthentication local</pre> <p>To update one client node to authenticate with the server, include AUTHENTICATION=LOCAL in the UPDATE NODE command:</p> <pre data-bbox="873 1514 1468 1562">update node authentication=local</pre>

Related information

[Authenticating IBM Spectrum Protect users by using an LDAP server](#)
[Managing passwords and log on procedures \(V7.1.1\)](#)

Securing the server on the system

Protect the system where the IBM Spectrum Protect server runs to prevent unauthorized access.

Procedure

Ensure that unauthorized users cannot access the directories for the server database and the server instance. Keep the access settings for these directories that you configured during implementation.

Restricting user access to the server

Authority levels determine what an administrator can do with the IBM Spectrum Protect server. An administrator with system authority can complete any task with the server. Administrators with policy, storage, or operator authority can complete subsets of tasks.

Procedure

1. After you register an administrator by using the **REGISTER ADMIN** command, use the **GRANT AUTHORITY** command to set the administrator's authority level.
For details about setting and changing authority, see “Managing administrators” on page 98.
2. To control the authority of an administrator to complete some tasks, use the following two server options:
 - a) You can select the authority level that an administrator must have to issue **QUERY** and **SELECT** commands with the **QUERYAUTH** server option. By default, no authority level is required. You can change the requirement to one of the authority levels, including system.
 - b) You can specify that system authority is required for commands that cause the server to write to an external file with the **REQSYSAUTHOUTFILE** server option. By default, system authority is required for such commands.
3. You can restrict data backup on a client node to only root user IDs or authorized users.
For example, to limit backups to the root user ID, issue the **REGISTER NODE** or **UPDATE NODE** command and specify the **BACKUPINITIATION=root** parameter:

```
update node backupinitiation=root
```

Limiting access through port restrictions

Limit access to the server by applying port restrictions.

About this task

You might have to restrict access to specific servers, based on your security requirements. The IBM Spectrum Protect server can be configured to listen on four TCP/IP ports: two that can be used for either regular TCP/IP protocols or Secure Sockets Layer (SSL)/Transport Layer Security (TLS) protocols and two that can be used only for the SSL/TLS protocol.

Procedure

You can set the server options to specify the port that you require, as listed in [Table 21 on page 101](#).

<i>Table 21. Server options and port access</i>	
Server option	Port access
TCPPORT	Specifies the port number on which the server TCP/IP communication driver is to wait for requests for client sessions. This port listens for both TCP/IP and SSL-enabled sessions. The default value is 1500.

Table 21. Server options and port access (continued)

Server option	Port access
TCPADMINPORT	Specifies the port number on which the server TCP/IP communication driver is to wait for requests for sessions other than client sessions. This port listens for both TCP/IP and SSL-enabled sessions. The default is the value of TCPPOINT . Use this option to separate administrative client traffic from regular client traffic that uses the TCPPOINT and SSLTCPPOINT options.
SSLTCPPOINT	Specifies the SSL TCP/IP port address for a server. This port listens for SSL-enabled sessions only. A default port value is not available.
SSLTCPADMINPORT	Specifies the port address on which the server TCP/IP communication driver waits for requests for SSL-enabled sessions. A default port value is not available. Use this option to separate administrative client traffic from regular client traffic that uses the TCPPOINT and SSLTCPPOINT options.

Restrictions:

The following restrictions apply when you specify the SSL-only server ports (**SSLTCPPOINT** and **SSLTCPADMINPORT**):

- When you specify the server's SSL-only port for the **LLADDRESS** on the **DEFINE SERVER** or **UPDATE SERVER** command, you must also specify the **SSL=YES** parameter.
- When you specify the server's SSL-only port for the client's **TCPPOINT** option, you must also specify **YES** for the SSL client option.

Related reference

[Planning firewall access](#)

Determine the firewalls that are set and the ports that must be open for the IBM Spectrum Protect solution to work.

Stopping and starting the server

Before you complete maintenance or reconfiguration tasks, stop the server. Then, start the server in maintenance mode. When you are finished with the maintenance or reconfiguration tasks, restart the server in production mode.

Before you begin

You must have system or operator privilege to stop and start the IBM Spectrum Protect server.

Stopping the server

Before you stop the server, prepare the system by ensuring that all database backup operations are completed, and all other processes and sessions are ended. In this way, you can safely shut down the server and ensure that data is protected.

About this task

When you issue the **HALT** command to stop the server, the following actions occur:

- All processes and client node sessions are canceled.
- All current transactions are stopped. (The transactions will be rolled back when the server is restarted.)

Procedure

To prepare the system and stop the server, complete the following steps:

1. Prevent new client node sessions from starting by issuing the **DISABLE SESSIONS** command:

```
disable sessions all
```

2. Determine whether any client node sessions or processes are in progress by completing the following steps:

- a. On the **Overview** page of the Operations Center, view the **Activity** area for the total numbers of processes and sessions that are currently active. If numbers differ significantly from the usual numbers that are displayed during your daily storage-management routine, view other status indicators in the Operations Center to check whether there is a problem.
- b. View the graph in the **Activity** area to compare the amount of network traffic over the following periods:

- The current period, that is, the most recent 24-hour period
- The previous period, that is, the 24 hours before the current period

If the graph for the previous period represents the expected amount of traffic, significant differences on the graph for the current period might indicate a problem.

- c. On the **Servers** page, select a server for which you want to view processes and sessions, and click **Details**. If the server is not registered as a hub or spoke server in the Operations Center, obtain information about processes by using administrative commands. Issue the **QUERY PROCESS** command to query processes and obtain information about sessions by issuing the **QUERY SESSION** command.
3. Wait until the client node sessions are completed or cancel them. To cancel processes and sessions, complete the following steps:
 - On the **Servers** page, select a server for which you want to view processes and sessions, and click **Details**.
 - Click the **Active Tasks** tab, and select one or more processes, sessions, or a combination of both that you want to cancel.
 - Click **Cancel**.
 - If the server is not registered as a hub or spoke server in the Operations Center, cancel sessions by using administrative commands. Issue the **CANCEL SESSION** command to cancel a session and cancel processes by using the **CANCEL PROCESS** command.

Tip: If the process that you want to cancel is waiting for a tape volume to be mounted, the mount request is canceled. For example, if you issue an **EXPORT**, **IMPORT**, or **MOVE DATA** command, the command might initiate a process that requires a tape volume to be mounted. However, if a tape volume is being mounted by an automated library, the cancel operation might not take effect until the mount process is complete. Depending on your system environment, this could take several minutes.

4. Stop the server by issuing the **HALT** command:

```
halt
```

Starting the server for maintenance or reconfiguration tasks

Before you begin server maintenance or reconfiguration tasks, start the server in maintenance mode. When you start the server in maintenance mode, you disable operations that might disrupt your maintenance or reconfiguration tasks.

About this task

Start the server in maintenance mode by running the **DSMSERV** utility with the **MAINTENANCE** parameter.

The following operations are disabled in maintenance mode:

- Administrative command schedules
- Client schedules
- Reclamation of storage space on the server
- Inventory expiration
- Migration of storage pools

In addition, clients are prevented from starting sessions with the server.

Tips:

- You do not have to edit the server options file, `dsmservev.opt`, to start the server in maintenance mode.
- While the server is running in maintenance mode, you can manually start the storage-space reclamation, inventory expiration, and storage-pool migration processes.

Procedure

- To start the server in maintenance mode, issue the following command:

```
dsmservev maintenance
```

Tip: To view a video about starting the server in maintenance mode, see [Starting a server in maintenance mode](#).

What to do next

To resume server operations in production mode, complete the following steps:

1. Shut down the server by issuing the **HALT** command:

```
halt
```

2. Start the server by using the method that you use in production mode. Follow the instructions for your operating system:
 - [AIX](#) Starting the server instance
 - [Linux](#) Starting the server instance
 - [Windows](#) Starting the server instance

Operations that were disabled during maintenance mode are reenabled.

Planning to upgrade the server

When a fix pack or interim fix becomes available, you can upgrade the IBM Spectrum Protect server to take advantage of product improvements. Servers and clients can be upgraded at different times. Ensure that you complete the planning steps before you upgrade the server.

About this task

Follow these guidelines:

- The preferred method is to upgrade the server by using the installation wizard. After you start the wizard, in the **IBM Installation Manager** window, click the **Update** icon; do not click the **Install** or **Modify** icon.
- If upgrades are available for both the server component and the Operations Center component, select the check boxes to upgrade both components.

Procedure

1. Review the list of fix packs and interim fixes. See [IBM Spectrum Protect Downloads - Latest Fix Packs and Interim Fixes](#).
2. Review product improvements, which are described in readme files.

Tip: When you obtain the installation package file from the [IBM Spectrum Protect support site](#), you can also access the readme file.

3. Ensure that the version that you upgrade your server to is compatible with other components, such as storage agents and library clients. See [Storage-agent and library-client compatibility with an IBM Spectrum Protect server](#).
4. If your solution includes servers or clients at a level that is earlier than V7.1, review the guidelines to ensure that client backup and archive operations are not disrupted. See [IBM Spectrum Protect Server-Client Compatibility and Upgrade Considerations](#).
5. Review the upgrade instructions. Ensure that you back up the server database, the device configuration information, and the volume history file.

What to do next

To install a fix pack or interim fix, follow the instructions for your operating system:

- **AIX** [Installing an IBM Spectrum Protect server fix pack](#)
- **Linux** [Installing an IBM Spectrum Protect server fix pack](#)
- **Windows** [Installing an IBM Spectrum Protect server fix pack](#)

Preparing for an outage or system update

Prepare IBM Spectrum Protect to maintain your system in a consistent state during a planned power outage or system update.

About this task

Ensure that you schedule activities regularly to manage, protect, and maintain the server.

Procedure

1. Cancel processes and sessions that are in progress by completing the following steps:
 - a. In the Operations Center, on the **Servers** page, select a server for which you want to view processes and sessions, and click **Details**.
 - b. Click the **Active Tasks** tab, and select one or more processes, sessions, or a combination of both that you want to cancel.
 - c. Click **Cancel**.
2. Stop the server by issuing the **HALT** command:

```
halt
```

Tip: You can issue the halt command from the Operations Center by hovering over the **Settings** icon and clicking **Command Builder**. Then, select the server, type halt, and press **Enter**.

Implementing a disaster recovery plan

Implement a disaster recovery strategy to recover your applications if a disaster occurs and to ensure high server availability.

About this task

Determine your disaster recovery requirements by identifying the business priorities for client node recovery, the systems that you use to recover data, and whether client nodes have connectivity to a recovery server. Use replication and storage pool protection to protect data. You must also determine how often directory-container storage pools are protected.

Completing recovery drills

Schedule disaster recovery drills to prepare for audits that certify the recoverability of the IBM Spectrum Protect server and to ensure that data can be restored and operations can resume after an outage. A drill also helps you ensure that all data can be restored and operations resumed before a critical situation occurs.

About this task

Restrictions: The following restrictions apply to single-site disk solutions:

- You can only restore the database.
- You cannot use replication because you do not have a target server at a recovery site.
- You cannot recover from damage to storage pools.

Procedure

Ensure that the database is backed up by completing the following steps:

- a. On the **TSM Servers** page of the Operations Center, select the server whose database you want to back up.
- b. Click **Back Up**, and follow the instructions in the **Back Up Server Database** window.

Recovering from system outages

For IBM Spectrum Protect single-site disk solutions, you can recover the inventory locally only and restore the database to protect your data.

Procedure

Use one of the following methods to recover inventory to a local site, based on the type of information that is backed up.

Restriction: Because single-site disk solutions do not have a second copy of the storage pool, you cannot restore storage pools. To review the architecture of disk solutions, see [Selecting an IBM Spectrum Protect solution for your environment](#).

Table 22. Scenarios for recovering from a disaster

Scenario	Procedure
Your system is inaccessible and you want to locally restore to an earlier version by using system tools.	<ul style="list-style-type: none"> • Use IBM Spectrum Protect to back up the server to another server. • Use operating system tools to back up and restore your system to an earlier version.
An outage or disaster occurs and you want to restore your data from backed up versions of the data.	<ul style="list-style-type: none"> • To back up a client, on the TSM Clients page of the Operations Center, select the clients that you want to back up, and click Back Up. • On the TSM Servers page of the Operations Center, select the server whose database you want to back up. Click Back Up, and follow the instructions in the Back Up Server Database window. <p>To restore a storage pool from a backed-up version of the storage pool, you must restore the database. Issue the DSMSERV RESTORE DB command to restore the database and associated storage pools to a backed-up version.</p>

Related information

[AUDIT CONTAINER \(Verify the consistency of database information for a directory-container storage pool\)](#)

[DSMSERV RESTORE DB \(Restore the database\)](#)

Restoring the database

You might have to restore the IBM Spectrum Protect database after a disaster. You can restore the database to the most current state or to a specified point in time. You must have full, incremental, or snapshot database backup volumes to restore the database.

Before you begin

If the database and recovery log directories are lost, re-create them before you issue the **DSMSERV RESTORE DB** server utility. For example, use the following commands:

```
Linux | AIX
mkdir /tsmdb001
mkdir /tsmdb002
mkdir /tsmdb003
mkdir /activelog
mkdir /archlog
mkdir /archfaillog
```

```
Windows
mkdir e:\tsm\db001
mkdir f:\tsm\db001
mkdir g:\tsm\db001
mkdir h:\tsm\activelog
mkdir i:\tsm\archlog
mkdir j:\tsm\archfaillog
```

Restrictions:

- To restore the database to its latest version, you must locate the archive log directory. If you are cannot locate the directory, you can restore the database only to a point in time.
- You cannot use Secure Sockets Layer (SSL) for database restore operations.

- If the release level of the database backup is different from the release level of the server that is being restored, you cannot restore the server database. For example, if you are using a Version 8.1 server and you try to restore a Version 7.1 database, an error occurs.

About this task

Point-in-time restore operations are typically used for situations such as disaster recovery or to remove the effects of errors that can cause inconsistencies in the database. To recover the database to the time when the database was lost, recover the database to its latest version.

Procedure

Use the **DSMSERV RESTORE DB** server utility to restore the database. Depending on the version of the database that you want to restore, choose one of the following methods:

- Restore a database to its latest version. For example, use the following command:

```
dsmserv restore db
```

- Restore a database to a point in time. For example, to restore the database to a backup series that was created on 19 April 2015, use the following command:

```
dsmserv restore db todate=04/19/2015
```

What to do next

If you restored the database and directory-container storage pools exist on the server, you must identify inconsistencies between the database and the file system.

1. If you restored the database to a point in time and you did not delay reuse of the directory-container storage pool, you must audit all the containers. To audit all containers, issue the following command:

```
audit container stgpool
```

2. If the server cannot identify containers on the system, complete the following steps to display a list of containers:

- a. From an administrative client, issue the following command:

```
select container_name from containers
```

- b. From the file system, issue the following command for the storage pool directory on the source server:

Tip: The storage pool directory is displayed in the command output:

```
Linux | AIX [root@source]$ ls -lR
```

```
Windows c:\source_stgpooldir>dir /s
```

- c. Compare the containers that are listed on the file system and the server.
- d. Issue the **AUDIT CONTAINER** command and specify the container that is missing from the server output. Specify the **ACTION=REMOVEDAMAGED** parameter to delete the container.
- e. To ensure that the containers are deleted on the file system, review the messages that are displayed.

Tip: After a database restore operation, if containers exist on the file system that are not referenced in the server database, the **QUERY STGPOOL** command inaccurately displays the storage pool usage. When you restore a database to a point in time, containers might remain on the file system, but are not referenced in the server database. To help ensure accurate statistics about storage pool usage, you must manually delete any containers that are available on the file system, but are not referenced in the server database.

Appendix A. Accessibility features for the IBM Spectrum Protect product family

Accessibility features assist users who have a disability, such as restricted mobility or limited vision, to use information technology content successfully.

Overview

The IBM Spectrum Protect family of products includes the following major accessibility features:

- Keyboard-only operation
- Operations that use a screen reader

The IBM Spectrum Protect family of products uses the latest W3C Standard, [WAI-ARIA 1.0](http://www.w3.org/TR/wai-aria/) (www.w3.org/TR/wai-aria/), to ensure compliance with [US Section 508](http://www.access-board.gov/guidelines-and-standards/communications-and-it/about-the-section-508-standards/section-508-standards) (www.access-board.gov/guidelines-and-standards/communications-and-it/about-the-section-508-standards/section-508-standards) and [Web Content Accessibility Guidelines \(WCAG\) 2.0](http://www.w3.org/TR/WCAG20/) (www.w3.org/TR/WCAG20/). To take advantage of accessibility features, use the latest release of your screen reader and the latest web browser that is supported by the product.

The product documentation in IBM Knowledge Center is enabled for accessibility. The accessibility features of IBM Knowledge Center are described in the [Accessibility](http://www.ibm.com/support/knowledgecenter/about/releasenotes.html?view=kc#accessibility) section of the [IBM Knowledge Center help](http://www.ibm.com/support/knowledgecenter/about/releasenotes.html?view=kc#accessibility) (www.ibm.com/support/knowledgecenter/about/releasenotes.html?view=kc#accessibility).

Keyboard navigation

This product uses standard navigation keys.

Interface information

User interfaces do not have content that flashes 2 - 55 times per second.

Web user interfaces rely on cascading style sheets to render content properly and to provide a usable experience. The application provides an equivalent way for low-vision users to use system display settings, including high-contrast mode. You can control font size by using the device or web browser settings.

Web user interfaces include WAI-ARIA navigational landmarks that you can use to quickly navigate to functional areas in the application.

Vendor software

The IBM Spectrum Protect product family includes certain vendor software that is not covered under the IBM license agreement. IBM makes no representation about the accessibility features of these products. Contact the vendor for accessibility information about its products.

Related accessibility information

In addition to standard IBM help desk and support websites, IBM has a TTY telephone service for use by deaf or hard of hearing customers to access sales and support services:

TTY service
800-IBM-3383 (800-426-3383)
(within North America)

For more information about the commitment that IBM has to accessibility, see [IBM Accessibility](http://www.ibm.com/able) (www.ibm.com/able).

Notices

This information was developed for products and services offered in the US. This material might be available from IBM in other languages. However, you may be required to own a copy of the product or product version in that language in order to access it.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing
IBM Corporation
North Castle Drive, MD-NC119
Armonk, NY 10504-1785
US*

For license inquiries regarding double-byte character set (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

*Intellectual Property Licensing
Legal and Intellectual Property Law
IBM Japan Ltd.
19-21, Nihonbashi-Hakozakicho, Chuo-ku
Tokyo 103-8510, Japan*

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product and use of those websites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact:

*IBM Director of Licensing
IBM Corporation
North Castle Drive, MD-NC119
Armonk, NY 10504-1785
US*

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment of a fee.

The licensed program described in this document and all licensed material available for it are provided by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement or any equivalent agreement between us.

The performance data discussed herein is presented as derived under specific operating conditions. Actual results may vary.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

COPYRIGHT LICENSE:

This information contains sample application programs in source language, which illustrate programming techniques on various operating platforms. You may copy, modify, and distribute these sample programs in any form without payment to IBM, for the purposes of developing, using, marketing or distributing application programs conforming to the application programming interface for the operating platform for which the sample programs are written. These examples have not been thoroughly tested under all conditions. IBM, therefore, cannot guarantee or imply reliability, serviceability, or function of these programs. The sample programs are provided "AS IS", without warranty of any kind. IBM shall not be liable for any damages arising out of your use of the sample programs.

Each copy or any portion of these sample programs or any derivative work must include a copyright notice as follows: © (your company name) (year). Portions of this code are derived from IBM Corp. Sample Programs. © Copyright IBM Corp. _enter the year or years_.

Trademarks

IBM, the IBM logo, and ibm.com® are trademarks or registered trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies. A current list of IBM trademarks is available on the Web at "Copyright and trademark information" at www.ibm.com/legal/copytrade.shtml.

Adobe is a registered trademark of Adobe Systems Incorporated in the United States, and/or other countries.

Linear Tape-Open, LTO, and Ultrium are trademarks of HP, IBM Corp. and Quantum in the U.S. and other countries.

Intel and Itanium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

Java™ and all Java-based trademarks and logos are trademarks or registered trademarks of Oracle and/or its affiliates.

UNIX is a registered trademark of The Open Group in the United States and other countries.

VMware, VMware vCenter Server, and VMware vSphere are registered trademarks or trademarks of VMware, Inc. or its subsidiaries in the United States and/or other jurisdictions.

Terms and conditions for product documentation

Permissions for the use of these publications are granted subject to the following terms and conditions.

Applicability

These terms and conditions are in addition to any terms of use for the IBM website.

Personal use

You may reproduce these publications for your personal, noncommercial use provided that all proprietary notices are preserved. You may not distribute, display or make derivative work of these publications, or any portion thereof, without the express consent of IBM.

Commercial use

You may reproduce, distribute and display these publications solely within your enterprise provided that all proprietary notices are preserved. You may not make derivative works of these publications, or reproduce, distribute or display these publications or any portion thereof outside your enterprise, without the express consent of IBM.

Rights

Except as expressly granted in this permission, no other permissions, licenses or rights are granted, either express or implied, to the publications or any information, data, software or other intellectual property contained therein.

IBM reserves the right to withdraw the permissions granted herein whenever, in its discretion, the use of the publications is detrimental to its interest or, as determined by IBM, the above instructions are not being properly followed.

You may not download, export or re-export this information except in full compliance with all applicable laws and regulations, including all United States export laws and regulations.

IBM MAKES NO GUARANTEE ABOUT THE CONTENT OF THESE PUBLICATIONS. THE PUBLICATIONS ARE PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, AND FITNESS FOR A PARTICULAR PURPOSE.

Privacy policy considerations

IBM Software products, including software as a service solutions, ("Software Offerings") may use cookies or other technologies to collect product usage information, to help improve the end user experience, to tailor interactions with the end user, or for other purposes. In many cases no personally identifiable information is collected by the Software Offerings. Some of our Software Offerings can help enable you to collect personally identifiable information. If this Software Offering uses cookies to collect personally identifiable information, specific information about this offering's use of cookies is set forth below.

This Software Offering does not use cookies or other technologies to collect personally identifiable information.

If the configurations deployed for this Software Offering provide you as customer the ability to collect personally identifiable information from end users via cookies and other technologies, you should seek your own legal advice about any laws applicable to such data collection, including any requirements for notice and consent.

For more information about the use of various technologies, including cookies, for these purposes, see IBM's Privacy Policy at <http://www.ibm.com/privacy> and IBM's Online Privacy Statement at <http://www.ibm.com/privacy/details> in the section entitled "Cookies, Web Beacons and Other Technologies," and the "IBM Software Products and Software-as-a-Service Privacy Statement" at <http://www.ibm.com/software/info/product-privacy>.

Glossary

A glossary is available with terms and definitions for the IBM Spectrum Protect family of products.
See the [IBM Spectrum Protect glossary](#).

Index

A

About this publication [vii](#)
access
 limit [101](#)
 server options [101](#)
accessibility features [109](#)
active log capacity [93](#)
archive log capacity [93](#)
archive operations
 scheduling [79](#)
 specifying rules [76](#)
AUDIT CONTAINER [92](#)
audit storage pool [92](#)
authority level [98](#)

B

back-end capacity licensing [66](#)
backup operations
 modifying scope [88](#)
 scheduling [79](#)
 specifying rules [76](#)

C

client acceptor
 configuring [82](#)
 restarting [86](#)
 stopping [86](#)
client management service
 configure Operations Center to use [49](#)
 installing [48](#)
 verify installation [48](#)
client nodes
 decommissioning [89](#)
 removing from production [89](#)
client/server communications
 configuring [84](#)
clients
 adding [74](#)
 assign to schedules [47](#)
 configuring [47](#), [81](#)
 configuring to run scheduled operations [82](#)
 connecting to server [80](#)
 define schedules [47](#)
 installing [47](#), [81](#)
 managing operations [85](#)
 protecting [74](#)
 register [47](#)
 registering [80](#)
 selecting software [75](#)
 upgrading [88](#)
commands
 HALT [102](#)
configuration
 changing [86](#)

configuration (*continued*)
 clients [81](#)
configuring
 clients [47](#)
 spoke server [69](#)

D

daily checklist of monitoring tasks [51](#)
data
 deactivating [92](#)
data deduplication
 configure [44](#)
data recovery
 strategy [106](#)
data retention rules
 define [44](#)
database capacity [93](#)
database restore [107](#)
deactivation process
 backup data [92](#)
decommission process
 client node [89](#)
disability [109](#)
disaster recovery [106](#)
disaster recovery manager [106](#)
DRM [106](#)
DSMSERV RESTORE DB [107](#)

E

email reports
 configuring [68](#)
error logs
 evaluating [85](#)

F

file systems
 [preparing, AIX server systems [32](#)
 planning for [5](#)
 preparing, Linux server systems [34](#)
 preparing, Windows server systems [34](#)
firewall [19](#)
firewalls
 configuring communications through [84](#)
front-end capacity licensing [66](#)

G

graphical wizard
 prerequisite RPM files [36](#)

H

halting

- halting *(continued)*
 - server [102](#)
- hardware requirements [2](#)
- hub server
 - changing [72](#)
 - restore to preconfigured state [72](#)

I

- IBM Knowledge Center [vii](#)
- IBM License Metric Tool [66](#)
- IBM Spectrum Protect directories
 - planning for [5](#)
- implementation
 - test operations [50](#)
- initial configuration wizard
 - configure [71](#)
- installation
 - clients [81](#)
- installing
 - clients [47](#)
- installing IBM Spectrum Protect
 - AIX systems [35](#)
 - Linux systems [35](#)
 - Windows systems [37](#)
- installing the operating system
 - AIX server systems [22](#)
 - Linux server systems [24](#)
 - Windows server systems [28](#)
- inventory capacity [93](#)
- issues
 - diagnosing [51](#)

K

- keyboard [109](#)
- Knowledge Center [vii](#)

L

- LDAP
 - password requirements [99](#)
- license compliance
 - verifying [66](#)

M

- maintenance
 - define schedule [44](#)
- maintenance mode
 - start server [102](#)
- maintenance tasks
 - scheduling [95](#)
 - start the server in maintenance mode [103](#)
- managing
 - access levels [101](#)
 - administrators [98](#)
 - authority [98](#)
- managing security [96](#)
- memory requirements
 - managing [95](#)
- monitoring
 - daily checklist [51](#)

- monitoring *(continued)*
 - goals [51](#)
 - periodic checklist [60](#)
 - tasks
 - daily checklist [51](#)
 - periodic checklist [60](#)
- multipath I/O
 - configure for AIX systems [29](#)
 - configure for Linux systems [30](#)
 - configure for Windows systems [31](#)

O

- operating system
 - install on AIX server systems [22](#)
 - install on Linux server systems [24](#)
 - install on Windows server systems [28](#)
 - security [101](#)
- Operations Center
 - configure [40](#)
 - restore to preconfigured state [72](#)
 - secure communications [41](#)
 - spoke server [69](#)
 - web server [70](#)
- options
 - set for server [39](#)
- outage
 - prepare [105](#)

P

- password requirements
 - LDAP [99](#)
- passwords
 - changing [99](#)
 - resetting [87](#)
- periodic checklist of monitoring tasks [60](#)
- planning solutions
 - single-site disk [1](#)
- planning worksheet [5](#)
- policies
 - editing [78](#)
 - specifying [76](#)
 - viewing [77](#)
- policy domains
 - specifying [76](#)
- privilege class
 - system privilege [98](#)
- processor usage [95](#)
- processor value unit (PVU) licensing [66](#)
- product license
 - register [43](#)
- publications [vii](#)

R

- reconfiguration tasks
 - start the server in maintenance mode [103](#)
- recover
 - local inventory [106](#)
- recovery
 - disaster recovery [106](#)
 - strategy [106](#)

- recovery drill [106](#)
- registration
 - clients [80](#)
- reports
 - email
 - configuring [68](#)
- restricting
 - user access [101](#)
- RPM files
 - install for graphical wizard [36](#)
- rules
 - editing [78](#)
 - specifying
 - backup and archive operations [76](#)
 - viewing [77](#)

S

- scheduled activities
 - tuning [95](#)
- schedules
 - backup and archive operations [79](#)
- secure communications
 - configure with SSL and TLS [40](#)
- security [96](#)
- server
 - configure [37](#)
 - create user ID for [31](#)
 - define maintenance schedule [44](#)
 - determine size of [2](#)
 - plan upgrade [104](#)
 - set options [39](#)
 - start in maintenance mode [102](#)
 - stop [102](#)
- servers
 - start in maintenance mode [103](#)
- shutting down
 - server [102](#)
- single-site disk solution
 - planning for [1](#)
- software
 - selecting [75](#)
- software requirements [4](#)
- solution
 - expanding [74](#)
- spoke server
 - adding [69](#)
 - remove [70](#)
- spoke servers
 - restore to preconfigured state [72](#)
- SSL [40](#)
- starting server
 - maintenance mode [102](#)
- status reports
 - obtaining [68](#)
- stopping
 - server [102](#)
- storage
 - planning for [16](#)
- storage configuration
 - planning for [5](#)
- storage hardware
 - configure [21](#)
- storage pools

- storage pools (*continued*)
 - auditing containers [92](#)
- storage space
 - releasing [92](#)
- system outage
 - recover from [106](#)
- system requirements
 - hardware [2](#)
- system status
 - tracking [68](#)
- system update
 - prepare [105](#)

T

- TLS [40](#)
- troubleshooting
 - administrator IDs [87](#)
 - errors in client operations [85](#)
 - locked client nodes [87](#)
 - password issues [87](#)

U

- upgrade
 - server [104](#)
- user ID
 - create for server [31](#)

W

- web server
 - start [70](#)
 - stop [70](#)



Product Number: 5725-W98
5725-W99
5725-X15