## IBM Spectrum Scale 5.0.4 Protocols Quick Overview

## **Before Starting**

Always start here to understand:

Common pre-requisites

Basic Install Toolkit operation

Requirements when an existing cluster exists, both with or without an ESS

**How does the Install Toolkit work?** IBM Spectrum Scale Install Toolkit operation can be

summarized by 4 phases: 1) User input via 'spectrumscale' commands

2) A 'spectrumscale install' phase 3) A 'spectrumscale deploy' phase

4) A 'spectrumscale upgrade' phase

Each phase can be run again at later points in time to introduce new nodes, protocols, authentication, NSDs, file systems, or updates.

All user input via 'spectrumscale' commands is recorded into a clusterdefinition.txt file in /usr/lpp/mmfs/5.0.4.x/ installer/configuration/

Each phase will act upon all nodes inputted into the cluster definition file. For example, if you only want to deploy protocols in a cluster containing a mix of unsupported and supported OSs, input only the supported protocol nodes and leave all other nodes out of the cluster definition.

**Hardware / Performance Sizing** Please work with your IBM account team or Business Partner for suggestions on the best configuration possible to fit your environment. In addition, make sure to review the protocol sizing guide.

OS levels and CPU architecture The Install Toolkit supports the following OSs:

> x86: RHEL7.x / 8.x, SLES12 / 15, Ubuntu16 / 18 ppc64 BE: RHEL7.x ppc64 LE: RHEL7.x / 8.x s390x: RHEL7.x / 8.x, SLES12 / 15, Ubuntu 16 / 18

All cluster nodes the Install Toolkit acts upon must be of the same CPU architecture and endianness.

All protocol nodes must be of the same OS, architecture. and endianness.

A base repository must be setup on every node. For RHEL8, also setup the AppStream repo. RHEL check: yum repolist, dnf repolist SLES check: zypper repos Ubuntu check: apt edit-sources

Firewall & Networking & SSH All nodes must be networked together and ping-able via

Reverse DNS lookup must be in place

If /etc/hosts is used for name resolution, ordering within must be: IP FQDN hostname

Promptless ssh must be setup between all nodes and themselves using IP, FQDN, and hostname

Firewalls should be turned off on all nodes else specific ports must be opened both internally for GPFS and the installer and externally for the protocols. See the IBM Knowledge Center for more details before proceeding.

Time sync among nodes is required A consistent time must be established on all nodes of the cluster. NTP can be automatically configured during install. See step 9 of the installation stage

Cleanup prior SMB, NFS, Object Prior implementations of SMB, NFS, and Object must be completely removed before proceeding with a new protocol deployment. Refer to the cleanup guide within the IBM Knowledge Center.

If a GPFS cluster pre-exists Proceed to the Protocol Deployment section as long as

a) file system(s) created and mounted ahead of time & nfs4 ACLs in place

b) ssh promptless access among all nodes c) firewall ports open d) CCR enabled

e) set mmchconfig release=LATEST f) installed GPFS rpms should match the exact build dates of those included within the protocols package

If an ESS is part of the cluster Proceed to the Cluster Installation section to use the Install Toolkit to install GPFS and add new nodes to the existing ESS cluster. Proceed to the Protocol Deployment section to deploy protocols.

a) CCR must be enabled

b) EMS node(s) must be in the ems nodeclass. IO nodes must be in their own nodeclass: gss or gss\_ppc64. c) GPFS on the ESS nodes must be at minimum 4.2.0.0 d) All Quorum and Quorum-Manager nodes are recommended to be at the latest levels possible e)A CES shared root file system has been created and

Protocols in a stretch cluster Refer to the stretch cluster use case within the

mounted on the EMS.

Extract Spectrum Scale package With 5.0.4.0, there is no longer a protocols specific package. Any standard, advanced, or data management package is now sufficient for protocol deployment.

./Spectrum\_Scale\_Data\_Management-5.0.4.x-<arch>-Linux-install

Extracting the package will present a license agreement.

**Explore the spectrumscale help** From location /usr/lpp/mmfs/5.0.4.x/installer Use the -h flag. ./spectrumscale -h ./spectrumscale setup -h ./spectrumscale node add -h ./spectrumscale config -h ./spectrumscale config protocols -h

**FAQ and Quick Reference** Refer to the Knowledge Center Quick Reference Refer to the Spectrum Scale FAQ

**Cluster Installation** 

Start here if you would like to:

Create a new cluster from scratch

Add and install new GPFS nodes to an existing cluster (client, NSD, GUI)

Create new NSDs on an existing cluster

Setup the node that will start the installation Pick an IP existing on this node which is accessible to/ from all nodes via promptless ssh:

./spectrumscale setup -s IP

Setup in an ESS environment

If the spectrumscale command is being run on a node(s) in a cluster with an ESS, make sure to switch to ESS mode (see page 2 for ESS examples):

./spectrumscale setup -s IP -st ess

Populate the cluster

If a cluster pre-exists, the Install Toolkit can automatically traverse the existing cluster and populate its clusterdefinition.txt file with current cluster configuration details. Point it at a node within the cluster with promptless ssh access to all other cluster nodes:

./spectrumscale config populate -N hostname

If in ESS mode, point config populate to the EMS:

./spectrumscale config populate -N ems1

\* Note the limitations of the config populate command

Add NSD server nodes (non-ESS nodes) Adding NSD nodes is necessary if you would like the install toolkit to configure new NSDs and file systems.

> /spectrumscale node add hostname -n /spectrumscale node add hostname -n

Add NSDs (non-ESS devices)

NSDs can be added as non-shared disks seen by a primary NSD server. NSDs can also be added as shared disks seen by a primary and multiple secondary NSD

In this example we add 4 /dev/dm disks seen by both primary and secondary NSD servers:

./spectrumscale nsd add -p primary\_nsdnode\_hostname -s secondary\_nsdnode\_hostname /dev/dm-1 /dev/dm-2 / dev/dm-3 /dev/dm-4

**Define file systems (non-ESS FSs)** File systems are defined by assigning a file system name to one or more NSDs. Filesystems will be defined but not created until this install is followed by a deploy.

In this example we assign all 4 NSDs to the fs1 file

./spectrumscale nsd list ./spectrumscale filesystem list ./spectrumscale nsd modify nsd1 -fs fs1 ./spectrumscale nsd modify nsd2 -fs fs1 ./spectrumscale nsd modify nsd3 -fs fs1 ./spectrumscale nsd modify nsd4 -fs fs1

If desired, multiple file systems can be assigned at this point. See the IBM Knowledge Center for details on "spectrumscale nsd modify". We recommend a separate file system for shared root to be used with protocols.

**Add GPFS client nodes** ./spectrumscale node add hostname

> The installer will assign quorum and manager nodes by default. Refer to the IBM Knowledge Center if a specific configuration is desired.

Add Spectrum Scale GUI nodes ./spectrumscale node add hostname -g -a

> The management GUI will automatically start after installation and allow for further cluster configuration and

**Configure performance monitoring** Configure performance monitoring consistently across

/spectrumscale config perfmon -r on

Configure network time protocol (NTP) The network time protocol can be automatically configured and started on all nodes provided the NTP package has been pre-installed on all nodes:

./spectrumscale config ntp -e on -s ntp\_server1, ntp\_server2, ntp\_server3, .

**Configure Callhome** 

Starting with 5.0.0.0, callhome is enabled by default within the Install Toolkit. Refer to the callhome settings and configure mandatory options for callhome:

./spectrumscale callhome config -h

Alternatively, disable callhome:

./spectrumscale callhome disable

Name your cluster ./spectrumscale config gpfs -c my\_cluster\_name

**Review your config** ./spectrumscale node list /spectrumscale nsd list ./spectrumscale filesystem list ./spectrumscale config gpfs --list

./spectrumscale install --precheck

Start the installation

./spectrumscale install

Upon completion you will have an active GPFS cluster with available NSDs, performance monitoring, time sync, callhome, and a GUI. File systems will be fully created and protocols installed in the next stage:

Install can be re-run in the future to: add GUI nodes add NSD server nodes add GPFS client nodes enable and configure or update callhome settings **Protocol & File System Deployment** 

Start here if you already have a cluster and would like to:

Add/Enable protocols on existing cluster nodes

Create a file system on existing NSDs

Configure File or Object Protocol Authentication

Setup the node that will start the installation Setup is necessary unless spectrumscale setup had previously been run on this node for a past GPFS installation or protocol deployment. Pick an IP existing on this node which is accessible to/from all nodes via

./spectrumscale setup -s IP

Setup in an ESS environment

If the spectrumscale command is being run on a node(s) in a cluster with an ESS, make sure to switch to ESS mode (see page 2 for ESS examples):

./spectrumscale setup -s IP -st ess

Populate the cluster

promptless ssh:

Optionally, the Install Toolkit can automatically traverse the existing cluster and populate its clusterdefinition.txt file with current cluster details. Point it at a node within the cluster with promptless ssh access to all other cluster nodes:

./spectrumscale config populate -N hostname

If in ESS mode, point config populate to the EMS:

./spectrumscale config populate -N ems1

\*Note the limitations of the config populate command

Add protocol nodes ./spectrumscale node add hostname -p

Assign protocol IPs (CES-IPs)

./spectrumscale node add hostname -p

Add a comma separated list of IPs to be used specifically for cluster export services such as NFS, SMB, Object. Reverse DNS lookup must be in place for all IPs. CES-IPs must be unique and different than cluster node IPs.

./spectrumscale config protocols -e EXPORT\_IP\_POOL

\*All protocol nodes must see the same CES-IP network(s). If CES-Groups are to be used, apply them after the deployment is successful.

Verify file system mount points are as expected

\*Skip this step if you setup file systems / NSDs manually and not through

Configure protocols to point to a shared root file system location

A ces directory will be automatically created at root of the specified file system mount point. This is used for protocol admin/config and needs >=4GB free. Upon completion of protocol deployment, GPFS configuration will point to this as cesSharedRoot. It is recommended that cesSharedRoot be a separate file system.

./spectrumscale config protocols -f fs1 -m /ibm/fs1

\*If you setup file systems / NSDs manually, perform a manual check of <mmlsnsd> and <mmlsfs all -L> to make sure all NSDs and file systems required by the deploy are active and mounted before continuing.

**Enable the desired file protocols** ./spectrumscale enable smb

**Enable the Object protocol if desired** 

Configure an admin user, password, and database password to be used for Object operations:

./spectrumscale config object -au admin -ap -dp

Configure the Object endpoint using a single hostname with a round robin DNS entry mapping to all CES IPs:

Specify a file system and fileset name where your Object

./spectrumscale config object -f fs1 -m /ibm/fs1

./spectrumscale config object -o Object\_Fileset

./spectrumscale config object -e hostname

\*The Object fileset must not pre-exist. If an existing fileset is detected at the same location, deployment will fail so that existing data is preserved.

**Setup Authentication** 

Authentication must be setup prior to using any protocols. I you are unsure of the appropriate authentication config you may skip this step and revisit by re-running the deployment at a later time or manually using the mmuserauth commands. Refer to the IBM Knowledge Center for the many supported authentication configurations.

Install Toolkit AD example for File and/or Object ./spectrumscale auth file ad ./spectrumscale auth object ad

**Configure Callhome** Starting with 5.0.0.0, callhome is enabled by default within the Install Toolkit. Refer to the callhome settings and

./spectrumscale callhome config -h

configure mandatory options for callhome:

Alternatively, disable callhome: ./spectrumscale callhome disable

Review your config

./spectrumscale deploy --precheck Start the deployment ./spectrumscale deploy

> Upon completion you will have protocol nodes with active cluster export services and IPs. File systems will have been created and Authentication will be configured and ready to use. Performance Monitoring tools will also be usable at this time.

Deploy can be re-run in the future to: enable additional protocols enable authentication for file or Object

create additional file systems (run install first to add more NSDs) add additional protocol nodes (run install first to add more nodes) enable and configure or update callhome settings

Configuration

Start here if you already have a cluster with protocols enabled and would like to:

Check cluster state and health, basic logging/debugging

Configure a basic SMB or NFS export or Object

Configure and Enable File Audit Logging / Watch Folders

Path to binaries: Add the following PATH variable to your shell profile to allow convenient access of gpfs 'mm' commands:

export PATH=\$PATH:/usr/lpp/mmfs/bin

**Basic GPFS Health** mmgetstate -aL mmlscluster mmlscluster --ces

mmnetverify

**CES service and IP check** mmces address list mmces service list -a mmhealth cluster show

mmhealth node show <component> -v

mmhealth node show -N all -v

Authentication mmuserauth service list

mmuserauth service check

mmces events list -a

Callhome mmcallhome info list mmcallhome group list

mmcallhome status list

File protocols (NFS & SMB) Verify all file systems to be used with protocols have nfs4 ACLs and locking in effect. Protocols will not work correctly without this setting in place.

Example NFS export creation: mkdir /ibm/fs1/nfs\_export1

Check with: mmlsfs all -D -k

mmnfs export add /ibm/fs1/nfs\_export1 -c "\*(Access\_Type=RW,Squash=no\_root\_squash,SecType=sys ,Protocols=3:4)"

mmnfs export list

Example SMB export creation: mkdir /ibm/fs1/smb\_export1

chown "DOMAIN\USER" /ibm/fs1/smb\_export1 mmsmb export add smb\_export1 /ibm/ts1/smb\_export1 --

mmsmb export list

object to a container:

option "browseable=yes"

Object protocol Verify the Object protocol by listing users and uploading an

swift upload test\_container test\_object1.txt

source \$HOME/openrc openstack user list openstack project list swift stat date > test\_object1.txt

**Performance Monitoring** systemctl status pmsensors systemctl status pmcollector mmperfmon config show

swift list test\_container

mmperfmon query -h File Audit Logging &/or Watch Folder File audit logging (FAL) and Watch Folder (WF) functionality is available with Advanced and Data Management Editions of

a) FAL: Enable and configure using the Install Toolkit as

/spectrumscale fileauditlogging enable ./spectrumscale filesystem modify —fileauditloggingenable gpfs1 /spectrumscale fileauditlogging list ./spectrumscale filesystem modify —logfileset <LOGFILESET>

b) WF: Enable and configure ./spectrumscale watchfolder enable

retention <days> gpfs1

\*If less than 3 protocol nodes, specify exact broker nodes ./spectrumscale node add hostname -b

c) Install the File Audit Logging / WF rpms on all nodes ./spectrumscale install --precheck ./spectrumscale install

d) Deploy the File Audit Logging / WF configuration \*gpfs.adv.\* or gpfs.dm.\* rpms must be installed on all nodes\*

./spectrumscale deploy --precheck /spectrumscale deploy

\*WF: Once deployed, use the mmwatch command to start a watch on a filesystem, fileset.

mmhealth node show FILEAUDITLOG -v mmhealth node show MSGQUEUE -v mmaudit all list mmmsgqueue status mmaudit all consumeStatus -N <node list>

**Logging & Debugging** allation / deployment /usr/lpp/mmfs/5.0.4.x/installer/logs

mmwatch all list

Verbose logging for all spectrumscale commands by adding a '-v' immediately after ./spectrumscale:

/usr/lpp/mmfs/5.0.4.x/installer/spectrumscale -v <cmd>

GPFS default log location: Linux syslog or journal is recommended to be enabled

Installation/Deploy/Upgrade specific:

/usr/lpp/mmfs/5.0.4.x/installer/installer.snap.py

**Data Capture for Support** System-wide data capture: /usr/lpp/mmfs/bin/gpfs.snap

Further IBM Spectrum Scale Education Best Practices, hints, tips, videos, white papers, and up to date news regarding IBM Spectrum Scale can be found on the IBM Spectrum Scale wiki.

**Upgrade & Cluster additions** 

Start here to gain a basic of understanding of:

Upgrade guidance

How to add nodes, NSDs, FSs, protocols, to an existing cluster

<u>Upgrading 4.1.1.x to 5.0.4.x:</u>

A direct path from 4.1.1.x to 5.0.4.x is not possible unless all nodes of the cluster are offline (see offline section below). However, it is possible to upgrade first, from 4.1.1.x to 4.2.x.x, and second, from 4.2.x.x to 5.0.4.x, while the cluster

**Upgrading 4.2.x.x or 5.0.x.x to 5.0.4.x** a) Extract the 5.0.4.x Spectrum Scale PTF package Spectrum\_Scale\_Data\_Management-5.0.4.x-Linux

b) Setup and Configure the Install Toolkit ./spectrumscale setup -s <IP of installer node>

./spectrumscale config populate -N <any cluster node> \*\*If config populate is incompatible with your cluster config, you will have to manually add the nodes and config to the Install Toolkit OR copy the last used clusterdefinition.txt file to the new 5.0.4.x Install Toolkit.\*\* cp -p /usr/ lpp/mmfs/<4.2.x.x.your\_last\_level>/installer/configuration/

clusterdefinition.txt /usr/lpp/mmfs/5.0.4.x/installer/configuration/ /spectrumscale node list ./spectrumscale nsd list ./spectrumscale filesystem list ./spectrumscale config gpfs ./spectrumscale config protocols /spectrumscale upgrade precheck ./spectrumscale upgrade run

**Upgrading 5.0.4.x to future PTFs** Follow the same procedure as indicated above.

g) Upgrade LTFS-EE if desired

**Upgrade compatibility with LTFS-EE** a) Itfsee stop (on all LTFSEE nodes) b) umount /ltfs (on all LTFSEE nodes) c) dsmmigfs disablefailover (on all LTFSEE nodes) d) dsmmigfs stop (on all LTFSEE nodes) e) systematl stop hsm.service (on all LTFSEE nodes) f) Upgrade using the Install Toolkit

**Upgrade compatibility with TCT** a) Stop TCT on all nodes prior to the upgrade mmcloudgateway service stop -N Node | Nodeclass b) Upgrade using the Install Toolkit c) Upgrade the TCT rpm(s) manually, then restart TCT

h) Reverse steps e through a and restart/enable

Offline upgrade using the Install Toolkit The Install Toolkit supports offline upgrade of all nodes in the cluster or a subset of nodes in the cluster. This is useful for 4.1.1.x -> 5.0.4.x upgrades. It is also useful when nodes are unhealthy and cannot be brought into a healthy/active state for upgrade. See the Knowledge Center for limitations.

a) Check the upgrade configuration /spectrumscale upgrade config list

c) Start the upgrade

b) Add nodes that are already shutdown ./spectrumscale upgrade config offline -N <node1,node2> ./spectrumscale upgrade config list

./spectrumscale upgrade precheck ./spectrumscale upgrade run <u>Upgrading subsets of nodes (excluding nodes)</u> The Install Toolkit supports excluding groups of nodes from the upgrade. This allows for staging cluster upgrades across multiple windows. For example, upgrading only NSD nodes

unreachable. See the Knowledge Center for limitations.

./spectrumscale upgrade config list

c) Start the upgrade

a) Check the upgrade configuration ./spectrumscale upgrade config list b) Add nodes that are NOT to be upgraded ./spectrumscale upgrade config exclude -N <node1,node2>

and then at a later time, upgrading only protocol nodes.

This is also useful if specific nodes are down and

./spectrumscale upgrade precheck ./spectrumscale upgrade run d) Prepare to upgrade the previously excluded nodes ./spectrumscale upgrade config list

./spectrumscale upgrade config exclude --clear

e) Start the upgrade ./spectrumscale upgrade precheck

./spectrumscale upgrade run

Resume of a failed upgrade If an Install Toolkit upgrade fails, it is possible to correct the failure and resume the upgrade without needing to recover all nodes/services. Resume with: ./spectrumscale upgrade run

./spectrumscale upgrade exclude -N <already\_upgraded\_nodes>

**Handling Linux kernel updates** The GPFS portability layer must be rebuilt on every node that undergoes a Linux kernel update. Apply the kernel, reboot, rebuild the GPFS portability layer on each node with this command prior to starting GPFS: /usr/lpp/mmfs/bin/mmbuildgpl. Or mmchconfig

Adding to the installation

/spectrumscale deploy -pr

./spectrumscale install

./spectrumscale deploy -pr

enablement.

autoBuildGPL=yes and mmstartup.

The procedures below can be combined to reduce the number of installs and deploys necessary. To add a node:

a) Choose one or more node types to add

Client node: ./spectrumscale node add hostname

NSD node: ./spectrumscale node add hostname -n

Protocol node: ./spectrumscale node add hostname -p GUI node: ./spectrumscale node add hostname -g -a . repeat for as many nodes as you'd like to add. b) Install GPFS on the new node(s): /spectrumscale install

./spectrumscale deploy a) Verify the NSD server connecting this new disk exists within the cluster

c) If a protocol node is being added, also run deploy

b) Add the NSD(s) to the install toolkit /spectrumscale nsd add -h . repeat for as many NSDs as you'd like to add /spectrumscale install -pr

To add a file system: a) Verify free NSDs exist and are known to the install toolkit b) Define the file system ./spectrumscale nsd list ./spectrumscale nsd modify nsdX -fs file\_system\_name c) Deploy the new file system

./spectrumscale deploy To enable another protocol: See the Protocol & File System deployment column. Proceed with steps 7, 8, 9, 10, 11. Note that some protocols necessitate removal of the Authentication configuration prior to

\*\*URL links are subject to change\*\*

13

## **Examples**

```
Example of readying Red Hat 7.x nodes for Spectrum Scale installation and deployment of protocols
Configure promptless SSH (promptless ssh is required)
# ssh-keygen
# ssh-copy-id <FQDN of node>
# ssh-copy-id <IP of node>
# ssh-copy-id <non-FQDN hostname of node>
repeat on all nodes to all nodes, including current node
Turn off firewalls (alternative is to open ports specific to each Spectrum Scale functionality)
# systemctl stop firewalld
# systemctl disable firewalld
repeat on all nodes
How to check if a yum repository is configured correctly
# yum repolist -> should return no errors. It must also show an RHEL7.x base repository. Other repository possibilities include a satellite site, a custom yum repository, an
RHEL7.x DVD iso, an RHEL7.x physical DVD.
Use the included local-repo tool to spin up a repository for a base OS DVD (this tool works on RHEL, Ubuntu, SLES)
# cd /usr/lpp/mmfs/5.0.4.x/tools/repo
# cat readme_local-repo I more
# ./local-repo --mount default --iso /root/RHEL7.4.iso
What if I don't want to use the Install Toolkit - how do I get a repository for all the Spectrum Scale rpms?
# cd /usr/lpp/mmfs/5.0.4.x/tools/repo
# ./local-repo --repo
# yum repolist
Pre-install pre-reg rpms to make installation and deployment easier
# yum install kernel-devel cpp gcc gcc-c++ glibc sssd ypbind openldap-clients krb5-workstation
Turn off selinux (or set to permissive mode)
# sestatus
# vi /etc/selinux/config
change SELINUX=xxxxxx to SELINUX=disabled
save and reboot
repeat on all nodes
Setup a default path to Spectrum Scale commands (not required)
# vi /root/.bash_profile
 ——add this line——
export PATH=$PATH:/usr/lpp/mmfs/bin
 --save/exit--
logout and back in for changes to take effect
```

# **Example of adding protocol nodes to an ESS**

#### Starting point

If you have a 5148-22L protocol node, stop following these directions: please refer to the ESS 5.3.4.1 (or higher) Quick Deployment Guide

The cluster containing ESS is active and online

RHEL7.x, SLES12, or Ubuntu16.04 is installed on all nodes that are going to serve as protocol nodes

RHEL7.x, SLES12, or Ubuntu 16.04 base repository is set up on nodes that are going to serve as protocol nodes

The nodes that will serve as protocol nodes have connectivity to the GPFS cluster network

Create a cesSharedRoot from the EMS: gssgenvdisks --create-vdisk --create-nsds --create-filesystem --contact-node gssio1-hs --creesfs

Mount the CES shared root file system on the EMS node and set it to automount. When done with this full procedure, make sure the protocol nodes are set to automount the CES shared root file system as well.

Use the ESS GUI or CLI to create additional file systems for protocols if desired. Configure each file system for nfsv4 ACLs Pick a protocol node to run the Install Toolkit from.

The Install Toolkit is contained within these packages: Spectrum Scale Protocols Standard or Advanced or Data Management Edition

Download and extract one of the Spectrum Scale Protocols packages to the protocol node that will run the Install Toolkit Once extracted, the Install Toolkit is located in the /usr/lpp/mmfs/5.0.4.x/installer directory.

Inputting the configuration into the Install Toolkit with the commands detailed below, involves pointing the Install Toolkit to the EMS node, telling the Install Toolkit about the mount points and paths to the CES shared root and optionally, the Object file systems, and designating the protocol

#### Install Toolkit commands:

/spectrumscale setup -s 10.11.10.11 -st ess <- internal GPFS network IP on the current Installer node that can see all protocol nodes

/spectrumscale config populate -N ems-node <- OPTIONAL. Have the Install Toolkit traverse the existing cluster and auto-populate its config.

<- OPTIONAL. Check the node configuration discovered by config populate. /spectrumscale node list <- designate the EMS node for the Install Toolkit to use for coordination of the install/deploy

/spectrumscale node add ems-node -a -e /spectrumscale node add cluster-node1 -p

/spectrumscale node add cluster-node2 -p /spectrumscale node add cluster-node3 -p

/spectrumscale node add cluster-node4 -p

nodes and protocol config to be installed/deployed.

/spectrumscale config protocols -e 172.31.1.10,172.31.1.11,172.31.1.12,172.31.1.13,172.31.1.14 /spectrumscale config protocols -f cesSharedRoot -m /ibm/cesSharedRoot

/spectrumscale enable nfs

/spectrumscale enable smb

spectrumscale enable object

/spectrumscale config object -e mycluster-ces /spectrumscale config object -o Object\_Fileset

/spectrumscale config object -f ObjectFS -m /ibm/ObjectFS

/spectrumscale config object -au admin -ap -dp

/spectrumscale node list <- It is normal for ESS IO nodes to not be listed in the Install Toolkit. Do not add them.

/spectrumscale install --precheck /spectrumscale install

<- The install will install GPFS on the new protocol nodes and add them to the existing ESS cluster

/spectrumscale deploy --precheck <- It's important to make sure CES shared root is mounted on all protocol nodes before continuing <- The deploy will install / configure protocols on the new protocol nodes /spectrumscale deploy

## **Install Outcome:**

EMS node used as an admin node by the Install Toolkit, to coordinate the installation

4 new nodes installed with GPFS and added to the existing ESS cluster

Performance sensors automatically installed on the 4 new nodes and pointed back to existing collector / GUI on the EMS node ESS I/O nodes, NSDs/vdisks, left untouched by the Install Toolkit.

## **Deploy Outcome:**

CES Protocol stack added to 4 nodes, now designated as Protocol nodes with server licenses

4 CES-IPs distributed among the protocol nodes

Protocol configuration and state data will use the cesSharedRoot file system, which was pre-created on the ESS

Object protocol will use the ObjectFS filesystem, which was pre-created on the ESS

## Example of Upgrading protocol nodes / other nodes in the same cluster as an ESS

## **Pre-Upgrade planning:**

Refer to the Knowledge Center for supported upgrade paths of Spectrum Scale nodes

If you have a 5148-22L protocol node attached to an ESS, please refer to the ESS 5.3.4.1 (or higher) Quick Deployment Guide Consider whether OS, FW, or drivers on the protocol node(s) should be upgraded and plan this either before or after the install toolkit upgrade

SMB: requires quiescing all I/O for the duration of the upgrade. Due to the SMB clustering functionality, differing SMB levels cannot co-exist within a cluster at the same time. This requires a full outage of SMB during the upgrade.

NFS: Recommended to quiesce all I/O for the duration of the upgrade. NFS experiences I/O pauses, and depending upon the client, mounts may disconnect during the upgrade.

Object: Recommended to quiesce all I/O for the duration of the upgrade. Object service will be down or interrupted at multiple times during the upgrade process. Clients may experience errors or they might be unable to connect during this time. They should retry as appropriate. - Performance Monitoring: Collector(s) may experience small durations in which no performance data is logged, as the nodes upgrade.

## Install Toolkit commands for Scale 5.0.0.0 or higher

./spectrumscale setup -s 10.11.10.11 -st ess <- internal gpfs network IP on the current Installer node that can see all protocol nodes</p>

/spectrumscale config populate -N ems1 <- Always point config populate to the EMS node when an ESS is in the same cluster \*\* If config populate is incompatible with your configuration, add the nodes and CES configuration to the install toolkit manually \*\*

Ispectrumscale node list <- This is the list of nodes the Install Toolkit will upgrade. Remove any non-CES nodes you would rather do manually /spectrumscale upgrade precheck

/spectrumscale upgrade run

#### Example of a new Spectrum Scale cluster installation followed by a protocol deployment

#### **Install Toolkit commands for Installation:**

- Toolkit is running from cluster-node1 with an internal cluster network IP of 10.11.10.11, which all nodes can reach

cd /usr/lpp/mmfs/5.0.4.x/installer/

./spectrumscale setup -s 10.11.10.11

./spectrumscale node add cluster-node1 -a -g

/spectrumscale node add cluster-node2 -a -g /spectrumscale node add cluster-node3

/spectrumscale node add cluster-node4 ./spectrumscale node add cluster-node5 -n

./spectrumscale node add cluster-node6 -n /spectrumscale nsd add -p node5.tuc.stglabs.ibm.com -s node6.tuc.stglabs.ibm.com -u dataAndMetadata -fs cesSharedRoot -fg 1 "/dev/sdb" ./spectrumscale nsd add -p node6.tuc.stglabs.ibm.com -s node5.tuc.stglabs.ibm.com -u dataAndMetadata -fs cesSharedRoot -fg 2 "/dev/sdc"

/spectrumscale nsd add -p node5.tuc.stglabs.ibm.com -s node6.tuc.stglabs.ibm.com -u dataAndMetadata -fs ObjectFS -fg 1 "/dev/sdd" /spectrumscale nsd add -p node5.tuc.stglabs.ibm.com -s node6.tuc.stglabs.ibm.com -u dataAndMetadata -fs ObjectFS -fg 1 "/dev/sde" /spectrumscale nsd add -p node6.tuc.stglabs.ibm.com -s node5.tuc.stglabs.ibm.com -u dataAndMetadata -fs ObjectFS -fg 2 "/dev/sdf"

/spectrumscale nsd add -p node6.tuc.stglabs.ibm.com -s node5.tuc.stglabs.ibm.com -u dataAndMetadata -fs ObjectFS -fg 2 "/dev/sdg" /spectrumscale nsd add -p node5.tuc.stglabs.ibm.com -s node6.tuc.stglabs.ibm.com -u dataAndMetadata -fs fs1 -fq 1 "/dev/sdh" /spectrumscale nsd add -p node5.tuc.stglabs.ibm.com -s node6.tuc.stglabs.ibm.com -u dataAndMetadata -fs fs1 -fg 1 "/dev/sdi" /spectrumscale nsd add -p node5.tuc.stglabs.ibm.com -s node6.tuc.stglabs.ibm.com -u dataAndMetadata -fs fs1 -fg 2 "/dev/sdj"

/spectrumscale nsd add -p node5.tuc.stglabs.ibm.com -s node6.tuc.stglabs.ibm.com -u dataAndMetadata -fs fs1 -fg 2 "/dev/sdk"

./spectrumscale config perfmon -r on ./spectrumscale config ntp -e on -s ntp\_server1,ntp\_server2,ntp\_server3

./spectrumscale callhome enable <- If you prefer not to enable callhome, change the enable to a disable /spectrumscale callhome config -n COMPANY\_NAME -i COMPANY\_ID -cn MY\_COUNTRY\_CODE -e MY\_EMAIL\_ADDRESS

/spectrumscale config gpfs -c mycluster ./spectrumscale node list

./spectrumscale install --precheck

/spectrumscale install

#### Install Outcome: A 6node Spectrum Scale cluster with active NSDs

2 GUI nodes 2 NSD nodes

2 client nodes 10 NSDs

configured performance monitoring

callhome configured

\*\*3 file systems defined, each with 2 failure groups. File systems will not be created until a deployment\*\*

#### Install Toolkit commands for Protocol Deployment (assumes cluster created from above configuration.)

Toolkit is running from the same node that performed the install above, cluster-node1

./spectrumscale node add cluster-node3 -p

./spectrumscale node add cluster-node4 -p /spectrumscale config protocols -e 172.31.1.10,172.31.1.11,172.31.1.12,172.31.1.13,172.31.1.14

./spectrumscale config protocols -f cesSharedRoot -m /ibm/cesSharedRoot ./spectrumscale enable nfs

./spectrumscale enable smb

./spectrumscale enable object

./spectrumscale config object -e mycluster-ces /spectrumscale config object -o Object\_Fileset

/spectrumscale config object -f ObjectFS -m /ibm/ObjectFS /spectrumscale config object -au admin -ap -dp

./spectrumscale node list

./spectrumscale deploy --precheck ./spectrumscale deploy

fs1 file system created and ready

### **Deploy Outcome:**

2 Protocol nodes

Active SMB and NFS file protocols

Active Object protocol

cesSharedRoot file system created and used for protocol configuration and state data ObjectFS file system created with an Object\_Fileset created within

## **Next Steps:**

Configure Authentication with mmuserauth or by configuring authentication with the Install Toolkit and re-running the deployment

## Example of adding protocols to an existing cluster

## Pre-req Configuration

Decide on a file system to use for cesSharedRoot (>=4GB). Preferably, a standalone file system solely for this purpose.

Take note of the file system name and mount point. Verify the file system is mounted on all protocol nodes.

Decide which nodes will be the Protocol nodes Set aside CES-IPs that are unused in the current cluster and network. Do not attempt to assign the CES-IPs to any adapters.

Verify each Protocol node has a pre-established network route and IP not only on the GPFS cluster network, but on the same network the CES-IPs will belong to. When Protocols are deployed, the CES-IPs will be aliased to the active network device matching their subnet. The CES-IPs must be free to move among nodes during failover cases.

Decide which protocols to enable. The protocol deployment will install all protocols but will enable only the ones you choose.

Add the new to-be protocol nodes to the existing cluster using mmaddnode (or use the Install Toolkit). In this example, we will add the protocol functionality to nodes already within the cluster.

## Install Toolkit commands (Toolkit is running on a node that will become a protocol node)

./spectrumscale setup -s 10.11.10.15 <- internal gpfs network IP on the current Installer node that can see all protocol nodes ./spectrumscale config populate -n cluster-node5 <- pick a node in the cluster for the toolkit to use for automatic configuration

./spectrumscale node add cluster-node5 -a -p

./spectrumscale node add cluster-node6 -p ./spectrumscale node add cluster-node7 -p

./spectrumscale node add cluster-node8 -p

./spectrumscale config protocols -e 172.31.1.10,172.31.1.11,172.31.1.12,172.31.1.13,172.31.1.14 ./spectrumscale config protocols -f cesSharedRoot -m /ibm/cesSharedRoot

./spectrumscale enable nfs ./spectrumscale enable smb

./spectrumscale enable object

./spectrumscale config object -e mycluster-ces ./spectrumscale config object -o Object\_Fileset

./spectrumscale config object -f ObjectFS -m /ibm/ObjectFS

./spectrumscale config object -au admin -ap -dp

./spectrumscale callhome enable <- If you prefer not to enable callhome, change the enable to a disable ./spectrumscale callhome config -n COMPANY\_NAME -i COMPANY\_ID -cn MY\_COUNTRY\_CODE -e MY\_EMAIL\_ADDRESS

./spectrumscale node list

./spectrumscale deploy --precheck ./spectrumscale deploy

## Deploy Outcome:

Callhome will be configured

Pre-Upgrade planning:

CES Protocol stack added to 4 nodes, now designated as Protocol nodes with server licenses

4 CES-IPs distributed among the protocol nodes Protocol configuration and state data will use the cesSharedRoot file system

Object protocol will use the ObjectFS filesystem

## Example of Upgrading protocol nodes / other nodes (not in an ESS)

- Refer to the Knowledge Center for supported upgrade paths of Spectrum Scale nodes Consider whether OS, FW, or drivers on the protocol node(s) should be upgraded and plan this either before or after the install toolkit upgrade SMB: requires guiescing all I/O for the duration of the upgrade. Due to the SMB clustering functionality, differing SMB levels cannot co-exist

within a cluster at the same time. This requires a full outage of SMB during the upgrade. - NFS: Recommended to guiesce all I/O for the duration of the upgrade. NFS experiences I/O pauses, and depending upon the client, mounts

may disconnect during the upgrade. - Object: Recommended to quiesce all I/O for the duration of the upgrade. Object service will be down or interrupted at multiple times during the upgrade process. Clients may experience errors or they might be unable to connect during this time. They should retry as appropriate. Performance Monitoring: Collector(s) may experience small durations in which no performance data is logged, as the nodes upgrade.

## Install Toolkit commands:

<- internal gpfs network IP on the current Installer node that can see all protocol nodes ./spectrumscale setup -s 10.11.10.11 -st ss

./spectrumscale config populate -N <hostname\_of\_any\_node\_in\_cluster> \*\* If config populate is incompatible with your configuration, add the nodes and CES configuration to the install toolkit manually \*\*

./spectrumscale node list <- This is the list of nodes the Install Toolkit will upgrade. Remove any non-CES nodes you would rather do manually ./spectrumscale upgrade precheck

./spectrumscale upgrade run