

IBM® TotalStorage® Storage Switch 2006-L10

IBM Storage and Server Interoperability Matrix

Last update: Sep. 6, 04

© Copyright International Business Machines Corporation 1999, 2003, 2004. All rights reserved.

The information provided in this document is provide "AS IS" without warranty of any kind, including any warranty of merchantability, fitness for a particular purpose, interoperability or compatibility. IBM's products are warranted in accordance with the agreements under which they are provided.

Unless otherwise specified, the product manufacturer, supplier, or publisher of non-IBM products provides warranty, service, and support directly to you. IBM makes no representations or warranties regarding non-IBM products.

The inclusion of an IBM or non-IBM product on an interoperability list is not a guarantee that it will work with the designated IBM storage product. In addition, not all software and hardware combinations created from compatible components will necessarily function properly together. The following list includes products developed or distributed by companies other than IBM. IBM does not provide service or support for the non-IBM products listed, but does not prohibit them from being used together with IBM's storage products. During problem debug and resolution, IBM may require that hardware or software additions be removed from the IBM product to provide problem determination and resolution on the IBM-supplied hardware/ software. For support issues regarding non-IBM products, please contact the manufacturer of the product directly. IBM does not warrant either functionality or problem resolution of any non-IBM products.

This information could include technical inaccuracies or typographical errors. IBM does not assume any liability for damages caused by such errors as this information is provided for convenience only; the reader should confirm any information contained herein with the associated vendor.

Changes are periodically made to the content of the document. These changes will be incorporated in new editions of the document. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this document at anytime without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product and use of those Web sites is at your own risk.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

All statements regarding IBM's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

This information is for planning purposes only. The information herein is subject to change before the products described become available.

IBM TotalStorage Storage Switch 2006-L10

The following terms are trademarks of the International Business Machines Corporation in the United States, other countries, or both:

e (logo)
Enterprise Storage Server
IBM

IBM logo
Netfinity
Server

TotalStorage
xSeries

Microsoft and Windows are trademarks of Microsoft Corporation in the United States, other countries, or both.

LTO and Ultrium are trademarks of IBM, Hewlett Packard and Certance in the United States, other countries, or both.

Other company, product, or service names may be trademarks or service marks of others.

Table of Contents

IBM TotalStorage [FAStT](#)

[Tape](#)

IBM [Tivoli® Storage Manager](#)

Notes:

- The supported firmware version is 2.08.
- IBM Tivoli® [Storage Manager](#) supported version is 5.2.2.3
- Contact IBM service for firmware package at: 1-800-657-6897 or 1-800-ibm-serv.
- Planned availability dates represent current estimates and are subject to change or withdrawal at any time without notice.

• **IBM TotalStorage FAStT Connectivity**

IBM eServer™ [xSeries](#)®, Netfinity Servers, [BladeCenter](#)™¹

Description	Operating Systems	Additional Information
IBM TotalStorage Storage Servers <ul style="list-style-type: none"> • FAStT900 • FAStT600 • Dual Controller • Single Controller • Turbo 	Microsoft® Windows® 2000 <ul style="list-style-type: none"> • Server • Advanced Server Microsoft Windows 2003 <ul style="list-style-type: none"> • Enterprise Edition 	Available IBM TotalStorage FAStT Storage Interoperability matrix IBM Server Proven® Interoperability matrix Fibre Channel Host Bus Adapter firmware and driver level matrix. ²
	Red Hat Enterprise Linux <ul style="list-style-type: none"> • 3.0 United Linux 1.0 <ul style="list-style-type: none"> • SuSE Linux Enterprise Server 8 	Available

¹ BladeCenter JS20 model with Optical Pass-thru connectivity

² qLogic 2340 and 2342 Host Bus Adapter support only

IBM [xSeries](#) and Netfinity Servers, [BladeCenter](#)³

Description	Operating Systems	Additional Information
IBM TotalStorage Storage Servers • FAST100	Microsoft Windows 2000 • Server • Advanced Server Microsoft Windows 2003 • Enterprise Edition	Available IBM TotalStorage FAST Storage Interoperability matrix IBM Server Proven Interoperability matrix Fibre Channel Host Bus Adapter firmware and driver level matrix. ⁴
	Red Hat Enterprise Linux • 3.0 United Linux 1.0 • SuSE Linux Enterprise Server 8	Available.

³ BladeCenter JS20 model with Optical Pass-thru connectivity

⁴ qLogic 2340 and 2342 Host Bus Adapter support only

xSeries Storage Array Connectivity

IBM [xSeries](#) and Netfinity Servers, [BladeCenter](#)⁵

Description	Operating Systems	Additional Information
IBM TotalStorage Storage Servers • DS400	Microsoft Windows 2000 • Server • Advanced Server Microsoft Windows 2003 • Enterprise Edition	Planned Availability is 9/24/04 IBM DS400 Storage Array IBM Server Proven Interoperability matrix Fibre Channel Host Bus Adapter firmware and driver level matrix. ⁶
	Red Hat Enterprise Linux • 3.0 United Linux 1.0 • SuSE Linux Enterprise Server 8	Planned Availability is 9/24/04.
	NetWare	

⁵ BladeCenter JS20 model with Optical Pass-thru connectivity

⁶ qLogic 2340 and 2342 Host Bus Adapter support only

TAPE Connectivity

IBM [xSeries](#), Netfinity Servers, [BladeCenter](#)⁷

Description	Operating Systems	Additional Information
<p>LTO® Ultrium® 3583 Scalable Tape Library with Native FC Ultrium 2 drives.</p>	<p>Microsoft Windows 2000</p> <ul style="list-style-type: none"> • Server • Advanced Server 	<p>Available.</p>
<p>LTO Ultrium 3583 Scalable Tape Library with Integrated SDG Module</p>	<p>Microsoft Windows 2003</p> <ul style="list-style-type: none"> • Enterprise Edition 	<p>Fibre Channel Host Bus Adapter firmware and driver level matrix.⁸</p>
<p>LTO Ultrium 3582 Tape Library with Native FC Ultrium 2 drives.</p>	<p>Red Hat Enterprise Linux</p> <ul style="list-style-type: none"> • 3.0 	<p>Available.</p>
<p>LTO Ultrium 3581 Tape Library with Native FC Ultrium 2 drives.</p>	<p>United Linux 1.0</p> <ul style="list-style-type: none"> • SuSE Linux Enterprise Server 8 	<p>Please review RMSS Technical Support Site.</p>
<p>IBM Modular Tape Library 4560 -SLX</p>		

⁷ BladeCenter JS20 model with Optical Pass-thru connectivity

⁸ qLogic 2340 and 2342 Host Bus Adapter support only

STORAGE SOFTWARE

IBM Tivoli Storage Manager ([TSM](#))

Version supported: 5.2.2.3

Veritas NetBackup ([NetBackup](#))

Version supported: 5.1