

Informacije podrške



Informacije podrške za Konzolu upravljanja hardverom (HMC) tip stroja (MT) 7063

Za informacije podrške za IBM Power Konzolu upravljanja hardverom (HMC) tip stroja (MT) 7063, pogledajte sljedeću Web stranicu.

Za POWER9 poslužitelje bazirane na procesoru, pogledajte:

- Instaliranje i konfiguriranje Konzole za upravljanje hardverom:
www.ibm.com/support/knowledgecenter/POWER9/p9hai/p9hai_kickoff.htm
- Usluga Za Konzolu upravljanja hardverom (tip stroja 7063):
www.ibm.com/support/knowledgecenter/POWER9/p9eav/p9eav_kickoff.htm

Za POWER8 poslužitelje bazirane na procesoru, pogledajte:

- Instaliranje i konfiguriranje Konzole za upravljanje hardverom:
www.ibm.com/support/knowledgecenter/POWER8/p8hai/p8hai_kickoff.htm
- Usluga Za Konzolu upravljanja hardverom (tip stroja 7063):
www.ibm.com/support/knowledgecenter/POWER8/p8eav/p8eav_7063_kickoff.htm

Ovo izdanje se odnosi na IBM® Power Systems poslužitelje koji sadrže POWER8 and POWER9 procesor i na sve povezane modele.
Tiskano u SAD-u

© **Copyright International Business Machines Corporation 2017, 2021.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

GC43-5488-02



(1P) P/N: 03GM256

