

Informações de suporte para o Hardware Management Console (HMC) Machine Type (MT) 7063

Para obter informações de suporte sobre o IBM Power Hardware Management Console (HMC), tipo de máquina (MT) 7063, consulte os websites a seguir.

Para servidores baseados no processador Power 10, consulte:

- Instalando e configurando o Hardware Management Console:
www.ibm.com/support/knowledgecenter/POWER10/p10hai/p10hai_kickoff.htm
- Serviço Hardware Management Console (tipo de máquina 7063):
www.ibm.com/support/knowledgecenter/POWER10/p10eav/p10eav_kickoff.htm

Para servidores baseados no processador POWER9, consulte:

- Instalando e configurando o Hardware Management Console:
www.ibm.com/support/knowledgecenter/POWER9/p9hai/p9hai_kickoff.htm
- Serviço Hardware Management Console (tipo de máquina 7063):
www.ibm.com/support/knowledgecenter/POWER9/p9eav/p9eav_kickoff.htm

Para servidores baseados no processador POWER8, consulte:

- Instalando e configurando o Hardware Management Console:
www.ibm.com/support/knowledgecenter/POWER8/p8hai/p8hai_kickoff.htm
- Serviço Hardware Management Console (tipo de máquina 7063):
www.ibm.com/support/knowledgecenter/POWER8/p8eav/p8eav_7063_kickoff.htm

Esta edição aplica-se a IBM® Power systems servidores que contêm o processador POWER8, POWER9e Power 10 e a todos os modelos associados.

Impresso nos USA

© **Copyright International Business Machines Corporation 2017, 2021.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

GC43-4070-03



(1P) P/N: 03KG334

