

Supporting Information for Hardware Management Console (HMC) Machine Type (MT) 7063

For supporting information about the IBM Power Hardware Management Console (HMC) Machine Type (MT) 7063, see the following websites.

For POWER9 processor-based servers, see:

- Installing and configuring the Hardware Management Console:
www.ibm.com/support/knowledgecenter/POWER9/p9hai/p9hai_kickoff.htm
- Hardware Management Console service (Machine Type 7063):
www.ibm.com/support/knowledgecenter/POWER9/p9eav/p9eav_kickoff.htm

For POWER8 processor-based servers, see:

- Installing and configuring the Hardware Management Console:
www.ibm.com/support/knowledgecenter/POWER8/p8hai/p8hai_kickoff.htm
- Hardware Management Console service (Machine Type 7063):
www.ibm.com/support/knowledgecenter/POWER8/p8eav/p8eav_7063_kickoff.htm

This edition applies to IBM® Power Systems servers that contain the POWER8® and POWER9™ processor and to all associated models.
Printed in USA

© **Copyright International Business Machines Corporation 2017, 2021.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

GI11-9927-02



(1P) P/N: 03GM167

