

# IBM TotalStorage DS4000 400GB SATA Drive Option Release Note



The IBM® TotalStorage® 400GB SATA drive option (P/N 39M4570) requires a certain minimum level of the DS4000 storage subsystem controller firmware and the EXP100 drive expansion enclosure ESM firmware.

Table 1 lists the required firmware versions for each IBM TotalStorage DS4000 product to enable support for the 400GB SATA drive option (P/N 39M4570).

*Table 1. Required firmware versions by product*

Product name	Machine type	Models	Required firmware versions <sup>1</sup>
IBM TotalStorage DS4100 Single controller (SCU)	1724	1SC 1Sy <sup>2</sup>	6.12.13.xx or higher
IBM TotalStorage DS4100 Dual Controller (Standard)	1724	100	6.12.13.xx or higher
IBM TotalStorage DS4300 Dual Controller (Standard)	1722	60X 60U	6.12.13.xx or higher
IBM TotalStorage DS4300 Dual Controller (with Turbo option)	1722	60X 60U	6.12.13.xx or higher
IBM TotalStorage DS4400	1742	1RX 1RY	6.12.13.xx or higher
IBM TotalStorage DS4500	1742	90X 90Y	6.12.13.xx or higher
IBM TotalStorage DS4800	1815	82A/H 84A/H 88A/H	6.15.16.xx or higher
IBM TotalStorage EXP100 drive expansion enclosure	1710	10X 10U	9563 or higher
	1724	1Xy <sup>2</sup>	

<sup>1</sup> Do not assume that any firmware versions higher than the listed version are compatible with the listed DS4000 storage products. Always check the README file of the firmware package for any non-support incompatibility statements, prerequisite tasks, cautions, required firmware download sequences, or limitations before performing the firmware download task.

**Important:** Depending on the existing version of the installed controller firmware, you might also need to schedule down time for the firmware upgrade.

<sup>2</sup> The *y* character in the model number indicates different models of the same machine type with the same first two-character model number.

Prior to installing the hard drive in your DS4000 configuration, your DS4000 storage subsystem firmware must be at the required versions listed in Table 1. If a firmware upgrade is required to install the 400GB drive option, upgrade to the latest firmware version required to maintain this minimum level for your

DS4000 storage subsystem. To download the latest firmware, go to the IBM DS4000 TotalStorage support Web site, and then click the applicable link for each of your DS4000 storage subsystems:

<http://www.ibm.com/servers/storage/support/disk/>

**Attention:** You might have to upgrade the DS4000 Storage Manager, which is installed in your management station, to a later version before downloading the newer firmware into your DS4000 storage subsystem controllers.

**Notes:**

1. Refer to the DS4000 Storage Manager Installation and Support Guide for your OS environment and to the DS4000 Storage Manager client online help for instructions on installing the host software and to perform firmware upgrades.
2. Subscribe to "My Support", on the IBM DS4000 TotalStorage support Web site, to automatically receive notifications on the availability of new firmware and Storage Manager host software for your DS4000 storage subsystems. To subscribe to "My Support" click **My Support**, and then follow the provided instructions. To learn more about the My Support subscription services, click **Tutorial**.

## Trademarks

IBM, the IBM logo, and TotalStorage are trademarks of International Business Machines Corporation in the United States, other countries, or both.

Other company, product, or service names may be trademarks or service marks of others.

---

**First edition (October 2005)**

© Copyright International Business Machines Corporation 2005. All rights reserved.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

(1P) P/N: 39M6021

