


Installing the RFID label



1. Remove the blue tape.
2. Remove the adhesive liner.
3. Rotate the RFID label until it is flat.
4. Press down on the adhesive area.

