




IBM System x3550 M4 DVD Drive Cable Option

The IBM® System x3550 M4 DVD Drive Cable option contains the following components.

Use this option kit to add a DVD drive cable to the server. See the server documentation for detailed instructions for installing this option in the server. The illustrations in this document might differ slightly from your hardware.



- One DVD drive cable
- IBM warranty information document
- Important notices document
- This document

Store this document with your other product documentation for future reference.


The product-specific documentation is provided on the IBM *Documentation* CD that comes with your server. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates. To access these pages, go to <http://www.ibm.com/systems/support/> and follow the instructions.

Installing the DVD drive cable


To install the DVD drive cable, complete the following steps:

1. See the server *Problem Determination and Service Guide* for installation guidelines and additional safety information.
2. If the server is operating, turn off the server and peripheral devices and disconnect the power cords and all external cables
3. If the server has been installed in a rack, slide the server out from the rack enclosure.
4. Remove the cover, using the instructions in your server documentation.
5. Remove the air baffle, using the instructions in your server documentation.

6. Align the cable connector with the connector on the rear of the DVD drive cage. Press the cable connector into the optical drive cage connector and slide it to the left until it is firmly seated.



The following illustration shows cable routing for the DVD cable:



7. Replace the air baffle, using the instructions in your server documentation.
8. Replace the cover, using the instructions in your server documentation.
9. Slide the server into the rack.
10. Reconnect the power cords and any cables that you removed.
11. Turn on the peripheral devices and the server.

First Edition, March 2012

IBM and the IBM logo are trademarks of the IBM Corporation in the United States, other countries, or both.

Printed in USA

© **Copyright IBM Corporation 2012.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

(1P) P/N: 90Y5630

