


## 7148/7149 – PCI Riser card Insertion Issue




Improper install method. The card should not be installed on an angle.


Note that when installed on an angle the card edge can enter the planar connector several contacts from the end. If the card is then slid back in the connector when installed, the planar connector can be damaged.



Close up view of potential pin damage.



## 7148/7149 – PCI Riser card Insertion Issue



Proper method for installing the card is to hold it flat and push it straight down into the planar connector.