

SafeNet Network HSM

LunaSH Command Reference Guide

Document Information

Product Version	6.2
Document Part Number	007-011136-010
Release Date	18 December 2015

Revision History

Revision	Date	Reason
A	18 December 2015	Initial release.

Trademarks

All intellectual property is protected by copyright. All trademarks and product names used or referred to are the copyright of their respective owners. No part of this document may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, chemical, photocopy, recording or otherwise without the prior written permission of Gemalto NV

Acknowledgements

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit.
(<http://www.openssl.org>)

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

This product includes software developed by the University of California, Berkeley and its contributors.

This product uses Brian Gladman's AES implementation.

Refer to the End User License Agreement for more information.

Regulatory Compliance

This product complies with the following regulatory regulations. To ensure compliancy, ensure that you install the products as specified in the installation instructions and use only SafeNet-supplied or approved accessories.

USA, FCC

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



Note: This equipment has been tested and found to comply with the limits for a "Class B" digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment

generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by SafeNet could void the user's authority to operate the equipment.

Canada

This class B digital apparatus meets all requirements of the Canadian interference-causing equipment regulations.

Europe

This product is in conformity with the protection requirements of EC Council Directive 2004/108/EC. Conformity is declared to the following applicable standards for electro-magnetic compatibility immunity and susceptibility; CISPR22 and IEC801. This product satisfies the CLASS B limits of EN 55022.

Disclaimer

Gemalto makes no representations or warranties with respect to the contents of this document and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Furthermore, Gemalto reserves the right to revise this publication and to make changes from time to time in the content hereof without the obligation upon Gemalto to notify any person or organization of any such revisions or changes.

We have attempted to make these documents complete, accurate, and useful, but we cannot guarantee them to be perfect. When we discover errors or omissions, or they are brought to our attention, we endeavor to correct them in succeeding releases of the product.

Gemalto invites constructive comments on the contents of this document. Send your comments, together with your personal and/or company details to the address below.

Contact Method	Contact Information
Mail	Gemalto NV 4690 Millennium Drive Belcamp, Maryland 21017 USA
Email	techpubs@safenet-inc.com

CONTENTS

PREFACE	About the LunaSH Command Reference Guide	15
Customer Release Notes		15
Gemalto Rebranding		15
Audience		16
Document Conventions		16
Notes		16
Cautions		16
Warnings		17
Command Syntax and Typeface Conventions		17
Support Contacts		17
1	Using LunaSH	19
LunaSH Features		19
Accessing LunaSH		19
Seeing More Commands		20
Exiting LunaSH		20
2	LunaSH Commands	21
audit		22
audit changepwd		24
audit config		25
audit init		27
audit log		29
audit log clear		30
audit log list		31
audit log tail		32
audit log tarlogs		34
audit log untarlogs		35
audit log verify		36
audit login		40
audit logout		41
audit remotehost		42
audit remotehost add		43
audit remotehost clear		44
audit remotehost delete		45
audit remotehost list		46
audit secret		47
audit secret export		48
audit secret import		49
audit show		50
audit sync		51
client		52
client assignpartition		53

client delete	54
client fingerprint	55
client hostip	56
client hostip map	57
client hostip show	58
client hostip unmap	59
client list	60
client register	61
client revokepartition	63
client show	64
hsm	65
hsm backup	68
hsm changepolicy	70
hsm changepw	71
hsm checkcertificates	72
hsm debug show	73
hsm displaylicenses	74
hsm duplicatemofn	75
hsm factoryreset	76
hsm firmware	78
hsm firmware rollback	79
hsm firmware show	82
hsm firmware upgrade	83
hsm fwupdateinfo	85
hsm generatedak	86
hsm information	87
hsm information monitor	88
hsm information reset	91
hsm information show	92
hsm init	93
hsm loadcustomercert	96
hsm login	97
hsm logout	98
hsm ped	99
hsm ped connect	100
hsm ped disconnect	102
hsm ped set	103
hsm ped show	105
hsm ped timeout	106
hsm ped timeout set	107
hsm ped timeout show	108
hsm ped vector	109
hsm ped vector erase	110
hsm ped vector init	111
hsm restore [reserved]	113
hsm selftest	114
hsm setlegacydomain	115
hsm show	116
hsm showpolicies	118

hsm srk	120
hsm srk disable	121
hsm srk enable	122
hsm srk keys	123
hsm srk keys resplit	124
hsm srk keys verify	125
hsm srk show	126
hsm srk transportmode	127
hsm srk transportmode enter	128
hsm srk transportmode recover	129
hsm stc	130
hsm stc activationTimeOut	132
hsm stc activationtimeout set	133
hsm stc activationtimeout show	134
hsm stc cipher	135
hsm stc cipher disable	136
hsm stc cipher enable	138
hsm stc cipher show	140
hsm stc client	141
hsm stc client deregister	142
hsm stc client list	143
hsm stc client register	144
hsm stc disable	145
hsm stc enable	146
hsm stc hmac	147
hsm stc hmac disable	148
hsm stc hmac enable	149
hsm stc hmac show	150
hsm stc identity	151
hsm stc identity create	152
hsm stc identity delete	153
hsm stc identity initialize	154
hsm stc identity partition	155
hsm stc identity partition deregister	156
hsm stc identity partition register	157
hsm stc identity show	158
hsm stc partition	159
hsm stc partition export	160
hsm stc partition show	161
hsm stc rekeyThreshold	162
hsm stc rekeythreshold set	163
hsm stc rekeythreshold show	164
hsm stc replayWindow	165
hsm stc replaywindow set	166
hsm stc replaywindow show	167
About the Replay Window	167
hsm supportinfo	168
hsm update	169
hsm update capability	170

hsm update show	171
hsm zeroize	172
htl	174
htl clearott command	175
htl generateott	176
htl set	177
htl set defaultottexpiry	178
htl set graceperiod	179
htl set ottexpiry	180
htl show	181
my	183
my file	184
my file clear	185
my file delete	186
my file list	187
my password	188
my password expiry show	189
my password set	190
my public-key	191
my public-key add	192
my public-key clear	193
my public-key delete	194
my public-key list	195
network	196
network dns	197
network dns add	198
network dns delete	199
network domain	200
network hostname	201
network interface	202
network interface static	204
network interface dhcp	205
network interface delete	206
network interface bonding	207
network interface bonding config	208
network interface bonding disable	209
network interface bonding enable	210
network interface bonding show	211
network ping	212
network route	213
network route add	214
network route clear	215
network route delete	216
network route show	217
network show	218
ntls	220
ntls activatekeys	221
ntls bind	222
ntls certificate	224

ntls certificate monitor	225
ntls certificate monitor disable	226
ntls certificate monitor enable	227
ntls certificate monitor show	228
ntls certificate monitor trap trigger	229
ntls certificate show	230
ntls deactivatekeys	232
ntls information	233
ntls information reset	234
ntls information show	235
ntls ipcheck	236
ntls ipcheck disable	237
ntls ipcheck enable	238
ntls ipcheck show	239
ntls show	240
ntls sslopsall	241
ntls sslopsrsa	242
ntls tcp_keepalive	243
ntls tcp_keepalive set	244
ntls tcp_keepalive show	246
ntls threads	247
ntls threads set	248
ntls threads show	249
ntls timer	250
ntls timer set	251
ntls timer show	252
package	253
package deletefile	254
package erase	255
package list	256
package listfile	257
package update	258
package verify	259
partition	260
partition activate	261
partition backup	263
partition changepolicy	267
partition changepw	268
partition clear	270
partition create	271
partition createuser	276
partition deactivate	278
partition delete	279
partition list	280
partition policytemplate	281
partition policytemplate change	282
partition policytemplate create	283
partition policytemplate delete	285
partition policytemplate list	286

partition policytemplate load	287
partition policytemplate save	288
partition policytemplate show	289
partition resetpw	290
partition resize	292
partition restore	294
partition sff	295
partition sff backup	296
partition sff clear	298
partition sff list	299
partition sff restore	300
partition sff showContents	302
partition setlegacydomain	304
partition show	305
partition showcontents	307
partition showpolicies	308
service	311
service list	312
service restart	313
service start	315
service status	316
service stop	317
status	318
status cpu	319
status date	320
status disk	321
status handles	322
status interface	324
status mac	325
status mem	326
status memmap	327
status netstat	329
status ps	330
status sensors	332
status sysstat	334
status sysstat code	335
status sysstat show	336
status time	337
status zone	338
stc	339
stc activationTimeOut	340
stc activationtimeout set	341
stc activationtimeout show	342
stc cipher	343
stc cipher disable	344
stc cipher enable	346
stc cipher show	348
stc client	349
stc client deregister	350

stc client list	351
stc client register	352
stc hmac	353
stc hmac disable	354
stc hmac enable	355
stc hmac show	356
stc partition	357
stc partition export	358
stc partition show	359
stc rekeyThreshold	360
stc rekeythreshold set	361
stc rekeythreshold show	362
stc replayWindow	363
stc replaywindow set	364
stc replaywindow show	365
sysconf	366
sysconf appliance	368
sysconf appliance cpugovernor	369
sysconf appliance cpugovernor disable	370
sysconf appliance cpugovernor enable	371
sysconf appliance cpugovernor show	372
sysconf appliance hardreboot	373
sysconf appliance poweroff	374
sysconf appliance reboot	375
sysconf appliance rebootonpanic	376
sysconf appliance rebootonpanic disable	377
sysconf appliance rebootonpanic enable	378
sysconf appliance rebootonpanic show	379
sysconf appliance watchdog	380
sysconf appliance watchdog disable	381
sysconf appliance watchdog enable	382
sysconf appliance watchdog show	383
sysconf banner	384
sysconf banner add	385
sysconf banner clear	387
sysconf config	389
sysconf config backup	390
sysconf config clear	391
sysconf config delete	392
sysconf config export	393
sysconf config import	394
sysconf config factoryreset	395
sysconf config list	398
sysconf config restore	399
sysconf config show	400
sysconf drift	401
sysconf drift init	402
sysconf drift reset	403
sysconf drift set	404

sysconf drift startmeasure	405
sysconf drift status	406
sysconf drift stopmeasure	407
sysconf fingerprint	408
sysconf fingerprint ntlis	409
sysconf fingerprint ssh	410
sysconf forcesologin	411
sysconf forcesologin disable	413
sysconf forcesologin enable	414
sysconf forcesologin show	416
sysconf hwregencert	417
sysconf ntp	420
sysconf ntp addserver	421
sysconf ntp autokeyauth	422
sysconf ntp autokeyauth clear	423
sysconf ntp autokeyauth generate	424
sysconf ntp autokeyauth install	426
sysconf ntp autokeyauth list	427
sysconf ntp autokeyAuth update	428
sysconf ntp deleteserver	429
sysconf ntp disable	430
sysconf ntp enable	431
sysconf ntp listservers	432
sysconf ntp log	433
sysconf ntp log tail	434
sysconf ntp ntpdate	435
sysconf ntp show	436
sysconf ntp status	437
sysconf ntp symmetricauth	439
sysconf ntp symmetricauth key	440
sysconf ntp symmetricauth key add	441
sysconf ntp symmetricauth key clear	442
sysconf ntp symmetricauth key delete	443
sysconf ntp symmetricauth key list	444
sysconf ntp symmetricauth trustedkeys	445
sysconf ntp symmetricauth trustedkeys add	446
sysconf ntp symmetricauth trustedkeys clear	447
sysconf ntp symmetricauth trustedkeys delete	448
sysconf ntp symmetricauth trustedkeys list	449
sysconf radius	449
sysconf radius addserver Command	450
Syntax	450
Example	450
sysconf radius deleteserver	450
Syntax	450
Example	451
sysconf radius disable	451
Syntax	451
Options	451

Example	451
sysconf radius enable	451
Syntax	451
Options	451
Example	451
sysconf radius show Command	452
Syntax	452
Example	452
sysconf regencert	453
sysconf securekeys	455
sysconf snmp	456
sysconf snmp disable	457
sysconf snmp enable	458
sysconf snmp notification	459
sysconf snmp notification add	460
sysconf snmp notification clear	461
sysconf snmp notification delete	462
sysconf snmp notification list	463
sysconf snmp show	464
sysconf snmp trap	465
sysconf snmp trap clear	466
sysconf snmp trap disable	467
sysconf snmp trap enable	468
sysconf snmp trap set	469
sysconf snmp trap show	470
sysconf snmp trap test	471
sysconf snmp user	473
sysconf snmp user add	474
sysconf snmp user clear	476
sysconf snmp user delete	477
sysconf snmp user list	478
sysconf ssh	479
sysconf ssh device	480
sysconf ssh ip	481
sysconf ssh password	482
sysconf ssh password disable	483
sysconf ssh password enable	484
sysconf ssh port	485
sysconf ssh publickey	486
sysconf ssh publickey disable	487
sysconf ssh publickey enable	488
sysconf ssh regenkeypair	489
sysconf ssh show	490
sysconf time	491
sysconf timezone	492
syslog	493
sylog cleanup	494
syslog export	495
syslog period	496

syslog rotate	497
syslog remotehost	498
syslog remotehost add	499
syslog remotehost clear	500
syslog remotehost delete	501
syslog remotehost list	502
syslog rotations	503
syslog severity set	504
syslog show	505
syslog tail	508
syslog tarlogs	509
token	510
token backup	511
token backup factoryreset	514
token backup init	516
token backup list	518
token backup login	520
token backup logout	522
token backup partition	523
token backup partition delete	525
token backup partition list	527
token backup partition show	529
token backup show	531
token backup update	533
token backup update capability	535
token backup update firmware	537
token backup update show	538
token pki	540
token pki activate	543
token pki changepin	544
token pki clone	546
token pki deploy	548
token pki factoryreset	550
token pki listall	551
token pki listdeployed	552
token pki predeploy	553
token pki resetpin	555
token pki undeploy	557
token pki update	558
token pki update capability	560
token pki update firmware	562
token pki update login	563
token pki update logout	564
token pki update show	565
user	566
user add	567
user delete	568
user disable	569
user enable	570

user list	571
user password	572
user radiusadd	573
user role	574
user role add	575
user role clear	577
user role delete	578
user role list	579
webserver	579
Syntax	579
webserver bind	581
webserver certificate	581
Syntax	581
webserver certificate generate	582
webserver certificate show	584
webserver ciphers	585
Syntax	585
webserver ciphers set	586
webserver ciphers show	587
webserver disable	588
webserver enable	588
webserver show	589

PREFACE

About the LunaSH Command Reference Guide

This document describes how to do something (insert a brief description). It contains the following chapters:

- "Using LunaSH" on page 19
- "LunaSH Commands" on page 21

This preface also includes the following information about this document:

- "Customer Release Notes" below
- "Gemalto Rebranding" below
- "Audience" on the next page
- "Document Conventions" on the next page
- "Support Contacts" on page 17

For information regarding the document status and revision history, see "Document Information" on page 2.

Customer Release Notes

The customer release notes (CRN) provide important information about this release that is not included in the customer documentation. It is strongly recommended that you read the CRN to fully understand the capabilities, limitations, and known issues for this release. You can view or download the latest version of the CRN for this release at the following location:

- http://www.securedbysafenet.com/releasenotes/luna/crn_luna_hsm_6-2.pdf

Gemalto Rebranding

In early 2015, Gemalto NV completed its acquisition of SafeNet, Inc. As part of the process of rationalizing the product portfolios between the two organizations, the Luna name has been removed from the SafeNet HSM product line, with the SafeNet name being retained. As a result, the product names for SafeNet HSMs have changed as follows:

Old product name	New product name
Luna SA HSM	SafeNet Network HSM
Luna PCI-E HSM	SafeNet PCI-E HSM
Luna G5 HSM	SafeNet USB HSM
Luna PED	SafeNet PED

Old product name	New product name
Luna Client	SafeNet HSM Client
Luna Dock	SafeNet Dock
Luna Backup HSM	SafeNet Backup HSM
Luna CSP	SafeNet CSP
Luna JSP	SafeNet JSP
Luna KSP	SafeNet KSP



Note: These branding changes apply to the documentation only. The SafeNet HSM software and utilities continue to use the old names.

Audience

This document is intended for personnel responsible for maintaining your organization's security infrastructure. This includes SafeNet HSM users and security officers, key manager administrators, and network administrators.

All products manufactured and distributed by Gemalto NV are designed to be installed, operated, and maintained by personnel who have the knowledge, training, and qualifications required to safely perform the tasks assigned to them. The information, processes, and procedures contained in this document are intended for use by trained and qualified personnel only.

It is assumed that the users of this document are proficient with security concepts.

Document Conventions

This document uses standard conventions for describing the user interface and for alerting you to important information.

Notes

Notes are used to alert you to important or helpful information. They use the following format:



Note: Take note. Contains important or helpful information.

Cautions

Cautions are used to alert you to important information that may help prevent unexpected results or data loss. They use the following format:



CAUTION: Exercise caution. Contains important information that may help prevent unexpected results or data loss.

Warnings

Warnings are used to alert you to the potential for catastrophic data loss or personal injury. They use the following format:



WARNING! Be extremely careful and obey all safety and security measures. In this situation you might do something that could result in catastrophic data loss or personal injury.

Command Syntax and Typeface Conventions

Format	Convention
bold	The bold attribute is used to indicate the following: <ul style="list-style-type: none"> • Command-line commands and options (Type <code>dir /p</code>.) • Button names (Click Save As.) • Check box and radio button names (Select the Print Duplex check box.) • Dialog box titles (On the Protect Document dialog box, click Yes.) • Field names (User Name: Enter the name of the user.) • Menu names (On the File menu, click Save.) (Click Menu > Go To > Folders.) • User input (In the Date box, type April 1.)
<i>italics</i>	In type, the italic attribute is used for emphasis or to indicate a related document. (See the <i>Installation Guide</i> for more information.)
<variable>	In command descriptions, angle brackets represent variables. You must substitute a value for command line arguments that are enclosed in angle brackets.
[optional] [<optional>]	Represent optional keywords or <variables> in a command line description. Optionally enter the keyword or <variable> that is enclosed in square brackets, if it is necessary or desirable to complete the task.
{a b c} {<a> <c>}	Represent required alternate keywords or <variables> in a command line description. You must choose one command line argument enclosed within the braces. Choices are separated by vertical (OR) bars.
[a b c] [<a> <c>]	Represent optional alternate keywords or variables in a command line description. Choose one command line argument enclosed within the braces, if desired. Choices are separated by vertical (OR) bars.

Support Contacts

Contact method	Contact
Address	Gemalto NV 4690 Millennium Drive Belcamp, Maryland 21017 USA

Contact method	Contact	
Phone	Global	+1 410-931-7520
	Australia	1800.020.183
	China	(86) 10 8851 9191
	France	0825 341000
	Germany	01803 7246269
	India	000.800.100.4290
	Netherlands	0800.022.2996
	New Zealand	0800.440.359
	Portugal	800.1302.029
	Singapore	800.863.499
	Spain	900.938.717
	Sweden	020.791.028
	Switzerland	0800.564.849
	United Kingdom	0800.056.3158
United States	(800) 545-6608	
Web	www.safenet-inc.com	
Support and Downloads	www.safenet-inc.com/support Provides access to the Gemalto Knowledge Base and quick downloads for various products.	
Technical Support Customer Portal	https://serviceportal.safenet-inc.com Existing customers with a Technical Support Customer Portal account can log in to manage incidents, get the latest software upgrades, and access the Gemalto Knowledge Base.	

Using LunaSH

This chapter describes how to access and use the LunaSH utility. It contains the following topics:

- "LunaSH Features" below
- "Accessing LunaSH" below
- "Seeing More Commands" on the next page
- "Exiting LunaSH" on the next page

LunaSH Features

LunaSH provides the following features:

- Command history is supported, using up/down arrows, [Home], [End], [Page Up], [Page Down].
- Command shortnames are supported. You must type sufficient letters of a command or sub-command to make the input unique in the current syntax. For example, you could invoke system syntax help with "help", "hel", "he", but not just "h" (because there is also an "hsm" command and typing just "h" is not sufficient to indicate whether you want "help" or "hsm"). Additionally, for syntax help, the alias "?" is available.
- When the logging function is active, the full name of a command is recorded in the log, not the short version.
- If you supply a short form that is ambiguous, an error message is presented, followed by the list of available commands, sub-commands, or options at the current level.
- Context-sensitive command completion is supported, using [Tab].
- Commands and options are case-insensitive.



Note: Sub-commands do not take a leading dash; options must be typed with a leading single dash. If a command is refused, retry, being careful to type correct syntax. If you are unsure, type the command name followed by a question mark, to force a syntax error and a summary of the proper syntax for that command.

Accessing LunaSH

LunaSH (`lunash`) is the command interface for SafeNet Network HSM.

Connect to the SafeNet appliance using any ssh-capable communication utility (Windows users can use the provided `putty.exe`).

When a successful connection is made, a terminal window opens and the prompt "login as:" appears.

For maximum access, type "admin" and press enter.

You are prompted for the admin password. If this is the first time you have connected, the default password is "PASSWORD", and you are required to change it to something more secure.

Once you have logged in, the system presents the LunaSH prompt, which includes the hostname that you have assigned to your SafeNet appliance:

```
[myLuna] lunash:>
```

You can now issue any `lunash` command. For a summary, type "?" or "help" and press [Enter].

If the admin user has previously created other users, and you know the relevant password, you can log in as a named user instead of "admin".

Seeing More Commands

All of the top-level LunaSH commands (except "exit") have sub-commands and options.

To view a syntax summary of a command, type "help" or "?" followed by the command name. You can also type a command name followed by a space, followed by a character that is unlikely to appear in the sub-commands or options, like "?" or "h".

Exiting LunaSH

Any time you wish to leave your `lunash:>` session, type "e", "ex", "exi", or "exit" at the prompt and press [Enter]. Your session terminates and the terminal window closes.

To return to `lunash:>`, you will need to open a new terminal session (with PuTTY.exe or SSH, as appropriate) and login as admin when the "login as:" prompt appears.

LunaSH Commands

This chapter describes the commands available in the SafeNet Network HSM command shell (lunash). The commands are described in alphabetical order and provide:

- a brief description of the command function
- the command syntax and parameter descriptions
- usage examples

The following list provides links to the top level commands in the hierarchy. Select a link to display the command syntax or to help you to navigate to the sub-command you need:

- ["audit "](#) on the next page. The audit command menu is available to the authenticated (logged in) Audit user, only.
- ["client"](#) on page 52
- ["hsm"](#) on page 65
- ["htl"](#) on page 174
- ["my"](#) on page 183
- ["network"](#) on page 196
- ["ntls"](#) on page 220
- ["package"](#) on page 253
- ["partition"](#) on page 260
- ["service"](#) on page 311
- ["status"](#) on page 318
- ["stc"](#) on page 339
- ["sysconf"](#) on page 366
- ["syslog"](#) on page 493
- ["token"](#) on page 510
- ["user"](#) on page 566
- ["webservice"](#) on page 579 (available when the REST API configuration upgrade is installed)

audit

Access commands that allow the **audit** user to perform HSM auditing tasks.



Note: Audit commands control HSM audit logging. They are visible only to the audit user, and are hidden from the appliance admin, operator, monitor, or any other non-auditor user.

The audit user also has access to a limited set of commands grouped under the following command menus:

hsm	Provides access to the following: <ul style="list-style-type: none"> the hsm show command. See "hsm show" on page 116. all hsm ped commands, except for the hsm ped vector commands. The audit appliance user is allowed to connect and disconnect remote PED connections, adjust timeout, and view connection information, but is not allowed to create (init) or erase a remote PED vector. See "hsm ped" on page 99.
my	Provides a set of commands equivalent to those provided to other non-admin users. See " my " on page 183
network	Provides only the show and ping commands. See " network " on page 196.

Syntax

audit

changepwd
config
init
log
login
logout
remotehost
secret
show
sync

Parameter	Shortcut	Description
changepwd	-ch	Changes the audit user password or PED key. See " audit changepwd " on page 24.
config	-co	Set the audit parameters. See " audit config " on page 25.
init	-i	Initialize the audit role. See " audit init " on page 27.
log	-log	Access commands that allow you to manage audit log files. See " audit log " on page 29.
login	-logi	Login as the audit user. See " audit login " on page 40
logout	-logo	Logout the audit user. See " audit logout " on page 41

Parameter	Shortcut	Description
remotehost	-r	Configure audit logging remote hosts. See "audit remotehost" on page 42.
secret	-se	Export or import the audit logging secret. See "audit secret" on page 47.
show	-sh	Display the current audit logging configuration. See "audit show" on page 50
sync	-sy	Synchronizes the HSM time to the host time. See "audit sync" on page 51

audit changepwd

Change the password or PED key contents for the HSM Audit role. Both the old and the new PED key are required for SafeNet Network HSM with PED authentication.

Syntax

```
audit changepwd [-serial <serialnum>] [-oldpw <password>] [-newpw <password>]
```

Parameter	Shortcut	Description
-newpw	-n	Specifies the new password for the Audit role. If you do not use this parameter, you are prompted to enter and confirm the password. A valid password should be a mix of upper and lower-case letters, digits, and other characters, and must be a minimum of 8 characters long.
-oldpw	-o	Specifies the current password for the HSM Audit role. If you do not use this parameter, you are prompted for the password. This parameter applies to password-authenticated HSMs only.
-serial	-s	Specifies the serial number of the HSM. This option allows the system to distinguish between two connected HSMs, as might occur with a PKI bundle configuration (secondary USB-attached SafeNet USB HSM).

Example

```
lunash:>audit changepwd
```

```
Please enter the old password:
```

```
> *****
```

```
Please enter the new password:
```

```
> *****
```

```
Please re-enter the new password:
```

```
> *****
```

```
Command Result : 0 (Success) lunash:>
```


audit config

Set the configuration parameters for audit logging.

Syntax

audit config **-parameter** <parameter> **-value** <value> [**-serial** <serialnum>]

Parameter	Shortcut	Description
-parameter	-p	<p>Specifies the type of parameter to set.</p> <p>Valid values (the value enclosed in parentheses [n] indicates a shortcut):</p> <ul style="list-style-type: none"> [e]vent - Include the list of events specified using the -value parameter in the log. [r]otation - Rotate the logs as specified by the -value parameter.
-serial	-s	<p>RESERVED FOR FUTURE USE.</p> <p>Specifies the serial number of the HSM. This option allows the system to distinguish between two connected HSMs, as might occur with a PKI bundle configuration (secondary USB-attached SafeNet USB HSM).</p>
-value	-v	<ul style="list-style-type: none"> If -parameter is set to event, this specifies a comma-separated list of events to include in the log. <p>Note: In addition to specifying an event category, you must also specify the conditions under which those events are to be logged - either f for failures, or s for successes, or both. See the examples.</p> <p>Valid values (the value enclosed in parentheses [] indicates a shortcut):</p> <ul style="list-style-type: none"> [f]ailure: log command failures [s]uccess: log command successes [a]ccess: log access attempts (logins) [m]anage: log HSM management (init/reset/etc) [k]eymanage: key management events (key create/delete) [u]sage: key usage (enc/dec/sig/ver) fi[r]st: first key usage only (enc/dec/sig/ver) e[x]ternal: log messages from CA_LogExternal lo[g] manage: log events relating to log configuration a[l]l: log everything (user will be warned) [n]one: turn logging off If -parameter is set to rotation, this specifies the log rotation interval. <p>Valid values (the value enclosed in parentheses [] indicates a shortcut):</p>

Parameter	Shortcut	Description
		<ul style="list-style-type: none"> - [h]ourly - [d]aily - [w]eekly - [m]onthly - [n]ever

Example

The following table provides some command usage examples:

Command	Description
<code>audit config -p e -v all</code>	Log everything.
<code>audit config -p e -v none</code>	Log nothing.
<code>audit config -p e -v f</code>	Log all command failures.
<code>audit config -p e -v u,f,s</code>	Log all key usage requests, both success and failure.
<code>audit config -p r -v daily</code>	Rotate the log daily.

The following example shows the warning displayed when you use the **all** option:

```
lunash:>audit config -p e -v all
```

```
Warning:: You have chosen to log all successful key usage events.
This can result in an extremely high volume of log messages, which
will significantly degrade the overall performance of the HSM.
```

```
Command Result : 0 (Success)
```

audit init

Initialize the Audit role. The **audit init** command is available only to the **audit** user of the HSM appliance and initializes the Audit role on the HSM. This command attaches an audit domain and a role password for password-authenticated HSMs, and creates a white Audit PED key for PED-authenticated HSMs. For PED-auth HSMs audit init also creates an audit domain, or receives an existing domain, so that selected HSMs are able to validate each others' HSM audit log files.



Note: Because this command destroys any existing Audit role on the HSM, the user is asked to “proceed” unless the **-force** switch is provided at the command line.

Syntax

audit init [-serial <serialnum>] [-domain <auditdomain>] [-defaultdomain] [-password <password>] [-force]

(Option)	Parameter	Description
-defaultdomain	-de	Specifies that the default domain string is to be used as key cloning domain for the HSM. Using the default domain implies that the HSM can be used in HSM Audit Log file validation operations with any other HSM in the world that retains the default domain - retaining the default domain is not recommended. This option is deprecated and will be discontinued in a future release. -defaultdomain and -domain are mutually exclusive -defaultdomain is ignored for PED-authenticated HSMs
-domain	-do	Specifies the string to be used as key cloning domain for the HSM. If no value is given for a SafeNet HSM with Password Authentication, you are prompted interactively. -defaultdomain and -domain are mutually exclusive -domain is ignored for PED-authenticated HSMs
-force	-f	Force the action without prompting.
-password	-p	Specifies the current password for the HSM Audit role. If you do not use this parameter, you are prompted for the password. This parameter applies to password-authenticated HSMs only.
-serial	-s	Specifies the serial number of the HSM. This option allows the system to distinguish between two connected HSMs, as might occur with a PKI bundle configuration (secondary USB-attached SafeNet USB HSM).

Example

```
[mypwlunasa] lunash:>audit init
```

```
    The AUDIT role will be initialized.
```

```
    Are you sure you wish to continue?
```

```
    Type proceed to continue, or quit to quit now -> proceed
```

```
    Please enter a domain to use for initializing the Audit role:
```

```
> *****
```

```
    Please re-enter domain to confirm:
```

```
> *****
```

```
    Please enter the password:
```

```
> *****
```

```
    Please re-enter password to confirm:
```

```
> *****
```

```
Command Result : 0 (Success)
```



Note: For PED-authenticated HSMs, after you type "proceed" you are referred to the PED (which must be connected and 'Awaiting command...') which prompts you for domain (red PED Key) and Audit authentication (white PED Key).

audit log

Access commands that allow you to manage the audit logs.

Syntax

audit log

clear
list
tail
tarlogs
untarlogs
verify

Parameter	Shortcut	Description
clear	c	Clears all of the audit logs from an HSM. See "audit log clear" on the next page.
list	l	Lists all of the audit logs on an HSM. See "audit log list" on page 31.
tail	tai	Displays the most recent entries in an audit log. See "audit log tail" on page 32.
tarlogs	tar	Archives an audit log. See "audit log tarlogs" on page 34
untarlogs	u	Unarchives a previously archived audit log. See "audit log untarlogs" on page 35.
verify	v	Verifies a set of records within an audit log. See "audit log verify" on page 36.

audit log clear

Clear all of the audit log files from an HSM.

Syntax

audit log clear [-serial <serialnum>] [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-serial	-s	Specifies the serial number of the HSM from which you want to clear the logs. This option is required only when there are multiple attached HSMs.

Example

```
lunash:>audit log clear -serial 150718 -f
```

```
Log files cleared.
```

```
Command Result : 0 (Success)
```

audit log list

Display a list of the audit log files.

Syntax

audit log list [-serial <serialnum>]

Parameter	Shortcut	Description
-serial	-s	Specifies the serial number of the HSM from which you want to list the logs. This option is required only when there are multiple attached HSMs. Default is the embedded HSM.

Example

```
lunash:>>audit log list
```

The current log file is:

```
6872 Dec 17 20:28 hsm_153722_00000001.log
```

Logs that are ready for archive:

```
586872 Dec 17 20:58 hsm_153722_00000000.log
```

Command Result : 0 (Success)

audit log tail

Display the last several entries of the named log file, with options to narrow the selection of the displayed entries.

Syntax

```
audit log tail -file <filename> [-serial <serialnum>] [-entries <logentries>] [-search <string>]
```

Parameter	Shortcut	Description
-entries	-e	Specifies the number of log entries to display.
-file	-f	Specifies the name of the log file to view.
-search	-sea	Specifies a search string, such that only log entries containing that string are returned, from the named file, and from the specified range of "-entries" within that file (if the "-entries" option is provided - otherwise, the entire file is searched).
-serial	-ser	Specifies the serial number of the HSM from which you want to clear the logs. This option is required only when there are multiple attached HSMs.

Example

The following example lists the twenty most recent log entries.

```
[sa5] lunash:>>audit log tail -file hsm_153722_00000000.log -entries 20
```

```
1472,12/12/18 02:27:12,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1473,12/12/18 02:27:12,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
CLOSE_SESSION returned RC_OK(0x00000000) session handle 2
1474,12/12/18 02:27:32,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1475,12/12/18 02:27:32,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
CLOSE_SESSION returned RC_OK(0x00000000) session handle 2
1476,12/12/18 02:27:47,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1477,12/12/18 02:27:52,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
CLOSE_SESSION returned RC_OK(0x00000000) session handle 2
1478,12/12/18 02:28:07,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1479,12/12/18 02:28:07,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
CLOSE_SESSION returned RC_OK(0x00000000) session handle 2
1480,12/12/18 02:28:27,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1481,12/12/18 02:28:27,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
CLOSE_SESSION returned RC_OK(0x00000000) session handle 2
1482,12/12/18 02:28:47,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1483,12/12/18 02:28:47,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
CLOSE_SESSION returned RC_OK(0x00000000) session handle 2
1484,12/12/18 02:29:02,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
```



```

OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1485,12/12/18 02:29:02,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
CLOSE_SESSION returned RC_OK(0x00000000) session handle 2
1486,12/12/18 02:29:22,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1487,12/12/18 02:29:22,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
CLOSE_SESSION returned RC_OK(0x00000000) session handle 2
1488,12/12/18 02:29:42,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1489,12/12/18 02:29:42,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
CLOSE_SESSION returned RC_OK(0x00000000) session handle 2
1490,12/12/18 02:29:47,S/N 153722 session 2 Access 2147483651:22817 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1491,12/12/18 02:29:47,S/N 153722 session 2 Access 2147483651:22817 SO container operation LUNA_
CLOSE_SESSION returned RC_OK(0x00000000) session handle 2

```

Command Result : 0 (Success)

The following example lists only those entries that contain the string "OPEN_SESSION", within the twenty most recent entries in the log.

```
[sa5] lunash:>>audit log tail -file hsm_153722_00000000.log -entries 20 -search OPEN_SESSION
```

```

1492,12/12/18 02:29:57,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1494,12/12/18 02:30:17,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1496,12/12/18 02:30:37,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1498,12/12/18 02:30:57,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1500,12/12/18 02:31:12,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1502,12/12/18 02:31:32,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1504,12/12/18 02:31:52,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1506,12/12/18 02:32:12,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1508,12/12/18 02:32:27,S/N 153722 session 2 Access 2147483651:3 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2
1510,12/12/18 02:32:27,S/N 153722 session 2 Access 2147483651:22817 SO container operation LUNA_
OPEN_SESSION returned RC_OK(0x00000000) session handle 2

```

Command Result : 0 (Success)

```
[sa5] lunash:>
```

audit log tarlogs

Archives log files to audit.tgz file in the user local directory.

Syntax

audit log tarlogs [-serial <serialnum>]

Parameter	Shortcut	Description
-serial	-s	Specifies the serial number of the HSM from which you want to clear the logs. This option is required only when there are multiple attached HSMs. The default is to use the embedded HSM.

Example

```
lunash:>audit log tarlogs -serial 153593
Compressing log files:
```

```
153593/
153593/hsm_153593_0000000a.log
153593/ready_for_archive/
153593/ready_for_archive/hsm_153593_00000003.log
153593/ready_for_archive/hsm_153593_00000002.log
153593/ready_for_archive/hsm_153593_00000007.log
153593/ready_for_archive/hsm_153593_00000005.log
153593/ready_for_archive/hsm_153593_00000004.log
153593/ready_for_archive/hsm_153593_00000009.log
153593/ready_for_archive/hsm_153593_00000008.log
153593/ready_for_archive/hsm_153593_00000006.log
153593/ready_for_archive/hsm_153593_00000001.log
```

```
Command Result : 0 (Success)
```

audit log untarlogs

Un-archives a previously archived log file to the local directory. The log file is restored to a subdirectory named with the HSM's serial number.

Syntax

audit log untarlogs [-file <logfilename>]

Parameter	Shortcut	Description
-file	-f	Specifies the name of the archived log file to restore.

Example

```
[mylunasa] lunash:>audit log untarlogs -file x.tgz
```

```
Cannot find the file in /home/audit/lush_files/
```

```
Found files:
```

```
153593.lws  audit-153593.tgz
```

```
Command Result : 65535 (Luna Shell execution)
```

```
[mylunasa] lunash:>audit log untarlogs -file audit-153593.tgz
```

```
Extracting logs to audit home:
```

```
153593/
153593/hsm_153593_0000000a.log
153593/ready_for_archive/
153593/ready_for_archive/hsm_153593_00000003.log
153593/ready_for_archive/hsm_153593_00000002.log
153593/ready_for_archive/hsm_153593_00000007.log
153593/ready_for_archive/hsm_153593_00000005.log
153593/ready_for_archive/hsm_153593_00000004.log
153593/ready_for_archive/hsm_153593_00000009.log
153593/ready_for_archive/hsm_153593_00000008.log
153593/ready_for_archive/hsm_153593_00000006.log
153593/ready_for_archive/hsm_153593_00000001.log
```

To verify these logs see the 'audit secret import' command to import the HSM's log secret.

```
Command Result : 0 (Success)
```

audit log verify

Verify the audit log records.

Syntax

```
audit log verify -file <filename> [-serialtarget <serialnum>] [-serialsource <serialnum>] [-start <number>] [-end <number>] [-external]
```

Parameter	Shortcut	Description
-end	-en	Specifies the final record of the subset of records to be verified from the file.
-external	-ex	Specifies that the file from which log entries are to be verified is from an external HSM. In this case, the audit secret for that HSM must either be the same secret (white PED Key) as is used on the current HSM, or must have been imported to the current HSM. The current HSM's own audit secret cannot verify log files from other HSMs if those were created using independent secrets. The HSM holds only one audit secret at a time, so the secret for the relevant HSM's logs must be brought into the HSM when needed for log verification, if it is not already present.
-file	-f	Specifies the name of the log file to verify.
-serialsource	-serials	Specifies the serial number of the HSM that generated the log file that is being verified.
-serialtarget	-serialt	Specifies the serial number of the HSM that is performing the verification.
-start	-st	Specifies the starting record of the subset of records to be verified from the file.

Example

Verification of my own log file, with my own secret

```
lunash:>audit log verify -f hsm_150073_00000011.log
```

```
Log file being verified hsm_150073_00000011.log.
```

```
Verifying log on HSM with serial 150073
```

```
Verified messages 236 to 236
```

```
Command Result : 0 (Success)
```

Attempted verification of external log, with my own secret

```
lunash:>audit log verify -f hsm_100548_000004a3.log
```

Log file being verified /home/audit/lush_files/hsm_100548_000004a3.log.

Verifying log from HSM with serial 150073 on HSM with serial 150073
Make sure that you have already imported the audit log secret.

Verify failed on record 10760271

If you have imported a log secret from another HSM please export then re-import your own log secret. For security reasons it is not possible to verify logs using two different secrets at the same time. One or more messages did not verify.

The audit sub-command failed. (LUNA_RET_LOG_BAD_RECORD_HMAC)

Command Result : 65535 (Luna Shell execution)

Verification of external log with external secret:

In this example, we show the process from both HSMs.

```
[myluna72] lunash:> audit secret export
```

The encrypted log secret file 153593.lws now available for scp.

Now that you have exported your log secret, if you wish to verify your logs on another HSM see the 'audit secret import' command. If you wish to verify your logs on another SafeNet Network HSM see the 'audit log tar' command.

Command Result : 0 (Success)

```
[myluna72] lunash:>audit log tar
```

Compressing log files:

```
153593/
153593/hsm_153593_00000019.log
153593/153593.lws
153593/ready_for_archive/
153593/ready_for_archive/hsm_153593_0000000b.log
153593/ready_for_archive/hsm_153593_00000003.log
153593/ready_for_archive/hsm_153593_00000002.log
153593/ready_for_archive/hsm_153593_00000011.log
153593/ready_for_archive/hsm_153593_00000010.log
153593/ready_for_archive/hsm_153593_00000007.log
153593/ready_for_archive/hsm_153593_00000005.log
153593/ready_for_archive/hsm_153593_00000004.log
153593/ready_for_archive/hsm_153593_00000016.log
153593/ready_for_archive/hsm_153593_0000000a.log
153593/ready_for_archive/hsm_153593_0000000d.log
153593/ready_for_archive/hsm_153593_00000009.log
153593/ready_for_archive/hsm_153593_00000008.log
153593/ready_for_archive/hsm_153593_00000013.log
153593/ready_for_archive/hsm_153593_0000000f.log
153593/ready_for_archive/hsm_153593_00000014.log
153593/ready_for_archive/hsm_153593_00000015.log
153593/ready_for_archive/hsm_153593_00000018.log
```

```

153593/ready_for_archive/hsm_153593_0000000c.log
153593/ready_for_archive/hsm_153593_0000000e.log
153593/ready_for_archive/hsm_153593_00000012.log
153593/ready_for_archive/hsm_153593_00000017.log
153593/ready_for_archive/hsm_153593_00000006.log
153593/ready_for_archive/hsm_153593_00000001.log

```

The tar file containing logs is now available as file 'audit-153593.tgz'.
If you wish to verify your logs on another SA, scp them to another SA's audit directory then use the 'audit log untar' command.

Command Result : 0 (Success)

Here is where we scp the secret file and the .tgz file to a different SafeNet Network HSM

```
lunash:> audit secret import -serialtarget 150825 -file 153593.lws -serialsource 153593
```

Successfully imported the encrypted log secret 153593.lws

Now that you have imported a log secret if you wish to verify your logs please see the 'audit log verify' command.

Command Result : 0 (Success)

```
[myluna73] lunash:> audit log untarlogs -file audit-153593.tgz
```

Extracting logs to audit home:

```

153593/
153593/hsm_153593_00000019.log
153593/153593.lws
153593/ready_for_archive/
153593/ready_for_archive/hsm_153593_0000000b.log
153593/ready_for_archive/hsm_153593_00000003.log
153593/ready_for_archive/hsm_153593_00000002.log
153593/ready_for_archive/hsm_153593_00000011.log
153593/ready_for_archive/hsm_153593_00000010.log
153593/ready_for_archive/hsm_153593_00000007.log
153593/ready_for_archive/hsm_153593_00000005.log
153593/ready_for_archive/hsm_153593_00000004.log
153593/ready_for_archive/hsm_153593_00000016.log
153593/ready_for_archive/hsm_153593_0000000a.log
153593/ready_for_archive/hsm_153593_0000000d.log
153593/ready_for_archive/hsm_153593_00000009.log
153593/ready_for_archive/hsm_153593_00000008.log
153593/ready_for_archive/hsm_153593_00000013.log
153593/ready_for_archive/hsm_153593_0000000f.log
153593/ready_for_archive/hsm_153593_00000014.log
153593/ready_for_archive/hsm_153593_00000015.log
153593/ready_for_archive/hsm_153593_00000018.log
153593/ready_for_archive/hsm_153593_0000000c.log
153593/ready_for_archive/hsm_153593_0000000e.log
153593/ready_for_archive/hsm_153593_00000012.log
153593/ready_for_archive/hsm_153593_00000017.log
153593/ready_for_archive/hsm_153593_00000006.log
153593/ready_for_archive/hsm_153593_00000001.log

```

To verify these logs see the 'audit secret import' command to import the HSM's log secret.

```
Command Result : 0 (Success)
[myluna73] lunash:> audit log verify -serialtarget 150825 -file hsm_153593_00000001.log -serialsource 153593
```

```
Log file being verified /home/audit/lush_files/153593/ready_for_archive/hsm_153593_00000001.log.
```

```
Verifying log from HSM with serial 153593 on HSM with serial 150825
Make sure that you have already imported the audit log secret.
```

```
Verified messages 39638 to 39641
```

```
Command Result : 0 (Success)
[myluna73]
```

On the verifying HSM ([myluna73] in the example), you just imported a secret (displacing the native secret of the local HSM) and used it to verify logs that were transported from a different HSM ([myluna72] in the example).

If you now wished to verify the second HSM's ([myluna73]) own log files, you would need to re-import that HSM's secret, having replaced it with the other HSM's ([myluna72]'s) secret for the example operation.

That is, [myluna72]'s log secret that was imported into [myluna73] to allow [myluna73] to verify logs received from [myluna72], is not useful to verify [myluna73]'s own logs. An HSM can have only one log secret at a time, so [myluna73] needs its own secret back if it is to verify its own logs, rather than the logs it received from [myluna72].

Attempted Verification of local log with external secret:

```
[myluna] lunash:>audit log verify -f hsm_150073_00000011.log
```

```
Log file being verified hsm_150073_00000011.log.
```

```
Verifying log on HSM with serial 150073
```

```
Verify failed on record 236
```

If you have imported a log secret from another HSM please export then re-import your own log secret. For security reasons it is not possible to verify logs using two different secrets at the same time. One or more messages did not verify. The log file you specified was either open by the logger daemon, or was improperly terminated. If the file was open by the logger daemon, the content of it may have changed as the result of new messages being logged. In this case, running the query again will succeed.

```
The audit sub-command failed. (LUNA_RET_LOG_BAD_RECORD_HMAC)
```

```
Command Result : 65535 (Luna Shell execution)
[myluna] lunash:>
```

audit login

Log in the HSM Audit user.

For SafeNet Network HSM with PED (Trusted Path) Authentication, a new Audit secret is created on the HSM and imprinted on a white PED Key, or an existing Audit secret is retrieved from a presented white PED Key and imprinted onto the HSM. After initialization, the appropriate white PED Key is needed for HSM Audit role login.

Syntax

audit login [-serial <serialnum>] [-password <password>]

Parameter	Shortcut	Description
-serial	-s <serialnum>	HSM Serial Number - identifies which HSM is to accept the login if you have multiple HSMs (for example a Backup HSM or a SafeNet USB HSM locally connected to your host).
-password	-p <password>	<p>The password of the HSM you are logging into. Used for Password-authenticated HSMs. If you prefer not to write the password, in the clear, on the command line, leave it out and you are prompted for it. Ignored for PED-authenticated HSMs.</p> <p>If the audit log area in the HSM becomes full, the HSM stops accepting most commands, and does not prompt for password when login is requested. In that case, provide the password with the command, and the login is accepted. Audit log full does not affect login for PED-auth HSMs.</p>

Example

PED-Authenticated HSM

```
lunash:>audit login
```

```
Luna PED operation required to login as HSM Auditor - use Audit user (white) PED key.
```

```
'audit
```

```
lunash:>
```

Password authenticated HSM

```
lunash:>audit login
```

```
  Please enter the password:
> *****
```

```
Command Result : 0 (Success)
```


audit logout

Log out the HSM Audit user.

Syntax

audit logout

Example

```
lunash:>audit logout
```

```
'audit logout' successful.  
Command Result : 0 (Success)
```

audit remotehost

Access commands that allow you to add, delete, or view the remote logging servers.

Syntax

audit remotehost

add
clear
delete
list

Parameter	Shortcut	Description
add	a	Adds a Remote Logging Server. See "audit remotehost add" on the next page.
clear	c	Deletes all Remote Logging Servers. See "audit remotehost clear" on page 44.
delete	d	Delete a Remote Logging Server. See "audit remotehost delete" on page 45.
list	l	Display a list of all currently configured Remote Logging Servers. See "audit remotehost list" on page 46.

audit remotehost add

Add an identified Remote Logging Server.

Syntax

```
audit remotehost add -host <hostnameoripaddress> [-protocol <protocol>] [-port <port>]
```

Parameter	Shortcut	Description
-host	-h	Specifies the Remote Logging Server Host Name or IP address.
-port	-po	Specifies the server port to use for the Remote Logging Server. Range: 0 to 65535 Default: 514.
-protocol	-pr	Specifies the protocol for remote logging with the specified server. Valid values: tcp, udp Default: udp

Example

```
lunash:>audit remotehost add -host mylogginghost -protocol tcp -port 1660
Remote logging server added.
```

```
Shutting down kernel logger:           [ OK ]
Shutting down system logger:          [ OK ]
Starting system logger:                 [ OK ]
Starting kernel logger:                [ OK ]
Saving firewall rules to /etc/sysconfig/iptables: [ OK ]
```

```
Command Result : 0 (Success)
```

audit remotehost clear

Delete all of the currently configured Remote Logging Servers.

Syntax

audit remotehost clear [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

With the -force option

```
lunash:>audit remotehost clear -f
```

```
Shutting down kernel logger:           [ OK ]
Shutting down system logger:          [ OK ]
Starting system logger:                [ OK ]
Starting kernel logger:                [ OK ]
```

```
Command Result : 0 (Success)
```

```
[myluna] lunash:>
```

Without the -force option

```
[myluna] lunash:>audit remotehost clear
```

```
All remote hosts receiving the audit logs will be deleted.
Are you sure you wish to continue?
```

```
Type proceed to continue, or quit to quit now -> proceed
```

```
Shutting down kernel logger:           [ OK ]
Shutting down system logger:          [ OK ]
Starting system logger:                [ OK ]
Starting kernel logger:                [ OK ]
```

```
Command Result : 0 (Success)
```

audit remotehost delete

Delete an identified remote logging server.

Syntax

```
audit remotehost delete -host <hostnameoripaddress>
```

Parameter	Shortcut	Description
-host	-h	Specifies the host name or IP address of the remote logging server.

Example

```
[myluna] lunash:>audit remotehost delete -host myotherluna
```

```
Shutting down kernel logger:          [ OK ]
Shutting down system logger:         [ OK ]
Starting system logger:              [ OK ]
Starting kernel logger:              [ OK ]
```

```
Command Result : 0 (Success)
```

audit remotehost list

Display a list of the currently configured remote logging servers.

Syntax

audit remotehost list

Example

```
lunash:>audit remotehost list
```

```
Remote logging server(s):  
=====
```

```
172.20.10.201:514, udp
```

```
Command Result : 0 (Success)
```

audit secret

Access commands that allow you to import or export the audit logging secret.

Syntax

audit secret

export
import

Parameter	Shortcut	Description
export	e	Export the audit logging secret. See "audit secret export" on the next page
import	i	Import the audit logging secret. See "audit secret import" on page 49.

audit secret export

Export the audit logging secret to the user's local directory and log archive directory. This is the secret that can later be used to verify log files and log records produced by the HSM identified by the serial number provided with this command.

Syntax

audit secret export [-serial <serialnum>]

Parameter	Shortcut	Description
-serial	-s	Specifies the serial number of the HSM whose logging secret you want to export. The default is to use the embedded HSM.

Example

```
lunash:>audit secret export -serial 150718
```

The encrypted log secret file 150718.lws now available for scp.

Now that you have exported your log secret, if you wish to verify your logs on another HSM see the 'audit secret import' command. If you wish to verify your logs on another SA see the 'audit log tar' command.

Command Result : 0 (Success)

audit secret import

Imports the audit logging secret from another HSM, in order to verify log records and log files from that other HSM. The logging secret must first have been exported from the originating (source) HSM using the audit secret export command, and the resulting audit-secret file transported to the location/host of the current (target) HSM.

Syntax

audit secret import -serialtarget <serialnum> **-serialsource** <serialnum> **-file** <filename>

Parameter	Shortcut	Description
-file	-f	Specifies the name of the audit secret file to import.
-serialsource	-serials	Specifies the serial number of the source HSM from which the logging secret was exported.
-serialtarget	-serialt	Specifies the serial number of the target HSM to which the logging secret will be imported.

Example

```
lunash:>audit secret import -serialt 150719 -serials 150718 -file 150718.lws
```

```
Command Result : 0 (Success)
```

audit show

Display the current audit logging information. The displayed information varies, depending on whether or not the 'audit' role is logged in.

Syntax

audit config -parameter <parameter> **-value** <value> [**-serial** <serialnum>]

Parameter	Shortcut	Description
-serial	-s	Specifies the serial number of the HSM whose audit logging information you want to display. The default is to use the embedded HSM.

Example

```
lunash:>audit show
```

```
HSM Logging Status:
```

```
HSM found logging daemon
Logging has been configured
HSM is currently storing 0 log records.
```

```
HSM Audit Role: logged in
```

```
HSM Time   : Mon Dec 17 17:50:35 2012
HOST Time  : Mon Dec 17 17:51:07 2012
```

```
Current Logging Configuration
```

```
-----
event mask      : Log everything
rotation interval : daily
```

```
Command Result : 0 (Success)
```

audit sync

Synchronize the HSM time to the host time.

Any computer's onboard time is subject to drift. This command causes the HSM to adjust its time to match that of the host computer (such as the SafeNet Network HSM appliance). This is especially useful when the host computer is synchronized by NTP, or by local drift correction. Among other benefits, this ensures that the log times of HSM events coincide with file creation and update events in the host file system.

Syntax

audit sync

Example

```
lunash:>audit sync
```

```
Command Result : 0 (Success)
```

client

Access commands that allow you to manage the SafeNet HSM clients that are able to use partitions on the appliance.

Syntax

client

assignpartition
delete
fingerprint
hostip
list
register
revokepartition
show

Parameter	Shortcut	Description
assignpartition	a	Assign partition access rights to a client. See " client assignpartition " on the next page.
delete	d	Delete a client. See " client delete " on page 54.
fingerprint	f	Display the certificate fingerprint for a registered client. See " client fingerprint " on page 55.
hostip	h	Display or configure the client-to-IP mapping. See " client hostip " on page 56.
list	l	Display a list of the registered clients by client name. See " client list " on page 60.
register	reg	Add a client to the list of clients that can access the SafeNet appliance's NTLS. See " client register " on page 61.
revokepartition	rev	Revoke access privileges to the specified partition from the specified client. See " client revokepartition " on page 63.
show	s	Display the hostname or IP address of a client, and any partitions assigned to the client. See " client show " on page 64.

client assignpartition

Assign access privileges for a registered client to the specified partitions. To assign a partition to a client, the client must be registered using the **client register** command and the partition must first be created using the **partition create** command.

This command is issued by the SafeNet appliance admin user.

Partitions can be 'unassigned' via revocation (**client revokePartition**), deletion of a Client association (**client delete**), deletion of the partition from the HSM (**partition delete**), or reinitialization of the HSM (**hsm init**).

Syntax

client assignpartition -client <clientname> -partition <name>

Parameter	Shortcut	Description
-client	-c	Specifies the name of the client to which a partition will be assigned. Use the client list command to display a list of registered clients,
-partition	-p	Specifies the name of the partition to which the client will gain access. Use the partition list command to obtain the partition name. Or if you are attempting to make a deployed token available to a client, use token pki listDeployed to see labels of deployed PKI tokens.

Example

```
lunash:>client assignPartition -client myPC -partition myPartition2
```

```
'client assignPartition' successful.
```

```
Command Result : 0 (Success)
```

client delete

Remove a client from the list of clients registered to use the SafeNet appliance. The command requires user interaction to verify that deletion should occur. This can be overridden with the **-force** option.

Syntax

client delete -client <clientname> [-force]

Parameter	Shortcut	Description
-client	-c	Specifies the name of the client to delete. Use the client list command to display a list of registered clients,
-force	-f	Force the action without prompting.

Example

```
lunash:>client delete -client myPC
```

```
CAUTION: Are you sure you wish to delete client named: myPC
Type 'proceed' to delete the client, or 'quit' to quit now.
```

```
> proceed
```

```
'client delete' successful.
```

```
Command Result : 0 (Success)
```

client fingerprint

Display the certificate fingerprint for a registered client. Compare this with the client's known certificate fingerprint to verify that the correct client was registered before assigning partitions to the client.

This command is executed by the (Luna appliance) admin.

Syntax

client fingerprint -client <clientname>

Parameter	Shortcut	Description
-client	-c	Specifies the name of the client whose certificate you want to display. Use the client list command to display a list of registered clients,

Example

```
lunash:> client -fingerprint -client myPC
```

```
Certificate fingerprint: D4:0F:8E:4C:CC:F2:49:FA:B7:3E:07:CB:0B:AE:1E:42
```

```
Command Result : 0 (Success)
```

client hostip

Access commands that allow you to display or configure the client-to-IP mapping.

Syntax

client hostip

map
show
unmap

Parameter	Shortcut	Description
map	m	Map a client to an IP address. See "client hostip map" on the next page.
show	s	Shows current client-host-to-IP mapping. See "client hostip show" on page 58.
unmap	u	Remove a client-to-IP mapping. See "client hostip unmap" on page 59.

client hostip map

Create an association between a client name and an IP address.

Syntax

```
client hostip map -clientname <client_name> -ipaddress <ip_address>
```

Parameter	Shortcut	Description
-client	-c	Specifies the name of the client for which you want to create the association.
-ip	-i	Specifies the IP address of the client for which you want to create the association.

Example

```
lunash:>client hostip map -c myPC -i 168.10.10.254
```

```
Command Result : 0 (Success)
```

client hostip show

Display the current client-to-IP mapping.

Syntax

client hostip show

Example

```
lunash:>client hostip show
```

Client Name	Host Name	Host IP
-----	-----	-----
myPC	myPC	168.10.10.254

```
Command Result : 0 (Success)
```

client hostip unmap

Remove an association between a client name and an IP address.

Syntax

client hostip unmap <clientname>

Option	Parameter	Description
-client	-c <clientname>	Specifies the name of the client for which you want to remove the association . Use the client list command to display a list of registered clients,

Example

```
lunash:>client hostip unmap myPC
```

```
Command Result : 0 (Success)
```

client list

Display a list of the registered clients by client name.

Syntax

client list

Example

```
lunash:> client list
```

```
registered client 1: brigitte  
registered client 2: suzanne  
registered client 3: pierre  
registered client 4: dan
```

client register

Add a client to the list of clients that can access the SafeNet appliance's NTLS. A client must be registered before you can assign partitions to it.



Note: The client's certificate file is needed to perform the registration.

Syntax

client register **-client** <clientname> [**-hostname** <hostname>] [**-ip** <ipaddress>] [**-requirehtl**] [**-ottexpiry** <seconds>] [**-generateott**] [**-force**]

Parameter	Shortcut	Description
-client	-c	The new client's name. The user may choose any name, so long as it is less than 255 characters, and is unique among all clients on the SafeNet HSM appliance. The client name need not be the hostname of the client.
-force	-f	Force the action without prompting.
-generateott	-g	Specifies creation of a one-time token as the client is registered. The name of the created file is the client name that you provided (above). Requires the -requirehtl option. Selecting this option is the equivalent of running the command htl generateott -client <clientname> .
-hostname	-h	The hostname of the new client. Use this parameter if the client certificate (and server certificates) were created with hostnames. If the certificates were created with IP addresses, use the -ip parameter instead.
-ip	-i	The IP address of the new client. Use this parameter if the client certificate (and server certificates) were created with IP addresses. If the certificates were created with hostnames, use the -hostname parameter instead.
-ottexpiry	-o	Sets the time, in seconds, before a one-time token (OTT) expires (values can be positive integers in the range of 0-to-3600 seconds). For practical reasons, you must allow at least enough time for certificate transfer, or the OTT could expire before it is ready to use. Requires the -requireHtl option. If the -ottExpiry option is not specified, the system-default OTT expiry for that client is used.
-requirehtl	-r	Specifies that the HTL protocol is required for all interactions between this client and the HSM appliance.

Example

```
lunash:>client register -c someclient -h someclient -r -g -f
```

```
Force option used. All proceed prompts bypassed.
'client register' successful.
Generating one-time token...
One-time token for client someclient is ready to use.
Filename is someclient.ott
```

Command Result : 0 (Success)

client revokepartition

Revoke access privileges to the specified partition from the specified client. Obtain a list of clients and the partitions they have access to using the **client -list** and **client -show** commands.

This command is executed by the (Luna appliance) admin.

Syntax

client revokepartition -client <name> -partition <partitionname>

Parameter	Shortcut	Description
-client	-c	Specifies the name of the client from which the partition will be revoked. Use the client list command to display a list of registered clients,
-partition	-p	Specifies the name of the partition to which the client will lose access. Use the partition list command to display a list of partitions.

Example

```
lunash:> client -revokePartition -client dan -partition test1
```

```
'client -revokePartition' successful.
```

client show

Display the hostname or IP address of a client, and any partitions assigned to the client.

Syntax

client show -client <name>

Parameter	Shortcut	Description
-client	-c	Specifies the name of the client for which you want to see additional information. Use the client list command to display a list of registered clients,

Example

Without DNS

```
lunash:> client -show -client myclient
```

```
ClientID: myclient
IPAddress: 121.22.35.4
HTL Required: yes
OTT Expiry: 160 sec (default)
Partitions: "mypart1"
```

With DNS

```
lunash:> client -show -client suzanne
```

```
ClientID: myclient
Hostname: myclient.sfnt.local
HTL Required: yes
OTT Expiry: 160 sec (default)
Partitions: "mypart1"
```


hsm

Access commands that allow you to manage the HSM on the appliance.



Note: HSM commands from LunaSH are queued along with other demands on the HSM (such as cryptographic operations), and can run more slowly than normal if the HSM is very busy, such as when it is performing high-volume ECDSA signing operations.

Syntax

hsm

backup
changepolicy
changepw
checkcertificates
debug
displaylicenses
factoryreset
firmware
fwupdateinfo
generatedak
information
init
loadcustomercert
login
logout
ped
restore
selftest
setlegacydomain
show
showpolicies
srk
stc
supportinfo
update
zeroize

Parameter	Shortcut	Description
backup	b	Backs up data or objects in the HSM's SO (or HSM Admin) space, such as the HSM's masking key (used in SIM) information, to a backup token. See " hsm backup " on page 68.
changepolicy	changepo	Sets a policy on or off, or to set it to a certain value if it is a numerical policy. See " hsm changepolicy " on page 70.
changepw	changepw	Changes the password or PED key contents for the HSM Admin. See " hsm changepw " on page 71.

Parameter	Shortcut	Description
checkcertificates	che	Checks the HSM for presence of MAC and DAC. See " hsm checkcertificates " on page 72.
debug	de	Display debug information. See " hsm debug show " on page 73.
displaylicenses	di	Display a list of all licenses on the HSM. See " hsm displaylicenses " on page 74.
factoryreset	fa	Set the HSM back to its factory default settings. Zeroize partitions, roles, and objects, delete the RPV (if any), and reset partition policies to original settings. See " hsm factoryreset " on page 76.
firmware	fi	Update or rollback the HSM firmware. See " hsm firmware " on page 78.
fwupdateinfo	fw	Saves HSM firmware update support information to a file. See " hsm fwupdateinfo " on page 85.
generatedak	ge	Generate a new DAK pair. See " hsm generatedak " on page 86.
information	inf	Display HSM information, reset the HSM counters, or monitor HSM performance. see " hsm information " on page 87.
init	ini	Initialize the HSM. See " hsm init " on page 93.
loadcustomercert	loa	Load the customer-signed MAC and DAC. See " hsm loadcustomercert " on page 96.
login	logi	Log in as the HSM Admin. See " hsm login " on page 97.
logout	logo	Log out the HSM Admin account. See " hsm logout " on page 98.
ped	p	Display or change the configuration of the PED. See " hsm ped " on page 99.
restore	r	Restore the contents of the HSM from a backup token. See " hsm restore [reserved] " on page 113.
selftest	sel	Test the cryptographic capabilities of the HSM. See " hsm selftest " on page 114.
setlegacydomain	set	Set the legacy cloning domain on an HSM. See " hsm setlegacydomain " on page 115
show	sh	Display a list showing the current configuration of the HSM. See " hsm show " on page 116.
showpolicies	showp	Display the current settings for all hsm capabilities and policies, or optionally restrict the listing to only the policies that are configurable. See " hsm showpolicies " on page 118.

Parameter	Shortcut	Description
srk	sr	Configure, or display information about, secure recovery keys (SRK) and secure transport mode. See " hsm srk " on page 120.
stc	st	Configure and manage the secure trusted channel (STC) link that is local to the appliance, that is, from the LunaSH shell to the HSM SO partition. See " hsm stc " on page 130.
supportinfo	su	Get HSM support information. See " hsm supportinfo " on page 168.
update	u	Display or install any available capability or firmware updates. See " hsm update " on page 169.
zeroize	z	Zeroize the HSM. Destroy all partitions, roles and objects, but preserve the RPV (if one exists) and preserve HSM policy settings. See " hsm zeroize " on page 172.

hsm backup

Backup data or objects in the HSM's SO (or HSM Admin) space, such as the HSM's masking key (used in SIM) information, to a backup token. The **hsm backup** command copies crucial HSM backup information to a special SafeNet backup device. The connected backup HSM, indicated by its serial number, is initialized and used during this process. The user is prompted to confirm that this destructive command should continue ("destructive" to any contents currently on the backup device, not destructive to the source HSM).

The hsm backup command backs up only data or objects in the HSM's SO (or HSM Admin) space. It does not back up the partition data. For that, you must use the **partition backup** commands.

Dual mode backup tokens are initialized to the same level (SafeNet HSM with Password Authentication or SafeNet HSM with PED (Trusted Path) Authentication) as the HSM.

When labeling HSMs or partitions, never use a numeral as the first, or only, character in the name/label. Token backup commands allow slot-number OR label as identifier which can lead to confusion if the label is a string version of a slot number.

For example, if the token is initialized with the label "1" then the user cannot use the label to identify the target for purposes of backup, because VTL parses "1" as signifying the numeric ID of the first slot rather than as a text label for the target in whatever slot it really occupies (the target is unlikely to be in the first slot), so backup fails.

Syntax

hsm backup -serial <serialnumber> [-password <password>] [-tokenAdminPw <password>] [-force]

Parameter	Shortcut	Description
-serial	-s	Specifies the serial number of the target backup HSM. This indicates which backup device to work with.
-password	-p	Specifies the source HSM Admin's (or SO's) text password. This parameter is required on password-authenticated HSMs. It is ignored on PED-authenticated HSMs.
-tokenAdminPw	-t	Specifies the password of the backup target HSM. On PED-authenticated HSMs, the SafeNet PED is used for the PIN and this value is ignored. The token password need not be the same password or PED key as used for the HSM partition.
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm backup -serial 667788
```

```
CAUTION: Are you sure you wish to initialize the backup
token named:
no label
Type 'proceed' to continue, or 'quit' to quit now.
> proceed
```

```
Luna PED operation required to initialize backup token - use Security Officer (blue) PED key.
Luna PED operation required to login to backup token - use Security Officer (blue) PED key.
```

Luna PED operation required to generate cloning domain on backup token - use Domain (red) PED key.

Luna PED operation required to login as HSM Administrator - use Security Officer (blue) PED key.

Luna PED operation required to login to backup token - use Security Officer (blue) PED key.
'hsm backup' successful.

Command Result : 0 (Success)

hsm changepolicy

Change HSM Admin-modifiable elements from the HSM policy set. Use this command to set a policy on or off, or to set it to a certain value if it is a numerical policy. Only certain portions of the policy set are user-modifiable. These policies and their current values can be determined using the **hsm showPolicies** command. After a successful policy change, with **hsm changepolicy**, then **hsm showpolicies** displays the new policy value.



Note: This command must be executed by the HSM Admin. If the HSM Admin is not authenticated, a “user not logged in” error message is returned.

If the policy is destructive, the you are given the choice to proceed or quit. This means that you cannot inadvertently destroy the contents of your HSM - you must acknowledge that you know that will happen before you proceed. Once a policy is changed, the program reports back the new value of the policy.

Syntax

hsm changePolicy **-policy** <hsm_policy_number> **-value** <hsm_policy_value> [**-force**]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting. If this option is included in the list for a destructive policy change, the policy will be changed without prompting the user for a confirmation of zeroizing the HSM.
-policy	-po	Specifies the policy code of the policy to alter. Policy descriptions and codes are obtained with the hsm showpolicies command.
-value	-v	Specifies the value to assign to the specified policy. When specifying values for a on/off type policy, use '1' for on and '0' for off.

Example

```
lunash:> hsm changePolicy -policy 6 -value 0
CAUTION: Are you sure you wish to change the destructive policy named:
Allow masking
Changing this policy will result in erasing all partitions on the HSM (zeroization)!
Type 'proceed' to zeroize your HSM and change the policy, or 'quit' to quit now.
> quit
'hsm changePolicy' aborted.
lunash:> hsm changePolicy -policy 16 -value 0
'hsm changePolicy' successful.
Policy Allow network replication is now set to value: 0
```

hsm changepw

Change the password or PED key contents for the HSM Admin. Both the old and the new PED key are required for PED-authenticated HSMs.

Syntax

hsm -changepw [-oldpw <password> -newpw <password>]

Parameter	Shortcut	Description
-newpw	-n	Specifies the new password that is used as the HSM Admin's login credential to the HSM. If the new password is not provided on the command line, the you are interactively prompted for the new password, and for confirmation of the new password. A valid password should be a mix of upper and lower-case letters, digits, and other characters, and must be a minimum of 8 characters long.
-oldpw	-o	Specifies the current password for the HSM Admin. If the current password is not provided on the command line, the user is interactively prompted for the current password.

hsm checkcertificates

Check the HSM for presence of MAC and DAC.

Syntax

hsm checkcertificates

Example

```
lunash:>hsm checkCertificates
```

```
MAC found -- certificatePolicies: evaluated to FIPS 140-2 Level 3  
DAC found -- certificatePolicies: meets requirements of FIPS 140-2 Level 3
```

```
Command Result : 0 (Success)
```


hsm debug show

Display HSM debug information. This command can dump many hundreds of lines of information to your display. In SSH/PuTTY sessions, you can stop and start the flow of output with Ctrl-S and Ctrl-Q respectively.

Syntax

hsm debug show

Example

```
[luna23] lunash:>hsm debug show
```

HSM Dualport dump:

```
Current dualport:
0000: 01 ff 03 ff      dc ff 01 ff      ff ff 15 ff      21 ff 04 ff      .....!...
0010: 01 ff 43 ff      68 ff 72 ff      79 ff 73 ff      61 ff 6c ff      ..C.h.r.y.s.a.l.
0020: 69 ff 73 ff      20 ff 49 ff      54 ff 53 ff      2c ff 20 ff      . i.s. .I.T.S.,.
0030: 49 ff 6e ff      63 ff 2e ff      00 ff 4c ff      75 ff 6e ff      I.n.c....L.u.n.
0040: 61 ff 00 ff      4b ff 36 ff      2e ff 30 ff      00 ff ff ff      a...K.6...0....
0050: 20 ff 04 ff      01 ff 89 ff      00 ff 01 ff      ff ff ff ff      .....
0060: 03 00 00 00      10 00 00 00      46 54 53 49      a5 83 02 02      .....FTSI....
0070: c0 00 00 00      c0 ff 01 ff      01 ff ff ff      40 00 00 00      .....@...
0080: 40 01 00 00      40 6b 00 00      80 6c 00 00      40 6b 00 00      @...@k...l..@k..
0090: 00 00 00 00      00 00 00 00      30 02 90 32      ff ff ff ff      .....0..2....
00a0: ff ff ff ff      ff ff ff ff      ff ff ff ff      ff ff ff ff      .....
00b0: ff ff ff ff      c0 d7 00 00      40 00 00 00      02 00 00 00      .....@.....
00c0: c0 08 00 00      40 ca 00 00      ff ff ff ff      ff ff ff ff      ....@.....
00d0: ff ff ff ff      ff ff ff ff      ff ff ff ff      ff ff ff ff      .....
...
```

[Sample truncated]

Command Result : 0 (Success)

hsm displaylicenses

Display a list of all licenses on the HSM. Licenses are either HSM upgrade licenses (which may be destructive), or HSM partition creation licenses. This command may be used by the HSM Admin to determine if they have available HSM partition licenses, before attempting to create a new HSM partition using the **partition create** command.

Syntax

hsm displaylicenses

Example

```
lunash:> hsm -displaylicenses
```

```
HSM UPGRADE LICENSES
```

```
License ID Destructive Description
```

```
=====
```

```
No HSM Upgrade licenses found
```

```
PARTITION LICENSES
```

```
License ID Total Avail Description
```

```
=====
```

```
0, 0 12 12 Generic or Secure Authentication & Access Control configuration
```

hsm duplicatemofn

Duplicate MofN PED Keys. This command starts a SafeNet PED operation that prompts for the existing set of green MofN PED Keys that are imprinted for this HSM. You must present the full set (all N of them - quantity M of those keys is not sufficient for this task). You must have enough blank green keys to make a full new set of N keys. This command requires HSM Admin or SO login (blue PED Key).

The command does not duplicate random MofN keys from another SafeNet Network HSM.

Syntax

hsm duplicatemofn

Example

```
lunash:>hsm duplicateMofN
You will need all N of your green MofN keys, and
a second set of N green keys to be used as duplicates.
Each of the N ORIGINAL keys will be prompted for, one
at a time, then each of the N DUPLICATE keys will be
prompted for.
If you are ready to start this operation, type 'proceed',
otherwise, type 'quit'
> proceed
Proceeding...
PED operation required
Command Result : 0 (success)
```

hsm factoryreset

Set the HSM back to its factory default settings, deleting the HSM SO, all users, and all objects. This command can be run via a local serial connection only; it is not accepted via SSH.



WARNING! This command deletes all objects and users on the HSM, leaving it in a zeroized state.

This command does not require HSM login. The assumption is that your organization's physical security protocols prevent unauthorized physical access to the HSM. If those protocols failed, an unauthorized person would have no access to the HSM contents, and would be limited to temporary denial of service by destruction of HSM contents.

Because this is a destructive command, you asked to "proceed" unless the **-force** switch is provided at the command line. See "[Comparison of destruction/denial actions](#)" on page 1 in the *Administration Guide* to view a table that compares and contrasts various "deny access" events or actions that are sometimes confused.

How the firmware version affects behavior

The behavior of this command differs depending on the HSM firmware, as follows:

- On firmware earlier than version 6.22.0, this command
 - **does not** erase the RPV (Remote PED Vector or orange PED Key authentication data), and
 - **does not** erase the Auditor role, from the HSM, and
 - **does not** reset HSM policies.
- On firmware 6.22.0, or higher, this command
 - **does** erase the RPV (Remote PED Vector or orange PED Key authentication data), and
 - **does** erase the Auditor role, from the HSM, and
 - **does** reset HSM policies.

The RPV data is required for Remote PED operations to function, including remote HSM initialization, if needed, so RPV must be reinstated after **hsm factoryreset** if you want to do any remote administration of the HSM.



Note: If the operation erased the RPV as described above, and you previously established a remote PED connection (using "hsm ped connect" on page 100), you must tear down the remote PED connection (using "hsm ped disconnect" on page 102) before you reinitialize the RPV and establish a new remote PED connection. The **hsm factoryReset** command operates on the internal HSM only, and not on software processes responsible for the remote PED connection.

Related commands

This command affects only the HSM, and not the settings for other components of the appliance. The command "[sysconf config factoryreset](#)" on page 395 affects appliance settings external to the HSM. To bring your entire SafeNet Network HSM as close as possible to original configuration, as shipped from the factory, run both commands.

If you wish to zeroize (remove all partitions, roles (except Auditor), and contents) while preserving HSM policies and the RPV - that is, zeroize before shipping the HSM off to be remotely configured - use the command "[hsm zeroize](#)" on page 172 instead.

Syntax

hsm factoryreset [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

Non-local (network connection) attempt:

```
lunash:>hsm factoryReset
Error: 'hsm
factoryReset' can only be run from the local console.
Login as 'admin' using the serial port on the
SafeNet Network HSM before running this command.
Command Result : 0 (Success)
lunash:>
```

Local attempt:

```
lunash:>hsm factoryReset
CAUTION: Are you sure you wish to reset this HSM to factory
default settings? All partitions and data will be erased.
Partition policies will be reverted to factory settings.
HSM level policies will be reverted to factory settings.
If you want to erase partitions and data only, use zeroize.
Remote PED vector will be erased.
Type 'proceed' to return the HSM to factory default, or
'quit' to quit now.
> proceed
'hsm factoryReset' successful.
Please wait while the HSM is reset to complete the process.
The remote PED vector (RPV) has been erased on HSM.
Command Result : 0 (success)
```

hsm firmware

Upgrade to the version of HSM firmware that is currently on standby in the SafeNet Network HSM appliance.

Rollback to the previous version of HSM firmware, retained in the SafeNet Network HSM appliance.

Syntax

hsm firmware

rollback
upgrade
show

Parameter	Shortcut	Description
show	s	Show HSM firmware version info. See " hsm firmware show " on page 82 .
upgrade	u	Update HSM firmware. See " hsm firmware upgrade " on page 83 .
rollback	r	Rollback HSM firmware. See " hsm firmware rollback " on the next page .

hsm firmware rollback

This command rolls back (downgrades) the HSM firmware to the previously installed version. You do not need to obtain the previously installed version - it was automatically saved to a special rollback holding area when you used the command "hsm firmware upgrade " on page 83.



Note: This command is intended primarily for SafeNet internal use (for example, for automated testing). It is recommended that you use this command only when instructed to do so by SafeNet technical support. The HSM capabilities and performance following a firmware rollback are uncertain.



CAUTION: This command is considered destructive, because an earlier firmware version can have fewer or older mechanisms and might have security vulnerabilities that a newer version does not. Therefore, the HSM requires that the SO be logged in to perform the **hsm firmware rollback** operation.

After rollback is complete, the command "hsm show" on page 116 indicates that you cannot rollback from the rolled-back firmware.

If you wish to reassert the newer firmware that was in the HSM before you rolled back, then use command "hsm firmware upgrade " on page 83, to [re-]upgrade to the newer firmware version. That version remains on standby in the appliance, so there is no need to re-upload or to re-install appliance software.

Syntax

hsm firmware rollback [-force]

Parameter	Shortcut	Description
-force	-f	Force the action

Example

The following example show the HSM configuration before and after the firmware rollback.

```
[local_host] lunash:>hsm show
```

```
Appliance Details:
=====
Software Version:          6.1.0-1

HSM Details:
=====
HSM Label:                 mysa6
Serial #:                  7000022
Firmware:                  6.22.0
HSM Model:                 K6 Base
Authentication Method:    PED keys
HSM Admin login status:   Logged In
HSM Admin login attempts left: 3 before HSM zeroization!
RPV Initialized:          Yes
```

```
Audit Role Initialized:      No
Remote Login Initialized:    No
Manually Zeroized:          No
```

```
Partitions created on HSM:
=====
```

.... (snip)...

Command Result : 0 (Success)

lunash:>

```
[local_host] lunash:>hsm firmware rollback
```

WARNING: This operation will rollback your HSM to the previous firmware version !!!

- (1) This is a destructive operation.
- (2) You will lose all your partitions.
- (3) You might lose some capabilities.
- (4) You must re-initialize the HSM.
- (5) If the PED use is remote, you must re-connect it.

Type 'proceed' to continue, or 'quit' to quit now.

> proceed

Proceeding...

Rolling back firmware. This may take several minutes.

Command Result : 0 (Success)

```
[local_host] lunash:>hsm show
```

```
Appliance Details:
=====
```

```
Software Version:          6.1.0-1
```

```
HSM Details:
=====
```

```
HSM Label:                 mysa6
Serial #:                  7000022
Firmware:                  6.20.0
HSM Model:                 K6 Base
Authentication Method:     PED keys
HSM Admin login status:    Not Logged In
HSM Admin login attempts left: 3 before HSM zeroization!
RPV Initialized:           Yes
Audit Role Initialized:    No
Remote Login Initialized:  No
Manually Zeroized:        No
```

```
Partitions created on HSM:
=====
```


.... (snip)...

Command Result : 0 (Success)

hsm firmware show

This command displays the current HSM firmware version, the rollback version, and the version (if any) that is on standby for upgrade.

Syntax

hsm firmware show

Example

```
[mylunaSA6] lunash:>hsm firmware show

Current Firmware:           6.20.0
Rollback Firmware:         6.2.1
Upgrade Firmware:          6.22.0

Command Result : 0 (Success)
[mylunaSA6] lunash:>
```

hsm firmware upgrade

This command updates the HSM firmware by applying the Firmware Update File that was saved in the standby location by the SafeNet factory, or by your most recent SafeNet Network HSM appliance update. The current HSM firmware version (before this command is run), becomes the rollback version after the command is run. See command "[hsm firmware rollback](#)" on page 79, to roll back to the previous firmware version.

The command example, below, shows that the command offers guidance about re-sizing of partitions, before you update the HSM firmware, in anticipation of the increased partition overhead with the newer firmware (and therefore slightly reduced space for objects in each partition) :

- Always archive your partition contents before manipulating the partition(s).
- Resizing is needed only if you intend to keep the partition contents.

Note: If you are both

- upgrading from an earlier firmware version to HSM firmware 6.22.0 (or newer)

AND

- applying the Per-Partition SO (PPSO) capability update,

be aware that the PPSO capability update is destructive. Therefore, there is no need to re-size partitions.



Instead, to avoid unnecessary duplication of effort, you should

- safeguard (archive) any existing partition contents,
- then zeroize the HSM for a clean update,
- then perform both the firmware AND capability updates,
- and finally restore to new partitions.

Syntax

hsm firmware upgrade

Parameter	Shortcut	Description
-force	-f	Force the action

Example

```
[mylunaSA2] lunash:>hsm firmware update
```

```
The HSM Administrator is logged in. Proceeding...
```

```
WARNING: This operation will upgrade the firmware and restart NTLS/HTL/STC !!!
```

- (1) All current NTLS and/or STC sessions will be reset.
- (2) If the server keys are in hardware, you must re-activate them.
- (3) If the PED use is remote, you must re-connect it.

```
*****
IMPORTANT NOTICE WITH UPGRADE TO FIRMWARE VERSION 6.22.0+
```

```
The architecture of the new firmware requires re-organization of memory on the HSM.
Before updating:
```

1. Backup the contents of your HSM.
2. Delete any unused partitions and their contents.
3. Re-size any partitions that reserved more space than needed.
4. If you have no unused partitions and none that you can resize, you must free up sufficient memory for the new firmware by moving some partitions and their contents to another HSM or upgrading memory if at the factory configuration.

Do not proceed with firmware update until you have increased the available memory on the HSM sufficiently.

Type 'proceed' to continue, or 'quit' to quit now.

```
> proceed
Proceeding...
```

Upgrade firmware version has requirements for available free space on HSM.
Checking that sufficient free space exists before firmware upgrade.

Partition #: 153182004 Name: Cryptoki User Status: Passed
Sufficient space exists for firmware upgrade.

```
Update Result : 0 (Success)
resetting HSM ...
Stopping ntl:OK
Starting ntl:OK
Stopping htl:OK
Starting htl:OK
Stopping stcd:           [ OK ]
Starting stcd:           [ OK ]
```

```
Command Result : 0 (Success)
[mylunaSA2] lunash:>
```

hsm fwupdateinfo

Saves HSM firmware update support information to the **fwupdateInfo.txt** file. The file must then be retrieved to a client/administrative computer using scp to view the information.

Syntax

hsm fwupdateinfo

Example

```
lunash:>hsm fwupdateinfo
```

```
'hsm fwupdateinfo' successful.
```

```
Use 'scp' from a client machine to get file named: fwupdateInfo.txt
```

```
Command Result : 0 (Success)
```

hsm generatedak

Generate a new DAK pair. These can be used to create a new MAC (Manufacturer's Authentication Certificate) & DAC (Device Authentication Certificate). Use this command if you wish to replace the default objects that were shipped from the SafeNet factory. If you are not using MAC and DAC in your operation, then this command and the related commands for the certificates are not of use to you, and running them will not harm anything. If your operation does use DAK and the derived certificates, use this command only in compliance with your operational procedures.

Synopsis

hsm generatedak [-force]

Example

```
lunash:>hsm generatedak
```

```
CAUTION: Are you sure you wish to re-generate the DAK?
All existing DACs on the HSM will be erased.
Type 'proceed' to generate the DAK, or 'quit' to quit now.
> proceed
'hsm generateDAK' successfully completed.
Use 'scp' from a client machine to get file named:
DAKCertRequest.bin
```

```
Command Result : 0 (Success)
```

hsm information

Access commands that allow you to display HSM information, reset the HSM counters, or monitor HSM performance.



Note: These commands require HSM firmware version 6.20.0 or newer.

Syntax

hsm information

monitor
reset
show

Parameter	Shortcut	Description
monitor	m	Monitors the HSM performance. See "hsm information monitor" on the next page.
reset	r	Resets the HSM counters. See "hsm information reset" on page 91.
show	s	Display HSM information. See "hsm information show" on page 92.

hsm information monitor

Sample the HSM to get some statistics, such as, HSM up-time, command counts, and utilization counters.

A single run of this command, without arguments, takes approximately five seconds to complete. One measurement is taken at launch, then after five seconds (the default minimum) a second measurement is taken and compared with the first.

The date and time in the output are derived from:

- the system time and
- the HSM count of seconds since reset.

In the examples, note the line "HSM Last Reset (+/- 5 Secs Error Margin)..." That margin is due to possible variability of the default system clock. To improve the accuracy of the input to those calculations, we suggest that you use NTP for system time. If that is inconvenient, or is blocked by your security regime, then we suggest using "sysconf drift" on [page 401](#) to precisely set the time, and then manage/prevent clock drift.



Note: This command requires HSM firmware version 6.20.0 or newer.



Note: For ongoing/continual collection of such HSM information, we recommend using SNMP.

See "HSM Information Monitor" on [page 1](#).

Syntax

hsm information monitor [-serial <integer>] [-interval <integer>] [-rounds <integer>] [-noheader] [-save]

Parameter	Shortcut	Description
-interval	-i	Set the interval over which the HSM is polled, in seconds Range: 5 to 999 Default: 5 seconds.
-noheader	-n	Turn off the header and footer that are normally provided with the displayed or saved records. You might choose to omit the header and footer in a saved file, in order to make the file cleaner for concatenation and parsing by your analysis tools.
-rounds	-r	Set the number of samples to collect during the HSM polling. The default is a single round, which includes a first sample at the time the command is launched, followed by the interval (either the default 5 seconds, or the interval that you specified), followed by a second sample which is compared with the first, to complete the round. The maximum number of rounds for one operation of <code>hsm information monitor</code> is 65535. Range: 1 to 65535 Default: 1
-save	-sa	Save the captured-and-calculated records to a file named hsm_

Parameter	Shortcut	Description
		stats , while also displaying the output to your terminal. The filename is not modifiable, so contents are overwritten each time the command is run. Use 'scp' to retrieve the file to a workstation for analysis.
-serial	-se	Specifies the serial number of HSM to monitor. The default is to use the embedded HSM. This parameter is optional if your SafeNet Network HSM does not have additional HSMs attached. If you have a USB-connected HSM, such as SafeNet USB HSM for PKI, then this command defaults to showing utilization data from the embedded HSM, but the serial parameter allows you to select an HSM other than the default. Data is collected for a single HSM when the command is run.

Example

With no arguments (output to terminal):

```
[mysa5] lunash:>hsm information monitor
```

HSM Uptime (Secs)	HSM Command Counts			HSM Utilization (%)		
	Since HSM Reset	Last	5 Secs	Since HSM Reset	Last	5 Secs
1,115,399	57,468,854		30	1.27		0.21

```
Average HSM Utilization In This Period : 0.21%
HSM Last Reset (+/-5 Secs Error Margin) : Fri May 31 14:59:47 2013
```

```
Command Result : 0 (Success)
```

```
[mysa5] lunash:>
```

With arguments (output to terminal):

```
[local_host] lunash:>hsm information monitor -interval 6 -rounds 6
```

HSM Uptime (Secs)	HSM Command Counts			HSM Utilization (%)		
	Since HSM Reset	Last	6 Secs	Since HSM Reset	Last	6 Secs
1,116,668	57,470,863		1	1.27		0.00
1,116,674	57,470,864		1	1.27		0.00
1,116,680	57,470,894		30	1.27		0.18
1,116,686	57,470,895		1	1.27		0.00
1,116,692	57,470,896		1	1.27		0.00
1,116,698	57,470,926		30	1.27		0.18

```
Average HSM Utilization In This Period : 0.06%
```

HSM Last Reset (+/-5 Secs Error Margin) : Fri May 31 14:59:46 2013

Command Result : 0 (Success)

[local_host] lunash:>

With arguments (output to file):

[local_host] lunash:>hsm information monitor -interval 6 -rounds 6 -save

HSM Uptime (Secs)	HSM Command Counts			HSM Utilization (%)		
	Since HSM Reset	Last	6 Secs	Since HSM Reset	Last	6 Secs
1,117,227	57,471,775		1	1.27		0.00
1,117,233	57,471,805		30	1.27		0.18
1,117,239	57,471,806		1	1.27		0.00
1,117,245	57,471,807		1	1.27		0.00
1,117,251	57,471,837		30	1.27		0.18
1,117,257	57,471,838		1	1.27		0.00

Average HSM Utilization In This Period : 0.06%

HSM Last Reset : Fri May 31 14:59:46 2013

The HSM utilization counters are saved to file hsm_stats.
Please run `my file list` command to see it. You may also
want to `scp` the file out for further analysis.

Command Result : 0 (Success)

hsm information reset

Reset the HSM counters.

Syntax

hsm information reset

Example

```
lunash:>hsm info reset
```

```
Command Result : 0 (Success)
```

hsm information show

Display the contents of the HSM counters.



Note: The "Operation Requests" counter increments rapidly (often by 42 or 47 counts) because even relatively simple LunaSH commands trigger a number of low-level operations, including checking of firmware version, checking of HSM status, and other actions, before the current high-level command is completed.

Syntax

hsm information show

Example

```
lunash:>hsm information show
```

```
HSM Information:
Operation Requests:          3083
Operation Errors:            0
Critical Events:             0
Non-Critical Events:        0
```

```
Command Result : 0 (Success)
```

hsm init

Initialize the HSM (K6 key card) in the SafeNet HSM Server. Initialization assigns an HSM label, creates or associates Security Officer (SO) or HSM Admin authentication for the HSM, creates or associates a Cloning Domain (with authentication) for the HSM, and applies other settings that make the HSM available for use.



CAUTION: Initializing the HSM erases all existing data on the key card, including all HSM Partitions and their data. HSM Partitions then must be recreated with the partition create command. Because this is a destructive command, the user is asked to “proceed” unless the -force switch is provided at the command line.



CAUTION: Invoking the **hsm init** command results in the HSM Admin being logged out, and all partitions being deactivated. These preparatory actions take place before the warning prompt appears, with its request for you to type "Proceed" or "Quit". That is, if you invoke **hsm init** and then type **quit** at the prompt, initialization does not take place (meaning that you do not lose existing token/HSM contents), but any current login or activation state is closed, whether you abort the command or not.

For more information, see "What is initialization? (PED-authentication)" on page 1 in the *Administration Guide*.

Syntax

hsm init -label <hsm_label> [**-domain** <hsm_domain>] [**-password** <hsm_admin_password>] [**-defaultdomain**] [**-authtimeconfig**] [**-force**]

Parameter	Shortcut	Description
-authtimeconfig	-a	Specifies that the SO role must be logged in to configure the time.
-defaultdomain	-de	This option is deprecated. The current and future HSM versions do not allow you to omit providing a domain, unless you include this "-defaultdomain" option, which is an insecure choice and generally not recommended. It is retained for benefit of existing customers who have previously set the default domain, and are constrained to continue with it until they create new objects on an HSM with a proper domain. The "-defaultdomain" option applies to Password-authenticated HSMs only. For PED-authenticated HSMs the PED always prompts for a physical PED Key and either reuses the value on the key that you insert, or generates a new value and imprints it on the PED Key.
-domain	-do	Specifies the string to be used as key cloning domain for the HSM. If no value is given for a SafeNet HSM with Password Authentication, you are prompted interactively. The HSM must support cloning, or this value is ignored. This parameter is considered mandatory in password-authenticated HSMs (except if the discouraged and deprecated -defaultdomain is specified). The -domain parameter is

Parameter	Shortcut	Description
		ignored in PED-authenticated HSMs.
-force	-f	Force the action without prompting.
-label	-l	Specifies the label to assign to the HSM. The label has a maximum length of 32 characters. Any data input over 32 characters is truncated.
-password	-p	Specifies the password to be used as login credential by the HSM Admin. For PED-authenticated HSMs, the SafeNet PED is used for the HSM Admin PIN/password, and data input for this value is ignored. This parameter is required in password-authenticated HSMs. It is ignored in PED-authenticated HSMs.

Example

PED-authenticated HSMs

If the HSM has been factory reset, then a complete "hard" initialization is performed when you invoke the **hsm init** command.

```
lunash:> hsm -init -label myluna
CAUTION: Are you sure you wish to re-initialize this HSM?
All partitions and data will be erased.
Type 'proceed' to initialize the HSM, or 'quit'
to quit now.
> proceed
Luna PED operation required to initialize HSM - use Security Officer (blue) PED Key
Luna PED operation required to login as HSM Administrator - use Security Officer (blue) PED Key
Luna PED operation required to generate cloning domain - use Domain (red) PED Key

'hsm -init successful'

Command result : 0 (Success)
lunash:>
```

If the HSM is NOT in factory reset condition when you invoke the **hsm init** command, then a "soft" initialization is performed - while the partitions and contents are destroyed, the Security officer/HSM Administrator identity and the Domain are preserved. The SO must be logged into the HSM to run HSM init when the HSM is not in factory reset condition.

```
lunash:> hsm -init -label myluna

CAUTION: Are you sure you wish to re-initialize this HSM?
All partitions and data will be erased.
Type 'proceed' to initialize the HSM, or 'quit' to quit now.
> proceed

Luna PED operation required to initialize HSM - use Security Officer (blue) PED Key
'hsm -init successful'

Command result : 0 (Success)
```

Password-authenticated HSMs

```
lunash:> hsm -init -label "new hsm" -sopw somepin -domain newdomain
```

```
CAUTION: Are you sure you wish to re-initialize this HSM?
```

```
All partitions and data will be erased.
```

```
Type 'proceed' to initialize the HSM, or 'quit' to quit now.
```

```
> proceed
```

```
'hsm -init successful'
```

hsm loadcustomercert

Load the customer-signed MAC (Manufacturer's Authentication Certificate) & DAC (Device Authentication Certificate) certificates in the specified file onto the HSM.

Syntax

```
hsm loadcustomercert -certfilename <filename>
```


hsm login

Log in as the HSM Admin.

- For SafeNet Network HSM with Password Authentication, the default password is 'PASSWORD'.
- For SafeNet Network HSM with PED (Trusted Path) Authentication, a default login is performed by the PED when you first begin to initialize a new or factory-reset HSM. After initialization, the appropriate blue PED Key is needed for HSM Admin login.

Syntax

```
lunash:> hsm login [-password <hsm_admin_password>]
```

Parameter	Shortcut	Description
-password	-p	HSM Admin Password (for password-authenticated HSM, only; ignored for PED-authenticated HSM)

Example

```
lunash:>hsm login
```

```
Luna PED operation required to login as HSM Administrator - use Security Officer (blue) PED key.
'hsm login' successful.
```

```
Command Result : 0 (Success)
```

hsm logout

Log out the HSM Admin account.

Syntax

```
lunash:> hsm logout
```

Example

```
lunash:>hsm logout
```

```
'hsm logout' successful.  
Command Result : 0 (Success)
```

hsm ped

Access commands that allow you to display or change the configuration of the PED.

Syntax

hsm ped

connect
disconnect
set
show
timeout
vector

Parameter	Shortcut	Description
connect	c	Connect to a remote PED. See "hsm ped connect" on the next page.
disconnect	d	Disconnect the current/active remote PED. See "hsm ped disconnect" on page 102.
set	se	Configure a default IP address and/or port that are used by the hsm ped connect command when establishing a connection to a Remote PED Server. See "hsm ped set" on page 103.
show	sh	Display information for the current HSM PED connection. See "hsm ped show" on page 105.
timeout	t	Set or display the remote PED connection timeout. See "hsm ped timeout" on page 106.
vector	v	Initialize or erase a remote PED vector. See "hsm ped vector" on page 109.

hsm ped connect

Connect to a remote PED. This command instructs PedClient to attempt to connect to the Remote PED Server at the IP address and port specified on the command line, or configured using the **hsm ped set** command. See "[hsm ped set](#)" on page 103 for more information.

Behavior when defaults are configured using hsm ped set

The **hsm ped set** command allows you to configure a default IP address and/or port for the Remote PED Server. These values are used if they are not specified when you issue the **hsm ped connect** command. The behavior of the **hsm ped connect** command when defaults are configured using **hsm ped set** is as follows:

Values set with hsm ped set	Parameters specified by hsm ped connect	IP address used	Port used
IP address and port	None	IP address configured with hsm ped set .	Port configured with hsm ped set .
	IP address	IP address specified by hsm ped connect	Port configured with hsm ped set .
	Port	IP address configured with hsm ped set .	Port specified by hsm ped connect
	IP address and port	IP address specified by hsm ped connect	Port specified by hsm ped connect
IP address only	None	IP address configured with hsm ped set .	Port 1503 (default).
	IP address	IP address specified by hsm ped connect	Port 1503 (default).
	Port	IP address configured with hsm ped set .	Port specified by hsm ped connect .
	IP address and port	IP address specified by hsm ped connect	Port specified by hsm ped connect .
Port only	None	Error. You must use the -ip parameter to specify an IP address.	Port configured with hsm ped set .
	IP address	IP address specified by hsm ped connect	Port configured with hsm ped set .
	Port	Error. You must use the -ip parameter to specify an IP address..	Port specified by hsm ped connect
	IP address and port	IP address specified by hsm ped connect	Port specified by hsm ped connect

Behavior when no defaults are configured using hsm ped set

If no defaults are configured using **hsm ped set**, you must specify at least an IP address. If no port is specified, the default port (1503) is used.



Note: To set up or erase a PED vector, or to make or break the Remote PED connection, on an HSM that is externally connected to the SafeNet Network HSM, use the "-serial" option to specify the target HSM. If "-serial" is not specified, then the command acts on the SafeNet Network HSM's internal HSM card.

Syntax

hsm ped connect [-ip <ip_address>] [-port <port>] [-serial <serial_num>] [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-ip	-i	Specifies the IP Address of the
-port	-p	Network Port (0-65535). Default: 1503
-serial	-s	Token Serial Number

Example

```
lunash:>hsm ped connect -ip 172.20.10.155
```

```
Luna PED operation required to connect to Remote PED - use orange PED key(s).
Ped Client Version 1.0.5 (10005)
Ped Client launched in startup mode.
PED client local IP : 172.20.9.77/192.168.255.223
Starting background process
Background process started
Ped Client Process created, exiting this process.
```

```
Command Result : 0 (Success)
```

hsm ped disconnect

Disconnect the current/active remote PED. No address information is required since only one remote PED connection can exist at one time.



Note: To set up or erase a PED vector, or to make or break the Remote PED connection, on an HSM that is externally connected to the SafeNet Network HSM, use the "-serial" option to specify the target HSM. If "-serial" is not specified, then the command acts on the SafeNet Network HSM's internal HSM card.

Syntax

hsm ped disconnect [-serial <serialnum>] [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-serial	-s	Token Serial Number

Example

```
lunash:>hsm ped disconnect
```

```
If you are sure that you wish to disconnect, then enter 'proceed', otherwise type 'quit'.
> proceed
Proceeding...
Remote PED connection closed.
```

```
Command Result : 0 (Success)
```

hsm ped set

Configure a default IP address and/or port that are used by the **hsm ped connect** command when establishing a connection to a Remote PED Server. See "**hsm ped connect**" on page 100 for more information.

Syntax

```
hsm ped set [-ip <ip_address>] [-port <port>]
```

Parameter	Shortcut	Description
-ip	-i	Specifies the default IP Address used by the hsm ped connect command.
-port	-p	Specifies the default port used by the hsm ped connect command. Range: 0-65535 Default: 1503

Example

```
lunash:>hsm ped set -ip 106.55.19.59 -port 3456
```

```
Command Result : 0 (Success)
```

```
lunash:>hsm ped show
```

```
Configured Remote PED Server IP address: 106.55.19.59
```

```
Configured Remote PED Server Port: 3456
```

```
Ped Client Version 2.0.0 (20000)
```

```
Ped Client launched in status mode.
```

```
Callback Server is running..
```

```
Callback Server Information:
```

```
  Hostname:                local_host
  IP:                      106.55.9.165
  Software Version:        2.0.0 (20000)
```

```
Operating Information:
```

```
  Admin Port:              1501
  External Admin Interface: No

  Callback Server Up Time:                269788 (secs)
  Callback Server Current Idle Time:      269788 (secs)
  Callback Server Total Idle Time:        269788 (secs) (100%)
  Idle Timeout Value:                    1800 (secs)
```

```
Number of PED ID Mappings: 0
```

```
Number of HMSs: 1
```

```
HSM List:
```

```
  Device Type:             PCI HSM
  HSM Serial Number:       789654
  HSM Firmware Version:    6.30.0
  HSM Cmd Protocol Version: 18
```

```
HSM Callback IO Version:      1
HSM Callback Protocol Version: 1
HSM Up Time:                  269787 (secs)
HSM Total Idle Time:          269787 (secs) (100%)
HSM Current Idle Time:        269787 (secs)
```

Show command passed.

Command Result : 0 (Success)

hsm ped show

Display information for the current HSM PED connection.

Syntax

```
hsm ped show
```

Example

```
lunash:>hsm ped show
```

```
Ped Client Version 1.0.5 (10005)  
Ped Client launched in status mode.  
Ped PedClient is not currently running.
```

```
Show command passed.
```

```
Command Result : 0 (Success)
```

hsm ped timeout

Access commands that allow you to set or display the remote PED connection timeout.

Syntax

hsm ped timeout

set
show

Parameter	Shortcut	Description
set	se	Set the remote PED connection timeouts. See "hsm ped timeout set" on the next page.
show	sh	Display the currently configured remote PED connection timeout values. See "hsm ped timeout show" on page 108.

hsm ped timeout set

Set the remote PED connection (**rped**) or PED key interaction (**pedk**) timeout values:

- **rped** - is the connection inactivity timeout. The default is 1800 seconds (30 minutes). While we do not anticipate any great security risk from having a Remote PED connection left open and unused for long periods, we do suggest that having sessions open indefinitely might be an invitation, so set the **rped** value as long as you realistically need, but not more.
- **pedk** - is for PED Key activities in particular. The default is 100 seconds. It might be useful to increase that timeout if you are initializing your HSM with large values for MofN on some-or-all PED Keys. We have tested initializations with all secrets set to the maximum Mof N, equal to 16 of 16, and a pedk value of 900 seconds (15 minutes) was adequate to complete the necessary interactions. If you are not using MofN, then leave 'pedk' at its default value.
- **pedo** - is for SFF remote backup due to the duration of the initialization operation.

After **rped** expires, you must re-establish the Remote PED link with **hsm ped disconnect** and **hsm ped connect** before issuing any HSM or application partition commands that require PED interaction. We recommend running disconnect before reconnecting because, although the link normally disconnects cleanly upon timeout, it can happen that the link is left in an indeterminate state, and a disconnect before a connect corrects that.

Syntax

hsm ped timeout set -type <type> -seconds <seconds>

Parameter	Shortcut	Description
-seconds	-s	Specifies the timeout value, in seconds, for the specified type. Range: 1 to 99999 Defaults: 1800 (rped), 200 (pedk), 820 (pedo)
-type	-t	Specifies the timeout type. Valid values: <ul style="list-style-type: none"> • rped - set the remote PED connection inactivity timeout. • pedk - set the PED key timeout. • pedo - set the entire PED operation timeout.

Example

```
lunash:>hsm ped timeout set -type rped -seconds 2000
```

Set the timeout value to 2000 seconds.

Command Result : 0 (Success)

hsm ped timeout show

Display the currently configured remote PED connection timeout values.

Syntax

hsm ped timeout show

Example

```
lunash:>hsm ped timeout show
```

```
The remote PED connection timeout value (seconds) = 1800  
The PED key interaction timeout value (seconds)    = 200  
The entire PED operation timeout value (seconds)  = 820
```

```
Command Result : 0 (Success)
```

hsm ped vector

Access commands that allow you to initialize or erase a remote PED vector (RPV) on the HSM.



Note: To set up or erase a PED vector, or to make or break the Remote PED connection, on an HSM that is externally connected to the SafeNet Network HSM, use the "-serial" option to specify the target HSM. If "-serial" is not specified, then the command acts on the SafeNet Network HSM's internal HSM card.

Syntax

hsm ped vector

erase
init

Parameter	Shortcut	Description
erase	e	Erase a remote PED vector. See "hsm ped vector erase" on the next page.
init	i	Initialize a remote PED vector. See "hsm ped vector init" on page 111.

hsm ped vector erase

Erase a Remote PED vector (RPV) from the current HSM so that it can no longer establish a Remote PED connection with any workstation that has that RPV on an orange PED Key.



Note: To set up or erase a PED vector, or to make or break the Remote PED connection, on an HSM that is externally connected to the SafeNet Network HSM, use the "-serial" option to specify the target HSM. If "-serial" is not specified, then the command acts on the SafeNet Network HSM's internal HSM card.

Syntax

hsm ped vector erase [-serial <serialnum>] [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-serial	-s	Specifies the serial number of the remote PED for which you want to erase the remote PED vector.

Example

```
lunash:>hsm ped vector erase
```

If you are sure that you wish to erase remote PED vector (RPV), then enter 'proceed', otherwise type 'quit'.
> proceed

Command Result : 0 (Success)

hsm ped vector init

Initialize a Remote PED vector. This command creates a new Remote PED Key by doing the following:

- initializing a Remote PED vector (RPV)
- imprinting the RPV onto the current HSM as well as onto an orange PED Key (RPK).
 - The RPK is kept with the Remote PED, when you set up a Remote PED workstation. The RPK allows a SafeNet Network HSM with that RPV to connect to a Remote PED workstation where the attached PED provides the matching RPV, via the orange RPK.]
 - The RPV is a secret that facilitates the secure connection between a particular HSM that has that secret, and a Remote PED Server computer that has the RPK containing the identical secret. The HSM must be connected to a computer that runs Remote PED client, to manage the HSM's end of the Remote PED connection. More than one HSM can be imprinted with the same RPV, but a single Remote PED Server can connect with only one such remotely located HSM (via its client) at one time.



Note: You must be logged into the HSM as SO/HSM Admin (with the blue SO PED Key), before you can run this command.



Note: To set up or erase a PED vector, or to make or break the Remote PED connection, on an HSM that is externally connected to the SafeNet Network HSM, use the "-serial" option to specify the target HSM. If "-serial" is not specified, then the command acts on the SafeNet Network HSM's internal HSM card.

Syntax

hsm ped vector init [-serial <serialnum>] [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-serial	-s	Specifies the serial number of the remote PED for which you want to erase the remote PED vector.

Example

```
lunash:>hsm ped vector init
```

If you are sure that you wish to initialize remote PED vector (RPV), then enter 'proceed', otherwise type 'quit'.

```
> proceed
Proceeding...
Luna PED operation required to initialize remote PED key vector - use orange PED key(s).
Ped Client Version 1.0.5 (10005)
Ped Client launched in shutdown mode.
PED client local IP : 172.20.9.77/192.168.255.223
Shutdown passed.
Command Result : 0 (Success)
```

```
[mylunasa] lunash:>
```


hsm restore [reserved]

Restore the contents of the HSM from a backup token.

Syntax

hsm restore -serial <serialnum> [**-password** <password>] [**-tokenAdminPw** <password>] [**-force**]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-password	-p	Specifies the HSM Admin Password. Passwords are needed only for password-authenticated HSMs, and are not required at the command line. If a password is needed, you are prompted for it, and your response is hidden by asterisk characters (*).
-serial	-s	Specifies the Token Serial Number. The serial number of the backup token is required.
-tokenAdminPw	-t	Specifies the Token Admin Password. Passwords are needed only for password-authenticated HSMs, and are not required at the command line. If a password is needed, you are prompted for it, and your response is hidden by asterisk characters (*).

Example

```
lunash:>token backup list
```

```
Token Details:
```

```
=====
```

```
Token Label:                SA78_SIM-21/12/2011
```

```
Slot:                        1
```

```
Serial #:                    300555
```

```
Firmware:                    4.8.6
```

```
Hardware Model:              Luna PCM G4
```

```
Command Result : 0 (Success)
```

```
lunash:>hsm restore -s 300555
```

```
CAUTION: This process will erase the current masking key on
this HSM and replace it with the one on the backup
token. Any keys masked off any partition on the
HSM with the existing masking key will be irretrievable.
Type 'proceed' to replace the masking key, or 'quit'
to quit now.
```

```
> proceed
```

```
Luna PED operation required to login as HSM Administrator - use Security Officer (blue) PED key.
```

```
Warning: You will need to connect Luna PED to the SafeNet Backup HSM to complete
this operation.
```

```
You may use the same Luna PED that you used for SafeNet Network HSM.
```

```
Please type 'proceed' and hit <enter> when you are ready to proceed> proceed
```

```
Luna PED operation required to login to token - use token Security Officer (blue) PED key.
```

```
Masking key successfully cloned.
```

```
'hsm restore' successful.
```

```
Command Result : 0 (Success)
```

hsm selftest

Test the cryptographic capabilities of the HSM.

Syntax

```
hsm selftest
```

Example

```
lunash:>hsm selftest
```

```
Self Test. Testing HSM cryptographic capabilities.  
'hsm selfTest' passed.  
HSM working as expected.
```

```
Command Result : 0 (Success)
```

hsm setlegacydomain

Set the legacy cloning domain on an HSM:

- for password-authenticated HSMs, this is the text string that was used as a cloning domain on the legacy token HSM whose contents are to be migrated to the SafeNet Network HSM.
- for PED-authenticated HSMs, this is the cloning domain secret on the red PED Key for the legacy PED-authenticated token HSM whose contents are to be migrated to the SafeNet Network HSM.

Your **target** SafeNet Network HSM has, and retains, whatever modern HSM cloning domain was imprinted (on a red PED Key) when the HSM was initialized. This command takes the domain value from your legacy HSM's red PED Key and associates that with the modern-format domain of the current HSM, to allow the HSM to be the cloning (restore...) recipient of objects from the legacy (token) HSM. The legacy domain associated with your SafeNet Network HSM is attached until the HSM is reinitialized.

Objects from legacy token/HSMs can only be migrated (restored) onto SafeNet Enterprise HSMs configured to use their legacy domain. In other words, you cannot defeat the security provision that prevents cloning of objects across different domains.

As well, you cannot migrate objects from a Password authenticated token/HSM to a PED authenticated SafeNet Network HSM, and you cannot migrate objects from a PED authenticated token/HSM to a Password authenticated SafeNet Network HSM. Again, this is a security provision.

See "[Legacy Domains and Migration](#)" on page 1 in the *Administration Guide* for a description and summary of the possible combinations of source (legacy) tokens/HSMs and target (modern) HSMs and the disposition of token objects from one to the other.

Syntax

hsm setlegacydomain [-domain <domain>]

Parameter	Shortcut	Description
-domain	-d	Specifies the Legacy Cloning Domain name. This parameter is required on password-authenticated HSMs. It is ignored on PED-authenticated HSMs, which retrieve the legacy domain name from the red PED key.

Example

```
lunash:> hsm setLegacyDomain
```

Luna PED operation required to set legacy cloning domain - use Domain (red) PED Key. The PED prompts for the legacy red domain PED Key (notice mention of "raw data" in the PED message).

Command result: Success!

hsm show

Display a list showing the current configuration of the HSM.

Syntax

```
lunash:> hsm show
```

Example

HSM is in a non-zeroized state

```
lunash:>hsm show
Appliance Details:
=====
Software Version:      5.2.0-1

HSM Details:
=====
HSM Label:      myluna
Serial #:       700022
Firmware        6.2.1
Hardware Model: Luna K6
Authentication Method:      PED Keys
HSM Admin login status:     Logged In
HSM Admin login attempts left:      3 before HSM zeroization!
RPV Initialized:      Yes
Audit Role Initialized:      Yes
Remote Login Initialized:      Yes
Manually Zeroized:      No

Partitions created on HSM:
=====
Partition: 700022006, Name: mypar2
Partition: 700022008, Name: mypar1

FIPS 140-2 Operation
=====
The HSM is NOT in FIPS 140-2 approved operation mode.

HSM Storage Information:
=====
Maximum HSM Storage Space (Bytes):      2097152
Space In Use (Bytes):      209714
Free Space Left (Bytes):      1887438

Command Result : 0 (Success)
```

HSM is in a zeroized state

```
lunash:>hsm show
Appliance Details:
=====
Software Version:      5.1.0-25
```

```
HSM Details:
=====
HSM Label:      no label
Serial #:       700022
Firmware        6.2.1
Hardware Model: Luna K6
Authentication Method: PED Keys
HSM Admin login status: Not Logged In
HSM Admin login attempts left:          HSM is zeroized!
Audit Role Initialized: Yes
RPV Initialized: Yes
Manually Zeroized: Yes
```

```
Partitions created on HSM:
=====
There are no partitions
```

FIPS 140-2 Operation

```
=====
The HSM is NOT in FIPS 140-2 approved operation mode.
```

```
HSM Storage Information:
=====
Maximum HSM Storage Space (Bytes):      2097152
Space In Use (Bytes):                   0
Free Space Left (Bytes):                 2097152
```

```
Command Result : 0 (Success)
```

hsm showpolicies

Display the current settings for all hsm capabilities and policies, or optionally restrict the listing to only the policies that are configurable.

SafeNet Network HSM 6 does not currently have a secure identity management (SIM) configuration. Certain HSM policy settings exist to enable migration from SafeNet Network HSM 4.x to SafeNet Network HSM 5.x or 6.x, specifically the “Enable masking” and “Enable portable masking key” values.

Syntax

hsm showpolicies [-configonly]

Parameter	Shortcut	Description
-configonly	-c	Restrict the list to configurable policies only.

Example

```
[myluna] lunash:>hsm showPolicies
HSM Label: myhsm
Serial #: 700022
Firmware: 6.2.1
The following capabilities describe this HSM, and cannot be altered
except via firmware or capability updates.
Description                               Value
=====
Enable PIN-based authentication            Disallowed
Enable PED-based authentication           Allowed
Performance level                         15
Enable domestic mechanisms & key sizes    Allowed
Enable masking                           Allowed
Enable cloning                           Allowed
Enable special cloning certificate        Disallowed
Enable full (non-backup) functionality    Allowed
Enable ECC mechanisms                    Allowed
Enable non-FIPS algorithms                Allowed
Enable SO reset of partition PIN         Allowed
Enable network replication                Allowed
Enable Korean Algorithms                  Allowed
FIPS evaluated                            Disallowed
Manufacturing Token                       Disallowed
Enable Remote Authentication              Allowed
Enable forcing user PIN change            Allowed
Enable portable masking key               Allowed
Enable partition groups                   Disallowed
Enable Remote PED usage                   Allowed
Enable external storage of MTK split      Allowed
HSM non-volatile storage space            2097152
Enable HA mode CGX                        Disallowed
Enable Acceleration                       Allowed
Enable unmasking                          Allowed
```

The following policies are set due to current configuration of this HSM and cannot be altered directly by the user.

```
Description                               Value
=====
```

```

PED-based authentication          True
Store MTK split externally       False

```

The following policies describe the current configuration of this HSM and may be changed by the HSM Administrator. Changing policies marked "destructive" will zeroize (erase completely) the entire HSM.

Description	Value	Code	Destructive
=====	=====	=====	=====
Allow masking	On	6	Yes
Allow cloning	On	7	Yes
Allow non-FIPS algorithms	On	12	Yes
SO can reset partition PIN	On	15	Yes
Allow network replication	On	16	No
Allow Remote Authentication	On	20	Yes
Force user PIN change after set/reset	Off	21	No
Allow offboard storage	On	22	Yes
Allow remote PED usage	On	25	No
Allow Acceleration	On	29	Yes
Allow unmasking	On	30	Yes

Command Result : 0 (Success)

hsm srk

Access commands that allow you to configure, or display information about, secure recovery keys (SRK) and secure transport mode.

Syntax

hsm srk

disable
enable
keys
show
transportmode

Parameter	Shortcut	Description
disable	d	Disables external secure recovery keys. See " hsm srk disable " on the next page.
enable	e	Enables external secure recovery keys. See " hsm srk enable " on page 122.
keys	k	Access commands that allow you to resplit or verify secure recovery keys. See " hsm srk keys " on page 123.
show	s	Displays the current SRK state. See " hsm srk show " on page 126.
transportmode	t	Access commands that allow you to enable or disable secure transport mode. See " hsm srk transportmode " on page 127.

hsm srk disable

Disable the use of external split(s) of the SRK (secure recovery key) on purple PED Keys. The SO must be logged in to the HSM to issue this command.

Syntax

hsm srk disable

Example

```
lunash:> hsm srk disable
```

```
Command Result : 0 (Success)
```

hsm srk enable

Enables the use of external split(s) of the SRK (secure recovery key) on purple PED Keys. The SO must be logged in to the HSM to issue this command.

Syntax

lunash:> hsm srk enable

Example

```
lunash:> hsm srk enable
```

```
Command Result : 0 (Success)
```

hsm srk keys

Access commands that allow you to resplit or verify secure recovery keys (SRK).

Syntax

hsm srk keys

resplit
verify

Parameter	Shortcut	Description
resplit	r	Re-splits the Secure Recovery Key. See "hsm srk keys resplit" on the next page
verify	v	Verifies an existing Secure Recovery Key. See "hsm srk keys verify" on page 125 .

hsm srk keys resplit

Generate a new split of the Secure Recovery Key. Internal splits are stored in secure memory areas on the HSM. The external split is imprinted upon a purple PED Key (or multiple purple keys if you have chosen MofN).

The PED must be connected, and you must present "new" purple PED Keys when prompted. "New" in this case, means a purple PED Key that is literally new, or a PED Key that has been used for another purpose - as long as it does not contain the current valid external SRK split, before the new splitting operation. For safety reasons, the HSM and PED detect and refuse to overwrite the current purple PED Key(s) for the current HSM.

Syntax

hsm srk keys resplit

Example

```
lunash:> hsm srk keys resplit
Luna PED operation required to resplit the SRK - use Secure Recovery (purple) PED key.
SRK resplit succeeded.
Command Result : 0 (Success)
```

hsm srk keys verify

Verify an existing secure recovery key. This command displays the verification string for the current SRK, allowing you to compare it with the text string that was generated when Transport Mode was set.

- If the strings do not match, then someone has performed a recovery and re-split on the HSM (and likely other operations) since the split that generated your verification string.
- If the string match, then the HSM has not been altered since it was placed in transport mode.

Syntax

hsm srk keys verify

Example

```
lunash:> hsm srk keys verify
```

```
Luna PED operation required to verify the SRK split - use Secure Recovery (purple) PED key.  
SRK verified.
```

```
Command Result : 0 (Success)
```

hsm srk show

hsm srk show - Display the current status of the Secure Recovery flags.

Syntax

hsm srk show

Example

```
lunash:> hsm srk show
```

```
Secure Recovery State flags:
```

```
=====
```

```
External split enabled:          yes
```

```
SRK resplit required:           no
```

```
Hardware tampered:              no
```

```
Transport mode:                 o
```

```
Command Result : 0 (Success)
```

hsm srk transportmode

Access commands that allow you to put the HSM into, or out of, secure transport mode.

Syntax

hsm srk transportmode

enter
recover

Parameter	Shortcut	Description
enter	e	Places the HSM in Transport Mode. See "hsm srk transportmode enter" on the next page.
recover	r	Takes the HSM out of Transport Mode. See "hsm srk transportmode recover" on page 129.

hsm srk transportmode enter

Place the HSM in transport mode, invalidating the Master Key and causing all HSM content to be unusable. The use of external split(s) of the SRK (secure recovery key) on purple PED Keys must already be enabled. The SO must be logged in to the HSM to issue this command.

Syntax

hsm srk transportmode enter

Example

```
lunash:> hsm srk transportMode enter
```

CAUTION: You are about configure the HSM in transport mode.

If you proceed, the HSM will be inoperable until it is recovered with the Secure Recovery Key.

Type 'proceed' to continue, or 'quit' to quit now.

> proceed

Configuring the HSM for transport mode...

Luna PED operation required to enter transport mode - use Secure Recovery (purple) PED key.

Be sure to record the verification string that is displayed after the MTK is zeroized.

HSM is now in Transport Mode.

Command Result : 0 (Success)

```
lunash:>hsm srk show
```

Secure Recovery State flags:

```
=====
External split enabled:      yes
SRK resplit required:       no
Hardware tampered:          no
Transport mode:              yes
```

Command Result : 0 (Success)

hsm srk transportmode recover

Exit transport or tamper mode. This command reconstitutes the Master Key on the HSM, using the SRV (secure recovery vector) split(s) on the purple SRK PED Key(s), allowing the HSM and its contents to be accessed and used again, following Transport Mode or a tamper event. The PED must be connected, and you must present the correct purple PED Keys when prompted.

Syntax

hsm srk transportmode recover

Example

```
lunash:> hsm srk transportMode recover
```

```
Attempting to recover from Transport Mode...
```

```
Luna PED operation required to recover the HSM - use Secure Recovery (purple) PED key.
```

```
Successfully recovered from transport mode.
```

```
HSM restored to normal operation.
```

```
Command Result : 0 (Success)
```

```
lunash:>hsm srk show
```

```
Secure Recovery State flags:
```

```
=====
```

```
External split enabled:          yes
```

```
SRK resplit required:           no
```

```
Hardware tampered:              no
```

```
Transport mode:                  no
```

```
Command Result : 0 (Success)
```

hsm stc

Access the HSM STC-level commands. Use these commands to configure and manage the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLIS, and the STC service) and the HSM SO partition.

Syntax

hsm stc

activationTimeout
cipher
client
disable
enable
hmac
identity
partition
rekeyThreshold
replayWindow
status

Parameter	Shortcut	Description
activationtimeout	a	Set and display the activation timeout for an STC link. See " hsm stc activationTimeOut " on page 132.
cipher	ci	Enable, disable, and show the use of a symmetric encryption cipher algorithm for data encryption on the link. See " hsm stc cipher " on page 135.
client	cl	Register, deregister, and list a client's STC public key from the specified partition. See " hsm stc client deregister " on page 142.
disable	d	Disable the secure trusted channel (STC) link that is local to the appliance, that is, from the LunaSH shell to the HSM SO partition. See " hsm stc disable " on page 145.
enable	e	Establish a local secure trusted channel (STC) link from the LunaSH shell to the HSM SO partition, and set all the local HSM-related applications in the appliance to communicate to the HSM via this STC link. See " hsm stc enable " on page 146.
hmac	h	Enable, disable, and display the use of an HMAC message digest algorithm for message integrity verification on the secure trusted channel (STC) link that is local to the appliance, that is, from the LunaSH shell to the HSM. See " hsm stc hmac disable " on page 148.
identity	i	Manage the HSM SO client identity for the LunaSH STC client token. See " hsm stc identity " on page 151

Parameter	Shortcut	Description
partition	p	Export the specified partition's public key to a file, or display that public key. See " hsm stc partition " on page 159.
rekeythreshold	rek	Set or display the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See " hsm stc rekeyThreshold " on page 162.
replaywindow	rep	Set or display the size of the packet replay window. See " hsm stc replaywindow set " on page 166.
status	st	Display status and configuration information for an STC link. See " stc status " on page 1.

hsm stc activationTimeOut

Display and set the activation timeout for STC.

Syntax

hsm stc activationTimeOut

set
show

Option	Shortcut	Description
activationtimeout set	a se	Set the activation timeout for an STC link. See "hsm stc activationtimeout set" on the next page.
activationtimeout show	a sh	Display the STC link activation timeout for the specified partition. See "hsm stc activationtimeout show" on page 134

hsm stc activationtimeout set

Set the activation timeout for the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition. The activation timeout is the maximum time allowed to establish the STC link before the channel request is dropped.

Syntax

hsm stc activationtimeout set -time <timeout>

Parameter	Shortcut	Description
-time <timeout>	-t <timeout>	Specifies the activation timeout, in seconds. Range: 1-240 Default: 120

Example

```
lunash:> hsm stc a se -t 30
```

Successfully changed the activation timeout for HSM to 30 seconds.

hsm stc activationtimeout show

Display the activation timeout for the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition. The activation timeout is the maximum time allowed to establish the STC link before the channel request is dropped.

Syntax

stc activationtimeout show

Example

```
lunash:>hsm stc a sh
```

The channel activation timeout for HSM is 120 seconds.

hsm stc cipher

View, enable, and disable STC cipher algorithms.

Syntax

hsm stc cipher

disable
enable
show

Option	Shortcut	Description
cipher disable	ci d	Disable the use of a symmetric encryption cipher algorithm for data encryption on the link. See " hsm stc cipher disable " on the next page.
cipher enable	ci e	Enable the use of a symmetric encryption cipher algorithm for data encryption on the link. See " hsm stc cipher enable " on page 138
cipher show	ci s	List the symmetric encryption cipher algorithms you can use for STC data encryption on the specified partition. See " hsm stc cipher show " on page 140.

hsm stc cipher disable

Disable the use of a symmetric encryption cipher algorithm for data encryption on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLN, and the STC service) and the HSM SO partition.

All data transmitted over the STC link will be encrypted using the cipher that is both enabled and that offers the highest level of security. For example, if AES 192 and AES 256 are enabled, and AES 128 is disabled, AES 256 will be used. You can use the command "hsm stc cipher show" on page 140 to show which ciphers are currently enabled/disabled and the command "stc status" on page 1 to display the cipher that is currently being used.



Note: Performance is reduced for larger ciphers.

Syntax

hsm stc cipher disable -all -id <cipher_id>

Parameter	Shortcut	Description
-all	-a	Disable all ciphers.
-id <cipher_id>	-id <cipher_id>	Specifies the numerical identifier of the cipher you want to disable, as listed using the command "stc configuration cipher show" on page 1.

Example

```
lunash:>hsm stc cipher show
```

This table lists the ciphers supported for STC links to the HSM SO partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the HSM SO partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	Yes

Command Result : 0 (Success)

```
lunash:>hsm stc cipher disable -id 3
```

AES 256 Bit with Cipher Block Chaining is now disabled.

Command Result : 0 (Success)

```
lunash:>hsm stc cipher show
```

This table lists the ciphers supported for STC links to the HSAM SO partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the HSM SO partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	No

Command Result : 0 (Success)

hsm stc cipher enable

Enable the use of a symmetric encryption cipher algorithm for data encryption on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

All data transmitted over the STC link will be encrypted using the cipher that is both enabled and that offers the highest level of security. For example, if AES 192 and AES 256 are enabled, and AES 128 is disabled, AES 256 will be used. You can use the command `"hsm stc cipher show"` on page 140 to show which ciphers are currently enabled/disabled and the command `"stc status"` on page 1 to display the cipher that is currently being used.



Note: Performance is reduced for larger ciphers.

Syntax

```
hsm stc cipher enable -all -id <cipher_id>
```

Parameter	Shortcut	Description
<code>-all</code>	<code>-a</code>	Enable all ciphers.
<code>-id <cipher_id></code>	<code>-id <cipher_id></code>	Specifies the numerical identifier of the cipher you want to use, as listed using the command <code>"stc configuration cipher show"</code> on page 1.

Example

```
lunash:>hsm stc cipher show
```

This table lists the ciphers supported for STC links to the HSM SO partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	No

Command Result : 0 (Success)

```
lunash:>hsm stc cipher enable -id 3
```

AES 256 Bit with Cipher Block Chaining is now enabled.

```
lunash:>hsm stc cipher show
```

This table lists the ciphers supported for STC links to the HSM SO partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	Yes

Command Result : 0 (Success)

hsm stc cipher show

List the symmetric encryption cipher algorithms you can use for data encryption on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

You can use the command "[stc status](#)" on [page 1](#) to display the cipher that is currently being used.

Syntax

hsm stc cipher show

Example

```
lunash:>hsm stc cipher show
```

This table lists the ciphers supported for STC links to the partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	No

Command Result : 0 (Success)

hsm stc client

List currently registered STC client identities. Register and de-register STC client identities with the HSM .

Syntax

hsm stc client

deregister
list
register

Option	Shortcut	Description
client deregister	cl d	Deregister a client's STC public key from the specified partition. See " hsm stc client deregister " on the next page.
client list	cl l	List the clients registered to the specified partition. See " hsm stc client list " on page 143.
client register	cl r	Register a client's STC public key to the specified partition. See " hsm stc client register " on page 144.

hsm stc client deregister

Deregister the STC public key for LunaSH from the HSM SO partition. You must be HSM SO to use this command.



CAUTION: Deregistering the LunaSH client's public key disables the STC link to that client.

Syntax

hsm stc client deregister -label <client_label>

Parameter	Shortcut	Description
-label <client_label>	-l <client_label>	A string used to identify the client being deregistered.

Example

```
lunash:> hsm stc client deregister
```

Successfully deregistered the client public key for the admin channel

hsm stc client list

List the clients registered to the HSM SO partition. You must be logged in as the HSM SO to use this command.

Syntax

hsm stc client list

Example

```
lunash:> hsm stc client list
```

Client Name	Client Identity	Public Key	SHA1 Hash
rellis			2fd4e1c67a2d28fced849ee1bb76e7391b93eb1

hsm stc client register

Register the STC public key for LunaSH to the HSM SO partition. You must be logged in as the HSM SO to use this command.

Syntax

```
hsm stc client register -label <client_label> -file <client_public_key>
```

Parameter	Shortcut	Description
-name <client_name>	-n <client_label>	A string used to identify the client being registered.
-file <client_public_key>	-f <client_public_key>	The full path to the client public key file.

Example

```
lunash:> stc client register -l bsalming -f 45021294.pem
```

Successfully registered the client public key of bsalming

hsm stc disable

Disable the secure trusted channel (STC) admin channel link. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

This command terminates the STC link, so that all communications between LunaSH and the HSM are transmitted over a non-encrypted link local to the appliance.



Note: Disabling the local STC link is service affecting. It causes an STC service restart, which temporarily terminates all existing STC links to the appliance. It also terminates the existing HSM login session.

Syntax

hsm stc disable [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm stc disable
```

Disabling STC on the admin channel will require a restart of STC service. Any existing STC connections will be terminated.

```
Type 'proceed' to disable STC on the admin channel, or 'quit'
to quit now.
```

```
> proceed
```

Successfully disabled STC on the admin channel.

```
Command Result : 0 (Success)
```

hsm stc enable

Enable the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLN, and the STC service) and the HSM SO partition.



Note: Enabling the local STC link is service affecting. It causes an STC service restart, which temporarily terminates all existing STC links to the appliance. It also terminates the existing HSM login session.

Syntax

hsm stc enable [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm stc enable
```

Enabling local STC will require a restart of STC service.
Any existing STC connections will be terminated.

Type 'proceed' to enable STC on the admin channel, or 'quit' to quit now.

```
> proceed
```

Successfully enabled STC on the admin channel.

```
Command Result : 0 (Success)
```

hsm stc hmac

Enable, disable, and show STC HMAC algorithms.

Syntax

hsm stc hmac

hmac disable
hmac enable
hmac show

Option	Shortcut	Description
hmac disable	h d	Disable the use of an HMAC message digest algorithm for message integrity verification on the secure trusted channel (STC) link that is local to the appliance, that is, from the LunaSH shell to the HSM. See " hsm stc hmac disable " on the next page.
hmac enable	h e	Enable the use of an HMAC message digest algorithm used for message integrity verification on the specified partition. See " hsm stc hmac enable " on page 149
hmac show	h s	List the HMAC message digest algorithms you can use for STC message integrity verification on the specified partition. See " hsm stc hmac show " on page 150.

hsm stc hmac disable

Disable the use of an HMAC message digest algorithm for message integrity verification on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

The HMAC algorithm that is both enabled and that offers the highest level of security is used. For example, if SHA 256 and SHA 512 are enabled, SHA 512 is used. You can use the command `"hsm stc hmac show"` on page 150 to show which HMAC message digest algorithms are currently enabled/disabled.



Note: You cannot disable all HMAC message digest algorithms.

Syntax

`hsm stc hmac disable -id <hmac_id>`

Parameter	Shortcut	Description
<code>-id <hmac_id></code>	<code>-i <hmac_id></code>	Specifies the numerical identifier of the HMAC algorithm you want to disable, as listed using the command <code>"hsm stc hmac show"</code> on page 150.

Example

```
lunash:> hsm stc hmac show
```

```
HMAC ID      HMAC Name                Enabled
0            HMAC with SHA 256 Bit    Yes
1            HMAC with SHA 512 Bit    Yes
```

```
Command Result : 0 (Success)
```

```
lunash:> hsm stc hmac disable -id 0
```

```
HMAC with SHA 256 Bit is now disabled for HSM.
```

```
Command Result : 0 (Success)
```

```
lunash:> hsm stc hmac show
```

```
HMAC ID      Name                    Enabled
0            HMAC with SHA 256 Bit    No
1            HMAC with SHA 512 Bit    Yes
```

```
Command Result : 0 (Success)
```

hsm stc hmac enable

Enable the use of an HMAC message digest algorithm for message integrity verification on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

The HMAC algorithm that is both enabled and that offers the highest level of security is used. For example, if SHA 256 and SHA 512 are enabled, SHA 512 is used. You can use the command `"hsm stc hmac show"` on the next page to show which HMAC message digest algorithms are currently enabled/disabled.



Note: You must enable at least one HMAC message digest algorithm.

Syntax

```
hsm stc hmac enable -id <hmac_id>
```

Parameter	Shortcut	Description
<code>-id <hmac_id></code>	<code>-i <hmac_id></code>	Specifies the numerical identifier of the HMAC algorithm you want to enable, as listed using the command <code>"hsm stc hmac show"</code> on the next page.

Example

```
lunash:>hsm stc hmac show
```

```
HMAC ID      Name                               Enabled
0            HMAC with SHA 256 Bit              No
1            HMAC with SHA 512 Bit              Yes
```

```
Command Result : 0 (Success)
```

```
lunash:>hsm stc hmac enable -id 0
```

```
Command Result : 0 (Success)
```

```
HMAC with SHA 256 Bit is now enabled for HSM.
```

```
lunash:>hsm stc hmac show
```

```
HMAC ID      HMAC Name                               Enabled
0            HMAC with SHA 256 Bit              Yes
1            HMAC with SHA 512 Bit              Yes
```

```
Command Result : 0 (Success)
```

hsm stc hmac show

List the HMAC message digest algorithms you can use for message integrity verification on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

Syntax

hsm stc hmac show

Example

```
lunash:>hsm stc hmac show
```

HMAC ID	HMAC Name	Enabled
0	HMAC with SHA 256 Bit	Yes
1	HMAC with SHA 512 Bit	Yes

hsm stc identity

Create and manage client identities for STC.

Syntax

hsm stc identity

identity create
identity delete
identity initialize
identity partition
identity show

Option	Shortcut	Description
identity create	i c	Create a STC client identity for the LunaSH client. See " hsm stc identity create " on the next page.
identity delete	i d	Delete the LunaSH STC client identity. See " hsm stc identity delete " on page 153.
identity initialize	i i	Initialize the LunaSH STC client token. See
identity partition	i p d	Remove the HSM SO partition identity public key that is currently registered with the LunaSH STC client token. See " hsm stc identity partition deregister " on page 156
identity show	i s	Display the client name, public key hash, and registered partitions for the LunaSH STC client token. See " hsm stc identity show " on page 158.

hsm stc identity create

Create a client identity for the STC admin channel client token. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

After it is created, the LunaSH client identity is exported to the file **HsmClientId.cid**.



WARNING! Do not execute this command if STC is currently enabled. If you do, you will lose the ability to communicate with the HSM, and will need to decommission the HSM to recover.

Syntax

hsm stc identity create

Example

```
lunash:> hsm stc identity create
```

The client identity successfully created and exported to file: HsmClientId.cid.

hsm stc identity delete

Delete the client identity from the STC admin channel identity token. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

This command, in conjunction with "[hsm stc identity create](#)" on the previous page allows you to re-generate the token identity key pair if required for security reasons (for example, if the token is compromised), or for administrative reasons (for example, to perform a key rotation).

This command does the following, in the order specified:

1. Deletes the LunaSH STC client identity public key in the HSM SO partition.
2. Deletes the HSM SO partition identity.
3. Deletes the LunaSH STC client identity.

If any of the identities fail to be deleted, the command will report the failure but will continue to delete the client identity.



WARNING! Do not execute this command if STC is currently enabled. If you do, you will lose the ability to communicate with the HSM, and will need to decommission the HSM to recover.

Syntax

stc identity delete [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:> hsm stc identity delete
```

```
Are you sure you want to delete the client identity HsmClientId?
```

```
All registered HSM partitions will no longer be available to this client token.
```

```
Type 'proceed' to continue, or 'quit' to quit now -> proceed
```

```
Successfully deleted client identity.
```

hsm stc identity initialize

Re-initialize the STC identity for the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

The STC identity for the secure trusted channel (STC) admin channel is automatically initialized when the STC admin channel is enabled. You should only use this command if you need to manually re-establish the STC admin channel.



WARNING! Do not execute this command if STC is currently enabled. If you do, you will lose the ability to communicate with the HSM, and will need to decommission the HSM to recover.

Syntax

hsm stc identity initialize [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm stc identity initialize
The client token is already initialized with the following client identity:
Public Key SHA1 Hash:          f3ac60ea5b8cef87b34ddf7dc71416c0d565824e
Registered Partition Identity:
Partition Serial Number:      154487
Partition Public Key SHA1 Hash: 543f73564ff7137897b7d8433b2df2e3b79ddfc3
Re-initialization will delete the client identity and remove existing partition registrations.
Type 'proceed' to continue, or 'quit'
to quit now.
>
```

hsm stc identity partition

Register and deregister HSM SO partition identities for STC.

Syntax

hsm stc identity partition

deregister
register

Option	Shortcut	Description
identity partition deregister	i p d	Remove the HSM SO partition identity public key that is currently registered with the LunaSH STC client token. See " hsm stc identity partition deregister " on the next page
identity partition register	i p d	Register the HSM SO partition identity public key with the LunaSH STC client token. See " hsm stc identity partition register " on page 157.

hsm stc identity partition deregister

Remove the HSM SO partition identity public key that is currently registered to the STC admin channel client token. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

Use this command only if you need to reconfigure the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the appliance operating system and the HSM SO partition for local services and applications, such as LunaSH and NTLS.



CAUTION: Deregistering the HSM SO partition disables the LunaSH STC link.

Syntax

hsm stc identity partition deregister [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm stc identity partition deregister
```

```
Are you sure you want to deregister the TBD?
```

```
Type 'proceed' to continue, or 'quit' to quit now -> proceed
```

```
TBD successfully deregistered from the client token.
```

hsm stc identity partition register

Register the HSM SO partition in the current slot to the STC admin channel client token. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

Use this command only if you need to re-register the partition to the client token, for example if the token has been re-initialized.

Syntax

hsm stc identity partition register -file <file_path>

Parameter	Shortcut	Description
-file <file_path>	-f <file_path>	Specifies the full path to the partition identity file.

Example

```
lunash:> hsm stc identity partition register -f <file>
```

```
Partition Identity successfully registered
```

hsm stc identity show

Display the following information for the STC admin channel client token:

- the public key SHA1 hash for the client identity
- whether the HSM SO partition is registered or not

The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLN, and the STC service) and the HSM SO partition.

Syntax

hsm stc identity show

Example

```
lunash:> hsm stc identity show
```

```
Public Key SHA1 Hash:          aa8983ae3c65b4e4bac24f374153f8dfffec0c2c
Registered Partition:          Yes
```

hsm stc partition

View the public key for the HSM SO partition, and export that public key to a file.

Syntax

hsm stc partition

export
show

Option	Shortcut	Description
partition export	p e	Export the specified partition's public key to a file. See " hsm stc partition export " on the next page.
partition show	p s	Display the public key and serial number for the current partition. See " hsm stc partition show " on page 161.

hsm stc partition export

Export the public key for the HSM SO partition to a file to be used to configure the STC admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

You must be logged in to the HSM as the SO to perform this command.

Syntax

hsm stc partition export

Example

```
lunash:>hsm stc partition export
```

```
Successfully exported partition identity for HSM to file: 359693009023.pid
```


hsm stc partition show

Display the public key and serial number for the HSM SO partition. You must be logged into the partition as the SO to perform this command.

Syntax

hsm stc partition show

Example

```
lunash:>hsm stc partiton show
```

```
Partition Serial Number:          359693009023  
Partition Identity Public Key SHA1 Hash: ee27ac0376af538a6f15523002c43c7b6febdf34
```

hsm stc rekeyThreshold

Display and set the rekey threshold for the symmetric key used to encrypt data on the STC admin channel.

Syntax

hsm stc rekeyThreshold

set
show

Parameter	Shortcut	Description
rekeythreshold set	rek se	Set the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See "hsm stc rekeythreshold set " on the next page.
rekeythreshold show	rek sh	Display the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See "hsm stc rekeythreshold show " on page 164.

hsm stc rekeythreshold set

Set the rekey threshold for the symmetric key used to encrypt data on the STC admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLN, and the STC service) and the HSM SO partition.

The symmetric key is used for the number of times specified by the threshold value, after which it is regenerated and the counter is reset to 0. Each command sent to the HSM over the HSM STC link uses one life.

Syntax

hsm stc rekeythreshold set **-partition** <partition> **-value** <key_life>

Parameter	Shortcut	Description
-value <key_life>	-v <key_life>	An integer that specifies the key life for the STC symmetric key, in millions of messages. Each message sent to the HSM over the STC link uses one life. Range: 0 - 4000 Default: 400

Example

```
lunash:>hsm stc rekeythreshold set -par mapleleafs -v 500
```

Successfully changed the rekey threshold for HSM to 500 million commands.

hsm stc rekeythreshold show

Display the rekey threshold for the symmetric key used to encrypt data on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLIS, and the STC service) and the HSM SO partition.

The symmetric key is used the number of times specified by the threshold value, after which it is regenerated and the counter is reset to 0. Each command sent to the HSM over the STC link uses one life.

Syntax

hsm stc rekeythreshold show

Example

```
lunash:>hsm stc rekeythreshold show
```

```
Current rekey threshold for HSM is 400 million messages.
```

hsm stc replayWindow

View and set the size of the packet replay window for the STC admin channel..

Syntax

hsm stc replayWindow

set
show

Option	Shortcut	Description
replaywindow set	rep se	Set the size of the packet replay window. See " hsm stc replaywindow set " on the next page.
replaywindow show	rep sh	Display the current setting for the size of the packet replay window. See " hsm stc replaywindow show " on page 167.

hsm stc replaywindow set

Set the size of the packet replay window for the STC admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

This value specifies the number of packets in the window of sequenced packets that are tracked to provide anti-replay protection.

About the Replay Window

All packets sent over an STC link are sequenced and tracked. This allows the receiver to reject old or duplicate packets, thus preventing an attacker from attempting to insert or replay packets. The receiver remembers which packets it has received within a specified window, and rejects any packets that have already been received or that are older than the oldest packet in the window.

The replay window is dynamic and is defined by the packets in the range $\{(X-N+1) \text{ to } X\}$, where X is the current packet number and N is the replay window size. Any packets numbered $X-N$ or older are discarded. Any packets in the range of the replay window $\{(X-N+1) \text{ to } X\}$ that have already been received are discarded. All other packets are accepted.



Note: Each STC packet corresponds to a single command. That is, each command sent to the HSM is encapsulated within a single STC packet.

Syntax

hsm stc replaywindow set -size <number_of_packets>

Parameter	Shortcut	Description
-size <number_of_packets>	-s <number_of_packets>	Specifies the number of packets (commands) in the replay window. Range: 100-1000 Default: 120

Example

```
lunash:>hsm stc replaywindow set -size 500
```

Successfully changed the size of the replay window for HSM to 500 commands.

hsm stc replaywindow show

Display the size of the packet replay window for the STC admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

This value specifies the number of packets in the window of sequenced packets that are tracked to provide anti-replay protection.

About the Replay Window

All packets sent over the STC link are sequenced and tracked. This allows the receiver to reject old or duplicate packets, thus preventing an attacker from attempting to insert or replay packets. The receiver remembers which packets it has received within a specified window, and rejects any packets that have already been received or that are older than the oldest packet in the window.

The replay window is dynamic and is defined by the packets in the range $\{(X-N+1) \text{ to } X\}$, where X is the current packet number and N is the replay window size. Any packets numbered $X-N$ or older are discarded. Any packets in the range of the replay window $\{(X-N+1) \text{ to } X\}$ that have already been received are discarded. All other packets are accepted.



Note: Each STC packet corresponds to a single command. That is, each command sent to the HSM is encapsulated within a single STC packet.

Syntax

hsm stc replaywindow show

Example

```
lunash:>hsm stc replaywindow show
```

The current replay window size for HSM is 120 commands.

hsm supportinfo

Get HSM support information in the **supportInfo.txt** file. The collected information includes a variety of information about the state and settings of the HSM, as well as other important appliance info such as the network settings and negotiated link status. The file must be transferred from the SafeNet appliance to you client using scp, and sent to Customer Support.

The file **supportInfo.txt** is generated by any of the following events:

- sysconf appliance reboot
- sysconf appliance power off
- a press of the Start/Stop button on the SafeNet Network HSM front panel

Syntax

hsm supportInfo

Example

```
lunash:>hsm supportInfo
```

```
'hsm supportInfo' successful.
```

```
Use 'scp' from a client machine to get file named:  
supportInfo.txt
```

```
Command Result : 0 (Success)
```


hsm update

Access commands that allow you to display or install any available capability or firmware updates.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like " C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

Syntax

hsm update

capability
show

Parameter	Shortcut	Description
capability	c	Apply a capability update. See "hsm update capability" on the next page.
show	s	Display a list of the available HSM updates. See "hsm update show" on page 171.

hsm update capability

Apply a capability update. You must use **scp** to transfer the capability update from your SafeNet HSM client workstation to the appliance before you can apply it. You can view any packages that have been transferred, but not yet installed, using the **hsm update show** command.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like " C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.



Note: The command dialog prompts for a slot on which to act. This is not currently used. Always select slot 0.

Syntax

hsm update capability -capability <capability_name> [-force]

Parameter	Shortcut	Description
-capability	-c	Specifies the name of the capability update to apply.
-force	-f	Force the action without prompting.

Example

```
lunash:> hsm update capability -capability brandnewcapability [-force]
```

```
SafeNet Firmware/Capability Update Utility for G5 and K6 moodules
Enter slot number (0 for the first slot found) : 0
Success
Capability "brandnewcapability" updated.
```

hsm update show

Display the HSM capability update packages that have been transferred onto the SafeNet appliance; shows both capability packages that have not yet been applied using the **hsm update capability** command, and packages that have been applied.



Note: Formerly, when a capability had been applied, it no longer appeared in the list. This changed with release 6.0 and firmware 6.22.0, to accommodate firmware rollback, which can remove any capabilities that were not applied in earlier firmware, or that are not supported by earlier firmware.

After rollback or update, the system retains the full list that you had purchased, allowing you to re-install where appropriate.

To verify if a capability has been successfully added, use the **hsm showpolicies** command or the **hsm displaylicenses** command.

Syntax

hsm update show

Example

```
lunash:> hsm update show
```

```
Capability Updates:
621000021-001    Performance level 15
621000045-001    15.5 megabytes of object storage
621000046-001    Maximum 100 partitions
621000099-001    Per-partition Security Officer
```

```
Command result : 0 (Success)
```

hsm zeroize

Removes all partitions and keys from the HSM.



CAUTION: This command puts the HSM in a zeroized state.

- This command destroys the HSM SO and all users (except Auditor), and their objects.
- This command can be run only via a local serial connection; it is not accepted via SSH. Because this is a destructive command, the user is asked to “proceed” unless the `-force` switch is provided at the command line. See ["Comparison of destruction/denial actions" on page 1](#) in the *Administration Guide* to view a table that compares and contrasts various "deny access" events or actions that are sometimes confused.
- This command does not require HSM login. The assumption is that your organization's physical security protocols prevent unauthorized physical access to the HSM. Nevertheless, if those protocols failed, an unauthorized person would have no access to HSM contents, and would be limited to temporary denial of service by destruction of HSM contents.
- This command was added with HSM firmware 6.22.0. It does not appear in the command list when the current slot is an older firmware version.
- This command does not reset HSM policies, except for policy 39: Allow Secure Trusted Channel. After zeroization, you will need to re-establish your STC links, as described in ["Restoring STC After HSM Zeroization" on page 1](#) in the *Administration Guide*, and in ["Creating an STC Link Between a Client and a Partition" on page 1](#) in the *Configuration Guide*.
- This command does not erase the RPV (Remote PED Vector or orange PED Key authentication data) from the HSM.
- This command does not delete the Auditor role.

To also reset HSM policies and destroy the RPV and destroy the Auditor, on HSMs with firmware 6.22.0 or newer, see ["hsm factoryreset" on page 76](#).

Syntax

hsm zeroize [-force]

Parameter	Shortcut	Description
<code>-force</code>	<code>-f</code>	Force the action without prompting.

Example

Non-local (network connection) attempt

```
lunash:>hsm zeroize
Error: 'hsm zeroize' can only be run from the local console.
  Login as 'admin' using the serial port on the
  SafeNet Network HSM before running this command.
Command Result : 0 (Success)
lunash:>
```

Local attempt

```
lunash:>hsm zeroize
```

```
CAUTION: Are you sure you wish to zeroize this HSM?  
All partitions and data will be erased.  
HSM level policies will not be changed.  
All current NTLS and/or STC sessions will be terminated.  
If you want policies reverted as well, use factory reset.  
Type 'proceed' to return the HSM to factory default, or  
'quit' to quit now.  
>  
> proceed  
'hsm zeroize' successful.  
Please wait while the HSM is reset to complete the process.  
Command Result : 0 (success)
```

htl

Access commands that allow you to view or configure a host trust link (HTL) for a client. Use these commands, combined with the client-side commands, to set up a host trust link.

For example, the command **vtl addserver** has the optional parameter **-htl**, to require a host trust link between the client where that command is run and the specified SafeNet HSM server. That is, this side (SafeNet HSM server) sets the parameters for HTL linking, and the client side determines whether that HTL is required when NTLS connections are made with that client.

Syntax

htl

clearott
generateott
set
show

Parameter	Shortcut	Description
clearott	c	Deletes an HTL client one-time token. See " htl clearott command " on the next page.
generateott	d	Generates an HTL client one-time token. See " htl generateott " on page 176.
set	l	Access commands that allow you to configure the attributes for an HTL client one-time token. See " htl set " on page 177.
show	r	Displays information for the currently configured HTL client one-time tokens. See " htl show " on page 181.

htl clearott command

Delete an HTL client one-time token. This command warns you if the one-time token is in use, that is, if the connection is not down, terminated, or in an unknown state. If the one-time token is in use, you can elect to delete it. If you do, however, recovery within the grace period would not work.

Syntax

htl clearott -client <client_name> [**-force**]

Parameter	Shortcut	Description
-client	-c	Specifies the client for which you want to delete the HTL one-time token. This is the client name provided when you registered the client using the client register command.
-force	-f	Force the action without prompting

Example

```
lunacm:> htl clearott -client myclient -force
```

```
Command Result : 0 (Success)
```

htl generateott

Generate an HTL client one-time token. This token is used to initiate the HTL strong-binding connection.

The command allows the user to regenerate the one-time token only if there is not already an one-time token for that client (that is, if the output of the **htl show** says "No file" for that user's one-time token status). This avoids the case where an existing HTL connection cannot resume operation during the grace period because the client's one-time token was overwritten with a new one.

Synopsis

htl generateott -client <clientname>

Parameter	Shortcut	Description
-client	-c	Specifies the client for which you want to generate the HTL one-time token. This is the client name provided when you registered the client using the client register command.

Example

```
lunacm:> htl generateOtt -client myclient
```

```
Command Result : 0 (Success)
```


htl set

Access commands that allow you to configure the attributes for an HTL client one-time token.

Syntax

htl set

defaulttosexpiry
graceperiod
otsexpiry

Parameter	Shortcut	Description
defaulttosexpiry	d	Sets the HTL one-time token default expiry time for a client. See " htl set defaulttosexpiry " on the next page.
graceperiod	g	Sets the HTL grace period. See " htl set graceperiod " on page 179.
otsexpiry	o	Set the HTL one-time token expiry time for a client. See " htl set otsexpiry " on page 180.

htl set defaultottexpiry

Set the HTL one-time token default expiry time for all clients. This command sets the system default that will be used for all HTL clients. You can use the **htl set ottexpiry command** to override the default for a specific HTL client.

Syntax

htl set defaultottexpiry -timeout

Parameter	Shortcut	Description
-timeout <seconds>	-t	Specifies the default timeout for all HTL clients, in seconds. Use a value of 0 to indicate that the that the one-time token never times out. Range: 0 to 3600

Example

```
lunacm:> htl set defaultOttExpiry -timeout 160
```

```
ottExpiry set to 160 seconds
```

```
Command Result : 0 (Success)
```

htl set graceperiod

Set the HTL grace period. The value that you set here applies to all clients of this SafeNet HSM appliance.

Synopsis

```
htl set graceperiod -timeout <seconds>
```

Parameter	Shortcut	Description
-timeout	-t	Specifies the grace period for all HTL clients, in seconds. Use a value of 0 to set grace period off. Range: 0 to 200

Example

```
lunacm:> htl set gracePeriod -timeout 200
```

```
Grace period set to 200 seconds
```

```
Command Result : 0 (Success)
```

htl set ottexpiry

Set the HTL one-time token expiry time for a client.

Syntax

```
htl set ottExpiry -client <clientname> {-timeout <seconds> | -default}
```

Parameter	Shortcut	Description
-client	-c	Specifies the client for which you want to specify the timeout. This is the client name provided when you registered the client using the client register command.
-default	-d	specifies that you want to use the system default specified by the htl set defaultottexpiry command, rather than the values specified by the -timeout parameter. This parameter is just a toggle.
-timeout	-t	Specifies the timeout for the specified client, in seconds. Use a value of 0 to indicate that the one-time token never times out. Range: 0 to 3600

Example

```
lunacm:> htl set ottExpiry -client myclient -timeout 45
```

```
'htl set ottExpiry' successful.
```

```
Command Result : 0 (Success)
```

htl show

Shows HTL information for all clients, unless a specific client is named, in which case HTL information for the named client, only, is shown. The following information is displayed:

HTL Grace Period	The system-level provisionable grace period, in seconds, as set with the htl set graceperiod command. This is how long the connection can be down, and still recover.
Default OTT Expiry	The system-level provisionable default OTT expiry period, in seconds, as set with the htl set defaultottexpiry command.
Client name	The client name, as set with the client register command.
HTL Status	Can be one of the following: <ul style="list-style-type: none"> • Up - the HTL link is up and operational. • Grace Period - the HTL link is down but the connection is still in the grace period for re-establishment without a new OTT. • Unknown - couldn't determine the HTL state (probably the HTL server is down). • Down - any other case, including an HTL link that's in the negotiation phase.
OTT Status	Can be one of the following: <ul style="list-style-type: none"> • Ready for d/I - the OTT file is available for download by the admin or operator users (currently available via scp only) • In use - there is an OTT file for this user in the HTL directory, which implies that it's being used by HTL at the moment • No file - there's no OTT file for this user on the system
OTT Expiry Time	Shows the provisioned OTT expiry time in seconds. This is the length of time for which a generated OTT is good, during which you must transfer it from the HSM to a client. If you have not specifically provisioned OTT expiry time, the system default is shown, with "(default)" after it.

Syntax

htl show [-client <clientname>]

Parameter	Shortcut	Description
-client	-c	Specifies the client for which you want to show HTL configuration information. This is the client name provided when you registered the client using the client register command.

Example

```
lunash:> htl show
HTL Grace period : 30 seconds
Default OTT expiry : 30 seconds
Client Name      HTL Status      OTT Status      OTT Expiry Time
```

```
localhost      Up           In use      30 (default)
myclient       Down        No file     60
Command Result : 0 (Success)
```

my

Access commands that allow the currently logged in user to manage their files, passwords, and public keys.

Syntax

my

file

password

public-key

Parameter	Shortcut	Description
file	f	Access commands that allow the currently logged in user to manage their files. See "my file" on the next page.
password	pa	Access commands that allow the currently logged in user to manage their password. See "my password" on page 188.
public-key	pu	Access commands that allow the currently logged in user to manage their public keys. See "my public-key" on page 191.

my file

Access commands that allow the currently logged in user to manage their files.

Syntax

my file

clear
delete
list
run

Parameter	Shortcut	Description
clear	c	Delete all of the files owned by the currently logged in user. See "my file clear" on the next page.
delete	d	Delete a file owned by the currently logged in user. See "my file delete" on page 186.
list	l	List the files owned by the currently logged in user. See "my file list" on page 187.

my file clear

Deletes all of the files owned by the currently logged in user.

Syntax

my file clear [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>my file clear
```

```
WARNING !! This command will delete all user files.
```

```
If you are sure that you wish to proceed, then enter 'proceed', otherwise this command will abort.
```

```
> proceed
```

```
Proceeding...
```

```
Command Result : 0 (Success)
```

my file delete

Delete a file owned by the currently logged in user.

Syntax

my file delete <filename>

Parameter	Shortcut	Description
<filename>		Specifies the name of the file to delete.

Example

```
lunash:>my file delete somefilename
```

```
somefilename deleted
```

```
Command Result : 0 (Success)
```

my file list

List the files owned by the currently logged in user.

Synopsis

my file list

Example

```
lunash:>my file list
```

```
375368 Oct 21 11:36 supportInfo.txt
21751010 Oct 21 11:25 lunasa_update-5.1.0-15.spkg
145054 Oct 17 10:29 logs.tgz
90615 Oct 13 10:28 syslog
294 Oct 5 15:23 pub.pub
294 Oct 5 15:22 pub
```

```
Command Result : 0 (Success)
```

my password

Access commands that allow the currently logged in user to manage their password.

Syntax

my password

expiry show
set

Parameter	Shortcut	Description
expiry show	e s	Displays password expiry information for the currently logged in user. See "my password expiry show" on the next page.
set	s	Change the password for the currently logged in user. See "my password set" on page 190.

my password expiry show

Display password expiry information for the currently logged in user.

Syntax

my password expiry show

Example

```
lunash:>my password expiry show
```

```
Last password change      : Sep 14, 2010  
Password expires          : never
```

```
Command Result : 0 (Success)
```

my password set

Change the password for the currently logged in user.

Syntax

my password set

Example

```
lunash:>my password set
Changing password for user admin.
```

You can now choose the new password.

A valid password should be a mix of upper and lower case letters, digits, and other characters. You can use a minimum 8 character long password with characters from at least 3 of these 4 classes.

An upper case letter that begins the password and a digit that ends it do not count towards the number of character classes used.

Enter new password:

Re-type new password:

```
passwd: all authentication tokens updated successfully.
```

```
Command Result : 0 (Success)
```

my public-key

Access commands that allow the currently logged in user to manage their public keys. Add a public key for your user if you wish to authenticate your sessions using public-key authentication rather than password. The SafeNet Network HSM is shipped with public-key authentication allowed, by default. However, you nevertheless must make your first connections using password authentication, until you have imported a public key from your computer and added it to the appliance with **my public-key add** command.



Note: The my public-key commands manage the existence of the public keys for use by ssh sessions, but the commands to enable and disable their use on SafeNet Network HSM are still at:

"sysconf ssh publickey enable" on page 488

and

"sysconf ssh publickey disable" on page 487

Syntax

my public-key

add
clear
delete
list

Parameter	Shortcut	Description
add	a	Adds an SSH public key for the currently logged in user. See "my public-key add" on the next page.
clear	c	Deletes all SSH public keys for the currently logged in user. See "my public-key clear" on page 193.
delete	d	Deletes an SSH public key for the currently logged in user. See "my public-key delete" on page 194.
list	l	Lists the SSH public keys owned by the currently logged in user. See "my public-key list" on page 195.

my public-key add

Add an SSH public key for the currently logged in user.



Note: The my public-key commands manage the existence of the public keys for use by ssh sessions, but the commands to enable and disable their use on SafeNet Network HSM are still at:
 "sysconf ssh publickey enable" on page 488
 and
 "sysconf ssh publickey disable" on page 487

Syntax

my public-key add <lunash_user_public_key>

Parameter	Shortcut	Description
<lunash_user_public_key>		Specifies the name of the public key to add.

Example

```
lunash:>my public-key add somekey
```

```
Command Result : 0 (Success)
```


my public-key clear

Delete all SSH public keys for the currently logged in user.



Note: The my public-key commands manage the existence of the public keys for use by ssh sessions, but the commands to enable and disable their use on SafeNet Network HSM are still at:
 "sysconf ssh publickey enable" on page 488
 and
 "sysconf ssh publickey disable" on page 487

Syntax

my public-key clear [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>my public-key clear
```

```
WARNING !! This command will delete all User SSH Public Keys.
If you are sure that you wish to proceed, then enter 'proceed', otherwise this command will
abort.
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

my public-key delete

Delete an SSH public key for the currently logged in user.



Note: The my public-key commands manage the existence of the public keys for use by ssh sessions, but the commands to enable and disable their use on SafeNet Network HSM are still at:
 "sysconf ssh publickey enable" on page 488
 and
 "sysconf ssh publickey disable" on page 487

Syntax

my public-key delete <lunash_user_public_key>

Parameter	Shortcut	Description
<lunash_user_public_key>		Specifies the name of the public key to delete.

Example

```
lunash:>my public-key delete somekey
```

```
Command Result : 0 (Success)
```

my public-key list

List the SSH public keys owned by the currently logged in user.



Note: The my public-key commands manage the existence of the public keys for use by ssh sessions, but the commands to enable and disable their use on SafeNet Network HSM are still at:
 "sysconf ssh publickey enable" on page 488
 and
 "sysconf ssh publickey disable" on page 487

Syntax

my public-key list

Example

```
lunash:>my public-key list
```

```
SSH Public Keys for user 'admin':
```

Name	Type	Bits	Fingerprint
pub1	ssh-rsa	1024	08:95:7b:9c:57:27:2e:cc:6f:f2:99:e4:19:41:1c:e9

```
Command Result : 0 (Success)
```

network

Access commands that allow you to view and configure the network settings for the appliance.

Syntax

network

dns
domain
hostname
interface
ping
route
show

Parameter	Shortcut	Description
dns	dn	Access commands that allow you to configure the appliance DNS settings. See "network dns" on the next page .
domain	do	Set the network domain. See "network domain" on page 200 .
hostname	h	Set the appliance hostname. See "network hostname" on page 201 .
interface	i	Configure the network interfaces. See "network interface" on page 202 .
ping	p	Test the network connectivity. See "network ping" on page 212 .
route	r	Access commands that allow you to configure the network routes for the appliance. See "network route" on page 213 .
show	s	Display the current network configuration. See "network show" on page 218 .

network dns

Access commands that allow you to configure the appliance DNS settings.

Syntax

network dns

add
delete

Parameter	Shortcut	Description
add	a	Add domain name servers and search domains to the network configuration. See " network dns add " on the next page.
delete	d	Delete domain name servers and search domains from the network configuration. See " network dns delete " on page 199.

network dns add

This command adds a domain name server or search domain to the system.

The user must execute the command once for each name server or search domain being added. To see the existing DNS settings, use the **network show** command.

Syntax

```
network dns add [{"-nameserver <ip_address>"} [{"-searchdomain <net_domain>}]
```

Parameter	Shortcut	Description
-nameserver	-n	Add the specified name server to the DNS table.
-searchdomain	-s	Add the specified search domain to the DNS table.

Example

```
lunash:> net dns add -nameserver 192.16.0.2  
Success: Nameserver 192.16.0.2 added
```

```
lunash:> net dns add -searchdomain 192.16.0.0  
Success: Searchdomain entry 192.16.0.0 added
```

network dns delete

This command deletes or removes a domain name server or search domain from the system.

The user must execute the command once for each name server or search domain being deleted. To see the existing DNS settings, use the **network show** command.

Syntax

network dns delete {[-nameserver <ip_address>] | [-searchdomain <net_domain>]}

Parameter	Shortcut	Description
-nameserver	-n	Delete the specified name server from the DNS table.
-searchdomain	-s	Delete the specified search domain from the DNS table.

Example

```
lunash:> net dns delete -nameserver 192.16.0.2
Success: Nameserver 192.16.0.2 deleted
```

```
lunash:> net dns delete -searchdomain 192.16.0.0
Success: Searchdomain entry 192.16.0.0 deleted
```

network domain

Set the network domain for this system. Note that the new domain will not be completely in effect until the network service is restarted (see the **service -start** command). To see the existing domain, use the **net show** command.

Syntax

network domain <netdomain>

Parameter	Shortcut	Description
<netdomain>		Set system domain name to the specified value.

Example

```
lunash:> net domain safenet-inc.com
```

```
Success: DomainName safenet-inc.com set.
```


network hostname

Set the system hostname. Note that the new hostname will not be completely in effect until the network service is restarted (see the **service -start** command). To see existing hostname, use the **network show** command.

Syntax

```
lunash:> network hostname <hostname>
```

Parameter	Shortcut	Description
<hostname>		Set system host name to the specified value.

Example

```
lunash:> net hostname Luna10
```

```
Success: Hostname Luna10 set.
```

network interface

Configure the network interface for the system. This command should be issued at least once for each Ethernet interface (Eth0 and Eth1) that will be connected to the network.

The delete sub-command can be used to remove the settings applied to a specific network interface.

Syntax

network interface

static
dhcp
delete
bonding

Parameter	Shortcut	Description
static	s	Set static IP configuration. See "network interface static " on page 204.
dhcp	dh	Set dynamic IP configuration. See "network interface dhcp " on page 205.
delete	del	Delete IP configuration. See "network interface delete " on page 206.
bonding	b	> Network interface bonding. See "network interface bonding" on page 207.

Syntax

network interface -device <netdevice> -ip <ipaddress> -netmask <ipaddress> [-force] [-gateway <ipaddress>]

net -interface -delete <ipaddress> -device <devicename>

Name	(short)	Description
delete	del	Delete IP Configuration
dhcp	dh	Set DHCP IP Configuration
static	s	Set Static IP Configuration
bonding	b	> Network Interface Bonding*

delete This command may be issued to disable a network interface (eth0 or eth1). Note that NTLS always uses eth0 (the top ethernet jack at the back of the SafeNet Network HSM).

dhcp [if adding, must specify one of -static or -dhcp] Indicate that this ethernet device will have a dynamic IP address. (Not recommended - note that using dhcp will automatically update the SafeNet appliance's system name servers and other network settings that are transmitted via DHCP). In general, we recommend against using DHCP for SafeNet appliances.

static [if adding, must specify one of `-static` or `-dhcp`] Indicate that this ethernet device will have a static IP address. (Recommended)

Options

The following options are available:

Name (short)	Description
<code>-device</code>	<code>-d</code> Network Device
<code>-ip</code>	<code>-i</code> IP Address
<code>-gateway</code>	<code>-g</code> Gateway IP Address
<code>-netmask</code>	<code>-n</code> Network IP Address Mask
<code>-force</code>	<code>-f</code> Force action

-device [mandatory] Indicate which ethernet device is currently being set up. Must select one of `eth0` or `eth1`. Recommended that you always use `eth0` for NTLS, and that you set it up first.

-gateway [mandatory] The gateway that this device will use (obtain from the network administrator).

-force [optional] The command is performed without prompting.

-ip [mandatory if using `-static`] The network device's new static IP address (obtain from the network administrator).

-netmask [mandatory if using `-static`] The IP address's netmask (obtain from the network administrator)

Sample Output

```
lunash:> net -interface -delete 192.22.101.77 -device eth1
```

Interface eth1 removed successfully.

```
'net -interface' successful. Ethernet device eth1 set to ip address (null).
```

```
lunash:> net -interface -static -device eth1 -ip 192.22.101.77 -gateway 192.16.0.2 -netmask 255.255.0.0
```

```
'net -interface' successful. Ethernet device eth1 set to ip address 192.22.101.77.
```

network interface static

Directs the specified Ethernet device to use the specified static IP address.

Syntax

network interface static -device <netdevice> -ip <ipaddress> -netmask <ipaddress> [-gateway <ipaddress>] [-force]

When setting "network interface" configuration, one of "static" or "dhcp" or "bonding" is required.

(Option)	Parameter	Description
-device	-d <netdevice>	Network Device (Eth0,Eth1).
-ip	-i <ipaddress>	IP address assigned to the device.
-netmask	-n <ipaddress>	Enable network interface bonding.
-gateway	-g <ipaddress>	Disable network interface bonding.
-force	-f	Force action.

Sample Output

```
lunash:> net -interface -static -device eth1 -ip 192.22.101.77 -gateway
192.16.0.2 -netmask 255.255.0.0
'net -interface' successful.
Ethernet device eth1 set to ip address 192.22.101.77.
```

network interface dhcp

Directs this Ethernet device to request a dynamic IP address. (Not recommended - note that using dhcp will automatically update the SafeNet appliance's system name servers and other network settings that are transmitted via DHCP).



Note: In general, we recommend against using DHCP for SafeNet appliances. Do not specify DHCP if you intend to use Network Interface Port Bonding - a change to the leased IP address disrupts port bonding, which must be manually disabled and then reconfigured before it can be re-enabled.

When setting "network interface" configuration, one or the other of "static" or "dhcp" or "bonding" is required.

Syntax

network interface dhcp -device <netdevice> [-force]

(Option)	Parameter	Description
-device	-d <netdevice>	Network Device (Eth0,Eth1).
-force	-f	Force action.

network interface delete

This command disables a network interface (Eth0 or Eth1). Note that NTLS always uses Eth0 (the top Ethernet jack at the back of the SafeNet Network HSM appliance).

Syntax

network interface delete -device <netdevice>

(Option)	Parameter	Description
-device	-d <netdevice>	Network Device (Eth0,Eth1).

Sample Output

```
lunash:> net -interface -delete 192.22.101.77 -device eth1
Interface eth1 removed successfully.
'net -interface' successful. Ethernet device eth1 set to ip address (null).
```

network interface bonding

Access commands that allow you to configure bonding of the two network interfaces as a single virtual device.

Use port bonding only with static addressing. If you set bonding where dynamically allocated addressing is in use, then any future change in a DHCP lease would break interface bonding.

Syntax

network interface bonding

config
show
enable
disable

Parameter	Shortcut	Description
config	c	Add network bonding interface. See " network interface bonding config " on the next page .
show	s	Show network interface bonding information. See " network interface bonding show " on page 211 .
enable	e	Enable network interface bonding. See " network interface bonding enable " on page 210 .
disable	d	Disable network interface bonding. See " network interface bonding disable " on page 209 .

network interface bonding config

Configure a network bonding interface - a virtual device that bonds Eth0 and Eth1.

Use port bonding only with static addressing. If you set bonding where dynamically allocated addressing is in use, then any future change in a DHCP lease would break interface bonding.

Syntax

network interface bonding config -ip <ipaddress> [-gateway <ipaddress>] -netmask <ipaddress>

Parameter	Shortcut	Description
-ip	-i	Specifies the IP address of the bonded virtual network device.
-gateway	-g	Specifies the gateway/router IP address. (This is indicated as "optional" in the command syntax, but the appropriate gateway address must always be supplied unless you and your clients are on the same subnet as the SafeNet Network HSM appliance.)
-netmask	-n	Specifies the network address mask.

Example

```
lunash:> network interface bonding config -ip 192.20.17.200 -netmask 255.255.255.0 -gateway
192.20.17.10
```

Command Result : 0 (Success)

network interface bonding disable

Disable network interface bonding.

Syntax

network interface bonding disable

Example

```
lunash:> >network interface bonding disable
```

Shutting down interface eth0:

At this point, the ssh session disconnects, and must be re-established, including login to the SafeNet Network HSM appliance.

```
lunash:>
```

network interface bonding enable

Enable network interface bonding.

Syntax

network interface bonding enable

Example

```
[172.20.9.127] lunash:>network interface bonding enable
```

```
Shutting down interface eth0: [ OK ]
Shutting down loopback interface: [ OK ]
Bringing up loopback interface: [ OK ]
Bringing up interface bond0: RTNETLINK answers: File exists
Error adding address 172.20.9.127 for bond0.
[ OK ]
MUST RESTART SYSTEM TO SET THE CORRECT BONDING PARAMETERS!!!
```

Command Result : 0 (Success)

```
[172.20.9.127] lunash:>
```

At this point, the ssh session disconnects, and must be re-established, including login to the SafeNet Network HSM appliance.



Note: Restart the system after the **network interface bonding enable** command, with **sysconf appliance restart**, to allow the system to begin using the new configuration.

network interface bonding show

Display the current network bonding interface status.

Syntax

network interface bonding show

Example

```
lunash:> >network interface bonding show
```

```
Bonding is configured, but not enabled.
```

```
===== Bonding Interface =====  
BOOTPROTO=static  
IPADDR=172.20.17.200  
NETMASK=255.255.255.0  
=====
```

```
Command Result : 0 (Success)
```

```
lunash:>
```

network ping

Test the network connectivity to the specified host. This command sends an ICMP ECHO message to another computer, to verify the presence and alertness of the target computer on the network.

Syntax

network ping <hostname_or_ipaddress>

Parameter	Shortcut	Description
<hostname_or_ipaddress>		Specifies the host name or IP address to ping.

Example

```
lunash:>network ping yourLuna
PING 192.12.11.102 (192.12.11.102) from 192.12.11.77 : 56(84) bytes of data.
64 bytes from 192.12.11.102: icmp_seq=0 ttl=255 time=163 usec
--- 192.12.11.102 ping statistics ---
1 packets transmitted, 1 packets received, 0% packet loss
round-trip min/avg/max/mdev = 0.163/0.163/0.163/0.000 ms
```

Command Result : 0 (Success)

network route

Access commands that allow you to configure the network routes for the appliance.

Syntax

network route

add
clear
delete
show

Parameter	Shortcut	Description
add	a	Add a network route. See "network route add" on the next page.
clear	c	Delete all network routes. See "network route clear" on page 215.
delete	d	Delete the specified network route. See "network route delete" on page 216.
show	s	Display the current network route configuration. See "network route show " on page 217.

network route add

Add a manually configured network route to the current configuration. This command should be used only on the advice of a network administrator.

Syntax

```
network route add <routetype> <ipaddress> [-device <netdevice>] [-force] [-gateway <ipaddress>] [-metric <metric>] [-netmask <ipaddress>]
```

Parameter	Shortcut	Description
<routetype>		Set to "network" or "host" for network or host specific routes respectively.
<ipaddress>		Specifies the IP address of the target network or host.
-device	-d	Specifies a specific network device for the route.
-force	-f	Force the action without prompting
-gateway	-g	Specifies the gateway/router IP address if this is not a locally connected network or host.
-metric	-m	Specifies a routing metric Range: 0 to 65535 Default: 0
-netmask	-n	Specifies the network mask. This parameter should only be provided for network routes. If not specified, default is Class C netmask 255.255.255.0.

Example

```
lunash:> network route add <routetype> <ipaddress>
[-device <netdevice>] [-force] [-gateway <ipaddress>] [-metric
<metric>] [-netmask <ipaddress>]
Command Result : 0 (Success)
```

network route clear

Delete all manually configured static routes (as set with **network route add**). Since this operation may delete valuable configuration data, you are presented with a "Proceed/Quit" prompt unless you use the **-force** option.

Syntax

network route clear [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting

Example

```
lunash:> network route clear
```

```
Command Result : 0 (Success)
```

network route delete

Delete a manually configured network route from the current configuration. This command should be used only on the advice of a network administrator.

Syntax

```
network route delete <routetype> <ipaddress> [-device <netdevice>] [-force] [-gateway <ipaddress>] [-metric <metric>] [-netmask <ipaddress>]
```

Parameter	Shortcut	Description
<routetype>		Set to "network" or "host" for network or host specific routes respectively.
<ipaddress>		Specifies the IP address of the target network or host.
-device	-d	Specifies a specific network device for the route.
-force	-f	Force the action without prompting
-gateway	-g	Specifies the gateway/router IP address if this is not a locally connected network or host.
-metric	-m	Specifies a routing metric Range: 0 to 65535 Default: 0
-netmask	-n	Specifies the network mask. This parameter should only be provided for network routes. If not specified, default is Class C netmask 255.255.255.0.

Example

```
lunash:> network route delete <routetype> <ipaddress>
[-device <netdevice>] [-force] [-gateway <ipaddress>] [-metric
<metric>] [-netmask <ipaddress>]
Command Result : 0 (Success)
```

network route show

Display the current network route configuration.

Syntax

network route show

Example

```
lunash:> network route show
Kernel IP routing table
Destination      Gateway    Genmask    Flags Metric Ref    Use Iface
192.168.10.0     0.0.0.0   255.255.255.0 U0    0     0     eth1
152.20.0.0       0.0.0.0   255.255.0.0  U0    0     0     eth0
127.0.0.0        0.0.0.0
```

Command Result : 0 (Success)

network show

Display the network configuration, including the currently-negotiated NIC speed setting. This information is also collected in the **hsm supportinfo** command.

Syntax

network show

Example

```
lunash:>network show
```

```

Hostname:          "mylunasa6"
Domain:           "amer.sfnt.local"

IP Address (eth0): 172.20.17.200
HW Address (eth0): 00:15:B2:A1:AC:00
Mask (eth0):      255.255.255.0
Gateway (eth0):   172.20.17.10

Name Servers:     172.20.10.20      172.16.2.14
Search Domain(s): amer.sfnt.local sfnt.local
```

Kernel IP routing table

Destination	Gateway	Genmask	Flags	Metric	Ref	Use	Iface
172.20.17.0	0.0.0.0	255.255.255.0	U	0	0	0	eth0
0.0.0.0	172.20.17.10	0.0.0.0	UG	0	0	0	eth0

Link status

eth0: Configured

Settings for eth0:

```

Supported ports: [ TP ]
Supported link modes:  10baseT/Half 10baseT/Full
                      100baseT/Half 100baseT/Full
                      1000baseT/Full
```

Supports auto-negotiation: Yes

```

Advertised link modes: 10baseT/Half 10baseT/Full
                      100baseT/Half 100baseT/Full
                      1000baseT/Full
```

Advertised auto-negotiation: Yes

Speed: 100Mb/s

Duplex: Full

Port: Twisted Pair

PHYAD: 2

Transceiver: internal

Auto-negotiation: on

Supports Wake-on: pumbg

Wake-on: g

Current message level: 0x00000007 (7)

Link detected: yes

eth1: Not configured

Command Result : 0 (Success)

ntls

Access commands that allow you to manage the network trust link service (NTLS) on the appliance.

Syntax

ntls

activatekeys
bind
certificate
deactivatekeys
information
ipcheck
show
sslopsall
sslopsrsa
tcp keepalive
threads
timer

Parameter	Shortcut	Description
activatekeys	a	Activate the NTLS keys container. See " ntls activatekeys " on the next page.
bind	b	Set the NTLS binding. See " ntls bind " on page 222.
certificate	c	Access commands that allow you to manage the NTLS certificates. See " ntls certificate " on page 224.
deactivatekeys	d	Deactivate the NTLS keys container. See " ntls deactivatekeys " on page 232.
information	in	Access commands that allow you to display NTLS status information. See " ntls information " on page 233.
ipcheck	ip	Access commands that allow you to manage the NTLS client source IP validation configuration. See " ntls ipcheck " on page 236.
show	sh	Show the NTLS binding. See " ntls show " on page 240.
sslopsall	sslopsa	Perform all NTLS SSL operations in hardware. See " ntls sslopsall " on page 241.
sslopsrsa	sslopsr	Perform only RSA NTLS SSL operations in hardware. See " ntls sslopsrsa " on page 242.
tcp_keepalive	tc	Access commands that allow you to manage TCP keepalive. See " ntls tcp_keepalive " on page 243.
threads	th	Access commands that allow you to manage the NTLS worker threads. See " ntls threads " on page 247.
timer	ti	Access commands that allow you to manage the NTLS timer. See " ntls timer " on page 250.

ntls activatekeys

Activate the NTLS keys container. If you are using a PED-authenticated HSM, this command requires PED operation.

Syntax

ntls activatekeys

Example

```
lunash:>ntls activateKeys  
Login successful.
```

```
Command Result : 0 (Success)
```

ntls bind

Binds the network trust link service (NTLS) to a network device (eth 0 or eth1) or to a hostname or IP address. You must bind to either a network device or a hostname/IP address.

The new setting takes effect only after NTLS is restarted.

If you wish, client traffic restriction could complement SSH traffic restriction using the command "[sysconf ssh ip](#)" on [page 481](#) or "[sysconf ssh device](#)" on [page 480](#), which restrict administrative traffic (over SSH) to a specific IP address or device name on your SafeNet Network HSM.

Syntax

ntls bind [<netdevice>] [**-bind** <hostname_or_ipaddress>] [**-force**]

Parameter	Shortcut	Description
-bind	-b	Bind the NTLS service to a hostname or IP address, if no ethernet device was specified.
-force	-f	Force the action without prompting.
<netdevice>		Bind the NTLS service to this ethernet device. Can be left blank if you are binding to a hostname or ip address, otherwise must be the loopback device or an ethernet device. Valid values: lo: Bind to the loopback device. eth0: Bind to the eth0 device. eth1: Bind to eth1 device. all: Bind to all devices. Default: lo

Example

For a device

```
lunash:>ntls bind eth0
```

```
Success: NTLS binding network device eth0 set.
```

```
NOTICE: The NTLS service must be restarted for new settings to take effect.
```

```
If you are sure that you wish to restart NTLS, then type 'proceed', otherwise type 'quit'
> proceed
```

```
Proceeding...
```

```
Restarting NTLS service...
```

```
Stopping ntlsh: [ OK ]
```

```
Starting ntlsh: [ OK ]
```

```
Command Result : 0 (Success)
```

For an IP address

```
[myluna] lunash:>ntls bind none -bind 192.20.10.96
```

```
Success: NTLS binding hostname or IP Address 192.20.10.96 set.
```

```
NOTICE: The NTLS service must be restarted for new settings to take effect.
```

If you are sure that you wish to restart NTLS, then type 'proceed', otherwise type 'quit'
> proceed

```
Proceeding...
Restarting NTLS service...
Stopping ntlsl: [ OK ]
Starting ntlsl: [ OK ]
Command Result : 0 (Success)
```

```
lunash:>ntls show
```

```
NTLS bound to network device: none IP
Address: "192.20.10.96" (eth0)
Command Result : 0 (Success)
```

ntls certificate

Access commands that allow you to manage the NTLS certificates.

Syntax

ntls certificate

monitor
show

Parameter	Shortcut	Description
monitor	m	Access commands that allow you to manage certificate expiry monitoring. See " ntls certificate monitor " on the next page.
show	s	Show the NTLS server certificate. See " ntls certificate show " on page 230.

ntls certificate monitor

The following subcommands are available:

Parameter	Shortcut	Description
disable	d	Disable certificate expiry monitoring. See "ntls certificate monitor disable" on the next page.
enable	e	Enable certificate expiry monitoring. See "ntls certificate monitor enable" on page 227"ntls certificate monitor disable" on the next page
show	s	Show the certificate expiry monitor status. See "ntls certificate monitor show" on page 228.
trap trigger	t	Set the NTLS certificate expiry SNMP trap trigger. See "ntls certificate monitor trap trigger" on page 229.

ntls certificate monitor disable

Disable NTLS certificate expiry monitoring.

Syntax

ntls certificate monitor disable

Example

```
lunash:> ntls certificate monitor disable
```

```
NTLS Server Cert Monitor disabled  
Shutting down certmonitord:
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

```
lush ntls Commands
```

ntls certificate monitor enable

Enable NTLS certificate expiry monitoring. The NTLS certificate used by the SafeNet appliance is only valid for a limited period. This command turns on lifetime monitoring so that as the expiry date nears, an SNMP trap notifies an administrator of the impending expiry of the certificate.

The SNMP trap must be configured before the NTLS certificate expiry trap can be sent even if the monitor daemon is enabled.

Syntax

ntls certificate monitor enable

Example

```
lunash:> ntls certificate monitor enable
```

```
NTLS Server Cert Monitor enabled  
Starting certmonitord:
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

ntls certificate monitor show

Report when the NTLS certificate will expire and whether certificate monitoring is enabled..

Syntax

ntls certificate monitor show

Example

```
lunash:>ntls certificate monitor enable
```

```
NTLS Server Certificate Expiry Monitor is enabled.  
NTLS Server Certificate will expire on "Apr 4 15:58:32 2021 GMT"  
Certificate expiry trap will be sent 5 days before the Certificate expiry day "Apr 4 15:58:32  
2021 GMT" and on every 12 hour(s)  
SNMP trap is not configured. No trap will be sent.
```

```
Command Result : 0 (Success)
```

ntls certificate monitor trap trigger

Set the NTLS certificate expiry SNMP trap. This command defines when, and how often, an SNMP trap is sent when the NTLS certificate is about to expire.

Syntax

ntls certificate monitor trap trigger -preexpiry <days> -trapinterval <hours>

Parameter	Shortcut	Description
-preexpiry	-p	Specifies the number of before the certificate expires that the trap is triggered. Range: 1 to 366
-trapinterval	-t	Specifies the interval, in hours, that the trap is sent once it has been triggered. Range: 1-720

Example

```
lunash:>ntls certificate monitor trap trigger -preexpiry 10 -trapinterval 36
Certificate expiry trap is configured to be sent 10 days before the Certificate expiry day "Apr
4 15:58:32 2021 GMT" and on every 36 hour(s)
Shutting down certmonitord:          [ OK ]
Starting certmonitord:                [ OK ]

Command Result : 0 (Success)
```

ntls certificate show

Display the contents of the NTLS server certificate.

Syntax

ntls certificate show

Example

```
lunash:>ntls certificate show
```

```
NTLS Server Certificate:
Data:
Version: 3 (0x2)
Serial Number: 0 (0x0)
Signature Algorithm: sha256WithRSAEncryption
Issuer: C=CA, ST=Ontario, L=Ottawa, O=Chrysalis-ITS, CN=168.20.20.254
Validity
Not Before: May  4 12:19:12 2011 GMT
Not After : May  5 12:19:12 2021 GMT
Subject: C=CA, ST=Ontario, L=Ottawa, O=Chrysalis-ITS, CN=168.20.20.254
Subject Public Key Info:
Public Key Algorithm: rsaEncryption
RSA Public Key: (2048 bit)
Modulus (2048 bit):
00:c1:4a:87:2f:0e:e0:a7:2d:01:d1:4e:d4:6c:b9:
8b:f0:67:46:34:e6:8b:6b:87:8f:90:83:53:49:cf:
af:30:a0:7e:f0:9a:04:8c:96:7e:3b:3a:9e:08:12:
ba:38:43:f3:e0:d0:52:01:25:37:04:b1:a1:71:f4:
b6:b6:cb:9a:ba:a4:9e:48:6d:a1:75:c3:60:6b:28:
ce:50:1e:8b:f4:5c:48:c9:5e:e2:4e:13:a0:36:9d:
ac:13:a6:b1:e9:cd:97:33:eb:f2:fb:45:c6:2d:2b:
65:0c:c4:7d:b8:c6:e0:6f:65:8d:79:89:c5:1c:6c:
ac:b2:dc:2f:15:55:d7:24:f1:7c:e0:97:83:e8:33:
e8:04:89:85:16:cc:1d:3e:6e:02:08:6a:16:08:d3:
f5:40:17:ac:e8:07:c0:05:40:76:c6:e5:1f:44:4d:
ca:e1:65:45:ef:75:73:76:6a:4d:ae:db:90:1e:84:
08:8f:5f:ae:48:de:10:02:88:71:b0:bc:6b:78:36:
21:ad:b4:f6:00:2a:92:17:e1:03:e0:3c:5e:55:94:
16:00:78:dc:bc:04:46:43:b3:26:35:01:80:1c:f7:
90:f5:1d:0d:04:bc:f7:80:12:3b:35:9c:e9:2e:4f:
7b:a8:ec:be:ab:44:f6:61:37:22:55:68:5c:2d:77:
e6:fl
Exponent: 65537 (0x10001)
Signature Algorithm: sha256WithRSAEncryption
7e:4d:b3:cf:95:e1:3b:8f:21:74:dc:e0:f7:c1:2a:c2:5e:5e:
c0:a7:70:9c:44:a0:b1:68:80:8c:2f:34:f2:eb:1e:5d:7c:b8:
19:75:ff:38:6a:6f:98:98:de:2a:4a:bd:88:ac:e7:12:69:62:
a2:07:78:4f:31:ed:92:0b:73:f4:6a:54:33:c9:9f:bb:16:1f:
67:6b:40:e8:01:8e:cd:52:66:b5:3c:5a:9c:00:34:88:e2:fa:
5d:a9:22:8f:28:8b:cf:56:f7:cd:4d:15:a5:25:59:c7:9a:4e:
8b:36:37:13:e3:dd:d5:8c:11:d9:1a:b5:69:54:77:30:97:ed:
23:9b:e7:f9:f3:66:b9:d0:b6:54:06:ba:46:da:44:22:08:b8:
87:ae:21:6e:3c:69:5f:5b:b5:d5:51:d4:53:61:5c:32:aa:87:
a4:1a:e2:cb:89:b9:0c:86:6a:15:23:2a:36:c8:72:da:23:76:
2d:d9:2c:c4:3d:8b:bd:75:4e:85:45:8e:ca:86:60:8a:07:ba:
2c:81:42:a7:c0:68:37:a9:7b:46:10:f1:e2:da:68:f7:7d:43:
eb:5c:6b:98:75:81:46:c0:31:b6:f9:68:1b:86:10:5f:3b:75:
```

```
4c:7b:79:41:b1:8b:eb:51:ad:ac:5e:3d:78:ba:9a:29:00:9f:  
46:b5:03:a2  
Command Result : 0 (Success)
```

ntls deactivatekeys

Deactivate the NTLS keys container.

Syntax

ntls deactivatekeys

Example

```
lunash:>ntls deactivateKeys
```

```
Command Result : 0 (Success)
```


ntls information

Access commands that allow you to display information about the NTLS connection or reset the NTLS counters.

Syntax

ntls information

reset
show

Parameter	Shortcut	Description
reset	r	Reset the NTLS counters. See "ntls information reset" on the next page.
show	s	Display NTLS information. See "ntls information show" on page 235.

ntls information reset

Reset the NTLS counters.



Note: Resetting counters produces what is known as a "counter discontinuity" in the SNMP agent, therefore the use of this functionality is discouraged. Counter discontinuities may result in SNMP management applications recording large false positive or negative spikes if rates are being monitored using delta methods. If you are not using SNMP, then this is not an issue.

Syntax

ntls information reset

Example

```
lunash:>ntls information reset
```

```
Command Result : 0 (Success)
```

ntls information show

Display information about the NTLS connection. The following information is displayed:

Operational Status	An unsigned 32-bit integer that indicates that status of the NTLS connection. The status is reported as follows. Note that this value will generally agree with the output of the service status ntls command: up: The NTLS service appears to be running OK. (Should be "up" when front panel LED is green.) down: the NTLS service appears not to be running. This could indicate a fault or that NTLS is not started yet, or has been purposely disabled with (for example) service stop ntls or that there is a software upgrade in progress. unknown: The NTLS service status cannot be determined. This should be rare.
Connected Clients	An unsigned 32-bit integer that indicates the current number of clients using the NTLS connection.
Links	An unsigned 32-bit integer that indicates the current number of links on the NTLS connection.
Successful Client Connections	A 64-bit integer counter that indicates the number of client sessions that have successfully connected to the HSM using the NTLS connection. This value can be reset using the ntls information reset command.
Failed Client Connections	A 64-bit integer counter that indicates the number of client sessions that did not successfully connect to the HSM using the NTLS connection. This value can be reset using the ntls information reset command.

Syntax

ntls information show

Example

```
lunash:>ntls information show
```

```
NTLS Information:
Operational Status:          1 (up)
Connected Clients:          2
Links:                       2
Successful Client Connections: 112
Failed Client Connections:   1
```

```
Command Result : 0 (Success)
```

ntls ipcheck

Access commands that allow you to enable, disable or view the configuration of NTLS client source IP validation.

Syntax

ntls ipcheck

disable
enable
show

Parameter	Shortcut	Description
disable	d	Disable NTLS client source IP validation. See "ntls ipcheck disable " on the next page .
enable	e	Enable NTLS client source IP validation. See "ntls ipcheck enable" on page 238 .
show	s	Display the current client source IP validation configuration. See "ntls ipcheck show" on page 239 .

ntls ipcheck disable

Disable client source IP address validation by NTLS upon an NTLA client connection. Use this command , for example, when you have network address translation (NAT) between your client(s) and the SafeNet Network HSM appliance. The checking is enabled by default.

Syntax

ntls ipcheck disable

Example

```
lunash:>ntls ipcheck disable
```

```
NTLS client source IP validation disabled
```

```
Command Result : 0 (Success)
```

ntls ipcheck enable

Enable client source IP address validation by NTLS upon an NTLA client connection. The checking is enabled by default. The best security of your client-to-SA link is in force when ipcheck remains enabled. Keep it enabled if you have do not have network address translation (NAT) between your client(s) and the SafeNet Network HSM appliance, or other situations where the ipcheck interferes with operation.

Syntax

ntls ipcheck enable

Example

```
lunash:>ntls ipcheck enable
```

```
NTLS client source IP validation enabled
```

```
Command Result : 0 (Success)
```

ntls ipcheck show

Display the current NTLS Client source IP validation configuration.

Syntax

ntls ipcheck show

Example

```
lunash:>ntls ipcheck show
```

```
NTLS client source IP validation : Enable
```

```
Command Result : 0 (Success)
```

ntls show

Display the NTLS binding network device or hostname/IP address.

Syntax

ntls show

Example

```
[myLuna] lunash:>ntls show
```

```
NTLS bound to network device: eth0 IP Address: "152.22.11.96" (eth0)
```

```
Command Result : 0 (Success)
```


ntls sslopsall

Perform all NTLS SSL operations in hardware. NTLS uses SSL to secure communication between the appliance and a client application. The **ntls sslopsall** command configures NTLS to perform all of the SSL operations on the HSM instead of in memory on the motherboard of the SafeNet appliance.

Syntax

ntls sslopsall

Example

```
lunash:>ntls sslopsall
```

```
Command Result : 0 (Success)
```

ntls sslopsrsa

Perform all NTLS SSL RSA operations in hardware. NTLS uses SSL to secure communication between the appliance and a client application. The **ntls sslopsrsa** command configures NTLS to perform the RSA operations of SSL on the HSM instead of in memory on the motherboard of the SafeNet appliance.

Syntax

ntls sslopsrsa

Example

```
lunash:>ntls sslopsrsa
```

```
Command Result : 0 (Success)
```

ntls tcp_keepalive

Access commands that allow you to view or configure the NTLS TCP keep alive settings.

Syntax

ntls tcp_keepalive

set
show

Parameter	Shortcut	Description
set	-se	Configure the NTLS TCP keep alive settings. See " ntls tcp_keepalive set " on the next page.
show	-sh	Display the current NTLS TCP keep alive configuration. See " ntls tcp_keepalive show " on page 246.

ntls tcp_keepalive set

Configure the NTLS TCP keep alive settings.

Note: TCPKeepAlive is a TCP stack option, available at the LunaClient, and at the SafeNet Network HSM appliance. For SafeNet purposes, it is controlled via an entry in the Chrystoki.conf /crystoki.ini file on the LunaClient, and in an equivalent file on SafeNet Network HSM. For SafeNet HSM 6.1 and newer, a fresh client software installation includes an entry "TCPKeepAlive=1" in the "LunaSA Client" section of the configuration file Chrystoki.conf (Linux/UNIX) or crystoki.ini (Windows). Config files and certificates are normally preserved through an uninstall, unless you explicitly delete them.



As such, if you update (install) LunaClient software where you previously had an older LunaClient that did not have a TCPKeepAlive entry, one is added and set to "1" (enabled), by default. In the case of update, if TCPKeepAlive is already defined in the configuration file, then your existing setting (enabled or disabled) is preserved.

On the SafeNet Network HSM appliance, where you do not have direct access to the file system, the TCPKeepAlive= setting is controlled by the lunash:> **ntls TCPKeepAlive set** command.

The settings at the appliance and the client are independent. This allows a level of assurance, in case (for example) a firewall setting blocks in one direction..

Syntax

ntls tcp_keepalive set -idle <seconds> -interval <seconds> -probes <number>

Parameter	Shortcut	Description
-idle	-id	Specifies the TCP keep alive idle timer, in seconds. This is the duration between two keep alive transmissions in idle condition. Range: 10 to 10,000 Default: 10
-interval	-in	Specifies the TCP keep alive interval time, in seconds. This is the duration between any two successive keep alive transmissions. Range: 10 to 360 Default: 10
-probes	-p	Specifies the number of retries to attempt if a transmission is not acknowledged. Default is 2. Range: 1 to 30 Default: 2

Example

```
lunash:>ntls tcp_keepalive set -idle 20 -interval 12 -probes 3
```

NOTICE: The NTLS service must be restarted for new settings to take effect.

Command Result : 0 (Success)

ntls tcp_keepalive show

Display the NTLS TCP keep alive configuration.

Note: TCPKeepAlive is a TCP stack option, available at the LunaClient, and at the SafeNet Network HSM appliance. For SafeNet purposes, it is controlled via an entry in the Chrystoki.conf /crystoki.ini file on the LunaClient, and in an equivalent file on SafeNet Network HSM. For SafeNet HSM 6.1 and newer, a fresh client software installation includes an entry "TCPKeepAlive=1" in the "LunaSA Client" section of the configuration file Chrystoki.conf (Linux/UNIX) or crystoki.ini (Windows). Config files and certificates are normally preserved through an uninstall, unless you explicitly delete them.



As such, if you update (install) LunaClient software where you previously had an older LunaClient that did not have a TCPKeepAlive entry, one is added and set to "1" (enabled), by default. In the case of update, if TCPKeepAlive is already defined in the configuration file, then your existing setting (enabled or disabled) is preserved.

On the SafeNet Network HSM appliance, where you do not have direct access to the file system, the TCPKeepAlive= setting is controlled by the lunash:> **ntls TCPKeepAlive set** command.

The settings at the appliance and the client are independent. This allows a level of assurance, in case (for example) a firewall setting blocks in one direction.

Syntax

ntls tcp_keepalive show

Example

```
lunash:>ntls tcp_show
```

NTLS TCP keepalive is configured as follows :

```
TCP_KEEPIIDLE : default (10)
TCP_KEEPIINTVL : default (10)
TCP_KEEPCNT : default (2)
```

ntls threads

Access commands that allow you to view or configure the NTLS worker threads settings.

Syntax

ntls threads

set
show

Parameter	Shortcut	Description
set	se	Configure the NTLS Datapath and CMD processor worker threads. See " ntls threads set " on the next page.
show	sh	Show the NTLS worker threads settings. See " ntls threads show " on page 249.

ntls threads set

Configure the NTLS Datapath and CMD processor worker threads. Data path threads control how many worker thread pairs are to be used to process inbound and outbound socket events. The default value of this configuration parameter is 5, which means there will be five inbound worker threads for reading data off the TLS/TCP socket and five outbound worker threads for writing data to the TLS/TCP socket. This implies that the data path can handle five different NTLS clients' data from five different sockets in parallel. In general, this configuration value should be increased if NTLS must service a high number of client NTLA connections.

The CMD Processor worker thread controls how many threads are used in the command processor to submit HSM requests to the K6 HSM key card inside the appliance. The default value of this configuration parameter (30 threads) is the ideal setting. Lowering this value will result in lower maximum throughput of some crypto operations, such as RSA Sign.

Above the "sweet spot" number of threads, increasing the threads does not increase throughput. The higher the number, the more task switching occurs within the process - this is the major trade-off that limits the number of threads that can provide optimum performance.

This command must be set individually and manually on all members of an HA group. Mixing settings across group members is untested and unsupported.



CAUTION: To achieve maximum performance with SafeNet Network HSM 5.x and 6.x, client applications must spawn 30+ threads. The 10 threads indicated for legacy SafeNet Network HSM 4.x is not sufficient to stress the current product.

Syntax

ntls threads set [-datapath <number>] [-cmdprocessor <number>]

Parameter	Shortcut	Description
-cmdprocessor	-c	Specifies the number of CMD processor threads. Range: 1 to 70
-datapath	-d	Specifies the number of data path threads. Range: 1 to 15

Example

```
lunash:>ntls threads set -datapath 10
NOTICE: The NTLS service must be restarted for new settings to take effect.
Command Result : 0 (Success)
```

```
lunash:>ntls threads set -cmdprocessor 60
NOTICE: The NTLS service must be restarted for new settings to take effect.
Command Result : 0 (Success)
```


ntls threads show

Display the configured number of NTLS worker threads that can run simultaneously.

Syntax

ntls threads show

Example

```
lunash:>ntls threads show
```

```
Data path      : default (5) threads  
CMD processor  : default (50) threads.  
Command Result : 0 (Success)
```

ntls timer

Access commands that allow you to view or configure the NTLS receive timeout setting.

Syntax

ntls timer

set

show

Parameter	Shortcut	Description
set	se	Configure the NTLS receive timeout value. See "ntls timer set" on the next page.
show	sh	Display the NTLS receive timeout value. See "ntls timer show" on page 252.

ntls timer set

Set the number of seconds that NTLS will wait before kicking out an unauthorized connection to port 1792. Default 20 secs. Setting this parameter does not require an NTLS restart.

This command must be set individually and manually on all members of an HA group. Mixing settings across group members is untested and unsupported.

Syntax

ntls timer set -timeout <seconds>

Parameter	Shortcut	Description
-timeout	-t	Specifies the timeout, in seconds. Range: 10 to 300 Default: 20

Example

```
lunash:>ntls timer set 11
```

```
Command Result : 0 (Success)
```

ntls timer show

Display the configured NTLS timeout period.

Syntax

ntls timer show

Example

```
lunash:>ntls timer show
```

```
NTLS Receive timeout timer is set to default at 20 seconds
```

```
Command Result : 0 (Success)
```

package

Access commands that allow you to manage secure package updates. Use these commands after you have copied the package files to the SafeNet Network HSM, using the **scp** utility.

Syntax

package

deletefile
erase
list
listfile
update
verify

Parameter	Shortcut	Description
deletefile	d	Delete a package file. See "package deletefile" on the next page.
erase	e	Delete a package . See "package erase" on page 255.
list	l	List the installed packages. See "package list" on page 256.
listfile	listf	List the uninstalled package files. See "package listfile" on page 257.
update	u	Update the package file. See "package update" on page 258.
verify	v	Verify the package file. See "package verify" on page 259.

package deletefile

Deletes a named package file from the SafeNet appliance.

Syntax

package deletefile <package_name>

Parameter	Shortcut	Description
<package_name>		Specifies the name of the package you want to delete.

Example

```
lunash:>package deletefile lunasa_update-5.1.0-8.spkg
```

```
Command Result : 0 (Success)
```

package erase

Erase the specified package. This command attempts to erase/uninstall the specified package from the SafeNet appliance. Package erase will not work if other packages are dependant upon the specified package. Only packages marked as "SOFTWARE" can be erased.



CAUTION: This command should never be used without the assistance or at the direction of SafeNet technical support staff.

Syntax

package erase <package_name>

Parameter	Shortcut	Description
<package_name>		Specifies the name of the package to erase. For a list of package names, use the package list command. (Do not specify version numbers of packages. For example, for package_abc.1.0.2-0, specify only package_abc).

Example

Please contact SafeNet for an example of this command.

package list

Display the list of all installed packages on the system. Packages are divided into system packages (cannot be erased) and software packages.

Syntax

package list

Example

```
lunash:> package list
RPM LIST (SYSTEM)
-----
  filesystem-2.4.0-2.el5.centos
  termcap-5.5-1.20060701.1
  kernel-headers-2.6.18-164.el5
  centos-release-notes-5.4-4
  glibc-common-2.5-42
    rootfiles-8.1-1.1.1
  compat-libgcc-296-2.96-138
  glibc-2.5-42
  |
  |
(long list - too long to include here)
RPM LIST (SOFTWARE)
-----
Command Result : 0 (Success)
```


package listfile

Displays a list of package files that have been transferred to the SafeNet Network HSM and are available to install.

Syntax

package listfile

Example

```
lunash:> package listfile
Zero package files were found.
lunash:> package listfile
803066 Dec 09 2010 13:22 fwupK53-4.6.1-0.i386.spkg
9538 Mar 19 2012 09:10 lunasa_update-5.1.0-25PEDTimeout.spkg
```

package update

Update an existing secure package on the SafeNet appliance. All packages from SafeNet are signed and encrypted and come with an authcode that must be provided to decrypt and use the package. Use this command to update packages that can be seen when using the “package listfile” command. You can verify a package with the “package verify” command.

It is strongly recommended that your SafeNet appliance be connected to an Uninterruptable Power Supply (UPS) when you run this command. There is a small chance that a power failure during the update command could leave the SafeNet appliance in an unrecoverable condition.

If a version of this package is already installed, an error occurs, for example:

```
Command failed: RPM update for original filename (fwupK6_real-6.0.9-RC1.i386.rpm)
```



Note: You might need to log into the HSM before you run this command.

Syntax

```
package update <filename> -authcode <authcode> [-des3] [-useevp]
```

Parameter	Shortcut	Description
-authcode	-a	Specifies the secure package authorization code provided by SafeNet with the secure package. The authorization code is checked during package installation to ensure that the package was encrypted and signed by SafeNet.
-des3	-d	Use DES3 Cipher for backward compatibility with older secure package updates.
-useevp	-u	Use the OpenSSL EVP (Digital EnVeloPe library) API to decrypt and validate the update package in appliance software without need for HSM login. If this option is not specified, the default action is to refer update verification to the HSM.
<filename>		Specifies the name of the package to update. The new version of the package must have been transferred to the SafeNet appliance using scp .

Example

```
lunash:>hsm login
Please attend to the PED...
Command Result : 0 (Success)
```

```
lunash:>package update fwupK6_real-6.0.9-RC1.spkg -authcode pHLJtJ7/xJXS/FFK
Command succeeded: decrypt package
Command succeeded: verify package certificate
Command succeeded: verify package signature
Preparing packages for installation...
fwupK6_real-6.0.9-RC1
Command Result : 0 (Success)
```

package verify

Verifies that the specified package is from SafeNet, and that the provided authcode is correct.

Syntax

package verify <package_name> **authcode** <authcode>

Option	Shortcut	Parameter	Description
.	.	<filename>	
-authcode	-a	<authcode>	Specifies the secure package authorization code provided by SafeNet with the secure package
-des3	-d	.	Use DES3 Cipher

Example

```
lunash:>package verify lunasa_update-6.1.0-24.spkg -a qxTDRMNFFMJHYHsR
```

```
Command succeeded: decrypt package
Command succeeded: verify package certificate
Command succeeded: verify package signature
Preparing packages for installation...
```

```
Command Result : 0 (Success)
```

partition

Commands to manage partitions on the HSM.

Note: Administration of partitions, using the **partition** commands below, applies to application partitions that are owned by the HSM SO.



Partitions that have their own Security Officer (PPSO) are administered from a Client computer using an appropriate application, with appropriate authentication. (You can supply your own application, or use the provided lunacm tool. See "Using LunaCM" on page 1.)

Syntax

partition

activate
 backup
 changepolicy
 changepw
 clear
 create
 createuser
 deactivate
 delete
 list
 policyTemplate
 resetpw
 resize
 restore
 setlegacydomain
 show
 showcontent
 showpolicies

Parameter	Shortcut	Description
activate	a	Activate a partition by caching its PED key data, allowing clients to authenticate with their partition password only. See "partition activate" on the next page.
backup	b	Backup the partition to a backup token. See "partition backup" on page 263.
changepolicy	changeпо	Change the policies for a partition. See "partition changepolicy" on page 267.
changepw	changepw	Change a partition password. See "partition changepw" on page 268.

Parameter	Shortcut	Description
clear	cl	Delete all objects on a partition. See "partition clear" on page 270.
create	create	Create an HSM partition on the HSM. See "partition create" on page 271.
createuser	createu	Create a Crypto-User on a partition. See "partition createuser" on page 276
deactivate	dea	De-activate a partition by de-caching its PED key data, so that clients can no longer authenticate with their partition password only. See "partition deactivate" on page 278.
delete	del	Delete an HSM partition from the HSM. See "partition delete" on page 279.
list	l	Display a list of the accessible partitions. See "partition list" on page 280.
policyTemplate	rese	Reset a Partition Owner's password. See "partition policytemplate" on page 281.
resetpw	rese	Reset a Partition Owner's password. See "partition resetpw" on page 290.
resize	resi	Resizes the storage space for a partition. See "partition resize" on page 292.
restore	rest	Restore the HSM partition contents from PCMCIA backup token. See "partition restore" on page 294.
setlegacydomain	se	Set the legacy cloning domain on a partition. See "partition setlegacydomain" on page 304.
show	sh	Display information for a partition. See "partition show" on page 305.
showcontents	showc	Display a list of the objects on a partition. See "partition showcontents" on page 307.
showpolicies	showp	Displays the policy configuration for a partition. See "partition showpolicies" on page 308.

partition activate

Caches a Partition's PED key data. Clients can then connect, authenticate with their Partition password, and perform operations with Partition objects, without need for hands-on PED operations each time. Activation/caching endures until explicitly terminated with **partition deactivate** or appliance power off. If a Partition has not been activated, then each access attempt by a Client causes a login call which initiates a SafeNet PED operation (requiring the appropriate black PED Key). Unattended operation is possible while the Partition is activated.

This action applies to an application partition that is administratively owned by the HSM SO. The HSM SO cannot activate or deactivate an application partition that has its own Security Officer (SO). For SafeNet application partitions that have Partition SO, the partition is accessed via the client connection, and administrative actions like activation and deactivation use commands in the **lunacm** utility while the partition in question is the currently selected slot.

Activation and auto-activation policies

If you wish to activate a Partition, then Partition policy number 22 "Allow activation" must be set to "On" for the named partition. Use **partition showPolicies** to view the current settings and use **partition changePolicy** to change the setting. The policy shows as "Off" or "On", but to change the policy you must give a numeric value of "0" or "1".

If you wish to automatically activate a Partition, then Partition policy number 23 "Allow auto-activation" can be set to "On" for the named partition. Use **partition showPolicies** to view the current settings and use **partition changePolicy** to change the setting. The policy shows as "Off" or "On", but to change the policy you must give a numeric value of "0" or "1". Autoactivation caches the activation authentication data in battery-backed memory so that activation can persist/recover following a shutdown/restart or a power outage up to 2 hours duration. If Partition Policy 23 is set, then partition activation includes autoactivation. If Partition Policy 23 is not set, then partition activation persists only while the appliance is powered on, and requires your intervention to reinstate activation following a shutdown or power outage.

Syntax

partition activate **-partition** <name> [**-password** <password>] [**-cu**]

Parameter	Shortcut	Description
-partition	-par	Specifies the name of the HSM partition to activate. Obtain the HSM partition name by using the partition list command.
-password	-pas	Specifies the password needed to access the HSM partition. This is the partition string provided by the SafeNet PED when you created the partition - associated with the partition Owner black PED Key. For password-authenticated HSMs, it is the entire authentication for the named partition. If you omit the password in the command, you are prompted for it.
-cu	-c	Perform the task as the Crypto-User. This option is required if you have invoked the Crypto Officer / Crypto User roles and are performing this action as the Crypto User.

Example

```
lunash:> partition activate -partition b1
```

```
Please enter the password for the partition:
```

```
> *****
```

```
Luna PED operation required to activate partition on HSM - use User or Partition Owner (black) PED key.
```

```
'partition activate' successful
```

```
Command Result : 0 (Success)
```

partition backup

Backup the HSM partition contents to a backup HSM. This command copies the contents of a HSM Partition to a special SafeNet backup token. The backup token is initialized during this process. The user is prompted to verify if this destructive command should continue (in case the token has any data on it).

The backup token is initialized to the same access control level as the HSM Partition being backed up.

This command requires the HSM's domain (string or PED Key) and the HSM Partition's Owner password (or PED Key and Partition password). If you chose MofN (values for N and for M greater than 1) at partition creation time, then quantity M of the black key are needed.

Because this is a destructive command (it initializes the backup token), the user is given the option to proceed/quit before continuing. The SafeNet appliance admin may wish to use the **token show** command to see the label of a token before issuing this destructive command.

Password-authenticated HSMs

If the passwords and domain aren't provided via the command line, the user is interactively prompted for them. User input is echoed as asterisks. The user is asked to confirm new token Admin and user passwords (if needed).

PED-authenticated HSMs

SafeNet Network HSM with Trusted Path Authentication backup tokens do not use text Partition Passwords in addition to PED Keys – they require only the PED Keys. Also, the passwords and blue/black PED Keys used for the backup token need not be the same as those used with the HSM.

Syntax

partition backup **-partition** <name> **-tokenPar** <name> **-serial** <serialnum> [**-password** <password>] [**-tokenSOPwd** <password>] [**-tokenPw** <password>] [**-domain** <domain>] [**-defaultdomain**] [**-add**] [**-replace**] [**-force**]

Option	Shortcut	Parameter	Description
-add	-a	.	Add objects to the named backup HSM partition. Incremental backup (append). If any of the source objects already exist on the target partition, they are not duplicated, and they are not overwritten. The system flags an error and continues to the next object. This parameter is mandatory for pre-existing target partitions, if -replace is not specified. Note: This parameter is not needed if the target partition did not already exist and is being created by the partition backup command. If the target partition exists, then there is no default - you must specify whether to add/append to whatever exists on the partition, or overwrite it.
-defaultdomain	-de	.	Use the default domain string. Deprecated. This is retained only for benefit of customers who have previously used the default domain, and are constrained to continue using it, until they create new objects on an HSM with a proper domain. For security reasons, avoid this option.

Option	Shortcut	Parameter	Description
-domain	-do	<domain>	<p>Specifies the text domain string that was used when creating the partition. This parameter is optional on password-authenticated HSMs. It is ignored on PED-authenticated HSMs. See the notes, below, for more information.</p> <p>Note 1: For SafeNet HSMs with Trusted Path Authentication, the red PED Key used for initializing the partition on the source HSM must be used for the backup HSM, as well. Ensure that a new domain is not created on the PED Key by answering NO to the SafeNet PED question “Do you wish to create a new domain?”.</p> <p>Note 2: When you call for a cloning operation (such as backup or restore), the source HSM transfers a single object, encrypted with the source domain. The target HSM then decrypts and verifies the received blob.</p> <p>If the verification is successful, the object is stored at its destination – the domains are a match. If the verification fails, then the blob is discarded and the target HSM reports the failure. Most likely the domain string or the domain PED Key, that you used when creating the target partition, did not match the domain of the source HSM partition. The source HSM moves to the next item in the object list and attempts to clone again, until the end of the list is reached.</p> <p>This means that if you issue a backup command for a source partition containing several objects, but have a mismatch of domains between your source HSM partition and the backup HSM partition, then you will see a separate error message for every object on the source partition as it individually fails verification at the target HSM.</p> <p>Note 3: If you do not specify a domain in the command line when creating a partition (partition create command), then you are prompted for it.</p> <p>The character string that you type at the prompt becomes the domain for the partition.</p> <p>When you run the partition backup command, you are again prompted for a domain for the target partition on the backup HSM. You can specify a string at the command line, or omit the parameter at the command line and specify a string when prompted. The domain that you apply to a backup HSM must match the domain on your source HSM partition.</p>
-force	-f	.	Force the action without prompting.
-partition	-par	<partition name>	The name of the HSM partition from which all data/key objects are backed up. Obtain the HSM partition name by using the partition list command.
-password	-pas	<partition password>	The application partition Crypto Officer's text password to be used

Option	Shortcut	Parameter	Description
			for login. If you do not supply this value on the command line, you are prompted for it. This parameter is mandatory for password-authenticated HSMs. It is ignored for PED-authenticated HSMs.
-replace	-r	.	Clone objects to the target partition, overwriting whatever might already exist there. This parameter is mandatory for pre-existing target partitions, if -add is not specified. Note: This parameter is not needed if the target partition did not already exist and is being created by the partition backup command. If the target partition exists, then there is no default - you must specify whether to add/append to whatever exists on the partition, or overwrite it.
-serial	-s	<serial number>	Specifies the backup token serial number.
-tokenPar	-tokenpa	<backup partition name>	This is the name of the partition on the backup HSM, to which the backup objects are to be cloned. If a partition exists on the backup HSM with the name that you provide, here, that partition is selected. If no partition exists with the supplied label, then one is created. Note: Do not begin your partition label with a numeral. This can later be misinterpreted by some commands as a slot number, rather than a text label, resulting in failure of the command.
-tokenPw	-tokenpw	<backup partition password>	The token user password . This is the equivalent of Crypto Officer password for the backup partition on the Backup HSM. This parameter is mandatory for password-authenticated HSMs. It is ignored for PED-authenticated HSMs.
-tokenSOPwd	-tokenS	<backup HSM SO password>	Token Admin (or Security Officer) password. This is the password to be used as login credential for the Backup HSM's security officer. The token SO password need not be the same password or PED Key as used for the source HSM Admin.

Example

```
lunash:> partition backup -partition j1 -password userpin
```

```
CAUTION: Are you sure you wish to initialize the backup
HSM named:
backuphsm
Type 'proceed' to continue, or 'quit' to quit now.
> proceed
```

```
Luna PED operation required to initialize backup token - use blue PED Key.
Luna PED operation required to login to backup token - use blue PED Key.
Luna PED operation required to generate cloning domain on backup token - use red PED Key.
Luna PED operation required to generate partition backup space - use black PED Key.
```

Luna PED operation required to login to partition backup space - use black PED Key.
Luna PED operation required to login to partition - use black PED Key.
Key handle 10 cloned from source to target.
Key handle 11 cloned from source to target.
'partition backup' successful.

partition changepolicy

Change HSM Admin-modifiable elements from the HSM partition policy. This command toggles or alters a policy of the specified HSM partition. Only certain portions of the policy set are HSM Admin-modifiable. These policies and their current values can be determined using the **partition showpolicies** command. After a successful policy change, the command displays the new policy value.

This command must be executed by the SafeNet appliance “admin” logged in to the HSM as HSM Admin. If the HSM Admin is not authenticated, a “user not logged in” error message is returned.

This command can set a policy on or off, or set it to a certain value if it is a numerical policy. Policies can be set only to more restrictive values than the associated capability. You cannot relax a policy to a less-restrictive setting than the associated capability value. See the Capabilities and Policies section of this Reference Help, for a list of all partition capabilities/policies and their meanings.

Syntax

partition changePolicy **-partition** <name> **-policy** <policynumber> **-value** <numvalue> [**-force**]

Option	Shortcut	Parameter	Description
-partition	-pa	<partition name>	Specifies the name of the HSM Partition on which to alter policies. HSM Partition names are obtained with the partition -list command.
-policy	-po	<policy number>	Specifies the policy code of the policy to alter. Policy descriptions and codes are obtained with the partition showpolicies command.
-value	-v	<policy value>	Specifies the value that should be assigned to the specified policy. When specifying values for an on/off type policy, use '1' for on and '0' for off.
-force	-f	.	Force the option. Useful for scripting.

Example

```
lunash:> partition changePolicy -partition c1 -policy 22 -value 0
```

```
'partition changePolicy' successful.
```

```
Policy "Allow activation" is now set to: 0
```

partition changepw

Change the password for the named HSM Partition. This command sets a partition password or PED Key. For PED-authenticated HSMs, this command invokes the SafeNet PED to change the value on the black PED Key and on the named partition, as well as allowing you to change the partition password (the challenge secret) supplied by the SafeNet PED, and used by client applications. For password-authenticated HSMs, this command changes the partition password.



Note: The option to "generate a new random challenge" is present for the Partition SO, only. Crypto Officer and Crypto User are allowed to change their challenge secrets to a string input via keyboard. If a new, random or default challenge is desired (generated by SafeNet PED), it is triggered by the SO using the "partition resetPw command."

Syntax

partition changePw **-partition** <partition_name> [**-cu**] [**-newpw** <new_partition_password>] [**-oldpw** <old_partition_password>]

Option	Short	Parameter	Description
-cu	-c	.	Use this option if you have invoked the Crypto Officer / Crypto User role distinctions, and wish to change passwords as Crypto User.
-newpw	-n	<new password>	Specifies the new partition password.
-oldpw	-o	<old password>	Specifies the existing partition password, to be replaced by the new password.
-partition	-p	<partition name>	Specifies the partition name. HSM Partition names are obtained with the partition -list command.

Example

Example if you provide **-oldpw** and **-newpw** at the command line:

```
lunash:> partition changePw -partition mypar1 -oldpw XxPJNH4bY439FNPE -newpw MyPa$$w0rd
```

Luna PED operation required to activate partition on HSM - use User or Partition Owner (black) PED Key.

```
'partition -changePw' successful.
```

```
Command Result : 0 (Success)
```

Example for Partition SO, if you do not provide **-oldpw** and **-newpw** at the command line:

```
lunash:> partition changePw -partition mylegacypar1
```

Which part of the partition password do you wish to change?

1. change partition owner (black) PED key data
2. generate new random password for partition owner
3. specify a new password for the partition owner

```
4. both options 1 and 2
0. abort command
Please select one of the above options: 3

> *****
Please enter the password for the partition:
>*****

Please enter a new password for the partition:
>*****

Luna PED operation required to activate partition on HSM - use User or Partition Owner (black)
PED Key

'partition -changePw' successful.

Command Result : 0 (Success)
```

Example for Partition Crypto Officer or Crypto User, if you do not provide -oldpw and -newpw at the command line:

```
lunash:> partition changePw -partition mypar1

Which part of the partition password do you wish to change?
1. change partition owner (black) PED key data
2. specify a new password for the partition owner
0. abort command
Please select one of the above options: 3

> *****
Please enter the password for the partition:
>*****

Please enter a new password for the partition:
>*****

Luna PED operation required to activate partition on HSM - use User or Partition Owner (black)
PED Key

'partition -changePw' successful.

Command Result : 0 (Success)
```

partition clear

Delete all objects on a partition. Because this is a destructive command, the user is prompted to proceed/quit before the erasure occurs.

For password-authenticated HSMs, if the password isn't entered on the command line, the user will be prompted for it interactively. User input will be echoed as asterisks.

For PED-authenticated HSMs, PED action is required, and the Partition Owner PED Key (black) is requested. Any password provided at the command line is ignored. However, if a PED PIN was specified when the HSM partition was created, that PED PIN must be entered at the PED keypad.

Syntax

partition clear **-partition** <partition_name> [**-password** <password>] [**-force**]

Option	Shortcut	Parameter	Description
-force	-f	.	Force the action without prompting.
-partition	-par	<partition name>	Specifies the name of the partition from which all objects are to be erased. To obtain a list of partitions, use the partition list command.
-password	-pas	<partition password>	The password to be used as login credential by the partition's user. This parameter is required on password-authenticated HSMs.

Example

```
lunash:>partition clear -partition mylegacypar1
```

```
Please enter the user password for the partition:
> *****
```

```
CAUTION: Are you sure you wish to clear the partition named:
          mylegacypar1
          This will ERASE all the objects on the partition.
```

```
Type 'proceed' to clear the partition, or 'quit'
to quit now.
> proceed
```

```
'partition clear' successful.
```

```
Command Result : 0 (Success)
```

partition create

Create an HSM partition on the HSM. This command creates and initializes a new HSM Partition on the HSM. To use the HSM partition create command you must be logged in to the HSM as HSM Admin (a.k.a. the SO).

By default, no clients are granted access to a new HSM Partition. The SafeNet appliance “admin” can run the **client assignPartition** command to give a registered client access to created HSM Partitions.

For password-authenticated HSMs, if the password is not provided via the command line, the user is interactively prompted for it. Input is echoed as asterisks, and user is asked for password confirmation. This creates the Crypto Officer role.

For PED-authenticated HSMs, PED action is required, and a partition Crypto Officer PED Key (black) is imprinted. Any password provided at the command line is ignored.



CAUTION: When labeling HSMs or partitions, never use a numeral as the first, or only, character in the name/label. Token backup commands allow slot-number or label as identifier, which can lead to confusion if the label is a string version of a slot number. For example, if the token is initialized with the label "1" then the user cannot use the label to identify the target for purposes of backup, because VTL parses "1" as signifying the numeric ID of the first slot rather than as a text label for the target in whatever slot it really occupies (the target is unlikely to be in the first slot), so backup fails.



Note: If you create a partition with name "somename" and do not specify a label, the label by default is "somename". If later you attempt to create another partition, and specify a label of "somename" the operation fails with LUNA_RET_ATTRIBUTE_VALUE_INVALID because the first partition has that label (even though you never explicitly set it to that string).

Partition and PKI token naming

When creating partitions on the HSM, a check is performed to ensure that the new partition's name is unique (on that HSM). However, this check does not extend to any token HSMs that might be inserted in connected card-reader slots. Therefore, it is possible to create a partition on the main, on-board HSM that has the same name as a PKI token in one of the reader slots. Avoid this by running the command **token pki listdeployed**, and checking the output, before invoking the **partition create** command.

Cloning is a repeating atomic action

When you call for a cloning operation (such as backup or restore), the source HSM transfers a single object, encrypted with the source domain. The target HSM then decrypts and verifies the received blob.

If the verification is successful, the object is stored at its destination – the domains are a match. If the verification fails, then the blob is discarded and the target HSM reports the failure. Most likely the domain string or the domain PED Key, that you used when creating the target partition, did not match the domain of the source HSM partition. The source HSM moves to the next item in the object list and attempts to clone again, until the end of the list is reached.

This means that if you issue a backup command for a source partition containing several objects, but have a mismatch of domains between your source HSM partition and the backup HSM partition, then you will see a separate error message for every object on the source partition as it individually fails verification at the target HSM.

Domain matching and the default domain

If you do not specify a domain in the command line when creating a partition (**partition create** command), then you are prompted for it.

If you type a character string at the prompt, that string becomes the domain for the partition.

When you run the partition backup command, you are again prompted for a domain for the target partition on the backup HSM. You can specify a string at the command line, or omit the parameter at the command line and specify a string when prompted. Otherwise press [Enter] with no string at the prompt to apply the default domain. The domain that you apply to a backup HSM must match the domain on your source HSM partition.

Syntax

partition create **-partition** <name> [**-haspso**] [**-label** <label>] [**-password** <password>] [**-domain** <domain>] [**-defaultdomain**] [**-defaultchallenge**] [**-size** <size>] [**-allfreestorage**] [**-force**]

Note: A partition **name** or a partition **label** can include any of the following characters :

```
!#$%()'*,.-/0123456789:=@ABCDEFGHIJKLMN0PQRSTUVWXYZ[]^_
abcdefghijklmnopqrstuvwxyz~
```

No spaces, unless you wish to surround the name or label in double quotation marks every time it is used.

No question marks, no double quotation marks within the string.

Minimum name or label length is 1 character. Maximum is 32 characters.

Valid characters that can be used in a **password** or in a cloning **domain**, when entered via LunaSH [¹]), are:

```
!#$%'*+,-./0123456789:=?@ABCDEFGHIJKLMN0PQRSTUVWXYZ[]^_
abcdefghijklmnopqrstuvwxyz~
```



(the first character in that list is the space character)

Invalid or problematic characters, not to be used in passwords or cloning domains are "&";<>\'|()

Valid characters that can be used in a **password** or in a cloning **domain**, when entered via *lunacm*, are:

```
!"#$%&\'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMN0PQRSTUVWXYZ[\]^_
`abcdefghijklmnopqrstuvwxyz{|}~
```

(the first character in that list is the space character)

Minimum password length is 7 characters; maximum is 255 characters in *lunash* or *lunacm*.

Minimum domain string length is 1 character; maximum domain length is 128 characters via *lunash*. No arbitrary maximum domain string length is enforced for domain strings entered via *lunacm*, and we have successfully input domain strings longer than 1000 characters in testing.



[¹] LunaSH on the SafeNet Network HSM has a few input-character restrictions that are not present in LunaCM, run from a client host. It is unlikely that you would ever be able to access via LunaSH a partition that received a password or domain via LunaCM, but the conservative approach would be to avoid the few "invalid or problematic characters" generally.

Names and labels have an additional restriction, in that you should avoid a leading space.

Option	Shortcut	Parameter	Description
-allfreestorage	-a	.	Create the partition using all the remaining, unused storage space on the HSM. After creating a partition with this option, you cannot create another without first deleting or resizing partitions to regain some space.
-defaultdomain	-defaultd	.	This "partition create" command, and the "setLegacyDomain" command both have the "-defaultdomain" option, which allows the use of the same default domain that would have been applied if you had just pressed [Enter] when prompted for a cloning domain with earlier SafeNet HSM versions. The current and future HSM versions do not allow you to omit providing a domain, unless you include this "-defaultdomain" option, which is an insecure choice and generally not recommended. The "-defaultdomain" option applies to Password-authenticated HSMs only. For PED-authenticated HSMs the PED always prompts for a physical PED Key and either reuses the value on the key that you insert, or generates a new value and imprints it on the PED Key.
-defaultchallenge	-defaultc	.	Specifies that the default Partition Challenge Secret 'PASSWORD' be used when the partition is created. This is useful when deploying many partitions automatically, for fully-automated testing, and when using Crypto Command Center (CCC) to create an HA group, which requires all member partitions to share the same password. The challenge password 'PASSWORD' is reserved, so it is not possible to change an existing challenge password to 'PASSWORD'.

Option	Shortcut	Parameter	Description
-domain	-do	<domain>	Specifies the cloning domain to be used when this partition needs to clone objects to/from another HSM, such as during backup/restore, or if the partition is included as a member of an HA group. For PED authenticated SafeNet Network HSM, the domain is either generated on the HSM and imprinted on a red PED Key, or is accepted from an existing domain PED Key and imprinted on the HSM (for this partition).
-force	-f	.	Force the partition creation with no prompting - you are still prompted by SafeNet PED, if yours is a PED authenticated HSM.
-haspso	-h	.	Create the partition with its own security officer. See " About Configuring an Application Partition with Its Own SO " on page 1 in the <i>Configuration Guide</i> .
-label	-l	<partition-label>	Specifies a label for the partition. This option does not apply to partitions with SO. If you include this option with the -haspso, it will be ignored. A partition label is applied later by the Partition SO, using the client-side lunacm tool.
-partition	-par	<partition-name>	Specifies the name to assign to the HSM Partition. The name must be unique among all HSM Partitions on the HSM.
-password	-pas	<password>	Specifies the password to be used as login credential by the password-authenticated HSM partition's Crypto Officer or client application. If you omit the password from the command, for a password-authenticated SafeNet Network HSM, you are prompted for it. For PED authenticated SafeNet Network HSM, the password is not needed as input - one is generated and presented to you by the PED - and the black PED Key becomes the administrative authentication (for activation, etc.)
-policyTemplate	-po	<template-name>	The named template (which must already exist) is read, and the policy values for the new partition are set according to the

Option	Shortcut	Parameter	Description
			template. If a template by that name is not found, the command fails.
-size	-s	<size>	Specifies the size, in bytes, to allocate to the partition, from the remaining storage available on the HSM. If you specify a size, the HSM attempts to use it after calculating overhead requirements. If you do not specify a size, the HSM creates the partition with the default size, as determined by your purchased options for number of partitions and total storage on the HSM.

Example

```
lunash:> partition -create -par alreadyused
```

```
Error: 'partition -create' failed. (1006)
```

```
Error: The name you provided for the new partition is not unique. Partitions must have unique names.
```

```
Use 'partition -list' for a list of existing partition names.
```

```
lunash:> partition -create -par b1
```

```
Please enter password
```

```
Please enter domain
```

```
Please enter size
```

```
'partition -create' successful.
```

partition createuser

The Crypto Officer creates a Crypto User on a partition.

For SafeNet HSM with firmware 6.22.0 and newer, this command applies to either PED-authenticated or Password-authenticated HSMs. The Crypto Officer's password is included as authentication before specifying the password that is assigned to the new Crypto User.

For older SafeNet HSM firmware versions, this command applied only to PED-authenticated HSMs, and had only the "-partition" option.

Syntax

partition createuser **-partition** <partition_name> [**-coPassword** <password>] [**-cuPassword** <password>] [**-defaultChallenge**]

Parameter	Shortcut	Description
-partition	-p <name>	The name of the HSM partition on which to create the Crypto User. Obtain the HSM partition name by using the partition list command.
-coPassword	-co <password>	The password of the Crypto Officer, when creating a Crypto User on a password-authenticated HSM.
-cuPassword	-cu <password>	The Crypto User password, being assigned when creating a Crypto User on a password-authenticated HSM.
-defaultChallenge	-d .	For PED-authenticated HSM, sets the default challenge string "PASSWORD", instead of getting a random, 16-character string from SafeNet PED.

Example creating Crypto User on password-authenticated HSM partition

```
lunash:> partition createuser -partition b1 -coPassword somePWstring -cuPassword someother-PWstring
```

```
'partition createuser' successful.
```

Example creating Crypto User on PED-authenticated HSM partition

For PED-authenticated HSM, the **partition createuser** dialog directs you to the PED for two separate PED Key operations:

- The first time, you provide the black PED Key for authentication by the Crypto Officer that was created when the application partition was first initialized.
- The second time, if you have the newer label sheets that include gray stickers, you provide a PED Key labeled with a gray sticker; otherwise, just use a black-labeled PED Key, but be sure to identify that key as Crypto User, to prevent confusing it with the black Crypto Officer key.

```
[MyLunaSA2] lunash:>partition show
```

```
Partition Name: P1SA2
```

```

Partition SN:                356654569703
Partition Label:             P1SA2
Crypto Officer PIN To Be Changed: no
Crypto Officer Challenge To Be Changed: no
Crypto Officer Locked Out:   no
Crypto Officer Login Attempts Left: 10
Crypto Officer is activated:  no
Crypto User is not initialized.
Legacy Domain Has Been Set:  no
Partition Storage Information (Bytes): Total=2087864, Used=0, Free=2087864
Partition Object Count:      0

```

Command Result : 0 (Success)

```
[MyLunaSA2] lunash:>partition createuser -partition P1SA2 -d
```

```

Please enter Crypto Officer password for the partition:
> *****

```

Warning: This partition will be created with default challenge password.

Luna PED operation required to activate partition on HSM - use Partition Owner (black) PED key.

Luna PED operation required to create user on partition - use Crypto User (black) PED key.

'partition createuser' successful.

Command Result : 0 (Success)

```
[MyLunaSA2] lunash:>partition show
```

```

Partition Name:                P1SA2
Partition SN:                356654569703
Partition Label:             P1SA2
Crypto Officer PIN To Be Changed: no
Crypto Officer Challenge To Be Changed: no
Crypto Officer Locked Out:   no
Crypto Officer Login Attempts Left: 10
Crypto Officer is activated:  no
Crypto User PIN To Be Changed: no
Crypto User Challenge To Be Changed: yes
Crypto User Locked Out:     no
Crypto User Login Attempts Left: 10
Crypto User is activated:    no
Legacy Domain Has Been Set:  no
Partition Storage Information (Bytes): Total=2087864, Used=0, Free=2087864
Partition Object Count:      0

```

Command Result : 0 (Success)

```
[MyLunaSA2] lunash:>
```

partition deactivate

De-cache a partition's PED key data. clients cannot authenticate to the partition with just their partition password. While the partition is deactivated, each client attempt initiates a login call, which invokes SafeNet PED operation with the appropriate black PED Key.

Syntax

partition deactivate **-partition** <partitionname> [**-cu**]

Option	Shortcut	Parameter	Description
-partition	-p	<name>	The name of the HSM partition to delete. Obtain the HSM partition name by using the partition list command.
-cu	-c	.	Perform the task as Crypto User

Example

```
lunash:> partition deactivate -partition b1
```

```
'partition deactivate' successful.
```

partition delete

Delete an HSM Partition from the HSM. This command deletes a HSM Partition on the HSM and frees the license used by the HSM Partition. To use the partition delete command you must be logged in to the HSM as HSM Admin.

Syntax

partition delete -partition <partition_name> [**-force**]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-partition	-p	The name of the HSM partition to deactivate. Obtain the HSM partition name by using the partition list command.

Example

```
lunash:> partition delete -partition b1
```

```
CAUTION: Are you sure you wish to delete the partition named:
b1
Type 'proceed' to delete the partition, or 'quit'
to quit now.
> quit
'partition delete' aborted.
```

```
lunash:> partition delete -partition b1
CAUTION: Are you sure you wish to delete the partition named:
b1
Type 'proceed' to delete the partition, or 'quit'
to quit now.
> proceed
'partition delete' successful.
```

partition list

Display a list of the accessible partitions on the HSM, including the number of objects on the partition, the partition size, and the used and free space.



Note: The HSM firmware needs approximately 2K bytes of memory to manage each partition and data objects in it. To avoid you having to calculate the exact memory space available for data storage -- with you deducting the memory used by internal data structures --the "partition list" command adjusts the memory size attributes for you. Thus, the total available memory reported by "partition list" will be different than that reported by "token backup show" and "token backup partition list."

Syntax

partition list

Example

```
lunash:> partition list
Storage (bytes)
Partition      Name      Objects  Total   Used    Free
700022006     mypar2   0         102701    0     102701
700022008     mypar1   3         102701  1800   100901
Command Result : 0 (Success)
```


partition policytemplate

Commands to manage and edit partition policy templates.

Note: Administration of partition policy templates, using the **partition policytemplate** commands below, applies to application partitions that are owned by the HSM SO.



Partitions that have their own Security Officer (PPSO) are administered from a Client computer using an appropriate application, with appropriate authentication. (You can supply your own application, or use the provided lunacm tool. See "Using LunaCM" on page 1.)

Syntax

partition policyTemplate

change
create
delete
list
load
save
show

Parameter	Shortcut	Description
change	ch	Modify policy settings. See "partition policytemplate change " on the next page.
create	create	Create an HSM partition on the HSM. See "partition policytemplate create " on page 283.
delete	d	Delete an HSM partition from the HSM. See "partition policytemplate delete " on page 285.
list	li	Display a list of the accessible partitions. See "partition policytemplate list" on page 286.
load	lo	Reset a Partition Owner's password. See "partition policytemplate load " on page 287.
save	sa	Reset a Partition Owner's password. See "partition policytemplate save " on page 288.
show	sh	Display information for a partition. See "partition policytemplate show " on page 289.

partition policytemplate change

Modify a policy's initial value and destructive settings within the partition policy template currently being edited. This change is done independently of any partition when the edit is performed. The change becomes accessible when the template is saved. The change becomes active if the template is applied to an application partition.

Syntax

partition policytemplate change -policy <policynumber> **-value** <[numvalue] or "on" | "off"> [-on<string>] [-off<string>]

Option	Shortcut	Parameter	Description
-off	-off	<partition name>	Specifies the name of the HSM Partition on which to alter policies. HSM Partition names are obtained with the partition -list command.
-on	-on	<partition name>	Specifies the name of the HSM Partition on which to alter policies. HSM Partition names are obtained with the partition -list command.
-policy	-p	<policy number>	Specifies the policy code of the policy to alter. Policy descriptions and codes are obtained with the partition showpolicies command.
-value	-v	<policy value>	Specifies the value that should be assigned to the specified policy. When specifying values for an on/off type policy, use '1' for on and '0' for off, or just type the text "on" or "off". Either is acceptable.

Example

```
lunash:> partition policyTemplate change -policy 22 -value 0 -on non-destructive -off non-destructive
```

Description	Destructive			
	Value	Code	Off-To-On	On-To-Off
Allow activation	1	22	No	No

Command Result : 0 (Success)

partition policytemplate create

Create an application partition policy template in memory (for editing). To preserve the template, it must be saved separately by the **partition policyTemplate save** command.

Partition policy template naming

A policy template must have a unique name, which can be a character string. Acceptable characters are:

-.0123456789ABCDEFGHIJKLMNOPQRSTUVWXYZ_abcdefghijklmnopqrstuvwxy

Minimum length is a single character.

Maximum length is 20 characters.

Syntax

partition create -policytemplate[-force]

Option	Shortcut	Parameter	Description
-force	-f	.	Force the partition creation with no prompting - you are still prompted by SafeNet PED, if yours is a PED authenticated HSM.

Example

```
lunash:> partition policyTemplate create
```

Description	Value	Code	Destructive	
			Off-To-On	On-To-Off
Allow private key cloning	1	0	Yes	Yes
Allow private key wrapping	0	1	Yes	Yes
Allow private key unwrapping	1	2	No	No
Allow private key masking	0	3	Yes	Yes
Allow secret key cloning	1	4	Yes	Yes
Allow secret key wrapping	1	5	No	No
Allow secret key unwrapping	1	6	No	No
Allow secret key masking	0	7	Yes	Yes
Allow multipurpose keys	1	10	No	No
Allow changing key attributes	1	11	No	No
Ignore failed challenge responses	1	15	No	No
Operate without RSA blinding	1	16	Yes	Yes
Allow signing with non-local keys	1	17	No	No
Allow raw RSA operations	1	18	No	No
Max failed user logins allowed	10	20	No	No
Allow high availability recovery	1	21	No	No
Allow activation	0	22	No	No
Allow auto-activation	0	23	No	No
Minimum pin length (inverted: 255 - min)	248	25	No	No
Maximum pin length	255	26	No	No
Allow Key Management Functions	1	28	No	No

Perform RSA signing without confirmation	1	29	No	No
Allow Remote Authentication	1	30	No	No
Allow private key unmasking	1	31	No	No
Allow secret key unmasking	1	32	No	No
Allow RSA PKCS mechanism	1	33	No	No
Allow CBC-PAD (un)wrap keys of any size	1	34	No	No
Allow private key SFF backup/restore	0	35	No	No
Allow secret key SFF backup/restore	0	36	No	No
Force Secure Trusted Channel	0	37	No	No

```
Type 'proceed' to continue, or 'quit'
to quit now.
> proceed
```

Successfully created and loaded the new partition policy template.

Use 'partition policyTemplate change' to edit the template and
'partition policyTemplate save' to save the template once you have applied all necessary
changes.

Command Result : 0 (Success)

partition policytemplate delete

Delete partition policy template.

Syntax

partition policytemplate delete [-all] [-name<template-name>] [-force]

Option	Shortcut	Parameter	Description
-all	-a	.	Delete all templates
-name	-n	<template name>	Specifies the name of the application partition policy template to delete. Application partition policy template names are obtained with the partition policyTemplate -list command.
-force	-f	.	Force the option. Useful for scripting.

Example

```
lunash:> partition policyTemplate delete -name MyTemplate01
```

```
Are you sure you wish to delete partition policy template: MyTemplate01
```

```
    Type 'proceed' to continue, or 'quit'
    to quit now.
    > proceed
```

```
Successfully deleted partition policy template: MyTemplate01
```

```
Command Result : 0 (Success)
```

partition policytemplate list

List the partition policies templates created by the HSM administrator and which template is currently being modified.

Syntax

partition policytemplate list

Example

```
lunash:> partition policytemplate list
```

Name	Description
bigbank1	Eastern region servers
bigbank2	Western region

```
Current Loaded Partition Policy Template: bigbank3
```

```
Command Result : 0 (Success)
```

Each row represents a template. The first column is the template name. Each template name is unique and is specified by the user when creating the template. The second column is a description of each template. You are also reminded if a partition policy template is currently being modified.

partition policytemplate load

Load a partition policy template for modification

Syntax

partition policytemplate load -name<template-name> [-force]

Option	Shortcut	Parameter	Description
-name	-n	<template name>	Specifies the name of the application partition policy template to load, for editing/altering policies. Application partition policy template names are obtained with the partition policyTemplate list command.
-force	-f	.	Force the option. Useful for scripting.

Example

```
lunash:> partition policyTemplate load -name c1
```

Successfully loaded c1 partition policy template for editing.

Command Result : 0 (Success)

partition policytemplate save

Save the partition policy template modifications. This command saves a newly created partition policy template from editing memory, or saves a previously created partition policy template that was loaded for editing and re-saving.

Syntax

partition policytemplate save [-name<template-name>] [-description<string>] [-force]

Option	Shortcut	Parameter	Description
-name	-n	<template name>	Specifies the name of the HSM Partition on which to alter policies. HSM Partition names are obtained with the partition -list command.
-description	-d	<comment>	An identifying comment for your own reference, when managing application partition policy templates.
-force	-f	.	Force the option. Useful for scripting.

Example

```
lunash:> partition policyTemplate save -name mytemplate01 -description "This one, not the other one."
```

```
mytemplate01 successfully saved.
```

```
Command Result : 0 (Success)
```


partition policytemplate show

Display the destructiveness and value of each policy from the specified partition policy template name.

Syntax

partition policyTemplate show [-name <template_name>]

Option	Shortcut	Parameter	Description
-name	-n	<template_name>	Specifies the name of the template for which to display information. If no template is named, the command shows the template that is currently loaded for editing, or tells you that no template is being modified.

Example

```
lunash:> partition show -policytemplate mytemplate
Partition Policy Template: <template name>
```

Description	Value	Code	Destructive	
			Off-To-On	On-To-Off
=====	=====	=====	=====	=====
Allow private key cloning	On	0	No	No
Allow private key wrapping	Off	1	No	No
Allow private key unwrapping	On	2	No	No
Allow secret key cloning	On	4	No	No
Allow secret key wrapping	On	5	No	No
Allow secret key unwrapping	On	6	No	No
Allow multipurpose keys	On	10	No	No
Allow changing key attributes	On	11	No	No
Ignore failed challenge responses	Off	15	No	No
Operate without RSA blinding	On	16	No	No
Allow signing with non-local keys	On	17	No	No
Allow raw RSA operations	On	18	No	No
Max failed user logins allowed	3	20		
Allow high availability recovery	On	21	No	No
Allow activation	On	22	No	No
Allow auto-activation	On	23	No	No
Minimum pin length (inverted: 255 - min)	248	25		
Maximum pin length	255	26		
Allow Key Management Functions	On	28	No	No
Perform RSA signing without confirmation	On	29	No	No
Allow Remote Authentication	On	30	No	No
Allow private key unmasking	On	31	No	No
Allow secret key unmasking	On	32	No	No
Allow RSA PKCS mechanism	On	33	No	No
Allow CBC-PAD (un)wrap keys of any size	On	34	No	No
Allow private key SFF backup/restore	On	35	No	No
Allow secret key SFF backup/restore	On	36	No	No
Force Secure Trusted Channel	Off	37	No	No

Command Result : 0 (Success)

partition resetpw

Resets a Partition Owner's password, or PED key data.

The HSM Admin must be logged in to execute this command. This command is available only if the destructive HSM policy "SO can reset partition PIN" is ON.

This command detects firmware level and determines whether an action is allowed.

For password-authenticated HSMs, if the new password is not provided via the command line, the user is interactively prompted for it. Input is echoed as asterisks, and the user is asked for password confirmation.

For PED-authenticated HSMs, PED action is required, and a Partition Owner PED Key (black) is imprinted. Any password provided at the command line is ignored.



Note: Reset the black PED Key before resetting the challenge. If not, the system presents an error

"Error: The HSM security policy does not allow the HSM Administrator to reset the password for partitions."

which should say something more informative like :

"Please reset black PED Key first before resetting challenge."

This command does not perform a 'pure' password reset, which would simply apply a default until the partition owner changed it to a suitable replacement. Doing so would create a security hole in a system deployed in a production environment. Instead, the HSM SO assigns a secure password and must inform the partition owner of the change, and must pass along the new password (whether that is a text string or a new PED Key).

Syntax

```
partition resetPw -partition <partitionname> [-cu] [-password <password>] [-newpw <password>]
```

Parameter	Shortcut	Description
-cu	-c	Perform task as Crypto-User
-newpw	-n	The new password to be used as the HSM Partition Owner's login credential to the named HSM Partition. Requires the SO to be logged in. This parameter is mandatory for password-authenticated HSMs. It is ignored on PED-authenticated HSMs. If you omit the password from the command line, you are prompted for it (password-authenticated HSMs).
-password	-pas	Partition Password
-partition	-par	Specifies the name of the HSM Partition ID for which to reset the Owner's PIN. Obtain the HSM partition name by using the partition list command.

Example

```
lunash:> partition resetpw -partition mypar
```

Which part of the partition password do you wish to change?

1. change Partition Owner (black) PED key data
2. generate new random password for partition owner
3. use default password for partition owner
4. both options 1 and 2
5. change crypto-user (black) PED key data
6. generate new random password for crypto-user
7. use default password for crypto-user
0. abort command

Please select one of the above options: 1

Luna PED operation required to reset partition PED key data - use User or Partition Owner (black) PED key.

'partition resetPw' successful.

Command Result : (Success)

partition resize

Resizes the storage space of the named partition.

You must be logged into the HSM administrative partition to run this command.

Syntax

partition resize -partition <name> [-size <size>] [-allfreestorage][-force]

Parameter	Shortcut	Description
-allfreestorage	-a	Resize this partition using all the remaining, unused storage space on the HSM. After creating or resizing a partition with this option, you cannot create another without first deleting or resizing partitions to regain some space.
-force	-f	Force the action without prompting.
-partition	-par	Specifies the name of the partition.
-size	-s	Specifies the size, in bytes, to allocate to the partition, from the remaining storage available on the HSM. If you specify a size (rather than the other option, -allfreestorage), the HSM attempts to use it after calculating overhead requirements that consider your purchased options for number of partitions and total storage remaining on the HSM.

Example

```
lunash:>partition show
Partition SN:      700022008
Partition Name:    mypartition
Activated:         yes
Auto Activation:   yes
Partition Owner Locked Out:    no
Partition Owner PIN To Be Changed:    no
Partition Owner Login Attempts Left:  10 before Owner is Locked Out
Crypto-User Locked Out:    no
Crypto-User Challenge To Be Changed:  no
Crypto-User Login Attempts Left:    10 before Crypto User is Locked Out!
Legacy Domain Has Been Set:    no
Partition Storage Information (Bytes):    Total=102701, Used=0, Free=102701
Partition Object Count:    2
Command Result : 0 (Success)
```

```
lunash:> partition resize -partition mypartition -allfreestorage
```

```
WARNING !!!
All all remaining free storage space will be allocated to this partition.
No more partitions can be created once this command is complete.
If you are sure you wish to continue, then type 'proceed'; otherwise type 'quit'
> proceed
Proceeding...
'partition resize' successful.
```

Command Result : 0 (Success)

```
[sa5] lunash:>partition show
Partition SN: 700022008
Partition Name: mypartition
Activated: yes
Auto Activation: yes
Partition Owner Locked Out: no
Partition Owner PIN To Be Changed: no
Partition Owner Login Attempts Left: 10 before Owner is Locked Out
Crypto-User Locked Out: no
Crypto-User Challenge To Be Changed: no
Crypto-User Login Attempts Left: 10 before Crypto User is Locked Out!
Legacy Domain Has Been Set: no
Partition Storage Information (Bytes): Total=2094996, Used=0, Free=2094996
Partition Object Count: 2
```

Command Result : 0 (Success)

```
lunash:> partition resize -partition mypartition -size 102701
```

'partition resize' successful.

Command Result : 0 (Success)

```
lunash:>partition show
Partition SN: 700022008
Partition Name: mypartition
Activated: yes
Auto Activation: yes
Partition Owner Locked Out: no
Partition Owner PIN To Be Changed: no
Partition Owner Login Attempts Left: 10 before Owner is Locked Out
Crypto-User Locked Out: no
Crypto-User Challenge To Be Changed: no
Crypto-User Login Attempts Left: 10 before Crypto User is Locked Out!
Legacy Domain Has Been Set: no
Partition Storage Information (Bytes): Total=102701, Used=0, Free=102701
Partition Object Count: 2
Command Result : 0 (Success)
```

partition restore

Restores the contents of an HSM partition from a backup token. This command securely moves contents from a backup token to an HSM partition on the HSM. The SafeNet Network HSM administrator executing this command has the option of replacing the objects existing on the HSM partition or adding to them. Note that if objects are added to the HSM partition it is possible that the same object may exist twice on the HSM partition with two different object handles.

Because replacing data in a partition is destructive, if this option is selected the user is prompted to proceed/quit.

If the passwords are not provided via the command line, the user is prompted for them interactively. User input is echoed as asterisks.

Syntax

partition restore [-partition name -password <password>] [-tokenpw <password>] [-add] [-replace [-force]]

Parameter	Shortcut	Description
-add	-a	Use this switch (no argument) to specify that the data objects on the backup token shall be added to those already existing on the specified HSM Partition. Note that even objects on the backup token that are identical to objects in the HSM Partition will be added to the HSM Partition when specifying this switch; thus it is possible that the HSM Partition may have two identical objects on it as a result of this command. You must specify either -add or -replace .
-force	-f	Force the action without prompting.
-partition	-par	Specifies the name of the HSM partition from which all data/key objects are to be restored. Obtain the HSM partition name by using the partition -list command.
-password	-pas	Specifies the HSM Partition Owner's (or Crypto Officer's) text password. This parameter is mandatory for password-authenticated HSMs. It is ignored on PED-authenticated HSMs.
-replace	-r	Use this switch (no argument) to erase any data/key objects existing on the specified HSM Partition before loading the keys from the backup token. You must specify either -add or -replace .
-serial	-s	Specifies the token serial number.
-tokenpar	-tokenpa	Specifies the token partition name.
-tokenpw	-tokenpw	The password for the user on the backup token. If this is a Secure Authentication & Access Control token, then SafeNet PED is required and any value provided here is ignored. If you do not enter this parameter you will be prompted for it. This parameter is mandatory for password-authenticated HSMs. It is ignored on PED-authenticated HSMs.

Example

The following example is for a PED-authenticated HSM

```
lunash:> partition restore -partition j1 -password userpin -replace
CAUTION: Are you sure you wish to erase all objects in the
partition named:
j1
Type 'proceed' to continue, or 'quit' to quit now.
> proceed
Luna PED operation required to login to partition backup space - use black PED Key.
Luna PED operation required to login to partition - use black PED Key.
Key handle 8 cloned from source to target.
Key handle 9 cloned from source to target.
'partition restore' successful.
```

partition sff

Access commands to perform backup and restore operations to-and-from a Small Form-Factor Backup device.

Syntax

partition sff

backup
clear
list
restore
showContents

Parameter	Shortcut	Description
backup	b	SFF Backup a Partition or Objects. See " partition sff backup " on the next page .
clear	c	Clear SFF backup token contents. See " partition sff clear " on page 298 .
list	l	Get SFF backup token information. See " partition sff list " on page 299 .
restore	r	Restore Partition or Objects. See " partition sff restore " on page 300 .
showContents	s	Get SFF backup token objects information. See " partition sff showContents " on page 302 .

partition sff backup

Perform backup of a Partition, or selected partition objects, onto a Small Form-Factor Backup token.

Syntax

partition sff backup [-partition <name> -label <label> [-password <password>] [-objects <name>] [-force]

Options	Short	Parameter	Description
-partition	-par	<partition name>	Partition Name
-password	-pas	<partition password>	Partition Password
-label	-l	<partition label>	Partition Label
-objects	-o	<list of objects>	Objects List
-force	-f	.	Force the action

Example 1 - Backup partition contents

```
lunash:>partition sff backup -partition P1 -label SFFToken1
```

```
WARNING: This operation will backup partition objects to SFF backup token !!!
```

```
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed
Proceeding...
```

```
Please enter the password for the HSM user partition:
```

```
> *****
```

```
Luna PED operation required to activate partition on HSM - use Partition Owner (black) PED key.
```

```
Operation in progress, please wait.
```

```
(1/4): Backing up object with handle 43... Success!
(2/4): Backing up object with handle 41... Success!
(3/4): Backing up object with handle 42... Success!
(4/4): Backing up object with handle 22... Success!
```

```
Backup Complete.
```

```
4 objects have been backed up to token with label SFFToken1
on the backup device
```

```
'partition sff backup' successful.
```

```
Command Result : 0 (Success)
```


Example 2 - Backup specific objects

```
lunash:>partition sff backup -partition P1 -label SFFToken1 -objects 22,41
```

```
WARNING: This operation will backup partition objects to SFF backup token !!!
```

```
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed  
Proceeding...
```

```
Please enter the password for the HSM user partition:
```

```
> *****
```

```
Luna PED operation required to activate partition on HSM - use Partition Owner (black) PED key.
```

```
Operation in progress, please wait.
```

```
(1/2): Backing up object with handle 22... Success!
```

```
(2/2): Backing up object with handle 41... Success!
```

```
Backup Complete.
```

```
2 objects have been backed up to token with label SFFToken1  
on the backup device
```

```
'partition sff backup' successful.
```

```
Command Result : 0 (Success)
```

partition sff clear

Clears Small Form-Factor Backup token contents.

Syntax

partition sff clear [-partition <name> -label <label> [-password <password>] [-objects <name>] [-force]

Options	Short	Parameter	Description
-partition	-par	<partition name>	Target partition name
-password	-pas	<partition password>	Partition Password
-force	-f	.	Force the action

Example

```
lunash:>partition sff clear -partition P1
```

```
Please enter the password for the HSM user partition:
```

```
> *****
```

```
Luna PED operation required to activate partition on HSM - use Partition Owner (black) PED key.
```

```
'partition sff clear' successful.
```

```
Command Result : 0 (Success)
```

```
.
```

partition sff list

Gets Small Form-Factor Backup token information.

Syntax

partition sff list [-partition <name> -label <label>] [-password <password>] [-objects <name>] [-force]

Parameter	Parameter	Description
-partition	-par <name>	Target partition name
-password	-pas <password>	Partition Password
-force	-f .	Force the action

Example

```
lunash:>partition sff list -partition P1
```

```
  Please enter the password for the HSM user partition:
  > *****
```

Luna PED operation required to activate partition on HSM - use Partition Owner (black) PED key.

```
  Partition:      SFFToken1
  Object Type:   Partition
  Object UID:    54030000bc00000779980800
```

```
'partition sff list' successful.
```

```
Command Result : 0 (Success)
```

partition sff restore

Restore partition objects from a Small Form-Factor Backup token.

Syntax

partition sff restore [-partition <name>] [-password <password>] [-objects <name>] [-force]

Option	Short	Parameter	Description
-partition	-par	<partition name>	Target partition name
-password	-pas	<partition password>	Partition Password
-objects	-o	<list of objects to restore>	Objects as a comma-delimited List
-force	-f	.	Force the action

Example 1 - Restore entire content of SFF backup token

```
lunash:>partition sff restore -partition P1
```

```
WARNING: This operation will restore objects from the SFF backup token !!!
```

```
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed
Proceeding...
```

```
Please enter the password for the HSM user partition:
```

```
> *****
```

```
Luna PED operation required to activate partition on HSM - use Partition Owner (black) PED key.
```

```
Restoring objects...
```

```
(1/4) Restoring object 00-3a050000bc00000779980800-053a4591b-
c955e4e4767ecc220462c1505d982861bb48765d8632798cd7e3ec2...Success - Handle 22
(2/4) Restoring object 00-39050000bc00000779980800-
ab8f192c2b3d6b14bbcd16f4a8ec841c285041c7d657c4a35e6f865898e591d2...Success - Handle 41
(3/4) Restoring object 00-b90000071f00000079980800-fc980e771f1ed79785cb-
bc484fdf7d00e468b1587af83145f38d0560fa181d58...Success - Handle 42
(4/4) Restoring object 00-b90000071e00000079980800-26b55de31c7d54b2010b-
f2b236abfc11796ab2991ad41018bd61ead9e219e659...Success - Handle 45
```

```
'partition sff restore' successful.
```

```
Command Result : 0 (Success)
```

Example 2 - Restore specific objects from SFF backup token

```
lunash:>partition sff restore -partition P1 -objects 1,4
```

```
WARNING: This operation will restore objects from the SFF backup token !!!
```

```
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed
```

```
Proceeding...
```

```
Please enter the password for the HSM user partition:
```

```
> *****
```

```
Luna PED operation required to activate partition on HSM - use Partition Owner (black) PED key.
```

```
Restoring objects...
```

```
(1/2) Restoring object 00-3a050000bc00000779980800-053a4591b-  
c955e4e4767ecc220462c1505d982861bb48765d8632798cd7e3ec2...Success - Handle 22  
(2/2) Restoring object 00-b90000071e0000079980800-26b55de31c7d54b2010b-  
f2b236abfc11796ab2991ad41018bd61ead9e219e659...Success - Handle 41
```

```
'partition sff restore' successful.
```

```
Command Result : 0 (Success)
```

partition sff showContents

Gets Small Form-Factor Backup token objects information.

Syntax

partition sff showContents [-partition <name> [-password <password>] [-quick]

Parameter	Parameter	Description
-partition	-par <name>	Target partition name
-password	-pas <password>	Partition Password
-quick	-q .	Show the contents in abbreviated format



Note: For full, detailed enumeration of SFF token content, the objects must be decrypted and enumerated within the secure boundary of the HSM. To run **partition sff showContents**, free space must be available within the target partition, equivalent to the size of the largest object on the SFF token.

Example

```
lunash:>partition sff showContents -partition P1
```

```
Please enter the password for the HSM user partition:
> *****
```

Luna PED operation required to activate partition on HSM - use Partition Owner (black) PED key.

```
Listing SFF Backup contents...
```

```
Found 4 backup objects:
```

```
Partition:      SFFToken1
Object Type:    Partition
Object UID:     54030000bc00000779980800
```

```
Label:          Generated DES3 Key
Index:          1
Object Type:    Public Key
Object UID:     3a050000bc00000779980800
Fingerprint:   053a4591bc955e4e4767ecc220462c1505d982861bb48765d8632798cd7e3ec2
```

```
Label:          Generated AES Key
Index:          2
Object Type:    Public Key
Object UID:     39050000bc00000779980800
Fingerprint:   ab8f192c2b3d6b14bbbed16f4a8ec841c285041c7d657c4a35e6f865898e591d2
```

```
Label:          Generated RSA Private Key
Index:          3
```

Object Type: Symmetric Key
Object UID: b90000071f00000079980800
Fingerprint: fc980e771f1ed79785cbbc484fdf7d00e468b1587af83145f38d0560fa181d58

Label: Generated RSA Public Key
Index: 4
Object Type: Private Key
Object UID: b90000071e00000079980800
Fingerprint: 26b55de31c7d54b2010bf2b236abfc11796ab2991ad41018bd61ead9e219e659

'partition sff showContents' successful.

Command Result : 0 (Success)

partition setLegacyDomain

Set the legacy cloning domain on a partition.

The legacy cloning domain for password-authenticated HSM partitions is the text string that was used as a cloning domain on the legacy token HSM whose contents are to be migrated to the SafeNet Network HSM partition.

The legacy cloning domain for PED-authenticated HSM partitions is the cloning domain secret on the red PED key for the legacy PED authenticated token HSM whose contents are to be migrated to the SafeNet Network HSM partition.

Your target HSM partition has, and retains, whatever modern partition cloning domain was imprinted (on a red PED Key) when the partition was created. This command takes the domain value from your legacy HSM's red PED Key and associates that with the modern-format domain of the partition, to allow the partition to be the cloning (restore...) recipient of objects from the legacy (token) HSM.

As well, you cannot migrate objects from a password-authenticated token/HSM to a PED-authenticated HSM partition, and you cannot migrate objects from a PED authenticated token/HSM to a password-authenticated HSM partition. Again, this is a security provision.

See "Legacy Domains and Migration" on page 1 in the *Administration Guide* for a description and summary of the possible combinations of source (legacy) tokens/HSMs and target (modern) HSM partitions and the disposition of token objects from one to the other.



Note: You can use this command repeatedly to associate different legacy domains to the current partition's cloning domain. This allows you to consolidate content from multiple legacy HSMs onto a single partition of a modern HSM.

Syntax

partition setLegacyDomain -partition <name> [-password <password>] [-domain <domain>]

Parameter	Shortcut	Description
-domain	-d	Specifies the legacy cloning domain name. This parameter is required on password-authenticated HSMs. It is ignored on PED-authenticated HSMs.
-partition	-par	Specifies the partition name.
-password	-pas	Specifies the partition password. This parameter is required on password-authenticated HSMs. It is ignored on PED-authenticated HSMs.

Example

```
lunash:> partition setLegacyDomain -partition <name>
```

The PED prompts for the legacy red domain PED Key (notice mention of "raw data" in the PED message).

Command result: Success!

partition show

Display a detailed list of accessible partitions with relevant information. This command outputs information about one or all partitions on the SafeNet appliance's key card (the HSM). It is not necessary to be logged in as HSM Admin to execute this command.

For each partition that is present, the following information is displayed:

- partition serial number
- partition name
- primary authentication status (activated or not)
- partition auto-authenticate status
- user lock-out status
- HSM serial number
- HSM label
- HSM firmware version

Syntax

partition show [-partition <partition_name>] [-all]

Option	Shortcut	Parameter	Description
-partition	-p	<partition_name>	Specifies the name of the partition for which to display information. By default information about all partitions is shown. Obtain the partition name by using the partition list command.
-all	-a	.	All partitions

Example

```
lunash:> partition show -partition mypar
Partition SN:

65010001
Partition Name:

mypar1
Activated:

yes
Auto Activation:

yes
Partition Owner Locked Out:

no
Partition Owner PIN To Be Changed:

no
Partition Owner Login Attempts Left:
```

10 before Owner is Locked Out
Crypto-User Locked Out:

no
Crypto-User Challenge To Be Changed:

no
Crypto-User Login Attempts Left:

10 before Crypto User is Locked Out!
Legacy Domain Has Been Set:

no
Partition Storage Information (Bytes):

Total=102701, Used=1800, Free=100901
Partition Object Count:

3
Command Result : 0 (Success)

partition showcontents

Display a list of all objects on a partition. The partition name, serial number and total object count is displayed. For each object that is found, the label and object type are displayed.

For SafeNet Network HSM with Password Authentication, if the HSM Partition Owner password isn't entered on the command line, the user is prompted for it interactively. User input is echoed as asterisks.

For SafeNet Network HSM with PED [Trusted Path] Authentication, PED action is required, and the Partition Owner PED Key (black) is requested. Any password provided at the command line is ignored. However, if a PED PIN was specified when the HSM Partition was created, that PED PIN must be entered at the PED keypad.

Syntax

partition showcontents **-partition** <partition_name> [-cu] **-password** <password>

Parameter	Shortcut	Description
-cu	-c	Perform task as Crypto-User. This option is required if you are using the Crypto-Officer/Crypto-User distinction.
-partition	-par	Specifies the name of the HSM Partition for which contents are to be displayed. Obtain the HSM Partition name by using the partition -list command.
-password	-pas	The HSM Partition Owner password or partition challenge password.

Example

```
lunash:> partition showContents -partition c1
```

```
Please enter the password for the partition:
```

```
> *****
```

```
Partition Name: c1
```

```
Partition SN: 150520009
```

```
Storage (Bytes): Total=102701, Used=1800, Free=100901
```

```
Number objects: 3
```

```
Object Label: Generated DES Key
```

```
Object Type: Symmetric Key
```

```
Object Label: Generated RSA Public Key
```

```
Object Type: Public Key
```

```
Object Label: Generated RSA Private Key
```

```
Object Type: Private Key
```

```
Command Result : 0 (Success)
```

partition showpolicies

Display the policy vectors of the specified HSM partition. This command displays the specified HSM Partition's policies and capabilities. The output is arranged into three sections

1. Capabilities
2. Write-restricted policies
3. HSM Admin-modifiable policies.

Each policy's current setting is displayed. For modifiable policies, the policy code is displayed for use when changing policies.

Syntax

partition showpolicies -partition <partition_name> [-configonly]

Parameter	Shortcut	Description
-configonly	-c	List only the HSM Admin-modifiable HSM partition policies.
-partition	-p	The name of the partition for which policies will be displayed. To obtain a list of partitions, use the partition list command.

Example

```
lunash:> partition showPolicies -partition mypartition
```

```
Partition Name: mypartition
Partition Num: 65038002
```

The following capabilities describe this HSM Partition and can never be changed.

Description	Value
=====	=====
Enable private key cloning	Allowed
Enable private key wrapping	Disallowed
Enable private key unwrapping	Allowed
Enable private key masking	Disallowed
Enable secret key cloning	Allowed
Enable secret key wrapping	Allowed
Enable secret key unwrapping	Allowed
Enable secret key masking	Disallowed
Enable multipurpose keys	Allowed
Enable changing key attributes	Allowed
Enable PED use without challenge	Allowed

Allow failed challenge responses	Allowed
Enable operation without RSA blinding	Allowed
Enable signing with non-local keys	Allowed
Enable raw RSA operations	Allowed
Max failed user logins allowed	10
Enable high availability recovery	Allowed
Enable activation	Allowed
Enable auto-activation	Allowed
Minimum pin length (inverted: 255 - min)	248
Maximum pin length	255
Enable Key Management Functions	Allowed
Enable RSA Signing without confirmation	Allowed
Enable Remote Authentication	Allowed
Enable private key unmasking	Allowed
Enable secret key unmasking	Allowed

The following policies are set due to current configuration of this partition and may not be altered directly by the user.

Description	Value
=====	=====
Challenge for authentication not needed	False

The following policies describe the current configuration of this partition and may be changed by the HSM Security Officer.

Description	Value	Code
=====	=====	=====
Allow private key cloning	On	0
Allow private key unwrapping	On	2
Allow secret key cloning	On	4
Allow secret key wrapping	On	5
Allow secret key unwrapping	On	6
Allow multipurpose keys	On	10
Allow changing key attributes	On	11
Ignore failed challenge responses	On	15
Operate without RSA blinding	On	16

Allow signing with non-local keys	On	17
Allow raw RSA operations	On	18
Max failed user logins allowed	10	20
Allow high availability recovery	On	21
Allow activation	Off	22
Allow auto-activation	Off	23
Minimum pin length (inverted: 255 - min)	248	25
Maximum pin length	255	26
Allow Key Management Functions	On	28
Perform RSA signing without confirmation	On	29
Allow Remote Authentication	On	30
Allow private key unmasking	On	31
Allow secret key unmasking	On	32
Command Result : 0 (Success)		

service

Access commands that allow you to view or manage services.

Syntax

service

list
restart
start
status
stop

Parameter	Shortcut	Description
list	l	Display a list of the services. See "service list" on the next page.
restart	r	Restart a service. See "service restart" on page 313.
start	star	Start a service. See "service start" on page 315.
status	stat	Display the status for a service. See "service status" on page 316.
stop	sto	Stop a service. See "service stop" on page 317.

service list

Lists the services that the user can start, stop, restart, or for which the user can request status information.

Syntax

service list

Example

```
lunash:>service list
```

The following are valid SafeNet Network HSM service names:

```
cbs      - HSM callback service
htl      - Host trust link service
lsta     - Luna SNMP trap agent service
network  - Network service (Needed for ntl, ssh and scp)
ntl      - Network trust link service
ntp      - Network time protocol service
snmp     - SNMP agent service
ssh      - Secure shell service (Needed for ssh and scp)
stc      - Secure trusted channel service
syslog   - Syslog service
sysstat  - System status monitoring (controls LCD)
```

```
Command Result : 0 (Success)
```


service restart

Restart a service on the SafeNet appliance. Services require restarting if their configurations have changed. For example, after changing any network settings using the **network** commands, you should restart the network service to ensure the new settings take affect. Also, after regenerating the server certificate with the `sysconf regencert` command, you must restart the NTLS service so that the new certificate is used for the NTLA. For a list of services that can be restarted, use the **service list** command.

Restarting a service isn't always the same as doing a service stop followed by a service start. If you restart the network service while connected to the SafeNet appliance via the network (ssh), you will not lose your connection (assuming no changes were made that would cause a connection loss). However, if you were to stop the network service, you would immediately lose your connection, and you would need to log in via the local console to start the service again. The same applies for the sshd service.



Note: It can sometimes take slightly more than a minute for NTLS to fully restart, depending on where the system was in its normal cycle of operation when you initiated the restart. This is relatively rare, with the usual NTLS restart time being on the order of ten seconds. We mention it here in case you notice an entry like **vtspd: Error: Server Listening Port could not Bind** in the logs. One or more occurrences can be normal behavior unless there is no recovery and no successful restart.

Syntax

service restart <service_name> [-force]

Parameter	Shortcut	Description
<service_name>		Specifies the service to restart. Valid values: network, ntlis, ntp, snmp, ssh, stc, sysstat, syslog
-force	-f	Force the action without prompting.

Example

```
lunash:>service restart syslog
```

```
Shutting down kernel logger:          [ OK ]
Shutting down system logger:         [ OK ]
Starting system logger:               [ OK ]
Starting kernel logger:               [ OK ]
```

```
Command Result : 0 (Success)
```

```
lunash:>service restart ntlis
```

```
Checking for connected clients before stopping NTLS service:
WARNING !! There are 1 client(s) connected to this SafeNet Network HSM
appliance. It is recommended that you disconnect all clients
before stopping or restarting the NTLS service.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'
> proceed
Proceeding...
Stopping ntlis:                       [ OK ]
```

```
Starting ntlm: [ OK ]
Command Result : 0 (Success)

lunash:>service restart ssh

Stopping sshd: [ OK ]
Starting sshd: [ OK ]
Command Result : 0 (Success)

[myLuna] lunash:>service restart network

Shutting down interface eth0: [ OK ]
Shutting down interface eth1: [ OK ]
Shutting down loopback interface: [ OK ]
Bringing up loopback interface: [ OK ]
Bringing up interface eth0: [ OK ]
Bringing up interface eth1: [ OK ]

Command Result : 0 (Success)

lunash:>service restart ntp

Shutting down ntp: [ OK ]
Starting ntp: [ OK ]
Command Result : 0 (Success)

lunash:>service restart snmp

Stopping snmpd: [ OK ]
Starting snmpd: [ OK ]
Command Result : 0 (Success)
```

service start

Start a named service on the SafeNet appliance. Services usually need to be started only if they were stopped with a service stop command, or if the service stopped unexpectedly.

Use the **service list** command to display a list of services that you can stop.

Syntax

service start <service_name>

Parameter	Shortcut	Description
<service_name>		Specifies the service to start. Valid values: network, ssh, ntlis, syslog, ntp, snmp, sysstat

Example

```
lunash:>service start syslog
```

```
Starting system logger:          [ OK ]
Starting kernel logger:         [ OK ]
```

```
Command Result : 0 (Success)
```

service status

Display the current status (running/stopped) for the specified service. You may wish to run this command to ensure that specific services are running properly. For example, if troubleshooting a problem with the NTLA, it is wise to ensure that the NTLS service is properly started. If it is not, the server may not be able to resolve itself by the hostname in the server certificate.

Syntax

service status <service_name>

Parameter	Shortcut	Description
<service_name>		Specifies the service for which you want to display the status. Valid values: network, ssh, ntlis, syslog, ntp, snmp, sysstat

Example

```
lunash:>service status ntp
```

```
ntp is not running
```

```
Command Result : 0 (Success)
```

service stop

Stop a service on the SafeNet appliance. Customer support might ask you to stop a particular service. Or, you may wish to control which functions are available on the SafeNet appliance. For example, if you are performing maintenance and prefer that nobody be able to use the NTLA to connect to the SafeNet Network HSM, you can stop the NTLS service. A user performing maintenance via the serial port can stop the ssh service to prevent anyone from accessing the SafeNet appliance.

Use the **service list** command to display a list of services that you can stop.

Syntax

service stop <serviceName>

Parameter	Shortcut	Description
<service_name>		Specifies the service to stop. Valid values: network, ssh, ntl, syslog, ntp, snmp, sysstat
-force	-f	Force the action without prompting.

Example

```
lunash:> service stop ntl
```

```
Checking for connected clients before stopping NTLS service:
There are no connected clients. Proceeding...
Stopping ntl:OK
```

```
Command Result : 0 (Success)
```

status

Access commands that allow you to view the current system status.

Syntax

status

cpu
date
disk
interface
mac
mem
netstat
ps
sensors
sysstat
time
zone

Parameter	Shortcut	Description
cpu	c	Display the current CPU load. See "status cpu" on the next page.
date	da	Display the current date and time. See "status date" on page 320
disk	di	Display the current disk usage. See "status disk" on page 321.
interface	i	Display the current network interface information. See "status interface" on page 324.
mac	ma	Display the current MAC address configuration. See "status mac" on page 325.
mem	me	Display the current memory usage. See "status mem" on page 326.
netstat	n	Display the current network connections. See "status netstat" on page 329.
ps	ps	Display the current status of processes. See "status ps" on page 330
sensors	se	Display the sensors output. See "status sensors" on page 332.
sysstat	sy	Display system status monitor information. See "status sysstat" on page 334.
time	t	Display the current time. See "status time" on page 337.
zone	z	Display the current time zone. See "status zone" on page 338.

status cpu

Display the current CPU load. The CPU load data is presented as a series of five entries, as follows:

1. The average CPU load for the previous minute. This value is 0.14 in the example below.
2. The average CPU load for the previous five minutes. This value is 0.10 in the example below.
3. The average CPU load for the previous ten minutes. This value is 0.08 in the example below.
4. The number of currently running processes and the total number of processes. The example below shows 1 of 68 processes running.
5. The last process ID used. This value is 11162 in the example below.

Syntax

status cpu

Example

```
lunash:>status cpu
```

```
CPU Load Averages:
```

```
0.14 0.10 0.08 1/68 11162
```

```
System uptime:
```

```
At Fri Jan 10 08:05:23 EST 2014, I am up 45 min
```

```
Command Result : 0 (Success)
```

status date

Display the current date and time.

Syntax

```
status date
```

Example

```
lunash:>status date
```

```
Thu Oct 30 16:28:05 EST 2011
```

```
Command Result : 0 (Success)
```


status disk

Display the current disk usage information from the SMART monitoring service.

Syntax

status disk

Example

```
lunash:>status disk
===== Hard Disk utilization =====
Filesystem      1K-blocks      Used    Available      Use%    Mounted on
/dev/sda5       988212         124028   813984         14%     /
/dev/sda7       1976492        35784   1840304         2%     /tmp
/dev/sda9       3945128        96496   3648224         3%     /var
/dev/sda10      1976492        35764   1840324         2%     /var/tmp
/dev/sda11      1976492        40712   1835376         3%     /var/log
/dev/sda12      29538432       176576  27861388         1%     /home
/dev/sda8       39381744       594544  36786708         2%     /usr
/dev/sda6       101086  14220   81647  15%     /boot
===== Hard Disk SMART Report =====

=== START OF INFORMATION SECTION ===
Device Model: WDC WD1600BEVT-00A23T0
Serial Number: WD-WX91A10N4146
Firmware Version: 04.04V06

=== START OF READ SMART DATA SECTION ===
SMART overall-health self-assessment test result: PASSED
SMART Attributes Data Structure revision number: 16
Vendor Specific SMART Attributes with Thresholds:

ID#      ATTRIBUTE_NAME            FLAG         VALUE  WORST  THRESH  TYPE      UPDATED  WHEN_FAILED  RAW_
VALUE
  1      Raw_Read_Error_Rate      124028     200    200    051      Pre-fail  Always       -           0
  3      Spin_Up_Time              35784      201    200    021      Pre-fail  Always       -          2933
  4      Start_Stop_Count         96496      100    100    000      Old_Age   Always       -           24
  5      Reallocated_Sector_Ct    35764      200    200    140      Pre-fail  Always       -           0
  7      Seek_Error_Rate          40712      200    200    000      Old_Age   Always       -           0
  9      Power_On_Hours           176576     100    100    000      Old_Age   Always       -          101
 10      Spin_Retry_Count         594544     100    253    000      Old_Age   Always       -           0
 11      Calibration_Retry_Count  0x0012     100    253    000      Old_Age   Always       -           0
 12      Power_Cycle_Count        0x0032     100    100    000      Old_Age   Always       -           24
 192     Power-Off_Retract_Count  0x0032     200    200    000      Old_Age   Always       -           4
 193     Load_Cycle_Count        0x0032     200    200    000      Old_Age   Always       -        385693
 194     Temperature_Celsius     0x0022     117    093    000      Old_Age   Always       -           30
 196     Reallocated_Event_Count  0x0032     200    200    000      Old_Age   Always       -           0
 197     Current_Pending_Sector  0x0012     200    200    000      Old_Age   Always       -           0
 198     Offline_Uncorrectable    0x0010     100    253    000      Old_Age   Offline     -           0
 199     UDMA_CRC_Error_count    0x0032     200    200    000      Old_age   Always       -           0
 200     Multi_Zone_Error_Rate   0x00008    100    253    000      Old_Age   Offline     -           0

SMART Error Log Version: 1

No Errors Logged

Command Result : 0 (Success)
```

status handles

Gets the open handle count for each process.

Syntax

status handles

Example

```
lunash:>status handles
```

HANDLES	PID	CMD
10	1	init
4	2	[migration/0]
4	3	[ksoftirqd/0]
4	4	[watchdog/0]
4	5	[migration/1]
4	6	[ksoftirqd/1]
4	7	[watchdog/1]
4	8	[events/0]
4	9	[events/1]
4	10	[khelper]
4	11	[kthread]
4	15	[kblockd/0]
4	16	[kblockd/1]
4	17	[kacpid]
4	163	[cqueue/0]
4	164	[cqueue/1]
4	167	[khubd]
4	169	[kseriod]
4	242	[khungtaskd]
4	243	[pdflush]
4	244	[pdflush]
4	245	[kswapd0]
4	246	[aio/0]
4	247	[aio/1]
4	411	[kpsmoused]
4	443	[ata/0]
4	444	[ata/1]
4	445	[ata_aux]
4	449	[scsi_eh_0]
4	450	[scsi_eh_1]
4	451	[scsi_eh_2]
4	452	[scsi_eh_3]
4	453	[scsi_eh_4]
4	454	[scsi_eh_5]
4	455	[kjournald]
4	472	[kauditd]
18	500	/sbin/udev
4	1377	[kjournald]
4	1379	[kjournald]
4	1381	[kjournald]
4	1383	[kjournald]
4	1385	[kjournald]

```
4 1387 [kjournald]
4 1389 [kjournald]
4 1391 [kjournald]
12 1824 irqbalance
11 1833 /usr/sbin/acpid
21 1841 rsyslogd
8 1845 rklogd
4 1866 [viper0_sm]
19 1892 crond
40 1954 /usr/lunasa/vts/htl_vtsd
20 2003 /usr/lunasa/oamp/oamp
30 2018 /usr/lunasa/stcd/bin/stcd
40 2112 /usr/lunasa/vts/ntls_vtsd
24 2235 /usr/lunasa/bin/pedClient
30 2236 /usr/lunasa/adminapi/adminApi
4 2262 [kipmi0]
16 2285 /usr/sbin/ipmievd
4 2355 [kondemand/0]
4 2357 [kondemand/1]
10 2384 /usr/lunasa/watchdog/wdt_heartbeat
15 2399 /usr/sbin/smartd
14 2414 /usr/lunasa/sysstat/sysstatd
10 4783 /sbin/mgetty
16 10445 /bin/bash
22 16896 /usr/sbin/sshd
42 21163 sshd:
12 21173 -lush
```

628 Total handles allocated.

Command Result : 0 (Success)

status interface

Display network interface information.

Syntax

status interface

Example

```
lunash:>status interface
eth0      Link encap:Ethernet  HWaddr 00:03:47:E7:56:1A
          inet addr:172.19.11.75  Bcast:172.19.255.255  Mask:255.255.0.0
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:9015 errors:0 dropped:0 overruns:0 frame:0
          TX packets:5683 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:100
          RX bytes:1040267 (1015.8 Kb)  TX bytes:514608 (502.5 Kb)
          Interrupt:11 Base address:0x7000
eth1      Link encap:Ethernet  HWaddr 00:02:B3:AB:C5:4D
          inet addr:192.168.2.21  Bcast:192.168.2.255  Mask:255.255.255.0
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:4539 errors:0 dropped:0 overruns:0 frame:0
          TX packets:595 errors:0 dropped:0 overruns:0 carrier:0
          collisions:539 txqueuelen:100
          RX bytes:2038531 (1.9 Mb)  TX bytes:39281 (38.3 Kb)
          Interrupt:11 Base address:0x9000
lo        Link encap:Local Loopback
          inet addr:127.0.0.1  Mask:255.0.0.0
          UP LOOPBACK RUNNING  MTU:16436  Metric:1
          RX packets:34 errors:0 dropped:0 overruns:0 frame:0
          TX packets:34 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:0
          RX bytes:2832 (2.7 Kb)  TX bytes:2832 (2.7 Kb)
Command Result : 0 (Success)
```

status mac

Display the network interface MAC addresses.

Syntax

status mac

Example

```
lunash:>status mac
```

```
eth0 00:03:47:EF:67:FE  
eth1 00:02:B3:AB:B5:D4
```

```
Command Result : 0 (Success)
```

status mem

Display the current memory usage.

Syntax

status mem

Example

```
lunash:>status mem
```

	total	used	free	shared	buffers	cached
Mem:	2067000	88764	1978236	0	21472	45608
-/+ buffers/cache:		21684	2045316			
Swap:	2008084	0	2008084			

```
Command Result : 0 (Success)
```

status memmap

Display the current memory usage.

Syntax

status memmap

Example

```
lunash:>status memmap
```

PID	CMD	MAPPED (K)	WR/PR (K)	SHARED (K)
1	init	2180	304	0
2	[migration/0]	0	0	0
3	[ksoftirqd/0]	0	0	0
4	[watchdog/0]	0	0	0
5	[migration/1]	0	0	0
6	[ksoftirqd/1]	0	0	0
7	[watchdog/1]	0	0	0
8	[events/0]	0	0	0
9	[events/1]	0	0	0
10	[khelper]	0	0	0
11	[kthread]	0	0	0
15	[kblockd/0]	0	0	0
16	[kblockd/1]	0	0	0
17	[kacpid]	0	0	0
163	[cqueue/0]	0	0	0
164	[cqueue/1]	0	0	0
167	[khubd]	0	0	0
169	[kseriod]	0	0	0
242	[khungtaskd]	0	0	0
243	[pdflush]	0	0	0
244	[pdflush]	0	0	0
245	[kswapd0]	0	0	0
246	[aio/0]	0	0	0
247	[aio/1]	0	0	0
411	[kpsmoused]	0	0	0
443	[ata/0]	0	0	0
444	[ata/1]	0	0	0
445	[ata_aux]	0	0	0
449	[scsi_eh_0]	0	0	0
450	[scsi_eh_1]	0	0	0
451	[scsi_eh_2]	0	0	0
452	[scsi_eh_3]	0	0	0
453	[scsi_eh_4]	0	0	0
454	[scsi_eh_5]	0	0	0
455	[kjournald]	0	0	0
472	[kauditd]	0	0	0
500	/sbin/udev	2356	400	0
1377	[kjournald]	0	0	0
1379	[kjournald]	0	0	0
1381	[kjournald]	0	0	0
1383	[kjournald]	0	0	0
1385	[kjournald]	0	0	0

1387	[kjournald]	0	0	0
1389	[kjournald]	0	0	0
1391	[kjournald]	0	0	0
1824	irqbalance	2580	308	0
1833	/usr/sbin/acpid	1780	256	0
1841	rsyslogd	13864	10944	0
1845	rklogd	1784	256	0
1866	[viper0_sm]	0	0	0
1892	crond	5416	1280	0
1954	/usr/lunasa/vts/htl_vtsd	318424	307844	44
2003	/usr/lunasa/oamp/oamp	3100	324	8
2018	/usr/lunasa/stcd/bin/stcd	705248	697280	16
2112	/usr/lunasa/vts/ntls_vtsd	778696	769712	32
2235	/usr/lunasa/bin/pedClient	58892	52896	16
2236	/usr/lunasa/adminapi/adminApi	28768	11432	0
2262	[kipmi0]	0	0	0
2285	/usr/sbin/ipmievd	4264	440	0
2355	[kondemand/0]	0	0	0
2357	[kondemand/1]	0	0	0
2384	/usr/lunasa/watchdog/wdt_heartbeat	1628	120	0
2399	/usr/sbin/smartd	3632	416	0
2414	/usr/lunasa/sysstat/sysstatd	2948	284	0
4783	/sbin/mgetty	1896	260	0
15186	/bin/bash	2528	296	0
16896	/usr/sbin/sshd	4976	608	0
21163	sshd:	8180	788	2560
21173	-lush	2064	480	0

Command Result : 0 (Success)

status netstat

Display the current network connections.

Syntax

status netstat

Example

```
lunash:>status netstat
Active Internet connections (servers and established)
Proto Recv-Q Send-Q Local Address           Foreign Address         State
tcp      0      0 0.0.0.0:22              0.0.0.0:*               LISTEN
tcp      0      232 172.19.11.75:22        172.21.100.69:1114     ESTABLISHED
Active UNIX domain sockets (servers and established)
Proto RefCnt Flags           Type           State           I-Node Path
unix  7      [ ]             DGRAM          State           746    /dev/log
unix  2      [ ACC ]         STREAM         LISTENING       847    /var/run/acpid.socket
unix  2      [ ]             DGRAM          State           23121689
unix  2      [ ]             DGRAM          State           6561
unix  2      [ ]             DGRAM          State           973
unix  2      [ ]             DGRAM          State           882
unix  2      [ ]             DGRAM          State           755
unix  2      [ ]             STREAM         CONNECTED       425
Command Result : 0 (Success)
```

status ps

Display the status of the appliance processes.

Syntax

status ps

Example

```
lunash:>status ps
USER      PID      % CPU    %MEM    VSZ     RSS     TTY     STAT    START   TIME    COMMAND
root      1        0.0     0.0     2068    672     ?       Ss      07:19   0:00    init [3]
root      2        0.0     0.0     0        0        ?       S<s     07:19   0:00    [migration/0]
root      3        0.0     0.0     0        0        ?       SN      07:19   0:00    [ksoftirqd/0]
root      4        0.0     0.0     0        0        ?       S<      07:19   0:00    [watchdog/0]
root      5        0.0     0.0     0        0        ?       S<      07:19   0:00    [migration/1]
root      6        0.0     0.0     0        0        ?       SN      07:19   0:00    [ksoftirqd/1]
root      7        0.0     0.0     0        0        ?       S<      07:19   0:00    [watchdog/1]
root      8        0.0     0.0     0        0        ?       S<      07:19   0:00    [events/0]
root      9        0.0     0.0     0        0        ?       S<      07:19   0:00    [events/1]
root     10        0.0     0.0     0        0        ?       S<      07:19   0:00    [khelper]
root     11        0.0     0.0     0        0        ?       S<      07:19   0:00    [kthread]
root     15        0.0     0.0     0        0        ?       S<      07:19   0:00    [kblockd/0]
root     16        0.0     0.0     0        0        ?       S<      07:19   0:00    [kblockd/1]
root     17        0.0     0.0     0        0        ?       S<      07:19   0:00    [kacpid]
root    163        0.0     0.0     0        0        ?       S<      07:19   0:00    [cqueue/0]
root    164        0.0     0.0     0        0        ?       S<      07:19   0:00    [cqueue/1]
root    167        0.0     0.0     0        0        ?       S<      07:19   0:00    [khubd]
root    169        0.0     0.0     0        0        ?       S<      07:19   0:00    [kseriod]
root    238        0.0     0.0     0        0        ?       S       07:19   0:00    [pdflush]
root    239        0.0     0.0     0        0        ?       S       07:19   0:00    [pdflush]
root    240        0.0     0.0     0        0        ?       S<      07:19   0:00    [kswapd0]
root    241        0.0     0.0     0        0        ?       S<      07:19   0:00    [aio/0]
root    242        0.0     0.0     0        0        ?       S<      07:19   0:00    [aio/1]
root    406        0.0     0.0     0        0        ?       S<      07:19   0:00    [kpsmoused]
root    437        0.0     0.0     0        0        ?       S<      07:19   0:00    [ata/0]
root    438        0.0     0.0     0        0        ?       S<      07:19   0:00    [ata/1]
root    439        0.0     0.0     0        0        ?       S<      07:19   0:00    [ata_aux]
root    443        0.0     0.0     0        0        ?       S<      07:19   0:00    [scsi_eh_0]
root    444        0.0     0.0     0        0        ?       S<      07:19   0:00    [scsi_eh_1]
root    445        0.0     0.0     0        0        ?       S<      07:19   0:00    [scsi_eh_2]
root    446        0.0     0.0     0        0        ?       S<      07:19   0:00    [scsi_eh_3]
root    447        0.0     0.0     0        0        ?       S<      07:19   0:00    [scsi_eh_4]
root    448        0.0     0.0     0        0        ?       S<      07:19   0:00    [scsi_eh_5]
root    449        0.0     0.0     0        0        ?       S<      07:19   0:00    [kjournald]
root    475        0.0     0.0     0        0        ?       S<      07:19   0:00    [kauditd]
root    508        0.0     0.0     2240    640     ?       S<s     07:20   0:00    /sbin/udev -d
root   1318        0.0     0.0     0        0        ?       S<      07:20   0:00    [kstriped]
root   1332        0.0     0.0     0        0        ?       S<      07:20   0:00    [kmpathd/0]
root   1333        0.0     0.0     0        0        ?       S<      07:20   0:00    [kmpathd/1]
root   1334        0.0     0.0     0        0        ?       S<      07:20   0:00    [kmpath_handlerd]
root   1372        0.0     0.0     0        0        ?       S<      07:20   0:00    [kjournald]
root   1374        0.0     0.0     0        0        ?       S<      07:20   0:00    [kjournald]
root   1376        0.0     0.0     0        0        ?       S<      07:20   0:00    [kjournald]
root   1378        0.0     0.0     0        0        ?       S<      07:20   0:00    [kjournald]
root   1380        0.0     0.0     0        0        ?       S<      07:20   0:00    [kjournald]
root   1382        0.0     0.0     0        0        ?       S<      07:20   0:00    [kjournald]
root   1384        0.0     0.0     0        0        ?       S<      07:20   0:00    [kjournald]
```

```

root    1941    0.0    0.0    2464    360    ?      Ss     07:20    0:00    irqbalance
root    1955    0.0    0.0    1672    532    ?      Ss     07:20    0:00    /usr/sbin/acpid
root    1985    0.0    0.0    4092    980    ?      Ss     07:20    0:00    /usr/sbin/sshd
root    2001    0.0    0.0    5296    1128   ?      Ss     07:20    0:00    crond
root    2221    0.0    0.1    1676    624    ?      Ss     07:20    0:00    /usr/lunasa/oamp/oamp
root    2240    0.0    0.2    0        0      ?      SN     07:20    0:00    [kipmi0]
root    2263    0.0    0.0    3952    664    ?      S      07:20    0:00    /usr/sbin/ipmievd open
root    2282    0.0    0.0    1516    1516   ?      S<L    07:20    0:00    /usr/lunasa//watchdog/wdt
root    2302    0.0    0.0    0        0      ?      S<s    07:20    0:00    [kondemand/0]
root    2303    0.0    0.0    0        0      ?      S<s    07:20    0:00    [kondemand/1]
root    2326    0.0    0.0    3512    584    ?      S      07:20    0:00    /usr/sbin/smartd -q never
root    2349    0.0    0.0    2824    1084   ?      S      07:20    0:00    /usr/lunasa/sysstat/syssta
root    2351    0.0    0.0    1784    628    ?      Ss     07:20    0:00    /sbin/mgetty /dev/ttyS0 -
root    3797    0.0    0.1    7300    2176   ?      Ss     07:20    0:00    sshd: admin@pts/0
root    5252    0.0    0.0    1952    844    pts/0   Ss+    07:21    0:00    -lush
root    10589   0.0    0.0    2408    960    pts/0   S+     08:10    0:00    /bin/sh S
root    10590   0.0    0.0    2180    816    pts/0   R+     08:10    0:00    ps auxw
root    11885   0.0    0.0    13424   916    ?       S1     07:42    0:00    rsyslogd -m 0
root    11889   0.0    0.0    1676    300    ?       Ss     07:42    0:00    rklogd -x
root    16685   0.0    0.1    16488   2512   ?       S      07:36    0:00    /usr/local/sbin/snmpd

```

Command Result : 0 (Success)

status sensors

Displays the fan speed, temperature and voltage of the motherboard and power supply units.

Depending upon when you purchased your SafeNet Network HSM appliance, the baseboard management controller firmware may be at a revision that reports more data on the power supply units than earlier BMC versions. The first example below shows the output from an earlier version of the BMC firmware. The second example shows the output from a more recent version. In this second example, the right PSU (facing the front of SafeNet Network HSM) has no A/C power connected to it (it is in an audible alarm state).

Syntax

status sensors [-log]

Option	Shortcut	Description
-log	-l	Show sensors event logs.

Example

```
lunash:>status sensors
```

This command displays the fan speed, temperature and voltage of the motherboard and power supply units.

Sensor	Reading	Unit	status	Thresholds
FAN1A	4400.000	RPM	ok	1000.000 2000.000 na na
FAN1B	6200.000	RPM	ok	1000.000 2000.000 na na
FAN2A	4400.000	RPM	ok	1000.000 2000.000 na na
FAN2B	6000.000	RPM	ok	1000.000 2000.000 na na
FAN3A	4300.000	RPM	ok	1000.000 2000.000 na na
FAN3B	6400.000	RPM	ok	1000.000 2000.000 na na
CPU	14.000	degrees C	ok	na na 87.000 92.000
VRD	27.000	degrees C	ok	na na 90.000 100.000
PCH	51.000	degrees C	ok	na na 90.000 100.000
MEM	51.000	degrees C	ok	na na na 105.000
Inlet	18.000	degrees C	ok	na na 40.000 50.000
CHA DIMM 0	31.000	degrees C	ok	na na 87.000 97.000
CHA DIMM 1	na	degrees C	na	na na 87.000 97.000
CHA DIMM 2	na	degrees C	na	na na 87.000 97.000
CHB DIMM 0	32.000	degrees C	ok	na na 87.000 97.000
CHB DIMM 1	na	degrees C	na	na na 87.000 97.000
CHB DIMM 2	na	degrees C	na	na na 87.000 97.000
RAM TMax	32.000	degrees C	ok	na na 87.000 97.000
InletM	28.000	degrees C	ok	na na na 105.000
CPU_VCORE	0.968	Volts	ok	na 0.632 1.440 na
VBAT	2.924	Volts	ok	na 2.796 na na
3VSB	3.364	Volts	ok	na 3.092 3.492 na
3VMain	3.364	Volts	ok	na 3.092 3.492 na
+5V	5.100	Volts	ok	na 4.692 5.304 na
+12V	11.960	Volts	ok	na 11.284 12.740 na
PSU1_Voltage	0x0	discrete	0x0200	na na na na
PSU1_Temp	0x0	discrete	0x0200	na na na na
PSU1_Fan	0x0	discrete	0x0200	na na na na

PSU2_Voltage	na	discrete	na	na	na	na	na
PSU2_Temp	na	discrete	na	na	na	na	na
PSU2_Fan	na	discrete	na	na	na	na	na
CPU_Thermtrip	0x0	discrete	NR	na	na	na	na
PSU1_Present	0x0	discrete	0x0200	na	na	na	na
PSU2_Present	0x0	discrete	ok	na	na	na	na

Notes:

NR: Not Reading (Error)

CR: Critical

0.00 RPM means fan unplugged, failed, or sensors not readable

DIMM: Dual In-Line Memory Module

PSU1: Power Supply Unit 1

PSU2: Power Supply Unit 2

Fan1, Fan2 and Fan3 are pluggable modules on the front of the appliance.

Each fan unit contains two fans: A and B.

----- Power Supplies Status -----

PSU1_Voltage	Failure detected
PSU1_Temp	Failure detected
PSU1_Fan	Failure detected
PSU2_Voltage	No Reading
PSU2_Temp	No Reading
PSU2_Fan	No Reading
CPU_Thermtrip	OK
PSU1_Present	Failure detected
PSU2_Present	Presence detected

----- Front Cooling Fans Status -----

FAN1A	OK	4400 RPM
FAN1B	OK	6200 RPM
FAN2A	OK	4400 RPM
FAN2B	OK	6000 RPM
FAN3A	OK	4300 RPM
FAN3B	OK	6400 RPM

----- chassis status -----

System Power	: on
Power Overload	: false
Power Interlock	: inactive
Main Power Fault	: false
Power Control Fault	: false
Power Restore Policy	: previous
Last Power Event	: ac-failed
Chassis Intrusion	: inactive
Front-Panel Lockout	: inactive
Drive Fault	: false
Cooling/Fan Fault	: false
Front Panel Control	: none

Command Result : 0 (Success)

status sysstat

Access commands that allow you to display system status monitor service information and status code descriptions.

Syntax

status sysstat

code
show

Parameter	Shortcut	Description
code	c	Display descriptive text for a status code. See " status sysstat code " on the next page.
show	s	Display system status monitor service information. See " status sysstat show " on page 336.

status sysstat code

Code lookup for the system status monitor service. Provide the integer code from the system status monitor and descriptive text will be provided to describe the error.

Syntax

status sysstat code all | <system-status-code>

Option	Shortcut	Parameter	Description
all	a	.	Display descriptions for all system status codes.
.	.	<system-status-code>	Specifies the system status code for which you want to display information.

Example

```
lunash:>status sysstat code 25
```

```
Code
```

```
=====
```

```
25
```

```
System State
```

```
=====
```

```
OOS
```

```
Code Description
```

```
=====
```

```
The NTLS is not bound to an Ethernet device. Please run the "ntls show", "ntls bind" and "syslog tail" commands for more information.
```

```
Command Result : 0 (Success)
```

status sysstat show

Display system status monitor service information.

Syntax

status sysstat show

Example

```
lunash:>status sysstat show
Volatile State:
sysstatd (pid 2432) is running...
Service Status: sysstatd (pid 2432) is running...

Non-volatile State:
Disabled

System Status Monitor - Current Status
=====
Hostname: snake21
Interface eth0: 172.20.11.21
Interface eth1: 192.168.254.1
Software Version: SA:6.x.0-25
System Status: ISO
System Status Code: 60
Status Check Time: 20:47 on 27/10/2015

System State Description
ISO (In Service Okay): The appliance is online and the necessary subsystems are operational.
IST (In Service with Trouble): The appliance is online and the necessary subsystems are operational with some troubles.
OFL (Off Line): The appliance is not currently connected to the ethernet network and cannot provide service.
OOS (Out Of Service): The appliance is online but the necessary subsystems are NOT operational.

Command Result : 0 (Success)
```


status time

Display the current time, using the 24 hour clock.

Syntax

```
status time
```

Example

```
lunash:> status time
```

```
09:41:23
```

```
Command Result : 0 (Success)
```

status zone

Displays the current time zone. This command is equivalent to the **sysconf timezone show** command.

Syntax

status zone

Example

```
lunash:> status zone
```

```
EST
```

```
Command Result : 0 (Success)
```

stc

Use these commands to configure and manage secure trusted channel (STC) partition-client network links.

You must be logged in as the HSM SO to use the **stc** commands.

Syntax

stc

activationtimeout
cipher
client
hmac
partition
rekeythreshold
replaywindow

Parameter	Shortcut	Description
activationtimeout	a	Set the activation timeout for an STC link. See " stc activationTimeOut " on the next page.
cipher	ci	Disable the use of a symmetric encryption cipher algorithm for data encryption on an STC link. See " stc cipher " on page 343.
client	cl	Deregister a client's STC public key from the specified partition. See " stc client " on page 349.
hmac	h	Disable the use of an HMAC message digest algorithm for identity verification on an STC link. See " stc hmac " on page 353.
partition	p	Export the specified partition's public key to a file. " stc partition " on page 357.
rekeythreshold	rek	Set the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See " stc rekeyThreshold " on page 360.
replaywindow	rep	Set the size of the packet replay window. See " stc replayWindow " on page 363

stc activationTimeOut

Control and monitor the STC activation timeout.

You must be logged in as the HSM SO to use the **stc activationTimeOut** commands.

Syntax

stc activationTimeOut

set
show

Option	Shortcut	Description
activationtimeout set	a se	Set the activation timeout for an STC link. See " stc activationtimeout set " on the next page.
activationtimeout show	a sh	Display the STC link activation timeout for the specified partition. See " stc activationtimeout show " on page 342

stc activationtimeout set

Set the activation timeout for an STC link. The activation timeout is the maximum time allowed to establish the STC link before the channel request is dropped.

You must be logged in as the HSM SO to use this command.

Syntax

stc activationtimeout set **-partition** <partition_name> **-time** <timeout>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition for which you want to set the STC link activation timeout.
-time <timeout>	-t <timeout>	Specifies the activation timeout, in seconds. Range: 1-240 Default:

Example

```
lunash:> stc a se -par mapleleafs -t 30
```

Successfully changed the activation timeout for partition mapleleafs to 30 seconds.

stc activationtimeout show

Display the activation timeout for an STC link. The activation timeout is the maximum time allowed to establish the STC link before the channel request is dropped.

You must be logged in as the HSM SO to use this command.

Syntax

stc activationtimeout show -partition <partition>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition for which you want to display the STC link activation timeout.

Example

```
lunash:> stc a sh -par mapleleafs
```

The channel activation timeout for partition mapleleafs is 30 seconds.

stc cipher

Control the use of symmetric encryption ciphers for STC.

You must be logged in as the HSM SO to use the **stc cipher** commands.

Syntax

stc cipher

disable
enable
show

Option	Shortcut	Description
cipher disable	ci d	Disable the use of a symmetric encryption cipher algorithm for data encryption on an STC link. See " stc cipher disable " on the next page.
cipher enable	ci e	Enable the use of a symmetric encryption cipher algorithm used for data encryption on an STC link. See " stc cipher enable " on page 346.
cipher show	ci s	List the symmetric encryption cipher algorithms you can use for STC data encryption on the specified partition. See " stc cipher show " on page 348.

stc cipher disable

Disable the use of a symmetric encryption cipher algorithm for data encryption on an STC link. All data transmitted over the STC link will be encrypted using the cipher that is both enabled and that offers the highest level of security. For example, if AES 192 and AES 256 are enabled, and AES 128 is disabled, AES 256 will be used. You can use the command "[stc cipher show](#)" on [page 348](#) to show which ciphers are currently enabled/disabled.

Disabling all of the ciphers turns off symmetric encryption on the link.

You must be logged in as the HSM SO to use this command.



Note: Performance is reduced for larger ciphers.

Syntax

stc cipher disable **-partition** <partition_name> **-all** **-id** <cipher_id>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition that will perform STC data encryption using the specified cipher.
-all	-a	Allow the specified cipher.
-id <cipher_id>	-id <cipher_id>	Specifies the numerical identifier of the cipher you want to use, as listed using the command " stc cipher show " on page 348 .

Example

```
lunash:>stc cipher show -p mapleleaves
```

This table lists the ciphers supported for STC links to the partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	Yes

Command Result : 0 (Success)

```
lunash:> stc cipher disable -par mapleleaves -id 3
```

AES 256 Bit with Cipher Block Chaining is now disabled.

Command Result : 0 (Success)

```
lunash:>stc cipher show -p mapleleaves
```

This table lists the ciphers supported for STC links to the partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	No

Command Result : 0 (Success)

stc cipher enable

Enable the use of a symmetric encryption cipher algorithm for data encryption on an STC link. All data transmitted over the STC link will be encrypted using the cipher that is both enabled and that offers the highest level of security. For example, if AES 192 and AES 256 are enabled, and AES 128 is disabled, AES 256 will be used. You can use the command "[stc cipher show](#)" on [page 348](#) to show which ciphers are currently enabled/disabled.

You must be logged in as the HSM SO to use this command.



Note: Performance is reduced for larger ciphers.

Syntax

stc cipher enable -partition <partition_name> **-all -id** <cipher_id>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition for which you want to enable the specified cipher.
-all	-a	Enable all ciphers.
-id <cipher_id>	-id <cipher_id>	Specifies the numerical identifier of the cipher you want to use, as listed using the command " stc cipher show " on page 348 .

Example

```
lunash:>stc cipher show -p mapleleafs
```

This table lists the ciphers supported for STC links to the partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	No

Command Result : 0 (Success)

```
lunash:> stc cipher enable -par mapleleafs -id 3
```

AES 256 Bit with Cipher Block Chaining is now enabled.

```
lunash:>stc cipher show -p mapleleafs
```

This table lists the ciphers supported for STC links to the partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	Yes

Command Result : 0 (Success)

stc cipher show

List the symmetric encryption cipher algorithms you can use for data encryption on an STC link. If all ciphers are disabled, symmetric encryption is not used on the link.

You must be logged in as the HSM SO to use this command.

Syntax

stc cipher show -partition <partition_name>

Example

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the partition for which you want to display the available ciphers.

```
lunash:>stc cipher show -p mapleleaves
```

This table lists the ciphers supported for STC links to the partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	No

Command Result : 0 (Success)

stc client

List, register, and de-register the STC clients.

You must be logged in as the HSM SO to use the **stc client** commands.

Syntax

stc

client deregister

client list

client register

Option	Shortcut	Description
client deregister	cl d	Deregister a client's STC public key from the specified partition. See "stc client deregister" on the next page.
client list	cl l	List the clients registered to the specified partition. See "stc client list" on page 351.
client register	cl r	Register a client's STC public key to the specified partition. See "stc client register" on page 352

stc client deregister

Deregister a client's STC public key from the specified partition. You must be the owner of the partition to use this command.

You must be logged in as the HSM SO to use this command.



CAUTION: Deregistering a client's public key disables the STC link to that client.

Syntax

stc client deregister -partition <partition_name> -label <client_label>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition containing the public key you want to deregister.
-label <client_label>	-l <client_label>	A string used to identify the client being deregistered.

Example

```
lunacm:> stc client deregister -par mapleleafs -label dkeon
```

Successfully deregistered the client public key of dkeon in partition mapleleafs

stc client list

List the clients registered to the specified partition. You must be logged in as the HSM SO and own the partition to use this command.

Syntax

stc client list -partition <partition_name>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition.

Example

```
lunash:> stc client list -par mapleleafs
```

```
Client Name      Client Identity Public Key SHA1 Hash
rellis          2fd4e1c67a2d28fced849ee1bb76e7391b93eb1
nullman         de9f2c7fd25e1b3afad3e85a0bd17d9b100db4b3
phenderson      da39a3ee5e6b4b0d3255bfef95601890afd80709
```

stc client register

Register a client's STC public key to the specified partition. You must be logged in as the HSM SO and own the partition to use this command.



Note: Each client identity registered to a partition uses 2332 bytes of storage on the partition. Before registering a client identity to a partition, ensure that there is adequate free space.

Syntax

stc client register **-partition** <partition_name> **-label** <client_label> **-file** <client_public_key>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition.
-label <client_name>	-l <client_label>	A string used to identify the client being registered.
-file <client_public_key>	-f <client_public_key>	The client public key file as displayed using the command "my file list" on page 187 .

Example

```
lunash:> stc client register -par mapleleafs -l bsalming -f 45021294.pem
```

Successfully registered the client public key of bsalming in partition mapleleafs

stc hmac

Enable, disable, and monitor the use of HMAC algorithms for STC.

You must be logged in as the HSM SO to use the **stc hmac** commands.

Syntax

stc hmac

hmac disable

hmac enable

hmac show

Option	Shortcut	Description
hmac disable	h d	Disable the use of an HMAC message digest algorithm for identity verification on an STC link. See " stc hmac disable " on the next page.
hmac enable	h e	Enable the use of an HMAC message digest algorithm for integrity verification on an STC link. See " stc hmac enable " on page 355
hmac show	h s	List the HMAC message digest algorithms you can use for STC message integrity verification on the specified partition. See " stc hmac show " on page 356

stc hmac disable

Disable the use of an HMAC message digest algorithm for message integrity verification on an STC link. The HMAC algorithm that is both enabled and that offers the highest level of security is used. For example, if SHA 256 and SHA 512 are enabled, SHA 512 is used. You can use the command "stc hmac show" on page 356 to show which HMAC message digest algorithms are currently enabled/disabled.



Note: All STC links use message integrity verification, so at least one HMAC algorithm must be enabled.

You must be logged in as the HSM SO to use this command.

Syntax

stc hmac disable **-partition** <partition_name> **-id** <hmac_id>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the partition for which you want to enable an HMAC algorithm.
-id <hmac_id>	-id <hmac_id>	Specifies the numerical identifier of the HMAC algorithm you want to disable, as listed using the command "stc hmac show" on page 356.

Example

```
lunash:> stc hmac show -par mapleleafs
```

```
HMAC ID      HMAC Name                Enabled
0            HMAC with SHA 256 Bit    Yes
1            HMAC with SHA 512 Bit    Yes
```

```
Command Result : 0 (Success)
```

```
lunash:> stc hmac disable -par mapleleafs -id 0
```

```
HMAC with SHA 256 Bit is now disabled for partition mapleleafs.
```

```
Command Result : 0 (Success)
```

```
lunash:> stc hmac show -par mapleleafs
```

```
HMAC ID      Name                    Enabled
0            HMAC with SHA 256 Bit    No
1            HMAC with SHA 512 Bit    Yes
```

```
Command Result : 0 (Success)
```

stc hmac enable

Enable the use of an HMAC message digest algorithm for message integrity verification on an STC link. The HMAC algorithm that is both enabled and that offers the highest level of security is used. For example, if SHA 256 and SHA 512 are enabled, SHA 512 is used. You can use the command "stc hmac show" on the next page to show which HMAC message digest algorithms are currently enabled/disabled.



Note: All STC links use message integrity verification, so at least one HMAC algorithm must be enabled.

You must be logged in as the HSM SO to use this command.

Syntax

stc hmac enable -partition <partition_name> -id <hmac_id>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the partition for which you want to enable the HMAC algorithm.
-id <hmac_id>	-id <hmac_id>	Specifies the numerical identifier of the HMAC algorithm you want to enable, as listed using the command "stc hmac show" on the next page.

Example

```
lunash:> stc hmac show -par mapleleafs
```

```
HMAC ID      Name                               Enabled
0            HMAC with SHA 256 Bit              No
1            HMAC with SHA 512 Bit              Yes
```

```
Command Result : 0 (Success)
```

```
lunash:> stc hmac enable -par mapleleafs -id 0
```

```
Command Result : 0 (Success)
```

```
HMAC with SHA 256 Bit is now enabled for partition mapleleafs.
```

```
lunash:> stc hmac show -par mapleleafs
```

```
HMAC ID      HMAC Name                               Enabled
0            HMAC with SHA 256 Bit              Yes
1            HMAC with SHA 512 Bit              Yes
```

```
Command Result : 0 (Success)
```

stc hmac show

List the HMAC message digest algorithms you can use for message integrity verification on an STC link.

You must be logged in as the HSM SO to use this command.

Syntax

```
stc hmac show -partition <partition_name>
```

Example

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the partition for which you want to display the available HMAC algorithms.

```
lunash:> stc hmac show -par mapleleafs
```

```
HMAC ID      HMAC Name          Enabled
0            HMAC with SHA 256 Bit  Yes
1            HMAC with SHA 512 Bit  Yes
```

stc partition

Export the STC partition identity.

You must be logged in as the HSM SO to use the **stc partition** commands.

Syntax

stc partition

export
show

Option	Shortcut	Description
partition export	p e	Export the specified partition's public key to a file. " stc partition export " on the next page.
partition show	p s	Display the public key and serial number for the current partition. See " stc partition show " on page 359.

stc partition export

Export the specified partition's public key to a file. You must be logged in to the partition as the SO to perform this command.



Note: If the HSM is zeroized while STC is enabled, the STC link between LunaSH and the admin partition will no longer authenticate, since the admin partition identity no longer exists. If this occurs, you will be unable to log into, or initialize, the HSM. To recover from this state, run the **stc partition export** command without any parameters. When you run the command, a new identity is created for the admin partition, and the new admin partition public key is exported to the default directory. This will restore the STC link between LunaSH and the admin partition, allowing you to re-initialize the HSM. You can only run this command, while not logged into the HSM, if the HSM is zeroized.

Syntax

stc partition export -partition <partition_name>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition whose public key you want to export.

Example

```
lunash:> stc partition export -par mapleleafs
```

Successfully exported partition identity for partition mapleleafs to file: 359693009023.pid

stc partition show

Display the public key and serial number for the current partition. You must be logged into the partition as the SO to perform this command.

Syntax

stc partition show -partition <partition_name>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition whose public key and serial number you want to display

Example

```
lunash:> stc partition show -par mapleleafs
```

```
Partition Serial Number:          359693009023
Partition Identity Public Key SHA1 Hash: ee27ac0376af538a6f15523002c43c7b6febdf34
```

stc rekeyThreshold

Monitor and set the STC re-keying threshold for the named partition.

You must be logged in as the HSM SO to use the **stc rekeyThreshold** commands.

Syntax

stc rekeyThreshold

set
show

Option	Shortcut	Description
rekeythreshold set	rek se	Set the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See " stc rekeythreshold set " on the next page.
rekeythreshold show	rek sh	Display the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See " stc rekeythreshold show " on page 362.

stc rekeythreshold set

Set the rekey threshold for the symmetric key used to encrypt data on an STC link. The symmetric key is used to encode the number of messages specified by the threshold value, after which it is regenerated and the counter is reset to 0.

The default of 400 million messages would force a rekeying operation once every 24 hours on an HSM under heavy load (processing approximately 5000 messages/second), or once a week for an HSM under light load (processing approximately 700 messages/second).

You must be logged in as the HSM SO to use this command.

Syntax

stc rekeythreshold set **-partition** <partition> **-value** <key_life>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition for which you want to specify the STC rekey threshold.
-value <key_life>	-v <key_life>	An integer that specifies the key life (in millions of encoded messages) for the STC symmetric key. Enter a value of 0 to disable rekeying. Range: 0 to 4000 million messages. Default: 400 million messages.

Example

```
lunash:> stc rekeythreshold set -par mapleleafs -v 200
```

Successfully changed the rekey threshold for partition mapleleafs to 200 million messages.

stc rekeythreshold show

Display the rekey threshold for the symmetric key used to encrypt data on an STC link. The symmetric key is used the number of times specified by the threshold value, after which it is regenerated and the counter is reset to 0. Each command sent to the HSM over the STC link uses one life.

You must be logged in as the HSM SO to use this command.

Syntax

stc rekeythreshold show -partition <partition_name>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition for which you want to display the STC rekey threshold.

Example

```
lunash:> stc rekeythreshold show -par mapleleafs
```

Current rekey threshold for partition mapleleafs is 400 million messages.

stc replayWindow

Review or set the size of the STC replay window for the named partition.

You must be logged in as the HSM SO to use the **stc replayWindow** commands.

Syntax

stc replayWindow

set
show

Option	Shortcut	Description
replaywindow set	rep se	Set the size of the packet replay window. See " stc replaywindow set " on the next page
replaywindow show	rep sh	Display the current setting for the size of the packet replay window. See " stc replaywindow show " on page 365.

stc replaywindow set

Set the size of the packet replay window for an STC link. This value specifies the number of packets in the window of sequenced packets that are tracked to provide anti-replay protection.

You must be logged in as the HSM SO to use this command.

About the Replay Window

All packets sent over the STC link are sequenced and tracked. This allows the receiver to reject old or duplicate packets, thus preventing an attacker from attempting to insert or replay packets on the link. STC employs a sliding window for replay prevention. The receiver remembers which packets it has received within the specified window, and rejects any packets that have already been received or that are older than the oldest packet in the window. Some flexibility is allowed in accepting packets ahead of the sequence window, as valid packets in a short range ahead of the window cause the window to slide forward.



Note: Each STC packet corresponds to a single command. That is, each command sent to the HSM is encapsulated within a single STC packet.

Syntax

stc replaywindow set **-partition** <partition_name> **-size** <number_of_packets>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition.
-size <number_of_packets>	-s <number_of_packets>	Specifies the number of packets (commands) in the replay window. Range: 100-1000 Default: 120

Example

```
lunash:> stc replaywindow set -par mapleleaves -size 500
```

Successfully changed the size of the replay window for partition mapleleaves to 500 commands.

stc replaywindow show

Display the size of the packet replay window for an STC link. This value specifies the number of packets in the window of sequenced packets that are tracked to provide anti-replay protection.

You must be logged in as the HSM SO to use this command.

About the Replay Window

All packets sent over the STC link are sequenced and tracked. This allows the receiver to reject old or duplicate packets, thus preventing an attacker from attempting to insert or replay packets on the link. STC employs a sliding window for replay prevention. The receiver remembers which packets it has received within the specified window, and rejects any packets that have already been received or that are older than the oldest packet in the window. Some flexibility is allowed in accepting packets ahead of the sequence window, as valid packets in a short range ahead of the window cause the window to slide forward.



Note: Each STC packet corresponds to a single command. That is, each command sent to the HSM is encapsulated within a single STC packet.

Syntax

stc replaywindow show -partition <partition_name>

Parameter	Shortcut	Description
-partition <partition_name>	-p <partition_name>	Specifies the name of the partition for which you want to display the STC replay window.

Example

```
lunash:> stc replaywindow show -par mapleleafs
```

The current replay window size for partition mapleleafs is 500 commands.

sysconf

Access commands that allow you to configure the appliance.

Syntax

sysconf

appliance
 config
 drift
 fingerprint
 hwregencert
 ntp
 radius
 regencert
 securekeys
 snmp
 ssh
 time
 timezone

Parameter	Shortcut	Description
appliance	a	Access commands that allow you to manage the appliance. See "sysconf appliance" on page 368 .
config	c	Access the system configuration commands. See "sysconf config" on page 389 .
drift	d	Access commands that allow you to view and configure the drift. See "sysconf drift" on page 401 .
fingerprint	f	Display the certificate fingerprints. See "sysconf fingerprint" on page 408 .
hwregencert	h	Generate or re-generate the SafeNet appliance server hardware certificate . See "sysconf hwregencert" on page 417
ntp	n	Access commands that allow you to view or configure the network time protocol (NTP). See "sysconf ntp" on page 420 .
radius	ra	Manage RADIUS configuration and identify RADIUS servers to use for enhanced authentication, authorization, and accounting of your SafeNet appliance users and roles "sysconf radius " on page 449 .
regenCert	re	Generate or re-generate the SafeNet appliance server hardware certificate. See "sysconf regencert" on page 453 .
securekeys	se	Move the SafeNet keys used to secure the NTLS link from the SafeNet appliance's file system into the HSM. See "sysconf securekeys" on page 455 .

Parameter	Shortcut	Description
snmp	sn	Access commands that allow you to view or configure the Simple Network Management Protocol (SNMP) settings for SafeNet appliance. See " sysconf snmp " on page 456.
ssh	ss	Access commands that allow you to view or configure the SSH options on the appliance. See " sysconf ssh " on page 479.
time	t	Set or display the time and date. See " sysconf time " on page 491.
timezone	timez	Set or display the time zone. See " sysconf timezone " on page 492.

sysconf appliance

Access the **sysconf appliance** commands to manage the appliance.

Syntax

sysconf appliance

cpugovernor
hardreboot
poweroff
reboot
rebootonpanic
watchdog

Parameter	Shortcut	Description
cpugovernor	c	System CPU on-demand governor. See "sysconf appliance cpugovernor" on the next page.
hardreboot	h	Reboot the appliance, bypassing graceful closing of services. See "sysconf appliance hardreboot" on page 373.
poweroff	p	Power off the appliance. See "sysconf appliance poweroff" on page 374.
reboot	r	Reboot the appliance. See "sysconf appliance reboot" on page 375.
rebootonpanic	rebooto	System reboot on panic. See "sysconf appliance rebootonpanic " on page 376.
watchdog	w	System watchdog. See "sysconf appliance watchdog" on page 380.

sysconf appliance cpugovernor

Access the sysconf appliance governor commands to enable or disable the CPU governor and view the current CPU governor status.

Syntax

The following subcommands are available:

Parameter	Shortcut	Description
disable	d	Disable the CPU governor. See "sysconf appliance cpugovernor disable" on the next page.
enable	e	Enable the CPU governor. See "sysconf appliance cpugovernor enable" on page 371.
show	s	Display CPU governor information. See "sysconf appliance cpugovernor show" on page 372.

sysconf appliance cpugovernor disable

Disable the system CPU on-demand governor. The system contains a CPU governor that lowers the clock frequency to save power in times of low demand. Once in a lower-demand state, as the demand on the processor increases, the governor returns the CPU clock frequency to its former setting. This command disables that function.

Syntax

sysconf appliance cpuGovernor disable

Example

```
lunash:>sysconf appliance cpuGovernor disable
```

```
Command Result : 0 (Success)
```

sysconf appliance cpugovernor enable

Enable the system CPU on-demand governor. The system contains a CPU governor that lowers the clock frequency to save power in times of low demand. Once in a lower-demand state, as the demand on the processor increases, the governor returns the CPU clock frequency to its former setting. This command enables that function.

Syntax

sysconf appliance cpugovernor enable

Example

```
lunash:>sysconf appliance cpuGovernor enable
```

```
Command Result : 0 (Success)
```

sysconf appliance cpugovernor show

Display the system CPU governor configuration status

Syntax

```
sysconf appliance cpugovernor show
```

Example

```
lunash:>sysconf appliance cpugovernor show
```

```
System CPU ondemand governor is enabled.
```

```
Command Result : 0 (Success)
```

sysconf appliance hardreboot

Perform a hard restart (reboot) of the SafeNet appliance.

When you do not have convenient physical access to your SafeNet appliances, this command replaces the "sysconf appliance reboot" command (see "[sysconf appliance reboot](#)" on page 375) which performs an orderly soft reboot sequence by ordering a large number of services/daemons to conclude their operations, and logs that process. That is the preferred method of rebooting a SafeNet Network HSM appliance, if you have physical access and can retry in case any of the processes hangs and prevents the soft reboot sequence from proceeding.

Use the **sysconf appliance hardreboot** command when the appliance is not accessible for physical intervention (such as in a secluded, lights-off facility), if needed. This command bypasses many running processes at shutdown, allowing the reboot to occur without hanging.

Syntax

sysconf appliance hardreboot [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf appliance hardReboot
WARNING !! This command will reboot the appliance without gracefully shutting down.
        All clients will be disconnected.
If you are sure that you wish to proceed, then type 'proceed',
otherwise type 'quit'
    > proceed

login as: admin
admin@192.20.11.22's password:
Last login: Fri Nov 22 10:20:25 2013 from 172.20.10.106

SafeNet Network HSM 5.4.0-5 Command Line Shell - Copyright (c) 2001-2013 SafeNet, Inc. All
rights reserved.

[local_host] lunash:>
[local_host] lunash:>
>
```

sysconf appliance poweroff

Power off the SafeNet Network HSM appliance.

Appliance reboot and power-off automatically take a snapshot of the system's known state so that a customer can later send that to SafeNet for further investigation. This is useful if the system is not behaving and needs reboot or power-off.

Syntax

sysconf appliance poweroff [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf appliance poweroff
    WARNING !! This command will power off the appliance.
All clients will be disconnected and the appliance will require a manual power on for further
access.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'> proceed
Proceeding...
'hsm supportInfo' successful.
Use 'scp' from a client machine to get file named:
supportInfo.txt
Broadcast message from root (pts/0) (Wed Aug 18 20:05:22 2010):
The system is going down for system halt NOW!
Power off commencing
```

sysconf appliance reboot

Performs a warm restart (reboot) of the SafeNet appliance, shutting down all running processes in a controlled manner.

Appliance reboot and power-off automatically take a snapshot of the system's known state so that a customer can later send that to SafeNet for further investigation. This is useful if the system is not behaving and needs reboot or power-off.

To deal with the possibility that a controlled shutdown might not be possible, see "[sysconf appliance rebootonpanic enable](#)" on page 378.

Syntax

sysconf appliance reboot [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf appliance reboot
WARNING !! This command will reboot the appliance.
    All clients will be disconnected.
If you are sure that you wish to proceed, then type 'proceed',
otherwise type 'quit'
    > proceed
Proceeding...
'hsm supportInfo' successful.
    Use 'scp' from a client machine to get file named:
supportInfo.txt
    Broadcast message from root (pts/0) (Wed Aug 18 20:05:22 2010):
    The system is going down for reboot NOW!
Reboot commencing
Command Result : 0 (Success)
[myluna] lunash:>
```

sysconf appliance rebootonpanic

Access commands that allow you to enable or disable reboot on panic and show reboot on panic information.

Syntax

sysconf appliance rebootonpanic

disable
enable
show

The following subcommands are available:

Parameter	Shortcut	Description
disable	d	Disable system reboot on panic. See "sysconf appliance rebootonpanic disable" on the next page.
enable	e	Enable system reboot on panic. See "sysconf appliance rebootonpanic enable" on page 378.
show	s	Show system reboot on panic information. See "sysconf appliance rebootonpanic show " on page 379.

sysconf appliance rebootonpanic disable

Disable system automatic reboot on kernel panic.

Syntax

sysconf appliance rebootonpanic disable

Example

```
lunash:>sysconf appliance rebootOnPanic disable
```

```
Command Result : 0 (Success)
```

sysconf appliance rebootonpanic enable

Enable automatic reboot in case of problem.

In normal situations, the command "[sysconf appliance reboot](#)" on [page 375](#) causes the appliance to shut down in a controlled manner.

This command (`sysconf appliance rebootonpanic enable`) configures the SafeNet appliance to automatically reboot in the event that the appliance fails to complete a normal shutdown. In conjunction with the `AutoActivation` setting, this option can allow SafeNet HSM cryptographic service to resume after a problem, without need for human intervention.

Syntax

sysconf appliance rebootonpanic enable

Example

```
lunash:>sysconf appliance rebootOnPanic enable
```

```
Command Result : 0 (Success)
```

sysconf appliance rebootonpanic show

Display the reboot-on-panic configuration status.

Syntax

sysconf appliance rebootonpanic show

Example

```
lunash:>sysconf appliance rebootonpanic show
```

```
System auto reboot on panic is enabled.
```

```
Command Result : 0 (Success)
```

sysconf appliance watchdog

Access commands that allow you to enable or disable the system watchdog and show system watchdog information.

Syntax

sysconf appliance watchdog

disable
enable
show

The following subcommands are available:

Parameter	Shortcut	Description
disable	d	Disable the system watchdog. See "sysconf appliance watchdog disable" on the next page.
enable	e	Enable the system watchdog. See "sysconf appliance watchdog enable " on page 382.
show	s	Show system watchdog information. See "sysconf appliance watchdog show" on page 383.

sysconf appliance watchdog disable

Disable the system watchdog. The system contains a standard hardware watchdog circuit that constantly monitors the CPU. If the CPU fails to show signs of life, the watchdog can independently trigger a system reboot. This command disables that function.

When the watchdog is enabled (`sysconf appliance watchdog enable`), look for the following syslog message:

```
kernel: iTCO_wdt: initialized. heartbeat=30 sec (nowayout=0)
```

When it is disabled (`sysconf appliance watchdog disable`), look for this log entry

```
kernel: iTCO_wdt: Watchdog Module Unloaded.
```

The absence of these messages on a `sysconf appliance watchdog enable` and `sysconf appliance watchdog disable` suggests that the watchdog timer device driver did not load successfully at power up.

Syntax

sysconf appliance watchdog disable

Example

```
lunash:>sysconf appliance watchdog disable
```

```
Command Result : 0    (Success)
```

sysconf appliance watchdog enable

Enable the system watchdog. The system contains a standard hardware watchdog circuit that constantly monitors the CPU. If the CPU fails to show signs of life, the watchdog can independently trigger a system reboot. This command enables that function.

When the watchdog is enabled (sysconf appliance watchdog enable), look for the following syslog message:

```
kernel: iTCO_wdt: initialized. heartbeat=30 sec (nowayout=0)
```

When it is disabled (sysconf appliance watchdog disable), look for this log entry

```
kernel: iTCO_wdt: Watchdog Module Unloaded.
```

The absence of these messages on a sysconf appliance watchdog enable and sysconf appliance watchdog disable suggests that the watchdog timer device driver did not load successfully at power up.

Syntax

sysconf appliance watchdog enable

Example

```
lunash:>sysconf appliance watchdog enable
```

```
Command Result : 0 (Success)
```

sysconf appliance watchdog show

Show the system watchdog configuration status.

Syntax

sysconf appliance watchdog show

Example

```
lunash:>sysconf appliance watchdog show
```

```
System watchdog is enabled.
```

```
Command Result : 0 (Success)
```

sysconf banner

Access the sysconf banner commands to set and clear an extended text banner, displayed to appliance administrative users when they log into a LunaSH session.

Syntax

sysconf banner

add
clear

Parameter	Shortcut	Description
add	a	Add extended banner text from a file. See " sysconf banner add " on the next page .
clear	c	Clear the extended banner text. See " sysconf banner clear " on page 387.

sysconf banner add

Add a custom text banner that is displayed when administrative users connect and log into the appliance. The text is initially obtained from a file. The file must already have been uploaded to the appliance's admin user, via scp/pscp.

Only the "admin" user can perform this operation. The command is not available to "operator".

A single extended banner is set for all users who log in; it is not possible to set different banners for different users or classes of users.

Use the command **user file list** to view available files and verify the name of the desired banner file.

The banner file size is limited to 8KB.

The banner filename is limited to characters a-z, A-Z, 0-9, '.', '-' or '_'.

For the banner text within the file, only standard ASCII characters are accepted (characters between 0 and 127 in <http://www.asciitable.com/>).

You must be logged into the HSM before issuing the command **sysconf banner add -file <filename>**

Syntax

sysconf banner add -file <filename>

Parameter	Shortcut	Description
-file	-f <filename>	Banner text file name.

Example

```
[myluna] lunash:>my file list
```

```
    248 Nov  4 12:10 banner2.txt
    213 Nov  4 12:00 banner1.txt
  323902 Nov  4 11:31 supportInfo.txt
    10505 Nov  4 11:29 update5_4_0_4.log
    127067 Oct 15 15:55 fwupdateInfo.txt
```

```
Command Result : 0 (Success)
```

```
[myluna] lunash:>sysconf banner add -file banner2.txt
```

```
Please login as HSM Admin first!
```

```
Command Result : 65535 (Luna Shell execution)
```

```
[myluna] lunash:>hsm login
```

```
Luna PED operation required to login as HSM Administrator - use Security Officer (blue) PED key.
```

```
'hsm login' successful.
```

```
Command Result : 0 (Success)
```

```
[myluna] lunash:>
```

```
[myluna] lunash:>sysconf banner add -file banner2.txt
```

```
Command Result : 0 (Success)
[myluna] lunash:> exit
```

```
login as: admin
admin@192.20.9.22's password:
Last login: Mon Nov  4 13:17:21 2013 from 192.20.11.20
```

```
SafeNet Network HSM 5.4.0-1 Command Line Shell - Copyright (c) 2001-2013 SafeNet, Inc.
All rights reserved.
```

```
* * * * W A R N I N G ! * * * *
```

```
Your use of this resource is monitored and
recorded for security and for quality-control
purposes.
```

```
* * * * * * * * * * * * * * * * * * * *
```

```
[local_host] lunash:>
```

sysconf banner clear

Remove a custom text banner that is displayed when administrative users connect and log into the appliance. The extended text was previously added from a file with the command **sysconf banner add -file <filename>**. If you wish to change an existing extended banner, simply re-issue the "add" command, naming a file with the new text. This command (**sysconf banner clear**) simply clears any extended banner text completely, with no replacement.

Only the "admin" user can perform this operation. The command is not available to "operator".

You must be logged into the HSM before issuing the command **sysconf banner clear**

Syntax

sysconf banner clear [-force]

Parameter	Shortcut	Description
-force	-f	Force the action (useful for scripting).

Example

```
login as: admin
admin@192.20.9.22's password:
Last login: Mon Nov  4 15:20:14 2013 from 192.20.10.109
SafeNet Network HSM 5.4.0-1 Command Line Shell - Copyright (c) 2001-2013 SafeNet, Inc. All
rights reserved.
```

```
* * * * W A R N I N G ! * * * *
Your use of this resource is monitored and
recorded for security and for quality-control
purposes.
Have a nice day.
* * * * * * * * * * * * * * * *
```

```
[myluna] lunash:>
[myluna] lunash:>sysconf banner clear
```

```
WARNING !! This command will clear the extended banner text.
If you are sure that you wish to proceed, then enter 'proceed', otherwise this command will
abort.
```

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

```
[myluna] lunash:>
```

```
login as: operator
operator@192.20.9.22's password:
Last login: Mon Nov  4 15:18:15 2013 from 192.20.10.109
SafeNet Network HSM 5.4.0-1 Command Line Shell - Copyright (c) 2001-2013 SafeNet, Inc. All
rights reserved.
```

```
[myluna] lunash:>
```

sysconf config

Access the system configuration commands. This command manages the various configuration files that are created and modified when you set up various system elements such as NTLS, SSH, NTP, SNMP, etc.

Syntax

sysconf config

backup
clear
delete
export
factoryreset
import
list
restore
show

Parameter	Shortcut	Description
backup	b	Backs up configuration data. See "sysconf config backup" on the next page.
clear	c	Deletes all the configuration backup files except the initial factory configuration file. See "sysconf config clear" on page 391.
delete	d	Deletes a configuration backup file. See "sysconf config delete" on page 392.
export	e	Exports a configuration backup file. See "sysconf config export" on page 393.
factoryreset	f	Factory reset. See "sysconf config factoryreset" on page 395.
import	i	Imports a configuration backup file. See "sysconf config import" on page 394.
list	l	List configuration backup files. See "sysconf config list" on page 398.
restore	r	Restores configuration backup. See "sysconf config restore" on page 399.
show	s	Show the current configuration. See "sysconf config show" on page 400.

sysconf config backup

Backs up configuration data. This command creates a backup of the configuration of the following modules and services:

- user accounts and files
- network settings
- syslog settings
- NTP settings
- SNMP settings
- SSH settings
- NTLS settings
- keys and certificates.

It does not include the HSM and partition configurations. You can save the backup file to the internal HSM, or an external backup token using the **sysconf config export** command.

Syntax

sysconf config backup -description <comment>

Parameter	Shortcut	Description
-description	-d	Comment describing this backup. The description must enclosed in double quotes if it contains spaces.

Example

```
lunash:>sysconf config backup -description mybackup2
Created configuration backup file: smyluna_Config_20120221_1725.tar.gz.
```

```
Command Result : 0 (Success)
```

sysconf config clear

Delete all the configuration backup files in the file system, in the internal HSM, or in an external backup token. This command does not delete the initial factory configuration file in the file system.

If the `-deviceType` parameter is not specified, the files in the file system are deleted.

`-serialNumber` is required if `-deviceType` is "token" and optional if `-deviceType` is "hsm".

`-serialNumber` is not required and is ignored if `-deviceType` is not specified.

SO login is required before running this command if `-deviceType` is "hsm" or "token".

Syntax

sysconf config clear [-force]

Parameter	Shortcut	Description
-deviceatypescription	-d <devicetype>	Comment describing this backup
-force	-f	Force the action without prompting.
-serialNumber	-s <serialnum>	Token Serial Number

Example

```
lunash:>sysconf config clear
```

```
WARNING !! This command deletes all the configuration backup files except the initial factory configuration file.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
```

```
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf config delete

Delete a configuration backup file.

Syntax

```
sysconf config delete -file <filename> [-deviceType <devicetype>] [-serialnumber <serialnum>] [-force]
```

Parameter	Shortcut	Description
-devicetype	-d <devicetype>	Device Type (hsm, token)
-file	-fi <filename>	File Name to delete
-force	-fo	Force Action (no prompting for confirmation)
-serialnumber	-s <serialnum>	Token Serial Number

Example

```
lunash:>sysconf config delete -file myluna_Config20101021_2015.tar.gz
```

```
WARNING !! This command deletes the configuration backup file: myluna_Config_20101021_2015.tar.gz.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
> proceed
```

```
Proceeding...
```

```
Command Result : 0 (Success)
```


sysconf config export

Exports a configuration backup file from the file system to the internal HSM, or to an external backup token. This command overwrites the existing configuration file with the same name.

-serialNumber is required if -deviceType is "token" and optional if -deviceType is "hsm".

SO login is required before running this command if -deviceType is "hsm" or "token".

Syntax

sysconf config export -file <filename> [-devicetype <devicetype>] [-serialnumber <serialnum>] [-force]

DESCRIPTION

Parameter	Shortcut	Description
-devicetype	-d <devicetype>	Device Type (hsm, token)
-file	-fi <filename>	File Name to delete
-force	-fo	Force Action (no prompting for confirmation)
-serialnumber	-s <serialnum>	Token Serial Number

Example

```
[myluna] lunash:>sysconf config export -file myluna_Config20101021_2015.tar.gz
-devicetype hsm
WARNING !! This command exports the configuration backup file: factoryInit_local_host_Con-
fig.tar.gz to the hsm.
It will overwrite the existing configuration file with the same name on the hsm.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'..
> proceed

Proceeding...

Command Result : 0 (Success)
```

sysconf config import

Import a configuration backup file from the internal HSM or from an external backup HSM and saves it as a file. This command overwrites the existing configuration file with the same name.

This command does NOT restore the configuration from the imported file. You can use the "sysconf config restore" command after running this command to restore the configurations.

-serialNumber is required if -deviceType is "token" and optional if -deviceType is "hsm".

SO login is required before running this command if -deviceType is "hsm" or "token".

Syntax

sysconf config import -file <filename> [-devicetype <devicetype>] [-serialnumber <serialnum>] [-force]

Parameter	Shortcut	Description
-devicetype	-d <devicetype>	Device Type (hsm, token)
-file	-fi <filename>	File Name to delete
-force	-fo	Force the action without prompting.
-serialnumber	-s <serialnum>	Token Serial Number

Example

```
lunash:>sysconf config import -file myluna_Config20101021_2015.tar.gz
-devicetype hsm
WARNING !! This command imports the configuration backup file: factoryInit_local_host_Con-
fig.tar.gz from the hsm.
```

It will overwrite the existing configuration file with the same name.

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
> proceed
```

```
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf config factoryreset



CAUTION: Do not use this command if you have updated from a SafeNet Network HSM 5.x version to SafeNet 6.x version. It can fail badly. See "Optional Configuration Tasks" on page 1 and the heading "Do not use 'sysconf config factoryReset' After 6.x Update" for discussion of what to do with commands **sysconf config backup** and **sysconf config restore** instead.

Reset the appliance to the settings created at the factory. This is the same action as running the **sysconf config restore** command on the 'factoryInit_local_host...' file. You can specify any individual service's configuration, or just reset all of them to the initial factory settings with the '-all' option. This reset is for the configurations of the indicated services and does not affect the HSM.

This command affects appliance settings external to the HSM. To reset the HSM, use **hsm factoryReset** (which can be run from a local serial console only).



Note: To reset the configuration for the NTLS service, you must first stop this service (**service stop ntl**).

Syntax

sysconf config factoryReset -service <service> [-force]

Parameter	Shortcut	Description
-force	-fo	Force the action without prompting.
-service	-s	Specifies the service name. Valid values: network,ssh,NTLS,syslog,ntp,snmp,users,system,all

Example

```
lunash:> [local_host] lunash:>sysconf config list
```

```
Configuration backup files in file system:
```

```
Size      | File Name                                     | Description
-----
8075     | factoryInit_local_host_Config.tar.gz       | Initial Factory Settings
```

```
Command Result : 0 (Success)
```

```
[local_host] lunash:>sysconf config factoryReset -service all
```

This command restores the initial factory configuration of service: all.
The HSM and Partition configurations are NOT included.

This command restores the previous configurations from the backup file: factoryInit_local_host_Config.tar.gz

WARNING !! This command restores the configuration backup file: factoryInit_local_host_Config.tar.gz.
It first creates a backup of the current configuration before restoring: factoryInit_local_host_Config.tar.gz.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.

```
> proceed
Proceeding...
```

Created configuration backup file: local_host_Config_20150925_1110.tar.gz

Restore the ntlm configuration: Succeeded.

Restore the network configuration: Succeeded.

Restore the syslog configuration: Succeeded.

Force option used. Proceed prompt bypassed.
All key and certificates files were deleted.
You must restart NTP for the changes to take effect.
Check NTP status after restarting it to make sure that the client is able to start and sync with the server.

Restore the ntp configuration: Succeeded.

Restore the snmp configuration: Succeeded.

Restore the ssh configuration: Succeeded.

Restore the users configuration: Succeeded.

Restore the system configuration: Succeeded.

You must either reboot the appliance or restart the service(s) for the changes to take effect.
Please check the new configurations BEFORE rebooting or restarting the services.
You can restore the previous configurations if the new settings are not acceptable.

Command Result : 0 (Success)



Note: Sometimes individual items can show in the output as having failed to reset, but the overall command succeeds. This is not an error.

It occurs simply because some of the configuration items might already be at factory default



settings and had never been configured. For example, not everybody configures NTP or SNMP. Therefore, no file of configuration settings for the particular service was ever created, and there was nothing for the **sysconf config factoryReset** command to do in those cases. This sometimes happens in integration laboratory environment.

sysconf config list

Show the list of configuration backup files.

Syntax

sysconf config list

Example

lunash:>sysconf config list

Size	Filename	Description
30411	myluna_Config_20090930_0934.tar.gz	Automatic Backup Before Restore
30397	myluna2_Config_20090930_0925.tar.gz	MyBackup
18400	factoryInit_local_host_Config_20011231_1901.tar.gz	Initial Factory Settings
25179	myluna2_Config_20100907_2122.tar.gz	Joe Backup 1

sysconf config restore

Restore configuration of the selected services from a backup file. The service(s) must be stopped before restoring their configuration. This command does not restore the HSM and Partition configurations.

You must reboot the appliance for the changes to take effect.

Please check the new configurations BEFORE rebooting or restarting the services.

It automatically creates a backup file of the current configurations before restoring a previous configuration. You can restore the previous configurations if the new settings are not acceptable.

Syntax

sysconf config restore -file <filename> -service <service> [-force]

Parameter	Shortcut	Description
-file	-fi	File name
-force	-fo	Force the action without prompting.
-service	-s	The service name. Valid values: network,ssh,NTLS,syslog,ntp,snmp,users,system,all

Example

```
[myluna] lunash:>sysconf config restore -file SA76_test_Config_20111104_1018.tar.gz -service users
```

```
WARNING !! This command restores the configuration backup file: SA76_test_Config_20111104_1018.tar.gz.
```

```
It first creates a backup of the current configuration before restoring: SA76_test_Config_20111104_1018.tar.gz.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
```

```
Proceeding...
```

```
Created configuration backup file: SA76_test_Config_20111104_1020.tar.gz
```

```
Restore the users configuration: Succeeded.
```

```
You must either reboot the appliance or restart the service(s) for the changes to take effect.
```

```
Please check the new configurations BEFORE rebooting or restarting the services.
```

```
You can restore the previous configurations if the new settings are not acceptable.
```

```
Command Result : 0 (Success)
```

sysconf config show

Shows the system information of a configuration backup file.

Syntax

sysconf config show -file <filename>

Show system config file information

Parameter	Shortcut	Description
-file	-fi	File name

Example

```
lunash:>sysconf config show -file myluna_Config_20090930_0925.tar.gz
```

System information when this backup was created:

```
hostname: myluna
eth0 IP Address: 172.20.11.21
eth1 IP Address: 192.168.254.1
Software Version: SafeNet Network HSM 5.1.0-25 [Build Time: 20120224 16:07]
HSM Firmware Version: 6.0.8
HSM Serial Number: 696910
uptime: 09:25:07 up 3 days, 9:50, 2 users, load average: 0.09, 0.12, 0.09
Current time: Fri Feb 24 09:25:07 IST 2012
Description: MyBackup
```

```
Command Result : 0 (Success)
```


sysconf drift

Access the sysconf drift commands to view and configure drift.

Syntax

sysconf drift

init
reset
set
startmeasure
status
stopmeasure

Parameter	Shortcut	Description
init	i	Activate automatic drift adjustments. See "sysconf drift init" on the next page.
reset	r	Reset all drift tracking data. See "sysconf drift reset" on page 403.
set	se	Manually set internal drift data. See "sysconf drift set" on page 404.
startmeasure	star	Set the time and start measuring. See "sysconf drift startmeasure" on page 405.
status	stat	Display the current drift data. See "sysconf drift status" on page 406.
stopmeasure	sto	Stop measuring and record the drift. See "sysconf drift stopmeasure" on page 407.

sysconf drift init

Sets the time, and activates the automatic periodic drift adjustments. This is done after you have completed a period of drift measurement with the **sysconf drift startmeasure** and **sysconf drift stopmeasure** commands, with at least an uninterrupted three day measurement period between the start and stop, to calculate the baseline of drift.

Syntax

```
sysconf drift init -currentprecisetime <currentprecisetime>
```

Parameter	Shortcut	Description
-currentprecisetime	-c	Current best precise time in hh:mm:ss format.

Example

```
lunash:>sysconf drift init -c 18:29:01
```

Measuring drift correction data on this appliance.

Setting the time to 18:29:01 and initializing drift correction of 5 seconds per day on this appliance. The time will be adjusted daily to compensate for this drift.

Use the command 'sysconf drift reset' to disable drift correction.

```
Date and time set to: Thu April 7 18:29:01 EDT 2011
```

```
Command Result : 0 (Success)
```

The following is the response if you did not run **sysconf drift startmeasure** and allow measurement for sufficient time before initializing drift correction.

```
lunash:>sysconf drift init -currentprecisetime 13:51:01
```

Measuring drift correction data on this appliance.

```
Error: unable to initialize drift correction. The internal data containing
drift values can not be found.
```

Ensure that the proper data acquisition steps were followed.

```
Command Result : 0 (Success)
```

sysconf drift reset

Reset drift and internal drift tracking data.

Syntax

sysconf drift reset [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting

Example

```
lunash:>sysconf drift reset
```

If you are sure that you wish to clear all data relating to drift correction, then type 'proceed', otherwise type 'quit'

```
> proceed
```

```
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf drift set

Manually set the internal drift measurement data.

Syntax

```
sysconf drift set
```

Example

```
lunash:>sysconf drift set
```

```
Enter the value to be used for drift (in seconds per day): 3
```

```
This value will overwrite the previous value of the drift that may have  
been measured. If you are sure that you wish to overwrite it, then type  
'proceed', otherwise type 'quit'  
> proceed
```

```
Proceeding...
```

```
NOTE: The new value will not take effect until 'sysconf drift init' is run.  
Command Result : 0 (Success)
```

sysconf drift startmeasure

Sets the time, and starts measuring drift.

Syntax

sysconf drift startmeasure -currentprecisetime <currentprecisetime>

Parameter	Shortcut	Description
-currentprecisetime	-c	Current best precise time in hh:mm:ss format.

Example

```
[myLuna] lunash:>sysconf drift startmeasure -c 13:53:01
```

```
Setting the time to 13:53:01 and recording data for drift correction mechanism.
Current date and time set to: Tue April 5 13:53:01 EDT 2011
```

```
Command Result : 0 (Success)
```

sysconf drift status

Display the status of the current drift data.

Syntax

sysconf drift status

Example

```
lunash:>sysconf drift status
  Drift measurement started on:  Fri Apr  8 14:47:00 EDT 2011
  Measurement has yet to be stopped.
  Current drift correction is:    4 seconds per day
  (Note that drift correction may be manually set.)
```

Command Result : 65535 (Luna Shell execution)

The following is the result if **sysconf drift startmeasure** was not run before this command.

```
lunash:>sysconf drift status
```

```
Internal configuration data indicates that drift measurement was never started.
No drift correction is in effect.
```

Command Result : 65535 (Luna Shell execution)

sysconf drift stopmeasure

Stops measuring and records the drift.

Syntax

sysconf drift stopmeasure -currentprecisetime <currentprecisetime>

Parameter	Shortcut	Description
-currentprecisetime	-c	Current best precise time in hh:mm:ss format.

Example

```
lunash:>sysconf drift drift stopmeasure -currentprecisetime 18:40:37
```

```
Measuring drift correction data on this appliance.
Storing measured drift of 12 seconds/day in internal configuration files.
Use the command 'sysconf drift init' to initialize drift correction.
```

```
Command Result : 0 (Success)
```

sysconf fingerprint

This command displays the system's certificate fingerprints for use when ensuring that ssh connections are being made to the correct host, or that the correct server certificate was brought to a client.

Specify if you wish to see the ssh certificate fingerprint or the NTLS certificate fingerprint. The NTLS certificate is created using the sha256WithRSAEncryption algorithm.

Syntax

sysconf fingerprint {ssh | ntl}

Parameter	Shortcut	Description
ssh	s	Display the fingerprint of the SSH certificate. (Compare this with the value presented by the SSH client upon first SSH to the SafeNet appliance admin interface.) See " sysconf fingerprint ssh " on page 410.
ntls	n	Display the fingerprint of the NTLS certificate. (On the client side, you can compare this with the value returned from <code>vtl fingerprint -f server.pem</code>) See " sysconf fingerprint ntl " on the next page.

sysconf fingerprint ntl

This command displays the system's certificate fingerprints for use when ensuring that the correct server certificate was brought to a client.

Syntax

sysconf fingerprint ntl

Parameter	Shortcut	Description
ntls	n	Display the fingerprint of the NTLS certificate. (On the client side, you can compare this with the value returned from <code>vtl fingerprint -f server.pem</code>)

Example

```
[mylunasa6] lunash:>sysconf fingerprint ntl
```

```
NTLS server certificate fingerprint: DC:0E:23:36:7E:E4:76:39:09:85:13:4C:76:FE:87:EC:86:DD:89:3D
```

```
Command Result : 0 (Success)
```

sysconf fingerprint ssh

This command displays the system's certificate fingerprint for use when ensuring that ssh connections are being made to the correct host.

Syntax

sysconf fingerprint ssh

Parameter	Shortcut	Description
ssh	s	Display the fingerprint of the SSH certificate. (Compare this with the value presented by the SSH client upon first SSH to the SafeNet appliance admin interface.)

Example

```
[mylunasa6] lunash:>sysconf fingerprint ssh
```

```
SSH Server Public Keys
```

```
Type    Bits  Fingerprint
```

```
-----
RSA      2048  26:29:d8:bf:23:cd:22:82:28:38:1c:01:d3:12:5c:d2
DSA      1024  d7:67:26:db:f3:f8:46:2c:5b:db:dd:6a:7c:c0:5a:29
ECDSA    256   13:9b:0c:01:22:5c:86:b5:99:66:b6:6f:10:49:58:4d
```

```
Command Result : 0 (Success)
```

sysconf forcesologin

Access commands that allow you to enable or disable SO login enforcement, or display the current SO login enforcement setting.

When SO login enforcement is enabled, access to some lunash commands is restricted to the HSM SO. See "[sysconf forcesologin enable](#)" on page 414 for a list of the affected commands.

Syntax

sysconf forcesologin

disable
enable
show

Parameter	Shortcut	Description
disable	d	Disable SO login enforcement. See " sysconf forcesologin disable " on page 413 (*).
enable	e	Enable SO login enforcement. See " sysconf forcesologin enable " on page 414 (**).
show	s	Display the current SO login enforcement setting. See " sysconf forcesologin show " on page 416.

(* On successful `hsm factoryReset` or `sysconf config factoryReset` (option "all") the SafeNet Network HSM Administrator Login Enforcement feature is reset to "disabled".)

(** If the HSM is not initialized, then the SafeNet Network HSM SO Login Enforcement feature cannot be enabled or disabled.)

Most SafeNet Network HSM lunash commands, except time- and partition-specific ones do not require HSM Security Officer (also known as HSM Administrator) to be logged in. The SafeNet Network HSM SO Login Enforcement option functions as follows:

- Only the SO can enable SafeNet Network HSM SO Login Enforcement.
- When enabled, the feature verifies that HSM SO is logged in before authorizing the operations described below.
- Only HSM Administrator can disable SafeNet Network HSM SO Login Enforcement.

Affected commands

The affected commands include all commands that can have an effect on the HSM, its partitions, or application access to the partitions. (Items that are solely appliance-level features generally are not affected.)

client

- `client assignPartition`
- `client revokePartition`
- `client register`
- `client delete`

- client hostip map
- client hostip unmap

ntls

- ntls bind
- ntls activateKeys
- ntls deactivateKeys
- ntls sslOpsAll
- ntls sslOpsRSA
- ntls information reset
- ntls certificate monitor enable
- ntls certificate monitor disable
- ntls certificate monitor trap trigger
- ntls tcp_keepalive set
- ntls timer set
- ntls threads set
- ntls ipcheck enable
- ntls ipcheck disable

htl

- htl clearOtt
- htl generateOtt
- htl set gracePeriod
- htl set ottExpiry
- htl set defaultOttExpiry

sysconf

- sysconf regenCert
- sysconf hwRegenCert
- sysconf secureKeys

sysconf forcesologin disable

Disable SO login enforcement.



Note: You must be logged in as the HSM SO to execute this command.



Note: The HSM must be initialized before you can execute this command. See "hsm init" on page 93 for more information.



Note: The SO login enforcement setting persists backup and restore operations.

Syntax

sysconf forcesologin disable

Example

```
lunash:> sysconf forcesologin disable
```

```
Command Result : 0 (Success)
```

```
lunash:> sysconf forcesologin show
```

```
HSM Administrator Login Enforcement is NOT enabled.
```

```
Command Result : 0 (Success)
```

sysconf forcesologin enable

Enable SO login enforcement. You must be logged in as the HSM SO to execute this command.

SO login enforcement is reset to disabled if the HSM is factory reset using the **hsm factoryReset** or **sysconf config factoryReset** commands. The SO login enforcement setting persists backup and restore operations.



Note: The HSM must be initialized before you can execute this command. See "hsm init" on page 93 for more information.

Affected Commands

When SO login enforcement is enabled, the following commands can be executed by the HSM Administrator only:

Client commands

- "client assignpartition" on page 53
- "client delete" on page 54
- "client hostip map" on page 57
- "client hostip unmap" on page 59
- "client register" on page 61
- "client revokepartition" on page 63

NTLS commands

- "ntls activatekeys" on page 221
- "ntls bind" on page 222
- "ntls certificate monitor disable" on page 226
- "ntls certificate monitor enable" on page 227
- "ntls certificate monitor trap trigger" on page 229
- "ntls deactivatekeys" on page 232
- "ntls information reset" on page 234
- "ntls ipcheck disable " on page 237
- "ntls ipcheck enable" on page 238
- "ntls sslopsall " on page 241
- "ntls sslopsrsa" on page 242
- "ntls tcp_keepalive set" on page 244
- "ntls threads set" on page 248
- "ntls timer set" on page 251

HTL commands

- "htl clearott command" on page 175
- "htl generateott" on page 176

- "htl set defaultottexpiry" on page 178
- "htl set graceperiod" on page 179
- "htl set ottexpiry" on page 180

Sysconf commands

- "sysconf hwregencert" on page 417
- "sysconf regencert" on page 453
- "sysconf securekeys" on page 455

Syntax

sysconf forcesologin enable

Example

```
lunash:> sysconf forcesologin enable

Command Result : 0 (Success)

lunash:> sysconf forcesologin show

HSM Administrator Login Enforcement is enabled.

Command Result : 0 (Success)
```

sysconf forcesologin show

Display the current SO login enforcement setting.

Syntax

sysconf forcesologin show

Example

```
lunash:> sysconf forcesologin show
```

```
HSM Administrator Login Enforcement is enabled.
```

```
Command Result : 0 (Success)
```


sysconf hwregencert

This command generates or re-generates the SafeNet appliance server certificate used for the NTLA in hardware.

If you are using a system with DNS, you should not specify an IP address. If you are using a system that does not use DNS, you should specify the IP address of eth0 so that the certificate will be properly generated.

It is very important that the certificates are properly generated or the NTLA will not work.

This command stores the resulting private and public keys in the HSM, and the certificate generated from them on the file system (hard disk) inside the SafeNet appliance.

If you prefer the additional speed of keys that are stored in the file system, use the command 'sysconf regenCert' instead.

Trade-off

If you use 'sysconf hwRegenCert', the private key exists only on the HSM. Therefore the parts of the NTLS-setup handshake that need the private key take slightly longer to complete. For applications that set up an NTLS link for an extended period and perform multiple crypto operations, the additional overhead is negligible.

For applications that set up the link, perform one operation, tear down the link, then set up another for the next operation, the overhead of storing the private key on the HSM could become noticeable.

Additional Commands Required

To use keys in hardware, the following sequence is necessary:

- at the SafeNet Network HSM, run **sysconf hwRegenCert**
- run **ntls bind**, as required; this also restarts NTLS
- run **ntls activateKeys**, to ensure that the keys in the special partition remain available
- transfer the new server certificate to clients
- at the client, register the new server certificate

As well, if the SafeNet appliance is rebooted/restarted for any reason (secure package update, power failure...) with the NTLS keys in the HSM, you must perform **ntls activateKeys** and **service restart ntl**.

This command generates a new key-pair. If you wish to use existing keys, that you have already created in the file system (not yet stored on the HSM), then you can move your existing keys into the HSM with **sysconf secureKeys**

You must be logged in to use this command.

The keys in hardware feature requires a special container "Cryptoki User" to keep the RSA key pair for NTLS. Even though it shows in the partition list, this container is not meant to be managed by customers directly. Once it is created, you should never need to touch this partition at all.

Syntax

sysconf hwRegenCert [<eth0_ip_address>]

Parameter	Shortcut	Description
<eth0_ip_address>		Provide the IP address of eth0 if the rest of your setup was done without DNS.

Parameter	Shortcut	Description
-days		Specifies the certificate validity period, in days. Range: 1 to 3653
-force		Force the action without prompting.
-startdate		Specifies the certificate validity start date, in numeric year, month, day format with four-digit year (yyyymmdd).

Example

```
[mylunaSA]lunash:>par create -par "Cryptoki User"
```

On completion, you will have this number of partitions: 1

-label: Not provided; using name for label.

Note: This partition is only to be used for NTLS Keys in Hardware.

Type 'proceed' to create the initialized partition, or
'quit' to quit now.

> proceed

Please ensure that you copy the password from the Luna PED and that you keep it in a safe place.

Luna PED operation required to create a partition - use User or Partition Owner (black) PED key.

Luna PED operation required to generate cloning domain on the partition - use Domain (red) PED key.

'partition create' successful.

Command Result : 0 (Success)

```
[mylunaSA] lunash:>sysconf hwRegenCert
```

WARNING !! This command will overwrite the current server certificate and private key.

All clients will have to add this server again with this new certificate.

If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'

> proceed

Proceeding...

NTLS certificate generated. Migrate NTLS private key into HSM hardware..

Enter User Password:

Proceeding to create/migrate keys to "Cryptoki User" with handle 9

Please attend to the PED to activate partition on HSM - use User or Partition Owner (black) PED key.

Success: NTLS keys are in hardware.

'sysconf hwRegenCert' successful. NTLS and/or STC must be (re)started before clients can connect.

Please use the 'ntls show' command to ensure that NTLS is bound to an appropriate network device or IP

address/hostname for the network device(s) NTLS should be active on. Use 'ntls bind' to change this binding if

necessary.

Command Result : 0 (Success)

[mylunaSA] lunash:>ntls activateKeys

Enter User Password:

Please attend to the PED to activate partition on HSM - use User or Partition Owner (black) PED key.

Stopping ntl:OK

Starting ntl:OK

Stopping htl:OK

Starting htl:OK

Command Result : 0 (Success)

[mylunaSA] lunash:>

sysconf ntp

Access the commands used to view and set the network time protocol (NTP) configuration.

Syntax

sysconf ntp

addserver
autokeyauth
deleteserver
disable
enable
listservers
log
ntpdate
show
status
symmetricauth

Parameter	Shortcut	Description
addserver	ad	Add NTP Server. See "sysconf ntp addserver" on the next page.
autokeyauth	au	NTP Autokey Authentication. See "sysconf ntp autokeyauth" on page 422.
deleteserver	de	Delete NTP Server. See "sysconf ntp deleteserver " on page 429.
disable	di	Disable NTP Service. See "sysconf ntp disable" on page 430.
enable	e	Enable NTP Service. See "sysconf ntp enable" on page 431.
listservers	li	List Configured NTP Servers. See "sysconf ntp listservers" on page 432.
log	lo	NTP Log Command. See "sysconf ntp log tail" on page 434.
ntpdate	n	Set date and time using NTP. See "sysconf ntp ntpdate" on page 435.
show	sh	Show NTP Configuration. See "sysconf ntp show" on page 436.
status	st	Get NTP Service Status. See "sysconf ntp status" on page 437
symmetricauth	sy	NTP Symmetric Key Authentication. See "sysconf ntp symmetricauth" on page 439.

sysconf ntp addserver

Add an NTP server.

Syntax

sysconf ntp addserver <hostname_or_ipaddress> [-autokey][[-key <keyid>] [-burst] [-iburst] [-prefer] [-version <version>]

Parameter	Shortcut	Description
<hostname_or_ipaddress>		Specifies the hostname or IP address of the NTP Server.
-autokey	au	Send and receive packets authenticated by the Autokey scheme (not used with key <keyid>).
-burst	de	Send multiple packets when the server is reachable.
-iburst	di	Send out bursts of 8 packets when the server is unreachable.
-key		Specifies the NTP Authentication Keyid (not used with Autokey) Range: 1 to 65535
-prefer	e	Set this server as the preferred server.
-version	li	Specifies the NTP version Valid values: 3 or 4

Example

```
lunash:> sysconf ntp addserver time.nrc.ca
NTP server 'server time.nrc.ca' added.
WARNING !! Server 'time.nrc.ca' added without authentication.
NTP is enabled
Shutting down ntpd:                [ OK ]
Starting ntpd:                      [ OK ]
Please wait to see the result .....
NTP is running
=====
NTP Associations Status:
ind  assid  status  conf  reach  auth  condition  last_event  cnt
=====
1  56579  8011   yes   no  none   reject   mobilize   1
2  56580  8011   yes   no  none   reject   mobilize   1
=====
Please look at the ntp log to see any potential problem.
Command Result : 0 (Success)
```

sysconf ntp autokeyauth

Access commands that allow you to configure Autokey NTP server authentication.

When you add a trusted NTP server, SafeNet Network HSM and the server negotiate, exchange certificates, and so on. You can optionally choose to use AutoKey to authenticate your connection. Additionally, if using AutoKey, you can optionally choose to use one of the supported identity schemes, IFF (Identify Friend or Foe), GQ (Guillou-Quisquater), or MV (Mu-Varadharajan), or by default none of those schemes, and just exchange private certificates.

Syntax

sysconf ntp autokeyauth

clear
generate
install
list
update

Parameter	Shortcut	Description
clear	c	Delete all keys and certificates. See " sysconf ntp autokeyauth clear " on the next page.
generate	g	Generate client keys and certificates (required to use AutoKey). See " sysconf ntp autokeyauth generate " on page 424.
install	i	Install Autokey Identity Scheme IFF GQ MV (optional). See " sysconf ntp autokeyauth install " on page 426.
list	l	Show Autokey keys and certificates. " sysconf ntp autokeyauth list " on page 427.
update	u	Update client certificates (a certificate usually has a ttl of one year, after which you must update to renew). " sysconf ntp autokeyAuth update " on page 428.

sysconf ntp autokeyauth clear

Delete all Autokey authentication keys and certificates.

Syntax

```
sysconf ntp autokeyAuth clear [-force]
```

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf ntp autokeyAuth clear -force
```

Force option used. Proceed prompt bypassed.

All key and certificates files were deleted.

You must restart NTP for the changes to take effect.

Check NTP status after restarting it to make sure that the client is able to start and sync with the server.

Command Result : 0 (Success)

sysconf ntp autokeyauth generate

Generate new keys and certificates for NTP public key authentication

Syntax

```
sysconf ntp autokeyAuth generate [-certalg <certalg>] [-modulus <modulus>] [-signalg <signalg>] [-password <ntpkey>]
```

Parameter	Shortcut	Description
-certalg	-c	NTP Certificate Algorithm. Valid values: RSA-MD5, RSA-SHA, RSA-SHA1, RSA-RIPMD160, DSA-SHA, DSA-SHA1 Default: RSA-SHA1
-modulus	-m	NTP Modulus Size Range: 512 to 2048 Default: 2048
-password	-p	NTP Symmetric Key Value
-signalg	-s	NTP Sign Algorithm Valid values: RSA, DSA Default: RSA



Note: If you set the signing algorithm to DSA (**-signalg sha**), specify DSA-SHA1, not DSA-SHA, for the certificate algorithm (**-certalg dsa-sha1**). Using DSA-SHA will cause a 'invalid digest type' error.

Example

```
lunash:>sysconf ntp autokeyAuth generate
```

Generate new keys and certificates using ntp-keygen

WARNING ! Generating keys without client Password.

Generating new keys and certificates using these arguments: -S RSA -c RSA-SHA1 -m 2048

Using OpenSSL version 90802f

Using host sa5 group sa5

Generating RSA keys (2048 bits)...

```
RSA 0 13 46      1 2 6          3 1 2
```

Generating new host file and link

```
ntpkey_host_sa5->ntpkey_RSAhost_sa5.3538763554
```

Generating RSA keys (2048 bits)...

```
RSA 0 0 698      1 2 12         3 1 4
```

Generating new sign file and link

```
ntpkey_sign_sa5->ntpkey_RSAsign_sa5.3538763554
```

Generating new certificate sa5 RSA-SHA1


```
X509v3 Basic Constraints: critical,CA:TRUE  
X509v3 Key Usage: digitalSignature,keyCertSign
```

Generating new cert file and link

```
ntpkey_cert_sa5->ntpkey_RSA-SHA1cert_sa5.3538763554
```

You must restart NTP for the changes to take effect.

Check NTP status after restarting it to make sure that the client is able to start and sync with the server.

Command Result : 0 (Success)

sysconf ntp autokeyauth install

Install an Autokey Identity scheme.

Syntax

```
sysconf ntp autokeyauth install -idscheme <identscheme> -keyfile <filename>
```

Parameter	Shortcut	Description
-idscheme	-i	Specifies the NTP AutoKey Identity Scheme to install. Valid values: IFF, GQ, or MV
-keyfile	-k	Specifies the keyfile name.

sysconf ntp autokeyauth list

List the NTP Autokey authentication keys.

Syntax

sysconf ntp autokeyauth list

Example

```
lunash:>sysconf ntp autokeyauth list

===== Installed keys and certificates: =====
ntpkey_RSA-SHA1cert_sa5.3538763554
ntpkey_RSAsign_sa5.3538763554
ntpkey_cert_sa5 -> ntpkey_RSA-SHA1cert_sa5.3538763554
ntpkey_sign_sa5 -> ntpkey_RSAsign_sa5.3538763554
ntpkey_RSAhost_sa5.3538763554
ntpkey_host_sa5 -> ntpkey_RSAhost_sa5.3538763554
===== Certificate details: =====
Certificate File: ntpkey_RSA-SHA1cert_sa5.3538763554
Certificate:
Data:
Version: 3 (0x2)
Serial Number: -756203742 (-0x2d12c0de)
Signature Algorithm: sha1WithRSAEncryption
Issuer: CN=sa5
Validity
Not Before: Feb 20 21:52:34 2012 GMT
Not After : Feb 19 21:52:34 2013 GMT
Subject: CN=sa5
X509v3 extensions:
X509v3 Basic Constraints: critical
CA:TRUE
X509v3 Key Usage:
Digital Signature, Certificate Sign
=====

Command Result : 0 (Success)
```

sysconf ntp autokeyAuth update

Update the client certificates and keys.

Syntax

sysconf ntp autokeyAuth update

Example

```
lunash:>sysconf ntp autokeyAuth update

----- Updating client autokey certificate -----
client password not configured.
Updating certificates without password.
Using OpenSSL version 90802f
Using host sa5 group sa5
Using host key ntpkey_RSAbest_sa5.3527441331
Using sign key ntpkey_RSAsign_sa5.3527441331
Generating new certificate sa5 RSA-SHA1
X509v3 Basic Constraints: critical,CA:TRUE
X509v3 Key Usage: digitalSignature,keyCertSign
Generating new cert file and link
ntpkey_cert_sa5->ntpkey_RSA-SHA1cert_sa5.3538440207
You must restart NTP for the changes to take effect.
Check NTP status after restarting it to make sure that the client is able to start and sync with
the server.

Command Result : 0 (Success)
```

sysconf ntp deleteserver

Delete an NTP server.

Syntax

sysconf ntp deleteserver <hostname_or_ipaddress>

Parameter	Shortcut	Description
<hostname_or_ipaddress>		Specifies the hostname or IP address of the NTP server to delete.

Example

```
lunash:> sysconf ntp deleteserver time.nrc.ca

NTP server 'server time.nrc.ca' deleted.
NTP is enabled
Shutting down ntpd: [ OK ]
Starting ntpd: [ OK ]
Please wait to see the result .....
NTP is running
=====
NTP Associations Status:
ind assid status conf reach auth condition last_event cnt
=====
  1 56579 963a yes yes none sys.peer sys_peer 3
=====
Please look at the ntp log to see any potential problem.

Command Result : 0 (Success)
```

sysconf ntp disable

Disable and stop the NTP service.

Syntax

sysconf ntp disable

Example

```
lunash:> sysconf ntp disable
```

```
NTP is disabled  
Shutting down ntpd: [ OK ]  
NTP is stopped
```

```
Command Result : 0 (Success)
```

sysconf ntp enable

Enable and start the NTP service.

Syntax

```
sysconf ntp enable
```

Example

```
lunash:> sysconf ntp enable
```

```
NTP is enabled
Shutting down ntpd:                [ OK ]
Starting ntpd:                      [ OK ]
Please wait to see the result .....
NTP is running
=====
NTP Associations Status:
ind  assid  status  conf  reach  auth  condition  last_event  cnt
=====
  1 18515  8011   yes   no   none   reject   mobilize   1
  2 18516  8011   yes   no   none   reject   mobilize   1
=====
Please look at the ntp log to see any potential problem.

Command Result : 0 (Success)
```

sysconf ntp listservers

List the configured NTP servers.

Syntax

sysconf ntp listservers

Example

```
lunash:> sysconf ntp listservers
```

```
=====
```

```
NTP Servers:
```

```
server 127.127.1.0
```

```
server time.nrc.ca
```

```
=====
```

```
Command Result : 0 (Success)
```

sysconf ntp log

Display the NTP logs.

Syntax

sysconf ntp log

Parameter	Shortcut	Description
tail		Display the log entries at the end of the log. See "sysconf ntp log tail" on the next page.

sysconf ntp log tail

Display the NTP logs.

Syntax

sysconf ntp log tail [-entries <logentries>]

Parameter	Shortcut	Description
tail		Display the log entries at the end of the log.
-entries	-e	Specifies the number of entries to display. Range: 0 to 2147483647

Example

```
lunash:> sysconf ntp log tail -entries 12
```

```
=====
syslog tail -l ntp -e 12
13 Oct 00:08:54 ntpd[842]: 0.0.0.0 064d 0d kern PPS no signal
13 Oct 00:43:48 ntpd[842]: 0.0.0.0 065d 0d kern PPS no signal
13 Oct 01:28:25 ntpd[842]: 0.0.0.0 066d 0d kern PPS no signal
13 Oct 02:03:54 ntpd[842]: 0.0.0.0 067d 0d kern PPS no signal
13 Oct 02:39:02 ntpd[842]: 0.0.0.0 068d 0d kern PPS no signal
13 Oct 03:14:38 ntpd[842]: 0.0.0.0 069d 0d kern PPS no signal
13 Oct 03:49:00 ntpd[842]: 0.0.0.0 06ad 0d kern PPS no signal
13 Oct 04:41:50 ntpd[842]: 0.0.0.0 06bd 0d kern PPS no signal
13 Oct 05:33:49 ntpd[842]: 0.0.0.0 06cd 0d kern PPS no signal
13 Oct 06:27:09 ntpd[842]: 0.0.0.0 06dd 0d kern PPS no signal
13 Oct 07:02:59 ntpd[842]: 0.0.0.0 06ed 0d kern PPS no signal
13 Oct 07:37:55 ntpd[842]: 0.0.0.0 06fd 0d kern PPS no signal
=====
```

```
Command Result : 0 (Success)
```

sysconf ntp ntpdate

Set the date and time using NTP

Syntax

```
sysconf ntp ntpdate <hostname_or_ipaddress> [-key <keyid>] [-version <version>]
```

Parameter	Shortcut	Description
<hostname_or_ipaddress>		Specifies the hostname or IP address of the NTP server.
-key	-k	NTP Authentication Keyid Range: 1 to 65535
-version	-v	Specifies the NTP version Valid values: 3 or 4

Example

```
[myluna] lunash:> sysconf ntp ntpdate 127.127.1.0
This command sets the date and time using ntp server "127.127.1.0" if NTP daemon is not running.
NTP daemon is running. You can stop ntpd using the "service stop ntp" command before running
this command.
Command Result : 0 (Success)
[myLuna] lunash:>
```

```
[myLuna] lunash:>service stop ntp
Shutting down ntp: [ OK ]
Command Result : 0 (Success)
[myluna] lunash:>
```

```
[myluna] lunash:> sysconf ntp ntpdate 127.127.1.0
This command sets the date and time using ntp server "127.127.1.0" if NTP daemon is not running.
Current time before running ntpdate: Wed Oct 12 20:47:17 PDT 2011
Current time after running ntpdate: Wed Oct 12 20:47:33 PDT 2011
Command Result : 0 (Success)
[myLuna] lunash:>
[myLuna] lunash:>service start ntp
Starting ntp: [ OK ]
Command Result : 0 (Success)
```

sysconf ntp show

Display the NTP configuration.

Syntax

sysconf ntp show

Example

```
lunash:> sysconf ntp show
```

```
----- NTP Version -----  
ntpq 4.2.6p2@1.2194-o Fri Oct  8 19:30:08 UTC 2010 (1)  
===== NTP Configuration =====  
restrict default kod nomodify notrap nopeer noquery  
restrict -6 default kod nomodify notrap nopeer noquery  
restrict 127.0.0.1  
restrict -6 ::1  
fudge 127.127.1.0 stratum 10  
----- NTP Servers -----  
server 127.127.1.0  
server time.nrc.ca  
=====
```

```
Command Result : 0 (Success)
```

sysconf ntp status

Display the NTP service status.

A “+” in front of an NTP server name means that it’s a good candidate for synchronization. More than one NTP server could be a good candidate.

A “*” in front of an NTP server name means that it’s the source of synchronization and the client has been synchronized to it. Only one NTP server at a time will be chosen as the source of synchronization.



Note: The command **sysconf ntp status** sends packets to the configured NTP servers. The response time from the server using unreliable UDP protocol, especially over large distances, is random due to the network delay, server availability etc. If no response is received from the server, the command eventually times out after some attempts; this causes a ‘random’ delay in the command output. Five-to-ten seconds seems to be the timeout period if no response is received from the server.

The default timeout is 5000 milliseconds. Note that since the command retries each query once after a timeout, the total waiting time for a timeout will be twice the timeout value set. For these reasons, you might see the command output begin, then pause for several seconds, before resuming. In other network configurations, and with “nearby” fast-responding NTP servers configured, you might never notice a pause.

Syntax

sysconf ntp status

Example

```
lunash:> sysconf ntp status
```

```
NTP is running
NTP is enabled
Peers:
=====
remote          refid          st t when poll reach  delay  offset  jitter
=====
*LOCAL(0)       .LOCL.         10 1  15   64    7      0.000  0.000  0.000
=====
Associations:
=====
ind assid status  conf reach auth condition  last_event cnt
=====
 1 12393  963a  yes   yes  none  sys.peer  sys_peer  3
=====
NTP Time:
=====
ntp_gettime() returns code 0 (OK)
time d2407aa3.4e858000 Wed, Oct 12 2011 13:44:19.306, (.306725),
maximum error 8020716 us, estimated error 0 us
ntp_adjtime() returns code 0 (OK)
modes 0x0 (),
offset 0.000 us, frequency 0.000 ppm, interval 1 s,
maximum error 8020716 us, estimated error 0 us,
```

```
status 0x1 (PLL),  
time constant 2, precision 1.000 us, tolerance 512 ppm,  
=====
```

```
Command Result : 0 (Success)
```

sysconf ntp symmetricauth

Access commands that allow you to manage NTP symmetric keys.

Syntax

sysconf ntp symmetricauth

key
trustedkeys

Parameter	Shortcut	Description
key	k	Manage symmetric keys. See "sysconf ntp symmetricauth key" on the next page.
trustedkeys	t	Manage trusted symmetric keys. See "sysconf ntp symmetricauth trustedkeys" on page 445.

sysconf ntp symmetricauth key

Access commands that allow you to manage the NTP symmetric authentication keys.

Syntax

sysconf ntp symmetricauth key

add
clear
delete
list

Parameter	Shortcut	Description
add	a	Add a symmetric authentication key. See "sysconf ntp symmetricauth key add" on the next page.
clear	c	Delete all NTP symmetric authentication keys. See "sysconf ntp symmetricauth key clear" on page 442.
delete	d	Delete an NTP symmetric authentication key. See "sysconf ntp symmetricauth key delete" on page 443.
list	l	List all of the currently configured NTP symmetric keys. See "sysconf ntp symmetricauth key list" on page 444.

sysconf ntp symmetricauth key add

Add an NTP symmetric authentication key.

Syntax

```
sysconf ntp symmetricauth trustedkeys add -id <keyid> -type <keytype> -value <ntpkey>
```

Parameter	Shortcut	Description
-id	-i	Specifies the key ID. Range: 1 to 65535
-type	-t	Specifies the key type.
-value	-v	Specifies the key value.

sysconf ntp symmetricauth key clear

Delete all symmetric Authentication Keys.

Syntax

sysconf ntp symmetricAuth key clear [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
[ott1-myluna1] lunash:>sysconf ntp symmetricauth trustedkeys clear  
  
some-id deleted  
  
some-other-id deleted  
  
Command Result : 0 (Success)
```

sysconf ntp symmetricauth key delete

Delete a single-named authentication key from the appliance's list.

Syntax

sysconf ntp symmetricauth key delete -id <keyid> -force

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-id	-i	Specifies the ID of the NTP authentication key to delete.

Example

```
lunash:>sysconf ntp symmetricauth key delete someid
```

```
someid deleted
```

```
Command Result : 0 (Success)
```

sysconf ntp symmetricauth key list

List the NTP symmetric authentication keys.

Syntax

sysconf ntp symmetricauth key list

Example

```
lunash:>sysconf ntp symmetricauth key list
```

```
NTP Symmetric Authentication Keys:
```

```
=====
keyId keyType KeyValue
=====
2 M *****
=====
```

```
Command Result : 0 (Success)
```

sysconf ntp symmetricauth trustedkeys

Access commands that allow you to manage symmetric NTP authentication trusted keys.

Syntax

sysconf ntp symmetricauth trustedkeys

add
clear
delete
list

Parameter	Shortcut	Description
add	a	Add a symmetric NTP authentication trusted key. See " sysconf ntp symmetricauth trustedkeys add " on the next page.
clear	c	Delete all symmetric NTP authentication trusted keys. See " sysconf ntp symmetricauth trustedkeys clear " on page 447.
delete	d	Delete an symmetric NTP authentication trusted key. See " sysconf ntp symmetricauth trustedkeys delete " on page 448.
list	l	List all of the currently configured symmetric trusted NTP keys. See " sysconf ntp symmetricauth trustedkeys list " on page 449.

sysconf ntp symmetricauth trustedkeys add

Add a trusted authentication key. The key should have already been added using the **sysconf ntp symmetricAuth key add** command.

Syntax

sysconf ntp symmetricauth trustedkeys add <keyid>

Parameter	Shortcut	Description
<keyid>		Specifies the ID of the key to add. Range: 1 to 65535

sysconf ntp symmetricauth trustedkeys clear

Delete all Trusted Authentication Keys.

Syntax

sysconf ntp symmetricauth trustedkeys clear [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf ntp symmetricauth trustedkeys clear
```

```
WARNING !! This command deletes all NTP symmetric trusted keys.  
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed  
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf ntp symmetricauth trustedkeys delete

Delete a single named trusted authentication key from the appliance's list of trusted NTP servers.

Syntax

```
sysconf ntp symmetricauth trustedkeys delete <keyid> [-force]
```

Parameter	Shortcut	Description
<keyid>		Specifies the ID of the key you want to delete. Range: 1-65535
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf ntp symmetricauth trustedkeys delete someid
```

```
someid deleted
```

```
Command Result : 0 (Success)
```


sysconf ntp symmetricauth trustedkeys list

Lists the trusted authentication keys in the appliance's list of trusted NTP servers.

Syntax

sysconf ntp symmetricauth trustedkeys list

Example

```
lunash:>sysconf ntp symmetricauth trustedkeys list
```

```
current trustedkeys:
```

```
Command Result : 0 (Success)
```

sysconf radius

Manage the appliance-side configuration of appliance-user authentication via a RADIUS server.

Syntax

sysconf radius

- addServer**
- deleteServer**
- disable**
- enable**
- show**

Name	(short)	Description
addServer	a	Add a RADIUS server "sysconf radius addserver Command" on the next page
deleteServer	de	Remove a RADIUS server "sysconf radius deleteserver " on the next page
disable	di	Disable RADIUS for SSH "sysconf radius disable " on page 451
enable	e	Enable RADIUS for SSH "sysconf radius enable " on page 451
show	s	Show RADIUS configuration "sysconf radius show Command" on page 452

For RADIUS configuration instructions, see "[Optional] Configure for RADIUS Authentication" on page 1.

sysconf radius addserver Command

Identify a RADIUS server to the SafeNet Network HSM, specifying the server's hostname or IP.

Note: RADIUS must already be enabled, by means of command **sysconf radius enable**, before you can run this command to add a RADIUS server.



In addition to enabling RADIUS, you must run the **sysconf radius addServer** command to identify the RADIUS server, as well as the **user role radiusAdd** and **user role add** commands to create a user on this appliance with the desired name, and identify that role as requiring RADIUS to authenticate.

Syntax

sysconf radius addServer -server <hostname> -port <port> -timeout <seconds>

Parameter	Shortcut	Description
-server	-s<hostname>	Host name
-port	-p<port>	Network port (0-65535)
-timeout	-t<seconds>	Time in seconds (1 - 300)

Example

```
lunash:>sysconf radius addServer -server 192.20.15.182 -port 1812 -timeout 60
```

Enter the server secret:

Re-enter the server secret:

Command Result : 0 (Success)

sysconf radius deleteserver

Remove a RADIUS server from the SafeNet Network HSM, specifying the server's hostname or IP.



Note: This command can be run only while RADIUS is enabled on the SafeNet Network HSM.

Syntax

sysconf radius addServer -server <hostname> -port <port> -timeout <seconds>

Parameter	Shortcut	Description
-server	-s<hostname>	Host name

Example

```
lunash:>sysconf radius deleteServer -server 192.20.15.182
```

Command Result : 0 (Success)

sysconf radius disable

Disable RADIUS service on SafeNet Network HSM

Syntax

sysconf radius disable

Options

None

Example

```
lunash:>sysconf radius disable
```

Command Result : 0 (Success)

sysconf radius enable

Enable RADIUS service on SafeNet Network HSM.



Note: In addition to enabling RADIUS, you must run the **sysconf radius addServer** command to identify the RADIUS server, as well as the **user role radiusAdd** and **user role add** commands to create a user on this appliance with the desired name, and identify that role as requiring RADIUS to authenticate.

Syntax

sysconf radius enable

Options

None

Example

```
lunash:>sysconf radius enable
```

Command Result : 0 (Success)

sysconf radius show Command

Show the current RADIUS configuration and status.

Syntax

sysconf radius show

Example

```
lunash:>sysconf radius show
```

```
RADIUS for SSH is enabled with the following deployed servers:
```

server:port	timeout
-----	-----
172.20.15.182:1812	60

Command Result : 0 (Success)

sysconf regencert

Generate server certificate in software. This command generates or re-generates the SafeNet appliance server certificate used for the NTLA in the SafeNet appliance file system.

If you are using a system with DNS, you should not specify an IP address. If you are using a system that does not use DNS, you should specify the IP address of eth0 so that the certificate will be properly generated.

It is very important that the certificates are properly generated or the NTLA will not work.

This command stores the resulting private and public keys, and the certificate generated from them, on the file system (hard disk) inside the SafeNet appliance.

If you prefer the additional security of keys that are stored inside the HSM, use the command **sysconf hwregencert** instead.

Syntax

```
sysconf regenCert <eth0_ipaddress> [-startdate <startdate>] [-days <days>] [-force]
```

Parameter	Shortcut	Description
<eth0_ipaddress>		Specifies the IP address of eth0. This parameter is required if the rest of your setup was done without DNS.
-days	-d	Specifies the number of days for which the new certificate will remain valid, starting on <startdate> Default: 10 years
-force	-f	Force the action without prompting.
-startdate	-s	Specifies the starting date upon which the certificate becomes valid - default is 24 hours ago, to obviate possible timezone mismatch issues if you need the certificate to be valid immediately anywhere in the world.

Example

```
lunash:>sysconf regencert
```

```
WARNING !! This command will overwrite the current server certificate and private key.
            All clients will have to add this server again with this new certificate.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'
```

```
> proceed
Proceeding...
```

```
ERROR. Partition named "Cryptoki User" not found
```

```
'sysconf regenCert' successful. NTLS and STC must be (re)started before clients can connect.
```

```
Please use the 'ntls show' command to ensure that NTLS is bound to an appropriate network device
or IP address/hostname
for the network device(s) NTLS should be active on. Use 'ntls bind' to change this binding if
necessary.
```

Command Result : 0 (Success)

sysconf securekeys

Move RSA keys to hardware. This command migrates the SafeNet keys used to secure the NTLS link from the SafeNet appliance's file system into the HSM.

If you use **sysconf regenCert**, the generated private key, public key and certificate reside, by default, in the SafeNet appliance's file system.

This command (**sysconf secureKeys**) moves your existing RSA keys into the HSM.

You must be logged in to use this command.

Once the keys reside in the HSM, any operation that needs the private key will require HSM access. For this reason, whenever the system is rebooted (maintenance, power outage, etc.) you must run **ntls activateKeys** to activate (authenticate to) the partition containing those keys.

If your application sets up an NTLS link and then runs multiple crypto operations over that link, you are unlikely to notice an operational difference. If your application sets up and tears down the link for each crypto operation, then the slight additional overhead might become apparent.

Syntax

sysconf securekeys [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:> sysconf secureKeys
WARNING !! This command migrates the SSL RSA keys to the internal hardware module.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'
> proceed
```

Proceeding...

```
Enter User Password:
Proceeding to migrate keys to "Cryptoki User" with handle 13
Success: NTLS keys are in hardware.
Command Result : 0 (Success)
[myLuna] lunash:>ntls activateKeys
Enter User Password:
Stopping ntl:OK
Starting ntl:OK:
```

```
Command Result : 0 (Success)
```

sysconf snmp

Access commands that allow you to configure the Simple Network Management Protocol (SNMP) settings for SafeNet appliance, and enable or disable the service. At least one user must be configured before the SNMP agent can be accessed.

Syntax

sysconf snmp

disable
enable
notification
show
trap
user

Parameter	Shortcut	Description
disable	d	Disable the SNMP service. See " sysconf snmp disable " on the next page.
enable	e	Enable the SNMP service. See " sysconf snmp enable " on page 458.
notification	n	Access commands that allow you to view or configure the notifications that can be sent by the SNMP agent. See " sysconf snmp notification " on page 459.
show	s	Display SNMP service information. See " sysconf snmp show " on page 464.
trap	t	Access commands that allow you to view or configure the SNMP trap hosts. See " sysconf snmp trap " on page 465.
user	u	Access commands that allow you to view or configure the users that can access the SNMP agent. See " sysconf snmp user " on page 473.

sysconf snmp disable

Disable and stop the SNMP service.

Syntax

sysconf snmp disable

Example

```
lunash:>sysconf snmp disable
SNMP is disabled
Stopping snmpd:      [ OK ]
SNMP is stopped
Command Result : 0 (Success)
```

sysconf snmp enable

Enable and start the SNMP service.

Syntax

sysconf snmp enable

Example

```
lunash:>sysconf snmp enable
SNMP is enabled
Starting snmpd:          [ OK ]
SNMP is started
Command Result : 0 (Success)
```

sysconf snmp notification

Access command that allow you to view and configure the notifications that can be sent by the SNMP agent. At least one user must be configured before the SNMP agent can be accessed.

Syntax

sysconf snmp notification

add
clear
delete
list

Parameter	Shortcut	Description
add	a	Add a notification target . See "sysconf snmp notification add" on the next page.
clear	c	Delete all notification targets. See "sysconf snmp notification clear" on page 461.
delete	d	Delete a notification target. See "sysconf snmp notification delete" on page 462.
list	l	Display a list of the notification targets. See "sysconf snmp notification list" on page 463.

sysconf snmp notification add

Add a single notification destination to be notified via the SNMP service.

Syntax

```
sysconf snmp notification add -ipaddress <ipaddress> -authpassword <password> [-authprotocol <protocol>] [-
notifytype {trap | inform}] -privpassword <password> -secname <userid> [-udpport <port>]
```

Parameter	Shortcut	Description
-authpassword	-authpa	Specifies the authentication password. The password may be 8-to-128 characters long.
-authprotocol	-authpr	Specifies the authentication protocol. Valid values: SHA Default: SHA
-ipaddress	-i	Specifies the IPv4 address of the destination (a machine running snmptrapd from Net-SNMP or some other SNMP management application, such as MG-Soft's MIB Browser or HP's Openview.)
-notifytype	-n	Specifies the notification type. Valid values: trap: one-way unconfirmed notification inform: confirmed notification with retries Default: trap
-privpassword	-p	Specifies the privacy password or encryption password. The password may be 8-to-128 characters long.
-secname	-s	Specifies the security name or user name for this user. The user name may be 1-to-31 characters. In the context of notifications this is the "Security Name" on whose behalf notifications are sent.
-udpport	-u	Specifies the UDP port on the notification target host to which notifications are sent. 162 is the SNMP default port for notifications. Default: 162

sysconf snmp notification clear

Deletes all users that are currently configured to use the SNMP command with this SafeNet appliance. If you do not use the `-force` option, a prompt requires you to type "proceed" if the operation is to go ahead - otherwise, it is aborted.

This command is most useful if you have a number of SNMPv3 notification targets defined and wish to delete all targets. This command is also useful for LunaSH scripts that need to ensure that all SNMPv3 notification targets have been deleted and that there is thus a clean and empty SNMP notification target configuration.

Syntax

sysconf snmp notification clear [-force]

Parameter	Shortcut	Description
<code>-force</code>	<code>-f</code>	Force the action without prompting.

Example

```
lunash:>sysconf snmp notification clear
```

```
WARNING !! This command deletes all notification target information from the SNMP Agent.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
```

```
Command Result : 0 (Success)
```

sysconf snmp notification delete

Delete all notification targets that are configured for IP address <ipaddress> and UDP Port <udpPort>. It is possible that there are 0, 1 or multiple such notification targets configured. (They could be using different values for <notifyType> and/or <secName> although this would not be common.) Note that if <udpPort> is not specified, then only notification targets configured for the default SNMP UDP port 162 will be deleted.

Syntax

sysconf snmp notification delete -ipaddress <ipaddress> [-udpport <port>]

Parameter	Shortcut	Description
-ipAddress	-i	Specifies the IP address of the notification target to delete.
-udpPort	-u	Specifies the UDP port of the notification target to delete. (0-65535) Default: 162

Example

```
lunash:>sysconf snmp notification delete -ipAddress 192.20.11.11
```

```
SNMP notification target information deleted
```

```
Command Result : 0 (Success)
```

sysconf snmp notification list

Lists the targets to which SNMPv3 notifications (traps or informs) will be sent.

Syntax

sysconf snmp notification list

Example

```
lunash:> sysconf snmp notification list
```

```
SNMP Notification Targets:
```

```
-----
```

```
172.21.100.82:162
```

```
utsp SHA AES
```

In this example the output conveys the following information:

Field	Description
172.21.100.82	The IP address of the notification target host (A machine running snmptrapd from Net-SNMP or some other SNMP management application, such as MG-Soft's MIB Browser or HP's Openview.)
162	The UDP port on the notification target host to which notifications are sent. 162 is the SNMP default port for notifications.
utsp	The "Security Name" (or user name) on whose behalf notifications are sent.
SHA	The authentication protocol used for notifications.
AES	The privacy (or encryption) protocol used for notifications (always AES for SafeNet Network HSM).

sysconf snmp show

Display SNMP service information.

Syntax

sysconf snmp show

Example

```
lunash:>sysconf snmp show
```

```
SNMP is not running  
SNMP is disabled
```

```
Command Result : 0 (Success)
```


sysconf snmp trap

Access commands that allow you to view or configure SNMP trap hosts.

Syntax

sysconf snmp trap

clear
disable
enable
set
show
test

Parameter	Shortcut	Description
clear	c	Clear SNMP trap host information. See "sysconf snmp trap clear" on the next page.
disable	d	Disable and stop the SafeNet SNMP Trap Agent (Ista). See "sysconf snmp trap disable" on page 467.
enable	e	Enable and start the SafeNet SNMP Trap Agent (Ista). See "sysconf snmp trap enable" on page 468.
set	se	Set SNMP trap host information. See "sysconf snmp trap set" on page 469.
show	sh	Display SNMP trap host information. See "sysconf snmp trap show" on page 470.
test	t	Test SNMP trap notification. See "sysconf snmp trap test" on page 471.

sysconf snmp trap clear

Deletes all SNMP Trap Host Information.

Syntax

sysconf snmp trap clear [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:> sysconf snmp trap clear
```

If you are sure that you wish to clear snmp trap information, then enter 'proceed', otherwise type 'quit'.

```
> Proceed
```

```
Command Result : 0 (Success)
```

sysconf snmp trap disable

Disable and stop the SafeNet SNMP Trap Agent (lsta).

Syntax

sysconf snmp trap disable

Example

```
lunash:>sysconf snmp trap disable
```

```
SNMP trap agent is disabled  
Shutting down lsta:  
SNMP trap agent is stopped
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

sysconf snmp trap enable

Enable and start the SafeNet SNMP Trap Agent (lsta).

Syntax

sysconf snmp trap enable

Example

```
lunash:>sysconf snmp trap enable
```

```
SNMP trap agent is enabled
```

```
Starting lsta:
```

```
SNMP trap agent is started
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

sysconf snmp trap set

Set SNMP trap host information.

Syntax

sysconf snmp trap set **-host** <hostname_or_ipaddress> [**-secname** <secname>] [**-engineid** <engineID>] [**-authprotocol** <protocol>] [**-authpwd** <password>] [**-privprotocol** <protocol>] [**-privpwd** <password>]

Parameter	Shortcut	Description
-host	-h	Specifies the trap host name or IP address.
-secname	-s	Specifies the SNMP v3 security name.
-engineID	-e	Specifies the SNMP v3 Engine ID (Hex Number, No 0x or 0X)
-authprotocol	-authpr	Specifies the SNMP v3 Authentication Protocol (SHA)
-authpwd	-authpw	Specifies the SNMP v3 Authentication password
-privProtocol	-privpr	Specifies the SNMP v3 Privacy protocol (AES)
-privPwd	-privpw	Specifies the SNMP v3 Privacy Password

Example

```
lunash:>sysconf snmp trap set -host mysnmphost
```

SNMP trap is not configured. No trap will be sent.

Command Result : 0 (Success)

sysconf snmp trap show

Display SNMP trap host information.

Syntax

sysconf snmp trap show

Example

```
lunash:>sysconf snmp trap show
```

```
SNMP trap is not configured. No trap will be sent.
```

```
Command Result : 0 (Success)
```

sysconf snmp trap test

Test the SNMP trap notification.

This command allows an administrator to create test logs to initiate trap notifications. Refer to the *Syslog Monitoring Guide* for details of which log messages result in traps.

To initiate a trap notification use the command parameters to format and record a log message via syslog. To distinguish between messages in the logs that are generated by this command and those that represent legitimate events, all log messages generated using this command are prefixed with "****TEST :", as shown in the following example:

```
2012 Feb 29 12:05:01 myLUT daemon crit smartd[19685]: ****TEST : Device: /dev/sda, Temperature
45 Celsius reached limit of 44 Celsius (Min/Max 31/49)
```



Note: The SafeNet administrative shell prohibits the '<' and '>' characters as parameters. However, some traps rely on the presence of these comparators in log messages. To enable test log messages of the form that need these comparators, use a ".lt" or ".gt" string in place of the '<' or '>' character in the formatted command.



Note: This command writes a record to the applicable system log file. The command has no dependency on the status of the SafeNet SNMP Trap Daemon. To test trap generation, ensure that you have enabled traps as described in the *Syslog and SNMP Monitoring Guide*.

Syntax

sysconf snmp trap test **-logfacility** <logfacility> **-loglevel** <loglevel> **-process** <process> **-message** <message> [**-pid**]

Parameter	Shortcut	Description
-logfacility	-logf	Specifies the log facility to use when generating the test message. Valid values: kern, user, daemon, auth, syslog, authpriv, cron, local0, local1, local2, local3, local4, local5, local6, local7
-loglevel	-logl	Specifies the severity level to assign to the test message. Valid values: emergency, alert, critical, crit, error, err, warning, warn, notice, info, debug
-process	-pr	Specifies the system process to use when generating the test message. Valid values: Any process defined for the system. For example, NTLN, impievd, smartd, sysstatd.
-message	-m	A string that specifies the body text for the test message. You must enclose the string in double quotes (" <string> ") if it contains spaces.
-pid	-pi	Add a process identifier to the test message.

Example

```
lunash:> sysconf snmp trap test -logfacility daemon -loglevel crit -process smartd -message  
"Device: /dev/sda, Temperature 45 Celsius reached limit of 44 Celsius (Min/Max 31/49)" -pid
```

```
Command Result : 0 (Success)
```


sysconf snmp user

Access commands that allow you to view and configure the users that can access the SNMP agent. At least one user must be configured before the SNMP agent can be accessed.

Syntax

sysconf snmp user

Parameter	Shortcut	Description
add	a	Add a user. See "sysconf snmp user add" on the next page.
clear	c	Delete all users. See "sysconf snmp user clear" on page 476.
delete	d	Delete a user. See "sysconf snmp user delete" on page 477.
list	l	List the currently configured users. See "sysconf snmp user list" on page 478.

sysconf snmp user add

Add a user who can use SNMP service. To enhance security, the authpassword and the privpassword should not be set to the same value. SNMP users created with this command are automatically configured for:

- read (GET/GET-NEXT/GET-BULK)
- write (SET) and
- notify (TRAP/INFORM) access to all MIB objects.



Note: It is not possible to modify the parameters for a configured user. You must use **sysconf snmp user delete** followed by **sysconf snmp user add**.



Note: If an ssh connection with a SafeNet Network HSM appliance is terminated while **sysconf snmp user add** command is in progress, it is not possible to reconnect immediately to re-run the command.

Syntax

sysconf snmp user add -secname <secname> -authpassword <password> [-authprotocol <protocol>] -privpassword <password>

Parameter	Shortcut	Description
-secName	-s	Specifies the security name. The name may be 1-to-31 characters; this is effectively the SNMPv3 term for "User name"
-authPassword	-authPa	Specifies the authentication password. The password may be 8-to-128 characters long (for better security, it should be different than the privpassword).
-authprotocol	-authPr	Specifies the authentication protocol. Valid values: SHA Default: SHA
-privPassword	-privPa	Specifies the privacy password or encryption password. The password may be 8-to-128 characters (for better security, it should be different than authPassword).
-privProtocol	-privPr	Specifies the privacy protocol. Valid values: AES Default: AES

Example

To create an SNMP user with the name "admin", issue the following command:

```
lunash:> sysconf snmp user add -secName admin -authPassword 12345678 -privPassword 87654321
```

An SNMP agent on the SafeNet host "myLuna1" can then be accessed by means of the Net-SNMP "snmpwalk utility, using a command like:

```
snmpwalk -v 3 -u admin -l authPriv -a SHA -A 12345678 -x AES -X 87654321 myLuna1 .1
```

sysconf snmp user clear

Delete all users that are currently configured to use the SNMP command with this SafeNet appliance. If you do not use the `-force` option, a prompt requires you to type "proceed" if the operation is to go ahead - otherwise, it is aborted.

Syntax

`sysconf snmp user clear [-force]`

Parameter	Shortcut	Description
<code>-force</code>	<code>-f</code>	Force the action without prompting.

Example

```
lunash:>sysconf snmp user clear
```

```
WARNING !! This command deletes all user account information from the SNMP Agent.  
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
```

```
Command Result : 65535 (Luna Shell execution)
```

sysconf snmp user delete

Delete a specific (named) user that is currently configured to use the SNMP command with this SafeNet appliance (allowed to access the SNMP agent).

Syntax

```
lunash:> sysconf snmp user delete -secname <userid>
```

Parameter	Shortcut	Description
-secname	-s	Specifies the user name of the user you want to delete.

Example

```
lunash:>sysconf snmp user delete -secname localsnmp
```

```
SNMP user account information deleted
```

```
Command Result : 0 (Success)
```

sysconf snmp user list

Display a list of the users that are currently configured to use the SNMP command with this SafeNet appliance.

Syntax

sysconf snmp user list

Example

```
lunash:> sysconf snmp user list
```

```
SNMP Users:
-----
aUser
admin
admintoo
anotherUser
yetAnotherUser
```

sysconf ssh

Access commands that allow you to view or configure SSH options on the appliance.

Syntax

sysconf ssh

```

device
ip
password
port
publickey
regenkeypair
show

```

Parameter	Shortcut	Description
device	d	Set the SSH device restriction policy. See "sysconf ssh device" on the next page.
ip	i	Set the SSH IP restriction policy. See "sysconf ssh ip" on page 481.
password	pa	Enable or disable password authentication. See "sysconf ssh password" on page 482.
port	po	Set the SSHD listen port number (22, 1024-65535). See "sysconf ssh port" on page 485.
publickey	pu	View or configure SSH public keys. See "sysconf ssh publickey" on page 486.
regenKeyPair	r	Regenerate the SSH key pair. See "sysconf ssh regenkeypair" on page 489
show	s	Display the currently set SSH restriction policies. See "sysconf ssh show" on page 490

sysconf ssh device

Set the SSH device restriction policy.

This command restricts appliance/HSM administrative traffic (over SSH) to only the indicated Ethernet port. Use this where you need to segregate administrative traffic from client (NTLS) traffic. This command is an alternative to the command ["sysconf ssh ip" on the next page](#), which performs the same action by specifying an IP address that corresponds to one of your network devices.

If you wish, SSH traffic restriction could complement client traffic restriction using the command ["ntls bind" on page 222](#), which binds client (NTLS) traffic to a specific IP or device name on your SafeNet Network HSM.

Syntax

sysconf ssh device <netdevice>

Parameter	Shortcut	Description
<netdevice>		Specifies the device to which you want to restrict the SSH service. Valid values: all: Allow SSH on all devices. eth0: Restrict SSH connections to the eth0 interface. eth1: Restrict SSH connections to the eth1 interface. lo: Default:

Example

```
lunash:>sysconf ssh device all
```

```
WARNING: SSH is already restricted to the specified IP address / ethernet card. No changes made.
```

```
Command Result : 0 (Success)
```

```
[myluna] lunash:>sysconf ssh device eth1
```

```
Success: SSH now restricted to ethernet device eth1 (ip address 192.168.255.2).  
Restarting ssh service.
```

```
Stopping sshd: [ OK ]
```

```
Starting sshd: [ OK ]
```

```
Command Result : 0 (Success)
```

```
[myluna] lunash:>sysconf ssh show
```

```
SSHD configuration:
```

```
SSHD Listen Port: 22 (Default)
```

```
SSH is restricted to ethernet device eth1 (ip address 192.168.255.2).
```

```
Password authentication is enabled
```

```
Public key authentication is enabled
```

```
Command Result : 0 (Success)
```


sysconf ssh ip

Set the SSH local-IP restriction policy.

This command restricts appliance/HSM administrative traffic (over SSH) to only the indicated IP address (bound to one of the SafeNet Network HSM's Ethernet ports). Use this where you need to segregate administrative traffic from client (NTLS) traffic. This command is an alternative to the command ["sysconf ssh device" on the previous page](#), which performs the same action by specifying an Ethernet device.

If you wish, SSH traffic restriction could complement client traffic restriction using the command ["ntls bind" on page 222](#), which binds client (NTLS) traffic to a specific IP or device name on your SafeNet Network HSM.

Syntax

sysconf ssh ip <ipaddress>

Parameter	Shortcut	Description
<ipaddress>		Specifies the IP address associated with the SafeNet Network HSM network interface device to which you want to restrict the SSH service. Valid values: Any ipv4 address.

Example

```
lunash:>sysconf ssh ip 192.20.10.200
```

```
Success: SSH now restricted to ethernet device eth0 (ip address 192.20.10.200).
```

```
Restarting ssh service.
```

```
Stopping sshd: [ OK ]
```

```
Starting sshd: [ OK ]
```

```
Command Result : 0 (Success)
```

sysconf ssh password

Access commands that allow you to enable or disable password authentication.

Syntax

sysconf ssh password

disable
enable

Parameter	Shortcut	Description
disable	d	Disable SSH password authentication. See " sysconf ssh password disable " on the next page.
enable	e	Enable SSH password authentication. See " sysconf ssh password enable " on page 484.

sysconf ssh password disable

Disable SSH password authentication.

Syntax

sysconf ssh password disable

Example

```
lunash:>sysconf ssh password disable
```

```
Password authentication disabled
```

```
Command Result : 0 (Success)
```

sysconf ssh password enable

Enable SSH password authentication.

Syntax

sysconf ssh password enable

Example

```
lunash:>sysconf ssh password enable
```

```
Password authentication enabled
```

```
Command Result : 0 (Success)
```

sysconf ssh port

Set the SSHD listen port number.

Syntax

sysconf ssh port <port>

Parameter	Shortcut	Description
<port>		Specifies the SSHD listen port number. Range: 22 or 1024-65535 Default: 22

Example

```
lunash:>sysconf ssh port 25
```

This command sets the SSHD listen port number.

Please make sure that you choose a new port number which is not used by other services.

Invalid New port number 25. It must be between 1024 and 65535 or 22.

Command Result : 65535 (Luna Shell execution)

```
[myluna] lunash:>sysconf ssh port 1024
```

This command sets the SSHD listen port number.

Please make sure that you choose a new port number which is not used by other services.

SSH Port Changed from 22 to: Port 1024

```
Flushing firewall rules: [ OK ]
Setting chains to policy ACCEPT: filter [ OK ]
Unloading iptables modules: [ OK ]
Applying iptables firewall rules: [ OK ]
Loading additional iptables modules: ip_conntrack_netbios_n [ OK ]
Stopping sshd: [ OK ]
Starting sshd: [ OK ]
```

Command Result : 0 (Success)

sysconf ssh publickey

View or configure SSH public keys.

To add, list, delete, or clear public keys, see "my public-key" on page 191.

Once you enable public key authentication for an administration computer, the private SSH key (/root/.ssh/id_rsa) must be protected, and access to that computer must be restricted and password-protected. Anyone who can log into that computer can log into the SafeNet Network HSM appliance without knowing the LunaSH admin password!

Note: The former commands to manage SSH publickeys have been removed

```
sysconf ssh publickey add
sysconf ssh publickey list
sysconf ssh publickey delete
sysconf ssh publickey clear
```



Those functions are now covered by equivalent commands:

```
my public-key add (See "my public-key add" on page 192)
my public-key clear (See "my public-key clear" on page 193)
my public-key delete (See "my public-key delete" on page 194)
my public-key list (See "my public-key list" on page 195)
```

Syntax

sysconf ssh publickey

```
disable
enable
```

Parameter	Shortcut	Description
disable	di	Disable SSH public key authentication. See "sysconf ssh publickey disable" on the next page.
enable	e	Enable SSH public key authentication. See "sysconf ssh publickey enable" on page 488.

sysconf ssh publickey disable

Disable SSH public key authentication.

Syntax

sysconf ssh publickey disable

Example

```
lunash:>sysconf ssh publicKey disable
```

```
Public key authentication disabled
```

```
Command Result : 0 (Success)
```

sysconf ssh publickey enable

Enable SSH public key authentication.

Once you enable public key authentication for an administration computer, the private SSH key (`/root/.ssh/id_rsa`) must be protected, and access to that computer must be restricted and password-protected. Anyone who can log into that computer can log into the SafeNet Network HSM appliance without knowing the LunaSH admin password!

Syntax

sysconf ssh publickey enable

Example

```
lunash:>sysconf ssh publicKey enable
```

```
Public key authentication enabled
```

```
Command Result : 0 (Success)
```

sysconf ssh regenkeypair

Regenerate the SSH key pair.

Syntax

sysconf ssh regenkeypair

Example

```
lunash:>sysconf ssh regenkeypair
```

```
WARNING !! This command regenerates SSH keypair.  
WARNING !! SSH will be restarted.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.  
> proceed
```

```
Proceeding...  
Stopping sshd: [ OK ]  
Generating SSH1 RSA host key: [ OK ]  
Generating SSH2 RSA host key: [ OK ]  
Generating SSH2 DSA host key: [ OK ]  
Starting sshd: [ OK ]
```

```
Command Result : 0 (Success)
```

sysconf ssh show

Display the currently configured SSH restrictions.

Syntax

sysconf ssh show

Example

```
lunash:>sysconf ssh show
```

```
SSHD configuration:
```

```
SSHD Listen Port: 22 (Default)
```

```
SSH is unrestricted.
```

```
Password authentication is enabled
```

```
Public key authentication is enabled
```

```
Command Result : 0 (Success)
```

sysconf time

Set the appliance clock. Time and system date may be set to user-specified values. Specify the correct timezone before setting a new value for the system time. The hardware clock is automatically kept in sync whenever a change is made to the system date, time, or timezone.

You can determine the current date/time setting using the **status date** command.

Syntax

sysconf time <time> [<date>]

Parameter	Description
<time>	Specifies the time using 24-hour clock in the following format: HH:MM
<date>	Set the date along with system time. Specify the date using the following format: YYYYMMDD

Example

```
lunash:> sysconf time 15:37 20120202  
Thu Feb 2 15:37:00 EST 2012
```

sysconf timezone

Show and set the timezone for the appliance's clock. This command allows the administrator to check and set the system timezone.

Syntax

sysconf timezone [**set** <timezone>] [**show**]

Parameter	Shortcut	Description
set	se	Set time zone.
show	sh	Shows the current timezone setting - but not in the format that the user needs to use when entering one; for example, it might show EST when the timezone code entered was EST5EDT.

Example

```
lunash:> sysconf timezone show
EST
```

```
lunash:> sysconf timezone set EST5EDT
Time zone set to EST5EDT
```

syslog

Access the syslog commands used to manage the system logs.



Note: Syslog uses system time. If you change the timezone setting for the appliance while syslog is running, syslog continues to log entries based on the old timezone, until you restart the syslog service.

Syntax

syslog

cleanup
export
period
policy
remotehost
rotate
rotations
severity
show
tail
tarlogs

Parameter	Shortcut	Description
cleanup	c	Delete log files. See "syslog cleanup" on the next page.
export	e	Export syslog. See "syslog export" on page 495.
period	p	Set the syslog period. See "syslog period" on page 496.
remotehost	re	Configure Syslog remote hosts. See "syslog remotehost" on page 498.
rotate	rotate	Rotate log files. See "syslog rotate" on page 497.
rotations	rotati	Set syslog rotations. See "syslog rotations" on page 503
severity	se	Log severity. See "syslog severity set" on page 504.
show	sh	Get Syslog configuration. See "syslog show" on page 505.
tail	tai	Get last entries of log. See "syslog tail" on page 508.
tarlogs	tar	Archive log files. See "syslog tarlogs" on page 509.

syslog cleanup

Delete log files. Using this command following "syslog rotate" causes all grow-able log files to be deleted.

Syntax

syslog cleanup [-force]

Parameter	Parameter	Description
-force	-f .	Forces the command to proceed silently without prompting. Useful for scripting.

Example

```
lunash:>syslog cleanup
WARNING !! This command creates an archive of the current logs then deletes ALL THE LOG FILES
except the hsm logs.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
> proceed
Command Result : 0(Success)
```

syslog export

Prepare system logs for transfer from appliance. This command copies the current system log file to the export directory so that the user can use scp to transfer the file to another computer. Can be used for offline storage of old log files or to send to Technical Support for troubleshooting the SafeNet appliance.

Syntax

syslog export

Example

```
lunash:>syslog export
```

```
System log files successfully prepared for secure transfer.  
Use scp from a client machine to get the file named: "syslog"
```

```
Command Result : 0 (Success)
```

syslog period

Set the time between syslog rotations.

Syntax

syslog period <syslogperiod>

Parameter	Shortcut	Description
<syslogperiod>		Specifies the log rotation period. Valid values: daily, weekly, monthly

Example

```
lunash:>syslog period daily
```

```
Log period set to daily.
```

```
Command Result : 0 (Success)
```


syslog rotate

Rotate log files immediately if they have not already been rotated on the same date. Logs cannot be rotated more than once per day.



Note: Using this command followed by "sysconf cleanup logs" causes all grow-able log files to be deleted.

EXCEPTION: The syslog rotate command does not rotate the NTP log file nor the hsm.log file. The HSM log is a small log file that provides critical information about the HSM. It does not grow very much throughout the life of the HSM.

Syntax

syslog rotate

Example

```
lunash:>syslog rotate  
Command Result : 0 (Success)
```

syslog remotehost

Access the **syslog remotehost** commands to manage the syslog remote hosts.

Syntax

syslog remotehost

add
delete
list

Parameter	Shortcut	Description
add	a	Add a remote host. See "syslog remotehost add" on the next page.
clear	c	Delete All Remote Logging Servers. See "syslog remotehost clear" on page 500.
delete	d	Delete a remote host. See "syslog remotehost delete" on page 501.
list	l	List all syslog remote hosts. See "syslog remotehost list" on page 502.

syslog remotehost add

Add a remote host receiving the logs. Can be any system that provides the remote syslog service.



Note: For this function to work you must open receiving udp port 514 on the remote log server.

Syntax

syslog remotehost add <hostname_or_IP_address>

Parameter	Shortcut	Description
<hostname_or_IP_address>		Specifies the hostname or the IP address of the remote computer system that will be accepting and storing the syslogs.

Example

```
lunash:>syslog remotehost add mylinuxbox
```

```
mylinuxbox added successfully
```

```
Please restart syslog with <service restart syslog> command
```

```
Make sure syslog service is started on mylinuxbox with -r option
```

```
Command Result : 0 (Success)
```

syslog remotehost clear

Delete all remote logging servers.

Syntax

syslog remotehost clear -force

Parameter	Shortcut	Description
-force	-f	Force the action; useful for scripting.

Example

```
[mylunasa6] lunash:>syslog remotehost clear
```

```
    All remote hosts receiving the logs will be deleted.
    Are you sure you wish to continue?
```

```
    Type proceed to continue, or quit to quit now -> proceed
```

```
Shutting down kernel logger:           [ OK ]
Shutting down system logger:          [ OK ]
Starting system logger:                [ OK ]
Starting kernel logger:                [ OK ]
```

```
Command Result : 0 (Success)
```

```
[mylunasa6] lunash:>
```

syslog remotehost delete

Delete a remote host receiving the logs. Use "syslog remotehost list" to see which systems are receiving the logs.

Syntax

syslog remotehost delete <hostname_or_IP_address>

Parameter	Shortcut	Description
<hostname_or_IP_address>		Specifies the hostname or the IP address of the remote computer system to delete from the list.

Example

```
lunash:>syslog remotehost delete mylinuxbox
```

```
mylinuxbox deleted successfully
```

```
Please restart syslog with <service restart syslog> command  
to stop logs to be sent to mylinuxbox
```

```
Command Result : 0 (Success)
```

syslog remotehost list

List the syslog remote hosts.

Syntax

syslog remotehost list

Example

```
lunash:>syslog remotehost list
```

```
List of syslog remote hosts:  
mylinuxbox
```

```
Command Result : 0 (Success)
```

syslog rotations

Set the number of history files to keep when rotating system log files. For example, two rotations would keep the current log files and the most recent set; three rotations would keep the current log files and the two most recent sets. Specify a whole number less than 100.

Syntax

```
syslog rotations <syslog_rotations>
```

Parameter	Shortcut	Description
<syslog_rotations>		An integer that specifies the number of history files to keep when rotating system log files. Range: 1 to 100

Example

```
lunash:> syslog rotations 5
```

```
Log rotations set to 5
```

```
Command Result : 0 (Success)
```

```
lunash syslog Commands
```

syslog severity set

Set the log service severity threshold for events to be logged.

Syntax

syslog severity set **-logname** <logname> **-loglevel** <loglevel>

Parameter	Shortcut	Description
-loglevel	-logl	Specifies the severity level of the log messages to include in the logs. Valid values: (emergency,alert,critical,crit,error,err,warning,warn,notice,info,debug Note: These values are arranged from those which produce the fewest log entries to those which produce the most log entries.
-logname	-logn	The name of the log file to which you want to apply severity levels. Only lunalogs can have severity levels applied.

Example

```
lunash:>syslog severity set -logname lunalogs -loglevel error
```

This command sets the severity level of log messages.
Only messages with the severity of higher than or equal to the new log level: "error" will be logged.
You must restart syslog using the "service restart syslog" command for the changes to take effect.

Command Result : 0 (Success)

syslog show

Display the current log rotation configuration, and show the configured log levels. Optionally show a list of the log files.

Syntax

syslog show [-files]

Parameter	Shortcut	Description
-files	-f	Binary option. If this option is present, a list of all log files is presented. If this option is absent, then a summary of log configuration is shown, without the file list.

Example

In the example below, the asterisk beside the "hsm" entry indicates that ALL HSM events get logged and that this setting is not user configurable.

```
mylunasa6] lunash:>syslog show
```

Syslog configuration

```
Rotations:          4
Rotation Period:    weekly
Log disk full policy: tarlogs_cleanup
```

Configured Log Levels:

```
-----
syslog:      *
lunalog:     info
hsm:         *
secure:      *
cron:        notice
boot:        *
```

Note: '*' means all log levels.

Command Result : 0 (Success)

```
[mylunasa6] lunash:>
```

```
[mylunasa6] lunash:>syslog show -file
```

Syslog configuration

```
Rotations:          4
Rotation Period:    weekly
Log disk full policy: tarlogs_cleanup
```

Configured Log Levels:

```
-----
syslog:      *
lunalog:     info
```

```

hsm:      *
secure:   *
cron:     notice
boot:     *

```

Note: '*' means all log levels.

LogFileName	Size	Date	Time
acpid	940	Apr 17	10:33
acpid-2014-04-09	439	Apr 9	2014
anaconda.log	140447	Mar 5	2013
anaconda.syslog	25575	Mar 5	2013
boot.log	0	Apr 9	2014
btmpt	5760	Apr 2	00:53
btmpt-20130516-0402	768	May 15	2013
btmpt-2015-04-01	5376	Mar 6	14:38
cron	456	Apr 29	04:02
cron-2015-04-05	1028	Apr 5	04:02
cron-2015-04-12	912	Apr 12	04:02
cron-2015-04-19	797	Apr 19	04:02
cron-2015-04-26	910	Apr 26	04:02
dmesg	21618	Apr 17	10:33
faillog	0	Feb 6	09:45
hsm.log	50063	Apr 28	19:04
lastlog	21900	Apr 29	14:36
lost+found	16384	Mar 5	2013
lunalog	1353225	Apr 29	14:52
lunalog-2015-04-05	2896633	Apr 5	04:02
lunalog-2015-04-12	2892767	Apr 12	04:01
lunalog-2015-04-19	2537642	Apr 19	04:01
lunalog-2015-04-26	2746220	Apr 26	04:01
maillog	0	Mar 5	2013
messages	2604899	Apr 29	14:51
messages-2015-04-05	8710648	Apr 5	04:02
messages-2015-04-12	8709357	Apr 12	04:02
messages-2015-04-19	6948162	Apr 19	04:02
messages-2015-04-26	5284444	Apr 26	04:02
ntls_bt_2015-02-06_10_08_34	3112	Feb 6	10:08
ntls_bt_2015-02-06_14_17_11	3112	Feb 6	14:17
prelink	4096	Mar 6	2013
rpmpkgs	5719	Apr 29	04:02
rpmpkgs-20130310-0402	4649	Mar 9	2013
rpmpkgs-20130317-0402	4649	Mar 16	2013
rpmpkgs-20130516-0402	4649	Mar 20	2013
rpmpkgs-20130519-0402	4649	May 18	2013
rpmpkgs-2015-04-05	5719	Apr 4	04:02
rpmpkgs-2015-04-12	5719	Apr 11	04:02
rpmpkgs-2015-04-19	5719	Apr 18	04:02
rpmpkgs-2015-04-26	5719	Apr 25	04:02
secure	248	Apr 29	14:36
secure-2015-04-05	9995	Apr 2	00:53
secure-2015-04-12	362	Apr 6	21:14
secure-2015-04-19	1662	Apr 17	13:36
secure-2015-04-26	720	Apr 20	13:55
spooler	0	Mar 5	2013
tallylog	0	Feb 6	09:45

```
update5_2_6_1.log          828 Feb 17 18:02
update6_0_0_31.log        11131 Feb 6 10:02
update6_0_0_33.log        10615 Feb 17 18:12
wtmp                       173184 Apr 29 14:36
wtmp-2015-04-23           1061760 Apr 23 03:14
```

Command Result : 0 (Success)

syslog tail

Display the last entries of the syslog. If no number is included, the command displays the entire syslog.

Syntax

```
syslog tail -logname <logname> [-entries <logentries>] [-search <string>]
```

Parameter	Shortcut	Description
-entries	-e <logname>	Specifies the number of entries to display. If this parameter is not specified, the entire log is displayed. Range: 0-2147483647
-logname	-l <logentries>	Specifies the log name. Valid values: lunalog, messages, secure, hsm, ntp, snmp
-search	-s <string>	Search for the specified string.

Example

```
lunash:>syslog tail -logname hsm -entries 3
```

```
2011 Apr 3 14:49:02 myLuna local6 info oamp[2244]: INFO: SM_Init OK
2011 Apr 3 14:49:02 myLuna local6 info oamp[2244]: INFO: Supported callback I/O v.1
2011 Apr 3 14:49:02 myLuna local6 info oamp[2244]: INFO: Supported callback protocol v.1
```

```
Command Result : 0 (Success)
```

syslog tarlogs

Archives log files to logs.tar file in scp temporary directory. A single logs.tgz file allows you to obtain all the logs in one operation.

Syntax

syslog tarlogs

Example

```
lunash:>syslog tarlogs
```

The tar file containing logs is now available via scp as filename 'logs.tgz'.

```
Command Result : 0 (Success)
```

token

Access the token-level commands. These commands are separate menus for token HSMS as backup devices or token HSMS used in PKI mode.

Syntax

token

backup

pki

Parameter	Shortcut	Description
backup	b	Access the token backup commands. See " token backup " on the next page.
pki	p	Access the token pki commands. See " token pki " on page 540.

token backup

Access the token backup commands.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

Syntax

token backup

factoryreset
init
list
login
logout
partition
show
update

Parameter	Shortcut	Description
factoryreset	f	Reset a backup token to factory default settings. See "token

Parameter	Shortcut	Description
		backup factoryreset" on page 514.
init	i	Initializes the token with the specified serial number and prepares it to receive backup data. See "token backup init" on page 516.
list	li	List all backup tokens. See "token backup list" on page 518.
login	logi	Login backup token admin. See "token backup login" on page 520.
logout	logo	Logout backup token admin. See "token backup logout" on page 522.
partition	p	Access the token backup partition commands to manage your backup partitions. See "token backup partition" on page 523.
show	s	Get backup token information. See "token backup show" on page 531.
update	u	Update commands. See "token backup update" on page 533.

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

When labeling HSMs or partitions, never use a numeral as the first, or only, character in the name/label. Token backup commands allow slot-number OR label as identifier which can lead to confusion if the label is a string version of a slot number.

For example, if the token is initialized with the label "1" then the user cannot use the label to identify the target for purposes of backup, because VTL parses "1" as signifying the numeric ID of the first slot rather than as a text label for the target in whatever slot it really occupies (the target is unlikely to be in the first slot), so backup fails.

LunaSH token backup commands on SafeNet Network HSM would be unable to see SafeNet Backup HSM slots maintained by Remote Backup server. Either connect the Backup HSM locally to the SafeNet Network HSM USB port to use token backup commands, or use VTL commands directed to a SafeNet Remote Backup HSM connected to a computer configured as a backup server.

token backup factoryreset

Reset a backup token to factory default settings (destroys the KEK or permanently denies access to existing objects, erases or authentication, so you need to initialize before using again). Can be run only from the local serial console.

The action is equivalent to the `hsm factoryReset` command that acts on the appliance's built-in HSM.

View a table that compares and contrasts various "deny access" events or actions that are sometimes confused. "[Destroy" action/event scenarios](#) (Right-click the link if you prefer that it not open in a new window.)

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

`hsm ped vector init -serial <serial#_of_external_HSM>`
and
`hsm ped connect -serial <serial#_of_external_HSM>`
before using `token pki` or `token backup` commands.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?



LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM [connects directly to a SafeNet Network HSM via USB cable]* and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case,

these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.



For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

Syntax

token backup factoryReset -serial <serialnum> [-force]

Parameter	Shortcut	Description
-serial	-s	Specifies the token serial number.
-force	-f	Force the action without prompting.

Example

```
lunash:> token backup factoryReset -serial 667788
```

```
Command Result : 0 (Success)
```

```
lunash:>
```

If you run the command via a network connection, the system refuses:

```
lunash:>token backup factoryReset
```

```
Error: 'token factoryReset' can only be run from the local
console. Login as 'admin' using the serial port on
the SafeNet Network HSM before running this command.
```

```
Command Result : 0 (Success)
```

token backup init

Initializes the token with the specified serial number and prepares it to receive backup data. Both the "-label" and "-serial" parameters are required at the command line. For SafeNet Network HSM with Password Authentication, the domain and Token Admin (SO) password are prompted, and your input is obscured by asterisk (*) symbols. For SafeNet Network HSM with Trusted Path authentication, any typed values for domain or password are ignored and you are prompted for SafeNet PED operations with PED Keys.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

Syntax

token backup init -label <label> -serial <serialnum> [-domain <domain>] [-tokenadminpw <password>] [-force]

Parameter	Shortcut	Description
-domain	-d	Backup Token Domain (required for Password authenticated HSMs, ignored for PED authenticated - if you prefer to not type it in the clear, on the command line, it is prompted later).
-force	-f	Force the action without prompting.

Parameter	Shortcut	Description
-label	-l	Token label.
-serial	-s	Token serial number.
-tokenadminpw	-t	Token Admin / SO Pas.sword (required for Password authenticated HSMs, ignored for PED authenticated - if you prefer to not type it in the clear, on the command line, it is prompted later).

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

Example

```
[myluna] lunash:> token init -label mytoken -serial 667788
Please enter a password for the Token Administrator:
> *****
Please enter a domain
> *****
Command result : 0 (Success)
[myluna] lunash:>
```

token backup list

Display a list all of the backup tokens on the system. This command shows all connected backup devices with their serial numbers. Use the serial number that you find with this command to identify specific backup HSMs or partitions that you can then query with the **token backup partition list** command for more detailed information.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

Syntax

token backup list

Example

```
lunash:>token backup list
```

```
Token Details:
=====
Token Label: G5backup2
Slot: 6
Serial #: 7000179
Firmware: 6.0.8
Hardware Model: SafeNet USB HSM
```

Token Details:

=====

Token Label: G5backup1

Slot: 7

Serial #: 700010

Firmware: 6.0.8

Hardware Model: SafeNet USB HSM

Token Details:

=====

Token Label: p1-15/04/2011

Slot: 1

Serial #: 5

Firmware: 4.8.6

Hardware Model: Luna PCM G4

Command Result : 0 (Success)

token backup login

Log the Backup Token Administrator into the backup token. This command is used immediately before performing a firmware update on a backup token.

Remember to always log out of the backup token using the **token backup logout** command.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and

hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

Syntax

token backup login -serial <serialnum> [-password <password>]

Parameter	Shortcut	Description
-serial	-s	Specifies the serial number of the backup HSM/token.
-password	-p	Specifies the Backup Token Administrator's password. This parameter is mandatory in SafeNet Network HSM with Password Authentication. It is ignored in SafeNet Network HSM with PED Authentication.

Example

```
lunash:> token backup login -serial 667788
```

```
Luna PED operation required to login to backup token - use blue PED Key.  
'token backup login' successful.
```

token backup logout

Log out the backup Token Administrator from the backup token.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

Syntax

token backup logout -serial <serialnum>

Parameter	Shortcut	Description
-serial	-s	Specifies the serial number of the backup HSM/token.

Example

```
lunash:> token backup logout -serial 667788
```

```
'token logout' successful.
```

token backup partition

Access the token backup partition commands to manage your backup partitions.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and

hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

Syntax

token backup partition

delete
list
show

Parameter	Shortcut	Description
delete	d	Delete a backup partition. See
list	l	List the backup partitions. See
show	s	List the objects on a backup token. See

token backup partition delete

Delete a backup partition on the Backup device and free the license used by the HSM Partition. To use the token backup partition delete command you must be logged in to the Backup HSM as HSM Admin.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

Syntax

token backup partition delete -partition <partition_name> -serial <serialnum> [-force]

Parameter	Shortcut	Description
-force	-f	Specifies that the Backup Token partition is erased without prompting the user for a confirmation of this destructive command.
-partition	-p	Specifies the name of the Backup Token partition to delete. Obtain the Backup Token partition name by using the token backup partition list command.
-serial	-s	Specifies the serial number of the Backup Token partition to delete. Obtain the Backup Token partition serial number by using the token backup partition list command.

Example

```
lunash:> token backup partition -delete -partition b1 -serial 667788
CAUTION: Are you sure you wish to delete the partition named:
b1
Type 'proceed' to delete the partition, or 'quit'
to quit now.
> quit
'token backup partition -delete' aborted.
lunash:> token backup partition -delete -partition b1
CAUTION: Are you sure you wish to delete the partition named:
b1
Type 'proceed' to delete the partition, or 'quit'
to quit now.
> proceed
'token backup partition -delete' successful.
```

token backup partition list

Display a list of the partitions on the specified SafeNet Backup HSM. The serial number and name of each partition is displayed. Login as HSM Admin is not needed for execution of this command.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

The HSM firmware needs approximately 2K bytes of memory to manage each partition and data objects in it. To avoid you having to calculate the exact memory space available for data storage -- with you deducting the memory used by internal data structures -- the "partition list" command adjusts the memory size attributes for you. Thus, the total available memory reported by "partition list" will be different than that reported by "token backup show" and "token backup partition list."

Syntax

token backup partition list -serial <serialnum>

Parameter	Shortcut	Description
-serial	-s	Specifies the serial number of the backup HSM/token.

-serial <serialnum> [mandatory] The serial number of the backup HSM/token.

Example

```
lunash:> token backup partition list -serial 667788  
Partition: 65001001,      Name: calvin  
Partition: 65001002,      Name: brigitte
```


token backup partition show

Display a list of objects on the backup token/HSM.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

Syntax

token backup partition show -partition [<partitionName>] **-serial** <serialnum> **-password** <backup_token/hsm_userPassword>

Option	Short	Parameter	Description
-password	-pas	<token partition password>	Specifies the password of the partition for which to display information. If you do not specify a password, you are prompted to enter it when you execute the command.
-partition	-par	<token partition name>	Specifies the name of the partition for which to display information. By default information about all partitions is shown. Obtain the partition name by using the partition list command.
-serial	-s	<token serial	The serial number of the partition for which to display information. By default

Option	Short	Parameter	Description
		number>	information about all partitions is shown. Obtain the partition name by using the partition list command.

Example

```
lunash:>token backup partition show -par mypartition1 -serial 667788
Please enter the user password for the token:
```

```
> *****
```

```
Partition Name: mypartition1
```

```
Partition SN: 696969008
```

```
Number objects: 9
```

```
Object Label: Generated DES3 Key
```

```
Object Type: Symmetric Key
```

```
Object Label: Generated RSA Public Key
```

```
Object Type: Public Key
```

```
Object Label: Generated RSA Private Key
```

```
Object Type: Private Key
```

```
Object Label: Generated RSA Public Key
```

```
Object Type: Public Key
```

```
Object Label: Generated RSA Private Key
```

```
Object Type: Private Key
```

```
Object Label: Generated DSA Public Key
```

```
Object Type: Public Key
```

```
Object Label: Generated DSA Private Key
```

```
Object Type: Private Key
```

```
Object Label: Generated DES Key
```

```
Object Type: Symmetric Key
```

```
Object Label: Generated AES Key
```

```
Object Type: Symmetric Key
```

```
Command Result : 0 (Success)
```

token backup show

Displays the token label and firmware version for the specified backup token.



CAUTION: Wait at least 20 seconds before you run the **token backup show** command after performing a backup token backup firmware update.

If you run the **token backup show** command within 10 seconds or less following a successful completion of token backup update firmware, the **token backup show** command will hang and the green LED on the token reader will continue to flash. The work-around for the hanging state is to remove and re-insert the backup token and then rerun the **token backup show** command.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM [connects directly to a SafeNet Network HSM via USB cable]* and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office [or other convenient location]*, connected to a computer acting as a *Remote Backup server [this could be your administrative workstation, or it could be a completely separate computer]*. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software [which must be installed on the computer that is acting as Remote Backup server]* - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

The HSM firmware needs approximately 2K bytes of memory to manage each partition and data objects in it. To avoid you having to calculate the exact memory space available for data storage -- with you deducting the memory used by internal data structures -- the "partition list" command adjusts the memory size attributes for you. Thus, the total available memory reported by "partition list" will be different than that reported by "token backup show" and "token backup partition list."

Syntax

token backup show -serial <serialnum>

Parameter	Shortcut	Description
-serial	-s	The serial number of the backup HSM/token.

Example

```

lunash:> token backup show -serial 667788
Token Details:
=====
Token Label: samBK
Serial #: 667788
Firmware: 6.0.8
Hardware Model: SafeNet USB HSM
Authentication Method: PED keys
Token Admin login status: Logged In
Token Admin login attempts left: 3 before Token zeroization!

Partition Information:
=====
Partitions licensed on token: 20
Partitions created on token: 0
-----

There are no partitions.

Token Storage Information:
=====
Maximum Token Storage Space (Bytes): 16252928
Space In Use (Bytes): 0
Free Space Left (Bytes): 16252928

License Information:
=====
621010355-000 621-010355-000 G5 Backup Device Base
621000005-001 621-000005-001 Backup Device Partitions 20
621000006-001 621-000006-001 Backup Device Storage 15.5 MB
621000007-001 621-000007-001 Backup Device Store MTK Split Externally
621000008-001 621-000008-001 Backup Device Remote Ped Enable

Command result : 0 (Success)

```

token backup update

Access the token backup update commands to update the backup token capabilities or firmware.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like " C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

Syntax

token backup update

capability
firmware
show

Parameter	Shortcut	Description
capability		Update the capabilities for a backup token. See "token backup update capability" on page 535.

Parameter	Shortcut	Description
firmware		Update the firmware on a backup token. See "token backup update firmware" on page 537.
show		Show a list of the available backup token updates. See "token backup update show" on page 538.

token backup update capability

Update Backup Token Capability, using a capability update package that you have acquired from SafeNet and transferred via scp to the SafeNet appliance. Before you can use this command, you must:

- acquire the secure package update file from SafeNet and send the file to the SafeNet Network HSM (using scp or pscp)
- open the file on the SafeNet Network HSM with the lunash command **package update** <filename> **-authcode** <authcode>

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like " C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

Syntax

token backup update capability -serial <serialnum> **-capability** <capabilityname> [**-force**]

Parameter	Shortcut	Description
-capability	-c	Specifies the capability name.
-force	-f	Force the action without prompting.
-serial	-s	Specifies the token serial number.

Example

```
lunash:>token backup update capability -serial 667788 -capability newcapability
```

CAUTION: This command updates the Token Capability.
This process cannot be reversed.

Type 'proceed' to continue, or 'quit'
to quit now.

```
> proceed
```

This is a NON-destructive capability update

Update Result :0 (Capability newcapability added)

Command Result : 0 (Success)

token backup update firmware

Update the firmware on a backup token, using a firmware update package available on the SafeNet appliance. The package must be transferred to the SafeNet appliance by scp (individually or as a component of a system update), and you must login to the backup token as Token Administrator (using the **token backup login** command) or SO before the token backup update firmware command is run. The command requires no package name.

The term "token" in this case refers to removable token-format HSMs connected via SafeNet DOCK 2 and USB, or SafeNet Remote Backup HSM, connected via USB.

Before you can use this command, you must:

- acquire the secure package update file from SafeNet and send the file to the SafeNet Network HSM (using scp or pscp)
- open the file on the SafeNet Network HSM using the **package update** command.



Note: Firmware update is a local operation only, and is not supported remotely.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like "C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

Syntax

token backup update firmware -serial <serialnum> [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-serial	-s	Specifies the token serial number.

Example

```
lunash:>token backup update firmware -serial 667788
```

CAUTION: This command updates the Token firmware.
This process cannot be reversed.

Type 'proceed' to continue, or 'quit'
to quit now.

```
>proceed
```

```
Success  
Firmware updated.
```

token backup update show

Display information about any capability updates that are available for backup tokens. This refers to update files that have been uploaded to the SafeNet appliance and are available to be applied to an attached backup HSM.

Note: WHEN to USE lunash "token backup" commands, or use "vtl backup" commands?

LunaSH token backup commands operate a SafeNet Backup HSM attached directly to SafeNet Network HSM via USB, and are **not** intended for use with remotely connected backup devices.

You might have a *locally-connected backup HSM* [connects directly to a SafeNet Network HSM via USB cable] and a locally connected serial terminal and be walking them from SafeNet Network HSM to SafeNet Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Network HSM to the next. In either case, these "token backup" commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Network HSM perspective, those are both local backup operations to a Backup HSM that is locally connected to the appliance.



VTL backup commands operate a SafeNet Backup HSM connected to a computer, and located distantly from your primary SafeNet Network HSM appliance. The VTL backup commands are **not** for use with a SafeNet Backup HSM that is connected directly to your SafeNet Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Remote Backup HSM located in your *administrator's office* [or other convenient location], connected to a computer acting as a *Remote Backup server* [this could be your administrative workstation, or it could be a completely separate computer]. This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Network HSM appliance(s). For that application, use the **backup commands in the VTL utility** supplied with the SafeNet Network HSM *Client software* [which must be installed on the computer that is acting as Remote Backup server] - the appliance token backup commands (previous paragraph) are not designed to work for Remote Backup.

Syntax

token backup update show -serial <serialnum>

Parameter	Shortcut	Description
-serial	-s	Specifies the serial number of the backup token.

Example

Capability updates are not available

```
lunash:> token backup update show -serial 667788
```

```
Capability Updates:
```

```
  There are no capability updates available.
```

Command Result : 0 (Success)

Capability updates are available

```
lunash:> token backup update show
```

```
Capability Updates:  
  HsmStorage15.5Meg  
  Partitions20
```

Command Result : 0 (Success)

token pki

Access the **token pki** commands. These commands allow you to operate token HSMs (with SafeNet USB HSM connected to the SafeNet Network HSM via USB) when used in PKI mode.



Note: The PKI Bundle feature is supported with PED-authenticated SafeNet Network HSM, and the connected SafeNet USB HSM must also be PED-authenticated.

PKI bundling with password-authenticated SafeNet Network HSM or SafeNet USB HSM is not supported.



Note: The SafeNet Network HSM PKI Bundle option does not support Per-Partition Security Officer (PPSO). That is, a SafeNet USB HSM that is USB-connected to a SafeNet Network HSM appliance can be configured with any compatible firmware, including firmware version 6.22.0 (or newer), but cannot have the PPSO capability applied.



Note: SafeNet Network HSM PKI Bundle option **does not support** the use of SafeNet DOCK2 and removable PCMCIA token HSMs (SafeNet CA4).

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

Syntax

token pki

activate
 changepin
 clone
 deploy
 factoryreset
 listall
 listdeployed
 predeploy
 resetpin
 undeploy
 update

Parameter	Shortcut	Description
activate	a	Activate PKI Token for use with your application. See "token pki activate" on page 543.
changepin	ch	Change PKI Token PIN. See "token pki changepin" on page 544.
clone	cl	Clone PKI Token contents. See "token pki clone" on page 546.
deploy	d	Deploy PKI Token. See "token pki deploy" on page 548.
factoryreset	fr	Factory Reset PKI Token. See "token pki factoryreset" on page 550.
listall	lista	List All PKI Tokens. See "token pki listall" on page 551.
listdeployed	listd	List All Deployed Tokens. See "token pki listdeployed" on page 552.
predeploy	p	Pre-deploy PKI Token. See "token pki predeploy" on page 553.
resetpin	r	Reset PKI Token PIN. See "token pki resetpin" on page 555.
undeploy	un	Undeploy PKI Token. See "token pki undeploy" on page 557.
update	up	Access the token pki update commands. See "token pki update" on page 558.



Note: The above commands prepare an HSM, externally connected to a SafeNet Network HSM appliance, for operation in the PKI use-case. However, once the external HSM has been deployed for PKI bundle, it must be assigned to the remote client, by means of the command "client assignpartition" on page 53.

token pki activate

Cache a deployed PKI token's PED key data. Clients can then connect, authenticate with their token password, and perform operations with token objects, without need for hands-on PED operations each time. Activation/caching endures until terminated by token removal or appliance power off. If a token has not been activated, then each access attempt by a Client causes a login call which initiates a SafeNet PED operation (requiring the appropriate black PED Key). Unattended operation is possible while the token is activated.

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and

hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

Syntax

token pki activate -label <token_label>

Parameter	Shortcut	Description
-label	-l	Specifies the name of the inserted, deployed token to activate. Use the token pki listdeployed command to get the token name.

Example

```
lunash:> token pki activate -label mylunaca4-1
```

```
'token activate' successful.
```

token pki changepin

Change the challenge secret or password for the indicated PKI device.

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

Syntax

token pki changePin -serial <tokenserialnumber> [-force]

Parameter	Shortcut	Description
-force	-f	Force the action with no prompting.
-serial	-s	Specifies the serial number of the inserted token, whose password or challenge is to change. Use the token pki list command to get the token serial number.

Example

```
lunash:> token pki changepin -serial 1766711
```

```
Please type "proceed" to continue, anything else to abort: proceed
```

```
*****  
*                                         *
```



```
*      About to change the user password      *
*      Please pay attention to the PED        *
*      *                                       *
*****
```

Please enter the current user challenge:

The partition has not been activated yet.

Luna PED operation required to activate partition on HSM - use User or Partition Owner (black) PED key.

Please enter the new user challenge:

Please re-enter the new user challenge:

Success changing the user password for slot 4 !

Command Result : 0 (Success)

token pki clone

Clone a source PKI device to a target PKI device.

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

Syntax

token pki clone -source <serial_number> -target <serial_number> [-force]

Parameter	Shortcut	Description
-force	-f	Force the action with no prompting.
-source	-s	Specifies the serial number of the inserted PKI token HSM, whose contents are to be securely copied (cloned) to another HSM. Use the token pki list command to get the token serial number.
-target	-t	Specifies the serial number of the inserted PKI token HSM, which is to receive the securely copied (cloned) contents of the source HSM. Use the token pki list command to get the token serial number.

Example

```
lunash:> token pki clone -source 700180 -target 700179
```

```
Please type "proceed" to continue, anything else to abort: proceed
```

```
Please enter the user challenge for source token:
```

```
Please enter the user challenge for target token:
```

```
Successfully cloned object 14 from source slot 5 to object 11 on target slot 4  
Successfully cloned object 15 from source slot 5 to object 12 on target slot 4  
Successfully cloned object 16 from source slot 5 to object 13 on target slot 4  
Successfully cloned object 17 from source slot 5 to object 14 on target slot 4  
Successfully cloned object 18 from source slot 5 to object 15 on target slot 4  
Successfully cloned object 19 from source slot 5 to object 16 on target slot 4  
Successfully cloned object 20 from source slot 5 to object 17 on target slot 4  
Successfully cloned object 21 from source slot 5 to object 18 on target slot 4  
Successfully cloned object 22 from source slot 5 to object 19 on target slot 4  
Successfully cloned object 23 from source slot 5 to object 20 on target slot 4  
Successfully cloned object 24 from source slot 5 to object 21 on target slot 4  
Successfully cloned object 25 from source slot 5 to object 22 on target slot 4  
Successfully cloned object 26 from source slot 5 to object 23 on target slot 4  
Successfully cloned object 27 from source slot 5 to object 24 on target slot 4  
Successfully cloned object 28 from source slot 5 to object 25 on target slot 4  
Successfully cloned object 29 from source slot 5 to object 26 on target slot 4  
Successfully cloned object 30 from source slot 5 to object 27 on target slot 4  
Successfully cloned object 31 from source slot 5 to object 28 on target slot 4  
Successfully cloned object 32 from source slot 5 to object 29 on target slot 4  
Successfully cloned object 33 from source slot 5 to object 30 on target slot 4
```

```
Success cloning 20 objects from source slot 5 to destination slot 4
```

```
Success cloning token with serial num: 700180 to token with serial num: 700179!
```

```
Command Result : 0 (Success)
```

token pki deploy

Make the pre-deployed (initialized) token/hsm available to the SafeNet Network HSM appliance as another (removable) HSM partition or PKCS#11 slot, for use by your application(s).



Note: It may take up to one minute for the token to be visible to all clients.

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

Syntax

token pki deploy -label <token_label> -serial <serial_number>

Parameter	Shortcut	Description
-label	-l	Specifies the name of the inserted, pre-deployed token to deploy.
-serial	-s	Specifies the serial number of the inserted, pre-deployed token to deploy.

Example

```
lunash:> token pki deploy -label mylunag5pki -serial 475289
```

```
*****  
*                                     *  
*   About to activate the token for testing. *  
*   Please pay attention to the PED         *  
*                                     *  
*****
```

Please enter the current user challenge:

Success deploying token mylunag5pki with serial num 475289 !

Command Result : 0 (Success)



Note: The above command prepares an HSM, externally connected to a SafeNet Network HSM appliance, for operation in the PKI use-case. However, once the external HSM has been deployed for PKI bundle, it must be assigned to the remote client, by means of the command "client assignpartition" on page 53.

token pki factoryreset

Resets the backup token to factory default. You must run this command from the local serial console.

This command works on a removable PKI token in a connected SafeNet DOCK 2, or on a SafeNet USB HSM. If both are connected, both are seen. If two SafeNet USB HSMs are connected for PKI, both are seen. With multiple PKI devices connected, the "tokenfactoryreset" command affects only the device that you identify by serial number. If a backup device (token or SafeNet Remote Backup HSM) is connected, it is ignored by the "token pki..." command.

The action is equivalent to the **hsm factoryReset** command that acts on the appliance's built-in HSM.

See "Destroy action/event scenarios" to view a table that compares and contrasts various "deny access" events or actions that are sometimes confused.

Syntax

token pki factoryreset -serial <serial_number> [-force]

Parameter	Shortcut	Description
-force	-l	Force the action without prompting.
-serial	-s	Specifies the serial number of the token to reset.

Example

```
lunash:> token pki factoryReset -serial 123456
```

```
Command Result : 0 (Success)
```

token pki listall

Lists all PKI devices on the system. For a list of only the deployed devices, run the **token pki listdeployed** command.

Syntax

token pki list

Example

```
lunash:> token pki listall
```

```
Token Details:
```

```
=====
```

```
Token Label:      G5PKI1
Slot:             5
Serial #:         7000180
Firmware:         6.0.8
Hardware Model:   SafeNet USB HSM
```

```
Token Details:
```

```
=====
```

```
Token Label:      CA4
Slot:             2
Serial #:         10007
Firmware:         4.8.6
Hardware Model:   Luna PCM G4
```

token pki listdeployed

Lists all deployed PKI devices.

Syntax

token pki listdeployed

Example

```
lunash:> token pki listdeployed
```

Label	Serial Num

G5PKI1	7000180

token pki predeploy

Initialize a G5 HSM/token for use as a PKI device in SafeNet Network HSM. This command prepares the token to be recognized and deployed.



Note: The PKI Bundle feature is supported with PED-authenticated SafeNet Network HSM. The connected SafeNet USB HSM must be PED-authenticated. PKI bundling with password-authenticated SafeNet Network HSM or SafeNet USB HSM is not supported.

Syntax

```
lunash:> token pki predeploy -label <tokenlabel> -serial <serialnum> [-force]
```

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-label	-l	Specifies the name of the inserted token to pre-deploy.
-serial	-s	Specifies the serial number of the token to pre-deploy.

Example

```
lunash:> token pki predeploy -label myPKI -serial 777199 -force
```

```
Please type "proceed" to continue, anything else to abort: proceed
```

```
*****
*                                     *
*      About to factory Reset the HSM   *
*                                     *
*****
*****
*                                     *
*      About to initialize the HSM       *
*      Please pay attention to the PED   *
*                                     *
*****
```

```
Do you want to use FIPS-approved algorithms and key strengths only (yes or no)? yes
```

```
*****
*                                     *
*      About to change the HSM FIPS policy *
*      Please pay attention to the PED   *
*                                     *
*****
*****
*                                     *
*      About to create a partition on the HSM *
*      Please pay attention to the PED   *
*                                     *
*****
*****
*                                     *
*      About to set the partition policies *
*                                     *
```

```
* Please pay attention to the PED *
* *
*****
*****
* *
* About to create a partition challenge *
* and activate the partition. *
* Please pay attention to the PED *
* Please write down the PED secret! *
* *
*****
```

Please enter the partition challenge:

Please attend to the PED.
Success predeploying the token!!

Command Result : 0 (Success)

token pki resetpin

Reset the challenge secret or password for the indicated PKI device.

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

Syntax

token pki resetPin -serial <token_serial_number> [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-serial	-s	Specifies the serial number of the inserted token, whose password or challenge is to be reset. Use the token pki list command to get the token serial number.

Example

```
lunash:> token pki resetPin -serial 475289
```

Please type "proceed" to continue, anything else to abort: proceed

Luna PED operation required to login as HSM Administrator - use Security Officer (blue) PED key.

Please ensure that you copy the password from the Luna PED and that you keep it in a safe place.

Command Result : 0 (Success)

token pki undeploy

Makes the deployed token/hsm unavailable to the SafeNet Network HSM appliance - no longer visible as another (removable) HSM partition or PKCS#11 slot, no longer accessible for use by your application(s).

Syntax

token pki undeploy -label <tokenlabel> [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-label	-l	Specifies the token label.

Example

```
lunash:> token pki undeploy -label myG5Pki
```

```
Please type "proceed" to continue, anything else to abort: proceed  
Success undeploying token myG5Pki
```

```
Command Result : 0 (Success)
```

token pki update

Access the pki update commands to update the token capabilities or firmware.

LunaSH token pki commands on SafeNet Network HSM would be unable to see SafeNet USB HSM PKI slots connected to a remote workstation. Either connect the SafeNet USB HSM locally to the SafeNet Network HSM USB port to use token backup commands, or use VTL commands on an HSM connected to a computer configured as a Client of your SafeNet Network HSM.

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like " C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

Syntax

pki update

capability
firmware
login
logout
show

Parameter	Shortcut	Description
capability	c	Update the token capabilities. See "token pki update capability" on the next page.
firmware	f	Update the token firmware. See "token pki update firmware" on page 562.
login	logi	Login the PKI token Admin. See "token pki update login" on page 563.
logout	logo	Logout the PKI token Admin. See "token pki update logout" on page 564.
show	s	Show the available token updates. See "token pki update show" on page 565.

token pki update capability

Update PKI Token Capability, using a capability update package available on the SafeNet appliance (that is, a package that you have acquired from SafeNet, and transferred via scp, to the SafeNet appliance). Before you can use this command, you must:

- a) acquire the secure package update file from SafeNet and send the file to the SafeNet Network HSM (using scp or pscp)
- b) open the file on the SafeNet Network HSM with the lunash command "package update <filename> -authcode <authcode>"

An external SafeNet HSM can be USB-connected to a SafeNet Network HSM appliance for:

- local backup/restore operations (SafeNet Backup HSM)
- PKI bundle operations (SafeNet USB HSM)

SafeNet Network HSM does not pass PED operations and data through to an externally connected SafeNet HSM from a SafeNet PED that is connected locally to the SafeNet Network HSM.

If the external HSM is PED-authenticated, then the options for SafeNet PED connection are:

- local PED connection, directly to the affected HSM, when needed, or
- Remote PED connection, passed through the SafeNet Network HSM



Note: Support for PKI Bundles with Remote PED begins at firmware version 6.10.1 in the external HSM.



Note: Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.



Note: Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM>
and

hsm ped connect -serial <serial#_of_external_HSM>
before using **token pki** or **token backup** commands.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like "C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

Syntax

token pki update capability -serial <serialnum> -capability <capabilityname> [-force]

Parameter	Shortcut	Description
-capability	-c	Specifies the capability name.
-force	-f	Force the action without prompting.
-serial	-l	Specifies the token serial number.

Example

```
lunash:> token pki update capability -serial 777199-capability newcapability -f
```

Success

Capability newcapability added.

Command result : 0 (Success)

token pki update firmware

Update Token firmware, using a firmware update package available on the SafeNet appliance.

The package must be transferred to the SafeNet appliance by scp (individually or as a component of a system update), and you must login to the PKI token as Token Administrator or SO before the 'token pki update firmware' command is run.

The command requires no package name.

The term "token" in this case refers to removable token-format HSMs connected via SafeNet DOCK 2 and USB (legacy equipment), or to a SafeNet USB HSM, connected via USB.

Before you can use this command, you must:

- acquire the secure package update file from SafeNet and send the file to the SafeNet Network HSM (using scp or pscp)
- open the file on the SafeNet Network HSM with the lunash command `package update <filename> -authcode <authcode>`

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like " C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

Syntax

token pki update firmware -serial <serialnum> [-force]

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.
-serial	-s	Specifies the token serial number.

Example

```
lunash:> token pki update firmware -serial 475289
```

CAUTION: This command updates the Token firmware.
This process cannot be reversed.

```
Type 'proceed' to continue, or 'quit'
to quit now.
> proceed
```

```
Partition #: 14 Name: Cryptoki User      Status: Passed
```

```
Update Result : 0 (Success)
```

```
Command Result : 0 (Success)
```

token pki update login

Logs in the PKI token admin - required before you can update the token firmware or token capabilities.

Syntax

token pki update login -serial <serialnum>

Option	Short	Parameter	Description
-password	-p	<backup hsm/token Admin/SO password>	Specifies the backup hsm or token's admin/SO password.
-serial	-s	<backup hsm/token serial number>	Specifies the token serial number.

Example

```
lunash:> token pki update login -serial 777199
```

Luna PED operation required to login to Token - use Security Officer (blue) PED Key.

```
'token pki login' successful.
```

```
Command result : 0 (Success)
```

token pki update logout

Log out the PKI token admin.

Syntax

token pki update logout -serial <serialnum>

Parameter	Shortcut	Description
-serial	-s	Specifies the token serial number.

Example

```
lunash:> token pki update logout -serial 777199
```

```
Command result : 0 (Success)
```

token pki update show

Show the available token capability updates.

Syntax

token pki update show

Example

```
lunash:> token pki update show  
Capability Updates:
```

```
    There are no capability updates available.
```

```
Command Result : 0 (Success)
```

user

Access the user-level command. With the user commands, the HSM Appliance admin can create (add) additional named users and assign them roles of greater or lesser capability on the system. The admin can also lock (disable), unlock (enable) such accounts, set/reset their passwords, or delete them entirely, as needed.

Users without the "admin" role cannot execute any "user" command, even to change their own password. They should use the **my password set** command to change their own password.

The current implementation creates named users that are separate from the roles that those users can hold. The purpose is to allow administrators to assign any of the roles to multiple people, to allow logged tracking, by name, of the actions of each user in a given role (this was not possible previously when the role was the user, and only one of each could exist).

Syntax

user

add
delete
disable
enable
list
password
role

Parameter	Shortcut	Description
add	a	Add LunaSH user. See "user add" on the next page.
delete	de	Delete a named LunaSH user. See "user delete" on page 568.
disable	di	Disable a LunaSH user (but the user still exists with role(s) assigned. See "user disable" on page 569
enable	e	Enable a locked LunaSH user (with whatever roles are assigned to that user). See "user enable" on page 570.
list	l	List the LunaSH user accounts. See "user list" on page 571.
password	p	Set User Password. See "user password" on page 572.
role	ro	Access the user role commands. See "user role" on page 574.

user add

Add a LunaSH user. Adds a new administrative lunash (command line) user. This command is available only to the 'admin' account. Administrative users' names can be a single character or as many as 128 characters, chosen from letters a-z, or A-Z, numbers 0-9, the dash, the dot, or the underscore. No spaces.

abcdefghijklmnopqrstuvwxyABCDEFGHIJKLMNOPQRSTUVWXYZ0123456789-._

After the new, named administrative user is created, its default password is PASSWORD. The newly-created administrative user cannot do anything in the LunaSH until the 'admin' assigns it a role with the **user role add** command.

Syntax

user add -username <clientname>

Parameter	Shortcut	Description
-username	-u	Specifies the user name of the user to create.

Example

```
lunash:> user add -u smith
Stopping sshd:          [ OK ]
Starting sshd:         [ OK ]
Command Result : 0 (Success)
```

user delete

Delete a role from a user. This command removes a LunaSH user. Works on any named users that you have created. Does not affect the permanent users 'admin', 'operator', and 'monitor'. A user must be logged out before you can delete that user.

Syntax

user delete -username <clientname>

Parameter	Shortcut	Description
-username	-u	Specifies the user name of the user being removed.

Example

```
lunash:>user list
Users      Roles      Status      RADIUS
admin      admin      enabled     no
bob        monitor    enabled     no
john       admin      enabled     no
monitor    monitor    enabled     no
operator   operator   enabled     no
```

Command Result : 0 (Success)

```
lunash:>user delete -userName john
Command Result : 0 (Success)
```

```
lunash:>user list
Users      Roles      Status      RADIUS
admin      admin      enabled     no
bob        monitor    enabled     no
monitor    monitor    enabled     no
operator   operator   enabled     no
```

Command Result : 0 (Success)

user disable

Disable a named LunaSH user.

Syntax

```
user disable -username <clientname>
```

Parameter	Shortcut	Description
-username	-u	Specifies the user name of the user to disable.

Example

```
lunash:>user disable -username indigo  
indigo was disabled successfully.
```

```
Command Result : 0 (Success)
```

user enable

Enable a locked LunaSH user.

Syntax

user enable -username <clientname>

Parameter	Shortcut	Description
-username	-u	Specifies the user name of the user being enabled.

Example

```
lunash:>user enable -username indigo  
indigo was enabled successfully.
```

```
Command Result : 0 (Success)
```

user list

List all of the LunaSH user accounts

Syntax

user list

Example

```
lunash:>user list
Users      Roles      Status      RADIUS
admin      admin      enabled     no
audit      audit      enabled     no
bob        monitor    enabled     no
john       admin      enabled     no
monitor    monitor    enabled     no
operator   operator   enabled     no
```

Command Result : 0 (Success)

user password

Sets/changes the specified user's password. This command allows the SafeNet appliance admin to change a user's password. The user with 'admin' role may set the password for any user. Non-admin users may set only their own password using the **my password set** command.

Syntax

user password [<clientname>]

Parameter	Shortcut	Description
<clientname>		This parameter is required when the admin user sets other user's passwords. It is optional for other users setting their own passwords. The user name option can be used by the admin user to specify any user that has been created. Users other than 'admin' may specify their own user name or leave the option blank. Users with the "admin" role can change their own passwords and other named users' passwords. The password is not input with the command - it is prompted after the command is issued, and the typed input is not displayed, for security reasons.

Example

```
lunash:> user password smith
```

Changing password for user smith.

You can now choose the new password.

A valid password should be a mix of upper and lower-case letters, digits, and other characters. You should use a minimum 8-character-long password with characters from at least 3 of these 4 classes.

An upper case letter that begins the password and a digit that ends it do not count towards the number of character classes used.

Enter new password:

Re-type new password:

passwd: all authentication tokens updated successfully.

Command Result: 0 (Success)

user radiusadd

Add a RADIUS-authenticated user. This command adds a new administrative lunash (command line) user. This command is available only to the 'admin' account. Administrative users' names can be a single character or as many as 128 characters, chosen from letters a-z, or A-Z, numbers 0-9, the dash, the dot, or the underscore. No spaces.

abcdefghijklmnopqrstuvwxyzABCDEFGHIJKLMNOPQRSTUVWXYZ0123456789-._

After the new, named administrative user is created, it can authenticate via RADIUS only. The newly-created administrative user cannot do anything in LunaSH until the 'admin' assigns it a role with the **user role add** command.

Syntax

user radiusadd -username <clientname>

Parameter	Shortcut	Description
-username	-u	Specifies the user name of the user to add.

Example

```
lunash:> user radiusadd -u smith
```

```
Stopping sshd:          [ OK ]
Starting sshd:         [ OK ]
```

```
Command Result : 0 (Success)
```

user role

Access the user role commands to manage the roles associated with a user account.

Syntax

user role

add
clear
delete
list

Option	Shortcut	Description
add	a	Add a role to a LunaSH user. See "user role add" on the next page.
clear	c	Clears user role assignments. See "user role clear" on page 577.
delete	d	Delete a role from a LunaSH user. See "user role delete" on page 578.
list	l	List the possible role assignments. See "user role list" on page 579.

user role add

A *user* is an identity on the SafeNet appliance. A user has a name. The name of a user:

- can be one of four standard/ built-in user names (the general administrative users 'admin', 'operator' or 'monitor', and the special 'audit' user whose only function is managing the auditing of the HSM), or
- it can be any name that you wish to make up for operational convenience.

A *role* is a profile defining a level of access and authority with respect to the appliance. A role has a name that can be any of 'admin', 'operator', 'monitor' or 'audit'. Those role names happen to be the same as the names of the built-in, permanent user names. The access and authority conferred by a role do not change.

A named user - one that you create - can have one of the four roles assigned to it, which confers upon that user a specific access and authority on the appliance. A built-in user always has the same role as its name, but a named user can have any one of the four roles, which then defines what that named user can do on the appliance.

This **user role add** command adds a role to a named LunaSH administrative or auditor user that you have already created with the **user add** command. This command is available only to the original 'admin' account, and cannot be used to modify the "built-in" 'admin', 'operator', 'monitor' or 'audit' accounts (whose names are permanently the same as their roles).

The purpose of this command in combination with the **user add** command is to apply one of the possible roles to a new named user, which defines the scope of access and authority of that named user.

For example, in the sample below, we create a new user called "indigo" and give indigo the authority of "operator". Therefore, if you can log in as the built-in user named "operator", you can perform read-and-write operations with some limits, and if you can log in as user "indigo", you have exactly the same scope of operation and abilities/constraints as would someone logged in as user "operator". Of course, this assumes that the role is also enabled with **user enable** command.

Adding a role to a user displaces or overwrites any previous role held by that user. To see the role currently held by a user, run the **user role list -userName <username>** command.

Syntax

user role add -username <username> -role <rolename>

Parameter	Shortcut	Description
-username	-u	Specifies the name of the existing named user account to which the role is being added.
-role	-r	The name of the administrative role being added to that user. The available roles, in descending order of capability are admin, operator, and monitor, for general administration, and audit for managing HSM auditing functions.

Example

```
lunash:>user role add -role operator -username indigo
```

```
User indigo was successfully modified.
```

```
Command Result : 0 (Success)
```

```
lunash:>user role list -userName indigo
```

Roles for user indigo:

operator

Command Result : 0 (Success)

user role clear

Clears all roles assigned to an account. This command is available only to the 'admin account and cannot be used to modify the admin, monitor or operator accounts. If user has only one role, then the effect is the same as the user role delete command. This command is infrastructure for possible future functionality.

Syntax

```
user role clear -username <clientname>
```

Option	Short	Parameter	Description
-username	-u	<name of user>	Specifies the name of the user account from which the role is being removed.
-force	-f	.	Force the action. Useful for scripting.

Example

```
lunash:>user role clear -username indigo
```

```
User indigo was successfully modified.
```

```
Command Result : 0 (Success)
```

user role delete

Delete a role from a user account. This command is available only to the original 'admin' account and cannot be used to modify the admin, monitor, operator, or audit accounts.

Syntax

user role delete -role <clientname> **-username** <clientname>

Parameter	Shortcut	Description
-username	-u	Specifies the name of the user account from which the role is being removed.
-role	-r	The role name of the role being removed from the user. The available roles, in descending order of capability are admin, operator and monitor, and the special role audit.

Example

```
lunash:>user role delete -role operator -username indigo
```

User indigo was successfully modified.

Command Result : 0 (Success)

user role list

List the available user roles that can be assigned to a user. The "built-in" account called 'admin' has the full "admin" role, the "built-in" account called 'operator' has the "operator" role, and "built-in" account called 'monitor' has the "monitor" role. Those three roles can also be applied/assigned, as desired, to any new named account that the original, built-in 'admin' user cares to create.

Syntax

user role list [-username <name of the role>]

Option	Short	Parameter	Description
-username	-u	<name of system user>	See the roles assigned to the named user.
.	.	.	If no user is named, all users and their roles are listed.

Example

```
lunash:>user role list
```

```
Available Roles:
```

```
-----
admin
audit
monitor
operator
```

```
Command Result : 0 (Success)
```

webserver

The **webserver** command set is available in LunaSH (lunash:>) if your SafeNet Network HSM appliance is at version 6.0 or higher, and you have the REST API configuration upgrade installed.

Syntax

webserver

```
enable
disable
certificate
bind
ciphers
show
```

Parameter	Shortcut	Description
enable	e	Enable REST API service. See " webserver enable " on page 588.
disable	d	Disable REST API service. See " webserver disable " on page 588.

Parameter	Shortcut	Description
certificate	ce	Manage REST API service certificate. See "webserver certificate " on the next page.
bind	b	Set REST API service network port. See "webserver bind " on the next page.
ciphers	ci	Manage REST API service cipher suite. See "webserver ciphers " on page 585.
show	s	Show REST API service configuration and status. See "webserver show " on page 589.

webserver bind

Set the REST API service to use a network port.

Syntax

webserver bind -netdevice <netdevice> [-port <port number>] [-force] [-restart]

Parameter	Shortcut	Description
-netdevice	-n	Network device that REST API Service is to use for communication. Valid values: all, eth0, eth1, bond0.
-force	-f	Force the action without prompting.
-port	-p	Network port that REST API Service is to use for communication. Range: 80 to 65535 Default: 8443
-restart	-r	Restart the REST API service if parameter is specified. Otherwise, the administrator must restart the REST API service via other means (i.e., "service start webserver").

Example

```
lunash:>webserver bind -netdevice eth0 -port 8443 -restart -force
```

```
Restarting REST API service...
Stopping webserv:OK
Starting webserv:OK
```

```
Command Result : 0 (Success)
```

webserver certificate

Syntax

webserver certificate

generate
show

Parameter	Shortcut	Description
generate	g	Create REST API service certificate. See " webserver certificate generate " on the next page.
show	s	Show REST API service configuration and status. See " webserver certificate show " on page 584.

webserver certificate generate

Generates a REST API Server certificate.

Syntax

```
webserver certificate generate -keytype <key_type> [-keysize <size>] [-curve <curve_name>] [-restart] [-force]
```

Parameter	Shortcut	Description
-keytype	-keyt <key_type>	Key type (ecc, rsa).
-keysize	-keys <size>	RSA key size: default to 2048 (2048,3072,4096).
-curve	-c <curve_name>	Elliptic Curve name: default to secp384r1
-force	-f	Force the action without prompting.
-restart	-r	Restart the REST API service if parameter is specified. Otherwise, the administrator must restart the REST API service via other means (i.e., "service start webserver").

Example

```
lunash:>webserver certificate generate -keytype ecc -restart
```

```
WARNING: This operation will generate/regenerate the REST API Server certificate !!!
```

```
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed
Proceeding...
```

```
REST API Server Certificate:
```

```
Data:
```

```
Version: 3 (0x2)
```

```
Serial Number:
```

```
92:9f:98:7e:a7:cc:71:ce
```

```
Signature Algorithm: ecdsa-with-SHA1
```

```
Issuer: C=CA, ST=Ontario, L=Ottawa, O=Gemalto, CN=mylunasa6
```

```
Validity
```

```
Not Before: Nov 3 15:47:00 2015 GMT
```

```
Not After : Oct 31 15:47:00 2025 GMT
```

```
Subject: C=CA, ST=Ontario, L=Ottawa, O=Gemalto, CN=mylunasa6
```

```
Subject Public Key Info:
```

```
Public Key Algorithm: id-ecPublicKey
```

```
Public-Key: (384 bit)
```

```
pub:
```

```
04:93:1e:c4:da:50:59:71:cf:97:50:32:6f:98:3c:
```

```
af:c2:e9:b2:e9:f9:9e:3c:5a:ee:e3:51:b5:68:b8:
```

```
d5:22:fe:04:ae:24:3b:9b:96:ac:8c:13:94:ee:2e:
```

```
0a:7d:c1:65:64:22:83:da:e1:6a:23:30:10:01:96:
```

```
5a:11:32:92:ce:65:2f:e2:fb:fe:61:f0:cd:a4:95:
```

```
25:50:7e:9f:f0:61:37:87:0e:e1:71:21:48:ce:bc:
```

```
        da:11:b5:64:ee:33:89
        ASN1 OID: secp384r1
X509v3 extensions:
  X509v3 Subject Key Identifier:
    0C:90:D7:97:8D:57:0F:E8:15:F1:63:CB:C1:4D:E0:B5:AD:95:AF:5C
  X509v3 Authority Key Identifier:
    keyid:0C:90:D7:97:8D:57:0F:E8:15:F1:63:CB:C1:4D:E0:B5:AD:95:AF:5C

  X509v3 Basic Constraints:
    CA:TRUE
Signature Algorithm: ecdsa-with-SHA1
30:65:02:30:4d:01:3b:d1:fd:ec:64:56:30:35:eb:bd:3b:32:
d3:40:5a:0a:83:1d:b5:ba:f0:ad:16:c4:b5:af:95:4a:53:eb:
ea:9b:53:ac:6e:54:1c:4c:4a:50:72:fd:0d:0b:2b:a5:02:31:
00:90:44:fc:05:42:37:fc:f7:3e:54:b8:04:75:af:62:7e:d2:
91:67:b3:39:6e:07:82:6b:4f:c0:37:82:c4:86:67:2e:68:1f:
66:df:b8:5d:8c:17:a6:ae:07:eb:79:f5:59
```

```
Restarting REST API service...
Stopping adminApi:OK
Starting adminApi:OK
```

```
Command Result : 0 (Success)
```

webserver certificate show

Shows the REST API Server certificate.

Syntax

webserver certificate show

Example

```
lunash:>webserver certificate show
```

REST API Server Certificate:

Data:

Version: 3 (0x2)

Serial Number:

9d:54:50:3d:9d:ba:db:74

Signature Algorithm: sha384WithRSAEncryption

Issuer: C=CA, ST=Ontario, L=Ottawa, O=Gemalto, CN=172.20.9.127

Validity

Not Before: Oct 21 12:15:19 2015 GMT

Not After : Oct 18 12:15:19 2025 GMT

Subject: C=CA, ST=Ontario, L=Ottawa, O=Gemalto, CN=172.20.9.127

Subject Public Key Info:

Public Key Algorithm: rsaEncryption

Public-Key: (2048 bit)

Modulus:

```
00:a5:72:4b:dd:0a:9a:f8:45:bf:06:d1:dd:e7:08:
ea:88:f5:6f:e8:98:0a:f1:8b:62:af:d2:dc:8e:9d:
27:0b:dd:74:bc:a2:56:cb:c2:7e:f5:67:b4:80:4a:
0b:85:d7:51:b4:e0:0d:63:a7:cf:d0:fc:2e:2b:58:
35:48:8c:74:1d:c4:43:52:ab:74:f1:ee:7e:4f:b0:
6d:30:e9:b6:43:35:08:8a:26:ae:9b:f9:a9:23:ca:
88:1c:a5:cc:8d:19:99:ce:c6:2f:52:83:d0:e3:9a:
0a:c0:4d:25:61:62:9d:51:fc:6a:e9:84:fd:88:66:
29:8b:ff:24:ac:3d:22:2a:bf:d7:42:e7:ba:32:22:
e2:cc:1a:37:5b:7f:be:4e:d6:9e:c3:82:65:4e:5a:
8f:1f:f8:48:58:9b:83:38:ff:4e:e7:84:2c:b7:fa:
d5:cc:d6:02:b9:49:91:4c:f5:99:fe:cf:82:8e:40:
16:0c:91:17:f0:df:3f:4f:e8:ce:a9:09:c6:cb:8c:
87:92:ef:60:34:09:db:0b:03:8f:44:c4:91:48:3f:
8d:67:30:36:78:e6:e5:8f:e6:af:74:5f:b2:97:d7:
4e:bf:e0:5f:05:cb:2b:41:ae:78:aa:f9:06:64:6d:
50:ee:d3:3a:37:09:61:05:c0:54:8e:53:13:ca:08:
6d:5b
```

Exponent: 65537 (0x10001)

X509v3 extensions:

X509v3 Subject Key Identifier:

7F:5B:21:C6:E2:54:18:3B:36:E3:E7:3E:22:23:8A:B5:94:B1:05:66

X509v3 Authority Key Identifier:

keyid:7F:5B:21:C6:E2:54:18:3B:36:E3:E7:3E:22:23:8A:B5:94:B1:05:66

X509v3 Basic Constraints:

CA:TRUE

Signature Algorithm: sha384WithRSAEncryption


```

71:47:49:46:3c:1b:9b:42:38:f9:1d:23:a3:fd:4c:a4:cc:68:
da:c6:14:2e:92:e8:78:85:71:e0:39:dc:e2:ea:e1:b0:0b:ba:
59:7b:41:ce:c4:60:33:f8:8d:30:bc:d4:34:9a:13:07:09:cc:
0a:d6:2e:26:77:65:f2:1e:ed:c8:13:6f:16:18:bf:71:9a:d7:
8e:df:d3:d7:86:b9:98:de:ae:90:cb:66:5c:2c:33:1e:d7:f6:
05:45:b3:3a:34:b8:1b:e9:c5:29:d1:48:4b:c5:7b:ac:a2:e2:
d7:af:df:5d:74:c7:7d:d2:32:3f:9d:09:41:6f:07:83:c0:b1:
ad:d8:ac:f4:95:43:4c:fa:da:4c:ea:27:1f:f1:33:75:40:d8:
bd:cc:45:11:04:0e:e1:95:da:70:89:fd:e6:26:a5:63:fa:d9:
3f:14:63:55:0e:06:63:c6:a3:54:7f:61:cc:07:54:3c:fb:47:
14:89:2e:84:ca:1d:c9:d7:dc:c6:1a:91:95:c0:32:40:2c:8f:
3c:4c:a8:d3:b7:aa:92:92:e4:fa:ce:91:c3:3d:d1:11:c5:ee:
7b:b5:cc:35:de:f6:6e:b4:91:f5:57:b7:d9:fd:70:e2:e3:1d:
2e:69:f3:39:3e:c8:c4:e2:3e:4d:b2:ed:10:94:d0:e5:00:9a:
56:ad:9e:97

```

Command Result : 0 (Success)

webserver ciphers

Set or show the REST API Server ciphers suite.

Syntax

webserver certificate

```

set
show

```

Parameters	Shortcut	Description
set	se	Set REST API Server ciphers suite. See " webserver ciphers set " on the next page.
show	sh	Show REST API Server supported ciphers. See " webserver ciphers show " on page 587 .

webserver ciphers set

Sets REST API Server ciphers suite.

Syntax

webserver ciphers set -list <cipher_list> [-restart] [-force]

Parameter	Shortcut	Description
-list	-l <cipher_list>	Colon separated list of ciphers. To allow all ciphers, set "-list all".
-force	-f	Force the action without prompting.
-restart	-r	Restart the REST API service if parameter is specified. Otherwise, the administrator must restart the REST API service via other means (i.e., "service restart webserver").

Example



Note: This example is small for illustrative purposes and does not reflect an adequate cipher suite for operational use.

```
lunash:>webserver ciphers set -list ECDHE-RSA-AES256-GCM-SHA384:ECDHE-ECDSA-AES256-GCM-
SHA384:ECDHE-RSA-AES256-SHA384:ECDHE-ECDSA-AES256-SHA384:DHE-DSS-AES256-GCM-SHA384:DHE-RSA-
AES256-GCM-SHA384:DHE-DSS-AES256-SHA256:DHE-DSS-AES256-SHA256:ADH-AES256-GCM-SHA384:ADH-AES256-
SHA256:ECDH-RSA-AES256-GCM-SHA384:ECDH-ECDSA-AES256-GCM-SHA384:ECDH-RSA-AES256-SHA384:ECDH-
ECDSA-AES256-SHA384:AES256-GCM-SHA384:AES256-SHA256 -restart -force
```

New REST API Service ciphers suite:

```
ECDHE-RSA-AES256-GCM-SHA384:ECDHE-ECDSA-AES256-GCM-SHA384:ECDHE-RSA-AES256-SHA384:ECDHE-ECDSA-
AES256-SHA384:DHE-DSS-AES256-GCM-SHA384:DHE-RSA-AES256-GCM-SHA384:DHE-DSS-AES256-SHA256:DHE-DSS-
AES256-SHA256:ADH-AES256-GCM-SHA384:ADH-AES256-SHA256:ECDH-RSA-AES256-GCM-SHA384:ECDH-ECDSA-
AES256-GCM-SHA384:ECDH-RSA-AES256-SHA384:ECDH-ECDSA-AES256-SHA384:AES256-GCM-SHA384:AES256-
SHA256
```

Restarting REST API service...

Stopping webserv:OK

Starting webserv:OK

Command Result : 0 (Success)

webservice ciphers show

Show the REST API Server supported ciphers.

Syntax

webservice ciphers show

Example

```
lunash:>webservice ciphers show
```

```
Ciphers suite supported by REST API Server:
```

```
ECDHE-RSA-AES256-GCM-SHA384, ECDHE-ECDSA-AES256-GCM-SHA384, ECDHE-RSA-AES256-SHA384,  
ECDHE-ECDSA-AES256-SHA384, DHE-RSA-AES256-GCM-SHA384, DHE-RSA-AES256-SHA256,  
ECDH-RSA-AES256-GCM-SHA384, ECDH-ECDSA-AES256-GCM-SHA384, ECDH-RSA-AES256-SHA384,  
ECDH-ECDSA-AES256-SHA384, AES256-GCM-SHA384, AES256-SHA256, ECDHE-RSA-AES128-GCM-SHA256,  
ECDHE-ECDSA-AES128-GCM-SHA256, ECDHE-RSA-AES128-SHA256, ECDHE-ECDSA-AES128-SHA256,  
DHE-RSA-AES128-GCM-SHA256, DHE-RSA-AES128-SHA256, ECDH-RSA-AES128-GCM-SHA256,  
ECDH-ECDSA-AES128-GCM-SHA256, ECDH-RSA-AES128-SHA256, ECDH-ECDSA-AES128-SHA256,  
AES128-GCM-SHA256, AES128-SHA256
```

```
Command Result : 0 (Success)
```

webserver disable

Disable the REST API service.

Syntax

webserver disable -force

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>webserver disable -force
```

```
Flushing firewall rules:                [ OK ]
Setting chains to policy ACCEPT: filter [ OK ]
Unloading iptables modules:            [ OK ]
Applying iptables firewall rules:      [ OK ]
Loading additional iptables modules: ip_conntrack_netbios_n[ OK ]
Stopping webserv:OK
```

```
Command Result : 0 (Success)
```

webserver enable

Enable the REST API service. After enabling the service, use “service start webserver” to start the service.

Syntax

webserver enable [-force]

Option	Shortcut	Description
-force	-f	Force the action without prompting - useful for scripting.

Example

```
lunash:>webserver enable -force
```

```
Flushing firewall rules:                [ OK ]
Setting chains to policy ACCEPT: filter [ OK ]
Unloading iptables modules:            [ OK ]
Applying iptables firewall rules:      [ OK ]
Loading additional iptables modules: ip_conntrack_netbios_n[ OK ]
```

```
Command Result : 0 (Success)
```

webservice show

Show the REST API Server configuration.

Syntax

webservice disable -force

Parameter	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>webservice show
```

```
REST API Service:
=====
Package Version: 1.0.0-2
API Version: 1
Configuration: enabled
Status: running
Hostname: 172.20.9.127
IP address: 0.0.0.0
Port: 8443
Certificate Key Type: ecc
Curve Name: secp384r1
```

```
Command Result : 0 (Success)
```