

Linux on System z



Using the Dump Tools February, 2007

Linux Kernel 2.6 (April 2004 stream)

Linux on System z



Using the Dump Tools February, 2007

Linux Kernel 2.6 (April 2004 stream)

Note

Before using this information and the product it supports, read the information in “Notices” on page 29.

Second Edition (February 2007)

This edition applies to Linux kernel 2.6 (April 2004 stream), s390-tools version 1.5.0, and to all subsequent releases and modifications until otherwise indicated in new editions.

© **Copyright International Business Machines Corporation 2001, 2007. All rights reserved.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Summary of changes	v
Edition 2 changes	v
Chapter 1. Introduction	1
Stand-alone tools	1
VMDUMP	2
Chapter 2. Using a DASD dump device	3
Installing the DASD dump tool.	3
Initiating a DASD dump	4
Copying the dump from DASD	4
Using the zgetdump tool	4
Using the lcrash tool	5
Chapter 3. Using a tape dump device	7
Installing the tape dump tool	7
Initiating a tape dump	7
Tape display messages	8
Copying the dump from tape	8
Preparing the dump tape.	8
Using the zgetdump tool	9
Chapter 4. Using a SCSI dump device	11
Installing the SCSI disk dump tool	11
SCSI dump tool parameters	11
Example 1: Combined dump and target partition	11
Example 2: Menu configuration with separate dump and target partitions	12
Initiating a SCSI dump	13
Printing the dump header	14
Chapter 5. Using VMDUMP	15
Initiating a dump with VMDUMP	15
Copying the dump to Linux	15
Converting the dump.	15
Appendix A. Examples for initiating dumps	17
z/VM	17
Using DASD.	17
Using tape	17
Using VMDUMP	17
HMC or SE	18
Appendix B. Obtaining a dump with limited size	23
Appendix C. Command summary	25
The zgetdump tool	25
Examples	25
The crash tool	27
The lcrash tool	27
The vmconvert tool	27
Example	28
Notices	29

Trademarks	30
----------------------	----

Summary of changes

This revision reflects changes to the April 2004 stream until February, 2007.

Edition 2 changes

Changes compared to SC33-8286-00 are as follows:

New Information

- The vmconvert tool now supports positional parameters.
- The vmconvert tool can now handle dumps from VM guests with more than 2 GB (for z/VM version 5.2 or later).

Changed Information

This revision also includes maintenance and editorial changes.

Deleted Information

- None.

Chapter 1. Introduction

This document describes tools for obtaining dumps of Linux® for System z, zSeries®, and S/390® instances.

You can use the dump analysis tool **lcrash** (from lkcdutils version 3.1.2 and higher) or **crash** (from version 3.10-13.2) to analyze a dump. Depending on your service contract, you might also want to send a dump to IBM® support to be analyzed.

Visit <http://lkcd.sourceforge.net> for more information on Linux dump analysis.

Table 1 summarizes the available dump tools:

Table 1. Dump tools summary

Tool	Stand-alone tools			VMDUMP
	DASD	SCSI	Tape	
Environment	VM and LPAR	LPAR only	VM and LPAR	VM only ⁽¹⁾
Size	small, depending on disk size ⁽²⁾	large, depending on SCSI disk and what other data it contains	large because of multivolume support	2 GB up to z/VM® 5.2
Speed	fast	fast	slow	medium
Medium	ECKD™ or FBA ⁽³⁾ DASD	Linux file system on a SCSI disk	tape cartridges	VM reader
Compression possible	no	yes	yes ⁽⁴⁾	no
Disruptive ⁽⁵⁾	yes	yes	yes	no

Notes:

1. Dumps can include z/VM NSS's and DCSS's.
2. ECKD model 27, for example, provides 27 GB.
3. As of z/VM 5.1, SCSI disks can be emulated as FBA disks. This dump method can, therefore, be used for SCSI-only VM installations.
4. IBM TotalStorage® Enterprise Tape System 3590 and IBM 3490 Magnetic Tape Subsystem offer hardware compression.
5. The dump process kills a running operating system.

Note on device nodes

In all examples, the traditional device nodes for DASD, tape, and SCSI devices are used. If you are using a Linux distribution that provides udev, you can also use the device nodes that udev creates for you. Refer to your distribution documentation to find out which nodes are available.

Stand-alone tools

Three stand-alone dump tools are shipped in the s390-tools package as part of the **zipl** package:

- DASD dump tool for dumps on DASD volumes
- Tape dump tool for dumps on (channel-attached) tape devices

- SCSI disk dump tool for dumps on a SCSI disks

You need to install these tools on the *dump device*. The dump device is the device you want to use for dumping the memory. If you install dump tools that are compiled for 64-bit, you can create both 64-bit and 31-bit Linux dumps. If you install dump tools that are compiled for 31-bit, you can create 31-bit Linux dumps only.

Typically, the system operator initiates a dump after a system crash, but you can initiate a dump at any time. To initiate a dump, you must IPL the dump device. This is destructive, that is, the running Linux operating system is killed. The IPL process writes the system memory to the IPL device (DASD and tape) or directly to a file on a SCSI disk.

All examples for installing stand-alone tools by using a **zipl** configuration file assume that `/etc/zipl.conf` is used as the configuration file and that `/etc/zipl.conf` is the default configuration file.

For more information on **zipl**, refer to the **zipl** man page and to the **zipl** description in *Linux on System z and zSeries Device Drivers, Features, and Commands*. You can find the latest version of this document on developerWorks® at:

ibm.com/developerworks/linux/linux390/october2005_documentation.html

VMDUMP

You can use the VM dump tool VMDUMP for the following types of Linux instances:

- VM guests on z/VM 5.1 or earlier with up to 2 GB memory
- VM guests on z/VM 5.2 or later with memory greater than 2 GB

The VMDUMP tool is a part of z/VM and does not need to be installed separately. Dumping with VMDUMP is not destructive. If you dump an operating Linux instance, the instance continues running after the dump is completed.

VMDUMP can also create dumps for VM guests that use z/VM named saved systems (NSS) and discontinuous saved segments (DCSS).

For more information on VMDUMP refer to *z/VM CP Command and Utility Reference*, SC24-6008.

Chapter 2. Using a DASD dump device

DASD dumps are written directly to a DASD partition that has not been formatted with a file system. The following DASD types are supported:

- ECKD DASDs
 - 3380
 - 3390
- FBA DASDs

This chapter provides information on how to install the stand-alone DASD dump tool, how to perform the dump process, and how to copy the dump to a file in a Linux file system.

Installing the DASD dump tool

Requirement: You need an unused DASD partition with enough space (memory size + 10 MB) to hold the system memory.

This section describes how to install the DASD dump tool on an unused DASD partition. Dumps are written to this partition.

The examples in this section assume that `/dev/dasdc` is the dump device and that we want to dump to the first partition `/dev/dasdc1`.

The steps you need to perform for installing the DASD dump tool depend on your type of DASD, ECKD or FBA:

- If you are using an ECKD-type DASD, perform all three of the following steps:
 - If you are using an FBA-type DASD, skip steps 1 and 2 and perform step 3 only:
1. Format your DASD with **dasdfmt** (ECKD only). A block size of 4 KB is recommended:

Example:

```
# dasdfmt -f /dev/dasdc -b 4096
```

2. Create a partition with **fdasd** (ECKD only). The partition must be sufficiently large (the memory size + 10 MB):

Example:

```
# fdasd /dev/dasdc
```

3. Install the dump tool using the **zipl** command. You can specify the dump device on the command line or use a configuration file.

Command line example:

```
# zipl -d /dev/dasdc1
```

Configuration file example:

- a. Edit `/etc/zipl.conf` to add the following lines:

```
[dump_dasd]
dumppto=/dev/dasdc1
```

- b. Issue:

```
# zipl dump_dasd
```

Note: When using an ECKD-type DASD formatted with the traditional Linux disk layout `ldl`, the dump tool must be reinstalled using **zipl** after each dump.

Initiating a DASD dump

To obtain a dump with the DASD dump tool, perform the following main steps:

1. Stop all CPUs.
2. Store status on the IPL CPU.
3. IPL the dump tool on the IPL CPU.

Note: Do not clear storage!

The dump process can take several minutes depending on the device type you are using and the amount of system memory. After the dump has completed, the IPL CPU should go into disabled wait.

The following PSW indicates that the dump process has completed successfully:

```
(31-bit) PSW: 000A0000 00000000  
(64-bit) PSW: 00020000 80000000 00000000 00000000
```

Any other disabled wait PSW indicates an error.

4. You can IPL Linux again.

See Appendix A, “Examples for initiating dumps,” on page 17 for more details.

Copying the dump from DASD

This section describes how to copy a DASD dump to a file system. You can use the **zgetdump** tool or the **lcrash** tool.

For general information on **zgetdump**, see “The zgetdump tool” on page 25 or the man page.

lcrash is maintained within the Linux Kernel Crash Dumps (LKCD) project. For more information, refer to the documentation at <http://lkcd.sourceforge.net> or to the man page.

Using the zgetdump tool

By default, the **zgetdump** tool takes the dump device as input and writes its contents to standard output. To write the dump to a file system you must redirect the output to a file.

Assuming that the dump is on DASD device `/dev/dasdb1` and you want to copy it to a file named `dump_file`:

```
# zgetdump /dev/dasdc1 > dump_file
```

You can also use **zgetdump** to display information on the dump. See “Checking whether a DASD dump is valid and printing the dump header” on page 27 for an example.

Using the lcrash tool

The '-s' (save dump) option of the LKCD crash analysis tool **lcrash** copies a dump from a DASD dump device to a file. The resulting dump is **gzip** compressed. This option is available with lkcdutils-4.2 or higher.

To copy a dump from DASD to a file system, call **lcrash** with the '-s' (save dump) and '-d' (dump device) options.

The '-s' option specifies the destination directory for the resulting dump file. If the destination directory contains a file 'bounds' which contains an ASCII integer *<n>*, **lcrash** uses this number to generate a dump file name of the form dump.<n>. After a dump has been written successfully, **lcrash** updates the bounds file and increments the number by 1.

If there is no bounds file, **lcrash** uses dump.0 as the dump file name. If there is no bounds file and a file dump.0 already exists, **lcrash** replaces the existing file dump.0 with the new dump.

You can optionally specify the '-p' option to display the progress of saving the dump.

Example:

```
# cat /tmp/bounds
# 2
# lcrash -s /tmp -d /dev/dasdc1 -p
lcrash
Lcrash is free software. It is covered by the GNU General Public License.
You are welcome to change it and/or distribute copies of it under certain
conditions. Type "help -C" to see the conditions. Absolutely no warranty
is given for Lcrash. Type "help -W" for warranty details.

- 100.0%

# ls /tmp
# bounds dump.2
# cat /tmp/bounds
# 3
```

The '-s' option is equivalent to using the **lcrash savedump** command (available with lkcdutils-4.2 or higher) but does not require the map and kerntypes files to be present. By using the **savedump** command, you can reduce the dump size further by discarding specific memory pages. Refer to the LKCD documentation for details.

Checking whether a dump is valid and printing the dump header

To print the dump file header and check if the dump is valid use **lcrash** with options '-i' and '-d'.

Example:

```
# lcrash -i -d /dev/dasdc1
Dump Type: s390 standalone dump
Machine: s390x (ESAME)
CPU ID: 0xff10000620640000

Memory Start: 0x0
Memory End: 0x10000000
Memory Size: 268435456
Time of dump: Fri Jul 2 18:51:06 2004
Number of pages: 65536
Kernel page size: 4096
Version number: 2
Magic number: 0xa8190173618f23fd
Dump header size: 4096
Dump level: 0x4
Build arch: s390x (ESAME)
Time of dump end: Fri Jul 2 18:51:31 2004

End Marker found! Dump is valid!
```

Chapter 3. Using a tape dump device

The following tape devices are supported:

- 3480
- 3490
- 3590

This chapter provides information on how to install the stand-alone tape dump tool, how to perform the dump process, and how to copy the dump to a file in a Linux file system.

Installing the tape dump tool

Requirement: Have enough empty tapes ready to hold the system memory (memory size + 10 MB).

The examples in this section assume that `/dev/ntibm0` is the tape device you want to dump to.

Perform these steps to install the tape dump tool:

1. Insert an empty dump cartridge into your tape device.
2. Ensure that the tape is rewound.
3. Install the dump tool using the **zipl** command. You can specify the dump device on the command line or use a configuration file.

Command line example:

```
# zipl -d /dev/ntibm0
```

Configuration file example:

- a. Edit `/etc/zipl.conf` to add the following lines:

```
[dump_tape]
dumpto=/dev/ntibm0
```

- b. Issue **zipl**:

```
# zipl dump_tape
```

Initiating a tape dump

You can accommodate a large dump by using multiple tapes. Only the first tape (that you IPL from) needs to have the tape dump tool installed.

To obtain a dump with the tape dump tool, perform the following main steps:

1. Set the cartridge loader to AUTO and insert a sufficient number of cartridges.
Attention: The dump tool loads tapes automatically from the cartridge holder and overwrites any data on them. Be sure that the cartridge holder does not hold tapes with data that are still needed.
2. Ensure that the tapes are rewound.
3. Stop all CPUs.
4. Store status on the IPL CPU.
5. IPL the dump tool on the IPL CPU.

Note: Do not clear storage!

The dump tool writes messages to the tape drive message display (not to the operator console). First the number of dumped MB is displayed. When a tape cartridge is full, it is automatically unloaded and the message `next*vol` is displayed. If more cartridges are available, they are loaded and the dump continues. If no cartridge is available, the dump tool waits for the operator to load one.

The dump process can take several minutes, depending on the device type you are using and the amount of system memory available. When the dump is complete, the message `dump*end` is displayed and the IPL CPU should go into disabled wait.

The following PSW indicates that the dump was taken successfully:

(31-bit) PSW: 000A0000 00000000
(64-bit) PSW: 00020000 80000000 00000000 00000000

Any other disabled wait PSW indicates an error.

6. You can IPL Linux again.

See Appendix A, “Examples for initiating dumps,” on page 17 for more details.

Tape display messages

next*vol

The dump tool loads the next tape cartridge, or, if none is available, waits for the operator to load one.

number

The number of MB dumped.

dump*end

The dump process ended successfully.

Copying the dump from tape

This section describes how to copy a tape dump to a file system using the **zgetdump** tool.

Prerequisite: You must have installed the **mt** utility.

Preparing the dump tape

You need to rewind the tape, and find the correct position on the tape to start copying from. Use the **mt** tool to do this.

1. Rewind the tape.

Example:

```
# mt -f /dev/ntibm0 rewind
```

2. Skip the first file on the tape (this is the dump tool itself).

Example:

```
# mt -f /dev/ntibm0 fsf
```


Using the zgetdump tool

For a multivolume dump, the cartridges must be loaded in the right order, starting with the first volume. You can use the cartridge loader for automatic loading. When **zgetdump** finds the end of a volume (that is not the end of the dump) it writes a message and attempts to load the next cartridge.

By default, the **zgetdump** tool takes the dump device as input and writes its contents to standard output. To write the dump to a file system you must redirect the output to a file.

Note: Always use the AUTO setting on your tape device when working with **zgetdump**.

Example: Assuming that the tape is in the correct position (see “Preparing the dump tape” on page 8) and is on tape device `/dev/ntibm0`, use the following command to copy the dump from tape to a file `dump_file` in the file system:

```
# zgetdump /dev/ntibm0 > dump_file
```

For general information on **zgetdump**, see “The zgetdump tool” on page 25 or the man page.

Checking whether a dump is valid, and printing the dump header

To check whether a single-volume or a multivolume dump is valid, use the **-i** option. For multivolume dumps, use the **-a** option to signal that you are working with a multivolume dump. For example, to check whether a multivolume dump is valid:

1. Ensure that the volumes are loaded in the correct sequence.
2. Skip the first file on the first tape (this is the dump tool itself):

```
# mt -f /dev/ntibm0 fsf
```

3. Issue:

```
# zgetdump -i -a /dev/ntibm0
```

zgetdump goes through all the volumes until it reaches the end of the dump. See also “Using zgetdump to copy a multivolume tape dump” on page 26.

Chapter 4. Using a SCSI dump device

You can use SCSI disks that are accessed through the `zfc` device driver as dump devices. SCSI disk dumps are written as files in an existing file system on the dump partition. No copying is necessary.

This section describes how to install the SCSI dump tool and how to initiate a SCSI dump.

Installing the SCSI disk dump tool

Requirement: The dump directory needs enough free space (memory size + 10 MB) to hold the system memory.

The SCSI dump tool (also referred to as the SCSI Linux System Dumper, or SD) is written to one partition, referred to here as the *target partition*. The dump can be written to a second partition, the *dump partition*, provided it is on the same physical disk. Only the target partition need be mounted when **zipl** is run. In a single-partition configuration, the target partition is also the dump partition.

SCSI dump tool parameters

When installing the SCSI disk dump tool, the following parameters can be specified in a 'parameters' line in the **zipl** configuration file or using the '-P' option in the **zipl** command line.

dump_dir=*/***<directory>**

Path to the directory (relative to the root of the dump partition) to which the dump file is to be written. This directory is specified with a leading slash. The directory must exist when the dump is initiated.

Example: If the dump partition is mounted as `/dumps`, and the parameter "dump_dir=/mydumps" is defined, the dump directory would be accessed as `/dumps/mydumps`.

The default is `"/"` (the root directory of the partition).

dump_compress=*gzip***none**

Dump compression option. Compression can be time-consuming on slower systems with a large amount of memory.

The default is `"none"`.

dump_mode=*interactive***auto**

Action taken if there is no room on the file system for the new dump file. "interactive" prompts the user to confirm that the dump with the lowest number is to be deleted. "auto" automatically deletes this file.

The default is `"interactive"`.

Example 1: Combined dump and target partition

This example assumes that `/dev/sda` is a SCSI device that contains no data and is to be used exclusively as a dump device. Because no other data is to be stored on the device, a single partition is created that serves as both dump and target partition. The example also shows how to use the **dump_compress** parameter to generate the dump in **gzip** format.

1. Create a single partition with **fdisk**, using the PC-BIOS layout:

Example:

```
# fdisk /dev/sda
```

The created partition is /dev/sda1.

2. Format this partition with a file system that is supported by the SCSI dump tool (for example, ext2 or ext3).

Example:

```
# mke2fs /dev/sda1
```

3. Mount the partition at a mount point of your choice and create a subdirectory to hold the dump files.

Example:

```
# mount /dev/sda1 /dumps  
# mkdir /dumps/mydumps
```

4. Install the dump tool using the **zipl** command. You can specify the dump device on the command line or use a configuration file.

Command line example:

```
# zipl -D /dev/sda1 -t /dumps -P "dump_dir=/mydumps dump_compress=gzip"
```

Configuration file example:

- a. Edit /etc/zipl.conf to add the following lines:

```
[scsidump]  
target=/dumps  
dumptofs=/dev/sda1  
parameters="dump_dir=/mydumps dump_compress=gzip"
```

- b. Issue **zipl**:

```
# zipl scsidump
```

5. Unmount the file system:

```
# umount /dumps
```

When /dev/sda1 is IPLed, the dump is written to directory mydumps on partition 1 of /dev/sda.

Example 2: Menu configuration with separate dump and target partitions

This example assumes that a SCSI device /dev/sda is to be used as a dump device. In the example, the dump configuration is part of a menu configuration. Menu configurations are specified in a zipl configuration file and have a common target directory that is specified in the menu section of the configuration file. To keep the dumps separated from other data, separate dump and target partitions are used. The example assumes that there are already three partitions:

- /dev/sda1 is the production partition and mounted as the root file system.
- /dev/sda2 is the target partition, has been formatted with the PC-BIOS disk layout, and is mounted under /boot. /boot contains files for two Linux boot configurations (parmfile, image-1, and image-2).

- /dev/sda3 is the dump partition and has been formatted with the PC-BIOS disk layout. The dump files are to be written to the root directory of the dump partition.
1. On the dump partition, create a file system that is supported by the SCSI dump tool (for example, ext2 or ext3):

```
# mke2fs /dev/sda3
```

2. Edit /etc/zip1.conf to add the following lines:

```
[ipl1]
image=/boot/image-1
parmfile=/boot/parmfile
target=/boot

[ipl2]
image=/boot/image-2
parmfile=/boot/parmfile
target=/boot

[scsidump1]
dumptofs=/dev/sda3
parameters="dump_compress=gzip"
target=/boot

# Menu containing all 3 configurations
:menu1
1=ipl1
2=ipl2
3=scsidump1
default=1
target=/boot
```

3. Install the menu configuration, including the dump tool, by issuing:

```
# zip1 --menu menu1
```

When specifying the configuration “scsidump1” at IPL time, the dump configuration is used and a system dump is initiated.

For more information on using a configuration file, see the zip1.conf man page or refer to *Linux on System z and zSeries Device Drivers, Features, and Commands*.

Initiating a SCSI dump

Restriction: You need to initiate SCSI dumps from the HMC or SE. You cannot initiate SCSI dumps from VM.

To initiate the dump, IPL the dump tool using the **SCSI dump** load type. See “HMC or SE” on page 18.

The dump process can take several minutes depending on the device type you are using and the amount of system memory. The dump progress and any error messages are reported on the operating system messages console.

The dump process creates a new dump file in the dump directory. All dumps are named dump.<n> where <n> is the dump number. A new dump receives the next highest dump number out of all dumps in the dump directory (see the **dump_dir** parameter under “SCSI dump tool parameters” on page 11).

Example: If there are already two dump files, “dump.0” and “dump.1”, in the dump directory, the new dump will be “dump.2”.

When the dump completes successfully, you can IPL Linux again.

See Appendix A, “Examples for initiating dumps,” on page 17 for more details.

You do not need to convert the dump or copy it to a different medium. To access the dumps, mount the dump partition.

Printing the dump header

To print the dump file header use **lcrash** with the **'-i'** and **'-d'** option.

```
# lcrash -i -d dump.0
Dump Type: LKCD-Dump
Systemname: Linux
Nodename: gfree06
Release: 2.6.5
Version: #7 SMP Fri Jul 2 16:17:35 CET 2004
Machine: s390x
Domainname: (none)
Memory Start: 0x0
Memory End: 0x10000000
Memory Size: 268435456
Time of dump: Fri Jul 2 18:51:06 2004
Panic string: zSeries-dump (CPUID = ff10000620640000)
Number of pages: 9378
Kernel page size: 4096
Version number: 8
Magic number: 0xa8190173618f23ed
mp header size: 734
Dump level: 0x4
```

Chapter 5. Using VMDUMP

You can use the VM dump tool VMDUMP and write the dump to a VM reader for the following types of Linux instances:

- VM guests on z/VM 5.1 or earlier with up to 2 GB memory
- VM guests on z/VM 5.2 or later with memory greater than 2 GB

VMDUMP does not need to be installed separately.

This section describes how to create a dump with VMDUMP, how to transfer the dump to Linux, and how to convert the VM dump to a convenient format.

Initiating a dump with VMDUMP

Issue the following command from the guest's 3270 console:

```
#CP VMDUMP
```

Result: VM stops the Linux guest and creates a dump file in the guest's VM reader. After the dump is complete the Linux guest continues operating.

You can use the "TO" option of the VMDUMP command to direct the dump to the reader of another guest of the same VM.

Example: To write the dump to a VM guest "linux02" issue:

```
#CP VMDUMP TO LINUX02
```

If you want to include NSSs and DCSSs in your dump, use the "ALL" operand:

```
#cp VMDUMP 0:ALL
```

For more information on VMDUMP refer to *z/VM CP Command and Utility Reference*, SC24-6008.

Copying the dump to Linux

Use the CMS DUMPLOAD command to access the dump. The DUMPLOAD command copies the dump from the VM reader to the CMS file system.

From the CMS file system, you can then transfer the dump to a Linux file system, for example with **ftp**.

Converting the dump

On Linux, you can use the **vmconvert** command to convert the dump into a format that can be processed with the Linux dump analysis tool **lcrash** or **crash**.

Example: To convert a VMDUMP-created dump file "myvmdump" into a dump file "mydump.lkcd" issue:

```
# vmconvert -f myvmdump -o mydump.lkcd
```

The created file, mydump.lkcd, can then be used as input to **lcrash**.

See “The vmconvert tool” on page 27 for more details.

Appendix A. Examples for initiating dumps

The following sections describe how to initiate a dump from different control points.

Note: SCSI dump from VM is not supported.

z/VM

The following examples assume the 64-bit mode. Corresponding 31-bit examples would have a different PSW but be the same otherwise.

Using DASD

If 193 is the dump device:

```
#cp cpu all stop
#cp store status
#cp i 193
```

On z/VM, a three-processor machine in this example, you will see messages about the disabled wait:

```
01: The virtual machine is placed in CP mode due to a SIGP stop from CPU 00.
02: The virtual machine is placed in CP mode due to a SIGP stop from CPU 00.
"CP entered; disabled wait PSW 00020000 80000000 00000000 00000000"
```

You can now IPL your Linux instance and resume operations.

Using tape

If 193 is the tape device:

```
#cp rewind 193
#cp cpu all stop
#cp store status
#cp i 193
```

On z/VM, a three-processor machine in this example, you will see messages about the disabled wait:

```
01: The virtual machine is placed in CP mode due to a SIGP stop from CPU 00.
02: The virtual machine is placed in CP mode due to a SIGP stop from CPU 00.
"CP entered; disabled wait PSW 00020000 80000000 00000000 00000000"
```

You can now IPL your Linux instance and resume operations.

Using VMDUMP

To initialize a dump with VMDUMP issue this command from your Linux guest's 3270 console:

```
#cp vmdump
```

Dumping does not force you to IPL. If the Linux instance ran as required before dumping, it will continue running when the dump is completed.


HMC or SE

You can initiate a dump process on an LPAR from an HMC (Hardware Management Console) or SE (Support Element). The following description refers to an HMC, but the steps also apply to an SE.


The steps are similar for DASD, tape, and SCSI. Differences are noted where applicable. You cannot initiate a dump with VMDUMP from the HMC or SE.

To initiate the dump:

1. Click the Groups icon in the Views Area of the HMC to display the Groups Work Area.



2. Click the Images icon in the Groups Work Area to display the CPC Images Work Area with all defined images.



Note: The appearance of the Stop and Start icons can vary. On some consoles

they appear as green  and red  traffic lights.

3. Select the image for which you want to initiate the dump.
4. Proceed according to your dump device:
 - If you are dumping to DASD or tape, click the Stop icon in the Task Area to stop all CPUs. Confirm when you are prompted to do so.
 - If you are dumping to a SCSI disk, skip this step and proceed with step 5.
5. Click the Load icon in the Task Area to display the Load panel.

For a dump to DASD or tape:

- a. Select **Load type** “Normal”.
- b. Select the **Store status** check box.
- c. Type the device number of the dump device into the **Load address** field.




Figure 1. Load panel for dumping to DASD or tape

For a dump to SCSI disk:

- a. Select **Load type** "SCSI dump".
- b. Type the device number of the FCP adapter for the SCSI disk into the **Load address** field.
- c. Type the World Wide Port name of the SCSI disk into the **World wide port name** field.
- d. Type the Logical Unit Number of the SCSI disk into the **Logical unit number** field.
- e. Type the configuration number of the dump IPL configuration in the **Boot program selector** field.

The 'configuration number' defines the IPL or dump configuration which is to be IPLed. The numbering starts with 1 and is related to the menu of IPL/dump entries in the **zipl** configuration file for the SCSI disk.

Configuration number 0 specifies the default configuration. In "Example 2: Menu configuration with separate dump and target partitions" on page 12, the dump configuration has the number 3.

- f. Leave the fields **Load parameter**, **Boot record logical block address**, and **OS specific load parameters** blank.




Figure 2. Load panel with enabled SCSI feature for dumping to SCSI disk

6. Click **OK** to start the dump.
7. Wait until the dump process completes. Check the dump progress according to your dump device:
 - If you are dumping to DASD or tape, click the Hardware Messages icon in the Task Area to display the hardware messages. When the dump process has completed, a hardware message indicates a disabled wait.
 - If you are dumping to a SCSI disk, click the Operating System Messages icon for progress and error information.

When the dump has completed successfully, you can IPL Linux again.

Appendix B. Obtaining a dump with limited size

The “mem” kernel parameter can make Linux use less memory than is available to it. A dump of a Linux system like this does not need to include the unused memory. You can use the **zipl** “size” option to limit the amount of memory that is dumped.

The “size” option is available for all **zipl** based dumps: DASD, tape, and SCSI, in command line mode or in configuration file mode. The “size” option is appended to the dump device specification, with a comma as separator.

The value is a decimal number that can optionally be suffixed with K for kilobytes, M for megabytes, or G for gigabytes. Values specified in byte or kilobyte are rounded to the next megabyte boundary.

Be sure not to limit the dump size below the amount of memory actually used by the system to be dumped. Limiting the below the amount of used memory results in an incomplete dump.

Example: The following command prepares a DASD dump device for a dump that is limited to 100 megabyte:

```
# zipl -d /dev/dasdc1,100M
```

An equivalent section in a configuration file could look like this:


```
[dump1]  
dumpto=/dev/dasdc1,100M
```


Appendix C. Command summary

The descriptions of the commands contain only the relevant options and parameters, for a full description refer to the man pages.

The zgetdump tool

The **zgetdump** tool reads a dump from the given dump device and writes its contents to standard out, unless the operator redirects it to a file.



Where:

<dumpdevice>

specifies the DASD or tape device where the dump is located.

<dump_file>

is the file to which the output is redirected. The default is standard out.

-i or --info

displays the header information from the dump and performs a validity check.

-a

signals that the dump is a multivolume tape dump.

-h or --help

displays the help information for the command.

Examples

Using zgetdump to copy a dump

Assuming that the dump is on DASD device `/dev/dasdb1` and that you want to copy it to a file named `dump_file`:

```
# zgetdump /dev/dasdb1 > dump_file
```

Using zgetdump to copy a multivolume tape dump

Assuming that the tape device is /dev/ntibm0:

```
# zgetdump /dev/ntibm0 > dump_file
Dump device: /dev/ntibm0

Tape Volume 0

>>> Dump header information <<<
Dump created on: Wed Jul  7 17:20:16 2004
Magic number:    0xa8190173618f23fd
Version number:  2
Header size:     4096
Page size:       4096
Physical memory: 268435456
Number of pages: 65536
cpu id:          0xff02453096720000
System Arch:     s390 (ESA)
Build Arch:      s390
>>> End of Dump header <<<

Reading dump content .....
End of Volume reached.

Waiting for next volume to be loaded... done

Tape Volume 1 of a multi volume dump.
Reading dump content .....
Dump ended on:   Wed Jul  7 17:23:31 2004

Dump End Marker found: this dump is valid.
```

Checking whether a multivolume tape dump is valid, and printing the dump header

Assuming that the tape device is /dev/ntibm0:

```
# zgetdump -i -a /dev/ntibm0

"zgetdump -i -a" checks if a multi-volume tape dump is valid.
Please make sure that all volumes are loaded in sequence.

Dump device: /dev/ntibm0

Tape Volume 0

>> Dump header information <<<
...

>> End of Dump header <<<

Checking if the dump is valid - this might take a while...
Reached End of Volume 0.
Waiting for Volume 1 to be loaded... done

Tape Volume 1 of a multi volume dump.
Dump End found: This Dump is valid.
```

Checking whether a DASD dump is valid and printing the dump header

Assuming that the dump is on a partition, part1, of a DASD device /dev/dasdb1:

```
# zgetdump -i /dev/dasdb1

> "zgetdump -i" checks if a dump on either
> a dasd volume or single tape is valid.
> If the tape is part of a multi-volume tape dump,
> it checks if it is a valid portion of the dump.

Dump device: /dev/dasdb1

>>> Dump header information <<<
Dump created on: Mon Jul  5 16:53:40 2004

Magic number:  0xa8190173618f23fd
Version number: 2
Header size:   4096
Page size:     4096
Physical memory: 268435456
Number of pages: 65536
cpu id:        0xff20000620640000
System Arch:   s390 (ESA)
Build Arch:    s390x (ESAME)
>>> End of Dump header <<<

Dump ended on:  Mon Jul  5 16:54:06 2004

Dump End Marker found: this dump is valid.
```

The crash tool

The **crash** tool is a GPL-licensed tool maintained by Red Hat. For more details see the tool online help.


The lcrash tool

The **lcrash** tool is maintained within the LKCD project. See the documentation at <http://lkcd.sourceforge.net> and the man page for further information.

The vmconvert tool

The **vmconvert** tool converts a dump that was created with VMDUMP into a that can be analyzed with **lcrash** or **crash**.

vmconvert syntax



Where:

`<vmdump_file>` or **-f** `<vmdump_file>` or **--file** `<vmdump_file>`
specifies the VMDUMP created dump file to be converted.

`<output_file>` or **-o** `<output_file>` or **--output** `<output_file>`
specifies the name of the dump file to be created. The default is dump.lkcd.

-v or **--version**
displays the tool version.

-h or **--help**
displays the help information for the command.

Example

To convert a VMDUMP-created dump file “vmdump1” into a dump file “dump1.lkcd” that can be processed with **lcrash** or **crash** issue:

```
# vmconvert -f vmdump1 -o dump1.lkcd
```

You can also use positional parameters:

```
# vmconvert vm.dump lkcd.dump
in: vm.dump, out: lkcd.dump
vmdump information: 20
architecture: 32 bit
date.....: Fri Feb 18 11:06:45 2005
storage.....: 16 MB
cpus.....: 6
16 of 16 |#####| 100%25
'lkcd.dump' has been written successfully.
```

Notices

This information was developed for products and services offered in the U.S.A. IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A.

For license inquiries regarding double-byte (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

IBM World Trade Asia Corporation
Licensing
2-31 Roppongi 3-chome, Minato-ku
Tokyo 106-0032, Japan

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law:

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

The licensed program described in this information and all licensed material available for it are provided by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement, or any equivalent agreement between us.

All statements regarding IBM's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

This information is for planning purposes only. The information herein is subject to change before the products described become available.

Trademarks

The following terms are trademarks of International Business Machines Corporation in the United States, other countries, or both:

- developerWorks
- ECKD
- IBM
- S/390
- System z
- TotalStorage
- zSeries
- z/VM
- z9

Linux is a trademark of Linus Torvalds in the United States, other countries, or both.

Other company, product, and service names may be trademarks or service marks of others.

Readers' Comments — We'd Like to Hear from You

Linux on System z
Using the Dump Tools
February, 2007
Linux Kernel 2.6 (April 2004 stream)

Publication No. SC33-8286-01

We appreciate your comments about this publication. Please comment on specific errors or omissions, accuracy, organization, subject matter, or completeness of this book. The comments you send should pertain to only the information in this manual or product and the way in which the information is presented.

For technical questions and information about products and prices, please contact your IBM branch office, your IBM business partner, or your authorized remarketer.

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute your comments in any way it believes appropriate without incurring any obligation to you. IBM or any other organizations will only use the personal information that you supply to contact you about the issues that you state on this form.

Comments:

Thank you for your support.

Submit your comments using one of these channels:

- Send your comments to the address on the reverse side of this form.
- Send your comments via e-mail to: eservdoc@de.ibm.com

If you would like a response from IBM, please fill in the following information:

Name

Address

Company or Organization

Phone No.

E-mail address



Cut or Fold
Along Line

Fold and Tape

Please do not staple

Fold and Tape

PLACE
POSTAGE
STAMP
HERE

IBM Deutschland Entwicklung GmbH
Information Development
Department 3248
Schoenaicher Strasse 220
71032 Boeblingen
Germany

Fold and Tape

Please do not staple

Fold and Tape

Cut or Fold
Along Line



SC33-8286-01

