

IBM BladeCenter 1/10Gb Uplink Ethernet Switch Module



# Application Guide



IBM BladeCenter 1/10Gb Uplink Ethernet Switch Module



# Application Guide

**Note:** Before using this information and the product it supports, read the general information in the *Safety information and Environmental Notices and User Guide* documents on the IBM *Documentation* CD and the *Warranty Information* document that comes with the product.

**First Edition (September 2012)**

**© Copyright IBM Corporation 2012**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

---

# Contents

<b>Preface</b> . . . . .	<b>17</b>
Who Should Use This Guide . . . . .	17
What You'll Find in This Guide . . . . .	17
Additional References. . . . .	19
Typographic Conventions . . . . .	20
How to Get Help . . . . .	21
 <b>Part 1:. Getting Started.</b> . . . . .	 <b>23</b>
 <b>Chapter 1. Switch Administration</b> . . . . .	 <b>25</b>
Administration Interfaces . . . . .	26
Management Module . . . . .	26
Command Line Interface . . . . .	27
Browser-Based Interface . . . . .	27
Establishing a Connection . . . . .	28
Using the BladeCenter Management Module . . . . .	28
Factory-Default vs. MM-Assigned IP Addresses . . . . .	28
Default Gateway . . . . .	29
Configuring the Management Module for Switch Access . . . . .	29
Using an External Switch Port . . . . .	30
Using Telnet. . . . .	31
Using Secure Shell . . . . .	31
Using a Web Browser . . . . .	32
Configuring HTTP Access to the BBI. . . . .	33
Configuring HTTPS Access to the BBI . . . . .	33
Browser-Based Interface Summary . . . . .	34
Using Simple Network Management Protocol . . . . .	37
BOOTP/DHCP Client IP Address Services. . . . .	38
Global BOOTP Relay Agent Configuration . . . . .	39
Domain-Specific BOOTP Relay Agent Configuration . . . . .	39
DHCP Option 82 . . . . .	40
DHCP Snooping . . . . .	40
Switch Login Levels . . . . .	41
Setup vs. the Command Line . . . . .	42
 <b>Chapter 2. Initial Setup.</b> . . . . .	 <b>43</b>
Information Needed for Setup. . . . .	44
Default Setup Options. . . . .	45
Stopping and Restarting Setup Manually . . . . .	45
Setup Part 1: Basic System Configuration . . . . .	46
Setup Part 2: Port Configuration. . . . .	48
Setup Part 3: VLANs . . . . .	50
Setup Part 4: IP Configuration . . . . .	51
IP Interfaces . . . . .	51
Loopback Interfaces. . . . .	52
Using Loopback Interfaces for Source IP Addresses . . . . .	52
Loopback Interface Limitation . . . . .	53
Default Gateways. . . . .	53
IP Routing. . . . .	54
Setup Part 5: Final Steps . . . . .	55
Optional Setup for Telnet Support . . . . .	56

<b>Part 2:. Securing the Switch</b>	<b>57</b>
<b>Chapter 3. Securing Administration</b>	<b>59</b>
Changing the Switch Passwords	60
Changing the Default Administrator Password	60
Changing the Default User Password	62
Secure Shell and Secure Copy	64
Configuring SSH/SCP Features on the Switch	64
Configuring the SCP Administrator Password	65
Using SSH and SCP Client Commands	65
SSH and SCP Encryption of Management Messages	67
Generating RSA Host Key for SSH Access	68
SSH/SCP Integration with RADIUS Authentication	68
SSH/SCP Integration with TACACS+ Authentication	68
SecurID Support	68
End User Access Control	70
Considerations for Configuring End User Accounts	70
Strong Passwords	70
User Access Control Menu	71
Listing Current Users	72
Logging In to an End User Account	72
Protected Mode	72
<b>Chapter 4. Authentication &amp; Authorization Protocols</b>	<b>73</b>
RADIUS Authentication and Authorization	74
How RADIUS Authentication Works	74
Configuring RADIUS on the Switch	74
RADIUS Authentication Features in IBM N/OS	75
Switch User Accounts	76
RADIUS Attributes for IBM N/OS User Privileges	76
TACACS+ Authentication	77
How TACACS+ Authentication Works	77
TACACS+ Authentication Features in IBM N/OS	78
Authorization	78
Accounting	79
Command Authorization and Logging	79
TACACS+ Password Change	80
Configuring TACACS+ Authentication on the Switch	81
LDAP Authentication and Authorization	83
<b>Chapter 5. 802.1X Port-Based Network Access Control</b>	<b>85</b>
Extensible Authentication Protocol over LAN	86
EAPoL Authentication Process	87
EAPoL Message Exchange	88
EAPoL Port States	89
Guest VLAN	89
Supported RADIUS Attributes	90
EAPoL Configuration Guidelines	92

<b>Chapter 6. Access Control Lists . . . . .</b>	<b>93</b>
Summary of Packet Classifiers . . . . .	94
Summary of ACL Actions . . . . .	96
Assigning Individual ACLs to a Port . . . . .	96
ACL Order of Precedence . . . . .	97
ACL Groups . . . . .	98
Assigning ACL Groups to a Port. . . . .	98
ACL Metering and Re-Marking . . . . .	99
ACL Port Mirroring . . . . .	100
Viewing ACL Statistics . . . . .	100
ACL Configuration Examples . . . . .	101
VLAN Maps. . . . .	104
 <b>Part 3:. Switch Basics . . . . .</b>	 <b>105</b>
 <b>Chapter 7. VLANs . . . . .</b>	 <b>107</b>
VLANs Overview. . . . .	108
VLANs and Port VLAN ID Numbers . . . . .	109
VLAN Tagging . . . . .	111
VLAN Topologies and Design Considerations . . . . .	115
Protocol-Based VLANs . . . . .	118
Port-Based vs. Protocol-Based VLANs . . . . .	119
PVLAN Priority Levels . . . . .	119
PVLAN Tagging . . . . .	119
PVLAN Configuration Guidelines. . . . .	120
Configuring PVLAN . . . . .	120
Private VLANs . . . . .	122
Private VLAN Ports . . . . .	122
Configuration Guidelines . . . . .	123
Configuration Example. . . . .	123
 <b>Chapter 8. Ports and Trunking . . . . .</b>	 <b>125</b>
Trunking Overview . . . . .	126
Static Trunks . . . . .	127
Static Trunk Requirements . . . . .	127
Inter-Switch Link . . . . .	127
Static Trunk Group Configuration Rules . . . . .	129
Configuring a Static Port Trunk . . . . .	130
Link Aggregation Control Protocol . . . . .	132
LACP Overview . . . . .	132
LACP Minimum Links Option . . . . .	133
Configuring LACP. . . . .	134
Configurable Trunk Hash Algorithm . . . . .	135

<b>Chapter 9. Spanning Tree Protocols</b>	<b>137</b>
Spanning Tree Protocol Modes	138
Global STP Control	138
PVSRT Mode	139
Port States	139
Bridge Protocol Data Units	140
Bridge Protocol Data Units Overview	140
Determining the Path for Forwarding BPDUs	140
Simple STP Configuration	142
Per-VLAN Spanning Tree Groups	144
Using Multiple STGs to Eliminate False Loops	144
VLAN and STG Assignment	144
Manually Assigning STGs	145
Guidelines for Creating VLANs	146
Rules for VLAN Tagged Ports	146
Adding and Removing Ports from STGs	146
Switch-Centric Configuration	147
Configuring Multiple STGs	148
Rapid Spanning Tree Protocol	150
Port States	150
RSTP Configuration Guidelines	150
RSTP Configuration Example	151
Multiple Spanning Tree Protocol	152
MSTP Region	152
Common Internal Spanning Tree	152
MSTP Configuration Guidelines	153
MSTP Configuration Examples	153
Port Type and Link Type	156
Edge Port	156
Link Type	156
<b>Chapter 10. Quality of Service</b>	<b>157</b>
QoS Overview	158
Using ACL Filters	159
Summary of ACL Actions	159
ACL Metering and Re-Marking	159
Using DSCP Values to Provide QoS	161
Differentiated Services Concepts	161
Trusted/Untrusted Ports	161
Per-Hop Behavior	162
QoS Levels	163
DSCP Re-Marking and Mapping	163
DSCP Re-Marking Overview	163
DSCP Re-Marking Configuration Examples	164
Using 802.1p Priorities to Provide QoS	166
Queuing and Scheduling	167
Control Plane Protection	167



<b>Part 4:. Advanced Switching Features . . . . .</b>	<b>.169</b>
<b>Chapter 11. Stacking . . . . .</b>	<b>.171</b>
Stacking Overview . . . . .	.172
Stacking Requirements . . . . .	.172
Stacking Limitations . . . . .	.173
Stack Membership . . . . .	.174
The Master Switch . . . . .	.174
Splitting and Merging One Stack . . . . .	.174
Merging Independent Stacks . . . . .	.175
Backup Switch Selection . . . . .	.175
Master Failover . . . . .	.176
Secondary Backup . . . . .	.176
Master Recovery . . . . .	.176
No Backup . . . . .	.176
Stack Member Identification . . . . .	.176
Configuring a Stack . . . . .	.177
Configuration Overview . . . . .	.177
Best Configuration Practices . . . . .	.177
Configuring Each Switch in a Stack . . . . .	.178
Additional Master Configuration . . . . .	.179
Configuring an External IPv4 Address for the Stack . . . . .	.179
Locating an External Stack Interface . . . . .	.180
Viewing Stack Connections . . . . .	.180
Binding Members to the Stack . . . . .	.181
Assigning a Stack Backup Switch . . . . .	.181
Managing a Stack . . . . .	.182
Upgrading Software in an Existing Stack . . . . .	.184
Replacing or Removing Stacked Switches . . . . .	.186
Removing a Switch from the Stack . . . . .	.186
Installing the New Switch or Healing the Topology . . . . .	.186
Binding the New Switch to the Stack . . . . .	.188
ISCLI Stacking Commands . . . . .	.189
<b>Chapter 12. Virtualization. . . . .</b>	<b>.191</b>
<b>Chapter 13. VMready . . . . .</b>	<b>.193</b>
VE Capacity . . . . .	.194
VM Group Types. . . . .	.194
Local VM Groups . . . . .	.195
Distributed VM Groups . . . . .	.197
VM Profiles . . . . .	.197
Initializing a Distributed VM Group . . . . .	.198
Assigning Members . . . . .	.198
Synchronizing the Configuration . . . . .	.198
Removing Member VEs . . . . .	.199
Virtual Distributed Switch . . . . .	.199
Prerequisites . . . . .	.199
Guidelines . . . . .	.200
Migrating to vDS . . . . .	.200

Virtualization Management Servers . . . . .	201
Assigning a vCenter . . . . .	201
vCenter Scans . . . . .	201
Deleting the vCenter . . . . .	202
Exporting Profiles . . . . .	203
VMware Operational Commands . . . . .	203
Pre-Provisioning VEs . . . . .	204
VLAN Maps . . . . .	205
VM Policy Bandwidth Control. . . . .	206
VM Policy Bandwidth Control Commands . . . . .	206
Bandwidth Policies vs. Bandwidth Shaping. . . . .	206
VMready Information Displays . . . . .	207
VMready Configuration Example . . . . .	211
<b>Part 5:. IP Routing . . . . .</b>	<b>213</b>
<b>Chapter 14. Basic IP Routing . . . . .</b>	<b>215</b>
IP Routing Benefits . . . . .	216
Routing Between IP Subnets. . . . .	216
Subnet Routing Example. . . . .	218
Using VLANs to Segregate Broadcast Domains . . . . .	219
BOOTP Relay Agent . . . . .	221
Dynamic Host Configuration Protocol . . . . .	222
DHCP Relay Agent . . . . .	222
DHCP Relay Agent Configuration . . . . .	223
<b>Chapter 15. Internet Protocol Version 6 . . . . .</b>	<b>225</b>
IPv6 Limitations . . . . .	226
IPv6 Address Format . . . . .	227
IPv6 Address Types . . . . .	228
IPv6 Address Autoconfiguration. . . . .	229
IPv6 Interfaces . . . . .	229
Neighbor Discovery . . . . .	230
Supported Applications . . . . .	232
Configuration Guidelines . . . . .	234
IPv6 Configuration Examples. . . . .	235
<b>Chapter 16. Using IPsec with IPv6 . . . . .</b>	<b>237</b>
IPsec Protocols . . . . .	238
Using IPsec with the GbESM. . . . .	239
Setting up Authentication . . . . .	240
Creating an IKEv2 Proposal . . . . .	240
Importing an IKEv2 Digital Certificate . . . . .	241
Generating an IKEv2 Digital Certificate . . . . .	241
Enabling IKEv2 Preshared Key Authentication. . . . .	242
Setting Up a Key Policy . . . . .	242
Using a Manual Key Policy . . . . .	244
Using a Dynamic Key Policy . . . . .	246

<b>Chapter 17. Routing Information Protocol . . . . .</b>	<b>.247</b>
Distance Vector Protocol . . . . .	.248
Stability . . . . .	.248
Routing Updates . . . . .	.249
RIPv1 . . . . .	.249
RIPv2 . . . . .	.249
RIPv2 in RIPv1 Compatibility Mode . . . . .	.250
RIP Features . . . . .	.250
RIP Configuration Example . . . . .	.252
 <b>Chapter 18. Internet Group Management Protocol . . . . .</b>	 <b>.253</b>
IGMP Terms . . . . .	.254
How IGMP Works . . . . .	.255
GbESM Capacity and IGMP Default Values . . . . .	.256
IGMP Snooping . . . . .	.257
IGMP Groups . . . . .	.257
IGMPv3 . . . . .	.257
IGMP Snooping Configuration Guidelines . . . . .	.258
IGMP Snooping Configuration Example . . . . .	.258
Advanced Configuration Example: IGMP Snooping. . . . .	.260
Prerequisites . . . . .	.261
Configuration . . . . .	.261
Switch B Configuration . . . . .	.262
Switch C Configuration . . . . .	.264
Troubleshooting . . . . .	.266
IGMP Relay . . . . .	.269
Configuration Guidelines . . . . .	.269
Configure IGMP Relay . . . . .	.270
Advanced Configuration Example: IGMP Relay . . . . .	.271
Prerequisites . . . . .	.272
Configuration . . . . .	.272
Troubleshooting . . . . .	.277
Additional IGMP Features . . . . .	.279
FastLeave. . . . .	.279
IGMP Filtering . . . . .	.279
Static Multicast Router . . . . .	.281
 <b>Chapter 19. Multicast Listener Discovery . . . . .</b>	 <b>.283</b>
MLD Terms . . . . .	.284
How MLD Works. . . . .	.285
MLD Querier. . . . .	.287
Dynamic M routers . . . . .	.287
MLD Capacity and Default Values . . . . .	.288
Configuring MLD. . . . .	.289
 <b>Chapter 20. Border Gateway Protocol . . . . .</b>	 <b>.291</b>
Internal Routing Versus External Routing . . . . .	.292
Forming BGP Peer Routers . . . . .	.293
Loopback Interfaces . . . . .	.293
What is a Route Map? . . . . .	.294
Incoming and Outgoing Route Maps . . . . .	.295
Precedence . . . . .	.295
Configuration Overview . . . . .	.295

Aggregating Routes . . . . .	298
Redistributing Routes. . . . .	298
BGP Attributes . . . . .	299
Selecting Route Paths in BGP . . . . .	300
BGP Failover Configuration . . . . .	301
Default Redistribution and Route Aggregation Example . . . . .	303
<b>Chapter 21. OSPF. . . . .</b>	<b>305</b>
OSPFv2 Overview . . . . .	306
Types of OSPF Areas . . . . .	306
Types of OSPF Routing Devices. . . . .	307
Neighbors and Adjacencies. . . . .	308
The Link-State Database. . . . .	308
The Shortest Path First Tree . . . . .	309
Internal Versus External Routing. . . . .	309
OSPFv2 Implementation in IBM N/OS . . . . .	310
Configurable Parameters . . . . .	310
Defining Areas. . . . .	311
Assigning the Area Index . . . . .	311
Using the Area ID to Assign the OSPF Area Number . . . . .	312
Attaching an Area to a Network . . . . .	312
Interface Cost . . . . .	313
Electing the Designated Router and Backup . . . . .	313
Summarizing Routes . . . . .	313
Default Routes. . . . .	314
Virtual Links. . . . .	315
Router ID. . . . .	315
Authentication . . . . .	316
Configuring Plain Text OSPF Passwords . . . . .	316
Configuring MD5 Authentication . . . . .	317
Host Routes for Load Balancing . . . . .	317
Loopback Interfaces in OSPF . . . . .	318
OSPF Features Not Supported in This Release . . . . .	318
OSPFv2 Configuration Examples . . . . .	319
Example 1: Simple OSPF Domain . . . . .	320
Example 2: Virtual Links . . . . .	322
Example 3: Summarizing Routes . . . . .	325
Verifying OSPF Configuration . . . . .	327
OSPFv3 Implementation in IBM N/OS . . . . .	328
OSPFv3 Differences from OSPFv2. . . . .	328
OSPFv3 Requires IPv6 Interfaces . . . . .	328
OSPFv3 Uses Independent Command Paths . . . . .	328
OSPFv3 Identifies Neighbors by Router ID . . . . .	329
Other Internal Improvements . . . . .	329
OSPFv3 Limitations. . . . .	329
OSPFv3 Configuration Example . . . . .	329

<b>Part 6:. High Availability Fundamentals . . . . .</b>	<b>.333</b>
<b>Chapter 22. Basic Redundancy . . . . .</b>	<b>.335</b>
Trunking for Link Redundancy . . . . .	.336
Hot Links . . . . .	.337
Forward Delay . . . . .	.337
Preemption . . . . .	.337
FDB Update . . . . .	.337
Configuration Guidelines . . . . .	.338
Configuring Hot Links . . . . .	.338
Active MultiPath Protocol . . . . .	.339
Health Checks . . . . .	.340
FDB Flush . . . . .	.340
Configuration Guidelines . . . . .	.340
Configuration Example . . . . .	.341
Stacking for High Availability Topologies . . . . .	.342
<b>Chapter 23. Layer 2 Failover . . . . .</b>	<b>.343</b>
Auto Monitoring Trunk Links . . . . .	.344
VLAN Monitor . . . . .	.344
Auto Monitor Configurations . . . . .	.344
Setting the Failover Limit . . . . .	.346
Manually Monitoring Port Links . . . . .	.346
L2 Failover with Other Features . . . . .	.347
LACP . . . . .	.347
Spanning Tree Protocol . . . . .	.347
Configuration Guidelines . . . . .	.348
Auto Monitor Guidelines . . . . .	.348
Manual Monitor Guidelines . . . . .	.348
Configuring Layer 2 Failover . . . . .	.349
Auto Monitor Example . . . . .	.349
Manual Monitor Example . . . . .	.349
<b>Chapter 24. Virtual Router Redundancy Protocol . . . . .</b>	<b>.351</b>
VRRP Overview . . . . .	.352
VRRP Components . . . . .	.352
VRRP Operation . . . . .	.353
Selecting the Master VRRP Router . . . . .	.354
Failover Methods . . . . .	.355
Active-Active Redundancy . . . . .	.356
Hot-Standby Redundancy . . . . .	.356
Virtual Router Group . . . . .	.357
IBM N/OS Extensions to VRRP . . . . .	.358
Virtual Router Deployment Considerations . . . . .	.359
High Availability Configurations . . . . .	.360
Active-Active Configuration . . . . .	.360
Hot-Standby Configuration . . . . .	.365

<b>Part 7:. Network Management.</b>	<b>369</b>
<b>Chapter 25. Link Layer Discovery Protocol</b>	<b>371</b>
LLDP Overview	372
Enabling or Disabling LLDP	373
Global LLDP Setting	373
Transmit and Receive Control.	373
LLDP Transmit Features	374
Scheduled Interval	374
Minimum Interval.	374
Time-to-Live for Transmitted Information	374
Trap Notifications	375
Changing the LLDP Transmit State.	376
Types of Information Transmitted	376
LLDP Receive Features.	378
Types of Information Received	378
Viewing Remote Device Information	378
Time-to-Live for Received Information	381
LLDP Example Configuration.	382
<b>Chapter 26. Simple Network Management Protocol.</b>	<b>383</b>
SNMP Version 1	384
SNMP Version 3	385
Configuring SNMP Trap Hosts	389
SNMP MIBs	392
Switch Images and Configuration Files	395
Loading a New Switch Image	396
Loading a Saved Switch Configuration	396
Saving the Switch Configuration	397
Saving a Switch Dump	397
<b>Part 8:. Monitoring</b>	<b>399</b>
<b>Chapter 27. Remote Monitoring</b>	<b>401</b>
RMON Overview	402
RMON Group 1—Statistics	403
RMON Group 2—History	404
History MIB Objects.	404
Configuring RMON History	404
RMON Group 3—Alarms	406
Alarm MIB Objects	406
Configuring RMON Alarms	407
RMON Group 9—Events	408
<b>Chapter 28. sFLOW</b>	<b>409</b>
sFlow Statistical Counters	410
sFlow Network Sampling	410
sFlow Example Configuration	411
<b>Chapter 29. Port Mirroring</b>	<b>413</b>
Port Mirroring Behavior	414

<b>Part 9:. Appendices</b>	<b>.415</b>
<b>Appendix A. Glossary</b>	<b>.417</b>
<b>Appendix B. RADIUS Server Configuration Notes</b>	<b>.419</b>
<b>Appendix C. Getting help and technical assistance</b>	<b>.421</b>
Before you call	.421
Using the documentation	.421
Getting help and information on the World Wide Web	.422
Software service and support	.422
Hardware service and support	.422
IBM Taiwan product service	.422
<b>Appendix D. Notices</b>	<b>.423</b>
Trademarks	.423
Important Notes	.424
Particulate contamination	.425
Documentation format	.426
Electronic emission notices	.426
Federal Communications Commission (FCC) statement	.426
Industry Canada Class A emission compliance statement	.426
Avis de conformité à la réglementation d'Industrie Canada	.426
Australia and New Zealand Class A statement	.426
European Union EMC Directive conformance statement	.427
Germany Class A statement	.427
Japan VCCI Class A statement	.428
Korea Communications Commission (KCC) statement	.428
Russia Electromagnetic Interference (EMI) Class A statement	.428
People's Republic of China Class A electronic emission statement	.429
Taiwan Class A compliance statement	.429
<b>Index</b>	<b>.431</b>





---

## Preface

The *IBM N/OS 7.4 Application Guide* describes how to configure and use the IBM Networking OS 7.4 software on the 1/10Gb Uplink Ethernet Switch Module for IBM BladeCenter (referred to as GbESM throughout this document). For documentation on installing the switch physically, see the *Installation Guide* for your GbESM.

---

## Who Should Use This Guide

This guide is intended for network installers and system administrators engaged in configuring and maintaining a network. The administrator should be familiar with Ethernet concepts, IP addressing, Spanning Tree Protocol, and SNMP configuration parameters.

---

## What You'll Find in This Guide

This guide will help you plan, implement, and administer IBM N/OS software. Where possible, each section provides feature overviews, usage examples, and configuration instructions. The following material is included:

### Part 1: Getting Started

This material is intended to help those new to N/OS products with the basics of switch management. This part includes the following chapters:

- [Chapter 1, "Switch Administration,"](#) describes how to access the GbESM in order to configure the switch and view switch information and statistics. This chapter discusses a variety of manual administration interfaces, including local management via the switch console, and remote administration via Telnet, a web browser, or via SNMP.
- [Chapter 2, "Initial Setup,"](#) describes how to use the built-in Setup utility to perform first-time configuration of the switch.

### Part 2: Securing the Switch

- [Chapter 3, "Securing Administration,"](#) describes methods for changing the default switch passwords, using Secure Shell and Secure Copy for administration connections, configuring end-user access control, and placing the switch in protected mode.
- [Chapter 4, "Authentication & Authorization Protocols,"](#) describes different secure administration for remote administrators. This includes using Remote Authentication Dial-in User Service (RADIUS), as well as TACACS+ and LDAP.
- [Chapter 5, "802.1X Port-Based Network Access Control,"](#) describes how to authenticate devices attached to a LAN port that has point-to-point connection characteristics. This feature prevents access to ports that fail authentication and authorization and provides security to ports of the GbESM that connect to blade servers.
- [Chapter 6, "Access Control Lists,"](#) describes how to use filters to permit or deny specific types of traffic, based on a variety of source, destination, and packet attributes.

### Part 3: Switch Basics

- [Chapter 7, “VLANs,”](#) describes how to configure Virtual Local Area Networks (VLANs) for creating separate network segments, including how to use VLAN tagging for devices that use multiple VLANs. This chapter also describes Protocol-based VLANs, and Private VLANs.
- [Chapter 8, “Ports and Trunking,”](#) describes how to group multiple physical ports together to aggregate the bandwidth between large-scale network devices.
- [Chapter 9, “Spanning Tree Protocols,”](#) discusses how Spanning Tree Protocol (STP) configures the network so that the switch selects the most efficient path when multiple paths exist. Covers Rapid Spanning Tree Protocol (RSTP), Per-VLAN Rapid Spanning Tree (PVRST), and Multiple Spanning Tree Protocol (MSTP).
- [Chapter 10, “Quality of Service,”](#) discusses Quality of Service (QoS) features, including IP filtering using Access Control Lists (ACLs), Differentiated Services, and IEEE 802.1p priority values.

### Part 4: Advanced Switching Features

- [Chapter 11, “Stacking,”](#) describes how to combine multiple switches into a single, aggregate switch entity.
- [Chapter 12, “Virtualization,”](#) provides an overview of allocating resources based on the logical needs of the data center, rather than on the strict, physical nature of components.
- [Chapter 13, “VMready,”](#) discusses virtual machine (VM) support on the GbESM.

### Part 5: IP Routing

- [Chapter 14, “Basic IP Routing,”](#) describes how to configure the GbESM for IP routing using IP subnets, BOOTP, and DHCP Relay.
- [Chapter 15, “Internet Protocol Version 6,”](#) describes how to configure the GbESM for IPv6 host management.
- [Chapter 16, “Using IPsec with IPv6,”](#) describes how to configure Internet Protocol Security (IPsec) for securing IP communications by authenticating and encrypting IP packets, with emphasis on Internet Key Exchange version 2, and authentication/confidentiality for OSPFv3.
- [Chapter 17, “Routing Information Protocol,”](#) describes how the N/OS software implements standard Routing Information Protocol (RIP) for exchanging TCP/IP route information with other routers.
- [Chapter 18, “Internet Group Management Protocol,”](#) describes how the N/OS software implements IGMP Snooping or IGMP Relay to conserve bandwidth in a multicast-switching environment.
- [Chapter 19, “Multicast Listener Discovery,”](#) describes how Multicast Listener Discovery (MLD) is used with IPv6 to support host users requests for multicast data for a multicast group.
- [Chapter 20, “Border Gateway Protocol,”](#) describes Border Gateway Protocol (BGP) concepts and features supported in N/OS.
- [Chapter 21, “OSPF,”](#) describes key Open Shortest Path First (OSPF) concepts and their implemented in N/OS, and provides examples of how to configure your switch for OSPF support.

## Part 6: High Availability Fundamentals

- [Chapter 22, “Basic Redundancy,”](#) describes how the GbESM supports redundancy through stacking, trunking, Active Multipass Protocol (AMP), and hotlinks.
- [Chapter 23, “Layer 2 Failover,”](#) describes how the GbESM supports high-availability network topologies using Layer 2 Failover.
- [Chapter 24, “Virtual Router Redundancy Protocol,”](#) describes how the GbESM supports high-availability network topologies using Virtual Router Redundancy Protocol (VRRP).

## Part 7: Network Management

- [Chapter 25, “Link Layer Discovery Protocol,”](#) describes how Link Layer Discovery Protocol helps neighboring network devices learn about each others’ ports and capabilities.
- [Chapter 26, “Simple Network Management Protocol,”](#) describes how to configure the switch for management through an SNMP client.

## Part 8: Monitoring

- [Chapter 27, “Remote Monitoring,”](#) describes how to configure the RMON agent on the switch, so that the switch can exchange network monitoring data.
- [Chapter 28, “sFLOW,”](#) described how to use the embedded sFlow agent for sampling network traffic and providing continuous monitoring information to a central sFlow analyzer.
- [Chapter 29, “Port Mirroring,”](#) discusses tools how copy selected port traffic to a monitor port for network analysis.

## Part 9: Appendices

- [Appendix A, “Glossary,”](#) describes common terms and concepts used throughout this guide.
- [Appendix B, “RADIUS Server Configuration Notes,”](#) discusses how to modify RADIUS configuration files for the Nortel Networks BaySecure Access Control RADIUS server, to provide authentication for users of the GbESM.

---

## Additional References

Additional information about installing and configuring the GbESM is available in the following guides:

- *1/10Gb Uplink Ethernet Switch Module Installation Guide*
- *IBM Networking OS 7.4 Command Reference*
- *IBM Networking OS 7.4 ISCLI Reference Guide*
- *IBM Networking OS 7.4 BBI Quick Guide*

---

## Typographic Conventions

The following table describes the typographic styles used in this book.

Table 1. *Typographic Conventions*

Typeface or Symbol	Meaning	Example
ABC123	This type is used for names of commands, files, and directories used within the text.  It also depicts on-screen computer output and prompts.	View the <code>readme.txt</code> file.  Main#
<b>ABC123</b>	This bold type appears in command examples. It shows text that must be typed in exactly as shown.	Main# <b>sys</b>
<ABC123>	This italicized type appears in command examples as a parameter placeholder. Replace the indicated text with the appropriate real name or value when using the command. Do not type the brackets.  This also shows book titles, special terms, or words to be emphasized.	To establish a Telnet session, enter: host# <b>telnet</b> <IP address>  Read your <i>User's Guide</i> thoroughly.
[ ]	Command items shown inside brackets are optional and can be used or excluded as the situation demands. Do not type the brackets.	host# <b>ls</b> [-a]
	The vertical bar (   ) is used in command examples to separate choices where multiple options exist. Select only one of the listed options. Do not type the vertical bar.	host# <b>set</b> left right
<b>AaBbCc123</b>	This block type depicts menus, buttons, and other controls that appear in Web browsers and other graphical interfaces.	Click the <b>Save</b> button.

---

## How to Get Help

If you need help, service, or technical assistance, visit our web site at the following address:

<http://www.ibm.com/support>

The warranty card received with your product provides details for contacting a customer support representative. If you are unable to locate this information, please contact your reseller. Before you call, prepare the following information:

- Serial number of the switch unit
- Software release version number
- Brief description of the problem and the steps you have already taken
- Technical support dump information (>> Main# /maint/tsdmp)



# **Part 1: Getting Started**





---

## Chapter 1. Switch Administration

Your 1/10Gb Uplink ESM (GbESM) is ready to perform basic switching functions right out of the box. Some of the more advanced features, however, require some administrative configuration before they can be used effectively.

The extensive IBM Networking OS switching software included in the GbESM provides a variety of options for accessing the switch to perform configuration, and to view switch information and statistics.

This chapter discusses the various methods that can be used to administer the switch.

---

## Administration Interfaces

IBM N/OS provides a variety of user-interfaces for administration. These interfaces vary in character and in the methods used to access them: some are text-based, and some are graphical; some are available by default, and some require configuration; some can be accessed by local connection to the switch, and others are accessed remotely using various client applications. For example, administration can be performed using any of the following:

- The BladeCenter management module tools for general chassis management
- A built-in, text-based command-line interface and menu system for access via serial-port connection or an optional Telnet or SSH session
- The built-in Browser-Based Interface (BBI) available using a standard web-browser
- SNMP support for access through network management software such as IBM Director or HP OpenView

The specific interface chosen for an administrative session depends on user preferences, as well as the switch configuration and the available client tools.

In all cases, administration requires that the switch hardware is properly installed and turned on. (see the *1/10Gb Uplink Ethernet Switch Module Installation Guide*).

## Management Module

The GbESM is an integral subsystem within the overall BladeCenter system. The BladeCenter chassis also includes a management module as the central element for overall chassis management and control. Using the tools available through the management module, the administrator can configure many of the GbESM features and can also access other GbESM administration interfaces.

For details, see [“Using the BladeCenter Management Module” on page 28](#).

## Command Line Interface

The N/OS Command Line Interface (CLI) provides a simple, direct method for switch administration. Using a basic terminal, you are presented with an organized hierarchy of menus, each with logically-related sub-menus and commands. These allow you to view detailed information and statistics about the switch, and to perform any necessary configuration and switch software maintenance. For example:

```
[Main Menu]
  info    - Information Menu
  stats   - Statistics Menu
  cfg     - Configuration Menu
  oper    - Operations Command Menu
  boot    - Boot Options Menu
  maint   - Maintenance Menu
  diff    - Show pending config changes [global command]
  apply   - Apply pending config changes [global command]
  save    - Save updated config to FLASH [global command]
  revert  - Revert pending or applied changes [global command]
  exit    - Exit [global command, always available]
>> #
```

You can establish a connection to the CLI in any of the following ways:

- Serial connection via the serial port on the GbESM (this option is always available)
- Telnet connection from the chassis management module or over the network
- SSH connection from the chassis management module or over the network

## Browser-Based Interface

The Browser-based Interface (BBI) provides access to the common configuration, management and operation features of the GbESM through your Web browser.

For more information, refer to the *BBI Quick Guide*.

---

## Establishing a Connection

The factory default settings permit initial switch administration through *only* the BladeCenter management module or the built-in serial port. All other forms of access require additional switch configuration before they can be used.

Remote access using the network requires the accessing terminal to have a valid, routable connection to the switch interface. The client IP address may be configured manually, or an IPv4 address can be provided automatically through the switch using a service such as DHCP or BOOTP relay (see [“BOOTP/DHCP Client IP Address Services” on page 38](#)), or an IPv6 address can be obtained using IPv6 stateless address configuration.

**Note:** Throughout this manual, *IP address* is used in places where either an IPv4 or IPv6 address is allowed. IPv4 addresses are entered in dotted-decimal notation (for example, 10.10.10.1), while IPv6 addresses are entered in hexadecimal notation (for example, 2001:db8:85a3::8a2e:370:7334). In places where only one type of address is allowed, *IPv4 address* or *IPv6 address* is specified.

## Using the BladeCenter Management Module

The BladeCenter GbESM is an integral subsystem within the overall BladeCenter system. The BladeCenter chassis includes a management module as the central element for overall chassis management and control.

The GbESM uses internal port 15 (MGT1) and port 16 (MGT2) to communicate with the management module(s). Even when the GbESM is in a factory default configuration, you can use the 100 Mbps Ethernet port on each BladeCenter management module to configure and manage the GbESM.

**Note:** Support for each management module is provided by a separate management port (MGT1 and MGT2). One port is active, and the other is used as a backup.

## Factory-Default vs. MM-Assigned IP Addresses

Each GbESM must be assigned its own Internet Protocol version 4 (IPv4) address, which is used for communication with an SNMP network manager or other transmission control protocol/Internet Protocol (TCP/IP) applications (for example, BOOTP or TFTP). The factory-default IPv4 address is 10.90.90.*x*, where *x* is based on the number of the bay into which the GbESM is installed. For additional information, see the *Installation Guide*. The management module assigns an IPv4 address of 192.168.70.1*xx*, where *xx* is also based on the number of the bay into which each GbESM is installed, as shown in the following table:

Table 2. GbESM IPv4 addresses, by switch-module bay numbers

Bay Number	Factory-Default IPv4 Address	IPv4 Address Assigned by MM
Bay 1	10.90.90.91	192.168.70.127
Bay 2	10.90.90.92	192.168.70.128
Bay 3	10.90.90.94	192.168.70.129
Bay 4	10.90.90.97	192.168.70.130

**Note:** GbESMs installed in Bay 1 and Bay 2 connect to server NICs 1 and 2, respectively. However, Windows operating systems using older I/O expansion adapters show that GbESMs installed in Bay 3 and Bay 4 connect to server NICs 4 and 3, respectively.

## Default Gateway

The default Gateway IP address determines where packets with a destination address outside the current subnet should be sent. Usually, the default Gateway is a router or host acting as an IP gateway to handle connections to other subnets of other TCP/IP networks. If you want to access the GbESM from outside your local network, use the management module to assign a default Gateway address to the GbESM. For example:


1. Choose I/O Module Tasks > Configuration from the navigation pane on the left.
2. Enter the default Gateway IP address (for example, 192.168.70.125).
3. Click Save.

## Configuring the Management Module for Switch Access

Complete the following initial configuration steps:

1. Connect the Ethernet port of the management module to a 10/100 Mbps network (with access to a management station) or directly to a management station.
2. Access and log on to the management module, as described in the *BladeCenter Management Module User's Guide*. The management module provides the appropriate IPv4 addresses for network access (see the applicable *BladeCenter Installation and User's Guide* publications for more information).
3. Select Configuration on the I/O Module Tasks menu on the left side of the BladeCenter Management Module window. See [Figure 1](#).

Figure 1. Switch Management on the BladeCenter Management Module



**Note:** The screen shown is an example only. Actual screen output may differ, depending on the type, version, and configuration of hardware and software installed in your systems.

4. You can use the default IPv4 addresses provided by the management module, or you can assign a new IPv4 or IPv6 address to the switch module through the management module. You can assign this IP address through one of the following methods:

- Manually through the BladeCenter management module
- Automatically through the IBM Director Configuration Wizard

**Note:** If you change the IP address of the GbESM, make sure that the switch module and the management module both reside on the same subnet.

5. Enable the following features in the management module:
  - External Ports (I/O Module Tasks > Admin/Power/Restart > Advanced Setup)
  - External management over all ports (Configuration > Advanced Configuration)
  - This setting is required if you want to access the management network through the external data ports (EXT<sub>x</sub>) on the GbESM.

The default value is `Disabled` for both features. If these features are not already enabled, change the value to `Enabled`, then click `Save`.

**Note:** In `Advanced Configuration > Advanced Setup`, enable “Preserve new IP configuration on all switch resets,” to retain the switch’s IP interface when you restore factory defaults. This setting preserves the management port’s IP address in the management module’s memory, so you maintain connectivity to the management module after a reset.

You can now start a Telnet or Secure Shell session to the switch CLI or ISCLI, or start a Web or secure HTTPS session to the switch BBI.

**Note:** Depending on your network requirements, BOOTP or DHCP may be required to be configured on the switch in order for remote clients to function. See [“BOOTP Relay Agent” on page 221](#) and [“Dynamic Host Configuration Protocol” on page 222](#) for more information.

## Using an External Switch Port

You can also use the external Ethernet ports (EXT<sub>x</sub>) on the GbESM for management and control of the switch. This feature must be enabled through the management module configuration utility program (shown in [Step 5 on page 30](#)).

See the applicable *BladeCenter Installation and User’s Guide* publications for more information.

## Using Telnet

A Telnet connection offers the convenience of accessing the switch from a workstation connected to the network. Telnet access provides the same options for user and administrator access as those available through the management module or console port.

By default, Telnet access is enabled. Use the following commands (available on the console only) to disable or re-enable Telnet access:

```
>> # /cfg/sys/telnet ena|dis
```

To use the management module to access the GbESM through Telnet, choose I/O Module Tasks > Configuration from the navigation pane on the left. Then select a bay number and click Advanced Configuration > Start Telnet/Web Session > Start Telnet Session. A Telnet window opens a connection to the Switch Module (requires Java 1.4 Plug-in).

Once the switch is configured with an IP address and gateway, you can use Telnet to access switch administration from any workstation connected to the management network.

To establish a Telnet connection with the switch, run the Telnet program on your workstation and issue the following Telnet command:

```
telnet <switch IPv4 or IPv6 address>
```

You will then be prompted to enter a password as explained [“Switch Login Levels” on page 41](#).

## Using Secure Shell

Although a remote network administrator can manage the configuration of a GbESM via Telnet, this method does not provide a secure connection. The Secure Shell (SSH) protocol enables you to securely log into another device over a network to execute commands remotely. As a secure alternative to using Telnet to manage switch configuration, SSH ensures that all data sent over the network is encrypted and secure.

The switch can do only one session of key/cipher generation at a time. Thus, a SSH/SCP client will not be able to login if the switch is doing key generation at that time. Similarly, the system will fail to do the key generation if a SSH/SCP client is logging in at that time.

The supported SSH encryption and authentication methods are listed below.

- Server Host Authentication: Client RSA-authenticates the switch when starting each connection
- Key Exchange: RSA
- Encryption: 3DES-CBC, DES
- User Authentication: Local password authentication, RADIUS, TACACS+

IBM Networking OS implements the SSH version 2.0 standard and is confirmed to work with SSH version 2.0-compliant clients such as the following:

- OpenSSH\_5.4p1 for Linux
- Secure CRT Version 5.0.2 (build 1021)
- Putty SSH release 0.60

## Using SSH to Access the Switch

By default, the SSH feature is disabled. For information on enabling and using SSH for switch access, see [“Secure Shell and Secure Copy” on page 64](#).

Once the IP parameters are configured and the SSH service is enabled, you can access the command line interface using an SSH connection.

To establish an SSH connection with the switch, run the SSH program on your workstation by issuing the SSH command, followed by the switch IPv4 or IPv6 address:

```
# ssh <switch IP address>
```

If SecurID authentication is required, use the following command:

```
# ssh -l ace <switch IP address>
```

You will then be prompted to enter a password as explained [“Switch Login Levels” on page 41](#).

## Using a Web Browser

The switch provides a Browser-Based Interface (BBI) for accessing the common configuration, management and operation features of the GbESM through your Web browser.

By default, BBI access via HTTP is enabled on the switch.

To use the management module to access the GbESM through a Web session, choose I/O Module Tasks > Configuration from the navigation pane on the left of the management tool. Next, select a bay number and click Advanced Configuration > Start Telnet/Web Session > Start Web Session. A browser window opens a connection to the Switch Module.

You can access the BBI directly from an open Web browser window. Enter the URL using the IP address of the switch interface (for example, `http://<IPv4 or IPv6 address>`).



## Configuring HTTP Access to the BBI

By default, BBI access via HTTP is enabled on the switch.

To disable or re-enable HTTP access to the switch BBI, use the following commands:

```
>> # /cfg/sys/access/http ena           (Enable HTTP access)
      -or-
>> # /cfg/sys/access/http dis           (Disable HTTP access)
```

The default HTTP web server port to access the BBI is port 80 (required by the management module). However, you can change the default Web server port with the following command:

```
>> # /cfg/sys/access/wport <TCP port number>
```

To access the BBI from a workstation, open a Web browser window and type in the URL using the IP address of the switch interface (for example, `http://<IPv4 or IPv6 address>`).

## Configuring HTTPS Access to the BBI

The BBI can also be accessed via a secure HTTPS connection.

1. Enable HTTPS.

By default, BBI access via HTTPS is disabled on the switch. To enable BBI Access via HTTPS, use the following command:

```
>> # /cfg/sys/access/https/access ena
```

2. Set the HTTPS server port number (optional).

To change the HTTPS Web server port number from the default port 443, use the following command:

```
>> # /cfg/sys/access/https/port <x>
```

3. Use the `apply` and `save` commands to activate and store the configuration changes.

#### 4. Generate the HTTPS certificate.

Accessing the BBI via HTTPS requires that you generate a certificate to be used during the key exchange. A default certificate is created the first time HTTPS is enabled, but you can create a new certificate defining the information you want to be used in the various fields.

```
>> /cfg/sys/access/https/generate
Country Name (2 letter code) []: <country code>
State or Province Name (full name) []: <state>
Locality Name (eg, city) []: <city>
Organization Name (eg, company) []: <company>
Organizational Unit Name (eg, section) []: <org. unit>
Common Name (eg, YOUR name) []: <name>
Email (eg, email address) []: <email address>
Confirm generating certificate? [y/n]: y
Generating certificate. Please wait (approx 30 seconds)
restarting SSL agent
```

#### 5. Save the HTTPS certificate.

The certificate is valid only until the switch is rebooted. In order to save the certificate so that it is retained beyond reboot or power cycles, use the following command:

```
>> # /cfg/sys/access/https/certsave
```

When a client (e.g. web browser) connects to the switch, the client is asked to accept the certificate and verify that the fields match what is expected. Once BBI access is granted to the client, the BBI can be used as described in the *IBM Networking OS 7.4 BBI Quick Guide*.

## Browser-Based Interface Summary

The BBI is organized at a high level as follows:

**Context buttons**—These buttons allow you to select the type of action you wish to perform. The *Configuration* button provides access to the configuration elements for the entire switch. The *Statistics* button provides access to the switch statistics and state information. The *Dashboard* button allows you to display the settings and operating status of a variety of switch features.

**Navigation Window**—This window provides a menu list of switch features and functions:

- **System**—this folder provides access to the configuration elements for the entire switch.
  - General
  - User Table
  - Radius
  - TACACS+
  - LDAP
  - NTP
  - sFlow
  - Boot
  - Syslog/Trap Features
  - Config/Image Control
  - Management Network
  - Transceiver
  - Protected Mode
  - Chassis
- **Switch Ports**—Configure each of the physical ports on the switch.
- **Port-Based Port Mirroring**—Configure port mirroring behavior.
- **Layer 2**—Configure Layer 2 features for the switch.
  - 802.1X
  - FDB
  - Virtual LANs
  - Spanning Tree Groups
  - MSTP/RSTP
  - LLDP
  - Failover
  - Hot Links
  - Trunk Groups
  - Trunk Hash
  - LACP
  - Uplink Fast
  - BPDU Guard
  - PVST+ compatibility
  - MAC Address Notification
- **RMON Menu**—Configure Remote Monitoring features for the switch.

- **Layer 3**—Configure Layer 3 features for the switch.
  - IP Interfaces
  - IP Loopback Interfaces
  - Network Routes
  - Network IPv6 Routes
  - Static IPMC Routes
  - ARP
  - NBR
  - Network Filters
  - Route Maps
  - Border Gateway Protocol
  - Default Gateways
  - IPv6 Default Gateways
  - IGMP
  - OSPF Routing Protocol
  - Routing Information Protocol
  - Virtual Router Redundancy Protocol
  - Domain Name System
  - Bootstrap Protocol Relay
  - General
- **QoS**—Configure Quality of Service features for the switch.
  - 802.1p
  - DSCP
- **Access Control**—Configure Access Control Lists to filter IP packets.
  - Access Control Lists
  - VLAN Map
  - Access Control List Groups
- **Virtualization** – Configure VMready.

For information on using the BBI, refer to the *IBM Networking OS 7.4 BBI Quick Guide*.

## Using Simple Network Management Protocol

N/OS provides Simple Network Management Protocol (SNMP) version 1, version 2, and version 3 support for access through any network management software, such as IBM Director or HP-OpenView.

To access the SNMP agent on the GbESM, the read and write community strings on the SNMP manager should be configured to match those on the switch. The default read community string on the switch is `public` and the default write community string is `private`.

The read and write community strings on the switch can be changed using the following commands:

```
>> # /cfg/sys/ssnmp/rcomm <1-32 characters>  
  
-and-  
  
>> # /cfg/sys/ssnmp/wcomm <1-32 characters>
```

The SNMP manager should be able to reach any one of the IP interfaces on the switch.

For the SNMP manager to receive the SNMPv1 traps sent out by the SNMP agent on the switch, configure the trap host on the switch with the following commands:

```
>> # /cfg/sys/ssnmp/trsrc <trap source IP interface>  
>> SNMP# thostadd <IPv4 address> <trap host community string>
```

For more information on SNMP usage and configuration, see [“Simple Network Management Protocol” on page 383](#).

---

## BOOTP/DHCP Client IP Address Services

For remote switch administration, the client terminal device must have a valid IP address on the same network as a switch interface. The IP address on the client device may be configured manually, or obtained automatically using IPv6 stateless address configuration, or an IPv4 address may be obtained automatically via BOOTP or DHCP relay as discussed below.

The GbESM can function as a relay agent for Bootstrap Protocol (BOOTP) or DHCP. This allows clients to be assigned an IPv4 address for a finite lease period, reassigning freed addresses later to other clients.

Acting as a relay agent, the switch can forward a client's IPv4 address request to up to four BOOTP/DHCP servers. In addition to the four global BOOTP/DHCP servers, up to four domain-specific BOOTP/DHCP servers can be configured for each of up to 10 VLANs.

When a switch receives a BOOTP/DHCP request from a client seeking an IPv4 address, the switch acts as a proxy for the client. The request is forwarded as a UDP Unicast MAC layer message to the BOOTP/DHCP servers configured for the client's VLAN, or to the global BOOTP/DHCP servers if no domain-specific BOOTP/DHCP servers are configured for the client's VLAN. The servers respond to the switch with a Unicast reply that contains the IPv4 default gateway and the IPv4 address for the client. The switch then forwards this reply back to the client.

DHCP is described in RFC 2131, and the DHCP relay agent supported on the GbESM is described in RFC 1542. DHCP uses UDP as its transport protocol. The client sends messages to the server on port 67 and the server sends messages to the client on port 68.

BOOTP and DHCP relay are collectively configured using the BOOTP commands and menus on the GbESM.

## Global BOOTP Relay Agent Configuration

To enable the GbESM to be a BOOTP (or DHCP) forwarder, enable the BOOTP relay feature, configure up to four global BOOTP server IPv4 addresses on the switch, and enable BOOTP relay on the interface(s) on which the client requests are expected.

Generally, you should configure BOOTP for the switch IP interface that is closest to the client, so that the BOOTP server knows from which IPv4 subnet the newly allocated IPv4 address should come.

In the GbESM implementation, there are no primary or secondary BOOTP servers. The client request is forwarded to all the global BOOTP servers configured on the switch (if no domain-specific servers are configured). The use of multiple servers provide failover redundancy. However, no health checking is supported.

1. Use the following commands to configure global BOOTP relay servers:

```
>> # /cfg/13/bootp
>> Bootstrap Protocol Relay# on
>> Bootstrap Protocol Relay# server <1-4>
>> BOOTP Server# address <IPv4 address>
```

2. Enable BOOTP relay on the appropriate IP interfaces.

BOOTP/DHCP Relay functionality may be assigned on a per-interface basis using the following commands:

```
>> BOOTP Server# /cfg/13/if <interface number>
>> IP Interface# relay enable
```

## Domain-Specific BOOTP Relay Agent Configuration

Use the following commands to configure up to four domain-specific BOOTP relay agents for each of up to 10 VLANs:

```
>> # /cfg/13/bootp/bdomain <1-10>
>> Broadcast Domain# vlan <VLAN number>
>> Broadcast Domain# enable
>> Broadcast Domain# server <1-4>
>> BOOTP Server# address <IPv4 address>
```

As with global relay agent servers, domain-specific BOOTP/DHCP functionality may be assigned on a per-interface basis (see [Step 2](#) in [page 39](#)).

## DHCP Option 82

DHCP Option 82 provides a mechanism for generating IP addresses based on the client device's location in the network. When you enable the DHCP relay agent option on the switch, it inserts the relay agent information option 82 in the packet, and sends a unicast BOOTP request packet to the DHCP server. The DHCP server uses the option 82 field to assign an IP address, and sends the packet, with the original option 82 field included, back to the relay agent. DHCP relay agent strips off the option 82 field in the packet and sends the packet to the DHCP client.

Configuration of this feature is optional. The feature helps resolve several issues where untrusted hosts access the network. See RFC 3046 for details.

Given below are the commands to configure DHCP Option 82:

```
>> Main# cfg/13/bootp/option82/on
>> DHCP Relay Option 82 menu# ..
>> Bootstrap Protocol Relay# on
>> Bootstrap Protocol Relay# server <1-5>/address <IP address>
```

## DHCP Snooping

DHCP snooping provides security by filtering untrusted DHCP packets and by building and maintaining a DHCP snooping binding table. This feature is applicable only to IPv4 and only works in non-stacking mode.

An untrusted interface is a port that is configured to receive packets from outside the network or firewall. A trusted interface receives packets only from within the network. By default, all DHCP ports are untrusted.

The DHCP snooping binding table contains the MAC address, IP address, lease time, binding type, VLAN number, and port number that correspond to the local untrusted interface on the switch; it does not contain information regarding hosts interconnected with a trusted interface.

By default, DHCP snooping is disabled on all VLANs. You can enable DHCP snooping on one or more VLANs. You must enable DHCP snooping globally. To enable this feature, enter the commands below:

```
>> Main# cfg/13/dhcp/snooping/addvlan <vlan number(s)>
>> DHCP Snooping# on
```

Given below is an example of DHCP snooping configuration, where the DHCP server and client are in VLAN 100, and the server connects using port 1.

```
>> Main# cfg/13/dhcp/snooping/addvlan 100
>> DHCP Snooping# on
>> DHCP Snooping# option82 enable           (Optional; add DHCP option 82)
>> DHCP Snooping# /cfg/port INT1
>> Port INT1# trust                         (Optional; Set port as trusted)
>> Port INT1# dhrate 100                   (Optional; Set DHCP packet rate)
```



---

## Switch Login Levels

To enable better switch management and user accountability, three levels or *classes* of user access have been implemented on the GbESM. Levels of access to CLI, Web management functions, and screens increase as needed to perform various switch management tasks. Conceptually, access classes are defined as follows:

- User interaction with the switch is completely passive—nothing can be changed on the GbESM. Users may display information that has no security or privacy implications, such as switch statistics and current operational state information.
- Operators can only effect temporary changes on the GbESM. These changes will be lost when the switch is rebooted/reset. Operators have access to the switch management features used for daily switch operations. Because any changes an operator makes are undone by a reset of the switch, operators cannot severely impact switch operation.
- Administrators are the only ones that may make permanent changes to the switch configuration—changes that are persistent across a reboot/reset of the switch. Administrators can access switch functions to configure and troubleshoot problems on the GbESM. Because administrators can also make temporary (operator-level) changes as well, they must be aware of the interactions between temporary and permanent changes.

Access to switch functions is controlled through the use of unique surnames and passwords. Once you are connected to the switch via local Telnet, remote Telnet, or SSH, you are prompted to enter a password. The default user names/password for each access level are listed in the following table.

**Note:** It is recommended that you change default switch passwords after initial configuration and as regularly as required under your network security policies. For more information, see [“Changing the Switch Passwords” on page 60](#).

Table 3. User Access Levels

User Account	Password	Description and Tasks Performed
user	user	The User has no direct responsibility for switch management. He or she can view all switch status information and statistics, but cannot make any configuration changes to the switch.
oper	oper	The Operator manages all functions of the switch. The Operator can reset ports, except the management ports.
admin	admin	The superuser Administrator has complete access to all menus, information, and configuration commands on the GbESM, including the ability to change both the user and administrator passwords.

**Note:** With the exception of the “admin” user, access to each user level can be disabled by setting the password to an empty value.

---

## Setup vs. the Command Line

Once the administrator password is verified, you are given complete access to the switch. If the switch is still set to its factory default configuration, the system will ask whether you wish to run Setup (see [“Initial Setup” on page 43](#)), a utility designed to help you through the first-time configuration process. If the switch has already been configured, the command line is displayed instead.

---

## Chapter 2. Initial Setup

To help with the initial process of configuring your switch, the IBM Networking OS software includes a Setup utility. The Setup utility prompts you step-by-step to enter all the necessary information for basic configuration of the switch.

Whenever you log in as the system administrator under the factory default configuration, you are asked whether you wish to run the Setup utility. Setup can also be activated manually from the command line interface any time after login.

---

## Information Needed for Setup

Setup requests the following information:

- Basic system information
  - Date & time
  - Whether to use Spanning Tree Group or not
- Optional configuration for each port
  - Speed, duplex, flow control, and negotiation mode (as appropriate)
  - Whether to use VLAN tagging or not (as appropriate)
- Optional configuration for each VLAN
  - Name of VLAN
  - Which ports are included in the VLAN
- Optional configuration of IP parameters
  - IP address/mask and VLAN for each IP interface
  - IP addresses for default gateway
  - Whether IP forwarding is enabled or not

---

## Default Setup Options

The Setup prompt appears automatically whenever you login as the system administrator under the factory default settings.

1. Connect to the switch.

After connecting, the login prompt will appear as shown below.

```
Enter Password:
```

2. Enter admin as the default administrator password.

If the factory default configuration is detected, the system prompts:

```
1/10Gb Uplink Ethernet Switch Module
18:44:05 Wed Jan 3, 2009

The switch is booted with factory default configuration.
To ease the configuration of the switch, a "Set Up" facility which
will prompt you with those configuration items that are essential to the
operation of the switch is provided.
Would you like to run "Set Up" to configure the switch? [y/n]:
```

**Note:** If the default admin login is unsuccessful, or if the administrator Main Menu appears instead, the system configuration has probably been changed from the factory default settings. If desired, return the switch to its factory default configuration.

3. Enter y to begin the initial configuration of the switch, or n to bypass the Setup facility.

---

## Stopping and Restarting Setup Manually

### Stopping Setup

To abort the Setup utility, press <Ctrl-C> during any Setup question. When you abort Setup, the system will prompt:

```
Would you like to run from top again? [y/n]
```

Enter n to abort Setup, or y to restart the Setup program at the beginning.

### Restarting Setup

You can restart the Setup utility manually at any time by entering the following command at the administrator prompt:

```
# /cfg/setup
```

---

## Setup Part 1: Basic System Configuration

When Setup is started, the system prompts:

"Set Up" will walk you through the configuration of  
System Date and Time, Spanning Tree, Port Speed/Mode,  
VLANs, and IP interfaces. [type Ctrl-C to abort "Set Up"]

1. Enter y if you will be configuring VLANs. Otherwise enter n.

If you decide not to configure VLANs during this session, you can configure them later using the configuration menus, or by restarting the Setup facility. For more information on configuring VLANs, see the *IBM Networking OS Application Guide*.

Next, the Setup utility prompts you to input basic system information.

2. Enter the year of the current date at the prompt:

System Date:  
Enter year [2009]:

Enter the four-digits that represent the year. To keep the current year, press <Enter>.

3. Enter the month of the current system date at the prompt:

System Date:  
Enter month [1]:

Enter the month as a number from 1 to 12. To keep the current month, press <Enter>.

4. Enter the day of the current date at the prompt:

Enter day [3]:

Enter the date as a number from 1 to 31. To keep the current day, press <Enter>.  
The system displays the date and time settings:

System clock set to 18:55:36 Wed Jan 28, 2009.

5. Enter the hour of the current system time at the prompt:

System Time:  
Enter hour in 24-hour format [18]:

Enter the hour as a number from 00 to 23. To keep the current hour, press <Enter>.

6. Enter the minute of the current time at the prompt:

Enter minutes [55]:

Enter the minute as a number from 00 to 59. To keep the current minute, press <Enter>.

7. Enter the seconds of the current time at the prompt:

```
Enter seconds [37]:
```

Enter the seconds as a number from 00 to 59. To keep the current second, press <Enter>. The system then displays the date and time settings:

```
System clock set to 8:55:36 Wed Jan 28, 2009.
```

8. Turn Spanning Tree Protocol on or off at the prompt:

```
Spanning Tree:  
Current Spanning Tree Group 1 setting: ON  
Turn Spanning Tree Group 1 OFF? [y/n]
```

Enter y to turn off Spanning Tree, or enter n to leave Spanning Tree on.

---

## Setup Part 2: Port Configuration

**Note:** When configuring port options for your switch, some prompts and options may be different.

1. Select whether you will configure VLANs and VLAN tagging for ports:

```
Port Config:
Will you configure VLANs and VLAN tagging for ports? [y/n]
```

If you wish to change settings for VLANs, enter *y*, or enter *n* to skip VLAN configuration.

**Note:** The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

2. Select the port to configure, or skip port configuration at the prompt:

```
Port Config:
Enter port (INT1-14, MGT1-2, EXT1-9):
```

If you wish to change settings for individual ports, enter the number of the port you wish to configure. To skip port configuration, press <Enter> without specifying any port and go to [“Setup Part 3: VLANs” on page 50](#).

3. Configure Gigabit Ethernet port flow parameters.

If you selected a port that has a Gigabit Ethernet connector, the system prompts:

```
Gig Link Configuration:
Port Flow Control:
Current Port EXT1 flow control setting:    both
Enter new value ["rx"/"tx"/"both"/"none"]:
```

Enter *rx* to enable receive flow control, *tx* for transmit flow control, *both* to enable both, or *none* to turn flow control off for the port. To keep the current setting, press <Enter>.

4. Configure Gigabit Ethernet port autonegotiation mode.

If you selected a port that has a Gigabit Ethernet connector, the system prompts:

```
Port Auto Negotiation:
Current Port EXT1 autonegotiation:        on
Enter new value ["on"/"off"]:
```

Enter *on* to enable port autonegotiation, *off* to disable it, or press <Enter> to keep the current setting.



5. If configuring VLANs, enable or disable VLAN tagging for the port.  
If you have selected to configure VLANs back in Part 1, the system prompts:

```
Port VLAN tagging config (tagged port can be a member of multiple VLANs)
Current VLAN tag support:                disabled
Enter new VLAN tag support [d/e]:
```

Enter d to disable VLAN tagging for the port or enter e to enable VLAN tagging for the port. To keep the current setting, press <Enter>.

6. The system prompts you to configure the next port:

```
Enter port (INT1-14, MGT1-2, EXT1-9):
```

When you are through configuring ports, press <Enter> without specifying any port. Otherwise, repeat the steps in this section.

---

## Setup Part 3: VLANs

If you chose to skip VLANs configuration back in Part 2, skip to [“Setup Part 4: IP Configuration” on page 51](#).

1. Select the VLAN to configure, or skip VLAN configuration at the prompt:

```
VLAN Config:
Enter VLAN number from 2 to 4094, NULL at end:
```

If you wish to change settings for individual VLANs, enter the number of the VLAN you wish to configure. To skip VLAN configuration, press <Enter> without typing a VLAN number and go to [“Setup Part 4: IP Configuration” on page 51](#).

2. Enter the new VLAN name at the prompt:

```
Current VLAN name: VLAN 2
Enter new VLAN name:
```

Entering a new VLAN name is optional. To use the pending new VLAN name, press <Enter>.

3. Enter the VLAN port numbers:

```
Define Ports in VLAN:
Current VLAN 2: empty
Enter ports one per line, NULL at end:
```

Enter each port, by port number or port alias, and confirm placement of the port into this VLAN. When you are finished adding ports to this VLAN, press <Enter> without specifying any port.

4. Configure Spanning Tree Group membership for the VLAN:

```
Spanning Tree Group membership:
Enter new Spanning Tree Group index [1-127]:
```

5. The system prompts you to configure the next VLAN:

```
VLAN Config:
Enter VLAN number from 2 to 4094, NULL at end:
```

Repeat the steps in this section until all VLANs have been configured. When all VLANs have been configured, press <Enter> without specifying any VLAN.

---

## Setup Part 4: IP Configuration

The system prompts for IPv4 parameters.

Although the switch supports both IPv4 and IPv6 networks, the Setup utility permits only IPv4 configuration. For IPv6 configuration, see [“Internet Protocol Version 6” on page 225](#).

### IP Interfaces

IP interfaces are used for defining the networks to which the switch belongs.

Up to 128 IP interfaces can be configured on the 1/10Gb Uplink ESM (GbESM). The IP address assigned to each IP interface provides the switch with an IP presence on your network. No two IP interfaces can be on the same IP network. The interfaces can be used for connecting to the switch for remote configuration, and for routing between subnets and VLANs (if used).

**Note:** Interface 128 is reserved for IPv4 switch management. If the IPv6 feature is enabled, interface 127 is also reserved.

1. Select the IP interface to configure, or skip interface configuration at the prompt:

```
IP Config:
IP interfaces:
Enter interface number: (1-128)
```

If you wish to configure individual IP interfaces, enter the number of the IP interface you wish to configure. To skip IP interface configuration, press <Enter> without typing an interface number and go to [“Default Gateways” on page 53](#).

**Note:** If you change the IP address of interfaces reserved for switch management, you can lose the connection to the management module. Use the management module to change the IP address of the GbESM.

2. For the specified IP interface, enter the IP address in IPv4 dotted decimal notation:

```
Current IP address:    0.0.0.0
Enter new IP address:
```

To keep the current setting, press <Enter>.

3. At the prompt, enter the IPv4 subnet mask in dotted decimal notation:

```
Current subnet mask:    0.0.0.0
Enter new subnet mask:
```

To keep the current setting, press <Enter>.

4. If configuring VLANs, specify a VLAN for the interface.

This prompt appears if you selected to configure VLANs back in Part 1:

```
Current VLAN:      1
Enter new VLAN [1-4094]:
```

Enter the number for the VLAN to which the interface belongs, or press <Enter> without specifying a VLAN number to accept the current setting.

5. At the prompt, enter y to enable the IP interface, or n to leave it disabled:

```
Enable IP interface? [y/n]
```

6. The system prompts you to configure another interface:

```
Enter interface number: (1-128)
```

Repeat the steps in this section until all IP interfaces have been configured. When all interfaces have been configured, press <Enter> without specifying any interface number.

## Loopback Interfaces

A loopback interface provides an IP address, but is not otherwise associated with a physical port or network entity. Essentially, it is a virtual interface that is perceived as being “always available” for higher-layer protocols to use and advertise to the network, regardless of other connectivity.

Loopback interfaces improve switch access, increase reliability, security, and provide greater flexibility in Layer 3 network designs. They can be used for many different purposes, but are most commonly for management IP addresses, router IDs for various protocols, and persistent peer IDs for neighbor relationships.

In IBM N/OS 7.4, loopback interfaces have been expanded for use with routing protocols such as OSPF and BGP. Loopback interfaces can also be specified as the source IP address for syslog, SNMP, RADIUS, TACACS+, NTP, and router IDs.

Loopback interfaces must be configured before they can be used in other features. Up to five loopback interfaces are currently supported. They can be configured using the following commands:

```
>> # /cfg/l3/loopif <1-5>
>> IP Loopback Interface# addr <IPv4 address>
>> IP Loopback Interface# mask <IPv4 subnet mask>
>> IP Loopback Interface# ..
```

## Using Loopback Interfaces for Source IP Addresses

The switch can use loopback interfaces to set the source IP addresses for a variety of protocols. This assists in server security, as the server for each protocol can be configured to accept protocol packets only from the expected loopback address block. It may also make it easier to locate or process protocol information, since packets have the source IP address of the loopback interface, rather than numerous egress interfaces.

Configured loopback interfaces can be applied to the following protocols:

- Syslogs

```
>> # /cfg/sys/syslog/sloopif <1-5>
```

- SNMP traps

```
>> # /cfg/sys/ssnmp/trloopif <1-5>
```

- RADIUS

```
>> # /cfg/sys/radius/sloopif <1-5>
```

- TACACS+

```
>> # /cfg/sys/tacacs+/sloopif <1-5>
```

- NTP

```
>> # /cfg/sys/ntp/sloopif <1-5>
```

## Loopback Interface Limitation

- ARP is not supported. Loopback interfaces will ignore ARP requests.
- Loopback interfaces cannot be assigned to a VLAN.

## Default Gateways

1. At the prompt, select an IP default gateway for configuration, or skip default gateway configuration:

```
IP default gateways:
Enter default gateway number: (1-4)
```

Enter the number for the IP default gateway to be configured. To skip default gateway configuration, press <Enter> without typing a gateway number and go to [“IP Routing” on page 54](#).

**Note:** IPv4 gateway 4 is reserved for switch management and can only be configured using the management module.

2. At the prompt, enter the IPv4 address for the selected default gateway:

```
Current IP address:    0.0.0.0
Enter new IP address:
```

Enter the IPv4 address in dotted decimal notation, or press <Enter> without specifying an address to accept the current setting.

3. At the prompt, enter y to enable the default gateway, or n to leave it disabled:

```
Enable default gateway? [y/n]
```

4. The system prompts you to configure another default gateway:

```
Enter default gateway number: (1-4)
```

Repeat the steps in this section until all default gateways have been configured. When all default gateways have been configured, press <Enter> without specifying any number.

## IP Routing

When IP interfaces are configured for the various IP subnets attached to your switch, IP routing between them can be performed entirely within the switch. This eliminates the need to send inter-subnet communication to an external router device. Routing on more complex networks, where subnets may not have a direct presence on the GbESM, can be accomplished through configuring static routes or by letting the switch learn routes dynamically.

This part of the Setup program prompts you to configure the various routing parameters.

At the prompt, enable or disable forwarding for IP Routing:

`Enable IP forwarding? [y/n]`

Enter y to enable IP forwarding. To disable IP forwarding, enter n. To keep the current setting, press <Enter>.

---

## Setup Part 5: Final Steps

1. When prompted, decide whether to restart Setup or continue:

`Would you like to run from top again? [y/n]`

Enter y to restart the Setup utility from the beginning, or n to continue.

2. When prompted, decide whether you wish to review the configuration changes:

`Review the changes made? [y/n]`

Enter y to review the changes made during this session of the Setup utility. Enter n to continue without reviewing the changes. We recommend that you review the changes.

3. Next, decide whether to apply the changes at the prompt:

`Apply the changes? [y/n]`

Enter y to apply the changes, or n to continue without applying. Changes are normally applied.

4. At the prompt, decide whether to make the changes permanent:

`Save changes to flash? [y/n]`

Enter y to save the changes to flash. Enter n to continue without saving the changes. Changes are normally saved at this point.

5. If you do not apply or save the changes, the system prompts whether to abort them:

`Abort all changes? [y/n]`

Enter y to discard the changes. Enter n to return to the “Apply the changes?” prompt.

**Note:** After initial configuration is complete, it is recommended that you change the default passwords as shown in [“Changing the Switch Passwords” on page 60](#).

---

## Optional Setup for Telnet Support

**Note:** This step is optional. Perform this procedure only if you are planning on connecting to the GbESM through a remote Telnet connection.

1. Telnet is enabled by default. To change the setting, use the following command:

```
>> # /cfg/sys/access/tnet
```

2. Apply and save the configuration(s).

```
>> System# apply  
>> System# save
```



# **Part 2: Securing the Switch**



---

## Chapter 3. Securing Administration

This chapter discusses different methods of securing local and remote administration on the 1/10Gb Uplink ESM (GbESM):

- [“Changing the Switch Passwords” on page 60](#)
- [“Secure Shell and Secure Copy” on page 64](#)
- [“End User Access Control” on page 70](#)
- [“Protected Mode” on page 72](#)

---

## Changing the Switch Passwords

It is recommended that you change the administrator and user passwords after initial configuration and as regularly as required under your network security policies.

To change the administrator password, you must login using the administrator password.

**Note:** If you forget your administrator password, call your technical support representative for help using the password fix-up mode.

## Changing the Default Administrator Password

The administrator has complete access to all menus, information, and configuration commands, including the ability to change both the user and administrator passwords.

The default password for the administrator account is `admin`. To change the default password, follow this procedure:

1. Connect to the switch and log in using the `admin` password.
2. From the Main Menu, use the following command to access the Configuration Menu:

```
Main# /cfg
```

The Configuration Menu is displayed.

```
[Configuration Menu]
sys      - System-wide Parameter Menu
port     - Port Menu
qos      - QOS Menu
acl      - Access Control List Menu
pmirr    - Port Mirroring Menu
l2       - Layer 2 Menu
l3       - Layer 3 Menu
rmon     - RMON Menu
setup    - Step by step configuration set up
dump     - Dump current configuration to script file
ptcfg    - Backup current configuration to FTP/TFTP server
gtcfg    - Restore current configuration from FTP/TFTP server
cur      - Display current configuration
```

3. From the Configuration Menu, use the following command to select the System Menu:

```
>> Configuration# sys
```

The System Menu is displayed.

```
[System Menu]
  syslog - Syslog Menu
  sshd   - SSH Server Menu
  radius - RADIUS Authentication Menu
  tacacs+ - TACACS+ Authentication Menu
  ldap   - LDAP Authentication Menu
  ntp     - NTP Server Menu
  snmp    - System SNMP Menu
  access  - System Access Menu
  dst     - Custom DST Menu
  date    - Set system date
  time    - Set system time
  timezone - Set system timezone (daylight savings)
  dlight  - Set system daylight savings
  idle    - Set timeout for idle CLI sessions
  notice  - Set login notice
  bannr   - Set login banner
  hprompt - Enable/disable display hostname (sysName) in CLI prompt
  rstctrl - Enable/disable System reset on panic
  cur     - Display current system-wide parameters
```

4. From the System Menu, use the following command to select the System Access Menu:

```
>> System# access
```

The System Access Menu is displayed.

```
[System Access Menu]
  mgmt - Management Network Definition Menu
  user  - User Access Control Menu (passwords)
  https - HTTPS Web Access Menu
  snmp  - Set SNMP access control
  tnport - Set Telnet server port number
  tport - Set the TFTP Port for the system
  wport - Set HTTP (Web) server port number
  http  - Enable/disable HTTP (Web) access
  tnet  - Enable/disable Telnet access
  tsbbi - Enable/disable Telnet/SSH configuration from BBI
  userbbi - Enable/disable user configuration from BBI
  cur   - Display current system access configuration
```

5. Select the administrator password.

```
System Access# user/admpw
```

6. Enter the current administrator password at the prompt:

```
Changing ADMINISTRATOR password; validation required...
Enter current administrator password:
```

**Note:** If you forget your administrator password, call your technical support representative for help using the password fix-up mode.

7. Enter the new administrator password at the prompt:

```
Enter new administrator password:
```

8. Enter the new administrator password, again, at the prompt:

```
Re-enter new administrator password:
```

9. Apply and save your change by entering the following commands:

```
System# apply
System# save
```

## Changing the Default User Password

The user login has limited control of the switch. Through a user account, you can view switch information and statistics, but you can't make configuration changes.

The default password for the user account is `user`. This password can be changed from the user account. The administrator can change all passwords, as shown in the following procedure.

1. Connect to the switch and log in using the `admin` password.
2. From the Main Menu, use the following command to access the Configuration Menu:

```
Main# cfg
```

3. From the Configuration Menu, use the following command to select the System Menu:

```
>> Configuration# sys
```

4. From the System Menu, use the following command to select the System Access Menu:

```
>> System# access
```

5. Select the user password.

```
System# user/usrpw
```

6. Enter the current administrator password at the prompt.

Only the administrator can change the user password. Entering the administrator password confirms your authority.

```
Changing USER password; validation required...
Enter current administrator password:
```

7. Enter the new user password at the prompt:

```
Enter new user password:
```

8. Enter the new user password, again, at the prompt:

Re-enter new user password:

9. Apply and save your changes:

System# apply  
System# save

---

## Secure Shell and Secure Copy

Because using Telnet does not provide a secure connection for managing a GbESM, Secure Shell (SSH) and Secure Copy (SCP) features have been included for GbESM management. SSH and SCP use secure tunnels to encrypt and secure messages between a remote administrator and the switch.

**SSH** is a protocol that enables remote administrators to log securely into the GbESM over a network to execute management commands.

**SCP** is typically used to copy files securely from one machine to another. SCP uses SSH for encryption of data on the network. On a GbESM, SCP is used to download and upload the switch configuration via secure channels.

Although SSH and SCP are disabled by default, enabling and using these features provides the following benefits:

- Identifying the administrator using Name/Password
- Authentication of remote administrators
- Authorization of remote administrators
- Determining the permitted actions and customizing service for individual administrators
- Encryption of management messages
- Encrypting messages between the remote administrator and switch
- Secure copy support

IBM Networking OS implements the SSH version 2.0 standard and is confirmed to work with SSH version 2.0-compliant clients such as the following:

- OpenSSH\_5.4p1 for Linux
- Secure CRT Version 5.0.2 (build 1021)
- Putty SSH release 0.60

## Configuring SSH/SCP Features on the Switch

SSH and SCP are disabled by default. To change the setting, using the following procedures.

### To Enable or Disable the SSH Feature

Begin a Telnet session from the console port and enter the following commands:

>> # /cfg/sys/sshd/on	<i>(Turn SSH on)</i>
>> # /cfg/sys/sshd/off	<i>(Turn SSH off)</i>



## To Enable or Disable SCP Apply and Save

Enter the following commands from the switch CLI to enable the SCP `putcfg_apply` and `putcfg_apply_save` commands:

```
>> # /cfg/sys/sshd/ena                                (Enable SCP apply and save)
SSHD# apply                                             (Apply changes to start generating
                                                         RSA host and server keys)

RSA host key generation starts.....
.....
RSA host key generation completes (lasts 212549 ms)
RSA host key is being saved to Flash ROM, please don't reboot
the box immediately.
RSA server key generation starts.....
RSA server key generation completes (lasts 75503 ms)
RSA server key is being saved to Flash ROM, please don't reboot
the box immediately.
-----
Apply complete; don't forget to "save" updated configuration.

>> # /cfg/sys/sshd/dis                                (Disable SSH/SCP apply/save)
```

## Configuring the SCP Administrator Password

To configure the SCP-only administrator password, enter the following command (the default password is `admin`):

```
>> /cfg/sys/sshd/scpadmin
Changing SCP-only Administrator password; validation required...
Enter current administrator password: <password>
Enter new SCP-only administrator password: <new password>
Re-enter new SCP-only administrator password: <new password>
New SCP-only administrator password accepted.
```

## Using SSH and SCP Client Commands

This section shows the format for using some common client commands.

### To Log In to the Switch from the Client

Syntax:

```
>> ssh [-4|-6] <switch IP address>

-OR-

>> ssh [-4|-6] <login name>@<switch IP address>
```

**Note:** The `-4` option (the default) specifies that an IPv4 switch address will be used. The `-6` option specifies IPv6.

Example:

```
>> ssh scpadmin@205.178.15.157
```

## To Copy the Switch Configuration File to the SCP Host

Syntax:

```
>> scp [-4|-6] <username>@<switch IP address>:getcfg <local filename>
```

Example:

```
>> scp scpadmin@205.178.15.157:getcfg ad4.cfg
```

## To Load a Switch Configuration File from the SCP Host

Syntax:

```
>> scp [-4|-6] <local filename> <username>@<switch IP address>:putcfg
```

Example:

```
>> scp ad4.cfg scpadmin@205.178.15.157:putcfg
```

## To Apply and Save the Configuration

When loading a configuration file to the switch, the `apply` and `save` commands are still required, in order for the configuration commands to take effect. The `apply` and `save` commands may be entered manually on the switch, or by using SCP commands.

Syntax:

```
>> scp [-4|-6] <local filename> <username>@<switch IP address>:putcfg_apply  
>> scp [-4|-6] <local filename> <username>@<switch IP address>:putcfg_apply_save
```

Example:

```
>> scp ad4.cfg scpadmin@205.178.15.157:putcfg_apply  
>> scp ad4.cfg scpadmin@205.178.15.157:putcfg_apply_save
```

- The `CLI diff` command is automatically executed at the end of `putcfg` to notify the remote client of the difference between the new and the current configurations.
- `putcfg_apply` runs the `apply` command after the `putcfg` is done.
- `putcfg_apply_save` saves the new configuration to the flash after `putcfg_apply` is done.
- The `putcfg_apply` and `putcfg_apply_save` commands are provided because extra `apply` and `save` commands are usually required after a `putcfg`; however, an SCP session is not in an interactive mode.

## To Copy the Switch Image and Boot Files to the SCP Host

Syntax:

```
>> scp [-4|-6] <username>@<switch IP address>:getimg1 <local filename>
>> scp [-4|-6] <username>@<switch IP address>:getimg2 <local filename>
>> scp [-4|-6] <username>@<switch IP address>:getboot <local filename>
```

Example:

```
>> scp scpadmin@205.178.15.157:getimg1 6.1.0_os.img
```

## To Load Switch Configuration Files from the SCP Host

Syntax:

```
>> scp [-4|-6] <local filename> <username>@<switch IP address>:putimg1
>> scp [-4|-6] <local filename> <username>@<switch IP address>:putimg2
>> scp [-4|-6] <local filename> <username>@<switch IP address>:putboot
```

Example:

```
>> scp 6.1.0_os.img scpadmin@205.178.15.157:putimg1
```

## SSH and SCP Encryption of Management Messages

The following encryption and authentication methods are supported for SSH and SCP:

- Server Host Authentication: Client RSA authenticates the switch at the beginning of every connection
- Key Exchange: RSA
- Encryption: 3DES-CBC, DES
- User Authentication: Local password authentication, RADIUS, SecurID (via RADIUS or TACACS+ for SSH only—does not apply to SCP)

## Generating RSA Host Key for SSH Access

To support the SSH host feature, an RSA host key is required. The host key is 1024 bits and is used to identify the GbESM.

To configure RSA host, first connect to the GbESM through the console port (commands are not available via external Telnet connection), and enter the following command to generate it manually.

```
>> # /cfg/sys/sshd/hkeygen (Generates the host key)
```

These two commands take effect immediately without the need of an `apply` command.

When the switch reboots, it will retrieve the host key from the FLASH memory.

**Note:** The switch will perform only one session of key/cipher generation at a time. Thus, an SSH/SCP client will not be able to log in if the switch is performing key generation at that time. Also, key generation will fail if an SSH/SCP client is logging in at that time.

## SSH/SCP Integration with RADIUS Authentication

SSH/SCP is integrated with RADIUS authentication. After the RADIUS server is enabled on the switch, all subsequent SSH authentication requests will be redirected to the specified RADIUS servers for authentication. The redirection is transparent to the SSH clients.

## SSH/SCP Integration with TACACS+ Authentication

SSH/SCP is integrated with TACACS+ authentication. After the TACACS+ server is enabled on the switch, all subsequent SSH authentication requests will be redirected to the specified TACACS+ servers for authentication. The redirection is transparent to the SSH clients.

## SecurID Support

SSH/SCP can also work with SecurID, a token card-based authentication method. The use of SecurID requires the interactive mode during login, which is not provided by the SSH connection.

**Note:** There is no SNMP or Browser-Based Interface (BBI) support for SecurID because the SecurID server, ACE, is a one-time password authentication and requires an interactive session.

### Using SecurID with SSH

Using SecurID with SSH involves the following tasks.

- To log in using SSH, use a special username, “ace,” to bypass the SSH authentication.
- After an SSH connection is established, you are prompted to enter the username and password (the SecurID authentication is being performed now).
- Provide your username and the token in your SecurID card as a regular Telnet user.

## Using SecuriD with SCP

Using SecuriD with SCP can be accomplished in two ways:

- Using a RADIUS server to store an administrator password.

You can configure a regular administrator with a fixed password in the RADIUS server if it can be supported. A regular administrator with a fixed password in the RADIUS server can perform both SSH and SCP with no additional authentication required.

- Using an SCP-only administrator password.

Set the SCP-only administrator password (`/cfg/sys/sshd/scpadm`) to bypass checking SecuriD.

An SCP-only administrator's password is typically used when SecuriD is not used. For example, it can be used in an automation program (in which the tokens of SecuriD are not available) to back up (download) the switch configurations each day.

**Note:** The SCP-only administrator's password must be different from the regular administrator's password. If the two passwords are the same, the administrator using that password will not be allowed to log in as an SSH user because the switch will recognize him as the SCP-only administrator. The switch will only allow the administrator access to SCP commands.

---

## End User Access Control

N/OS allows an administrator to define end user accounts that permit end users to perform operation tasks via the switch CLI commands. Once end user accounts are configured and enabled, the switch requires username/password authentication.

For example, an administrator can assign a user, who can then log into the switch and perform operational commands (effective only until the next switch reboot).

## Considerations for Configuring End User Accounts

- A maximum of 10 user IDs are supported on the switch.
- N/OS supports end user support for Console, Telnet, BBI, and SSHv2 access to the switch.
- If RADIUS authentication is used, the user password on the Radius server will override the user password on the GbESM. Also note that the password change command modifies only the user switch password on the switch and has no effect on the user password on the Radius server. Radius authentication and user password cannot be used concurrently to access the switch.
- Passwords can be up to 128 characters in length for TACACS, RADIUS, Telnet, SSH, Console, and Web access.

## Strong Passwords

The administrator can require use of Strong Passwords for users to access the GbESM. Strong Passwords enhance security because they make password guessing more difficult.

The following rules apply when Strong Passwords are enabled:

- Each passwords must be 8 to 14 characters
- Within the first 8 characters, the password:
  - must have at least one number or one symbol
  - must have both upper and lower case letters
  - cannot be the same as any four previously used passwords

The following are examples of strong passwords:

- 1234AbcXyz
- Super+User
- Exo1cet2

The administrator can choose the number of days allowed before each password expires. When a strong password expires, the user is allowed to log in one last time (last time) to change the password. A warning provides advance notice for users to change the password.

Use the Strong Password menu to configure Strong Passwords.

```
>> # /cfg/sys/access/user/strongpw
```

## User Access Control Menu

The end user access control menu is located in the System access menu.

```
>> # /cfg/sys/access/user
```

### Setting Up User IDs

Up to 10 user IDs can be configured in the User ID menu.

```
>> # /cfg/sys/access/user/uid 1
```

### Defining User Names and Passwords

Use the User ID menu to define user names and passwords.

```
>> User ID 1 # name user1                (Assign name to user ID 1)
Current user name:
New user name:    user1
>> User ID 1 # pwd                      (Assign password to user ID 1)
Changing user1 password; validation required:
Enter current admin password: <current administrator password>
Enter new user1 password: <new user password>
Re-enter new user1 password: <new user password>
New user1 password accepted.
```

### Defining a User's Access Level

The end user is by default assigned to the user access level (also known as class of service, or CoS). CoS for all user accounts have global access to all resources except for User CoS, which has access to view only resources that the user owns. For more information, see [Table 4 on page 76](#).

To change the user's level, enter the class of service `cos` command:

```
>> User ID 1 # cos <user|oper|admin>
```

### Validating a User's Configuration

```
>> User ID 2 # cur
    name jane      , dis, cos user      , password valid, offline
```

### Enabling or Disabling a User

An end user account must be enabled before the switch recognizes and permits login under the account. Once enabled, the switch requires any user to enter both username and password.

```
>> # /cfg/sys/access/user/uid <user ID>/ena
>> # /cfg/sys/access/user/uid <user ID>/dis
```

## Listing Current Users

The `cur` command displays defined user accounts and whether or not each user is currently logged into the switch.

```
>> # /cfg/sys/access/user/cur

Usernames:
  user      - Enabled - offline
  oper      - Disabled - offline
  admin     - Always Enabled - online 1 session

Current User ID table:
  1: name jane      , ena, cos user      , password valid, online
  2: name john      , ena, cos user      , password valid, online
```

## Logging In to an End User Account

Once an end user account is configured and enabled, the user can login to the switch, using the username/password combination. The level of switch access is determined by the CoS established for the end user account.

---

## Protected Mode

Protected Mode settings allow the switch administrator to block the management module from making configuration changes that affect switch operation. The switch retains control over those functions.

The following management module functions are disabled when Protected Mode is turned on:

- External Ports: Enabled/Disabled
- External management over all ports: Enabled/Disabled
- Restore Factory Defaults
- New Static IP Configuration

In this release, configuration of the functions listed above are restricted to the local switch when you turn Protected Mode on. In future releases, individual control over each function may be added.

**Note:** Before you turn Protected Mode on, make sure that external management (Telnet) access to one of the switch's IP interfaces is enabled.

Use the following command to turn Protected Mode on: `/oper/prm/on`

If you lose access to the switch through the external ports, use the console port to connect directly to the switch, and configure an IP interface with Telnet access.



---

## Chapter 4. Authentication & Authorization Protocols

Secure switch management is needed for environments that perform significant management functions across the Internet. The following are some of the functions for secured IPv4 management and device access:

- [“RADIUS Authentication and Authorization” on page 74](#)
- [“TACACS+ Authentication” on page 77](#)
- [“LDAP Authentication and Authorization” on page 83](#)

**Note:** IBM Networking OS 7.4 does not support IPv6 for RADIUS, TACACS+ or LDAP.

---

## RADIUS Authentication and Authorization

IBM N/OS supports the RADIUS (Remote Authentication Dial-in User Service) method to authenticate and authorize remote administrators for managing the switch. This method is based on a client/server model. The Remote Access Server (RAS)—the switch—is a client to the back-end database server. A remote user (the remote administrator) interacts only with the RAS, not the back-end server and database.

RADIUS authentication consists of the following components:

- A protocol with a frame format that utilizes UDP over IP (based on RFC 2138 and 2866)
- A centralized server that stores all the user authorization information
- A client, in this case, the switch

The GbESM—acting as the RADIUS client—communicates to the RADIUS server to authenticate and authorize a remote administrator using the protocol definitions specified in RFC 2138 and 2866. Transactions between the client and the RADIUS server are authenticated using a shared key that is not sent over the network. In addition, the remote administrator passwords are sent encrypted between the RADIUS client (the switch) and the back-end RADIUS server.

### How RADIUS Authentication Works

1. Remote administrator connects to the switch and provides user name and password.
2. Using Authentication/Authorization protocol, the switch sends request to authentication server.
3. Authentication server checks the request against the user ID database.
4. Using RADIUS protocol, the authentication server instructs the switch to grant or deny administrative access.

### Configuring RADIUS on the Switch

Use the following procedure to configure Radius authentication on your GbESM. For more information, see [“RADIUS Server Configuration Notes” on page 419](#).

1. Turn RADIUS authentication on, then configure the Primary and Secondary RADIUS servers.

```
>> Main# /cfg/sys/radius                               (Select the RADIUS Server menu)
>> RADIUS Server# on                                     (Turn RADIUS on)
Current status: OFF
New status:      ON
>> RADIUS Server# prisrv 10.10.1.1                       (Enter primary server IPv4 address)
Current primary RADIUS server: 0.0.0.0
New pending primary RADIUS server: 10.10.1.1
>> RADIUS Server# secsrv 10.10.1.2                       (Enter secondary server IPv4 address)
Current secondary RADIUS server: 0.0.0.0
New pending secondary RADIUS server: 10.10.1.2
```

**Note:** You can use a configured loopback address as the source address so the RADIUS server accepts requests only from the expected loopback address block. Use the following command to specify the loopback interface:

```
>> # /cfg/sys/radius/sloopif <I-5>
```

## 2. Configure the RADIUS secret.

```
>> RADIUS Server# secret
Enter new RADIUS secret: <1-32 character secret>
>> RADIUS Server# secret2
Enter new secondary RADIUS server secret: <1-32 character secret>
```



### CAUTION:

**If you configure the RADIUS secret using any method other than through the console port or management module, the secret may be transmitted over the network as clear text.**

## 3. If desired, you may change the default UDP port number used to listen to RADIUS.

The well-known port for RADIUS is 1645.

```
>> RADIUS Server# port
Current RADIUS port: 1645
Enter new RADIUS port [1500-3000]: <UDP port number>
```

## 4. Configure the number retry attempts for contacting the RADIUS server, and the timeout period.

```
>> RADIUS Server# retries
Current RADIUS server retries: 3
Enter new RADIUS server retries [1-3]: <server retries>
>> RADIUS Server# timeout
Current RADIUS server timeout: 3
Enter new RADIUS server timeout [1-10]: <the timeout period in minutes>
```

## RADIUS Authentication Features in IBM N/OS

N/OS supports the following RADIUS authentication features:

- Supports RADIUS client on the switch, based on the protocol definitions in RFC 2138 and RFC 2866.
- Allows a RADIUS secret password of up to 32 characters.
- Supports *secondary authentication server* so that when the primary authentication server is unreachable, the switch can send client authentication requests to the secondary authentication server. Use the `/cfg/sys/radius/cur` command to show the currently active RADIUS authentication server.
- Supports user-configurable RADIUS server retry and time-out values:
  - Time-out value = 1-10 seconds
  - Retries = 1-3

The switch will time out if it does not receive a response from the RADIUS server within 1-10 seconds. The switch automatically retries connecting to the RADIUS server 1-3 times before it declares the server down.

- Supports user-configurable RADIUS application port. The default is UDP port 1645. UDP port 1812, based on RFC 2138, is also supported.

- Allows network administrator to define privileges for one or more specific users to access the switch at the RADIUS user database.
- SecurID is supported if the RADIUS server can do an ACE/Server client proxy. The password is the PIN number, plus the token code of the SecurID card.

## Switch User Accounts

The user accounts listed in [Table 4](#) can be defined in the RADIUS server dictionary file.

Table 4. User Access Levels

User Account	Description and Tasks Performed	Password
User	The User has no direct responsibility for switch management. He/she can view all switch status information and statistics but cannot make any configuration changes to the switch.	user
Operator	In addition to User capabilities, the Operator has limited switch management access, including the ability to make temporary, operational configuration changes to some switch features, and to reset switch ports (other than management ports).	oper
Administrator	The super-user Administrator has complete access to all menus, information, and configuration commands on the switch, including the ability to change both the user and administrator passwords.	admin

## RADIUS Attributes for IBM N/OS User Privileges

When the user logs in, the switch authenticates his/her level of access by sending the RADIUS access request, that is, the client authentication request, to the RADIUS authentication server.

If the remote user is successfully authenticated by the authentication server, the switch will verify the *privileges* of the remote user and authorize the appropriate access. The administrator has an option to allow *backdoor* access via Telnet, SSH, HTTP, and HTTPS. The default GbESM setting for backdoor access is *disabled*. Backdoor access is always enabled on the console port.

**Note:** To obtain the RADIUS backdoor password for your GbESM, contact your IBM Service and Support line.

All user privileges, other than those assigned to the Administrator, have to be defined in the RADIUS dictionary. RADIUS attribute 6 which is built into all RADIUS servers defines the administrator. The file name of the dictionary is RADIUS vendor-dependent. The following RADIUS attributes are defined for N/OS user privileges levels:

Table 5. IBM N/OS-proprietary Attributes for RADIUS

User Name/Access	User-Service-Type	Value
User	Vendor-supplied	255
Operator	Vendor-supplied	252
Admin	Vendor-supplied	6

---

## TACACS+ Authentication

N/OS supports authentication, authorization, and accounting with networks using the Cisco Systems TACACS+ protocol. The GbESM functions as the Network Access Server (NAS) by interacting with the remote client and initiating authentication and authorization sessions with the TACACS+ access server. The remote user is defined as someone requiring management access to the GbESM either through a data or management port.

TACACS+ offers the following advantages over RADIUS:

- TACACS+ uses TCP-based connection-oriented transport; whereas RADIUS is UDP-based. TCP offers a connection-oriented transport, while UDP offers best-effort delivery. RADIUS requires additional programmable variables such as re-transmit attempts and time-outs to compensate for best-effort transport, but it lacks the level of built-in support that a TCP transport offers.
- TACACS+ offers full packet encryption whereas RADIUS offers password-only encryption in authentication requests.
- TACACS+ separates authentication, authorization and accounting.

## How TACACS+ Authentication Works

TACACS+ works much in the same way as RADIUS authentication as described on [page 74](#).

1. Remote administrator connects to the switch and provides user name and password.
2. Using Authentication/Authorization protocol, the switch sends request to authentication server.
3. Authentication server checks the request against the user ID database.
4. Using TACACS+ protocol, the authentication server instructs the switch to grant or deny administrative access.

During a session, if additional authorization checking is needed, the switch checks with a TACACS+ server to determine if the user is granted permission to use a particular command.

## TACACS+ Authentication Features in IBM N/OS

Authentication is the action of determining the identity of a user, and is generally done when the user first attempts to log in to a device or gain access to its services. N/OS supports ASCII inbound login to the device. PAP, CHAP and ARAP login methods, TACACS+ change password requests, and one-time password authentication are not supported.

### Authorization

Authorization is the action of determining a user's privileges on the device, and usually takes place after authentication.

The default mapping between TACACS+ authorization levels and N/OS management access levels is shown in [Table 6](#). The authorization levels listed in this table must be defined on the TACACS+ server.

*Table 6. Default TACACS+ Authorization Levels*

N/OS User Access Level	TACACS+ Level
user	0
oper	3
admin	6

Alternate mapping between TACACS+ authorization levels and N/OS management access levels is shown in [Table 7](#). Use the `/cfg/sys/tacacs/cmap ena` command to use the alternate TACACS+ authorization levels.

*Table 7. Alternate TACACS+ Authorization Levels*

N/OS User Access Level	TACACS+ Level
user	0–1
oper	6–8
admin	14–15

You can customize the mapping between TACACS+ privilege levels and GbESM management access levels. Use the `/cfg/sys/tacacs/usermap` command to manually map each TACACS+ privilege level (0-15) to a corresponding GbESM management access level.

If the remote user is successfully authenticated by the authentication server, the switch verifies the *privileges* of the remote user and authorizes the appropriate access. The administrator has an option to allow *backdoor* access via Telnet (`/cfg/sys/tacacs/bckdoor`). The default value for Telnet access is `disabled`. The administrator also can enable *secure backdoor* (`/cfg/sys/tacacs/secbd`), to allow access if both the primary and the secondary TACACS+ servers fail to respond.

**Note:** To obtain the TACACS+ backdoor password for your switch, contact your IBM Service and Support line.

## Accounting

Accounting is the action of recording a user's activities on the device for the purposes of billing and/or security. It follows the authentication and authorization actions. If the authentication and authorization is not performed via TACACS+, there are no TACACS+ accounting messages sent out.

You can use TACACS+ to record and track software login access, configuration changes, and interactive commands.

The GbESM supports the following TACACS+ accounting attributes:

- protocol (console/telnet/ssh/http)
- start\_time
- stop\_time
- elapsed\_time
- disc-cause

**Note:** When using the Browser-Based Interface, the TACACS+ Accounting Stop records are sent only if the Quit button on the browser is clicked.

## Command Authorization and Logging

When TACACS+ Command Authorization is enabled (/cfg/sys/tacacs/cauth ena), N/OS configuration commands are sent to the TACACS+ server for authorization. When TACACS+ Command Logging is enabled (/cfg/sys/tacacs/clog ena), N/OS configuration commands are logged on the TACACS+ server.

The following examples illustrate the format of N/OS commands sent to the TACACS+ server:

```
authorization request, cmd=cfgtree, cmd-arg=/cfg/l3/if
accounting request, cmd=/cfg/l3/if, cmd-arg=1
authorization request, cmd=cfgtree, cmd-arg=/cfg/l3/if/ena
accounting request, cmd=/cfg/l3/if/ena
authorization request, cmd=cfgtree, cmd-arg=/cfg/l3/if/addr
accounting request, cmd=/cfg/l3/if/addr, cmd-arg=10.90.90.91

authorization request, cmd=apply
accounting request, cmd=apply
```

The following rules apply to TACACS+ command authorization and logging:

- Only commands from a Console, Telnet, or SSH connection are sent for authorization and logging. SNMP, BBI, or file-copy commands (for example, TFTP or sync) are not sent.
- Only leaf-level commands are sent for authorization and logging. For example, `/cfg` is not sent, but `/cfg/sys/tacacs/cauth` is sent.
- The full path of each command is sent for authorization and logging. For example:  
`/cfg/sys/tacacs/cauth`
- Command arguments are not sent for authorization. For `/cauth ena`, only `/cauth` is authorized. The command and its first argument are logged, if issued on the same line.
- Only executed commands are logged.
- Invalid commands are checked by N/OS, and are not sent for authorization or logging.
- Authorization is performed on each leaf-level command separately. If the user issues multiple commands at once, each command is sent separately as a full path.
- Only the following global commands are sent for authorization and logging:
  - `apply`
  - `diff`
  - `ping`
  - `revert`
  - `save`
  - `telnet`
  - `traceroute`

## TACACS+ Password Change

N/OS supports TACACS+ password change. When enabled, users can change their passwords after successful TACACS+ authorization. Use the command `/cfg/sys/tacacs/passch` to enable or disable this feature.

Use the following commands to change the password for the primary and secondary TACACS+ servers:

<code>&gt;&gt; # /cfg/sys/tacacs/chpass_p</code>	<i>(Change primary TACACS+ password)</i>
<code>&gt;&gt; # /cfg/sys/tacacs/chpass_s</code>	<i>(Change secondary TACACS+ password)</i>



## Configuring TACACS+ Authentication on the Switch

1. Turn TACACS+ authentication on, then configure the Primary and Secondary TACACS+ servers.

```
>> Main# /cfg/sys/tacacs+ (Select the TACACS+ Server menu)
>> TACACS+ Server# on (Turn TACACS+ on)
Current status: OFF
New status: ON
>> TACACS+ Server# prisrv 10.10.1.1 (Enter primary server IPv4 address)
Current primary TACACS+ server: 0.0.0.0
New pending primary TACACS+ server: 10.10.1.1
>> TACACS+ Server# secsrv 10.10.1.2 (Enter secondary server IPv4 address)
Current secondary TACACS+ server: 0.0.0.0
New pending secondary TACACS+ server: 10.10.1.2
```

**Note:** You can use a configured loopback address as the source address so the TACACS+ server accepts requests only from the expected loopback address block. Use the following command to specify the loopback interface:

```
>> # /cfg/sys/tacacs+/sloopif <I-5>
```

2. Configure the TACACS+ secret and second secret.

```
>> TACACS+ Server# secret
Enter new TACACS+ secret: <1-32 character secret>
>> TACACS+ Server# secret2
Enter new TACACS+ second secret: <1-32 character secret>
```



### CAUTION:

**If you configure the TACACS+ secret using any method other than a direct console connection or through a secure management module connection, the secret may be transmitted over the network as clear text.**

3. If desired, you may change the default TCP port number used to listen to TACACS+. The well-known port for TACACS+ is 49.

```
>> TACACS+ Server# port
Current TACACS+ port: 49
Enter new TACACS+ port [1-65000]: <port number>
```

4. Configure the number of retry attempts, and the timeout period.

```
>> TACACS+ Server# retries
Current TACACS+ server retries: 3
Enter new TACACS+ server retries [1-3]: <server retries>
>> TACACS+ Server# time
Current TACACS+ server timeout: 5
Enter new TACACS+ server timeout [4-15]: <timeout period in minutes>
```

5. Configure custom privilege-level mapping (optional).

```
>> TACACS+ Server# usermap 2
Current privilege mapping for remote privilege 2: not set
Enter new local privilege mapping: user
>> TACACS+ Server# usermap 3 user
>> TACACS+ Server# usermap 4 user
>> TACACS+ Server# usermap 5 oper
```

6. Apply and save the configuration.

---

## LDAP Authentication and Authorization

N/OS supports the LDAP (Lightweight Directory Access Protocol) method to authenticate and authorize remote administrators to manage the switch. LDAP is based on a client/server model. The switch acts as a client to the LDAP server. A remote user (the remote administrator) interacts only with the switch, not the back-end server and database.

LDAP authentication consists of the following components:

- A protocol with a frame format that utilizes TCP over IP
- A centralized server that stores all the user authorization information
- A client, in this case, the switch

Each entry in the LDAP server is referenced by its Distinguished Name (DN). The DN consists of the user-account name concatenated with the LDAP domain name. If the user-account name is John, the following is an example DN:

```
uid=John,ou=people,dc=domain,dc=com
```

### Configuring the LDAP Server

GbESM user groups and user accounts must reside within the same domain. On the LDAP server, configure the domain to include GbESM user groups and user accounts, as follows:

- User Accounts:  
Use the *uid* attribute to define each individual user account.
- User Groups:  
Use the *members* attribute in the *groupOfNames* object class to create the user groups. The first word of the common name for each user group must be equal to the user group names defined in the GbESM, as follows:
  - admin
  - oper
  - user

## Configuring LDAP Authentication on the Switch

1. Turn LDAP authentication on, then configure the Primary and Secondary LDAP servers.

```
>> Main# /cfg/sys/ldap                               (Select the LDAP Server menu)
>> LDAP Server# on                                    (Turn LDAP on)
Current status: OFF
New status: ON
>> LDAP Server# prisrv 10.10.1.1                      (Enter primary server IPv4 address)
Current primary LDAP server: 0.0.0.0
New pending primary LDAP server: 10.10.1.1
>> LDAP Server# secsrv 10.10.1.2                     (Enter secondary server IPv4 address)
Current secondary LDAP server: 0.0.0.0
New pending secondary LDAP server: 10.10.1.2
```

2. Configure the domain name.

```
>> LDAP Server# domain
Current LDAP domain name: ou=people,dc=domain,dc=com
Enter new LDAP domain name: ou=people,dc=mydomain,dc=com
```

3. If desired, you may change the default TCP port number used to listen to LDAP. The well-known port for LDAP is 389.

```
>> LDAP Server# port
Current LDAP port: 389
Enter new LDAP port [1-65000]: <port number>
```

4. Configure the number of retry attempts for contacting the LDAP server, and the timeout period.

```
>> LDAP Server# retries
Current LDAP server retries: 3
Enter new LDAP server retries [1-3]: <server retries>
>> LDAP Server# timeout
Current LDAP server timeout: 5
Enter new LDAP server timeout [4-15]: 10 (Enter the timeout period in minutes)
```

5. Apply and save the configuration.

---

## Chapter 5. 802.1X Port-Based Network Access Control

Port-Based Network Access control provides a means of authenticating and authorizing devices attached to a LAN port that has point-to-point connection characteristics. It prevents access to ports that fail authentication and authorization. This feature provides security to ports of the 1/10Gb Uplink ESM (GbESM) that connect to blade servers.

The following topics are discussed in this section:

- [“Extensible Authentication Protocol over LAN” on page 86](#)
- [“EAPoL Authentication Process” on page 87](#)
- [“EAPoL Port States” on page 89](#)
- [“Guest VLAN” on page 89](#)
- [“Supported RADIUS Attributes” on page 90](#)
- [“EAPoL Configuration Guidelines” on page 92](#)

---

## Extensible Authentication Protocol over LAN

IBM Networking OS can provide user-level security for its ports using the IEEE 802.1X protocol, which is a more secure alternative to other methods of port-based network access control. Any device attached to an 802.1X-enabled port that fails authentication is prevented access to the network and denied services offered through that port.

The 802.1X standard describes port-based network access control using Extensible Authentication Protocol over LAN (EAPoL). EAPoL provides a means of authenticating and authorizing devices attached to a LAN port that has point-to-point connection characteristics and of preventing access to that port in cases of authentication and authorization failures.

EAPoL is a client-server protocol that has the following components:


- **Supplicant or Client**  
The Supplicant is a device that requests network access and provides the required credentials (user name and password) to the Authenticator and the Authenticator Server.
- **Authenticator**  
The Authenticator enforces authentication and controls access to the network. The Authenticator grants network access based on the information provided by the Supplicant and the response from the Authentication Server. The Authenticator acts as an intermediary between the Supplicant and the Authentication Server: requesting identity information from the client, forwarding that information to the Authentication Server for validation, relaying the server's responses to the client, and authorizing network access based on the results of the authentication exchange. The GbESM acts as an Authenticator.
- **Authentication Server**  
The Authentication Server validates the credentials provided by the Supplicant to determine if the Authenticator should grant access to the network. The Authentication Server may be co-located with the Authenticator. The GbESM relies on external RADIUS servers for authentication.

Upon a successful authentication of the client by the server, the 802.1X-controlled port transitions from unauthorized to authorized state, and the client is allowed full access to services through the port. When the client sends an EAP-Logoff message to the authenticator, the port will transition from authorized to unauthorized state.

## EAPoL Authentication Process

The clients and authenticators communicate using Extensible Authentication Protocol (EAP), which was originally designed to run over PPP, and for which the IEEE 802.1X Standard has defined an encapsulation method over Ethernet frames, called EAP over LAN (EAPoL). Figure 2 shows a typical message exchange initiated by the client.

Figure 2. Authenticating a Port Using EAPoL



---

## EAPoL Message Exchange

During authentication, EAPoL messages are exchanged between the client and the GbESM authenticator, while RADIUS-EAP messages are exchanged between the GbESM authenticator and the RADIUS server.

Authentication is initiated by one of the following methods:

- The GbESM authenticator sends an EAP-Request/Identity packet to the client
- The client sends an EAPoL-Start frame to the GbESM authenticator, which responds with an EAP-Request/Identity frame.

The client confirms its identity by sending an EAP-Response/Identity frame to the GbESM authenticator, which forwards the frame encapsulated in a RADIUS packet to the server.

The RADIUS authentication server chooses an EAP-supported authentication algorithm to verify the client's identity, and sends an EAP-Request packet to the client via the GbESM authenticator. The client then replies to the RADIUS server with an EAP-Response containing its credentials.

Upon a successful authentication of the client by the server, the 802.1X-controlled port transitions from unauthorized to authorized state, and the client is allowed full access to services through the controlled port. When the client later sends an EAPoL-Logoff message to the GbESM authenticator, the port transitions from authorized to unauthorized state.

If a client that does not support 802.1X connects to an 802.1X-controlled port, the GbESM authenticator requests the client's identity when it detects a change in the operational state of the port. The client does not respond to the request, and the port remains in the unauthorized state.

**Note:** When an 802.1X-enabled client connects to a port that is not 802.1X-controlled, the client initiates the authentication process by sending an EAPoL-Start frame. When no response is received, the client retransmits the request for a fixed number of times. If no response is received, the client assumes the port is in authorized state, and begins sending frames, even if the port is unauthorized.



---

## EAPoL Port States

The state of the port determines whether the client is granted access to the network, as follows:

- **Unauthorized**

While in this state the port discards all ingress and egress traffic except EAP packets.

- **Authorized**

When the client is successfully authenticated, the port transitions to the authorized state allowing all traffic to and from the client to flow normally.

- **Force Unauthorized**

You can configure this state that denies all access to the port.

- **Force Authorized**

You can configure this state that allows full access to the port.

Use the 802.1X Global Configuration Menu (`/cfg/12/8021x/global`) to configure 802.1X authentication for all ports in the switch. Use the 802.1X Port Menu (`/cfg/12/8021x/port <x>`) to configure a single port.

---

## Guest VLAN

The guest VLAN provides limited access to unauthenticated ports. The guest VLAN can be configured from the following menu:

```
>> # /cfg/12/8021x/global/gvlan
```

Client ports that have not received an EAPOL response are placed into the Guest VLAN, if one is configured on the switch. Once the port is authenticated, it is moved from the Guest VLAN to its configured VLAN.

When Guest VLAN enabled, the following considerations apply while a port is in the unauthenticated state:

- The port is placed in the guest VLAN.
- The Port VLAN ID (PVID) is changed to the Guest VLAN ID.
- Port tagging is disabled on the port.

## Supported RADIUS Attributes

The 802.1X Authenticator relies on external RADIUS servers for authentication with EAP. [Table 8](#) lists the RADIUS attributes that are supported as part of RADIUS-EAP authentication based on the guidelines specified in Annex D of the 802.1X standard and RFC 3580.

Table 8. Support for RADIUS Attributes

#	Attribute	Attribute Value	A-R	A-A	A-C	A-R
1	User-Name	The value of the Type-Data field from the supplicant's EAP-Response/Identity message. If the Identity is unknown (i.e. Type-Data field is zero bytes in length), this attribute will have the same value as the Calling-Station-Id.	1	0-1	0	0
4	NAS-IP-Address	IPv4 address of the authenticator used for Radius communication.	1	0	0	0
5	NAS-Port	Port number of the authenticator port to which the supplicant is attached.	1	0	0	0
24	State	Server-specific value. This is sent unmodified back to the server in an Access-Request that is in response to an Access-Challenge.	0-1	0-1	0-1	0
30	Called-Station-ID	The MAC address of the authenticator encoded as an ASCII string in canonical format, such as 000D5622E3 9F.	1	0	0	0
31	Calling-Station-ID	The MAC address of the supplicant encoded as an ASCII string in canonical format, such as 00034B436206.	1	0	0	0
64	Tunnel-Type	Only VLAN (type 13) is currently supported (for 802.1X RADIUS VLAN assignment). The attribute must be untagged (the Tag field must be 0).	0	0-1	0	0
65	Tunnel-Medium-Type	Only 802 (type 6) is currently supported (for 802.1X RADIUS VLAN assignment). The attribute must be untagged (the Tag field must be 0).	0	0-1	0	0

Table 8. Support for RADIUS Attributes (continued)

#	Attribute	Attribute Value	A-R	A-A	A-C	A-R
81	Tunnel-Private-Group-ID	VLAN ID (1-4094). When 802.1X RADIUS VLAN assignment is enabled on a port, if the RADIUS server includes the tunnel attributes defined in RFC 2868 in the Access-Accept packet, the switch will automatically place the authenticated port in the specified VLAN. Reserved VLANs (such as for management or stacking) may not be specified. The attribute must be untagged (the Tag field must be 0).	0	0-1	0	0
79	EAP-Message	Encapsulated EAP packets from the supplicant to the authentication server (Radius) and vice-versa. The authenticator relays the decoded packet to both devices.	1+	1+	1+	1+
80	Message-Authenticator	Always present whenever an EAP-Message attribute is also included. Used to integrity-protect a packet.	1	1	1	1
87	NAS-Port-ID	Name assigned to the authenticator port, e.g. Server1_Port3	1	0	0	0
<p><b>Legend:</b> RADIUS Packet Types: A-R (Access-Request), A-A (Access-Accept), A-C (Access-Challenge), A-R (Access-Reject)</p> <p>RADIUS Attribute Support:</p> <ul style="list-style-type: none"> <li>• 0 This attribute MUST NOT be present in a packet.</li> <li>• 0+ Zero or more instances of this attribute MAY be present in a packet.</li> <li>• 0-1 Zero or one instance of this attribute MAY be present in a packet.</li> <li>• 1 Exactly one instance of this attribute MUST be present in a packet.</li> <li>• 1+ One or more of these attributes MUST be present.</li> </ul>						

---

## EAPoL Configuration Guidelines

When configuring EAPoL, consider the following guidelines:

- The 802.1X port-based authentication is currently supported only in point-to-point configurations, that is, with a single supplicant connected to an 802.1X-enabled switch port.
- 802.1X authentication is not supported on ISL ports or on any port that is part of a trunk.
- When 802.1X is enabled, a port has to be in the authorized state before any other Layer 2 feature can be operationally enabled. For example, the STG state of a port is operationally disabled while the port is in the unauthorized state.
- The 802.1X supplicant capability is not supported. Therefore, none of its ports can successfully connect to an 802.1X-enabled port of another device, such as another switch, that acts as an authenticator, unless access control on the remote port is disabled or is configured in forced-authorized mode. For example, if a GbESM is connected to another GbESM, and if 802.1X is enabled on both switches, the two connected ports must be configured in force-authorized mode.
- Unsupported 802.1X attributes include Service-Type, Session-Timeout, and Termination-Action.
- RADIUS accounting service for 802.1X-authenticated devices or users is not currently supported.
- Configuration changes performed using SNMP and the standard 802.1X MIB will take effect immediately.

---

## Chapter 6. Access Control Lists

Access Control Lists (ACLs) are filters that permit or deny traffic for security purposes. They can also be used with QoS to classify and segment traffic in order to provide different levels of service to different traffic types. Each filter defines the conditions that must match for inclusion in the filter, and also the actions that are performed when a match is made.

IBM Networking OS 7.4 supports the following ACLs:

- IPv4 ACLs

Up to 640 ACLs are supported for networks that use IPv4 addressing. IPv4 ACLs are configured using the following CLI menu:

```
# /cfg/acl/acl <IPv4 ACL number>
```

- IPv6 ACLs

Up to 128 ACLs are supported for networks that use IPv6 addressing. IPv6 ACLs are configured using the following CLI menu:

```
# /cfg/acl/acl6 <IPv6 ACL number>
```

- VLAN Maps (VMaps)

Up to 128 VMaps are supported for attaching filters to VLANs rather than ports. See [“VLAN Maps” on page 104](#) for details.

---

## Summary of Packet Classifiers

ACLs allow you to classify packets according to a variety of content in the packet header (such as the source address, destination address, source port number, destination port number, and others). Once classified, packet flows can be identified for more processing.

IPv4 ACLs, IPv6 ACLs, and VMaps allow you to classify packets based on the following packet attributes:

- Ethernet header options (for IPv4 ACLs and VMaps only)
  - Source MAC address
  - Destination MAC address
  - VLAN number and mask
  - Ethernet type (ARP, IP, IPv6, MPLS, RARP, etc.)
  - Ethernet Priority (the IEEE 802.1p Priority)
- IPv4 header options (for IPv4 ACLs and VMaps only)
  - Source IPv4 address and subnet mask
  - Destination IPv4 address and subnet mask
  - Type of Service value
  - IP protocol number or name as shown in [Table 9](#):

*Table 9. Well-Known Protocol Types*

Number	Protocol Name
1	icmp
2	igmp
6	tcp
17	udp
89	ospf
112	vrrp

- IPv6 header options (for IPv6 ACLs only)
  - Source IPv6 address and prefix length
  - Destination IPv6 address and prefix length
  - Next Header value
  - Flow Label value
  - Traffic Class value

- TCP/UDP header options (for all ACLs)
  - TCP/UDP application source port as shown in [Table 10](#)

Table 10. Well-Known Application Ports

Port	TCP/UDP Application	Port	TCP/UDP Application	Port	TCP/UDP Application
20	ftp-data	79	finger	179	bgp
21	ftp	80	http	194	irc
22	ssh	109	pop2	220	imap3
23	telnet	110	pop3	389	ldap
25	smtp	111	sunrpc	443	https
37	time	119	nntp	520	rip
42	name	123	ntp	554	rtsp
43	whois	143	imap	1645/1812	Radius
53	domain	144	news	1813	Radius
69	tftp	161	snmp	1985	Accounting
70	gopher	162	snmptrap		hsrp

- TCP/UDP application destination port and mask as shown in [Table 10](#)
- TCP/UDP flag value as shown in [Table 11](#)

Table 11. Well-Known TCP flag values

Flag	Value
URG	0x0020
ACK	0x0010
PSH	0x0008
RST	0x0004
SYN	0x0002
FIN	0x0001

- Packet format (for IPv4 ACLs and VMaps only)
  - Ethernet format (eth2, SNAP, LLC)
  - Ethernet tagging format
  - IP format (IPv4, IPv6)
- Egress port packets (for all ACLs)

---

## Summary of ACL Actions

Once classified using ACLs, the identified packet flows can be processed differently. For each ACL, an *action* can be assigned. The action determines how the switch treats packets that match the classifiers assigned to the ACL. GbESM ACL actions include the following:

- Pass or Drop the packet
- Re-mark the packet with a new DiffServ Code Point (DSCP)
- Re-mark the 802.1p field
- Set the COS queue

---

## Assigning Individual ACLs to a Port

Once you configure an ACL, you must assign the ACL to the appropriate ports. Each port can accept multiple ACLs, and each ACL can be applied for multiple ports. ACLs can be assigned individually, or in groups.

To assign an individual ACLs to a port, use the following commands: When multiple

```
# /cfg/port <x>/aclqos/add acl <IPv4 ACL number> (For IPv4 ACLs)
# /cfg/port <x>/aclqos/add acl6 <IPv6 ACL number> (For IPv6 ACLs)
```

ACLs are assigned to a port, higher-priority ACLs are considered first, and their action takes precedence over lower-priority ACLs. ACL order of precedence is discussed in the next section.

**Note:** When IPv6 ACLs are applied to a port, some IPv4 ACLs are restricted from being applied to the same port. Only IPv4 ACLs 1 through 384 may be applied to ports that also use IPv6 ACLs.

To create and assign ACLs in groups, see [“ACL Groups” on page 98](#).



---

## ACL Order of Precedence

When multiple ACLs are assigned to a port, the order in which the ACLs are applied to port traffic (or whether they are applied at all) depends on the following factors:

- The precedence group in which the ACL resides;
- The ACL number;
- Whether a prior ACL in the precedence group is also matched;
- And whether the ACL action is compatible with preceding ACLs.

ACLs are automatically divided into precedence groups as follows:

Precedence Group 1 includes ACL 1–128.  
Precedence Group 2 includes ACL 129–256.  
Precedence Group 3 includes ACL 257–384.  
Precedence Group 4 includes ACL 385–512.  
Precedence Group 5 includes ACL 513–640.

The switch processes each precedence group in numeric sequence; Precedence group 1 is evaluated first, followed by precedence group 2, and so on.

Within each precedence group, ACLs assigned to the port are processed in numeric sequence, based on ACL number. Lower-numbered ACLs take precedence over higher-numbered ACLs. For example, ACL 1 (if assigned to the port) is evaluated first and has top priority within precedence group 1.

For each precedence group, only the first assigned ACL that matches the port traffic is considered. If multiple ACLs in the precedence group match the traffic, only the one with the lowest ACL number is considered. The others in the precedence group are ignored.

One ACL match from each precedence group is permitted, meaning that up to five ACL matches may be considered for action: one from precedence group 1, one from precedence group 2, and so on.

Of the matching ACLs permitted, each configured ACL action is applied in sequence, based on ACL number, with the lowest-numbered ACL's action applied first. If an ACL action contradicts a preceding ACL (one with a lower ACL number), the action of the higher-numbered ACL is ignored.

If no assigned ACL matches the port traffic, no ACL action is applied.

---

## ACL Groups

To assist in organizing multiple ACLs and assigning them to ports, you can place ACLs into ACL Groups, thereby defining complex traffic profiles. ACLs and ACL Groups can then be assigned on a per-port basis. Any specific ACL can be assigned to multiple ACL Groups, and any ACL or ACL Group can be assigned to multiple ports. If, as part of multiple ACL Groups, a specific ACL is assigned to a port multiple times, only one instance is used. The redundant entries are ignored.

- **Individual ACLs**

The GbESM supports up to 640 ACLs. Each ACL defines one filter rule for matching traffic criteria. Each filter rule can also include an action (permit or deny the packet). For example:

<b>ACL 1:</b> VLAN = 1 SIP = 10.10.10.1 (255.255.255.0) Action = permit
--

- **Access Control List Groups**

An Access Control List Group (ACL Group) is a collection of ACLs. For example:

<b>ACL Group 1</b>
<b>ACL 1:</b> VLAN = 1 SIP = 10.10.10.1 (255.255.255.0) Action = permit
<b>ACL 2:</b> VLAN = 2 SIP = 10.10.10.2 (255.255.255.0) Action = deny
<b>ACL 3:</b> Priority = 7 DIP = 10.10.10.3 (255.255.255.0) Action = permit

ACL Groups organize ACLs into traffic profiles that can be more easily assigned to ports. The GbESM supports up to 640 ACL Groups.

**Note:** ACL Groups are used for convenience in assigning multiple ACLs to ports. ACL Groups have no effect on the order in which ACLs are applied (see [“ACL Order of Precedence” on page 97](#)). All ACLs assigned to the port (whether individually assigned or part of an ACL Group) are considered as individual ACLs for the purposes of determining their order of precedence.

---

## Assigning ACL Groups to a Port

To assign an ACL Group to a port, use the following command:

<pre># /cfg/port &lt;x&gt;/aclqos/add grp 20</pre>
--

---

## ACL Metering and Re-Marking

You can define a profile for the aggregate traffic flowing through the GbESM by configuring a QoS meter (if desired) and assigning ACLs to ports.

**Note:** When you add ACLs to a port, make sure they are ordered correctly in terms of precedence (see [“ACL Order of Precedence” on page 97](#)).

Actions taken by an ACL are called *In-Profile* actions. You can configure additional In-Profile and Out-of-Profile actions on a port. Data traffic can be metered, and re-marked to ensure that the traffic flow provides certain levels of service in terms of bandwidth for different types of network traffic.

### Metering

QoS metering provides different levels of service to data streams through user-configurable parameters. A meter is used to measure the traffic stream against a traffic profile which you create. Thus, creating meters yields In-Profile and Out-of-Profile traffic for each ACL, as follows:

- **In-Profile**—If there is no meter configured or if the packet conforms to the meter, the packet is classified as In-Profile.
- **Out-of-Profile**—If a meter is configured and the packet does not conform to the meter (exceeds the committed rate or maximum burst rate of the meter), the packet is classified as Out-of-Profile.

**Note:** Metering is not supported for IPv6 ACLs. All traffic matching an IPv6 ACL is considered in-profile for re-marking purposes.

Using meters, you set a Committed Rate in Kbps (1000 bits per second in each Kbps). All traffic within this Committed Rate is In-Profile. Additionally, you can set a Maximum Burst Size that specifies an allowed data burst larger than the Committed Rate for a brief period. These parameters define the In-Profile traffic.

Meters keep the sorted packets within certain parameters. You can configure a meter on an ACL, and perform actions on metered traffic, such as packet re-marking.

### Re-Marking

Re-marking allows for the treatment of packets to be reset based on new network specifications or desired levels of service. You can configure the ACL to re-mark a packet as follows:

- Change the DSCP value of a packet, used to specify the service level that traffic should receive.
- Change the 802.1p priority of a packet.

---

## ACL Port Mirroring

For IPv4 ACLs and VMaps, packets that match the filter can be mirrored to another switch port for network diagnosis and monitoring.

The source port for the mirrored packets cannot be a portchannel, but may be a member of a portchannel.

The destination port to which packets are mirrored must be a physical port.

If the ACL or VMap has an action (permit, drop, etc.) assigned, it cannot be used to mirror packets for that ACL.

Use the following commands to add mirroring to an ACL:

- For IPv4 ACLs:

```
# /cfg/acl/acl <ACL number>/mirror
Mirror Options Menu# port <destination port number> (Mirror port)
Mirror Options Menu# dest {port|none} (Enable mirroring)
```

The ACL must be also assigned to its target ports as usual (see [“Assigning Individual ACLs to a Port” on page 96](#), or [“Assigning ACL Groups to a Port” on page 98](#)).

- For VMaps (see [“VLAN Maps” on page 104](#)):

```
# /cfg/acl/vmap <VMap number>/mirror
Mirror Options Menu# port <destination port number> (Mirror port)
Mirror Options Menu# dest {port|none} (Enable mirroring)
```

See the configuration example on [page 104](#).

---

## Viewing ACL Statistics

ACL statistics display how many packets have “hit” (matched) each ACL. Use ACL statistics to check filter performance or to debug the ACL filter configuration.

You must enable statistics for each ACL that you wish to monitor:

```
# /cfg/acl/acl <ACL number>/stats ena
```

---

## ACL Configuration Examples

### ACL Example 1

Use this configuration to block traffic to a specific host. All traffic that ingresses on port EXT1 is denied if it is destined for the host at IP address 100.10.1.1

1. Configure an Access Control List.

```
>> # /cfg/acl/acl 1                                (Define ACL 1)
>> ACL 1# ipv4/dip 100.10.1.1 255.255.255.255
>> Filtering IPv4# ..
>> ACL 1# action deny
```

2. Add ACL 1 to port EXT1.

```
>> ACL 1# /cfg/port ext1/aclqos                      (Select port EXT 1 to assign ACLs)
>> Port EXT1 ACL# add acl 1                          (Assign ACL 1 to the port)
```

3. Apply and save the configuration.

```
>> Port EXT1 ACL# apply
>> Port EXT1 ACL# save
```

### ACL Example 2

Use this configuration to block traffic from a network destined for a specific host address. All traffic that ingresses in port EXT2 with source IP from class 100.10.1.0/24 and destination IP 200.20.2.2 is denied.

1. Configure an Access Control List.

```
>> # /cfg/acl/acl 2                                (Define ACL 2)
>> ACL 2# ipv4/sip 100.10.1.0 255.255.255.0
>> Filtering IPv4# dip 200.20.2.2 255.255.255.255
>> Filtering IPv4# ..
>> ACL 2# action deny
```

2. Add ACL 2 to port EXT2.

```
>> ACL 2# /cfg/port ext2/aclqos                      (Select port EXT2 to assign ACLs)
>> Port EXT2 ACL# add acl 2                          (Assign ACL 2 to the port)
```

3. Apply and save the configuration.

```
>> Port EXT2 ACL# apply
>> Port EXT2 ACL# save
```

### ACL Example 3

Use this configuration to block traffic from a specific IPv6 source address. All traffic that ingresses port EXT2 with source IP from class 2001:0:0:5:0:0:0:2/128 is denied.

1. Configure an Access Control List.

```
>> # /cfg/acl/acl6 3 (Define IPv6 ACL 3)
>> ACL 3# ipv6/sip 2001:0:0:5:0:0:0:2 128
>> Filtering IPv6# ..
>> ACL 3# action deny
```

2. Add ACL 2 to port EXT2.

```
>> ACL 3# /cfg/port ext2/aclqos (Select port EXT2 to assign ACLs)
>> Port EXT2 ACL# add acl6 3 (Assign IPv6 ACL 3 to the port)
```

3. Apply and save the configuration.

```
>> Port EXT2 ACL# apply
>> Port EXT2 ACL# save
```

### ACL Example 4

Use this configuration to deny all ARP packets that ingress a port.

1. Configure an Access Control List.

```
>> # /cfg/acl/acl 2 (Define ACL 2)
>> ACL 2# ethernet
>> Filtering Ethernet# etype ARP
>> Filtering Ethernet# ..
>> ACL 2# action deny
```

2. Add ACL 2 to port EXT2.

```
>> ACL 2# /cfg/port ext2/aclqos (Select port EXT2 to assign ACL)
>> Port EXT2 ACL# add acl 2 (Assign ACL 2 to the port)
```

3. Apply and save the configuration.

```
>> Port EXT2 ACL# apply
>> Port EXT2 ACL# save
```

## ACL Example 5

Use the configuration below to permit access to hosts with destination MAC address that matches 11:05:00:10:00:00 FF:F5:FF:FF:FF:FF and deny access to all other hosts.

### 1. Configure Access Control Lists.

```
>> /cfg/acl/acl 30
>> ACL 30# ethernet
>> Filtering Ethernet# dmac 11:05:00:10:00:00 FF:F5:FF:FF:FF:FF
>> Filtering Ethernet# ..
>> ACL 30# action permit

>> ACL 30# ../acl 100
>> ACL 100# ethernet
>> Filtering Ethernet# dmac 00:00:00:00:00:00 00:00:00:00:00:00
>> Filtering Ethernet# ..
>> ACL 100# action deny
```

### 2. Add ACLs to a port.

```
>> ACL 100# /cfg/port EXT2/aclqos
>> Port EXT2 ACL# add acl 30
>> Port EXT2 ACL# add acl 100
```

### 3. Apply and save the configuration.

```
>> Port EXT2 ACL# apply
>> Port EXT2 ACL# save
```

## ACL Example 6

This configuration blocks traffic from a network that is destined for a specific egress port. All traffic that ingresses port EXT1 from the network 100.10.1.0/24 and is destined for port INT3 is denied.

### 1. Configure an Access Control List.

```
>> # /cfg/acl/acl 4 (Define ACL 4)
>> ACL 4# ipv4/sip 100.10.1.0 255.255.255.0
>> Filtering IPv4# ..
>> ACL 4# egrport int3
>> ACL 4# action deny
```

### 2. Add ACL 4 to port EXT1.

```
>> ACL 4# /cfg/port ext1/aclqos (Select port EXT1 to assign ACLs)
>> Port EXT1 ACL# add acl 4 (Assign ACL 4 to the port)
```

### 3. Apply and save the configuration.

```
>> Port EXT1 ACL# apply
>> Port EXT1 ACL# save
```

---

## VLAN Maps

A VLAN map (VMap) is an ACL that can be assigned to a VLAN or VM group rather than to a switch port as with IPv4 ACLs. This is particularly useful in a virtualized environment where traffic filtering and metering policies must follow virtual machines (VMs) as they migrate between hypervisors.

VMaps are configured from the ACL menu, available with the following CLI command:

```
# /cfg/acl/vmap <VMap ID (1-128)>
```

The GbESM supports up to 128 VMaps.

Individual VMap filters are configured in the same fashion as IPv4 ACLs, except that VLANs cannot be specified as a filtering criteria (unnecessary, since the VMaps are assigned to a specific VLAN or associated with a VM group VLAN).

Once a VMap filter is created, it can be assigned or removed using the following configuration commands:

- For a regular VLAN:

```
/cfg/12/vlan <VLAN ID>/vmap {add|rem} <VMap ID> [intports|extports]
```

- For a VM group (see [“VM Group Types” on page 194](#)):

```
/cfg/virt/vmgroup <ID>/vmap {add|rem} <VMap ID> [intports|extports]
```

**Note:** Each VMap can be assigned to only one VLAN or VM group. However, each VLAN or VM group may have multiple VMaps assigned to it.

When the optional `intports` or `extports` parameter is specified, the action to add or remove the VMap applies for either the internal ports or external ports only. If omitted, the operation will be applied to all ports in the associated VLAN or VM group.

**Note:** VMaps have a lower priority than port-based ACLs. If both an ACL and a VMap match a particular packet, both filter actions will be applied as long as there is no conflict. In the event of a conflict, the port ACL will take priority, though switch statistics will count matches for both the ACL and VMap.

### VMap Example

In this example, EtherType 2 traffic from VLAN 3 internal ports is mirrored to a network monitor on port EXT4.

```
>> Main# /cfg/acl/vmap 21
>> VMAP 21# pktfmt
>> Filtering Packet Format# ethfmt eth2
>> Filtering Packet Format# ..
>> VMAP 21# mirror/port EXT4
>> VMAP 21# mirror/dest port
>> Mirror Options Menu# /cfg/vlan 3
>> VLAN 3# vmap add 21 intports
```



# Part 3: Switch Basics

This section discusses basic switching functions:

- VLANs
- Port Trunking
- Spanning Tree Protocols (Spanning Tree Groups, Rapid Spanning Tree Protocol, and Multiple Spanning Tree Protocol)
- Quality of Service



---

## Chapter 7. VLANs

This chapter describes network design and topology considerations for using Virtual Local Area Networks (VLANs). VLANs are commonly used to split up groups of network users into manageable broadcast domains, to create logical segmentation of workgroups, and to enforce security policies among logical segments. The following topics are discussed in this chapter:

- [“VLANs and Port VLAN ID Numbers” on page 109](#)
- [“VLAN Tagging” on page 111](#)
- [“VLAN Topologies and Design Considerations” on page 115](#)
- [“Protocol-Based VLANs” on page 118](#)
- [“Private VLANs” on page 122](#)

**Note:** Basic VLANs can be configured during initial switch configuration (see “Using the Setup Utility” in the *IBM Networking OS 7.4 Command Reference*). More comprehensive VLAN configuration can be done from the Command Line Interface (see “VLAN Configuration” as well as “Port Configuration” in the *IBM Networking OS 7.4 Command Reference*).

---

## VLANs Overview

Setting up virtual LANs (VLANs) is a way to segment networks to increase network flexibility without changing the physical network topology. With network segmentation, each switch port connects to a segment that is a single broadcast domain. When a switch port is configured to be a member of a VLAN, it is added to a group of ports (workgroup) that belong to one broadcast domain.

Ports are grouped into broadcast domains by assigning them to the same VLAN. Frames received in one VLAN can only be forwarded within that VLAN, and multicast, broadcast, and unknown unicast frames are flooded only to ports in the same VLAN.

The GbESM automatically supports jumbo frames. This default cannot be manually configured or disabled.

The 1/10Gb Uplink ESM (GbESM) supports jumbo frames with a Maximum Transmission Unit (MTU) of 9,216 bytes. Within each frame, 18 bytes are reserved for the Ethernet header and CRC trailer. The remaining space in the frame (up to 9,198 bytes) comprise the packet, which includes the payload of up to 9,000 bytes and any additional overhead, such as 802.1q or VLAN tags. Jumbo frame support is automatic: it is enabled by default, requires no manual configuration, and cannot be manually disabled.

**Note:** Jumbo frames are not supported for traffic sent to switch management interfaces.

---

## VLANs and Port VLAN ID Numbers

### VLAN Numbers

IBM N/OS supports up to 1024 VLANs per switch. Even though the maximum number of VLANs supported at any given time is 1024, each can be identified with any number between 1 and 4095. VLAN 1 is the default VLAN for the external ports and the internal blade ports.

VLAN 4095 is reserved for use by the management network, which includes internal management ports (MGT1 and MGT2) and (by default) internal ports. This configuration allows Serial over LAN (SoL) management—a feature available on certain server blades. Management functions can also be assigned to other VLANs (using the `/cfg/l2/vlan <x>/mgmt ena` command).

Use the following command to view VLAN information:

```
>> /info/l2/vlan
```

VLAN	Name	Status	Ports
1	Default VLAN	ena	INT1-INT14 EXT1-EXTx
4095	Mgmt VLAN	ena	MGT1 MGT2

PVLAN	Protocol	FrameType	EtherType	Priority	Status	Ports
1	2	empty	0000	0	dis	empty

PVLAN	PVLAN-Tagged Ports
none	none

**Note:** The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

## PVID Numbers

Each port in the switch has a configurable default VLAN number, known as its *PVID*. By default, the PVID for all non-management ports is set to 1, which correlates to the default VLAN ID. The PVID for each port can be configured to any VLAN number between 1 and 4094.

Use the following CLI commands to view PVIDs:

- Port information:

```
>> /info/port
```

Alias	Port	Tag	Fast	RMON	Ln	Fld	PVID	NAME	VLAN(s)
INT1	1	y	n	d	e	e	1	INT1	1 4095
INT2	2	y	n	d	e	e	1	INT2	1 4095
INT3	3	y	n	d	e	e	1	INT3	1 4095
INT4	4	y	n	d	e	e	1	INT4	1 4095
INT5	5	y	n	d	e	e	1	INT5	1 4095
INT6	6	y	n	d	e	e	1	INT6	1 4095
INT7	7	y	n	d	e	e	1	INT7	1 4095
INT8	8	y	n	d	e	e	1	INT8	1 4095
INT9	9	y	n	d	e	e	1	INT9	1 4095
INT10	10	y	n	d	e	e	1	INT10	1 4095
INT11	11	y	n	d	e	e	1	INT11	1 4095
INT12	12	y	n	d	e	e	1	INT12	1 4095
ISL1	13	n	n	d	e	e	1	ISL1	1
ISL2	14	n	n	d	e	e	1	ISL2	1
MGT1	15	y	n	d	e	e	4095*	MGT1	4095
MGT2	16	y	n	d	e	e	4095*	MGT2	4095
EXT1	17	n	n	d	e	e	1	EXT1	1
EXT2	18	n	n	d	e	e	1	EXT2	1
EXT3	19	n	n	d	e	e	1	EXT3	1
...									

\* = PVID is tagged.

**Note:** The sample output that appears in this document might differ slightly from that displayed by your system. Output varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

- Port Configuration:

```
>> /cfg/port INT7/pvid 7
Current port VLAN ID: 1
New pending port VLAN ID: 7
```

Each port on the switch can belong to one or more VLANs, and each VLAN can have any number of switch ports in its membership. Any port that belongs to multiple VLANs, however, must have VLAN *tagging* enabled (see [“VLAN Tagging” on page 111](#)).

---

## VLAN Tagging

N/OS software supports 802.1Q VLAN *tagging*, providing standards-based VLAN support for Ethernet systems.

Tagging places the VLAN identifier in the frame header of a packet, allowing each port to belong to multiple VLANs. When you add a port to multiple VLANs, you also must enable tagging on that port.


Since tagging fundamentally changes the format of frames transmitted on a tagged port, you must carefully plan network designs to prevent tagged frames from being transmitted to devices that do not support 802.1Q VLAN tags, or devices where tagging is not enabled.

Important terms used with the 802.1Q tagging feature are:

- VLAN identifier (VID)—the 12-bit portion of the VLAN tag in the frame header that identifies an explicit VLAN.
- Port VLAN identifier (PVID)—a classification mechanism that associates a port with a specific VLAN. For example, a port with a PVID of 3 (PVID =3) assigns all untagged frames received on this port to VLAN 3. Any untagged frames received by the switch are classified with the PVID of the receiving port.
- Tagged frame—a frame that carries VLAN tagging information in the header. This VLAN tagging information is a 32-bit field (VLAN tag) in the frame header that identifies the frame as belonging to a specific VLAN. Untagged frames are marked (tagged) with this classification as they leave the switch through a port that is configured as a tagged port.
- Untagged frame—a frame that does not carry any VLAN tagging information in the frame header.
- Untagged member—a port that has been configured as an untagged member of a specific VLAN. When an untagged frame exits the switch through an untagged member port, the frame header remains unchanged. When a tagged frame exits the switch through an untagged member port, the tag is stripped and the tagged frame is changed to an untagged frame.
- Tagged member—a port that has been configured as a tagged member of a specific VLAN. When an untagged frame exits the switch through a tagged member port, the frame header is modified to include the 32-bit tag associated with the PVID. When a tagged frame exits the switch through a tagged member port, the frame header remains unchanged (original VID remains).

**Note:** If a 802.1Q tagged frame is received by a port that has VLAN-tagging disabled, then the frame is dropped at the ingress port.

Figure 3. Default VLAN settings



**Note:** The port numbers specified in these illustrations may not directly correspond to the physical port configuration of your switch model.


When a VLAN is configured, ports are added as members of the VLAN, and the ports are defined as either *tagged* or *untagged* (see [Figure 4](#) through [Figure 7](#)).

The default configuration settings for GbESMs have all ports set as untagged members of VLAN 1 with all ports configured as PVID = 1. In the default configuration example shown in [Figure 3](#), all incoming packets are assigned to VLAN 1 by the default port VLAN identifier (PVID = 1).

[Figure 4](#) through [Figure 7](#) illustrate generic examples of VLAN tagging. In [Figure 4](#), untagged incoming packets are assigned directly to VLAN 2 (PVID = 2). Port 5 is configured as a *tagged* member of VLAN 2, and port 7 is configured as an *untagged* member of VLAN 2.

**Note:** The port assignments in the following figures are general examples and are not meant to match any specific GbESM.


Figure 4. Port-based VLAN assignment





As shown in Figure 5, the untagged packet is marked (tagged) as it leaves the switch through port 5, which is configured as a tagged member of VLAN 2. The untagged packet remains unchanged as it leaves the switch through port 7, which is configured as an untagged member of VLAN 2.


Figure 5. 802.1Q tagging (after port-based VLAN assignment)



BS45012A

In Figure 6, tagged incoming packets are assigned directly to VLAN 2 because of the tag assignment in the packet. Port 5 is configured as a *tagged* member of VLAN 2, and port 7 is configured as an *untagged* member of VLAN 2.


Figure 6. 802.1Q tag assignment



BS45013A

As shown in Figure 7, the tagged packet remains unchanged as it leaves the switch through port 5, which is configured as a tagged member of VLAN 2. However, the tagged packet is stripped (untagged) as it leaves the switch through port 7, which is configured as an untagged member of VLAN 2.

Figure 7. 802.1Q tagging (after 802.1Q tag assignment)



**Note:** Set the configuration to factory default (/boot/conf factory) to reset all non-management ports to VLAN 1.

---

## VLAN Topologies and Design Considerations

- By default, the N/OS software is configured so that tagging is disabled on all external ports, and enabled on all internal ports.
- By default, the N/OS software is configured so that all internal ports are members of VLAN 1. Internal ports are also members of VLAN 4095 (the default management VLAN) to allow Serial over LAN (SoL) management, a feature of certain server blades.
- By default, the N/OS software is configured so that the management ports (MGT1 and MGT2) are members of the default management VLAN 4095.
- Multiple management VLANs can be configured on the switch, in addition to the default VLAN 4095, using the `/cfg/12/vlan <x>/mgmt ena` command.
- When using Spanning Tree, STG 2-128 may contain only one VLAN unless Multiple Spanning-Tree Protocol (MSTP) mode is used. With MSTP mode, STG 1 to 32 can include multiple VLANs.


### VLAN Configuration Rules

VLANs operate according to specific configuration rules. When creating VLANs, consider the following rules that determine how the configured VLAN reacts in any network topology:

- All ports involved in trunking and port mirroring must have the same VLAN configuration. If a port is on a trunk with a mirroring port, the VLAN configuration cannot be changed. For more information trunk groups, see [“Configuring a Static Port Trunk” on page 130](#).
- All ports that are involved in port mirroring must have memberships in the same VLANs. If a port is configured for port mirroring, the port’s VLAN membership cannot be changed. For more information on configuring port mirroring, see [“Port Mirroring” on page 413](#).
- Management VLANs must contain the management ports (MGT1 and MGT2), and can include one or more internal ports (INT<sub>x</sub>). External ports (EXT<sub>x</sub>) cannot be members of any management VLAN.

## Example: Multiple VLANs with Tagging Adapters

Figure 8. Multiple VLANs with VLAN-Tagged Gigabit Adapters



The features of this VLAN are described below:

Component	Description
GbE Switch Module	This switch is configured for three VLANs that represent three different IP subnets. Two servers and five clients are attached to the switch.
Server #1	This server is a member of VLAN 3 and has presence in only one IP subnet. The associated internal switch port is only a member of VLAN 3, so tagging is disabled.
Server #2	This high-use server needs to be accessed from all VLANs and IP subnets. The server has a VLAN-tagging adapter installed with VLAN tagging turned on. The adapter is attached to one of the internal switch ports, that is a member of VLANs 1, 2, and 3, and has tagging enabled. Because of the VLAN tagging capabilities of both the adapter and the switch, the server is able to communicate on all three IP subnets in this network. Broadcast separation between all three VLANs and subnets, however, is maintained.
PCs #1 and #2	These PCs are attached to a shared media hub that is then connected to the switch. They belong to VLAN 2 and are logically in the same IP subnet as Server 2 and PC 5. The associated external switch port has tagging disabled.
PC #3	A member of VLAN 1, this PC can only communicate with Server 2 and PC 5. The associated external switch port has tagging disabled.

Component	Description (continued)
PC #4	A member of VLAN 3, this PC can only communicate with Server 1 and Server 2. The associated external switch port has tagging disabled.
PC #5	A member of both VLAN 1 and VLAN 2, this PC has a VLAN-tagging Gigabit Ethernet adapter installed. It can communicate with Server 2 and PC 3 via VLAN 1, and to Server 2, PC 1 and PC 2 via VLAN 2. The associated external switch port is a member of VLAN 1 and VLAN 2, and has tagging enabled.

**Note:** VLAN tagging is required only on ports that are connected to other GbESMs or on ports that connect to tag-capable end-stations, such as servers with VLAN-tagging adapters.

---

## Protocol-Based VLANs

Protocol-based VLANs (PVLANS) allow you to segment network traffic according to the network protocols in use. Traffic for supported network protocols can be confined to a particular port-based VLAN. You can give different priority levels to traffic generated by different network protocols.

With PVLAN, the switch classifies incoming packets by Ethernet protocol of the packets, not by the configuration of the ingress port. When an untagged or priority-tagged frame arrives at an ingress port, the protocol information carried in the frame is used to determine a VLAN to which the frame belongs. If a frame's protocol is not recognized as a pre-defined PVLAN type, the ingress port's PVID is assigned to the frame. When a tagged frame arrives, the VLAN ID in the frame's tag is used.

Each VLAN can contain up to eight different PVLANS. You can configure separate PVLANS on different VLANs, with each PVLAN segmenting traffic for the same protocol type. For example, you can configure PVLAN 1 on VLAN 2 to segment IPv4 traffic, and PVLAN 8 on VLAN 100 to segment IPv4 traffic.

To define a PVLAN on a VLAN, configure a PVLAN number (1-8) and specify the frame type and the Ethernet type of the PVLAN protocol. You must assign at least one port to the PVLAN before it can function. Define the PVLAN frame type and Ethernet type as follows:

- Frame type—consists of one of the following values:
  - Ether2 (Ethernet II)
  - SNAP (Subnetwork Access Protocol)
  - LLC (Logical Link Control)
- Ethernet type—consists of a 4-digit (16 bit) hex value that defines the Ethernet type. You can use common Ethernet protocol values, or define your own values. Following are examples of common Ethernet protocol values:
  - IPv4 = 0800
  - IPv6 = 86dd
  - ARP = 0806

## Port-Based vs. Protocol-Based VLANs

Each VLAN supports both port-based and protocol-based association, as follows:

- The default VLAN configuration is port-based. All data ports are members of VLAN 1, with no PVLAN association.
- When you add ports to a PVLAN, the ports become members of both the port-based VLAN and the PVLAN. For example, if you add port EXT1 to PVLAN 1 on VLAN 2, the port also becomes a member of VLAN 2.
- When you delete a PVLAN, its member ports remain members of the port-based VLAN. For example, if you delete PVLAN 1 from VLAN 2, port EXT1 remains a member of VLAN 2.
- When you delete a port from a VLAN, the port is deleted from all corresponding PVLANS.

## PVLAN Priority Levels

You can assign each PVLAN a priority value of 0-7, used for Quality of Service (QoS). PVLAN priority takes precedence over a port's configured priority level. If no priority level is configured for the PVLAN (priority = 0), each port's priority is used (if configured).

All member ports of a PVLAN have the same PVLAN priority level.

## PVLAN Tagging

When PVLAN tagging is enabled, the switch tags frames that match the PVLAN protocol. For more information about tagging, see ["VLAN Tagging" on page 111](#).

Untagged ports must have PVLAN tagging disabled. Tagged ports can have PVLAN tagging either enabled or disabled.

PVLAN tagging has higher precedence than port-based tagging. If a port is tag enabled (`/cfg/port <x>/tag`), and the port is a member of a PVLAN, the PVLAN tags egress frames that match the PVLAN protocol.

Use the tag list command (`/cfg/l2/vlan <x>/pvlan <x>/taglist`) to define the complete list of tag-enabled ports in the PVLAN. Note that all ports not included in the PVLAN tag list will have PVLAN tagging disabled.

## PVLAN Configuration Guidelines

Consider the following guidelines when you configure protocol-based VLANs:

- Each port can support up to 16 VLAN protocols.
- The GbESM can support up to 16 protocols simultaneously.
- Each PVLAN must have at least one port assigned before it can be activated.
- The same port within a port-based VLAN can belong to multiple PVLANs.
- An untagged port can be a member of multiple PVLANs.
- A port cannot be a member of different VLANs with the same protocol association.

## Configuring PVLAN

Follow this procedure to configure a Protocol-based VLAN (PVLAN).

1. Create a VLAN and define the protocol type(s) supported by the VLAN.

```
>> /cfg/12/vlan 2                               (Select VLAN 2)
>> VLAN 2# ena                                   (enable VLAN 2)
Current status: disabled
New status:    enabled
>> VLAN 2# pvlan
Enter protocol number [1-8]: 1                   (Select a protocol number)
>> VLAN 2 Protocol 1# pty
Current FrameType: empty; EtherType: empty
Enter new frame type(Ether2/SNAP/LLC): ether2(Define the frame type)
Enter new Ether type: 0800                       (Define the Ethernet type)
New pending FrameType: Ether2; EtherType: 0800
```

2. Configure the priority value for the protocol.

```
>> VLAN 2 Protocol 1# prio 1                     (Configure the priority value)
```

3. Add member ports for this PVLAN.

```
>> VLAN 2 Protocol 1# add int1
Port INT1 is an UNTAGGED port and its current PVID is 1.
Confirm changing PVID from 1 to 2 [y/n]: y
Current ports for VLAN 2:    empty
Current ports for VLAN 1, Protocol 3:    empty
Pending new ports for VLAN 2:    INT1
Pending new ports for VLAN 2, Protocol 1:    INT1

>> VLAN 2 Protocol 1# add ext1
Port EXT1 is an UNTAGGED port and its current PVID is 1.
Confirm changing PVID from 1 to 2 [y/n]: y
Current ports for VLAN 2:    empty
Current ports for VLAN 1, Protocol 2:    empty
Pending new ports for VLAN 2:    INT1 EXT1
Pending new ports for VLAN 2, Protocol 1:    INT1 EXT1
```

**Note:** If VLAN tagging is turned on and the port being added to the VLAN has a different default VLAN (PVID), you will be asked to confirm changing the PVID to the current VLAN, as shown in the example.



#### 4. Configure VLAN tagging for ports.

```
>> VLAN 2 Protocol 1# /cfg/port int1/tag ena (Enable tagging on port)
Current VLAN tag support: disabled
New VLAN tag support:    enabled
Port INT1 changed to tagged.

>> Port INT1# /cfg/12/vlan 2/pvlan 1/tagpv1 (Enable PVLAN tagging)
Enter port to be tagged:    int1
Ena/Dis pvlan tag:         ena
Current status: disabled
New status:    enabled
WARN: Tagging status of Port 1 in VLAN 2 will be changed for
      all protocols.
Confirm changing port's pvlan tagging status [y/n]: y
```

#### 5. Enable the PVLAN.

```
>> VLAN 2 Protocol 1# ena (Enable protocol-based VLAN)
Current status: disabled
New status:    enabled
>> VLAN 2 Protocol 1# apply (Apply the configuration)
>> VLAN 2 Protocol 1# save (Save your changes)
```

#### 6. Verify PVLAN operation.

---

## Private VLANs

Private VLANs provide Layer 2 isolation between the ports within the same broadcast domain. Private VLANs can control traffic within a VLAN domain, and provide port-based security for host servers.

Use Private VLANs to partition a VLAN domain into sub-domains. Each sub-domain is comprised of one primary VLAN and one secondary VLAN, as follows:

- **Primary VLAN**—carries unidirectional traffic downstream from promiscuous ports. Each Private VLAN has only one primary VLAN. All ports in the Private VLAN are members of the primary VLAN.
- **Secondary VLAN**—Secondary VLANs are internal to a private VLAN domain, and are defined as follows:
  - **Isolated VLAN**—carries unidirectional traffic upstream from the host servers toward ports in the primary VLAN and the gateway. Each Private VLAN can contain only one Isolated VLAN.
  - **Community VLAN**—carries upstream traffic from ports in the community VLAN to other ports in the same community, and to ports in the primary VLAN and the gateway. Each Private VLAN can contain multiple community VLANs.

After you define the primary VLAN and one or more secondary VLANs, you map the secondary VLAN(s) to the primary VLAN.

## Private VLAN Ports

Private VLAN ports are defined as follows:

- **Promiscuous**—A promiscuous port is an external port that belongs to the primary VLAN. The promiscuous port can communicate with all the interfaces, including ports in the secondary VLANs (Isolated VLAN and Community VLANs). Each promiscuous port can belong to only one Private VLAN.
- **Isolated**—An isolated port is a host port that belongs to an isolated VLAN. Each isolated port has complete layer 2 separation from other ports within the same private VLAN (including other isolated ports), except for the promiscuous ports.
  - Traffic sent to an isolated port is blocked by the Private VLAN, except the traffic from promiscuous ports.
  - Traffic received from an isolated port is forwarded only to promiscuous ports.
- **Community**—A community port is a host port that belongs to a community VLAN. Community ports can communicate with other ports in the same community VLAN, and with promiscuous ports. These interfaces are isolated at layer 2 from all other interfaces in other communities and from isolated ports within the Private VLAN.

Only external ports are promiscuous ports. Only internal ports may be isolated or community ports.

## Configuration Guidelines

The following guidelines apply when configuring Private VLANs:

- Management VLANs cannot be Private VLANs. Management ports (MGT1 and MGT2) cannot be members of a Private VLAN.
- The default VLAN 1 cannot be a Private VLAN.
- Protocol-based VLANs must be disabled when you use Private VLANs.
- IGMP Snooping must be disabled on isolated VLANs.
- Each secondary port's (isolated port and community ports) PVID must match its corresponding secondary VLAN ID.
- Private VLAN ports cannot be members of a trunk group. Link Aggregation Control Protocol (LACP) must be turned off on ports within a Private VLAN.
- Ports within a secondary VLAN cannot be members of other VLANs.
- All VLANs that comprise the Private VLAN must belong to the same Spanning Tree Group.
- Blade servers connected to internal ports (secondary VLAN ports) must be configured to tag packets with the primary VLAN number.

## Configuration Example

Follow this procedure to configure a Private VLAN.

1. Select a VLAN and define the Private VLAN type as primary.

```
>> /cfg/12/vlan 100 (Select VLAN 100)
>> VLAN 100# privlan/type primary (Define the Private VLAN type)
Current Private-VLAN type:
Pending Private-VLAN type: primary
>> privlan# ena
```

2. Configure a secondary VLAN and map it to the primary VLAN.

```
>> /cfg/12/vlan 110 (Select VLAN 110)
>> VLAN 110# privlan/type isolated (Define the Private VLAN type)
Current Private-VLAN type:
Pending Private-VLAN type: isolated
>> privlan# map 100 (Map to the primary VLAN)
Vlan 110 is mapped to the primary vlan 100.
Vlan 110 port(s) will be added to vlan 100.
>> privlan# ena
>> privlan# apply (Apply the configuration)
>> privlan# save (Save your changes)
```



---

## Chapter 8. Ports and Trunking

Trunk groups can provide super-bandwidth, multi-link connections between the 1/10Gb Uplink ESM (GbESM) and other trunk-capable devices. A trunk group is a group of ports that act together, combining their bandwidth to create a single, larger virtual link. This chapter provides configuration background and examples for trunking multiple ports together:

- [“Trunking Overview” on page 126](#)
- [“Static Trunks” on page 127](#)
- [“Link Aggregation Control Protocol” on page 132](#)
- [“Configurable Trunk Hash Algorithm” on page 135](#)


---

## Trunking Overview

When using port trunk groups between two switches, as shown in [Figure 9](#), you can create a virtual link between them, operating with combined throughput levels that depends on how many physical ports are included.

Two trunk types are available: static trunk groups (portchannel), and dynamic LACP trunk groups. Up to 16 trunks of each type are supported in stand-alone (non-stacking) mode, and 64 trunks of each type are supported in stacking mode, depending of the number and type of available ports. Each trunk can include up to 8 member ports.

Figure 9. Port Trunk Group



Trunk groups are also useful for connecting a GbESM to third-party devices that support link aggregation, such as Cisco routers and switches with EtherChannel technology (*not* ISL trunking technology) and Sun's Quad Fast Ethernet Adapter. Trunk Group technology is compatible with these devices when they are configured manually.

Trunk traffic is statistically distributed among the ports in a trunk group, based on a variety of configurable options.

Also, since each trunk group is comprised of multiple physical links, the trunk group is inherently fault tolerant. As long as one connection between the switches is available, the trunk remains active and statistical load balancing is maintained whenever a port in a trunk group is lost or returned to service.

---

## Static Trunks

### Static Trunk Requirements

When you create and enable a static trunk, the trunk members (switch ports) take on certain settings necessary for correct operation of the trunking feature.

Before you configure your trunk, you must consider these settings, along with specific configuration rules, as follows:

1. Read the configuration rules provided in the section, [“Static Trunk Group Configuration Rules” on page 129.](#)
2. Determine which switch ports are to become *trunk members* (the specific ports making up the trunk).
3. Ensure that the chosen switch ports are set to `enabled`, using the `/cfg/port` command. Trunk member ports must have the same VLAN configuration.
4. Consider how the existing Spanning Tree will react to the new trunk configuration. See [“Spanning Tree Protocols” on page 137](#) for configuration guidelines.
5. Consider how existing VLANs will be affected by the addition of a trunk.

### Inter-Switch Link

When the GbESM resides in a BladeCenter HT chassis (BCHT), internal port 13 (ISL1) and internal port 14 (ISL2) are statically-configured as members of Trunk Group 16. These ports can provide an Inter-Switch Link (ISL) between two GbESMs in the chassis. The ISL provides fixed links between switch modules.

The ISL trunk configuration is as follows:

```
Bay 1 GbESM ISL1 connects to Bay 2 GbESMISL1
Bay 1 GbESM ISL2 connects to Bay 2 GbESMISL2

Bay 3 GbESM ISL1 connects to Bay 4 GbESMISL1
Bay 3 GbESM ISL2 connects to Bay 4 GbESMISL2
```

By default, the ISL ports are `disabled`. When these ports are enabled, they are automatically included in the ISL Trunk Group, which is enabled by default, and cannot be disabled or deleted. You can add up to 6 external ports to each ISL trunk (for a total of up to 8 ports), but no other internal ports can be added.

When the ISL option is detected, the GbESM includes the ISL ports in its configuration and status menus. For example:

```
>> /info/port
```

Alias	Port	Tag	Fast	Lrn	Fld	PVID	NAME	VLAN(s)
INT1	1	y	n	e	e	1	INT1	1 4095
INT2	2	y	n	e	e	1	INT2	1 4095
...								
INT11	11	y	n	e	e	1	INT11	1 4095
INT12	12	y	n	e	e	1	INT12	1 4095
ISL1	13	y	n	e	e	1	ISL1	1
ISL2	14	y	n	e	e	1	ISL2	1
MGT1	15	y	n	e	e	4095*	MGT	4095
MGT2	16	y	n	e	e	4095*	MGT	4095
EXT1	17	n	n	e	e	1	EXT1	1
...								

The trunk information command displays information about the ISL trunk, as follows:

```
>> # /info/12/trunk
Trunk group 11: Enabled
Protocol - Static
port state:
  ISL1: STG 1 DOWN
Reminder: Port 13 needs to be enabled.
  ISL2: STG 1 DOWN
Reminder: Port 14 needs to be enabled.
```



## Static Trunk Group Configuration Rules


The trunking feature operates according to specific configuration rules. When creating trunks, consider the following rules that determine how a trunk group reacts in any network topology:

- All trunks must originate from one network entity (a single device, or multiple devices acting in a stack) and lead to one destination entity. For example, you cannot combine links from two different servers into one trunk group.
- Ports from different member switches in the same stack (see [“Stacking” on page 171](#)) may be aggregated together in one trunk.
- Any physical switch port can belong to only one trunk group.
- Depending on port availability, the switch supports up to 8 ports in each trunk group.
- Internal (INT<sub>x</sub>) and external ports (EXT<sub>x</sub>) cannot become members of the same trunk group.
- Trunking from third-party devices must comply with Cisco® EtherChannel® technology.
- All trunk member ports must be assigned to the same VLAN configuration before the trunk can be enabled.
- If you change the VLAN settings of any trunk member, you cannot apply the change until you change the VLAN settings of all trunk members.
- When an active port is configured in a trunk, the port becomes a *trunk member* when you enable the trunk using the following command (`/cfg/12/trunk <x>/ena`). The Spanning Tree parameters for the port then change to reflect the new trunk settings.
- All trunk members must be in the same Spanning Tree Group (STG) and can belong to only one Spanning Tree Group (STG). However if all ports are *tagged*, then all trunk ports can belong to multiple STGs.
- If you change the Spanning Tree participation of any trunk member to *enabled* or *disabled*, the Spanning Tree participation of all members of that trunk changes similarly.
- When a trunk is enabled, the trunk Spanning Tree participation setting takes precedence over that of any trunk member.
- 802.1X authentication is not supported on ISL ports or on any port that is part of a trunk.
- You cannot configure a trunk member as a monitor port in a port-mirroring configuration.
- Trunks cannot be monitored by a monitor port; however, trunk members can be monitored.
- All ports in static trunks must have the same link configuration (speed, duplex, flow control).

## Configuring a Static Port Trunk

In the example below, three ports are trunked between two switches.

Figure 10. Port Trunk Group Configuration Example



Prior to configuring each switch in the above example, you must connect to the appropriate switch's Command Line Interface (CLI) as the administrator.

**Note:** For details about accessing and using any of the menu commands described in this example, see the IBM Networking OS *Command Reference*.

1. Connect the switch ports that will be members in the trunk group.
2. Configure the trunk using these steps on the GbESM:
  - a. Define a trunk group.

```
>> # /cfg/12/trunk 1                (Select trunk group 1)
>> Trunk group 1# add EXT1           (Add port EXT1 to trunk group 1)
>> Trunk group 1# add EXT2           (Add port EXT2 to trunk group 1)
>> Trunk group 1# add EXT3           (Add port EXT3 to trunk group 1)
>> Trunk group 1# ena                (Enable trunk group 1)
```

- b. Apply and verify the configuration.

```
>> Trunk group 1# apply              (Make your changes active)
>> Trunk group 1# cur                (View current trunking configuration)
```

Examine the resulting information. If any settings are incorrect, make appropriate changes.

- c. Save your new configuration changes.

```
>> Trunk group 1# save               (Save for restore after reboot)
```

3. Repeat the process on the other switch.

```
>> # /cfg/12/trunk 3                (Select trunk group 3)
>> Trunk group 3# add 2              (Add port 2 to trunk group 3)
>> Trunk group 3# add 12             (Add port 12 to trunk group 3)
>> Trunk group 3# add 22             (Add port 22 to trunk group 3)
>> Trunk group 3# ena                (Enable trunk group 3)
>> Trunk group 3# apply              (Make your changes active)
>> Trunk group 3# cur                 (View current trunking configuration)
>> Trunk group 3# save                (Save for restore after reboot)
```

Trunk group 1 (on the GbESM) is now connected to trunk group 3 on the Application Switch.

**Note:** In this example, a GbESM and an application switch are used. If a third-party device supporting link aggregation is used (such as Cisco routers and switches with EtherChannel technology or Sun's Quad Fast Ethernet Adapter), trunk groups on the third-party device should be configured manually. Connection problems could arise when using automatic trunk group negotiation on the third-party device.

4. Examine the trunking information on each switch.

```
>> # /info/12/trunk                  (View trunking information)
```

Information about each port in each configured trunk group is displayed. Make sure that trunk groups consist of the expected ports and that each port is in the expected state.

---

## Link Aggregation Control Protocol

### LACP Overview

Link Aggregation Control Protocol (LACP) is an IEEE 802.3ad standard for grouping several physical ports into one logical port (known as a dynamic trunk group or Link Aggregation group) with any device that supports the standard. Please refer to IEEE 802.3ad-2002 for a full description of the standard.

IEEE 802.3ad allows standard Ethernet links to form a single Layer 2 link using the Link Aggregation Control Protocol (LACP). Link aggregation is a method of grouping physical link segments of the same media type and speed in full duplex, and treating them as if they were part of a single, logical link segment. If a link in a LACP trunk group fails, traffic is reassigned dynamically to the remaining link or links of the dynamic trunk group.

The GbESM supports up to 16 LACP trunks, each with up to 8 ports.

**Note:** LACP implementation in IBM N/OS does not support the Churn machine, an option used to detect if the port is operable within a bounded time period between the actor and the partner. Only the Marker Responder is implemented, and there is no marker protocol generator.

A port's Link Aggregation Identifier (LAG ID) determines how the port can be aggregated. The Link Aggregation ID (LAG ID) is constructed mainly from the *system ID* and the port's *admin key*, as follows:

- **System ID:** an integer value based on the switch's MAC address and the system priority assigned in the CLI.
- **Admin key:** a port's Admin key is an integer value (1 - 65535) that you can configure in the CLI. Each GbESM port that participates in the same LACP trunk group must have the same *admin key* value. The Admin key is *local significant*, which means the partner switch does not need to use the same Admin key value.

For example, consider two switches, an Actor (the GbESM) and a Partner (another switch), as shown in [Table 12](#).

*Table 12. Actor vs. Partner LACP configuration*

Actor Switch	Partner Switch 1
Port EXT1 (admin key = 100)	Port 1 (admin key = 50)
Port EXT2 (admin key = 100)	Port 2 (admin key = 50)

In the configuration shown in [Table 12](#), Actor switch ports EXT1 and EXT2 aggregate to form an LACP trunk group with Partner switch ports 1 and 2.

LACP automatically determines which member links can be aggregated and then aggregates them. It provides for the controlled addition and removal of physical links for the link aggregation.

Each port in the GbESM can have one of the following LACP modes.

- `off` (default)  
The user can configure this port in to a regular static trunk group.
- `active`  
The port is capable of forming an LACP trunk. This port sends LACPDU packets to partner system ports.
- `passive`  
The port is capable of forming an LACP trunk. This port only responds to the LACPDU packets sent from an LACP *active* port.

Each active LACP port transmits LACP data units (LACPDUs), while each passive LACP port listens for LACPDUs. During LACP negotiation, the admin key is exchanged. The LACP trunk group is enabled as long as the information matches at both ends of the link. If the admin key value changes for a port at either end of the link, that port's association with the LACP trunk group is lost.

When the system is initialized, all ports by default are in LACP *off* mode and are assigned unique *admin keys*. To make a group of ports aggregatable, you assign them all the same *admin key*. You must set the port's LACP mode to *active* to activate LACP negotiation. You can set other port's LACP mode to *passive*, to reduce the amount of LACPDU traffic at the initial trunk-forming stage.

Use the `/info/12/trunk` command or the `/info/12/lacp/dump` command to check whether the ports are trunked. Static trunks are listed as trunks 1 through 16. Dynamic trunks are listed as 17 through 32.

## LACP Minimum Links Option

For dynamic trunks that require a guaranteed amount of bandwidth in order to be considered useful, you can specify the minimum number of links for the trunk. If the specified minimum number of ports are not available, the trunk link will not be established. If an active LACP trunk loses one or more component links, the trunk will be placed in the down state if the number of links falls below the specified minimum. By default, the minimum number of links is 1, meaning that LACP trunks will remain operational as long as at least one link is available.

The LACP minimum links setting can be configured as follows:

```
> # /cfg/12/lacp/port <port number or range> /minlinks <minimum links>
```

## Configuring LACP

Use the following procedure to configure LACP for port EXT1 and port EXT2 to participate in link aggregation.

1. Set the LACP mode on port EXT1.

>> # /cfg/12/lacp/port EXT1	<i>(Select port EXT1)</i>
>> LACP port EXT1# mode active	<i>(Set port EXT1 to LACP active mode)</i>

2. Define the admin key on port EXT1. Only ports with the same admin key can form a LACP trunk group.

>> LACP port EXT1# adminkey 100	<i>(Set port EXT1 adminkey to 100)</i>
Current LACP port adminkey: 17	
New pending LACP port adminkey: 100	

3. Set the LACP mode on port EXT2.

>> # /cfg/12/lacp/port EXT2	<i>(Select port EXT2)</i>
>> LACP port EXT2# mode active	<i>(Set port EXT2 to LACP active mode)</i>

4. Define the admin key on port EXT2.

>> LACP port EXT2# adminkey 100	<i>(Set port EXT2 adminkey to 100)</i>
Current LACP port adminkey: 18	
New pending LACP port adminkey: 100	

5. Apply and verify the configuration.

>> LACP port EXT2# apply	<i>(Make your changes active)</i>
>> LACP port EXT2# cur	<i>(View current trunking configuration)</i>

6. Save your new configuration changes.

>> LACP port EXT2# save	<i>(Save for restore after reboot)</i>
-------------------------	--

---

## Configurable Trunk Hash Algorithm

Traffic in a trunk group is statistically distributed among member ports using a *hash* process where various address and attribute bits from each transmitted frame are recombined to specify the particular trunk port the frame will use.

The switch can be configured to use a variety of hashing options. To achieve the most even traffic distribution, select options that exhibit a wide range of values for your particular network. Avoid hashing on information that is not usually present in the expected traffic, or which does not vary.

The GbESM supports the following hashing options, which can be used in any combination:

- Frame MAC and IP information. One of the following combinations is required:
  - Source MAC address (*smac*)

```
>> # /cfg/l2/thash/l2hash/smac {enable|disable}
```

- Destination MAC address (*dmac*)

```
>> # /cfg/l2/thash/l2hash/dmac {enable|disable}
```

- Both source and destination MAC address
  - IPv4/IPv6 source IP address (*sip*)

```
>> # /cfg/l2/thash/l3hash/sip {enable|disable}
```

- IPv4/IPv6 destination IP address (*dip*)

```
>> # /cfg/l2/thash/l3hash/dip {enable|disable}
```

- Both source and destination IPv4/IPv6 address (enabled by default)

**Note:** Layer 2 options and Layer 3 options are mutually exclusive. To use Layer 2 *smac* and *dmac* options, Layer 3 *sip* and *dip* options must be disabled prior to applying the configuration. Likewise, to use Layer 3 options, Layer 2 options must be disabled.

- Ingress port number (disabled by default)

```
>> # /cfg/l2/thash/ingress {enable|disable}
```

- Layer 4 port information (disabled by default)

```
>> # /cfg/l2/thash/L4port {enable|disable}
```

When enabled, Layer 4 port information (TCP, UDP, etc.) is added to the hash if available. The *L4port* option is ignored when Layer 4 information is not included in the packet (such as for Layer 2 packets).





---

## Chapter 9. Spanning Tree Protocols

When multiple paths exist between two points on a network, Spanning Tree Protocol (STP), or one of its enhanced variants, can prevent broadcast loops and ensure that the 1/10Gb Uplink ESM (GbESM) uses only the most efficient network path.

This chapter covers the following topics:

- [“Spanning Tree Protocol Modes” on page 138](#)
- [“Global STP Control” on page 138](#)
- [“PVSRT Mode” on page 139](#)
- [“Rapid Spanning Tree Protocol” on page 150](#)
- [“Multiple Spanning Tree Protocol” on page 152](#)
- [“Port Type and Link Type” on page 156](#)

---

## Spanning Tree Protocol Modes

IBM Networking OS 7.4 supports the following STP modes:

- Rapid Spanning Tree Protocol (RSTP)

IEEE 802.1D (2004) RSTP allows devices to detect and eliminate logical loops in a bridged or switched network. When multiple paths exist, STP configures the network so that only the most efficient path is used. If that path fails, STP automatically configures the best alternative active path on the network in order to sustain network operations. RSTP is an enhanced version of IEEE 802.1D (1998) STP, providing more rapid convergence of the Spanning Tree network path states on STG 1.

See [“Rapid Spanning Tree Protocol” on page 150](#) for details.

- Per-VLAN Rapid Spanning Tree (PVRST)

PVRST mode is based on RSTP to provide rapid Spanning Tree convergence, but supports instances of Spanning Tree, allowing one STG per VLAN. PVRST mode is compatible with Cisco R-PVST/R-PVST+ mode.

PVRST is the default Spanning Tree mode on the GbESM. See [“PVSRT Mode” on page 139](#) for details.

- Multiple Spanning Tree Protocol (MSTP)

IEEE 802.1Q (2003) MSTP provides both rapid convergence and load balancing in a VLAN environment. MSTP allows multiple STGs, with multiple VLANs in each.

MSTP is supported in stand-alone (non-stacking) mode only.

See [“Multiple Spanning Tree Protocol” on page 152](#) for details.

---

## Global STP Control

By default, the Spanning Tree feature is globally enabled on the switch, and is set for PVRST mode. Spanning Tree (and thus any currently configured STP mode) can be globally disabled or re-enabled using the following commands:

>> # /cfg/12/nostp enable	<i>(Globally disable Spanning Tree)</i>
>> # /cfg/12/nostp disable	<i>(Globally enable Spanning Tree)</i>

---

## PVSRT Mode

**Note:** Per-VLAN Rapid Spanning Tree (PVRST) is enabled by default on the GbESM.

Using STP, network devices detect and eliminate logical loops in a bridged or switched network. When multiple paths exist, Spanning Tree configures the network so that a switch uses only the most efficient path. If that path fails, Spanning Tree automatically sets up another active path on the network to sustain network operations.

IBM N/OS PVRST mode is based on IEEE 802.1w RSTP. Like RSTP, PVRST mode provides rapid Spanning Tree convergence. However, PVRST mode is enhanced for multiple instances of Spanning Tree. In PVRST mode, each VLAN may be automatically or manually assigned to one of 127 available STGs, with each STG acting as an independent, simultaneous instance of STP. PVRST uses IEEE 802.1Q tagging to differentiate STP BPDUs and is compatible with Cisco R-PVST/R-PVST+ modes.

The relationship between ports, trunk groups, VLANs, and Spanning Trees is shown in [Table 13](#).

*Table 13. Ports, Trunk Groups, and VLANs*

Switch Element	Belongs To
Port	Trunk group, or one or more VLANs
Trunk group	One or more VLANs
VLAN (non-default)	<ul style="list-style-type: none"><li>• PVRST: One VLAN per STG</li><li>• RSTP: All VLANs are in STG 1</li><li>• MSTP: Multiple VLANs per STG</li></ul>

## Port States

The port state controls the forwarding and learning processes of Spanning Tree. In PVRST, the port state has been consolidated to the following: discarding, learning, and forwarding.

Due to the sequence involved in these STP states, considerable delays may occur while paths are being resolved. To mitigate delays, ports defined as *edge ports* ([“Port Type and Link Type” on page 156](#)) may bypass the discarding and learning states, and enter directly into the forwarding state.

## Bridge Protocol Data Units

### Bridge Protocol Data Units Overview

To create a Spanning Tree, the switch generates a configuration Bridge Protocol Data Unit (BPDU), which it then forwards out of its ports. All switches in the Layer 2 network participating in the Spanning Tree gather information about other switches in the network through an exchange of BPDUs.

A bridge sends BPDU packets at a configurable regular interval (2 seconds by default). The BPDU is used to establish a path, much like a hello packet in IP routing. BPDUs contain information about the transmitting bridge and its ports, including bridge MAC addresses, bridge priority, port priority, and path cost. If the ports are tagged, each port sends out a special BPDU containing the tagged information.

The generic action of a switch on receiving a BPDU is to compare the received BPDU to its own BPDU that it will transmit. If the received BPDU is better than its own BPDU, it will replace its BPDU with the received BPDU. Then, the switch adds its own bridge ID number and increments the path cost of the BPDU. The switch uses this information to block any necessary ports.

**Note:** If STP is globally disabled, BPDUs from external devices will transit the switch transparently. If STP is globally enabled, for ports where STP is turned off, inbound BPDUs will instead be discarded.

### Determining the Path for Forwarding BPDUs

When determining which port to use for forwarding and which port to block, the GbESM uses information in the BPDU, including each bridge ID. A technique based on the “lowest root cost” is then computed to determine the most efficient path for forwarding.

#### Bridge Priority

The bridge priority parameter controls which bridge on the network is the STG root bridge. To make one switch become the root bridge, configure the bridge priority lower than all other switches and bridges on your network. The lower the value, the higher the bridge priority. Use the following command to configure the bridge priority:

```
>> # /cfg/12/stg <x>/brg/prio <0-65535>
```

#### Port Priority

The port priority helps determine which bridge port becomes the root port or the designated port. The case for the root port is when two switches are connected using a minimum of two links with the same path-cost. The case for the designated port is in a network topology that has multiple bridge ports with the same path-cost connected to a single segment, the port with the lowest port priority becomes the designated port for the segment. Use the following command to configure the port priority:

```
>> # /cfg/12/stg <STG>/port <port>/prio <priority value>
```

where *priority value* is a number from 0 to 255, in increments of 16 (such as 0, 16, 32, and so on). If the specified priority value is not evenly divisible by 16, the value will be automatically rounded down to the nearest valid increment whenever manually changed in the configuration, or whenever a configuration file from a release prior to N/OS 6.5 is loaded.

## Root Guard

The root guard feature provides a way to enforce the root bridge placement in the network. It keeps a new device from becoming root and thereby forcing STP re-convergence. If a root-guard enabled port detects a root device, that port will be placed in a blocked state.

You can configure the root guard at the port level using the following commands:

```
>> Main# cfg/port <port number>/stp/guard/type root
```

The default state is “none”, i.e. disabled.

## Loop Guard

In general, STP resolves redundant network topologies into loop-free topologies. The loop guard feature performs additional checking to detect loops that might not be found using Spanning Tree. STP loop guard ensures that a non-designated port does not become a designated port.

To globally enable loop guard, enter the following command:

```
>> Main# cfg/l2/loopgrd enable
```

**Note:** The global loop guard command will be effective on a port only if the port-level loop guard command is set to default as shown below:

```
>> Main# cfg/port <port number>/stp/guard/default
```

To enable loop guard at the port level, enter the following command:

```
>> Main# cfg/port <port number>/stp/guard/type loop
```

The default state is “none”, i.e. disabled.

## Port Path Cost

The port path cost assigns lower values to high-bandwidth ports, such as 10 Gigabit Ethernet, to encourage their use. The cost of a port also depends on whether the port operates at full-duplex (lower cost) or half-duplex (higher cost). For example, if a 100-Mbps (Fast Ethernet) link has a “cost” of 10 in half-duplex mode, it will have a cost of 5 in full-duplex mode. The objective is to use the fastest links so that the route with the lowest cost is chosen. A value of 0 (the default) indicates that the default cost will be computed for an auto-negotiated link or trunk speed.

Use the following command to modify the port path cost:


```
>> # /cfg/l2/stp <STG>/port <port number>/cost <path cost>
```

The port path cost can be a value from 1 to 200000000. Specify 0 for automatic path cost.

## Simple STP Configuration

[Figure 11](#) depicts a simple topology using a switch-to-switch link between two GbESM 1 and 2 (via either external ports or internal Inter-Switch Links).


Figure 11. Spanning Tree Blocking a Switch-to-Switch Link



To prevent a network loop among the switches, STP must block one of the links between them. In this case, it is desired that STP block the link between the IBM switches, and not one of the GbESM uplinks or the Enterprise switch trunk.

During operation, if one GbESM experiences an uplink failure, STP will activate the IBM switch-to-switch link so that server traffic on the affected GbESM may pass through to the active uplink on the other GbESM, as shown in [Figure 12](#).

Figure 12. Spanning Tree Restoring the Switch-to-Switch Link



In this example, port 10 on each GbESM is used for the switch-to-switch link. To ensure that the GbESM switch-to-switch link is blocked during normal operation, the port path cost is set to a higher value than other paths in the network. To configure the port path cost on the switch-to-switch links in this example, use the following commands on each GbESM.

```
>> # /cfg/12/stg 1/port 10/cost 60000
```

## Per-VLAN Spanning Tree Groups

PVRST mode supports a maximum of 127 STGs, with each STG acting as an independent, simultaneous instance of STP.


Multiple STGs provide multiple data paths which can be used for load-balancing and redundancy. To enable load balancing between two GbESMs using multiple STGs, configure each path with a different VLAN and then assign each VLAN to a separate STG. Since each STG is independent, they each send their own IEEE 802.1Q tagged Bridge Protocol Data Units (BPDUs).

Each STG behaves as a bridge group and forms a loop-free topology. The default STG 1 may contain multiple VLANs (typically until they can be assigned to another STG). STGs 2-127 may contain only one VLAN each.

### Using Multiple STGs to Eliminate False Loops

Figure 13 shows a simple example of why multiple STGs are needed. In the figure, two ports on a GbESM are connected to two ports on an application switch. Each of the links is configured for a different VLAN, preventing a network loop. However, in the first network, since a single instance of Spanning Tree is running on all the ports of the GbESM, a physical loop is assumed to exist, and one of the VLANs is blocked, impacting connectivity even though no actual loop exists.

Figure 13. Using Multiple Instances of Spanning Tree Group



In the second network, the problem of improper link blocking is resolved when the VLANs are placed into different Spanning Tree Groups (STGs). Since each STG has its own independent instance of Spanning Tree, each STG is responsible only for the loops within its own VLAN. This eliminates the false loop, and allows both VLANs to forward packets between the switches at the same time.

### VLAN and STG Assignment

In PVRST mode, up to 127 STGs are supported. Ports cannot be added directly to an STG. Instead, ports must be added as members of a VLAN, and the VLAN must then be assigned to the STG.

STG 1 is the default STG. Although VLANs can be added to or deleted from default STG 1, the STG itself cannot be deleted from the system. By default, STG 1 is enabled and includes VLAN 1, which by default includes all switch ports (except for management VLANs and management ports).



STG 128 is reserved for switch management. By default, STG 128 is disabled, but includes management VLAN 4095 and the management ports.

By default, all other STGs (STG 2 through 127) are enabled, though they initially include no member VLANs. VLANs must be assigned to STGs. By default, this is done automatically using VLAN Automatic STG Assignment (VASA), though it can also be done manually (see [“Manually Assigning STGs” on page 145](#)).

When VASA is enabled (as by default), each time a new VLAN is configured, the switch will automatically assign that new VLAN to its own STG. Conversely, when a VLAN is deleted, if its STG is not associated with any other VLAN, the STG is returned to the available pool.

The specific STG number to which the VLAN is assigned is based on the VLAN number itself. For low VLAN numbers (1 through 127), the switch will attempt to assign the VLAN to its matching STG number. For higher numbered VLANs, the STG assignment is based on a simple modulus calculation; the attempted STG number will “wrap around,” starting back at the top of STG list each time the end of the list is reached. However, if the attempted STG is already in use, the switch will select the next available STG. If an empty STG is not available when creating a new VLAN, the VLAN is automatically assigned to default STG 1.

If ports are tagged, each tagged port sends out a special BPDU containing the tagged information. Also, when a tagged port belongs to more than one STG, the egress BPDUs are tagged to distinguish the BPDUs of one STG from those of another STG.

VASA is enabled by default, but can be disabled or re-enabled using the following commands:

```
>> # /cfg/12/vlanstg e|d
```

If VASA is disabled, when you create a new VLAN, that VLAN automatically belongs to default STG 1. To place the VLAN in a different STG, assign it manually.

VASA applies only to PVRST mode and is ignored in RSTP and MSTP modes.

## Manually Assigning STGs

The administrator may manually assign VLANs to specific STGs, whether or not VASA is enabled.

1. If no VLANs exist (other than default VLAN 1), see [“Guidelines for Creating VLANs” on page 146](#) for information about creating VLANs and assigning ports to them.
2. Assign the VLAN to an STG using one of the following methods:
  - From within the STG Configuration menu:

```
>> # /cfg/12/stg <STG number>/add <VLAN number>
```

- Or from within the VLAN Configuration menu:

```
>> # /cfg/12/vlan <VLAN number>/stg <STG number>
```

When a VLAN is assigned to a new STG, the VLAN is automatically removed from its prior STG.

**Note:** For proper operation with switches that use Cisco PVST+, it is recommended that you create a separate STG for each VLAN.

## Guidelines for Creating VLANs

- When you create a new VLAN, if VASA is enabled (the default), that VLAN is automatically assigned its own STG. If VASA is disabled, the VLAN automatically belongs to STG 1, the default STG. To place the VLAN in a different STG, see [“Manually Assigning STGs” on page 145](#). The VLAN is automatically removed from its old STG before being placed into the new STG.
- Each VLANs must be contained *within* a single STG; a VLAN cannot span multiple STGs. By confining VLANs within a single STG, you avoid problems with Spanning Tree blocking ports and causing a loss of connectivity within the VLAN. When a VLAN spans multiple switches, it is recommended that the VLAN remain within the same STG (be assigned the same STG ID) across all the switches.
- If ports are tagged, all trunked ports can belong to multiple STGs.
- A port cannot be directly added to an STG. The port must first be added to a VLAN, and that VLAN added to the desired STG.

## Rules for VLAN Tagged Ports

- Tagged ports can belong to more than one STG, but untagged ports can belong to only one STG.
- When a tagged port belongs to more than one STG, the egress BPDUs are tagged to distinguish the BPDUs of one STG from those of another STG.

## Adding and Removing Ports from STGs

- When you add a port to a VLAN that belongs to an STG, the port is also added to that STG. However, if the port you are adding is an untagged port and is already a member of another STG, that port will be removed from its current STG and added to the new STG. An untagged port cannot belong to more than one STG.

For example: Assume that VLAN 1 belongs to STG 1, and that port 1 is untagged and does not belong to any STG. When you add port 1 to VLAN 1, port 1 will automatically become part of STG 1.

However, if port 5 is untagged and is a member of VLAN 3 in STG 2, then adding port 5 to VLAN 1 in STG 1 will not automatically add the port to STG 1. Instead, the switch will prompt you to decide whether to change the PVID from 3 to 1:

"Port 5 is an UNTAGGED port and its current PVID is 3.  
Confirm changing PVID from 3 to 1 [y/n]:" y

- When you remove a port from VLAN that belongs to an STG, that port will also be removed from the STG. However, if that port belongs to another VLAN in the same STG, the port remains in the STG.

As an example, assume that port 2 belongs to only VLAN 2, and that VLAN 2 belongs to STG 2. When you remove port 2 from VLAN 2, the port is moved to default VLAN 1 and is removed from STG 2.

However, if port 2 belongs to both VLAN 1 and VLAN 2, and both VLANs belong to STG 2, removing port 2 from VLAN 2 does not remove port 2 from STG 1, because the port is still a member of VLAN 1, which is still a member of STG 1.

- An STG cannot be deleted, only disabled. If you disable the STG while it still contains VLAN members, Spanning Tree will be off on all ports belonging to that VLAN.


The relationship between port, trunk groups, VLANs, and Spanning Trees is shown in [Table 13 on page 139](#).

## Switch-Centric Configuration

PVRST is switch-centric: STGs are enforced only on the switch where they are configured. The STG ID is not transmitted in the Spanning Tree BPDU. Each Spanning Tree decision is based entirely on the configuration of the particular switch.

For example, in [Figure 14](#), though VLAN 2 is shared by the Switch A and Switch B, each switch is responsible for the proper configuration of its own ports, VLANs, and STGs. Switch A identifies its own port 17 as part of VLAN 2 on STG 2, and the Switch B identifies its own port 8 as part of VLAN 2 on STG 2.

Figure 14. Implementing Multiple Spanning Tree Groups



The VLAN participation for each Spanning Tree Group in [Figure 14 on page 147](#) is as follows:

- **VLAN 1 Participation**

Assuming Switch B to be the root bridge, Switch B transmits the BPDU for VLAN 1 on ports 1 and 2. Switch C receives the BPDU on port 2, and Switch D receives the BPDU on port 1. Because there is a network loop between the switches in VLAN 1, either Switch D will block port 8 or Switch C will block port 1, depending on the information provided in the BPDU.

- **VLAN 2 Participation**

Switch B, the root bridge, generates a BPDU for STG 2 from port 8. Switch A receives this BPDU on port 17, which is assigned to VLAN 2, STG 2. Because switch B has no additional ports participating in STG 2, this BPDU is not forwarded to any additional ports and Switch B remains the designated root.

- **VLAN 3 Participation**

For VLAN 3, Switch A or Switch C may be the root bridge. If Switch A is the root bridge for VLAN 3, STG 3, then Switch A transmits the BPDU from port 18. Switch C receives this BPDU on port 8 and is identified as participating in VLAN 3, STG 2. Since Switch C has no additional ports participating in STG 3, this BPDU is not forwarded to any additional ports and Switch A remains the designated root.

## Configuring Multiple STGs

This configuration shows how to configure the three instances of STGs on the switches A, B, C, and D illustrated in [Figure 14 on page 147](#).

Because VASA is enabled by default, each new VLAN is automatically assigned its own STG. However, for this configuration example, some VLANs are explicitly reassigned to other STGs.

1. Set the Spanning Tree mode on each switch to PVRST.

>> # /cfg/12/mrst	(Select Multiple Spanning Tree menu)
>> Multiple Spanning Tree# mode pvrst	(Set mode to PVRST)
>> Multiple Spanning Tree# on	(Turn PVRST on)

**Note:** PVRST is the default mode on the GbESM. This step is not required unless the STP mode has been previously changed, and is shown here merely as an example of manual configuration.

2. Configure the following on Switch A:

Add port 17 to VLAN 2, port 18 to VLAN 3, and define STG 2 for VLAN 2 and STG 3 for VLAN 3.

>> # /cfg/12/vlan 2	(Select VLAN 2 menu)
>> VLAN 2# ena	(Enable VLAN 2)
>> VLAN 2# add 17	(Add port 17)
>> VLAN 2# stg 2	(Add VLAN 2 to STG 2)
>> VLAN 2# ../vlan 3	(Select VLAN 3 menu)
>> VLAN 3# ena	(Enable VLAN 3)
>> VLAN 3# add 18	(Add port 18)
>> VLAN 3# stg 3	(Add VLAN 3 to STG 3)
>> VLAN 3# apply	

VLAN 2 and VLAN 3 are removed from STG 1.

3. Configure the following on Switch B:

Add port 8 to VLAN 2 and define STG 2 for VLAN 2.

>> # /cfg/12/vlan 2	(Select VLAN 2 menu)
>> VLAN 2# ena	(Enable VLAN 2)
>> VLAN 2# add 8	(Add port 8)
>> VLAN 2# stg 2	(Add VLAN 2 to STG 2)
>> VLAN 2# apply	

VLAN 2 is automatically removed from STG 1. By default VLAN 1 remains in STG 1.

4. Configure the following on application switch C:  
Add port 8 to VLAN 3 and define STG 2 for VLAN 3.

>> # /cfg/12/vlan 3	<i>(Select VLAN 3 menu)</i>
>> VLAN 3# ena	<i>(Enable VLAN 3)</i>
>> VLAN 3# add 8	<i>(Add port 8)</i>
>> VLAN 3# stg 3	<i>(Add VLAN 3 to STG 3)</i>
>> VLAN 3# apply	

VLAN 3 is automatically removed from STG 1. By default VLAN 1 remains in STG 1.

5. Switch D does not require any special configuration for multiple Spanning Trees. Switch D uses default STG 1 only.

---

## Rapid Spanning Tree Protocol

RSTP provides rapid convergence of the Spanning Tree and provides the fast re-configuration critical for networks carrying delay-sensitive traffic such as voice and video. RSTP significantly reduces the time to reconfigure the active topology of the network when changes occur to the physical topology or its configuration parameters. RSTP reduces the bridged-LAN topology to a single Spanning Tree.

RSTP was originally defined in IEEE 802.1w (2001) and was later incorporated into IEEE 802.1D (2004), superseding the original STP standard.

RSTP parameters apply only to Spanning Tree Group (STG) 1. The PVRST mode STGs 2-128 are not used when the switch is placed in RSTP mode.

RSTP is compatible with devices that run IEEE 802.1D (1998) Spanning Tree Protocol. If the switch detects IEEE 802.1D (1998) BPDUs, it responds with IEEE 802.1D (1998)-compatible data units. RSTP is not compatible with Per-VLAN Rapid Spanning Tree (PVRST) protocol.

**Note:** In RSTP mode, Spanning Tree for the management ports is turned off by default.

## Port States

RSTP port state controls are the same as for PVRST: discarding, learning, and forwarding.

Due to the sequence involved in these STP states, considerable delays may occur while paths are being resolved. To mitigate delays, ports defined as *edge* ports ([“Port Type and Link Type” on page 156](#)) may bypass the discarding and learning states, and enter directly into the forwarding state.

## RSTP Configuration Guidelines

This section provides important information about configuring RSTP. When RSTP is turned on, the following occurs:

- STP parameters apply only to STG 1.
- Only STG 1 is available. All other STGs are turned off.
- All VLANs, including management VLANs, are moved to STG 1.

## RSTP Configuration Example

This section provides steps to configure RSTP.

1. Configure port and VLAN membership on the switch.
2. Set the Spanning Tree mode to Rapid Spanning Tree.

>> # /cfg/l2/mrst	<i>(Select Multiple Spanning Tree menu)</i>
>> Multiple Spanning Tree# mode rstp	<i>(Set mode to Rapid Spanning Tree)</i>
>> Multiple Spanning Tree# on	<i>(Turn Rapid Spanning Tree on)</i>

3. Configure STP Group 1 parameters.

>> # /cfg/l2/stg 1	<i>(Select Spanning Tree Protocol menu)</i>
>> Spanning Tree Group 1# add 2	<i>(Add VLAN 2 STP Group 1)</i>

4. Apply and save the configuration.

---

## Multiple Spanning Tree Protocol

**Note:** MSTP is supported in stand-alone (non-stacking) mode only.

Multiple Spanning Tree Protocol (MSTP) extends Rapid Spanning Tree Protocol (RSTP), allowing multiple Spanning Tree Groups (STGs) which may each include multiple VLANs. MSTP was originally defined in IEEE 802.1s (2002) and was later included in IEEE 802.1Q (2003).

In MSTP mode, the GbESM supports up to 32 instances of Spanning Tree, corresponding to STGs 1-32, with each STG acting as an independent, simultaneous instance of STP.

MSTP allows frames assigned to different VLANs to follow separate paths, with each path based on an independent Spanning Tree instance. This approach provides multiple forwarding paths for data traffic, thereby enabling load-balancing, and reducing the number of Spanning Tree instances required to support a large number of VLANs.

Due to Spanning Tree's sequence of discarding, learning, and forwarding, lengthy delays may occur while paths are being resolved. Ports defined as *edge* ports (["Port Type and Link Type" on page 156](#)) bypass the Discarding and Learning states, and enter directly into the Forwarding state.

**Note:** In MSTP mode, Spanning Tree for the management ports is turned off by default.

## MSTP Region

A group of interconnected bridges that share the same attributes is called an MST region. Each bridge within the region must share the following attributes:

- Alphanumeric name
- Revision number
- VLAN-to STG mapping scheme

MSTP provides rapid re-configuration, scalability and control due to the support of regions, and multiple Spanning-Tree instances support within each region.

## Common Internal Spanning Tree

The Common Internal Spanning Tree (CIST) provides a common form of Spanning Tree Protocol, with one Spanning-Tree instance that can be used throughout the MSTP region. CIST allows the switch to interoperate with legacy equipment, including devices that run IEEE 802.1D (1998) STP.

CIST allows the MSTP region to act as a virtual bridge to other bridges outside of the region, and provides a single Spanning-Tree instance to interact with them.

CIST port configuration includes Hello time, Edge port enable/disable, and Link Type. These parameters do not affect Spanning Tree Groups 1–128. They apply only when the CIST is used.



## MSTP Configuration Guidelines

This section provides important information about configuring Multiple Spanning Tree Groups:

- When MSTP is turned on, the switch automatically moves management VLAN 4095 to the CIST. When MSTP is turned off, the switch moves VLAN 4095 from the CIST to Spanning Tree Group 128.
- When you enable MSTP, you must configure the Region Name. A default version number of 1 is configured automatically.
- Each bridge in the region must have the same name, version number, and VLAN mapping.

## MSTP Configuration Examples

### Example 1

This section provides steps to configure MSTP on the GbESM.

1. Configure port and VLAN membership on the switch.
2. Set the mode to Multiple Spanning Tree, and configure MSTP region parameters.

>> # /cfg/12/mrst	<i>(Select Multiple Spanning Tree menu)</i>
>> Multiple Spanning Tree# mode mstp	<i>(Set mode to Multiple Spanning Trees)</i>
>> Multiple Spanning Tree# on	<i>(Turn Multiple Spanning Trees on)</i>
>> Multiple Spanning Tree# name <name>	<i>(Define the Region name)</i>

3. Assign VLANs to Spanning Tree Groups.


>> # /cfg/12/stg 2	<i>(Select Spanning Tree Group 2)</i>
>> Spanning Tree Group 2# add 2	<i>(Add VLAN 2)</i>

4. Apply and save the configuration.

## MSTP Configuration Example 2

This configuration shows how to configure MSTP Groups on the switch, as shown in [Figure 15](#).

Figure 15. Implementing Multiple Spanning Tree Groups



This example shows how multiple Spanning Trees can provide redundancy without wasting any uplink ports. In this example, the server ports are split between two separate VLANs. Both VLANs belong to two different MSTP groups. The Spanning Tree *priority* values are configured so that each routing switch is the root for a different MSTP instance. All of the uplinks are active, with each uplink port backing up the other.

1. Configure port membership and define the STGs for VLAN 1. Enable tagging on uplink ports that share VLANs. Port 19 and port 20 connect to the Enterprise Routing switches.

```
>> # /cfg/port 19
>> Port 19# tag enable
>> Port 19# ../port 20
>> Port 20# tag enable
```

2. Add server ports 1 and 2 to VLAN 1. Add uplink ports 19 and port 20 to VLAN 1.

```
>> Port 20# /cfg/12/vlan 1           (Select VLAN 1)
>> VLAN 1# ena                       (Enable VLAN 1)
>> VLAN 1# add 1,2,19,20             (Add ports to VLAN 1)
>> VLAN 1# stg 1                     (Set STG 1 for VLAN 1)
```

3. Configure MSTP: Spanning Tree mode, region name, and version.

>> VLAN 1# /cfg/12/mrst	(Select Multiple Spanning Tree menu)
>> Multiple Spanning Tree# mode mstp	(Set mode to Multiple Spanning Trees)
>> Multiple Spanning Tree# on	(Turn Multiple Spanning Trees on)
>> Multiple Spanning Tree# name MyRegion	(Define the Region name)
>> Multiple Spanning Tree# rev 100	(Define the Revision level)

4. Configure port membership and define the STGs for VLAN 2. Add server ports 3, 4, and 5 to VLAN 2. Add uplink ports 19 and 20 to VLAN 2. Assign VLAN 2 to STG 2.

>> Port 20# /cfg/12/vlan 2	(Select VLAN 2)
>> VLAN 2# ena	(Enable VLAN 2)
>> VLAN 1# add 3,4,19,20	(Add ports to VLAN 2)
>> VLAN 1# stg 2	(Set STG 2 for VLAN 2)

**Note:** Each STG is enabled by default.

5. Apply and save the configuration.

---

## Port Type and Link Type

### Edge Port

A port that does not connect to a bridge is called an *edge port*. Since edge ports are assumed to be connected to non-STP devices (such as directly to hosts or servers), they are placed in the forwarding state as soon as the link is up. Ports INT1-INT14 should be configured as edge ports.

Edge ports send BPDUs to upstream STP devices like normal STP ports, but should not receive BPDUs. If a port with *edge* enabled does receive a BPDU, it immediately begins working as a normal (non-edge) port, and participates fully in Spanning Tree.

Use the following commands to define or clear a port as an edge port:

```
>> # /cfg/port <port>/stp/edge {enable|disable}
```

### Link Type

The link type determines how the port behaves in regard to Rapid Spanning Tree. Use the following commands to define the link type for the port:

```
>> # /cfg/port <port>/stp/link <type>
```

where *type* corresponds to the duplex mode of the port, as follows:

- *p2p*                      A full-duplex link to another device (point-to-point)
- *shared*                  A half-duplex link is a shared segment and can contain more than one device.
- *auto*                    The switch dynamically configures the link type.

**Note:** Any STP port in full-duplex mode can be manually configured as a shared port when connected to a non-STP-aware shared device (such as a typical Layer 2 switch) used to interconnect multiple STP-aware devices.

---

## Chapter 10. Quality of Service

Quality of Service (QoS) features allow you to allocate network resources to mission-critical applications at the expense of applications that are less sensitive to such factors as time delays or network congestion. You can configure your network to prioritize specific types of traffic, ensuring that each type receives the appropriate QoS level.

The following topics are discussed in this section:

- [“QoS Overview” on page 158](#)
- [“Using ACL Filters” on page 159](#)
- [“Using DSCP Values to Provide QoS” on page 161](#)
- [“Using 802.1p Priorities to Provide QoS” on page 166](#)
- [“Queuing and Scheduling” on page 167](#)
- [“Control Plane Protection” on page 167](#)

---


## QoS Overview

QoS helps you allocate guaranteed bandwidth to critical applications, and limit bandwidth for less critical applications. Applications such as video and voice must have a certain amount of bandwidth to work correctly; using QoS, you can provide that bandwidth when necessary. Also, you can put a high priority on applications that are sensitive to timing out or those that cannot tolerate delay, assigning that traffic to a high-priority queue.

By assigning QoS levels to traffic flows on your network, you can ensure that network resources are allocated where they are needed most. QoS features allow you to prioritize network traffic, thereby providing better service for selected applications.

Figure 16 on page 158 shows the basic QoS model used by the 1/10Gb Uplink ESM (GbESM).

Figure 16. QoS Model



The GbESM uses the Differentiated Services (DiffServ) architecture to provide QoS functions. DiffServ is described in IETF RFC 2474 and RFC 2475.

With DiffServ, you can establish policies for directing traffic. A policy is a traffic-controlling mechanism that monitors the characteristics of the traffic (for example, its source, destination, and protocol) and performs a controlling action on the traffic when certain characteristics are matched.

The GbESM can classify traffic by reading the DiffServ Code Point (DSCP) or IEEE 802.1p priority value, or by using filters to match specific criteria. When network traffic attributes match those specified in a traffic pattern, the policy instructs the GbESM to perform specified actions on each packet that passes through it. The packets are assigned to different Class of Service (COS) queues and scheduled for transmission.

The basic GbESM QoS model works as follows:

- Classify traffic:
  - Read DSCP
  - Read 802.1p Priority
  - Match ACL filter parameters
- Meter traffic:
  - Define bandwidth and burst parameters
  - Select actions to perform on in-profile and out-of-profile traffic
- Perform actions:
  - Drop packets
  - Pass packets
  - Mark DSCP or 802.1p Priority
  - Set COS queue (with or without re-marking)
- Queue and schedule traffic:
  - Place packets in one of the available COS queues
  - Schedule transmission based on the COS queue weight

---

## Using ACL Filters

Access Control Lists (ACLs) are filters that allow you to classify and segment traffic, so you can provide different levels of service to different traffic types. Each filter defines conditions that packets must match for inclusion in a particular service class, and also the actions that are performed for matching traffic.

The GbESM allows you to classify packets based on various parameters. For example:

- Ethernet—source MAC, destination MAC, VLAN number/mask, Ethernet type, priority
- IPv4—source IP address/mask, destination address/mask, type of service, IP protocol number
- IPv6—source IP address/prefix, destination address/prefix, next header, flow label, traffic class
- TCP/UDP—source port, destination port, TCP flag
- Packet format—Ethernet format, tagging format, IPv4, IPv6
- Egress port

For ACL details, see [“Access Control Lists” on page 93](#).

## Summary of ACL Actions

Actions determine how the traffic is treated. The GbESM QoS actions include the following:

- Pass or Drop the packet
- Re-mark the packet with a new DiffServ Code Point (DSCP)
- Re-mark the 802.1p field
- Set the COS queue

## ACL Metering and Re-Marking

You can define a profile for the aggregate traffic flowing through the GbESM by configuring a QoS meter (if desired) and assigning ACL Groups to ports. When you add ACL Groups to a port, make sure they are ordered correctly in terms of precedence.

Actions taken by an ACL are called *In-Profile* actions. You can configure additional In-Profile and Out-of-Profile actions on a port. Data traffic can be metered, and re-marked to ensure that the traffic flow provides certain levels of service in terms of bandwidth for different types of network traffic.

## Metering

QoS metering provides different levels of service to data streams through user-configurable parameters. A meter is used to measure the traffic stream against a traffic profile which you create. Thus, creating meters yields In-Profile and Out-of-Profile traffic for each ACL, as follows:

- **In-Profile**—If there is no meter configured or if the packet conforms to the meter, the packet is classified as In-Profile.
- **Out-of-Profile**—If a meter is configured and the packet does not conform to the meter (exceeds the committed rate or maximum burst rate of the meter), the packet is classified as Out-of-Profile.

**Note:** Metering is not supported for IPv6 ACLs. All traffic matching an IPv6 ACL is considered in-profile for re-marking purposes.

Using meters, you set a Committed Rate in Kbps (1000 bits per second in each Kbps). All traffic within this Committed Rate is In-Profile. Additionally, you can set a Maximum Burst Size that specifies an allowed data burst larger than the Committed Rate for a brief period. These parameters define the In-Profile traffic.

Meters keep the sorted packets within certain parameters. You can configure a meter on an ACL, and perform actions on metered traffic, such as packet re-marking.

## Re-Marking

Re-marking allows for the treatment of packets to be reset based on new network specifications or desired levels of service. You can configure the ACL to re-mark a packet as follows:

- Change the DSCP value of a packet, used to specify the service level traffic should receive.
- Change the 802.1p priority of a packet.



---


## Using DSCP Values to Provide QoS

The six most significant bits in the TOS byte of the IP header are defined as DiffServ Code Points (DSCP). Packets are marked with a certain value depending on the type of treatment the packet must receive in the network device. DSCP is a measure of the Quality of Service (QoS) level of the packet.

### Differentiated Services Concepts

To differentiate between traffic flows, packets can be classified by their DSCP value. The Differentiated Services (DS) field in the IP header is an octet, and the first six bits, called the DS Code Point (DSCP), can provide QoS functions. Each packet carries its own QoS state in the DSCP. There are 64 possible DSCP values (0-63).

Figure 17. Layer 3 IPv4 Packet



The GbESM can perform the following actions to the DSCP:

- Read the DSCP value of ingress packets
- Re-mark the DSCP value to a new value
- Map the DSCP value to an 802.1p priority

Once the DSCP value is marked, the GbESM can use it to direct traffic prioritization.

### Trusted/Untrusted Ports

By default, all ports on the GbESM are trusted. To configure untrusted ports, re-mark the DSCP value of the incoming packet to a lower DSCP value using the following command:

```
>> /cfg/port EXT1
>> Port EXT1# dscpmrk enable

>> /cfg/qos/dscp
>> DSCP Remark# dscp <DSCP Value (0-63)> <New DSCP Value (0-63)>
>> DSCP Remark# on
```

## Per-Hop Behavior

The DSCP value determines the Per Hop Behavior (PHB) of each packet. The PHB is the forwarding treatment given to packets at each hop. QoS policies are built by applying a set of rules to packets, based on the DSCP value, as they hop through the network.

The GbESM default settings are based on the following standard PHBs, as defined in the IEEE standards:

- Expedited Forwarding (EF)—This PHB has the highest egress priority and lowest drop precedence level. EF traffic is forwarded ahead of all other traffic. EF PHB is described in RFC 2598.
- Assured Forwarding (AF)—This PHB contains four service levels, each with a different drop precedence, as shown below. Routers use drop precedence to determine which packets to discard last when the network becomes congested. AF PHB is described in RFC 2597.

Drop Precedence	Class 1	Class 2	Class 3	Class 4
Low	AF11 (DSCP 10)	AF21 (DSCP 18)	AF31 (DSCP 26)	AF41 (DSCP 34)
Medium	AF12 (DSCP 12)	AF22 (DSCP 20)	AF32 (DSCP 28)	AF42 (DSCP 36)
High	AF13 (DSCP 14)	AF23 (DSCP 22)	AF33 (DSCP 30)	AF43 (DSCP 38)

- Class Selector (CS)—This PHB has eight priority classes, with CS7 representing the highest priority, and CS0 representing the lowest priority, as shown below. CS PHB is described in RFC 2474.

Priority	Class Selector	DSCP
Highest	CS7	56
	CS6	48
	CS5	40
	CS4	32
	CS3	24
	CS2	16
	CS1	8
Lowest	CS0	0

## QoS Levels

[Table 14](#) shows the default service levels provided by the GbESM, listed from highest to lowest importance:

*Table 14. Default QoS Service Levels*

Service Level	Default PHB	802.1p Priority
Critical	CS7	7
Network Control	CS6	6
Premium	EF, CS5	5
Platinum	AF41, AF42, AF43, CS4	4
Gold	AF31, AF32, AF33, CS3	3
Silver	AF21, AF22, AF23, CS2	2
Bronze	AF11, AF12, AF13, CS1	1
Standard	DF, CS0	0

## DSCP Re-Marking and Mapping

### DSCP Re-Marking Overview

The GbESM can re-mark the DSCP value of ingress packets to a new value, and set the 802.1p priority value, based on the DSCP value. You can view the settings by using the following command:

```
>> # /cfg/qos/dscp/cur
Current DSCP Remarking Configuration: OFF
```

DSCP	New DSCP	New 802.1p Prio
0	0	0
1	1	0
...		
51	51	0
52	52	0
53	53	0
54	54	0
55	55	0
56	56	7
57	57	0
58	58	0
59	59	0
60	60	0
61	61	0
62	62	0
63	63	0

Use the `/cfg/qos/dscp/on` command to turn on DSCP re-marking globally. Then you must enable DSCP re-marking (`/cfg/port <x>/dscpmrk/ena`) on any port that you wish to perform this function.

**Note:** If an ACL meter is configured for DSCP re-marking, the meter function takes precedence over QoS re-marking.

## DSCP Re-Marking Configuration Examples

### Example 1

1. Turn DSCP re-marking on globally, and define the DSCP-DSCP-802.1p mapping. You can use the default mapping, as shown in the /cfg/qos/dscp/cur command output.

```
>> # /cfg/qos/dscp/on                (Turn on DSCP re-marking)
>> DSCP Remark# dscp 8 10            (Define DSCP re-marking)
>> DSCP Remark# prio 10 2            (Define DSCP-to-802.1p mapping)
```

2. Enable DSCP re-marking on a port.

```
>> # /cfg/port EXT1                  (Select port)
>> Port EXT1# dscpmrk ena            (Enable DSCP re-marking)
Current DSCP remarking: disabled
New DSCP remarking:      enabled
```

3. Apply and save the configuration.

### Example 2

The following example includes steps to assign strict priority to VoIP traffic and a lower priority to all other traffic.

1. Create an ACL to re-mark DSCP value and COS queue for all VoIP packets.

```
>> /cfg/acl/acl 2
>> ACL 2# tcpudp
>> Filtering TCP/UDP# sport 5060 0x5060
>> Filtering TCP/UDP# ..
>> ACL 2# meter
>> Metering# cir 10000000
>> Metering# enable
>> Metering# ..
>> ACL 2# re-mark
>> Re-mark# inprof
>> Re-marking - In Profile# updscp 56
>> Re-marking - In Profile# ..
>> Re-mark# up1p
>> Update User Priority# value 7
>> Update User Priority# ..
>> Re-mark# ..
>> ACL 2# action permit
```

2. Create an ACL to set a low priority to all other traffic.

```
>> ACL 2# ../acl 3
>> ACL 3# action setprio 1
>> ACL 3# action permit
```

3. Apply the ACLs to a port and enable DSCP marking.

```
>> ACL 3# /cfg/port EXT5/aclqos
>> Port EXT5 ACL# add acl 2
>> Port EXT5 ACL# add acl 3
>> Port EXT5 ACL# ..
>> Port EXT5# dscpmrk enable
```

4. Enable DSCP re-marking globally.

```
>> Port EXT5# /cfg/qos/dscp
>> DSCP Remark# on
```

5. Assign the DSCP re-mark value.

```
>> DSCP Remark# dscp 46 9
```

6. Assign strict priority to VoIP COS queue.

```
>> DSCP Remark# /cfg/qos/8021p
>> 802.1p# qweight 7 0
```

7. Map priority value to COS queue for non-VoIP traffic.

```
>> 802.1p# priq 1 1
```

8. Assign weight to the non-VoIP COS queue.

```
>> 802.1p# qweight 1 2
```

9. Apply and save the configuration.


## Using 802.1p Priorities to Provide QoS

### 802.1p Overview

IBM Networking OS provides Quality of Service functions based on the priority bits in a packet's VLAN header. (The priority bits are defined by the 802.1p standard within the IEEE 802.1q VLAN header.) The 802.1p bits, if present in the packet, specify the priority that should be given to packets during forwarding. Packets with a numerically higher (non-zero) priority are given forwarding preference over packets with lower priority bit value.

The IEEE 802.1p standard uses eight levels of priority (0-7). Priority 7 is assigned to highest priority network traffic, such as OSPF or RIP routing table updates, priorities 5-6 are assigned to delay-sensitive applications such as voice and video, and lower priorities are assigned to standard applications. A value of 0 (zero) indicates a “best effort” traffic prioritization, and this is the default when traffic priority has not been configured on your network. The GbESM can filter packets based on the 802.1p values, and it can assign or overwrite the 802.1p value in the packet.

Figure 18. Layer 2 802.1q/802.1p VLAN Tagged Packet



Ingress packets receive a priority value, as follows:

- **Tagged packets**—GbESM reads the 802.1p priority in the VLAN tag.
- **Untagged packets**—GbESM tags the packet and assigns an 802.1p priority, based on the port's default priority (`/cfg/port <x>/8021ppri`).

Egress packets are placed in a COS queue based on the priority value, and scheduled for transmission based on the scheduling weight of the COS queue.

### 802.1p Configuration Example

1. Configure a port's default 802.1p priority.

```
>> # /cfg/port EXT1                               (Select port)
>> Port EXT1# 8021ppri 1                           (Set port's default 802.1p priority)
>> Port EXT1# ena
```

2. Map the 802.1p priority value to a COS queue and set the COS queue scheduling weight.

```
>> Port EXT1# /cfg/qos/8021p                       (Select 802.1p menu)
>> 802.1p# priq 1 1                                (Set COS queue assignments)
>> 802.1p# qweight 1 10                            (Set COS queue weights)
```

See [“Queuing and Scheduling” on page 167](#) for details on scheduling weights.

3. Apply and save the configuration.

---

## Queuing and Scheduling

The GbESM can be configured to have either 2 or 8 output Class of Service (COS) queues per port, into which each packet is placed. Each packet's 802.1p priority determines its COS queue, except when an ACL action sets the COS queue of the packet.

**Note:** In stacking mode, because one COS queue is reserved for internal use, the number of configurable COS queues is either 1 or 7.

You can configure the following attributes for COS queues:

- Map 802.1p priority value to a COS queue
- Define the scheduling weight of each COS queue

Use the 802.1p menu (`/cfg/qos/8021p`) to configure COS queues.

The scheduling weight can be set from 0 to 15. Weight values from 1 to 15 set the queue to use weighted round-robin (WRR) scheduling, which distributes larger numbers of packets to queues with the highest weight values. For distribution purposes, each packet is counted the same, regardless of the packet's size.

A scheduling weight of 0 (zero) indicates strict priority. Traffic in strict priority queue has precedence over other all queues. If more than one queue is assigned a weight of 0, the strict queue with highest queue number will be served first. Once all traffic in strict queues is delivered, any remaining bandwidth will be allocated to the WRR queues, divided according to their weight values.

**Note:** Use caution when assigning strict scheduling to queues. Heavy traffic in queues assigned with a weight of 0 can starve lower priority queues.

---

## Control Plane Protection

Control plane receives packets that are required for the internal protocol state machines. This type of traffic is usually received at low rate. However, in some situations such as DOS attacks, the switch may receive this traffic at a high rate. If the control plane protocols are unable to process the high rate of traffic, the switch may become unstable.

The control plane receives packets that are channeled through protocol-specific packet queues. Multiple protocols can be channeled through a common packet queue. However, one protocol cannot be channeled through multiple packet queues. These packet queues are applicable only to the packets received by the software and does not impact the regular switching or routing traffic. Packet queue with a higher number has higher priority.

You can configure the bandwidth for each packet queue. Protocols that share a packet queue will also share the bandwidth.

Given below are the commands to configure the control plane protection (CoPP) feature:

```
GbESM(config)# qos protocol-packet-control packet-queue-map <0-31>
<protocol>                                     (Configure a queue for a protocol)
GbESM(config)# qos protocol-packet-control rate-limit-packet-queue <0-31> <1-10000>
(Set the bandwidth for the queue,                                     in packets per second)
```





# **Part 4: Advanced Switching Features**



---

## Chapter 11. Stacking

This chapter describe how to implement the stacking feature in the 1/10Gb Uplink Ethernet Switch Module. The following concepts are covered:

- [“Stacking Overview” on page 172](#)
- [“Stack Membership” on page 174](#)
- [“Configuring a Stack” on page 177](#)
- [“Managing a Stack” on page 182](#)
- [“Upgrading Software in an Existing Stack” on page 184](#)
- [“Replacing or Removing Stacked Switches” on page 186](#)
- [“ISCLI Stacking Commands” on page 189](#)

---

## Stacking Overview

A *stack* is a group of up to eight 1/10Gb Uplink ESM switches with IBM Networking OS that work together as a unified system. A stack has the following properties, regardless of the number of switches included:

- The network views the stack as a single entity.
- The stack can be accessed and managed as a whole using standard switch IP interfaces configured with IPv4 addresses.
- Once the stacking links have been established (see below), the number of ports available in a stack equals the total number of remaining ports of all the switches that are part of the stack.
- The number of available IP interfaces, VLANs, Trunks, Trunk Links, and other switch attributes are not aggregated among the switches in a stack. The totals for the stack as a whole are the same as for any single switch configured in stand-alone mode.

## Stacking Requirements

Before IBM N/OS switches can form a stack, they must meet the following requirements:

- All switches must be the same model (1/10Gb Uplink ESM).
- Each switch must be installed with N/OS, version 7.4 or later. The same release version is not required, as the Master switch will push a firmware image to each differing switch which is part of the stack.
- The recommended stacking topology is a bidirectional ring (see [Figure 19 on page 178](#)). To achieve this, two external 10Gb Ethernet ports on each switch must be reserved for stacking. By default, the first two 10Gb Ethernet ports are used.
- The cables used for connecting the switches in a stack carry low-level, inter-switch communications as well as cross-stack data traffic critical to shared switching functions. Always maintain the stability of stack links in order to avoid internal stack reconfiguration.

## Stacking Limitations

The GbESM with N/OS 7.4 can operate in one of two modes:

- Default mode, which is the regular stand-alone (or non-stacked) mode.
- Stacking mode, in which multiple physical switches aggregate functions as a single switching device.

When in stacking mode, the following stand-alone features are not supported:

- Active Multi-Path Protocol (AMP)
- BCM rate control
- Border Gateway Protocol (BGP)
- IGMP Relay and IGMPv3
- IPv6
- Loopback Interfaces
- MAC address notification
- MSTP
- OSPF and OSPFv3
- Port flood blocking
- Protocol-based VLANs
- RIP
- Router IDs
- Route maps
- sFlow port monitoring
- Static MAC address adding
- Static multicast
- Uni-Directional Link Detection (UDLD)
- Virtual Router Redundancy Protocol (VRRP)

**Note:** In stacking mode, switch menus and command for unsupported features may be unavailable, or may have no effect on switch operation.

---

## Stack Membership

A stack contains up to eight switches, interconnected by a stack trunk in a local ring topology (see [Figure 19 on page 178](#)). With this topology, only a single stack link failure is allowed.

An operational stack must contain one Master and one or more Members, as follows:

- **Master**  
One switch controls the operation of the stack and is called the Master. The Master provides a single point to manage the stack. A stack must have one and only one Master. The firmware image, configuration information, and run-time data are maintained by the Master and pushed to each switch in the stack as necessary.
- **Member**  
Member switches provide additional port capacity to the stack. Members receive configuration changes, run-time information, and software updates from the Master.
- **Backup**  
One member switch can be designated as a Backup to the Master. The Backup takes over control of the stack if the Master fails. Configuration information and run-time data are synchronized with the Master.

## The Master Switch

An operational stack can have only one active Master at any given time. In a normal stack configuration, one switch is configured as a Master and all others are configured as Members.

When adding new switches to an existing stack, the administrator should explicitly configure each new switch for its intended role as a Master (only when replacing a previous Master) or as a Member. All stack configuration procedures in this chapter depict proper role specification.

However, although uncommon, there are scenarios in which a stack may temporarily have more than one Master switch. Should this occur, one Master switch will automatically be chosen as the active Master for the entire stack. The selection process is designed to promote stable, predictable stack operation and minimize stack reboots and other disruptions.

## Splitting and Merging One Stack

If stack links or Member switches fail, any Members which cannot access either the Master or Backup are considered *isolated* and will not process network traffic (see [“No Backup” on page 176](#)). Members which have access to a Master or Backup (or both), despite other link or Member failures, will continue to operate as part of their active stack.

If multiple stack links or stack Member switches fail, thereby separating the Master and Backup into separate sub-stacks, the Backup automatically becomes an active Master for the partial stack in which it resides. Later, if the topology failures are corrected, the partial stacks will merge, and the two active Masters will come into contact.

In this scenario, if both the (original) Master and the Backup (acting as Master) are in operation when the merger occurs, the original Master will reassert its role as active Master for the entire stack. If any configuration elements were changed and applied on the Backup during the time it acted as Master (and forwarded to its connected Members), the Backup and its affected Members will reboot and will be reconfigured by the returning Master before resuming their regular roles.

However, if the original Master switch is disrupted (powered down or in the process of rebooting) when it is reconnected with the active stack, the Backup (acting as Master) will retain its acting Master status in order to avoid disruption to the functioning stack. The deferring Master will temporarily assume a role as Backup.

If both the Master and Backup are rebooted, the switches will assume their originally configured roles.

If, while the stack is still split, the Backup (acting as Master) is explicitly reconfigured to become a regular Master, then when the split stacks are finally merged, the Master with the lowest MAC address will become the new active Master for the entire stack.

## Merging Independent Stacks

If switches from different stacks are linked together in a stack topology without first reconfiguring their roles as recommended, it is possible that more than one switch in the stack might be configured as a Master.

Although all switches which are configured for stacking and joined by stacking links are recognized as potential stack participants by any operational Master switches, they are not brought into operation within the stack until explicitly assigned (or “bound”) to a specific Master switch.

Consider two independent stacks, Stack A and Stack B, which are merged into one stacking topology. The stacks will behave independently until the switches in Stack B are bound to Master A (or vice versa). In this example, once the Stack B switches are bound to Master A, Master A will automatically reconfigure them to operate as Stack A Members, regardless of their original status within Stack B.

However, for purposes of future Backup selection, reconfigured Masters retain their identity as configured Masters, even though they otherwise act as Members and lose all settings pertaining to their original stacks.

## Backup Switch Selection

An operational stack can have one optional Backup at any given time. Only the Backup specified in the active Master’s configuration is eligible to take over current stack control when the Master is rebooted or fails. The Master automatically synchronizes configuration settings with the specified Backup to facilitate the transfer of control functions.

The Backup retains its status until one of the following occurs:

- The Backup setting is deleted or changed using the following command from the active Master:

```
>> # /cfg/stack/backup <csnum 1-8, or 0 to delete>
```

- A new Master assumes operation as active Master in the stack, and uses its own configured Backup settings.
- The active Master is rebooted with the boot configuration set to factory defaults (clearing the Backup setting).

## Master Failover

When the Master switch is present, it controls the operation of the stack and pushes configuration information to the other switches in the stack. If the active Master fails, then the designated Backup (if one is defined in the Master's configuration) becomes the new acting Master and the stack continues to operate normally.

## Secondary Backup

When a Backup takes over stack control operations, if any other configured Masters (acting as Member switches) are available within the stack, the Backup will select one as a secondary Backup. The primary Backup automatically reconfigures the secondary Backup and specifies itself (the primary Backup) as the new Backup in case the secondary fails. This prevents the chain of stack control from migrating too far from the original Master and Backup configuration intended by the administrator.

## Master Recovery

If the prior Master recovers in a functioning stack where the Backup has assumed stack control, the prior Master does not reassert itself as the stack Master. Instead, the prior Master will assume a role as a secondary Backup to avoid further stack disruption.

Upon stack reboot, the Master and Backup will resume their regular roles.

## No Backup

If a Backup is not configured on the active Master, or the specified Backup is not operating, then if the active Master fails, the stack will reboot without an active Master.

When a group of stacked switches are rebooted without an active Master present, the switches are considered to be *isolated*. All isolated switches in the stack are placed in a `WAITING` state until a Master appears. During this `WAITING` period, all the external ports and internal server ports of these Member switches are placed into operator-disabled state. Without the Master, a stack cannot respond correctly to networking events.

## Stack Member Identification

Each switch in the stack has two numeric identifiers, as follows:

- **Attached Switch Number** (`asnum`)  
An `asnum` is automatically assigned by the Master switch, based on each Member switch's physical connection in relation to the Master. The `asnum` is mainly used as an internal ID by the Master switch and is not user-configurable.
- **Configured Switch Number** (`csnum`):  
The `csnum` is the logical switch ID assigned by the stack administrator. The `csnum` is used in most stacking-related configuration commands and switch information output. It is also used as a port prefix to distinguish the relationship between the ports on different switches in the stack.

It is recommended that `asnum 1` and `csnum 1` be used for identifying the Master switch. By default, `csnum 1` is assigned to the Master. If `csnum 1` is not available, the lowest available `csnum` is assigned to the Master.



---

## Configuring a Stack

### Configuration Overview

This section provides procedures for creating a stack of switches. The high-level procedure is as follows:

- Choose one Master switch for the entire stack.
- Set all stack switches to stacking mode.
- Configure the same stacking VLAN for all switches in the stack.
- Configure the desired stacking interlinks.
- Configure an external IP interface on the Master (if external management is desired).
- Bind Member switches to the Master.
- Assign a Backup switch.

These tasks are covered in detail in the following sections.

### Best Configuration Practices

The following are guidelines for building an effective switch stack:

- Always connect the stack switches in a complete ring topology (see [Figure 19 on page 178](#)).
- Avoid disrupting the stack connections unnecessarily while the stack is in operation.
- For enhanced redundancy when creating port trunks, include ports from different stack members in the trunks.
- Avoid altering the stack `asnum` and `csnum` definitions unnecessarily while the stack is in operation.
- When in stacking mode, the highest QoS priority queue is reserved for internal stacking requirements. Therefore, only seven priority queues will be available for regular QoS use.
- Configure only as many QoS levels as necessary. This allows the best use of packet buffers.

## Configuring Each Switch in a Stack

To configure each switch for stacking, connect to the internal management IP interface for each switch (assigned by the management system) and use the CLI to perform the following steps.

**Note:** IPv6 is not supported in stacking mode. IP interfaces must use IPv4 addressing for proper stack configuration.

1. On each switch, enable stacking:

```
>> # /boot/stack/ena
```

2. On each switch, set the stacking membership mode.

By default, each switch is set to Member mode. However, one switch must be set to Master mode. Use the following command on only the designated Master switch:

```
>> Boot Stacking# mode master
```

**Note:** If any Member switches are incorrectly set to Master mode, use the `mode member` option to set them back to Member mode.

3. On each switch, configure the stacking VLAN (or use the default setting).

Although any VLAN (except VLAN 1) may be defined for stack traffic, it is highly recommended that the default, VLAN 4090 as shown below, be reserved for stacking.

```
>> Boot Stacking# vlan 4090
```

4. On each switch, designate the stacking links.

To create the recommended topology, at least two 10Gb external ports on each switch should be dedicated to stacking. By default, 10Gb Ethernet ports EXT1 and EXT2 are used. Use the following command to specify the links to be used in the stacking trunk:

```
>> Boot Stacking# stktrnk <list of port names or aliases>
```

5. On each switch, perform a reboot:

```
>> # /boot/reset
```


6. Physically connect the stack trunks.

To create the recommended topology, attach the two designated stacking links in a bidirectional ring. As shown in [Figure 19](#), connect each switch in turn to the next, starting with the Master switch. To complete the ring, connect the last Member switch back to the Master.

Figure 19. Example of Stacking Connections

**Note:** The stacking feature is designed such that the stacking links in a ring topology do not result in broadcast loops. The stacking ring is thus valid (no stacking links are blocked), even when Spanning Tree protocol is enabled.

Once the stack trunks are connected, the switches will perform low-level stacking configuration.



**Note:** Although stack link failover/failback is accomplished on a sub-second basis, to maintain the best stacking operation and avoid traffic disruption, it is recommended not to disrupt stack links after the stack is formed.

## Additional Master Configuration

Once the stack links are connected, access the internal management IP interface of the Master switch (assigned by the management system) and complete the configuration.

## Configuring an External IPv4 Address for the Stack

In addition to the internal management IP interface assigned to the Master switch by the management system, a standard switch IP interface can be used for connecting to and managing the stack externally. Configure an IP interface with the following:

- Stack IPv4 address and mask
- IPv4 default gateway address
- VLAN number used for external access to the stack (rather than the internal VLAN 4090 used for inter-stack traffic)

Use the following commands:

```
>> # /cfg/13/if <IP interface number>
>> IP Interface# addr <stack IPv4 address>
>> IP Interface# maskplen <IPv4 subnet mask>
>> IP Interface# vlan <VLAN ID>
>> IP Interface# ena
>> # /cfg/13/gw <gateway number>
>> Default gateway# addr <gateway IPv4 address>
>> Default gateway# ena
```

Remember to apply and save the configuration.

One completed, stack management can be performed via Telnet or BBI (if enabled) from any point in the configured VLAN, using the IPv4 address of the configured IP interface.

In the event that the Master switch fails, if a Backup switch is configured (see [“Assigning a Stack Backup Switch” on page 181](#)), the external IP interface for the stack will still be available. Otherwise, the administrator must manage the stack through the internal management IP interface assigned to the Backup switch by the management system.

## Locating an External Stack Interface

If the IPv4 address and VLAN of an external IP interface for the stack is unknown, connect to the Master switch using the IPv4 address assigned by the management system, and execute the following command:

```
>> # /info/13/if
```

## Viewing Stack Connections

To view information about the switches in a stack, execute the following command:

```
>> # /info/stack/switch

Stack name:
Local switch is the master.

Local switch:
  csnum          - 1
  MAC            - 00:00:00:00:01:00
  UUID           - 0d258000000000000000000000000000145ee06000
  Bay Number     - 7
  Switch Type    - 7 (1-10GbESM)
  Chassis Type   - 2 (BladeCenter H)
  Switch Mode (cfg) - Master
  Priority        - 225
  Stack MAC      - 00:00:00:00:01:1f

Master switch:
  csnum          - 1
  MAC            - 00:00:00:00:01:00
  UUID           - 0d258000000000000000000000000000145ee06000
  Bay Number     - 7

Backup switch:
  csnum          - 2
  MAC            - 00:22:00:ad:43:00
  UUID           - 0d258000000000000000000000000000145ee06000
  Bay Number     - 8

Configured Switches:
-----
csnum          UUID                      BAY    MAC                      asnum
-----
C1  0d258000000000000000000000000000145ee06000  7  00:00:00:00:01:00  A1
C2  0d258000000000000000000000000000145ee06000  8  00:22:00:ad:43:00  A3
C3  0d258000000000000000000000000000145ee06000  9  00:11:00:af:ce:00  A2

Attached Switches in Stack:
-----
asnum          UUID                      BAY    MAC                      csnum  State
-----
A1  0d258000000000000000000000000000145ee06000  7  00:00:00:00:01:00  C1  IN_STACK
A2  0d258000000000000000000000000000145ee06000  7  00:11:00:af:ce:00  C3  IN_STACK
A3  0d258000000000000000000000000000145ee06000  7  00:22:00:ad:43:00  C2  IN_STACK
```

## Binding Members to the Stack

You can bind Member switches to a stack `csnum` using either their `asnum` or its chassis UUID and bay number:

```
>> # /cfg/stack/swnum <csnum>/uuid <chassis UUID>
>> # /cfg/stack/swnum <csnum>/bay <bay number>

-or-

>> # /cfg/stack/swnum <csnum>/bind <asnum>
```

To remove a Member switch, execute the following command:

```
>> # /cfg/stack/swnum <csnum>/del
```

## Assigning a Stack Backup Switch

To define a Member switch as a Backup (optional) which will assume the Master role if the Master switch should fail, execute the following command:

```
>> # /cfg/stack/backup <csnum>
```

---

## Managing a Stack

### Managing through the Stack Master

The stack is managed primarily through the Master switch. The Master switch then pushes configuration changes and run-time information to the Member switches.

Use Telnet or the Browser-Based Interface (BBI) to access the Master, as follows:

- Use the management IP address assigned to the Master by the management system.
- On any switch in the stack, connect to any port that is not part of an active trunk, and use the IP address of any IP interface to access the stack.

### Connecting to Member Switches


Though the stack is managed primarily through the Master switch, limited management functions are available on any Member switch in the stack.

Using Telnet to access the management IP address of any Member switch, the administrator can view a wide variety of switch information and can change some of the Member stacking properties.

Other forms of access (such as BBI or SNMP) are not available through Member switch IP management interfaces.

### Stacking Port Numbers

Once a stack is configured, port numbers are displayed throughout the BBI using the `cnum` to identify the switch, followed by the switch port number. For example:



### Stacking VLANs

VLAN 4090 is the default VLAN reserved for internal traffic on stacking ports.

**Note:** Do not use VLAN 4090 for any purpose other than internal stacking traffic.

### Rebooting Stacked Switches using the CLI

The administrator can reboot individual switches in the stack, or the entire stack using the following commands:

>> # /boot/reset	(Reboot all switches in the stack)
>> # /boot/reset master	(Reboot only the stack Master)
>> # /boot/reset <cnum list>	(Reboot only the listed switches)

## Rebooting Stacked Switches using the BBI

The **Configure > System > Config/Image Control** window allows the administrator to perform a reboot of individual switches in the stack, or the entire stack. The following table describes the stacking Reboot buttons.

Table 15. Stacking Boot Management buttons

Field	Description
Reboot Stack	Performs a software reboot/reset of all switches in the stack. The software image specified in the Image To Boot drop-down list becomes the active image.
Reboot Master	Performs a software reboot/reset of the Master switch. The software image specified in the Image To Boot drop-down list becomes the active image.
Reboot Switches	Performs a reboot/reset on selected switches in the stack. Select one or more switches in the drop-down list, and click Reboot Switches. The software image specified in the Image To Boot drop-down list becomes the active image.

The **Update Image/Cfg** section of the window applies to the Master. When a new software image or configuration file is loaded, the file first loads onto the Master, and the Master pushes the file to all other switches in the stack, placing it in the same software or configuration bank as that on the Master. For example, if the new image is loaded into image 1 on the Master switch, the Master will push the same firmware to image 1 on each Member switch.

## Managing Stack Link Bandwidth

In a stack topology, packets received on a switch that is part of a stack may be passed on to any of the trunk links on any of the stack switches for egress. Configuring local preference ensures that packets received on a particular switch are sent out only from one of the trunk links on that same switch. The ingress packets are restricted from being passed on to other trunk links on other switches in the stack, thus protecting the bandwidth of the stacking links. By default, local preference is disabled.

To enable local preference for the stack, use the following command:

```
>> Main# /cfg/thash/localprf enable
```

Both ingress and egress traffic may flow on the trunk. However, local preference can be configured only for egress traffic, and is applied only to known unicast traffic. Regular hashing mechanism is applied to the broadcast, unknown multicast, and unknown unicast traffic. When enabled, all trunk links configured on the stack will automatically be configured for local preference.

**Note:** Compared to local preference being disabled, there is a higher probability of the local trunk link getting oversubscribed and traffic being discarded when local preference is enabled.

---

## Upgrading Software in an Existing Stack

Upgrade all stacked switches at the same time. The Master controls the upgrade process. Use the following procedure to perform a software upgrade for a stacked system.

1. Load new software on the Master.

The Master pushes the new software image to all Members in the stack, as follows:

- If the new software is loaded into image 1, the Master pushes the software into image 1 on all Members.
- If loaded into image 2, the Master pushes the software into image 2 on all Members.

The software push can take several minutes to complete.

2. Verify that the software push is complete. Use either the BBI or the ISCLI:

- From the BBI, go to Dashboard > Stacking > Push Status and view the Image Push Status Information, or
- From the CLI, use following command to verify the software push:

```
>> # info/stack/pushstat

Image 1 transfer status info:
  Switch 00:16:60:f9:33:00:
    last receive successful
  Switch 00:17:ef:c3:fb:00:
    not received - file not sent or transfer in progress

Image 2 transfer status info:
  Switch 00:16:60:f9:33:00:
    last receive successful
  Switch 00:17:ef:c3:fb:00:
    last receive successful

Boot image transfer status info:
  Switch 00:16:60:f9:33:00:
    last receive successful
  Switch 00:17:ef:c3:fb:00:
    last receive successful

Config file transfer status info:
  Switch 00:16:60:f9:33:00:
    last receive successful
  Switch 00:17:ef:c3:fb:00:
    last receive successful
```

3. Reboot all switches in the stack. Use either the CLI or the BBI.

- From the BBI, select Configure > System > Config/Image Control. Click Reboot Stack.
- From the CLI, use the following command:

```
>> # /boot/reset
```



4. Once the switches in the stack have rebooted, verify that all of them are using the same version of firmware. Use either the CLI or the BBI.
  - From the BBI, open Dashboard > Stacking > Stack Switches and view the Switch Firmware Versions Information from the Attached Switches in Stack.
  - From the CLI, use the following command:

```
>> # /info/stack/vers
Switch Firmware Versions:
-----
asnum  csnum      MAC          S/W   Version  Serial #
-----
A1     C1         00:00:00:00:01:00  image1  0.0.0.0  CH49000000
A2     C2         00:11:00:af:ce:00  image1  0.0.0.0  CH49000001
A3           00:22:00:ad:43:00  image1  0.0.0.0  CH49000002
```

---

## Replacing or Removing Stacked Switches

Stack switches may be replaced or removed while the stack is in operation. However, the following conditions must be met in order to avoid unnecessary disruption:

- If removing an active Master switch, make sure that a valid Backup exists in the stack.
- It is best to replace only one switch at a time.
- If replacing or removing multiple switches in a ring topology, when one switch has been properly disconnected (see the procedures that follow), any adjacent switch can also be removed.
- Removing any two, non-adjacent switches in a ring topology will divide the ring and disrupt the stack.

Use the following procedures to replace a stack switch.

### Removing a Switch from the Stack

1. Make sure the stack is configured in a ring topology.

**Note:** When an open-ended daisy-chain topology is in effect (either by design or as the result of any failure of one of the stacking links in a ring topology), removing a stack switch from the interior of the chain can divide the chain and cause serious disruption to the stack operation.

2. If removing a Master switch, make sure that a Backup switch exists in the stack, then turn off the Master switch via the management system, or reset the Master. For example:

```
>> # /boot/reset master
```

This will force the Backup switch to assume Master operations for the stack.

3. Remove the stack link cables from the old switch only.
4. Disconnect all network cables from the old switch only.
5. Remove the old switch from the chassis.

### Installing the New Switch or Healing the Topology

If using a ring topology, but not installing a new switch for the one removed, close the ring by connecting the open stack links together, essentially bypassing the removed switch.

Otherwise, if replacing the removed switch with a new unit, use the following procedure:

1. Make sure the new switch meets the stacking requirements on [page 172](#).
2. Place the new switch in its determined place according to the *1/10Gb Uplink ESM Installation Guide*.
3. Connect to the CLI of the new switch (not the stack interface)
4. Enable stacking:

```
>> # /boot/stack/ena
```

5. Set the stacking mode.

By default, each switch is set to Member mode. However, if the incoming switch has been used in another stacking configuration, it may be necessary to ensure the proper mode is set.

- If replacing a Member or Backup switch:

```
>> # /boot/stack/mode member
```

- If replacing a Master switch:

```
>> # /boot/stack/mode master
```

6. Configure the stacking VLAN on the new switch, or use the default setting.

Although any VLAN may be defined for stack traffic, it is highly recommended that the default, VLAN 4090, be reserved for stacking (shown below).

```
>> # /boot/stack/vlan 4090
```

7. Designate the stacking links.

It is recommended that you designate the same number of external 10Gb ports for stacking as the switch being replaced. At least one 10Gp port is required. Use the following command to specify the links to be used in the stacking trunk:

```
>> # /boot/stack/stktrnk <list of port names or aliases>
```

8. Attach the required stack link cables to the designated stack links on the new switch.

9. Attach the desired network cables to the new switch.

10. Reboot the new switch:

```
>> # /boot/reset
```

When the new switch boots, it will join the existing stack. Wait for this process to complete.

## Binding the New Switch to the Stack

1. Log in to the stack interface.

**Note:** If replacing the Master switch, be sure to log in to the stack interface (hosted temporarily on the Backup switch) rather than logging in directly to the newly installed Master.

2. From the stack interface, assign the `csnum` for the new switch.

You can bind Member switches to a stack `csnum` using either the new switch's `asnum` or its chassis UUID and bay number:

```
>> # /cfg/stack/swnum <csnum>/uuid <chassis UUID>
>> # /cfg/stack/swnum <csnum>/bay <bay number>

-or-

>> # /cfg/stack/swnum <csnum>/bind <asnum>
```

3. Apply and save your configuration changes.

**Note:** If replacing the Master switch, the Master will not assume control from the Backup unless the Backup is rebooted or fails.

---

## ISCLI Stacking Commands

Stacking-related ISCLI commands are listed below. For details on specific commands, see the *1/10Gb Uplink ESM ISCLI Reference*.

- [no] boot stack enable
- boot stack hlgig-trunk *<port list>*
- boot stack mode master|member
- boot stack push-image boot-image|image1|image2 *<asnum>*
- boot stack vlan *<VLAN>* *<asnum>*|master|backup|all
- default boot stack *<asnum>*|master|backup|all
- [no] logging log stacking
- no stack backup
- no stack name
- no stack switch-number *<csnum>*
- show boot stack *<asnum>*|master|backup|all
- show stack attached-switches
- show stack backup
- show stack dynamic
- show stack link
- show stack name
- show stack path-map [*<csnum>*]
- show stack push-status
- show stack switch
- show stack switch-number [*<csnum>*]
- show stack version
- stack backup *<csnum>*
- stack name *<word>*
- stack switch-number *<csnum>* bind *<asnum>*
- stack switch-number *<csnum>* universal-unic-id *<chassis UUID>*  
[bay *<bay number>*]
- stack switch-number *<csnum>* bay *<bay number>*  
[universal-unic-id *<chassis UUID>*]



---

## Chapter 12. Virtualization

Virtualization allows resources to be allocated in a fluid manner based on the logical needs of the data center, rather than on the strict, physical nature of components. The following virtualization features are included in IBM Networking OS 7.4 on the 1/10Gb Uplink ESM (GbESM):

- Virtual Local Area Networks (VLANs)  
VLANs are commonly used to split groups of networks into manageable broadcast domains, create logical segmentation of workgroups, and to enforce security policies among logical network segments.  
For details on this feature, see [“VLANs” on page 107](#).
- Port trunking  
A port trunk pools multiple physical switch ports into a single, high-bandwidth logical link to other devices. In addition to aggregating capacity, trunks provides link redundancy.  
For details on this feature, see [“Ports and Trunking” on page 125](#).
- Stacking  
Multiple switches (from the same or different chassis) can be aggregated into a single super-switch, combining port capacity while at the same time simplifying their management. IBM N/OS 7.4 supports one stack with up to eight switches.  
For details on this feature, see [“Stacking” on page 171](#).
- VMready  
The switch’s VMready software makes it *virtualization aware*. Servers that run hypervisor software with multiple instances of one or more operating systems can present each as an independent *virtual machine* (VM). With VMready, the switch automatically discovers virtual machines (VMs) connected to switch.  
For details on this feature, see [“VMready” on page 193](#).

N/OS virtualization features provide a highly-flexible framework for allocating and managing switch resources.





---

## Chapter 13. VMready

Virtualization is used to allocate server resources based on logical needs, rather than on strict physical structure. With appropriate hardware and software support, servers can be virtualized to host multiple instances of operating systems, known as virtual machines (VMs). Each VM has its own presence on the network and runs its own service applications.

Software known as a *hypervisor* manages the various virtual entities (VEs) that reside on the host server: VMs, virtual switches, and so on. Depending on the virtualization solution, a virtualization management server may be used to configure and manage multiple hypervisors across the network. With some solutions, VMs can even migrate between host hypervisors, moving to different physical hosts while maintaining their virtual identity and services.

The IBM Networking OS 7.4 VMready feature supports up to 1024 VEs in a virtualized data center environment. The switch automatically discovers the VEs attached to switch ports, and distinguishes between regular VMs, Service Console Interfaces, and Kernel/Management Interfaces in a VMware® environment.

VEs may be placed into VM groups on the switch to define communication boundaries: VEs in the same VM group may communicate with each other, while VEs in different groups may not. VM groups also allow for configuring group-level settings such as virtualization policies and ACLs.

The administrator can also pre-provision VEs by adding their MAC addresses (or their IPv4 address or VM name in a VMware environment) to a VM group. When a VE with a pre-provisioned MAC address becomes connected to the switch, the switch will automatically apply the appropriate group membership configuration.

The GbESM with VMready also detects the migration of VEs across different hypervisors. As VEs move, the GbESM NMotion™ feature automatically moves the appropriate network configuration as well. NMotion gives the switch the ability to maintain assigned group membership and associated policies, even when a VE moves to a different port on the switch.

VMready also works with VMware Virtual Center (vCenter) management software. Connecting with a vCenter allows the GbESM to collect information about more distant VEs, synchronize switch and VE configuration, and extend migration properties.

---

## VE Capacity

When VMready is enabled, the switch will automatically discover VEs that reside in hypervisors directly connected on the switch ports. IBM N/OS 7.4 supports up to 1024 VEs. Once this limit is reached, the switch will reject additional VEs.

**Note:** In rare situations, the switch may reject new VEs prior to reaching the supported limit. This can occur when the internal hash corresponding to the new VE is already in use. If this occurs, change the MAC address of the VE and retry the operation. The MAC address can usually be changed from the virtualization management server console (such as the VMware Virtual Center).

---

## VM Group Types

VEs, as well as internal ports, external ports, static trunks and LACP trunks, can be placed into VM groups on the switch to define virtual communication boundaries. Elements in a given VM group are permitted to communicate with each other, while those in different groups are not. The elements within a VM group automatically share certain group-level settings.

There are two different types of VM groups:

- Local VM groups are maintained locally on the switch. Their configuration is not synchronized with hypervisors.
- Distributed VM groups are automatically synchronized with a virtualization management server (see [“Assigning a vCenter” on page 201](#)).

Each VM group type is covered in detail in the following sections.

---

## Local VM Groups

The configuration for local VM groups is maintained on the switch (locally) and is not directly synchronized with hypervisors. Local VM groups may include only local elements: local switch ports and trunks, and only those VEs connected to one of the switch ports or pre-provisioned on the switch.

Local VM groups support limited VE migration: as VMs and other VEs move to different hypervisors connected to different ports on the switch, the configuration of their group identity and features moves with them. However, VE migration to and from more distant hypervisors (those not connected to the GbESM, may require manual configuration when using local VM groups.

### Configuring a Local VM Group

Local VM groups are configured in the VM Group menu:

```
>> # /cfg/virt/vmgroup <VM group number>
```

Within the VM Group menu, use the following commands to assign group properties and membership:

vlan <VLAN number>	(Specify the group VLAN)
vmap <VMAP number>	(Specify VMAP number)
tag ena dis	(Set VLAN tagging on ports)
addvm <MAC>   <index>   <UUID>   <IPv4 address>   <name>	(Add VM member to group)
remvm <MAC>   <index>   <UUID>   <IPv4 address>   <name>	(Remove VM member)
addport <port alias or number>	(Add port member to group)
remport <port alias or number>	(Remove port member)
addtrunk <trunk group number>	(Add static trunk to group)
remtrunk <trunk group number>	(Remove static trunk)
addkey <LACP trunk key>	(Add LACP trunk to group)
remkey <LACP trunk key>	(Remove LACP trunk)
stg <Spanning Tree group>	(Add STG to group)
del	(Clear the VM group config.)

The following rules apply to the local VM group configuration commands:

- **addkey** or **remkey**: Add or remove LACP trunks to the group.
- **addport** or **remport**: Add or remove internal or external switch ports to the group.
- **addtrunk** or **remtrunk**: Add or remove static port trunks to the group.
- **addprof** or **remprof**: The profile options are not applicable to local VM groups. Only distributed VM groups may use VM profiles (see [“VM Profiles” on page 197](#)).
- **stg**: The group may be assigned to a Spanning-Tree group for broadcast loop control (see [“Spanning Tree Protocols” on page 137](#)).
- **tag**: Enable or disable VLAN tagging for the VM group. If the VM group contains ports which also exist in other VM groups, tagging should be enabled in both VM groups.

- `vlan`: Each VM group must have a unique VLAN number. This is required for local VM groups. If one is not explicitly configured, the switch will automatically assign the next unconfigured VLAN when a VE or port is added to the VM group.
- `vmap`: Each VM group may optionally be assigned a VLAN-based ACL (see [“VLAN Maps” on page 205](#)).
- `addvm` or `remvm`: Add or remove VMs.

VMs and other VEs are primarily specified by MAC address. They can also be specified by UUID or by the index number as shown in various VMready information output (see [“VMready Information Displays” on page 207](#)).

If VMware Tools software is installed in the guest operating system (see VMware documentation for information on installing recommended tools), VEs may also be specified by IPv4 address or VE name. However, if there is more than one possible VE for the input, the switch will display a list of candidates and prompt for a specific MAC address.

Only VEs currently connected to the switch port (local) or pending connection (pre-provisioned) are permitted in local VM groups.

- `del`: Clear all settings associated with the VM group number.

---

## Distributed VM Groups

Distributed VM groups allow configuration profiles to be synchronized between the GbESM and associated hypervisors and VEs. This allows VE configuration to be centralized, and provides for more reliable VE migration across hypervisors.

Using distributed VM groups requires a virtualization management server. The management server acts as a central point of access to configure and maintain multiple hypervisors and their VEs (VMs, virtual switches, and so on).

The GbESM must connect to a virtualization management server before distributed VM groups can be used. The switch uses this connection to collect configuration information about associated VEs, and can also automatically push configuration profiles to the virtualization management server, which in turn configures the hypervisors and VEs. See [“Virtualization Management Servers” on page 201](#) for more information.

## VM Profiles

VM profiles are required for configuring distributed VM groups. They are not used with local VM groups. A VM profile defines the VLAN and virtual switch bandwidth shaping characteristics for the distributed VM group. The switch distributes these settings to the virtualization management server, which in turn distributes them to the appropriate hypervisors for VE members associated with the group.

Creating VM profiles is a two part process. First, the VM profile is created as shown in the following command on the switch:

```
>> # /cfg/virt/vmprof/create <profile name>
```

Next, the profile must be edited and configured using the following configuration commands:

```
>> # /cfg/virt/vmprof/edit <profile name>
>> # vlan <VLAN number>
>> # shaping <average bandwidth> <burst size> <peak>
```

For virtual switch bandwidth shaping parameters, average and peak bandwidth are specified in kilobits per second (a value of 1000 represents 1 Mbps). Burst size is specified in kilobytes (a value of 1000 represents 1 MB).

**Note:** The bandwidth shaping parameters in the VM profile are used by the hypervisor virtual switch software. To set bandwidth policies for individual VEs, see [“VM Policy Bandwidth Control” on page 206](#).

Once configured, the VM profile may be assigned to a distributed VM group as shown in the following section.

## Initializing a Distributed VM Group

**Note:** A VM profile is required before a distributed VM group may be configured. See [“VM Profiles” on page 197](#) for details.

Once a VM profile is available, a distributed VM group may be initialized using the following configuration command:

```
>> # /cfg/virt/vmgroup <VM group number> /addprof <VM profile name>
```

Only one VM profile can be assigned to a given distributed VM group. To change the VM profile, the old one must first be removed.

**Note:** The VM profile can be added only to an empty VM group (one that has no VLAN, VMs, or port members). Any VM group number currently configured for a local VM group (see [“Local VM Groups” on page 195](#)) cannot be converted and must be deleted before it can be used for a distributed VM group.

## Assigning Members

VMs, ports, and trunks may be added to the distributed VM group only after the VM profile is assigned.

When you add a member to a distributed VM group, a port group is created on the virtual switch (or distributed virtual switch; See [“Virtual Distributed Switch” on page 199](#)) to which the member is connected.

Group members are added, pre-provisioned, or removed from distributed VM groups in the same manner as with local VM groups ([“Local VM Groups” on page 195](#)), with the following exceptions:

- VMs: VMs and other VEs are not required to be local. Any VE known by the virtualization management server can be part of a distributed VM group.
- The VM group `vlan` option (see [page 196](#)) cannot be used with distributed VM groups. For distributed VM groups, the VLAN is assigned in the VM profile.

## Synchronizing the Configuration

When the configuration for a distributed VM group is applied (using the CLI `apply` command), the switch updates the assigned virtualization management server. The management server then distributes changes to the appropriate hypervisors.

For VM membership changes, hypervisors modify their internal virtual switch port groups, adding or removing internal port memberships to enforce the boundaries defined by the distributed VM groups. Virtual switch port groups created in this fashion can be identified in the virtual management server by the name of the VM profile, formatted as follows:

```
IBM_<VM profile name>
```

Using the VM Group menu `addvm` command (`/cfg/virt/vmgroup <x> /addvm`) to add a server host interface to a distributed VM group does not create a new port group on the virtual switch or move the host. Instead, because the host interface already has its own virtual switch port group on the hypervisor, the VM profile settings are applied to its existing port group.

**Note:** When applying the distributed VM group configuration, the virtualization management server and associated hypervisors must take appropriate actions. If a hypervisor is unable to make requested changes, an error message will be displayed on the switch. Be sure to evaluate all error message and take the appropriate actions to be sure the expected changes are properly applied.

## Removing Member VEs

Removing a VE from a distributed VM group on the switch will have the following effects on the hypervisor:

- The VE will be moved to the `IBM_Default` port group in VLAN 0 (zero).
- Traffic shaping will be disabled for the VE.
- All other properties will be reset to default values inherited from the virtual switch.

---

## Virtual Distributed Switch

A virtual Distributed Switch (vDS ) allows the hypervisor's NIC to be attached to the vDS instead of its own virtual switch. The vDS connects to the vCenter and spans across multiple hypervisors in a datacenter. The administrator can manage virtual machine networking for the entire data center from a single interface. The vDS enables centralized provisioning and administration of virtual machine networking in the data center using the VMware vCenter server.

When a member is added to a distributed VM group, a distributed port group is created on the vDS. The member is then added to the distributed port group.

Distributed port groups on a vDS are available to all hypervisors that are connected to the vDS. Members of a single distributed port group can communicate with each other.

**Note:** vDS works with ESX 4.0 or higher versions.

To add a vDS, use the command:

```
>> # /oper/virt/vmware/dvswitch/add <datacenter-name> <dvSwitch-name> <dvSwitch-version>
```

## Prerequisites

Before adding a vDS on the GbESM, ensure the following:

- VMware vCenter is fully installed and configured and includes a “bladevm” administration account and a valid SSL certificate.
- A virtual distributed switch instance has been created on the vCenter. The vDS version must be higher or the same as the hypervisor version on the hosts.
- At least two hypervisors are configured.

## Guidelines

Before migrating VMs to a vDS, consider the following:

- At any one time, a VM NIC can be associated with only one virtual switch: to the hypervisor's virtual switch, or to the vDS.
- Management connection to the server must be ensured during the migration. The connection is via the Service Console or the Kernel/Management Interface.
- The vDS configuration and migration can be viewed in vCenter at the following locations:
  - vDS: Home > Inventory > Networking
  - vDS Hosts: Home > Inventory > Networking > vDS > Hosts

**Note:** These changes will not be displayed in the running configuration on the GbESM.

## Migrating to vDS

You can migrate VMs to the vDS using vCenter. The migration may also be accomplished using the operational commands on the GbESM available in the following CLI menus:

For VMware vDS operations:

```
>> # /oper/virt/vmware/dvswitch
```

For VMware distributed port group operations:

```
>> # /oper/virt/vmware/dpg
```



---

## Virtualization Management Servers

The GbESM can connect with a virtualization management server to collect configuration information about associated VEs. The switch can also automatically push VM group configuration profiles to the virtualization management server, which in turn configures the hypervisors and VEs, providing enhanced VE mobility.

One virtual management server must be assigned on the switch before distributed VM groups may be used. N/OS 7.4 currently supports only the VMware Virtual Center (vCenter).

### Assigning a vCenter

Assigning a vCenter to the switch requires the following:

- The vCenter must have a valid IPv4 address which is accessible to the switch (IPv6 addressing is not supported for the vCenter).
- A user account must be configured on the vCenter to provide access for the switch. The account must have (at a minimum) the following vCenter user privileges:
  - Network
  - Host Network > Configuration
  - Virtual Machine > Modify Device Settings

Once vCenter requirements are met, the following configuration command can be used on the GbESM to associate the vCenter with the switch:

```
>> # /cfg/virt/vmware/vcspec <vCenter IPv4 address> <username> [noauth]
```

This command specifies the IPv4 address and account username that the switch will use for vCenter access. Once entered, the administrator will be prompted to enter the password for the specified vCenter account.

The `noauth` option causes the switch to ignore SSL certificate authentication. This is required when no authoritative SSL certificate is installed on the vCenter.

**Note:** By default, the vCenter includes only a self-signed SSL certificate. If using the default certificate, the `noauth` option is required.

Once the vCenter configuration has been applied on the switch, the GbESM will connect to the vCenter to collect VE information.

### vCenter Scans

Once the vCenter is assigned, the switch will periodically scan the vCenter to collect basic information about all the VEs in the datacenter, and more detailed information about the local VEs that the switch has discovered attached to its own ports.

The switch completes a vCenter scan approximately every two minutes. Any major changes made through the vCenter may take up to two minutes to be reflected on the switch. However, you can force an immediate scan of the vCenter by using one of the following commands:

```
>> # /oper/virt/vmware/scan (Scan the vCenter)

-or-

>> # /info/virt/vm/dump -v -r (Scan vCenter and display result)
```

## Deleting the vCenter

To detach the vCenter from the switch, use the following configuration command:

```
>> # /cfg/virt/vmware/vcspec delete
```

**Note:** Without a valid vCenter assigned on the switch, any VE configuration changes must be manually synchronized.

Deleting the assigned vCenter prevents synchronizing the configuration between the GbESM and VEs. VEs already operating in distributed VM groups will continue to function as configured, but any changes made to any VM profile or distributed VM group on the switch will affect only switch operation; changes on the switch will not be reflected in the vCenter or on the VEs. Likewise, any changes made to VE configuration on the vCenter will no longer be reflected on the switch.

## Exporting Profiles

VM profiles for discovered VEs in distributed VM groups are automatically synchronized with the virtual management server and the appropriate hypervisors. However, VM profiles can also be manually exported to specific hosts before individual VEs are defined on them.

By exporting VM profiles to a specific host, IBM port groups will be available to the host's internal virtual switches so that new VMs may be configured to use them.

VM migration requires that the target hypervisor includes all the virtual switch port groups to which the VM connects on the source hypervisor. The VM profile export feature can be used to distribute the associated port groups to all the potential hosts for a given VM.

A VM profile can be exported to a host using the following command:

```
>> # /oper/virt/vmware/export <VM profile name> <host list> [<virtual switch name>]
```

The host list can include one or more target hosts, specified by host name, IPv4 address, or UUID, with each list item separated by a space. If the virtual switch name is omitted, the administrator will be prompted to select one from a list or to enter a new virtual switch name.

Once executed, the requisite port group will be created on the specified virtual switch. If the specified virtual switch does not exist on the target host, it will be created with default properties, but with no uplink connection to a physical NIC (the administrator must assign uplinks using VMware management tools).

## VMware Operational Commands

The GbESM may be used as a central point of configuration for VMware virtual switches and port groups using the VMware operational menu, available with the following CLI command:

```
>> # /oper/virt/vmware
```

---

## Pre-Provisioning VEs

VEs may be manually added to VM groups in advance of being detected on the switch ports. By pre-provisioning the MAC address of VEs that are not yet active, the switch will be able to later recognize the VE when it becomes active on a switch port, and immediately assign the proper VM group properties without further configuration.

Undiscovered VEs are added to or removed from VM groups using the following configuration commands:

>> # /cfg/virt/vmgroup <VM group number>	(Select VM group)
>> # addvm <VE MAC address>	(Add undiscovered VE)
>> # remvm <VE MAC address>	(Remove VE)

For the pre-provisioning of undiscovered VEs, a MAC address is required. Other identifying properties, such as IPv4 address or VM name permitted for known VEs, cannot be used for pre-provisioning.

---

## VLAN Maps

A VLAN map (VMAP) is a type of Access Control List (ACL) that is applied to a VLAN or VM group rather than to a switch port as with regular ACLs (see [“Access Control Lists” on page 93](#)). In a virtualized environment, VMAPs allow you to create traffic filtering and metering policies that are associated with a VM group VLAN, allowing filters to follow VMs as they migrate between hypervisors.

VMAPs are configured from the ACL menu, available with the following CLI command:

```
# /cfg/acl/vmap <VMAP ID (1-128)>
```

N/OS 7.4 supports up to 128 VMAPs. Individual VMAP filters are configured in the same fashion as regular ACLs, except that VLANs cannot be specified as a filtering criteria (unnecessary, since VMAPs are assigned to a specific VLAN or associated with a VM group VLAN).

Once a VMAP filter is created, it can be assigned or removed using the following commands:

- For a regular VLAN:

```
/cfg/12/vlan <VLAN ID>/vmap {add|rem} <VMAP ID> [intports|extports]
```

- For a VM group:

```
/cfg/virt/vmgroup <ID>/vmap {add|rem} <VMAP ID> [intports|extports]
```

**Note:** Each VMAP can be assigned to only one VLAN or VM group. However, each VLAN or VM group may have multiple VMAPs assigned to it.

The optional `intports` or `extports` parameter can be specified to apply the action (to add or remove the VMAP) for either the internal ports or external ports only. If omitted, the operation will be applied to all ports in the associated VLAN or VM group.

**Note:** VMAPs have a lower priority than port-based ACLs. If both an ACL and a VMAP match a particular packet, both filter actions will be applied as long as there is no conflict. In the event of a conflict, the port ACL will take priority, though switch statistics will count matches for both the ACL and VMAP.

---

## VM Policy Bandwidth Control

In a virtualized environment where VEs can migrate between hypervisors and thus move among different ports on the switch, traffic bandwidth policies must be attached to VEs, rather than to a specific switch port.

VM Policy Bandwidth Control allows the administrator to specify the amount of data the switch will permit to flow from a particular VE, without defining a complicated matrix of ACLs or VMAPs for all port combinations where a VE may appear.

## VM Policy Bandwidth Control Commands

VM Policy Bandwidth Control can be configured using the following configuration commands:

```
# /cfg/virt/vmpolicy/vmbwidth <VM MAC> | <index> | <UUID> | <IPv4 address> | <name>
# txrate <committed rate> <burst> [<ACL number>] (Set the VM to switch rate)
# bwctrl {ena|dis} (Set control on or off for VM)
# delete (Clear settings)
```

Bandwidth allocation can be defined for transmit (TX) traffic only. Because bandwidth allocation is specified from the perspective of the VE, the switch command for TX Rate Control (`txrate`) sets the data rate to be sent from the VM to the switch.

The *committed rate* is specified in multiples of 64 kbps, from 64 to 10,000,000. The maximum *burst* rate is specified as 32, 64, 128, 256, 1024, 2048, or 4096 kb. If both the committed rate and burst are set to 0, bandwidth control will be disabled.

When `txrate` is specified, the switch automatically selects an available ACL for internal use with bandwidth control. Optionally, if automatic ACL selection is not desired, a specific ACL may be selected. If there are no unassigned ACLs available, `txrate` cannot be configured.

## Bandwidth Policies vs. Bandwidth Shaping

VM Profile Bandwidth Shaping differs from VM Policy Bandwidth Control.

VM Profile Bandwidth Shaping (see [“VM Profiles” on page 197](#)) is configured per VM group and is enforced on the server by a virtual switch in the hypervisor. Shaping is unidirectional and limits traffic transmitted from the virtual switch to the GbESM. Shaping is performed prior to transmit VM Policy Bandwidth Control. If the egress traffic for a virtual switch port group exceeds shaping parameters, the traffic is dropped by the virtual switch in the hypervisor. Shaping uses server CPU resources, but prevents extra traffic from consuming bandwidth between the server and the GbESM. Shaping is not supported simultaneously on the same ports as vNICs.

VM Policy Bandwidth Control is configured per VE, and can be set independently for transmit traffic. Bandwidth policies are enforced by the GbESM. VE traffic that exceeds configured levels is dropped by the switch upon ingress. Setting `txrate` uses ACL resources on the switch.

Bandwidth shaping and bandwidth policies can be used separately or in concert.

---

## VMready Information Displays

The GbESM can be used to display a variety of VMready information.

**Note:** Some displays depict information collected from scans of a VMware vCenter and may not be available without a valid vCenter. If a vCenter is assigned (see [“Assigning a vCenter” on page 201](#)), scan information might not be available for up to two minutes after the switch boots or when VMready is first enabled. Also, any major changes made through the vCenter may take up to two minutes to be reflected on the switch unless you force an immediate vCenter scan (see [“vCenter Scans” on page 201](#)).

### Local VE Information

A concise list of local VEs and pre-provisioned VEs is available with the following command:

```
>> # /info/virt/vm/dump
```

IP Address	VMAC Address	Index	Port	VM Group (Profile)
*172.16.46.50	00:50:56:4e:62:00	4	INT3	
*172.16.46.10	00:50:56:4f:f2:00	2	INT4	
+172.16.46.51	00:50:56:72:ec:00	1	INT3	
+172.16.46.11	00:50:56:7c:1c:00	3	INT4	
172.16.46.25	00:50:56:9c:00:00	5	INT4	
172.16.46.15	00:50:56:9c:21:00	0	INT4	
172.16.46.35	00:50:56:9c:29:00	6	INT3	
172.16.46.45	00:50:56:9c:47:00	7	INT3	

Number of entries: 8  
\* indicates VMware ESX Service Console Interface  
+ indicates VMware ESX/ESXi VMKernel or Management Interface

**Note:** The Index numbers shown in the VE information displays can be used to specify a particular VE in configuration commands.

If a vCenter is available, more verbose information can be obtained using the following command option:

```
>> # /info/virt/vm/dump -v
```

Index	MAC Address, IP Address	Name (VM or Host), @Host (VMs only)	Port, VLAN	Group	Vswitch, Port Group
0	00:50:56:9c:21:2f 172.16.46.15	atom @172.16.46.10	INT4 500		vSwitch0 Eng_A
+1	00:50:56:72:ec:86 172.16.46.51	172.16.46.50	INT3 0		vSwitch0 VMkernel
*2	00:50:56:4f:f2:85 172.16.46.10	172.16.46.10	INT4 0		vSwitch0 Mgmt
+3	00:50:56:7c:1c:ca 172.16.46.11	172.16.46.10	INT4 0		vSwitch0 VMkernel
*4	00:50:56:4e:62:f5 172.16.46.50	172.16.46.50	INT3 0		vSwitch0 Mgmt
5	00:50:56:9c:00:c8 172.16.46.25	quark @172.16.46.10	INT4 0		vSwitch0 Corp
6	00:50:56:9c:29:29 172.16.46.35	particle @172.16.46.50	INT3 0		vSwitch0 VM Network
7	00:50:56:9c:47:fd 172.16.46.45	nucleus @172.16.46.50	INT3 0		vSwitch0 Finance

```
--
12 of 12 entries printed
* indicates VMware ESX Service Console Interface
+ indicates VMware ESX/ESXi VMkernel or Management Interface
```

To view additional detail regarding any specific VE, see [“vCenter VE Details” on page 210](#)).

## vCenter Hypervisor Hosts

If a vCenter is available, the following command displays the name and UUID of all VMware hosts, providing an essential overview of the data center:

```
>> # /info/virt/vm/vmware/hosts
```

UUID	Name(s), IP Address
00a42681-d0e5-5910-a0bf-bd23bd3f7800	172.16.41.30
002e063c-153c-dd11-8b32-a78dd1909a00	172.16.46.10
00f1fe30-143c-dd11-84f2-a8ba2cd7ae00	172.16.44.50
0018938e-143c-dd11-9f7a-d8defa4b8300	172.16.46.20
...	



Using the following command, the administrator can view more detailed vCenter host information, including a list of virtual switches and their port groups, as well as details for all associated VEs:

```
>> # /info/virt/vm/vmware/showhost {<host UUID>|<host IPv4 address>| <host name>}
Vswitches available on the host:
    vSwitch0

Port Groups and their Vswitches on the host:
    IBM_Default          vSwitch0
    VM Network           vSwitch0
    Service Console      vSwitch0
    VMkernel              vSwitch0

-----
MAC Address      00:50:56:9c:21:2f
Port             INT4
Type             Virtual Machine
VM vCenter Name  halibut
VM OS hostname   localhost.localdomain
VM IP Address    172.16.46.15
VM UUID          001c41f3-ccd8-94bb-1b94-6b94b03b9200
Current VM Host  172.16.46.10
Vswitch          vSwitch0
Port Group       IBM_Default
VLAN ID          0
...

```

## vCenter VEs

If a vCenter is available, the following command displays a list of all known VEs:

```
>> # /info/virt/vm/vmware/vms
UUID                                     Name(s), IP Address
-----
001cdf1d-863a-fa5e-58c0-d197ed3e3300  30vm1
001c1fba-5483-863f-de04-4953b5caa700  VM90
001c0441-c9ed-184c-7030-d6a6bc9b4d00  VM91
001cc06e-393b-a36b-2da9-c71098d9a700  vm_new
001c6384-f764-983c-83e3-e94fc78f2c00  sturgeon
001c7434-6bf9-52bd-c48c-a410da0c2300  VM70
001cad78-8a3c-9cbe-35f6-59ca5f392500  VM60
001cf762-a577-f42a-c6ea-090216c11800  30VM6
001c41f3-ccd8-94bb-1b94-6b94b03b9200  halibut, localhost.localdomain,
                                         172.16.46.15
001cf17b-5581-ea80-c22c-3236b89ee900  30vm5
001c4312-a145-bf44-7edd-49b7a2fc3800  vm3
001caf40-a40a-de6f-7b44-9c496f123b00  30VM7

```

## vCenter VE Details

If a vCenter is available, the following command displays detailed information about a specific VE:

```
>> # /info/virt/vm/vmware/showvm {<VM UUID>|<VM IPv4 address>|<VM name>}  
-----  
MAC Address      00:50:56:9c:21:2f  
Port             INT4  
Type             Virtual Machine  
VM vCenter Name  halibut  
VM OS hostname   localhost.localdomain  
VM IP Address    172.16.46.15  
VM UUID          001c41f3-ccd8-94bb-1b94-6b94b03b9200  
Current VM Host  172.16.46.10  
Vswitch          vSwitch0  
Port Group       IBM_Default  
VLAN ID          0
```

---

## VMready Configuration Example

This example has the following characteristics:

- A VMware vCenter is fully installed and configured prior to VMready configuration and includes a “bladevm” administration account and a valid SSL certificate.
- The distributed VM group model is used.
- The VM profile named “Finance” is configured for VLAN 30, and specifies NIC-to-switch bandwidth shaping for 1Mbps average bandwidth, 2MB bursts, and 3Mbps maximum bandwidth.
- The VM group includes four discovered VMs on internal switch ports INT1 and INT2, and one static trunk (previously configured) that includes external ports EXT3 and EXT4.

1. Enable the VMready feature.

```
>> # /cfg/virt/enavmr
```

2. Specify the VMware vCenter IPv4 address.

```
>> Virtualization# vmware/vcspec 172.16.100.1 bladevm
```

When prompted, enter the user password that the switch must use for access to the vCenter.

3. Create the VM profile.

```
>> VMware-specific Settings# ../vmprof/create Finance
>> VM Profiles# edit Finance
>> VM Profiles "Finance"# vlan 30
>> VM Profiles "Finance"# shaping 1000 2000 3000
```

4. Define the VM group.

```
>> VM Profiles "Finance"# ../vmgroup 1
>> VM group 1# addprof Finance
>> VM group 1# addvm arctic
>> VM group 1# addvm monster
>> VM group 1# addvm sierra
>> VM group 1# addvm 00:50:56:4f:f2:00
>> VM group 1# addtrunk 1
```

When VMs are added, the internal server ports on which they appear are automatically added to the VM group. In this example, there is no need to manually add ports INT1 and INT2.

5. If necessary, enable VLAN tagging for the VM group:

```
>> VM group 1# tag ena
```

**Note:** If the VM group contains ports which also exist in other VM groups, tagging should be enabled in both VM groups. In this example configuration, no ports exist in more than VM group.

6. Apply and save the configuration.

```
>> VM group 1# apply  
>> VM group 1# save
```

# Part 5: IP Routing

This section discusses Layer 3 switching functions. In addition to switching traffic at near line rates, the application switch can perform multi-protocol routing. This section discusses basic routing and advanced routing protocols:

- Basic Routing
- IPv6 Host Management
- Routing Information Protocol (RIP)
- Internet Group Management Protocol (IGMP)
- Border Gateway Protocol (BGP)
- Open Shortest Path First (OSPF)



---

## Chapter 14. Basic IP Routing

This chapter provides configuration background and examples for using the 1/10Gb Uplink ESM (GbESM) to perform IP routing functions. The following topics are addressed in this chapter:

- [“IP Routing Benefits” on page 216](#)
- [“Routing Between IP Subnets” on page 216](#)
- [“Subnet Routing Example” on page 218](#)
- [“Dynamic Host Configuration Protocol” on page 222](#)

---

## IP Routing Benefits

The GbESM uses a combination of configurable IP switch interfaces and IP routing options. The switch IP routing capabilities provide the following benefits:

- Connects the server IP subnets to the rest of the backbone network.
- Provides the ability to route IP traffic between multiple Virtual Local Area Networks (VLANs) configured on the switch.

---

## Routing Between IP Subnets

The physical layout of most corporate networks has evolved over time. Classic hub/router topologies have given way to faster switched topologies, particularly now that switches are increasingly intelligent. The GbESM is intelligent and fast enough to perform routing functions on par with wire-speed Layer 2 switching.

The combination of faster routing and switching in a single device provides another service—it allows you to build versatile topologies that account for legacy configurations.

For example, consider a corporate campus that has migrated from a router-centric topology to a faster, more powerful, switch-based topology. As is often the case, the legacy of network growth and redesign has left the system with a mix of illogically distributed subnets.

This is a situation that switching alone cannot cure. Instead, the router is flooded with cross-subnet communication. This compromises efficiency in two ways:

- Routers can be slower than switches. The cross-subnet side trip from the switch to the router and back again adds two hops for the data, slowing throughput considerably.
- Traffic to the router increases, increasing congestion.


Even if every end-station could be moved to better logical subnets (a daunting task), competition for access to common server pools on different subnets still burdens the routers.

This problem is solved by using GbESMs with built-in IP routing capabilities. Cross-subnet LAN traffic can now be routed within the switches with wire speed Layer 2 switching performance. This not only eases the load on the router but saves the network administrators from reconfiguring each and every end-station with new IP addresses.



Take a closer look at the BladeCenter's GbESM in the following configuration example:

Figure 20. Switch-Based Routing Topology



The GbESM connects the Gigabit Ethernet and Fast Ethernet trunks from various switched subnets throughout one building. Common servers are placed on another subnet attached to the switch. A primary and backup router are attached to the switch on yet another subnet.

Without Layer 3 IP routing on the switch, cross-subnet communication is relayed to the default gateway (in this case, the router) for the next level of routing intelligence. The router fills in the necessary address information and sends the data back to the switch, which then relays the packet to the proper destination subnet using Layer 2 switching.

With Layer 3 IP routing in place on the GbESM, routing between different IP subnets can be accomplished entirely within the switch. This leaves the routers free to handle inbound and outbound traffic for this group of subnets.

## Subnet Routing Example

Prior to configuring, you must be connected to the switch Command Line Interface (CLI) as the administrator.

**Note:** For details about accessing and using any of the menu commands described in this example, see the *IBM Networking OS 7.4 Command Reference*.

1. Assign an IP address (or document the existing one) for each router and client workstation.

In the example topology in [Figure 20 on page 217](#), the following IP addresses are used:

Table 16. Subnet Routing Example: IP Address Assignments

Subnet	Devices	IP Addresses
1	Primary and Secondary Default Routers	205.21.17.1 and 205.21.17.2
2	First Floor Client Workstations	100.20.10.2-254
3	Second Floor Client Workstations	131.15.15.2-254
4	Common Servers	206.30.15.2-254

2. Assign an IP interface for each subnet attached to the switch.

Since there are four IP subnets connected to the switch, four IP interfaces are needed:

Table 17. Subnet Routing Example: IP Interface Assignments

Interface	Devices	IP Interface Address
IF 1	Primary and Secondary Default Routers	205.21.17.3
IF 2	First Floor Client Workstations	100.20.10.1
IF 3	Second Floor Client Workstations	131.15.15.1
IF 4	Common Servers	206.30.15.1

IP interfaces are configured using the following commands at the CLI:

```
>> # /cfg/13/if 1 (Select IP interface 1)
>> IP Interface 1# addr 205.21.17.3 (Assign IP address for the interface)
>> IP Interface 1# ena (Enable IP interface 1)
>> IP Interface 1# ../if 2 (Select IP interface 2)
>> IP Interface 2# addr 100.20.10.1 (Assign IP address for the interface)
>> IP Interface 2# ena (Enable IP interface 2)
>> IP Interface 2# ../if 3 (Select IP interface 3)
>> IP Interface 3# addr 131.15.15.1 (Assign IP address for the interface)
>> IP Interface 3# ena (Enable IP interface 3)
>> IP Interface 3# ../if 4 (Select IP interface 4)
>> IP Interface 4# addr 206.30.15.1 (Assign IP address for the interface)
>> IP Interface 4# ena (Enable IP interface 4)
```

3. Set each server and workstation's default gateway to the appropriate switch IP interface (the one in the same subnet as the server or workstation).
4. Configure the default gateways to the routers' addresses.

Configuring the default gateways allows the switch to send outbound traffic to the routers:

```
>> IP Interface 5# ../gw 1                (Select primary default gateway)
>> Default gateway 1# addr 205.21.17.1    (Assign IP address for primary router)
>> Default gateway 1# ena                 (Enable primary default gateway)
>> Default gateway 1# ../gw 2            (Select secondary default gateway)
>> Default gateway 2# addr 205.21.17.2    (Assign address for secondary router) >> Default
gateway 2# ena                            (Enable secondary default gateway)
```

5. Apply and verify the configuration.

```
>> Default gateway 2# # apply              (Make your changes active)
>> Default gateway 2# /cfg/13/cur          (View current IP settings)
```

Examine the resulting information. If any settings are incorrect, make the appropriate changes.

6. Save your new configuration changes.

```
>> IP# save                               (Save for restore after reboot)
```

## Using VLANs to Segregate Broadcast Domains

In the previous example, devices that share a common IP network are all in the same broadcast domain. If you want to limit the broadcasts on your network, you could use VLANs to create distinct broadcast domains. For example, as shown in the following procedure, you could create one VLAN for the client trunks, one for the routers, and one for the servers.

In this example, you are adding to the previous configuration.

1. Determine which switch ports and IP interfaces belong to which VLANs.

The following table adds port and VLAN information:

Table 18. Subnet Routing Example: Optional VLAN Ports

VLAN	Devices	IP Interface	Switch Port	VLAN #
1	First Floor Client Workstations	2	EXT1	1
	Second Floor Client Workstations	3	EXT2	1
2	Primary Default Router	1	EXT3	2
	Secondary Default Router	1	EXT4	2
3	Common Servers 1	4	INT5	3
	Common Servers 2	4	INT6	3

2. Add the switch ports to their respective VLANs.

The VLANs shown in [Table 18](#) are configured as follows:

```
>> # /cfg/12/vlan 1                (Select VLAN 1)
>> VLAN 1# add ext1                (Add port for 1st floor to VLAN 1)
>> VLAN 1# add ext2                (Add port for 2nd floor to VLAN 1)
>> VLAN 1# ena                     (Enable VLAN 1)
>> VLAN 1# ../vlan 2              (Select VLAN 2)
>> VLAN 2# add ext3                (Add port for default router 1)
>> VLAN 2# add ext4                (Add port for default router 2)
>> VLAN 2# ena                     (Enable VLAN 2)
>> VLAN 2# ../vlan 3              (Select VLAN 3)
>> VLAN 3# add int5                (Add port for default router 3)
>> VLAN 3# add int6                (Add port for common server 1)
>> VLAN 3# ena                     (Enable VLAN 3)
```

Each time you add a port to a VLAN, you may get the following prompt:

```
Port 4 is an untagged port and its current PVID is 1.
Confirm changing PVID from 1 to 2 [y/n]?
```

Enter y to set the default Port VLAN ID (PVID) for the port.

3. Add each IP interface to the appropriate VLAN.

Now that the ports are separated into three VLANs, the IP interface for each subnet must be placed in the appropriate VLAN. From [Table 18 on page 219](#), the settings are made as follows:

```
>> VLAN 3# /cfg/13/if 1            (Select IP interface 1 for def. routers)
>> IP Interface 1# vlan 2          (Set to VLAN 2)
>> IP Interface 1# ../if 2         (Select IP interface 2 for first floor)
>> IP Interface 2# vlan 1          (Set to VLAN 1)
>> IP Interface 2# ../if 3         (Select IP interface 3 for second floor)
>> IP Interface 3# vlan 1          (Set to VLAN 1)
>> IP Interface 3# ../if 4         (Select IP interface 4 for servers)
>> IP Interface 4# vlan 3          (Set to VLAN 3)
```

4. Apply and verify the configuration.

```
>> IP Interface 5# apply            (Make your changes active)
>> IP Interface 5# /info/12/vlan    (View current VLAN information)
>> Information# port                (View current port information)
```

Examine the resulting information. If any settings are incorrect, make the appropriate changes.

5. Save your new configuration changes.

```
>> Information# save                (Save for restore after reboot)
```

---

## BOOTP Relay Agent


### BOOTP Relay Agent Overview

The GbESM can function as a Bootstrap Protocol relay agent, enabling the switch to forward a client request for an IP address up to two BOOTP servers with IP addresses that have been configured on the switch.

When a switch receives a BOOTP request from a BOOTP client requesting an IP address, the switch acts as a proxy for the client. The request is then forwarded as a UDP Unicast MAC layer message to two BOOTP servers whose IP addresses are configured on the switch. The servers respond to the switch with a Unicast reply that contains the default gateway and IP address for the client. The switch then forwards this reply back to the client.

Figure 21 shows a basic BOOTP network example.

Figure 21. BOOTP Relay Agent Configuration



The use of two servers provide failover redundancy. The client request is forwarded to both BOOTP servers configured on the switch. However, no health checking is supported.

### BOOTP Relay Agent Configuration

To enable the GbESM to be the BOOTP forwarder, you need to configure the BOOTP server IP addresses on the switch, and enable BOOTP relay on the interface(s) on which the BOOTP requests are received.

Generally, you should configure the command on the switch IP interface that is closest to the client, so that the BOOTP server knows from which IP subnet the newly allocated IP address should come.

Use the following commands to configure the switch as a BOOTP relay agent:

```
>> # /cfg/13/bootp
>> Bootstrap Protocol Relay# addr <IP address> (IP address of BOOTP server)
>> Bootstrap Protocol Relay# addr2 <IP address> (IP address of 2nd BOOTP server)
>> Bootstrap Protocol Relay# on (Globally turn BOOTP relay on)
>> Bootstrap Protocol Relay# off (Globally turn BOOTP relay off)
>> Bootstrap Protocol Relay# cur (Display current configuration)
```

Use the following command to enable the Relay functionality on an IP interface:

```
>> # /cfg/13/if <interface number>/relay ena
```

---

## Dynamic Host Configuration Protocol

Dynamic Host Configuration Protocol (DHCP) is a transport protocol that provides a framework for automatically assigning IP addresses and configuration information to other IP hosts or clients in a large TCP/IP network. Without DHCP, the IP address must be entered manually for each network device. DHCP allows a network administrator to distribute IP addresses from a central point and automatically send a new IP address when a device is connected to a different place in the network.

DHCP is an extension of another network IP management protocol, Bootstrap Protocol (BOOTP), with an additional capability of being able to dynamically allocate reusable network addresses and configuration parameters for client operation.

Built on the client/server model, DHCP allows hosts or clients on an IP network to obtain their configurations from a DHCP server, thereby reducing network administration. The most significant configuration the client receives from the server is its required IP address; (other optional parameters include the “generic” file name to be booted, the address of the default gateway, and so forth).

DHCP relay agent eliminates the need to have DHCP/BOOTP servers on every subnet. It allows the administrator to reduce the number of DHCP servers deployed on the network and to centralize them. Without the DHCP relay agent, there must be at least one DHCP server deployed at each subnet that has hosts needing to perform the DHCP request.

### DHCP Relay Agent

DHCP is described in RFC 2131, and the DHCP relay agent supported on GbESMs is described in RFC 1542. DHCP uses UDP as its transport protocol. The client sends messages to the server on port 67 and the server sends messages to the client on port 68.

DHCP defines the methods through which clients can be assigned an IP address for a finite lease period and allowing reassignment of the IP address to another client later. Additionally, DHCP provides the mechanism for a client to gather other IP configuration parameters it needs to operate in the TCP/IP network.

In the DHCP environment, the GbESM acts as a relay agent. The DHCP relay feature (`/cfg/13/bootp`) enables the switch to forward a client request for an IP address to two BOOTP servers with IP addresses that have been configured on the switch.


When a switch receives a UDP broadcast on port 67 from a DHCP client requesting an IP address, the switch acts as a proxy for the client, replacing the client source IP (SIP) and destination IP (DIP) addresses. The request is then forwarded as a UDP Unicast MAC layer message to two BOOTP servers whose IP addresses are configured on the switch. The servers respond as a UDP Unicast message back to the switch, with the default gateway and IP address for the client. The destination IP address in the server response represents the interface address on the switch that received the client request. This interface address tells the switch on which VLAN to send the server response to the client.

## DHCP Relay Agent Configuration

To enable the GbESM to be the BOOTP forwarder, you need to configure the DHCP/BOOTP server IP addresses on the switch. Generally, you should configure the switch IP interface on the client side to match the client's subnet, and configure VLANs to separate client and server subnets. The DHCP server knows from which IP subnet the newly allocated IP address should come.

The following figure shows a basic DHCP network example:

Figure 22. DHCP Relay Agent Configuration



In GbESM implementation, there is no need for primary or secondary servers. The client request is forwarded to the BOOTP servers configured on the switch. The use of two servers provide failover redundancy. However, no health checking is supported.

Use the following commands to configure the switch as a DHCP relay agent:

```
>> # /cfg/13/bootp
>> Bootstrap Protocol Relay# addr          (Set IP address of BOOTP server)
>> Bootstrap Protocol Relay# addr2        (Set IP address of 2nd BOOTP server)
>> Bootstrap Protocol Relay# on           (Globally turn BOOTP relay on)
>> Bootstrap Protocol Relay# off          (Globally turn BOOTP relay off)
>> Bootstrap Protocol Relay# cur           (Display current configuration)
```

Additionally, DHCP Relay functionality can be assigned on a per interface basis. Use the following command to enable the Relay functionality:

```
>> # /cfg/13/if <interface number>/relay ena
```





---

## Chapter 15. Internet Protocol Version 6

Internet Protocol version 6 (IPv6) is a network layer protocol intended to expand the network address space. IPv6 is a robust and expandable protocol that meets the need for increased physical address space. The switch supports the following RFCs for IPv6-related features:

- RFC 1981
- RFC 2404
- RFC 2410
- RFC 2451
- RFC 2460
- RFC 2474
- RFC 2526
- RFC 2711
- RFC 2740
- RFC 3289
- RFC 3306
- RFC 3307
- RFC 3411
- RFC 3412
- RFC 3413
- RFC 3414
- RFC 3484
- RFC 3602
- RFC 3810
- RFC 3879
- RFC 4007
- RFC 4213
- RFC 4291
- RFC 4292
- RFC 4293
- RFC 4301
- RFC 4302
- RFC 4303
- RFC 4306
- RFC 4307
- RFC 4443
- RFC 4552
- RFC 4718
- RFC 4835
- RFC 4861
- RFC 4862
- RFC 5095
- RFC 5114

This chapter describes the basic configuration of IPv6 addresses and how to manage the switch via IPv6 host management.

---

## IPv6 Limitations

The following IPv6 features are not supported in this release.

- Dynamic Host Control Protocol for IPv6 (DHCPv6)
- Border Gateway Protocol for IPv6 (BGP)
- Routing Information Protocol for IPv6 (RIPng)

Most other IBM Networking OS 7.4 features permit IP addresses to be configured using either IPv4 or IPv6 address formats. However, the following switch features support IPv4 only:

- Default switch management IP address
- Bootstrap Protocol (BOOTP) and DHCP
- RADIUS, TACACS+ and LDAP
- QoS metering and re-marking ACLs for out-profile traffic
- Stacking
- VMware Virtual Center (vCenter) for VMready
- Routing Information Protocol (RIP)
- Internet Group Management Protocol (IGMP)
- Border Gateway Protocol (BGP)
- Virtual Router Redundancy Protocol (VRRP)
- sFLOW

---

## IPv6 Address Format

The IPv6 address is 128 bits (16 bytes) long and is represented as a sequence of eight 16-bit hex values, separated by colons.

Each IPv6 address has two parts:

- Subnet prefix representing the network to which the interface is connected
- Local identifier, either derived from the MAC address or user-configured

The preferred hexadecimal format is as follows:

XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX

Example IPv6 address:

FEDC:BA98:7654:BA98:FEDC:1234:ABCD:5412

Some addresses can contain long sequences of zeros. A single contiguous sequence of zeros can be compressed to :: (two colons). For example, consider the following IPv6 address:

FE80:0:0:0:2AA:FF:FA:4CA2

The address can be compressed as follows:

FE80::2AA:FF:FA:4CA2

Unlike IPv4, a subnet mask is not used for IPv6 addresses. IPv6 uses the subnet prefix as the network identifier. The prefix is the part of the address that indicates the bits that have fixed values or are the bits of the subnet prefix. An IPv6 prefix is written in address/prefix-length notation. For example, in the following address, 64 is the network prefix:

21DA:D300:0000:2F3C::/64

IPv6 addresses can be either user-configured or automatically configured. Automatically configured addresses always have a 64-bit subnet prefix and a 64-bit interface identifier. In most implementations, the interface identifier is derived from the switch's MAC address, using a method called EUI-64.

Most IBM N/OS 7.4 features permit IP addresses to be configured using either IPv4 or IPv6 address formats. Throughout this manual, *IP address* is used in places where either an IPv4 or IPv6 address is allowed. In places where only one type of address is allowed, the type (*IPv4* or *IPv6*) is specified.

---

## IPv6 Address Types

IPv6 supports three types of addresses: unicast (one-to-one), multicast (one-to-many), and anycast (one-to-nearest). Multicast addresses replace the use of broadcast addresses.

### Unicast Address

Unicast is a communication between a single host and a single receiver. Packets sent to a unicast address are delivered to the interface identified by that address. IPv6 defines the following types of unicast address:

- **Global Unicast address:** An address that can be reached and identified globally. Global Unicast addresses use the high-order bit range up to FF00, therefore all non-multicast and non-link-local addresses are considered to be global unicast. A manually configured IPv6 address must be fully specified. Autoconfigured IPv6 addresses are comprised of a prefix combined with the 64-bit EUI. RFC 4291 defines the IPv6 addressing architecture.

The interface ID must be unique within the same subnet.

- **Link-local unicast address:** An address used to communicate with a neighbor on the same link. Link-local addresses use the format FE80 : : EUI

Link-local addresses are designed to be used for addressing on a single link for purposes such as automatic address configuration, neighbor discovery, or when no routers are present.

Routers must not forward any packets with link-local source or destination addresses to other links.

### Multicast

Multicast is communication between a single host and multiple receivers. Packets are sent to all interfaces identified by that address. An interface may belong to any number of multicast groups.

A multicast address (FF00 - FFFF) is an identifier for a group interface. The multicast address most often encountered is a solicited-node multicast address using prefix FF02 : : 1 : FF00 : 0000 / 104 with the low-order 24 bits of the unicast or anycast address.

The following well-known multicast addresses are pre-defined. The group IDs defined in this section are defined for explicit scope values, as follows:

FF00 : : : : : 0 through FF0F : : : : : 0

### Anycast

Packets sent to an anycast address or list of addresses are delivered to the nearest interface identified by that address. Anycast is a communication between a single sender and a list of addresses.

Anycast addresses are allocated from the unicast address space, using any of the defined unicast address formats. Thus, anycast addresses are syntactically indistinguishable from unicast addresses. When a unicast address is assigned to more than one interface, thus turning it into an anycast address, the nodes to which the address is assigned must be explicitly configured to know that it is an anycast address.

---

## IPv6 Address Autoconfiguration

IPv6 supports the following types of address autoconfiguration:

- **Stateful address configuration**  
Address configuration is based on the use of a stateful address configuration protocol, such as DHCPv6, to obtain addresses and other configuration options.
- **Stateless address configuration**  
Address configuration is based on the receipt of Router Advertisement messages that contain one or more Prefix Information options.

N/OS 7.4 supports stateless address configuration.

Stateless address configuration allows hosts on a link to configure themselves with link-local addresses and with addresses derived from prefixes advertised by local routers. Even if no router is present, hosts on the same link can configure themselves with link-local addresses and communicate without manual configuration.

---

## IPv6 Interfaces

Each IPv6 interface supports multiple IPv6 addresses. You can manually configure up to two IPv6 addresses for each interface, or you can allow the switch to use stateless autoconfiguration. By default, the switch automatically configures the IPv6 address of its management interface.

You can manually configure two IPv6 addresses for each interface, as follows:

- Initial IPv6 address is a global unicast or anycast address (`/cfg/l3/if <x>/addr`).  
Note that you cannot configure both addresses as anycast. If you configure an anycast address on the interface you must also configure a global unicast address on that interface.
- Second IPv6 address can be a unicast or anycast address (`/cfg/l3/if <x>/secaddr6`).

You cannot configure an IPv4 address on an IPv6 management interface. Each interface can be configured with only one address type: either IPv4 or IPv6, but not both. When changing between IPv4 and IPv6 address formats, the prior address settings for the interface are discarded.

Each IPv6 interface can belong to only one VLAN. Each VLAN can support only one IPv6 interface. Each VLAN can support multiple IPv4 interfaces.

Interface 127 is reserved for IPv6 host support. This interface is included in management VLAN 4095. Use the IPv6 default gateway menu to configure the IPv6 gateways (`/cfg/l3/gw6`).

IPv6 gateway 1 is reserved for IPv6 data interfaces. IPv6 gateway 4 is the default IPv6 management gateway.

---

## Neighbor Discovery

### Neighbor Discovery Overview

The switch uses Neighbor Discovery protocol (ND) to gather information about other router and host nodes, including the IPv6 addresses. Host nodes use ND to configure their interfaces and perform health detection. ND allows each node to determine the link-layer addresses of neighboring nodes, and to keep track of each neighbor's information. A neighboring node is a host or a router that is linked directly to the switch. The switch supports Neighbor Discovery as described in RFC 4861.

Neighbor Discover messages allow network nodes to exchange information, as follows:

- *Neighbor Solicitations* allow a node to discover information about other nodes.
- *Neighbor Advertisements* are sent in response to Neighbor Solicitations. The Neighbor Advertisement contains information required by nodes to determine the link-layer address of the sender, and the sender's role on the network.
- IPv6 hosts use *Router Solicitations* to discover IPv6 routers. When a router receives a Router Solicitation, it responds immediately to the host.
- Routers use *Router Advertisements* to announce its presence on the network, and to provide its address prefix to neighbor devices. IPv6 hosts listen for Router Advertisements, and use the information to build a list of default routers. Each host uses this information to perform autoconfiguration of IPv6 addresses.
- *Redirect messages* are sent by IPv6 routers to inform hosts of a better first-hop address for a specific destination. Redirect messages are only sent by routers for unicast traffic, are only unicast to originating hosts, and are only processed by hosts.

ND configuration for various advertisements, flags, and interval settings is performed on a per-interface basis using the following menu:

```
>> # /cfg/13/if <interface number>/ip6nd
```

Other ND configuration options are available using the following menus:

>> # /cfg/13/nbrcache	(Manage static neighbor cache entries)
>> # /cfg/13/ndprefix	(Define prefix profiles for router advertisements sent from an interface)
>> # /cfg/13/ppt	(Manage prefix policy table entries)

## Host vs. Router

Each IPv6 interface can be configured as a router node or a host node, as follows:

- A router node's IP address is configured manually. Router nodes can send Router Advertisements.
- A host node's IP address is autoconfigured. Host nodes listen for Router Advertisements that convey information about devices on the network.

**Note:** When IP forwarding is turned on (`/cfg/13/frwd/on`), all IPv6 interfaces configured on the switch can forward packets.

You can configure each IPv6 interface as either a host node or a router node. You can manually assign an IPv6 address to an interface in host mode, or the interface can be assigned an IPv6 address by an upstream router, using information from router advertisements to perform stateless auto-configuration.

To set an interface to host mode, use the following command:

```
>> # /cfg/13/if <interface number>/ip6host enable
```

By default, host mode is enabled on the management interface, and disabled on data interfaces.

The GbESM supports up to 1156 IPv6 routes.

---

## Supported Applications

The following applications have been enhanced to provide IPv6 support.

- **Ping**

The ping command supports IPv6 addresses. Use the following format to ping an IPv6 address:

```
ping <host name> | <IPv6 address> [-n <tries (0-4294967295)>]
[-w <msec delay (0-4294967295)>] [-l <length (0/32-65500/2080)>]
[-s <IP source>] [-v <TOS (0-255)>] [-f] [-t]
```

To ping a link-local address (begins with FE80), provide an interface index, as follows:

```
ping <IPv6 address>%<Interface index> [-n <tries (0-4294967295)>]
[-w <msec delay (0-4294967295)>] [-l <length (0/32-65500/2080)>]
[-s <IP source>] [-v <TOS (0-255)>] [-f] [-t]
```

- **Traceroute**

The traceroute command supports IPv6 addresses (but not link-local addresses).

Use the following format to perform a traceroute to an IPv6 address:

```
traceroute <host name> | <IPv6 address> [<max-hops (1-32)>]
[<msec delay (1-4294967295)>]]
```

- **Telnet server**

The telnet command supports IPv6 addresses (but not link-local addresses).

Use the following format to Telnet into an IPv6 interface on the switch:

```
telnet <host name> | <IPv6 address> [<port>]
```

- **Telnet client**

The telnet command supports IPv6 addresses (but not link-local addresses).

Use the following format to Telnet to an IPv6 address:

```
telnet <host name> | <IPv6 address> [<port>]
```

- **HTTP/HTTPS**

The HTTP/HTTPS servers support both IPv4 and IPv6 connections.

- **SSH**

Secure Shell (SSH) connections over IPv6 are supported, (but not link-local addresses). The following syntax is required from the client:

```
ssh -u <IPv6 address>
```

Example:

```
ssh -u 2001:2:3:4:0:0:0:142
```

- **TFTP**

The TFTP commands support both IPv4 and IPv6 addresses. Link-local addresses are not supported.

- **FTP**

The FTP commands support both IPv4 and IPv6 addresses. Link-local addresses are not supported.



- **DNS client**

DNS commands support both IPv4 and IPv6 addresses. Link-local addresses are not supported. Use the following command to specify the type of DNS query to be sent first:

```
>> # /cfg/l3/dns/reqver v4|v6
```

If you set the request version to `v4`, the DNS application sends an `A` query first, to resolve the hostname with an IPv4 address. If no `A` record is found for that hostname (no IPv4 address for that hostname) an `AAAA` query is sent to resolve the hostname with a IPv6 address.

If you set the request version to `v6`, the DNS application sends an `AAAA` query first, to resolve the hostname with an IPv6 address. If no `AAAA` record is found for that hostname (no IPv6 address for that hostname) an `A` query is sent to resolve the hostname with an IPv4 address.

---

## Configuration Guidelines

When you configure an interface for IPv6, consider the following guidelines:

- Support for subnet router anycast addresses is not available.
- Interface 127 is reserved for IPv6 management.
- A single interface can accept either IPv4 or IPv6 addresses, but not both IPv4 and IPv6 addresses.
- A single interface can accept multiple IPv6 addresses.
- A single interface can accept only one IPv4 address.
- If you change the IPv6 address of a configured interface to an IPv4 address, all IPv6 settings are deleted.
- A single VLAN can support only one IPv6 interface.
- Health checks are not supported for IPv6 gateways.
- IPv6 interfaces support Path MTU Discovery. The CPU's MTU is fixed at 1500 bytes.
- Support for jumbo frames (1,500 to 9,216 byte MTUs) is limited. Any jumbo frames intended for the CPU must be fragmented by the remote node. The switch can re-assemble fragmented packets up to 9k. It can also fragment and transmit jumbo packets received from higher layers.

---

## IPv6 Configuration Examples

This section provides steps to configure IPv6 on the switch.

### IPv6 Example 1

The following example uses IPv6 host mode to autoconfigure an IPv6 address for the interface. By default, the interface is assigned to VLAN 1.

1. Enable IPv6 host mode on an interface.

```
>> # /cfg/13/if 2                               (Select IP interface 2)
>> IP Interface 2# ip6host enable                 (Enable IPv6 host mode)
>> IP Interface 2# ena                             (Enable the IP interface)
```

2. Configure the IPv6 default gateway.

```
>> IP Interface 2# /cfg/13/gw6 1                 (Select IPv6 default gateway)
>> Default gateway 1# addr 2001:BA98:7654:BA98:FEDC:1234:ABCD:5412
>> Default gateway 1# ena                         (Enable default gateway)
```

3. Apply and save the configuraiton.
4. Verify the interface address.

```
>> Default gateway 1# /info/13/if 2              (Display interface information)
```

### IPv6 Example 2

Use the following example to manually configure IPv6 on an interface.

1. Assign an IPv6 address and prefix length to the interface.

```
>> # /cfg/13/if 3
>> IP Interface 3# addr 2001:BA98:7654:BA98:FEDC:1234:ABCD:5214
>> IP Interface 3# maskplen 64
>> IP Interface 3# secaddr6 2003::1 32
>> IP Interface 3# vlan 2
>> IP Interface 3# ena
```

The secondary IPv6 address is compressed, and the prefix length is 32.

2. Configure the IPv6 default gateway.

```
>> IP Interface 3# /cfg/13/gw6 1
>> Default gateway 1# addr 2001:BA98:7654:BA98:FEDC:1234:ABCD:5412
>> Default gateway 1# ena                         (Enable default gateway)
```

3. Configure Neighbor Discovery advertisements for the interface (optional)

```
>> Default gateway 1# /cfg/13/if 1/ip6nd
>> IP6 Neighbor Discovery # rtradv enable         (Enable Router Advertisements)
```

4. Apply and save the configuration.

5. Verify the configuration.

>> IP6 Neighbor Discovery # /cfg/13/cur	<i>(View current IP settings)</i>
---	-----------------------------------

---

## Chapter 16. Using IPsec with IPv6

Internet Protocol Security (IPsec) is a protocol suite for securing Internet Protocol (IP) communications by authenticating and encrypting each IP packet of a communication session. IPsec also includes protocols for establishing mutual authentication between agents at the beginning of the session and negotiation of cryptographic keys to be used during the session.

Since IPsec was implemented in conjunction with IPv6, all implementations of IPv6 must contain IPsec. To support the National Institute of Standards and Technology (NIST) recommendations for IPv6 implementations, IBM Networking OS IPv6 feature compliance has been extended to include the following IETF RFCs, with an emphasis on IP Security (IPsec) and Internet Key Exchange version 2, and authentication/confidentiality for OSPFv3:

- RFC 4301 for IPv6 security
- RFC 4302 for the IPv6 Authentication Header
- RFCs 2404, 2410, 2451, 3602, and 4303 for IPv6 Encapsulating Security Payload (ESP), including NULL encryption, CBC-mode 3DES and AES ciphers, and HMAC-SHA-1-96.
- RFCs 4306, 4307, 4718, and 4835 for IKEv2 and cryptography
- RFC 4552 for OSPFv3 IPv6 authentication
- RFC 5114 for Diffie-Hellman groups

**Note:** This implementation of IPsec supports DH groups 1, 2, 5, 14, and 24.

The following topics are discussed in this chapter:

- [“IPsec Protocols” on page 238](#)
- [“Using IPsec with the GbESM” on page 239](#)

---

## IPsec Protocols

The IBM N/OS implementation of IPsec supports the following protocols:

- **Authentication Header (AH)**  
AHs provide connectionless integrity and data origin authentication for IP packets, and provide protection against replay attacks. In IPv6, the AH protects the AH itself, the Destination Options extension header after the AH, and the IP payload. It also protects the fixed IPv6 header and all extension headers before the AH, except for the mutable fields DSCP, ECN, Flow Label, and Hop Limit. AH is defined in RFC 4302.
- **Encapsulating Security Payload (ESP)**  
ESPs provide confidentiality, data origin authentication, integrity, an anti-replay service (a form of partial sequence integrity), and some traffic flow confidentiality. ESPs may be applied alone or in combination with an AH. ESP is defined in RFC 4303.
- **Internet Key Exchange Version 2 (IKEv2)**  
IKEv2 is used for mutual authentication between two network elements. An IKE establishes a security association (SA) that includes shared secret information to efficiently establish SAs for ESPs and AHs, and a set of cryptographic algorithms to be used by the SAs to protect the associated traffic. IKEv2 is defined in RFC 4306.

Using IKEv2 as the foundation, IPsec supports ESP for encryption and/or authentication, and/or AH for authentication of the remote partner.

Both ESP and AH rely on security associations. A security association (SA) is the bundle of algorithms and parameters (such as keys) that encrypt and authenticate a particular flow in one direction.

---

## Using IPsec with the GbESM

IPsec supports the fragmentation and reassembly of IP packets that occurs when data goes to and comes from an external device. The 1/10Gb Uplink Ethernet Switch Module acts as an end node that processes any fragmentation and reassembly of packets but does not forward the IPsec traffic. The IKEv2 key must be authenticated before you can use IPsec.

The security protocol for the session key is either ESP or AH. Outgoing packets are labeled with the SA SPI (Security Parameter Index), which the remote device will use in its verification and decryption process.

Every outgoing IPv6 packet is checked against the IPsec policies in force. For each outbound packet, after the packet is encrypted, the software compares the packet size with the MTU size that it either obtains from the default minimum maximum transmission unit (MTU) size (1500) or from path MTU discovery. If the packet size is larger than the MTU size, the receiver drops the packet and sends a message containing the MTU size to the sender. The sender then fragments the packet into smaller pieces and retransmits them using the correct MTU size.

The maximum traffic load for each IPsec packet is limited to the following:

- IKEv2 SAs: 5
- IPsec SAs: 10 (5 SAs in each direction)
- SPDs: 20 (10 policies in each direction)

IPsec is implemented as a software cryptography engine designed for handling control traffic, such as network management. IPsec is not designed for handling data traffic, such as a VPN.

## Setting up Authentication

Before you can use IPsec, you need to have key policy authentication in place. There are two types of key policy authentication:

- **Preshared key (default)**  
The parties agree on a shared, secret key that is used for authentication in an IPsec policy. During security negotiation, information is encrypted before transmission by using a session key created by using a Diffie-Hellman calculation and the shared, secret key. Information is decrypted on the receiving end using the same key. One IPsec peer authenticates the other peer's packet by decryption and verification of the hash inside the packet (the hash inside the packet is a hash of the preshared key). If authentication fails, the packet is discarded.
- **Digital certificate (using RSA algorithms)**  
The peer being validated must hold a digital certificate signed by a trusted Certificate Authority and the private key for that digital certificate. The side performing the authentication only needs a copy of the trusted certificate authorities digital certificate. During IKEv2 authentication, the side being validated sends a copy of the digital certificate and a hash value signed using the private key. The certificate can be either generated or imported.

**Note:** During the IKEv2 negotiation phase, the digital certificate takes precedence over the preshared key.

## Creating an IKEv2 Proposal

With IKEv2, a single policy can have multiple encryption and authentication types, as well as multiple integrity algorithms.

To create an IKEv2 proposal:

1. Enter IKEv2 proposal mode.

```
>> /cfg/13/ikev2/prop
```

2. Set the DES encryption algorithm.

```
>> IKEv2 Proposal# cipher des|3des|aes (default: 3des)
```

3. Set the authentication integrity algorithm type.

```
>> IKEv2 Proposal# auth sha1|md5|none (default: sha1)
```

4. Set the Diffie-Hellman group.

```
>> IKEv2 Proposal# group 1|2|5|14|24 (default: 2)
```



## Importing an IKEv2 Digital Certificate

To import an IKEv2 digital certificate for authentication:

1. Import the CA certificate file.

```
>> /cfg/sys/access/https/gtca
Enter hostname or IP address of FTP/TFTP server: <hostname or IPv4 address>
Enter name of file on FTP/TFTP server: <path and filename of CA certificate file>
Enter the port to use for down the file
["mgt"|"data"]:
Confirm download operation [y/n]: y
```

2. Import the host key file.

```
>> /cfg/sys/access/https/gthkey <hostname or IPv4 address>
Enter name of file on FTP/TFTP server: <path and filename of host private key file>
Enter the port to use for down the file
["mgt"|"data"]:
Confirm download operation [y/n]: y
```

3. Import the host certificate file.

```
>> /cfg/sys/access/https/gthcert <hostname or IPv4 address>
Enter name of file on FTP/TFTP server: <path and filename of host certificate file>
Enter the port to use for down the file
["mgt"|"data"]:
Confirm download operation [y/n]: y
```

**Note:** When prompted for the port to use for download the file, if you used a management port to connect the switch to the server, enter `mgt`, otherwise enter `data`.

## Generating an IKEv2 Digital Certificate

To create an IKEv2 digital certificate for authentication:

1. Create an HTTPS certificate defining the information you want to be used in the various fields.

```
>> /cfg/sys/access/https/generate
Country Name (2 letter code) []: <country code>
State or Province Name (full name) []: <state>
Locality Name (eg, city) []: <city>
Organization Name (eg, company) []: <company>
Organizational Unit Name (eg, section) []: <org. unit>
Common Name (eg, YOUR name) []: <name>
Email (eg, email address) []: <email address>
Confirm generating certificate? [y/n]: y
Generating certificate. Please wait (approx 30 seconds)
restarting SSL agent
```

2. Save the HTTPS certificate.

The certificate is valid only until the switch is rebooted. To save the certificate so that it is retained beyond reboot or power cycles, use the following command:

```
>> # /cfg/sys/access/https/certSave
```

3. Enable IKEv2 RSA-signature authentication:

```
>> # /cfg/sys/access/https/enable
```

## Enabling IKEv2 Preshared Key Authentication

To set up IKEv2 preshared key authentication:

1. Enter the local preshared key.

```
>> /cfg/13/ikev2/psk/loc-key <preshared key, a string of 1-256 characters>
```

2. If asymmetric authentication is supported, enter the remote key:

```
>> /cfg/13/ikev2/psk/rem-key/addr <IPv6 host>
>> /cfg/13/ikev2/psk/rem-key/key <preshared key>
```

where the following parameters are used:

- *preshared key* A string of 1-256 characters
- *IPv6 host* An IPv6-format host, such as “3000::1”

3. Set up the IKEv2 identification type by entering *one* of the following commands:

```
>> /cfg/13/ikev2/ident/addr (use an IPv6 address)
>> /cfg/13/ikev2/ident/email <email address>
>> /cfg/13/ikev2/ident/fqdn <domain name>
```

To disable IKEv2 RSA-signature authentication method and enable preshared key authentication, enter:

```
>> # /cfg/sys/access/https/disable
```

## Setting Up a Key Policy

When configuring IPsec, you must define a key policy. This key policy can be either manual or dynamic. Either way, configuring a policy involves the following steps:

- Create a transform set—This defines which encryption and authentication algorithms are used.
  - Create a traffic selector—This describes the packets to which the policy applies.
  - Establish an IPsec policy.
  - Apply the policy.
1. To define which encryption and authentication algorithms are used, create a transform set:

```
>> # /cfg/13/ipsec/txform <transform ID>
>> Transform_set 1# cipher <encryption method>
>> Transform_set 1# integy <integrity algorithm>
>> Transform_set 1# auth <AH authentication algorithm>
```

where the following parameters are used:

- *transform ID* A number from 1-10
- *encryption method* One of the following: esp-des | esp-3des | esp-aes-cbc | esp-null
- *integrity algorithm* One of the following: esp-sha1 | esp-md5 | none
- *AH authentication algorithm* One of the following: ah-sha1 | ah-md5 | none

2. Decide whether to use tunnel or transport mode. The default mode is transport.

```
>> Transform_set 1# mode tunnel|tport
```

3. To describe the packets to which this policy applies, create a traffic selector using the following commands:

```
>> # /cfg/13/ipsec/selector <traffic selector number>
>> Traffic_selector 1# permit|deny (permit or deny traffic)
>> Traffic_selector 1# proto/icmp <type>|tcp|any(protocol traffic selector)
>> Traffic_selector 1# src <IPv6 address of the source>
>> Traffic_selector 1# prefix <prefix length>
>> Traffic_selector 1# dst <IPv6 destination address>
```

where the following parameters are used:

- *traffic selector number* an integer from 1-10
- permit|deny whether or not to permit IPsec encryption of traffic that meets the criteria specified in this command
- proto/any apply the selector to any type of traffic
- proto/icmp *type*|any only apply the selector only to ICMP traffic of the specified *type* (an integer from 1-255) or to any ICMP traffic
- proto/tcp only apply the selector to TCP traffic
- *source IP address*|any the source IP address in IPv6 format or “any” source
- *destination IP address*|any the destination IP address in IPv6 format or “any” destination
- *prefix length* (Optional) the length of the destination IPv6 prefix; an integer from 1-128

Permitted traffic that matches the policy in force is encrypted, while denied traffic that matches the policy in force is dropped. Traffic that does not match the policy bypasses IPsec and passes through *clear* (unencrypted).

4. Choose whether to use a manual or a dynamic policy.

## Using a Manual Key Policy

A manual policy involves configuring policy and manual SA entries for local and remote peers.

To configure a manual key policy, you need:

- The IP address of the peer in IPv6 format (for example, “3000::1”).
- Inbound/Outbound session keys for the security protocols.

You can then assign the policy to an interface. The peer represents the other end of the security association. The security protocol for the session key can be either ESP or AH.

To create and configure a manual policy:

1. Enter a manual policy to configure.

```
>> # /cfg/l3/ipsec/policy/manual <policy number>
```

2. Configure the policy.

```
>> Manual_Policy 1# peer <peer's IPv6 address>
>> Manual_Policy 1# selector <IPsec traffic selector>
>> Manual_Policy 1# txform <IPsec transform set>
>> Manual_Policy 1# in-ah/auth-key <inbound AH IPsec key>
>> Manual_Policy 1# in-ah/spi <inbound AH IPsec SPI>
>> Manual_Policy 1# in-esp/enc-key <inbound ESP cipher key>
>> Manual_Policy 1# in-esp/spi <inbound ESP SPI>
>> Manual_Policy 1# in-esp/auth-key <inbound ESP authenticator key>
>> Manual_Policy 1# out-ah/auth-key <outbound AH IPsec key>
>> Manual_Policy 1# out-ah/spi <outbound AH IPsec SPI>
>> Manual_Policy 1# out-esp/enc-key <outbound ESP cipher key>
>> Manual_Policy 1# out-esp/spi <outbound ESP SPI>
>> Manual_Policy 1# out-esp/auth-key <outbound ESP authenticator key>
```

where the following parameters are used:

- |   |   |
|---|---|
| – <i>peer's IPv6 address</i>            | The IPv6 address of the peer (for example, 3000::1)     |
| – <i>IPsec traffic-selector</i>         | A number from 1-10                                      |
| – <i>IPsec of transform-set</i>         | A number from 1-10                                      |
| – <i>inbound AH IPsec key</i>           | The inbound AH key code, in hexadecimal                 |
| – <i>inbound AH IPsec SPI</i>           | A number from 256-4294967295                            |
| – <i>inbound ESP cipher key</i>         | The inbound ESP key code, in hexadecimal                |
| – <i>inbound ESP SPI</i>                | A number from 256-4294967295                            |
| – <i>inbound ESP authenticator key</i>  | The inbound ESP authenticator key code, in hexadecimal  |
| – <i>outbound AH IPsec key</i>          | The outbound AH key code, in hexadecimal                |
| – <i>outbound AH IPsec SPI</i>          | A number from 256-4294967295                            |
| – <i>outbound ESP cipher key</i>        | The outbound ESP key code, in hexadecimal               |
| – <i>outbound ESP SPI</i>               | A number from 256-4294967295                            |
| – <i>outbound ESP authenticator key</i> | The outbound ESP authenticator key code, in hexadecimal |

**Note:** When configuring a manual policy ESP, the ESP authenticator key is optional.

**Note:** If using third-party switches, the IPsec manual policy session key must be of fixed length as follows:

For AH key: SHA1 is 20 bytes; MD5 is 16 bytes

For ESP cipher key: 3DES is 24 bytes; AES-cbc is 24 bytes; DES is 8 bytes

For ESP auth key: SHA1 is 20 bytes; MD5 is 16 bytes

3. After you configure the IPSec policy, you need to apply it to the interface to enforce the security policies on that interface and save it to keep it in place after a reboot. To accomplish this, enter:

```
>> Main# apply
>> Main# save
```

## Using a Dynamic Key Policy

When you use a dynamic key policy, the first packet triggers IKE and sets the IPsec SA and IKEv2 SA. The initial packet negotiation also determines the lifetime of the algorithm, or how long it stays in effect. When the key expires, a new key is automatically created. This helps prevent break-ins.

To configure a dynamic key policy:

1. Choose a dynamic policy to configure.

```
>> # /cfg/13/ipsec/policy/dynamic <policy number>
```

2. Configure the policy.

```
>> Dynamic_Policy 1# peer <peer IPv6 address>
>> Dynamic_policy 1# selector <index of traffic selector>
>> Dynamic_policy 1# txform <index of transform set>
>> Dynamic_policy 1# lifetime <SA lifetime, in seconds>
>> Dynamic_policy 1# pfs enable|disable
```

where the following parameters are used:

- |                                    |  |
|------------------------------------|--|
| – <i>peer's IPv6 address</i>       | The IPv6 address of the peer (for example, 3000::1)  |
| – <i>index of traffic-selector</i> | A number from 1-10   |
| – <i>index of transform-set</i>    | A number from 1-10   |
| – <i>SA lifetime, in seconds</i>   | The length of time the SA is to remain in effect; an integer from 120-86400                |
| – <i>pfs enable disable</i>        | Whether to enable or disable the perfect forward security feature. The default is disable. |

**Note:** In a dynamic policy, the AH and ESP keys are created by IKEv2.

3. After you configure the IPSec policy, you need to apply it to the interface to enforce the security policies on that interface and save it to keep it in place after a reboot. To accomplish this, enter:

```
>> Dynamic_policy 1# apply
>> Dynamic_policy 1# save
```

---

## Chapter 17. Routing Information Protocol

In a routed environment, routers communicate with one another to keep track of available routes. Routers can learn about available routes dynamically using the Routing Information Protocol (RIP). IBM Networking OS software supports RIP version 1 (RIPv1) and RIP version 2 (RIPv2) for exchanging TCP/IPv4 route information with other routers.

**Note:** IBM N/OS 7.4 does not support IPv6 for RIP.

---

## Distance Vector Protocol

RIP is known as a distance vector protocol. The vector is the network number and next hop, and the distance is the cost associated with the network number. RIP identifies network reachability based on metric, and metric is defined as hop count. One hop is considered to be the distance from one switch to the next, which typically is 1.

When a switch receives a routing update that contains a new or changed destination network entry, the switch adds 1 to the metric value indicated in the update and enters the network in the routing table. The IPv4 address of the sender is used as the next hop.

---

## Stability

RIP includes a number of other stability features that are common to many routing protocols. For example, RIP implements the split horizon and hold-down mechanisms to prevent incorrect routing information from being propagated.

RIP prevents routing loops from continuing indefinitely by limiting the number of hops allowed in a path from the source to a destination. The maximum number of hops in a path is 15. The network destination network is considered unreachable if increasing the metric value by 1 causes the metric to be 16 (that is infinity). This limits the maximum diameter of a RIP network to less than 16 hops.

RIP is often used in stub networks and in small autonomous systems that do not have many redundant paths.



---

## Routing Updates

RIP sends routing-update messages at regular intervals and when the network topology changes. Each router “advertises” routing information by sending a routing information update every 30 seconds. If a router doesn’t receive an update from another router for 180 seconds, those routes provided by that router are declared invalid. The routes are removed from the routing table, but they remain in the RIP routes table (`/info/13/rip/routes`). After another 120 seconds without receiving an update for those routes, the routes are removed from regular updates.

When a router receives a routing update that includes changes to an entry, it updates its routing table to reflect the new route. The metric value for the path is increased by 1, and the sender is indicated as the next hop. RIP routers maintain only the best route (the route with the lowest metric value) to a destination.

For more information see The Configuration Menu, Routing Information Protocol Configuration (`/cfg/13/rip`) in the *IBM Networking OS 7.4 Command Reference*.

---

## RIPv1

RIP version 1 uses broadcast User Datagram Protocol (UDP) data packets for the regular routing updates. The main disadvantage is that the routing updates do not carry subnet mask information. Hence, the router cannot determine whether the route is a subnet route or a host route. It is of limited usage after the introduction of RIPv2. For more information about RIPv1 and RIPv2, refer to RFC 1058 and RFC 2453.

---

## RIPv2

RIPv2 is the most popular and preferred configuration for most networks. RIPv2 expands the amount of useful information carried in RIP messages and provides a measure of security. For a detailed explanation of RIPv2, refer to RFC 1723 and RFC 2453.

RIPv2 improves efficiency by using multicast UDP (address 224.0.0.9) data packets for regular routing updates. Subnet mask information is provided in the routing updates. A security option is added for authenticating routing updates, by using a shared password. N/OS supports using clear password for RIPv2.

---

## RIPv2 in RIPv1 Compatibility Mode

N/OS allows you to configure RIPv2 in RIPv1 compatibility mode, for using both RIPv2 and RIPv1 routers within a network. In this mode, the regular routing updates use broadcast UDP data packet to allow RIPv1 routers to receive those packets. With RIPv1 routers as recipients, the routing updates have to carry natural or host mask. Hence, it is not a recommended configuration for most network topologies.

**Note:** When using both RIPv1 and RIPv2 within a network, use a single subnet mask throughout the network.

---

## RIP Features

N/OS provides the following features to support RIPv1 and RIPv2:

### Poison Reverse

Simple split horizon in RIP omits routes learned from one neighbor in updates sent to that neighbor. That is the most common configuration used in RIP, with the Poison Reverse feature disabled. Split horizon with poisoned reverse enabled includes such routes in updates, but sets their metrics to 16. The disadvantage of using this feature is the increase of size in the routing updates.

### Triggered Updates

Triggered updates are an attempt to speed up convergence. When Triggered Updates is enabled (`/cfg/l3/rip/if <x>/trigg/e`), whenever a router changes the metric for a route, it sends update messages almost immediately, without waiting for the regular update interval. It is recommended to enable Triggered Updates.

### Multicast

RIPv2 messages use IPv4 multicast address (224.0.0.9) for periodic updates. Multicast RIPv2 updates are not processed by RIPv1 routers. IGMP is not needed since these are inter-router messages which are not forwarded.

To configure RIPv2 in RIPv1 compatibility mode, set multicast to `disable`, and set version to `both`.

### Default Route

The RIP router can listen and supply a default route, usually represented as IPv4 0.0.0.0 in the routing table. When a router does not have an explicit route to a destination network in its routing table, it uses the default route to forward those packets.

### Metric

The metric field contains a configurable value between 1 and 15 (inclusive) which specifies the current metric for the interface. The metric value typically indicates the total number of hops to the destination. The metric value of 16 represents an unreachable destination.

## Authentication

RIPv2 authentication uses plain text password for authentication. If configured using Authentication password, then it is necessary to enter an authentication key value.

The following method is used to authenticate a RIP message:

- If the router is not configured to authenticate RIPv2 messages, then RIPv1 and unauthenticated RIPv2 messages are accepted; authenticated RIPv2 messages are discarded.
- If the router is configured to authenticate RIPv2 messages, then RIPv1 and RIPv2 messages which pass authentication testing are accepted; unauthenticated and failed authentication RIPv2 messages are discarded.

For maximum security, RIPv1 messages are ignored when authentication is enabled (`cfg/13/rip/if <x>/auth/password`); otherwise, the routing information from authenticated messages is propagated by RIPv1 routers in an unauthenticated manner.

---

## RIP Configuration Example

**Note:** An interface RIP disabled uses all the default values of the RIP, no matter how the RIP parameters are configured for that interface. RIP sends out RIP regular updates to include an UP interface, but not a DOWN interface.

### 1. Add VLANs for routing interfaces.

```
>> Main# /cfg/12/vlan 2/ena           (Enable VLAN 2)
>> VLAN 2# add ext2                   (Add port EXT2 to VLAN 2)
Port EXT2 is an UNTAGGED port and its current PVID is 1.
Confirm changing PVID from 1 to 2 [y/n]: y
>> VLAN 2# /cfg/12/vlan 3/ena         (Enable VLAN 3)
>> VLAN 3# add ext3                   (Add port EXT3 to VLAN 3)
Port EXT3 is an UNTAGGED port and its current PVID is 1.
Confirm changing PVID from 1 to 3 [y/n]: y
```

### 2. Add IP interfaces with IPv4 addresses to VLANs.

```
>> VLAN 3# /cfg/13/if 2/ena           (Enable interface 2)
>> IP Interface 2# addr 102.1.1.1     (Define IPv4 address for interface 2)
>> IP Interface 2# vlan 2             (Add interface 2 to VLAN 2)
>> IP Interface 2# /cfg/13/if 3/ena   (Enable interface 3)
>> IP Interface 3# addr 103.1.1.1     (Define IPv4 address for interface 3)
>> IP Interface 3# vlan 3             (Add interface 3 to VLAN 3)
```

### 3. Turn on RIP globally and enable RIP for each interface.

```
>> IP Interface 3# /cfg/13/rip/on      (Turn on RIP globally)
>> Routing Information Protocol# if 2/ena (Enable RIP on IP interface 2)
>> RIP Interface 2# ..
>> Routing Information Protocol# if 3/ena (Enable RIP on IP interface 3)
>> RIP Interface 3# apply              (Apply your changes)
>> RIP Interface 3# save              (Save the configuration)
```

Use the `/maint/route/dump` command to check the current valid routes in the routing table of the switch.

For those RIP learnt routes within the garbage collection period, that are routes phasing out of the routing table with metric 16, use the `/info/13/rip/routes` command. Locally configured static routes do not appear in the RIP Routes table.

---

## Chapter 18. Internet Group Management Protocol

Internet Group Management Protocol (IGMP) is used by IPv4 Multicast routers (Mrouters) to learn about the existence of host group members on their directly attached subnet. The IPv4 Mrouters get this information by broadcasting IGMP Membership Queries and listening for IPv4 hosts reporting their host group memberships. This process is used to set up a client/server relationship between an IPv4 multicast source that provides the data streams and the clients that want to receive the data. The switch supports three versions of IGMP:

- IGMPv1: Defines the method for hosts to join a multicast group. However, this version does not define the method for hosts to leave a multicast group. See RFC 1112 for details.
- IGMPv2: Adds the ability for a host to signal its desire to leave a multicast group. See RFC 2236 for details.
- IGMPv3: Adds support for source filtering by which a host can report interest in receiving packets only from specific source addresses, or from all but specific source addresses, sent to a particular multicast address. See RFC 3376 for details.

The 1/10Gb Uplink ESM (GbESM) can perform IGMP Snooping, or act as an IGMP Relay (proxy) device.

The following topics are discussed in this chapter:

- [“IGMP Terms” on page 254](#)
- [“How IGMP Works” on page 255](#)
- [“GbESM Capacity and IGMP Default Values” on page 256](#)
- [“IGMP Snooping” on page 257](#)
- [“IGMP Relay” on page 269](#)
- [“Additional IGMP Features” on page 279](#)

---

## IGMP Terms

Listed below are the commonly used IGMP terms:

- Multicast traffic: Flow of data from one source to multiple destinations.
- Group: A multicast stream to which a host can join. Multicast groups have IP addresses in the range: 224.0.1.0 to 239.255.255.255.
- IGMP Querier: A router or switch in the subnet that generates *Membership Queries*.
- IGMP Snooper: A Layer 3 device that forwards multicast traffic only to hosts that are interested in receiving multicast data. This device can be a router or a Layer 3 switch.
- Multicast Router: A router configured to make routing decisions for multicast traffic. The router identifies the type of packet received (unicast or multicast) and forwards the packet to the intended destination.
- IGMP Proxy: A device that filters Join messages and Leave messages sent upstream to the Mrouter to reduce the load on the Mrouter.
- Membership Report: A report sent by the host that indicates an interest in receiving multicast traffic from a multicast group.
- Leave: A message sent by the host when it wants to leave a multicast group.
- FastLeave: A process by which the switch stops forwarding multicast traffic to a port as soon as it receives a Leave message.
- Membership Query: Message sent by the Querier to verify if hosts are listening to a group.
- General Query: A *Membership Query* sent to all hosts. The Group address field for general queries is 0.0.0.0 and the destination address is 224.0.0.1.
- Group-specific Query: A *Membership Query* sent to all hosts in a multicast group.

---

## How IGMP Works

When IGMP is not configured, switches forward multicast traffic through all ports, increasing network load. When IGMPv2 is configured on a switch, multicast traffic flows as follows:

- A server sends multicast traffic to a multicast group.
- The Mrouter sends *Membership Queries* to the switch, which forwards them to all ports in a given VLAN.
- Hosts respond with *Membership Reports* if they want to join a group. The switch forwards these reports to the Mrouter.
- The switch forwards multicast traffic only to hosts that have joined a group.
- The Mrouter periodically sends *Membership Queries* to ensure that a host wants to continue receiving multicast traffic. If a host does not respond, the IGMP Snooper stops sending traffic to the host.
- The host can initiate the Leave process by sending an IGMP Leave packet to the IGMP Snooper.
- When a host sends an IGMPv2 Leave packet, the IGMP Snooper queries to find out if any other host connected to the port is interested in receiving the multicast traffic. If it does not receive a Join message in response, the IGMP Snooper removes the group entry and passes on the information to the Mrouter.

---

## GbESM Capacity and IGMP Default Values

The following table lists the maximum and minimum values of the GbESM variables.

*Table 19. GbESM Capacity Table*

Variable	Maximum
IGMP Entries - Snoop	2048
IGMP Entries - Relay	1000
VLANs - Snoop	1023
VLANs - Relay	8
Static Mrouters	16
Dynamic Mrouters	16
Number of IGMP Filters	16
IPMC Groups (IGMP Relay)	1000

The following table lists the default settings for IGMP features and variables.

*Table 20. IGMP Default Configuration Settings*

Field	Default Value
Global IGMP State	Disabled
IGMP Snooping	Disabled
IGMP Filtering	Disabled
IP Multicast (IPMC) Flood	Enabled
IGMP FastLeave	Disabled for all VLANs
IGMP Mrouter Timeout	255 Seconds
IGMP Report Timeout Variable	10 Seconds
IGMP Query-Interval Variable	125 Seconds
IGMP Robustness Variable	2
IGMPv3	Disabled
IGMPv3 number of sources	8 (The switch processes only the first eight sources listed in the IGMPv3 group record.) Valid range: 1 - 64
IGMPv3 - allow v1v2 Snooping	Enabled



---

## IGMP Snooping

IGMP Snooping allows a switch to listen to the IGMP conversation between hosts and M routers. By default, a switch floods multicast traffic to all ports in a broadcast domain. With IGMP Snooping enabled, the switch learns the ports interested in receiving multicast data and forwards it only to those ports. IGMP Snooping conserves network resources.

The switch can sense IGMP *Membership Reports* from attached hosts and act as a proxy to set up a dedicated path between the requesting host and a local IPv4 M router. After the path is established, the switch blocks the IPv4 multicast stream from flowing through any port that does not connect to a host member, thus conserving bandwidth.

## IGMP Groups

When the switch is in stacking mode, one IGMP entry is allocated for each unique join request, based on the combination of the port, VLAN, and IGMP group address. If multiple ports join the same IGMP group, they require separate IGMP entries, even if using the same VLAN.

In stand-alone (non-stacking) mode, one IGMP entry is allocated for each unique Join request, based on the VLAN and IGMP group address only (regardless of the port). If multiple ports join the same IGMP group using the same VLAN, only a single IGMP entry is used.

## IGMPv3

IGMPv3 includes new Membership Report messages that extend IGMP functionality. The GbESM provides snooping capability for all types of IGMPv3 *Membership Reports*.

IGMPv3 is supported in stand-alone (non-stacking) mode only.

IGMPv3 supports Source-Specific Multicast (SSM). SSM identifies session traffic by both source and group addresses. The GbESM uses *source filtering*, which allows hosts to report interest in receiving multicast packets only from specific source addresses, or from all but specific source addresses.

The GbESM supports the following IGMPv3 filter modes:

- INCLUDE mode: The host requests membership to a multicast group and provides a list of IPv4 addresses from which it wants to receive traffic.
- EXCLUDE mode: The host requests membership to a multicast group and provides a list of IPv4 addresses from which it does not want to receive traffic. This indicates that the host wants to receive traffic only from sources that are not part of the Exclude list. To disable snooping on EXCLUDE mode reports, use the following command:

```
>> # /cfg/13/igmp/snoop/igmpv3/exclude dis
```

By default, the GbESM snoops the first eight sources listed in the IGMPv3 Group Record. Use the following command to change the number of snooping sources:

```
>> # /cfg/13/igmp/snoop/igmpv3/sources <1-64>
```

IGMPv3 Snooping is compatible with IGMPv1 and IGMPv2 Snooping. To disable snooping on version 1 and version 2 reports, use the following command:

```
>> # /cfg/l3/igmp/snoop/igmpv3/v1v2 dis
```

## IGMP Snooping Configuration Guidelines

Consider the following guidelines when you configure IGMP Snooping:

- IGMP operation is independent of the routing method. You can use RIP, OSPF, or static routes for Layer 3 routing.
- When multicast traffic flood is disabled, the multicast traffic sent by the multicast server is discarded if no hosts or Mrouter are learned on the switch.
- The Mrouter periodically sends IGMP Queries.
- The switch learns the Mrouter on the port connected to the router when it sees Query messages. The switch then floods the IGMP queries on all other ports including a Trunk Group, if any.
- Multicast hosts send IGMP Reports as a reply to the IGMP Queries sent by the Mrouter.
- The switch can also learn an Mrouter when it receives a PIM Hello packet from another device. However, an Mrouter learned from a PIM packet has a lower priority than an Mrouter learned from an IGMP Query. A switch overwrites an Mrouter learned from a PIM packet when it receives an IGMP Query on the same port.
- A host sends an IGMP Leave message to its multicast group. The expiration timer for this group is updated to IGMP timeout variable (the default is 10 seconds). The L3 switch sends IGMP Group-Specific Query to the host that had sent the Leave message. If the host does not respond with an IGMP Report during the timeout interval, all the groups expire and the switch deletes the host from the IGMP groups table. The switch then proxies the IGMP Leave messages to the Mrouter.

## IGMP Snooping Configuration Example

This section provides steps to configure IGMP Snooping on the GbESM.

1. Configure port and VLAN membership on the switch.
2. Turn on IGMP.

```
>> # /cfg/l3/igmp/on (Turn on IGMP)
```

3. Add VLANs to IGMP Snooping and enable the feature.

```
>> IGMP# snoop (Access IGMP Snoop menu)  
>> IGMP Snoop# add 1 (Add VLAN 1 to IGMP snooping)  
>> IGMP Snoop# ena (Enable IGMP Snooping)
```

4. Enable IGMPv3 Snooping (optional).

```
>> IGMP Snoop# igmpv3 (Access IGMPv3 menu)  
>> IGMP V3 Snoop# ena (Enable IGMPv3 Snooping)
```

5. Apply and save the configuration.

```
>> IGMP V3 Snoop# apply (Apply the configuration)
>> IGMP V3 Snoop# save (Save your changes)
```

6. View dynamic IGMP information.

To display information about IGMP Groups:

```
>> Main# /info/l3/igmp/dump
Note: Local groups (224.0.0.x) are not snooped/relayed and do not appear.
Source      Group      VLAN  Port  Version  Mode  Expires  Fwd
-----
10.1.1.1    232.1.1.1  2     EXT4  V3       INC   4:16     Yes
10.1.1.5    232.1.1.1  2     EXT4  V3       INC   4:16     Yes
*           232.1.1.1  2     EXT4  V3       INC   -        No
10.10.10.43 235.0.0.1  9     EXT1  V3       INC   2:26     Yes
*           236.0.0.1  9     EXT1  V3       EXC   -        Yes
```

To display information about Mroutes learned by the switch:


```
>> Main# /info/l3/igmp/mrouter/dump
SrcIP      VLAN  Port  Version  Expires  MRT  QRV  QQIC
-----
*           1     EXT4  V2       static   -    -    -
10.10.10.10 2     EXT3  V3       4:09     128  2    125
```

**Note:** If IGMP Snooping v1/v2 is enabled and IGMPv3 Snooping is disabled, the output of IGMPv3 reports and queries show some items as IGMPv3 (V3), though they retain v2 behavior. For example, the Source IPv4 address is not relevant for v2 entries.

## Advanced Configuration Example: IGMP Snooping

Figure 23 shows an example topology. Switches B and C are configured with IGMP Snooping.

Figure 23. Topology



Devices in the above topology are configured as follows:

- STG 2 includes VLAN 2; STG 3 includes VLAN 3.
- The multicast server sends IP multicast traffic for the following groups:
  - VLAN 2, 225.10.0.11 – 225.10.0.12, Source: 22.10.0.11
  - VLAN 2, 225.10.0.13 – 225.10.0.15, Source: 22.10.0.13
  - VLAN 3, 230.0.2.1 – 230.0.2.2, Source: 22.10.0.1
  - VLAN 3, 230.0.2.3 – 230.0.2.5, Source: 22.10.0.3
- The Mrouter sends IGMP Query packets in VLAN 2 and VLAN 3. The Mrouter's IP address is 10.10.10.10.
- The multicast hosts send the following IGMP Reports:
  - IGMPv2 Report, VLAN 2, Group: 225.10.0.11, Source: \*
  - IGMPv2 Report, VLAN 3, Group: 230.0.2.1, Source: \*
  - IGMPv3 IS\_INCLUDE Report, VLAN 2, Group: 225.10.0.13, Source: 22.10.0.13
  - IGMPv3 IS\_INCLUDE Report, VLAN 3, Group: 230.0.2.3, Source: 22.10.0.3

- The hosts receive multicast traffic as follows:
  - Host 1 receives multicast traffic for groups (\*, 225.10.0.11), (22.10.0.13, 225.10.0.13)
  - Host 2 receives multicast traffic for groups (\*, 225.10.0.11), (\*, 230.0.2.1), (22.10.0.13, 225.10.0.13), (22.10.0.3, 230.0.2.3)
  - Host 3 receives multicast traffic for groups (\*, 230.0.2.1), (22.10.0.3, 230.0.2.3)
- The Mrouter receives all the multicast traffic.

## Prerequisites

Before you configure IGMP Snooping, ensure you have performed the following actions:

- Configured VLANs.
- Enabled IGMP.
- Configured a switch or Mrouter as the Querier.
- Identified the IGMP version(s) you want to enable.
- Disabled IGMP flooding.

## Configuration

This section provides the configuration details of the switches shown in [Figure 23](#).

### Switch A Configuration

1. Configure VLANs 2 and 3, enable tagging on ports 1 through 5 and add them to the VLANs 2 and 3. Remove ports 1 through 5 from VLAN 1.

```
>> # /cfg/port 1
>> Port 1# tag enable
>> Port 1# /cfg/12/vlan 2
>> VLAN 2# ena
>> VLAN 2# add 1
>> VLAN 2# ../vlan 3
>> VLAN 3# ena
>> VLAN 3# add 1
>> VLAN 3# ../vlan 1
>> VLAN 1# rem 1
```

Repeat the above step for ports 2 through 5.

2. Configure an IP interface with IPv4 address, and assign a VLAN.

```
>> VLAN 1# /cfg/13/if 1
>> IP Interface 1# addr 10.10.10.1
>> IP Interface 1# ena
>> IP Interface 1# vlan 2
```

3. Configure STP. Assign a bridge priority lower than the default bridge priority to enable the switch to become the STP root in STG 2 and STG 3.

```
>> IP Interface 1# /cfg/12/stg 2
>> Spanning Tree Group 2# add 2
>> Spanning Tree Group 2# brg/prior 4096

>> Spanning Tree Group 2# /cfg/12/stg 3
>> Spanning Tree Group 3# add 3
>> Spanning Tree Group 3# brg/prior 4096
```

4. Configure LACP dynamic trunk groups (portchannels).

```
>> Spanning Tree Group 3# /cfg/12/lacp/port 1
>> LACP Port 1# mode active
>> LACP Port 1# adminkey 100
>> LACP Port 1# ../port 2
>> LACP Port 2# mode active
>> LACP Port 2# adminkey 100
>> LACP Port 2# ../port 3
>> LACP Port 3# mode active
>> LACP Port 3# adminkey 200
>> LACP Port 3# ../port 4
>> LACP Port 4# mode active
>> LACP Port 4# adminkey 200
```

## Switch B Configuration

1. Configure VLANs 2 and 3. Enable tagging on ports 1 through 4 and port 6. Add the ports to VLANs 2 and 3.

```
>> # /cfg/port 1
>> Port 1# tag ena
>> Port 1# /cfg/12/vlan 2
>> VLAN 2# ena
>> VLAN 2# add 1
>> VLAN 2# ../vlan 3
>> VLAN 3# ena
>> VLAN 3# add 1
```

Repeat the step for ports 2, 3, 4, and 6.

2. Remove ports 1 through 6 from VLAN 1.

```
>> VLAN 3# /cfg/12/vlan 1
>> VLAN 1# rem 1
```

Repeat the step for ports 2 through 6.

3. Configure an IP interface with IPv4 address, and assign a VLAN.

```
>> VLAN 1# /cfg/13/if 1
>> IP Interface 1# addr 10.10.10.2
>> IP Interface 1# ena
>> IP Interface 1# vlan 2
```

4. Configure STP. Reset the ports to make the edge configuration operational.

```
>> IP Interface 1# /cfg/12/stg 2
>> Spanning Tree Group 2# add 2

>> Spanning Tree Group 2# ../stg 3
>> Spanning Tree Group 3# add 3

>> Spanning Tree Group 3# /cfg/port 5
>> Port 5# stp
>> Port 5 STP# edge enable

>> Port 5 STP# /cfg/port 6
>> Port 6# stp
>> Port 6 STP# edge enable
>> Port 6 STP# apply
>> Port 6 STP# /oper/port 5,6/disable/enable
```

5. Configure an LACP dynamic trunk group (portchannel).

```
>> Port 6 STP# /cfg/12/lacp/port 1
>> LACP Port 1# adminkey 300
>> LACP Port 1# mode active
>> LACP Port 1# ../port 2
>> LACP Port 2# adminkey 300
>> LACP Port 2# mode active
```

6. Configure a static trunk group (portchannel).

```
>> LACP Port 2# /cfg/12/trunk 1
>> Trunk group 1# add 3,4
>> Trunk group 1# enable
```

7. Configure IGMP Snooping.

```
>> Trunk group 1# /cfg/13/igmp/on
>> IGMP# snoop
>> IGMP Snoop# add 2,3
>> IGMP Snoop# srcip 10.10.10.2
>> IGMP Snoop# igmpv3
>> IGMP V3 Snoop# ena
>> IGMP V3 Snoop# sources 64
>> IGMP V3 Snoop# ..
>> IGMP Snoop# ena

>> IGMP Snoop# /cfg/13/flooding
>> flooding# vlan 2
>> VLAN 2 Flooding# flood d
>> VLAN 2 Flooding# ..
>> flooding# vlan 3
>> VLAN 3 Flooding# flood d
```

## Switch C Configuration

1. Configure VLAN 2. Add ports 1 through 4 and port 6 to VLAN 2. Enable tagging.

```
>> # /cfg/port 1
>> Port 1# tag ena
>> Port 1# /cfg/12/vlan 2
>> VLAN 2# ena
>> VLAN 2# add 1
```

Repeat the step for ports 2, 3, 4, and 6.

2. Configure VLAN 3. Add ports 1 through 6 to VLAN 3.

```
>> VLAN 2# /cfg/12/vlan 3
>> VLAN 3# ena
>> VLAN 3# add 1
```

Repeat the step for ports 2 through 6.

3. Remove ports 1 through 6 from VLAN 1.

```
>> VLAN 3# /cfg/12/vlan 1
>> VLAN 1# rem 1
```

Repeat the step for ports 2 through 6.

4. Configure an IP interface with IPv4 address, and assign a VLAN.

```
>> VLAN 1# /cfg/13/if 1
>> IP Interface 1# addr 10.10.10.3
>> IP Interface 1# ena
>> IP Interface 1# vlan 2
```

5. Configure STP. Reset the ports to make the edge configuration operational.

```
>> IP Interface 1# /cfg/12/stg 2
>> Spanning Tree Group 2# add 2

>> Spanning Tree Group 2# ../stg 3
>> Spanning Tree Group 3# add 3

>> Spanning Tree Group 3# /cfg/port 5
>> Port 5# stp
>> Port 5 STP# edge enable

>> Port 5 STP# /cfg/port 6
>> Port 6# stp
>> Port 6 STP# edge enable
>> Port 6 STP# apply
>> Port 6 STP# /oper/port 5,6/disable/enable
```

6. Configure an LACP dynamic trunk group (portchannel).

```
>> Port 6 STP# /cfg/12/lacp/port 1
>> LACP Port 1# adminkey 400
>> LACP Port 1# mode active
>> LACP Port 1# ../port 2
>> LACP Port 2# adminkey 400
>> LACP Port 2# mode active
```



## 7. Configure a static trunk group (portchannel).

```
>> LACP Port 2# /cfg/12/trunk 1
>> Trunk group 1# add 3,4
>> Trunk group 1# enable
```

## 8. Configure IGMP Snooping.

```
>> LACP Port 2# /cfg/13/igmp/on
>> IGMP# snoop
>> IGMP Snoop# add 2,3
>> IGMP Snoop# srcip 10.10.10.3
>> IGMP Snoop# igmpv3
>> IGMP V3 Snoop# ena
>> IGMP V3 Snoop# sources 64
>> IGMP V3 Snoop# ..
>> IGMP Snoop# ena

>> IGMP Snoop# /cfg/13/flooding
>> flooding# vlan 2
>> VLAN 2 Flooding# flood d
>> VLAN 2 Flooding# ..
>> flooding# vlan 3
>> VLAN 3 Flooding# flood d
```

## Troubleshooting

This section provides the steps to resolve common IGMP Snooping configuration issues. The topology described in [Figure 23](#) is used as an example.

### Issue: Multicast traffic from non-member groups reaches the host or Mrouter

- Check if traffic is unregistered. For unregistered traffic, an IGMP entry is not displayed in the IGMP groups table.

```
>> # /info/13/igmp/dump
```

- Ensure IPMC flooding is disabled and CPU is enabled.

```
>> # /cfg/13/flooding
>> flooding# vlan 2
>> VLAN 2 Flooding# flood d
>> VLAN 2 Flooding# cpu e
>> VLAN 2 Flooding# ..
>> flooding# vlan 3
>> VLAN 3 Flooding# flood d
>> VLAN 3 Flooding# cpu e
```

- Check the egress port's VLAN membership. The ports to which the hosts and Mrouter are connected must be used only for VLAN 2 and VLAN 3.

```
>> # /info/12/vlan
```

**Note:** To avoid such a scenario, disable IPMC flooding for all VLANs enabled on the switches (if this is an acceptable configuration).

- Check IGMP Reports on switches B and C for information about the IGMP groups.

```
>> # /info/13/igmp/dump
```

If the non-member IGMP groups are displayed in the table, close the application that may be sending the IGMP Reports for these groups.

Identify the traffic source by using a sniffer on the hosts and reading the source IP/MAC address. If the source IP/MAC address is unknown, check the port statistics to find the ingress port.

```
>> # /info/port <port id>
```

- Ensure no static multicast MACs, static multicast groups, or static Mrouters are configured.

```
>> # /info/12/oam/dump
>> # /info/13/igmp/ipmcgrp
>> # /info/13/igmp/mrouter/dump
```

- Ensure IGMP Relay and PIM are not configured.

```
>> # /cfg/13/igmp/relay/cur
```

### Issue: Not all multicast traffic reaches the appropriate receivers

- Ensure hosts are sending IGMP Reports for all the groups. Check the VLAN on which the groups are learned.

```
>> # /info/13/igmp/dump
```

If some of the groups are not displayed, ensure the multicast application is running on the host device and the generated IGMP Reports are correct.

- Ensure multicast traffic reaches the switch to which the host is connected.

Close the application sending the IGMP Reports. Clear the IGMP groups by flapping (disabling, then re-enabling) the port.

**Note:** To clear all IGMP groups, use the following commands:

```
>> # /cfg/12/trunk <group number>
```

```
>> Trunk group# rem <port number>
```

However, this will clear all the IGMP groups and will influence other hosts.

Check if the multicast traffic reaches the switch.

```
>> # /info/13/igmp/ipmcgrp
```

If the multicast traffic group is not displayed in the table, check the link state, VLAN membership, and STP convergence.

- Ensure multicast server is sending all the multicast traffic.
- Ensure no static multicast MACs, static multicast groups, or static multicast routes are configured.

### Issue: IGMP queries sent by the Mrouter do not reach the host

- Ensure the Mrouter is learned on switches B and C.

```
>> # /info/13/igmp/mrouter/dump
```

If it is not learned on switch B but is learned on switch C, check the link state of the trunk group, VLAN membership, and STP convergence.

If it is not learned on any switch, ensure the multicast application is running and is sending correct IGMP Query packets.

If it is learned on both switches, check the link state, VLAN membership, and STP port states for the ports connected to the hosts.

### Issue: IGMP Reports/Leaves sent by the hosts do not reach the Mrouter

- Ensure IGMP Queries sent by the Mrouter reach the hosts.
- Ensure the Mrouter is learned on both switches. Note that the Mrouter may not be learned on switch B immediately after a trunk group failover/failback.

```
>> # /info/13/igmp/mrouter/dump
```

- Ensure the host's multicast application is started and is sending correct IGMP Reports/Leaves.

```
>> # /info/13/igmp/dump
```

### Issue: Multicast traffic reaches incorrect VLAN

- Check port VLAN membership.
- Check IGMP Reports sent by the host.
- Check multicast data sent by the server.

### Issue: The Mrouter is learned on the incorrect trunk group

- Check link state. Trunk group 1 might be down or in STP discarding state.
- Check STP convergence.
- Check port VLAN membership.

### Issue: Hosts receive multicast traffic at a lower rate than normal

**Note:** This behavior is expected if IPMC flood is disabled and CPU is enabled. As soon as the IGMP/IPMC entries are installed on ASIC, the IPMC traffic recovers and is forwarded at line rate. This applies to unregistered IPMC traffic.

- Ensure a multicast threshold is not configured on the trunks.

```
>> # /cfg/port <port id>  
>> Port <port id># mrate dis
```

- Check link speeds and network congestion.

---

## IGMP Relay

The GbESM can act as an IGMP Relay (or IGMP Proxy) device that relays IGMP multicast messages and traffic between an Mrouter and end stations. IGMP Relay allows the GbESM to participate in network multicasts with no configuration of the various multicast routing protocols, so you can deploy it in the network with minimal effort.

To an IGMP host connected to the GbESM, IGMP Relay appears to be an IGMP Mrouter. IGMP Relay sends *Membership Queries* to hosts, which respond by sending an IGMP response message. A host can also send an unsolicited Join message to the IGMP Relay.

To an Mrouter, IGMP Relay appears as a host. The Mrouter sends IGMP host queries to IGMP Relay, and IGMP Relay responds by forwarding IGMP host reports and unsolicited Join messages from its attached hosts.

IGMP Relay also forwards multicast traffic between the Mrouter and end stations, similar to IGMP Snooping.

You can configure up to two Mrouters to use with IGMP Relay. One Mrouter acts as the primary Mrouter, and one is the backup Mrouter. The GbESM uses health checks to select the primary Mrouter.

## Configuration Guidelines

Consider the following guidelines when you configure IGMP Relay:

- IGMP Relay is supported in stand-alone (non-stacking) mode only.
- IGMP Relay and IGMP Snooping are mutually exclusive—if you enable IGMP Relay, you must turn off IGMP Snooping.
- Add the upstream Mrouter VLAN to the IGMP Relay list, using the following command:

```
>> # /cfg/l3/igmp/relay/add <VLAN number>
```

- If IGMP hosts reside on different VLANs, you must disable IGMP flooding (/cfg/l3/flooding/vlan <vlan id>/flood dis) and enable CPU forwarding (/cfg/l3/flooding/vlan <vlan id>/cpu ena) to ensure that multicast data is forwarded across the VLANs.

## Configure IGMP Relay

Use the following procedure to configure IGMP Relay.

1. Configure IP interfaces with IPv4 addresses, and assign VLANs.

>> # /cfg/13/if 2	(Select IP interface 2)
>> IP Interface 2# addr 10.10.1.1	(Configure IPv4 address for IF 2)
>> IP Interface 2# mask 255.255.255.0	(Configure mask for IF 2)
>> IP Interface 2# vlan 2	(Assign VLAN 2 to IF 2)
>> IP Interface 2# /cfg/13/if 3	(Select IP interface 3)
>> IP Interface 3# addr 10.10.2.1	(Configure IPv4 address for IF 3)
>> IP Interface 3# mask 255.255.255.0	(Configure mask for IF 3)
>> IP Interface 3# vlan 3	(Assign VLAN 3 to IF 3)

2. Turn on IGMP.

>> IP Interface 3# /cfg/13/igmp/on	(Turn on IGMP)
------------------------------------	----------------

3. Enable IGMP Relay and add VLANs to the downstream network.

>> IGMP# /cfg/13/igmp/relay/ena	(Enable IGMP Relay)
>> IGMP Relay# add 2	(Add VLAN 2 to IGMP Relay)
Vlan 2 added.	
>> IGMP Relay# add 3	(Add VLAN 3 to IGMP Relay)
Vlan 3 added.	

4. Configure the upstream Mrouters with IPv4 addresses.

>> IGMP Relay# mrtr 1/addr 100.0.1.2/ena
Current IP address: 0.0.0.0
New pending IP address: 100.0.1.2
Current status: disabled
New status: enabled
>> Multicast router 1# ..
>> IGMP Relay# mrtr 2/addr 100.0.2.4/ena
Current IP address: 0.0.0.0
New pending IP address: 100.0.2.4
Current status: disabled
New status: enabled


5. Apply and save the configuration.

>> Multicast router 2# apply	(Apply the configuration)
>> Multicast router 2# save	(Save the configuration)

## Advanced Configuration Example: IGMP Relay

Figure 24 shows an example topology. Switches B and C are configured with IGMP Relay.

Figure 24. Topology



Devices in the above topology are configured as follows:

- The IP address of Multicast Router 1 is 5.5.5.5
- The IP address of Multicast Router 2 is 5.5.5.6
- STG 2 includes VLAN2; STG 3 includes VLAN 3; STG 5 includes VLAN 5.
- The multicast server sends IP multicast traffic for the following groups:
  - VLAN 2, 225.10.0.11 – 225.10.0.15
- The multicast hosts send the following IGMP Reports:
  - Host 1: 225.10.0.11 – 225.10.0.12, VLAN 3
  - Host 2: 225.10.0.12 – 225.10.0.13, VLAN 2; 225.10.0.14 – 225.10.0.15, VLAN 3
  - Host 3: 225.10.0.13 – 225.10.0.14, VLAN 2
- The Mrouter receives all the multicast traffic.

## Prerequisites

Before you configure IGMP Snooping, ensure you have performed the following actions:

- Configure VLANs.
- Enable IGMP.
- Identify the IGMP version(s) you want to enable.
- Disable IGMP flooding.
- Disable IGMP Snooping.

## Configuration

This section provides the configuration details of the switches in [Figure 24](#).

### Switch A Configuration

1. Configure a VLAN.

```
>> # /cfg/12/vlan 2
>> VLAN 2# ena
>> VLAN 2# add 1-5
```

2. Configure an IP interface with IPv4 address, and assign a VLAN.

```
>> VLAN 2# /cfg/13/if 2
>> IP Interface 2# addr 2.2.2.10
>> IP Interface 2# ena
>> IP Interface 2# vlan 2
```

3. Configure STP and root bridge. Assign a bridge priority lower than the default bridge priority to enable the switch to become the STP root in STG 2.

```
>> IP Interface 2# /cfg/12/stg 2
>> Spanning Tree Group 2# add 2
>> Spanning Tree Group 2# brg
>> Spanning Tree Group 2# prior 4096
```

4. Configure LACP dynamic trunk groups (portchannels).

```
>> Spanning Tree Group 2# /cfg/12/lacp/port 1
>> LACP Port 1# adminkey 100
>> LACP Port 1# mode active

>> LACP Port 1# ../port 2
>> LACP Port 2# adminkey 100
>> LACP Port 2# mode active

>> LACP Port 2# ../port 3
>> LACP Port 3# adminkey 200
>> LACP Port 3# mode active

>> LACP Port 3# ../port 4
>> LACP Port 4# adminkey 200
>> LACP Port 4# mode active
```



## Switch B Configuration

### 1. Configure VLANs and tagging.

```
>> # /cfg/12/vlan 2
>> VLAN 2# ena
>> VLAN 2# add 1
>> VLAN 2# add 2
>> VLAN 2# add 3
>> VLAN 2# add 4
>> VLAN 2# add 6
>> VLAN 2# /cfg/port 6
>> Port 6# tag enable

>> Port 6# /cfg/12/vlan 3
>> VLAN 3# ena
>> VLAN 3# add 5
>> VLAN 3# add 6
```

### 2. Configure IP interfaces with IPv4 addresses, and assign VLANs.

```
>> VLAN 3# /cfg/13/if 2
>> Interface IP 2# addr 2.2.2.20
>> Interface IP 2# ena
>> Interface IP 2# vlan 2

>> Interface IP 2# /cfg/13/if 3
>> Interface IP 3# addr 3.3.3.20
>> Interface IP 3# ena
>> Interface IP 3# vlan 3

>> Interface IP 3# /cfg/13/gw 2
>> Default gateway 2# addr 2.2.2.30
>> Default gateway 2# ena
```

### 3. Configure STP.

```
>> Default gateway 2# /cfg/12/stg 2
>> Spanning Tree Group 2# add 2

>> Spanning Tree Group 2# /cfg/12/stg 3
>> Spanning Tree Group 3# add 3

>> Spanning Tree Group 3# /cfg/port 5
>> Port 5# stp
>> Port 5 STP# edge d
>> Port 5 STP# edge e

>> Port 5 STP# /cfg/port 6
>> Port 6# stp
>> Port 6 STP# edge d
>> Port 6 STP# edge e
```

#### 4. Configure an LACP dynamic trunk group (portchannel).

```
>> Port 6 STP# /cfg/12/lacp/port 1
>> LACP Port 1# adminkey 300
>> LACP Port 1# mode active

>> LACP Port 1# /cfg/12/lacp/port 2
>> LACP Port 2# adminkey 300
>> LACP Port 2# mode active
```

#### 5. Configure a static trunk group (portchannel).

```
>> LACP Port 2# /cfg/12/trunk 1
>> Trunk group 1# add 3,4
>> Trunk group 1# enable
```

#### 6. Configure IGMP Relay.

```
>> LACP Port 2# /cfg/13/igmp/on (Turn on IGMP)
>> IGMP# relay
>> IGMP Relay# add 2
>> IGMP Relay# add 3

>> IGMP Relay# mrtr 1
>> Multicast router 1# addr 5.5.5.5
>> Multicast router 1# ena
>> Multicast router 1# ..
>> IGMP Relay# mrtr 2
>> Multicast router 2# addr 5.5.5.6
>> Multicast router 2# ena
>> Multicast router 2# ..

>> IGMP Relay# ena

>> IGMP Relay# /cfg/13/flooding
>> flooding# vlan 2
>> VLAN 2 Flooding# flood disable
>> VLAN 2 Flooding# ..
>> flooding# vlan 3
>> VLAN 3 Flooding# flood disable
```

## Switch C Configuration

### 1. Configure VLANs.

```
>> # /cfg/12/vlan 2
>> VLAN 2# ena
>> VLAN 2# add 1
>> VLAN 2# add 2
>> VLAN 2# add 3
>> VLAN 2# add 4
>> VLAN 2# add 5

>> VLAN 2# /cfg/12/vlan 5
>> VLAN 5# ena
>> VLAN 5# add 6
>> VLAN 5# add 7
```

### 2. Configure IP interfaces with IPv4 addresses, and assign VLANs.

```
>> VLAN 5# /cfg/13/if 2
>> Interface IP 2# addr 2.2.2.30
>> Interface IP 2# ena
>> Interface IP 2# vlan 2

>> Interface IP 2# /cfg/13/if 3
>> Interface IP 3# addr 5.5.5.30
>> Interface IP 3# ena
>> Interface IP 3# vlan 5

> Interface IP 3# /cfg/13/gw 2
>> Default gateway 2# addr 2.2.2.20
>> Default gateway 2# ena
```

### 3. Configure STP.

```
>> Default gateway 2# /cfg/12/stg 2
>> Spanning Tree Group 2# add 2

>> Spanning Tree Group 2# /cfg/12/stg 5
>> Spanning Tree Group 5# add 5

>> Spanning Tree Group 5# /cfg/port 5
>> Port 5# stp
>> Port 5 STP# edge d
>> Port 5 STP# edge e

>> Port 5 STP# /cfg/port 6
>> Port 6# stp
>> Port 6 STP# edge d
>> Port 6 STP# edge e

>> Port 6 STP# /cfg/port 7
>> Port 7# stp
>> Port 7 STP# edge d
>> Port 7 STP# edge e
```

#### 4. Configure an LACP dynamic trunk group (portchannel).

```
>> Port 7 STP# /cfg/12/lacp/port 1
>> LACP Port 1# adminkey 400
>> LACP Port 1# mode active

>> LACP Port 1# /cfg/12/lacp/port 2
>> LACP Port 2# adminkey 400
>> LACP Port 2# mode active
```

#### 5. Configure a static trunk group (portchannel).

```
>> LACP Port 2# /cfg/12/trunk 1
>> Trunk group 1# add 3,4
>> Trunk group 1# enable
```

#### 6. Enable IGMP.

```
>> LACP Port 2# /cfg/13/igmp/on (Enable IGMP)
```

#### 7. Configure IGMP Relay.

```
>> IGMP# relay
>> IGMP Relay# add 2
>> IGMP Relay# add 5

>> IGMP Relay# mrtr 1
>> Multicast router 1# addr 5.5.5.5
>> Multicast router 1# ena
>> Multicast router 1# ..

>> IGMP Relay# mrtr 2
>> Multicast router 2# addr 5.5.5.6
>> Multicast router 2# ena
>> Multicast router 2# ..

>> IGMP Relay# ena

>> IGMP Relay# /cfg/13/flooding
>> flooding# vlan 2
>> VLAN 2 Flooding# flood d
>> VLAN 2 Flooding# ..
>> flooding# vlan 5
>> VLAN 5 Flooding# flood d
```

## Troubleshooting

This section provides the steps to resolve common IGMP Relay configuration issues. The topology described in [Figure 24](#) is used as an example.

### Issue: Multicast traffic from non-member groups reaches the hosts or Mrouter

- Ensure IPMC flood is disabled.

```
>> # /cfg/13/flooding
>> flooding# vlan <VLAN number>
>> VLAN <n> Flooding# flood disable
```

- Check the egress port's VLAN membership. The ports to which the hosts and Mrouter are connected must be used only for VLAN 2, VLAN 3, or VLAN 5.

```
>> # /info/12/vlan
```

**Note:** To avoid such a scenario, disable IPMC flooding for all VLANs enabled on the switches (if this is an acceptable configuration).

- Check IGMP Reports on switches B and C for information about IGMP groups.

```
>> # /info/13/igmp/dump
```

If non-member IGMP groups are displayed in the table, close the application that may be sending the IGMP Reports for these groups.

Identify the traffic source by using a sniffer on the hosts and reading the source IP address/MAC address. If the source IP address/MAC address is unknown, check the port statistics to find the ingress port.

```
>> # /info/port <port ID>
```

- Ensure no static multicast MACs and static Mrouters are configured.

### Issue: Not all multicast traffic reaches the appropriate receivers

- Ensure hosts are sending IGMP Reports for all the groups. Check the VLAN on which the groups are learned.

```
>> # /info/13/igmp/dump
```

If some of the groups are not displayed, ensure the multicast application is running on the host device and the generated IGMP Reports are correct.

- Ensure the multicast traffic reaches the switch to which the host is connected. Close the application sending the IGMP Reports. Clear the IGMP groups by flapping (disabling, then re-enabling) the port.

**Note:** To clear all IGMP groups, use the following commands:

```
>> # /cfg/12/trunk <group number>
>> Trunk group# rem <port number>
```

However, this will clear all the IGMP groups and will influence other hosts.

Check if the multicast traffic reaches the switch.

```
>> # /info/13/igmp/ipmcgrp
```

If the multicast traffic group is not displayed in the table, check the link state, VLAN membership, and STP convergence.

- Ensure the multicast server is sending all the multicast traffic.
- Ensure no static multicast MACs or static multicast routes are configured.
- Ensure PIM is not enabled on the switches.

### **Issue: IGMP Reports/Leaves sent by the hosts do not reach the Mrouter**

- Ensure one of the Mrouters is learned on both switches. If not, the IGMP Reports/Leaves are not forwarded. Note that the Mrouter may not be learned on switch B immediately after a trunk group failover/failback.

```
>> # /info/13/igmp/mrouter/dump
```

- Ensure the host's multicast application is started and is sending correct IGMP Reports/Leaves.

```
>> # /info/13/igmp/dump
```

### **Issue: The Mrouter is learned on the incorrect trunk group**

- Check link state. Trunk group 1 may be down or in STP discarding state.
- Check STP convergence.
- Check port VLAN membership.

### **Issue: Hosts receive multicast traffic at a lower rate than normal.**

- Ensure a multicast threshold is not configured on the trunk groups.

```
>> # /cfg/port <port id>
>> Port <port id># mrate disable
```

- Check link speeds and network congestion.

---

## Additional IGMP Features

The following topics are discussed in this section:

- [“FastLeave” on page 279](#)
- [“IGMP Filtering” on page 279](#)
- [“Static Multicast Router” on page 281](#)

### FastLeave

In normal IGMP operation, when the switch receives an IGMPv2 Leave message, it sends a Group-Specific Query to determine if any other devices in the same group (and on the same port) are still interested in the specified multicast group traffic. The switch removes the affiliated port from that particular group if the switch does not receive an IGMP Membership Report within the query-response-interval.

With FastLeave enabled on the VLAN, a port can be removed immediately from the port list of the group entry when the IGMP Leave message is received.

**Note:** Only IGMPv2 supports FastLeave. Enable FastLeave on ports that have only one host connected. If more than one host is connected to a port, you may lose some hosts unexpectedly.

Use the following command to enable FastLeave.

```
>> # /cfg/13/igmp/adv/fastlv <vlan number> e
```

### IGMP Filtering

With IGMP filtering, you can allow or deny certain IGMP groups to be learned on a port. IGMP filtering works with all versions of IGMP.

If access to a multicast group is denied, IGMP *Membership Reports* from the port are dropped, and the port is not allowed to receive IPv4 multicast traffic from that group. If access to the multicast group is allowed, *Membership Reports* from the port are forwarded for normal processing.

To configure IGMP filtering, you must globally enable IGMP filtering, define an IGMP filter, assign the filter to a port, and enable IGMP filtering on the port. To define an IGMP filter, you must configure a range of IPv4 multicast groups, choose whether the filter will allow or deny multicast traffic for groups within the range, and enable the filter.

#### Configuring the Range

Each IGMP filter allows you to set a start and end point that defines the range of IPv4 addresses upon which the filter takes action. Each IPv4 address in the range must be between 224.0.0.0 and 239.255.255.255.

#### Configuring the Action

Each IGMP filter can allow or deny IPv4 multicasts to the range of IPv4 addresses configured. If you configure the filter to deny IPv4 multicasts, then IGMP *Membership Reports* from multicast groups within the range are dropped. You can configure another filter with a numerically lower ID to allow IPv4 multicasts to a small

range of addresses within a larger range that a filter with a numerically higher ID is configured to deny. The two filters work together to allow IPv4 multicasts to a small subset of addresses within the larger range of addresses.

**Note:** Lower-numbered filters take precedence over higher-number filters. For example, the action defined for IGMP filter 1 supersedes the action defined for IGMP filter 2.

## Configure IGMP Filtering

1. Enable IGMP filtering on the switch.

```
>> # /cfg/13/igmp/igmpflt (Select IGMP filtering menu)
>> IGMP Filter# ena (Enable IGMP filtering)
Current status: disabled
New status: enabled
```

2. Define an IGMP filter.

```
>>IGMP Filter# filter 1 (Select Filter 1 Definition menu)
>>IGMP Filter 1 Definition# range 224.0.0.0 (Enter first IPv4 address of the range)
Current multicast address2:
Enter new multicast address2: 226.0.0.0 (Enter second IPv4 address)
Current multicast address1:
New pending multicast address1: 224.0.0.0
Current multicast address2:
New pending multicast address2: 226.0.0.0
>>IGMP Filter 1 Definition# action deny (Deny multicast traffic)
>>IGMP Filter 1 Definition# ena (Enable the filter)
```

3. Assign the IGMP filter to a port.

```
>>IGMP Filter 1 Definition# ..
>>IGMP Filter# port EXT3 (Select port EXT3)
>>IGMP Port EXT3# filt ena (Enable IGMP filtering on the port)
Current port EXT3 filtering: disabled
New port EXT3 filtering: enabled
>>IGMP Port EXT3# add 1 (Add IGMP filter 1 to the port)
>>IGMP Port EXT3# apply (Make your changes active)
```

The following example includes the steps to enable IGMP filtering in ISCLI mode.

```
GbESM(config)# ip igmp filtering (globally enable filtering)
GbESM(config)# ip igmp profile 1 action deny
GbESM(config)# ip igmp profile 1 range 225.10.1.10 225.10.1.20 (Ignore packets from this
range of IP addresses)
GbESM(config)# ip igmp profile 1 enable

GbESM(config)# interface port 6
GbESM(config-if)# ip igmp filtering (Enable filtering for port 6)
GbESM(config-if)# ip igmp profile 1 (add profile 1 to port 6)
```



## Static Multicast Router

A static Mrouter can be configured for a particular port on a particular VLAN. A static Mrouter does not have to be learned through IGMP Snooping.

A total of 16 static Mrouters can be configured on the GbESM. Both internal and external ports can accept a static Mrouter.

**Note:** When static Mrouters are used, the switch will continue learning dynamic Mrouters via IGMP snooping. However, dynamic Mrouters will not replace static Mrouters. If a dynamic Mrouter has the same port and VLAN combination as a static Mrouter, the dynamic Mrouter will not be learned.

Following is an example of configuring a static Mrouter:

1. Configure a port to which the static Mrouter is connected, and enter the appropriate VLAN.

```
>> # /cfg/13/igmp/mrouter          (Select IGMP Mrouter menu)
>> Static Multicast Router# add EXT4 (Add EXT4 Static Mrouter port)
Enter VLAN number: (1-4094) 1       (Enter the VLAN number)
Enter the version number of mrouter [1|2|3]: 2 Enter IGMP version number)
```

2. Apply, verify, and save the configuration.

```
>> Static Multicast Router# apply    (Apply the configuration)
>> Static Multicast Router# cur      (View the configuration)
>> Static Multicast Router# save     (Save your changes)
```



---

## Chapter 19. Multicast Listener Discovery

Multicast Listener Discovery (MLD) is an IPv6 protocol that a host uses to request multicast data for a multicast group. An IPv6 router uses MLD to discover the presence of multicast listeners (nodes that want to receive multicast packets) on its directly attached links, and to discover specifically the multicast addresses that are of interest to those neighboring nodes.

MLD version 1 is derived from Internet Group Management Protocol version 2 (IGMPv2) and MLDv2 is derived from IGMPv3. MLD uses ICMPv6 (IP Protocol 58) message types. See RFC 2710 and RFC 3810 for details.

MLDv2 protocol, when compared to MLDv1, adds support for source filtering—the ability for a node to report interest in listening to packets only from specific source addresses, or from all but specific source addresses, sent to a particular multicast address. MLDv2 is interoperable with MLDv1. See RFC 3569 for details on Source-Specific Multicast (SSM).

The following topics are discussed in this chapter:

- [“MLD Terms” on page 284](#)
- [“How MLD Works” on page 285](#)
- [“MLD Capacity and Default Values” on page 288](#)
- [“Configuring MLD” on page 289](#)

---

## MLD Terms

Following are the commonly used MLD terms:

- Multicast traffic: Flow of data from one source to multiple destinations.
- Group: A multicast stream to which a host can join.
- Multicast Router (Mrouter): A router configured to make routing decisions for multicast traffic. The router identifies the type of packet received (unicast or multicast) and forwards the packet to the intended destination.
- Querier: An Mrouter that sends periodic query messages. Only one Mrouter on the subnet can be elected as the Querier.
- Multicast Listener Query: Messages sent by the Querier. There are three types of queries:
  - General Query: Sent periodically to learn multicast address listeners from an attached link. GbESM uses these queries to build and refresh the Multicast Address Listener state. General Queries are sent to the link-scope all-nodes multicast address (FF02::1), with a multicast address field of 0, and a maximum response delay of *query response interval*.
  - Multicast Address Specific Query: Sent to learn if a specific multicast address has any listeners on an attached link. The multicast address field is set to the IPv6 multicast address.
  - Multicast Address and Source Specific Query: Sent to learn if, for a specified multicast address, there are nodes still listening to a specific set of sources. Supported only in MLDv2.

**Note:** Multicast Address Specific Queries and Multicast Address and Source Specific Queries are sent only in response to State Change Reports, and never in response to Current State Reports.

- Multicast Listener Report: Sent by a host when it joins a multicast group, or in response to a Multicast Listener Query sent by the Querier. Hosts use these reports to indicate their current multicast listening state, or changes in the multicast listening state of their interfaces. These reports are of two types:
  - Current State Report: Contains the current Multicast Address Listening State of the host.
  - State Change Report: If the listening state of a host changes, the host immediately reports these changes through a State Change Report message. These reports contain either Filter Mode Change records and/or Source List Change records. State Change Reports are retransmitted several times to ensure all Mrouters receive it.
- Multicast Listener Done: Sent by a host when it wants to leave a multicast group. This message is sent to the link-scope all-routers IPv6 destination address of FF02::2. When an Mrouter receives a Multicast Listener Done message from the last member of the multicast address on a link, it stops forwarding traffic to this multicast address.

---

## How MLD Works

The software uses the information obtained through MLD to maintain a list of multicast group memberships for each interface and forwards the multicast traffic only to interested listeners.

Without MLD, the switch forwards IPv6 multicast traffic through all ports, increasing network load. Following is an overview of operations when MLD is configured on GbESM:

- The switch acts as an Mrouter when MLDv1/v2 is configured and enabled on each of its directly attached links. If the switch has multiple interfaces connected to the same link, it operates the protocol on any one of the interfaces.
- If there are multiple Mrouters on the subnet, the Mrouter with the numerically lowest IPv6 address is elected as the Querier.
- The Querier sends general queries at short intervals to learn multicast address listener information from an attached link.
- Hosts respond to these queries by reporting their per-interface Multicast Address Listening state, through Current State Report messages sent to a specific multicast address that all MLD routers on the link listen to.
- If the listening state of a host changes, the host immediately reports these changes through a State Change Report message.
- The Querier sends a Multicast Address Specific Query to verify if hosts are listening to a specified multicast address or not. Similarly, if MLDv2 is configured, the Querier sends a Multicast Address and Source Specific Query to verify, for a specified multicast address, if hosts are listening to a specific set of sources, or not. MLDv2 listener report messages consists of Multicast Address Records:
  - INCLUDE: to receive packets from source specified in the MLDv2 message
  - EXCLUDE: to receive packets from all sources except the ones specified in the MLDv2 message
- A host can send a State Change Report to indicate its desire to stop listening to a particular multicast address (or source in MLDv2). The Querier then sends a multicast address specific query to verify if there are other listeners of the multicast address. If there aren't any, the Mrouter deletes the multicast address from its Multicast Address Listener state and stops sending multicast traffic. Similarly in MLDv2, the Mrouter sends a Multicast Address and Source Specific Query to verify if, for a specified multicast address, there are hosts still listening to a specific set of sources.

GbESM supports MLD versions 1 and 2.

**Note:** MLDv2 operates in version 1 compatibility mode when, in a specific network, not all hosts are configured with MLDv2.

## How Flooding Impacts MLD

When `flood` option is disabled, the unknown multicast traffic is discarded if no Mrouter is learned on the switch. You can set the flooding behavior by configuring the `flood` and `cpu` options. You can optimize the flooding to ensure that unknown IP multicast (IPMC) data packets are not dropped during the learning phase.

The flooding options include:

- `flood`: Enable hardware flooding in VLAN for the unregistered IPMC; This option is enabled by default.
- `cpu`: Enable sending unregistered IPMC to the Mrouter ports. However, during the learning period, there will be some packet loss. The `cpu` option is enabled by default. You must ensure that the `flood` and `optflood` options are disabled.
- `optflood`: Enable optimized flooding to allow sending the unregistered IPMC to the Mrouter ports without having any packet loss during the learning period; This option is disabled by default; When `optflood` is enabled, the `flood` and `cpu` settings are ignored.

The flooding parameters must be configured per VLAN. Enter the following command to set the `flood` or `cpu` options:

```
>> # /cfg/l3/flooding/vlan <VLAN number>/flood <d/e>  
>> # /cfg/l3/flooding/vlan <VLAN number>/cpu <d/e>  
>> # /cfg/l3/flooding/vlan <VLAN number>/optflood <d/e>
```

## MLD Querier

An Mrouter acts as a Querier and periodically (at short query intervals) sends query messages in the subnet. If there are multiple Mrouters in the subnet, only one can be the Querier. All Mrouters on the subnet listen to the messages sent by the multicast address listeners, and maintain the same multicast listening information state.

All MLDv2 queries are sent with the FE80::/64 link-local source address prefix.

### Querier Election

Only one Mrouter can be the Querier per subnet. All other Mrouters will be non-Queriers. MLD versions 1 and 2 elect the Mrouter with the numerically lowest IPv6 address as the Querier.

If the switch is configured as an Mrouter on a subnet, it also acts as a Querier by default and sends multiple general queries. If the switch receives a general query from another Querier with a numerically lower IPv6 address, it sets the *other querier present timer* to the *other querier present timeout*, and changes its state to non-Querier. When the *other querier present timer* expires, it regains the Querier state and starts sending general queries.

**Note:** When MLD Querier is enabled on a VLAN, the switch performs the role of an MLD Querier only if it meets the MLD Querier election criteria.

## Dynamic Mrouters

The switch learns Mrouters on the ingress VLANs of the MLD-enabled interface. All report or done messages are forwarded to these Mrouters. By default, the option of dynamically learning Mrouters is disabled. To enable it, use the following command:

```
>> Main# /cfg/13/mld/if <interface number>/dmrtr enable
```

---

## MLD Capacity and Default Values

Table 21 lists the maximum and minimum values of the GbESM variables.

Table 21. GbESM Capacity Table

Variable	Maximum Value
IPv6 Multicast Entries	256
IPv6 Interfaces for MLD	8

Table 22 lists the default settings for MLD features and variables.

Table 22. MLD Timers and Default Values

Field	Default Value
Robustness Variable (RV)	2
Query Interval (QI)	125 seconds
Query Response Interval (QRI)	10 seconds
Multicast Address Listeners Interval (MALI)	260 seconds [derived: $RV \cdot QI + QRI$ ]
Other Querier Present Interval [OQPT]	255 seconds [derived: $RV \cdot QI + \frac{1}{2} QRI$ ]
Start up Query Interval [SQI]	31.25 seconds [derived: $\frac{1}{4} \cdot QI$ ]
Startup Query Count [SQC]	2 [derived: RV]
Last Listener Query Interval [LLQI]	1 second
Last Listener Query Count [LLQC]	2 [derived: RV]
Last Listener Query Time [LLQT]	2 seconds [derived: $LLQI \cdot LLQT$ ]
Older Version Querier Present Timeout: [OVQPT]	260 seconds [derived: $RV \cdot QI + QRI$ ]
Older Version Host Present Interval [OVHPT]	260 seconds [derived: $RV \cdot QI + QRI$ ]



---

## Configuring MLD

Following are the steps to enable MLD and configure the interface parameters:

1. Turn on MLD globally.

```
>> # /cfg/l3/mls on
```

2. Create an IPv6 interface.

```
>> MLD# /cfg/l3/if 2
>> IP Interface 2# ena
>> IP Interface 2# addr 2002:1:0:0:0:0:3
>> IP Interface 2# masklen 64
```

3. Enable MLD on the IPv6 interface.

```
>> IP Interface 2# /cfg/l3/mls/if 2
>> MLD Interface 2# ena
```

4. Configure the MLD parameters on the interface: version, robustness, query response interval, MLD query interval, and last listener query interval.

```
>> MLD Interface 2# version <1-2>           (MLD version)
>> MLD Interface 2# robust <2-10>           (Robustness)
>> MLD Interface 2# qri <1-608>             (In seconds)
>> MLD Interface 2# qintrval <1-256>        (In seconds)
>> MLD Interface 2# llistnr <1-32>          (In seconds)
```



---

## Chapter 20. Border Gateway Protocol

Border Gateway Protocol (BGP) is an Internet protocol that enables routers on an IPv4 network to share and advertise routing information with each other about the segments of the IPv4 address space they can access within their network and with routers on external networks. BGP allows you to decide what is the “best” route for a packet to take from your network to a destination on another network rather than simply setting a default route from your border router(s) to your upstream provider(s). BGP is defined in RFC 1771.

1/10Gb Uplink ESMs (GbESMs) can advertise their IP interfaces and IPv4 addresses using BGP and take BGP feeds from as many as 16 BGP router peers. This allows more resilience and flexibility in balancing traffic from the Internet.

**Note:** IBM Networking OS 7.4 does not support IPv6 for BGP.

The following topics are discussed in this section:

- [“Internal Routing Versus External Routing” on page 292](#)
- [“Forming BGP Peer Routers” on page 293](#)
- [“Loopback Interfaces” on page 293](#)
- [“What is a Route Map?” on page 294](#)
- [“Aggregating Routes” on page 298](#)
- [“Redistributing Routes” on page 298](#)
- [“BGP Attributes” on page 299](#)
- [“Selecting Route Paths in BGP” on page 300](#)
- [“BGP Failover Configuration” on page 301](#)
- [“Default Redistribution and Route Aggregation Example” on page 303](#)

---

## Internal Routing Versus External Routing

To ensure effective processing of network traffic, every router on your network needs to know how to send a packet (directly or indirectly) to any other location/destination in your network. This is referred to as *internal routing* and can be done with static routes or using active, internal dynamic routing protocols, such as RIP, RIPv2, and OSPF.


Static routes should have a higher degree of precedence than dynamic routing protocols. If the destination route is not in the route cache, then the packets are forwarded to the default gateway which may be incorrect if a dynamic routing protocol is enabled.

It is also useful to tell routers outside your network (upstream providers or *peers*) about the routes you can access in your network. External networks (those outside your own) that are under the same administrative control are referred to as *autonomous systems* (AS). Sharing of routing information between autonomous systems is known as *external routing*.

External BGP (eBGP) is used to exchange routes between different autonomous systems whereas internal BGP (iBGP) is used to exchange routes within the same autonomous system. An iBGP is a type of internal routing protocol you can use to do active routing inside your network. It also carries AS path information, which is important when you are an ISP or doing BGP transit.

The iBGP peers have to maintain reciprocal sessions to every other iBGP router in the same AS (in a full-mesh manner) in order to propagate route information throughout the AS. If the iBGP session shown between the two routers in AS 20 was not present (as indicated in Figure 25), the top router would not learn the route to AS 50, and the bottom router would not learn the route to AS 11, even though the two AS 20 routers are connected via the BladeCenter and the Application Switch.

Figure 25. iBGP and eBGP



Typically, an AS has one or more *border routers*—peer routers that exchange routes with other ASs—and an internal routing scheme that enables routers in that AS to reach every other router and destination within that AS. When you *advertise* routes to border routers on other autonomous systems, you are effectively committing to carry data to the IPv4 space represented in the route being advertised. For example, if you advertise 192.204.4.0/24, you are declaring that if another router sends you data destined for any address in 192.204.4.0/24, you know how to carry that data to its destination.

---

## Forming BGP Peer Routers

Two BGP routers become peers or neighbors once you establish a TCP connection between them. For each new route, if a peer is interested in that route (for example, if a peer would like to receive your static routes and the new route is static), an update message is sent to that peer containing the new route. For each route removed from the route table, if the route has already been sent to a peer, an update message containing the route to withdraw is sent to that peer.

For each Internet host, you must be able to send a packet to that host, and that host has to have a path back to you. This means that whoever provides Internet connectivity to that host must have a path to you. Ultimately, this means that they must “hear a route” which covers the section of the IPv4 space you are using; otherwise, you will not have connectivity to the host in question.

---

## Loopback Interfaces

In many networks, multiple connections may exist between network devices. In such environments, it may be useful to employ a loopback interface for a common BGP router address, rather than peering the switch to each individual interface.

When a loopback interface is created for BGP, the switch automatically uses the loopback interface as the BGP peer ID, instead of the switch’s local IP interface address.

**Note:** To ensure that the loopback interface is reachable from peer devices, it should be advertised using an interior routing protocol (such as OSPF), or a static route should be configured on the peer.

To configure an existing loopback interface for BGP neighbor use the following commands:

```
>> # /cfg/13/bgp
>> Border Gateway Protocol# peer <#>
>> BGP Peer# uloopsrc <I-5>
```

---

## What is a Route Map?


A route map is used to control and modify routing information. Route maps define conditions for redistributing routes from one routing protocol to another or controlling routing information when injecting it in and out of BGP. Route maps are used by OSPF only for redistributing routes. For example, a route map is used to set a preference value for a specific route from a peer router and another preference value for all other routes learned via the same peer router. For example, the following command is used to define a route map:

>> # /cfg/13/rmap 1	(Select a route map)
---------------------	----------------------

A route map allows you to match attributes, such as metric, network address, and AS number. It also allows users to overwrite the local preference metric and to append the AS number in the AS route. See [“BGP Failover Configuration” on page 301](#).

IBM N/OS allows you to configure 32 route maps. Each route map can have up to eight access lists. Each access list consists of a network filter. A network filter defines an IPv4 address and subnet mask of the network that you want to include in the filter. [Figure 26](#) illustrates the relationship between route maps, access lists and network filters.

Figure 26. Distributing Network Filters in Access Lists and Route Maps



## Incoming and Outgoing Route Maps

You can have two types of route maps: incoming and outgoing. A BGP peer router can be configured to support up to eight route maps in the incoming route map list and outgoing route map list.

If a route map is not configured in the incoming route map list, the router imports all BGP updates. If a route map is configured in the incoming route map list, the router ignores all unmatched incoming updates. If you set the action to `deny`, you must add another route map to permit all unmatched updates.

Route maps in an outgoing route map list behave similar to route maps in an incoming route map list. If a route map is not configured in the outgoing route map list, all routes are advertised or permitted. If a route map in the outgoing route map list is set to `permit`, matched routes are advertised and unmatched routes are ignored.

## Precedence

You can set a priority to a route map by specifying a precedence value with the following command:

```
>> # /cfg/13/rmap <x>/pre (Specify a precedence)
```

The smaller the value the higher the precedence. If two route maps have the same precedence value, the smaller number has higher precedence.

## Configuration Overview

To configure route maps, you need to do the following:

1. Define network filter.

```
>> # /cfg/13/nwf 1 (Specify a network filter number)
>> IP Network Filter 1# addr <IPv4 address> (Specify IPv4 network address)
>> IP Network Filter 1# mask <IPv4 mask> (Specify IPv4 network mask)
>> IP Network Filter 1# ena (Enable network filter)
```

Enter a filter number from 1 to 256. Specify the IPv4 address and subnet mask of the network that you want to match. Enable the network filter. You can distribute up to 256 network filters among 32 route maps each containing eight access lists.

2. (Optional) Define the criteria for the access list and enable it.

Specify the access list and associate the network filter number configured in Step 1.

```
>> IP Network Filter 1# ../rmap 1      (Specify a route map number)
>> IP Route Map 1# alist 1            (Specify the access list number)
>> IP Access List 1# nwf 1            (Specify the network filter number)
>> IP Access List 1# metric           (Define a metric)
>> IP Access List 1# action deny      (Specify action for the access list)
>> IP Access List 1# ena              (Enable the access list)
```

Steps 2 and 3 are optional, depending on the criteria that you want to match. In Step 2, the network filter number is used to match the subnets defined in the network filter. In Step 3, the autonomous system number is used to match the subnets. Or, you can use both (Step 2 and Step 3) criteria: access list (network filter) and access path (AS filter) to configure the route maps.

3. (Optional) Configure the attributes in the AS filter menu.

```
>> IP Access List 1# ../aspath 1      (Specify the attributes in the filter)
>> AS Filter 1# as 1                  (Specify the AS number)
>> AS Filter 1# action deny           (Specify the action for the filter)
>> AS Filter 1# ena                  (Enable the AS filter)
```

4. Set up the BGP attributes.

If you want to overwrite the attributes that the peer router is sending, then define the following BGP attributes:

- Specify the AS numbers that you want to prepend to a matched route and the local preference for the matched route.
- Specify the metric [Multi Exit Discriminator (MED)] for the matched route.

```
>> AS Filter 1# /cfg/13/rmap 1        (Specify a route map number)
>> IP Route Map 1# ap                  (Specify the AS numbers to prepend)
>> IP Route Map 1# lp                  (Specify the local preference)
>> IP Route Map 1# metric              (Specify the metric)
```

5. Enable the route map.

```
>> IP Route Map 1# ena                (Enable the route map)
```

6. Turn BGP on.

```
>> IP Route Map 1# ../bgp/on          (Globally turn BGP on)
```



7. Assign the route map to a peer router.

Select the peer router and then add the route map to the incoming route map list,

```
>> Border Gateway Protocol# peer 1/addi      (Add to the incoming route map)
```

or to the outgoing route map list.

```
>> Border Gateway Protocol# peer 1/addo      (Add to the outgoing route map)
```

8. Apply and save the configuration.

```
>> Border Gateway Protocol# apply      (Apply the configuration)  
>> Border Gateway Protocol# save      (Save your changes)
```

---

## Aggregating Routes

Aggregation is the process of combining several different routes in such a way that a single route can be advertised, which minimizes the size of the routing table. You can configure aggregate routes in BGP either by redistributing an aggregate route into BGP or by creating an aggregate entry in the BGP routing table.

To define an aggregate route in the BGP routing table, use the following commands:

>> # /cfg/13/bgp	(Specify BGP)
>> Border Gateway Protocol# aggr 1	(Specify aggregate list number)
>> BGP aggr 1 # addr <IPv4 address>	(Enter aggregation network address)
>> BGP aggr 1 # mask <IPv4 subnet mask>	(Enter aggregation network mask)
>> BGP aggr 1 # ena	(Enable aggregation)

An example of creating a BGP aggregate route is shown in [“Default Redistribution and Route Aggregation Example” on page 303](#).

---

## Redistributing Routes

In addition to running multiple routing protocols simultaneously, N/OS software can redistribute information from one routing protocol to another. For example, you can instruct the switch to use BGP to re-advertise static routes. This applies to all of the IP-based routing protocols.

You can also conditionally control the redistribution of routes between routing domains by defining a method known as route maps between the two domains. For more information on route maps, see [“What is a Route Map?” on page 294](#). Redistributing routes is another way of providing policy control over whether to export OSPF routes, fixed routes, and static routes. For an example configuration, see [“Default Redistribution and Route Aggregation Example” on page 303](#).

Default routes can be configured using the following methods:

- Import
- Originate—The router sends a default route to peers if it does not have any default routes in its routing table.
- Redistribute—Default routes are either configured through the default gateway or learned via other protocols and redistributed to peer routers. If the default routes are from the default gateway, enable the static routes because default routes from the default gateway are static routes. Similarly, if the routes are learned from another routing protocol, make sure you enable that protocol for redistribution.
- None

---

## BGP Attributes

The following two BGP attributes are discussed in this section: Local preference and metric (Multi-Exit Discriminator).

### Local Preference Attribute

When there are multiple paths to the same destination, the local preference attribute indicates the preferred path. The path with the higher preference is preferred (the default value of the local preference attribute is 100). Unlike the weight attribute, which is only relevant to the local router, the local preference attribute is part of the routing update and is exchanged among routers in the same AS.

The local preference attribute can be set in one of two ways:

- `/cfg/13/bgp/pref`

This command uses the BGP default local preference method, affecting the outbound direction only.

- `/cfg/13/rmap/lp`

This command uses the route map local preference method, which affects both inbound and outbound directions.

### Metric (Multi-Exit Discriminator) Attribute

This attribute is a hint to external neighbors about the preferred path into an AS when there are multiple entry points. A lower metric value is preferred over a higher metric value. The default value of the metric attribute is 0.

Unlike local preference, the metric attribute is exchanged between ASs; however, a metric attribute that comes into an AS does not leave the AS.

When an update enters the AS with a certain metric value, that value is used for decision making within the AS. When BGP sends that update to another AS, the metric is reset to 0.

Unless otherwise specified, the router compares metric attributes for paths from external neighbors that are in the same AS.

---

## Selecting Route Paths in BGP

BGP selects only one path as the best path. It does not rely on metric attributes to determine the best path. When the same network is learned via more than one BGP peer, BGP uses its policy for selecting the best route to that network. The BGP implementation on the GbESM uses the following criteria to select a path when the same route is received from multiple peers.

1. Local fixed and static routes are preferred over learned routes.
2. With iBGP peers, routes with higher local preference values are selected.
3. In the case of multiple routes of equal preference, the route with lower AS path weight is selected.

AS path weight =  $128 \times \text{AS path length (number of autonomous systems traversed)}$ .

4. In the case of equal weight and routes learned from peers that reside in the same AS, the lower metric is selected.

**Note:** A route with a metric is preferred over a route without a metric.

5. The lower cost to the next hop of routes is selected.
6. In the case of equal cost, the eBGP route is preferred over iBGP.
7. If all routes are from eBGP, the route with the lower router ID is selected.


When the path is selected, BGP puts the selected path in its routing table and propagates the path to its neighbors.

## BGP Failover Configuration

Use the following example to create redundant default gateways for a GbESM at a Web Host/ISP site, eliminating the possibility, should one gateway go down, that requests will be forwarded to an upstream router unknown to the switch.

As shown in [Figure 27](#), the switch is connected to ISP 1 and ISP 2. The customer negotiates with both ISPs to allow the switch to use their peer routers as default gateways. The ISP peer routers will then need to announce themselves as default gateways to the GbESM.

Figure 27. BGP Failover Configuration Example



On the GbESM, one peer router (the secondary one) is configured with a longer AS path than the other, so that the peer with the shorter AS path will be seen by the switch as the primary default gateway. ISP 2, the secondary peer, is configured with a metric of "3," thereby appearing to the switch to be three router *hops* away.

### 1. Define the VLANs.

For simplicity, both default gateways are configured in the same VLAN in this example. The gateways could be in the same VLAN or different VLANs.

```
>> # /cfg/12/vlan 1 (Select VLAN 1)
>> vlan 1# add <port number> (Add a port to the VLAN membership)
```

2. Define the IP interfaces with IPv4 addresses.

The switch will need an IP interface for each default gateway to which it will be connected. Each interface must be placed in the appropriate VLAN. These interfaces will be used as the primary and secondary default gateways for the switch.

```
>> vlan 1# /cfg/13/if 1                (Select interface 1)
>> IP Interface 1# ena                  (Enable switch interface 1)
>> IP Interface 1# addr 200.200.200.1   (Configure IPv4 address of interface 1)
>> IP Interface 1# mask 255.255.255.0   (Configure IPv4 subnet address mask)
>> IP Interface 1# ../if 2              (Select interface 2)
>> IP Interface 2# ena                  (Enable switch interface 2)
>> IP Interface 2# addr 210.210.210.1   (Configure IPv4 address of interface 2)
>> IP Interface 2# mask 255.255.255.0   (Configure IPv4 subnet address mask)
```

3. Enable IP forwarding.

IP forwarding is turned on by default and is used for VLAN-to-VLAN (non-BGP) routing. Make sure IP forwarding is on if the default gateways are on different subnets or if the switch is connected to different subnets and those subnets need to communicate through the switch (which they almost always do).

```
>> IP Interface 2# /cfg/13/frwd/on      (Enable IP forwarding)
```

**Note:** To help eliminate the possibility for a Denial of Service (DoS) attack, the forwarding of directed broadcasts is disabled by default.

4. Configure BGP peer router 1 and 2.

```
>> # /cfg/13/bgp/peer 1                 (Select BGP peer router 1)
>> BGP Peer 1# ena                       (Enable this peer configuration)
>> BGP Peer 1# addr 200.200.200.2        (Set IPv4 address for peer router 1)
>> BGP Peer 1# ras 100                   (Set remote AS number)
>> BGP Peer 1# /cfg/13/bgp/peer 2       (Select BGP peer router 2)
>> BGP Peer 2# ena                       (Enable this peer configuration)
>> BGP Peer 2# addr 210.210.210.2       (Set IPv4 address for peer router 2)
>> BGP Peer 2# ras 200                   (Set remote AS number)
```

5. On the switch, apply and save your configuration changes.


```
>> BGP Peer 2# apply                     (Make your changes active)
>> BGP Peer 2# save                       (Save for restore after reboot)
```

## Default Redistribution and Route Aggregation Example

This example shows you how to configure the switch to redistribute information from one routing protocol to another and create an aggregate route entry in the BGP routing table to minimize the size of the routing table.

As illustrated in [Figure 28](#), you have two peer routers: an internal and an external peer router. Configure the GbESM to redistribute the default routes from AS 200 to AS 135. At the same time, configure for route aggregation to allow you to condense the number of routes traversing from AS 135 to AS 200.

Figure 28. Route Aggregation and Default Route Redistribution



1. Configure the IP interface.
2. Configure the AS number (AS 135) and router ID number (10.1.1.135).

```
>> # /cfg/13/bgp                               (Select BGP menu)
>> Border Gateway Protocol# as 135               (Specify an AS number)
>> Border Gateway Protocol# ../rtrid 10.1.1.135 (Specify a router ID)
```

3. Configure internal peer router 1 and external peer router 2.

```
>> Border Gateway Protocol# /cfg/13/bgp/peer 1 (Select internal peer router 1)
>> BGP Peer 1# ena                             (Enable this peer configuration)
>> BGP Peer 1# addr 10.1.1.4                    (Set IPv4 address for peer router 1)
>> BGP Peer 1# ras 135                          (Set remote AS number)
>> BGP Peer 1# ../peer 2                        (Select external peer router 2)
>> BGP Peer 2# ena                             (Enable this peer configuration)
>> BGP Peer 2# addr 20.20.20.2                  (Set IPv4 address for peer router 2)
>> BGP Peer 2# ras 200                          (Set remote AS number)
```

4. Configure redistribution for Peer 1.

```
>> BGP Peer 2# /cfg/13/bgp/peer 1/redist       (Select redistribute)
>> Redistribution# default redistribute          (Set default to redistribute)
>> Redistribution# fixed ena                    (Enable fixed routes)
```

5. Configure aggregation policy control.

Configure the routes that you want aggregated.

>> Redistribution# /cfg/13/bgp/aggr 1	<i>(Set aggregation number)</i>
>> BGP Aggr 1# addr 135.0.0.0	<i>(Add IPv4 address to aggregate 1)</i>
>> BGP Aeer 1# mask 255.0.0.0	<i>(Add IPv4 mask to aggregate 1)</i>

6. Apply and save the configuration.



---

## Chapter 21. OSPF

IBM Networking OS supports the Open Shortest Path First (OSPF) routing protocol. The IBM N/OS implementation conforms to the OSPF version 2 specifications detailed in Internet RFC 1583, and OSPF version 3 specifications in RFC 2740. The following sections discuss OSPF support for the 1/10Gb Uplink ESM (GbESM):

- [“OSPFv2 Overview” on page 306](#). This section provides information on OSPFv2 concepts, such as types of OSPF areas, types of routing devices, neighbors, adjacencies, link state database, authentication, and internal versus external routing.
- [“OSPFv2 Implementation in IBM N/OS” on page 310](#). This section describes how OSPFv2 is implemented in N/OS, such as configuration parameters, electing the designated router, summarizing routes, defining route maps and so forth.
- [“OSPFv2 Configuration Examples” on page 319](#). This section provides step-by-step instructions on configuring different OSPFv2 examples:
  - Creating a simple OSPF domain
  - Creating virtual links
  - Summarizing routes
- [“OSPFv3 Implementation in IBM N/OS” on page 328](#). This section describes differences and additional features found in OSPFv3.

---

## OSPFv2 Overview

OSPF is designed for routing traffic within a single IP domain called an Autonomous System (AS). The AS can be divided into smaller logical units known as *areas*.

All routing devices maintain link information in their own Link State Database (LSDB). The LSDB for all routing devices within an area is identical but is not exchanged between different areas. Only routing updates are exchanged between areas, thereby significantly reducing the overhead for maintaining routing information on a large, dynamic network.

The following sections describe key OSPF concepts.


### Types of OSPF Areas

An AS can be broken into logical units known as *areas*. In any AS with multiple areas, one area must be designated as area 0, known as the *backbone*. The backbone acts as the central OSPF area. All other areas in the AS must be connected to the backbone. Areas inject summary routing information into the backbone, which then distributes it to other areas as needed.

As shown in [Figure 29](#), OSPF defines the following types of areas:

- **Stub Area**—an area that is connected to only one other area. External route information is not distributed into stub areas.
- **Not-So-Stubby-Area (NSSA)**—similar to a stub area with additional capabilities. Routes originating from within the NSSA can be propagated to adjacent transit and backbone areas. External routes from outside the AS can be advertised within the NSSA but are not distributed into other areas.
- **Transit Area**—an area that allows area summary information to be exchanged between routing devices. The backbone (area 0), any area that contains a virtual link to connect two areas, and any area that is not a stub area or an NSSA are considered transit areas.

Figure 29. OSPF Area Types




## Types of OSPF Routing Devices

As shown in [Figure 30](#), OSPF uses the following types of routing devices:

- **Internal Router (IR)**—a router that has all of its interfaces within the same area. IRs maintain LSDBs identical to those of other routing devices within the local area.
- **Area Border Router (ABR)**—a router that has interfaces in multiple areas. ABRs maintain one LSDB for each connected area and disseminate routing information between areas.
- **Autonomous System Boundary Router (ASBR)**—a router that acts as a gateway between the OSPF domain and non-OSPF domains, such as RIP, BGP, and static routes.

Figure 30. OSPF Domain and an Autonomous System



## Neighbors and Adjacencies

In areas with two or more routing devices, *neighbors* and *adjacencies* are formed.

*Neighbors* are routing devices that maintain information about each others' health. To establish neighbor relationships, routing devices periodically send hello packets on each of their interfaces. All routing devices that share a common network segment, appear in the same area, and have the same health parameters (*hello* and *dead* intervals) and authentication parameters respond to each other's hello packets and become neighbors. Neighbors continue to send periodic hello packets to advertise their health to neighbors. In turn, they listen to hello packets to determine the health of their neighbors and to establish contact with new neighbors.

The hello process is used for electing one of the neighbors as the area's Designated Router (DR) and one as the area's Backup Designated Router (BDR). The DR is adjacent to all other neighbors and acts as the central contact for database exchanges. Each neighbor sends its database information to the DR, which relays the information to the other neighbors.

The BDR is adjacent to all other neighbors (including the DR). Each neighbor sends its database information to the BDR just as with the DR, but the BDR merely stores this data and does not distribute it. If the DR fails, the BDR will take over the task of distributing database information to the other neighbors.

## The Link-State Database

OSPF is a link-state routing protocol. A *link* represents an interface (or routable path) from the routing device. By establishing an adjacency with the DR, each routing device in an OSPF area maintains an identical Link-State Database (LSDB) describing the network topology for its area.

Each routing device transmits a Link-State Advertisement (LSA) on each of its *active* interfaces. LSAs are entered into the LSDB of each routing device. OSPF uses *flooding* to distribute LSAs between routing devices. Interfaces may also be *passive*. Passive interfaces send LSAs to active interfaces, but do not receive LSAs, hello packets, or any other OSPF protocol information from active interfaces. Passive interfaces behave as stub networks, allowing OSPF routing devices to be aware of devices that do otherwise participate in OSPF (either because they do not support it, or because the administrator chooses to restrict OSPF traffic exchange or transit).

When LSAs result in changes to the routing device's LSDB, the routing device forwards the changes to the adjacent neighbors (the DR and BDR) for distribution to the other neighbors.

OSPF routing updates occur only when changes occur, instead of periodically. For each new route, if an adjacency is interested in that route (for example, if configured to receive static routes and the new route is indeed static), an update message containing the new route is sent to the adjacency. For each route removed from the route table, if the route has already been sent to an adjacency, an update message containing the route to withdraw is sent.

## The Shortest Path First Tree

The routing devices use a link-state algorithm (Dijkstra's algorithm) to calculate the shortest path to all known destinations, based on the cumulative *cost* required to reach the destination.

The cost of an individual interface in OSPF is an indication of the overhead required to send packets across it. The cost is inversely proportional to the bandwidth of the interface. A lower cost indicates a higher bandwidth.

## Internal Versus External Routing

To ensure effective processing of network traffic, every routing device on your network needs to know how to send a packet (directly or indirectly) to any other location/destination in your network. This is referred to as *internal routing* and can be done with static routes or using active internal routing protocols, such as OSPF, RIP, or RIPv2.

It is also useful to tell routers outside your network (upstream providers or *peers*) about the routes you have access to in your network. Sharing of routing information between autonomous systems is known as *external routing*.

Typically, an AS will have one or more border routers (peer routers that exchange routes with other OSPF networks) as well as an internal routing system enabling every router in that AS to reach every other router and destination within that AS.

When a routing device *advertises* routes to boundary routers on other autonomous systems, it is effectively committing to carry data to the IP space represented in the route being advertised. For example, if the routing device advertises 192.204.4.0/24, it is declaring that if another router sends data destined for any address in the 192.204.4.0/24 range, it will carry that data to its destination.

---

## OSPFv2 Implementation in IBM N/OS

N/OS supports a single instance of OSPF and up to 4K routes on the network. The following sections describe OSPF implementation in N/OS:

- [“Configurable Parameters” on page 310](#)
- [“Defining Areas” on page 311](#)
- [“Interface Cost” on page 313](#)
- [“Electing the Designated Router and Backup” on page 313](#)
- [“Summarizing Routes” on page 313](#)
- [“Default Routes” on page 314](#)
- [“Virtual Links” on page 315](#)
- [“Router ID” on page 315](#)
- [“Authentication” on page 316](#)

### Configurable Parameters

In N/OS, OSPF parameters can be configured through the Command Line Interfaces (CLI/ISCLI), Browser-Based Interface (BBI), or through SNMP. For more information, see [“Switch Administration” on page 25.](#)

The CLI supports the following parameters: interface output cost, interface priority, dead and hello intervals, retransmission interval, and interface transmit delay.

In addition to the above parameters, you can also specify the following:

- Shortest Path First (SPF) interval—Time interval between successive calculations of the shortest path tree using the Dijkstra’s algorithm.
- Stub area metric—A stub area can be configured to send a numeric metric value such that all routes received via that stub area carry the configured metric to potentially influence routing decisions.
- Default routes—Default routes with weight metrics can be manually injected into transit areas. This helps establish a preferred route when multiple routing devices exist between two areas. It also helps route traffic to external networks.
- Passive—When enabled, the interface sends LSAs to upstream devices, but does not otherwise participate in OSPF protocol exchanges.
- Point-to-Point—For LANs that have only two OSPF routing agents (the GbESM and one other device), this option allows the switch to significantly reduce the amount of routing information it must carry and manage.

## Defining Areas

If you are configuring multiple areas in your OSPF domain, one of the areas must be designated as area 0, known as the *backbone*. The backbone is the central OSPF area and is usually physically connected to all other areas. The areas inject routing information into the backbone which, in turn, disseminates the information into other areas.

Since the backbone connects the areas in your network, it must be a contiguous area. If the backbone is partitioned (possibly as a result of joining separate OSPF networks), parts of the AS will be unreachable, and you will need to configure *virtual links* to reconnect the partitioned areas (see [“Virtual Links” on page 315](#)).

Up to three OSPF areas can be connected to the GbESM with N/OS software. To configure an area, the OSPF number must be defined and then attached to a network interface on the switch. The full process is explained in the following sections.

An OSPF area is defined by assigning **two** pieces of information: an *area index* and an *area ID*. The commands to define and enable an OSPF area are as follows:

```
>> # /cfg/l3/ospf/aindex <area index>/areaid <n.n.n.n>/ena
```

**Note:** The `aindex` option above is an arbitrary index used only on the switch and does not represent the actual OSPF area number. The actual OSPF area number is defined in the `areaid` portion of the command as explained in the following sections.

## Assigning the Area Index

The `aindex <area index>` option is actually just an arbitrary index (0–2) used only by the GbESM. This index does not necessarily represent the OSPF area number, though for configuration simplicity, it should where possible.

For example, both of the following sets of commands define OSPF area 0 (the backbone) and area 1 because that information is held in the area ID portion of the command. However, the first set of commands is easier to maintain because the arbitrary area indexes agree with the area IDs:

- Area index and area ID agree

```
/cfg/l3/ospf/aindex 0/areaid 0.0.0.0(Use index 0 to set area 0 in ID octet format)
/cfg/l3/ospf/aindex 1/areaid 0.0.0.1(Use index 1 to set area 1 in ID octet format)
```
- Area index set to an arbitrary value

```
/cfg/l3/ospf/aindex 1/areaid 0.0.0.0(Use index 1 to set area 0 in ID octet format)
/cfg/l3/ospf/aindex 2/areaid 0.0.0.1(Use index 2 to set area 1 in ID octet format)
```

## Using the Area ID to Assign the OSPF Area Number

The OSPF area number is defined in the `areaid <IP address>` option. The octet format is used to be compatible with two different systems of notation used by other OSPF network vendors. There are two valid ways to designate an area ID:

- Single Number

Most common OSPF vendors express the area ID number as a single number. For example, the Cisco IOS-based router command “network 1.1.1.0 0.0.0.255 area 1” defines the area number simply as “area 1.”

- Multi-octet (*IP address*): Placing the area number in the last octet (0.0.0.*n*)

Some OSPF vendors express the area ID number in multi-octet format. For example, “area 0.0.0.2” represents OSPF area 2 and can be specified directly on the GbESM as “area-id 0.0.0.2”.

On the GbESM, using the last octet in the area ID, “area 1” is equivalent to “area-id 0.0.0.1”.

**Note:** Although both types of area ID formats are supported, be sure that the area IDs are in the same format throughout an area.

## Attaching an Area to a Network

Once an OSPF area has been defined, it must be associated with a network. To attach the area to a network, you must assign the OSPF area index to an IP interface that participates in the area. The format for the command is as follows:

```
>> # /cfg/13/ospf/if <interface number>/aindex <area index>
```

For example, the following commands could be used to configure IPv4 interface 14 for a presence on the IPv4 10.10.10.1/24 network, to define OSPF area 1, and to attach the area to the network:

>> # /cfg/13/if 14	(Select menu for IP interface 14)
>> IP Interface 14# addr 10.10.10.1	(Define IP address on backbone)
>> IP Interface 14# mask 255.255.255.0	(Define IP mask on backbone)
>> IP Interface 14# ena	(Enable IP interface 14)
>> IP Interface 14# ../ospf/aindex 1	(Select menu for area index 1)
>> OSPF Area (index) 1 # areaid 0.0.0.1	(Define area ID as OSPF area 1)
>> OSPF Area (index) 1 # ena	(Enable area index 1)
>> OSPF Area (index) 1 # ../if 14	(Select OSPF menu for interface 14)
>> OSPF Interface 14# aindex 1	(Attach area to interface 14 network)
>> OSPF Interface 14# enable	(Enable interface 14 for area index 1)

**Note:** OSPFv2 supports IPv4 only. IPv6 is supported in OSPFv3 (see [“OSPFv3 Implementation in IBM N/OS” on page 328](#)).



## Interface Cost

The OSPF link-state algorithm (Dijkstra's algorithm) places each routing device at the root of a tree and determines the cumulative *cost* required to reach each destination. Usually, the cost is inversely proportional to the bandwidth of the interface. Low cost indicates high bandwidth. You can manually enter the cost for the output route with the following command:

```
>> # /cfg/l3/ospf/if <OSPF interface number>/cost <cost value (1-65535)>
```

## Electing the Designated Router and Backup

In any area with more than two routing devices, a Designated Router (DR) is elected as the central contact for database exchanges among neighbors, and a Backup Designated Router (BDR) is elected in case the DR fails.

DR and BDR elections are made through the hello process. The election can be influenced by assigning a priority value to the OSPF interfaces on the GbESM. The command is as follows:

```
>> # /cfg/l3/ospf/if <OSPF interface number>/prio <priority value (0-255)>
```

A priority value of 255 is the highest, and 1 is the lowest. A priority value of 0 specifies that the interface cannot be used as a DR or BDR. In case of a tie, the routing device with the highest router ID wins. Interfaces configured as *passive* do not participate in the DR or BDR election process:

```
>> # /cfg/l3/ospf/if <OSPF interface number>/passive enable
```

## Summarizing Routes

Route summarization condenses routing information. Without summarization, each routing device in an OSPF network would retain a route to every subnet in the network. With summarization, routing devices can reduce some sets of routes to a single advertisement, reducing both the load on the routing device and the perceived complexity of the network. The importance of route summarization increases with network size.

Summary routes can be defined for up to 16 IP address ranges using the following command:

```
>> # /cfg/l3/ospf/range <range number>/addr <IPv4 address>/mask <subnet mask>
```

where *<range number>* is a number 1 to 16, *<IPv4 address>* is the base IP address for the range, and *<subnet mask>* is the IPv4 address mask for the range. For a detailed configuration example, see [“Example 3: Summarizing Routes” on page 325](#).


**Note:** OSPFv2 supports IPv4 only. IPv6 is supported in OSPFv3 (see [“OSPFv3 Implementation in IBM N/OS” on page 328](#)).

## Default Routes

When an OSPF routing device encounters traffic for a destination address it does not recognize, it forwards that traffic along the *default route*. Typically, the default route leads upstream toward the backbone until it reaches the intended area or an external router.

Each GbESM acting as an ABR automatically inserts a default route into each attached area. In simple OSPF stub areas or NSSAs with only one ABR leading upstream (see Area 1 in Figure 31), any traffic for IP address destinations outside the area is forwarded to the switch's IP interface, and then into the connected transit area (usually the backbone). Since this is automatic, no further configuration is required for such areas.

Figure 31. Injecting Default Routes



If the switch is in a transit area and has a configured default gateway, it can inject a default route into rest of the OSPF domain. Use the following command to configure the switch to inject OSPF default routes:

```
>> # /cfg/13/ospf/default <metric value> <metric type (1 or 2)>
```

In the preceding command, *<metric value>* sets the priority for choosing this switch for default route. The value `none` sets no default and 1 sets the highest priority for default route. Metric type determines the method for influencing routing decisions for external routes.

When the switch is configured to inject a default route, an AS-external LSA with link state ID 0.0.0.0 is propagated throughout the OSPF routing domain. This LSA is sent with the configured metric value and metric type.

The OSPF default route configuration can be removed with the command:

```
>> # /cfg/13/ospf/default none
```

## Virtual Links

Usually, all areas in an OSPF AS are physically connected to the backbone. In some cases where this is not possible, you can use a *virtual link*. Virtual links are created to connect one area to the backbone through another non-backbone area (see [Figure 29 on page 307](#)).

The area which contains a virtual link must be a transit area and have full routing information. Virtual links cannot be configured inside a stub area or NSSA. The area type must be defined as `transit` using the following command:

```
>> # /cfg/l3/ospf/aindex <area index>/type transit
```

The virtual link must be configured on the routing devices at each endpoint of the virtual link, though they may traverse multiple routing devices. To configure a GbESM as one endpoint of a virtual link, use the following command:

```
>> # /cfg/l3/ospf/virt <link number>/aindex <area index>/nbr <router ID>
```

where *<link number>* is a value between 1 and 3, *<area index>* is the OSPF area index of the transit area, and *<router ID>* is the IP address of the virtual neighbor (nbr), the routing device at the target endpoint. Another router ID is needed when configuring a virtual link in the other direction. To provide the GbESM with a router ID, see the following section, [Router ID](#).

For a detailed configuration example on Virtual Links, see [“Example 2: Virtual Links” on page 322](#).

## Router ID

Routing devices in OSPF areas are identified by a router ID, expressed in IP address format. The router ID is not required to be part of any IP interface range or in any OSPF area, and may even use the GbESM loopback interface (see [“Loopback Interfaces in OSPF” on page 318](#)).

The router ID can be configured in one of the following two ways:

- Dynamically (the default)—OSPF protocol configures the router ID as the lowest IP loopback interface IP address, if available, or else the lowest IP interface IP address, if available. Once dynamically configured, the router ID does not normally undergo further updates.
- Statically—Use the following command to manually configure the router ID:

```
>> # /cfg/l3/rtrid <IPv4 address>
```

To change the router ID from static to dynamic, set the router ID to 0.0.0.0, save the configuration, and reboot the GbESM. To view the router ID, enter:

```
>> # /info/l3/ospf/gen
```


## Authentication

OSPF protocol exchanges can be authenticated so that only trusted routing devices can participate. This ensures less processing on routing devices that are not listening to OSPF packets.

OSPF allows packet authentication and uses IP multicast when sending and receiving packets. Routers participate in routing domains based on pre-defined passwords. N/OS supports simple password (type 1 plain text passwords) and MD5 cryptographic authentication. This type of authentication allows a password to be configured per area.

Figure 32 shows authentication configured for area 0 with the password `test`. Simple authentication is also configured for the virtual link between area 2 and area 0. Area 1 is not configured for OSPF authentication.

Figure 32. OSPF Authentication



## Configuring Plain Text OSPF Passwords

To configure plain text OSPF passwords as shown in Figure 32 use the following commands:

1. Enable OSPF authentication for Area 0 on switches 1, 2, and 3.

```
>> # /cfg/13/ospf/aindex 0/auth password (Turn on password authentication)
```

2. Configure a simple text password up to eight characters for each OSPF IP interface in Area 0 on switches 1, 2, and 3.

```
>> # /cfg/13/ospf/if 1/key test
>> OSPF Interface 1 # ../if 2/key test
>> OSPF Interface 2 # ../if 3/key test
```

3. Enable OSPF authentication for Area 2 on switch 4.

```
>> # /cfg/13/ospf/aindex 2/auth password (Turn on password authentication)
```

4. Configure a simple text password up to eight characters for the virtual link between Area 2 and Area 0 on switches 2 and 4.

```
>> # /cfg/l3/ospf/virt 1/key blade
```

## Configuring MD5 Authentication

Use the following commands to configure MD5 authentication on the switches shown in [Figure 32](#):

1. Enable OSPF MD5 authentication for Area 0 on switches 1, 2, and 3.

```
>> # /cfg/l3/ospf/aindex 0/auth md5 (Turn on MD5 authentication)
```

2. Configure MD5 key ID for Area 0 on switches 1, 2, and 3.

```
>> # /cfg/l3/ospf/md5key 1/key test
```

3. Assign MD5 key ID to OSPF interfaces on switches 1, 2, and 3.

```
>> # /cfg/l3/ospf/if 1/mdkey 1
>> OSPF Interface 1 # ../if 2/mdkey 1
>> OSPF Interface 2 # ../if 3/mdkey 1
```

4. Enable OSPF MD5 authentication for Area 2 on switch 4.

```
>> # /cfg/l3/ospf/aindex 2/auth md5
```

5. Configure MD5 key for the virtual link between Area 2 and Area 0 on switches 2 and 4.

```
>> # /cfg/l3/ospf/md5key 2/key blade
```

6. Assign MD5 key ID to OSPF virtual link on switches 2 and 4.

```
>> # /cfg/l3/ospf/virt 1/mdkey 2
```

## Host Routes for Load Balancing

N/OS implementation of OSPF includes host routes. Host routes are used for advertising network device IP addresses to external networks, accomplishing the following goals:

- ABR Load Sharing

As a form of load balancing, host routes can be used for dividing OSPF traffic among multiple ABRs. To accomplish this, each switch provides identical services but advertises a host route for a different IP address to the external network. If each IP address serves a different and equal portion of the external world, incoming traffic from the upstream router should be split evenly among ABRs.

- **ABR Failover**  
Complementing ABR load sharing, identical host routes can be configured on each ABR. These host routes can be given different costs so that a different ABR is selected as the preferred route for each server and the others are available as backups for failover purposes.
- **Equal Cost Multipath (ECMP)**  
With equal cost multipath, a router potentially has several available next hops towards any given destination. ECMP allows separate routes to be calculated for each IP Type of Service. All paths of equal cost to a given destination are calculated, and the next hops for all equal-cost paths are inserted into the routing table.

If redundant routes via multiple routing processes (such as OSPF, RIP, BGP, or static routes) exist on your network, the switch defaults to the OSPF-derived route.

## Loopback Interfaces in OSPF

A loopback interface is an IP interface which has an IP address, but is not associated with any particular physical port. The loopback interface is thus always available to the general network, regardless of which specific ports are in operation. Because loopback interfaces are always available on the switch, loopback interfaces may present an advantage when used as the router ID.

If dynamic router ID selection is used (see [“Router ID” on page 315](#)), loopback interfaces can be used to force router ID selection. If a loopback interface is configured, its IP address is automatically selected as the router ID, even if other IP interfaces have lower IP addresses. If more than one loopback interface is configured, the lowest loopback interface IP address is selected.

Loopback interfaces can be advertised into the OSPF domain by specifying an OSPF host route with the loopback interface IP address.

**Note:** Loopback interfaces are not advertised via the OSPF route redistribution of fixed routes.

To enable OSPF on an existing loopback interface:

```
>> # /cfg/13/ospf
>> Open Shortest Path First# loopif <1-5>
>> OSPF Loopback Interface# aindex <area ID>
>> OSPF Loopback Interface# enable
```

## OSPF Features Not Supported in This Release

The following OSPF features are not supported in this release:

- Summarizing external routes
- Filtering OSPF routes
- Using OSPF to forward multicast routes
- Configuring OSPF on non-broadcast multi-access networks (such as frame relay, X.25, or ATM)

---

## OSPFv2 Configuration Examples


A summary of the basic steps for configuring OSPF on the GbESM is listed here. Detailed instructions for each of the steps is covered in the following sections:

1. Configure IP interfaces.  
One IP interface is required for each desired network (range of IP addresses) being assigned to an OSPF area on the switch.
2. (Optional) Configure the router ID.  
The router ID is required only when configuring virtual links on the switch.
3. Enable OSPF on the switch.
4. Define the OSPF areas.
5. Configure OSPF interface parameters.  
IP interfaces are used for attaching networks to the various areas.
6. (Optional) Configure route summarization between OSPF areas.
7. (Optional) Configure virtual links.
8. (Optional) Configure host routes.

## Example 1: Simple OSPF Domain

In this example, two OSPF areas are defined—one area is the backbone and the other is a stub area. A stub area does not allow advertisements of external routes, thus reducing the size of the database. Instead, a default summary route of IP address 0.0.0.0 is automatically inserted into the stub area. Any traffic for IP address destinations outside the stub area will be forwarded to the stub area's IP interface, and then into the backbone.

Figure 33. A Simple OSPF Domain



Follow this procedure to configure OSPF support as shown in [Figure 33](#):

1. Configure IP interfaces on each network that will be attached to OSPF areas.  
In this example, two IP interfaces are needed:
  - Interface 1 for the backbone network on 10.10.7.0/24
  - Interface 2 for the stub area network on 10.10.12.0/24

```
>> # /cfg/13/if 1                               (Select menu for IP interface 1)
>> IP Interface 1# addr 10.10.7.1                 (Set IP address on backbone)
>> IP Interface 1# mask 255.255.255.0             (Set IP mask on backbone)
>> IP Interface 1# enable                         (Enable IP interface 1)
>> IP Interface 1# ../if 2                       (Select menu for IP interface 2)
>> IP Interface 2# addr 10.10.12.1                (Set IP address on stub area)
>> IP Interface 2# mask 255.255.255.0            (Set IP mask on stub area)
>> IP Interface 2# enable                         (Enable IP interface 2)
```

**Note:** OSPFv2 supports IPv4 only. IPv6 is supported in OSPFv3 (see [“OSPFv3 Implementation in IBM N/OS” on page 328](#)).

2. Enable OSPF.

```
>> IP Interface 2# /cfg/13/ospf/on                (Enable OSPF on the switch)
```

3. Define the backbone.

The backbone is always configured as a transit area using `areaid 0.0.0.0`.

```
>> Open Shortest Path First# aindex 0            (Select menu for area index 0)
>> OSPF Area (index) 0# areaid 0.0.0.0           (Set the ID for backbone area 0)
>> OSPF Area (index) 0# type transit              (Define backbone as transit type)
>> OSPF Area (index) 0# enable                   (Enable the area)
```



4. Define the stub area.

```
>> OSPF Area (index) 0# ../aindex 1      (Select menu for area index 1)
>> OSPF Area (index) 1# areaid 0.0.0.1    (Set the area ID for OSPF area 1)
>> OSPF Area (index) 1# type stub          (Define area as stub type)
>> OSPF Area (index) 1# enable             (Enable the area)
```

5. Attach the network interface to the backbone.

```
>> OSPF Area 1# ../if 1                  (Select OSPF menu for interface 1)
>> OSPF Interface 1# aindex 0             (Attach network to backbone index)
>> OSPF Interface 1# enable                (Enable the backbone interface)
```

6. Attach the network interface to the stub area.

```
>> OSPF Interface 1# ../if 2              (Select OSPF menu for interface 2)
>> OSPF Interface 2# aindex 1              (Attach network to stub area index)
>> OSPF Interface 2# enable                (Enable the stub area interface)
```


7. Apply and save the configuration changes.

```
>> OSPF Interface 2# apply                 (Apply all configuration changes)
>> OSPF Interface 2# save                   (Save applied changes)
```

## Example 2: Virtual Links

In the example shown in [Figure 34](#), area 2 is not physically connected to the backbone as is usually required. Instead, area 2 will be connected to the backbone via a virtual link through area 1. The virtual link must be configured at each endpoint.

Figure 34. Configuring a Virtual Link



**Note:** OSPFv2 supports IPv4 only. IPv6 is supported in OSPFv3 (see [“OSPFv3 Implementation in IBM N/OS” on page 328](#)).

### Configuring OSPF for a Virtual Link on Switch #1

1. Configure IP interfaces on each network that will be attached to the switch.  
In this example, two IP interfaces are needed:
  - Interface 1 for the backbone network on 10.10.7.0/24
  - Interface 2 for the transit area network on 10.10.12.0/24

```
>> # /cfg/13/if 1                               (Select menu for IP interface 1)
>> IP Interface 1# addr 10.10.7.1                 (Set IP address on backbone)
>> IP Interface 1# mask 255.255.255.0             (Set IP mask on backbone)
>> IP Interface 1# enable                         (Enable IP interface 1)
>> IP Interface 1# ../if 2                       (Select menu for IP interface 2)
>> IP Interface 2# addr 10.10.12.1               (Set IP address on transit area)
>> IP Interface 2# mask 255.255.255.0           (Set IP mask on transit area)
>> IP Interface 2# enable                       (Enable interface 2)
```

2. Configure the router ID.

A router ID is required when configuring virtual links. Later, when configuring the other end of the virtual link on Switch 2, the router ID specified here will be used as the target virtual neighbor (nbr) address.

```
>> IP Interface 2# /cfg/13/rtrid 10.10.10.1      (Set static router ID on switch 1)
```

3. Enable OSPF.

```
>> IP # /cfg/13/ospf/on                         (Enable OSPF on switch 1)
```

#### 4. Define the backbone.

```
>> Open Shortest Path First# aindex 0      (Select menu for area index 0)
>> OSPF Area (index) 0# areaid 0.0.0.0    (Set area ID for backbone area 0)
>> OSPF Area (index) 0# type transit       (Define backbone as transit type)
>> OSPF Area (index) 0# enable             (Enable the area)
```

#### 5. Define the transit area.

The area that contains the virtual link must be configured as a transit area.

```
>> OSPF Area (index) 0# ../aindex 1        (Select menu for area index 1)
>> OSPF Area (index) 1# areaid 0.0.0.1    (Set the area ID for OSPF area 1)
>> OSPF Area (index) 1# type transit       (Define area as transit type)
>> OSPF Area (index) 1# enable            (Enable the area)
```

#### 6. Attach the network interface to the backbone.

```
>> OSPF Area (index) 1# ../if 1           (Select OSPF menu for interface 1)
>> OSPF Interface 1# aindex 0             (Attach network to backbone index)
>> OSPF Interface 1# enable               (Enable the backbone interface)
```

#### 7. Attach the network interface to the transit area.

```
>> OSPF Interface 1# ../if 2             (Select OSPF menu for interface 2)
>> OSPF Interface 2# aindex 1             (Attach network to transit area)
>> OSPF Interface 2# enable               (Enable the transit area interface)
```

#### 8. Configure the virtual link.

The nbr router ID configured in this step must be the same as the router ID that will be configured for Switch #2 in [Step 2 on page 324](#).

```
>> OSPF Interface 2# ../virt 1           (Specify a virtual link number)
>> OSPF Virtual Link 1# aindex 1         (Set transit area for virtual link)
>> OSPF Virtual Link 1# nbr 10.10.14.1   (Set the router ID of the recipient)
>> OSPF Virtual Link 1# enable           (Enable the virtual link)
```

#### 9. Apply and save the configuration changes.

```
>> OSPF Interface 2# apply                (Apply all configuration changes)
>> OSPF Interface 2# save                  (Save applied changes)
```

## Configuring OSPF for a Virtual Link on Switch #2

1. Configure IP interfaces on each network that will be attached to OSPF areas.  
In this example, two IP interfaces are needed:

- Interface 1 for the transit area network on 10.10.12.0/24
- Interface 2 for the stub area network on 10.10.24.0/24

```
>> # /cfg/13/if 1 (Select menu for IP interface 1)
>> IP Interface 1# addr 10.10.12.2 (Set IP address on transit area)
>> IP Interface 1# mask 255.255.255.0 (Set IP mask on transit area)
>> IP Interface 1# enable (Enable IP interface 1)
>> IP Interface 1# ../if 2 (Select menu for IP interface 2)
>> IP Interface 2# addr 10.10.24.1 (Set IP address on stub area)
>> IP Interface 2# mask 255.255.255.0 (Set IP mask on stub area)
>> IP Interface 2# enable (Enable IP interface 2)
```

2. Configure the router ID.

A router ID is required when configuring virtual links. This router ID should be the same one specified as the target virtual neighbor (nbr) on switch 1 in [Step 8 on page 323](#).

```
>> IP Interface 2# /cfg/13/rtrid 10.10.14.1 (Set static router ID on switch 2)
```

3. Enable OSPF.

```
>> IP# /cfg/13/ospf/on (Enable OSPF on switch 2)
```

4. Define the backbone.

This version of N/OS requires that a backbone index be configured on the non-backbone end of the virtual link as follows:

```
>> Open Shortest Path First# aindex 0 (Select the menu for area index 0)
>> OSPF Area (index) 0# areaid 0.0.0.0 (Set the area ID for OSPF area 0)
>> OSPF Area (index) 0# enable (Enable the area)
```

5. Define the transit area.

```
>> OSPF Area (index) 0# ../aindex 1 (Select menu for area index 1)
>> OSPF Area (index) 1# areaid 0.0.0.1 (Set the area ID for OSPF area 1)
>> OSPF Area (index) 1# type transit (Define area as transit type)
>> OSPF Area (index) 1# enable (Enable the area)
```

6. Define the stub area.

```
>> OSPF Area (index) 1# ../aindex 2 (Select the menu for area index 2)
>> OSPF Area (index) 2# areaid 0.0.0.2 (Set the area ID for OSPF area 2)
>> OSPF Area (index) 2# type stub (Define area as stub type)
>> OSPF Area (index) 2# enable (Enable the area)
```

7. Attach the network interface to the backbone.

```
>> OSPF Area (index) 2# ../if 1          (Select OSPF menu for interface 1)
>> OSPF Interface 1# aindex 1           (Attach network to transit area)
>> OSPF Interface 1# enable             (Enable the transit area interface)
```

8. Attach the network interface to the transit area.

```
>> OSPF Interface 1# ../if 2          (Select OSPF menu for interface 2)
>> OSPF Interface 2# aindex 2         (Attach network to stub area index)
>> OSPF Interface 2# enable           (Enable the stub area interface)
```

9. Configure the virtual link.

The nbr router ID configured in this step must be the same as the router ID that was configured for switch #1 in [Step 2 on page 322](#).

```
>> OSPF Interface 2# ../virt 1        (Specify a virtual link number)
>> OSPF Virtual Link 1# aindex 1      (Set transit area for virtual link)
>> OSPF Virtual Link 1# nbr 10.10.10.1 (Set the router ID of the recipient)
>> OSPF Virtual Link 1# enable        (Enable the virtual link)
```

10. Apply and save the configuration changes.

```
>> OSPF Interface 2# apply            (Apply all configuration changes)
>> OSPF Interface 2# save              (Save applied changes)
```

### Other Virtual Link Options

- You can use redundant paths by configuring multiple virtual links.
- Only the endpoints of the virtual link are configured. The virtual link path may traverse multiple routers in an area as long as there is a routable path between the endpoints.

## Example 3: Summarizing Routes


By default, ABRs advertise all the network addresses from one area into another area. Route summarization can be used for consolidating advertised addresses and reducing the perceived complexity of the network.

If the network IP addresses in an area are assigned to a contiguous subnet range, you can configure the ABR to advertise a single summary route that includes all the individual IP addresses within the area.

The following example shows one summary route from area 1 (stub area) injected into area 0 (the backbone). The summary route consists of all IP addresses from 36.128.192.0 through 36.128.254.255 except for the routes in the range 36.128.200.0 through 36.128.200.255.

**Note:** OSPFv2 supports IPv4 only. IPv6 is supported in OSPFv3 (see [“OSPFv3 Implementation in IBM N/OS” on page 328](#)).

Figure 35. Summarizing Routes



**Note:** You can specify a range of addresses to prevent advertising by using the hide option. In this example, routes in the range 36.128.200.0 through 36.128.200.255 are kept private.

Follow this procedure to configure OSPF support as shown in [Figure 35](#):

1. Configure IP interfaces for each network which will be attached to OSPF areas.

```
>> # /cfg/13/if 1                               (Select menu for IP interface 1)
>> IP Interface 1# addr 10.10.7.1                 (Set IP address on backbone)
>> IP Interface 1# mask 255.255.255.0             (Set IP mask on backbone)
>> IP Interface 1# ena                             (Enable IP interface 1)
>> IP Interface 1# ../if 2                         (Select menu for IP interface 2)
>> IP Interface 2# addr 36.128.192.1              (Set IP address on stub area)
>> IP Interface 2# mask 255.255.192.0             (Set IP mask on stub area)
>> IP Interface 2# ena                             (Enable IP interface 2)
```

2. Enable OSPF.

```
>> IP Interface 2# /cfg/13/ospf/on                (Enable OSPF on the switch)
```

3. Define the backbone.

```
>> Open Shortest Path First# aindex 0             (Select menu for area index 0)
>> OSPF Area (index) 0# areaid 0.0.0.0           (Set the ID for backbone area 0)
>> OSPF Area (index) 0# type transit              (Define backbone as transit type)
>> OSPF Area (index) 0# enable                    (Enable the area)
```

4. Define the stub area.

```
>> OSPF Area (index) 0# ../aindex 1               (Select menu for area index 1)
>> OSPF Area (index) 1# areaid 0.0.0.1           (Set the area ID for OSPF area 1)
>> OSPF Area (index) 1# type stub                 (Define area as stub type)
>> OSPF Area (index) 1# enable                    (Enable the area)
```

5. Attach the network interface to the backbone.

```
>> OSPF Area (index) 1# ../if 1                   (Select OSPF menu for interface 1)
>> OSPF Interface 1# aindex 0                     (Attach network to backbone index)
>> OSPF Interface 1# enable                       (Enable the backbone interface)
```

6. Attach the network interface to the stub area.

```
>> OSPF Interface 1# ../if 2          (Select OSPF menu for interface 2)
>> OSPF Interface 2# aindex 1        (Attach network to stub area index)
>> OSPF Interface 2# enable          (Enable the stub area interface)
```

7. Configure route summarization by specifying the starting address and mask of the range of addresses to be summarized.

```
>> OSPF Interface 2# ../range 1      (Select menu for summary range)
>> OSPF Summary Range 1# addr 36.128.192.0 (Set base IP address of range)
>> OSPF Summary Range 1# mask 255.255.192.0 (Set mask address for range)
>> OSPF Summary Range 1# aindex 0      (Add summary route to backbone)
>> OSPF Summary Range 1# enable        (Enable summary range)
```

8. Use the hide command to prevent a range of addresses from advertising to the backbone.

```
>> OSPF Summary Range 1# ../range 2  (Select menu for summary range)
>> OSPF Summary Range 2# addr 36.128.200.0 (Set base IP address)
>> OSPF Summary Range 2# mask 255.255.255.0 (Set mask address)
>> OSPF Summary Range 2# hide enable    (Hide the range of addresses)
```

9. Apply and save the configuration changes.

```
>> OSPF Summary Range 2# apply        (Apply all configuration changes)
>> OSPF Summary Range 2# save          (Save applied changes)
```

## Verifying OSPF Configuration

Use the following commands to verify the OSPF configuration on your switch:

- /info/l3/ospf/general
- /info/l3/ospf/nbr
- /info/l3/ospf/dbase/dbsum
- /info/l3/ospf/route
- /stats/l3/route

Refer to the *IBM Networking OS Command Reference* for information on the above commands.

---

## OSPFv3 Implementation in IBM N/OS

OSPF version 3 is based on OSPF version 2, but has been modified to support IPv6 addressing. In most other ways, OSPFv3 is similar to OSPFv2: They both have the same packet types and interfaces, and both use the same mechanisms for neighbor discovery, adjacency formation, LSA flooding, aging, and so on. The administrator should be familiar with the OSPFv2 concepts covered in the preceding sections of this chapter before implementing the OSPFv3 differences as described in the following sections.

Although OSPFv2 and OSPFv3 are very similar, they represent independent features on the GbESM. They are configured separately, and both can run in parallel on the switch with no relation to one another, serving different IPv6 and IPv4 traffic, respectively.

The IBM N/OS implementation conforms to the OSPFv3 interface-based authentication/confidentiality specifications in RFC 4552.

## OSPFv3 Differences from OSPFv2

**Note:** When OSPFv3 is enabled, the OSPF backbone area (0.0.0.0) is created by default and is always active.

## OSPFv3 Requires IPv6 Interfaces

OSPFv3 is designed to support IPv6 addresses. This requires IPv6 interfaces to be configured on the switch and assigned to OSPF areas, in much the same way IPv4 interfaces are assigned to areas in OSPFv2. This is the primary configuration difference between OSPFv3 and OSPFv2.

See [“Internet Protocol Version 6” on page 225](#) for configuring IPv6 interfaces.

## OSPFv3 Uses Independent Command Paths

Though OSPFv3 and OSPFv2 are very similar, they are configured independently. They each have their own separate menus in the CLI, and their own command paths in the ISCLI. OSPFv3 base menus and command paths are located as follows:

- In the CLI

>> # /cfg/13/ospf3	(OSPFv3 config menu)
>> # /info/13/ospf3	(OSPFv3 information menu)
>> # /stats/13/ospf3	(OSPFv3 statistics menu)

- In the ISCLI

GbESM(config)# ipv6 router ospf	(OSPFv3 router config mode)
GbESM(config-router-ospf3)# ?	
GbESM(config)# interface ip <Interface number>	(Configure OSPFv3)
GbESM(config-ip-if)# ipv6 ospf ?	(OSPFv3 interface config)
GbESM# show ipv6 ospf ?	(Show OSPFv3 information)



## OSPFv3 Identifies Neighbors by Router ID

Where OSPFv2 uses a mix of IPv4 interface addresses and Router IDs to identify neighbors, depending on their type, OSPFv3 configuration consistently uses a Router ID to identify all neighbors.

Although Router IDs are written in dotted decimal notation, and may even be based on IPv4 addresses from an original OSPFv2 network configuration, it is important to realize that Router IDs are not IP addresses in OSPFv3, and can be assigned independently of IP address space. However, maintaining Router IDs consistent with any legacy OSPFv2 IPv4 addressing allows for easier implementation of both protocols.

## Other Internal Improvements

OSPFv3 has numerous improvements that increase the protocol efficiency in addition to supporting IPv6 addressing. These improvements change some of the behaviors in the OSPFv3 network and may affect topology consideration, but have little direct impact on configuration. For example:

- Addressing fields have been removed from Router and Network LSAs.
- Link-local flooding scope has been added, along with a Link LSA. This allows flooding information to relevant local neighbors without forwarding it beyond the local router.
- Flexible treatment of unknown LSA types to make integration of OSPFv3 easier.

## OSPFv3 Limitations

N/OS 7.4 does not currently support the following OSPFv3 features:


- Multiple instances of OSPFv3 on one IPv6 link.
- Authentication of OSPFv3 packets via IPv6 Security (IPsec) for virtual links.

## OSPFv3 Configuration Example

The following example depicts the OSPFv3 equivalent configuration of [“Example 3: Summarizing Routes” on page 325](#) for OSPFv2.

In this example, one summary route from area 1 (stub area) is injected into area 0 (the backbone). The summary route consists of all IP addresses for the 36::0/32 portion of the 36::0/56 network except for the routes in the 36::0/8 range.

Figure 36. Summarizing Routes



**Note:** You can specify a range of addresses to prevent advertising by using the `hide` option. In this example, routes in the 36::0/8 range are kept private.

Use the following procedure to configure OSPFv3 support as shown in [Figure 36](#):

**Note:** Except for configuring IPv6 addresses for the interfaces, and using the `/cfg/l3/ospf3` menu path, most of the following commands are identical to OSPFv2 configuration.

1. Configure IPv6 interfaces for each link which will be attached to OSPFv3 areas.

```
>> # /cfg/l3/if 3                (Select menu for IP interface 31)
>> IP Interface 3# addr 10:0:0:0:0:0:1 (Set IPv6 address on backbone)
>> IP Interface 3# maskplen 56        (Set IPv6 mask on backbone)
>> IP Interface 3# ena                (Enable IP interface 3)
>>> IP Interface 3# ../if 4           (Select menu for IP interface 4)
>> IP Interface 4# addr 36:0:0:0:0:0:1 (Set IPv6 address on stub area)
>> IP Interface 4# maskplen 56        (Set IPv6 mask on stub area)
>> IP Interface 4# ena                (Enable IP interface 4)
```

This is equivalent to configuring the IP address and netmask for IPv4 interfaces.

2. Enable OSPFv3.

```
>> IP Interface 4# ../ospf3/on
```

3. Define the backbone.

```
>> Open Shortest Path First v3# aindex 0 (Select menu for area index 0)
>> OSPFv3 Area (index) 0# areaid 0.0.0.0 (Set the ID for backbone area 0)
>> OSPFv3 Area (index) 0# type transit   (Define backbone as transit type)
>> OSPFv3 Area (index) 0# enable         (Enable the area)
```

4. Define the stub area.

```
>> OSPFv3 Area (index) 0# ../aindex 1 (Select menu for area index 1)
>> OSPFv3 Area (index) 1# areaid 0.0.0.1 (Set the area ID for OSPF area 1)
>> OSPFv3 Area (index) 1# type stub      (Define area as stub type)
>> OSPFv3 Area (index) 1# enable         (Enable the area)
```

5. Attach the network interface to the backbone.

```
>> OSPFv3 Area (index) 1# ../if 3      (Select OSPF menu for interface 3)
>> OSPFv3 Interface 3# aindex 0         (Attach network to backbone index)
>> OSPFv3 Interface 3# enable           (Enable the backbone interface)
```

6. Attach the network interface to the stub area.

```
>> OSPFv3 Interface 3# ../if 4          (Select OSPF menu for interface 4)
>> OSPFv3 Interface 4# aindex 1          (Attach network to stub area index)
>> OSPFv3 Interface 4# enable            (Enable the stub area interface)
```

7. Configure route summarization by specifying the starting address and prefix length of the range of addresses to be summarized.

```
>> OSPFv3 Interface 4# ../range 1          (Select summary range menu)
>> OSPFv3 Summary Range 1# addr 36:0:0:0:0:0:0 (Set base IP address of range)
>> OSPFv3 Summary Range 1# maskplen 32      (Set address range mask)
>> OSPFv3 Summary Range 1# aindex 0        (Add summary route to area 0)
>> OSPFv3 Summary Range 1# enable          (Enable summary range)
```

8. Use the hide command to prevent a range of addresses from advertising to the backbone.

```
>> OSPFv3 Summary Range 1 # ../range 2     (Select summary range menu)
>> OSPFv3 Summary Range 2 # addr 36:0:0:0:0:0:0 (Set base IP address)
>> OSPFv3 Summary Range 2 # maskplen 8      (Set address range mask)
>> OSPFv3 Summary Range 2 # hide enable     (Hide the range of addresses)
```

9. Apply and save the configuration changes.

```
>> OSPF Summary Range 2 # apply             (Apply all configuration changes)
>> OSPF Summary Range 2 # save              (Save applied changes)
```



# Part 6: High Availability Fundamentals

Internet traffic consists of myriad services and applications which use the Internet Protocol (IP) for data delivery. However, IP is not optimized for all the various applications. High Availability goes beyond IP and makes intelligent switching decisions to provide redundant network configurations.



---

## Chapter 22. Basic Redundancy

IBM Networking OS 7.4 includes various features for providing basic link or device redundancy:

- [“Trunking for Link Redundancy” on page 336](#)
- [“Hot Links” on page 337](#)
- [“Active MultiPath Protocol” on page 339](#)
- [“Stacking for High Availability Topologies” on page 342](#)


---

## Trunking for Link Redundancy

Multiple switch ports can be combined together to form robust, high-bandwidth trunks to other devices. Since trunks are comprised of multiple physical links, the trunk group is inherently fault tolerant. As long as one connection between the switches is available, the trunk remains active.

In [Figure 37](#), four ports are trunked together between the switch and the enterprise routing device. Connectivity is maintained as long as one of the links remain active. The links to the server are also trunked, allowing the secondary NIC to take over in the event that the primary NIC link fails.

Figure 37. Trunking Ports for Link Redundancy



For more information on trunking, see [“Ports and Trunking” on page 125](#).



---

## Hot Links

For network topologies that require Spanning Tree to be turned off, Hot Links provides basic link redundancy with fast recovery.

Hot Links consists of up to 25 triggers. A trigger consists of a pair of layer 2 interfaces, each containing an individual port, trunk, or LACP adminkey. One interface is the Master, and the other is a Backup. While the Master interface is set to the active state and forwards traffic, the Backup interface is set to the standby state and blocks traffic until the Master interface fails. If the Master interface fails, the Backup interface is set to active and forwards traffic. Once the Master interface is restored, it transitions to the standby state and blocks traffic until the Backup interface fails.

You may select a physical port, static trunk, or an LACP adminkey as a Hot Link interface. Only external ports (EXT<sub>x</sub>) and Inter-Switch Link (ISL) ports can be members of a Hot Links trigger interface.

## Forward Delay

The Forward Delay timer allows Hot Links to monitor the Master and Backup interfaces for link stability before selecting one interface to transition to the active state. Before the transition occurs, the interface must maintain a stable link for the duration of the Forward Delay interval.

For example, if you set the Forward delay timer to 10 seconds (`/cfg/l2/hotlink/trigger <x>/fdelay 10`), the switch will select an interface to become active only if a link remained stable for the duration of the Forward Delay period. If the link is unstable, the Forward Delay period starts again.

## Preemption

You can configure the Master interface to resume the active state whenever it becomes available. With Hot Links preemption enabled (`/cfg/l2/hotlink/trigger <x>/preempt ena`), the Master interface transitions to the active state immediately upon recovery. The Backup interface immediately transitions to the standby state. If Forward Delay is enabled, the transition occurs when an interface has maintained link stability for the duration of the Forward Delay period.

## FDB Update

Use the FDB update option to notify other devices on the network about updates to the Forwarding Database (FDB). When you enable FDB update (`/cfg/l2/hotlinks/sndfdb ena`), the switch sends multicasts of addresses in the forwarding database (FDB) over the active interface, so that other devices on the network can learn the new path. The Hot Links FDB update option uses the station update rate (`/cfg/l2/update`) to determine the rate at which to send FDB packets.

## Configuration Guidelines

The following configuration guidelines apply to Hot links:

- Only external ports and inter-switch links can be configured as Hot Links.
- When Hot Links is turned on, MSTP, RSTP, and PVRST must be turned off (/cfg/l2/mrst/off).
- When Hot Links is turned on, UplinkFast must be disabled (/cfg/l2/upfast d).
- A port that is a member of the Master interface cannot be a member of the Backup interface. A port that is a member of one Hot Links trigger cannot be a member of another Hot Links trigger.
- An individual port that is configured as a Hot Link interface cannot be a member of a trunk.

## Configuring Hot Links

Use the following commands to configure Hot Links.

>> # /cfg/l2/hotlink/trigger 1 ena	<i>(Enable Hot Links Trigger 1)</i>
>> Trigger 1# master/port ext1	<i>(Add port to Master interface)</i>
>> Master# ..	
>> Trigger 1# backup/port ext2	<i>(Add port to Backup interface)</i>
>> Backup# ..	
>> Trigger 1# ..	
>> Hot Links# on	<i>(Turn on Hot Links)</i>
>> Hot Links# apply	<i>(Make your changes active)</i>
>> Hot Links# save	<i>(Save for restore after reboot)</i>

---


## Active MultiPath Protocol

Active MultiPath Protocol (AMP) allows you to connect three switches in a loop topology, and load-balance traffic across all uplinks (no blocking). When an AMP link fails, upstream communication continues over the remaining AMP link. Once the failed AMP link re-establishes connectivity, communication resumes to its original flow pattern.

AMP is supported over Layer 2 only. Layer 3 routing is not supported. Spanning Tree is not required in an AMP Layer 2 domain. STP BPDUs will not be forwarded over the AMP links, and any BPDU packets received on AMP links are dropped.

Each AMP group contains two aggregator switches and one access switch. Aggregator switches support up to 22 AMP groups. Access switches support only one AMP group. [Figure 38](#) shows a typical AMP topology, with two aggregators supporting a number of AMP groups.

Figure 38. AMP Topology



Each AMP group requires two links on each switch. Each AMP link consists of a single port, a static trunk group, or an LACP trunk group. Local non-AMP ports can communicate via local Layer 2 switching without passing traffic through the AMP links. No two switches in the AMP loop can have another active connection between them through a non-AMP switch.

Each AMP switch has a priority value (1-255). The switch with the lowest priority value has the highest precedence over the other switches. If there is a conflict between switch priorities, the switch with lowest MAC address has the highest precedence.

**Note:** For proper AMP operation, all access switches should be configured with a higher priority value (lower precedence) than the aggregators. Otherwise, some AMP control packets may be sent to access switches, even when their AMP groups are disabled.

When the AMP loop is broken, the STP port states are set to forwarding or blocking, depending on the switch priority and port/trunk precedence, as follows:

- An aggregator's port/trunk has higher precedence over an access switch's port/trunk.
- Static trunks have highest precedence, followed by LACP trunks, then physical ports.
- Between two static trunks, the trunk with the lower trunk ID has higher precedence.
- Between two LACP trunks, the trunk with the lower *admin key* has higher precedence.
- Between two ports, the port with the lowest port number has higher precedence.

## Health Checks

An AMP keep-alive message is passed periodically from each switch to its neighbors in the AMP group. The keep-alive message is a BPDU-like packet that passes on an AMP link even when the link is blocked by Spanning Tree. The keep-alive message carries status information about AMP ports/trunks, and is used to verify that a physical loop exists.

An AMP link is considered healthy if the switch has received an AMP keep-alive message on that link. An AMP link is considered unhealthy if a number of consecutive AMP keep-alive messages have not been received recently on that link.

## FDB Flush

When an AMP port/trunk is in the blocking state, FDB flush is performed on that port/trunk. Any time there is a change in the data path for an AMP group, the FDB entries associated with the ports in the AMP group are flushed. This ensures that communication is not blocked while obsolete FDB entries are aged out.

FDB flush is performed when an AMP link goes down, and when an AMP link comes up.

## Configuration Guidelines

The following configuration guidelines apply to Active MultiPath Protocol:

- The GbESM can be used as an AMP access switch only.
- Enable AMP on all switches in the AMP group before connecting the switch ports.
- Access switches should be configured with a higher priority value (lower precedence) than the aggregators. Otherwise, unexpected AMP keep-alive packets may be sent from one aggregator switches to another, even when its AMP group is disabled.
- Only one active connection (port or trunk) is allowed between switches in an AMP group.
- Spanning Tree must be disabled on AMP trunks/ports.
- Hot Links must be disabled on AMP trunk/ports.
- Private VLANs must be disabled before AMP is enabled.
- AMP ports cannot be used as monitoring ports in a port-mirroring configuration.
- Do not configure AMP ports as Layer 2 Failover control ports.
- Layer 3 routing protocols are not supported on AMP-configured switches.

## Configuration Example

Perform the following steps to configure AMP on an access switch:

1. Turn off Spanning Tree.

```
>> # /cfg/l2/nostp ena
```

2. Turn AMP on.

```
>> Layer 2# amp/on
```

3. Define the AMP group links, and enable the AMP group.

```
>> Active Multipath# group 1
>> AMP Group 1# port EXT3
>> AMP Group 1# port2 EXT4
>> AMP Group 1# ena
```

### Verifying AMP Operation

Display AMP group information to verify that the AMP loop is healthy.

```
>> # /info/l2/amp/group 1

Group 1: enabled, topology UP
  Port EXT3: access
    State : forwarding
    Peer  : 00:22:00:ac:bd:00
            aggregator, priority 10
  Port EXT4: aggregator
    State : forwarding
    Peer  : 00:25:03:49:82:00
            aggregator, priority 1
```

Verify that the AMP topology is UP, and that each link state is set to forwarding.


---

## Stacking for High Availability Topologies

A *stack* is a group of up to eight 1/10Gb Uplink ESM devices that work together as a unified system. Because the multiple members of a stack acts as a single switch entity with distributed resources, high-availability topologies can be more easily achieved.

In [Figure 39](#), a simple stack using two switches provides full redundancy in the event that either switch were to fail. As shown with the servers in the example, stacking permits ports within different physical switches to be trunked together, further enhancing switch redundancy.

Figure 39. High Availability Topology Using Stacking



For more information on stacking, see [“Stacking” on page 171](#).

---

## Chapter 23. Layer 2 Failover

The primary application for Layer 2 Failover is to support Network Adapter Teaming. With Network Adapter Teaming, all the NICs on each server share the same IP address, and are configured into a team. One NIC is the primary link, and the other is a standby link. For more details, refer to the documentation for your Ethernet adapter.

**Note:** Only two links per server blade can be used for Layer 2 Trunk Failover (one primary and one backup). Network Adapter Teaming allows only one backup NIC for each server blade.

---

## Auto Monitoring Trunk Links

Layer 2 Failover can be enabled on any trunk group in the GbESM, including LACP trunks. Trunks can be added to failover trigger groups. Then, if some specified number of trigger links fail, the switch disables all the internal ports in the switch (unless VLAN Monitor is turned on). When the internal ports are disabled, it causes the NIC team on the affected server blades to failover from the primary to the backup NIC. This process is called a failover event.

When the appropriate number of links in a trigger group return to service, the switch enables the internal ports. This causes the NIC team on the affected server blades to fail back to the primary switch (unless Auto-Fallback is disabled on the NIC team). The backup switch processes traffic until the primary switch's internal links come up, which can take up to five seconds.

## VLAN Monitor

The VLAN Monitor allows Layer 2 Failover to discern different VLANs. With VLAN Monitor turned on:

- If enough links in a trigger fail (see [“Setting the Failover Limit” on page 346](#)), the switch disables all internal ports that reside in the same VLAN membership as the trunk(s) in the trigger.
- When enough links in the trigger return to service, the switch enables the internal ports that reside in the same VLAN membership as the trunk(s) in the trigger.

If you turn off the VLAN Monitor (`/cfg/l2/failovr/vlan/off`), only one failover trigger is allowed. When a link failure occurs on the trigger, the switch disables all internal server-blade ports.

## Auto Monitor Configurations

[Figure 40](#) is a simple example of Layer 2 Failover. One GbESM is the primary, and the other is used as a backup. In this example, all external ports on the primary switch belong to a single trunk group, with Layer 2 Failover enabled, and Failover Limit set to 2. If two or fewer links in trigger 1 remain active, the switch temporarily disables all internal server-blade ports that reside in VLAN 1. This action causes a failover event on Server 1 and Server 2.

Figure 40. Basic Layer 2 Failover






Figure 41 shows a configuration with two trunks, each in a different Failover Trigger. GbESM 1 is the primary switch for Server 1 and Server 2. GbESM 2 is the primary switch for Server 3 and Server 4. VLAN Monitor is turned on. STP is turned off.

If all links go down in trigger 1, GbESM 1 disables all internal ports that reside in VLAN 1. If all links in trigger 2 go down, GbESM 1 disables all internal ports that reside in VLAN 2.

Figure 41. Two trunks, each in a different Failover Trigger





Figure 42 shows a configuration with two trunks. VLAN Monitor is turned off, so only one Failover Trigger is configured on each switch. GbESM 1 is the primary switch for Server 1 and Server 2. GbESM 2 is the primary switch for Server 3 and Server 4. STP is turned off.

If all links in trigger 1 go down, GbESM 1 disables all internal links to server blades.

Figure 42. Two trunks, one Failover Trigger



---

## Setting the Failover Limit

The failover limit lets you specify the minimum number of operational links required within each trigger before the trigger initiates a failover event. For example, if the limit is two (`/cfg/12/failovr/trigger <x>/limit 2`), a failover event occurs when the number of operational links in the trigger is two or fewer. When you set the limit to zero, the switch triggers a failover event only when no links in the trigger are operational.

---

## Manually Monitoring Port Links

The Manual Monitor allows you to configure a set of ports and/or trunks to monitor for link failures (a monitor list), and another set of ports and/or trunks to disable when the trigger limit is reached (a control list). When the switch detects a link failure on the monitor list, it automatically disables the items in control list. When server ports are disabled, the corresponding server's network adapter can detect the disabled link, and trigger a network-adaptor failover to another port or trunk on the switch, or another switch in the chassis.

The switch automatically enables the control list items when the monitor list items return to service.

### Monitor Port State

A monitor port is considered operational as long as the following conditions are true:

- The port must be in the `Link Up` state.
- If STP is enabled, the port must be in the `Forwarding` state.
- If the port is part of an LACP trunk, the port must be in the `Aggregated` state.

If any of the above conditions is false, the monitor port is considered to have failed.

### Control Port State

A control port is considered Operational if the monitor trigger is up. As long as the trigger is up, the port is considered operational from a teaming perspective, even if the port itself is actually in the `Down` state, `Blocking` state (if STP is enabled on the port), or `Not Aggregated` state (if part of an LACP trunk).

A control port is considered to have failed only if the monitor trigger is in the `Down` state.

To view the state of any port, use one of the following commands:

<code>&gt;&gt; # /info/link</code>	<i>(View port link status)</i>
<code>&gt;&gt; # /info/12/stp</code>	<i>(View port STP status)</i>
<code>&gt;&gt; # /info/12/lacp/dump</code>	<i>(View port LACP status)</i>

---

## L2 Failover with Other Features

L2 Failover works together with Link Aggregation Control Protocol (LACP) and with Spanning Tree Protocol (STP), as described below.

### LACP

Link Aggregation Control Protocol allows the switch to form dynamic trunks. You can use the *admin key* to add up to two LACP trunks to a failover trigger using automatic monitoring. When you add an *admin key* to a trigger (`/cfg/l2/failovr/trigger <x>/amon/addkey`), any LACP trunk with that *admin key* becomes a member of the trigger.

### Spanning Tree Protocol

If Spanning Tree Protocol (STP) is enabled on the ports in a failover trigger, the switch monitors the port STP state rather than the link state. A port failure results when STP is not in a Forwarding state (such as Listening, Learning, Blocking, or No Link) in all the Spanning Tree Groups (STGs) to which the port belongs. The switch automatically disables the appropriate control ports.

When the switch determines that ports in the trigger are in STP Forwarding state in any one of the STGs it belongs to, then it automatically enables the appropriate control ports. The switch *fails back* to normal operation.

For example, if a monitor port is a member of STG1, STG2, and STG3, a failover will be triggered only if the port is not in a forwarding state in all the three STGs. When the port state in any of the three STGs changes to forwarding, then the control port is enabled and normal switch operation is resumed.

---

## Configuration Guidelines

This section provides important information about configuring Layer 2 Failover.

**Note:** Auto Monitor and Manual Monitor are mutually exclusive. They cannot both be configured on the switch.

### Auto Monitor Guidelines

- Any specific failover trigger may monitor static trunks only or LACP trunks only, but not both.
- All external ports in all static or LACP trunks added to any specific failover trigger must belong to the same VLAN.
- A maximum of two LACP keys can be added per trigger.
- When VLAN Monitor is on, the following additional guidelines apply:
  - All external ports in all static or LACP trunks added to a specific failover trigger must belong to the same VLAN and have the same PVID.
  - Different triggers are not permitted to operate on the same VLAN.
  - Different triggers are not permitted to operate on the same internal port.
  - For each port in each trunk in a specific failover trigger, the trigger will monitor the STP state on only the default PVID.

### Manual Monitor Guidelines

- A Manual Monitor can monitor only external ports.
- Any specific failover trigger can monitor external ports only, static trunks only, or LACP trunks only. The different types cannot be combined in the same trigger.
- A maximum of two LACP keys can be added per trigger.
- Port membership for different triggers should not overlap. Any specific port should be a member of only one trigger.

---

## Configuring Layer 2 Failover

### Auto Monitor Example

The following procedure pertains to the configuration shown in [Figure 40](#).

1. Configure Network Adapter Teaming on the servers.
2. Define a trunk group on the GbESM.

```
>> # /cfg/l2/trunk 1                (Select trunk group 1)
>> Trunk group 1# add EXT1           (Add port EXT1 to trunk group 1)
>> Trunk group 1# add EXT2           (Add port EXT2 to trunk group 1)
>> Trunk group 1# add EXT3           (Add port EXT3 to trunk group 1)
>> Trunk group 1# ena                (Enable trunk group 1)
```

3. Configure Failover parameters.

```
>> # /cfg/l2/failovr/on              (Turn Failover on)
>> Failover# trigger 1               (Select trigger group 1)
>> Trigger 1# ena                    (Enable trigger group 1)
>> Trigger 1# limit 2                (Set Failover limit to 2 links)
>> Trigger 1# amon                   (Select Auto Monitor menu)
>> Auto Monitor# addtrnk 1           (Add trunk group 1)
```

4. Apply and verify the configuration.

```
>> Auto Monitor# apply               (Make your changes active)
>> Auto Monitor# cur                 (View current trunking configuration)
```

5. Save the configuration.

```
>> Auto Monitor# save                (Save for restore after reboot)
```

### Manual Monitor Example

Use the following procedure to configure a Layer 2 Failover Manual Monitor.

1. Configure Network Adapter Teaming on the servers.
2. Configure general Layer 2 Failover parameters.

```
>> # /cfg/l2/failovr/on              (Turn Failover on)
>> Failover# trigger 2               (Select trigger 2)
>> Trigger 2# ena                    (Enable trigger 2)
>> Trigger 2# limit 2                (Set Failover limit to 2 links)
```

3. Specify the links to monitor.

```
>> Trigger 2# mmon/monitor           (Select Manual Monitor, Monitor menu)
>> Monitor# addport EXT4             (Add port EXT4)
>> Monitor# addport EXT5             (Add port EXT5)
>> Monitor# addport EXT6             (Add port EXT6)
>> Monitor# ..
```

4. Specify the links to disable when the failover limit is reached.

>> Manual Monitor# control	<i>(Select Manual Monitor - Control menu)</i>
>> Control# addport INT13	<i>(Add port INT13)</i>
>> Control# addport INT14	<i>(Add port INT14)</i>

5. Apply and verify the configuration.

>> Control# apply	<i>(Make your changes active)</i>
>> # /cfg/12/failovr/cur	<i>(View current Failover configuration)</i>

6. Save the configuration.

>> Failover# save	<i>(Save for restore after reboot)</i>
-------------------	--

---

## Chapter 24. Virtual Router Redundancy Protocol

The IBM 1/10Gb Uplink ESM (GbESM) supports IPv4 high-availability network topologies through an enhanced implementation of the Virtual Router Redundancy Protocol (VRRP).

**Note:** IBM Networking OS 7.4 does not support IPv6 for VRRP.

The following topics are discussed in this chapter:

- [“VRRP Overview” on page 352](#). This section discusses VRRP operation and IBM N/OS redundancy configurations.
- [“Failover Methods” on page 355](#). This section describes the three modes of high availability.
- [“IBM N/OS Extensions to VRRP” on page 358](#). This section describes VRRP enhancements implemented in N/OS.
- [“Virtual Router Deployment Considerations” on page 359](#). This section describes issues to consider when deploying virtual routers.
- [“High Availability Configurations” on page 360](#). This section discusses the more useful and easily deployed redundant configurations.
  - [“Active-Active Configuration” on page 360](#)
  - [“Hot-Standby Configuration” on page 365](#)

---

## VRRP Overview

In a high-availability network topology, no device can create a single point-of-failure for the network or force a single point-of-failure to any other part of the network. This means that your network will remain in service despite the failure of any single device. To achieve this usually requires redundancy for all vital network components.

VRRP enables redundant router configurations within a LAN, providing alternate router paths for a host to eliminate single points-of-failure within a network. Each participating VRRP-capable routing device is configured with the same virtual router IPv4 address and ID number. One of the virtual routers is elected as the master, based on a number of priority criteria, and assumes control of the shared virtual router IPv4 address. If the master fails, one of the backup virtual routers will take control of the virtual router IPv4 address and actively process traffic addressed to it.

With VRRP, Virtual Interface Routers (VIR) allow two VRRP routers to share an IP interface across the routers. VIRs provide a single Destination IPv4 (DIP) address for upstream routers to reach various servers, and provide a virtual default Gateway for the server blades.

## VRRP Components

Each physical router running VRRP is known as a *VRRP router*.

### Virtual Router

Two or more VRRP routers can be configured to form a *virtual router* (RFC 2338). Each VRRP router may participate in one or more virtual routers. Each virtual router consists of a user-configured *virtual router identifier* (VRID) and an IPv4 address.

### Virtual Router MAC Address

The VRID is used to build the *virtual router MAC Address*. The five highest-order octets of the virtual router MAC Address are the standard MAC prefix (00-00-5E-00-01) defined in RFC 2338. The VRID is used to form the lowest-order octet. For virtual routers with a VRID greater than 255, the MAC addresses block 00:0F:6A:9A:40:00 through 00:0F:6A:9A:47:FF is allocated.

### Owners and Renters

Only one of the VRRP routers in a virtual router may be configured as the IPv4 address owner. This router has the virtual router's IPv4 address as its real interface address. This router responds to packets addressed to the virtual router's IPv4 address for ICMP pings, TCP connections, and so on.

There is no requirement for any VRRP router to be the IPv4 address owner. Most VRRP installations choose not to implement an IPv4 address owner. For the purposes of this chapter, VRRP routers that are not the IPv4 address owner are called *renters*.



## Master and Backup Virtual Router

Within each virtual router, one VRRP router is selected to be the virtual router master. See [“Selecting the Master VRRP Router” on page 354](#) for an explanation of the selection process.

**Note:** If the IPv4 address owner is available, it will always become the virtual router master.

The virtual router master forwards packets sent to the virtual router. It also responds to Address Resolution Protocol (ARP) requests sent to the virtual router's IPv4 address. Finally, the virtual router master sends out periodic advertisements to let other VRRP routers know it is alive and its priority.

Within a virtual router, the VRRP routers not selected to be the master are known as virtual router backups. Should the virtual router master fail, one of the virtual router backups becomes the master and assumes its responsibilities.

## Virtual Interface Router

At Layer 3, a Virtual Interface Router (VIR) allows two VRRP routers to share an IP interface across the routers. VIRs provide a single Destination IPv4 (DIP) address for upstream routers to reach various destination networks, and provide a virtual default Gateway.

**Note:** Every VIR must be assigned to an IP interface, and every IP interface must be assigned to a VLAN. If no port in a VLAN has link up, the IP interface of that VLAN is down, and if the IP interface of a VIR is down, that VIR goes into INIT state.

## VRRP Operation

Only the virtual router master responds to ARP requests. Therefore, the upstream routers only forward packets destined to the master. The master also responds to ICMP ping requests. The backup does not forward any traffic, nor does it respond to ARP requests.

If the master is not available, the backup becomes the master and takes over responsibility for packet forwarding and responding to ARP requests.

## Selecting the Master VRRP Router

Each VRRP router is configured with a priority between 1–254. A bidding process determines which VRRP router is or becomes the master—the VRRP router with the highest priority.

The master periodically sends advertisements to an IPv4 multicast address. As long as the backups receive these advertisements, they remain in the backup state. If a backup does not receive an advertisement for three advertisement intervals, it initiates a bidding process to determine which VRRP router has the highest priority and takes over as master.

If, at any time, a backup determines that it has higher priority than the current master does, it can preempt the master and become the master itself, unless configured not to do so. In preemption, the backup assumes the role of master and begins to send its own advertisements. The current master sees that the backup has higher priority and will stop functioning as the master.


A backup router can stop receiving advertisements for one of two reasons—the master can be down, or all communications links between the master and the backup can be down. If the master has failed, it is clearly desirable for the backup (or one of the backups, if there is more than one) to become the master.

**Note:** If the master is healthy but communication between the master and the backup has failed, there will then be two masters within the virtual router. To prevent this from happening, configure redundant links to be used between the switches that form a virtual router.

## Failover Methods

With service availability becoming a major concern on the Internet, service providers are increasingly deploying Internet traffic control devices, such as application switches, in redundant configurations. Traditionally, these configurations have been *hot-standby* configurations, where one switch is active and the other is in a standby mode. A non-VRRP hot-standby configuration is shown [Figure 43](#):

**Figure 43** A Non-VRRP, Hot-Standby Configuration



While hot-standby configurations increase site availability by removing single points-of-failure, service providers increasingly view them as an inefficient use of network resources because one functional application switch sits by idly until a failure calls it into action. Service providers now demand that vendors' equipment support redundant configurations where all devices can process traffic when they are healthy, increasing site throughput and decreasing user response times when no device has failed.

N/OS high availability configurations are based on VRRP. The N/OS implementation of VRRP includes proprietary extensions.

The N/OS implementation of VRRP supports the following modes of high availability:


- **Active-Active**—based on proprietary N/OS extensions to VRRP
- **Hot-Standby**—supports Network Adapter Teaming on your server blades

## Active-Active Redundancy

In an active-active configuration, shown in [Figure 44](#), two switches provide redundancy for each other, with both active at the same time. Each switch processes traffic on a different subnet. When a failure occurs, the remaining switch can process traffic on all subnets.

For a configuration example, see [“High Availability Configurations” on page 360](#).

Figure 44. Active-Active Redundancy




## Hot-Standby Redundancy

The primary application for VRRP-based hot-standby is to support Server Load Balancing when you have configured Network Adapter Teaming on your server blades. With Network Adapter Teaming, the NICs on each server share the same IPv4 address, and are configured into a team. One NIC is the primary link, and the others are backup links. For more details, refer to the NetXen 10 Gb Ethernet Adapter documentation.

The hot-standby model is shown in [Figure 45](#).

Figure 45. Hot-Standby Redundancy



## Virtual Router Group

The virtual router group ties all virtual routers on the switch together as a single entity. By definition, hot-standby requires that all virtual routers failover as a group, and not individually. As members of a group, all virtual routers on the switch (and therefore the switch itself), are in either a master or standby state.

The virtual router group cannot be used for active-active configurations or any other configuration that require shared interfaces.

A VRRP group has the following characteristics:

- When enabled, all virtual routers behave as one entity, and all group settings override any individual virtual router settings.
- All individual virtual routers, once the VRRP group is enabled, assume the group's tracking and priority.
- When one member of a VRRP group fails, the priority of the group decreases, and the state of the entire switch changes from Master to Standby.

Each VRRP advertisement can include up to 128 addresses. All virtual routers are advertised within the same packet, conserving processing and buffering resources.

---

## IBM N/OS Extensions to VRRP

This section describes VRRP enhancements that are implemented in N/OS.

N/OS supports a tracking function that dynamically modifies the priority of a VRRP router, based on its current state. The objective of tracking is to have, whenever possible, the master bidding processes for various virtual routers in a LAN converge on the same switch. Tracking ensures that the selected switch is the one that offers optimal network performance. For tracking to have any effect on virtual router operation, preemption must be enabled.

N/OS can track the attributes listed in [Table 23](#):

*Table 23. VRRP Tracking Parameters*

Parameter	Description
Number of IP interfaces on the switch that are active (“up”)  <code>/cfg/13/vrrp/track/ifs</code>	Helps elect the virtual routers with the most available routes as the master. (An IP interface is considered active when there is at least one active port on the same VLAN.) This parameter influences the VRRP router's priority in virtual interface routers.
Number of active ports on the same VLAN  <code>/cfg/13/vrrp/track/ports</code>	Helps elect the virtual routers with the most available ports as the master. This parameter influences the VRRP router's priority in virtual interface routers.  <b>Note:</b> In a hot-standby configuration, only external ports are tracked.
Number of virtual routers in master mode on the switch  <code>/cfg/13/vrrp/track/vrs</code>	Useful for ensuring that traffic for any particular client/server pair is handled by the same switch, increasing routing efficiency. This parameter influences the VRRP router's priority in virtual interface routers.

Each tracked parameter has a user-configurable weight associated with it. As the count associated with each tracked item increases (or decreases), so does the VRRP router's priority, subject to the weighting associated with each tracked item. If the priority level of a standby is greater than that of the current master, then the standby can assume the role of the master.

See [“Configuring the Switch for Tracking” on page 359](#) for an example on how to configure the switch for tracking VRRP priority.

---

## Virtual Router Deployment Considerations

### Assigning VRRP Virtual Router ID

During the software upgrade process, VRRP virtual router IDs will be automatically assigned if failover is enabled on the switch. When configuring virtual routers at any point after upgrade, virtual router ID numbers (`/cfg/13/vrrp/vr #/vrid`) must be assigned. The virtual router ID may be configured as any number between 1 and 128.

### Configuring the Switch for Tracking

Tracking configuration largely depends on user preferences and network environment. Consider the configuration shown in [Figure 44 on page 356](#). Assume the following behavior on the network:

- Switch 1 is the master router upon initialization.
- If switch 1 is the master and it has one fewer active servers than switch 2, then switch 1 remains the master.  
This behavior is preferred because running one server down is less disruptive than bringing a new master online and severing all active connections in the process.
- If switch 1 is the master and it has two or more active servers fewer than switch 2, then switch 2 becomes the master.
- If switch 2 is the master, it remains the master even if servers are restored on switch 1 such that it has one fewer or an equal number of servers.
- If switch 2 is the master and it has one active server fewer than switch 1, then switch 1 becomes the master.

The user can implement this behavior by configuring the switch for tracking as follows:

1. Set the priority for switch 1 to 101.
2. Leave the priority for switch 2 at the default value of 100.
3. On both switches, enable tracking based on ports (`ports`), interfaces (`ifs`), or virtual routers (`vr`). You can choose any combination of tracking parameters, based on your network configuration.

**Note:** There is no shortcut to setting tracking parameters. The goals must first be set and the outcomes of various configurations and scenarios analyzed to find settings that meet the goals.

## High Availability Configurations


GbESMs offer flexibility in implementing redundant configurations. This section discusses the more useful and easily deployed configurations:

- [“Active-Active Configuration” on page 360](#)
- [“Hot-Standby Configuration” on page 365](#)

### Active-Active Configuration

[Figure 46](#) shows an example configuration where two GbESMs are used as VRRP routers in an active-active configuration. In this configuration, both switches respond to packets.

Figure 46. Active-Active High-Availability Configuration



Although this example shows only two switches, there is no limit on the number of switches used in a redundant configuration. It is possible to implement an active-active configuration across all the VRRP-capable switches in a LAN.

Each VRRP-capable switch in an active-active configuration is autonomous. Switches in a virtual router need not be identically configured.

In the scenario illustrated in [Figure 46](#), traffic destined for IPv4 address 10.0.1.1 is forwarded through the Layer 2 switch at the top of the drawing, and ingresses GbESM 1 on port EXT1. Return traffic uses default gateway 1 (192.168.1.1).

If the link between GbESM 1 and the Layer 2 switch fails, GbESM 2 becomes the Master because it has a higher priority. Traffic is forwarded to GbESM 2, which forwards it to GbESM 1 through port EXT4. Return traffic uses default gateway 2 (192.168.2.1), and is forwarded through the Layer 2 switch at the bottom of the drawing.



To implement the active-active example, perform the following switch configuration.

### Task 1: Configure GbESM 1

#### 1. Configure client and server interfaces.

```
/cfg/l3/if 1                                (Select interface 1)
>> IP Interface 1# addr 192.168.1.100        (Define IPv4 address for interface 1)
>> IP Interface 1# mask 255.255.255.0        (Define subnet mask for interface 1)
>> IP Interface 1# vlan 10                   (Assign VLAN 10 to interface 1)
>> IP Interface 1# ena                       (Enable interface 1)
>> IP Interface 1# ..
>> Layer 3# if 2                             (Select interface 2)
>> IP Interface 2# addr 192.168.2.101        (Define IPv4 address for interface 2)
>> IP Interface 2# mask 255.255.255.0        (Define subnet mask for interface 2)
>> IP Interface 2# vlan 20                   (Assign VLAN 20 to interface 2)
>> IP Interface 2# ena                       (Enable interface 2)
>> IP Interface 2# ..
>> Layer 3# if 3                             (Select interface 3)
>> IP Interface 3# addr 10.0.1.100           (Define IPv4 address for interface 3)
>> IP Interface 3# mask 255.255.255.0        (Define subnet mask for interface 3)
>> IP Interface 3# ena                       (Enable interface 3)
>> IP Interface 3# ..
>> Layer 3# if 4                             (Select interface 4)
>> IP Interface 4# addr 10.0.2.101           (Define IPv4 address for interface 4)
>> IP Interface 4# mask 255.255.255.0        (Define subnet mask for interface 4)
>> IP Interface 4# ena                       (Enable interface 4)
```

#### 2. Configure the default gateways. Each default gateway points to a Layer 3 router.

```
/cfg/l3/gw 1                                (Select default gateway 1)
>> Default gateway 1# addr 192.168.1.1      (Point gateway to the first L3 router)
>> Default gateway 1# ena                   (Enable the default gateway)
>> Default gateway 1# ..
>> Layer 3# gw 2                             (Select default gateway 2)
>> Default gateway 2# addr 192.168.2.1      (Point gateway to the second router)
>> Default gateway 2# ena                   (Enable the default gateway)
```

#### 3. Turn on VRRP and configure two Virtual Interface Routers.

```
/cfg/l3/vrrp/on                             (Turn VRRP on)
>> Virtual Router Redundancy Protocol# vr 1 (Select virtual router 1)
>> VRRP Virtual Router 1# vrid 1            (Set VRID to 1)
>> VRRP Virtual Router 1# if 1              (Set interface 1)
>> VRRP Virtual Router 1# addr 192.168.1.200 (Define IPv4 address)
>> VRRP Virtual Router 1# ena               (Enable virtual router 1)
>> VRRP Virtual Router 1# ..               (Enable virtual router 1)
>> Virtual Router Redundancy Protocol# vr 2 (Select virtual router 2)
>> VRRP Virtual Router 2# vrid 2            (Set VRID to 2)
>> VRRP Virtual Router 2# if 2              (Set interface 2)
>> VRRP Virtual Router 2# addr 192.168.2.200 (Define IPv4 address)
>> VRRP Virtual Router 2# ena               (Enable virtual router 2)
```

4. Enable tracking on ports. Set the priority of Virtual Router 1 to 101, so that it becomes the Master.

```
/cfg/13/vrrp/vr 1 (Select VRRP virtual router 1)
>> VRRP Virtual Router 1# track/ports/ena (Set tracking on ports)
>> VRRP Virtual Router 1 Priority Tracking# ..
>> VRRP Virtual Router 1# prio 101 (Set the VRRP priority)
>> VRRP Virtual Router 1# ..
>> Virtual Router Redundancy Protocol# vr 2 (Select VRRP virtual router 2)
>> VRRP Virtual Router 1# track/ports/ena (Set tracking on ports)
```

5. Configure ports.

```
/cfg/12/vlan 10 (Select VLAN 10)
>> VLAN 10# ena (Enable VLAN 10)
>> VLAN 10# add ext1 (Add port EXT 1 to VLAN 10)
>> VLAN 10# ..
>> Layer 2# vlan 20 (Select VLAN 20)
>> VLAN 20# ena (Enable VLAN 20)
>> VLAN 20# add ext2 (Add port EXT 2 to VLAN 20)
```

6. Turn off Spanning Tree Protocol globally, then apply and save the configuration.

```
/cfg/12/stg 1/off (Turn off STG)
>> Spanning Tree Group 1# apply
>> Spanning Tree Group 1# save
```

## Task 2: Configure GbESM 2

### 1. Configure client and server interfaces.

```
/cfg/l3/if 1                                (Select interface 1)
>> IP Interface 1# addr 192.168.1.101      (Define IPv4 address for interface 1)
>> IP Interface 1# mask 255.255.255.0      (Define subnet mask for interface 1)
>> IP Interface 1# vlan 10                 (Assign VLAN 10 to interface 1)
>> IP Interface 1# ena                     (Enable interface 1)
>> IP Interface 1# ..
>> Layer 3# if 2                            (Select interface 2)
>> IP Interface 2# addr 192.168.2.100      (Define IPv4 address for interface 2)
>> IP Interface 2# mask 255.255.255.0      (Define subnet mask for interface 2)
>> IP Interface 2# vlan 20                 (Assign VLAN 20 to interface 2)
>> IP Interface 2# ena                     (Enable interface 2)
>> IP Interface 2# ..
>> Layer 3# if 3                            (Select interface 3)
>> IP Interface 3# addr 10.0.1.101         (Define IPv4 address for interface 3)
>> IP Interface 3# mask 255.255.255.0      (Define subnet mask for interface 3)
>> IP Interface 3# ena                     (Enable interface 3)
>> IP Interface 3# ..
>> Layer 3# if 4                            (Select interface 4)
>> IP Interface 4# addr 10.0.2.100         (Define IPv4 address for interface 4)
>> IP Interface 4# mask 255.255.255.0      (Define subnet mask for interface 4)
>> IP Interface 4# ena                     (Enable interface 4)
```

### 2. Configure the default gateways. Each default gateway points to a Layer 3 router.

```
/cfg/l3/gw 1                                (Select default gateway 1)
>> Default gateway 1# addr 192.168.2.1    (Point gateway to the first L3 router)
>> Default gateway 1# ena                  (Enable the default gateway)
>> Default gateway 1# ..
>> Layer 3# gw 2                            (Select default gateway 2)
>> Default gateway 2# addr 192.168.1.1    (Point gateway to the second router)
>> Default gateway 2# ena                  (Enable the default gateway)
```

### 3. Turn on VRRP and configure two Virtual Interface Routers.

```
/cfg/l3/vrrp/on                             (Turn VRRP on)
>> Virtual Router Redundancy Protocol# vr 1 (Select virtual router 1)
>> VRRP Virtual Router 1# vrid 1           (Set VRID to 1)
>> VRRP Virtual Router 1# if 1             (Set interface 1)
>> VRRP Virtual Router 1# addr 192.168.1.200 (Define IPv4 address)
>> VRRP Virtual Router 1# ena               (Enable virtual router 1)
>> VRRP Virtual Router 1# ..               (Enable virtual router 1)
>> Virtual Router Redundancy Protocol# vr 2 (Select virtual router 2)
>> VRRP Virtual Router 2# vrid 2           (Set VRID to 2)
>> VRRP Virtual Router 2# if 2             (Set interface 2)
>> VRRP Virtual Router 2# addr 192.168.2.200 (Define IPv4 address)
>> VRRP Virtual Router 2# ena               (Enable virtual router 2)
```

4. Enable tracking on ports. Set the priority of Virtual Router 2 to 101, so that it becomes the Master.

```
/cfg/13/vrrp/vr 1 (Select VRRP virtual router 1)
>> VRRP Virtual Router 1# track/ports/ena (Set tracking on ports)
>> VRRP Virtual Router 1 Priority Tracking# ..
>> VRRP Virtual Router 1# ..
>> Virtual Router Redundancy Protocol# vr 2 (Select VRRP virtual router 2)
>> VRRP Virtual Router 2# track/ports/ena (Set tracking on ports)
>> VRRP Virtual Router 2 Priority Tracking# ..
>> VRRP Virtual Router 2# prio 101 (Set the VRRP priority)
```

5. Configure ports.

```
/cfg/12/vlan 10 (Select VLAN 10)
>> VLAN 10# ena (Enable VLAN 10)
>> VLAN 10# add ext1 (Add port EXT 1 to VLAN 10)
>> VLAN 10# ..
>> Layer 2# vlan 20 (Select VLAN 20)
>> VLAN 20# ena (Enable VLAN 20)
>> VLAN 20# add ext2 (Add port EXT 2 to VLAN 20)
```

6. Turn off Spanning Tree Protocol globally, then apply and save changes.

```
/cfg/12/stg 1/off (Turn off STG)
>> Spanning Tree Group 1# apply
>> Spanning Tree Group 1# save
```

## Hot-Standby Configuration

The primary application for VRRP-based hot-standby is to support Network Adapter Teaming on your server blades. With Network Adapter Teaming, the NICs on each server share the same IPv4 address, and are configured into a team. One NIC is the primary link, and the others are backup links. For more details, refer to the NetXen 10 Gb Ethernet Adapter documentation.


A hot-standby configuration allows all processes to failover to a standby switch if any type of failure should occur. All Virtual Interface Routers (VIRs) are bundled into one Virtual Router group, and then they failover together. When there is a failure that causes the VRRP Master to failover to the Standby, then the original primary switch temporarily disables the internal server links, which, in turn, causes the NIC teams to failover as well.

**Note:** When using hot-standby redundancy, peer switches should have an equal number of connected ports.

If hot-standby is implemented in a looped environment, the hot-standby feature automatically disables the hot-standby ports on the VRRP Standby. If the Master switch should failover to the Standby switch, it would change the hot-standby ports from *disabled* to *forwarding*, without relying on Spanning Tree or manual intervention. Therefore, Spanning Tree must be disabled.

Figure 47 illustrates a common hot-standby implementation on a single blade server. Notice that the BladeCenter server NICs are configured into a team that shares the same IPv4 address across both NICs. Because only one link can be active at a time, the hot-standby feature controls the NIC failover by having the Standby switch disable its internal ports (holding down the server links).

Figure 47. Hot-Standby Configuration



## Task 1: Configure GbESM 1

1. On GbESM 1, configure the interfaces for clients (174.14.20.110) and servers (10.1.1.110).

```
/cfg/l3/if 1
>> IP Interface 1# addr 174.14.20.110      (Define IPv4 address for interface 1)
>> IP Interface 1# ena                    (Enable interface 1)
>> IP Interface 1# ..
>> Layer 3# if 2
>> IP Interface 2# addr 10.1.1.110        (Define IPv4 address for interface 2)
>> IP Interface 2# ena                    (Enable interface 2)
```

2. Configure Virtual Interface Routers.

```
/cfg/l3/vrrp/on      (Turn on VRRP)
>> Virtual Router Redundancy Protocol# vr 1 (Select Virtual Router 1)
>> VRRP Virtual Router 1# ena              (Enable VR 1)
>> VRRP Virtual Router 1# vrid 1           (Select the Virtual Router ID)
>> VRRP Virtual Router 1# if 1             (Select interface for VR 1)
>> VRRP Virtual Router 1# addr 174.14.20.100 (Define IPv4 address for VR 1)
>> VRRP Virtual Router 1# ..
>> Virtual Router Redundancy Protocol# vr 2 (Select Virtual Router 2)
>> VRRP Virtual Router 2# ena              (Enable VR 2)
>> VRRP Virtual Router 2# vrid 2           (Select the Virtual Router ID)
>> VRRP Virtual Router 2# if 2             (Select interface for VR 2)
>> VRRP Virtual Router 2# addr 10.1.1.100  (Define IPv4 address for VR 2)
```

3. Enable VRRP Hot Standby.

```
/cfg/l3/vrrp/hotstan ena      (Enable Hot Standby)
```

4. Configure VRRP Group parameters. Set the VRRP priority to 101, so that this switch is the Master.

```
/cfg/l3/vrrp/group
>> VRRP Virtual Router Group# ena          (Enable Virtual Router Group)
>> VRRP Virtual Router Group# vrid 1       (Set Virtual Router ID for Group)
>> VRRP Virtual Router Group# if 1         (Set interface for Group)
>> VRRP Virtual Router Group# prio 101     (Set VRRP priority to 101)
>> VRRP Virtual Router Group# track/ports ena (Enable tracking on ports)
```

5. Turn off Spanning Tree Protocol globally. Apply and save changes.

```
/cfg/l2/stg 1/off      (Turn off Spanning Tree)
>> Spanning Tree Group 1# apply            (Apply changes)
>> Spanning Tree Group 1# save
```

## Task 2: Configure GbESM 2

1. On GbESM 2, configure the interfaces for clients (174.14.20.111) and servers (10.1.1.111).

```
/cfg/13/if 1
>> IP Interface 1# addr 174.14.20.111      (Define IPv4 address for interface 1)
>> IP Interface 1# ena                      (Enable interface 1)
>> IP Interface 1# ..
>> Layer 3# if 2
>> IP Interface 2# addr 10.1.1.111         (Define IPv4 address for interface 2)
>> IP Interface 2# ena                     (Enable interface 2)
```

2. Configure Virtual Interface Routers.

```
/cfg/13/vrrp/on                                (Turn on VRRP)
>> Virtual Router Redundancy Protocol# vr 1    (Select Virtual Router 1)
>> VRRP Virtual Router 1# ena                  (Enable VR 1)
>> VRRP Virtual Router 1# vrid 1               (Select the Virtual Router ID)
>> VRRP Virtual Router 1# if 1                 (Select interface for VR 1)
>> VRRP Virtual Router 1# addr 174.14.20.100  (Define IPv4 address for VR 1)
>> VRRP Virtual Router 1# ..
>> Virtual Router Redundancy Protocol# vr 2    (Select Virtual Router 2)
>> VRRP Virtual Router 2# ena                  (Enable VR 2)
>> VRRP Virtual Router 2# vrid 2               (Select the Virtual Router ID)
>> VRRP Virtual Router 2# if 2                 (Select interface for VR 2)
>> VRRP Virtual Router 2# addr 10.1.1.100    (Define IPv4 address for VR 2)
```

3. Enable VRRP Hot Standby.

```
/cfg/13/vrrp/hotstan ena                      (Enable Hot Standby)
```

4. Configure VRRP Group parameters. Use the default VRRP priority of 100, so that this switch is the Standby.

```
/cfg/13/vrrp/group
>> VRRP Virtual Router Group# ena              (Enable Virtual Router Group)
>> VRRP Virtual Router Group# vrid 1           (Set Virtual Router ID for Group)
>> VRRP Virtual Router Group# if 1             (Set interface for Group)
>> VRRP Virtual Router Group# track/ports ena (Enable tracking on ports)
```

5. Turn off Spanning Tree Protocol globally. Apply and save changes.

```
/cfg/12/stg 1/off                             (Turn off Spanning Tree)
>> Spanning Tree Group 1# apply                (Apply changes)
>> Spanning Tree Group 1# save
```





# **Part 7: Network Management**



---

## Chapter 25. Link Layer Discovery Protocol

The IBM Networking OS software support Link Layer Discovery Protocol (LLDP). This chapter discusses the use and configuration of LLDP on the switch:

- [“LLDP Overview” on page 372](#)
- [“Enabling or Disabling LLDP” on page 373](#)
- [“LLDP Transmit Features” on page 374](#)
- [“LLDP Receive Features” on page 378](#)
- [“LLDP Example Configuration” on page 382](#)

---

## LLDP Overview

Link Layer Discovery Protocol (LLDP) is an IEEE 802.1AB-2005 standard for discovering and managing network devices. LLDP uses Layer 2 (the data link layer), and allows network management applications to extend their awareness of the network by discovering devices that are direct neighbors of already known devices.

With LLDP, the GbESM can advertise the presence of its ports, their major capabilities, and their current status to other LLDP stations in the same LAN. LLDP transmissions occur on ports at regular intervals or whenever there is a relevant change to their status. The switch can also receive LLDP information advertised from adjacent LLDP-capable network devices.

In addition to discovery of network resources, and notification of network changes, LLDP can help administrators quickly recognize a variety of common network configuration problems, such as unintended VLAN exclusions or mis-matched port aggregation membership.

The LLDP transmit function and receive function can be independently configured on a per-port basis. The administrator can allow any given port to transmit only, receive only, or both transmit and receive LLDP information.

The LLDP information to be distributed by the GbESM ports, and that which has been collected from other LLDP stations, is stored in the switch's Management Information Base (MIB). Network Management Systems (NMS) can use Simple Network Management Protocol (SNMP) to access this MIB information. LLDP-related MIB information is read-only.

Changes, either to the local switch LLDP information or to the remotely received LLDP information, are flagged within the MIB for convenient tracking by SNMP-based management systems.

For LLDP to provide expected benefits, all network devices that support LLDP should be consistent in their LLDP configuration.

### LLDP - Stacking Mode

In stacking mode, LLDP can be configured only on the ports that are not used to create the stack. The LLDP configuration menus on the stacking ports are disabled.

When configuring LLDP on a port, use the correct port syntax. See [“Stacking Port Numbers” on page 182](#).

---

## Enabling or Disabling LLDP

### Global LLDP Setting

By default, LLDP is enabled on the GbESM. To turn LLDP off or on, use the following commands:

>> # /cfg/l2/lldp/off	<i>(Turn LLDP off globally)</i>
<b>or</b>	
>> # /cfg/l2/lldp/on	<i>(Turn LLDP on globally)</i>

### Transmit and Receive Control

The GbESM can also be configured to transmit or receive LLDP information on a port-by-port basis. By default, when LLDP is globally enabled on the switch, GbESM ports transmit and receive LLDP information (see the `tx_rx` option below). To change the LLDP transmit and receive state, the following commands are available:

>> # /cfg/l2/lldp/port <n>	<i>(Select a switch port)</i>
>> LLDP Port# admstat tx_rx	<i>(Transmit and receive LLDP)</i>
>> LLDP Port# admstat tx_only	<i>(Only transmit LLDP)</i>
>> LLDP Port# admstat rx_only	<i>(Only receive LLDP)</i>
>> LLDP Port# admstat disabled	<i>(Do not participate in LLDP)</i>

To view the LLDP transmit and receive status, use the following commands:

>> # /cfg/l2/lldp/cur	<i>(View LLDP status of all ports)</i>
<b>or</b>	
>> # /cfg/l2/lldp/port <n>/cur	<i>(View status of the selected port)</i>

---

## LLDP Transmit Features

Numerous LLDP transmit options are available, including scheduled and minimum transmit interval, expiration on remote systems, SNMP trap notification, and the types of information permitted to be shared.

**Note:** In stacking mode, only the stack Master transmits LLDP information for all the ports in a stack. The stack MAC address is used as the source address in the LLDP packets.

### Scheduled Interval

The GbESM can be configured to transmit LLDP information to neighboring devices once each 5 to 32768 seconds. The scheduled interval is global; the same interval value applies to all LLDP transmit-enabled ports. However, to help balance LLDP transmissions and keep them from being sent simultaneously on all ports, each port maintains its own interval clock, based on its own initialization or reset time. This allows switch-wide LLDP transmissions to be spread out over time, though individual ports comply with the configured interval.

The global transmit interval can be configured using the following command:

```
>> # /cfg/12/lldp/msgtxint <interval>
```

where *interval* is the number of seconds between LLDP transmissions. The range is 5 to 32768. The default is 30 seconds.

### Minimum Interval

In addition to sending LLDP information at scheduled intervals, LLDP information is also sent when the GbESM detects relevant changes to its configuration or status (such as when ports are enabled or disabled). To prevent the GbESM from sending multiple LLDP packets in rapid succession when port status is in flux, a transmit delay timer can be configured.

The transmit delay timer represents the minimum time permitted between successive LLDP transmissions on a port. Any interval-driven or change-driven updates will be consolidated until the configured transmit delay expires.

The minimum transmit interval can be configured using the following command:

```
>> # /cfg/12/lldp/txdelay <interval>
```

where *interval* is the minimum number of seconds permitted between successive LLDP transmissions on any port. The range is 1 to one-quarter of the scheduled transmit interval (*msgtxint*), up to 8192. The default is 2 seconds.

### Time-to-Live for Transmitted Information

The transmitted LLDP information is held by remote systems for a limited time. A time-to-live parameter allows the switch to determine how long the transmitted data should be held before it expires. The hold time is configured as a multiple of the configured transmission interval.

```
>> # /cfg/12/lldp/msgtxhld <multiplier>
```

where *multiplier* is a value between 2 and 10. The default value is 4, meaning that remote systems will hold the port's LLDP information for 4 x the 30-second *msgtxint* value, or 120 seconds, before removing it from their MIB.

## Trap Notifications

If SNMP is enabled on the GbESM (see [“Using Simple Network Management Protocol” on page 37](#)), each port can be configured to send SNMP trap notifications whenever:

- An invalid LLDP Data Unit (LLDPDU) is received on a port.
- The Media Service Access Point (MSAP) for a port ages out.
- New MSAP is learnt on a port.

By default, trap notification is disabled for each port. The trap notification state can be changed using the following commands:

```
>> # /cfg/l2/lldp/port <n>/snmptrap ena      (Send SNMP trap notifications)
      or
>> # /cfg/l2/lldp/port <n>/snmptrap dis      (Do not send trap notifications)
```

In addition to sending LLDP information at scheduled intervals, LLDP information is also sent when the GbESM detects relevant changes to its configuration or status (such as when ports are enabled or disabled). To prevent the GbESM from sending multiple trap notifications in rapid succession when port status is in flux, a global trap delay timer can be configured.

The trap delay timer represents the minimum time permitted between successive trap notifications on any port. Any interval-driven or change-driven trap notices from the port will be consolidated until the configured trap delay expires.

The minimum trap notification interval can be configured using the following command:

```
>> # /cfg/l2/lldp/notifint <interval>
```

where *interval* is the minimum number of seconds permitted between successive LLDP transmissions on any port. The range is 1 to 3600. The default is 5 seconds.

If SNMP trap notification is enabled, the notification messages can also appear in the system log. This is enabled by default. To change whether the SNMP trap notifications for LLDP events appear in the system log, use the following commands:

```
>> # /cfg/sys/syslog/log lldp ena      (Add LLDP notification to Syslog)
      or
>> # /cfg/sys/syslog/log lldp dis      (Do not log LLDP notifications)
```

## Changing the LLDP Transmit State

When the port is disabled, or when LLDP transmit is turned off for the port using the `admstat` command's `rx_only` or `disabled` options (see [“Transmit and Receive Control” on page 373](#)), a final LLDP packet is transmitted with a time-to-live value of 0. Neighbors that receive this packet will remove the LLDP information associated with the GbESM port from their MIB.

In addition, if LLDP is fully disabled on a port (using `admstat disabled`) and later re-enabled, the GbESM will temporarily delay resuming LLDP transmissions on the port in order to allow the port LLDP information to stabilize. The reinitialization delay interval can be globally configured for all ports using the following command:

```
>> # /cfg/12/1ldp/reldelay <interval>
```

where *interval* is the number of seconds to wait before resuming LLDP transmissions. The range is between 1 and 10. The default is 2 seconds.

## Types of Information Transmitted

When LLDP transmission is permitted on the port (see [“Enabling or Disabling LLDP” on page 373](#)), the port advertises the following required information in type/length/value (TLV) format:

- Chassis ID
- Port ID
- LLDP Time-to-Live

LLDP transmissions can also be configured to enable or disable inclusion of optional information, using the following command:

```
>> # /cfg/12/1ldp/port <n>/tlv/<type> {ena|dis}
```

where *type* is an LLDP information option from [Table 24](#):

Table 24. LLDP Optional Information Types

Type	Description	Default
portdesc	Port Description	Enabled
sysname	System Name	Enabled
sysdescr	System Description	Enabled
syscap	System Capabilities	Enabled
mgmtaddr	Management Address	Enabled
portvid	IEEE 802.1 Port VLAN ID	Disabled
portprot	IEEE 802.1 Port and Protocol VLAN ID	Disabled
vlanname	IEEE 802.1 VLAN Name	Disabled
protid	IEEE 802.1 Protocol Identity	Disabled



Table 24. LLDP Optional Information Types (continued)

Type	Description	Default
macphy	IEEE 802.3 MAC/PHY Configuration/Status, including the auto-negotiation, duplex, and speed status of the port.	Disabled
powermdi	IEEE 802.3 Power via MDI, indicating the capabilities and status of devices that require or provide power over twisted-pair copper links.	Disabled
linkaggr	IEEE 802.3 Link Aggregation status for the port.	Disabled
framesz	IEEE 802.3 Maximum Frame Size for the port.	Disabled
all	Select all optional LLDP information for inclusion or exclusion.	Disabled

---

## LLDP Receive Features

### Types of Information Received

When the LLDP receive option is enabled on a port (see [“Enabling or Disabling LLDP” on page 373](#)), the port may receive the following information from LLDP-capable remote systems:

- Chassis Information
- Port Information
- LLDP Time-to-Live
- Port Description
- System Name
- System Description
- System Capabilities Supported/Enabled
- Remote Management Address

The GbESM stores the collected LLDP information in the MIB. Each remote LLDP-capable device is responsible for transmitting regular LLDP updates. If the received updates contain LLDP information changes (to port state, configuration, LLDP MIB structures, deletion), the switch will set a change flag within the MIB for convenient notification to SNMP-based management systems.

**Note:** In stacking mode, both the Master and the Backup receive LLDP information for all the ports in a stack and update the LLDP table. The Master and Backup switches synchronize the LLDP tables.

### Viewing Remote Device Information

LLDP information collected from neighboring systems can be viewed in numerous ways:

- Using a centrally-connected LLDP analysis server
- Using an SNMP agent to examine the GbESM MIB
- Using the GbESM Browser-Based Interface (BBI)
- Using CLI or isCLI commands on the GbESM

Using the CLI the following command displays remote LLDP information:

```
>> # /info/12/11dp/remodev [<index number>]
```

To view a summary of remote information, omit the *Index number* parameter. For example:

```
>> # /info/12/11dp/remodev
LLDP Remote Devices Information
```

LocalPort	Index	Remote Chassis ID	Remote Port	Remote System Name
EXT3	1	00 18 b1 33 1d 00	23	

To view detailed information for a remote device, specify the *Index number* as found in the summary. For example, in keeping with the sample summary, to list details for the first remote device (with an Index value of 1), use the following command:

```
>> # /info/12/11dp/remodev 1
Local Port Alias: EXT3
    Remote Device Index      : 1
    Remote Device TTL        : 99
    Remote Device RxChanges  : false
    Chassis Type             : Mac Address
    Chassis Id               : 00-18-b1-33-1d-00
    Port Type                : Locally Assigned
    Port Id                  : 23
    Port Description         : EXT7

    System Name              :
    System Description       : IBM Networking Operating System 1/10Gb Uplink
    Ethernet Switch Module for IBM BladeCenter, IBM Networking OS: version 7.4, Boot
    Image: version 6.9.1.14

    System Capabilities Supported : bridge, router
    System Capabilities Enabled   : bridge, router

    Remote Management Address:
        Subtype                 : IPv4
        Address                  : 10.100.120.181
        Interface Subtype       : ifIndex
        Interface Number        : 128
        Object Identifier       :
```

**Note:** Received LLDP information can change very quickly. When using `/info/12/11ddp/rx` or `/info/12/11dp/remodev` commands, it is possible that flags for some expected events may be too short-lived to be observed in the output.

To view detailed information of all remote devices, use the following command:

```
>> # /info/12/11dp/remodev detail
Local Port Alias: MGTA
    Remote Device Index      : 1
    Remote Device TTL       : 4678
    Remote Device RxChanges  : false
    Chassis Type            : Mac Address
    Chassis Id              : 08-17-f4-a1-db-00
    Port Type               : Locally Assigned
    Port Id                 : 25
    Port Description        : MGTA

    System Name             :
    System Description      : IBM Networking Operating System 1/10Gb
Uplink Ethernet Switch Module for IBM BladeCenter, IBM Networking OS: version 7.4,
Boot Image: version 6.9.1.14
    System Capabilities Supported : bridge, router
    System Capabilities Enabled   : bridge, router

    Remote Management Address:
        Subtype                : IPv4
        Address                 : 10.38.22.23
        Interface Subtype       : ifIndex
        Interface Number        : 127
        Object Identifier       :

Local Port Alias: 2
    Remote Device Index      : 2
    Remote Device TTL       : 4651
    Remote Device RxChanges  : false
    Chassis Type            : Mac Address
    Chassis Id              : 08-17-f4-a1-db-00
    Port Type               : Locally Assigned
    Port Id                 : 2
    Port Description        : 2

    System Name             :
    System Description      : IBM Networking Operating System 1/10Gb
Uplink Ethernet Switch Module for IBM BladeCenter, IBM Networking OS: version 7.4,
Boot Image: version 6.9.1.14
    System Capabilities Supported : bridge, router
    System Capabilities Enabled   : bridge, router

    Remote Management Address:
        Subtype                : IPv4
        Address                 : 10.38.22.23
        Interface Subtype       : ifIndex
        Interface Number        : 127
        Object Identifier       :

Total entries displayed: 2
```

## Time-to-Live for Received Information

Each remote device LLDP packet includes an expiration time. If the switch port does not receive an LLDP update from the remote device before the time-to-live clock expires, the switch will consider the remote information to be invalid, and will remove all associated information from the MIB.

Remote devices can also intentionally set their LLDP time-to-live to 0, indicating to the switch that the LLDP information is invalid and should be immediately removed.

---

## LLDP Example Configuration

1. Turn LLDP on globally.

```
>> # /cfg/12/11dp/on
```

2. Set the global LLDP timer features.

```
>> LLDP# msgtxint 30           (Schedule transmit every 30 seconds)
>> LLDP# txdelay 2             (Never more often than 2 seconds)
>> LLDP# msgtxhld 4            (Hold on remote side for 4 intervals)
>> LLDP# redelay 2             (Wait 2 seconds after reinitialization)
>> LLDP# notifint 5            (Minimum 5 seconds between traps)
```

3. Set LLDP options for each port.

```
>> LLDP# port <n>              (Select a switch port)
>> LLDP Port# admstat tx_rx     (Transmit and receive LLDP)
>> LLDP Port# snmptrap ena      (Enable SNMP trap notifications)
>> LLDP Port# tlv/all ena       (Transmit all optional information)
```

4. Enable syslog reporting.

```
>> # /cfg/sys/syslog/log 11dp ena
```

5. Apply and Save the configuration.

6. Verify the configuration settings:

```
>> # /cfg/12/11dp/cur
```

7. View remote device information as needed.

```
>> # /info/12/11dp/remodev
or
>> # /info/12/11dp/remodev <index number>
or
>> # /info/12/11dp/remodev detail
```

---

## Chapter 26. Simple Network Management Protocol

IBM Networking OS provides Simple Network Management Protocol (SNMP) version 1, version 2, and version 3 support for access through any network management software, such as IBM Director or HP-OpenView.

---

## SNMP Version 1

To access the SNMP agent on the GbESM, the read and write community strings on the SNMP manager should be configured to match those on the switch. The default read community string on the switch is `public` and the default write community string is `private`.

The read and write community strings on the switch can be changed using the following commands on the CLI:

```
>> # /cfg/sys/ssnmp/rcomm <1-32 characters>
      -and-
>> # /cfg/sys/ssnmp/wcomm <1-32 characters>
```

The SNMP manager should be able to reach the management interface or any one of the IP interfaces on the switch.

For the SNMP manager to receive the SNMPv1 traps sent out by the SNMP agent on the switch, configure the trap host on the switch with the following command:

```
>> # /cfg/sys/ssnmp/trsrc <trap source IP interface>
>> SNMP# thostadd <IPv4 address> <trap host community string>
```

**Note:** You can use a loopback interface to set the source IP address for SNMP traps. Use the following command to apply a configured loopback interface:

```
>> # /cfg/sys/ssnmp/trloopif <0-5>
```



---

## SNMP Version 3

SNMP version 3 (SNMPv3) is an enhanced version of the Simple Network Management Protocol, approved by the Internet Engineering Steering Group in March, 2002. SNMPv3 contains additional security and authentication features that provide data origin authentication, data integrity checks, timeliness indicators and encryption to protect against threats such as masquerade, modification of information, message stream modification and disclosure.

SNMPv3 allows clients to query the MIBs securely.

SNMPv3 configuration is managed using the following menu:

```
>> # /cfg/sys/ssnmp/snmpv3
```

For more information on SNMP MIBs and the commands used to configure SNMP on the switch, see the *IBM Networking OS 7.4 Command Reference*.

### Default Configuration

IBM N/OS has two SNMPv3 users by default. Both of the following users have access to all the MIBs supported by the switch:

- User 1 name is `adminmd5` (password `adminmd5`). Authentication used is MD5.
- User 2 name is `adminsha` (password `adminsha`). Authentication used is SHA.

**Up to 16 SNMP users can be configured on the switch. To modify an SNMP user, enter the following commands:**

```
>> # /cfg/sys/ssnmp/snmpv3/usm <user number (1-16)>
>> SNMPv3 usmUser# name <user name (1-32 characters)>
>> SNMPv3 usmUser# authpw <user password>
```

Users can be configured to use the authentication/privacy options. The GbESM support two authentication algorithms: MD5 and SHA, as specified in the following command:

```
>> SNMPv3 usmUser# auth {md5 | sha | none }
```

## User Configuration Example

1. To configure a user with name “admin,” authentication type MD5, and authentication password of “admin,” privacy option DES with privacy password of “admin,” use the following CLI commands.

```
>> # /cfg/sys/ssnmp/snmpv3/usm 5
>> SNMPv3 usmUser 5# name "admin"           (Configure 'admin' user type)
>> SNMPv3 usmUser 5# auth md5
>> SNMPv3 usmUser 5# authpw admin
>> SNMPv3 usmUser 5# priv des
>> SNMPv3 usmUser 5# privpw admin
```

2. Configure a user access group, along with the views the group may access. Use the access table to configure the group's access level.

```
>> # /cfg/sys/ssnmp/snmpv3/access 5
>> SNMPv3 vacmAccess 5# name "admingrp"      (Configure an access group)
>> SNMPv3 vacmAccess 5# level authPriv
>> SNMPv3 vacmAccess 5# rview "iso"
>> SNMPv3 vacmAccess 5# wview "iso"
>> SNMPv3 vacmAccess 5# nview "iso"
```

Because the read view (rview), write view (wview), and notify view (nview) are all set to “iso,” the user type has access to all private and public MIBs.

3. Assign the user to the user group. Use the group table to link the user to a particular access group.

```
>> # /cfg/sys/ssnmp/snmpv3/group 5
>> SNMPv3 vacmSecurityToGroup 5# uname admin
>> SNMPv3 vacmSecurityToGroup 5# gname admingrp
```

If you want to allow user access only to certain MIBs, see “View-Based Configuration,” next.

## View-Based Configurations

- Switch User equivalent

To configure an SNMP user equivalent to the switch “user” login, use the following configuration:

```
/c/sys/ssnmp/snmpv3/usm 4           (Configure the user)
    name "usr"
/c/sys/ssnmp/snmpv3/access 3        (Configure access group 3)
    name "usrgrp"
    rview "usr"
    wview "usr"
    nview "usr"
/c/sys/ssnmp/snmpv3/group 4         (Assign user to access group 3)
    uname usr
    gname usrgrp
/c/sys/ssnmp/snmpv3/view 6          (Create views for user)
    name "usr"
    tree "1.3.6.1.4.1.1872.2.5.1.2" (Agent statistics)
/c/sys/ssnmp/snmpv3/view 7
    name "usr"
    tree "1.3.6.1.4.1.1872.2.5.1.3" (Agent information)
/c/sys/ssnmp/snmpv3/view 8
    name "usr"
    tree "1.3.6.1.4.1.1872.2.5.2.2" (L2 statistics)
/c/sys/ssnmp/snmpv3/view 9
    name "usr"
    tree "1.3.6.1.4.1.1872.2.5.2.3" (L2 information)
/c/sys/ssnmp/snmpv3/view 10
    name "usr"
    tree "1.3.6.1.4.1.1872.2.5.3.2" (L3 statistics)
/c/sys/ssnmp/snmpv3/view 11
    name "usr"
    tree "1.3.6.1.4.1.1872.2.5.3.3" (L3 information)
```

- Switch Oper equivalent

/c/sys/ssnmp/snmpv3/usm 5 name "oper"	(Configure the oper)
/c/sys/ssnmp/snmpv3/access 4 name "opergrp" rview "oper" wview "oper" nview "oper"	(Configure access group 4)
/c/sys/ssnmp/snmpv3/group 4 uname oper gname opergrp	(Assign oper to access group 4)
/c/sys/ssnmp/snmpv3/view 20 name "usr" tree "1.3.6.1.4.1.1872.2.5.1.2"	(Create views for oper) (Agent statistics)
/c/sys/ssnmp/snmpv3/view 21 name "usr" tree "1.3.6.1.4.1.1872.2.5.1.3"	(Agent information)
/c/sys/ssnmp/snmpv3/view 22 name "usr" tree "1.3.6.1.4.1.1872.2.5.2.2"	(L2 statistics)
/c/sys/ssnmp/snmpv3/view 23 name "usr" tree "1.3.6.1.4.1.1872.2.5.2.3"	(L2 information)
/c/sys/ssnmp/snmpv3/view 24 name "usr" tree "1.3.6.1.4.1.1872.2.5.3.2"	(L3 statistics)
/c/sys/ssnmp/snmpv3/view 25 name "usr" tree "1.3.6.1.4.1.1872.2.5.3.3"	(L3 information)

---

## Configuring SNMP Trap Hosts

### SNMPv1 Trap Host

1. Configure a user with no authentication and password.

```
>> # /cfg/sys/ssnmp/snmpv3/usm 10/name "v1trap"
```

2. Configure an access group and group table entries for the user. Use the following menu to specify which traps can be received by the user:

```
>> # /cfg/sys/ssnmp/snmpv3/access <user number>
```

In the example below the user will receive the traps sent by the switch.

```
/c/sys/ssnmp/snmpv3/access 10           (Access group to view SNMPv1 traps)
  name "v1trap"
  model snmpv1
  nview "iso"
/c/sys/ssnmp/snmpv3/group 10           (Assign user to the access group)
  model snmpv1
  uname v1trap
  gname v1trap
```

3. Configure an entry in the notify table.

```
/c/sys/ssnmp/snmpv3/notify 10          (Assign user to the notify table)
  name v1trap
  tag v1trap
```

4. Specify the IPv4 address and other trap parameters in the `targetAddr` and `targetParam` tables. Use the following menus to specify the user name associated with the `targetParam` table:

```
/c/sys/ssnmp/snmpv3/taddr 10           (Define an IP address to send traps)
  name v1trap
  addr 47.80.23.245
  taglist v1trap
  pname vlparam
/c/sys/ssnmp/snmpv3/tparam 10          (Specify SNMPv1 traps to send)
  name vlparam
  mpmodel snmpv1
  uname v1trap
  model snmpv1
```

**Note:** N/OS 7.4 supports only IPv4 addresses for SNMP trap hosts.

5. Use the community table to specify which community string is used in the trap.

```
/c/sys/ssnmp/snmpv3/comm 10           (Define the community string)
  index v1trap
  name public
  uname v1trap
```

## SNMPv2 Trap Host Configuration

The SNMPv2 trap host configuration is similar to the SNMPv1 trap host configuration. Wherever you specify the model, use `snmpv2` instead of `snmpv1`.

```
/c/sys/ssnmp/snmpv3/usm 10           (Configure user named "v2trap")
    name "v2trap"
/c/sys/ssnmp/snmpv3/access 10        (Access group to view SNMPv2 traps)
    name "v2trap"
    model snmpv2
    nview "iso"
/c/sys/ssnmp/snmpv3/group 10         (Assign user to the access group)
    model snmpv2
    uname v2trap
    gname v2trap
/c/sys/ssnmp/snmpv3/notify 10        (Assign user to the notify table)
    name v2trap
    tag v2trap
/c/sys/ssnmp/snmpv3/taddr 10         (Define an IP address to send traps)
    name v2trap
    addr 47.81.25.66
    taglist v2trap
    pname v2param
/c/sys/ssnmp/snmpv3/tparam 10        (Specify SNMPv2 traps to send)
    name v2param
    mpmodel snmpv2c
    uname v2trap
    model snmpv2
/c/sys/ssnmp/snmpv3/comm 10          (Define the community string)
    index v2trap
    name public
    uname v2trap
```

**Note:** N/OS 7.4 supports only IPv4 addresses for SNMP trap hosts.

## SNMPv3 Trap Host Configuration

To configure a user for SNMPv3 traps, you can choose to send the traps with both privacy and authentication, with authentication only, or without privacy or authentication.

This is configured in the access table using the following commands:

```
>> # /cfg/sys/ssnmp/snmpv3/access <1-32>/level  
>> # /cfg/sys/ssnmp/snmpv3/tparam <1-16>
```

Configure the user in the user table accordingly.

It is not necessary to configure the community table for SNMPv3 traps because the community string is not used by SNMPv3.

The following example shows how to configure a SNMPv3 user v3trap with authentication only:

```
/c/sys/ssnmp/snmpv3/usm 11                (Configure user named "v3trap")  
    name "v3trap"  
    auth md5  
    authpw v3trap  
/c/sys/ssnmp/snmpv3/access 11              (Access group to view SNMPv3 traps)  
    name "v3trap"  
    level authNoPriv  
    nview "iso"  
/c/sys/ssnmp/snmpv3/group 11               (Assign user to the access group)  
    uname v3trap  
    gname v3trap  
/c/sys/ssnmp/snmpv3/notify 11              (Assign user to the notify table)  
    name v3trap  
    tag v3trap  
/c/sys/ssnmp/snmpv3/taddr 11               (Define an IP address to send traps)  
    name v3trap  
    addr 47.81.25.66  
    taglist v3trap  
    pname v3param  
/c/sys/ssnmp/snmpv3/tparam 11              (Specify SNMPv3 traps to send)  
    name v3param  
    uname v3trap  
    level authNoPriv                       (Set the authentication level)
```

**Note:** N/OS 7.4 supports only IPv4 addresses for SNMP trap hosts.

---

## SNMP MIBs

The N/OS SNMP agent supports SNMP version 3. Security is provided through SNMP community strings. The default community strings are “public” for SNMP GET operation and “private” for SNMP SET operation. The community string can be modified only through the Command Line Interface (CLI). Detailed SNMP MIBs and trap definitions of the N/OS SNMP agent are contained in the following N/OS enterprise MIB document:

GbESM-10Ub-L2L3.mib

The N/OS SNMP agent supports the following standard MIBs:

- dot1x.mib
- ieee8021ab.mib
- ieee8023ad.mib
- rfc1213.mib
- rfc1215.mib
- rfc1493.mib
- rfc1573.mib
- rfc1643.mib
- rfc1657.mib
- rfc1757.mib
- rfc1850.mib
- rfc1907.mib
- rfc2037.mib
- rfc2233.mib
- rfc2465.mib
- rfc2571.mib
- rfc2572.mib
- rfc2573.mib
- rfc2574.mib
- rfc2575.mib
- rfc2576.mib
- rfc2790.mib
- rfc3176.mib
- rfc4133.mib
- rfc4363.mib

The N/OS SNMP agent supports the following generic traps as defined in RFC 1215:

- ColdStart
- WarmStart
- LinkDown
- LinkUp
- AuthenticationFailure

The SNMP agent also supports two Spanning Tree traps as defined in RFC 1493:

- NewRoot
- TopologyChange



The following are the enterprise SNMP traps supported in N/OS:

**Table 25. IBM N/OS-Supported Enterprise SNMP Traps**

Trap Name	Description
altSwDefGwUp	Signifies that the default gateway is alive.
altSwDefGwDown	Signifies that the default gateway is down.
altSwDefGwInService	Signifies that the default gateway is up and in service
altSwDefGwNotInService	Signifies that the default gateway is alive but not in service
altSwVrrpNewMaster	Indicates that the sending agent has transitioned to "Master" state.
altSwVrrpNewBackup	Indicates that the sending agent has transitioned to "Backup" state.
altSwVrrpAuthFailure	Signifies that a packet has been received from a router whose authentication key or authentication type conflicts with this router's authentication key or authentication type. Implementation of this trap is optional.
altSwLoginFailure	Signifies that someone failed to enter a valid username/password combination.
altSwTempExceedThreshold	Signifies that the switch temperature has exceeded maximum safety limits.
altSwTempReturnThreshold	Signifies that the switch temperature has returned below maximum safety limits.
altSwStgNewRoot	Signifies that the bridge has become the new root of the STG.
altSwStgTopologyChanged	Signifies that there was a STG topology change.
altSwStgBlockingState	An altSwStgBlockingState trap is sent when port state is changed in blocking state.
altSwCistNewRoot	Signifies that the bridge has become the new root of the CIST.
altSwCistTopologyChanged	Signifies that there was a CIST topology change.
altSwHotlinksMasterUp	Signifies that the Master interface is active.
altSwHotlinksMasterDn	Signifies that the Master interface is not active.
altSwHotlinksBackupUp	Signifies that the Backup interface is active.
altSwHotlinksBackupDn	Signifies that the Backup interface is not active.

*Table 25. IBM N/OS-Supported Enterprise SNMP Traps (continued)*

Trap Name	Description
altSwHotlinksNone	Signifies that there are no active interfaces.
altSwValidLogin	Signifies that a user login has occurred.
altSwValidLogout	Signifies that a user logout has occurred.
altSwNtpNotServer	An altSwNtpNotServer trap is sent when cannot contact primary or secondary NTP server.
altSwNtpUpdateClock	An altSwNtpUpdateClock trap is sent when received NTP update.

---

## Switch Images and Configuration Files

This section describes how to use MIB calls to work with switch images and configuration files. You can use a standard SNMP tool to perform the actions, using the MIBs listed in [Table 26](#).

[Table 26](#) lists the MIBs used to perform operations associated with the Switch Image and Configuration files.

*Table 26. MIBs for Switch Image and Configuration Files*

MIB Name	MIB OID
agTransferServer	1.3.6.1.4.26543.2.5.1.1.7.1.0
agTransferImage	1.3.6.1.4.26543.2.5.1.1.7.2.0
agTransferImageFileName	1.3.6.1.4.26543.2.5.1.1.7.3.0
agTransferCfgFileName	1.3.6.1.4.26543.2.5.1.1.7.4.0
agTransferDumpFileName	1.3.6.1.4.26543.2.5.1.1.7.5.0
agTransferAction	1.3.6.1.4.26543.2.5.1.1.7.6.0
agTransferLastActionStatus	1.3.6.1.4.26543.2.5.1.1.7.7.0
agTransferUserName	1.3.6.1.4.26543.2.5.1.1.7.9.0
agTransferPassword	1.3.6.1.4.1.26543.2.5.1.1.7.10.0
agTransferTSDumpFileName	1.3.6.1.4.1.26543.2.5.1.1.7.11.0

The following SNMP actions can be performed using the MIBs listed in [Table 26](#).

- Load a new Switch image (boot or running) from a FTP/TFTP server
- Load a previously saved switch configuration from a FTP/TFTP server
- Save the switch configuration to a FTP/TFTP server
- Save a switch dump to a FTP/TFTP server

## Loading a New Switch Image

To load a new switch image with the name "MyNewImage-1.img" into image2, follow the steps below. This example shows an FTP/TFTP server at IPv4 address 192.168.10.10, though IPv6 is also supported.

1. Set the FTP/TFTP server address where the switch image resides:

```
Set agTransferServer.0 "192.168.10.10"
```

2. Set the area where the new image will be loaded:

```
Set agTransferImage.0 "image2"
```

3. Set the name of the image:

```
Set agTransferImageFileName.0 "MyNewImage-1.img"
```

4. If you are using an FTP server, enter a username:

```
Set agTransferUserName.0 "MyName"
```

5. If you are using an FTP server, enter a password:

```
Set agTransferPassword.0 "MyPassword"
```

6. Initiate the transfer. To transfer a switch image, enter 2 (gting):

```
Set agTransferAction.0 "2"
```

## Loading a Saved Switch Configuration

To load a saved switch configuration with the name "MyRunningConfig.cfg" into the switch, follow the steps below. This example shows a TFTP server at IPv4 address 192.168.10.10, though IPv6 is also supported.

1. Set the FTP/TFTP server address where the switch Configuration File resides:

```
Set agTransferServer.0 "192.168.10.10"
```

2. Set the name of the configuration file:

```
Set agTransferCfgFileName.0 "MyRunningConfig.cfg"
```

3. If you are using an FTP server, enter a username:

```
Set agTransferUserName.0 "MyName"
```

4. If you are using an FTP server, enter a password:

```
Set agTransferPassword.0 "MyPassword"
```

5. Initiate the transfer. To restore a running configuration, enter 3:

```
Set agTransferAction.0 "3"
```

## Saving the Switch Configuration

To save the switch configuration to a FTP/TFTP server follow the steps below. This example shows a FTP/TFTP server at IPv4 address 192.168.10.10, though IPv6 is also supported.

1. Set the FTP/TFTP server address where the configuration file is saved:  
`Set agTransferServer.0 "192.168.10.10"`
2. Set the name of the configuration file:  
`Set agTransferCfgFileName.0 "MyRunningConfig.cfg"`
3. If you are using an FTP server, enter a username:  
`Set agTransferUserName.0 "MyName"`
4. If you are using an FTP server, enter a password:  
`Set agTransferPassword.0 "MyPassword"`
5. Initiate the transfer. To save a running configuration file, enter 4:  
`Set agTransferAction.0 "4"`

## Saving a Switch Dump

To save a switch dump to a FTP/TFTP server, follow the steps below. This example shows an FTP/TFTP server at 192.168.10.10, though IPv6 is also supported.

1. Set the FTP/TFTP server address where the configuration will be saved:  
`Set agTransferServer.0 "192.168.10.10"`
2. Set the name of dump file:  
`Set agTransferDumpFileName.0 "MyDumpFile.dmp"`
3. If you are using an FTP server, enter a username:  
`Set agTransferUserName.0 "MyName"`
4. If you are using an FTP server, enter a password:  
`Set agTransferPassword.0 "MyPassword"`
5. Initiate the transfer. To save a dump file, enter 5:  
`Set agTransferAction.0 "5"`



# Part 8: Monitoring

The ability to monitor traffic passing through the GbESM can be invaluable for troubleshooting some types of networking problems. This sections cover the following monitoring features:

- Remote Monitoring (RMON)
- sFLOW
- Port Mirroring





---

## Chapter 27. Remote Monitoring

Remote Monitoring (RMON) allows network devices to exchange network monitoring data.

RMON performs the following major functions:

- Gathers cumulative statistics for Ethernet interfaces
- Tracks a history of statistics for Ethernet interfaces
- Creates and triggers alarms for user-defined events

---

## RMON Overview

The RMON MIB provides an interface between the RMON agent on the switch and an RMON management application. The RMON MIB is described in RFC 1757.

The RMON standard defines objects that are suitable for the management of Ethernet networks. The RMON agent continuously collects statistics and proactively monitors switch performance. RMON allows you to monitor traffic flowing through the switch.

The switch supports the following RMON Groups, as described in RFC 1757:

- Group 1: Statistics
- Group 2: History
- Group 3: Alarms
- Group 9: Events

---

## RMON Group 1—Statistics

The switch supports collection of Ethernet statistics as outlined in the RMON statistics MIB, in reference to `etherStatsTable`. You can enable RMON statistics on a per-port basis, and you can view them using the following command:

`/stat/port <x>/rmon`. RMON statistics are sampled every second, and new data overwrites any old data on a given port.

**Note:** RMON port statistics must be enabled for the port before you can view RMON statistics.

To configure RMON Statistics:

1. Enable RMON on each port where you wish to collect RMON statistics.

```
>> # /cfg/port 23/rmon                (Select Port 23 RMON)
>> Port 23 RMON# ena                  (Enable RMON)
>> Port 23 RMON# apply                 (Make your changes active)
>> Port 23 RMON# save                  (Save for restore after reboot)
```

2. View RMON statistics for the port.

```
>> # /stats/port 23                    (Select Port 23 Stats)
>> Port Statistics# rmon
-----
RMON statistics for port 23:
etherStatsDropEvents:                NA
etherStatsOctets:                    7305626
etherStatsPkts:                      48686
etherStatsBroadcastPkts:             4380
etherStatsMulticastPkts:             6612
etherStatsCRCAlignErrors:            22
etherStatsUndersizePkts:             0
etherStatsOversizePkts:             0
etherStatsFragments:                2
etherStatsJabbers:                  0
etherStatsCollisions:                0
etherStatsPkts64Octets:              27445
etherStatsPkts65to127Octets:         12253
etherStatsPkts128to255Octets:        1046
etherStatsPkts256to511Octets:        619
etherStatsPkts512to1023Octets:       7283
etherStatsPkts1024to1518Octets:      38
```

---

## RMON Group 2—History

The RMON History Group allows you to sample and archive Ethernet statistics for a specific interface during a specific time interval.

**Note:** RMON port statistics must be enabled for the port before an RMON history group can monitor the port.

Data is stored in buckets, which store data gathered during discreet sampling intervals. At each configured interval, the history instance takes a sample of the current Ethernet statistics, and places them into a bucket. History data buckets reside in dynamic memory. When the switch is re-booted, the buckets are emptied.

Requested buckets (`/cfg/rmon/hist <x>/rbnum`) are the number of buckets, or data slots, requested by the user for each History Group. Granted buckets (`/info/rmon/hist <x>/gbnum`) are the number of buckets granted by the system, based on the amount of system memory available. The system grants a maximum of 50 buckets.

Use an SNMP browser to view History samples.

## History MIB Objects

The type of data that can be sampled must be of an `ifIndex` object type, as described in RFC1213 and RFC1573. The most common data type for the history sample is as follows:

```
1.3.6.1.2.1.2.2.1.1.<x>  
-mgmt.interfaces.ifTable.ifIndex.interface
```

The last digit (*x*) represents the interface on which to monitor, which corresponds to the switch port number. History sampling is done per port, by utilizing the interface number to specify the port number.

## Configuring RMON History

This example configuration creates an RMON History Group to monitor port 23. It takes a data sample every two minutes, and places the data into one of the 30 requested buckets. After 30 samples are gathered, the new samples overwrite the previous samples, beginning with the first bucket.

1. Enable RMON on each port where you wish to collect RMON History.

```
>> # /cfg/port 23/rmon                (Select Port 23 RMON)  
>> Port 23# ena                       (Enable RMON)  
>> Port 23 RMON# apply                (Make your changes active)  
>> Port 23 RMON# save                 (Save for restore after reboot)
```

2. Configure the RMON History parameters.

```
>> # /cfg/rmon/hist 1                  (Select RMON History 1)  
>> RMON History 1# ifoid 1.3.6.1.2.1.2.2.1.1.23  
>> RMON History 1# rbnum 30  
>> RMON History 1# intrval 120  
>> RMON History 1# owner "Owner_History_1"
```

3. Apply and save the configuration.

>> RMON History 1# apply	<i>(Make your changes active)</i>
>> RMON History 1# save	<i>(Save for restore after reboot)</i>

Use SNMP to view the data.

---

## RMON Group 3—Alarms

The RMON Alarm Group allows you to define a set of thresholds used to determine network performance. When a configured threshold is crossed, an alarm is generated. For example, you can configure the switch to issue an alarm if more than 1,000 CRC errors occur during a 10-minute time interval.

Each Alarm index consists of a variable to monitor, a sampling time interval, and parameters for rising and falling thresholds. The Alarm group can be used to track rising or falling values for a MIB object. The object must be a counter, gauge, integer, or time interval.

Use the `/cfg/rmon/alarm <x>/revtidx` command or the `/cfg/rmon/alarm <x>/fevtidx` command to correlate an alarm index to an event index. When the alarm threshold is reached, the corresponding event is triggered.

### Alarm MIB Objects

The most common data types used for alarm monitoring are `ifStats`: errors, drops, bad CRCs, and so on. These MIB Object Identifiers (OIDs) correlate to the ones tracked by the History group. An example of an ICMP stat is as follows:

```
1.3.6.1.2.1.5.1.<x> - mgmt.icmp.icmpInMsgs
```

where *x* represents the interface on which to monitor, which corresponds to the switch interface number or port number, as follows:

- 1 through 128 = Switch interface number
- 129 = Switch port 1
- 130 = Switch port 2
- 131 = Switch port 3, and so on.

This value represents the alarm's MIB OID, as a string. Note that for non-tables, you must supply a `.0` to specify an end node.

## Configuring RMON Alarms

### Alarm Example 1

This example configuration creates an RMON alarm that checks `ifInOctets` on port 20 once every hour. If the statistic exceeds two billion, an alarm is generated that triggers event index 6.

1. Configure the RMON Alarm parameters to track the number of packets received on a port.

```
>> # /cfg/rmon/alarm 6                               (Select RMON Alarm 6)
>> RMON Alarm 6# oid 1.3.6.1.2.1.2.2.1.10.276
>> RMON Alarm 6# intrval 3600
>> RMON Alarm 6# almttype rising
>> RMON Alarm 6# rlimit 2000000000
>> RMON Alarm 6# revtidx 6
>> RMON Alarm 6# sample abs
>> RMON Alarm 6# owner "Alarm_for_ifInOctets"
```

2. Apply and save the configuration.

```
>> RMON Alarm 6# apply                               (Make your changes active)
>> RMON Alarm 6# save                                 (Save for restore after reboot)
```

### Alarm Example 2

This example configuration creates an RMON alarm that checks `icmpInEchos` on the switch once every minute. If the statistic exceeds 200 within a 60 second interval, an alarm is generated that triggers event index 5.

1. Configure the RMON Alarm parameters to track ICMP messages.

```
>> # /cfg/rmon/alarm 5                               (Select RMON Alarm 5)
>> RMON Alarm 5# oid 1.3.6.1.2.1.5.8.0
>> RMON Alarm 5# intrval 60
>> RMON Alarm 5# almttype rising
>> RMON Alarm 5# rlimit 200
>> RMON Alarm 5# revtidx 5
>> RMON Alarm 5# sample delta
>> RMON Alarm 5# owner "Alarm_for_icmpInEchos"
```

2. Apply and save the configuration.

```
>> RMON Alarm 5# apply                               (Make your changes active)
>> RMON Alarm 5# save                                 (Save for restore after reboot)
```

---

## RMON Group 9—Events

The RMON Event Group allows you to define events that are triggered by alarms. An event can be a log message, an SNMP trap message, or both.

When an alarm is generated, it triggers a corresponding event notification. Use the `/cfg/rmon/alarm <x>/revtidx` and `/cfg/rmon/alarm <x>/fevtidx` commands to correlate an event index to an alarm.

RMON events use SNMP and system logs to send notifications. Therefore, an SNMP trap host must be configured for trap event notification to work properly.

RMON uses a syslog host to send syslog messages. Therefore, an existing syslog host (`/cfg/sys/syslog`) must be configured for event log notification to work properly. Each log event generates a system log message of type RMON that corresponds to the event.

### Configuring RMON Events

This example configuration creates an RMON event that sends a SYSLOG message each time it is triggered by an alarm.

1. Configure the RMON Event parameters.

```
>> # /cfg/rmon/event 5                               (Select RMON Event 5)
>> RMON Event 5# descn "SYSLOG_generation_event"
>> RMON Event 5# type log
>> RMON Event 5# owner "Owner_event_5"
```

2. Apply and save the configuration.

```
>> RMON Alarm 5# apply                                (Make your changes active)
>> RMON Alarm 5# save                                  (Save for restore after reboot)
```



---

## Chapter 28. sFLOW

The GbESM supports sFlow technology for monitoring traffic in data networks. The switch includes an embedded sFlow agent which can be configured to sample network traffic and provide continuous monitoring information of IPv4 traffic to a central sFlow analyzer.

The switch is responsible only for forwarding sFlow information. A separate sFlow analyzer is required elsewhere on the network in order to interpret sFlow data.

**Note:** IBM Networking OS 7.4 does not support IPv6 for sFLOW.

---

## sFlow Statistical Counters

The GbESM can be configured to send network statistics to an sFlow analyzer at regular intervals. For each port, a polling interval of 5 to 60 seconds can be configured, or 0 (the default) to disable this feature.

When polling is enabled, at the end of each configured polling interval, the GbESM reports general port statistics (as found in the output of the `/stats/port <x>/if` command) and port Ethernet statistics (as found in the output of the `/stats/port <x>/ether` command).

---

## sFlow Network Sampling

In addition to statistical counters, the GbESM can be configured to collect periodic samples of the traffic data received on each port. For each sample, 128 bytes are copied, UDP-encapsulated, and sent to the configured sFlow analyzer.

For each port, the sFlow sampling rate can be configured to occur once each 256 to 65536 packets, or 0 to disable (the default). A sampling rate of 256 means that one sample will be taken for approximately every 256 packets received on the port. The sampling rate is statistical, however. It is possible to have slightly more or fewer samples sent to the analyzer for any specific group of packets (especially under low traffic conditions). The actual sample rate becomes most accurate over time, and under higher traffic flow.

sFlow sampling has the following restrictions:

- **Sample Rate**—The fastest sFlow sample rate is 1 out of every 256 packets.
- **ACLs**—sFlow sampling is performed before ACLs are processed. For ports configured both with sFlow sampling and one or more ACLs, sampling will occur regardless of the action of the ACL.
- **Port Mirroring**—sFlow sampling will not occur on mirrored traffic. If sFlow sampling is enabled on a port that is configured as a port monitor, the mirrored traffic will not be sampled.

**Note:** Although sFlow sampling is not generally a CPU-intensive operation, configuring fast sampling rates (such as once every 256 packets) on ports under heavy traffic loads can cause switch CPU utilization to reach maximum. Use larger rate values for ports that experience heavy traffic.

---

## sFlow Example Configuration

1. Specify the location of the sFlow analyzer (the server and optional port to which the sFlow information will be sent):

```
>> # /cfg/sys/sflow/saddress <IPv4 address>      (sFlow server address)
>> sFlow# sport <service port>                    (Set the optional service port)
>> sFlow# ena                                       (Enable sFlow features)
```

By default, the switch uses established sFlow service port 6343.

To disable sFlow features across all ports, use the `/cfg/sys/sflow/dis` command.

2. On a per-port basis, define the statistics polling rate:

```
>> sFlow# port <port number or alias>              (Select the port)
>> sFlow Port# polling <polling rate>               (Statistics polling rate)
```

Specify a polling rate between 5 and 60 seconds, or 0 to disable. By default, polling is 0 (disabled) for each port.

3. On a per-port basis, define the data sampling rate:

```
>> sFlow Port# sampling <sampling rate>            (Data sampling rate)
```

Specify a sampling rate between 256 and 65536 packets, or 0 to disable. By default, the sampling rate is 0 (disabled) for each port.

4. Apply and save the configuration.




## Chapter 29. Port Mirroring

The IBM Networking OS port mirroring feature allows you to mirror (copy) the packets of a target port, and forward them to a monitoring port. Port mirroring functions for all layer 2 and layer 3 traffic on a port. This feature can be used as a troubleshooting tool or to enhance the security of your network. For example, an IDS server or other traffic sniffer device or analyzer can be connected to the monitoring port in order to detect intruders attacking the network.

**Note:** You can also use ACLs and VMaps with the port mirroring feature to monitor packets that match a filter. See [“ACL Port Mirroring” on page 100](#).

The GbESM supports a “many to one” mirroring model. As shown in [Figure 48](#), selected traffic for ports EXT1 and EXT2 is being monitored by port EXT3. In the example, both ingress traffic and egress traffic on port EXT2 are copied and forwarded to the monitor. However, port EXT1 mirroring is configured so that only ingress traffic is copied and forwarded to the monitor. A device attached to port EXT3 can analyze the resulting mirrored traffic.

Figure 48. Mirroring Ports



The GbESM supports one monitor port. The monitor port can receive mirrored traffic from any number of target ports.

IBM N/OS does not support “one to many” or “many to many” mirroring models where traffic from a specific port traffic is copied to multiple monitor ports. For example, port EXT1 traffic cannot be monitored by both port EXT3 and EXT4 at the same time, nor can port EXT2 ingress traffic be monitored by a different port than its egress traffic.

Ingress and egress traffic is duplicated and sent to the monitor port after processing.

**Note:** The 1/10Gb Uplink ESM (GbESM) cannot mirror LACPDU packets. Also, traffic on management VLANs is not mirrored to the external ports.

---

## Port Mirroring Behavior

This section describes the composition of monitored packets in the GbESM, based on the configuration of the ports.

- Packets mirrored at port egress are mirrored prior to VLAN tag processing and may have a different PVID than packets that egress the port toward their actual network destination.
- Packets mirrored at port ingress are not modified.

### Configuring Port Mirroring

The following procedure may be used to configure port mirroring for the example shown in [Figure 48 on page 413](#):

1. Specify the monitor port.

```
>> # /cfg/pmirr/monport EXT3           (Select port EXT3 as the monitor)
```

2. Select the ports that you want to mirror.

```
>> Port EXT3 # add EXT1                 (Select port EXT1 to mirror)
>> Enter port mirror direction [in, out, or both]: in
                                           (Monitor ingress traffic at port EXT1)
>> Port EXT3 # add EXT2                 (Select port EXT2 to mirror)
>> Enter port mirror direction [in, out, or both]: both
                                           (Monitor ingress and egress traffic)
```

3. Enable port mirroring.

```
>> # /cfg/pmirr/mirr ena               (Enable port mirroring)
```

4. Apply and save the configuration.

```
>> PortMirroring# apply                (Apply the configuration)
>> PortMirroring# save                  (Save the configuration)
```

5. View the current configuration.

```
>> PortMirroring# cur                  (Display the current settings)
Port mirroring is enabled
Monitoring Ports    Mirrored Ports
INT1                none
INT2                none
INT3                none
INT4                none
...
EXT1                none
EXT2                none
EXT3                (EXT1, in) (EXT2, both)
EXT4                none
...
```

# Part 9: Appendices

This section describes the following topics:

- Glossary
- RADIUS Server Configuration Notes
- Getting help and technical assistance
- Notices





---

## Appendix A. Glossary

<b>CNA</b>	Converged Network Adapter. A device used for I/O consolidation such as that in Converged Enhanced Ethernet (CEE) environments implementing Fibre Channel over Ethernet (FCoE). The CNA performs the duties of both a Network Interface Card (NIC) for Local Area Networks (LANs) and a Host Bus Adapter (HBA) for Storage Area Networks (SANs).
<b>DIP</b>	The destination IP address of a frame.
<b>Dport</b>	The destination port (application socket: for example, http-80/https-443/DNS-53)
<b>HBA</b>	Host Bus Adapter. An adapter or card that interfaces with device drivers in the host operating system and the storage target in a Storage Area Network (SAN). It is equivalent to a Network Interface Controller (NIC) from a Local Area Network (LAN).
<b>NAT</b>	Network Address Translation. Any time an IP address is changed from one source IP or destination IP address to another address, network address translation can be said to have taken place. In general, half NAT is when the destination IP or source IP address is changed from one address to another. Full NAT is when both addresses are changed from one address to another. No NAT is when neither source nor destination IP addresses are translated.
<b>Preemption</b>	In VRRP, preemption will cause a Virtual Router that has a lower priority to go into backup should a peer Virtual Router start advertising with a higher priority.
<b>Priority</b>	In VRRP, the value given to a Virtual Router to determine its ranking with its peer(s). Minimum value is 1 and maximum value is 254. Default is 100. A higher number will win out for master designation.
<b>Proto (Protocol)</b>	The protocol of a frame. Can be any value represented by a 8-bit value in the IP header adherent to the IP specification (for example, TCP, UDP, OSPF, ICMP, and so on.)
<b>SIP</b>	The source IP address of a frame.
<b>SPort</b>	The source port (application socket: for example, HTTP-80/HTTPS-443/DNS-53).
<b>Tracking</b>	<p>In VRRP, a method to increase the priority of a virtual router and thus master designation (with preemption enabled). Tracking can be very valuable in an active/active configuration.</p> <p>You can track the following:</p> <ul style="list-style-type: none"><li>• Active IP interfaces on the Web switch (increments priority by 2 for each)</li><li>• Active ports on the same VLAN (increments priority by 2 for each)</li><li>• Number of virtual routers in master mode on the switch</li></ul>
<b>VIR</b>	Virtual Interface Router. A VRRP address is an IP interface address shared between two or more virtual routers.

<b>Virtual Router</b>	<p>A shared address between two devices utilizing VRRP, as defined in RFC 2338. One virtual router is associated with an IP interface. This is one of the IP interfaces that the switch is assigned. All IP interfaces on the GbESMs must be in a VLAN. If there is more than one VLAN defined on the Web switch, then the VRRP broadcasts will only be sent out on the VLAN of which the associated IP interface is a member.</p>
<b>VRID</b>	<p>Virtual Router Identifier. In VRRP, a numeric ID is used by each virtual router to create its MAC address and identify its peer for which it is sharing this VRRP address. The VRRP MAC address as defined in the RFC is 00-00-5E-00-01-<i>&lt;VRID&gt;</i>. For a virtual router with a VRID greater than 255, the following block of MAC addresses is allocated: 00:0F:6A:9A:40:00 through 00:0F:6A:9A:47:FF.</p> <p>If you have a VRRP address that two switches are sharing, then the VRID number needs to be identical on both switches so each virtual router on each switch knows with whom to share.</p>
<b>VRRP</b>	<p>Virtual Router Redundancy Protocol. A protocol that acts very similarly to Cisco's proprietary HSRP address sharing protocol. The reason for both of these protocols is so devices have a next hop or default gateway that is always available. Two or more devices sharing an IP interface are either advertising or listening for advertisements. These advertisements are sent via a broadcast message to an address such as 224.0.0.18.</p> <p>With VRRP, one switch is considered the master and the other the backup. The master is always advertising via the broadcasts. The backup switch is always listening for the broadcasts. Should the master stop advertising, the backup will take over ownership of the VRRP IP and MAC addresses as defined by the specification. The switch announces this change in ownership to the devices around it by way of a Gratuitous ARP, and advertisements. If the backup switch didn't do the Gratuitous ARP the Layer 2 devices attached to the switch would not know that the MAC address had moved in the network. For a more detailed description, refer to RFC 2338.</p>

---

## Appendix B. RADIUS Server Configuration Notes

Use the following information to modify your RADIUS configuration files for the Nortel Networks BaySecure Access Control RADIUS server, to provide authentication for users of the 1/10Gb Uplink ESM (GbESM).

1. Create a dictionary file called `blade.dct`, with the following content:

```
#####
# blade.dct - RADLINX BLADE dictionary
#
# (See README.DCT for more details on the format of this file)
#####
#
# Use the Radius specification attributes in lieu of the
# RADLINX BLADE ones
#
@radius.dct

#
# Define additional RADLINX BLADE parameters
# (add RADLINX BLADE specific attributes below)

ATTRIBUTE   Radlinx-Vendor-Specific  26  [vid=648 data=string]  R

#####
# blade.dct - RADLINX BLADE dictionary
#####

#Define 1/10Gb Uplink ESM dictionary
#@radius.dct

@blade.dct
    VALUE          Service-Type          user255
    VALUE          Service-Type          oper252
#####
```

2. Open the `dictionary.dcm` file, and add the following line (as in the example):  
`@blade.dct`

```
#####
# dictionary.dcm
#####
# Generic Radius

@radius.dct

#
# Specific Implementations (vendor specific)
#
@pprt1213.dct
@acc.dct
@accessbd.dct
@blade.dct
.
.
.
#####
# dictionary.dcm
#####
```

3. Open the vendor file (`vendor.ini`), and add the following data to the Vendor-Product identification list:

<code>vendor-product</code>	<code>= BLADE Blade-server module</code>
<code>dictionary</code>	<code>= blade</code>
<code>ignore-ports</code>	<code>= no</code>
<code>help-id</code>	<code>= 0</code>

---

## Appendix C. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about IBM products, you will find a wide variety of sources available from IBM to assist you. This section contains information about where to go for additional information about IBM and IBM products, what to do if you experience a problem with your system, and whom to call for service, if it is necessary.

---

### Before you call

Before you call, make sure that you have taken these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Use the troubleshooting information in your system documentation, and use the diagnostic tools that come with your system. Information about diagnostic tools is in the *Problem Determination and Service Guide* on the IBM Documentation CD that comes with your system.
- Go to the IBM support website at <http://www.ibm.com/systems/support/> to check for technical information, hints, tips, and new device drivers or to submit a request for information.

You can solve many problems without outside assistance by following the troubleshooting procedures that IBM provides in the online help or in the documentation that is provided with your IBM product. The documentation that comes with IBM systems also describes the diagnostic tests that you can perform. Most systems, operating systems, and programs come with documentation that contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

---

### Using the documentation

Information about your IBM system and pre-installed software, if any, or optional device is available in the documentation that comes with the product. That documentation can include printed documents, online documents, ReadMe files, and Help files. See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates. To access these pages, go to <http://www.ibm.com/systems/support/> and follow the instructions. Also, some documents are available through the IBM Publications Center at <http://www.ibm.com/shop/publications/order/>.

---

## Getting help and information on the World Wide Web

On the World Wide Web, the IBM website has up-to-date information about IBM systems, optional devices, services, and support. The address for IBM System x<sup>®</sup> and xSeries<sup>®</sup> information is <http://www.ibm.com/systems/x/>. The address for IBM BladeCenter information is <http://www.ibm.com/systems/bladecenter/>. The address for IBM IntelliStation<sup>®</sup> information is <http://www.ibm.com/intellistation/>.

You can find service information for IBM systems and optional devices at <http://www.ibm.com/systems/support/>.

---

## Software service and support

Through IBM Support Line, you can get telephone assistance, for a fee, with usage, configuration, and software problems with System x and x Series servers, BladeCenter products, IntelliStation workstations, and appliances. For information about which products are supported by Support Line in your country or region, see <http://www.ibm.com/services/sl/products/>.

For more information about Support Line and other IBM services, see <http://www.ibm.com/services/>, or see <http://www.ibm.com/planetwide/> for support telephone numbers. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

---

## Hardware service and support

You can receive hardware service through your IBM reseller or IBM Services. To locate a reseller authorized by IBM to provide warranty service, go to <http://www.ibm.com/partnerworld/> and click **Find Business Partners** on the right side of the page. For IBM support telephone numbers, see <http://www.ibm.com/planetwide/>. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

In the U.S. and Canada, hardware service and support is available 24 hours a day, 7 days a week. In the U.K., these services are available Monday through Friday, from 9 a.m. to 6 p.m.

---

## IBM Taiwan product service

台灣 IBM 產品服務聯絡方式：  
台灣國際商業機器股份有限公司  
台北市松仁路 7 號 3 樓  
電話：0800-016-888

IBM Taiwan product service contact information:

IBM Taiwan Corporation  
3F, No 7, Song Ren Rd.  
Taipei, Taiwan  
Telephone: 0800-016-888

---

## Appendix D. Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing  
IBM Corporation  
North Castle Drive  
Armonk, NY 10504-1785  
U.S.A.*

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product, and use of those websites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

---

## Trademarks

IBM, the IBM logo, and ibm.com are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. If these and other IBM trademarked terms are marked on their first occurrence in this information with a trademark symbol (® or ™), these symbols indicate U.S. registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common law trademarks in other countries. A current list of IBM trademarks is available on the web at "Copyright and trademark information" at <http://www.ibm.com/legal/copytrade.shtml>.

Adobe and PostScript are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Cell Broadband Engine is a trademark of Sony Computer Entertainment, Inc., in the United States, other countries, or both and is used under license therefrom.

Intel, Intel Xeon, Itanium, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Java and all Java-based trademarks are trademarks of Sun Microsystems, Inc., in the United States, other countries, or both.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Other company, product, or service names may be trademarks or service marks of others.

---

## Important Notes

Processor speed indicates the internal clock speed of the microprocessor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1024 bytes, MB stands for 1 048 576 bytes, and GB stands for 1 073 741 824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1 000 000 bytes, and GB stands for 1 000 000 000 bytes. Total user-accessible capacity can vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard disk drive bays with the largest currently supported drives that are available from IBM.

Maximum memory might require replacement of the standard memory with an optional memory module.

IBM makes no representation or warranties regarding non-IBM products and services that are ServerProven, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. These products are offered and warranted solely by third parties.

IBM makes no representations or warranties with respect to non-IBM products. Support (if any) for the non-IBM products is provided by the third party, not IBM.

Some software might differ from its retail version (if available) and might not include user manuals or all program functionality.



---

## Particulate contamination

**Attention:** Airborne particulates (including metal flakes or particles) and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the device that is described in this document. Risks that are posed by the presence of excessive particulate levels or concentrations of harmful gases include damage that might cause the device to malfunction or cease functioning altogether. This specification sets forth limits for particulates and gases that are intended to avoid such damage. The limits must not be viewed or used as definitive limits, because numerous other factors, such as temperature or moisture content of the air, can influence the impact of particulates or environmental corrosives and gaseous contaminant transfer. In the absence of specific limits that are set forth in this document, you must implement practices that maintain particulate and gas levels that are consistent with the protection of human health and safety. If IBM determines that the levels of particulates or gases in your environment have caused damage to the device, IBM may condition provision of repair or replacement of devices or parts on implementation of appropriate remedial measures to mitigate such environmental contamination. Implementation of such remedial measures is a customer responsibility.

Contaminant	Limits
Particulate	<ul style="list-style-type: none"><li>• The room air must be continuously filtered with 40% atmospheric dust spot efficiency (MERV 9) according to ASHRAE Standard 52.2<sup>1</sup>.</li><li>• Air that enters a data center must be filtered to 99.97% efficiency or greater, using high-efficiency particulate air (HEPA) filters that meet MIL-STD-282.</li><li>• The deliquescent relative humidity of the particulate contamination must be more than 60%<sup>2</sup>.</li><li>• The room must be free of conductive contamination such as zinc whiskers.</li></ul>
Gaseous	<ul style="list-style-type: none"><li>• Copper: Class G1 as per ANSI/ISA 71.04-1985<sup>3</sup></li><li>• Silver: Corrosion rate of less than 300 Å in 30 days</li></ul>

<sup>1</sup> ASHRAE 52.2-2008 - *Method of Testing General Ventilation Air-Cleaning Devices for Removal Efficiency by Particle Size*. Atlanta: American Society of Heating, Refrigerating and Air-Conditioning Engineers, Inc.

<sup>2</sup> The deliquescent relative humidity of particulate contamination is the relative humidity at which the dust absorbs enough water to become wet and promote ionic conduction.

<sup>3</sup> ANSI/ISA-71.04-1985. *Environmental conditions for process measurement and control systems: Airborne contaminants*. Instrument Society of America, Research Triangle Park, North Carolina, U.S.A.

---

## Documentation format

The publications for this product are in Adobe Portable Document Format (PDF) and should be compliant with accessibility standards. If you experience difficulties when you use the PDF files and want to request a web-based format or accessible PDF document for a publication, direct your mail to the following address:

Information Development  
IBM Corporation  
205/A0153039 E. Cornwallis Road  
P.O. Box 12195  
Research Triangle Park, North Carolina 27709-2195  
U.S.A.

In the request, be sure to include the publication part number and title.

When you send information to IBM, you grant IBM a non-exclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

---

## Electronic emission notices

### Federal Communications Commission (FCC) statement

**Note:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Industry Canada Class A emission compliance statement

This Class A digital apparatus complies with Canadian ICES-003.

### Avis de conformité à la réglementation d'Industrie Canada

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

### Australia and New Zealand Class A statement

**Attention:** This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

## European Union EMC Directive conformance statement

This product is in conformity with the protection requirements of EU Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a nonrecommended modification of the product, including the fitting of non-IBM option cards.

**Attention:** This is an EN 55022 Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Responsible manufacturer:

International Business Machines Corp.  
New Orchard Road  
Armonk, New York 10504  
914-499-1900

European Community contact:

IBM Technical Regulations, Department M456  
IBM-Allee 1, 71137 Ehningen, Germany  
Telephone: +49 7032 15-2937  
E-mail: tjahn@de.ibm.com

## Germany Class A statement

**Deutschsprachiger EU Hinweis:**

### **Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit**

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2004/108/EG zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022 Klasse A ein.

Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung der IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung der IBM gesteckt/eingebaut werden.

EN 55022 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden: "Warnung: Dieses ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funk-Störungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen zu ergreifen und dafür aufzukommen."

### **Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten**

Dieses Produkt entspricht dem "Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG)". Dies ist die Umsetzung der EU-Richtlinie 2004/108/EG in der Bundesrepublik Deutschland.

**Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) (bzw. der EMC EG Richtlinie 2004/108/EG) für Geräte der Klasse A**

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Einhaltung der EMV Vorschriften ist der Hersteller:

International Business Machines Corp.  
New Orchard Road  
Armonk, New York 10504  
914-499-1900

Der verantwortliche Ansprechpartner des Herstellers in der EU ist:

IBM Deutschland  
Technical Regulations, Department M456  
IBM-Allee 1, 71137 Ehningen, Germany  
Telephone: +49 7032 15-2937  
E-mail: tjahn@de.ibm.com

**Generelle Informationen:**

**Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 Klasse A.**

## Japan VCCI Class A statement

この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用する  
と電波妨害を引き起こすことがあります。この場合には使用者が適切な対策  
を講ずるよう要求されることがあります。 VCCI-A

This is a Class A product based on the standard of the Voluntary Control Council for Interference (VCCI). If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.

## Korea Communications Commission (KCC) statement

이 기기는 업무용으로 전자파 적합등록을 받은 기기  
이오니, 판매자 또는 사용자는 이점을 주의하시기  
바라며, 만약 잘못 구입하셨을 때에는 구입한 곳에  
서 비업무용으로 교환하시기 바랍니다.

Please note that this equipment has obtained EMC registration for commercial use. In the event that it has been mistakenly sold or purchased, please exchange it for equipment certified for home use.

## Russia Electromagnetic Interference (EMI) Class A statement

ВНИМАНИЕ! Настоящее изделие относится к классу А.  
В жилых помещениях оно может создавать радиопомехи, для  
снижения которых необходимы дополнительные меры

## People's Republic of China Class A electronic emission statement

中华人民共和国“A类”警告声明

声 明

此为A级产品，在生活环境中，该产品可能会造成无线电干扰。在这种情况下，可能需要用户对其干扰采取切实可行的措施。

## Taiwan Class A compliance statement

警告使用者：  
這是甲類的資訊產品，在  
居住的環境中使用時，可  
能會造成射頻干擾，在這  
種情況下，使用者會被要  
求採取某些適當的對策。



---

# Index

## Symbols

[ ] 20

## Numerics

802.1Q VLAN tagging 111

## A

Access Control Lists. *See* ACLs.  
access switch (AMP) 339  
accessible documentation 426  
accessing the switch  
    Browser-based Interface 27, 32  
    LDAP authentication 83  
    RADIUS authentication 74  
    security 73  
ACLs 93, 159  
active-active redundancy 356  
administrator account 41, 43, 76  
aggregating routes 298  
    example 303  
aggregator switch (AMP) 339  
AH 238  
anycast address, IPv6 228  
application ports 95  
assistance, getting 415, 421  
authenticating, in OSPF 316  
Authentication Header (AH) 238  
autoconfiguration  
    link 48  
autoconfiguration, IPv6 229  
auto-negotiation  
    setup 48  
autonomous systems (AS) 309

## B

BBI 26  
BBI. *See* Browser-Based Interface  
Border Gateway Protocol (BGP) 291  
    attributes 299  
    failover configuration 301  
    route aggregation 298  
    route maps 294  
    selecting route paths 300  
Bridge Protocol Data Unit (BPDU) 140  
broadcast domains 107, 219  
Browser-Based Interface 26, 310

## C

Cisco EtherChannel 129  
CIST 152  
Class A electronic emission notice 426

Class of Service queueCOS queue 167  
command conventions 20  
Command Line Interface 310  
Command-Line Interface (CLI) 43  
Community VLAN 122  
configuration rules  
    port mirroring 129  
    spanning tree 129  
    Trunking 129  
    VLANs 129  
configuring  
    BGP failover 301  
    IP routing 218  
    OSPF 319  
    port trunking 130  
    spanning tree groups 148, 154  
contamination, particulate and gaseous 425

## D

date  
    setup 46  
default gateway 217  
    configuration example 219  
default password 41, 76  
default route, OSPF 314  
Differentiated Services Code Point (DSCP)DSCP 161  
digital certificate 240  
    generating 241  
    importing 241  
documentation format 426

## E

EAPoL 86  
electronic emission Class A notice 426  
Encapsulating Security Payload (ESP) 238  
End user access control, configuring 70  
ESP 238  
EtherChannel 126  
    as used with port trunking 129  
Extensible Authentication Protocol over LAN 86  
external routing 292, 309

## F

factory default configuration 42, 43, 45  
failover 343  
    overview 355  
FCC Class A notice 426  
Final Steps 55  
first-time configuration 42, 43 to 63  
flow control  
    setup 48  
frame size 108  
frame tagging. *See* VLANs tagging.

## G

gaseous contamination 425  
gateway. *See* default gateway.  
getting help 421

## H

hardware service and support 422  
help, getting 421  
high-availability 351  
host routes, OSPF 317  
Hot Links 337  
hot-standby redundancy 356  
HP-OpenView 37, 383

## I

IBM DirectorSNMP  
    IBM Director 37, 383  
IBM support line 422  
ICMP 94  
IEEE standards  
    802.1D 138  
    802.1s 152  
    802.1x 86  
IGMP 94, 253  
    Querier 287  
IGMP Relay 269  
IGMPv3 257  
IKEv2 238  
    digital certificate 240, 241  
    preshared key 240, 242  
IKEv2 proposal 240  
incoming route maps 295  
internal routing 292, 309  
Internet Group Management Protocol (IGMP) 253  
Internet Key Exchange Version 2 (IKEv2) 238  
Internet Protocol Security  
    *See also* IPsec 237  
Inter-Switch Link, ISL 127  
IP address 51  
    IP interface 51  
IP address routing example 218  
IP configuration via setup 51  
IP interfaces 51  
IP interfaces, example configuration 218, 220  
IP routing 51  
    cross-subnet example 216  
    default gateway configuration 219  
    IP interface configuration 218, 220  
    subnet configuration example 218  
    switch-based topology 217  
IP subnet mask 51  
IP subnets 217  
    routing 217  
    VLANs 107  
IPSec  
    maximum traffic load 239

IPsec 237  
    key policy 242  
IPv6 addressing 225, 227  
ISL Trunking 126  
Isolated VLAN 122

## J

jumbo frames 108

## L

LACP 132  
Layer 2 Failover 343  
LDAP authentication 83  
Link Aggregation Control Protocol 132  
logical segment. *See* IP subnets.  
LSAs 308

## M

management module 26, 28  
manual style conventions 20  
Maximum Transmission Unit 108  
meter 99, 160  
mirroring ports 413  
monitoring ports 413  
MSTP 152  
MTU 108  
multi-links between switches using port trunking 125  
multiple spanning tree groups 144  
Multiple Spanning Tree Protocol 152

## N

Neighbor Discovery, IPv6 230  
network management 26, 37, 383  
notes, important 424  
notices 423  
notices, electronic emission 426  
notices, FCC Class A 426



## O

### OSPF

- area types 306
  - authentication 316
  - configuration examples 320 to 331
  - default route 314
  - external routes 318
  - filtering criteria 94
  - host routes 317
  - link state database 308
  - neighbors 308
  - overview 306
  - redistributing routes 294, 298
  - route maps 294, 295
  - route summarization 313
  - router ID 315
  - virtual link 315
- outgoing route maps 295

## P

- packet size 108
- particulate contamination 425
- password
- administrator account 41, 76
  - default 41, 76
  - user account 41, 76
- passwords 41
- payload size 108
- Per Hop Behavior (PHB)PHB 162
- port flow control. *See* flow control.
- port mirroring 413
- configuration rules 129
- port trunking
- configuration example 130
  - EtherChannel 126
- ports
- configuration 48
  - for services 95
  - monitoring 413
  - physical. *See* switch ports.
- presared key 240
- enabling 242
- priority value (802.1p) 166
- Private VLANs 122
- promiscuous port 122
- protocol types 94
- PVID (port VLAN ID) 110
- PVLAN 118

## Q

- Querier (IGMP) 287

## R

### RADIUS

- authentication 74
  - port 1812 and 1645 95
  - port 1813 95
  - SSH/SCP 68
- Rapid Spanning Tree Protocol (RSTP) 150
- receive flow control 48
- redistributing routes 294, 298, 303
- redundancy
- active-active 356
  - hot-standby 356
- re-mark 99, 160
- restarting switch setup 45
- RIP (Routing Information Protocol)
- advertisements 249
  - distance vector protocol 248
  - hop count 248
  - TCP/IP route information 18, 247
  - version 1 248
- route aggregation 298, 303
- route maps 294
- configuring 295
  - incoming and outgoing 295
- route paths in BGP 300
- Router ID, OSPF 315
- routers 216, 219
- border 309
  - peer 309
  - port trunking 126
  - switch-based routing topology 217
- routes, advertising 309
- routing 292
- internal and external 309
- Routing Information Protocol. *See* RIP
- RSA keys 68
- RSTP 150
- rx flow control 48

## S

- SA 238
- SecurID 68
- security
- LDAP authentication 83
  - port mirroring 413
  - RADIUS authentication 74
  - VLANs 107
- security association (SA) 238
- segmentation. *See* IP subnets.
- segments. *See* IP subnets.
- service and support 422
- service ports 95

- setup facility 42, 43
  - IP configuration 51
  - IP subnet mask 51
  - port auto-negotiation mode 48
  - port configuration 48
  - port flow control 48
  - restarting 45
  - Spanning-Tree Protocol 47
  - starting 45
  - stopping 45
  - system date 46
  - system time 46
  - VLAN name 50
  - VLAN tagging 49
  - VLANs 50
- SNMP 26, 37, 310, 383
  - HP-OpenView 37, 383
- SNMP Agent 383
- software service and support 422
- Source-Specific MulticastSSM 257
- Spanning Tree Protocol
  - configuration rules 129
- Spanning-Tree Protocol
  - multiple instances 144
  - setup (on/off) 47
- SSH/SCP
  - configuring 64
  - RSA host and server keys 68
- stacking 172, 342
- starting switch setup 45
- stopping switch setup 45
- subnet mask 51
- subnets 51
- summarizing routes 313
- support line 422
- support web site 422
- switch failover 355
- switch ports VLANs membership 110

## T

- TACACS+ 77
- tagging. *See* VLANs tagging.
- TCP 94
- technical assistance 421
- technical terms
  - port VLAN identifier (PVID) 111
  - tagged frame 111
  - tagged member 111
  - untagged frame 111
  - untagged member 111
  - VLAN identifier (VID) 111
- telephone assistance 422
- telephone numbers 422
- Telnet support
  - optional setup for Telnet support 56
- text conventions 20

- time
  - setup 46
- trademarks 423
- transmit flow control 48
- Trunking configuration rules 129
- tx flow control 48
- typographic conventions 20

## U

- UDP 94
- user account 41, 76

## V

- vDS. *See* virtual Distributed Switch
- virtual Distributed Switch 199
- virtual interface router (VIR) 352
- virtual link, OSPF 315
- Virtual Local Area Networks. *See* VLANs.
- virtual router group 357
- virtual router ID numbering 359
- VLAN tagging
  - setup 49
- VLANs 51
  - broadcast domains 107, 219
  - configuration rules 129
  - default PVID 110
  - example showing multiple VLANs 116
  - ID numbers 109
  - interface 52
  - IP interface configuration 220
  - multiple spanning trees 139
  - multiple VLANs 111
  - name setup 50
  - port members 110
  - PVID 110
  - routing 219
  - security 107
  - setup 50
  - Spanning-Tree Protocol 139
  - tagging 49, 110 to 117
  - topologies 115
- VRRP (Virtual Router Redundancy Protocol)
  - active-active redundancy 356
  - hot-standby redundancy 356
  - overview 352
  - virtual interface router 352
  - virtual router ID numbering 359
  - vrid 352

## W

- website, publication ordering 421
- website, support 422
- website, telephone support numbers 422