

LPARDesign Extended

USER'S GUIDE


Version V01-T01



Doc : LPARDesign-Extended-V01-T01_UserGuide.docx
© 2020 Thierry Deleris - Alain Maneville
Updated: May 13th, 2020

Alain Maneville
Executive I/T Specialist, zChampion
z Client Architect
IBM France

Table Of Content

1. PURPOSE OF THE DOCUMENT.....	2
2. DISCLAIMER OF WARRANTIES:.....	2
3. HOW TO GET THE PRODUCT – IMPORTANT NOTICE:.....	3
3.1 FROM THE IBM WLM WEB SITE (WORK IN PROGRESS)	3
3.2 FROM GITHUB	3
4. CHANGES IN THIS RELEASE.....	4
4.1 WHAT’S NEW IN V01T01.....	4
4.1.1 Support for LPARDesign V11-T01.....	4
4.1.2 Support for zPCR 9.4	4
5. THE NAVIGATION AND ACTION BAR.	5
5.1 BAR FUNCTIONS.....	5
6. LPARDESIGN EXTENDED WORKFLOW – CREATING A STUDY AND LOADING FILES.....	6
6.1 STEP-1: CREATE A NEW STUDY (INITIAL USAGE).....	6
6.2 STEP-2: LOAD LPARDESIGN CONFIGURATION FILES	6
6.3 STEP-3: REFINE LPARDESIGN CONFIGURATION FILES WITH FURTHER INFORMATION FOR ZPCR.	7
6.4 SETTING THE LPARDESIGN EXTEND STUDY ID	8
7. LPARDESIGN EXTENDED WORKFLOW – COMPARING CONFIGURATIONS.....	9
7.1 IMPORTANT NOTES ON THE COMPARISON PROCESS:	9
7.2 STEP-1: REVIEWING THE LOADED CONFIGURATIONS.....	9
7.3 STEP-2: COMPARING CONFIGURATIONS – ENHANCED DASHBOARD	9
7.4 STEP-3 – COMPARE THE CONFIGURATIONS BY LPAR NAMES AND PU TYPES (GCP, zIIP, IFL, ICF)	10
7.5 STEP-4 – THE SORT RULES.....	10
8. OTHER FEATURES.	12
8.1 SIMPLE DASHBOARD.	12
8.2 zPCR STUDY GENERATION	12
8.2.1 zPCR study generation workflow.	12
8.3 THE DATA BUTTON - 	12
8.4 HOUSEKEEPING	13



1. PURPOSE OF THE DOCUMENT.

This document explains how to use the LPARDesign Extended Tool.

This tool helps in comparing various LPAR configurations that have been created by the LPARDesign Tool. It provides visual comparisons and can create a zPCR study including these various LPAR configurations.

2. DISCLAIMER OF WARRANTIES:

The following [enclosed] macro is sample code created by Thierry Deleris (BPCE-IT) and Alain Maneville (IBM France).

This sample macro is not part of any standard IBM product and is provided to you solely for assisting you in the PR/SM LPAR® and HiperDispatch® Configuration.

The code is provided "AS IS", without warranty of any kind. Thierry Deleris and Alain Maneville shall not be liable for any damages arising out of your use of such sample code, even if you have been advised of the possibility of such damage

Support: Support will be provided on a "best effort" basis. Send the spreadsheet for an analysis to thierry.deleris@bpce-it.fr, and/or to alain_maneville@fr.ibm.com




3. HOW TO GET THE PRODUCT – IMPORTANT NOTICE:

3.1 From the IBM WLM WEB Site (work in progress)

<https://www.ibm.com/it-infrastructure/z/zos-workload-management>

Go down to this section (skip the Featured products and More products sections)



The screenshot shows a sidebar with 'Popular links' including FAQs, Guides, Redbooks, 'Tools for WLM' (highlighted), and 'Tools for RMF'. The main content area is divided into three sections: 'WLMQUE tool', 'LPAR design tool', and 'Reporting tools'. Each section contains a brief description and a download link. The 'LPAR design tool' link is highlighted with a mouse cursor.

Tool Name	Description	Download Link	File Size
WLMQUE tool	The WLM Work Queue Viewer (WLMQUE) is a small ISPF-based tool to assist in displaying the application environments that are currently being used on your z/OS system.	Download WLMQUE tool (ZIP, 381 KB)	381 KB
LPAR design tool	The LPAR design tool assists you in planning the LPAR layout of your Central Processor Complexes.	Download LPAR design tool (ZIP, 2.2 MB)	2.2 MB
Reporting tools	The topology report displays logical processor topology and the SMF 113 reporting tool provides insight into usage of cache structures.	Download topology report (EXE, 1.13 KB) Download SMF 113 reporting (EXE, 6.2 MB)	1.13 KB / 6.2 MB

[Download LPAR design tool \(ZIP, 2.2 MB\)](#)

And click on

3.2 From Github

Due to a change in IBM's way of managing WEB sites, the product is now available on the GitHub Web site at the URL:

<https://github.com/AlainManeville/z-OS-LPARDesign>

You will get this page :

AlainManeville Add files via upload		Latest commit c0118b4 13 minutes ago
LPARDesign-Extended-V01-T01.xlsm	Add files via upload	13 minutes ago
LPARDesign-Extended-V01-T01_UserGuide.pdf	Add files via upload	13 minutes ago
LPARDesign-HD-zPCR-V11-T01_IBM.xls	Add files via upload	15 minutes ago
LPARDesign-HD-zPCR-V11-T01_UserGuide.pdf	Add files via upload	15 minutes ago
README.md	Update README.md	18 minutes ago

Then, Click on the LPAR Design Hyperlink for the spreadsheet **AND** the User's Guide to download them.



4. CHANGES IN THIS RELEASE.

4.1 What's new in V01T01

The V01-T01 is the first version of the product.

4.1.1 Support for LPARDesign V11-T01

The configuration .xml files created by LPARDesign V11-T01 are supported in this tool.

4.1.2 Support for zPCR 9.4


zPCR 9.4 is supported in this release




5. THE NAVIGATION AND ACTION BAR.

To make things simpler and easier, a navigation and action BAR is provided.
It is available when you open the spreadsheet and stays until you close it.
You can move it anywhere in the worksheets (you will do that when first opening the product).

5.1 BAR Functions.




Sliding the mouse pointer to one of the icons shows its function:



6. LPARDesign Extended Workflow – Creating a Study and loading files.


6.1 STEP-1: Create a New Study (initial usage)



This will create a fresh LPARDesign Extended Study.


Now you must LOAD LPARDesign configuration files (.xml Files) to further compare them.

6.2 STEP-2: LOAD LPARDesign Configuration Files



6.3 STEP-3: Refine LPARDesign Configuration Files with further information for zPCR.


For example, you might need to specify what is the **Maxnnn** value for this z15-T01 machine. **This is for zPCR configuration to be accurate.**



At that time you have Loaded this LPARDesign xml file, you will receive a confirmation PopUp and you can see you loaded configuration in the main worksheet:

LparDesign Configuration(s) list																		
<div><div>Id</div><div></div></div>	<div><div>Name</div><div></div></div>	<div><div>Customer</div><div></div></div>	<div><div>Machine Type</div><div></div></div>	<div><div>GCP Count</div><div></div></div>	<div><div>IIP Count</div><div></div></div>	<div><div>IFL Count</div><div></div></div>	<div><div>ICF Count</div><div></div></div>	<div><div>Hardware Model</div><div></div></div>	<div><div>z/OS Version for each LPAR</div><div></div></div>	<div><div>Workload Type for each z/OS LPAR</div><div></div></div>	<div><div>zIIP Loading %</div><div></div></div>	<div><div>zIIP SMT Enabled ?</div><div></div></div>	<div><div>zIIP SMT benefit %</div><div></div></div>	<div><div>IFL SMT Enabled ?</div><div></div></div>	<div><div>IFL SMT benefit %</div><div></div></div>	<div><div>VM Version for each VM LPAR</div><div></div></div>	<div><div>VM Workload for each VM LPAR</div><div></div></div>	<div><div>Origin XML File</div><div></div></div>
M1	Machine#1 z15	IBM Corp	8561-718	18	18	18	18	Max108	z/OS-2.3	User Defined	100%	Yes	25%	Yes	25%	z/VM-7.1	Average	LPARDesign-HD-zPCR-V11-T01_IBM v3r9e.xml

The Id and the Name are those that you have set in :



You will do that for every LPARDesign configuration .xml file that you want to further compare



6.4 Setting the LPARDesign Extend Study Id

At any time, you can set or change the “name” of the study:

LPARDesign Extended - Study Id :



7.4 STEP-3 – Compare the configurations by LPAR Names and PU Types (GCP, zIIP, IFL, ICF)

In this example, we compare the Dashboards from the M1 and M2 configurations for the GCP PU.

LPARDesign Extended V01-T01 - Configurations Dashboard for Processors comparison

Legend :

LP High

x%

LP Medium or SHR with x% of Share

LP Low

x%

LP Low Always Unparked with a Share of x%

LP DED

Sort Rules

LPAR Name

Join

1

Ascending

Guarant #PP

2

Descending

M1

GCP

Configuration Id 'M1' - 8561-718 with 18 GCP Processors

LPAR Name	% Share	Guarant #PP	LP01	LP02	LP03	LP04	LP05	LP06	LP07	LP08	LP09	LP10
W013	8.9%	1.42	71.0%	71.0%								
W014	15.1%	2.42		71.0%	71.0%							
W015	12.3%	1.96			96.0%							
W017	18.9%	3.02					51.0%		51.0%			
W018	3.8%	0.60		30.0%	30.0%							
W019	18.8%	3.00										
W020	18.8%	3.00					100%					
W021	3.6%	0.58		25.0%	25.0%							

M2

GCP

Configuration Id 'M2' - 8561-718 with 18 GCP Processors

LPAR Name	% Share	Guarant #PP	LP01	LP02	LP03	LP04	LP05	LP06	LP07	LP08	LP09	LP10
W013	8.9%	1.42	71.0%	71.0%								
W014	15.6%	2.50								50.0%		
W015	12.3%	1.96			96.0%							
W017	18.9%	3.02					51.0%		51.0%			
W018	3.8%	0.60		30.0%	30.0%							
W019	18.8%	3.00										
W020	18.8%	3.00					100%					
W021	3.1%	0.50		25.0%	25.0%							

We can easily determine that the W014 LPAR has one more VH in configuration M2:

LPARDesign Extended V01-T01 - Configurations Dashboard for Processors comparison																													
<div><div><div>Legend :</div><div><div><div></div>LP High</div><div><div>x%</div>LP Medium or SHR with x% of Share</div><div><div></div>LP Low</div><div><div>x%</div>LP Low Always Unparked with a Share of x%</div><div><div></div>LP DED</div></div></div><div><div>Sort Rules</div><div><div>LPAR Name</div><div>Join</div><div>1</div><div>Ascending</div><div>2</div><div>Descending</div></div><div><div>Guarant #PP</div><div>1</div><div>Descending</div></div></div></div>																													
<div><div>M1</div><div>GCP</div><div>Configuration Id 'M1' - 8561-718 with 18 GCP Processors</div></div>														<div><div>M2</div><div>GCP</div><div>Configuration Id 'M2' - 8561-718 with 18 GCP Processors</div></div>															
LPAR Name			%	Guarant #PP	LP01	LP02	LP03	LP04	LP05	LP06	LP07	LP08	LP09	LP10	LPAR Name			%	Guarant #PP	LP01	LP02	LP03	LP04	LP05	LP06	LP07	LP08	LP09	LP10
W014			15.1%	2.42		71.0%	71.0%								W014			15.6%	2.50			50.0%							

Others PU types can be compared too – Just scroll the PU Type button list:



in each configurations.

Note: To better analyze the configurations, scroll to have the LPAR name you want to check just below the column titles.

7.5 STEP-4 – The Sort Rules.

In the **Enhanced Dashboard** you could use the **Sort Rules Box** for your study:

</

In details here is the box :

Sort Rules

LPAR Name

Join

1

Ascending

Guarant #PP

2

Descending



The sort rules are divided between **LPAR Name** and **Guaranteed number of Physical Processor** (« **Guarant #PP** ») keys.

- In the **LPAR Name** part of the Box, the first button is the **Join/No Join** button
 - o When **Join** is selected this lets you build a Dashboard where the lines of the two configurations are joined on the LPAR Name.

- In this case the **LPAR Name** will necessary be the first order Key and the **Guarant #PP** the second Key

- o When **No Join** is selected there is no join on the **LPAR Name** between the lines of the two configurations selected in the Dashboard.

- In this case you could select the Key order of your choice.

- For each of these keys you could build the sort order by selecting the first and the second key by clicking on the corresponding button to switch

- o Example :

In this case the sort order is first (« **1** ») **LPAR Name** and second (« **2** ») **Guarant #PP** without any join on the LPAR Name.

- o Example :

From the previous box clicking on the the « **1** » button in the **LPAR Name** key part will switch it to « **2** » and so the **Gurant #PP** key will switch to « **1** ».

In this case the sort order is first (« **1** ») **Guarant #PP** and second (« **2** ») **LPAR Name**

- For each of these keys you could too select the sort order between **Ascending** and **Descending** thanks to the corresponding button.

- o In the last example :

You could see that the **LPAR Name** will be sorted in **Ascending** order and the **Guarant #PP** will be sorted in **Descending** order



8. Other Features.

8.1 Simple Dashboard.




When you hit **Simple** you will have a unique Dashboard display as you have in LPARDesign. This is done to figure out a single configuration.

8.2 zPCR study generation

In this Tool, you can have multiple configurations.

So you can generate a zPCR study including those configurations (with the limitation of zPCR)

8.2.1 zPCR study generation workflow.



8.3 The DATA button -



This will show you the raw values of the configurations you have loaded in the study.




ConfigId	ConfigName	ConfigCustom	ConfigMachine	CType	TotCP	LparName	Weight	LCP	SharedPct	Guarantee	Workload	HDhigh	HDmedium	HDmedium	HDlow	HDActive
M1	Machine#1 z15	IBM Corp	8561-718	GCP	18	W013	142	2	8.9%	1.42	High	0	2	71.0%	0	2
M1	Machine#1 z15	IBM Corp	8561-718	GCP	18	W014	242	3	15.1%	2.42	Avg-High	1	2	71.0%	0	3
M1	Machine#1 z15	IBM Corp	8561-718	GCP	18	W015	196	3	12.3%	1.96	High	1	1	96.0%	1	2
M1	Machine#1 z15	IBM Corp	8561-718	GCP	18	W017	302	4	18.9%	3.02	Avg-High	2	2	51.0%	0	4
M1	Machine#1 z15	IBM Corp	8561-718	GCP	18	W018	60	2	3.8%	0.6	Average	0	1	60.0%	1	2
M1	Machine#1 z15	IBM Corp	8561-718	GCP	18	W019	300	3	18.8%	3	High	3	0	0.0%	0	3
M1	Machine#1 z15	IBM Corp	8561-718	GCP	18	W020	300	5	18.8%	3	Average	2	1	100.0%	2	3
M1	Machine#1 z15	IBM Corp	8561-718	GCP	18	W021	58	2	3.6%	0.58	Avg-High	0	1	58.0%	1	2
M1	Machine#1 z15	IBM Corp	8561-718	GCP	18	W022	DED	2	100.0%	2	Average	2	0	0.0%	0	2
M1	Machine#1 z15	IBM Corp	8561-718	IIP	18	W013	142	2	8.9%	1.42	-	0	2	71.0%	0	2
M1	Machine#1 z15	IBM Corp	8561-718	IIP	18	W014	242	3	15.1%	2.42	-	1	2	71.0%	0	3
M1	Machine#1 z15	IBM Corp	8561-718	IIP	18	W015	196	3	12.3%	1.96	-	1	1	96.0%	1	2
M1	Machine#1 z15	IBM Corp	8561-718	IIP	18	W017	302	4	18.9%	3.02	-	2	2	51.0%	0	4
M1	Machine#1 z15	IBM Corp	8561-718	IIP	18	W018	60	2	3.8%	0.6	-	0	1	60.0%	1	2
M1	Machine#1 z15	IBM Corp	8561-718	IIP	18	W019	300	3	18.8%	3	-	3	0	0.0%	0	3
M1	Machine#1 z15	IBM Corp	8561-718	IIP	18	W020	300	5	18.8%	3	-	2	1	100.0%	2	3
M1	Machine#1 z15	IBM Corp	8561-718	IIP	18	W021	58	2	3.6%	0.58	-	0	1	58.0%	1	2
M1	Machine#1 z15	IBM Corp	8561-718	IIP	18	W022	DED	2	100.0%	2	-	2	0	0.0%	0	2
M1	Machine#1 z15	IBM Corp	8561-718	IFL	18	ZVM1	142	2	8.9%	1.42	-	0	2	71.0%	0	2
M1	Machine#1 z15	IBM Corp	8561-718	IFL	18	ZVM2	242	3	15.1%	2.42	-	1	2	71.0%	0	3
M1	Machine#1 z15	IBM Corp	8561-718	IFL	18	ZVM1	196	3	12.3%	1.96	-	1	1	96.0%	1	2
M1	Machine#1 z15	IBM Corp	8561-718	IFL	18	ZVM3	302	4	18.9%	3.02	-	2	2	51.0%	0	4
M1	Machine#1 z15	IBM Corp	8561-718	IFL	18	ZVM6	60	2	3.8%	0.6	-	0	1	60.0%	1	2
M1	Machine#1 z15	IBM Corp	8561-718	IFL	18	ZVM3	300	3	18.8%	3	-	3	0	0.0%	0	3
M1	Machine#1 z15	IBM Corp	8561-718	IFL	18	ZVM3	300	5	18.8%	3	-	2	1	100.0%	2	3
M1	Machine#1 z15	IBM Corp	8561-718	IFL	18	ZVM5	58	2	3.6%	0.58	-	0	1	58.0%	1	2
M1	Machine#1 z15	IBM Corp	8561-718	IFL	18	ZVM0	DED	2	100.0%	2	-	2	0	0.0%	0	2
M1	Machine#1 z15	IBM Corp	8561-718	ICF	18	ICF1	200	2	50.0%	2	-	0	2	100.0%	0	2


8.4 Housekeeping

There are various buttons that helps you:

- Create (new)
- Restore (Load)
- Save
- Add (.xml Configuration)
- Delete (.xml Configuration)

to keep you study useful.





END OF DOCUMENT - Lpardesign-Extended-V01-T01 Userguide.Docx

